
Valid as of version (Device firmware)

Operating Instructions **Proline Promass O 300**

Coriolis flowmeter FOUNDATION Fieldbus







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document	6	6	Installation	21
1.1	Document function		6.1	Installation conditions	
1.2	Symbols	6		6.1.1 Mounting position	21
	1.2.1 Safety symbols	6		6.1.2 Environmental and process	າວ
	5	6		requirements	
	3	6	()	6.1.3 Special mounting instructions	
	1.2.4 Tool symbols	/	6.2	Mounting the measuring device	
	1.2.5 Symbols for	7		6.2.1 Required tools	
	certain types of information			6.2.2 Preparing the measuring device	
1 0	1.2.6 Symbols in graphics			6.2.3 Mounting the measuring device	
1.3	Documentation			6.2.4 Turning the transmitter housing	
		8	()	6.2.5 Turning the display module	
	1.3.2 Supplementary device-dependent		6.3	Post-installation check	29
1 /	documentation				
1.4	Registered trademarks	8	7	Electrical connection	30
2	Safety instructions	^	7.1	Connection conditions	
	-			7.1.1 Required tools	
2.1	Requirements for the personnel 1			7.1.2 Requirements for connecting cable	
2.2	3	.0		7.1.3 Terminal assignment	
2.3	Workplace safety 1	1		7.1.4 Device plugs available	33
2.4	Operational safety			7.1.5 Pin assignment of device plug	33
2.5	Product safety 1	.2		7.1.6 Shielding and grounding	33
2.6	IT security			7.1.7 Preparing the measuring device	
2.7	Device-specific IT security 1	.2	7.2	Connecting the measuring device	35
	2.7.1 Protecting access via hardware write			7.2.1 Connecting the transmitter	35
	protection 1	.2		7.2.2 Connecting the remote display and	
	2.7.2 Protecting access via a password 1			operating module DKX001	38
	2.7.3 Access via Web server 1	.3	7.3	Ensuring potential equalization	38
				7.3.1 Requirements	
3	Product description	4	7.4	Special connection instructions	
3.1	Product design	4	7.5	7.4.1 Connection examples	
J.1	Troudet debign	•	7.5 7.6	Ensuring the degree of protection Post-connection check	
4	Incoming acceptance and product		7.0	1 ost connection eneck	72
	identification 1	5	8	Operation options	43
4.1	Incoming acceptance	.5	8.1	Overview of operation options	43
4.2	Product identification		8.2	Structure and function of the operating	
	4.2.1 Transmitter nameplate 1			menu	44
		7		8.2.1 Structure of the operating menu	44
	1	.8		8.2.2 Operating philosophy	45
	,		8.3	Access to the operating menu via the local	
5	Storage and transport 1	g		display	46
	J 1			8.3.1 Operational display	46
5.1	Storage conditions			8.3.2 Navigation view	48
5.2	Transporting the product 1	.9		8.3.3 Editing view	50
	5.2.1 Measuring devices without lifting			8.3.4 Operating elements	52
	3	.9		8.3.5 Opening the context menu	52
	3 3 3	0		8.3.6 Navigating and selecting from list	54
	5.2.3 Transporting with a fork lift 2			8.3.7 Calling the parameter directly	54
5.3	Packaging disposal 2	U		8.3.8 Calling up help text	55
				8.3.9 Changing the parameters	55
				8.3.10 User roles and related access	
				authorization	56

		Disabling write protection via access code	56		10.6.4 Configuring the totalizer	105
		Enabling and disabling the keypad			configurations	107
		ock	57		10.6.6 WLAN configuration	
3.4	Access to	the operating menu via the Web			10.6.7 Configuration management	
	browser.		57		10.6.8 Using parameters for device	
		Function range	57		administration	112
		Prerequisites	58	10.7	Simulation	114
	8.4.3 E	Establishing a connection	59	10.8	Protecting settings from unauthorized access	116
	8.4.4 I	Logging on	61		10.8.1 Write protection via access code	116
	8.4.5 L	Jser interface	62		10.8.2 Write protection via write protection	
		Disabling the Web server	63		switch	118
	8.4.7 L	Logging out	63		10.8.3 Write protection via block operation	118
3.5	Access to	the operating menu via the				
		g tool	64	11	Operation	119
		Connecting the operating tool	64		-	
		Field Xpert SFX350, SFX370	66	11.1	Reading the device locking status	
		FieldCare	67	11.2	Adjusting the operating language	
		DeviceCare	68	11.3	Configuring the display	119
		AMS Device Manager	68	11.4	Reading measured values	119
	8.5.6 F	Field Communicator 475	69		11.4.1 Measured variables submenu	120
					11.4.2 Totalizer Submenu	121 122
9	System	integration	70		11.4.5 Input values submenu	123
9.1	-	of device description files		11.5	Adapting the measuring device to the process	14)
7.1		Current version data for the device		11.7	conditions	125
		Operating tools	70	11.6	Performing a totalizer reset	125
9.2		ta transmission	70	11.0	11.6.1 Function scope of the "Control	147
9.4		Block model	70		Totalizer" parameter	126
		Description of the modules	71		11.6.2 Function scope of the "Reset all	120
		Execution times			totalizers" parameter	126
		Methods		11.7	Showing data logging	126
10	Commi	ssioning	76	12	Diagnostics and troubleshooting	130
10.1	Function	check	76	12.1	General troubleshooting	130
10.2		g on the measuring device	-	12.2	Diagnostic information via light emitting	100
10.3		ng via FieldCare		12.2	diodes	132
10.4		ne operating language			12.2.1 Transmitter	
10.5		ing the measuring device		12.3	Diagnostic information on local display	
10.5		Defining the tag name		10.5	2	133
		ciming the tag name			12.3.1 Diagnostic message	
					12.3.1 Diagnostic message	
	10.5.2 S	Setting the system units	78	12.4	12.3.2 Calling up remedial measures	135
	10.5.2 S 10.5.3 S	Setting the system units Selecting and setting the medium	78 81	12.4	12.3.2 Calling up remedial measures Diagnostic information in the Web browser .	135 135
	10.5.2 S 10.5.3 S 10.5.4 C	Setting the system units	78 81 83	12.4	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 135
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I	Setting the system units	78 81 83 83		12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C	Setting the system units	78 81 83 83 84	12.4 12.5	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 135 136
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C	Setting the system units	78 81 83 83 84 85		12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 135 136
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C	Setting the system units	78 81 83 83 84		12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 135 136 136
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C	Setting the system units	78 81 83 83 84 85 86	12.5	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C	Setting the system units	78 81 83 83 84 85 86		12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C s 10.5.10 C	Setting the system units	78 81 83 83 84 85 86	12.5	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C 10.5.10 C 10.5.11 C	Setting the system units	78 81 83 83 84 85 86 89 96	12.5	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C s 10.5.10 C 10.5.11 C	Setting the system units	78 81 83 83 84 85 86 89 96 98	12.5 12.6	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138
	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C s 10.5.10 C 10.5.11 C 10.5.12 C	Setting the system units	78 81 83 83 84 85 86 89 96 98	12.5 12.6	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138 138
10.6	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C s 10.5.10 C 10.5.11 C 10.5.12 C	Setting the system units	78 81 83 83 84 85 86 89 96 98	12.5 12.6	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138 142 143
10.6	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.9 C s 10.5.10 C 10.5.11 C 10.5.12 C Advanced	Setting the system units	78 81 83 83 84 85 86 89 96 98 100	12.5 12.6	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138 142 143 145
10.6	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 I 10.5.6 C 10.5.7 C 10.5.8 C 10.5.10 C 10.5.11 C 10.5.12 C Advanced 10.6.1 U	Setting the system units Selecting and setting the medium Configuring the analog inputs Configuring the I/O configuration Configuring the current input Configuring the status input Configuring the pulse/frequency/ switch output Configuring the relay output Configuring the local display Configuring the low flow cut off Configuring the partial filled pipe detection d settings Jsing the parameter to enter the	78 81 83 83 84 85 86 89 96 98 100	12.5 12.6 12.7	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 136 137 138 138 142 143 151
10.6	10.5.2 S 10.5.3 S 10.5.4 C 10.5.5 E 10.5.6 C 10.5.7 C 10.5.8 C 10.5.10 C 10.5.11 C 10.5.12 C Advanced 10.6.1 L	Setting the system units	78 81 83 83 84 85 86 89 96 98 100	12.5 12.6 12.7	12.3.2 Calling up remedial measures Diagnostic information in the Web browser . 12.4.1 Diagnostic options	135 135 136 136 137 138 138 142 143 151 158

	Diagnostic list	164 165
	12.11.1 Reading out the event logbook	165
	12.11.2 Filtering the event logbook	166
10 10	12.11.3 Overview of information events	166
12.12	Resetting the measuring device	167167
	12.12.2 Function scope of the "Service reset"	107
	parameter	168
12.13	Device information	168
	Firmware history	170
13		171
13.1	Maintenance tasks	171
	13.1.1 Exterior cleaning	171
13.2	Measuring and test equipment	171
13.3	Endress+Hauser services	171
14	Repair	172
14.1	General notes	172
	14.1.1 Repair and conversion concept	172
	14.1.2 Notes for repair and conversion	172
14.2	Spare parts	172
14.3	Endress+Hauser services	172
14.4	Return	172
14.5	Disposal	173
	14.5.1 Removing the measuring device	173 173
	14.5.2 Disposing of the measuring device	1/3
15		174
15.1	Device-specific accessories	174
	15.1.1 For the transmitter	174
	15.1.2 For the sensor	175
15.2	Communication-specific accessories	175
15.3	Service-specific accessories	176
15.4	System components	176
16	Technical data	177
16.1	Application	177
16.2	Function and system design	177
16.3	Input	178
16.4	Output	181
16.5	Power supply	186
16.6	Performance characteristics	188
16.7	Installation	191
16.8	Environment	192
16.9	Process	192 195
	Mechanical construction	195
	Human interface	201
	Application packages	201
	Accessories	205
	Supplementary documentation	205
		207

1 About this document

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

⚠ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

▲ WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
===	Direct current
~	Alternating current
$\overline{}$	Direct current and alternating current
=	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections.
	The ground terminals are situated inside and outside the device: Inner ground terminal: Connects the protectiv earth to the mains supply. Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Communication symbols

Symbol	Meaning
	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
•	LED Light emitting diode is off.

Symbol	Meaning
茶	LED Light emitting diode is on.
×	LED Light emitting diode is flashing.

1.2.4 Tool symbols

Symbol	Meaning
0	Flat blade screwdriver
06	Allen key
Ó	Open-ended wrench

1.2.5 Symbols for certain types of information

Symbol	Meaning
✓	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
<u> </u>	Reference to documentation.
	Reference to page.
	Reference to graphic.
•	Notice or individual step to be observed.
1., 2., 3	Series of steps.
L	Result of a step.
?	Help in the event of a problem.
	Visual inspection.

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
×	Safe area (non-hazardous area)
≋➡	Flow direction

1.3 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from nameplate
 - *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate
- Detailed list of the individual documents along with the documentation code $\Rightarrow \stackrel{ riangle}{\Rightarrow} 205$

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.
	 Incoming acceptance and product identification Storage and transport Installation
Transmitter Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).
	 Product description Installation Electrical connection Operation options System integration Commissioning Diagnostic information
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use

Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ► Keep within the specified pressure and temperature range.
- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ► Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation → 🖺 8.
- ► Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

A WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

▲ WARNING

The electronics and the medium may cause the surfaces to heat up. This presents a burn hazard!

► For elevated fluid temperatures, ensure protection against contact to prevent burns.

A WARNING

Danger of housing breaking due to measuring tube breakage!

If a measuring tube ruptures, the pressure inside the sensor housing will rise according to the operating process pressure.

▶ Use a rupture disk.

A WARNING

Danger from medium escaping!

For device versions with a rupture disk: medium escaping under pressure can cause injury or material damage.

▶ Take precautions to prevent injury and material damage if the rupture disk is actuated.

2.3 Workplace safety

For work on and with the device:

Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

▶ Due to the increased risk of electric shock, gloves must be worn.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater inoperation safety if used correctly. An overview of the most important functions is provided in the following section.

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \stackrel{ riangle}{=} 12$	Not enabled.	On an individual basis following risk assessment.
Access code (also applies for Web server login or FieldCare connection) → 🖺 13	Not enabled (0000).	Assign a customized access code during commissioning.
WLAN (order option in display module)	Enabled.	On an individual basis following risk assessment.
WLAN security mode	Enabled (WPA2- PSK)	Do not change.
WLAN passphrase (password) → 🖺 13	Serial number	Assign an individual WLAN passphrase during commissioning.
WLAN mode	Access Point	On an individual basis following risk assessment.
Web server→ 🖺 13	Enabled.	On an individual basis following risk assessment.
CDI-RJ45 service interface	-	On an individual basis following risk assessment.

2.7.1 Protecting access via hardware write protection

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the motherboard). When hardware write protection is enabled, only read access to the parameters is possible.

2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

- User-specific access code
 - Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- WLAN passphrase
 - The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode
 When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

WLAN passphrase: Operation as WLAN access point

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter $(\rightarrow \boxminus 111)$.

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.

2.7.3 Access via Web server

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.


3 Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design




A00295

- $\blacksquare 1$ Important components of a measuring device
- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing
- 4 Electronics compartment cover
- 5 Sensor

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
 - Depending on the device version, the CD-ROM might not be part of the delivery!
 The Technical Documentation is available via the Internet or via the Endress+Hauser Operations App, see the "Product identification" section → 16.

4.2 Product identification


The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in the *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the device is displayed.
- Enter the serial number from nameplates in the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate using the *Endress+Hauser Operations App*: All information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The "Additional standard documentation on the device" → 8 and "Supplementary device-dependent documentation" → 8 sections
- The *W@M Device Viewer*: enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Transmitter nameplate




A00291

■ 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Manufacturing date: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, C-Tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable 17 Permitted ambient temperature (T_a)
- 18 Information on cable aland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

4.2.2 Sensor nameplate



A0029199

■ 3 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of the sensor; flange nominal diameter/nominal pressure; sensor test pressure; medium temperature range; material of measuring tube and manifold; sensor-specific information: e.g. pressure range of sensor housing, wide-range density specification (special density calibration)
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Flow direction
- 9 Manufacturing date: year-month
- 10 2-D matrix code
- 11 Document number of safety-related supplementary documentation
- 12 CE mark, C-Tick
- 13 Surface roughness
- 14 Permitted ambient temperature (T_a)

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on measuring device

Symbol	Meaning
\triangle	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
(i	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ► Store in a dry and dust-free place.
- ▶ Do not store outdoors.

Storage temperature → 192

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



m)

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

A WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ► Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0029214

5.2.2 Measuring devices with lifting lugs

A CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ► The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:


- Outer packaging of device
 Polymer stretch wrap that complies with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material Paper pads

6 Installation

6.1 Installation conditions

6.1.1 Mounting position

Mounting location




To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A00287

- \blacksquare 4 Installation in a down pipe (e.g. for batching applications)
- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Batching tank

D	N	Ø orifice plate, pipe restriction		
[mm] [in]		[mm]	[in]	
80	3	50	1.97	
100	4	65	2.60	
150	6	90	3.54	
250	10	150	5.91	


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Orientation					
A	Vertical orientation	A0015591	√ √ 1)			
В	Horizontal orientation, transmitter at top	A0015589	\checkmark \checkmark \checkmark \checkmark Exceptions: \rightarrow \checkmark 5, १ 22			
С	Horizontal orientation, transmitter at bottom	A0015590	✓ ✓ ³) Exceptions: → • 5, • 22			
D	Horizontal orientation, transmitter at side	A0015592	×			

- 1) This orientation is recommended to ensure self-draining.
- 2) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 3) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.



 \blacksquare 5 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.
- 2 Avoid this orientation for outgassing fluids: Risk of gas accumulating.

Inlet and outlet runs



Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section .

6.1.2 Environmental and process requirements

Ambient temperature range

Measuring device	 −40 to +60 °C (−40 to +140 °F) Order code for "Test, certificate", option JP: −50 to +60 °C (−58 to +140 °F)
Readability of the local display	-20 to $+60$ °C (-4 to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.

- Page Dependency of ambient temperature on medium temperature → 192
- ► If operating outdoors:

 Avoid direct sunlight, particularly in warm climatic regions.
- You can order a weather protection cover from Endress+Hauser. $\rightarrow \triangleq 174$.

System pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- ► Ensure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



A0028777

Thermal insulation

In the case of some fluids, it is important to keep the heat radiated from the sensor to the transmitter to a low level. A wide range of materials can be used for the required insulation.


The following device versions are recommended for versions with thermal insulation: Version with extended neck:

Order code for "Measuring tube material", option FA with an extended neck length of 105 mm (4.13 in).

NOTICE

Electronics overheating on account of thermal insulation!

- ► Recommended orientation: horizontal orientation, transmitter housing pointing downwards.
- ▶ Do not insulate the transmitter housing .
- ▶ Maximum permissible temperature at the lower end of the transmitter housing: $80 \,^{\circ}\text{C} (176 \,^{\circ}\text{F})$
- ► Thermal insulation with extended neck free: We recommend that you do not insulate the extended neck in order to ensure optimum dissipation of heat.



■ 6 Thermal insulation with extended neck free

A0034391

Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter .
- ► Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE

Danger of overheating when heating

- ► Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F).
- ► Ensure that sufficient convection takes place at the transmitter neck.
- ► Ensure that a sufficiently large area of the transmitter neck remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.
- ▶ When using in potentially explosive atmospheres, observe the information in the device-specific Ex documentation. For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

24

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

6.1.3 Special mounting instructions

Drainability

The measuring tubes can be completely drained and protected against solids build-up in vertical orientation.

Sanitary compatibility



- When installing in hygienic applications, please refer to the information in the "Certificates and approvals/hygienic compatibility" section
- In the case of measuring devices with the order code for "Housing", option B "Stainless, hygienic", to seal the connection compartment cover, screw it closed finger-tight and then tighten it by another 45° (corresponds to 15 Nm).

Rupture disk

Information that is relevant to the process: $\rightarrow \blacksquare 194$.

A WARNING

Danger from medium escaping!

Medium escaping under pressure can cause injury or material damage.


- ► Take precautions to prevent danger to persons and damage if the rupture disk is actuated.
- ▶ Observe information on the rupture disk sticker.
- ► Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- ▶ Do not use a heating jacket.
- ▶ Do not remove or damage the rupture disk.

The position of the rupture disk is indicated by a sticker beside it.

The transportation quard must be removed.

The existing connecting nozzles are not intended for the purpose of rinsing or pressure monitoring, but instead serve as the mounting location for the rupture disk.

In the event of a failure of the rupture disk, a drain device can be screwed onto the female thread of the rupture disk in order to drain off any escaping medium.



A003034

- 1 Rupture disk label
- 2 Rupture disk with 1/2" NPT female thread and 1" width across flat
- *3 Transportation guard*


For information on the dimensions: see the "Mechanical construction" section of the "Technical Information" document

Zero point adjustment

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

Protective cover



■ 7 Engineering unit mm (in)


Cover locking

NOTICE

Order code for "Housing", option L "Cast, stainless": The covers of the transmitter housing are provided with a borehole to lock the cover.

The cover can be locked using screws and a chain or cable provided by the customer.

- ▶ It is recommended to use stainless steel cables or chains.
- ► If a protective coating is applied, it is recommended to use a heat shrink tube to protect the housing paint.



- 1 Cover borehole for the securing screw
- 2 Securing screw to lock the cover

6.2 Mounting the measuring device

6.2.1 Required tools

For sensor

For flanges and other process connections: Corresponding mounting tools

6.2.2 Preparing the measuring device

- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.


6.2.3 Mounting the measuring device

A WARNING

Danger due to improper process sealing!


- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the seals are clean and undamaged.
- ► Secure the seals correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.

2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- A0029993
- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Release the fixing screw.
- 4. Turn the housing to the desired position.
- 5. Firmly tighten the securing screw.
- 6. Screw on the connection compartment cover.
- 7. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.2.5 Turning the display module

The display module can be turned to optimize display readability and operability.



A003003

- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Turn the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 4. Screw on the connection compartment cover.
- 5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.3 Post-installation check

Is the device undamaged (visual inspection)?		
Does the measuring device conform to the measuring point specifications? For example: Process temperature → 192 Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) Ambient temperature Measuring range		
Has the correct orientation for the sensor been selected? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids)		
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $		
Are the measuring point identification and labeling correct (visual inspection)?		
Is the device adequately protected from precipitation and direct sunlight?		
Are the securing screw and securing clamp tightened securely?		

7 **Electrical connection**

NOTICE

The measuring device does not have an internal circuit breaker.

- ▶ For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 10 A) should be integrated into the system installation.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver ≤ 3 mm (0.12 in)

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Protective ground cable

Cable $\geq 2.08 \text{ mm}^2 \text{ (14 AWG)}$

The grounding impedance must be less than 1Ω .

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable

Standard installation cable is sufficient.

Signal cable

FOUNDATION Fieldbus

Twisted, shielded two-wire cable.



For further information on planning and installing FOUNDATION Fieldbus networks see:

- Operating Instructions for "FOUNDATION Fieldbus Overview" (BA00013S)
- FOUNDATION Fieldbus Guideline
- IEC 61158-2 (MBP)

Current output 0/4 to 20 mA

Standard installation cable is sufficient.

Pulse/frequency/switch output

Standard installation cable is sufficient.

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient.

Status input

Standard installation cable is sufficient.

Cable diameter

Cable glands supplied:

 $M20 \times 1.5$ with cable Ø 6 to 12 mm (0.24 to 0.47 in)

■ Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Requirements for the connecting cable – Remote display and operating module DKX001

Optionally available connecting cable

A cable is supplied depending on the order option

- Order code for measuring device: order code 030 for "Display; operation", option 0
- Order code for measuring device: order code 030 for "Display; operation", option M
 and
- Order code for DKX001: order code **040** for "Cable", option **A, B, D, E**

Standard cable	$2\times2\times0.34~\text{mm}^2$ (22 AWG) PVC cable with common shield (2 pairs, pairstranded)		
Flame resistance	According to DIN EN 60332-1-2		
Oil-resistance	According to DIN EN 60811-2-1		
Shielding	Tin-plated copper-braid, optical cover ≥ 85 %		
Capacitance: core/shield	≤200 pF/m		
L/R	<24 μH/Ω		
Available cable length	5 m (15 ft)/10 m (35 ft)/20 m (65 ft)/30 m (100 ft)		
Operating temperature	When mounted in a fixed position: -50 to $+105$ °C (-58 to $+221$ °F); when cable can move freely: -25 to $+105$ °C (-13 to $+221$ °F)		

Standard cable - customer-specific cable

No cable is supplied, and it must be provided by the customer (up to max.

300 m (1000 ft)) for the following order option:

Order code for DKX001: Order code $\bf 040$ for "Cable", option $\bf 1$ "None, provided by customer, max 300 m"

A standard cable can be used as the connecting cable.

Standard cable	4 cores (2 pairs); pair-stranded with common shield
Shielding	Tin-plated copper-braid, optical cover ≥ 85 %
Capacitance: core/shield	Maximum 1000 nF for Zone 1, Class I, Division 1

L/R	Maximum 24 μ H/ Ω for Zone 1, Class I, Division 1
Cable length	Maximum 300 m (1000 ft), see the following table

Cross-section	Max. cable length for use in Non-hazardous area, Ex Zone 2, Class I, Division 2 Ex Zone 1, Class I, Division 1
0.34 mm ² (22 AWG)	80 m (270 ft)
0.50 mm ² (20 AWG)	120 m (400 ft)
0.75 mm ² (18 AWG)	180 m (600 ft)
1.00 mm ² (17 AWG)	240 m (800 ft)
1.50 mm ² (15 AWG)	300 m (1000 ft)

7.1.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply voltage		Input/o	utput 1	Input/c	output 2	Input/c	output 3
1 (+)	2 (-)	26 (A)	27 (B)	24 (+)	25 (-)	22 (+)	23 (-)
		Device-specific terminal assignment: adhesive label in terminal cover.					

7.1.4 Device plugs available

Provice plugs may not be used in hazardous areas!

Order code for "Input; output 1", option SA "FOUNDATION Fieldbus"

	Order code for	Cable entry/connection		
"Ele	ectrical connection"	2	3	
	M, 3, 4, 5	7/8" connector	-	

7.1.5 Pin assignment of device plug

	Pin		Assignment	Coding	Plug/socket
2 / 3	1	+	Signal +	A	Plug
1 4	2	-	Signal –		
	3		Grounding		
	4		Not assigned		

7.1.6 Shielding and grounding

Optimal electromagnetic compatibility (EMC) of the fieldbus system can be guaranteed only if the system components and, in particular, the lines are shielded and the shield forms as complete a cover as possible. A shield coverage of 90 %is ideal.

- 1. To ensure optimal EMC protection, connect the shield to the reference ground as often as possible.
- 2. For reasons concerning explosion protection, it is recommended that grounding be dispensed with.

To comply with both requirements, there are basically three different types of shielding in the fieldbus system:

- Shielding at both ends
- Shielding at one end on the feed side with capacitance termination at the field device
- Shielding at one end on the feed side

Experience shows that the best results with regard to EMC are achieved in most cases in installations with one-sided shielding on the feed side (without capacitance termination at the field device). Appropriate measures with regard to input wiring must be taken to allow

unrestricted operation when EMC interference is present. These measures have been taken into account for this device. Operation in the event of disturbance variables as per NAMUR NE21 is thus quaranteed.


- 1. Observe national installation requirements and quidelines during installation.
- 2. Where there are large differences in potential between the individual grounding points,
 - connect only one point of the shielding directly to the reference ground.
- 3. In systems without potential equalization, the cable shielding of fieldbus systems should be grounded on one side only, for example at the fieldbus supply unit or at safety barriers.

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- ▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.
- ▶ Insulate the shield that is not connected.



A002876

■ 8 Connection example for FOUNDATION Fieldbus

- 1 Control system (e.g. PLC)
- 2 Power conditioner (FOUNDATION Fieldbus)
- 3 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential equalization conductor

7.1.7 Preparing the measuring device

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- ▶ Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.

34

- 2. If the measuring device is supplied without cable glands:
 Provide suitable cable gland for corresponding connecting cable.
- 3. If the measuring device is supplied with cable glands:

 Observe requirements for connecting cables →

 30.


7.2 Connecting the measuring device

NOTICE

Limitation of electrical safety due to incorrect connection!


- ► Have electrical connection work carried out by appropriately trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- ▶ Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the transmitter




A0026781

- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45); optional: connection for external WLAN antenna or remote display and operating module DKX001
- 4 Protective earth (PE)




A002981

- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.




A002981

- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.



A00298

- 7. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9. Connect the protective ground.




A002981

- 10. Connect the cable in accordance with the terminal assignment.
 - Signal cable terminal assignment: The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

- 11. Firmly tighten the cable glands.
 - ► This concludes the cable connection process.
- 12. Close the terminal cover.
- 13. Fit the display module holder in the electronics compartment.
- 14. Screw on the connection compartment cover.
- 15. Secure the securing clamp of the connection compartment cover.

Removing a cable




- **■** 9 Engineering unit mm (in)
- 1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

7.2.2 Connecting the remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra $\Rightarrow \triangleq 174$.

- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module.
 Only one display or operation unit may be connected to the transmitter at any one time.



A00275

- 1 Remote display and operating module DKX001
- 2 Protective earth (PE)
- 3 Connecting cable
- 4 Measuring device
- 5 Protective earth (PE)

7.3 Ensuring potential equalization


7.3.1 Requirements

No special measures for potential equalization are required.

7.4 Special connection instructions

7.4.1 Connection examples

FOUNDATION Fieldbus




40020740

■ 10 Connection example for FOUNDATION Fieldbus

- 1 Control system (e.g. PLC)
- 2 Power Conditioner (FOUNDATION Fieldbus)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 T-box
- 5 Measuring device
- 6 Local grounding
- 7 Bus terminator
- 8 Potential matching line


Current output 4-20 mA



A0028758

■ 11 Connection example for 4-20 mA current output (active)


- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load
- 3 Transmitter



■ 12 Connection example for 4-20 mA current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load
- 4 Transmitter


Pulse/frequency output



■ 13 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- *3 Transmitter: Observe input values → 🖺 182*

Switch output




14 Connection example for switch output (passive)

- 1 Automation system with switch input (e.g. PLC)
- 2 Power supply
- *3 Transmitter: Observe input values* → 🖺 182

40 Endress+Hauser

A002876


Relay output



■ 15 Connection example for relay output (passive)

- Automation system with relay input (e.g. PLC)
- 2 Power supply
- *Transmitter: Observe input values* → 🖺 183


Current input



Connection example for 4 to 20 mA current input

- Power supply
- Terminal box
- External measuring device (to read in pressure or temperature, for instance)
- Transmitter

Status input



■ 17 $Connection\ example\ for\ status\ input$

- Automation system with status output (e.g. PLC)
- 2 Power supply
- Transmitter


7.5 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.
- 5. To ensure that moisture does not enter the cable entry:

 Route the cable so that it loops down before the cable entry ("water trap").



A00292


6. Insert dummy plugs into unused cable entries.

7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables used meet the requirements?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" → 🖺 42?	
If supply voltage is present, do values appear on the display module?	

8 Operation options

8.1 Overview of operation options




A0024E12

- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: "Description of Device Parameters" document supplied with the device $\rightarrow 205$



 \blacksquare 18 Schematic structure of the operating menu

8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.


For custody transfer, once the device has been put into circulation or sealed, its operation is restricted.

Men	u/parameter	User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuring the operational display Reading measured values	 Defining the operating language Defining the Web server operating language Resetting and controlling totalizers
Operation			 Configuring the operational display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs Configuration of the communication interface	Wizards for fast commissioning: Setting the system units Configuration of the communication interface Defining the medium Displaying the I/O/configuration Configuring the inputs Configuring the outputs Configuration of the operational display Setting the low flow cut off Configuring partial and empty pipe detection Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers Configuring the WLAN settings Administration (define access code, reset measuring device)
Diagnostics		"Maintenance" role Fault elimination: Diagnostics and elimination of process and device errors Measured value simulation	Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device. Measured values Contains all current measured values. Data logging submenu with "Extended HistoROM" order option Storage and visualization of measured values Heartbeat The functionality of the device is checked on demand and the verification results are documented. Simulation Is used to simulate measured values or output values.

Menu/parameter		User role and tasks	Content/meaning
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-order device parameters which do not concern the measurement or the communication interface. Sensor Configuration of the measurement. Output Configure the pulse/frequency/switch output. Input Configuration of the status input. Output Configuration of the analog current outputs as well as the pulse/frequency and switch output. Communication Configuration of the digital communication interface and the Web server. Submenus for function blocks (e.g. "Analog Inputs") Configuration of function blocks. Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



A002934

- 1 Operational display
- 2 Device tag
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements→ 🖺 52

Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 133
 - **F**: Failure
 - **C**: Function check
 - **S**: Out of specification
 - M: Maintenance required
- Diagnostic behavior → 🗎 134
 - Alarm
 - <u>M</u>: Warning
- 🛱: Locking (the device is locked via the hardware)
- ←: Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured values

Symbol	Meaning
ṁ	Mass flow
Ü	Volume flowCorrected volume flow
P	DensityReference density
4	Temperature
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.
€	Status input

Measurement channel numbers


Symbol	Meaning
1 4	Measurement channel 1 to 4

The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).

Diagnostic behavior


The number and display format of the measured values can be configured via the **Format display** parameter ($\rightarrow \triangleq 99$).

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



For more information about the icons in the menu, refer to the "Display area" section $\Rightarrow \triangleq 49$

Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal

For information on the diagnostic behavior and status signal →
 □ 133
 For information on the function and entry of the direct access code →
 □ 54

Display area

Menus

Symbol	Meaning
P	Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu
۶	Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
ਨੰ	Diagnostics Appears: ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the Diagnostics menu
±,€	Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
55.	Wizard
Ø.	Parameters within a wizard No display symbol exists for parameters in submenus.

Locking


Symbol	Meaning
û	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. By a user-specific access code By the hardware write protection switch

Wizard operation

Symbol	Meaning
←	Switches to the previous parameter.
√	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 **Editing view**


Numeric editor



■ 19 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- Operating elements

Text editor



- 20 For entering text in parameters (e.g. tag name)
- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- Operating elements
- Move entry position 5
- 6 Delete entry
- Reject or confirm entry

Using the operating elements in the editing view

Operating key(s)	Meaning
	Minus key Move the entry position to the left.
+	Plus key Move the entry position to the right.

Operating key(s)	Meaning
E	 Enter key Press the key briefly: confirm your selection. Press the key for 2 s: confirm the entry.
-++	Escape key combination (press keys simultaneously) Close the editing view without accepting the changes.

Input screens

Symbol	Meaning
А	Upper case
a	Lower case
1	Numbers
+*.	Punctuation marks and special characters: = + - * / 2 3 $\frac{1}{4}$ $\frac{1}{2}$ $\frac{3}{4}$ () < > { }
@	Punctuation marks and special characters:
ä	Umlauts and accents

Controlling data entries

Symbol	Meaning
←→	Move entry position
X	Reject entry
4	Confirm entry
4 X	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

8.3.4 Operating elements

Operating key(s)	Meaning
Θ	Minus key In a menu, submenu Moves the selection bar upwards in a picklist. With a Wizard Confirms the parameter value and goes to the previous parameter. With a text and numeric editor Move the entry position to the left.
(+)	Plus key In a menu, submenu Moves the selection bar downwards in a picklist. With a Wizard Confirms the parameter value and goes to the next parameter. With a text and numeric editor Move the entry position to the right.
E	Enter key For operational display Pressing the key briefly opens the operating menu. In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter. With a Wizard Opens the editing view of the parameter. With a text and numeric editor Press the key briefly: confirm your selection. Press the key for 2 s: confirm the entry.
(a)+(+)	Escape key combination (press keys simultaneously) In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). With a Wizard Exits the wizard and takes you to the next higher level. With a text and numeric editor Close the editing view without accepting the changes.
(-)+E	 Minus/Enter key combination (press the keys simultaneously) If the keypad lock is active: Press the key for 3 s: deactivate the keypad lock. If the keypad lock is not active: Press the key for 3 s: the context menu opens along with the option for activating the keypad lock.

8.3.5 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- 1. Press the \Box and \Box keys for longer than 3 seconds.
 - └ The context menu opens.



A0034608-E

- 2. Press = + ± simultaneously.
 - ightharpoonup The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press ± to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - ► The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\rightarrow \triangleq 48$

Example: Setting the number of displayed measured values to "2 values"




8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

Expert → Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is accessed automatically.
 Example: Enter 00914 → Assign process variable parameter
- If a different channel is accessed: Enter the direct access code with the corresponding channel number.

Example: Enter **00914-2** → **Assign process variable** parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

- 1. Press E for 2 s.
 - ► The help text for the selected parameter opens.



A0014002-EI

- 21 Example: Help text for parameter "Enter access code"
- 2. Press \Box + \pm simultaneously.
 - ► The help text is closed.

8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

A0014049-E

For a description of the editing view - consisting of the text editor and numeric editor - with symbols $\rightarrow \implies 50$, for a description of the operating elements $\rightarrow \implies 52$

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access $\rightarrow \blacksquare 116$.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ▶ Define the access code.
 - The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ 1)

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	1)

- Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section
- The user role with which the user is currently logged on is indicated by the **Access** status parameter. Navigation path: Operation \rightarrow Access status

8.3.11 Disabling write protection via access code

If the $\widehat{\mbox{$\mathbb B$}}$ -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\rightarrow \mbox{$\mathbb B$}$ 116.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ($\rightarrow \triangleq 103$) via the respective access option.

1. After you press E, the input prompt for the access code appears.

- 2. Enter the access code.
 - The \(\bar{\text{\mathbb{O}}}\) -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

- The keypad lock is switched on automatically:
 - If the device has not been operated via the display for > 1 minute.
 - Each time the device is restarted.

To activate the keylock manually:

- 1. The device is in the measured value display.

 Press the □ and □ keys for 3 seconds.
 - ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- ► The keypad lock is switched on.
 Press the □ and □ keys for 3 seconds.
 - ► The keypad lock is switched off.

8.4 Access to the operating menu via the Web browser

8.4.1 Function range

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device $\rightarrow \stackrel{\triangle}{=} 206$

8.4.2 Prerequisites

Computer hardware

Hardware	Interface	
	CDI-RJ45	WLAN
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.
Connection	Standard Ethernet cable with RJ45 connector.	Connection via Wireless LAN.
Screen	Recommended size: ≥12" (depends on the screen resolution)	

Computer software

Software	re Interface	
	CDI-RJ45	WLAN
Recommended operating systems	 Microsoft Windows 7 or higher. Mobile operating systems: iOS Android Microsoft Windows XP is supported 	
Web browsers supported	 Microsoft Internet Explorer 8 or higher Microsoft Edge Mozilla Firefox Google Chrome Safari 	

Computer settings

Settings	Interface	
	CDI-RJ45	WLAN
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).	
Proxy server settings of the Web browser	The Web browser setting <i>Use a Proxy Server for Your LAN</i> must be deselected .	
JavaScript	JavaScript must be enabled.	
	If JavaScript cannot be enabled: enter http://192.168.1.212/basic.html in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.	
	When installing a new firmware version: To enable correct data displaced clear the temporary memory (cache) of the Web browser under Intercoptions .	
Network connections	Only the active network connections to the measuring device should be used.	
	Switch off all other network connections such as WLAN.	Switch off all other network connections.

Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface	
Measuring device	The measuring device has an RJ45 interface.	
Web server	Web server must be enabled; factory setting: ON	
	For information on enabling the Web server $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	

Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna: Transmitter with integrated WLAN antenna Transmitter with external WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ON For information on enabling the Web server $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

8.4.3 Establishing a connection

Via service interface (CDI-RJ45)

Preparing the measuring device

- 1. Depending on the housing version:

 Release the securing clamp or securing screw of the housing cover.
- 2. Depending on the housing version: Unscrew or open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol:

 Connect the computer to the RJ45 connector via the standard Ethernet connecting cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- 2. Connect to the computer using a cable $\rightarrow \triangleq 64$.
- 3. If a 2nd network card is not used, close all the applications on the notebook.
 - Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 \rightarrow e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- ▶ Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

► Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal: Select the measuring device using the SSID (e.g. EH_Promass_300_A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - LED on display module flashes: it is now possible to operate the measuring device with the Web browser. FieldCare or DeviceCare.
- 🚹 The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.


Disconnecting

► After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

Starting the Web browser

1. Start the Web browser on the computer.

- 2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212
 - ► The login page appears.



- 1 Picture of device
- 2 Device name
- 3 Device tag
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
-) Login
- 10 Reset access code ($\rightarrow \equiv 113$)


8.4.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (factory setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal → 🖺 136
- Current measured values

Function row

Functions	Meaning	
Measured values	Displays the measured values of the measuring device	
Menu	 Access to the operating menu from the measuring device The structure of the operating menu is the same as for the local display For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device 	
Device status	Displays the diagnostic messages currently pending, listed in order of priority	
Data management	Data exchange between PC and measuring device: Device configuration: Load settings from the device (XML format, save configuration) Save settings to the device (XML format, restore configuration) Logbook - Export Event logbook (.csv file) Documents - Export documents: Export backup data record (.csv file, create documentation of the measuring point configuration) Verification report (PDF file, only available with the "Heartbeat Verification" application package) File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring device: FOUNDATION Fieldbus: DD file Firmware update - Flashing a firmware version	
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the measuring device: Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version)	
Logout	End the operation and call up the login page	

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu \rightarrow Communication \rightarrow Web server

Parameter overview with brief description

Parameter	Description	Selection
Web server functionality	Switch the Web server on and off.	OffHTML OffOn

Function scope of the "Web server functionality" parameter

Option	Description
Off	The web server is completely disabled.Port 80 is locked.
On	 The complete functionality of the web server is available. JavaScript is used. The password is transferred in an encrypted state. Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

- Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.
- 1. Select the **Logout** entry in the function row.
 - ► The home page with the Login box appears.
- 2. Close the Web browser.
- 3. If no longer needed:


8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool

Via FOUNDATION Fieldbus network

This communication interface is available in device versions with FOUNDATION Fieldbus.



■ 22 Options for remote operation via FOUNDATION Fieldbus network

- 1 Automation system
- 2 Computer with FOUNDATION Fieldbus network card
- 3 Industry network
- 4 High Speed Ethernet FF-HSE network
- 5 Segment coupler FF-HSE/FF-H1
- 6 FOUNDATION Fieldbus FF-H1 network
- 7 Power supply FF-H1 network
- 8 T-box
- 9 Measuring device

Service interface


Via service interface (CDI-RJ45)

A point-to-point connection can be established to configure the device onsite. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

i

An adapter for RJ45 and the M12 connector is optionally available: Order code for "Accessories", option **NB**: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 connector mounted in the cable entry. Therefore the connection to the service interface can be established via an M12 connector without opening the device.




23 € Connection via service interface (CDI-RJ45)

- Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated $device\ Web\ server\ or\ with\ "Field Care",\ "Device Care"\ operating\ tool\ with\ COM\ DTM\ "CDI\ Communication\ TCP/IP"$
- Standard Ethernet connecting cable with RJ45 connector
- Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



A0034570

- Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- LED lit constantly: WLAN reception is enabled on measuring device
- LED flashing: WLAN connection established between operating unit and measuring device
- Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antennas	 Internal antenna External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Only one antenna active in each case!

Range	 Internal antenna: typically 10 m (32 ft) External antenna: typically 50 m (164 ft) 		
Materials (external antenna)	 Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Connector: Nickel-plated brass Angle bracket: Stainless steel 		

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- ▶ Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ▶ If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

▶ Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal: Select the measuring device using the SSID (e.g. EH Promass 300 A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.
- 🎮 The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting

► After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

8.5.2 Field Xpert SFX350, SFX370

Function range

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

Source for device description files

See information $\rightarrow \blacksquare 70$

8.5.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- CDI-RJ45 service interface → 🗎 64
- WLAN interface → 🗎 65

Typical functions:


- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook




Source for device description files

See information $\rightarrow \blacksquare 70$

Establishing a connection



User interface



A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal→ 🖺 136
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.5.4 DeviceCare

Function scope

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure INO1047S $\,$

Source for device description files

See information $\rightarrow \blacksquare 70$

8.5.5 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via FOUNDATION Fieldbus H1 protocol.

Source for device description files

See data \rightarrow \blacksquare 70

8.5.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via FOUNDATION Fieldbus H1 protocol.

Source for device description files

See data $\rightarrow \blacksquare 70$

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.00.zz	 On the title page of the Operating instructions On the transmitter nameplate Firmware version Diagnostics → Device information → Firmware version 		
Release date of firmware version	02.2017			
Manufacturer ID	0x452B48 (hex)	Manufacturer ID Diagnostics → Device information → Manufacturer ID		
Device type ID	0x103B (hex)	Device type Diagnostics → Device information → Device type		
Device revision	1	 On the transmitter nameplate Device revision Diagnostics → Device information → Device revision 		
DD revision		Information and files under:		
CFF revision	www.endress.cwww.fieldbus.c			

For an overview of the different firmware versions for the device $\rightarrow \triangleq 170$

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via FOUNDATION Fieldbus	Sources for obtaining device descriptions	
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser) 	
DeviceCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser) 	
■ Field Xpert SFX350 ■ Field Xpert SFX370	Use update function of handheld terminal	
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area	
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal	

9.2 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

9.2.1 Block model

The block model shows which input and output data the measuring device makes available for cyclic data exchange. Cyclic data exchange takes place with a FOUNDATION Fieldbus master (Class 1), e.g. a control system etc.

Display text (xxxx = serial number)	Base index	Description
RESOURCE_ xxxxxxxxxxx	400	Resource block
SETUP_xxxxxxxxxxx	600	"Setup" Transducer block
TRDDISP_ xxxxxxxxxx	800	"Display" Transducer block
TRDHROM_ xxxxxxxxxxx	1000	"HistoROM" Transducer block
TRDDIAG_ xxxxxxxxxx	1200	"Diagnostic" Transducer block
EXPERT_CONFIG_xxxxxxxxxxx	1400	"Expert configuration" Transducer block
SERVICE_SENSOR_xxxxxxxxxxx	1600	"Service sensor" Transducer block
TRDTIC_xxxxxxxxxx	1800	"Totalizer" Transducer block
TRDHBT_ xxxxxxxxxx	2000	Transducer block "Heartbeat results"
ANALOG_INPUT_1_xxxxxxxxxxx	3400	Analog Input function block 1 (AI)
ANALOG_INPUT_2_xxxxxxxxxxx	3600	Analog Input function block 2 (AI)
ANALOG_INPUT_3_xxxxxxxxxxx	3800	Analog Input function block 3 (AI)
ANALOG_INPUT_4_xxxxxxxxxxx	4000	Analog Input function block 4 (AI)
ANALOG_INPUT_5_xxxxxxxxxxx	4200	Analog Input function block 5 (AI)
ANALOG_INPUT_6_xxxxxxxxxxx	4400	Analog Input function block 6 (AI)
ANALOG_INPUT_7_xxxxxxxxxxx	4600	Analog Input function block 7 (AI)
ANALOG_INPUT_8_xxxxxxxxxxx	4800	Analog Input function block 8 (AI)
MAO_xxxxxxxxxx	5000	Multiple Analog Output block (MAO)
DIGITAL_INPUT_1_ xxxxxxxxxxx	5200	Digital Input function block 1 (DI)
DIGITAL_INPUT_2_ xxxxxxxxxxx	5400	Digital Input function block 2 (DI)
MDO_xxxxxxxxxx	5600	Multiple Digital Output block (MDO)
PID_ xxxxxxxxxx	5800	PID function block (PID)
INTEGRATOR_xxxxxxxxxxx	6000	Integrator function block (INTG)

9.2.2 Description of the modules

The input value of a module/function block is defined via the CHANNEL parameter.

AI module (Analog Input)

Eight Analog Input blocks are available.

CHANNEL	Measured variable
0	Uninitialized (factory setting)
7	Temperature
9	Volume flow
10	Concentration 1)
11	Mass flow
13	Corrected volume flow
14	Density
15	Reference density
16	Totalizer 1
17	Totalizer 2
18	Totalizer 3
33	Oscillation frequency 1)

CHANNEL	Measured variable	
43	Frequency fluctuation ¹⁾	
51	Carrier pipe temperature 1)	
57	Carrier mass flow 1)	
58	Target mass flow 1)	
63	Oscillation damping ¹⁾	
65	Electronic temperature	
66	Tube damping fluctuation ¹⁾	
68	Exciter current 1)	
81	HBSI ¹⁾	
99	Current input 1 1)	

1) Visible depending on the order options or device settings

MAO module (Multiple Analog Output)

Channel	Description
121	Channel_0

Structure

Channel_0							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Values	Measured variable		
Value 1	External pressure 1)		
Value 2	External temperature ¹⁾		
Value 3	External reference density ¹⁾		
Value 4	Not assigned		
Value 5	Not assigned		
Value 6	Not assigned		
Value 7	Not assigned		
Value 8	Not assigned		

- 1) The external measured values must be transmitted to the device in the SI basic unit
- The selection is made via: Expert \rightarrow Sensor \rightarrow External compensation

DI module (Discrete Input)

Two Discrete Input blocks are available.

CHANNEL	Device function	State
0	Uninitialized (factory setting)	-
101	Switch output state	0 = off, 1 = active
103	Low flow cut off	0 = off, 1 = active

CHANNEL	Device function	State
104	Empty pipe detection	0 = off, 1 = active
105	Verification status ¹⁾	Overall result of the verification Verification: 16 = Failed 22 = Passed 64 = Not performed
		Verification status Verification: 1 = Not performed 2 = Failed 4 = Being performed 8 = Finished
		Status; result 17 = Status: not performed; Result: failed 18 = Status: failed; Result: failed 20 = Status: being performed; Result: failed 24 = Status: finished; Result: failed 33 = Status: not performed; Result: passed 34 = Status: failed; Result: passed 36 = Status: being performed; Result: passed 40 = Status: finished; Result: passed 65 = Status: not performed Result: not performed 66 = Status: failed; Result: not performed 68 = Status: being performed Result: not performed

1) Only available with the Heartbeat Verification application package

MDO module (Multiple Discrete Output)

Channel	Description
122	Channel_DO

Structure

Channel_DO							
Value 1	Value 2	Value 3	Value 4	Value 5	Value 6	Value 7	Value 8

Value	Device function	State
Value 1	Reset totalizer 1	0 = off, 1 = execute
Value 2	Reset totalizer 2	0 = off, 1 = execute
Value 3	Reset totalizer 3	0 = off, 1 = execute
Value 4	Flow override	0 = off, 1 = active
Value 5	Start heartbeat verification 1)	0 = off, 1 = start
Value 6	Status output	0 = off, 1 = active

Value	Device function	State
Value 7	Zero point adjustment	0 = off, 1 = on
Value 8	Not assigned	_

1) Only available with the Heartbeat Verification application package

9.2.3 Execution times

Function block	Execution time (ms)
Analog Input function block (AI)	6
Digital Input function block (DI)	4
PID function block (PID)	5
Multiple Analog Output block (MAO)	4
Multiple Digital Output block (MDO)	4
Integrator function block (INTG)	5

9.2.4 Methods

Method	Block	Navigation	Description
Set to "AUTO" mode	Resource block	Via menu: Expert → Communication → Resource block → Target mode	This method sets the Resource Block and all the Transducer Blocks to the AUTO (Automatic) mode.
Set to "OOS" mode	Resource block	Via menu: Expert → Communication → Resource block → Target mode	This method sets the Resource Block and all the Transducer Blocks to the OOS (Out of service) mode.
Restart	Resource block	Via menu: Expert → Communication → Resource block → Restart	This method is used to select the configuration for the Restart parameter in the Resource Block. This resets device parameters to a specific value.
			The following options are supported: Uninitialized Run Resource Defaults Processor To delivery settings
ENP parameter	Resource block	Via menu: Actions → Methods→ Calibrate → ENP parameter	This method is used to display and configure the parameters of the electronic nameplate (ENP).
Overview diagnostics - Remedy information	Diagnostic Transducer Block	Via link: Namur symbol	This method is used to display the diagnostic event with the highest priority that is currently active and the corresponding remedial measures.
Actual diagnostics – Remedy information	Diagnostic Transducer Block	Via menu: ■ Configure/Setup → Diagnostics → Actual diagnostics Diagnostics	This method is used to display remedial measures for the diagnostic event with the highest priority that is currently active.
		■ Device/Diagnostics → Diagnostics	This method is available only if an appropriate diagnostic event has occurred.
Previous diagnostics – Remedy information	Diagnostic Transducer Block	Via menu: ■ Configure/Setup → Diagnostics → Previous	This method is used to display remedial measures for the previous diagnostic event.
		diagnostics ■ Device/Diagnostics → Diagnostics	This method is available only if an appropriate diagnostic event has occurred.

76

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist → 🖺 29
- "Post-connection check" checklist → 🖺 42

10.2 Switching on the measuring device


- ▶ After a successful function check, switch on the measuring device.
 - After a successful startup, the local display switches automatically from the startup display to the operational display.

10.3 Connecting via FieldCare

- For FieldCare → 🖺 64 connection
- For connecting via FieldCare $\rightarrow \triangleq 67$
- For the FieldCare → 🗎 68 user interface

10.4 Setting the operating language


Factory setting: English or ordered local language



 \blacksquare 24 Taking the example of the local display


10.5 Configuring the measuring device


- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the **Setup** menu



ightharpoons25 Taking the example of the local display


Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.





10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



 \blacksquare 26 Header of the operational display with tag name

- 1 Tag name

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry
Device tag	51	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /)


10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

Navigation

"Setup" menu → System units



Corrected volume flow unit	→ 🖺 79
Corrected volume unit	→ 🖺 79
Density unit	→ 🗎 79
Reference density unit	→ 🖺 79
Temperature unit	→ 🖺 80
Pressure unit	→ 🖺 80

Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: kg/h lb/min
Mass unit	Select mass unit.	Unit choose list	Country-specific: kg lb
Volume flow unit	Select volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: l/h gal/min (us)
Volume unit	Select volume unit.	Unit choose list	Country-specific: • 1 (DN > 150 (6"): m³ option) • gal (us)
Corrected volume flow unit	Select corrected volume flow unit. Result The selected unit applies for: Corrected volume flow parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Unit choose list	Country-specific: NI/h Sft³/min
Corrected volume unit	Select corrected volume unit.	Unit choose list	Country-specific: NI Sft³
Density unit	Select density unit. Result The selected unit applies for: Output Simulation process variable Density adjustment (Expert menu)	Unit choose list	Country-specific: • kg/l • lb/ft³
Reference density unit	Select reference density unit.	Unit choose list	Country-dependent • kg/Nl • lb/Sft ³


Parameter	Description	Selection	Factory setting
Temperature unit	Select temperature unit. Result The selected unit applies for: • Electronic temperature parameter (6053) • Maximum value parameter (6051) • Minimum value parameter (6052) • Maximum value parameter (6108) • Minimum value parameter (6109) • Carrier pipe temperature parameter (6027) • Maximum value parameter (6029) • Minimum value parameter (6030) • Reference temperature parameter (1816) • Temperature parameter	Unit choose list	Country-specific: ■ °C ■ °F
Pressure unit	Select process pressure unit. Result The unit is taken from: ■ Pressure value parameter (→ 🖺 82) ■ External pressure parameter (→ 🖺 82) ■ Pressure value	Unit choose list	Country-specific: bar a psi a

10.5.3 Selecting and setting the medium

The **Select medium** wizard submenu contains parameters that must be configured in order to select and set the medium.

Navigation

"Setup" menu \rightarrow Select medium



Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Select medium	-	Select medium type.	LiquidGas	-
Select gas type	The Gas option is selected in the Select medium parameter.	Select measured gas type.	 Air Ammonia NH3 Argon Ar Sulfur hexafluoride SF6 Oxygen O2 Ozone O3 Nitrogen oxide N2O Nitrogen N2 Nitrogen N2 Nitrogen N2 Hydrogen H2 Helium He Hydrogen chloride HCl Hydrogen sulfide H2S Ethylene C2H4 Carbon dioxide CO2 Carbon monoxide CO Chlorine Cl2 Butane C4H10 Propane C3H8 Propylene C3H6 Ethane C2H6 Others 	
Reference sound velocity	In the Select gas type parameter, the Others option is selected.	Enter sound velocity of gas at 0 °C (32 °F).	1 to 99 999.9999 m/s	_
Temperature coefficient sound velocity	The Others option is selected in the Select gas type parameter.	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	0 (m/s)/K
Pressure compensation	-	Select pressure compensation type.	 Off Fixed value External value Current input 1* 	-
Pressure value	The Fixed value option or the Current input 1n option is selected in the Pressure compensation parameter.	Enter process pressure to be used for pressure correction.	Positive floating- point number	-
External pressure	The Fixed value option or the Current input 1n option is selected in the Pressure compensation parameter.	Shows the external process pressure value.	Positive floating- point number	-


^{*} Visibility depends on order options or device settings

10.5.4 Configuring the analog inputs

The **Analog inputs** submenu guides the user systematically to the individual **Analog input 1 to n** submenu. From here you get to the parameters of the individual analog input.

Navigation

"Setup" menu \rightarrow Analog inputs



Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Block tag	Unique name of the measuring device.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /).	ANALOG_INPUT_1 4_Serial number
Channel	Use this function to select the process variable.	Mass flow Volume flow Corrected volume flow Target mass flow Density Reference density Concentration Temperature Carrier pipe temperature Carrier pipe temperature Carrier pipe temperature Oscillation frequency 0 Oscillation amplitude 0 Frequency fluctuation 0 Oscillation damping fluctuation 0 Signal asymmetry Exciter current 0 HBSI Totalizer 1 Totalizer 2 Totalizer 3 Current input 1 Uninitialized	
Process Value Filter Time	Enter the filter time specification for the filtering of the unconverted input value (PV).	Positive floating-point number	-


Visibility depends on order options or device settings

10.5.5 Displaying the I/O configuration

The **I/O** configuration submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu → I/O configuration



Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry
I/O module terminal numbers	Shows the terminal numbers used by the I/O module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2)
I/O module information	Shows information of the plugged I/O module.	 Not plugged Invalid Not configurable Configurable Fieldbus
I/O module type	Shows the I/O module type.	 Off Current output* Current input* Status input* Pulse/frequency/switch output*
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	■ No ■ Yes
Conversion code	Enter the code in order to change the I/O configuration.	Positive integer


^{*} Visibility depends on order options or device settings

10.5.6 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation

"Setup" menu \rightarrow Current input



84

0/4 mA value	→ 🖺 85
20 mA value	→ 🖺 85
Current span	→ 🖺 85
Failure mode	→ 🖺 85
Failure value	→ 🖺 85


Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	Not used24-25 (I/O 2)	-
Signal mode	The measuring device is not approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	Passive Active	Active
0/4 mA value	_	Enter 4 mA value.	Signed floating-point number	-
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA 420 mA NAMUR 420 mA US 020 mA 	Country-specific: 420 mA NAMUR 420 mA US
Failure mode	-	Define input behavior in alarm condition.	AlarmLast valid valueDefined value	-
Failure value	In the Failure mode parameter, the Defined value option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	_


10.5.7 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu \rightarrow Status input






Parameter	Description	User interface / Selection / User entry
Terminal number	Shows the terminal numbers used by the status input module.	Not used24-25 (I/O 2)
Assign status input	Select function for the status input.	 Off Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override
Active level	Define input signal level at which the assigned function is triggered.	High Low
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms

10.5.8 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation

"Setup" menu \rightarrow Current output



86

Failure mode	→ 🖺 88
Failure current	→ 🖺 88

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	Not used24-25 (I/O 2)	-
Signal mode	-	Select the signal mode for the current output.	PassiveActive	Active
Assign current output		Select process variable for current output.	Off Mass flow Volume flow Corrected volume flow Target mass flow Density Reference density Concentration Temperature Carrier pipe temperature Carrier pipe temperature Carrier pipe temperature Oscillation frequency 0 Oscillation amplitude 0 Frequency fluctuation 0 Oscillation damping 0 Oscillation damping 0 Oscillation damping fluctuation 0 Signal asymmetry Exciter current 0 HBSI*	
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA NAMUR 420 mA US 420 mA 020 mA Fixed current 	Country-specific: 420 mA NAMUR 420 mA US
0/4 mA value	One of the following options is selected in the Current span parameter (→ 🖺 87): 420 mA NAMUR 420 mA US 420 mA 020 mA	Enter 4 mA value.	Signed floating-point number	Country-specific: 0 kg/h 0 lb/min
20 mA value	One of the following options is selected in the Current span parameter (→ 🖺 87): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Fixed current	The Fixed current option is selected in the Current span parameter (→ 🖺 87).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA
Damping output	A process variable is selected in the Assign current output parameter (→ 🖺 87) and one of the following options is selected in the Current span parameter (→ 🖺 87): • 420 mA NAMUR • 420 mA US • 420 mA • 020 mA	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	-
Failure mode	A process variable is selected in the Assign current output parameter (→ 🖺 87) and one of the following options is selected in the Current span parameter (→ 🖺 87): 420 mA NAMUR 420 mA US 420 mA 020 mA	Define output behavior in alarm condition.	 Min. Max. Last valid value Actual value Defined value 	-
Failure current	The Defined value option is selected in the Failure mode parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA

^{*} Visibility depends on order options or device settings

10.5.9 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Pulse/frequency/switch output




Parameter overview with brief description

Parameter	Description	Selection
Operating mode	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output



Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	-
Terminal number	-	Shows the terminal numbers used by the PFS output module.	Not used24-25 (I/O 2)	-
Signal mode	-	Select the signal mode for the PFS output.	PassiveActive	-
Assign pulse output 1 to n	The Pulse option is selected in the Operating mode parameter parameter.	Select process variable for pulse output.	 Off Mass flow Volume flow Corrected volume flow Target mass flow * Carrier mass flow * 	-
Value per pulse	The Pulse option is selected in the Operating mode parameter (→ 🖺 89) and a process variable is selected in the Assign pulse output parameter (→ 🖺 90).	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	The Pulse option is selected in the Operating mode parameter (→ 🗎 89) and a process variable is selected in the Assign pulse output parameter (→ 🖺 90).	Define time width of the output pulse.	0.05 to 2 000 ms	-
Failure mode	The Pulse option is selected in the Operating mode parameter (→ 🖺 89) and a process variable is selected in the Assign pulse output parameter (→ 🖺 90).	Define output behavior in alarm condition.	Actual valueNo pulses	-
Invert output signal	-	Invert the output signal.	No Yes	-

^{*} Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

► Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 91
Terminal number	→ 🖺 91
Signal mode	→ 🗎 91

Assign frequency output	→ 🖺 92
Minimum frequency value	→ 🖺 92
Maximum frequency value	→ 🖺 92
Measuring value at minimum frequency	→ 🗎 92
Measuring value at maximum frequency	→ 🖺 92
Failure mode	→ 🖺 92
Failure frequency	→ 🖺 93
Invert output signal	→ 🖺 93

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	_
Terminal number	-	Shows the terminal numbers used by the PFS output module.	Not used24-25 (I/O 2)	-
Signal mode	-	Select the signal mode for the PFS output.	PassiveActive	-

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Assign frequency output	The Frequency option is selected in the Operating mode parameter (→ 🖺 89) parameter.	Select process variable for frequency output.	Off Mass flow Volume flow Corrected volume flow Target mass flow * Carrier mass flow * Density Reference density Concentration * Temperature Carrier pipe temperature * Electronic temperature Oscillation frequency 0 Oscillation amplitude 0 Frequency fluctuation 0 Oscillation damping 0 Oscillation damping 0 Oscillation damping fluctuation 0 Signal asymmetry Exciter current 0 HBSI *	
Minimum frequency value	The Frequency option is selected in the Operating mode parameter ($\Rightarrow \implies 89$) and a process variable is selected in the Assign frequency output parameter ($\Rightarrow \implies 92$).	Enter minimum frequency.	0.0 to 10 000.0 Hz	-
Maximum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \triangleq 89$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \triangleq 92$).	Enter maximum frequency.	0.0 to 10 000.0 Hz	-
Measuring value at minimum frequency	The Frequency option is selected in the Operating mode parameter (→ 🖺 89) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \cong 89$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \cong 92$).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The Frequency option is selected in the Operating mode parameter (→ 🖺 89) and a process variable is selected in the Assign frequency output parameter (→ 🖺 92).	Define output behavior in alarm condition.	Actual valueDefined value0 Hz	_

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Failure frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \triangleq 89$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \triangleq 92$).	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	-
Invert output signal	-	Invert the output signal.	NoYes	-

^{*} Visibility depends on order options or device settings

Configuring the switch output

Navigation

"Setup" menu → Pulse/frequency/switch output

► Pulse/frequ 1 to n	ency/switch output	
	Operating mode	→ 🖺 94
	Terminal number	→ 🖺 94
	Signal mode	→ 🖺 94
	Switch output function	→ 🖺 95
	Assign diagnostic behavior	→ 🖺 95
	Assign limit	→ 🖺 95
	Assign flow direction check	→ 🖺 95
	Assign status	→ 🖺 95
	Switch-on value	→ 🖺 95
	Switch-off value	→ 🖺 95
	Switch-on delay	→ 🖺 95
	Switch-off delay	→ 🖺 96
	Failure mode	→ 🖺 96
	Invert output signal	→ 🖺 96

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	-
Terminal number	-	Shows the terminal numbers used by the PFS output module.	Not used24-25 (I/O 2)	-
Signal mode	-	Select the signal mode for the PFS output.	PassiveActive	_

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	Off On Diagnostic behavior Limit Flow direction check Status	-
Assign diagnostic behavior	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. 	Select diagnostic behavior for switch output.	AlarmAlarm or warningWarning	_
Assign limit	 The Switch option is selected in the Operating mode parameter parameter. The Limit option is selected in the Switch output function parameter parameter. 	Select process variable for limit function.	 Mass flow Volume flow Corrected volume flow Target mass flow * Carrier mass flow * Density Reference density Concentration * Temperature Totalizer 1 Totalizer 2 Totalizer 3 Oscillation damping 	
Assign flow direction check	 The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. 	Select process variable for flow direction monitoring.	OffVolume flowMass flowCorrected volume flow	-
Assign status	 The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. 	Select device status for switch output.	 Partially filled pipe detection Low flow cut off Digital output 6 	-
Switch-on value	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Limit option is selected. 	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-off value	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Limit option is selected. 	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 kg/h • 0 lb/min
Switch-on delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-on of status output.	0.0 to 100.0 s	-

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-off of status output.	0.0 to 100.0 s	-
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	-
Invert output signal	-	Invert the output signal.	NoYes	-

Visibility depends on order options or device settings

10.5.10 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu \rightarrow Relay output 1 to n

► RelaisOutput 1 to n	
Switch output function	→ 🗎 97
Assign flow direction check	→ 🖺 97
Assign limit	→ 🖺 97
Assign diagnostic behavior	→ 🖺 97
Assign status	→ 🖺 97
Switch-off value	→ 🖺 97
Switch-on value	→ 🖺 97
Failure mode	→ 🖺 97

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Relay output function	-	Select the function for the relay output.	 Closed Open Diagnostic behavior Limit Flow direction check Digital Output 	-
Terminal number	-	Shows the terminal numbers used by the relay output module.	Not used24-25 (I/O 2)	_
Assign flow direction check	In the Relay output function parameter, the Flow direction check option is selected.	Select process variable for flow direction monitoring.	OffVolume flowMass flowCorrected volume flow	-
Assign limit	The Limit option is selected in the Relay output function parameter parameter.	Select process variable for limit function.	■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Target mass flow ■ Carrier mass flow ■ Density ■ Reference density ■ Concentration ■ Temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Oscillation damping	-
Assign diagnostic behavior	In the Relay output function parameter, the Diagnostic behavior option is selected.	Select diagnostic behavior for switch output.	AlarmAlarm or warningWarning	-
Assign status	In the Relay output function parameter, the Digital Output option is selected.	Select device status for switch output.	Partially filled pipe detectionLow flow cut offDigital output 6	-
Switch-off value	In the Relay output function parameter, the Limit option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: Okg/h Olb/min
Switch-off delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-off of status output.	0.0 to 100.0 s	-
Switch-on value	In the Relay output function parameter, the Limit option is selected.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: Okg/h Olb/min
Switch-on delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-on of status output.	0.0 to 100.0 s	-
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	-

^{*} Visibility depends on order options or device settings

10.5.11 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu \rightarrow Display



Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	Mass flow Volume flow Corrected volume flow Target mass flow Target mass flow Density Reference density Concentration Temperature Carrier pipe temperature Electronic temperature Oscillation frequency 0 Oscillation amplitude 0 Frequency fluctuation 0 Oscillation damping 0 Oscillation damping fluctuation 0 Signal asymmetry Exciter current 0 Totalizer 1 Totalizer 2 Totalizer 3 Current output 1	
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: Okg/h Olb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🖺 99)	-
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: Okg/h Olb/min
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	_
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🖺 99)	_


^{*} Visibility depends on order options or device settings

10.5.12 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	OffMass flowVolume flowCorrected volume flow	-
On value low flow cutoff	A process variable is selected in the Assign process variable parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter ($\rightarrow \implies 100$).	Enter off value for low flow cut off.	0 to 100.0 %	_
Pressure shock suppression	A process variable is selected in the Assign process variable parameter ($\rightarrow \blacksquare$ 100).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	_


100

10.5.13 Configuring the partial filled pipe detection

The **Partial filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

Navigation

"Setup" menu \rightarrow Partially filled pipe detection




Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry
Assign process variable	-	Select process variable for partially filled pipe detection.	OffDensityReference density
Low value partial filled pipe detection	A process variable is selected in the Assign process variable parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number
High value partial filled pipe detection	A process variable is selected in the Assign process variable parameter (→ 🖺 101).	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number
Response time part. filled pipe detect.	A process variable is selected in the Assign process variable parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s

10.6 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.


Navigation to the "Advanced setup" submenu




The number of submenus can vary depending on the device version. Some submenus are not dealt with in the Operating Instructions. These submenus and the parameters they contain are explained in the Special Documentation for the device.

Navigation

"Setup" menu → Advanced setup





10.6.1 Using the parameter to enter the access code

Navigation

"Setup" menu → Advanced setup

Parameter overview with brief description


Parameter	Description	User entry	
Enter access code	Enter access code to disable write protection of parameters.	0 to 9 999	

10.6.2 Calculated values

The **Calculated values** submenu contains parameters for calculating the corrected volume flow.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Calculated values



Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	 Fixed reference density Calculated reference density Reference density by API table 53 External reference density Current input 1* 	-
External reference density	-	Shows external reference density.	Floating point number with sign	-
Fixed reference density	The Fixed reference density option is selected in the Corrected volume flow calculation parameter parameter.	Enter fixed value for reference density.	Positive floating- point number	-
Reference temperature	The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter.	Enter reference temperature for calculating the reference density.	-273.15 to 99999 °C	Country-specific: ■ +20 °C ■ +68 °F
Linear expansion coefficient	The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter.	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	-
Square expansion coefficient	The Calculated reference density option is selected in the Corrected volume flow calculation parameter parameter.	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	-


^{*} Visibility depends on order options or device settings

10.6.3 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment



Parameter	Description	Selection
Installation direction	Set sign of flow direction to match the direction of the arrow on	■ Flow in arrow direction
	the sensor.	 Flow against arrow direction

Zero point adjustment


All measuring devices are calibrated in accordance with state-of-the-art technology. Calibration takes place under reference conditions $\Rightarrow \triangleq 188$. Therefore, a zero point adjustment in the field is generally not required.

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates.
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment \rightarrow Zero point adjustment



Parameter overview with brief description


Parameter	Description	Selection / User interface	Factory setting
Zero point adjustment control	Start zero point adjustment.	CancelBusyZero point adjust failureStart	-
Progress	Shows the progress of the process.	0 to 100 %	-

10.6.4 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n



Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	 Off Volume flow Mass flow Corrected volume flow Target mass flow* Carrier mass flow* 	-
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Select process variable totalizer unit.	Unit choose list	Country-specific: • kg • lb
Totalizer operation mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxminus 106$) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	-
Failure mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxminus 106$) of the Totalizer 1 to n submenu.	Define totalizer behavior in alarm condition.	StopActual valueLast valid value	-

^{*} Visibility depends on order options or device settings

10.6.5 Carrying out additional display configurations

In the ${\bf Display}$ submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display		
	Format display	→ 🖺 108
	Value 1 display	→ 🖺 108
	0% bargraph value 1	→ 🖺 108
	100% bargraph value 1	→ 🖺 108
	Decimal places 1	→ 🖺 108
	Value 2 display	→ 🖺 108
	Decimal places 2	→ 🖺 108
	Value 3 display	→ 🖺 108
	0% bargraph value 3	→ 🖺 109
	100% bargraph value 3	→ 🖺 109
	Decimal places 3	→ 🖺 109
	Value 4 display	→ 🖺 109
	Decimal places 4	→ 🖺 109
	Display language	→ 🖺 109
	Display interval	→ 🖺 109
	Display damping	→ 🖺 109
	Header	→ 🖺 109
	Header text	→ 🖺 109
	Separator	→ 🖺 110
	Backlight	→ 🗎 110

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	-
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	Mass flow Volume flow Corrected volume flow Target mass flow Density Reference density Concentration Temperature Carrier pipe temperature Electronic temperature Oscillation frequency 0 Oscillation amplitude 0 Frequency fluctuation 0 Oscillation damping 0 Oscillation damping 0 Signal asymmetry Exciter current 0 Totalizer 1 Totalizer 2 Totalizer 3 Current output 1	
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: Okg/h Olb/min
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	X X.X X.XX X.XXX X.XXX	-
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter	-
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXX	-
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🖺 99)	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: Okg/h Olb/min
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	-
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	X X.X X.XX X.XXX X.XXX	-
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 🖺 99)	-
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	XX.XX.XXX.XXXX.XXX	-
Display language	A local display is provided.	Set display language.	English Deutsch* Français* Español* Italiano* Nederlands* Portuguesa* Polski* pycский язык (Russian)* Svenska* Türkçe* 中文 (Chinese)* 日本語 (Japanese)* ・ 한국어 (Korean)* Bahasa Indonesia* tiếng Việt (Vietnamese)* cěština (Czech)*	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	-
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	-
Header	A local display is provided.	Select header contents on local display.	Device tagFree text	-
Header text	In the Header parameter, the Free text option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	-

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	. (point), (comma)	. (point)
Backlight	One of the following conditions is met: Order code for "Display; operation", option F "4-line, illum.; touch control" Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN" Order code for "Display; operation", option O "Separate 4-line display, illum.; 10m/30ft cable; touch control"	Switch the local display backlight on and off.	■ Disable ■ Enable	_


^{*} Visibility depends on order options or device settings

10.6.6 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow WLAN Settings



Parameter overview with brief description

Parameter	Prerequisite	Description	User entry / Selection	Factory setting
WLAN IP address	-	Enter IP address of the device WLAN interface.	4 octet: 0 to 255 (in the particular octet)	-
Security type	_	Select the security type of the WLAN interface.	UnsecuredWPA2-PSK	-

Parameter	Prerequisite	Description	User entry / Selection	Factory setting
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters). The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user-defined name.	Device tagUser-defined	-
SSID name	 The User-defined option is selected in the Assign SSID name parameter. The WLAN access point option is selected in the WLAN mode parameter. 	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Promass_300_A 802000)
Apply changes	-	Use changed WLAN settings.	CancelOk	-


10.6.7 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup** submenu.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Configuration backup



Parameter overview with brief description

Parameter	Description	User interface / Selection
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Last backup	Shows when the last data backup was saved to embedded HistoROM.	Days (d), hours (h), minutes (m) and seconds (s)

Parameter	Description	User interface / Selection
Configuration management	Select action for managing the device data in the embedded HistoROM.	 Cancel Execute backup Restore Compare Clear backup data
Backup state	Shows the current status of data saving or restoring.	 None Backup in progress Restoring in progress Delete in progress Compare in progress Restoring failed Backup failed
Comparison result	Comparison of current device data with embedded HistoROM.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible

Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.

- HistoROM backup
 A HistoROM is a "non-volatile" device memory in the form of an EEPROM.
- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.6.8 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration




► Reset access code	→ 🖺 113
Device reset	→ 🖺 114

Using the parameter to define the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code




Parameter overview with brief description

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the entered access code.	Max. 16-digit character string comprising numbers, letters and special characters

Using the parameter to reset the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Reset access code



Parameter overview with brief description

Parameter	Description	User interface / User entry
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)
Reset access code	Reset access code to factory settings. For a reset code, contact your Endress+Hauser service organization.	Character string comprising numbers, letters and special characters
	The reset code can only be entered via: Web browser DeviceCare, FieldCare (via service interface CDI-RJ45) Fieldbus	

Using the parameter to reset the device

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

Parameter overview with brief description

Parameter	Description	Selection
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	 Cancel To delivery settings Restart device Restore S-DAT backup ENP restart

10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu \rightarrow Simulation

► Simulation		
	Assign simulation process variable	→ 🖺 115
	Process variable value	→ 🖺 115
	Status input simulation	→ 🗎 115
	Input signal level	→ 🖺 115
	Current input 1 to n simulation	→ 🖺 115
	Value current input 1 to n	→ 🖺 115
	Current output 1 to n simulation	→ 🖺 115
	Value current output 1 to n	→ 🖺 115
	Frequency output simulation 1 to n	→ 🖺 115
	Frequency value 1 to n	→ 🖺 115
	Pulse output simulation 1 to n	→ 🖺 115
	Pulse value 1 to n	→ 🖺 116
	Switch output simulation 1 to n	→ 🖺 116

Switch status 1 to n	→ 🖺 116
Relay output 1 to n simulation	→ 🖺 116
Switch status 1 to n	→ 🖺 116
Device alarm simulation	→ 🖺 116
Diagnostic event category	→ 🖺 116
Diagnostic event simulation	→ 🗎 116

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	 Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature Target mass flow * Carrier mass flow * Concentration *
Process variable value	A process variable is selected in the Assign simulation process variable parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	Enter the simulation value for the selected process variable.	Depends on the process variable selected
Status input simulation	-	Switch simulation of the status input on and off.	• Off • On
Input signal level	In the Status input simulation parameter, the On option is selected.	Select the signal level for the simulation of the status input.	■ High ■ Low
Current input simulation	-	Switch simulation of the current input on and off.	Off On
Value current input	In the Current input 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	0 to 22.5 mA
Current output simulation	-	Switch the simulation of the current output on and off.	• Off • On
Value current output	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA
Frequency output simulation	In the Operating mode parameter, the Frequency option is selected.	Switch the simulation of the frequency output on and off.	• Off • On
Frequency value	In the Frequency output simulation 1 to n parameter, the On option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz
Pulse output simulation	In the Operating mode parameter, the Pulse option is selected.	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (> \equiv 90) defines the pulse width of the pulses output.	OffFixed valueDown-counting value

Parameter	Prerequisite	Description	Selection / User entry / User interface
Pulse value	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535
Switch output simulation	In the Operating mode parameter, the Switch option is selected.	Switch the simulation of the switch output on and off.	• Off • On
Switch status	-	Select the status of the status output for the simulation.	OpenClosed
Relay output simulation	-	Switch simulation of the relay output on and off.	Off On
Switch status	The On option is selected in the Switch output simulation 1 to n parameter parameter.	Select status of the relay output for the simulation.	■ Open ■ Closed
Pulse output simulation	-	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	OffFixed valueDown-counting value
Pulse value	In the Pulse output simulation parameter, the Down-counting value option is selected.	Set and switch off the pulse output simulation.	0 to 65 535
Device alarm simulation	-	Switch the device alarm on and off.	Off On
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	Off Diagnostic event picklist (depends on the category selected)
Logging interval	-	Define the logging interval tlog for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s

Visibility depends on order options or device settings

10.8 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code →

 ☐ 116

10.8.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via local display

- 1. Navigate to the **Define access code** parameter ($\Rightarrow \triangleq 113$).
- 2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the **Confirm access code** parameter ($\rightarrow \implies 113$) to confirm the code.
 - ► The 🗈-symbol appears in front of all write-protected parameters.


The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.



- If parameter write protection is activated via an access code, it can also only be deactivated via this access code → 56.

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the Web browser

- 1. Navigate to the **Define access code** parameter ($\rightarrow \equiv 113$).
- 2. Define a max. 16-digit numeric code as an access code.
- 3. Enter the access code again in the **Confirm access code** parameter ($\rightarrow \triangleq 113$) to confirm the code.
 - ► The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
- If parameter write protection is activated via an access code, it can also only be deactivated via this access code $\rightarrow \triangleq 56$.
 - The user role with which the user is currently logged on via Web browser is indicated by the Access status parameter. Navigation path: Operation → Access status

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus


- For a reset code, contact your Endress+Hauser service organization.
- 1. Navigate to the **Reset access code** parameter ($\rightarrow \triangleq 113$).
- 2. Enter the reset code.
 - The access code has been reset to the factory setting **0000**. It can be redefined $\rightarrow \boxminus 117$.

10.8.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via FOUNDATION Fieldbus



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

☐ In the **Locking status** parameter the **Hardware locked** option is displayed \Rightarrow ☐ 119. In addition, on the local display the a-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0029425

- 2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.

10.8.3 Write protection via block operation

Locking via block operation:

- Block: **DISPLAY (TRDDISP)**; parameter: **Define access code**
- Block: **EXPERT CONFIG (TRDEXP)**; parameter: **Enter access code**

11 **Operation**

11.1 Reading the device locking status

Device active write protection: Locking status parameter

Operation → Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status parameter applies $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) .
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language



Petailed information:

- To configure the operating language → 🖺 76
- For information on the operating languages supported by the measuring device → 🖺 197

11.3 Configuring the display

Detailed information:


- On the advanced settings for the local display $\rightarrow \implies 107$

11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu → Measured values



11.4.1 "Measured variables" submenu

The **Measured variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Measured variables

► Measured variable	es	
	Mass flow	→ 🖺 120
	Volume flow	→ 🖺 120
	Corrected volume flow	→ 🖺 120
[]	Density	→ 🖺 120
	Reference density	→ 🖺 121
[*	Temperature	→ 🖺 121
[1	Pressure value	→ 🖺 121
(Concentration	→ 🖺 121
	Target mass flow	→ 🖺 121
[1	Carrier mass flow	→ 🗎 121

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Mass flow	-	Displays the mass flow currently measured.	Signed floating-point number
		Dependency The unit is taken from the Mass flow unit parameter (→ 🖺 79).	
Volume flow	_	Displays the volume flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Volume flow unit parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
Corrected volume flow	-	Displays the corrected volume flow currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Corrected volume flow unit parameter (→ 🖺 79).	
Density	-	Shows the density currently measured. Dependency The unit is taken from the Density unit parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \)$.	Signed floating-point number

120

Parameter	Prerequisite	Description	User interface
Reference density	-	Displays the reference density currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Reference density unit parameter (→ 12 79).	
Temperature	-	Shows the medium temperature currently measured.	Signed floating-point number
		Dependency The unit is taken from the Temperature unit parameter $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
Pressure value	-	Displays either a fixed or external pressure value.	Signed floating-point number
		Dependency The unit is taken from the Pressure unit parameter (→ 🖺 80).	
Concentration	For the following order code: Order code for "Application package",	Displays the concentration currently calculated.	Signed floating-point number
	option ED "Concentration" The software options currently enabled are displayed in the Software option overview parameter.	Dependency The unit is taken from the Concentration unit parameter.	
Target mass flow	With the following conditions: Order code for "Application package", option ED "Concentration"	Displays the mass flow currently measured for the target medium.	Signed floating-point number
	The software options currently enabled are displayed in the Software option overview parameter.	Dependency The unit is taken from the Mass flow unit parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
Carrier mass flow	With the following conditions: Order code for "Application package",	Displays the mass flow currently measured for the carrier medium.	Signed floating-point number
	option ED "Concentration"	Dependency	
	The software options currently enabled are displayed in the Software option overview parameter.	The unit is taken from the Mass flow unit parameter ($\rightarrow \implies 79$).	

11.4.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer



Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	A process variable is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu.	Displays the current totalizer counter value.	Signed floating-point number
Totalizer overflow 1 to n	A process variable is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu.	Displays the current totalizer overflow.	Integer with sign

11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values




Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Current input 1 to n



Parameter overview with brief description

Parameter	Description	User interface
Measured values	Displays the current input value.	Signed floating-point number
Measured current	Displays the current value of the current input.	0 to 22.5 mA

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Status input 1 to n



Parameter overview with brief description


Parameter	Description	User interface
Value status input	Shows the current input signal level.	■ High ■ Low

11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values




Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu → Measured values → Output values → Value current output 1 to n



Parameter overview with brief description


Parameter	Description	User interface
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Pulse/frequency/switch output 1 to n



Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Output frequency	In the Operating mode parameter, the Frequency option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output	The Pulse option is selected in the Operating mode parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch status	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	■ Open ■ Closed

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Relay output 1 to n



Parameter overview with brief description

Parameter	Description	User interface
Switch status	Shows the current relay switch status.	OpenClosed
Switch cycles	Shows number of all performed switch cycles.	Positive integer
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu (\rightarrow $\stackrel{\triangle}{=}$ 77)
- Advanced settings using the Advanced setup submenu (→ 🗎 102)


11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu → Totalizer handling



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter (→ 🖺 106) of the Totalizer 1 to n submenu.	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize Hold 	_
Preset value 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxminus 106$) of the Totalizer 1 to n submenu.	Specify start value for totalizer. Dependency The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 106).	Signed floating-point number	Country-specific: 0 kg 0 lb
Reset all totalizers	-	Reset all totalizers to 0 and start.	CancelReset + totalize	-

11.6.1 Function scope of the "Control Totalizer" parameter

Options	Description	
Totalize	The totalizer is started or continues running.	
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.	
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.	
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.	
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.	
Hold	Totalizing is stopped.	

11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description	
Cancel	No action is executed and the user exits the parameter.	
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.	

11.7 Showing data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.




Data logging is also available via:

- Web browser

Function range

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



■ 27 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

 $\begin{array}{l} \textbf{Navigation} \\ \text{"Diagnostics" menu} \rightarrow \text{Data logging} \end{array}$

▶ Data logging	
Assign channel 1	→ 🗎 128
Assign channel 2	→ 🗎 128
Assign channel 3	→ 🗎 128
Assign channel 4	→ 🖺 128
Logging interval	→ 🖺 128
Clear logging data	→ 🖺 128
Data logging	→ 🖺 128
Logging delay	→ 🖺 128
Data logging control	→ 🖺 128
Data logging status	→ 🖺 129
Entire logging duration	→ 🖺 129
▶ Display channel 1	
▶ Display channel 2	
▶ Display channel 3	
▶ Display channel 4	

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	Off Mass flow Volume flow Corrected volume flow Target mass flow* Carrier mass flow* Density Reference density Concentration* Temperature Carrier pipe temperature Oscillation frequency 0 Frequency fluctuation 0 Oscillation amplitude* Oscillation damping fluctuation 0 Signal asymmetry Exciter current 0 Current output 1 Current output 2 Current output 3 Current output 4 HBSI*
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🖺 128)
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🖺 128)
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Picklist, see Assign channel 1 parameter (→ 🖺 128)
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 999.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data
Data logging	-	Select the data logging method.	OverwritingNot overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	NoneDelete + startStop

Parameter	Prerequisite	Description	Selection / User entry / User interface
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	DoneDelay activeActiveStopped
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating-point number

^{*} Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Solution
Local display dark and no output signals	Supply voltage does not match the value indicated on the nameplate.	Apply the correct supply voltage → 🖺 35.
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective. Main electronics module is defective.	Order spare part → 🖺 172.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🖺 172.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures → 🖺 142
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press □ + ⊕ for 2 s ("home position"). 2. Press □. 3. Set the desired language in the Display language parameter (→ 圖 109).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part → 172.

For output signals

Error	Possible causes	Solution
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🖺 172.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access


Error	Possible causes	Solution
No write access to parameters	Hardware write protection enabled	Set the write protection switch on main electronics module to the OFF position $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
No write access to parameters	Current user role has limited access authorization	1. Check user role → 🖺 56. 2. Enter correct customer-specific access code → 🖺 56.
No connection via FOUNDATION Fieldbus	Device plug connected incorrectly	Check the pin assignment of the connector .
Not connecting to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary → 🖺 63.
	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) → 🖺 59→ 🗎 59. 2. Check the network settings with the IT manager.
Not connecting to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 → 🖺 59 → 🖺 59
Not connecting to Web server	Incorrect WLAN access data	 Check WLAN network status. Log on to the device again using WLAN access data. Verify that WLAN is enabled on the measuring device and operating device →
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	 Check if WLAN reception is present: LED on display module is lit blue Check if WLAN connection is enabled: LED on display module flashes blue Switch on instrument function.
Network connection not present or unstable	WLAN network is weak.	 Operating device is outside of reception range: Check network status on operating device. To improve network performance, use an external WLAN antenna.
	Parallel WLAN and Ethernet communication	Check network settings.Temporarily enable only the WLAN as an interface.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	Check cable connection and power supply. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	1. Use the correct Web browser version → 🗎 58. 2. Clear the Web browser cache and restart the Web browser.
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	JavaScript not enabledJavaScript cannot be enabled	Enable JavaScript. Enter http://XXX.XXX.X.XXX/basic.html as the IP address.

Error	Possible causes	Solution
Operation with FieldCare or DeviceCare via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter

Different LEDs in the transmitter provide information on the device status.



A0029629


- Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

LED		Color	Meaning
1	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.
2	Device status (normal	Red	Problem
operation)		Flashing red	Warning
2 Device status (during start-up)		Flashes red slowly	If > 30 seconds: problem with the boot loader.
		Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	White	Communication active.
5	Service interface (CDI)	Yellow	Connection established.
		Flashing yellow	Communication active.
		Off	No connection.

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

 - Via submenus \rightarrow 🗎 164

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning		
F	Failure A device error has occurred. The measured value is no longer valid.		
С	Function check The device is in service mode (e.g. during a simulation).		
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)		
М	Maintenance required Maintenance is required. The measured value remains valid.		

Diagnostic behavior

Symbol	Meaning	
*	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. 	
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.	

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Key	Meaning	
(+)	Plus key In a menu, submenu Opens the message about remedy information.	
E	Enter key In a menu, submenu Opens the operating menu.	

12.3.2 Calling up remedial measures



Δ0029431-FN

- 28 Message about remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures
- 1. The user is in the diagnostic message.

Press ± (① symbol).

- The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \Box .
 - ► The message about the remedial measures opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

12.4 Diagnostic information in the Web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedy information with Service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

 - Via submenu → 🖺 164

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning		
8	Failure A device error has occurred. The measured value is no longer valid.		
W	Function check The device is in service mode (e.g. during a simulation).		
<u>^</u>	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)		
&	Maintenance required Maintenance is required. The measured value is still valid.		

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- l Status area with status signal→ 🖺 133
- 2 Diagnostic information → 🖺 134
- 3 Remedy information with Service ID
- In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:
 - Via parameter →

 163
 - Via submenu → 🖺 164

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ► A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior



A0014048-EN

■ 29 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description	
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.	
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.	
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (Event list submenu) and is not displayed in alternation with the operational display.	
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.	

12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic event category** submenu.

Expert → Communication → Diagnostic event category

Available status signals

Configuration as per FOUNDATION Fieldbus Specification (FF912), in accordance with NAMUR NE107.

Symbol	Meaning	
Failure A device error is present. The measured value is no longer valid.		
C	Function check The device is in service mode (e.g. during a simulation).	

Symbol	Meaning		
S	Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)		
A0013957	Maintenance required Maintenance is required. The measured value is still valid.		

Enabling the configuration of the diagnostic information according to FF912

For compatibility reasons, the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912 is not enabled when the device is delivered from the factory.

Enabling the configuration of the diagnostic information according to FOUNDATION Fieldbus Specification FF912

- 1. Open the Resource block.
- 2. In **Feature Selection** parameter, select **Multi-bit Alarm (Bit-Alarm) Support** option.
 - The diagnostic information can be configured according to FOUNDATION Fieldbus Specification FF912.

Grouping the diagnostic information

Diagnostic information is assigned to different groups. The groups differ depending on the weighting (severity) of the diagnostic event:

- Highest weighting
- High weighting
- Low weighting

Assignment of the diagnostic information (factory setting)

The assignment of the diagnostic information ex-works is indicated in the following tables.

Some diagnostic information can be assigned individually, irrespective of their range $\rightarrow \implies 141$.

ho Overview and description of all diagnostic information ho 🗎 142

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Highest	Failure (F)	Sensor	F000 to 199
		Electronics	F200 to 399
		Configuration	F400 to 700
		Process	F800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
High	Function check (C)	Sensor	C000 to 199
		Electronics	C200 to 399


Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
		Configuration	C400 to 700
		Process	C800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Out of specification (S)	Sensor	S000 to 199
		Electronics	S200 to 399
		Configuration	S400 to 700
		Process	S800 to 999

Weighting	Status signal (factory setting)	Allocation	Diagnostic information range
Low	Maintenance required (M)	Sensor	M000 to 199
		Electronics	M200 to 399
		Configuration	M400 to 700
		Process	M800 to 999

Changing the assignment of the diagnostic information

The individual ranges of the diagnostic information can be assigned to another status signal. This is done by changing the bit in the associated parameter. The bit change always applies for the entire range of the diagnostic information.



Each status signal has a parameter in the Resource Block in which it is possible to define the diagnostic event for which the status signal is transmitted:

- Failure (F): **FD_FAIL_MAP** parameter
- Function check (C): **FD_CHECK_MAP** parameter
- Out of specification (S): **FD_OFFSPEC_MAP** parameter
- Maintenance required (M): **FD_MAINT_MAP** parameter

Structure and assignment of the parameters for the status signals (factory setting)

Weighting	Allocation	Bit	FD_ FAIL_ MAP	FD_ CHECK_ MAP	FD_ OFFSPEC_ MAP	FD_ MAINT_ MAP
Highest	Sensor	31	1	0	0	0
	Electronics	30	1	0	0	0
	Configuration	29	1	0	0	0
	Process	28	1	0	0	0
High	Sensor	27	0	1	0	0
	Electronics	26	0	1	0	0
	Configuration	25	0	1	0	0
	Process	24	0	1	0	0
Low	Sensor	23	0	0	1	0
	Electronics	22	0	0	1	0
	Configuration	21	0	0	1	0

Weighting	Allocation	Bit	FD_ FAIL_ MAP	FD_ CHECK_ MAP	FD_ OFFSPEC_ MAP	FD_ MAINT_ MAP
	Process	20	0	0	1	0
Low	Sensor	19	0	0	0	1
	Electronics	18	0	0	0	1
	Configuration	17	0	0	0	1
	Process	16	0	0	0	1
Configurable range → 🗎 141		15 to 1	0	0	0	0
Reserved (Fieldbus Foundat	Reserved (Fieldbus Foundation)		0	0	0	0

Changing the status signal for a range of diagnostic information

Example: The status signal for the diagnostic information for electronics with the "Highest" weighting is to be changed from failure (F) to function check (C).

- 1. Set the Resource Block to the **OOS** block mode.
- 2. Open the **FD FAIL MAP** parameter in the Resource Block.
- 3. Change **Bit 30** to **0** in the parameter.
- 4. Open the **FD_CHECK_MAP** parameter in the Resource Block.
- 5. Change **Bit 26** to **1** in the parameter.
 - If a diagnostic event occurs for electronics with the "Highest weighting", the diagnostic information to this effect is displayed with the function check (C) status signal.
- 6. Set the Resource Block to the **AUTO** block mode.

NOTICE

No status signal is assigned to an area of diagnostic information.

If a diagnostic event occurs in this area, no status signal is transmitted to the control system.

- ▶ If you are changing the parameters, make sure that a status signal is assigned to all areas.
- If FieldCare is used, the status signal is enabled and disabled using the check box of the particular parameter.

Assigning diagnostic information individually to a status signal

Some diagnostic information can be individually assigned to a status signal, irrespective of their original range.

Assigning diagnostic information individually to a status signal via FieldCare.

- 1. In the FieldCare navigation window: **Expert** → **Communication** → **Field diagnostics** → **Alarm detection enable**
- 2. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.
- 3. Press Enter to confirm.
- 4. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 2).
- 5. Press Enter to confirm.
 - ► The diagnostic event of the selected diagnostic information is recorded.

- 6. In the FieldCare navigation window: **Expert** → **Communication** → **Field diagnostics** → **Alarm broadcast enable**
- 7. Select the desired diagnostic information from one of the fields **Configurable Area Bits 1** to **Configurable Area Bits 15**.
- 8. Press Enter to confirm.
- 9. When selecting the desired status signal (e.g. Offspec Map), also select the **Configurable Area Bit 1** to **Configurable Area Bit 15** that was assigned previously to the diagnostic information (step 7).
- 10. Press Enter to confirm.
 - The selected diagnostic information is transmitted over the bus when a diagnostic event to this effect occurs.
- A change in the status signal does not affect diagnostic information that already exists. The new status signal is only assigned if this error occurs again after the status signal has changed.

Transmitting the diagnostic information over the bus

Prioritizing diagnostic information for transmission over the bus

Diagnostic information is only transmitted over the bus if its priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Diagnostic information with priority 0 (factory setting) is ignored.

It is possible to change the priority individually for the different status signals. The following parameters of the Resource Block are used for this purpose:

- FD FAIL PRI
- FD CHECK PRI
- FD OFFSPEC PRI
- FD_MAINT_PRI

Suppressing certain diagnostic information

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare Expert \rightarrow Communication \rightarrow Field diagnostics \rightarrow Alarm broadcast enable. The mask is a negative selection mask, i.e. if a field is selected the associated diagnostic information is not transmitted over the bus.

12.7 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
 - All of the measured variables affected in the entire Promass instrument family are always listed under "Measured variables affected". The measured variables available for the device in question depend on the device version. When assigning the measured variables to the device functions, for example to the individual outputs, all of the measured variables available for the device version in question are available for selection.
- In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information $\rightarrow \implies 138$

12.7.1 Diagnostic of sensor

	Diagnostic i	information	Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
022	Temperature sensor defective		Check or replace sensor	■ Empty pipe detection	
	Measured variable status		electronic module (ISEM) 2. If available: Check connection	optionLow flow cut off option	
	Quality	Bad	cable between sensor and transmitter 3. Replace sensor	 Switch output status option 	
	Quality substatus	Sensor failure		 Pressure option 	
	Status signal [from the factory] 1)	F			
	Diagnostic behavior	Alarm			

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
046	Sensor limit exceeded	or limit exceeded		Empty pipe detection
	Measured variable status [from the factory] 1)		2. Check process condition	optionLow flow cut off option
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		Pressure option
	Status signal [from the factory] 2)	s		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
062	Sensor connection faulty		1. Check or replace sensor	■ Empty pipe detection
	Measured variable status		electronic module (ISEM) 2. If available: Check connection	optionLow flow cut off option
	Quality	Bad	cable between sensor and	 Switch output status option
	Quality substatus	transmitter tatus Sensor failure 3. Replace sensor		 Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
063	Exciter current faulty		1. Check or replace sensor	■ Empty pipe detection
	Measured variable status		electronic module (ISEM) 2. If available: Check connection	option • Low flow cut off option
	Quality	Bad	cable between sensor and transmitter 3. Replace sensor	_
	Quality substatus	Sensor failure		
	. 1)			
	Status signal [from the factory] 1)	S		
	Diagnostic behavior	Alarm		

Status signal can be changed. 1)

	Diagnostic :	information	Remedy instructions	Influenced measured
No.	Short text			variables
082			Check module connections Contact service	■ Empty pipe detection
				option Low flow cut off option
	Quality	Bad		• Switch output status option
	Quality substatus	Sensor failure		• Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
083			1. Restart device	■ Empty pipe detection
	Measured variable status		2. Restore HistoROM S-DAT backup ('Device reset' parameter)	option • Low flow cut off option
	Quality	Bad	3. Replace HistoROM S-DAT	 Switch output status option
	Quality substatus	Sensor failure		• Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic :	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
140	Sensor signal asymmetrical		1. Check or replace sensor	■ Empty pipe detection
	Measured variable status [from	the factory] ¹⁾	electronic module (ISEM) 2. If available: Check connection	option • Low flow cut off option
	Quality	Good	cable between sensor and transmitter	 Switch output status option
	Quality substatus	Non specific	3. Replace sensor	• Pressure option
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Alarm		

- Quality can be changed. This causes the overall status of the measured variable to change. Status signal can be changed. 1)
- 2) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
144	Measuring error too high		Check or change sensor	■ Empty pipe detection
	Measured variable status [from th	the factory] ¹⁾	2. Check process conditions	 option Low flow cut off option Switch output status option Pressure option
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 2)	F		
	Diagnostic behavior [from the	Alarm		
	factory] 3)	Thum		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

12.7.2 Diagnostic of electronic

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
201			Restart device Contact service	Empty pipe detection option
	Quality	Bad		 Low flow cut off option Switch output status option Pressure option
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
242	Software incompatible		Check software Flash or change main electronics	Empty pipe detection ontion
	Measured variable status		module module	optionLow flow cut off optionSwitch output status
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Device failure		
	1)			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic :	information	Remedy instructions	Influenced measured
No.	Short text			variables
252	Modules incompatible		Check electronic modules	■ Empty pipe detection
	Measured variable status		2. Change electronic modules	option Low flow cut off option Switch output status option Pressure option
	Quality	Bad		
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
262	Sensor electronic connection fault	у	Check or replace connection	■ Empty pipe detection
	Measured variable status		cable between sensor electronic module (ISEM) and main	option Low flow cut off option
	Quality	Bad	electronics 2. Check or replace ISEM or main electronics	• Pressure option
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
270	Main electronic failure		Change main electronic module	■ Empty pipe detection
	Measured variable status			option • Low flow cut off option
	Quality	Bad		 Switch output status option
	Quality substatus	Device failure		 Pressure option
	(2)			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
271	Main electronic failure		Restart device	■ Empty pipe detection
	Measured variable status		2. Change main electronic module	 option Low flow cut off option Switch output status option
	Quality	Bad		
	Quality substatus	Device failure		• Pressure option
	1)			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured variables
No.	SI	nort text		variables
272	Main electronic failure		Restart device	■ Empty pipe detection
	Measured variable status		2. Contact service	option • Low flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
273	Main electronic failure		Change electronic	■ Empty pipe detection
	Measured variable status			option Low flow cut off option
	Quality	Bad		Switch output status option
	Quality substatus	Device failure		■ Pressure option
	0			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
275	I/O module 1 to n defective		Change I/O module	■ Empty pipe detection
	Measured variable status			option Low flow cut off option
	Quality	Bad		 Switch output status option
	Quality substatus	Device failure		 Pressure option
	C	-		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
276	I/O module 1 to n faulty		Restart device	■ Empty pipe detection
	Measured variable status		2. Change I/O module	option • Low flow cut off option
	Quality	Uncertain		Switch output status optionPressure option
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
276	I/O module 1 to n faulty		1. Restart device	■ Empty pipe detection
	Measured variable status		2. Change I/O module option • Low flow o	optionLow flow cut off option
	Quality	Bad		• Switch output status option
	Quality substatus	Device failure		• Pressure option
	Status signal [from the factory] 1)	F		
	Status signal [Hom the factory]	1.		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
283	Memory content		1. Reset device	Empty pipe detection
	Measured variable status		2. Contact service option Low flow cu	optionLow flow cut off option
	Quality	Bad		• Switch output status option
	Quality substatus	Device failure		• Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
302	Device verification active		Device verification active, please	■ Empty pipe detection
	Measured variable status		wait.	option • Low flow cut off option
	Quality	Bad		 Switch output status option
	Quality substatus	Device failure		• Pressure option
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
311	Electronic failure		1. Do not reset device	■ Empty pipe detection
	Measured variable status		2. Contact service	option • Low flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Device failure		
	1)			
	Status signal [from the factory] 1)	M		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
332	Writing in embedded HistoROM fa	ailed	Replace user interface board	■ Empty pipe detection
	Measured variable status		Ex d/XP: replace transmitter	option • Low flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Device failure		
	Ctatura si anna 1 (furuma tha a faratanna 1 1)	F		
	Status signal [from the factory] 1)	ř .		
	Diagnostic behavior	Alarm		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
361	I/O module 1 to n faulty		Restart device	■ Empty pipe detection
	Measured variable status		Check electronic modules Change I/O Modul or main	option Low flow cut off option
	Quality	Bad	electronics	• Switch output status option
	Quality substatus	Device failure		Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
372	Sensor electronic (ISEM) faulty		1. Restart device	■ Empty pipe detection
	Measured variable status		2. Check if failure recurs3. Replace sensor electronic module	 option Low flow cut off option Switch output status option Pressure option
	Quality	Bad	(ISEM)	
	Quality substatus	Device failure		
	2			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
373	Sensor electronic (ISEM) faulty		Transfer data or reset device	■ Empty pipe detection
	Measured variable status		2. Contact service	option • Low flow cut off option
	Quality	Bad		 Switch output status option
	Quality substatus	Device failure		 Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
374	Sensor electronic (ISEM) faulty		1. Restart device	■ Empty pipe detection
	Measured variable status [from the	the factory] ¹⁾	2. Check if failure recurs3. Replace sensor electronic module	option • Low flow cut off option
	Quality	Good	(ISEM)	• Switch output status option
	Quality substatus	Non specific		• Pressure option
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) 3) Status signal can be changed.
- Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
375	I/O- 1 to n communication failed		1. Restart device	■ Empty pipe detection
	Measured variable status		1	option • Low flow cut off option
	Quality	Bad	electronic modules	Switch output status optionPressure option
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
382	Data storage		1. Insert T-DAT	 Empty pipe detection option Low flow cut off option Pressure option
	Measured variable status		2. Replace T-DAT	
	Quality	Bad		
	Quality substatus	Device failure		
	C+++	F		
	Status signal [from the factory] 1)	r		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

No.	Diagnostic information Short text		Remedy instructions	Influenced measured variables
383	· · · · · · · · · · · · · · · · · · ·		Restart device Delete T-DAT via 'Reset device'	Empty pipe detection option
	Quality Quality	Bad	parameter 3. Replace T-DAT	Low flow cut off optionSwitch output status option
	Quality substatus Status signal [from the factory] 1)	Device failure		■ Pressure option
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
387	Embedded HistoROM failed		Contact service organization	■ Empty pipe detection
	Measured variable status			optionLow flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Device failure		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

12.7.3 Diagnostic of configuration

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	ort text		variables
303	I/O 1 to n configuration changed		1. Apply I/O module configuration	-
	Measured variable status		(parameter 'Apply I/O configuration')	
	Quality	Good	Afterwards reload device description and check wiring	
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	M		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
330	Flash file invalid		Update firmware of device	■ Empty pipe detection
	Measured variable status		2. Restart device	option • Low flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Configuration error		
	(0) (1) (1) (1) (1)	26		
	Status signal [from the factory] 1)	M		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	o. Short text			variables
331	1 Firmware update failed	Update firmware of device	■ Empty pipe detection	
	Measured variable status		2. Restart device	option • Low flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Configuration error		
	(Charters as a second 1)	r		
	Status signal [from the factory] 1)	r		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic :	information	Remedy instructions	Influenced measured
No.	Short text			variables
410			1. Check connection	■ Empty pipe detection
	Measured variable status		2. Retry data transfer	 option Low flow cut off option Switch output status option
	Quality	Bad		
	Quality substatus	Configuration error		 Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
412	Processing download		Download active, please wait	■ Empty pipe detection
	Measured variable status			option • Low flow cut off option
	Quality	Uncertain		 Switch output status option
	Quality substatus	Non specific		■ Pressure option
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
431	Trim 1 to n		Carry out trim	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	C	C		
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
437	Configuration incompatible		1. Restart device	■ Empty pipe detection
	Measured variable status		■ Switch or option	optionLow flow cut off option
	Quality	Bad		Switch output status optionPressure option
	Quality substatus	Configuration error		
		_		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured variables
No.	SI	nort text		variables
438	Dataset		1. Check data set file	■ Empty pipe detection
	Measured variable status		Check device configuration Up- and download new	option Low flow cut off option Switch output status
	Quality	Uncertain	configuration	Switch output status optionPressure option
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	M		
	Diagnostic behavior	Warning		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
441	Current output 1 to n		1. Check process	_
	Measured variable status		2. Check current output settings	
	Quality	Good		
	Quality substatus	Non specific		
	. 1)			
	Status signal [from the factory] 1)	S		
	Diagnostic behavior [from the factory] ²⁾	Warning		

- 1)
- Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
442	Frequency output 1 to n		1. Check process	_
	Measured variable status		2. Check frequency output settings	
	Quality	Good		
	Quality substatus	Non specific		
	(2)			
	Status signal [from the factory] 1)	5		
	Diagnostic behavior [from the factory] ²⁾	Warning		

- 1)
- Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
443	Pulse output 1 to n		1. Check process	_
	Measured variable status		2. Check pulse output settings	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	S		
	Diagnostic behavior [from the factory] ²⁾	Warning		

- 1)
- Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
444	Current input 1 to n		1. Check process	-
	Measured variable status		2. Check current input settings	
	Quality	Good		
	Quality substatus	Non specific		
	1)			
	Status signal [from the factory] 1)	S		
	Diagnostic behavior [from the factory] ²⁾	Warning		

- 1)
- Status signal can be changed. Diagnostic behavior can be changed. 2)

	Diagnostic information		Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
453	Flow override		Deactivate flow override		■ Empty pipe detection
	Measured variable status			option • Low flow cut off option • Switch output status option	
	Quality	Good			
	Quality substatus	Non specific		 Pressure option 	
	2				
	Status signal [from the factory] 1)	С			
	Diagnostic behavior	Warning			

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
463	Analog input 1 to n selection inva	lid	1. Check module/channel	■ Empty pipe detection
	Measured variable status		3	option Low flow cut off option
	Quality	Bad	_	 Switch output status option
	Quality substatus	Configuration error		 Pressure option
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
484	Failure mode simulation		Deactivate simulation	■ Empty pipe detection
	Measured variable status			optionLow flow cut off option
	Quality	Bad		Switch output status option
	Quality substatus	Configuration error		■ Pressure option
	1)			
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
485	Measured variable simulation		Deactivate simulation	■ Empty pipe detection
	Measured variable status			option Low flow cut off option
	Quality	Good		Switch output status optionPressure option
	Quality substatus	Non specific		
	2 15 15 11			
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
486	Current input 1 to n simulation		Deactivate simulation	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	SI	nort text		
491	Current output 1 to n simulation		Deactivate simulation	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	1)			
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Warning		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
492	Simulation frequency output 1 to 1	1	Deactivate simulation frequency	_
	Measured variable status		output	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
493	Simulation pulse output 1 to n		Deactivate simulation pulse output	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
494	Switch output simulation 1 to n		Deactivate simulation switch output	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
495	Diagnostic event simulation		Deactivate simulation	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
		_		
	Status signal [from the factory] 1)	C		
	Diagnostic behavior	Warning		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
496	Status input simulation		Deactivate simulation status input	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

No.	Diagnostic information No. Short text		Remedy instructions	Influenced measured variables
497	Simulation block output		Deactivate simulation	-
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
520	I/O 1 to n hardware configuration	invalid	Check I/O hardware configuration Replace wrong I/O module Plug the module of double pulse output on correct slot	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	. 1)			
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

No.	Diagnostic information Short text		Remedy instructions	Influenced measured variables
537	Configuration		Check IP addresses in network	-
	Measured variable status		2. Change IP address	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Warning		

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	Short text			variables
594	Relay output simulation		Deactivate simulation switch output	_
	Measured variable status			
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	С		
	Diagnostic behavior	Warning		

1) Status signal can be changed.

12.7.4 Diagnostic of process

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
803	Current loop 1 to n		1. Check wiring	_
	Measured variable status		2. Change I/O module	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	nort text		variables
830	Sensor temperature too high		Reduce ambient temp. around the	■ Empty pipe detection
	Measured variable status [from	the factory] 1)	sensor housing	option Low flow cut off option Switch output status option Pressure option
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 2)	c		
	Status signal [from the factory]	3		
	Diagnostic behavior [from the factory] ³⁾	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
831	<u> </u>		Increase ambient temp. around the	■ Empty pipe detection
	Measured variable status [from	the factory] ¹⁾	sensor housing	option Low flow cut off option
	Quality	Good		Switch output status optionPressure option
	Quality substatus	Non specific		
	(1)	C		
	Status signal [from the factory] 2)	5		
	Diagnostic behavior [from the factory] ³⁾	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
832	Electronic temperature too high		Reduce ambient temperature	■ Empty pipe detection
	Measured variable status [from t	the factory] ¹⁾		 poption Low flow cut off option Switch output status option Pressure option
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
833	Electronic temperature too low		Increase ambient temperature	■ Empty pipe detection
	Measured variable status [from the factory] 1)	the factory] ¹⁾		option • Low flow cut off option
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		 Pressure option
	. 2)			
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] ³⁾	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
834	Process temperature too high		Reduce process temperature	■ Empty pipe detection
	Measured variable status [from	the factory] ¹⁾		option • Low flow cut off option
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		 Pressure option
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured
No.	SI	hort text		variables
835	Process temperature too low		Increase process temperature	■ Empty pipe detection
	Measured variable status [from the fa	the factory] ¹⁾		option • Low flow cut off option
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		• Pressure option
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic information		Remedy instructions	Influenced measured variables
No.	Short text			
842	Process limit		Low flow cut off active!	■ Empty pipe detection
	Measured variable status		Check low flow cut off configuration	option Low flow cut off option
	Quality	Good		Switch output status optionPressure option
	Quality substatus	Non specific		
	(Charters and a 1 (Second that Second 1)	c		
	Status signal [from the factory] 1)	5		
	Diagnostic behavior	Warning		

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
843	Process limit		Check process conditions	■ Empty pipe detection
	Measured variable status			option • Low flow cut off option
	Quality	Good		Switch output status option
	Quality substatus	Non specific		• Pressure option
	. 1)			
	Status signal [from the factory] 1)	Š		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
862	Partly filled pipe		1. Check for gas in process	-
	Measured variable status [from the factory] 1)		2. Adjust detection limits	
	Quality	Good		
	Quality substatus	Non specific		
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
882	Input signal		Check input configuration	-
	Measured variable status		2. Check external device or process conditions	
	Quality	Bad		
	Quality substatus	Non specific		
	Status signal [from the factory] 1)	F		
	Diagnostic behavior	Alarm		

1) Status signal can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured	
No.	SI	nort text		variables	
910	Tubes not oscillating		1. Check electronic	■ Empty pipe detection	
	Measured variable status		2. Inspect sensor	option • Low flow cut off option	
	Quality	Bad		• Switch output status option	
	Quality substatus	Non specific		• Pressure option	
	Status signal [from the factory] 1)	F			
	Diagnostic behavior	Alarm			

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
912	Medium inhomogeneous		1. Check process cond.	■ Empty pipe detection
	Measured variable status [from	the factory] ¹⁾	2. Increase system pressure option • Low flow cut off opt	option Low flow cut off option
	Quality	Good		• Switch output status option
	Quality substatus	Non specific		 Pressure option
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- Status signal can be changed.
- 2) 3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	hort text		variables
913	Medium unsuitable	2. Check electronic modules or option	Empty pipe detection	
	Measured variable status [from the factory] 1)		optionLow flow cut off option	
	Quality	Good	Switch output st optionPressure option	Switch output status ontion
	Quality substatus	Non specific		*
	Status signal [from the factory] 2)	c		
	Status signal [from the factory]	3		
	Diagnostic behavior [from the factory] ³⁾	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	information	Remedy instructions	Influenced measured
No.	SI	nort text		variables
944	J		 Empty pipe detection option Low flow cut off option 	
	Measured variable status [from the factory] 1)			Heartbeat Monitoring
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		 Pressure option
	Status signal [from the factory] 2)	S		
	3 1			
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.

	Diagnostic i	nformation	Remedy instructions	Influenced measured
No.	SI	nort text		variables
948	Oscillation damping too high		Check process conditions	■ Empty pipe detection
	Measured variable status [from	the factory] ¹⁾		option • Low flow cut off option
	Quality	Good		 Switch output status option
	Quality substatus	Non specific		Pressure option
	2			
	Status signal [from the factory] 2)	S		
	Diagnostic behavior [from the factory] 3)	Warning		

- 1) Quality can be changed. This causes the overall status of the measured variable to change.
- 2) Status signal can be changed.
- 3) Diagnostic behavior can be changed.


12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event:
 - Via local display → 🖺 135
 - Via Web browser → 🖺 136
 - Via "FieldCare" operating tool \rightarrow 🖺 137
 - Via "DeviceCare" operating tool \rightarrow 🖺 137
- Other pending diagnostic events can be displayed in the **Diagnostic list** submenu $\rightarrow \stackrel{ riangle}{=} 164$

Navigation

"Diagnostics" menu





Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.9 Diagnostic messages in the DIAGNOSTIC Transducer Block


- The Actual diagnostics parameter (actual diagnostics) displays the message with the highest priority.
- A list of the active alarms can be viewed via the Diagnostics 1 parameter (diagnostics_1) to Diagnostics 5 (diagnostics 5). If more than 5 messages are pending, the messages with the highest priority are shown on the display.
- You can view the last alarm that is no longer active via the **Previous diagnostics** parameter (**previous diagnostics**).

12.10 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list



30 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display →

 135
- Via Web browser → 🖺 136
- Via "FieldCare" operating tool → 🖺 137


12.11 Event logbook

12.11.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu → **Event logbook** submenu → Event list



A0014008-EN

- 31 Taking the example of the local display
- A maximum of 20 event messages can be displayed in chronological order.
- If the Extended HistoROM application package (order option) is enabled in the device, the event list can contain up to 100 entries.

The event history includes entries for:

- Diagnostic events → 🖺 142
- Information events \rightarrow 🗎 166

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ①: Occurrence of the event
 - 🕒: End of the event
- Information event
 - €: Occurrence of the event
- To call up the measures to rectify a diagnostic event:
 - Via local display →

 135
 - Via Web browser →

 136
 - Via "FieldCare" operating tool \rightarrow 🖺 137

12.11.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

 $Diagnostics \rightarrow Event logbook \rightarrow Filter options$

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Embedded HistoROM deleted
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1184	Display connected
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1256	Display: access status changed
I1278	I/O module reset detected
I1335	Firmware changed
I1361	Web server login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1447	Record application reference data
I1448	Application reference data recorded
I1449	Recording application ref. data failed
I1450	Monitoring off

Info number	Info name
I1451	Monitoring on
I1457	Measured error verification failed
I1459	I/O module verification failed
I1460	HBSI verification failed
I1461	Sensor verification failed
I1462	Sensor electronic module verific. failed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1618	I/O module replaced
I1619	I/O module replaced
I1621	I/O module replaced
I1622	Calibration changed
I1624	Reset all totalizers
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server login successful
I1628	Display login successful
I1629	CDI login successful
I1631	Web server access changed
I1632	Display login failed
I1633	CDI login failed
I1634	Parameter factory reset
I1635	Parameter delivery reset
I1637	FOUNDATION Fieldbus specific reset done
I1639	Max. switch cycles number reached
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1712	New flash file received
I1725	Sensor electronic module (ISEM) changed
I1726	Configuration backup failed

12.12 Resetting the measuring device

Using the **Restart** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

12.12.1 Function scope of the "Restart" parameter

Options	Description
Uninitialized	The selection has no effect on the device.
Run	The selection has no effect on the device.
Resource	The selection has no effect on the device.

Options	Description
Defaults	All FOUNDATION Fieldbus blocks are reset to their factory settings. Example: Analog Input Channel to the Uninitialized option.
Processor	The device is restarted.
To delivery settings	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information) and device parameters for which a customer-specific default setting was ordered are reset to this customer-specific value.

12.12.2 Function scope of the "Service reset" parameter


Options	Description
Uninitialized	The selection has no effect on the device.
To delivery settings + MIB	Advanced FOUNDATION Fieldbus parameters (FOUNDATION Fieldbus blocks, schedule information, device tag and device address) and the device parameters for which a customer-specific default setting was ordered, are reset to this customer-specific value.
ENP restart	The parameters of the electronic name plate are reset. The device is restarted.

12.13 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information



Parameter overview with brief description

Parameter	Description	User entry / User interface	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e. g. @, %, /)	-
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Promass 300/500	-
Firmware version	Shows the device firmware version installed.	Character string with the following format: xx.yy.zz	-
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).	Character string in the format xx.yy.zz	-

12.14 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
02.2017	01.00.zz	Option 74	Original firmware	Operating Instructions	BA01521D/06/EN/01.16

- It is possible to flash the firmware to the current version or the previous version using the service interface.
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 803B
 The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \implies 174 \rightarrow \implies 176$

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ► Carry out the repair according to the Installation Instructions.
- ► Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

- Measuring device serial number:
 - Is located on the nameplate of the device.
 - Can be read out via the Serial number parameter in the Device information submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the website for more information: http://www.endress.com/support/return-material
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

A WARNING

Danger to persons from process conditions.

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

A WARNING

Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- ▶ Observe valid federal/national regulations.
- ► Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Proline 300 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: Approvals Output Input Display/operation Housing Software Installation Instructions EA01200D
Remote display and operating module DKX001	 If ordered directly with the measuring device: Order code for "Display; operation", option O "Remote display 4-line illum.; 10 m (30 ft) Cable; touch control" If ordered separately: Measuring device: order code for "Display; operation", option M "W/o, prepared for remote display" DKX001: Via the separate product structure DKX001 If ordered subsequently: DKX001: Via the separate product structure DKX001 Mounting bracket for DKX001 If ordered directly: order code for "Accessory enclosed", option RA "Mounting bracket, pipe 1/2" If ordered subsequently: order number: 71340960 Connecting cable (replacement cable) Via the separate product structure: DKX002 Further information on display and operating module DKX001→ 198.
	Special Documentation SD01763D
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area". ■ The external WLAN antenna is not suitable for use in hygienic applications. ■ Further information on the WLAN interface → 🗎 65. Order number: 71351317 Installation Instructions EA01238D
Protective cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight. Order number: 71343505
	Installation Instructions EA01160D

15.1.2 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids.
	If using oil as a heating medium, please consult with Endress+Hauser.
	Special Documentation SD02159D

15.2 Communication-specific accessories

Accessories	Description	
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices	
	 Technical Information TI01297S Operating Instructions BA01778S Product page: www.endress.com/fxa42 	
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.	
	 Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt70 	
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.	
	 Technical Information TI01418S Operating Instructions BA01923S Product page: www.endress.com/smt77 	

15.3 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices for industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	Applicator is available: • Via the Internet: https://portal.endress.com/webapp/applicator • As a downloadable DVD for local PC installation.
W@M	W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle. W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime. Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, visit www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Operating Instructions BA00027S and BA00059S
DeviceCare	Tool to connect and configure Endress+Hauser field devices. Innovation brochure IN01047S

15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	 Technical Information Ti00133R Operating Instructions BA00247R
Cerabar M	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
	 Technical Information TI00426P and TI00436P Operating Instructions BA00200P and BA00382P
Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
	 Technical Information TI00383P Operating Instructions BA00271P
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.
	"Fields of Activity" document FA00006T

16 Technical data

16.1 Application

The measuring device is intended only for the flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Mass flow measurement based on the Coriolis measuring principle	
Measuring system	The device consists of a transmitter and a sensor.	
	The device is available as a compact version: The transmitter and sensor form a mechanical unit.	
	For information on the structure of the device $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	

16.3 Input

Measured variable

Direct measured variables

- Mass flow
- Density
- Temperature

Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

Measuring range

Measuring range for liquids

DN		Measuring range full scal	e values $\dot{m}_{\min(F)}$ to $\dot{m}_{\max(F)}$
[mm]	[in]	[kg/h]	[lb/min]
80	3	0 to 180 000	0 to 6615
100	4	0 to 350 000	0 to 12 860
150	6	0 to 800 000	0 to 29 400
250	10	0 to 2 200 000	0 to 80 850

Measuring range for gases

The full scale value depends on the density and the sound velocity of the gas used and can be calculated with the formula below:

 $\dot{m}_{max(G)} = minimum (\dot{m}_{max(F)} \cdot \rho_G : x ; \rho_G \cdot c_G \cdot \pi/2 \cdot (d_i)^2 \cdot 3600)$

m _{max(G)}	Maximum full scale value for gas [kg/h]	
m _{max(F)}	Maximum full scale value for liquid [kg/h]	
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{\max(G)}$ can never be greater than $\dot{m}_{\max(F)}$	
ρ_{G}	Gas density in [kg/m³] at operating conditions	
х	Constant dependent on nominal diameter	
c_G	Sound velocity (gas) [m/s]	
d_i	Measuring tube internal diameter [m]	

DN		х
[mm]	[in]	[kg/m³]
80	3	110
100	4	130
150	6	200
250	10	200

Calculation example for gas

- Sensor: Promass O, DN 80
- Gas: Air with a density of 60.3 kg/m³ (at 20 °C and 50 bar)
- Measuring range (liquid): 180000 kg/h
- $x = 130 \text{ kg/m}^3 \text{ (for Promass O, DN 80)}$

Maximum possible full scale value:

 $\dot{m}_{\,\, max(G)} = \dot{m}_{\,\, max(F)} \cdot \rho_G : x = 180\,000 \,\, kg/h \cdot 60.3 \,\, kg/m^3 : 130 \,\, kg/m^3 = 83\,500 \,\, kg/h$

Recommended measuring range



Flow limit $\rightarrow \blacksquare 194$

Operable flow range

Over 1000:1.


Flow rates above the preset full scale value do not override the electronics unit, with the result that the totalizer values are registered correctly.

Input signal

External measured values

To increase the accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write different measured values to the measuring device:

- Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S)
- Medium temperature to increase accuracy (e.g. iTEMP)
- Reference density for calculating the corrected volume flow for gases



It is recommended to read in external measured values to calculate the corrected volume flow.

Current input

Digital communication

The measured values are written from the automation system to the measuring device via FOUNDATION Fieldbus.

Current input 0/4 to 20 mA

Current input	0/4 to 20 mA (active/passive)
Current span	4 to 20 mA (active)0/4 to 20 mA (passive)
Resolution	1 μΑ
Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	≤ 30 V (passive)
Open-circuit voltage	≤ 28.8 V (active)
Possible input variables	PressureTemperatureDensity

Status input

Maximum input values	■ DC -3 to 30 V ■ If status input is active (ON): $R_i > 3 \text{ k}\Omega$
Response time	Configurable: 5 to 200 ms

Input signal level	 Low signal: DC -3 to +5 V High signal: DC 12 to 30 V
Assignable functions	 Off Reset the individual totalizers separately Reset all totalizers Flow override

16.4 Output

Output signal

FOUNDATION Fieldbus

FOUNDATION Fieldbus	H1, IEC 61158-2, galvanically isolated
Data transfer	31.25 kbit/s
Current consumption	10 mA
Permitted supply voltage	9 to 32 V
Bus connection	With integrated reverse polarity protection

Current output 4 to 20 mA

Signal mode	Can be set to: Active Passive
Current span	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronics temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 The range of options increases if the measuring device has one or more application packages.

Current output 4 to 20 mA Ex i passive

Order code	"Output; input 2" (21), "Output; input 3" (022): Option C: current output 4 to 20 mA Ex i passive
Signal mode	Passive
Current span	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA Fixed current
Maximum output values	22.5 mA
Maximum input voltage	DC 30 V

Load	0 to $700~\Omega$
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronics temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 The range of options increases if the measuring device has one or more application packages.

Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output
Version	Open collector Can be set to: Active Passive Passive NAMUR Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Adjustable
Assignable measured variables	Mass flowVolume flowCorrected volume flow
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Adjustable: end value frequency 2 to $10000\mathrm{Hz}$ (f $_\mathrm{max}$ = $12500\mathrm{Hz}$)
Damping	Configurable: 0 to 999.9 s
Pulse/pause ratio	1:1

Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Electronics temperature Oscillation frequency 0 Oscillation damping 0 Signal asymmetry Exciter current 0 The range of options increases if the measuring device has one or more application packages.
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching delay	Configurable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	 Off On Diagnostic behavior Limit value Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1-3 Flow direction monitoring Status Partially filled pipe detection Low flow cut off The range of options increases if the measuring device has one or more application packages.

Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: NO (normally open), factory setting NC (normally closed)

Maximum switching capacity (passive)	■ DC 30 V, 0.1 A ■ AC 30 V, 0.5 A
Assignable functions	 Off On Diagnostic behavior Limit value Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1-3 Flow direction monitoring Status Partially filled pipe detection Low flow cut off
	The range of options increases if the measuring device has one or more application packages.

User-configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm

Depending on the interface, failure information is displayed as follows:

FOUNDATION Fieldbus

Status and alarm messages	Diagnostics in accordance with FF-891
Failure current FDE (Fault Disconnection Electronic)	0 mA

Current output 0/4 to 20 mA

4 to 20 mA

Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Freely definable value between: 3.59 to 22.5 mA Actual value Last valid value

0 to 20 mA

Failure mode	Choose from:
	■ Maximum alarm: 22 mA
	■ Freely definable value between: 0 to 20.5 mA

Pulse/frequency/switch output

Pulse output		
Failure mode	Choose from: Actual value No pulses	
Frequency output	Frequency output	
Failure mode	Choose from: Actual value O Hz Defined value (f max 2 to 12 500 Hz)	
Switch output	Switch output	
Failure mode	Choose from: Current status Open Closed	

Relay output

Failure mode	Choose from:
	Current status
	■ Open
	■ Closed

Local display

Plain text display	With information on cause and remedial measures	
Backlight	Red backlighting indicates a device error.	



Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication: FOUNDATION Fieldbus
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	---

Web browser

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	The following information is displayed depending on the device version: ■ Supply voltage active ■ Data transmission active ■ Device alarm/error has occurred ■ Diagnostic information via light emitting diodes → ■ 132

Low flow cut off	The switch points for low flow cut off are user-selectable.
Galvanic isolation	The outputs are galvanically isolated from one another and from earth (PE).

Protocol-specific data

Manufacturer ID	0x452B48 (hex)			
Ident number	0x103B (hex)			
Device revision	1			
DD revision	Information and files under:			
CFF revision	www.endress.comwww.fieldbus.org			
Interoperability Test Kit (ITK)	Version 6.2.0			
ITK Test Campaign Number	Information: www.endress.com www.fieldbus.org			
Link Master capability (LAS)	Yes			
Choice of "Link Master" and "Basic Device"	Yes Factory setting: Basic Device			
Node address	Factory setting: 247 (0xF7)			
Supported functions	The following methods are supported: Restart ENP Restart Diagnostic Set to OOS Set to AUTO Read trend data Read event logbook			
Virtual Communication Relation	onships (VCRs)			
Number of VCRs	44			
Number of link objects in VFD	50			
Permanent entries	1			
Client VCRs	0			
Server VCRs	10			
Source VCRs	43			
Sink VCRs	0			
Subscriber VCRs	43			
Publisher VCRs	43			
Device Link Capabilities				
Slot time	4			
Min. delay between PDU	8			
Max. response delay	16			
System integration	Information regarding system integration $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $			
	 Cyclic data transmission Description of the modules Execution times Methods 			

16.5 Power supply

Terminal assignment

→ 🖺 33

Cable specification

→ 🖺 30

Device plugs available	→ 🖺 33				
Pin assignment, device plug	→ 🖺 33				
Supply voltage	Order code for "Power supply"		Terminal voltage		Frequency range
	Option D		DC 24 V	±20%	-
	Option E		AC 100 to 240 V	-15 to +10%	50/60 Hz
	0.44		DC 24 V	±20%	-
	Option I		AC 100 to 240 V	-15 to +10%	50/60 Hz
Power consumption	Transmitter				
r ower consumption	Max. 10 W (active p	power)			
	switch-on current	Max. 3	x. 36 A (<5 ms) as per NAMUR Recommendation NE 21		
Current consumption	Transmitter				
	 Max. 400 mA (24 V) Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz) 				
Power supply failure	 Totalizers stop at Depending on the the pluggable data Error messages (in 	device ver a memory	sion, the config (HistoROM DA)	T).	ained in the device memoryor in
Electrical connection	→ 🖺 35				
Potential equalization	→ 🗎 38				
Terminals	Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm ² (24 to 12 AWG).				
Cable entries	■ Cable gland: M20 ■ Thread for cable e ■ NPT ½" ■ G ½" ■ M20 ■ Device plug for dig	entry:			o 0.47 in)

Performance characteristics 16.6

Reference operating conditions

- Error limits based on ISO 11631
- Water with +15 to +45 °C (+59 to +113 °F) at 2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- Accuracy based on accredited calibration rigs that are traced to ISO 17025.
- To obtain measured errors, use the *Applicator* sizing tool $\rightarrow \implies 176$

Maximum measured error

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base accuracy

🚹 Design fundamentals → 🖺 191

Mass flow and volume flow (liquids)

±0.05 % o.r. (PremiumCal; order code for "Calibration flow", option D, for mass flow) ±0.10 % o.r.

Mass flow (gases)

±0.35 % o.r.

Density (liquids)

Under reference conditions	Standard density calibration 1)	Wide-range Density specification ^{2) 3)}		
[g/cm³]	[g/cm³]	[g/cm³]		
±0.0005	±0.01	±0.001		

- 1) Valid over the entire temperature and density range
- Valid range for special density calibration: 0 to 2 g/cm^3 , +5 to +80 °C (+41 to +176 °F) 2)
- Order code for "Application package", option EE "Special density"

Temperature

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Zero point stability

D	N	Zero point stability		
[mm] [in]		[kg/h]	[lb/min]	
80	3	9	0.330	
100	4	14	0.514	
150	6	32	1.17	
250	10	88	3.23	

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
80	180 000	18000	9 000	3 600	1800	360
100	350000	35 000	17500	7 000	3500	700
150	800 000	80000	40 000	16000	8000	1600
250	2 200 000	220000	110 000	44000	22 000	4 400

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3	6615	661.5	330.8	132.3	66.15	13.23
4	12860	1286	643.0	257.2	128.6	25.72
6	29 400	2940	1470	588	294	58.80
10	80850	8085	4043	1617	808.5	161.7

Accuracy of outputs

The outputs have the following base accuracy specifications.

Current output

Accuracy	±5 μA

Pulse/frequency output

o.r. = of reading

Accuracy Max. ±	50 ppm o.r. (over the entire ambient temperature range)
-----------------	---

Repeatability

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability



Design fundamentals → 🖺 191

Mass flow and volume flow (liquids)

 ± 0.025 % o.r. (PremiumCal, for mass flow) ± 0.05 % o.r.

Mass flow (gases)

±0.25 % o.r.

Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$

Temperature

 ± 0.25 °C ± 0.0025 · T °C (± 0.45 °F ± 0.0015 · (T-32) °F)

Response time

The response time depends on the configuration (damping).

Influence of ambient temperature

Current output

Temperature coefficient Max. 1 µA/°C	
--------------------------------------	--

Pulse/frequency output

Temperature coefficient	No additional effect. Included in accuracy.
-------------------------	---

Influence of medium temperature

Mass flow and volume flow

o.f.s. = of full scale value

When there is a difference between the temperature for zero point adjustment and the process temperature, the additional measured error of the sensor is typically ±0.0002 % o.f.s./°C (±0.0001 % o. f.s./°F).


The effect is reduced if zero point adjustment is performed at process temperature.

Density

When there is a difference between the density calibration temperature and the process temperature, the typical measured error of the sensor is ± 0.00005 g/cm³ /°C (± 0.000025 g/cm³ /°F). Field density calibration is possible.

Wide-range density specification (special density calibration)

If the process temperature is outside the valid range $(\rightarrow \triangleq 188)$ the measured error is $\pm 0.00005 \text{ g/cm}^3 \text{ /°C } (\pm 0.000025 \text{ g/cm}^3 \text{ /°F})$



- Field density calibration, for example at +20 °C (+68 °F)
- Special density calibration

Temperature

 $\pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.005 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Influence of medium pressure

The table below shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure.

o.r. = of reading



It is possible to compensate for the effect by:

- Reading in the current pressure measured value via the current input.
- Specifying a fixed value for the pressure in the device parameters.

Operating Instructions.

DN		[% o.r./bar]	[% o.r./psi]
[mm]	[in]		
80	3	-0.0055	-0.0004
100	4	-0.0035	-0.0002
150	6	-0.002	-0.0001
250	10	-0.002	-0.0001

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	AU021337
$< \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	$\pm \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot ZeroPoint}{BaseRepeat} \cdot 100$	± BaseRepeat
A0021335	A0021340
$<\frac{\frac{1}{2} \cdot ZeroPoint}{BaseRepeat} \cdot 100$	$\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021336	A0021337

Example for maximum measured error



- E Maximum measured error in % o.r. (example)
- Q Flow rate in % of maximum full scale value

16.7 Installation

Installation conditions


→ 🖺 21


16.8 **Environment**

Ambient temperature
range

→ 🗎 23→ 🗎 23

Temperature tables





Storage temperature

 $-50 \text{ to } +80 ^{\circ}\text{C} (-58 \text{ to } +176 ^{\circ}\text{F})$

Climate class

DIN EN 60068-2-38 (test Z/AD)

Degree of protection

Measuring device

- As standard: IP66/67, type 4X enclosure
- When housing is open: IP20, type 1 enclosure
- Display module: IP20, type 1 enclosure

External WLAN antenna

IP67

Vibration- and shockresistance

Vibration sinusoidal, in accordance with IEC 60068-2-6

- 2 to 8.4 Hz, 3.5 mm peak
- 8.4 to 2000 Hz, 1 g peak

Vibration broad-band random, according to IEC 60068-2-64

- 10 to 200 Hz, 0.003 g²/Hz
- 200 to 2000 Hz, 0.001 q²/Hz
- Total: 1.54 g rms

Shock half-sine, according to IEC 60068-2-27

6 ms 30 g

Rough handling shocks, according to IEC 60068-2-31

Mechanical load

Never use the transmitter housing as a ladder or climbing aid.

Electromagnetic compatibility (EMC)




Details are provided in the Declaration of Conformity.

16.9 **Process**

Medium temperature range

-40 to +205 °C (-40 to +401 °F)

Dependency of ambient temperature on medium temperature



 ${
m I\! I}$ 32 Exemplary representation, values in the table below.

- T_a Ambient temperature range
- *T_m* Medium temperature
- A Maximum permitted medium temperature T_m at $T_{a max}$ = 60 °C (140 °F); higher medium temperatures T_m require a reduced ambient temperature T_a
- B Maximum permitted ambient temperature T_a for the maximum specified medium temperature T_m of the sensor
- Values for devices used in the hazardous area: Separate Ex documentation (XA) for the device $\Rightarrow \triangleq 206$.

Not insulated			Insulated				
A		В		A		В	
T _a	T _m	Ta	T _m	Ta	T _m	Ta	T_{m}
60 °C (140 °F)	170 °C (338 °F)	50 °C (122 °F)	205 °C (401 °F)	60 °C (140 °F)	110 °C (230 °F)	50 °C (122 °F)	205 °C (401 °F)

Density

0 to 5000 kg/m^3 (0 to 312 lb/cf)

Pressure-temperature ratings



An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document

Sensor housing

The sensor housing is filled with dry nitrogen gas and protects the electronics and mechanics inside.

If a measuring tube fails (e.g. due to process characteristics like corrosive or abrasive fluids), the fluid will initially be contained by the sensor housing.

In the event of a tube failure, the pressure level inside the sensor housing will rise according to the operating process pressure. If the user judges that the sensor housing burst pressure does not provide an adequate safety margin, the device can be fitted with a rupture disk. This prevents excessively high pressure from forming inside the sensor housing. Therefore, the use of a rupture disk is strongly recommended in applications involving high gas pressures, and particularly in applications in which the process pressure is greater than 2/3 of the sensor housing burst pressure.

If there is a need to drain the leaking medium into a discharge device, the sensor should be fitted with a rupture disk. Connect the discharge to the additional threaded connection .

If the sensor is to be purged with gas (gas detection), it should be equipped with purge connections.

Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low pressure to purge.

Maximum pressure:

- DN 80 to 150 (3 to 6"): 5 bar (72.5 psi)
- DN 250 (10"): 3 bar (43.5 psi)

Burst pressure of the sensor housing


The following sensor housing burst pressures are only valid for standard devices and/or devices equipped with closed purge connections (not opened/as delivered).

If a device fitted with purge connections (order code for "Sensor option", option CH "Purge connection") is connected to the purge system, the maximum pressure is determined by the purge system itself or by the device, depending on which component has the lower pressure classification.

If the device is fitted with a rupture disk (order code for "Sensor option", option CA "Rupture disk"), the rupture disk trigger pressure is decisive.

The sensor housing burst pressure refers to a typical internal pressure which is reached prior to mechanical failure of the sensor housing and which was determined during type testing. The corresponding type test declaration can be ordered with the device (order code for "Additional approval", option LN "Sensor housing burst pressure, type test").

DN		Sensor housing burst pressure		
[mm]	[in]	[bar]	[psi]	
80	3	120	1740	
100	4	95	1370	
150	6	75	1080	
250	10	50	720	



Rupture disk

To increase the level of safety, a device version with a rupture disk with a trigger pressure of 10 to 15 bar (145 to 217.5 psi)can be used (order code for "Sensor option", option CA "rupture disk").



For information on the dimensions of the rupture disk: see the "Mechanical construction" section of the "Technical Information" document

Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.

For an overview of the full scale values for the measuring range, see the "Measuring range" section $\rightarrow \blacksquare 178$

- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- In most applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
 - The flow velocity in the measuring tubes should not exceed half the sound velocity (0.5 Mach).
 - The maximum mass flow depends on the density of the gas: formula $\rightarrow \blacksquare 178$
- ho To calculate the flow limit, use the *Applicator* sizing tool ho ho 176

Pressure loss


To calculate the pressure loss, use the *Applicator* sizing tool $\rightarrow \stackrel{\triangle}{=} 176$

System pressure

→ 🖺 23

16.10 Mechanical construction

Design, dimensions



Weight

All values (weight exclusive of packaging material) refer to devices with ASME B16.5 Class 900 flanges. Weight specifications including transmitter as per order code for "Housing", option A "Aluminum, coated".

Different values due to different transmitter versions:

- Transmitter version for the hazardous area
 (Order code for "Housing", option A "Aluminum, coated"; Ex d): +2 kg (+4.4 lbs)
- Cast transmitter version, stainless (Order code for "Housing", option L "Cast, stainless"): +6 kg (+13 lbs)

Weight in SI units

DN [mm]	Weight [kg]
80	75
100	141
150	246
250	572

Weight in US units

DN [in]	Weight [lbs]
3	165
4	311
6	542
10	1261

Materials

Transmitter housing

Order code for "Housing":

- Option A "Aluminum, coated": aluminum, AlSi10Mq, coated
- Option L "Cast, stainless": cast, stainless steel, 1.4409 (CF3M) similar to 316L

Window material

Order code for "Housing":

- Option **A** "Aluminum, coated": glass
- Option **L** "Cast, stainless": glass

Cable entries/cable glands

Order code for "Housing", option A "Aluminum, coated"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material	
Coupling M20 × 1.5	Non-Ex: plastic	
Coupling M20 ^ 1.5	Z2, D2, Ex d/de: brass with plastic	
Adapter for cable entry with female thread G 1/2"	Nickel-plated brass	
Adapter for cable entry with female thread NPT ½"		

Order code for "Housing", option L "Cast, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with female thread G 1/2"	
Adapter for cable entry with female thread NPT ½"	

Device plug

Electrical connection	Material
Plug M12x1	 Socket: Stainless steel, 1.4404 (316L) Contact housing: Polyamide Contacts: Gold-plated brass

Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel, 1.4404 (316L)

Measuring tubes

Stainless steel, 1.4410/UNS S32750 25Cr Duplex (Super Duplex)

Process connections

Stainless steel, 1.4410/F53 25Cr Duplex (Super Duplex)

Seals

Welded process connections without internal seals

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Process connections

Fixed flange connections:

- EN 1092-1 (DIN 2512N) flange
- ASME B16.5 flange
- JIS B2220 flange
- i

Process connection materials → 🖺 196

Surface roughness

All data relate to parts in contact with fluid. The following surface roughness quality can be ordered.

Not polished

16.11 Human interface

Languages

Can be operated in the following languages:


- Via local operation
 - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via Web browser
 - English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese


Local operation

Via display module

Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"





A002678

■ 33 Operation with touch control

Display elements


- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.

Operating elements

- External operation via touch control (3 optical keys) without opening the housing: ±,
 □. □
- Operating elements also accessible in the various zones of the hazardous area

Via remote display and operating module DKX001

- The remote display and operating module DKX001 is available as an optional extra $\Rightarrow \triangleq 174$.
 - The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
 - If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module.
 Only one display or operation unit may be connected to the transmitter at any one time.



■ 34 Operation via remote display and operating module DKX001

1002676

Display and operating elements

Housing material

The housing material of the display and operating module DKX001 depends on the choice of transmitter housing material.

Transmitter housing	Remote display and operating module	
Order code for "Housing"	Material	Material
Option A "Aluminum, coated"	AlSi10Mg, coated	AlSi10Mg, coated
Option L "Cast, stainless"	Cast stainless steel, 1.4409 (CF3M) similar to 316L	1.4409 (CF3M)

Cable entry

Corresponds to the choice of transmitter housing, order code for "Electrical connection".

Connecting cable

→ 🖺 31

Dimensions



Information on the dimensions:

"Mechanical construction" section of the "Technical Information" document.

→ 🖺 64 Remote operation Service interface → 🖺 64

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	CDI-RJ45 service interfaceWLAN interface	Special Documentation for device → 🖺 206
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🖺 176
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🖺 176
Device Xpert	Field Xpert SFX 100/350/370	HART and FOUNDATION Fieldbus fieldbus protocol	Operating Instructions BA01202S Device description files: Use update function of handheld terminal

- Other operating tools based on FDT technology with a device driver such as DTM/ iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
 - FactoryTalk AssetCentre (FTAC) by Rockwell Automation → www.rockwellautomation.com
 - Asset Management Solutions (AMS) by Emerson → www.emersonprocess.com
 - FieldCommunicator 375/475 by Emerson → www.emersonprocess.com
 - Field Device Manager (FDM) by Honeywell → www.honeywellprocess.com
 - FieldMate by Yokogawa → www.yokogawa.com
 - PACTWare → www.pactware.com

The associated device description files are available at: www.endress.com \rightarrow Downloads

Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) or via a WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration



Web server special documentation $\rightarrow \triangleq 206$

HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.



When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	Device memory	T-DAT	S-DAT
Available data	 Event logbook such as diagnostic events for example Parameter data record backup Device firmware package Driver for system integration for exporting via Web server, e.g: DD for FOUNDATION Fieldbus 	 Measured value logging ("Extended HistoROM" order option) Current parameter data record (used by firmware at run time) Peakhold indicator (min/max values) Totalizer values 	 Sensor data: nominal diameter etc. Serial number Calibration data Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

- Data backup function
 Backup and subsequent restoration of a device configuration in the device memory
 HistoROM backup
- Data comparison function
 Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transfer

Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.:
 DD for FOUNDATION Fieldbus

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g.
 FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Currently available certificates and approvals can be called up via the product configurator.

CE mark

The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied. Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

RCM-tick symbol

The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".

Ex approval

The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.

FOUNDATION Fieldbus certification

FOUNDATION Fieldbus interface

The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications:

- Certified in accordance with FOUNDATION Fieldbus H1
- Interoperability Test Kit (ITK), revision version 6.2.0 (certificate available on request)
- Physical Layer Conformance Test
- The device can also be operated with certified devices of other manufacturers (interoperability)

Pressure Equipment Directive

- With the identification PED/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms conformity with the "Essential Safety Requirements" specified in Appendix I of the Pressure Equipment Directive 2014/68/EU.
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Article 4 paragraph 3 of the Pressure Equipment Directive 2014/68/EU. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU.

Radio approval

The measuring device has radio approval.



For detailed information regarding radio approval, see Special Documentation
→ 🖺 206

Additional certification

CRN approval

Some device versions have CRN approval. A CRN-approved process connection with a CSA approval must be ordered for a CRN-approved device.

Tests and certificates

- EN10204-3.1 material certificate, parts and sensor housing in contact with medium
- Pressure testing, internal procedure, inspection certificate
- PMI test (XRF), internal procedure, wetted parts, test report
- EN10204-2.1 confirmation of compliance with the order and EN10204-2.2 test report

Testing of welded connections

Option	Test s	Com	ponent			
	ISO 23277 AL2x (PT) ISO 10675-1 AL1 (RT, DR)	ASME B31.3 NFS	ASME VIII Div.1 Appx. 4+8	NORSOK M-601	Measuring tube	Process connection
CF	Х				PT	RT
KK		х			PT	RT
KP			х		PT	RT

Option	Test s	Com	ponent			
	ISO 23277 AL2x (PT) ISO 10675-1 AL1 (RT, DR)	ASME B31.3 NFS	ASME VIII Div.1 Appx. 4+8	NORSOK M-601	Measuring tube	Process connection
KR				х	VT, PT	VT, RT
K1	Х				PT	DR
K2		х			PT	DR
КЗ			х		PT	DR
K4				Х	VT, PT	VT, DR

PT = penetrant testing, RT = radiographic testing, VT = visual testing, DR = digital radiography All options with test report

Other standards and quidelines

■ EN 60529

Degrees of protection provided by enclosures (IP code)

■ IEC/EN 60068-2-6

Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal).

■ IEC/EN 60068-2-31

Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices.

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements

■ IEC/EN 61326

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

■ NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 80

The application of the pressure equipment directive to process control devices

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

■ NAMUR NE 107

Self-monitoring and diagnosis of field devices

■ NAMUR NE 131

Requirements for field devices for standard applications

■ NAMUR NE 132

Coriolis mass meter

■ NACE MR0103

Materials resistant to sulfide stress cracking in corrosive petroleum refining environments.

■ NACE MR0175/ISO 15156-1

Materials for use in H2S-containing Environments in Oil and Gas Production.

■ ETSI EN 300 328

Guidelines for 2.4 GHz radio components.

■ EN 301489

Electromagnetic compatibility and radio spectrum matters (ERM).

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



Detailed information on the application packages: Special Documentation for the device $\rightarrow \stackrel{\triangle}{=} 206$

Diagnostics functions

Package	Description
Extended HistoROM	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	 Data logging (line recorder): Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.

Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment". Functional testing in the installed state without interrupting the process. Traceable verification results on request, including a report. Simple testing process via local operation or other operating interfaces. Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications. Extension of calibration intervals according to operator's risk assessment.
	Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to: Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time. Schedule servicing in time. Monitor the process or product quality, e.g. gas pockets.

Concentration

Package	Description
Concentration	Calculation and outputting of fluid concentrations
	The measured density is converted to the concentration of a substance of a binary mixture using the "Concentration" application package: Choice of predefined fluids (e.g. various sugar solutions, acids, alkalis, salts, ethanol etc.) Common or user-defined units ("Brix, "Plato, "M mass, "M volume, mol/l etc.) for standard applications. Concentration calculation from user-defined tables.

204

Special density	Package	Description
	Special density	Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system. The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.

Petroleum

Package	Description
Petroleum	The most important parameters for the Oil & Gas Industry can be calculated and displayed with this application package.
	 Corrected volume flow and calculated reference density in accordance with the "API Manual of Petroleum Measurement Standards, Chapter 11.1" Water content, based on density measurement Weighted mean of the density and temperature

16.14 Accessories



Supplementary documentation



- W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from nameplate
- Endress+Hauser Operations App: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

Standard documentation **Brief Operating Instructions**

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Promass O	KA01285D

Brief Operating Instructions for transmitter

Measuring device	Documentation code
Proline 300	KA01229D

Technical Information

Measuring device	Documentation code
Promass O 300	TI01275D

Description of Device Parameters

Measuring device	Documentation code
Promass 300	GP01094D

Device-dependent additional documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01405D
ATEX/IECEx Ex ec	XA01439D
cCSAus XP	XA01373D
cCSAus Ex d/ Ex de	XA01372D
cCSAus Ex nA	XA01507D
INMETRO Ex d/Ex de	XA01468D
INMETRO Ex ec	XA01470D
NEPSI Ex d/Ex de	XA01469D
NEPSI Ex nA	XA01471D
EAC Ex d/Ex de	XA01656D
EAC Ex nA	XA01657D
JPN Ex d	XA01778D

Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Remote display and operating module DKX001	SD01763D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Web server	SD01665D
Heartbeat Technology	SD01696D
Concentration measurement	SD01706D
Petroleum	-

Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via W@M Device Viewer → ■ 172 Accessories available for order with Installation Instructions → ■ 174

Index

Α	Density
Access authorization to parameters	Design fundamentals
Read access	Maximum measured error
Write access	Repeatability
Access code	Designated use
Incorrect input	Device components
Accuracy	Device description files
Adapting the diagnostic behavior	Device documentation
Adapting the status signal	Supplementary documentation 8
Additional certification 202	Device locking, status
Ambient temperature	Device name
Influence	Sensor
AMS Device Manager 68	Transmitter
Function	Device repair
Application	Device revision
Application packages	Device type ID
Applicator	DeviceCare
Approvals	Device description file
11pp101ate 11111111111111111111111111111111111	Diagnostic behavior
C	Explanation
Cable entries	Symbols
Technical data	Diagnostic information
Cable entry	Design, description
Degree of protection	DeviceCare
CE mark	FieldCare
Certificates	Light emitting diodes
Check	Local display
Installation	Overview
Checklist	Remedial measures
Post-connection check 42	Web browser
Post-installation check	Diagnostic list
Cleaning	Diagnostic message
Exterior cleaning	DIAGNOSTIC Transducer Block
Climate class	Diagnostics
Commissioning	Symbols
Advanced settings	DIP switches
Configuring the measuring device	see Write protection switch
Connecting cable	Direct access
Connecting the measuring device	Direct access code
Connecting the signal cables	Disabling write protection
Connecting the supply voltage cables	Display
Connection	see Onsite display
see Electrical connection	Display and operating module DKX001 198
Connection preparations	Display area
Connection tools	For operational display 47
Context menu	In the navigation view 49
Calling up	Display values
Closing	For locking status
Explanation	Disposal
Current consumption	Document
Cyclic data transmission	Function 6
cyclic data transmission	Symbols 6
D	Document function 6
Declaration of Conformity	Down pipe
Define access code	Down pipe
Degree of protection	

E	Function scope
Editing view	AMS Device Manager 68
Input screen	Field Communicator 69
Using operating elements 50, 51	Field Communicator 475 69
Electrical connection	Functions
Degree of protection	see Parameter
Measuring device	
Operating tools	G
Via FOUNDATION Fieldbus network 64	Galvanic isolation
Via service interface (CDI-RJ45) 64	
Via WLAN interface 65	Н
Web server	Hardware write protection
WLAN interface	Help text
Electromagnetic compatibility	Calling up
Electronics module	Closing
Enabling write protection	Explanation
Enabling write protection	HistoROM
Endress+Hauser services	
	I
Maintenance	Identifying the measuring device
Repair	Incoming acceptance
Environment 102	Influence
Mechanical load	Ambient temperature
Storage temperature	Medium pressure
Vibration- and shock-resistance	Medium temperature
Error messages	Information on the document 6
see Diagnostic messages	Inlet runs
Event list	Input
Event logbook	Inspection
Ex approval	Received goods
Extended order code	Inspection check
Sensor	Connection
Transmitter	Installation
Exterior cleaning	Installation conditions
F	Down pipe
_	Inlet and outlet runs
Field Communicator	Installation dimensions 23
Function	Mounting location
Field Communicator 475 69	Orientation
Field of application	Rupture disk
Residual risks	Sensor heating
Field Xpert	System pressure
Function	Thermal insulation
Field Xpert SFX350	Vibrations
FieldCare	Installation dimensions
Device description file	
Establishing a connection 67	L
Function	Languages, operation options 197
User interface	Line recorder
Filtering the event logbook	Local display
Firmware	Navigation view
Release date	see Diagnostic message
Version	see In alarm condition
Firmware history	see Operational display
Flow direction	Low flow cut off
Flow limit	25 25 64. 64. 64. 6 6 6 6 6 6 6
FOUNDATION Fieldbus certification 202	M
Function check	Main electronics module
Function range	Maintenance tasks
Field Xpert	Managing the device configuration

208

Manufacturer ID	Operating keys
Manufacturing date	see Operating elements
Materials	Operating menu
Maximum measured error	Menus, submenus
Measured values	Structure
see Process variables	Submenus and user roles
Measuring and test equipment	Operating philosophy
Measuring device	Operation
Configuration	Operation options
Conversion	Operational display
Disposal	Operational safety
Mounting the sensor	Order code
Preparing for electrical connection	Orientation (vertical, horizontal)
Preparing for mounting	Outlet runs
Removing	Output
Repairs	Output signal
Structure	P
Switch-on	-
Measuring principle	Packaging disposal
Measuring range	Parameter
Calculation example for gas 178	Changing
For gases	Entering values or text
For liquids	Parameter settings
Measuring range, recommended 194	Administration (Submenu)
Measuring system	Advanced setup (Submenu)
Mechanical load	Analog inputs (Submenu)
Medium pressure	Calculated values (Submenu) 103
Influence	Configuration backup (Submenu) 111
Medium temperature	Current input
Influence	Current input (Wizard) 84
Menu	Current input 1 to n (Submenu) 122
Diagnostics	Current output
Setup	Current output (Wizard)
Menus	Data logging (Submenu)
For measuring device configuration	Define access code (Wizard)
For specific settings	Device information (Submenu) 168
Mounting dimensions	Diagnostics (Menu)
see Installation dimensions	Display (Submenu)
Mounting location	Display (Wizard)
Mounting preparations	I/O configuration
Mounting tools	I/O configuration (Submenu) 83
iviounting tools	Low flow cut off (Wizard) 100
N	Measured variables (Submenu)
Nameplate	Partially filled pipe detection (Wizard) 101
Sensor	Pulse/frequency/switch output
Transmitter	Pulse/frequency/switch output (Wizard) 89, 90, 94
Navigation path (navigation view) 48	Pulse/frequency/switch output 1 to n (Submenu) 124
Navigation view	Relay output
In the submenu	Relay output 1 to n (Submenu)
In the wizard	Relay output 1 to n (Wizard)
Numeric editor	Reset access code (Submenu)
Numeric editor	
0	Select medium (Wizard)
Onsite display	Sensor adjustment (Submenu)
Numeric editor	Setup (Menu)
Text editor	Simulation (Submenu)
	Status input (Submanu)
Operable flow range	Status input (Submenu)
Operating elements	Status input 1 to n (Submenu)
	System units (Submenu)

Totalizer (Submenu)	Settings
Totalizer 1 to n (Submenu) 105	Adapting the measuring device to the process
Totalizer handling (Submenu) 125	conditions
Value current output 1 to n (Submenu) 123	Administration
Web server (Submenu) 63	Advanced display configurations 107
WLAN Settings (Submenu)	Analog input 83
Zero point adjustment (Submenu) 105	Current input
Performance characteristics	Current output
Post-connection check (checklist) 42	Device reset
Post-installation check	Device tag
Post-installation check (checklist) 29	I/O configuration
Potential equalization	Local display
Power consumption	Low flow
Power supply failure	Managing the device configuration 111
Pressure Equipment Directive 202	Medium
Pressure loss	Operating language
Pressure-temperature ratings	Partial filled pipe detection 101
Process connections	Pulse output
Process variables	Pulse/frequency/switch output 89, 90
Calculated	Relay output
Measured	Resetting the totalizer
Product safety	Restart device
Protecting parameter settings	Sensor adjustment
J 1	Simulation
R	Status input
Radio approval	Switch output
RCM-tick symbol	System units
Read access	Totalizer
Reading measured values	Totalizer reset
Recalibration	WLAN
Reference operating conditions	Showing data logging
Registered trademarks	Signal on alarm
Remedial measures	Software release
Calling up	Spare part
Closing	Spare parts
Remote operation	Special connection instructions
Repair	Special mounting instructions
Repair of a device	Sanitary compatibility
Repairs	Standards and quidelines
Notes	Status area
Repeatability	For operational display
Replacement	In the navigation view 48
Device components	Status signals
Requirements for personnel	Storage concept
Response time	Storage conditions
Return	Storage temperature
Rupture disk	Storage temperature range
Safety instructions	Structure
Triggering pressure	Measuring device
	Operating menu
S	Submenu
Safety	Administration
Sensor	Advanced setup
Mounting	Analog inputs
Sensor heating	Calculated values
Sensor housing	Configuration backup
Serial number	Current input 1 to n
Setting the operating language	Data logging
	Device information
	Device information 100

Display	Tool tip
Event list	see Help text
I/O configuration	Tools
Input values	Electrical connection
Measured values	For mounting
Measured variables	Transport
Output values	Totalizer
Overview	Configuration
Process variables	Transmitter
Pulse/frequency/switch output 1 to n 124	Turning the display module 28
Relay output 1 to n	Turning the housing
Reset access code	Transporting the measuring device
Sensor adjustment	Troubleshooting
Simulation	General
Status input	Turning the display module
Status input 1 to n	Turning the electronics housing
System units	see Turning the transmitter housing
Totalizer	Turning the transmitter housing 28
Totalizer 1 to n	U
Totalizer handling	
Value current output 1 to n	Use of the measuring device
Web server	Borderline cases
WLAN Settings	Incorrect use
Zero point adjustment	see Designated use
Supply voltage	User interface
Surface roughness	Current diagnostic event
Switch output	Previous diagnostic event
Symbols	User roles
Controlling data entries 51	V
For communication 47	
For diagnostic behavior 47	Version data for the device
For locking	Vibration- and shock-resistance
For measured variable 47	Vibrations
For measurement channel number 47	W
For menus	W@M 171, 172
For parameters	W@M Device Viewer
For status signal	Weight
For submenu	SI units
For wizard	Transport (notes)
In the status area of the local display 47	US units
Input screen	Wizard
Operating elements 50	Current input
System design	Current output
Measuring system	Define access code
see Measuring device design	Display
System integration	Low flow cut off
System pressure	Partially filled pipe detection
Tr.	Pulse/frequency/switch output 89, 90, 94
T	Relay output 1 to n
Technical data, overview	Select medium
Temperature range	WLAN settings
Ambient temperature range for display 197	Workplace safety
Medium temperature	Write access
Storage temperature	Write access
Terminal assignment	Via access code
Terminals	Via block operation
Tests and certificates	
Text editor	Via write protection switch
Thermal insulation	Write protection switch



www.addresses.endress.com