
01.00.zz (Device firmware)

Description of Device Parameters **Deltabar PMD78B**

Differential pressure measurement HART







Deltabar PMD78B HART Table of contents

Table of contents

1	About this document 4
1.1	Document function
1.2	Target audience 4
1.3	Using this document 4
1.4	Symbols used 5
1.5	Documentation 5
2	Overview of the operating menu 6
3	Description of device parameters 15
3.1	"Guidance" menu
3.2	"Diagnostics" menu
3.3	"Application" menu
3.4	"System" menu
Inde	x 69

About this document Deltabar PMD78B HART

1 About this document

1.1 **Document function**

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target audience

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and their parameters that are available when the "Maintenance" option user role is activated.



For the operating concept of the operating menus, see the Operating Instructions.

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Factory setting: Default setting on leaving the factory
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function

Deltabar PMD78B HART About this document

1.4 Symbols used

1.4.1 Symbols for certain types of information

Additional information: 🚹

Reference to documentation: 📵

Operation via local display: 🗐

Operation via operating tool:

Write-protected parameter: 🗈

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

The Operating Instructions are available on the Internet at: www.endress.com → Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

The Special Documentation is available on the Internet at: www.endress.com → Download

2 Overview of the operating menu

Guidance		→ 🖺 17
► Commissioning		→ 🖺 17
	Device tag	→ 🖺 17
	Assign PV	→ 🖺 17
	Assign SV	→ 🖺 17
	Damping	→ 🖺 18
	Pressure unit	→ 🖺 18
	Temperature unit	→ 🖺 18
	Zero adjustment	→ 🖺 19
	Pressure	→ 🖺 19
	Output current transfer function	→ 🖺 19
	Low flow cut off	→ 🖺 20
	Scaled variable unit	→ 🖺 20
	Free text	→ 🖺 21
	Temperature unit	→ 🖺 18
	Zero adjustment	→ 🖺 19
	Pressure	→ 🖺 19
	Scaled variable transfer function	→ 🖺 21
	Table not available	→ 🖺 21
	Pressure value 1	→ 🖺 21
	Scaled variable value 1	→ 🖺 22
	Pressure value 2	→ 🖺 22
	Scaled variable value 2	→ 🖺 22
	Lower range value output	→ 🖺 22

	Pressure	→ 🖺 19
	Upper range value output	→ 🖺 23
	Pressure	→ 🖺 19
	Lower range value output	→ 🖺 22
	Scaled variable	→ 🖺 23
	Upper range value output	→ 🖺 23
	Scaled variable	→ 🖺 23
	Current range output	→ 🖺 23
	Failure behavior current output	→ 🖺 23
► SIL confirmatio		→ 🖺 24
, old community	Proof test via Bluetooth allowed?	→ 🖺 24
		→ 🖺 24
	Enter SIL locking code	
	SIL status	→ 🖺 24
	Character test string	→ 🖺 25
	Device tag	→ 🖺 25
	Device name	→ 🖺 25
	Serial number	→ 🖺 26
	CRC device configuration	→ 🖺 26
	Stored CRC device configuration	→ 🖺 26
	Timestamp stored CRC device config.	→ 🖺 26
	Operating time	→ 🖺 27
	Configuration counter	→ 🖺 27
	Zero adjustment offset	→ 🖺 27
	Zero adjustment offset	→ 🖺 27
	HP/LP swap	→ 🖺 27

	Damning]	→ 🖺 28
	Damping		→ 🗏 28
	Sensor pressure range behavior		→ 🖺 28
	Output current transfer function		→ 🖺 28
	Output current transfer function		→ 🖺 28
	Low cutoff		→ 🖺 28
	Failure behavior current output		→ 🖺 28
	Current range output		→ 🖺 29
	Measuring mode current output		→ 🖺 29
	Lower range value output		→ 🖺 29
	Upper range value output		→ 🖺 29
	Assign PV		→ 🖺 30
	Enter SIL locking code		→ 🖺 24
	Code incorrect		→ 🖺 30
	Locking status		→ 🖺 30
▶ Deactivate SIL			→ 🖺 31
	Enter SIL unlocking code		→ 🖺 31
	Code incorrect		→ 🖺 31
	Locking status		→ 🖺 32
Diagnostics			→ 🖺 33
► Active diagnost	ics		→ 🖺 33
	Active diagnostics		→ 🖺 33
	Timestamp		→ 🖺 33
	Previous diagnostics		→ 🖺 34
	Timestamp		→ 🖺 34

8

	Operating time from restart	→ 🖺 34
	Operating time	→ 🖺 35
► Minimum/max	imum values	→ 🖺 35
	Pressure min	→ 🖺 35
	Pressure max	→ 🖺 35
	Counter limit underruns sensor Pmin	→ 🖺 35
	Counter limit overruns sensor Pmax	→ 🖺 35
	Counter underruns of user limit Pmin	→ 🖺 36
	Counter overruns of user limit Pmax	→ 🖺 36
	Reset user defined counters P and T	→ 🖺 36
	Minimum sensor temperature	→ 🖺 36
	Maximum sensor temperature	→ 🖺 36
	Counter limit overruns sensor Tmax	→ 🖺 36
	Counter limit underruns sensor Tmin	→ 🗎 37
		→ 3 7
	Counter underruns of user limit Tmin	
	Counter overruns of user limit Tmax	→ 🖺 37
	Minimum terminal voltage	→ 🖺 37
	Maximum terminal voltage	→ 🖺 37
	Minimum electronics temperature	→ 🖺 37
	Maximum electronics temperature	→ 🖺 38
► Simulation		→ 🖺 38
	Simulation	→ 🗎 38
	Value pressure simulation	→ 🖺 38
	Value current output	→ 🖺 38

	Diagnostic event category		→ 🗎 38
	Diagnostic event simulation		→ 🖺 39
► Heartbeat Tech	ology		→ 🖺 39
	► Heartbeat Verification		→ 🖺 39
	Start verification		→ 🖺 39
	Operating time (V	erification)	→ 🖺 40
	Verification result		→ 🖺 40
	Status		→ 🖺 40
	► Loop diagnostics		→ 🖺 40
	Rebuild baseline		→ 🖺 40
	Tolerated deviatio	n +/-	→ 🖺 41
	806 Alarm delay		→ 🖺 41
	Baseline status		→ 🖺 41
	Loop diagnostics		→ 🖺 41
	Terminal voltage		→ 🖺 42
	Clamping voltage	lower threshold	→ 🖺 42
	Clamping voltage	upper threshold	→ 🖺 42
	► Statistical Sensor Diagnostics		→ 🗎 42
	SSD: Statistical Ser	nsor Diagnostics	→ 🖺 42
	System status		→ 🖺 43
	Signal status		→ 🖺 43
	Signal noise status	3	→ 🖺 43
Application			→ 🖺 44
► Measured value			→ 🖺 44
	Terminal voltage 1		→ 🖺 44

10

	Terminal current			→ 🖺 44
	Electronics tempera	iture		→ 🖺 44
	Sensor temperature	,		→ 🖺 45
► Sensor				→ 🖺 45
	► Sensor configura	ation		→ 🖺 47
		Output current tran	sfer function	→ 🖺 47
		Damping		→ 🖺 47
		HP/LP swap		→ 🖺 47
		Low flow cut off		→ 🖺 48
	► Wet calibration			→ 🖺 48
		▶ Zero		→ 🖺 48
			Zero	→ 🖺 48
			Pressure	→ 🖺 48
			Pressure value 1	→ 🖺 48
			Lower range value output	→ 🖺 49
		► Span		→ 🖺 49
			Span	→ 🖺 49
			Pressure	→ 🖺 49
			Pressure value 2	→ 🖺 49
			Upper range value output	→ 🖺 50
► HART output]		→ 🖺 50
	► Configuration			→ 🖺 50
		HART address		→ 🖺 50
		HART short tag		→ 🖺 50
		Device tag		→ 🖺 51
		9		-

			No. of preambles	→ 🖺 51
			Loop current mode	→ 🖺 51
System				→ 🖺 52
	▶ Device manage	ment		→ 🖺 52
		Device tag		→ 🖺 52
		Locking status		→ 🖺 52
		Configuration coun	ter	→ 🖺 53
		Reset device		→ 🖺 53
	▶ User managem	ent]	→ 🖺 54
		User role		→ 🖺 54
		► Change user rol	е	→ 🖺 54
			Enter access code	→ 🖺 54
		► Change user rol	е	→ 🖺 55
			Start	→ 🖺 55
			Password	→ 🖺 55
			Status password entry	→ 🖺 55
		▶ Define passwore	d	→ 🖺 56
			Start	→ 🖺 56
			New password	→ 🖺 56
			Status password entry	→ 🖺 56
			Confirm new password	→ 🖺 57
			Status password entry	→ 🖺 56
		► Change passwo	rd	→ 🖺 57
			Start	→ 🖺 57
			Old password	→ 🖺 57

12

		Status password entry	→ 🖺 57
		New password	→ 🖺 58
		Status password entry	→ 🖺 57
		Confirm new password	→ 🖺 58
		Status password entry	→ 🖺 57
	► Delete passwor	d	→ 🗎 58
		Start	→ 🖺 58
		Old password	→ 🖺 58
		Status password entry	→ 🖺 59
	► Reset password		→ 🖺 59
		Start	→ 🖺 59
		Reset password	→ 🖺 59
		Status password entry	→ 🖺 59
	► Logout		→ 🖺 60
		Start	→ 🖺 60
		User role	→ 🖺 60
► Bluetooth confi	iguration		→ 🖺 61
	Bluetooth activatio	n	→ 🖺 61
► Display			→ 🗎 15
	Language		→ 🖺 15
	Format display		→ 🗎 62
	Value 1 display		→ 🖺 62
	Value 2 display		→ 🖺 63
	Value 3 display		→ 🖺 63

	Value 4 display		→ 🖺 64
	Contrast display		→ 🖺 64
► Information			→ 🖺 66
	Device name		→ 🖺 66
	Manufacturer		→ 🖺 66
	Serial number		→ 🖺 67
	Order code		→ 🖺 67
	Firmware version		→ 🖺 67
	Hardware version		→ 🖺 68
	Checksum		→ 🖺 68
► Software confi	iguration	-	→ 🖺 65
	CRC device configuration		→ 🖺 65
	Stored CRC device configuration		→ 🖺 65
	Timestamp stored CRC device config.		→ 🖺 65
	Activate SW option]	→ 🖺 65
			_ 0,

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

The parameter description of the operating tool is contained in the operating tool.

Language	
Navigation	
Prerequisite	A local display is provided.
Description	Use this function to select the configured language on the local display.
Selection	■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ Bahasa Indonesia ■ tiếng Việt (Vietnamese) ■ čeština (Czech)
Factory setting	English (alternatively, the ordered language is preset in the device)

Access status display

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.

User interface • Operator

Maintenance


Additional information

Description

If the \Box -symbol appears in front of a parameter, the parameter cannot be modified via the local display with the current access authorization.

- Access authorization can be modified via the **Enter access code** parameter.
- For the **Enter access code** parameter: See the "Disabling write protection via the access code" section of the Operating Instructions for the device.
- If additional write protection is active, this restricts the current access authorization even further.

User interface



3.1 "Guidance" menu

3.1.1 "Commissioning" wizard

Navigation \Box Guidance \rightarrow Commissioning

Device tag		
Navigation		
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.	
User entry	Character string comprising numbers, letters and special characters (#32)	
Assign PV		
Navigation		
Description	Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).	
Selection	PressureScaled variable	
Assign SV		
Navigation		
Description	Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).	
Selection	 Pressure Scaled variable Sensor temperature Sensor pressure Electronics temperature Terminal current * Terminal voltage 1 * Median of pressure signal * 	

^{*} Visibility depends on order options or device settings

- Noise of pressure signal *
- Percent of range
- Loop current
- Not used

Additional information

Selection

■ Sensor pressure option

Sensor Pressure is the raw signal from sensor before damping and position adjustment.

■ **Terminal current** option

The terminal current is the read-back current on terminal block.

■ Loop current option

The loop current is the output current set by the applied pressure.

Damping			6
Navigation	阊□ Guidance →	Commissioning \rightarrow Damping	
Description	Enter damping constant. The damping constant affects the speed at which the measured value reacts to pressure changes.		
User entry	0 to 999.0 s		
Pressure unit			6
Navigation	■ Guidance →	Commissioning → Pressure un	it
Description	Use this function to	select the unit for the pipe pr	essure.
Selection	SI units MPa kPa Pa bar mbar a torr atm kgf/cm² gf/cm²	US units psi	Other units inH2O inH2O (4°C) mmH2O mmH2O (4°C) mH2O mH2O ftH2O inHg mmHg

Temperature unit

Description Use this function to select the unit for the temperature.

18

^{*} Visibility depends on order options or device settings

Selection SI units US units

■ °C

■ K

Factory setting Country-specific:

• °C • °F

Additional information Selection

Description Due to the mounting position of the measuring instrument, a pressure shift may occur.

The pressure shift can be corrected with the zero adjustment.

Guidance → Commissioning → Zero adjustment

Selection ■ No

Confirm

Pressure

Zero adjustment

Navigation

Output current transfer function

Navigation \blacksquare Guidance \rightarrow Commissioning \rightarrow Curr. trans.func

Description Linear'

The linear pressure signal is used for the current output. The flow must be calculated in

the evaluation unit.

 $\hbox{'Square root-differential pressure only'}\\$

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

Selection • Linear

Square root *

Additional information Selection

"Square root" option

Is used when a linear output porportional to the flow is required. The flow calcualtion is

done internally in the transmitter.

Visibility depends on order options or device settings

Low flow cut off

Navigation

Description When activated, this function suppresses small flows which can lead to large fluctuations

in the measured value.

0.0 to 50.0 % **User entry**

Selection

Scaled variable unit

Navigation

Description Use 'Free text', first selection, if the desired unit is not available in the selection list. It is

■ ft

■ in ■ ft³

■ OZ

■ lb ■ STon

■ lb/s ■ lb/min

■ lb/h

■ STon/min

■ STon/h

■ STon/d

■ ft³/min

gal/s (us)

qal/h (us)

qal/d (us) bbl/s (us;oil)

gal/min (us)

■ bbl/min (us;oil)

■ bbl/h (us;oil)

bbl/d (us;oil) ■ Sft³/min

■ Sft³/h

■ Sft³/d

• ft^3/s

■ ft³/h ■ ft³/d

qal (us)

bbl (us;oil)

possible to define a customer specific unit with another parameter.

SI units

- **•** %
- mm
- cm
- m
- **-** 1
- hl
- m³
- **■** q
- ka
- t
- q/s ■ kg/s
- kg/min
- kg/h
- t/min
- t/h
- t/d
- $= m^3/s$
- m³/min
- m³/h
- $= m^3/d$
- 1/s
- l/min ■ 1/h
- Nm³/h
- Nl/h
- \blacksquare Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d
- Nm^3/s
- \blacksquare q/cm³
- kg/m³

US units Imperial units

- qal (imp)
- gal/s (imp)
- qal/min (imp)
- qal/h (imp)

Custom-specific units Free text

Free text

Navigation Guidance \rightarrow Commissioning \rightarrow Free text

User entry Character string comprising numbers, letters and special characters (#32)

Scaled variable transfer function

Navigation Guidance \rightarrow Commissioning \rightarrow Scal. v. trans.

Description 'Linear'

> The linear pressure signal is used for the current output. The flow must be calculated in the evaluation unit. Deviating from the bar graph (current output), the digital value on the

display shows continues to be the eradicated value.

'Square root'

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

The output ist defined according to the scaled variable / pressure table entered.

Selection ■ Linear

Square root *

■ Table

Additional information Selection

"Square root" option

Is used when a linear output porportional to the flow is required. The flow calcualtion is

done internally in the transmitter.

Table not available

Navigation Guidance \rightarrow Commissioning \rightarrow Table not avail.

User interface Character string comprising numbers, letters and special characters (#2)

Pressure value 1

Navigation \blacksquare ■ Guidance \rightarrow Commissioning \rightarrow P. value 1

Description Enter pressure for the first scaling point. 'Scaled variable value 1' will be allocated to this

pressure.

Visibility depends on order options or device settings

User entry Signed floating-point number

Scaled variable value 1

Description Enter value for the first scaling point. This value is allocated to 'Pressure value 1'.

User entry Signed floating-point number

Pressure value 2

Description If Span is confirmed, the applied pressure is transferred to the field "Pressure value 2" and

set to 20mA. The "Pressure value 2" is assigned to the Scaled variable value 2.

User entry Signed floating-point number

Scaled variable value 2

Navigation \blacksquare Guidance \rightarrow Commissioning \rightarrow Sc. var.value 2

Description Assignment of Pressure Value 2 to Scaled Variable value 2.

User entry Signed floating-point number

Lower range value output

Navigation \blacksquare Guidance \rightarrow Commissioning \rightarrow Low.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper

range values.

Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

_				
υ	re	 211	re	2

Navigation \square Guidance \rightarrow Commissioning \rightarrow Pressure

Upper range value output

Navigation \square Guidance \rightarrow Commissioning \rightarrow Upp.range outp

Description Depending of which variable has been selected as PV, define the related lower and upper

range values.

Assignment PV value to 4 mA and 20 mA.

User entry Signed floating-point number

Scaled variable

User interface Signed floating-point number

Current range output

Navigation \Box Guidance \rightarrow Commissioning \rightarrow Cur.range outp

Description Define the current range used to transmit the measured or calculated value.

In brackets are indicated the "low saturation value" and the "high saturation value". If Measured value <= "low saturation", the output current is set to "low saturation". If Measured value >= "high saturation", the output current is set to "high saturation".

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection ■ 4...20 mA (4... 20.5 mA)

4...20 mA NE (3.8...20.5 mA)4...20 mA US (3.9...20.8 mA)

Failure behavior current output

Navigation \blacksquare Guidance \rightarrow Commissioning \rightarrow Fail.behav.out

Description Defines which current the output assumes in the case of an error.

Min: < 3.6 mA Max: >21.5 mA Selection

■ Min.

Max.

3.1.2 "SIL confirmation" wizard

Navigation $\ \ \ \ \ \ \ \$ Guidance \rightarrow SIL confirmation

Proof test via Bluetooth allowed?

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Bluetooth

Description After completition of the SIL activation/deactivation wizard, the device will be write

protected via software lock.

To use the proof test wizard (optional) where alarm currents are simulated, the device

does not have to be unlocked.

It must be defined, if the proof test wizard via Bluetooth is allowed.

Selection

No

Yes

Enter SIL locking code

Description Enter the locking code to start the SIL/WHG locking sequence.

User entry 0 to 65 535

Additional information

Locking codes

WHG: 7450SIL: 7452

■ SIL and WHG: 7454

SIL status

Navigation

User interface ■ Not active

■ SIL sequence active

Active

■ Failed

■ Finished

Character test string

Navigation Guidance \rightarrow SIL confirmation \rightarrow Char.test string

Description Check the shown character string for correct representations of the characters and digits.

User interface Character string comprising numbers, letters and special characters (#14)

Device tag


Navigation Guidance \rightarrow SIL confirmation \rightarrow Device tag

Description Displays a unique name for the measuring point so it can be identified quickly within the

plant. The name is displayed in the header.

User interface Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Additional information User interface



1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Device name

Navigation Guidance \rightarrow SIL confirmation \rightarrow Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the

transmitter.

User interface Max. 32 characters such as letters or numbers.

Serial number

Description Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information Description

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

CRC device configuration

Description CRC device configuration based on current settings of safety relevant parameters.

The CRC device configuration is unique and can be used to detect changes in safety

relevant parameter settings.

User interface 0 to 65 535

Stored CRC device configuration

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Stored CRC conf.

Description Stored CRC after the last SIL lock. Factory delivery is 65535 means that the device has not

yet been SIL locked.

User interface 0 to 65 535

Timestamp stored CRC device config.

Navigation Guidance \rightarrow SIL confirmation \rightarrow TS stored CRC

Description Gives the time stamp when the CRC was last stored following completion of the SIL-Mode

Wizard.

User interface Character string comprising numbers, letters and special characters (#20)

Operating time

Navigation Suidance \rightarrow SIL confirmation \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information Maximum time: 9 999 d (≈ 27 years)

Configuration counter

Navigation Guidance \rightarrow SIL confirmation \rightarrow Config. counter

Description Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.

- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.

- Once the counter has reached the value 65535, it restarts at 0.

User interface 0 to 65 535

Zero adjustment offset

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Zero adj. offset

Description Assigned value of zero adjustment due to mounting position.

User interface Character string comprising numbers, letters and special characters (#20)

HP/LP swap

Navigation Suidance \rightarrow SIL confirmation \rightarrow HP/LP swap

Description Assigned setting high pressure / low pressure.

User interface ■ No

■ Yes

Damping

Navigation Suidance \rightarrow SIL confirmation \rightarrow Damping

Description Assigned damping value.

User interface Character string comprising numbers, letters and special characters (#20)

Sensor pressure range behavior

Navigation Guidance \rightarrow SIL confirmation \rightarrow P-range behavior

Description Assigned event behavior in case of over/under pressure outside of measuring range.

User interface ■ Alarm

Warning

Remark

Special

Output current transfer function

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Curr. trans.func

Description Assigned transfer function for current output.

User interface ■ Linear

■ Square root

Low cutoff

Navigation Suidance \rightarrow SIL confirmation \rightarrow Low cutoff

User interface Character string comprising numbers, letters and special characters (#20)

Failure behavior current output

Description Assigned value of current output in case of an error.

User interface ■ Min.

Max.

Current range output

Navigation Guidance \rightarrow SIL confirmation \rightarrow Cur.range outp

Description Assigned current range used to transmit the measured value.

User interface ■ 4...20 mA (4... 20.5 mA)

4...20 mA NE (3.8...20.5 mA)4...20 mA US (3.9...20.8 mA)

Customer specific

Measuring mode current output

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Meas.mode outp

Description Assigned setting of curve form of current output.

User interface • Standard

■ Inverse

■ Bi-directional

Lower range value output

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow Low.range outp

Description Assigned value 4 mA.

User interface Character string comprising numbers, letters and special characters (#20)

Upper range value output

Navigation Guidance \rightarrow SIL confirmation \rightarrow Upp.range outp

Description Assigned value 20 mA.

User interface Character string comprising numbers, letters and special characters (#20)

		-
Assi	Tn	PV
1 1001	4	

Navigation Guidance \rightarrow SIL confirmation \rightarrow Assign PV

Description Identifies the process variable linked with the primary variable. Primary variable is used in

HART as current output.

User interface • Pressure

Scaled variable

Enter SIL locking code

Navigation \blacksquare Guidance \rightarrow SIL confirmation \rightarrow SIL locking code

Description Enter the locking code to start the SIL/WHG locking sequence.

User entry 0 to 65 535

Additional information Locking codes

WHG: 7450SIL: 7452

■ SIL and WHG: 7454

Code incorrect

Navigation Guidance \rightarrow SIL confirmation \rightarrow Code incorrect

Description Abort SIL confirmation sequence or reenter SIL locking code.

Selection • Reenter code

Abort sequence

Locking status

Navigation Guidance \rightarrow SIL confirmation \rightarrow Locking status

Description Displays the active write protection.

User interface • Hardware locked

■ SIL locked

■ Temporarily locked

Additional information

Selection

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter (\rightarrow $\ \ \ \ \ \ \ \ \ \ \ \ \ $
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

3.1.3 "Deactivate SIL" wizard

Guidance → Deactivate SIL Navigation

Enter SIL unlocking code		
Navigation		
Description	The SIL locking/unlocking code can be found in the corresponding safety manual.	
User entry	0 to 65 535	
Code incorrect		
Navigation		
Description	Abort SIL confirmation sequence or reenter SIL locking code.	

Endress+Hauser 31

■ Reenter code Abort sequence

Locking status

Navigation

Guidance → Deactivate SIL → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- SIL locked
- Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter (\Rightarrow \boxminus 15) applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

3.2 "Diagnostics" menu

Navigation

Diagnostics

3.2.1 "Active diagnostics" submenu

Navigation \square Diagnostics \rightarrow Active diagnos.

Active diagnostics

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Active diagnos. \rightarrow Active diagnos.

Prerequisite A diagnostic event has occurred.

Description Displays the current diagnostic message. If two or more messages occur simultaneously,

the message with the highest priority is shown on the display.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *User interface*

Additional pending diagnostic messages can be viewed in the **Diagnostic list**

submenu.

Example

For the display format:

⊗F271 Main electronic failure

Timestamp

Description Displays the operating time when the current diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information User interface

The diagnostic message can be viewed via the **Actual diagnostics** parameter (\rightarrow) 33).

Example

For the display format: 24d12h13m00s

Previous diagnostics

Navigation \blacksquare Diagnostics \rightarrow Active diagnos. \rightarrow Prev.diagnostics

Prerequisite Two diagnostic events have already occurred.

Description Displays the diagnostic message that occurred before the current message.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information User interface

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the E key.

Example

For the display format:

⊗F271 Main electronic failure

Timestamp

Navigation \square Diagnostics \rightarrow Active diagnos. \rightarrow Timestamp

Description Displays the operating time when the last diagnostic message before the current message

occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information User interface

The diagnostic message can be viewed via the **Previous diagnostics** parameter

 $(\rightarrow \stackrel{\circ}{\blacksquare} 34).$

Example

For the display format: 24d12h13m00s

Operating time from restart

Navigation \blacksquare Diagnostics \rightarrow Active diagnos. \rightarrow Time fr. restart

Description Shows the time the device has been in operation since the last device restart.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation \blacksquare Diagnostics \rightarrow Active diagnos. \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information Maximum time: 9 999 d (≈ 27 years)

3.2.2 "Minimum/maximum values" submenu

Navigation \square Diagnostics \rightarrow Min/max val.

Pressure min

Navigation \Box Diagnostics \rightarrow Min/max val. \rightarrow Pressure min

User interface Signed floating-point number

Pressure max

Navigation □□ Diagnostics → Min/max val. → Pressure max

User interface Signed floating-point number

Counter limit underruns sensor Pmin

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Counter P < Pmin

User interface 0 to 65 535

Counter limit overruns sensor Pmax

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Counter P > Pmax

User interface 0 to 65 535

Counter underruns of user limit Pmin

Navigation \square Diagnostics \rightarrow Min/max val. \rightarrow Counter < P user

User interface 0 to 65 535

Counter overruns of user limit Pmax

User interface 0 to 65 535

Reset user defined counters P and T

Selection • Cancel

lacktriangle Confirm

Minimum sensor temperature

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Min. sensor temp

User interface -273.15 to 9726.85 °C

Maximum sensor temperature

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Max. Sensor temp

User interface −273.15 to 9 726.85 °C

 $Counter\ limit\ overruns\ sensor\ Tmax$

Navigation \blacksquare Diagnostics \rightarrow Min/max val. \rightarrow Counter T > Tmax

User interface 0 to 65 535

Counter limit underruns sensor Tmin

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Counter T < Tmin

User interface 0 to 65 535

Counter underruns of user limit Tmin

Navigation \Box Diagnostics \rightarrow Min/max val. \rightarrow Counter < T user

User interface 0 to 65 535

Counter overruns of user limit Tmax

Navigation \Box Diagnostics \rightarrow Min/max val. \rightarrow Counter > T user

User interface 0 to 65 535

Minimum terminal voltage

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Min.term.volt.

User interface 0.0 to 50.0 V

Maximum terminal voltage

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Max.term.voltage

User interface 0.0 to 50.0 V

Minimum electronics temperature

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Min.electr.temp.

User interface Signed floating-point number

Maximum electronics temperature

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Min/max val. \rightarrow Max.electr.temp.

User interface Signed floating-point number

3.2.3 "Simulation" submenu

Simulation

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Simulation

Selection ■ Off

Pressure

Current output

■ Diagnostic event simulation

Value pressure simulation

Navigation \square Diagnostics \rightarrow Simulation \rightarrow Value pressure

User entry Signed floating-point number

Value current output

Navigation \blacksquare Diagnostics \rightarrow Simulation \rightarrow Val. curr.outp

Description Defines the value of the simulated output current.

User entry 3.59 to 23 mA

Diagnostic event category

Navigation \blacksquare Diagnostics \rightarrow Simulation \rightarrow Event category

Description Use this function to select the category of the diagnostic events that are displayed for the

simulation in the **Diagnostic event simulation** parameter ($\rightarrow \implies 39$).

Selection

- Sensor
- Electronics
- Configuration
- Process

Diagnostic event simulation

Navigation \blacksquare Diagnostics \rightarrow Simulation \rightarrow Diag. event sim.

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection ■ Off

Diagnostic event picklist (depends on the category selected)

Additional information

Description

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter ($\Rightarrow \triangleq 38$).

3.2.4 "Heartbeat Technology" submenu

Navigation

Diagnostics → HBT

"Heartbeat Verification" submenu

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow HBT Verification

Start verification

Navigation $\blacksquare \Box$ Diagnostics \rightarrow HBT \rightarrow HBT Verification \rightarrow Start verificat.

Description Start verification.

To carry out a complete verification, select the selection parameters individually. Once the external measured values have been recorded, verification is started using the **Start** option.

optio.

Selection

or

- Cancel
- Start

Additional information

Operating time (Verification)

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow HBT Verification \rightarrow Operating time

Description Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation $\blacksquare \blacksquare$ Diagnostics \rightarrow HBT \rightarrow HBT Verification \rightarrow Verific. result

User interface ■ Not done

PassedNot doneFailed

Status

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow HBT Verification \rightarrow Status

Description Displays the current status of the verification.

User interface ■ Done

Busy

Failed

■ Not done

"Loop diagnostics" submenu

Navigation \square Diagnostics \rightarrow HBT \rightarrow Loop diagn.

Rebuild baseline

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Reb. baseline

Description Notice

The current output is simulated.

Bridge the PLC or take other appropriate measures to prevent an erroneous triggering of

alarm messages or changes in the control loop behavior.

The baseline should be rebuilt if planned changes have been made in the loop.

Selection

NoYes

Tolerated deviation +/-

Navigation Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Toler. deviation

Description A value should be chosen to ensure that normal voltage deviations do not lead to

unwanted messages.

Default 1.5 V DC

User entry 0.5 to 3.0 V

806 Alarm delay

Navigation Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow 806 Alarm delay

User entry 0 to 60 s

Baseline status

Navigation Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Baseline status

Description 'Failed'

Means, baseline is not available or creation not possible.

'Passed'

Baseline is available.

User interface ■ Failed

Success

Loop diagnostics

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Loop diagn.

Selection • Disable

■ Enable

Terminal voltage 1

Navigation $\blacksquare \blacksquare$ Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output.

User interface 0.0 to 50.0 V

Clamping voltage lower threshold

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Lower threshold

User interface 0.0 to 50.0 V

Clamping voltage upper threshold

Navigation $\blacksquare \blacksquare$ Diagnostics \rightarrow HBT \rightarrow Loop diagn. \rightarrow Upper threshold

User interface 0.0 to 50.0 V

"Statistical Sensor Diagnostics" submenu

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow SSD

SSD: Statistical Sensor Diagnostics

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow SSD \rightarrow Stat. Sens. Diag

Description Enable or disable SSD.

After selecting 'Disable', no statistical sensor diagnosis takes place. No diagnostic messages

are output.

Selection • Disable

■ Enable

System status

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow SSD \rightarrow System status

User interface ■ Idle

No sufficient signal noise

StableNot stable

Verify System Dynamics

Signal status

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow SSD \rightarrow Signal status

User interface ■ Idle

Building BaselineVerifying BaselineVerifying baseline failed

MonitoringOut of range

Monitoring inactive

Signal noise status

Navigation \blacksquare Diagnostics \rightarrow HBT \rightarrow SSD \rightarrow Noise status

User interface ■ Idle

Building BaselineVerifying BaselineVerifying baseline failed

MonitoringOut of range

Monitoring inactive

Counter Baseline creation SSD

Navigation $\blacksquare \Box$ Diagnostics \rightarrow HBT \rightarrow SSD \rightarrow Counter Baseline

Description Specifies how often the baseline has been rebuilt.

User interface Positive integer

3.3 "Application" menu

Navigation

Application

3.3.1 "Measured values" submenu

Navigation \bigcirc Application \rightarrow Measured values

Terminal voltage 1

Description Shows the current terminal voltage that is applied at the output.

User interface 0.0 to 50.0 V

Terminal current

Navigation \blacksquare Application \rightarrow Measured values \rightarrow Terminal curr.

Description Shows the current value of the current output which is currently measured.

User interface 0 to 30 mA

Electronics temperature

Navigation \blacksquare Application \rightarrow Measured values \rightarrow Electronics temp

User interface Signed floating-point number

Pressure Navigation Application \rightarrow Measured values \rightarrow Pressure Scaled variable Navigation Application \rightarrow Measured values \rightarrow Scaled variable User interface Signed floating-point number Sensor temperature **Navigation** Application \rightarrow Measured values \rightarrow Sensor temp. User interface -273.15 to 9726.85 ℃ "Sensor" submenu 3.3.2 Navigation Application \rightarrow Sensor "Sensor calibration" submenu Navigation Application \rightarrow Sensor \rightarrow Sensor cal. Zero adjustment

Calibration offset		
Navigation		
Prerequisite	Absolute pressure sensor	
User entry	Signed floating-point number	
Zono o diverture out officet		
Zero adjustment offset		<u> </u>
Navigation		
User entry	Signed floating-point number	
Sensor Trim Reset		
Navigation		
Selection	■ No ■ Confirm	
Lower sensor trim		<u> </u>
Zower Bendor trim		
Navigation		
User entry	Signed floating-point number	
Upper sensor trim		<u> </u>
opper sensor triii		
Navigation		
User entry	Signed floating-point number	

"Sensor configuration" submenu

Application \rightarrow Sensor \rightarrow Sensor conf. **Navigation**

Output current transfer function

47

 \blacksquare Application \rightarrow Sensor \rightarrow Sensor conf. \rightarrow Curr. trans.func **Navigation**

Description 'Linear'

The linear pressure signal is used for the current output. The flow must be calculated in

the evaluation unit.

'Square root - differential pressure only'

The root flow signal is used for the current output. The 'Flow (square root)' current signal is indicated on the on-site display with a root symbol.

Selection ■ Linear

Square root *

Additional information

Damping

HP/LP swap

Selection

"Square root" option

Is used when a linear output porportional to the flow is required. The flow calcualtion is

done internally in the transmitter.

Navigation Application \rightarrow Sensor \rightarrow Sensor conf. \rightarrow Damping

Description Enter damping constant.

The damping constant affects the speed at which the measured value reacts to pressure

changes.

User entry 0 to 999.0 s

Navigation

Description With this parameter the high and low pressure side of the differential pressure transmitter

can be interchanged.

Selection No

Yes

Visibility depends on order options or device settings

Low flow cut off	
Navigation	
Description	When activated, this function suppresses small flows which can lead to large fluctuations in the measured value.
User entry	0.0 to 50.0 %
	"Wet calibration" submenu
	Navigation $\ \ \ \ \ \ \ \ \ \ $
	"Zero" wizard
	Navigation $\ \ \ \ \ \ \ \ \ \ $
Zero	
Navigation	
Selection	NoConfirm
Pressure	
Navigation	
Pressure value 1	
Navigation	
Description	Enter pressure for the first scaling point. 'Scaled variable value 1' will be allocated to this pressure.
User entry	Signed floating-point number

Lower range value outp	ut
Navigation	
Description	Depending of which variable has been selected as PV, define the related lower and upper range values. Assignment PV value to 4 mA and 20 mA.
User entry	Signed floating-point number
	"Span" wizard Navigation
Span	8
Navigation	
Selection	■ No ■ Confirm
Pressure	
Navigation	
Pressure value 2	
Navigation	
Description	If Span is confirmed, the applied pressure is transferred to the field "Pressure value 2" and set to 20mA. The "Pressure value 2" is assigned to the Scaled variable value 2.
User entry	Signed floating-point number

Upper range value output		
Navigation		Application \rightarrow Sensor \rightarrow Wet calibration \rightarrow Span \rightarrow Upp.range outp
Description	range	nding of which variable has been selected as PV, define the related lower and upper values. nment PV value to 4 mA and 20 mA.
User entry	Signe	d floating-point number

3.3.3 "HART output" submenu

"Configuration" submenu

Navigation $\ \ \ \ \ \ \ \ \$ Application \rightarrow HART output \rightarrow Configuration

HART address		
Navigation		
Description	Define the HART address of the device.	
User entry	0 to 63	
Additional information	 The measured value can only be transmitted via the current value if the address is set "0". The current is fixed at 4.0 mA for all other addresses (Multidrop mode). Only addresses in the range 0 to 15 are permitted for a system according to HART 5.0 All addresses in the range 0 to 63 are permitted for a system with HART 6.0 and high 	0.

HART short tag		
Navigation		
Description	Defines the short tag for the measuring point.	
	Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters	
User entry	Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation mark %).	.cs, @,

50

Device tag		
Navigation		
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.	
User entry	Character string comprising numbers, letters and special characters (#32)	
No. of preambles		
Navigation		
Description	Defines the number of preambles in the HART telegram.	
User entry	5 to 20	
Loop current mode		
Navigation		
Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-is a HART digital communication mode where multiple devices may share the same pawires for power and communications. In this mode the output current is fixed.	
Selection	Disable	

■ Enable

"System" menu 3.4

Navigation System

3.4.1 "Device management" submenu

Navigation System \rightarrow Device manag.

Device tag		1
Navigation	System → Device manag. → Device tag	

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

Character string comprising numbers, letters and special characters (#32) **User entry**

Locking status

Navigation

Description Displays the active write protection.

User interface Hardware locked

SIL locked

■ Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Selection

Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter ($\rightarrow \implies 15$) applies. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (e.g. via the local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Configuration counter

Navigation System \rightarrow Device manag. \rightarrow Config. counter

Description Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device
- Once the counter has reached the value 65535, it restarts at 0.

User interface 0 to 65 535

Reset device

Navigation System \rightarrow Device manag. \rightarrow Reset device

DescriptionUse this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection • Cancel

- To factory defaults
 To delivery settings
- Restart device

Additional information

Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
To factory defaults	Every parameter is reset to its factory setting.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting. This option is not visible if no customer-specific settings have been ordered.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Visibility depends on order options or device settings

3.4.2 "User management" submenu

Navigation \square System \rightarrow User manag.

User role

Description Displays the access authorization to the parameters via the operating tool.

User interface ■ Operator ■ Maintenance

Expert

Additional information

Description

Access authorization can be modified via the **Enter access code** parameter.

If additional write protection is active, this restricts the current access authorization even further.

User interface

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations

Instructions for the device.

"Change user role" wizard

Navigation \square System \rightarrow User manag. \rightarrow Change user role

Enter access code

Navigation System \rightarrow User manag. \rightarrow Change user role \rightarrow Ent. access code

Description Use this function to enter the user-specific release code to remove parameter write

protection in the operating tool.

User entry 0 to 9 999

"Change user role" wizard

Navigation System \rightarrow User manag. \rightarrow Change user role

Start

Navigation System \rightarrow User manag. \rightarrow Change user role \rightarrow Start

User interface Character string comprising numbers, letters and special characters (#14)

Password

Navigation System \rightarrow User manag. \rightarrow Change user role \rightarrow Password

Description Enter the password for the 'Maintenance' user role to get access to the functionality of this

role.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation System \rightarrow User manag. \rightarrow Change user role \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface ------

Wrong password

Password rule violated

Password accepted

Permission denied

Confirm PW mismatch

Reset password accepted

■ Invalid user role

Wrong sequence of entry

"Define password" wizard

Navigation \square System \rightarrow User manag. \rightarrow Define password

Start

Navigation System \rightarrow User manag. \rightarrow Define password \rightarrow Start

User interface Character string comprising numbers, letters and special characters (#14)

New password

Navigation System \rightarrow User manag. \rightarrow Define password \rightarrow New password

Description If the factory setting is not changed, the device works without write-protection, using

userrole 'Maintenance'. The configuration data of the device can always be modified. Once the password has been defined, write-protected devices can only be set to maintenance mode if a correct password is entered in the parameter 'Password'. A new password is valid, after it has been confirmed within the parameter 'Confirm new

A new password is valid, after it has been confirmed within the parameter 'Confirm new password'.

Any new password must consist of at least 4 and a maximum of 16 characters and can

contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation System \rightarrow User manag. \rightarrow Define password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface • ------

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Confirm new password		
Navigation		
Description	Enter the new password again to confirm.	
User entry	Character string comprising numbers, letters and special characters (#16)	
	"Change password" wizard	
	Navigation \square System \rightarrow User manag. \rightarrow Change password	
Start		
Navigation	System → User manag. → Change password → Start	
User interface	Character string comprising numbers, letters and special characters (#14)	
Old password		
Navigation	System → User manag. → Change password → Old password	
Description	Enter the current password, to subsequently change the existing password.	
User entry	Character string comprising numbers, letters and special characters (#16)	
Status password entry		
Navigation		
Description	Use this function to display the status of the password verification.	
User interface	 Wrong password Password rule violated Password accepted Permission denied Confirm PW mismatch Reset password accepted Invalid user role Wrong sequence of entry 	

New password		
Navigation		
Description	If the factory setting is not changed, the device works without write-protection, using userrole 'Maintenance'. The configuration data of the device can always be modified. Once the password has been defined, write-protected devices can only be set to maintenance mode if a correct password is entered in the parameter 'Password'. A new password is valid, after it has been confirmed within the parameter 'Confirm new password'. Any new password must consist of at least 4 and a maximum of 16 characters and can contain letters and numbers.	V
User entry	Character string comprising numbers, letters and special characters (#16)	
Confirm new password		A
Navigation		
Description	Enter the new password again to confirm.	
User entry	Character string comprising numbers, letters and special characters (#16)	
	"Delete password" wizard Navigation □ System → User manag. → Delete password	
	Travigation System > Oser manag. > Defect password	
Start		
Navigation	System → User manag. → Delete password → Start	
User interface	Character string comprising numbers, letters and special characters (#14)	
Old password		
Navigation		
Description	Enter the current password, to subsequently change the existing password.	
<u>-</u>		

Status password entry

Navigation System \rightarrow User manag. \rightarrow Delete password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Reset password" wizard

Navigation \square System \rightarrow User manag. \rightarrow Reset password

Start

Navigation System \rightarrow User manag. \rightarrow Reset password \rightarrow Start

User interface Character string comprising numbers, letters and special characters (#14)

Reset password

Navigation System \rightarrow User manag. \rightarrow Reset password \rightarrow Reset password

Description Enter a code to reset the current password.

CAUTION: Use this function only if the current password is lost. Contact your Endress

+Hauser Sales Center.

User entry Character string comprising numbers, letters and special characters (#16)

Status password entry

Navigation System \rightarrow User manag. \rightarrow Reset password \rightarrow Status pw entry

Description Use this function to display the status of the password verification.

User interface

- **----**
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Logout" wizard

Navigation \square System \rightarrow User manag. \rightarrow Logout

Start

Navigation

User interface

Character string comprising numbers, letters and special characters (#14)

User role

Navigation

Description

Displays the access authorization to the parameters via the operating tool.

User interface

- Operator
- Maintenance
- Expert

Additional information

Description



Access authorization can be modified via the ${\bf Enter\ access\ code}$ parameter.



If additional write protection is active, this restricts the current access authorization even further.

User interface



Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.4.3 "Bluetooth configuration" submenu

Navigation \square System \rightarrow Bluetooth conf.

Bluetooth activation

Navigation System \rightarrow Bluetooth conf. \rightarrow Bluetooth active

Selection • Disable

■ Enable

3.4.4 "Display" submenu

Navigation

☐ System → Display

Language

Prerequisite A local display is provided.

Description Use this function to select the configured language on the local display.

Selection • English

Deutsch

■ Français

■ Español

■ Italiano

Nederlands

Portuguesa

■ Polski

■ русский язык (Russian)

Svenska

■ Türkçe

■ 中文 (Chinese)

■ 日本語 (Japanese)

■ 한국어 (Korean)

■ Bahasa Indonesia

• tiếng Việt (Vietnamese)

• čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation \blacksquare System \rightarrow Display \rightarrow Format display

Prerequisite A local display is provided.

Description Use this function to select how the measured value is shown on the local display.

Selection ■ 1 value, max. size


■ 1 bargraph + 1 value

■ 2 values

Additional information

Description

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



• If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter.

Value 1 display

Prerequisite A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection • Pressure

Scaled variable

Current output

Sensor temperature

Percent of range

Additional information

Description

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.

The **Format display** parameter ($\rightarrow \triangleq 62$) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu.

62

Value 2 display

Navigation $\blacksquare \square$ System \rightarrow Display \rightarrow Value 2 display

Prerequisite A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection ■ None


■ Pressure

- Scaled variable
- Current output
- Sensor temperature
- Percent of range

Additional information

Description

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



Dependency

The unit of the displayed measured value is taken from the **System units** submenu.

Value 3 display	
· · · · · · · · · · · · · · · · · · ·	

Prerequisite A local display is provided.

Description Use this function to select one of the measured values shown on the local display.


Selection • None

- Pressure
- Scaled variable
- Current output
- Sensor temperature
- Percent of range

Additional information

Description

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.



Selection

The unit of the displayed measured value is taken from the **System units** submenu.

Value 4 display

Prerequisite A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection • None

- Pressure
- Scaled variableCurrent output
- Sensor temperaturePercent of range

Additional information

Description

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

The **Format display** parameter ($\rightarrow \triangleq 62$) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu.

Contrast display

Navigation System \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

Factory setting Depends on the display

Additional information

Set the contrast via the push-buttons:

■ Weaker: Press the 🖸 and 📵 buttons simultaneously

■ Stronger: Press the 🕀 and 📵 buttons simultaneously

3.4.5 "Software configuration" submenu

Navigation \square System \rightarrow Softw. config.

CRC device configuration

Navigation System \rightarrow Softw. config. \rightarrow CRC device conf.

Description CRC device configuration based on current settings of safety relevant parameters.

The CRC device configuration is unique and can be used to detect changes in safety

relevant parameter settings.

User interface 0 to 65 535

Stored CRC device configuration

Navigation System \rightarrow Softw. config. \rightarrow Stored CRC conf.

Description Stored CRC after the last SIL lock. Factory delivery is 65535 means that the device has not

yet been SIL locked.

User interface 0 to 65 535

Timestamp stored CRC device config.

Navigation System \rightarrow Softw. config. \rightarrow TS stored CRC

Description Gives the time stamp when the CRC was last stored following completion of the SIL-Mode

Wizard.

User interface Character string comprising numbers, letters and special characters (#20)

Activate SW option

Navigation System \rightarrow Softw. config. \rightarrow Activate SW opt.

Description Use this function to enter an activation code to enable an additional, ordered software

option.

User entry Max. 10-digit string of numbers.

Factory setting Depends on the software option ordered

Additional information

Description

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry



To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code from the parameter protocol.
- ► Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ If the code entered is incorrect or invalid, enter the old activation code from the parameter protocol.
- ► Have the Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option EA "Extended HistoROM"

3.4.6 "Information" submenu

Navigation		System	\rightarrow	Information
------------	--	--------	---------------	-------------

Device name		
Navigation		
Description	Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.	
User interface	Max. 32 characters such as letters or numbers.	
Manufacturer		
Navigation	System → Information → Manufacturer	
User interface	Character string comprising numbers, letters and special characters (#32)	

Serial number

Navigation System \rightarrow Information \rightarrow Serial number

Description Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information Description

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Order code 6

Navigation System \rightarrow Information \rightarrow Order code

Description Shows the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Factory setting -

Additional information Description

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

T Uses of the order code

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Firmware version

Navigation System \rightarrow Information \rightarrow Firmware version

Description Displays the device firmware version that is installed.

User interface Character string in the format xx.yy.zz

Additional information *User interface*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

TT 1	•
Hardware	version
I I I I I I I I I I I I I I I I I I I	ACTOIGH

Description Displays the hardware revision of the module.

User interface Max. 16 characters, such as letters, numbers or special characters (e.g. @, %, /)

XML build number

Navigation System \rightarrow Information \rightarrow XML build no.

User interface Positive integer

Checksum

User interface Positive integer

Deltabar PMD78B HART Index

Index

0 9	Display (Submenu)
806 Alarm delay (Parameter) 41	Document
·	Design
A	Explanation of the structure of a parameter
Access status display (Parameter)	description
Activate SW option (Parameter)	Function
Active diagnostics (Parameter)	Symbols used
Active diagnostics (Submenu)	Target audience
Application (Menu)	Document function 4
Assign SV (Parameter)	Document function
1651gii 5 v (i didilicter)	E
В	Electronics temperature (Parameter) 44
Baseline status (Parameter) 41	Enter access code (Parameter) 54
Bluetooth activation (Parameter) 61	Enter SIL locking code (Parameter) 24, 30
Bluetooth configuration (Submenu) 61	Enter SIL unlocking code (Parameter)
C	E.
C	Failure habarian aumant autuut (Paramatan)
Change paggyard (Minard)	Failure behavior current output (Parameter) 23, 28 Firmware version (Parameter) 67
Change password (Wizard)	Format display (Parameter)
Character test string (Parameter)	Free text (Parameter)
Checksum (Parameter)	Function
Clamping voltage lower threshold (Parameter) 42	see Parameter
Clamping voltage upper threshold (Parameter) 42	see i diametei
Code incorrect (Parameter)	G
Commissioning (Wizard)	Guidance (Menu)
Configuration (Submenu) 50	
Configuration counter (Parameter)	Н
Confirm new password (Parameter) 57, 58	Hardware version (Parameter) 68
Contrast display (Parameter) 64	HART address (Parameter) 50
Counter Baseline creation SSD (Parameter) 43	HART output (Submenu)
Counter limit overruns sensor Pmax (Parameter) 35	HART short tag (Parameter)
Counter limit overruns sensor Tmax (Parameter) 36	Heartbeat Technology (Submenu)
Counter limit underruns sensor Pmin (Parameter) 35	Heartbeat Verification (Submenu)
Counter limit underruns sensor Tmin (Parameter) 37	HP/LP swap (Parameter) 27, 47
Counter overruns of user limit Pmax (Parameter) 36	I
Counter overruns of user limit Tmax (Parameter) 37	Information (Submenu)
Counter underruns of user limit Pmin (Parameter) 36	(
Counter underruns of user limit Tmin (Parameter) 37	L
CRC device configuration (Parameter)	Language (Parameter)
Current range output (rarameter)	Locking status (Parameter) 30, 32, 52
D	Logout (Wizard) 60
Damping (Parameter)	Loop current mode (Parameter)
Deactivate SIL (Wizard)	Loop diagnostics (Parameter)
Define password (Wizard)	Loop diagnostics (Submenu)
Delete password (Wizard)	Low cutoff (Parameter)
Description of device parameters	Low flow cut off (Parameter)
Device management (Submenu)	Lower range value output (Parameter) 22, 29, 49 Lower sensor trim (Parameter)
Device name (Parameter)	Lower sensor timi (rarameter)40
Device tag (Parameter)	M
Diagnostic event category (Parameter)	Manufacturer (Parameter)
Diagnostic event simulation (Parameter)	Maximum electronics temperature (Parameter) 38
Diagnostics (Menu)	Maximum sensor temperature (Parameter)
Direct access	Maximum terminal voltage (Parameter) 37
Access status display	-

Index Deltabar PMD78B HART

Measured values (Submenu)	SIL status (Parameter)	
Menu	Simulation (Submenu)	38
Application	Software configuration (Submenu)	
Diagnostics	Span (Parameter)	
Guidance	Span (Wizard)	
System	SSD: Statistical Sensor Diagnostics (Parameter)	
Minimum electronics temperature (Parameter) 37	Start (Parameter)	
Minimum sensor temperature (Parameter)	Start verification (Parameter)	
Minimum terminal voltage (Parameter)	Statistical Sensor Diagnostics (Submenu)	
Minimum/maximum values (Submenu)	Status (Parameter)	
N	Status password entry (Parameter) 55, 56, 57, 5	
New password (Parameter)	Stored CRC device configuration (Parameter) 26, 6 Submenu	כט
No. of preambles (Parameter)	Active diagnostics	33
ivo. or preumotes (rurameter)	Bluetooth configuration	
0	Configuration	
Old password (Parameter) 57, 58	Device management	
Operating time (Parameter) 27, 35	Display	
Operating time (Verification) (Parameter) 40	HART output	
Operating time from restart (Parameter) 34	Heartbeat Technology	
Order code (Parameter) 67	Heartbeat Verification	
Output current transfer function (Parameter) 19, 28, 47	Information	
P	Loop diagnostics	40
	Measured values	
Parameter Structure of a parameter description (4)	Minimum/maximum values	
Structure of a parameter description 4 Password (Parameter)	Sensor	
Pressure (Parameter)	Sensor calibration	
Pressure max (Parameter)	Sensor configuration	
Pressure min (Parameter)	Simulation	
Pressure unit (Parameter)	Software configuration	
Pressure value 1 (Parameter)	Statistical Sensor Diagnostics	
Pressure value 2 (Parameter)	User management	
Previous diagnostics (Parameter)	Wet calibration	
Proof test via Bluetooth allowed? (Parameter) 24	System status (Parameter)	
R		ユノ
Rebuild baseline (Parameter)	T	
Reset device (Parameter)	Table not available (Parameter)	
Reset password (Parameter)	Target audience	
Reset password (Wizard)	Temperature unit (Parameter)	
Reset user defined counters P and T (Parameter) 36	Terminal current (Parameter)	
	Terminal voltage 1 (Parameter)	
S	Timestamp (Parameter)	
Scaled variable (Parameter) 23, 45	Timestamp stored CRC device config. (Parameter) 26, 0 Tolerated deviation +/- (Parameter)	
Scaled variable transfer function (Parameter) 21	Tolerated deviation +/- (Farameter)	41
Scaled variable unit (Parameter) 20	U	
Scaled variable value 1 (Parameter)	Upper range value output (Parameter) 23, 29,	50
Scaled variable value 2 (Parameter)	Upper sensor trim (Parameter)	
Sensor (Submenu)	User management (Submenu)	
Sensor calibration (Submenu)	User role (Parameter)	
Sensor configuration (Submenu)		
Sensor pressure range behavior (Parameter) 28	V	
Sensor temperature (Parameter)	Value 1 display (Parameter)	
Sensor Trim Reset (Parameter)	Value 2 display (Parameter)	
Serial number (Parameter)	Value 3 display (Parameter)	
Signal status (Parameter)	Value 4 display (Parameter)	
SIL confirmation (Wizard)	Value current output (Parameter)	38

Deltabar PMD78B HART Index

Value pressure simulation (Parameter)	
W	
Wet calibration (Submenu) 4	8
Wizard	
Change password 5	7
Change user role	
Commissioning	
Deactivate SIL	
Define password	6
Delete password	
Logout 6	0
Reset password 5	9
SIL confirmation	4
Span	9
Zero	8
T/	
X	_
XML build number (Parameter) 6	8
Z	
Zero (Parameter)	8
Zero (Wizard)	
Zero adjustment (Parameter) 19, 4	
Zero adjustment offset (Parameter) 27, 4	



www.addresses.endress.com