

Description of Device Parameters

Proline Promag 400

HART

Electromagnetic flowmeter




Table of contents

1 About this document	4	
1.1 Document function	4	
1.2 Target group	4	
1.3 Using this document	4	
1.3.1 Information on the document structure	4	
1.3.2 Structure of a parameter description ..	6	
1.4 Symbols used	6	
1.4.1 Symbols for certain types of information	6	
1.4.2 Symbols in graphics	7	
1.5 Documentation	7	
1.5.1 Standard documentation	7	
1.5.2 Supplementary device-dependent documentation	7	
2 Overview of the Expert operating menu	8	
3 Description of device parameters ...	11	
3.1 "System" submenu	14	
3.1.1 "Display" submenu	14	
3.1.2 "Diagnostic handling" submenu	28	
3.1.3 "Administration" submenu	37	
3.2 "Sensor" submenu	42	
3.2.1 "Measured values" submenu	43	
3.2.2 "System units" submenu	51	
3.2.3 "Process parameters" submenu	58	
3.2.4 "External compensation" submenu ...	74	
3.2.5 "Sensor adjustment" submenu	76	
3.2.6 "Calibration" submenu	83	
3.3 "Input" submenu	85	
3.3.1 "Status input 1 to n" submenu	85	
3.4 "Output" submenu	87	
3.4.1 "Current output 1" submenu	87	
3.4.2 "Pulse/frequency/switch output 1 to n" submenu	99	
3.5 "Communication" submenu	117	
3.5.1 "HART input" submenu	118	
3.5.2 "HART output" submenu	123	
3.5.3 "Web server" submenu	140	
3.5.4 "WLAN settings" wizard	143	
3.5.5 "Diagnostic configuration" submenu ..	150	
3.6 "Application" submenu	157	
3.6.1 "Totalizer 1 to n" submenu	158	
3.6.2 "Custody transfer" submenu	162	
3.7 "Diagnostics" submenu	162	
3.7.1 "Diagnostic list" submenu	166	
3.7.2 "Event logbook" submenu	170	
3.7.3 "Custody transfer logbook" submenu ..	172	
3.7.4 "Device information" submenu	172	
3.7.5 "Main electronic module + I/O module 1" submenu	176	
3.7.6 "Sensor electronic module (ISEM)" submenu	177	
3.7.7 "Display module" submenu	178	
3.7.8 "Minimum/maximum values" submenu	179	
3.7.9 "Data logging" submenu	181	
3.7.10 "Heartbeat" submenu	189	
3.7.11 "Simulation" submenu	189	
4 Country-specific factory settings ..	197	
4.1 SI units	197	
4.1.1 System units	197	
4.1.2 Full scale values	197	
4.1.3 Output current span	198	
4.1.4 Pulse value	198	
4.1.5 Switch-on point low flow cut off	199	
4.2 US units	200	
4.2.1 System units	200	
4.2.2 Full scale values	200	
4.2.3 Output current span	201	
4.2.4 Pulse value	202	
4.2.5 Switch-on point low flow cut off ...	203	
5 Explanation of abbreviated units ..	204	
5.1 SI units	204	
5.2 US units	204	
5.3 Imperial units	205	
Index	206	

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
Navigation path to the parameter via the operating tool
The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Promag D 400	BA01061D
Promag L 400	BA01062D
Promag W 400	BA01063D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Content	Documentation code
Heartbeat Verification + Monitoring application package	SD01847D
Display modules A309/A310	SD01793D
Information on Custody Transfer Measurement	SD02038D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access status (0005)	→ 13
Enter access code (0003)	→ 13
 System	→ 14
► Display	→ 14
► Diagnostic handling	→ 28
► Administration	→ 37
 Sensor	→ 42
► Measured values	→ 43
► System units	→ 51
► Process parameters	→ 58
► External compensation	→ 74
► Sensor adjustment	→ 76
► Calibration	→ 83
 Input	→ 85
► Status input	→ 85
 Output	→ 87
► Current output 1	→ 87
► Pulse/frequency/switch output 1 to n	→ 99

▶ Communication	→ 117
▶ HART input	→ 118
▶ HART output	→ 123
▶ Web server	→ 140
▶ Diagnostic configuration	→ 150
▶ WLAN settings	→ 143
▶ Application	→ 157
Reset all totalizers (2806)	→ 157
▶ Totalizer 1 to n	→ 158
▶ Custody transfer	→ 162
▶ Diagnostics	→ 162
Active diagnostics (0691)	→ 163
Previous diagnostics (0690)	→ 164
Operating time from restart (0653)	→ 165
Operating time (0652)	→ 165
▶ Diagnostic list	→ 166
▶ Event logbook	→ 170
▶ Custody transfer logbook	→ 172
▶ Device information	→ 172
▶ Mainboard module	→ 176
▶ Sensor electronic module (ISEM)	→ 177
▶ Display module	→ 178
▶ Minimum/maximum values	→ 179
▶ Data logging	→ 181

	► Heartbeat Technology	→  189
	► Simulation	→  189

3 Description of device parameters


In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access status (0005)	→ 13
Enter access code (0003)	→ 13
▶ System	→ 14
▶ Sensor	→ 42
▶ Input	→ 85
▶ Output	→ 87
▶ Communication	→ 117
▶ Application	→ 157
▶ Diagnostics	→ 162

Direct access



Navigation	Expert → Direct access (0106)
Description	Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.
User entry	0 to 65 535
Additional information	<p><i>User entry</i></p> <p>The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.</p>



A0029414

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter 00914 → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign process variable** parameter

Locking status

Navigation

Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- CT active - defined parameters
- CT active - all parameters
- Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7

Selection

Options	Description
None	The access status displayed in the Access status display parameter (→ 28) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).
CT active - defined parameters (priority 2)	<p> Only available for Promag W.</p> <p>The DIP switch for custody transfer mode is activated on the I/O module. This locks write access to defined parameters (e.g. via local display or operating tool).</p> <p> For detailed information on custody transfer mode, see the Special Documentation for the device → 7</p>

Options	Description
CT active - all parameters (priority 3)	<p> Only available for Promag W.</p> <p>The DIP switch for custody transfer mode is activated on the I/O module. This locks write access to all the parameters (e.g. via local display or operating tool).</p> <p> For detailed information on custody transfer mode, see the Special Documentation for the device → 图 7</p>
Temporarily locked (Priority 4)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status

Navigation	  Expert → Access status (0005)
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> Access authorization can be modified via the Enter access code parameter (→ 图 13).</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 图 7</p>

Enter access code

Navigation	  Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection.
User entry	Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation

Expert → System

▶ System	
▶ Display	→ 14
▶ Diagnostic handling	→ 28
▶ Administration	→ 37

3.1.1 "Display" submenu

Navigation

Expert → System → Display

▶ Display	
Display language (0104)	→ 15
Format display (0098)	→ 16
Value 1 display (0107)	→ 18
0% bargraph value 1 (0123)	→ 19
100% bargraph value 1 (0125)	→ 19
Decimal places 1 (0095)	→ 20
Value 2 display (0108)	→ 20
Decimal places 2 (0117)	→ 21
Value 3 display (0110)	→ 21
0% bargraph value 3 (0124)	→ 22
100% bargraph value 3 (0126)	→ 22
Decimal places 3 (0118)	→ 23
Value 4 display (0109)	→ 23
Decimal places 4 (0119)	→ 24
Display interval (0096)	→ 24

Display damping (0094)	→ 25
Header (0097)	→ 26
Header text (0112)	→ 26
Separator (0101)	→ 27
Contrast display (0105)	→ 27
Backlight (0111)	→ 27

Display language

Navigation

Expert → System → Display → Display language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting

English (alternatively, the ordered language is preset in the device)

* Visibility depends on order options or device settings

Format display

Navigation

  Expert → System → Display → Format display (0098)

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information

Description

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→  18) to **Value 4 display** parameter (→  23) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→  24).

Custody transfer mode



Only available for Promag W.


- Once the measuring device has been enabled for custody transfer mode, the display automatically switches to the **1 value large + 2 values** option.
- In addition, a padlock symbol appears in the header of the display ().




For detailed information on custody transfer mode, see the Special Documentation for the device →  7

Possible measured values shown on the local display:


"1 value, max. size" option




"1 bargraph + 1 value" option




"2 values" option



"1 value large + 2 values" option



"4 values" option



Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">▪ Volume flow▪ Mass flow▪ Corrected volume flow▪ Flow velocity *▪ Conductivity *▪ Corrected conductivity *▪ Electronic temperature▪ Totalizer 1▪ Totalizer 2▪ Totalizer 3▪ Current output 1▪ Noise *▪ Coil current shot time *▪ Reference electrode potential against PE *▪ Build-up measured value *▪ Test point 1▪ Test point 2▪ Test point 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Custody transfer mode</i></p> <p> Only available for Promag W.</p> <p>Once the measuring device has been enabled for custody transfer mode, the display automatically switches to the Totalizer 1 option.</p> <p> For detailed information on custody transfer mode, see the Special Documentation for the device → 7</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 51).</p>

* Visibility depends on order options or device settings

0% bargraph value 1



Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Description</i> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 51).

100% bargraph value 1



Navigation	Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 197
Additional information	<i>Description</i> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 51).

Decimal places 1



Navigation

Expert → System → Display → Decimal places 1 (0095)

Prerequisite

A measured value is defined in the **Value 1 display** parameter (→ [18](#)).

Description

Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information

Description

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Custody transfer mode

Only available for Promag W.

Once the device has been enabled for custody transfer mode, the number of decimal places for the 1st display value changes depending on the approval for custody transfer and the nominal diameter.

For detailed information on custody transfer mode, see the Special Documentation for the device → [7](#)

Value 2 display



Navigation

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 2 display** parameter (→ [20](#))

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Custody transfer mode

Only available for Promag W.

Once the measuring device has been enabled for custody transfer mode, the display automatically switches to the **Volume flow** option.



For detailed information on custody transfer mode, see the Special Documentation for the device → 7

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device.

The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display**Navigation**

Expert → System → Display → Value 3 display (0110)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 2 display** parameter (→ 20)

Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p>i The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p>i The unit of the displayed measured value is taken from the System units submenu (→ 51).</p>

0% bargraph value 3	
Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 21).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p>i The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p>i The unit of the displayed measured value is taken from the System units submenu (→ 51).</p>

100% bargraph value 3	
Navigation	Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	A selection was made in the Value 3 display parameter (→ 21).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Decimal places 3**Navigation**

Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 21).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display**Navigation**

Expert → System → Display → Value 4 display (0109)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 2 display** parameter (→ 20)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

 The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Custody transfer mode

 Only available for Promag W.

Once the measuring device has been enabled for custody transfer mode, the display automatically switches to the **Custody transfer counter** option.

 For detailed information on custody transfer mode, see the Special Documentation for the device → 7

Decimal places 4**Navigation**

  Expert → System → Display → Decimal places 4 (0119)

Prerequisite

A measured value is specified in the **Value 4 display** parameter (→ 23).

Description

Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval**Navigation**

  Expert → System → Display → Display interval (0096)

Prerequisite

A local display is provided.

Description

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ▪ The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 23) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Custody transfer mode

-  Only available for Promag W.

Once the measuring device has been enabled for custody transfer mode, the following settings change automatically:

- The value displayed for the following parameters changes:
 - **Value 1 display** parameter (→ 18): **Totalizer 1** option
 - **Value 2 display** parameter (→ 20): **Volume flow** option
 - **Value 4 display** parameter (→ 23): **Custody transfer counter** option
- The interval period changes to 10 s.

 For detailed information on custody transfer mode, see the Special Documentation for the device → 7

Display damping



Navigation   Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

 Damping is switched off if **0** is entered (factory setting).

1) proportional transmission behavior with first order delay

Header**Navigation**

Expert → System → Display → Header (0097)

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

Selection

- Device tag
 - Is defined in the **Device tag** parameter (→ 173).
- Free text
 - Is defined in the **Header text** parameter (→ 26).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 26), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting 50 %

Backlight

Navigation Expert → System → Display → Backlight (0111)

Prerequisite A local display is provided.

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting

Enable

Access status display

Navigation

Expert → System → Display → Access stat.disp (0091)

Prerequisite

A local display is provided.

Description

Displays the access authorization to the parameters via the local display.

User interface

- Operator
- Maintenance

Factory setting

Operator

Additional information

Description

If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.

 Access authorization can be modified via the **Enter access code** parameter (→ [13](#)).

 For information about the **Enter access code** parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device → [7](#)

 If additional write protection is active, this restricts the current access authorization even further.


User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

3.1.2 "Diagnostic handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay**Navigation**

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.



The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- 170 Coil resistance
- 832 Electronic temperature too high
- 833 Electronic temperature too low
- 834 Process temperature too high
- 835 Process temperature too low
- 962 Pipe empty

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 29).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 170) (Event list submenu (→ 171)) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Navigation

Expert → System → Diagn. handling → Diagn. behavior

Diagnostic behavior

Assign behavior of diagnostic no. 043
(0650)

→ 31

Assign behavior of diagnostic no. 302 (0739)	→ 31
Assign behavior of diagnostic no. 376 (0645)	→ 31
Assign behavior of diagnostic no. 377 (0777)	→ 32
Assign behavior of diagnostic no. 441 (0657)	→ 32
Assign behavior of diagnostic no. 442 (0658)	→ 32
Assign behavior of diagnostic no. 443 (0659)	→ 33
Assign behavior of diagnostic no. 531 (0741)	→ 33
Assign behavior of diagnostic no. 832 (0681)	→ 33
Assign behavior of diagnostic no. 833 (0682)	→ 34
Assign behavior of diagnostic no. 834 (0700)	→ 34
Assign behavior of diagnostic no. 835 (0702)	→ 35
Assign behavior of diagnostic no. 842 (0638)	→ 35
Assign behavior of diagnostic no. 962 (0745)	→ 35
Assign behavior of diagnostic no. 937 (0743)	→ 36
Assign behavior of diagnostic no. 938 (0642)	→ 36
Assign behavior of diagnostic no. 961 (0736)	→ 36

Assign behavior of diagnostic no. 043 (Sensor short circuit)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 043 (0650)
Description	Use this function to change the diagnostic behavior of the 043 Sensor short circuit diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 302 (Device verification active)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0739)
Description	Use this function to change the diagnostic behavior of the 302 Device verification active diagnostic message.
Selection	<ul style="list-style-type: none">■ Alarm■ Warning
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 376 (Sensor electronic (ISEM) faulty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 376 (0645)
Description	Use this function to change the diagnostic behavior of the 376 Sensor electronic (ISEM) faulty diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 377 (Sensor electronic (ISEM) faulty)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 377 (0777)

Description

Use this function to change the diagnostic behavior of the **377 Sensor electronic (ISEM) faulty** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)

Assign behavior of diagnostic no. 441 (Current output 1)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)

Description

Use this function to change the diagnostic behavior of the **441 Current output 1** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)

Assign behavior of diagnostic no. 442 (Frequency output 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the **442 Frequency output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)

Assign behavior of diagnostic no. 443 (Pulse output 1 to n)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the **443 Pulse output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)



Assign behavior of diagnostic no. 531 (Empty pipe detection)

Navigation

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531 (0741)

Description

Use this function to change the diagnostic behavior of the **531 Empty pipe detection** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)



Assign behavior of diagnostic no. 832 (Electronic temperature too high)

Navigation

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0681)

Description

Use this function to change the diagnostic behavior of the **832 Electronic temperature too high** diagnostic message.

Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Logbook entry only
Additional information	 Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 833 (Electronic temperature too low)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0682)
Description	Use this function to change the diagnostic behavior of the 833 Electronic temperature too low diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Logbook entry only
Additional information	 Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 834 (Process temperature too high)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0700)
Description	Use this function to change the diagnostic behavior of the 834 Process temperature too high diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 835 (Process temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0702)
Description	Use this function to change the diagnostic behavior of the 835 Process temperature too low diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 842



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)
Description	Change behavior of diagnostic event with diagnostic number 842 'Process limit'.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Off

Assign behavior of diagnostic no. 962 (Pipe empty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 962 (0745)
Description	Use this function to change the diagnostic behavior of the 862 Pipe empty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection: → 29

Assign behavior of diagnostic no. 937 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937 (0743)

Description

Use this function to change the diagnostic behavior of the **937 EMC interference** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection: → [29](#)

Assign behavior of diagnostic no. 938 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 938 (0642)

Description

Use this function to change the diagnostic behavior of the **938 EMC interference** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional information

Detailed description of the options available for selection: → [29](#)

Assign behavior of diagnostic no. 961**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 961 (0736)

Description

Select diagnostic behavior for the selected diagnostic number.

Selection

- Off
- Alarm
- Warning
- Logbook entry only


Factory setting

Alarm

3.1.3 "Administration" submenu

Navigation

Expert → System → Administration




"Define access code" wizard

i The **Define access code** wizard (→ 37) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (→ 39) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code



Define access code



Navigation

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry 0 to 9 999

Factory setting 0

Additional information *Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

i Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).

i If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.


Confirm access code



Navigation	Expert → System → Administration → Def. access code → Confirm code
Description	Enter the defined release code a second time to confirm the release code.
User entry	0 to 9 999
Factory setting	0

"Reset access code" submenu

Navigation Expert → System → Administration → Reset acc. code



Operating time

Navigation	Expert → System → Administration → Reset acc. code → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

Reset access code

Navigation

Expert → System → Administration → Reset acc. code → Reset acc. code (0024)

Description

Use this function to enter a reset code to reset the user-specific access codes to the factory setting .

User entry

Character string comprising numbers, letters and special characters

Factory setting

0x00

Additional information*Description*

 For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via CDI RJ45 interface)
- Fieldbus

Additional parameters in the "Administration" submenu

Define access code

**Navigation**

Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  13).

 If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Reset device**Navigation**

  Expert → System → Administration → Reset device (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *

Factory setting

Cancel

Activate SW option**Navigation**

  Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

* Visibility depends on order options or device settings

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→  41).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- ▶ If the code entered is incorrect or invalid, enter the old activation code .
- ▶ Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

 The software options currently enabled are displayed in the **Software option overview** parameter (→  41).

Web browser

 Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview**Navigation**

 Expert → System → Administration → SW option overv. (0015)

Description

Displays all the software options that are enabled in the device.

User interface

- Extended HistoROM
- PFS output 2 + status input
- Certified pulse output
- Electrode cleaning circuit
- Heartbeat Verification
- Custody transfer
- Build-up detection
- Heartbeat Monitoring

Additional information*Description*

Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"PFS output 2 + status input" option

Order code for "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"

"Certified pulse output" option

 Only available for Promag W.

Order code for "Output; input", option J "4-20mA HART, certified pulse output, switch output; status input"

"Electrode cleaning circuit" option

 Only available for Promag L and W.

Order code for "Application package", option EC "ECC electrode cleaning"

"Heartbeat Verification" option and "Heartbeat Monitoring" option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

"Custody transfer" option

The measuring device has an approval for custody transfer measurement.

 Only available for Promag W.

 Detailed information on the national and international approvals for custody transfer that are currently available can be supplied by your Endress+Hauser sales organization.

3.2 "Sensor" submenu

Navigation

  Expert → Sensor

 Sensor	
 Measured values	→  43
 System units	→  51
 Process parameters	→  58
 External compensation	→  74

▶ Sensor adjustment	→ 76
▶ Calibration	→ 83

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

▶ Measured values	
▶ Process variables	→ 43
▶ Totalizer	→ 46
▶ Input values	→ 48
▶ Output values	→ 48

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

▶ Process variables	
Volume flow (1838)	→ 43
Mass flow (1847)	→ 44
Corrected volume flow (1851)	→ 44
Flow velocity (1854)	→ 44
Conductivity (1850)	→ 44
Corrected conductivity (1853)	→ 45
Temperature (1852)	→ 45
Density (1857)	→ 45

Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description

Displays the volume flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Volume flow unit** parameter (→ [51](#))

Mass flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description Displays the mass flow that is currently calculated.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Mass flow unit** parameter (→ [55](#))

Corrected volume flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1851)

Description Displays the corrected volume flow that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Corrected volume flow unit** parameter (→ [57](#))

Flow velocity

Navigation  Expert → Sensor → Measured val. → Process variab. → Flow velocity (1854)

Description Displays the flow velocity that is currently calculated.

User interface Signed floating-point number

Conductivity

Navigation  Expert → Sensor → Measured val. → Process variab. → Conductivity (1850)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ [62](#)).

Description Displays the conductivity that is currently measured.

User interface Signed floating-point number

Additional information *Dependency*



The unit is taken from the **Conductivity unit** parameter (→ 53)

Corrected conductivity

Navigation Expert → Sensor → Measured val. → Process variab. → CorrConductivity (1853)

Prerequisite The following conditions are met:
■ The **On** option is selected in the **Conductivity measurement** parameter (→ 62).
■ The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 75).

Description Displays the conductivity that is currently corrected.

User interface Positive floating-point number

Additional information *Dependency*



The unit is taken from the **Conductivity unit** parameter (→ 53)

Temperature

Navigation Expert → Sensor → Measured val. → Process variab. → Temperature (1852)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 75).

Description Displays the temperature that is currently calculated.

User interface Positive floating-point number

Additional information *Dependency*



The unit is taken from the **Temperature unit** parameter (→ 54)

Density

Navigation Expert → Sensor → Measured val. → Process variab. → Density (1857)

Description Displays the current fixed density or density read in from an external device.

User interface Signed floating-point number


Additional information *Dependency*

 The unit is taken from the **Density unit** parameter (→ [56](#))

"Totalizer" submenu

Navigation

 Expert → Sensor → Measured val. → Totalizer



Totalizer value 1 to n



Navigation

 Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911-1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [158](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Displays the current totalizer counter reading.

User interface

Signed floating-point number

Additional information*Description*

As the operating tool can only display a maximum of 7 digits, if the display range is exceeded the current counter reading is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to n** parameter.

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 162).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 160).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 159).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1 968 457 m³
- Value in the **Totalizer overflow 1** parameter: 1 · 10⁷ (1 overflow) = 10 000 000 m³
- Current totalizer reading: 11 968 457 m³

Totalizer overflow 1 to n**Navigation**

 Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910-1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 158) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow.

The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to n** parameter.

User interface

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 159).

Example


Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m³
- Value in the **Totalizer overflow 1** parameter: $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

"Input values" submenu

Navigation

Expert → Sensor → Measured val. → Input values



Value status input

Navigation

Expert → Sensor → Measured val. → Input values → Val.stat.inp. (1353)

Prerequisite

For the following order code:

- "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"
- "Output; input", option J "4-20mA HART, certified pulse output, switch output; status input"

Description

Displays the current input signal level.


User interface

- High
- Low

"Output values" submenu

Navigation

Expert → Sensor → Measured val. → Output values



Measured current 1 (0366-1)	→ 49
Pulse output 1 (0456-1)	→ 49
Output frequency 1 (0471-1)	→ 50
Switch status 1 (0461-1)	→ 50
Output frequency 2 (0471-2)	→ 50
Pulse output 2 (0456-2)	→ 49
Switch status 2 (0461-2)	→ 50

Output current 1

Navigation	Expert → Sensor → Measured val. → Output values → Output curr. 1 (0361-1)
Description	Displays the current value currently calculated for the current output.
User interface	0 to 22.5 mA

Measured current 1


Navigation	Expert → Sensor → Measured val. → Output values → Measur. curr. 1 (0366-1)
Description	Displays the actual measured value of the output current.
User interface	0 to 30 mA

Pulse output 1 to n

Navigation	Expert → Sensor → Measured val. → Output values → Pulse output 1 (0456-1) Expert → Sensor → Measured val. → Output values → Pulse output 2 (0456-2)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 100) parameter.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number

Additional information**Description**

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 102) and **Pulse width** parameter (→ 103) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC Normally closed
 NO Normally opened

The output behavior can be reversed via the **Invert output signal** parameter (→ 117) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 104)) can be configured.

Output frequency 1 to n**Navigation**

- ④ ④ Expert → Sensor → Measured val. → Output values → Output freq. 1 (0471-1)
- ④ ④ Expert → Sensor → Measured val. → Output values → Output freq. 2 (0471-2)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Switch status 1 to n**Navigation**

- ④ ④ Expert → Sensor → Measured val. → Output values → Switch status 1 (0461-1)
- ④ ④ Expert → Sensor → Measured val. → Output values → Switch status 2 (0461-2)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Switch** option is selected.

Description

Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*Selection*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

3.2.2 "System units" submenu

Navigation Expert → Sensor → System units

► System units	
Volume flow unit (0553)	→  51
Volume unit (0563)	→  53
Conductivity unit (0582)	→  53
Temperature unit (0557)	→  54
Mass flow unit (0554)	→  55
Mass unit (0574)	→  55
Density unit (0555)	→  56
Corrected volume flow unit (0558)	→  57
Corrected volume unit (0575)	→  57
Date/time format (2812)	→  58

Volume flow unit*Navigation* Expert → Sensor → System units → Volume flow unit (0553)**Description**

Use this function to select the unit for the volume flow.

Selection

- | <i>SI units</i> | <i>US units</i> | <i>Imperial units</i> |
|------------------------|--------------------------|-----------------------|
| ■ cm ³ /s | ■ af/s | ■ gal/s (imp) |
| ■ cm ³ /min | ■ af/min | ■ gal/min (imp) |
| ■ cm ³ /h | ■ af/h | ■ gal/h (imp) |
| ■ cm ³ /d | ■ af/d | ■ gal/d (imp) |
| ■ dm ³ /s | ■ ft ³ /s | ■ Mgal/s (imp) |
| ■ dm ³ /min | ■ ft ³ /min | ■ Mgal/min (imp) |
| ■ dm ³ /h | ■ ft ³ /h | ■ Mgal/h (imp) |
| ■ dm ³ /d | ■ ft ³ /d | ■ Mgal/d (imp) |
| ■ m ³ /s | ■ MMft ³ /s | ■ bbl/s (imp;beer) |
| ■ m ³ /min | ■ MMft ³ /min | ■ bbl/min (imp;beer) |
| ■ m ³ /h | ■ MMft ³ /h | ■ bbl/h (imp;beer) |
| ■ m ³ /d | ■ Mft ³ /d | ■ bbl/d (imp;beer) |
| ■ ml/s | ■ fl oz/s (us) | ■ bbl/s (imp;oil) |
| ■ ml/min | ■ fl oz/min (us) | ■ bbl/min (imp;oil) |
| ■ ml/h | ■ fl oz/h (us) | ■ bbl/h (imp;oil) |
| ■ ml/d | ■ fl oz/d (us) | ■ bbl/d (imp;oil) |
| ■ l/s | ■ gal/s (us) | |
| ■ l/min | ■ gal/min (us) | |
| ■ l/h | ■ gal/h (us) | |
| ■ l/d | ■ gal/d (us) | |
| ■ hl/s | ■ Mgal/s (us) | |
| ■ hl/min | ■ Mgal/min (us) | |
| ■ hl/h | ■ Mgal/h (us) | |
| ■ hl/d | ■ Mgal/d (us) | |
| ■ Ml/s | ■ bbl/s (us;liq.) | |
| ■ Ml/min | ■ bbl/min (us;liq.) | |
| ■ Ml/h | ■ bbl/h (us;liq.) | |
| ■ Ml/d | ■ bbl/d (us;liq.) | |
| | ■ bbl/s (us;beer) | |
| | ■ bbl/min (us;beer) | |
| | ■ bbl/h (us;beer) | |
| | ■ bbl/d (us;beer) | |
| | ■ bbl/s (us;oil) | |
| | ■ bbl/min (us;oil) | |
| | ■ bbl/h (us;oil) | |
| | ■ bbl/d (us;oil) | |
| | ■ bbl/s (us;tank) | |
| | ■ bbl/min (us;tank) | |
| | ■ bbl/h (us;tank) | |
| | ■ bbl/d (us;tank) | |
| | ■ kgal/s (us) | |
| | ■ kgal/min (us) | |
| | ■ kgal/h (us) | |
| | ■ kgal/d (us) | |

Factory setting

Country-specific:

- l/h
- gal/min (us)

Additional information*Effect*

The selected unit applies for:
Volume flow parameter (→ 43)

Selection

 For an explanation of the abbreviated units: → 204

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Volume unit**Navigation**

 Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- Mft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- gal (us)

Additional information*Selection*

 For an explanation of the abbreviated units: → 204

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Conductivity unit**Navigation**

 Expert → Sensor → System units → Conductiv. unit (0582)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 62) parameter.

Description Use this function to select the unit for the conductivity.

Selection

SI units

- nS/cm
- μ S/cm
- μ S/m
- μ S/mm
- mS/m
- mS/cm
- S/cm
- S/m
- kS/m
- MS/m

Factory setting μ S/cm

Additional information *Effect*
The selected unit applies for:
Conductivity parameter (→ 44)

Selection

 For an explanation of the abbreviated units: → 204

Temperature unit



Navigation  Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection

SI units

- °C
- K

US units

- °F
- °R

Factory setting Country-specific:
■ °C
■ °F

Additional information *Effect*
The selected unit applies for:
■ **Maximum value** parameter (→ 180)
■ **Minimum value** parameter (→ 179)

Selection

 For an explanation of the abbreviated units: → 204

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Effect*

The selected unit applies for:

Mass flow parameter (→ 44)

Selection

For an explanation of the abbreviated units: → 204

Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter.

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

 For an explanation of the abbreviated units: → [204](#)

Customer-specific units

 The unit for the customer-specific mass is specified in the **User mass text** parameter.

Density unit**Navigation**

 Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Effect*

The selected unit applies for:

- **External density** parameter (→ [75](#))
- **Fixed density** parameter (→ [74](#))

Selection

- SD = specific density

The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

- SG = specific gravity

The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

 For an explanation of the abbreviated units: → [204](#)

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nhl/s
- Nhl/min
- Nhl/h
- Nhl/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sl/s
- Sl/min
- Sl/h
- Sl/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- MMSft³/s
- MMSft³/min
- MMSft³/h
- MMSft³/d
- Sbbl/s (us;oil)
- Sbbl/min (us;oil)
- Sbbl/h (us;oil)
- Sbbl/d (us;oil)

Imperial units

- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting

Country-specific:

- NI/h
- Sft³/h

Additional information*Selection*

For an explanation of the abbreviated units: → 204

Corrected volume unit**Navigation**

Expert → Sensor → System units → Corr. vol. unit (0575)

Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- NI
- Nhl
- Nm³
- Sl
- Sm³

US units

- Sft³
- MMSft³
- Sgal (us)
- Sbbl (us;liq.)
- Sbbl (us;oil)

Imperial units

- Sgal (imp)

Factory setting

Country-specific:

- Nm³
- Sft³

Additional information*Selection*For an explanation of the abbreviated units: → [204](#)**Date/time format****Navigation**

Expert → Sensor → System units → Date/time format (2812)

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*For an explanation of the abbreviated units: → [204](#)

3.2.3 "Process parameters" submenu

Navigation

Expert → Sensor → Process param.

► Process parameters	
Filter options (6710)	→ 59
Flow damping (6661)	→ 61
Flow override (1839)	→ 61
Conductivity measurement (6514)	→ 62
Conductivity damping (1803)	→ 62
Conductivity temperature coefficient (1891)	→ 63
Temperature damping (1886)	→ 63
Reference density (1885)	→ 63
► Low flow cut off	→ 64

▶ Empty pipe detection	→ 66
▶ Electrode cleaning circuit	→ 69
▶ Build-up detection	→ 71

Filter options**Navigation**

Expert → Sensor → Process param. → Filter options (6710)

Description

Use this function to select a filter option.

Selection

- Adaptive
- Adaptive CIP on
- Dynamic
- Dynamic CIP on
- Binomial
- Binomial CIP on

Factory setting

Binomial

Additional information*Description*

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects

the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

Selection

■ **Adaptive**

- Strong flow damping with a short output signal response time.
- Some time is needed before a stable output signal can be generated.
- Not suitable for pulsating flow as the average flow can be different here.

■ **Dynamic**

- Average flow damping with a delayed output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **Binomial**

- Weak flow damping with a short output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **CIP**

- This filter makes the **Adaptive** and **Dynamic** filter options additionally available.
- If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
- If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

Examples

Possible applications for the filters

Application	Adaptive	Adaptive CIP	Dynamic	Dynamic CIP	Binomial	Binomial CP
Pulsating flow (flow is negative intermittently)	---	---	++	--	++	
Flow changes frequently (flow is dynamic)	-	--	++	-	++	
Clear signal, fast control loop (< 1 s)	--	--	+ ¹⁾		++	
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	---	
Permanently bad signal	++	--	-	---	-	
Short and severe signal distortion after a while		++		++		
Replacement of a Promag 50/53: system damping Promag 400 = 0.5 * system damping Promag 50/53					+++	
Replacement of a Promag 10: system damping Promag 400 = system damping Promag 10 + 2			+++			
For a stable flow signal (no other requirements)	+++					

1) Value of flow damping < 6

Flow damping**Navigation**

Expert → Sensor → Process param. → Flow damping (6661)

Description

Use this function to enter a value for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

4

Additional information

Input range 0 to 15

- Value = 0: no damping
- Value = 1: minor damping
- Value = 15: strong damping

- The damping depends on the measuring period and the filter type selected.
▪ An increase or decrease in the damping depends on the application.

Effect

The damping affects the following variables of the device:

- Outputs → [87](#)
- Low flow cut off → [64](#)
- Totalizers → [158](#)

Flow override**Navigation**

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**

- The **453 Flow override** diagnostic message is output.
- Output values
 - Output: value at zero flow
 - Temperature: continues to be output
 - Totalizers 1-3: stop being totalized

The **Flow override** option can also be activated in the **Status input** submenu: **Assign status input** parameter (→ [85](#)).

Conductivity measurement



Navigation

Expert → Sensor → Process param. → Conduct. measur. (6514)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 62) parameter.

Description

Use this function to enable and disable conductivity measurement.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.

Conductivity damping



Navigation

Expert → Sensor → Process param. → Conduct. damping (1803)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 62).

Description

Use this function to enter a time constant for conductivity damping (PT1 element).

User entry

0 to 999.9 s

Factory setting

0 s

Additional information

Description

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if **0** is entered (factory setting).

2) Proportional behavior with first-order lag

Conductivity temperature coefficient**Navigation**

Expert → Sensor → Process param. → Cond. temp.coeff (1891)

Prerequisite

The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 75).

Description

Use this function to enter the temperature coefficient for the conductivity.

User entry

Signed floating-point number

Factory setting

2.1 %/K

Temperature damping**Navigation**

Expert → Sensor → Process param. → Temp. damping (1886)

Prerequisite

The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 75).

Description

Use this function to enter the time constant for temperature damping.

User entry

0 to 999.9 s

Factory setting

0 s

Reference density**Navigation**

Expert → Sensor → Process param. → Ref.density (1885)

Description

Use this function to enter a fixed value for the reference density.

User entry

Positive floating-point number

Factory setting

Country-specific:

- 1 kg/l
- 1 lb/ft³

Additional information

Dependency

The unit is taken from the **Density unit** parameter (→ 56)

"Low flow cut off" submenu**Navigation**
 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign process variable (1837)	→  64
On value low flow cutoff (1805)	→  64
Off value low flow cutoff (1804)	→  65
Pressure shock suppression (1806)	→  65

Assign process variable**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

On value low flow cutoff**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→  64).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  65.

User entry

Positive floating-point number

Factory setting


Depends on country and nominal diameter →  199

Additional information*Dependency*

 The unit depends on the process variable selected in the **Assign process variable** parameter (→  64).

Off value low flow cutoff

Navigation	Expert → Sensor → Process param. → Low flow cut off → Off value (1804)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 64).
Description	Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 64.
User entry	0 to 100.0 %
Factory setting	50 %
Additional information	<i>Example</i>



A0012887

- Q Flow
 t Time
 H Hysteresis
 A Low flow cut off active
 1 Low flow cut off is activated
 2 Low flow cut off is deactivated
 3 On value entered
 4 Off value entered

Pressure shock suppression


Navigation	Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 64).
Description	Use this function to enter the time interval for signal suppression (= active pressure shock suppression).
User entry	0 to 100 s
Factory setting	0 s
Additional information	<i>Description</i> Pressure shock suppression is enabled <ul style="list-style-type: none"> ▪ Prerequisite: Flow rate < on-value of low flow cut off ▪ Output values <ul style="list-style-type: none"> ▪ Current output: outputs the current corresponding to zero flow ▪ Flow displayed: 0 ▪ Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.




A0012888

Q	Flow
t	Time
A	Drip
B	Pressure shock
C	Pressure shock suppression active as per the time entered
D	Pressure shock suppression inactive
1	Valve closes
2	Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
3	The time entered has elapsed: pressure shock suppression is deactivated
4	The actual flow value is processed again and output
5	On-value for low flow cut off
6	Off-value for low flow cut off

"Empty pipe detection" submenu

Navigation

Expert → Sensor → Process param. → Empty pipe det.



Response time empty pipe detection (1859)	→ 67
New adjustment (6560)	→ 68
Progress (6571)	→ 68
Empty pipe adjust value (6527)	→ 68
Full pipe adjust value (6548)	→ 69
Measured value EPD (6559)	→ 69

Empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Empty pipe det. (1860)
Description	Use this function to switch empty pipe detection on and off.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

Switch point empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD (6562)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 67).
Description	Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.
User entry	0 to 100 %
Factory setting	50 %

Response time empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Response time (1859)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 67).

Description Use this function to enter the minimum length of time (debouncing time) the signal must be present for the **△S862 Pipe empty** diagnostic message to be triggered if the measuring pipe is empty or partially full.

User entry 0 to 100 s

Factory setting 1 s

New adjustment



Navigation Expert → Sensor → Process param. → Empty pipe det. → New adjustment (6560)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [67](#)).

Description For selecting whether to perform an empty pipe or full pipe adjustment.

Selection

- Cancel
- Empty pipe adjust
- Full pipe adjust

Factory setting Cancel

Progress

Navigation Expert → Sensor → Process param. → Empty pipe det. → Progress (6571)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [67](#)).

Description Use this function to view the progress.

User interface

- Ok
- Busy
- Not ok

Empty pipe adjust value



Navigation Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value (6527)

Prerequisite

- In the **Empty pipe detection** parameter (→ [67](#)), the **On** option is selected.
- Adjustment value > full pipe value.

Description Displays the adjustment value when the measuring pipe is empty.

User interface Positive floating-point number

Full pipe adjust value

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Full pipe value (6548)
Prerequisite	<ul style="list-style-type: none"> ■ In the Empty pipe detection parameter (→ 67), the On option is selected. ■ Adjustment value < empty pipe value.
Description	Displays the adjustment value when the measuring pipe is full.
User interface	Positive floating-point number

Measured value EPD

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD (6559)
Prerequisite	In the Empty pipe detection parameter (→ 67), the On option is selected.
Description	Displays the current measured value.
User interface	Positive floating-point number

"Electrode cleaning circuit" submenu*Navigation*

Expert → Sensor → Process param. → ECC

► Electrode cleaning circuit	
Electrode cleaning circuit (6528)	→ 70
ECC duration (6555)	→ 70
ECC recovery time (6556)	→ 70
ECC cleaning cycle (6557)	→ 71
ECC Polarity (6631)	→ 71

Electrode cleaning circuit**Navigation**

Expert → Sensor → Process param. → ECC → ECC (6528)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enable and disable cyclic electrode cleaning.

Selection

- Off
- On

Factory setting

Off

Additional information

Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits developing in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.

ECC duration**Navigation**

Expert → Sensor → Process param. → ECC → ECC duration (6555)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enter the duration of electrode cleaning in seconds.

User entry

0.01 to 30 s

Factory setting

2 s

ECC recovery time**Navigation**

Expert → Sensor → Process param. → ECC → ECC recov. time (6556)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.

User entry

1 to 600 s

Factory setting

5 s

ECC cleaning cycle

Navigation Expert → Sensor → Process param. → ECC → ECC clean. cycle (6557)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enter the pause duration until the next electrode cleaning.

User entry 0.5 to 168 h

Factory setting 0.7 h

ECC Polarity

Navigation Expert → Sensor → Process param. → ECC → ECC Polarity (6631)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Displays the polarity of the electrode cleaning circuit.

User interface

- Positive
- Negative

Factory setting Depends on the electrode material:

- Tantalum: **Negative** option
- Platinum, Alloy C22, stainless steel: **Positive** option

"Coating detection" submenu

Build-up detection is only available:

- In conjunction with the Promag W sensor
- In the compact device version (transmitter and sensor form a mechanical unit)
- For detailed information on build-up detection: see the Special Documentation for the **Heartbeat Verification + Monitoring** application package → 7

Navigation

Expert → Sensor → Process param. → Build-up detect.

Build-up detection

Build-up detection

→ 72

Build-up detection damping

→ 72

Build-up measured value

→ 72

Build-up limit	→ 73
Build-up limit hysteresis	→ 73

Build-up detection



Navigation Expert → Sensor → Process param. → Build-up detect. → Build-up detect. (6734)

Description Select mode for build-up detection.

- Selection**
- Off
 - Slow
 - Standard
 - Fast

Factory setting Off

Build-up detection damping

Navigation Expert → Sensor → Process param. → Build-up detect. → Build-up damping (6840)

Description Enter damping value for build-up detection.

Damping value:

- 0 = minimum damping
- 15 = maximum damping

The damping value should only be increased if the measured value is unstable.

User entry 0 to 15

Factory setting 0

Build-up measured value

Navigation Expert → Sensor → Process param. → Build-up detect. → Build-up value (12111)

Description Shows current build-up measured value.

User interface 0.0 to 100.0 %

Factory setting 0.0 %

Additional information The formation of build-up is output as a percentage in the Build-up index value (→ 72) parameter. The higher the percentage, the thicker the build-up.

Build-up index value (\rightarrow 72) = 0%

- No build-up present
- Measuring tube as-delivered state (initial value)
- Measuring tube was cleaned thoroughly after formation of build-up

Build-up index value (\rightarrow 72) = 100%

- Value for the maximum measurable build-up thickness
- The thickness of the build-up at 100% varies depending on the process
- A value of 100% should not be equated with a blocked measuring tube

The percentage indicated in the Build-up index value (\rightarrow 72) parameter does not provide direct information about the absolute thickness or the composition of the build-up. Therefore, to make optimum use of the build-up detection function, it is necessary to first compare the formation of build-up in the process, as known from experience, with the associated Build-up index value (\rightarrow 72). The aim is to determine the Build-up index value (\rightarrow 72) at the time the cleaning is usually performed.

On the basis of the Build-up index value (\rightarrow 72) during cleaning, it is possible to make a valid assessment of the condition inside the measuring tube and to plan the cleaning using the build-up limit and build-up detection hysteresis parameters.

In addition, conclusions about possible effects on neighboring processes can be drawn from the Build-up index value (\rightarrow 72).

Build-up limit

Navigation	  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up detect. \rightarrow Build-up limit (6466)
Description	Enter limit value for the build-up measured value.
User entry	0 to 100 %
Factory setting	50 %

Build-up limit hysteresis

Navigation	  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up detect. \rightarrow Buildup lim.hyst (6467)
Description	Enter hysteresis for build-up detection.
	If the value for build-up detection hysteresis is higher than the Build-up limit (\rightarrow 73), the "Build-up detected" diagnostic information is not reset until the measuring tube has been cleaned and a restart has been performed.
User entry	0 to 100 %
Factory setting	20 %

3.2.4 "External compensation" submenu

Navigation

Expert → Sensor → External comp.

► External compensation	
Density source (6615)	→ 74
Fixed density (6623)	→ 74
External density (6630)	→ 75
Temperature source (6712)	→ 75
External temperature (6673)	→ 75
Reference temperature (1816)	→ 76

Density source



Navigation

Expert → Sensor → External comp. → Density source (6615)

Description

Use this function to select the density source.

Selection

- Fixed density
- External density

Factory setting

Fixed density

Fixed density



Navigation

Expert → Sensor → External comp. → Fixed density (6623)

Prerequisite

The **Fixed density** option is selected in the **Density source** parameter (→ 74).

Description

Use this function to enter a fixed value for the density.

User entry

Positive floating-point number

Factory setting

Depends on country:

- 1 000 kg/m³
- 62 lb/ft³

Additional information

Dependency

The unit is taken from the **Density unit** parameter (→ 56)

External density

Navigation	  Expert → Sensor → External comp. → External density (6630)
Prerequisite	The External density option is selected in the Density source parameter (→ 74).
Description	Displays the density read in from the external device.
User entry	Positive floating-point number
Additional information	<i>Dependency</i>
	 The unit is taken from the Density unit parameter (→ 56)

Temperature source



Navigation	  Expert → Sensor → External comp. → Temp. source (6712)
Description	Use this function to select the temperature source.
Selection	<ul style="list-style-type: none">■ Internal temperature sensor *■ Off■ External value
Factory setting	Off

External temperature

Navigation	  Expert → Sensor → External comp. → External temp. (6673)
Prerequisite	The External value option is selected in the Temperature source parameter (→ 75).
Description	Displays the temperature read in from the external device.
User entry	Floating point number with sign
Additional information	<i>Dependency</i>
	 The unit is taken from the Temperature unit parameter (→ 54)

* Visibility depends on order options or device settings

Reference temperature**Navigation**

Expert → Sensor → External comp. → Ref. temperature (1816)

Prerequisite

The **Fixed density** option or **External density** option are selected in the **Density source** parameter (→ [74](#)).

Description

Use this function to enter a reference temperature for calculating the reference density.

User interface

-273.15 to 99 999 °C

Factory setting

Country-specific:

- +20 °C
- +68 °F

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ [54](#))

Reference density calculation

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_n : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

3.2.5 "Sensor adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm.

Sensor adjustment	
Installation direction (1809)	→ 77
Integration time (6533)	→ 77
Measuring period (6536)	→ 77
Process variable adjustment	→ 77

Installation direction**Navigation**

Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description

Use this function to change the sign of the medium flow direction.

Selection

- Flow in arrow direction
- Flow against arrow direction

Factory setting

Flow in arrow direction

Additional information*Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time**Navigation**

Expert → Sensor → Sensor adjustm. → Integration time (6533)

Description

Displays the duration of the integration time.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface

1 to 65 ms

Measuring period**Navigation**

Expert → Sensor → Sensor adjustm. → Measuring period (6536)

Description

Display the time of a full measuring period.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface

2 to 1000 ms

"Process variable adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm. → Variable adjust

▶ Process variable adjustment

Volume flow offset (1831)

→ 79

Volume flow factor (1832)	→ 78
Mass flow offset (1841)	→ 79
Mass flow factor (1846)	→ 79
Conductivity offset (1848)	→ 80
Conductivity factor (1849)	→ 80
Corrected volume flow offset (1866)	→ 80
Corrected volume flow factor (1867)	→ 81
Temperature offset (1868)	→ 81
Temperature factor (1869)	→ 81
Corrected conductivity offset (1870)	→ 82
Corrected conductivity factor (1871)	→ 82
Flow velocity offset (1879)	→ 82
Flow velocity factor (1880)	→ 83

Volume flow factor



Navigation

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information

Description

Corrected value = (factor × value) + offset

Volume flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)
Description	Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m ³ /s.
User entry	Signed floating-point number
Factory setting	0 m ³ /s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Mass flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Mass flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.
User entry	Signed floating-point number
Factory setting	0 kg/s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Conductivity offset



Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset (1848)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 62).

Description Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m.

User entry Signed floating-point number

Factory setting 0 S/m

Additional information *Description*

Corrected value = (factor × value) + offset

Conductivity factor



Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor (1849)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 62).

Description Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

Corrected volume flow offset



Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1866)

Description Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm³/s.

User entry Signed floating-point number

Factory setting 0 Nm³/s

Additional information *Description*

Corrected value = (factor × value) + offset

Corrected volume flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1867)
Description	Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1868)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1869)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.offset (1870)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 62) parameter.
Description	Use this function to enter the zero point shift to trim the corrected conductivity. The conductivity unit on which the shift is based is $\mu\text{S}/\text{cm}$.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.factor (1871)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 62) parameter.
Description	Use this function to enter a quantity factor for the corrected conductivity. In each case, this factor refers to the conductivity in $\mu\text{S}/\text{cm}$.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Flow velocity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. offset (1879)
Description	Use this function to enter the zero point shift for the flow velocity trim. The flow velocity unit on which the shift is based is m/s.
User entry	Signed floating-point number
Factory setting	0 m/s

Additional information	Description
	 Corrected value = (factor × value) + offset

Flow velocity factor

Navigation  Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. factor (1880)

Description Use this function to enter a quantity factor (without time) for the flow velocity. This multiplication factor is applied over the flow velocity range.


User entry Positive floating-point number

Factory setting 1

Additional information	Description
	 Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu

Navigation  Expert → Sensor → Calibration

**Nominal diameter**

Navigation  Expert → Sensor → Calibration → Nominal diameter (2807)

Description Displays the nominal diameter of the sensor.

User interface DNxx / x"

Factory setting Depends on the size of the sensor

Additional information*Description*

The value is also specified on the sensor nameplate.

Calibration factor

Navigation Expert → Sensor → Calibration → Cal. factor (6522)

Description Displays the current calibration factor for the sensor.

User interface Positive floating-point number

Factory setting Depends on nominal diameter and calibration.

Zero point



Navigation Expert → Sensor → Calibration → Zero point (6546)

Description This function shows the zero point correction value for the sensor.

User interface Signed floating-point number

Factory setting Depends on nominal diameter and calibration

Conductivity calibration factor



Navigation Expert → Sensor → Calibration → Cond. cal. fact. (6718)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 62) parameter.


Description Displays the calibration factor for the conductivity measurement.

User interface 0.01 to 10 000

3.3 "Input" submenu

Navigation


Expert → Input



3.3.1 "Status input 1 to n" submenu

Navigation

Expert → Input → Status input 1 to n



Assign status input



Navigation

Expert → Input → Status input → Assign stat.inp. (1352)

Description

Use this function to select the function for the status input.

Selection

- Off
- Reset totalizer 1
- Reset totalizer 2
- Reset totalizer 3
- Reset all totalizers
- Flow override

Factory setting

Off

Additional information

Custody transfer mode

Only available for Promag W.

NOTE!

Before enabling the measuring device for custody transfer mode, make sure that the **Off** option is selected in the Assign status input.

For detailed information on custody transfer mode, see the Special Documentation for the device → [7](#)

Additional information*Selection*

- Off
The status input is switched off.
- Reset totalizer 1...3
The individual totalizers are reset.
- Reset all totalizers
All totalizers are reset.
- Flow override
The Flow override (→ 61) is activated.



Note on the Flow override (→ 61):

- The Flow override (→ 61) is enabled as long as the level is at the status input (continuous signal).
- All other assignments react to a change in level (pulse) at the status input.

Value status input**Navigation**

Expert → Input → Status input → Val.stat.inp. (1353)

Prerequisite

For the following order code:

- "Output; input", option I "4-20mA HART, 2x pul./freq./switch output; status input"
- "Output; input", option J "4-20mA HART, certified pulse output, switch output; status input"

Description

Displays the current input signal level.

User interface

- High
- Low

Active level**Navigation**

Expert → Input → Status input → Active level (1351)

Description

Use this function to determine the input signal level at which the assigned function is activated.

Selection

- High
- Low

Factory setting

High

Response time status input**Navigation**

Expert → Input → Status input → Response time (1354)

Description

Use this function to enter the minimum time period for which the input signal level must be present before the selected function is activated.


User entry 5 to 200 ms

Factory setting 50 ms

3.4 "Output" submenu

Navigation


Expert → Output



3.4.1 "Current output 1" submenu

Navigation

Expert → Output → Curr.output 1



Assign current output 1**Navigation**

Expert → Output → Curr.output 1 → Assign curr. 1 (0359-1)

Description

Use this function to select a process variable for the current output.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Volume flow

Current span**Navigation**

Expert → Output → Curr.output 1 → Current span (0353-1)

Description

Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

Selection

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)
- Fixed current

Factory setting

Country-specific:

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

* Visibility depends on order options or device settings

Additional information*Description*


- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 97).
- If the measured value is outside the measuring range, the **△S441 Current output 1** diagnostic message is displayed.
- The measuring range is specified via the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91).

"Fixed current" option

- This option is used for a HART Multidrop network.
- It can only be used for the 4...20 mA HART current output (current output 1).
- The current value is set via the **Fixed current** parameter (→ 89).

Example

Shows the relationship between the current range for the output of the process value and the lower and upper alarm levels:



- 1 Current range for process value
2 Lower level for signal on alarm
3 Upper level for signal on alarm

Selection

Selection	1	2	3
4...20 mA NAMUR (3.8...20.5 mA)	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US (3.9...20.8 mA)	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA (4... 20.5 mA)	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA (0... 20.5 mA)	0 to 20.5 mA	< 0 mA	> 21.95 mA

- If the flow exceeds or falls below the upper or lower signal on alarm level, the **△S441 Current output 1** diagnostic message is displayed.

Fixed current**Navigation**

Expert → Output → Curr.output 1 → Fixed current (0365-1)

Prerequisite

The **Fixed current** option is selected in the **Current span** parameter (→ 88).

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

0/4 mA value**Navigation**

Expert → Output → Curr.output 1 → 0/4 mA value (0367-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 88):

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a value for the 0/4 mA current.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 88). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 91).

Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 88).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 88)
- Measuring mode (→ 92)
- Failure mode (→ 97)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measurement mode with **Forward flow** option

- **0/4 mA value** parameter (→ 90) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 91) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




Q Flow
I Current

1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91). If the effective flow exceeds or falls below this operational range, the **△S441 Current output 1** diagnostic message is displayed.

Configuration example B

Measurement mode with **Forward/Reverse flow** option



A0013758

- I* Current
- Q* Flow
- 1 Value assigned to the 0/4 mA current
- 2 Forward flow
- 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91) must have the same algebraic sign. The value for the **20 mA value** parameter (→ 91) (e.g. reverse flow) corresponds to the mirrored value for the **0/4 mA value** parameter (→ 90) (e.g. flow).

Configuration example C

Measurement mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → 92.

20 mA value



Navigation

Expert → Output → Curr.output 1 → 20 mA value (0372-1)

Prerequisite

In the **Current span** parameter (→ 88), one of the following options is selected:

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → 197

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 88). In addition, the value can be greater

than or smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→ 90).

Dependency

 The unit depends on the process variable selected in the **Assign current output** parameter (→ 88).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse flow** option is selected in the **Measuring mode** parameter (→ 92), different signs cannot be entered for the values of the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91). The **△S441 Current output 1** diagnostic message is displayed.

Configuration examples

 Observe the configuration examples for the **0/4 mA value** parameter (→ 90).

Measuring mode



Navigation

 Expert → Output → Curr.output 1 → Measuring mode (0351-1)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 88):

- Volume flow
- Mass flow
- Flow velocity

One of the following options is selected in the **Current span** parameter (→ 88):

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse flow *
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Description

 The process variable that is assigned to the current output via the **Assign current output** parameter (→ 88) is displayed below the parameter.

"Forward flow" option


The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.

* Visibility depends on order options or device settings

The flow components outside the scaled measuring range are taken into account for signal output as follows:

- Both values are defined such that they are not equal to zero flow e.g.:
 - 0/4 mA current value = $-5 \text{ m}^3/\text{h}$
 - 20 mA current value = $10 \text{ m}^3/\text{h}$
- If the effective flow exceeds or falls below this measuring range, the **△S441 Current output 1** diagnostic message is displayed.

"Forward/Reverse flow" option



- | | |
|---|--------------------------------------|
| I | Current |
| Q | Flow |
| 1 | Value assigned to the 0/4 mA current |
| 2 | Forward flow |
| 3 | Reverse flow |

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91) must have the same sign.
- The value for the **20 mA value** parameter (→ 91) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 91) (e.g. forward flow).

"Reverse flow compensation" option

The **Reverse flow compensation** option is primarily used to compensate for abrupt reverse flow that can occur with positive displacement pumps as a result of wear or high viscosity. The reverse flow is recorded in a buffer memory and offset against the next forward flow.

If buffering cannot be processed within approx. 60 s, the **△S441 Current output 1** diagnostic message is displayed.


In the event of prolonged and undesired reverse flow, flow values can accumulate in the buffer memory. Due to the configuration of the current output, these values are not factored in, however, i.e. there is no compensation for the reverse flow.

If this option is set, the measuring device does not smoothen the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1


Defined measuring range: lower range value and upper range value with the **same** sign

**Fig 2 Measuring range***I* Current*Q* Flow


1 Lower range value (value assigned to 0/4 mA current)

2 Upper range value (value assigned to 20 mA current)


With the following flow response:

**Fig 3 Flow response***Q* Flow*t* TimeWith **Forward flow** option


The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output:

*I* Current*t* TimeWith **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.

*I* Current*t* TimeWith **Reverse flow compensation** option

Flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.



I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different** signs





Fig 4 Measuring range

I Current
 Q Flow
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)


With flow a (--) outside, b (- -) inside the measuring range



Q Flow
 t Time
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

- a (--): The flow components outside the scaled measuring range cannot be taken into account for signal output.
The **△S441 Current output 1** diagnostic message is output.
- b (- -): The current output signal is proportional to the process variable assigned.




I Current
t Time

With Forward/Reverse flow option

This option cannot be selected here since the values for the **0/4 mA value** parameter (→ 90) and **20 mA value** parameter (→ 91) have different algebraic signs.

With Reverse flow compensation option

Flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.



I Current
t Time
S Flow components saved
A Balancing of saved flow components

Damping output 1



Navigation

Expert → Output → Curr.output 1 → Damping out. 1 (0363-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ 88) and one of the following options is selected in the **Current span** parameter (→ 88):

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

1.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element³⁾) for current output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

Failure mode**Navigation**

Diagram: Expert → Output → Curr.output 1 → Failure mode (0364-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ 88) and one of the following options is selected in the **Current span** parameter (→ 88):

- 4...20 mA NAMUR (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

Factory setting

Max.

3) proportional transmission behavior with first order delay

Additional information**Description**

 This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→ 88).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→ 88).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (→ 98).

Failure current**Navigation**

 Expert → Output → Curr.output 1 → Failure current (0352-1)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (→ 97).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output current 1**Navigation**

 Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)

Description

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measured current 1

Navigation Expert → Output → Curr.output 1 → Measur. curr. 1 (0366-1)

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA

3.4.2 "Pulse/frequency/switch output 1 to n" submenu

Navigation

Expert → Output → PFS output 1 to n

► Pulse/frequency/switch output 1 to n	
Operating mode (0469-1 to n)	→ 100
Assign pulse output 1 to n (0460-1 to n)	→ 102
Pulse scaling (0455-1 to n)	→ 102
Pulse width (0452-1 to n)	→ 103
Measuring mode (0457-1 to n)	→ 104
Failure mode (0480-1 to n)	→ 104
Pulse output 1 to n (0456-1 to n)	→ 105
Assign frequency output (0478-1 to n)	→ 106
Minimum frequency value (0453-1 to n)	→ 106
Maximum frequency value (0454-1 to n)	→ 106
Measuring value at minimum frequency (0476-1 to n)	→ 107
Measuring value at maximum frequency (0475-1 to n)	→ 107
Measuring mode (0479-1 to n)	→ 108
Damping output 1 to n (0477-1 to n)	→ 108

Response time (0491-1 to n)	→ 109
Failure mode (0451-1 to n)	→ 109
Failure frequency (0474-1 to n)	→ 110
Output frequency 1 to n (0471-1 to n)	→ 110
Switch output function (0481-1 to n)	→ 111
Assign diagnostic behavior (0482-1 to n)	→ 111
Assign limit (0483-1 to n)	→ 112
Switch-on value (0466-1 to n)	→ 114
Switch-off value (0464-1 to n)	→ 114
Assign flow direction check (0484-1 to n)	→ 115
Assign status (0485-1 to n)	→ 115
Switch-on delay (0467-1 to n)	→ 115
Switch-off delay (0465-1 to n)	→ 116
Failure mode (0486-1 to n)	→ 116
Switch status 1 to n (0461-1 to n)	→ 116
Invert output signal (0470-1 to n)	→ 117

Operating mode



Navigation

Expert → Output → PFS output 1 to n → Operating mode (0469-1 to n)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse *
- Frequency *
- Switch *

Factory setting

Pulse

* Visibility depends on order options or device settings

Additional information**"Pulse" option**

Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass or volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s




Fig. 5 Quantity-dependent pulse (pulse value) with configurable pulse width

B Pulse width entered

P Pauses between the individual pulses

"Frequency" option

Flow-dependent frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as mass flow, volume flow, flow velocity, conductivity or electronic temperature.

Example

- Flow approx. 100 g/s
- Max. frequency 10 kHz
- Flow at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz





Fig. 6 Flow-dependent frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




A0026884

图 7 No alarm, high level

Example

Alarm response in case of alarm



A0026885

图 8 Alarm, low level

Assign pulse output 1 to n**Navigation**

图 2 Expert → Output → PFS output 1 to n → Assign pulse 1 to n (0460-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 图 100).**Description**

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Off

Pulse scaling**Navigation**

图 2 Expert → Output → PFS output 1 to n → Pulse scaling (0455-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 图 100) and a process variable is selected in the **Assign pulse output** parameter (→ 图 102).**Description**

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating point number

Factory setting

Depends on country and nominal diameter → 图 198

Additional information*User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width**Navigation**

Expert → Output → PFS output 1 to n → Pulse width (0452–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 100) and a process variable is selected in the **Assign pulse output** parameter (→ 102).

Description

Use this function to enter the duration of the output pulse.

User entry


0.05 to 2 000 ms

Factory setting

100 ms

Additional information*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the **443 Pulse output 1 to n** diagnostic message.



B Pulse width entered

P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode



Navigation

Expert → Output → PFS output 1 to n → Measuring mode (0457–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse output** parameter (→ 102):

- Mass flow
- Volume flow

Description

Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Selection

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Reverse flow compensation
The flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

For a detailed description of the options available, see the **Measuring mode** parameter (→ 92)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 92)

Failure mode



Navigation

Expert → Output → PFS output 1 to n → Failure mode (0480–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 100) and a process variable is selected in the **Assign pulse output** parameter (→ 102).

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

*Selection***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output 1 to n**Navigation**

Diagram Expert → Output → PFS output 1 to n → Pulse output 1 to n (0456–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 100) parameter.

Description

Displays the pulse frequency currently output.


User interface

Positive floating-point number

Additional information*Description***■ The pulse output is an open collector output.**

This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.

The **Value per pulse** parameter (→ 102) and **Pulse width** parameter (→ 103) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0028726

- 0 Non-conductive
- 1 Conductive
- NC NC contact (normally closed)
- NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 117) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 104)) can be configured.

Assign frequency output



Navigation	Expert → Output → PFS output 1 to n → Assign freq. (0478–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100).
Description	Use this function to select the process variable for the frequency output.
Selection	<ul style="list-style-type: none">▪ Off▪ Volume flow▪ Mass flow▪ Corrected volume flow▪ Flow velocity *▪ Conductivity *▪ Corrected conductivity *▪ Temperature *▪ Electronic temperature▪ Noise *▪ Coil current shot time *▪ Reference electrode potential against PE *▪ Build-up measured value *▪ Test point 1▪ Test point 2▪ Test point 3
Factory setting	Off

Minimum frequency value



Navigation	Expert → Output → PFS output 1 to n → Min. freq. value (0453–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100) and a process variable is selected in the Assign frequency output parameter (→ 106).
Description	Use this function to enter the minimum frequency.
User entry	0.0 to 10 000.0 Hz
Factory setting	0.0 Hz

Maximum frequency value



Navigation	Expert → Output → PFS output 1 to n → Max. freq. value (0454–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100) and a process variable is selected in the Assign frequency output parameter (→ 106).

* Visibility depends on order options or device settings

Description	Use this function to enter the end value frequency.
User entry	0.0 to 10 000.0 Hz
Factory setting	10 000.0 Hz

Measuring value at minimum frequency



Navigation	Expert → Output → PFS output 1 to n → Val. at min.freq (0476–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100) and a process variable is selected in the Assign frequency output parameter (→ 106).
Description	Use this function to enter the measured value for the start value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i> The entry depends on the process variable selected in the Assign frequency output parameter (→ 106).

Measuring value at maximum frequency



Navigation	Expert → Output → PFS output 1 to n → Val. at max.freq (0475–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100) and a process variable is selected in the Assign frequency output parameter (→ 106).
Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Description</i> Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency. <i>Dependency</i> The entry depends on the process variable selected in the Assign frequency output parameter (→ 106).

Measuring mode



Navigation

Expert → Output → PFS output 1 to n → Measuring mode (0479–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Frequency** option is selected, and one of the following options is selected in the **Assign frequency output** parameter (→ 106):

- Volume flow
- Mass flow
- Flow velocity
- Conductivity *
- Electronic temperature

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Selection

For a detailed description of the options available, see the **Measuring mode** parameter (→ 92)

Examples

For a detailed description of the configuration examples, see the **Measuring mode** parameter (→ 92)

Damping output 1 to n



Navigation

Expert → Output → PFS output 1 to n → Damping out. 1 to n (0477–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Frequency** option is selected, and one of the following options is selected in the **Assign frequency output** parameter (→ 106):

- Volume flow
- Mass flow
- Flow velocity
- Conductivity *
- Electronic temperature

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

* Visibility depends on order options or device settings

Additional information*User entry*

Use this function to enter a time constant (PT1 element⁴⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time**Navigation**

Expert → Output → PFS output 1 to n → Response time (0491–1 to n)

Prerequisite

In the **Operating mode** parameter (→ [100](#)), the **Frequency** option is selected, and one of the following options is selected in the **Assign frequency output** parameter (→ [106](#)):

- Volume flow
- Mass flow
- Flow velocity
- Conductivity*
- Electronic temperature

Description

Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

Additional information*Description*

The response time is made up of the time specified for the following dampings:

- Damping of pulse/frequency/switch output → [96](#)
and
- Depending on the measured variable assigned to the output.
Flow damping

Failure mode**Navigation**

Expert → Output → PFS output 1 to n → Failure mode (0451–1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ [100](#)) and a process variable is selected in the **Assign frequency output** parameter (→ [106](#)).

Description

Use this function to select the failure mode of the frequency output in the event of a device alarm.

⁴⁾ proportional transmission behavior with first order delay
* Visibility depends on order options or device settings

Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz
Factory setting	0 Hz
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored. ▪ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→ 110) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm. ▪ 0 Hz In the event of a device alarm, the frequency output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Failure frequency



Navigation	Expert → Output → PFS output 1 to n → Failure freq. (0474–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 100) and a process variable is selected in the Assign frequency output parameter (→ 106).
Description	Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.
User entry	0.0 to 12 500.0 Hz
Factory setting	0.0 Hz

Output frequency 1 to n

Navigation	Expert → Output → PFS output 1 to n → Output freq. 1 to n (0471–1 to n)
Prerequisite	In the Operating mode parameter (→ 100), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz

Switch output function

Navigation Expert → Output → PFS output 1 to n → Switch out funct (0481–1 to n)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (→ 100) parameter.

Description Use this function to select a function for the switch output.

- Selection**
- Off
 - On
 - Diagnostic behavior
 - Limit
 - Flow direction check
 - Status

Factory setting Off

Additional information *Selection*

- Off
The switch output is permanently switched off (open, non-conductive).
- On
The switch output is permanently switched on (closed, conductive).
- Diagnostic behavior
Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.
- Limit
Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.
- Flow direction check
Indicates the flow direction (forward or reverse flow).
- Status
Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior

Navigation Expert → Output → PFS output 1 to n → Assign diag. beh (0482–1 to n)

Prerequisite

- In the **Operating mode** parameter (→ 100), the **Switch** option is selected.
- In the **Switch output function** parameter (→ 111), the **Diagnostic behavior** option is selected.

Description Use this function to select the diagnostic event category that is displayed for the switch output.

- Selection**
- Alarm
 - Alarm or warning
 - Warning

Factory setting Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to n → Assign limit (0483–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Limit** option is selected in the **Switch output function** parameter (→ 111).

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Temperature *
- Electronic temperature

Factory setting


Volume flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive

* Visibility depends on order options or device settings




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



A0026893

- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value**Navigation**

Expert → Output → PFS output 1 to n → Switch-on value (0466–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Limit** option is selected in the **Switch output function** parameter (→ 111).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 112).

Switch-off value**Navigation**

Expert → Output → PFS output 1 to n → Switch-off value (0464–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Limit** option is selected in the **Switch output function** parameter (→ 111).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 112).

Assign flow direction check



Navigation Expert → Output → PFS output 1 to n → Assign dir.check (0484-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Flow direction check** option is selected in the **Switch output function** parameter (→ 111).

Description Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting Volume flow

Assign status



Navigation Expert → Output → PFS output 1 to n → Assign status (0485-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Status** option is selected in the **Switch output function** parameter (→ 111).

Description Use this function to select a device status for the switch output.

Selection

- Empty pipe detection
- Low flow cut off
- Build-up detection *

Factory setting Empty pipe detection

Additional information *Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay



Navigation Expert → Output → PFS output 1 to n → Switch-on delay (0467-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 100).
- The **Limit** option is selected in the **Switch output function** parameter (→ 111).

Description Use this function to enter a delay time for switching on the switch output.

User entry 0.0 to 100.0 s

* Visibility depends on order options or device settings

Factory setting	0.0 s
-----------------	-------

Switch-off delay



Navigation	Expert → Output → PFS output 1 to n → Switch-off delay (0465–1 to n)
Prerequisite	<ul style="list-style-type: none">■ The Switch option is selected in the Operating mode parameter (→ 100).■ The Limit option is selected in the Switch output function parameter (→ 111).
Description	Use this function to enter a delay time for switching off the switch output.
User entry	0.0 to 100.0 s
Factory setting	0.0 s

Failure mode



Navigation	Expert → Output → PFS output 1 to n → Failure mode (0486–1 to n)
Description	Use this function to select a failsafe mode for the switch output in the event of a device alarm.
Selection	<ul style="list-style-type: none">■ Actual status■ Open■ Closed
Factory setting	Open
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ Actual status In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The Actual status option behaves in the same way as the current input value.■ Open In the event of a device alarm, the switch output's transistor is set to non-conductive.■ Closed In the event of a device alarm, the switch output's transistor is set to conductive.

Switch status 1 to n

Navigation	Expert → Output → PFS output 1 to n → Switch status 1 to n (0461–1 to n)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 100).
Description	Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information

User interface

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal

Navigation Expert → Output → PFS output 1 to n → Invert outp.sig. (0470-1 to n)


Description Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting No

Additional information *Selection*
No option (passive - negative)




Yes option (passive - positive)



3.5 "Communication" submenu

Navigation Expert → Communication



▶ Web server	→ 140
▶ Diagnostic configuration	→ 150
▶ WLAN settings	→ 143

3.5.1 "HART input" submenu

Navigation

Expert → Communication → HART input

▶ HART input	
▶ Configuration	→ 118
▶ Input	→ 123

"Configuration" submenu

Navigation

Expert → Communication → HART input → Configuration

▶ Configuration	
Capture mode (7001)	→ 118
Device ID (7007)	→ 119
Device type (7008)	→ 119
Manufacturer ID (7009)	→ 120
Burst command (7006)	→ 120
Slot number (7010)	→ 121
Timeout (7005)	→ 121
Failure mode (7011)	→ 122
Failure value (7012)	→ 122

Capture mode



Navigation

Expert → Communication → HART input → Configuration → Capture mode (7001)

Description

Use this function to select the capture mode via burst or master communication.

Selection	<ul style="list-style-type: none"> ■ Off ■ Burst network ■ Master network
Factory setting	Off
Additional information	<p><i>"Burst network" option</i> The device records data transmitted via burst in the network.</p> <p><i>"Master network" option</i> In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.</p>

Device ID		
Navigation	 Expert → Communication → HART input → Configuration → Device ID (7007)	
Prerequisite	The Master network option is selected in the Capture mode parameter (→  118).	
Description	Use this function to enter the device ID of the HART slave device whose data are to be recorded.	
User entry	<p>6-digit value:</p> <ul style="list-style-type: none"> ■ Via local operation: enter as hexadecimal or decimal number ■ Via operating tool: enter as decimal number 	
Factory setting	0	
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.	

Device type		
Navigation	 Expert → Communication → HART input → Configuration → Device type (7008)	
Prerequisite	In the Capture mode parameter (→  118), the Master network option is selected.	
Description	Use this function to enter the device type of the HART slave device whose data are to be recorded.	
User entry	2-digit hexadecimal number	
Factory setting	0x00	
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.	

Manufacturer ID

Navigation Expert → Communication → HART input → Configuration → Manufacturer ID (7009)

Prerequisite The **Master network** option is selected in the **Capture mode** parameter (→ 118).

Description Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.

User entry 2-digit value:

- Via local operation: enter as hexadecimal or decimal number
- Via operating tool: enter as decimal number

Factory setting 0

Additional information In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Burst command

Navigation Expert → Communication → HART input → Configuration → Burst command (7006)

Prerequisite The **Burst network** option or the **Master network** option are selected in the **Capture mode** parameter (→ 118).

Description Use this function to select the burst command to be recorded.

Selection

- Command 1
- Command 3
- Command 9
- Command 33

Factory setting Command 1

Additional information *Selection*

- Command 1
Use this function to capture the primary variable.
- Command 3
Use this function to capture the dynamic HART variables and the current.
- Command 9
Use this function to capture the dynamic HART variables including the associated status.
- Command 33
Use this function to capture the dynamic HART variables including the associated unit.

Slot number**Navigation**

Expert → Communication → HART input → Configuration → Slot number (7010)

Prerequisite

The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→ 118).

Description

Use this function to enter the position of the process variable to be recorded in the burst command.

User entry

1 to 8

Factory setting

1

Additional information

User entry

Slot	Command			
	1	3	9	33
1	PV	PV	HART variable (slot 1)	HART variable (slot 1)
2	–	SV	HART variable (slot 2)	HART variable (slot 2)
3	–	TV	HART variable (slot 3)	HART variable (slot 3)
4	–	QV	HART variable (slot 4)	HART variable (slot 4)
5	–	–	HART variable (slot 5)	–
6	–	–	HART variable (slot 6)	–
7	–	–	HART variable (slot 7)	–
8	–	–	HART variable (slot 8)	–

Timeout**Navigation**

Expert → Communication → HART input → Configuration → Timeout (7005)

Prerequisite

The **Burst network** option or the **Master network** option is selected in the **Capture mode** parameter (→ 118).

Description

Use this function to enter the maximum permitted interval between two HART frames.

User entry

1 to 120 s

Factory setting

5 s

Additional information

Description

If the interval is exceeded, the measuring device displays the **XF882 Input signal** diagnostic message.

Failure mode**Navigation**

Expert → Communication → HART input → Configuration → Failure mode (7011)

Prerequisite

In the **Capture mode** parameter (→ 118), the **Burst network** option or **Master network** option is selected.

Description

Use this function to select the device behavior if no data are recorded within the maximum permitted interval.

Selection

- Alarm
- Last valid value
- Defined value

Factory setting

Alarm

Additional information*Options*

- Alarm
An error message is set.
- Last valid value
The last valid measured value is used.
- Defined value
A user-defined measured value is used: (**Failure value** parameter (→ 122)).

Failure value**Navigation**

Expert → Communication → HART input → Configuration → Failure value (7012)

Prerequisite

The following conditions are met:

- In the **Capture mode** parameter (→ 118), the **Burst network** option or **Master network** option is selected.
- In the **Failure mode** parameter (→ 122), the **Defined value** option is selected.

Description


Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.

User entry

Signed floating-point number

Factory setting

0

"Input" submenu**Navigation**
 Expert → Communication → HART input → Input
**Value****Navigation**
 Expert → Communication → HART input → Input → Value (7003)
Description

Displays the value of the device variable recorded by the HART input.

User interface


Signed floating-point number

Status**Navigation**
 Expert → Communication → HART input → Input → Status (7004)
Description

Displays the value of the device variable recorded by the HART input in accordance with the HART specification.

User interface

- Manual/Fixed
- Good
- Poor accuracy
- Bad

3.5.2 "HART output" submenu**Navigation**
 Expert → Communication → HART output


► Information	→ 132
► Output	→ 135

"Configuration" submenu**Navigation**

Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→ 124
Device tag (0215)	→ 124
HART address (0219)	→ 125
No. of preambles (0217)	→ 125
Fieldbus writing access (0273)	→ 125

HART short tag**Navigation**

Expert → Communication → HART output → Configuration → HART short tag (0220)

Description

Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry

Max. 8 characters: A to Z, 0 to 9 and certain special characters (e.g. punctuation marks, @, %).

Factory setting

PROMAG

Device tag**Navigation**

Expert → Communication → HART output → Configuration → Device tag (0215)

Description

Use this function to enter the name for the measuring point.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag

HART address

Navigation	Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0
Additional information	<p><i>Description</i></p> <p>For addressing in a HART Multidrop network, the Fixed current option must be set in the Current span parameter (→ 88) (current output 1).</p>

No. of preambles

Navigation	Expert → Communication → HART output → Configuration → No. of preambles (0217)
Description	Use this function to enter the number of preambles in the HART protocol.
User entry	2 to 20
Factory setting	5
Additional information	<p><i>User entry</i></p> <p>As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.</p>

Fieldbus writing access

Navigation	Expert → Communication → HART output → Configuration → Fieldb.writ.acc. (0273)
Description	Use this function to restrict access to the measuring device via fieldbus (HART interface).
Selection	<ul style="list-style-type: none"> ■ Read + write ■ Read only
Factory setting	Read + write

Additional information**Description**

If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.

Selection

- Read + write
The parameters are readable and writable.
- Read only
The parameters are only readable.

"Burst configuration 1 to n" submenu**Navigation**

Expert → Communication → HART output → Burst config.
→ Burst config. 1 to n

► Burst configuration	
► Burst configuration 1 to n	
Burst mode 1 to n (2032-1 to n)	→ 127
Burst command 1 to n (2031-1 to n)	→ 127
Burst variable 0 (2033)	→ 128
Burst variable 1 (2034)	→ 129
Burst variable 2 (2035)	→ 129
Burst variable 3 (2036)	→ 129
Burst variable 4 (2037)	→ 129
Burst variable 5 (2038)	→ 130
Burst variable 6 (2039)	→ 130
Burst variable 7 (2040)	→ 130
Burst trigger mode (2044-1 to n)	→ 130
Burst trigger level (2043-1 to n)	→ 131
Min. update period (2042-1 to n)	→ 131
Max. update period (2041-1 to n)	→ 132

Burst mode 1 to n

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst mode 1 to n (2032-1 to n)
Description	Use this function to select whether to activate the HART burst mode for burst message X.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Off The measuring device transmits data only when requested by the HART master. ▪ On The measuring device transmits data regularly without being requested.

Burst command 1 to n

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst command 1 to n (2031-1 to n)
Description	Use this function to select the HART command that is sent to the HART master.
Selection	<ul style="list-style-type: none"> ▪ Command 1 ▪ Command 2 ▪ Command 3 ▪ Command 9 ▪ Command 33 ▪ Command 48
Factory setting	Command 2
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Command 1 Read out the primary variable. ▪ Command 2 Read out the current and the main measured value as a percentage. ▪ Command 3 Read out the dynamic HART variables and the current. ▪ Command 9 Read out the dynamic HART variables including the related status. ▪ Command 33 Read out the dynamic HART variables including the related unit. ▪ Command 48 Read out the complete device diagnostics. <p><i>"Command 33" option</i></p> <p>The HART device variables are defined via Command 107.</p>

The following measured variables (HART device variables) can be read out:

- Volume flow
- Mass flow
- Flow velocity^{*}
- Conductivity^{*}
- Electronic temperature
- Density
- HART input
- Totalizer 1...3
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)

Commands



- Information about the defined details of the command: HART specifications
- The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 87).

Burst variable 0



Navigation

Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Burst variable 0 (2033)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity^{*}
- Conductivity^{*}
- Corrected conductivity^{*}
- Electronic temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Density
- Temperature^{*}
- HART input
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting

Volume flow

* Visibility depends on order options or device settings

Additional information*Selection*

The **Not used** option is set if a burst message is not configured.

Burst variable 1**Navigation**

④⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 1 (2034)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ 128).

Factory setting

Not used

Burst variable 2**Navigation**

④⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 2 (2035)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ 128).

Factory setting

Not used

Burst variable 3**Navigation**

④⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 3 (2036)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

See the **Burst variable 0** parameter (→ 128).

Factory setting

Not used

Burst variable 4**Navigation**

④⑤ Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 4 (2037)

Description

For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 128).

Factory setting Not used

Burst variable 5



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 5 (2038)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 128).

Factory setting Not used

Burst variable 6



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 6 (2039)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 128).

Factory setting Not used

Burst variable 7



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Burst variable 7 (2040)

Description For HART command 9: select the HART device variable or the process variable.

Selection See the **Burst variable 0** parameter (→ 128).

Factory setting Not used

Burst trigger mode



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Trigger mode (2044-1 to n)

Description Use this function to select the event that triggers burst message X.

Selection	<ul style="list-style-type: none"> ■ Continuous ■ Window * ■ Rising * ■ Falling * ■ On change
Factory setting	Continuous
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→ 131). ■ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→ 131). ■ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→ 131). ■ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→ 131). ■ On change The message is sent if a measured value changes in the burst message.

Burst trigger level

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Trigger level (2043–1 to n)
Description	For entering the burst trigger value.
User entry	Signed floating-point number
Additional information	<p><i>Description</i></p> <p>Together with the option selected in the Burst trigger mode parameter (→ 130) the burst trigger value determines the time of burst message X.</p>

Min. update period

Navigation	Expert → Communication → HART output → Burst config. → Burst config. 1 to n → Min. upd. per. (2042–1 to n)
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer

* Visibility depends on order options or device settings

Factory setting 1 000 ms

Max. update period

Navigation  Expert → Communication → HART output → Burst config. → Burst config. 1 to n
→ Max. upd. per. (2041-1 to n)

Description Use this function to enter the maximum time span between two burst commands of burst message X.

User entry Positive integer

Factory setting 2 000 ms

"Information" submenu

Navigation  Expert → Communication → HART output → Information

 Information	
Device revision (0204)	→  133
Device ID (0221)	→  133
Device type (0209)	→  133
Manufacturer ID (0259)	→  134
HART revision (0205)	→  134
HART descriptor (0212)	→  134
HART message (0216)	→  134
Hardware revision (0206)	→  135
Software revision (0224)	→  135
HART date code (0202)	→  135

Device revision

Navigation	  Expert → Communication → HART output → Information → Device revision (0204)
Description	Displays the device revision with which the device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	9
Additional information	<i>Description</i>  The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation	  Expert → Communication → HART output → Information → Device ID (0221)
Description	Use this function to view the device ID for identifying the measuring device in a HART network.
User interface	6-digit hexadecimal number
Additional information	<i>Description</i>  In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	  Expert → Communication → HART output → Information → Device type (0209)
Description	Displays the device type with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x69 (for Promag 400)
Additional information	<i>Description</i>  The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID

Navigation	  Expert → Communication → HART output → Information → Manufacturer ID (0259)
Description	Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x11 (for Endress+Hauser)

HART revision

Navigation	  Expert → Communication → HART output → Information → HART revision (0205)
Description	Use this function to display the HART protocol revision of the measuring device.
User interface	5 to 7
Factory setting	7

HART descriptor

Navigation	  Expert → Communication → HART output → Information → HART descriptor (0212)
Description	Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	Promag 400

HART message

Navigation	  Expert → Communication → HART output → Information → HART message (0216)
Description	Use this function to enter a HART message which is sent via the HART protocol when requested by the master.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	Promag 400

Hardware revision

Navigation	 Expert → Communication → HART output → Information → Hardware rev. (0206)
Description	Displays the hardware revision of the measuring device.
User interface	0 to 255
Factory setting	1

Software revision

Navigation	 Expert → Communication → HART output → Information → Software rev. (0224)
Description	Displays the software revision of the measuring device.
User interface	0 to 255
Factory setting	9

HART date code

Navigation	 Expert → Communication → HART output → Information → HART date code (0202)
Description	Use this function to enter the date information for individual use.
User entry	Date entry format: yyyy-mm-dd
Factory setting	2009-07-20
Additional information	<p><i>Example</i></p> <p>Device installation date</p>

"Output" submenu

Navigation  Expert → Communication → HART output → Output

► Output	
Assign PV (0234)	→  136
Primary variable (PV) (0201)	→  136

Assign SV (0235)	→ 137
Secondary variable (SV) (0226)	→ 137
Assign TV (0236)	→ 138
Tertiary variable (TV) (0228)	→ 138
Assign QV (0237)	→ 139
Quaternary variable (QV) (0203)	→ 139

Assign PV

Expert → Communication → HART output → Output → Assign PV (0234)

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Off *
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Volume flow

Primary variable (PV)**Navigation**

Expert → Communication → HART output → Output → Primary var (PV) (0201)

Description

Displays the current measured value of the primary dynamic variable (PV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→ 136).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Assign SV**Navigation**

Expert → Communication → HART output → Output → Assign SV (0235)

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Density
- Totalizer 1
- Totalizer 2
- Totalizer 3
- HART input *
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 1

Secondary variable (SV)**Navigation**

Expert → Communication → HART output → Output → Second.var(SV) (0226)

Description

Displays the current measured value of the secondary dynamic variable (SV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (→ 137).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Assign TV**Navigation**

 Expert → Communication → HART output → Output → Assign TV (0236)

Description

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Density
- Totalizer 1
- Totalizer 2
- Totalizer 3
- HART input
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 2

Tertiary variable (TV)**Navigation**

 Expert → Communication → HART output → Output → Tertiary var(TV) (0228)

Description

Displays the current measured value of the tertiary dynamic variable (TV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign TV** parameter (→ 138).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

Assign QV**Navigation**

Expert → Communication → HART output → Output → Assign QV (0237)

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Density
- Totalizer 1
- Totalizer 2
- Totalizer 3
- HART input
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 3

Quaternary variable (QV)**Navigation**

Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)

Description

Displays the current measured value of the quaternary dynamic variable (QV).

User interface

Signed floating-point number

* Visibility depends on order options or device settings

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→ [139](#)).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→ [51](#)).

3.5.3 "Web server" submenu

Navigation

 Expert → Communication → Web server

 Web server	
Web server language (7221)	→ 140
MAC address (7214)	→ 141
DHCP client (7212)	→ 141
IP address (7209)	→ 142
Subnet mask (7211)	→ 142
Default gateway (7210)	→ 142
Web server functionality (7222)	→ 142
Login page (7273)	→ 143

Web server language

Navigation

 Expert → Communication → Web server → Webserv.language (7221)

Description

Use this function to select the Web server language setting.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska

- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ລາວ/ໄທ (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting	English
------------------------	---------

MAC address

Navigation	  Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁵⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<p><i>Example</i></p> <p>For the display format 00:07:05:10:01:5F</p>

DHCP client



Navigation	  Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On
Additional information	<p><i>Effect</i></p> <p>If the DHCP client functionality of the web server is selected, the IP address (→ 142), Subnet mask (→ 142) and Default gateway (→ 142) are set automatically.</p> <p> ■ Identification is via the MAC address of the measuring device.</p> <p>■ The IP address (→ 142) in the IP address parameter (→ 142) is ignored as long as the DHCP client parameter (→ 141) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→ 142) in the parameter of the same name is only used if the DHCP client parameter (→ 141) is inactive.</p>

* Visibility depends on order options or device settings

5) Media Access Control

IP address**Navigation**

Expert → Communication → Web server → IP address (7209)

Description

Display or enter the IP address of the Web server integrated in the measuring device.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

192.168.1.212

Subnet mask**Navigation**

Expert → Communication → Web server → Subnet mask (7211)

Description

Display or enter the subnet mask.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

255.255.255.0

Default gateway**Navigation**

Expert → Communication → Web server → Default gateway (7210)

Description

Display or enter the Default gateway (→ 142).

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

0.0.0.0

Web server functionality**Navigation**

Expert → Communication → Web server → Webserver funct. (7222)

Description

Use this function to switch the Web server on and off.

Selection

- Off
- On

Factory setting

On

Additional information*Description*

Once disabled, the Web server functionality can only be re-enabled via or the operating tool FieldCare.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ■ The web server is completely disabled. ■ Port 80 is locked.
On	<ul style="list-style-type: none"> ■ The complete functionality of the web server is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Diagram: Expert → Communication → Web server → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.5.4 "WLAN settings" wizard*Navigation*

Diagram: Expert → Communication → WLAN settings

► WLAN settings	
WLAN (2702)	→ 144
WLAN mode (2717)	→ 144
SSID name (2714)	→ 145
Network security (2705)	→ 145
Security identification (2718)	→ 145
User name (2715)	→ 146
WLAN password (2716)	→ 146
WLAN IP address (2711)	→ 146

WLAN MAC address (2703)	→ 146
WLAN subnet mask (2709)	→ 147
WLAN MAC address (2703)	→ 146
WLAN passphrase (2706)	→ 147
WLAN MAC address (2703)	→ 146
Assign SSID name (2708)	→ 147
SSID name (2707)	→ 148
2.4 GHz WLAN channel (2704)	→ 148
Select antenna (2713)	→ 148
Connection state (2722)	→ 149
Received signal strength (2721)	→ 149
WLAN IP address (2711)	→ 146
Gateway IP address (2719)	→ 149
IP address domain name server (2720)	→ 149

WLAN**Navigation**

Expert → Communication → WLAN settings → WLAN (2702)

Description

Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting

Enable

WLAN mode**Navigation**

Expert → Communication → WLAN settings → WLAN mode (2717)

Description

Use this function to select the WLAN mode.

Selection WLAN access point

Factory setting WLAN access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.

Security identification

Navigation Expert → Communication → WLAN settings → Sec. identific. (2718)

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

* Visibility depends on order options or device settings

User interface

- Trusted issuer certificate
- Device certificate
- Device private key

User name**Navigation**

Expert → Communication → WLAN settings → User name (2715)

Description

Use this function to enter the username of the WLAN network.

User entry

–

Factory setting

–

WLAN password**Navigation**

Expert → Communication → WLAN settings → WLAN password (2716)

Description

Use this function to enter the WLAN password for the WLAN network.

User entry

–

Factory setting

–

WLAN IP address**Navigation**

Expert → Communication → WLAN settings → WLAN IP address (2711)

Description

Use this function to enter the IP address of the measuring device's WLAN connection.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

192.168.1.212

WLAN MAC address**Navigation**

Expert → Communication → WLAN settings → WLAN MAC address (2703)

Description

Displays the MAC⁶⁾ address of the measuring device.

User interface

Unique 12-digit character string comprising letters and numbers

6) Media Access Control

Factory setting Each measuring device is given an individual address.

Additional information *Example*

For the display format

00:07:05:10:01:5F

WLAN subnet mask



Navigation Expert → Communication → WLAN settings → WLAN subnet mask (2709)

Description Use this function to enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

WLAN passphrase



Navigation Expert → Communication → WLAN settings → WLAN passphrase (2706)

Prerequisite The **WPA2-PSK** option is selected in the **Security type** parameter (→ 145).

Description Use this function to enter the network key.

User entry 8 to 32-digit character string comprising numbers, letters and special characters (without spaces)

Factory setting Serial number of the measuring device (e.g. L100A802000)

Assign SSID name



Navigation Expert → Communication → WLAN settings → Assign SSID name (2708)

Description Use this function to select which name is used for the SSID⁷⁾.

Selection

- Device tag
- User-defined

Factory setting User-defined

7) Service Set Identifier

Additional information*Selection*

- Device tag
The device tag name is used as the SSID.
- User-defined
A user-defined name is used as the SSID.

SSID name**Navigation**

Expert → Communication → WLAN settings → SSID name (2707)

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (→ 147).
- The **WLAN access point** option is selected in the **WLAN mode** parameter (→ 144).

Description

Use this function to enter a user-defined SSID name.

User entry

Max. 32-digit character string comprising numbers, letters and special characters

Factory setting**2.4 GHz WLAN channel****Navigation**

Expert → Communication → WLAN settings → WLAN channel (2704)

Description

Use this function to enter the 2.4 GHz WLAN channel.

User entry

1 to 11

Factory setting

6

Additional information*Description*

- It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.
■ If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna**Navigation**

Expert → Communication → WLAN settings → Select antenna (2713)

Description

Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting

Internal antenna

Connection state

Navigation	 Expert → Communication → WLAN settings → Connection state (2722)
Description	The connection status is displayed.
User interface	<ul style="list-style-type: none">■ Connected■ Not connected
Factory setting	Not connected

Received signal strength

Navigation	  Expert → Communication → WLAN settings → Rec.sig.strength (2721)
Description	Displays the signal strength received.
User interface	<ul style="list-style-type: none">■ Low■ Medium■ High
Factory setting	High

Gateway IP address

Navigation	  Expert → Communication → WLAN settings → Gateway IP addr. (2719)
Description	Use this function to enter the IP address of the gateway.
User interface	Character string comprising numbers, letters and special characters (#15)
Factory setting	192.168.1.212

IP address domain name server

Navigation	  Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
User interface	Character string comprising numbers, letters and special characters (#15)
Factory setting	192.168.1.212

3.5.5 "Diagnostic configuration" submenu

 For a list of all the diagnostic events, see the Operating Instructions for the device
→  7

Assign a category to the particular diagnostic event:

Category	Meaning
Failure (F)	A device error is present. The measured value is no longer valid.
Function check (C)	The device is in service mode (e.g. during a simulation).
Out of specification (S)	The device is being operated: ▪ Outside its technical specification limits (e.g. outside the process temperature range) ▪ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
Maintenance required (M)	Maintenance is required. The measured value is still valid.
No effect (N)	Has no effect on the condensed status ¹⁾ .

1) Condensed status according to NAMUR recommendation NE107

Navigation

  Expert → Communication → Diag. config.

► Diagnostic configuration	
Event category 043	→  151
Event category 376	→  151
Event category 377	→  151
Event category 441	→  152
Event category 442	→  153
Event category 443	→  153
Event category 531	→  153
Event category 832	→  154
Event category 833	→  154
Event category 834	→  155
Event category 835	→  155
Event category 861	→  155
Event category 842	→  156
Event category 962	→  156

Event category 937	→ 156
Event category 938	→ 157

Event category 043 (Sensor short circuit)



Navigation Expert → Communication → Diag. config. → Event category 043 (0285)

Description Use this option to select a category for the **043 Sensor short circuit** diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → 150

Event category 376 (Sensor electronic (ISEM) faulty)



Navigation Expert → Communication → Diag. config. → Event category 376 (0286)

Description Use this option to select a category for the **376 Sensor electronic (ISEM) faulty** diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → 150

Event category 377 (Sensor electronic (ISEM) faulty)



Navigation Expert → Communication → Diag. config. → Event category 377 (0287)

Description Use this option to select a category for the **377 Sensor electronic (ISEM) faulty** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [150](#)

Event category 004 (Sensor)**Navigation** Expert → Communication → Diag. config. → Event category 004 (0238)**Description**Use this option to select a category for the **004 Sensor** diagnostic message.**Selection**

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [150](#)

Event category 441 (Current output 1)**Navigation** Expert → Communication → Diag. config. → Event category 441 (0210)**Description**Use this option to select a category for the **441 Current output 1** diagnostic message.**Selection**

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information For a detailed description of the event categories available for selection: → [150](#)

Event category 442 (Frequency output 1 to n)

Navigation  Expert → Communication → Diag. config. → Event category 442 (0230)

Prerequisite The pulse/frequency/switch output is available.

Description Use this option to select a category for the **442 Frequency output 1 to n** diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the event categories available for selection: → [150](#)

Event category 443 (Pulse output 1 to n)

Navigation  Expert → Communication → Diag. config. → Event category 443 (0231)

Prerequisite The pulse/frequency/switch output is available.

Description Use this option to select a category for the **443 Pulse output 1 to n** diagnostic message.

- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the event categories available for selection: → [150](#)

Event category 531 (Empty pipe detection)

Navigation  Expert → Communication → Diag. config. → Event category 531 (0262)

Description Use this option to select a category for the **531 Empty pipe detection** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

 For a detailed description of the event categories available for selection: → [150](#)

Event category 832 (Electronic temperature too high)**Navigation**

 Expert → Communication → Diag. config. → Event category 832 (0218)

Description

Use this function to select a category for the **832 Electronic temperature too high** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

 For a detailed description of the event categories available for selection: → [150](#)

Event category 833 (Electronic temperature too low)**Navigation**

 Expert → Communication → Diag. config. → Event category 833 (0225)

Description

Use this option to select a category for the **833 Electronic temperature too low** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

 For a detailed description of the event categories available for selection: → [150](#)

Event category 834 (Process temperature too high)

Navigation

 Expert → Communication → Diag. config. → Event category 834 (0227)

Description

Use this option to select a category for the **834 Process temperature too high** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

 For a detailed description of the event categories available for selection: → [150](#)

Event category 835 (Process temperature too low)

Navigation

 Expert → Communication → Diag. config. → Event category 835 (0229)

Description

Use this option to select a category for the **835 Process temperature too low** diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Additional information

Selection

 For a detailed description of the event categories available for selection: → [150](#)

Event category 861

Navigation

 Expert → Communication → Diag. config. → Event category 861 (0261)

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting

Out of specification (S)

Event category 842

Navigation	Expert → Communication → Diag. config. → Event category 842 (0295)
Description	Change status signal of diagnostic event with diagnostic number 842 'Process limit'.
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Function check (C)▪ Out of specification (S)▪ Maintenance required (M)▪ No effect (N)
Factory setting	Out of specification (S)

Event category 862 (Pipe empty)

Navigation	Expert → Communication → Diag. config. → Event category 962 (0214)
Description	Use this option to select a category for the 862 Pipe empty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Function check (C)▪ Out of specification (S)▪ Maintenance required (M)▪ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the event categories available for selection: → 150

Event category 937 (EMC interference)

Navigation	Expert → Communication → Diag. config. → Event category 937 (0260)
Description	Use this option to select a category for the 937 EMC interference diagnostic message.
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Function check (C)▪ Out of specification (S)▪ Maintenance required (M)▪ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the event categories available for selection: → 150

Event category 938 (EMC interference)

Navigation Expert → Communication → Diag. config. → Event category 938 (0284)

Description Use this option to select a category for the **938 EMC interference** diagnostic message.


- Selection**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - No effect (N)

Factory setting Failure (F)

Additional information For a detailed description of the event categories available for selection: → 150

3.6 "Application" submenu

Navigation Expert → Application



Reset all totalizers

Navigation Expert → Application → Reset all tot. (2806)

Description Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

- Selection**
- Cancel
 - Reset + totalize

Factory setting Cancel

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.6.1 "Totalizer 1 to n" submenu*Navigation*

Expert → Application → Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable (0914-1 to n)	→ 158
Unit totalizer 1 to n (0915-1 to n)	→ 159
Totalizer operation mode (0908-1 to n)	→ 160
Control Totalizer 1 to n (0912-1 to n)	→ 161
Preset value 1 to n (0913-1 to n)	→ 161
Failure mode (0901-1 to n)	→ 162

Assign process variable**Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (0914-1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only the **Assign process variable** parameter (→ 158) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Unit totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 158) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ 158).

Selection*SI units*

- g *
- kg *
- t *

US units

- oz *
- lb *
- STon *

* Visibility depends on order options or device settings

or

SI units

- cm³*
- dm³*
- m³*
- ml*
- l*
- hl*
- Ml Mega*

US units

- af *
- ft³*
- Mft³*
- fl oz (us)*
- gal (us)*
- kgal (us)*
- Mgal (us)*
- bbl (us;liq.)*
- bbl (us;beer)*
- bbl (us;oil)*
- bbl (us;tank)*

Imperial units

- gal (imp) *
- Mgal (imp) *
- bbl (imp;beer) *
- bbl (imp;oil) *

* Visibility depends on order options or device settings

or

SI units

- Nl*
- Nhl*
- Nm³*
- Sl*
- Sm³*

US units

- Sft³*
- MMSft³*
- Sgal (us)*
- Sbbl (us;liq.)*
- Sbbl (us;oil)*

Imperial units

- Sgal (imp) *

* Visibility depends on order options or device settings

or

Other units
None *

* Visibility depends on order options or device settings

Factory setting

Country-specific:

- 1
- gal (us)

Additional information

Description

 The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 51).

Selection

The selection is dependent on the process variable selected in the **Assign process variable** parameter (→ 158).

Custody transfer mode

 Only available for Promag W.

Totalizer 1 is configured for the unit **m³** option in custody transfer mode.

Totalizer operation mode



Navigation

 Expert → Application → Totalizer 1 to n → Operation mode (0908–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 158) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total

Factory setting

Net flow total

Additional information

Selection

- Net flow total

Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.

- Forward flow total

Only the flow in the forward flow direction is totalized.

- Reverse flow total

Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Totalizer 1 to n

Navigation	 Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912–1 to n)												
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 158) of the Totalizer 1 to n submenu.												
Description	Use this function to select the control of totalizer value 1-3.												
Selection	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold 												
Factory setting	Totalize												
Additional information	<i>Selection</i>												
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr style="background-color: #cccccc;"> <th style="text-align: left; padding: 2px;">Options</th> <th style="text-align: left; padding: 2px;">Description</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">Totalize</td> <td style="padding: 2px;">The totalizer is started or continues running.</td> </tr> <tr> <td style="padding: 2px;">Reset + hold</td> <td style="padding: 2px;">The totaling process is stopped and the totalizer is reset to 0.</td> </tr> <tr> <td style="padding: 2px;">Preset + hold</td> <td style="padding: 2px;">The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.</td> </tr> <tr> <td style="padding: 2px;">Reset + totalize</td> <td style="padding: 2px;">The totalizer is reset to 0 and the totaling process is restarted.</td> </tr> <tr> <td style="padding: 2px;">Preset + totalize</td> <td style="padding: 2px;">The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.</td> </tr> </tbody> </table>		Options	Description	Totalize	The totalizer is started or continues running.	Reset + hold	The totaling process is stopped and the totalizer is reset to 0.	Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.	Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.	Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.
Options	Description												
Totalize	The totalizer is started or continues running.												
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.												
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.												
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.												
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.												

Preset value 1 to n

Navigation	 Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913–1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 158) of the Totalizer 1 to n submenu.
Description	Use this function to enter a start value for the Totalizer 1 to n.
User entry	Signed floating-point number
Factory setting	0.1
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 159).</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Failure mode**Navigation**

Expert → Application → Totalizer 1 to n → Failure mode (0901-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ [158](#)) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Stop

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop
The totalizer is stopped in the event of a device alarm.
- Actual value
The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.6.2 "Custody transfer" submenu

Only available for Promag W.

For detailed information on the parameter descriptions for custody transfer measurement, see the Special Documentation for the device → [7](#)

Navigation

Expert → Application → Custody transfer

Custody transfer

3.7 "Diagnostics" submenu*Navigation*

Expert → Diagnostics

Diagnostics

Active diagnostics (0691)

→ [163](#)

Previous diagnostics (0690)	→ 164
Operating time from restart (0653)	→ 165
Operating time (0652)	→ 165
▶ Diagnostic list	→ 166
▶ Event logbook	→ 170
▶ Custody transfer logbook	→ 172
▶ Device information	→ 172
▶ Mainboard module	→ 176
▶ Sensor electronic module (ISEM)	→ 177
▶ Display module	→ 178
▶ Minimum/maximum values	→ 179
▶ Data logging	→ 181
▶ Heartbeat Technology	→ 189
▶ Simulation	→ 189

Active diagnostics

Navigation

Expert → Diagnostics → Active diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 166).

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:

F271 Main electronic failure

Timestamp**Navigation**

 Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Active diagnostics** parameter (→ 163).

Example

For the display format:

24d12h13m00s

Previous diagnostics**Navigation**

  Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite

Two diagnostic events have already occurred.

Description

Displays the diagnostic message that occurred before the current message.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:

F271 Main electronic failure

Timestamp

Navigation	  Expert → Diagnostics → Timestamp
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  164).
	<i>Example</i> For the display format: 24d12h13m00s

Operating time from restart

Navigation	  Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)


Operating time

Navigation	  Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.7.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 166).

Example

For the display format:

24d12h13m00s

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

Description

Displays the current diagnostics message with the second-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 167).

Example

For the display format:

24d12h13m00s

Diagnostics 3

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  ΔS442 Frequency output
-  F276 I/O module failure

Timestamp

Navigation

  Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 3** parameter (→  168).

Example

For the display format:

24d12h13m00s

Diagnostics 4

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)

Description

Displays the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (→  168).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp

Navigation

█ Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

i The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ [169](#)).

Example


For the display format:
24d12h13m00s

3.7.2 "Event logbook" submenu

Displays previous event messages

Navigation

█ Expert → Diagnostics → Event logbook



Filter options**Navigation**

█ Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information*Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu


The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation

Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→ 170).

User interface

- For a "Category I" event message

Information event, short message, symbol for event recording and operating time when error occurred

- For a "Category F, C, S, M" event message (status signal)

Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ΔS442 Frequency output
⊖ 01d04h12min30s

 Additional information, such as remedial measures, can be retrieved via the  key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **Extended HistoROM** application package, see the "Application packages" section of the "Technical Information" document

3.7.3 "Custody transfer logbook" submenu

 Only available for Promag W.

 For detailed information on the parameter descriptions for custody transfer measurement, see the Special Documentation for the device → 

Navigation

 Expert → Diagnostics → Cust.transf.log.

 Custody transfer logbook

3.7.4 "Device information" submenu

Navigation

 Expert → Diagnostics → Device info

 Device information	
Device tag (0011)	→ 
Serial number (0009)	→ 
Firmware version (0010)	→ 
Device name (0013)	→ 
Order code (0008)	→ 
Extended order code 1 (0023)	→ 
Extended order code 2 (0021)	→ 

Extended order code 3 (0022)	→ 175
Configuration counter (0233)	→ 175
ENP version (0012)	→ 176

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag

Additional information

User interface



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation

Expert → Diagnostics → Device info → Serial number (0009)

Description

Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information

Description

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation  Expert → Diagnostics → Device info → Firmware version (0010)

Description Displays the device firmware version installed.

User interface Character string in the format xx.yy.zz

Additional information *Display*

-  The Firmware version is also located:
- On the title page of the Operating instructions
 - On the transmitter nameplate

Device name

Navigation  Expert → Diagnostics → Device info → Device name (0013)

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Max. 32 characters such as letters or numbers.

Factory setting Promag 400

Order code



Navigation  Expert → Diagnostics → Device info → Order code (0008)

Description Displays the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information *Description*

-  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1

Navigation	Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)
Description	Displays the first part of the extended order code. On account of length restrictions, the extended order code is split into a maximum of 3 parameters.
User interface	Character string
Additional information	<i>Description</i> The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2

Navigation	Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)
Description	Displays the second part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→ 175)

Extended order code 3

Navigation	Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)
Description	Displays the third part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→ 175)

Configuration counter


Navigation	Expert → Diagnostics → Device info → Config. counter (0233)
Description	Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.
User interface	0 to 65 535

ENP version

Navigation	  Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
User interface	Character string
Factory setting	2.02.00
Additional information	<i>Description</i> This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.7.5 "Main electronic module + I/O module 1" submenu

Navigation   Expert → Diagnostics → Mainboard module



Software revision

Navigation	  Expert → Diagnostics → Mainboard module → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

Build no. software

Navigation	  Expert → Diagnostics → Mainboard module → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → Mainboard module → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.7.6 "Sensor electronic module (ISEM)" submenu

Navigation

 Expert → Diagnostics → Sens. electronic



Software revision

Navigation  Expert → Diagnostics → Sens. electronic → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision


Navigation  Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.7.7 "Display module" submenu

Navigation  Expert → Diagnostics → Display module



Software revision

Navigation  Expert → Diagnostics → Display module → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Display module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → Display module → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.7.8 "Minimum/maximum values" submenu

Navigation


 Expert → Diagnostics → Min/max val.



"Main electronic temperature" submenu

Navigation

 Expert → Diagnostics → Min/max val. → Main elect.temp.



Minimum value

Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (6547)

Description Displays the lowest previously measured temperature value of the main electronics module.

User interface Signed floating-point number

Additional information *Dependency*


 The unit is taken from the **Temperature unit** parameter (→ 54)

Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (6545)
Description	Displays the highest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→ 54)

"Medium temperature" submenu

Navigation   Expert → Diagnostics → Min/max val. → Medium temp.



Minimum value

Navigation	  Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (6681)
Description	Displays the lowest previously measured medium temperature value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→ 54)

Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (6680)
Description	Displays the highest previously measured medium temperature value.
User interface	Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 54)

3.7.9 "Data logging" submenu

Navigation

Expert → Diagnostics → Data logging

► Data logging	
Assign channel 1 (0851)	→ 182
Assign channel 2 (0852)	→ 182
Assign channel 3 (0853)	→ 183
Assign channel 4 (0854)	→ 183
Logging interval (0856)	→ 183
Clear logging data (0855)	→ 184
Data logging (0860)	→ 184
Logging delay (0859)	→ 185
Data logging control (0857)	→ 185
Data logging status (0858)	→ 186
Entire logging duration (0861)	→ 186
► Display channel 1	→ 186
► Display channel 2	→ 187
► Display channel 3	→ 188
► Display channel 4	→ 188

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

i The software options currently enabled are displayed in the **Software option overview** parameter (→ 41).

Description

Use this function to select a process variable for the data logging channel.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature
- Current output 1
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Off

Additional information

Description

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

i The log contents are cleared if the option selected is changed.

Assign channel 2



Navigation

Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite

The **Extended HistoROM** application package is available.

i The software options currently enabled are displayed in the **Software option overview** parameter (→ 41).

* Visibility depends on order options or device settings

Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 182)
Factory setting	Off

Assign channel 3



Navigation	Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 41).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 182)
Factory setting	Off

Assign channel 4



Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 41).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 182)
Factory setting	Off

Logging interval



Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 41).
Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	0.1 to 3 600.0 s

Factory setting	1.0 s
Additional information	<p>Description</p> <p>This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log}:</p> <ul style="list-style-type: none"> ▪ If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$ ▪ If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$ ▪ If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$ ▪ If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$ <p>Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).</p> <p> The log contents are cleared if the length of the logging interval is changed.</p> <p>Example</p> <p>If 1 logging channel is used:</p> <ul style="list-style-type: none"> ▪ $T_{\log} = 1000 \times 1 \text{ s} = 1 \text{ 000 s} \approx 15 \text{ min}$ ▪ $T_{\log} = 1000 \times 10 \text{ s} = 10 \text{ 000 s} \approx 3 \text{ h}$ ▪ $T_{\log} = 1000 \times 80 \text{ s} = 80 \text{ 000 s} \approx 1 \text{ d}$ ▪ $T_{\log} = 1000 \times 3 \text{ 600 s} = 3 \text{ 600 000 s} \approx 41 \text{ d}$

Clear logging data



Navigation	  Expert → Diagnostics → Data logging → Clear logging (0855)
Prerequisite	The Extended HistoROM application package is available.
	 The software options currently enabled are displayed in the Software option overview parameter (→  41).
Description	Use this function to clear the entire logging data.
Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Clear data
Factory setting	Cancel
Additional information	<p>Selection</p> <ul style="list-style-type: none"> ▪ Cancel The data is not cleared. All the data is retained. ▪ Clear data The logging data is cleared. The logging process starts from the beginning.

Data logging



Navigation	  Expert → Diagnostics → Data logging → Data logging (0860)
Description	Use this function to select the data logging method.

Selection	<ul style="list-style-type: none"> ▪ Overwriting ▪ Not overwriting
Factory setting	Overwriting
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Overwriting The device memory applies the FIFO principle. ▪ Not overwriting Data logging is canceled if the measured value memory is full (single shot).

Logging delay



Navigation	Expert → Diagnostics → Data logging → Logging delay (0859)
Prerequisite	In the Data logging parameter (→ 184), the Not overwriting option is selected.
Description	Use this function to enter the time delay for measured value logging.
User entry	0 to 999 h
Factory setting	0 h
Additional information	<p><i>Description</i></p> <p>Once measured value logging has been started with the Data logging control parameter (→ 185), the device does not save any data for the duration of the time delay entered.</p>

Data logging control



Navigation	Expert → Diagnostics → Data logging → Data log.control (0857)
Prerequisite	In the Data logging parameter (→ 184), the Not overwriting option is selected.
Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none"> ▪ None ▪ Delete + start ▪ Stop
Factory setting	None
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ None Initial measured value logging status. ▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again. ▪ Stop Measured value logging is stopped.

Data logging status

Navigation	  Expert → Diagnostics → Data logging → Data log. status (0858)
Prerequisite	In the Data logging parameter (→ 184), the Not overwriting option is selected.
Description	Displays the measured value logging status.
User interface	<ul style="list-style-type: none">■ Done■ Delay active■ Active■ Stopped
Factory setting	Done
Additional information	<i>Selection</i> <ul style="list-style-type: none">■ Done Measured value logging has been performed and completed successfully.■ Delay active Measured value logging has been started but the logging interval has not yet elapsed.■ Active The logging interval has elapsed and measured value logging is active.■ Stopped Measured value logging is stopped.

Entire logging duration

Navigation	  Expert → Diagnostics → Data logging → Logging duration (0861)
Prerequisite	In the Data logging parameter (→ 184), the Not overwriting option is selected.
Description	Displays the total logging duration.
User interface	Positive floating-point number
Factory setting	0 s

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation

 Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  41).

One of the following options is selected in the **Assign channel 1** parameter (→  182):


- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature
- Electronic temperature
- Current output 1

Description

Displays the measured value trend for the logging channel in the form of a chart.

Additional information

Description



A0034352


 9 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation

 Expert → Diagnostics → Data logging → Displ.channel 2



* Visibility depends on order options or device settings

Display channel 2

Navigation

Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is defined in the **Assign channel 2** parameter.


Description

See the **Display channel 1** parameter → [187](#)

"Display channel 3" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation

Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign channel 3** parameter.

Description

See the **Display channel 1** parameter → [187](#)

"Display channel 4" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign channel 4** parameter.

DescriptionSee the **Display channel 1** parameter → 187

3.7.10 "Heartbeat" submenu

For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → 7

Navigation

Expert → Diagnostics → HBT

Heartbeat Technology

3.7.11 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation

Simulation

Assign simulation process variable
(1810)

→ 190

Process variable value (1811)

→ 190

Status input simulation 1 (1355-1)

→ 191

Input signal level 1 (1356-1)

→ 191

Current output 1 simulation (0354-1)

→ 192

Value current output 1 (0355-1)

→ 192

Frequency output simulation 1 to n
(0472-1 to n)

→ 192

Frequency value 1 to n (0473-1 to n)

→ 193

Pulse output simulation 1 to n
(0458-1 to n)

→ 193

Pulse value 1 to n (0459-1 to n)

→ 194

Switch output simulation 1 to n
(0462-1 to n)

→ 194

Switch status 1 to n (0463-1 to n)

→ 195

Device alarm simulation (0654)

→ 195

Diagnostic event category (0738)	→ 196
Diagnostic event simulation (0737)	→ 196

Assign simulation process variable



Navigation

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *

Factory setting

Off

Additional information

Description

The simulation value of the process variable selected is defined in the **Process variable value** parameter (→ 190).

Process variable value



Navigation

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

A process variable is selected in the **Assign simulation process variable** parameter (→ 190).

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 51).

* Visibility depends on order options or device settings

Status input simulation 1**Navigation**

Expert → Diagnostics → Simulation → Status inp.sim 1 (1355–1)

Prerequisite

For the following order code:

- "Output; input", option I "4–20mA HART, 2x pul./freq./switch output; status input"
- "Output; input", option J "4–20mA HART, certified pulse output, switch output; status input"

Description

Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Input signal level** parameter (→ [191](#)).

Selection

- Off
Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Simulation for the status input is active.

Input signal level 1**Navigation**

Expert → Diagnostics → Simulation → Signal level 1 (1356–1)

Prerequisite

In the **Status input simulation** parameter (→ [191](#)), the **On** option is selected.

Description

Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units.

Selection

- High
- Low

Current output 1 simulation



Navigation

Expert → Diagnostics → Simulation → Curr.out. 1 sim. (0354–1)

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is specified in the **Value current output 1** parameter (→ 192).

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value current output 1



Navigation

Expert → Diagnostics → Simulation → Value curr.out 1 (0355–1)

Prerequisite

In the **Current output 1 simulation** parameter, the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

0 to 22.5 mA

Additional information

User entry

The value must be entered with a period (.) as the separator.

Frequency output simulation 1 to n



Navigation

Expert → Diagnostics → Simulation → FreqOutputSim 1 to n (0472–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Frequency** option is selected.

Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is defined in the Frequency value 1 to n parameter.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Frequency simulation is active.

Frequency value 1 to n



Navigation	 Expert → Diagnostics → Simulation → Freq value 1 to n (0473-1 to n)
Prerequisite	In the Frequency output simulation 1 to n parameter, the On option is selected.
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.
User entry	0.0 to 12 500.0 Hz

Pulse output simulation 1 to n



Navigation	 Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n (0458-1 to n)
Prerequisite	In the Operating mode parameter (→  100), the Pulse option is selected.
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Fixed value ▪ Down-counting value
Factory setting	Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value 1 to n** parameter.

Selection

- Off

Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Fixed value

Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 103).

- Down-counting value

The pulses specified in the **Pulse value** parameter (→ 194) are output.

Pulse value 1 to n**Navigation**

Expert → Diagnostics → Simulation → Pulse value 1 to n (0459-1 to n)

Prerequisite

In the **Pulse output simulation 1 to n** parameter, the **Down-counting value** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch output simulation 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch sim. 1 to n (0462-1 to n)

Prerequisite

In the **Operating mode** parameter (→ 100), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Switch status 1 to n** parameter.

Selection

- Off

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- On

Switch simulation is active.

Switch status 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch status 1 to n (0463-1 to n)

Description

Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information*Selection*

- Open

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Closed

Switch simulation is active.

Device alarm simulation**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category

Navigation Expert → Diagnostics → Simulation → Event category (0738)

Description Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (→ 196).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting Process

Diagnostic event simulation

Navigation Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→ 196).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h option
Volume	m ³ option
Conductivity	µS/cm
Temperature	°C option
Mass flow	kg/h option
Mass	kg option
Density	kg/l option

4.1.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

 For detailed information about the full scale value for measuring devices for custody transfer, see the Special Documentation for the device →  7

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
150	150
200	300
250	500
300	750
350	1000
375	1200
400	1200
500	2000
600	2500

Nominal diameter [mm]	($v \sim 2.5$ m/s) [m 3 /h]
700	3 500
750	4 000
800	4 500
900	6 000
1 000	7 000
1 200	10 000
1 400	14 000
1 600	18 000
1 800	23 000
2 000	28 500
2 200	34 000
2 400	40 000
2 600	48 000
2 800	55 500
3 000	63 500

4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
------------------	------------------

4.1.4 Pulse value

 For detailed information about the pulse value for measuring devices for custody transfer, see the Special Documentation for the device →  7

Nominal diameter [mm]	(~ 2 pulse/s at $v \sim 2.5$ m/s) [dm 3]
25	0.5
32	1
40	1.5
50	2.5
65	5
80	5
100	10
125	15

Nominal diameter [mm]	(~ 2 pulse/s at $v \sim 2.5$ m/s) [m 3]
150	0.03
200	0.05
250	0.05
300	0.1
350	0.1
375	0.15

Nominal diameter [mm]	(~ 2 pulse/s at v ~ 2.5 m/s) [m ³]
400	0.15
500	0.25
600	0.3
700	0.5
750	0.5
800	0.75
900	0.75
1000	1
1200	1.5
1400	2
1600	2.5
1800	3
2000	3.5
2200	4.5
2400	5.5
2600	7
2800	8
3000	9

4.1.5 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	(v ~ 0.04 m/s) [dm ³ /min]
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
150	2.5
200	5
250	7.5
300	10
350	15
375	20
400	20

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
450	25
500	30
600	40
700	50
750	60
800	75
900	100
1 000	125
1 200	150
1 400	225
1 600	300
1 800	350
2 000	450
2 200	540
2 400	650
2 600	775
2 800	875
3 000	1 025

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us) option
Volume	gal (us) option
Temperature	°F option
Mass flow	lb/min option
Mass	lb option
Density	lb/ft ³ option

4.2.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

 For detailed information about the full scale value for measuring devices for custody transfer, see the Special Documentation for the device →  7

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1	18
1½	50

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
2	75
3	200
4	300
6	600
8	1200
10	1500
12	2400
14	3600
15	4800
16	4800
18	6000
20	7500
24	10500
28	13500
30	16500
32	19500
36	24000
40	30000
42	33000
48	42000

Nominal diameter [in]	(v ~ 2.5 m/s) [Mgal/d]
54	75
60	95
66	120
72	140
78	175
84	190
90	220
96	265
102	300
108	340
114	375
120	415

4.2.3 Output current span

Current output 1	4 to 20 mA US
------------------	---------------

4.2.4 Pulse value

 For detailed information about the pulse value for measuring devices for custody transfer, see the Special Documentation for the device →  7

Nominal diameter [in]	(~ 2 pulse/s at v ~ 2.5 m/s) [gal]
1	0.2
1½	0.5
2	0.5
3	2
4	2
6	5
8	10
10	15
12	25
14	30
15	50
16	50
18	50
20	75
24	100
28	125
30	150
32	200
36	225
40	250
42	250
48	400

Nominal diameter [in]	(~ 2 pulse/s at v ~ 2.5 m/s) [Mgal]
54	0.0005
60	0.0005
66	0.0008
72	0.0008
78	0.001
84	0.0011
90	0.0013
96	0.0015
102	0.0017
108	0.0020
114	0.0022
120	0.0024

4.2.5 Switch-on point low flow cut off



The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1	0.25
1½	0.75
2	1.25
3	2.5
4	4
6	12
8	15
10	30
12	45
14	60
15	60
16	60
18	90
20	120
24	180
28	210
30	270
32	300
36	360
40	480
42	600
48	600

Nominal diameter [in]	(v ~ 0.04 m/s) [Mgal/d]
54	1.3
60	1.3
66	2.2
72	2.6
78	3.0
84	3.2
90	3.6
96	4.0
102	5.0
108	5.0
114	6.0
120	7.0

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano-, Micro-, Milli-, Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro-, Milli-, Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot

Process variable	Units	Explanation
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0/4 mA value (Parameter)	90
0% bargraph value 1 (Parameter)	19
0% bargraph value 3 (Parameter)	22
2.4 GHz WLAN channel (Parameter)	148
20 mA value (Parameter)	91
100% bargraph value 1 (Parameter)	19
100% bargraph value 3 (Parameter)	22

A

Access status (Parameter)	13
Access status display (Parameter)	28
Activate SW option (Parameter)	40
Active diagnostics (Parameter)	163
Active level (Parameter)	86
Administration (Submenu)	37
Alarm delay (Parameter)	29
Application (Submenu)	157
Assign behavior of diagnostic no. 043 (Parameter)	31
Assign behavior of diagnostic no. 302 (Parameter)	31
Assign behavior of diagnostic no. 376 (Parameter)	31
Assign behavior of diagnostic no. 377 (Parameter)	32
Assign behavior of diagnostic no. 441 (Parameter)	32
Assign behavior of diagnostic no. 442 (Parameter)	32
Assign behavior of diagnostic no. 443 (Parameter)	33
Assign behavior of diagnostic no. 531 (Parameter)	33
Assign behavior of diagnostic no. 832 (Parameter)	33
Assign behavior of diagnostic no. 833 (Parameter)	34
Assign behavior of diagnostic no. 834 (Parameter)	34
Assign behavior of diagnostic no. 835 (Parameter)	35
Assign behavior of diagnostic no. 842 (Parameter)	35
Assign behavior of diagnostic no. 937 (Parameter)	36
Assign behavior of diagnostic no. 938 (Parameter)	36
Assign behavior of diagnostic no. 961 (Parameter)	36
Assign behavior of diagnostic no. 962 (Parameter)	35
Assign channel 1 (Parameter)	182
Assign channel 2 (Parameter)	182
Assign channel 3 (Parameter)	183
Assign channel 4 (Parameter)	183
Assign current output 1 (Parameter)	88
Assign diagnostic behavior (Parameter)	111
Assign flow direction check (Parameter)	115
Assign frequency output (Parameter)	106
Assign limit (Parameter)	112
Assign process variable (Parameter)	64, 158
Assign pulse output 1 to n (Parameter)	102
Assign PV (Parameter)	136
Assign QV (Parameter)	139
Assign simulation process variable (Parameter)	190
Assign SSID name (Parameter)	147
Assign status (Parameter)	115
Assign status input (Parameter)	85
Assign SV (Parameter)	137
Assign TV (Parameter)	138

B

Backlight (Parameter)	27
Bootloader revision (Parameter)	177, 178, 179
Build no. software (Parameter)	176, 177, 178
Build-up detection (Parameter)	72
Build-up detection (Submenu)	71
Build-up detection damping (Parameter)	72
Build-up limit (Parameter)	73
Build-up limit hysteresis (Parameter)	73
Build-up measured value (Parameter)	72
Burst command (Parameter)	120
Burst command 1 to n (Parameter)	127
Burst configuration 1 to n (Submenu)	126
Burst mode 1 to n (Parameter)	127
Burst trigger level (Parameter)	131
Burst trigger mode (Parameter)	130
Burst variable 0 (Parameter)	128
Burst variable 1 (Parameter)	129
Burst variable 2 (Parameter)	129
Burst variable 3 (Parameter)	129
Burst variable 4 (Parameter)	129
Burst variable 5 (Parameter)	130
Burst variable 6 (Parameter)	130
Burst variable 7 (Parameter)	130

C

Calibration (Submenu)	83
Calibration factor (Parameter)	84
Capture mode (Parameter)	118
Clear logging data (Parameter)	184
Communication (Submenu)	117
Conductivity (Parameter)	44
Conductivity calibration factor (Parameter)	84
Conductivity damping (Parameter)	62
Conductivity factor (Parameter)	80
Conductivity measurement (Parameter)	62
Conductivity offset (Parameter)	80
Conductivity temperature coefficient (Parameter)	63
Conductivity unit (Parameter)	53
Configuration (Submenu)	118, 124
Configuration counter (Parameter)	175
Confirm access code (Parameter)	38
Connection state (Parameter)	149
Contrast display (Parameter)	27
Control Totalizer 1 to n (Parameter)	161
Corrected conductivity (Parameter)	45
Corrected conductivity factor (Parameter)	82
Corrected conductivity offset (Parameter)	82
Corrected volume flow (Parameter)	44
Corrected volume flow factor (Parameter)	81
Corrected volume flow offset (Parameter)	80
Corrected volume flow unit (Parameter)	57
Corrected volume unit (Parameter)	57
Current output 1 (Submenu)	87
Current output 1 simulation (Parameter)	192
Current span (Parameter)	88

Custody transfer (Submenu)	162	Assign behavior of diagnostic no. 376 (0645)	31
Custody transfer logbook (Submenu)	172	Assign behavior of diagnostic no. 377 (0777)	32
D		Assign behavior of diagnostic no. 441 (0657)	32
Damping output 1 (Parameter)	96	Assign behavior of diagnostic no. 442 (0658)	32
Damping output 1 to n (Parameter)	108	Assign behavior of diagnostic no. 443 (0659)	33
Data logging (Parameter)	184	Assign behavior of diagnostic no. 531 (0741)	33
Data logging (Submenu)	181	Assign behavior of diagnostic no. 832 (0681)	33
Data logging control (Parameter)	185	Assign behavior of diagnostic no. 833 (0682)	34
Data logging status (Parameter)	186	Assign behavior of diagnostic no. 834 (0700)	34
Date/time format (Parameter)	58	Assign behavior of diagnostic no. 835 (0702)	35
Decimal places 1 (Parameter)	20	Assign behavior of diagnostic no. 842 (0638)	35
Decimal places 2 (Parameter)	21	Assign behavior of diagnostic no. 937 (0743)	36
Decimal places 3 (Parameter)	23	Assign behavior of diagnostic no. 938 (0642)	36
Decimal places 4 (Parameter)	24	Assign behavior of diagnostic no. 961 (0736)	36
Default gateway (Parameter)	142	Assign behavior of diagnostic no. 962 (0745)	35
Define access code (Parameter)	37, 39	Assign channel 1 (0851)	182
Define access code (Wizard)	37	Assign channel 2 (0852)	182
Density (Parameter)	45	Assign channel 3 (0853)	183
Density source (Parameter)	74	Assign channel 4 (0854)	183
Density unit (Parameter)	56	Assign current output 1 (0359-1)	88
Device alarm simulation (Parameter)	195	Assign diagnostic behavior	
Device ID (Parameter)	119, 133	Pulse/frequency/switch output 1 to n (0482-1 to n)	111
Device information (Submenu)	172	Assign flow direction check	
Device name (Parameter)	174	Pulse/frequency/switch output 1 to n (0484-1 to n)	115
Device revision (Parameter)	133	Assign frequency output	
Device tag (Parameter)	124, 173	Pulse/frequency/switch output 1 to n (0478-1 to n)	106
Device type (Parameter)	119, 133	Assign limit	
DHCP client (Parameter)	141	Pulse/frequency/switch output 1 to n (0483-1 to n)	112
Diagnostic behavior (Submenu)	29	Assign process variable	
Diagnostic configuration (Submenu)	150	Totalizer 1 to n (0914-1 to n)	158
Diagnostic event category (Parameter)	196	Assign process variable (1837)	64
Diagnostic event simulation (Parameter)	196	Assign pulse output 1 to n (0460-1 to n)	102
Diagnostic handling (Submenu)	28	Assign PV (0234)	136
Diagnostic list (Submenu)	166	Assign QV (0237)	139
Diagnostics (Submenu)	162	Assign simulation process variable (1810)	190
Diagnostics 1 (Parameter)	166	Assign SSID name (2708)	147
Diagnostics 2 (Parameter)	167	Assign status	
Diagnostics 3 (Parameter)	168	Pulse/frequency/switch output 1 to n (0485-1 to n)	115
Diagnostics 4 (Parameter)	168	Assign status input (1352)	85
Diagnostics 5 (Parameter)	169	Assign SV (0235)	137
Direct access		Assign TV (0236)	138
0/4 mA value		Backlight (0111)	27
Current output 1 (0367-1)	90	Bootloader revision (0073)	177, 178, 179
0% bargraph value 1 (0123)	19	Build no. software (0079)	176, 177, 178
0% bargraph value 3 (0124)	22	Build-up detection (6734)	72
2.4 GHz WLAN channel (2704)	148	Build-up detection damping (6840)	72
20 mA value		Build-up limit (6466)	73
Current output 1 (0372-1)	91	Build-up limit hysteresis (6467)	73
100% bargraph value 1 (0125)	19	Build-up measured value (12111)	72
100% bargraph value 3 (0126)	22	Burst command (7006)	120
Access status (0005)	13	Burst command 1 to n (2031-1 to n)	127
Access status display (0091)	28	Burst mode 1 to n (2032-1 to n)	127
Activate SW option (0029)	40	Burst trigger level	
Active diagnostics (0691)	163	Burst configuration 1 to n (2043-1 to n)	131
Active level (1351)	86		
Alarm delay (0651)	29		
Assign behavior of diagnostic no. 043 (0650)	31		
Assign behavior of diagnostic no. 302 (0739)	31		

Burst trigger mode	195
Burst configuration 1 to n (2044–1 to n)	130
Burst variable 0	133
Burst configuration 1 to n (2033)	119
Burst variable 1	174
Burst configuration 1 to n (2034)	128
Burst variable 2	124
Burst configuration 1 to n (2035)	129
Burst variable 3	119
Burst configuration 1 to n (2036)	129
Burst variable 4	166
Burst configuration 1 to n (2037)	129
Burst variable 5	167
Burst configuration 1 to n (2038)	130
Burst variable 6	168
Burst configuration 1 to n (2039)	130
Burst variable 7	169
Burst configuration 1 to n (2040)	130
Calibration factor (6522)	84
Capture mode (7001)	118
Clear logging data (0855)	184
Conductivity (1850)	44
Conductivity calibration factor (6718)	84
Conductivity damping (1803)	62
Conductivity factor (1849)	80
Conductivity measurement (6514)	62
Conductivity offset (1848)	80
Conductivity temperature coefficient (1891)	63
Conductivity unit (0582)	53
Configuration counter (0233)	175
Connection state (2722)	149
Contrast display (0105)	27
Control Totalizer 1 to n (0912–1 to n)	161
Corrected conductivity (1853)	45
Corrected conductivity factor (1871)	82
Corrected conductivity offset (1870)	82
Corrected volume flow (1851)	44
Corrected volume flow factor (1867)	81
Corrected volume flow offset (1866)	80
Corrected volume flow unit (0558)	57
Corrected volume unit (0575)	57
Current output 1 simulation (0354–1)	192
Current span	192
Current output 1 (0353–1)	88
Damping output 1 (0363–1)	96
Damping output 1 to n (0477–1 to n)	108
Data logging (0860)	184
Data logging control (0857)	185
Data logging status (0858)	186
Date/time format (2812)	58
Decimal places 1 (0095)	20
Decimal places 2 (0117)	21
Decimal places 3 (0118)	23
Decimal places 4 (0119)	24
Default gateway (7210)	142
Define access code	39
Density (1857)	45
Density source (6615)	74
Density unit (0555)	56
Device alarm simulation (0654)	195
Device ID (0221)	133
Device ID (7007)	119
Device name (0013)	174
Device revision (0204)	133
Device tag (0011)	173
Device tag (0215)	124
Device type (0209)	133
Device type (7008)	119
DHCP client (7212)	141
Diagnostic event category (0738)	196
Diagnostic event simulation (0737)	196
Diagnostics 1 (0692)	166
Diagnostics 2 (0693)	167
Diagnostics 3 (0694)	168
Diagnostics 4 (0695)	168
Diagnostics 5 (0696)	169
Direct access (0106)	11
Display damping (0094)	25
Display interval (0096)	24
Display language (0104)	15
ECC cleaning cycle (6557)	71
ECC duration (6555)	70
ECC Polarity (6631)	71
ECC recovery time (6556)	70
Electrode cleaning circuit (6528)	70
Empty pipe adjust value (6527)	68
Empty pipe detection (1860)	67
ENP version (0012)	176
Enter access code (0003)	13
Entire logging duration (0861)	186
Event category 004 (0238)	152
Event category 043 (0285)	151
Event category 376 (0286)	151
Event category 377 (0287)	151
Event category 441 (0210)	152
Event category 442 (0230)	153
Event category 443 (0231)	153
Event category 531 (0262)	153
Event category 832 (0218)	154
Event category 833 (0225)	154
Event category 834 (0227)	155
Event category 835 (0229)	155
Event category 842 (0295)	156
Event category 861 (0261)	155
Event category 937 (0260)	156
Event category 938 (0284)	157
Event category 962 (0214)	156
Extended order code 1 (0023)	175
Extended order code 2 (0021)	175
Extended order code 3 (0022)	175
External density (6630)	75
External temperature (6673)	75
Failure current	192
Current output 1 (0352–1)	98
Failure frequency	192
Pulse/frequency/switch output 1 to n (0474–1 to n)	110

Failure mode	
Current output 1 (0364-1)	97
Pulse/frequency/switch output 1 to n (0451-1 to n)	109
Pulse/frequency/switch output 1 to n (0480-1 to n)	104
Pulse/frequency/switch output 1 to n (0486-1 to n)	116
Totalizer 1 to n (0901-1 to n)	162
Failure mode (7011)	122
Failure value (7012)	122
Fieldbus writing access (0273)	125
Filter options (0705)	170
Filter options (6710)	59
Firmware version (0010)	174
Fixed current	
Current output 1 (0365-1)	89
Fixed density (6623)	74
Flow damping (6661)	61
Flow override (1839)	61
Flow velocity (1854)	44
Flow velocity factor (1880)	83
Flow velocity offset (1879)	82
Format display (0098)	16
Frequency output simulation 1 to n (0472-1 to n)	
.	192
Frequency value 1 to n (0473-1 to n)	193
Full pipe adjust value (6548)	69
Gateway IP address (2719)	149
Hardware revision (0206)	135
HART address (0219)	125
HART date code (0202)	135
HART descriptor (0212)	134
HART message (0216)	134
HART revision (0205)	134
HART short tag (0220)	124
Header (0097)	26
Header text (0112)	26
Input signal level 1 (1356-1)	191
Installation direction (1809)	77
Integration time (6533)	77
Invert output signal	
Pulse/frequency/switch output 1 to n (0470-1 to n)	117
IP address (7209)	142
IP address domain name server (2720)	149
Locking status (0004)	12
Logging delay (0859)	185
Logging interval (0856)	183
Login page (7273)	143
MAC address (7214)	141
Manufacturer ID (0259)	134
Manufacturer ID (7009)	120
Mass flow (1847)	44
Mass flow factor (1846)	79
Mass flow offset (1841)	79
Mass flow unit (0554)	55
Mass unit (0574)	55
Max. update period	
Burst configuration 1 to n (2041-1 to n)	132
Maximum frequency value	
Pulse/frequency/switch output 1 to n (0454-1 to n)	106
Maximum value (6545)	180
Maximum value (6680)	180
Measured current 1 (0366-1)	49, 99
Measured value EPD (6559)	69
Measuring mode	
Current output 1 (0351-1)	92
Pulse/frequency/switch output 1 to n (0457-1 to n)	104
Pulse/frequency/switch output 1 to n (0479-1 to n)	108
Measuring period (6536)	77
Measuring value at maximum frequency	
Pulse/frequency/switch output 1 to n (0475-1 to n)	107
Measuring value at minimum frequency	
Pulse/frequency/switch output 1 to n (0476-1 to n)	107
Min. update period	
Burst configuration 1 to n (2042-1 to n)	131
Minimum frequency value	
Pulse/frequency/switch output 1 to n (0453-1 to n)	106
Minimum value (6547)	179
Minimum value (6681)	180
Network security (2705)	145
New adjustment (6560)	68
No. of preambles (0217)	125
Nominal diameter (2807)	83
Off value low flow cutoff (1804)	65
On value low flow cutoff (1805)	64
Operating mode	
Pulse/frequency/switch output 1 to n (0469-1 to n)	100
Operating time (0652)	38, 165
Operating time from restart (0653)	165
Order code (0008)	174
Output current 1 (0361-1)	49, 98
Output frequency 1 (0471-1)	50
Output frequency 1 to n (0471-1 to n)	110
Output frequency 2 (0471-2)	50
Preset value 1 to n (0913-1 to n)	161
Pressure shock suppression (1806)	65
Previous diagnostics (0690)	164
Primary variable (PV) (0201)	136
Process variable value (1811)	190
Progress (6571)	68
Pulse output 1 (0456-1)	49
Pulse output 1 to n (0456-1 to n)	105
Pulse output 2 (0456-2)	49
Pulse output simulation 1 to n (0458-1 to n)	193
Pulse scaling	
Pulse/frequency/switch output 1 to n (0455-1 to n)	102
Pulse value 1 to n (0459-1 to n)	194

Pulse width	
Pulse/frequency/switch output 1 to n (0452-1 to n)	103
Quaternary variable (QV) (0203)	139
Received signal strength (2721)	149
Reference density (1885)	63
Reference temperature (1816)	76
Reset access code (0024)	39
Reset all totalizers (2806)	157
Reset device (0000)	40
Response time	
Pulse/frequency/switch output 1 to n (0491-1 to n)	109
Response time empty pipe detection (1859)	67
Response time status input (1354)	86
Secondary variable (SV) (0226)	137
Security identification (2718)	145
Select antenna (2713)	148
Separator (0101)	27
Serial number (0009)	173
Slot number (7010)	121
Software option overview (0015)	41
Software revision (0072)	176, 177, 178
Software revision (0224)	135
SSID name (2707)	148
SSID name (2714)	145
Status (7004)	123
Status input simulation 1 (1355-1)	191
Subnet mask (7211)	142
Switch output function	
Pulse/frequency/switch output 1 to n (0481-1 to n)	111
Switch output simulation 1 to n (0462-1 to n)	194
Switch point empty pipe detection (6562)	67
Switch status 1 (0461-1)	50
Switch status 1 to n (0461-1 to n)	116
Switch status 1 to n (0463-1 to n)	195
Switch status 2 (0461-2)	50
Switch-off delay	
Pulse/frequency/switch output 1 to n (0465-1 to n)	116
Switch-off value	
Pulse/frequency/switch output 1 to n (0464-1 to n)	114
Switch-on delay	
Pulse/frequency/switch output 1 to n (0467-1 to n)	115
Switch-on value	
Pulse/frequency/switch output 1 to n (0466-1 to n)	114
Temperature (1852)	45
Temperature damping (1886)	63
Temperature factor (1869)	81
Temperature offset (1868)	81
Temperature source (6712)	75
Temperature unit (0557)	54
Tertiary variable (TV) (0228)	138
Timeout (7005)	121
Timestamp	164, 165, 166, 167, 168, 169, 170

Totalizer operation mode	
Totalizer 1 to n (0908-1 to n)	160
Totalizer overflow 1 to n (0910-1 to n)	47
Totalizer value 1 to n (0911-1 to n)	46
Unit totalizer 1 to n (0915-1 to n)	159
User name (2715)	146
Value (7003)	123
Value 1 display (0107)	18
Value 2 display (0108)	20
Value 3 display (0110)	21
Value 4 display (0109)	23
Value current output 1 (0355-1)	192
Value status input (1353)	48, 86
Volume flow (1838)	43
Volume flow factor (1832)	78
Volume flow offset (1831)	79
Volume flow unit (0553)	51
Volume unit (0563)	53
Web server functionality (7222)	142
Web server language (7221)	140
WLAN (2702)	144
WLAN IP address (2711)	146
WLAN MAC address (2703)	146
WLAN mode (2717)	144
WLAN passphrase (2706)	147
WLAN password (2716)	146
WLAN subnet mask (2709)	147
Zero point (6546)	84
Direct access (Parameter)	11
Display (Submenu)	14
Display channel 1 (Submenu)	186
Display channel 2 (Submenu)	187
Display channel 3 (Submenu)	188
Display channel 4 (Submenu)	188
Display damping (Parameter)	25
Display interval (Parameter)	24
Display language (Parameter)	15
Display module (Submenu)	178
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4
Document function	4
E	
ECC cleaning cycle (Parameter)	71
ECC duration (Parameter)	70
ECC Polarity (Parameter)	71
ECC recovery time (Parameter)	70
Electrode cleaning circuit (Parameter)	70
Electrode cleaning circuit (Submenu)	69
Empty pipe adjust value (Parameter)	68
Empty pipe detection (Parameter)	67
Empty pipe detection (Submenu)	66
ENP version (Parameter)	176

Enter access code (Parameter)	13	HART date code (Parameter)	135
Entire logging duration (Parameter)	186	HART descriptor (Parameter)	134
Event category 004 (Parameter)	152	HART input (Submenu)	118
Event category 043 (Parameter)	151	HART message (Parameter)	134
Event category 376 (Parameter)	151	HART output (Submenu)	123
Event category 377 (Parameter)	151	HART revision (Parameter)	134
Event category 441 (Parameter)	152	HART short tag (Parameter)	124
Event category 442 (Parameter)	153	Header (Parameter)	26
Event category 443 (Parameter)	153	Header text (Parameter)	26
Event category 531 (Parameter)	153	Heartbeat Technology (Submenu)	189
Event category 832 (Parameter)	154		
Event category 833 (Parameter)	154		
Event category 834 (Parameter)	155		
Event category 835 (Parameter)	155		
Event category 842 (Parameter)	156		
Event category 861 (Parameter)	155		
Event category 937 (Parameter)	156		
Event category 938 (Parameter)	157		
Event category 962 (Parameter)	156		
Event list (Submenu)	171		
Event logbook (Submenu)	170		
Extended order code 1 (Parameter)	175		
Extended order code 2 (Parameter)	175		
Extended order code 3 (Parameter)	175		
External compensation (Submenu)	74		
External density (Parameter)	75		
External temperature (Parameter)	75		
F			
Factory settings	197		
SI units	197		
US units	200		
Failure current (Parameter)	98		
Failure frequency (Parameter)	110		
Failure mode (Parameter)	97, 104, 109, 116, 122, 162		
Failure value (Parameter)	122		
Fieldbus writing access (Parameter)	125		
Filter options (Parameter)	59, 170		
Firmware version (Parameter)	174		
Fixed current (Parameter)	89		
Fixed density (Parameter)	74		
Flow damping (Parameter)	61		
Flow override (Parameter)	61		
Flow velocity (Parameter)	44		
Flow velocity factor (Parameter)	83		
Flow velocity offset (Parameter)	82		
Format display (Parameter)	16		
Frequency output simulation 1 to n (Parameter)	192		
Frequency value 1 to n (Parameter)	193		
Full pipe adjust value (Parameter)	69		
Function			
see Parameter			
G			
Gateway IP address (Parameter)	149		
H			
Hardware revision (Parameter)	135		
HART address (Parameter)	125		
I			
Information (Submenu)	132		
Input (Submenu)	85, 123		
Input signal level 1 (Parameter)	191		
Input values (Submenu)	48		
Installation direction (Parameter)	77		
Integration time (Parameter)	77		
Invert output signal (Parameter)	117		
IP address (Parameter)	142		
IP address domain name server (Parameter)	149		
L			
Locking status (Parameter)	12		
Logging delay (Parameter)	185		
Logging interval (Parameter)	183		
Login page (Parameter)	143		
Low flow cut off (Submenu)	64		
M			
MAC address (Parameter)	141		
Main electronic temperature (Submenu)	179		
Mainboard module (Submenu)	176		
Manufacturer ID (Parameter)	120, 134		
Mass flow (Parameter)	44		
Mass flow factor (Parameter)	79		
Mass flow offset (Parameter)	79		
Mass flow unit (Parameter)	55		
Mass unit (Parameter)	55		
Max. update period (Parameter)	132		
Maximum frequency value (Parameter)	106		
Maximum value (Parameter)	180		
Measured current 1 (Parameter)	49, 99		
Measured value EPD (Parameter)	69		
Measured values (Submenu)	43		
Measuring mode (Parameter)	92, 104, 108		
Measuring period (Parameter)	77		
Measuring value at maximum frequency (Parameter)	107		
Measuring value at minimum frequency (Parameter)	107		
Medium temperature (Submenu)	180		
Min. update period (Parameter)	131		
Minimum frequency value (Parameter)	106		
Minimum value (Parameter)	179, 180		
Minimum/maximum values (Submenu)	179		
N			
Network security (Parameter)	145		
New adjustment (Parameter)	68		

No. of preambles (Parameter) 125
 Nominal diameter (Parameter) 83

O

Off value low flow cutoff (Parameter) 65
 On value low flow cutoff (Parameter) 64
 Operating mode (Parameter) 100
 Operating time (Parameter) 38, 165
 Operating time from restart (Parameter) 165
 Order code (Parameter) 174
 Output (Submenu) 87, 135
 Output current 1 (Parameter) 49, 98
 Output frequency 1 (Parameter) 50
 Output frequency 1 to n (Parameter) 110
 Output frequency 2 (Parameter) 50
 Output values (Submenu) 48

P

Parameter
 Structure of a parameter description 6
 Preset value 1 to n (Parameter) 161
 Pressure shock suppression (Parameter) 65
 Previous diagnostics (Parameter) 164
 Primary variable (PV) (Parameter) 136
 Process parameters (Submenu) 58
 Process variable adjustment (Submenu) 77
 Process variable value (Parameter) 190
 Process variables (Submenu) 43
 Progress (Parameter) 68
 Pulse output 1 (Parameter) 49
 Pulse output 1 to n (Parameter) 105
 Pulse output 2 (Parameter) 49
 Pulse output simulation 1 to n (Parameter) 193
 Pulse scaling (Parameter) 102
 Pulse value 1 to n (Parameter) 194
 Pulse width (Parameter) 103
 Pulse/frequency/switch output 1 to n (Submenu) 99

Q

Quaternary variable (QV) (Parameter) 139

R

Received signal strength (Parameter) 149
 Reference density (Parameter) 63
 Reference temperature (Parameter) 76
 Reset access code (Parameter) 39
 Reset access code (Submenu) 38
 Reset all totalizers (Parameter) 157
 Reset device (Parameter) 40
 Response time (Parameter) 109
 Response time empty pipe detection (Parameter) 67
 Response time status input (Parameter) 86

S

Secondary variable (SV) (Parameter) 137
 Security identification (Parameter) 145
 Select antenna (Parameter) 148
 Sensor (Submenu) 42
 Sensor adjustment (Submenu) 76
 Sensor electronic module (ISEM) (Submenu) 177

Separator (Parameter) 27
 Serial number (Parameter) 173
 Simulation (Submenu) 189
 Slot number (Parameter) 121
 Software option overview (Parameter) 41
 Software revision (Parameter) 135, 176, 177, 178
 SSID name (Parameter) 145, 148
 Status (Parameter) 123
 Status input 1 to n (Submenu) 85
 Status input simulation 1 (Parameter) 191
 Submenu
 Administration 37
 Application 157
 Build-up detection 71
 Burst configuration 1 to n 126
 Calibration 83
 Communication 117
 Configuration 118, 124
 Current output 1 87
 Custody transfer 162
 Custody transfer logbook 172
 Data logging 181
 Device information 172
 Diagnostic behavior 29
 Diagnostic configuration 150
 Diagnostic handling 28
 Diagnostic list 166
 Diagnostics 162
 Display 14
 Display channel 1 186
 Display channel 2 187
 Display channel 3 188
 Display channel 4 188
 Display module 178
 Electrode cleaning circuit 69
 Empty pipe detection 66
 Event list 171
 Event logbook 170
 External compensation 74
 HART input 118
 HART output 123
 Heartbeat Technology 189
 Information 132
 Input 85, 123
 Input values 48
 Low flow cut off 64
 Main electronic temperature 179
 Mainboard module 176
 Measured values 43
 Medium temperature 180
 Minimum/maximum values 179
 Output 87, 135
 Output values 48
 Process parameters 58
 Process variable adjustment 77
 Process variables 43
 Pulse/frequency/switch output 1 to n 99
 Reset access code 38
 Sensor 42

Sensor adjustment	76
Sensor electronic module (ISEM)	177
Simulation	189
Status input 1 to n	85
System	14
System units	51
Totalizer	46
Totalizer 1 to n	158
Web server	140
Subnet mask (Parameter)	142
Switch output function (Parameter)	111
Switch output simulation 1 to n (Parameter)	194
Switch point empty pipe detection (Parameter)	67
Switch status 1 (Parameter)	50
Switch status 1 to n (Parameter)	116, 195
Switch status 2 (Parameter)	50
Switch-off delay (Parameter)	116
Switch-off value (Parameter)	114
Switch-on delay (Parameter)	115
Switch-on value (Parameter)	114
System (Submenu)	14
System units (Submenu)	51

T

Target group	4
Temperature (Parameter)	45
Temperature damping (Parameter)	63
Temperature factor (Parameter)	81
Temperature offset (Parameter)	81
Temperature source (Parameter)	75
Temperature unit (Parameter)	54
Tertiary variable (TV) (Parameter)	138
Timeout (Parameter)	121
Timestamp (Parameter)	164, 165, 166, 167, 168, 169, 170
Totalizer (Submenu)	46
Totalizer 1 to n (Submenu)	158
Totalizer operation mode (Parameter)	160
Totalizer overflow 1 to n (Parameter)	47
Totalizer value 1 to n (Parameter)	46

U

Unit totalizer 1 to n (Parameter)	159
User name (Parameter)	146

V

Value (Parameter)	123
Value 1 display (Parameter)	18
Value 2 display (Parameter)	20
Value 3 display (Parameter)	21
Value 4 display (Parameter)	23
Value current output 1 (Parameter)	192
Value status input (Parameter)	48, 86
Volume flow (Parameter)	43
Volume flow factor (Parameter)	78
Volume flow offset (Parameter)	79
Volume flow unit (Parameter)	51
Volume unit (Parameter)	53

W

Web server (Submenu)	140
Web server functionality (Parameter)	142
Web server language (Parameter)	140
Wizard	
Define access code	37
WLAN settings	143
WLAN (Parameter)	144
WLAN IP address (Parameter)	146
WLAN MAC address (Parameter)	146
WLAN mode (Parameter)	144
WLAN passphrase (Parameter)	147
WLAN password (Parameter)	146
WLAN settings (Wizard)	143
WLAN subnet mask (Parameter)	147

Z

Zero point (Parameter)	84
----------------------------------	----



71535809

www.addresses.endress.com
