

Description of Device Parameters

FTL51B

HART

Vibronic




Table of contents

1 About this document 3

- 1.1 Document function 3
- 1.2 Target group 3
- 1.3 Using this document 3
- 1.4 Symbols 4
- 1.5 Documentation 4

2 Overview of the operating menu 5

3 Description of device parameters ... 17

- 3.1 "Guidance" menu 19
- 3.2 "Diagnostics" menu 29
- 3.3 "Application" menu 50
- 3.4 "System" menu 70

Index 88

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters. The document provides a detailed explanation of each individual parameter.

Performance of tasks that require detailed knowledge of the functioning of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases

1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

This document lists the submenus and parameters that are available when the "Maintenance" option user role is enabled.

 For the operating concept of the operating menus, see the Operating Instructions.

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

- Navigation: Navigation path to the parameter via the local display
- Prerequisite: The parameter is only available under these specific conditions
- Description: Description of the parameter function
- Selection: List of the individual options for the parameter
- User entry: Input range for the parameter
- User interface: Display value/data of the parameter
- Factory setting: Default setting on leaving the factory
- Additional information:
 - On individual options
 - On display values/data
 - On the input range
 - On the factory setting
 - On the parameter function

1.4 Symbols

1.4.1 Symbols for certain types of information

Additional information: 

Reference to documentation: 

Operation via local display: 

Operation via operating tool: 

Write-protected parameter: 

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

 The Operating Instructions are available via the Internet: www.endress.com → Download

1.5.2 Supplementary device-dependent documentation

Special Documentation

 The Special Documentation is available via the Internet: www.endress.com → Download

2 Overview of the operating menu

Language	
User role	
Guidance	→ 19
▶ Commissioning	→ 19
Device tag	
Temperature unit	→ 19
Mode of operation	→ 19
Safety function	→ 19
Density setting	→ 20
Lower range value output	→ 20
Upper range value output	→ 20
Current range output	→ 21
Failure behavior current output	→ 21
▶ Safety lock	→ 21
Proof test via Bluetooth allowed?	→ 21
Enter safety locking code	→ 22
Locking status	→ 26
SIL status	→ 22
Character test string	→ 22
Device tag	→ 22
Device name	→ 23
Serial number	→ 23
CRC device configuration	→ 23
Stored CRC device configuration	→ 23

Operating time	→ 24
Timestamp stored CRC device config.	→ 24
Operating time	→ 24
Configuration counter	
Density setting	→ 24
Safety function	→ 24
Switching delay uncovered to covered	→ 24
Switching delay uncovered to covered	→ 25
Switching delay covered to uncovered	→ 25
Switching delay covered to uncovered	→ 25
Failure behavior current output	→ 25
Current range output	→ 26
Lower range value output	→ 26
Upper range value output	→ 26
Enter safety locking code	→ 22
Code incorrect	→ 27
Locking status	→ 26
► Safety unlock	→ 27
Enter safety unlocking code	→ 27
Code incorrect	→ 27
Locking status	→ 28
Diagnostics	→ 29
► Active diagnostics	→ 29
Active diagnostics	→ 29
Timestamp	→ 29

Previous diagnostics	→ 29
Timestamp	→ 29
Operating time from restart	→ 30
Operating time	→ 30
► Minimum/maximum values	→ 30
Frequency min	→ 30
Frequency max	→ 30
Minimum terminal voltage	→ 31
Maximum terminal voltage	→ 31
Minimum electronics temperature	→ 31
Maximum electronics temperature	→ 31
Minimum sensor temperature	→ 31
Maximum sensor temperature	→ 32
► Simulation	→ 32
Value current output	→ 32
Simulation	→ 32
Frequency simulation value	→ 33
Fork state simulation value	→ 33
Diagnostic event category	→ 33
Diagnostic event simulation	→ 33
► Heartbeat Technology	→ 34
► Heartbeat Verification	→ 34
Start verification	→ 34
Date/time Heartbeat Verification	→ 34
Operating time (Verification)	→ 34

Overall result	→ 35
Status	→ 35
► Frequency history	→ 35
Sensor frequency 1	→ 35
Sensor frequency 2	→ 35
Sensor frequency 3	→ 36
Sensor frequency 4	→ 36
Sensor frequency 5	→ 36
Sensor frequency 6	→ 36
Sensor frequency 7	→ 36
Sensor frequency 8	→ 36
Sensor frequency 9	→ 37
Sensor frequency 10	→ 37
Sensor frequency 11	→ 37
Sensor frequency 12	→ 37
Sensor frequency 13	→ 37
Sensor frequency 14	→ 37
Sensor frequency 15	→ 38
Sensor frequency 16	→ 38
Date 1	→ 38
Date 2	→ 38
Date 3	→ 38
Date 4	→ 38
Date 5	→ 39
Date 6	→ 39

Date 7	→ 39
Date 8	→ 39
Date 9	→ 39
Date 10	→ 39
Date 11	→ 40
Date 12	→ 40
Date 13	→ 40
Date 14	→ 40
Date 15	→ 40
Date 16	→ 40
► Loop diagnostics	→ 41
Rebuild baseline	→ 41
Tolerated deviation +/-	→ 41
Baseline status	→ 41
Loop diagnostics	→ 42
Terminal voltage 1	→ 42
Clamping voltage lower threshold	→ 42
Clamping voltage upper threshold	→ 42
806 Alarm delay	→ 42
► Process window	→ 43
Sensor frequency	→ 43
900 Process alert frequency too low	→ 43
900 Alarm delay	→ 43
Low alert value	→ 43
901 Process alert frequency too high	→ 44

901 Alarm delay	→ 44
High alert value	→ 44
► Proof test	→ 44
Date/time proof test	→ 44
Time stamp of last proof test	→ 45
► Diagnostic settings	→ 45
► Properties	→ 45
49 Corrosion warning	→ 45
Upper warning frequency	→ 45
825 Electronics temperature	→ 46
826 Sensor temperature	→ 46
► Sensor	→ 46
49 Diagnostic behavior	→ 46
49 Event category	→ 47
► Process	→ 47
806 Diagnostic behavior	→ 47
806 Event category	→ 47
900 Diagnostic behavior	→ 48
900 Event category	→ 48
901 Diagnostic behavior	→ 48
901 Event category	→ 49
Application	→ 50
► Measured values	→ 50
Sensor frequency	→ 50
Fork state	→ 50

Terminal voltage 1	→ 50
Terminal current	→ 50
Sensor temperature	→ 51
Electronics temperature	→ 51
► Measuring Units	→ 51
Temperature unit	→ 51
► Sensor	→ 52
► Sensor configuration	→ 52
Mode of operation	→ 52
Safety function	→ 52
Density setting	→ 52
Damping	→ 53
Switching delay uncovered to covered	→ 53
Customer delay to covered	→ 53
Switching delay covered to uncovered	→ 54
Customer delay to uncovered	→ 54
► Stored frequency	→ 54
Stored uncovered frequency	→ 54
Stored covered frequency	→ 54
► Sensor calibration	→ 55
Lower switching point at density	→ 55
Upper switching point at density	→ 55
Frequency at delivery status	→ 55
Upper warning frequency	→ 55
Upper alarm frequency	→ 56

▶ Current output	→ 56
Assign PV	→ 56
Current range output	→ 56
Lower range value output	→ 57
Upper range value output	→ 57
Failure behavior current output	→ 57
Failure current	→ 57
Output current	→ 58
Terminal current	→ 58
▶ HART output	→ 58
▶ Configuration	→ 58
HART address	→ 58
HART short tag	→ 58
Device tag	→ 59
No. of preambles	→ 59
Loop current mode	→ 59
▶ HART output	→ 60
Assign PV	→ 60
Primary variable (PV)	→ 60
Assign SV	→ 60
Secondary variable (SV)	→ 61
Assign TV	→ 61
Tertiary variable (TV)	→ 61
Assign QV	→ 61
Quaternary variable (QV)	→ 62

► Burst configuration 1	→ 62
Burst mode 1	→ 62
Burst command 1	→ 62
Burst variable 0	→ 63
Burst variable 1	→ 63
Burst variable 2	→ 64
Burst variable 3	→ 64
Burst variable 4	→ 65
Burst variable 5	→ 65
Burst variable 6	→ 65
Burst variable 7	→ 66
Burst trigger mode	→ 66
Burst trigger level	→ 67
Min. update period	→ 67
Max. update period	→ 67
► Information	→ 67
Device ID	→ 67
Device type	→ 68
Device revision	→ 68
HART short tag	→ 68
HART revision	→ 68
HART descriptor	→ 68
HART message	→ 69
HART date code	→ 69
System	→ 70

► Device management	→ 70
Device tag	→ 70
Locking status	→ 70
Configuration counter	→ 71
Reset device	→ 71
► User management	→ 71
User role	→ 71
► Change user role	→ 72
Enter access code	→ 72
► Define password	→ 73
Start	→ 72
Password	→ 72
Status password entry	→ 73
► Change password	→ 74
Start	→ 74
Old password	→ 74
Status password entry	→ 75
New password	→ 75
Status password entry	→ 75

Confirm new password	→ 75
Status password entry	→ 75
► Delete password	→ 76
Start	→ 76
Old password	→ 76
Status password entry	→ 76
► Reset password	→ 77
Start	→ 77
Reset password	→ 77
Status password entry	→ 77
► Logout	→ 78
Start	→ 78
User role	→ 78
► Bluetooth configuration	→ 78
Bluetooth activation	→ 78
► Display	→ 79
Language	→ 79
Format display	→ 79
Value 1 display	→ 79
Decimal places 1	→ 80
Value 2 display	→ 80
Decimal places 2	→ 80
Value 3 display	→ 81
Decimal places 3	→ 81
Value 4 display	→ 81

Decimal places 4	→ 81
Contrast display	→ 82
► Geolocation	→ 82
Process Unit Tag	→ 82
Location Description	→ 82
Longitude	→ 82
Latitude	→ 83
Altitude	→ 83
Location method	→ 83
► Information	→ 84
Device name	→ 84
Manufacturer	→ 84
Serial number	→ 84
Order code	→ 84
Firmware version	→ 85
Hardware version	→ 85
Extended order code 1	→ 85
Extended order code 2	→ 85
Extended order code 3	→ 85
► Software configuration	→ 86
CRC device configuration	→ 86
Stored CRC device configuration	→ 86
Timestamp stored CRC device config.	→ 86
Activate SW option	→ 86
Software option overview	→ 87

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display.

The operating menu is dynamic and adapts the choice of parameters to the selected options.

 The parameter description of the operating tool is contained in the operating tool.

Navigation  System → Display

Navigation  System → User manag. → User role

Language

Navigation  System → Display → Language

Description Set display language

Selection

- English *
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العَرَبِيَّة (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech)

User role

Navigation  System → User manag. → User role

Description Shows the access authorization to the parameters via the operating tool

* Visibility depends on order options or device settings

User interface

- Operator
- Maintenance
- Expert
- Production
- Development

3.1 "Guidance" menu

Navigation   Guidance

3.1.1 "Commissioning" wizard

Navigation   Guidance → Commissioning

Temperature unit



Navigation  Guidance → Commissioning → Temperature unit

Description Used to display the electronics temperature.

Selection *SI units* *US units*
 °C °F
 K

Mode of operation



Navigation  Guidance → Commissioning → Mode of operat.

Description Level limit detection: Switching mode, output is either 8 mA (demand) or 16 mA (good).
 Sensor frequency : Continuous mode, output between 4 mA and 20 mA proportional to sensor frequency.

Selection  Level limit detection
 Sensor frequency

Safety function



Navigation  Guidance → Commissioning → Safety function

Description MIN: Use for dry run protection.
 MAX: Use for overfill protection.

Selection  MIN
 MAX

Density setting**Navigation**

Guidance → Commissioning → Density setting

Selection

- > 0.4 g/cm³ *
- > 0.4 g/cm³ *
- > 0.5 g/cm³
- > 0.7 g/cm³

Additional information*Selection*

- **> 0.4 g/cm³** option
For liquids with a density of 0.4...0.6 g/cm³
- **> 0.4 g/cm³** option
For liquids with a density of 0.4...0.6 g/cm³
- **> 0.5 g/cm³** option
For liquids with a density 0.5...0.8 g/cm³
- **> 0.7 g/cm³** option
Standard setting for liquids with a density > 0.7 g/cm³

Lower range value output**Navigation**

Guidance → Commissioning → Low.range outp

Description

Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry

4 to 23 mA

Upper range value output**Navigation**

Guidance → Commissioning → Upp.range outp

Description

Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.

User entry

4 to 23 mA

* Visibility depends on order options or device settings

Current range output**Navigation**

Guidance → Commissioning → Cur.range outp

Description

Defines the current range used to transmit the measured or calculated value.
 In brackets are indicated the “low saturation value” and the “high saturation value”.
 If Measured value \leq “low saturation”, the output current is set to “low saturation”.
 If Measured value \geq “high saturation”, the output current is set to “high saturation”.

Note:

Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.

Selection

- 4...20 mA (4... 20.5 mA)
- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Failure behavior current output**Navigation**

Guidance → Commissioning → Fail.behav.out

Description

Defines which current the output assumes in the case of an error.
 Min: < 3.6 mA
 Max: >21.5 mA

Selection

- Min.
- Max.

3.1.2 "Safety lock" wizard

Navigation Guidance → Safety lock

Proof test via Bluetooth allowed?**Navigation**

Guidance → Safety lock → Bluetooth

Description

After completion of the Safety mode wizard, the device will be write protected via software lock.
 To use the proof test wizard (optional), the device does not have to be unlocked.
 It must be defined, if the proof test wizard via Bluetooth is allowed.

Selection

- No
- Yes

Enter safety locking code

Navigation Guidance → Safety lock → Safety code

Description The Safety locking/unlocking code can be found in the corresponding safety manual or the WHG documentation.

User entry 0 to 65 535

SIL status

Navigation Guidance → Safety lock → SIL status

User interface

- Not active
- SIL sequence active
- Active
- Failed
- Finished

Character test string

Navigation Guidance → Safety lock → Char.test string

Description The following character string is displayed:
0123456789+-,.

Set the 'Confirm' parameter to 'Yes' if this string is rendered correctly.

Set the 'Confirm' parameter to 'No' if this string is not rendered correctly. Safety locking is not possible in this case.

User interface Character string comprising numbers, letters and special characters

Device tag

Navigation Guidance → Safety lock → Device tag

Description Enter the name for the measuring point.

User interface Character string comprising numbers, letters and special characters

Device name

Navigation	 Guidance → Safety lock → Device name
Description	Use this function to display the device name. It can also be found on the nameplate.
User interface	Character string comprising numbers, letters and special characters

Serial number

Navigation	 Guidance → Safety lock → Serial number
Description	The serial number is a unique alphanumerical code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.
User interface	Character string comprising numbers, letters and special characters

CRC device configuration

Navigation	 Guidance → Safety lock → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535

Stored CRC device configuration

Navigation	 Guidance → Safety lock → Stored CRC conf.
Description	Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.
User interface	0 to 65 535

Timestamp stored CRC device config.

Navigation	 Guidance → Safety lock → TS stored CRC
Description	Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.
User interface	Character string comprising numbers, letters and special characters

Operating time

Navigation	  Guidance → Safety lock → Operating time
Description	Indicates how long the device has been in operation.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Density setting

Navigation	 Guidance → Safety lock → Density setting
User interface	<ul style="list-style-type: none">■ > 0.4 g/cm³ *■ > 0.4 g/cm³ *■ > 0.5 g/cm³■ > 0.7 g/cm³

Safety function

Navigation	 Guidance → Safety lock → Safety function
User interface	<ul style="list-style-type: none">■ MIN■ MAX

Switching delay uncovered to covered

Navigation	 Guidance → Safety lock → Time delay cover
User interface	<ul style="list-style-type: none">■ 0.25 s■ 0.50 s■ 1.00 s

* Visibility depends on order options or device settings

- 1.50 s
- 5.00 s
- Customer specific

Switching delay uncovered to covered

Navigation  Guidance → Safety lock → Time delay cover**User interface** Character string comprising numbers, letters and special characters

Switching delay covered to uncovered

Navigation  Guidance → Safety lock → Time delay free

- User interface**
- 0.25 s
 - 0.50 s
 - 1.00 s
 - 1.50 s
 - 5.00 s
 - Customer specific

Switching delay covered to uncovered

Navigation  Guidance → Safety lock → Time delay free**User interface** Character string comprising numbers, letters and special characters

Failure behavior current output

Navigation  Guidance → Safety lock → Fail.behav.out**Description** Assigned value of current output in case of an error.

- User interface**
- Min.
 - Max.

Current range output

Navigation	 Guidance → Safety lock → Cur.range outp
Description	Assigned current range used to transmit the measured value.
User interface	<ul style="list-style-type: none">■ 4...20 mA (4... 20.5 mA)■ 4...20 mA NE (3.8...20.5 mA)■ 4...20 mA US (3.9...20.8 mA)■ Customer specific

Lower range value output

Navigation	 Guidance → Safety lock → Low.range outp
Description	Assigned value 4 mA.
User interface	Character string comprising numbers, letters and special characters

Upper range value output

Navigation	 Guidance → Safety lock → Upp.range outp
Description	Assigned value 20 mA.
User interface	Character string comprising numbers, letters and special characters

Locking status

Navigation	  Guidance → Safety lock → Locking status
Description	Indicates the type of locking. 'Hardware locked' (HW) The device is locked by the 'WP' switch on the main electronics module. To unlock, set the switch into the OFF position. 'Safety locked' (SW) Unlock the device by entering the appropriate access code in 'Enter safety unlocking code'. 'Temporarily locked' (SW) The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.
User interface	<ul style="list-style-type: none">■ Hardware locked■ Safety locked■ Temporarily locked

Code incorrect

Navigation Guidance → Safety lock → Code incorrect

Description Abort SIL confirmation sequence or reenter SIL locking code.

Selection

- Reenter code
- Abort sequence

3.1.3 "Safety unlock" wizard

Navigation Guidance → Safety unlock

Enter safety unlocking code

Navigation Guidance → Safety unlock → Safe.unlock code

Description The Safety locking/unlocking code can be found in the corresponding safety manual or the WHG documentation.

User entry 0 to 65 535

Code incorrect

Navigation Guidance → Safety unlock → Code incorrect

Description Abort SIL confirmation sequence or reenter SIL locking code.

Selection

- Reenter code
- Abort sequence

Locking status

Navigation	 Guidance → Safety unlock → Locking status
Description	<p>Indicates the type of locking.</p> <p>'Hardware locked' (HW)</p> <p>The device is locked by the 'WP' switch on the main electronics module. To unlock, set the switch into the OFF position.</p> <p>'Safety locked' (SW)</p> <p>Unlock the device by entering the appropriate access code in 'Enter safety unlocking code'.</p> <p>'Temporarily locked' (SW)</p> <p>The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.</p>
User interface	<ul style="list-style-type: none">■ Hardware locked■ Safety locked■ Temporarily locked

3.2 "Diagnostics" menu

Navigation

④ Diagnostics

3.2.1 "Active diagnostics" submenu

Navigation

④ Diagnostics → Active diagnos.

Active diagnostics

Navigation

④④ Diagnostics → Active diagnos. → Active diagnos.

Description

Displays the currently active diagnostic message.

If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.

User interface

Positive integer

Timestamp

Navigation

④④ Diagnostics → Active diagnos. → Timestamp

Description

Displays the timestamp for the currently active diagnostic message.

User interface

Days (d), hours (h), minutes (m), seconds (s)

Previous diagnostics

Navigation

④④ Diagnostics → Active diagnos. → Prev.diagnostics

Description

Displays the diagnostic message for the last diagnostic event that has ended.

User interface

Positive integer

Timestamp

Navigation

④④ Diagnostics → Active diagnos. → Timestamp

Description

Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time from restart

Navigation  Diagnostics → Active diagnos. → Time fr. restart

Description Indicates how long the device has been in operation since the last time the device was restarted.

User interface Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation  Diagnostics → Active diagnos. → Operating time

Description Indicates how long the device has been in operation.

User interface Days (d), hours (h), minutes (m), seconds (s)

3.2.2 "Minimum/maximum values" submenu

Navigation  Diagnostics → Min/max val.

Frequency min

Navigation  Diagnostics → Min/max val. → Frequency min

Description Minimum or maximum measured sensor frequency.

User interface Signed floating-point number

Frequency max

Navigation  Diagnostics → Min/max val. → Frequency max

Description Minimum or maximum measured sensor frequency.

User interface Signed floating-point number

Minimum terminal voltage

Navigation  Diagnostics → Min/max val. → Min.term.volt.**Description** Minimum or maximum measured terminal (supply) voltage.**User interface** 0.0 to 50.0 V**Maximum terminal voltage**

Navigation  Diagnostics → Min/max val. → Max.term.voltage**Description** Minimum or maximum measured terminal (supply) voltage.**User interface** 0.0 to 50.0 V**Minimum electronics temperature**

Navigation  Diagnostics → Min/max val. → Min.electr.temp.**Description** Minimum or maximum measured main electronics temperature.**User interface** Signed floating-point number**Maximum electronics temperature**

Navigation  Diagnostics → Min/max val. → Max.electr.temp.**Description** Minimum or maximum measured main electronics temperature.**User interface** Signed floating-point number**Minimum sensor temperature**

Navigation  Diagnostics → Min/max val. → Min. sensor temp**Description** Minimum or maximum measured sensor (sensor electronics) temperature.**User interface** Signed floating-point number

Maximum sensor temperature

Navigation   Diagnostics → Min/max val. → Max. Sensor temp

Description Minimum or maximum measured sensor (sensor electronics) temperature.

User interface Signed floating-point number

3.2.3 "Simulation" submenu

Navigation   Diagnostics → Simulation

Value current output



Navigation   Diagnostics → Simulation → Val. curr.outp

Description Defines the value of the simulated output current.

User entry 3.59 to 23 mA

Simulation



Navigation   Diagnostics → Simulation → Simulation

Description By activating the simulation, the following can be simulated:

- Fork state
- Sensor frequency
- Current output
- Diagnostic event simulation

The simulation can affect the output current.

Selection

- Off
- Fork state
- Sensor frequency
- Current output
- Diagnostic event simulation

Frequency simulation value**Navigation**

Diagnostics → Simulation → Freq. simulation

Description

In level limit detection mode, output current and fork state are independent of frequency simulation value.

User entry

0 to 10 000 Hz

Fork state simulation value**Navigation**

Diagnostics → Simulation → Fork. simul.val.

Description

In sensor frequency mode, output current is independent of fork state simulation value. In level limit detection mode, sensor frequency is independent of fork state simulation value.

Selection

- Fork covered
- Fork uncovered

Diagnostic event category**Navigation**

Diagnostics → Simulation → Event category

Description

Select which diagnostic events can be simulated.

Selection

- Sensor
- Electronics
- Configuration
- Process

Diagnostic event simulation**Navigation**

Diagnostics → Simulation → Diag. event sim.

Description

Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select "Off".

Selection

Off

3.2.4 "Heartbeat Technology" submenu

Navigation  Diagnostics → Heartbeat Techn.

"Heartbeat Verification" submenu

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif.

Date/time Heartbeat Verification

Navigation   Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification

Description Date and time of last Heartbeat Verification.

This value is updated with every Heartbeat verification.

Note:

If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.

User interface Character string comprising numbers, letters and special characters

Start verification



Navigation   Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Start verificat.

Description Start verification.

Selection

- Cancel
- Start

Operating time (Verification)

Navigation   Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time

User interface Days (d), hours (h), minutes (m), seconds (s)

Overall result

Navigation	  Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Overall result
User interface	<ul style="list-style-type: none">■ Not done■ Passed■ Not done■ Failed

Status

Navigation	  Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status
Description	Shows the actual status.
User interface	<ul style="list-style-type: none">■ Done■ Busy■ Failed■ Not done

"Frequency history" submenu

Navigation  Diagnostics → Heartbeat Techn. → Freq. history

Sensor frequency 1

Navigation	  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 1
User interface	Signed floating-point number

Sensor frequency 2

Navigation	  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 2
User interface	Signed floating-point number

Sensor frequency 3

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 3

User interface Signed floating-point number

Sensor frequency 4

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 4

User interface Signed floating-point number

Sensor frequency 5

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 5

User interface Signed floating-point number

Sensor frequency 6

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 6

User interface Signed floating-point number

Sensor frequency 7

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 7

User interface Signed floating-point number

Sensor frequency 8

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 8

User interface Signed floating-point number

Sensor frequency 9

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 9**User interface** Signed floating-point number**Sensor frequency 10**

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 10**User interface** Signed floating-point number**Sensor frequency 11**

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 11**User interface** Signed floating-point number**Sensor frequency 12**

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 12**User interface** Signed floating-point number**Sensor frequency 13**

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 13**User interface** Signed floating-point number**Sensor frequency 14**

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Frequency 14**User interface** Signed floating-point number

Sensor frequency 15

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Frequency 15

User interface Signed floating-point number

Sensor frequency 16

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Frequency 16

User interface Signed floating-point number

Date 1

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Date 1

User interface Character string comprising numbers, letters and special characters

Date 2

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Date 2

User interface Character string comprising numbers, letters and special characters

Date 3

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Date 3

User interface Character string comprising numbers, letters and special characters

Date 4

Navigation   Diagnostics → Heartbeat Techn. → Freq. history → Date 4

User interface Character string comprising numbers, letters and special characters

Date 5

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 5

User interface Character string comprising numbers, letters and special characters

Date 6

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 6

User interface Character string comprising numbers, letters and special characters

Date 7

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 7

User interface Character string comprising numbers, letters and special characters

Date 8

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 8

User interface Character string comprising numbers, letters and special characters

Date 9

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 9

User interface Character string comprising numbers, letters and special characters

Date 10

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 10

User interface Character string comprising numbers, letters and special characters

Date 11

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 11

User interface Character string comprising numbers, letters and special characters

Date 12

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 12

User interface Character string comprising numbers, letters and special characters

Date 13

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 13

User interface Character string comprising numbers, letters and special characters

Date 14

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 14

User interface Character string comprising numbers, letters and special characters

Date 15

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 15

User interface Character string comprising numbers, letters and special characters

Date 16

Navigation  Diagnostics → Heartbeat Techn. → Freq. history → Date 16

User interface Character string comprising numbers, letters and special characters

"Loop diagnostics" submenu**Navigation**

Diagnostics → Heartbeat Techn. → Loop diagn.

**Rebuild baseline****Navigation**

Diagnostics → Heartbeat Techn. → Loop diagn. → Reb. baseline

Description**Notice**

The current output is simulated.

Bridge the PLC or take other appropriate measures to prevent an erroneous triggering of alarm messages or changes in the control loop behavior.

The baseline should be rebuilt if planned changes have been made in the loop.

Selection

- No
- Yes

**Tolerated deviation +/-****Navigation**

Diagnostics → Heartbeat Techn. → Loop diagn. → Toler. deviation

Description

A value should be chosen to ensure that normal voltage deviations do not lead to unwanted messages.

Default
1.5 V DC

User entry

0.5 to 3.0 V

**Baseline status****Navigation**

Diagnostics → Heartbeat Techn. → Loop diagn. → Baseline status

Description**'Failed'**

Means, baseline is not available or creation not possible.

'Passed'

Baseline is available.

User interface

- Failed
- Success

Loop diagnostics

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → Loop diagn.

Selection

- Disable
- Enable

Terminal voltage 1

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V

Clamping voltage lower threshold

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → Lower threshold

User interface 0.0 to 50.0 V

Clamping voltage upper threshold

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → Upper threshold

User interface 0.0 to 50.0 V

806 Alarm delay

Navigation Diagnostics → Heartbeat Techn. → Loop diagn. → 806 Alarm delay

User entry 0 to 60 s

"Process window" submenu**Navigation**

Diagnostics → Heartbeat Techn. → Process window

Sensor frequency**Navigation**

Diagnostics → Heartbeat Techn. → Process window → Frequency

Description

Actual fork frequency.

User interface

0 to 10 000 Hz

900 Process alert frequency too low**Navigation**

Diagnostics → Heartbeat Techn. → Process window → 900 Freq. too low

Description

Note: With the MAX safety function, no event for 'Process alert frequency too low' is triggered if the fork is covered.

Selection

- Disable
- Enable

900 Alarm delay**Navigation**

Diagnostics → Heartbeat Techn. → Process window → 900 Alarm delay

User entry

0 to 300 s

Low alert value**Navigation**

Diagnostics → Heartbeat Techn. → Process window → Low alert value

Description

If this limit value is undercut, an event is generated. There is no hysteresis. A typical value is 1% below the actual frequency.

User entry

0 to 2 000 Hz

901 Process alert frequency too high**Navigation**

Diagnostics → Heartbeat Techn. → Process window → 901 Freq. high

Description

Note: With the MIN safety function, no event for 'Process alert frequency too high' is triggered if the fork is uncovered.

Selection

- Disable
- Enable

901 Alarm delay**Navigation**

Diagnostics → Heartbeat Techn. → Process window → 901 Alarm delay

User entry

0 to 300 s

High alert value**Navigation**

Diagnostics → Heartbeat Techn. → Process window → High alert value

Description

If this limit value is exceeded an event is generated. There is no hysteresis. With stable environmental conditions a typical value is 1% above the actual frequency.

User entry

0 to 2 000 Hz

3.2.5 "Proof test" submenu

Navigation

Diagnostics → Proof test

Date/time proof test**Navigation**

Diagnostics → Proof test → Date/time

Description

This value is updated with every proof test and with inspector decision „Passed“.

User interface

Character string comprising numbers, letters and special characters

Time stamp of last proof test

Navigation  Diagnostics → Proof test → Last proof test

Description As soon as key is pressed, actual operating hours counter is saved.

User interface Character string comprising numbers, letters and special characters

3.2.6 "Diagnostic settings" submenu

Navigation  Diagnostics → Diag. settings

"Properties" submenu

Navigation  Diagnostics → Diag. settings → Properties

49 Corrosion warning

Navigation  Diagnostics → Diag. settings → Properties → 49 Corr. warning

Description Enables or disable the corrosion warning. The corrosion warning is set if sensor frequency exceeds frequency at delivery status by 5%.
If turned on event category can be set in menu -> Diagnostics -> Diagnostic settings -> Configuration
Diagnostic behaviour can be changed to 'Logbook entry only' in the same menu.

Selection

- Off
- On

Upper warning frequency

Navigation  Diagnostics → Diag. settings → Properties → U. warning freq.

Description If the sensor frequency is currently greater than the upper warning frequency, then a warning is generated. The switching output remains in the current state. It is recommended to remove the sensor and check it for corrosion.

User interface 0 to 10 000 Hz

825 Electronics temperature**Navigation**

Diagnostics → Diag. settings → Properties → 825 Electr. temp

Description

Activates the monitoring of the electronics temperature. The limit values are fixed and depend on the order code of the device (+85°C and -40/-50/-60°C or 185°F and -40/-58/-76°F).

Selection

- Off
- On

826 Sensor temperature**Navigation**

Diagnostics → Diag. settings → Properties → 826 Sensor temp.

Description

Activates the monitoring of the sensor (electronics) temperature. The limit values are fixed and depend on the order code of the device (+85°C and -40/-50/-60°C or 185°F and -40/-58/-76°F).

Selection

- Off
- On

"Sensor" submenu*Navigation*

Diagnostics → Diag. settings → Sensor

49 Diagnostic behavior**Navigation**

Diagnostics → Diag. settings → Sensor → 49 Diag. behav.

Description

Select event behavior

'Logbook entry only': no digital or analog transmission of the message.

'Warning': Current output unchanged. Message is output digitally (default).

If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

49 Event category

Navigation Diagnostics → Diag. settings → Sensor → 49Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

"Process" submenu

Navigation Diagnostics → Diag. settings → Process

806 Diagnostic behavior

Navigation Diagnostics → Diag. settings → Process → 806 Diag. behav.

Description Select event behavior
'Logbook entry only': no digital or analog transmission of the message.
'Warning': Current output unchanged. Message is output digitally (default).
If the permissible conditions are reached again, the warning is no longer available in the instrument.

Selection

- Warning
- Logbook entry only

806 Event category

Navigation Diagnostics → Diag. settings → Process → 806Event category

Description Select category for diagnostic message.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

900 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Process → 900 Diag. behav.
Description	Select event behavior 'Logbook entry only': no digital or analog transmission of the message. 'Warning': Current output unchanged. Message is output digitally (default). If the permissible conditions are reached again, the warning is no longer available in the instrument.
Selection	<ul style="list-style-type: none">▪ Warning▪ Logbook entry only

900 Event category

Navigation	Diagnostics → Diag. settings → Process → 900Event category
Selection	<ul style="list-style-type: none">▪ Failure (F)▪ Function check (C)▪ Out of specification (S)▪ Maintenance required (M)▪ No effect (N)

901 Diagnostic behavior

Navigation	Diagnostics → Diag. settings → Process → 901 Diag. behav.
Description	Select event behavior 'Logbook entry only': no digital or analog transmission of the message. 'Warning': Current output unchanged. Message is output digitally (default). If the permissible conditions are reached again, the warning is no longer available in the instrument.
Selection	<ul style="list-style-type: none">▪ Warning▪ Logbook entry only

901 Event category**Navigation**

Diagram Diagnostics → Diag. settings → Process → 901Event category

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

3.3 "Application" menu

Navigation  Application

3.3.1 "Measured values" submenu

Navigation  Application → Measured values

Sensor frequency

Navigation   Application → Measured values → Frequency

Description Actual fork frequency.

User interface 0 to 10 000 Hz

Fork state

Navigation   Application → Measured values → Fork state

Description The condition of the fork is displayed.

User interface

- Fork covered
- Fork uncovered

Terminal voltage 1

Navigation   Application → Measured values → Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output

User interface 0.0 to 50.0 V

Terminal current

Navigation   Application → Measured values → Terminal curr.

Description Shows the current value of the current output which is currently measured

User interface 0 to 30 mA

Sensor temperature

Navigation Application → Measured values → Sensor temp.

User interface Signed floating-point number

Electronics temperature

 Application → Measured values → Electronics temp

User interface Signed floating-point number

3.3.2 "Measuring Units" submenu

Navigation Application → Measuring Units

Temperature unit

Navigation Application → Measuring Units → Temperature unit

Description Used to display the electronics temperature.

Selection	<i>SI units</i>	<i>US units</i>
	■ °C	°F
	■ K	

3.3.3 "Sensor" submenu

Navigation



Application → Sensor

"Sensor configuration" submenu

Navigation



Application → Sensor → Sensor conf.

Mode of operation



Navigation



Application → Sensor → Sensor conf. → Mode of operat.

Description

Level limit detection: Switching mode, output is either 8 mA (demand) or 16 mA (good).

Sensor frequency : Continuous mode, output between 4 mA and 20 mA proportional to sensor frequency.

Selection

- Level limit detection
- Sensor frequency

Safety function



Navigation



Application → Sensor → Sensor conf. → Safety function

Description

MIN: Use for dry run protection.

MAX: Use for overfill protection.

Selection

- MIN
- MAX

Density setting



Navigation



Application → Sensor → Sensor conf. → Density setting

Selection

- > 0.4 g/cm³ *
- > 0.4 g/cm³ *
- > 0.5 g/cm³
- > 0.7 g/cm³

* Visibility depends on order options or device settings

Additional information*Selection*

- > **0.4 g/cm³** option
For liquids with a density of 0.4...0.6 g/cm³
- > **0.4 g/cm³** option
For liquids with a density of 0.4...0.6 g/cm³
- > **0.5 g/cm³** option
For liquids with a density 0.5...0.8 g/cm³
- > **0.7 g/cm³** option
Standard setting for liquids with a density > 0.7 g/cm³

Damping**Navigation**

Application → Sensor → Sensor conf. → Damping

Description

Damping, used for Sensor frequency only. Does not affect Level limit detection and Fork state.

User entry

0 to 999 s

Switching delay uncovered to covered**Navigation**

Application → Sensor → Sensor conf. → Delay to covered

Description

Choose between predefined values or select 'Customer specific' to enter a value between 1.00 s and 60.00 s.

Selection

- 0.25 s
- 0.50 s
- 1.00 s
- 1.50 s
- 5.00 s
- Customer specific

Customer delay to covered**Navigation**

Application → Sensor → Sensor conf. → Cust. delay cov.

User entry

1 to 60 s

Switching delay covered to uncovered**Navigation**

Application → Sensor → Sensor conf. → Delay to uncov.

Description

Choose between predefined values or select 'Customer specific' to enter a value between 1.00 s and 60.00 s.

Selection

- 0.25 s
- 0.50 s
- 1.00 s
- 1.50 s
- 5.00 s
- Customer specific

Customer delay to uncovered**Navigation**

Application → Sensor → Sensor conf. → Cust. delay unc.

User entry

1 to 60 s

"Stored frequency" submenu**Navigation**

Application → Sensor → Stored frequency

Stored uncovered frequency**Navigation**

Application → Sensor → Stored frequency → St. uncov. freq

Description

In this parameter the actual sensor frequency can be stored, which is only possible if the fork is uncovered. The value is displayed on the Heartbeat Technology verification report and can be used as a reference for further/future analyses.

User interface

0 to 10 000 Hz

Stored covered frequency**Navigation**

Application → Sensor → Stored frequency → Stor. cov. freq

Description

In this parameter the actual sensor frequency can be stored, which is only possible if the fork is covered. The value is displayed on the Heartbeat Technology verification report and can be used as a reference for further/future analyses.

User interface	0 to 10 000 Hz
----------------	----------------

"Sensor calibration" submenu

Navigation



Application → Sensor → Sensor cal.

Lower switching point at density

Navigation	Application → Sensor → Sensor cal. → Lower sw. point
------------	--

Description	This is the sensor frequency at which the fork status changes to covered (depending on the density selected).
-------------	---

User interface	0 to 2 000 Hz
----------------	---------------

Upper switching point at density

Navigation	Application → Sensor → Sensor cal. → Upper sw. point
------------	--

Description	This is the sensor frequency at which the fork status changes to uncovered (depending on the density selected).
-------------	---

User interface	0 to 2 000 Hz
----------------	---------------

Frequency at delivery status

Navigation	Application → Sensor → Sensor cal. → Freq. delivery
------------	---

Description	Sensor frequency at delivery status.
-------------	--------------------------------------

User interface	0 to 10 000 Hz
----------------	----------------

Upper warning frequency

Navigation	Application → Sensor → Sensor cal. → U. warning freq.
------------	---

Description	If the sensor frequency is currently greater than the upper warning frequency, then a warning is generated. The switching output remains in the current state. It is recommended to remove the sensor and check it for corrosion.
-------------	---

User interface	0 to 10 000 Hz
----------------	----------------

Upper alarm frequency

Navigation	 Application → Sensor → Sensor cal. → Upper alarm f.
------------	---

Description	If the sensor frequency is currently greater than the upper alarm frequency, then an alarm is generated and the switching output switches to the safety related state.
-------------	--

User interface	0 to 10 000 Hz
----------------	----------------

3.3.4 "Current output" submenu

Navigation  Application → Curr.output

Assign PV

Navigation	 Application → Curr.output → Assign PV
------------	---

Description	Assign a measured variable to the primary dynamic variable (PV). Additional information: The assigned measured variable is also used by the current output.
-------------	---

User interface	<ul style="list-style-type: none">■ Level limit detection■ Sensor frequency
----------------	--

Current range output



Navigation	 Application → Curr.output → Cur.range outp
------------	--

Description	Defines the current range used to transmit the measured or calculated value. In brackets are indicated the “low saturation value” and the “high saturation value”. If Measured value \leq “low saturation”, the output current is set to “low saturation”. If Measured value \geq “high saturation”, the output current is set to “high saturation”. Note: Currents below 3.6 mA or above 21.5 mA can be used to signal an alarm.
-------------	--

Selection	<ul style="list-style-type: none">■ 4...20 mA (4... 20.5 mA)■ 4...20 mA NE (3.8...20.5 mA)■ 4...20 mA US (3.9...20.8 mA)
-----------	--

Lower range value output

Navigation  Application → Curr.output → Low.range outp**Description** Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.**User entry** 4 to 23 mA

Upper range value output

Navigation  Application → Curr.output → Upp.range outp**Description** Depending of which variable has been selected as PV, define the related lower and upper range values.
Assignment PV value to 4 mA and 20 mA.**User entry** 4 to 23 mA

Failure behavior current output

Navigation  Application → Curr.output → Fail.behav.out**Description** Defines which current the output assumes in the case of an error.
Min: < 3.6 mA
Max: > 21.5 mA**Selection**

- Min.
- Max.

Failure current

Navigation  Application → Curr.output → Failure current**Description** Enter current output value in alarm condition**User entry** 21.5 to 23 mA

Output current

Navigation	  Application → Curr.output → Output curr.
Description	Shows the value currently calculated for the current output
User interface	3.59 to 23 mA

Terminal current

Navigation	  Application → Curr.output → Terminal curr.
Description	Shows the current value of the current output which is currently measured
User interface	0 to 30 mA

3.3.5 "HART output" submenu

Navigation  Application → HART output

"Configuration" submenu

Navigation  Application → HART output → Configuration

HART address

Navigation	  Application → HART output → Configuration → HART address
Description	Enter the address to exchange data via the HART protocol.
User entry	0 to 63

HART short tag

Navigation	  Application → HART output → Configuration → HART short tag
Description	Defines the short tag for the measuring point. Maximum length: 8 characters Allowed characters: A-Z, 0-9, certain special characters

User entry	Character string comprising numbers, letters and special characters (8)
-------------------	---

Device tag	
-------------------	---

Navigation	  Application → HART output → Configuration → Device tag
-------------------	--

Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
--------------------	--

User entry	Character string comprising numbers, letters and special characters (32)
-------------------	--

No. of preambles	
-------------------------	---

Navigation	  Application → HART output → Configuration → No. of preambles
-------------------	--

Description	Defines the number of preambles in the HART telegram
--------------------	--

User entry	5 to 20
-------------------	---------

Loop current mode	
--------------------------	---

Navigation	  Application → HART output → Configuration → Loop curr mode
-------------------	--

Description	If Loop current mode is disabled, Multi-drop communication mode is activated. Multi-drop is a HART digital communication mode where multiple devices may share the same pair of wires for power and communications. In this mode the output current is fixed.
--------------------	--

Selection	<ul style="list-style-type: none">■ Disable■ Enable
------------------	--

"HART output" submenu*Navigation*

Application → HART output → HART output

Assign PV**Navigation**

Application → HART output → HART output → Assign PV

Description

Assign a measured variable to the primary dynamic variable (PV).

Additional information:

The assigned measured variable is also used by the current output.

User interface

- Level limit detection
- Sensor frequency

Primary variable (PV)**Navigation**

Application → HART output → HART output → Primary var (PV)

Description

Shows the current measured value of the primary dynamic variable (PV)

User interface

4 to 23 mA

Assign SV**Navigation**

Application → HART output → HART output → Assign SV

Description

Assign a measured variable to the second dynamic variable (SV).

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage *
- Not used

Additional information*Selection*

- **Fork state** option

Indicates fork state 'Fork covered' (1) or 'Fork uncovered' (0).

- **Sensor temperature** option

Temperature of sensor electronics in the housing.

* Visibility depends on order options or device settings

Secondary variable (SV)

Navigation	  Application → HART output → HART output → Second.var(SV)
Description	Shows the current measured value of the secondary dynamic variable (SV)
User interface	0 to 10 000 Hertz

Assign TV

Navigation	  Application → HART output → HART output → Assign TV
Description	Assign a measured variable to the tertiary dynamic variable (TV).
Selection	<ul style="list-style-type: none"> ▪ Level limit detection ▪ Sensor frequency ▪ Fork state ▪ Sensor temperature ▪ Electronics temperature ▪ Measured current [*] ▪ Terminal voltage [*] ▪ Not used
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Fork state option Indicates fork state 'Fork covered' (1) or 'Fork uncovered' (0). ▪ Sensor temperature option Temperature of sensor electronics in the housing.

Tertiary variable (TV)

Navigation	  Application → HART output → HART output → Tertiary var(TV)
Description	Shows the current measured value of the tertiary (third) dynamic variable (TV)
User interface	0 to 1.0 ManufacturerNoUnit

Assign QV

Navigation	  Application → HART output → HART output → Assign QV
Description	Assign a measured variable to the quaternary dynamic variable (QV).

* Visibility depends on order options or device settings

Selection	<ul style="list-style-type: none"> ■ Level limit detection ■ Sensor frequency ■ Fork state ■ Sensor temperature ■ Electronics temperature ■ Measured current [*] ■ Terminal voltage [*] ■ Not used
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Fork state option Indicates fork state 'Fork covered' (1) or 'Fork uncovered' (0). ■ Sensor temperature option Temperature of sensor electronics in the housing.

Quaternary variable (QV)

Navigation	 Application → HART output → HART output → Quaterna.var(QV)
Description	Shows the current measured value of the quaternary (fourth) dynamic variable (QV)
User interface	Signed floating-point number

"Burst configuration 1" submenu

Navigation  Application → HART output → Burst config. 1

Burst mode	
Navigation	 Application → HART output → Burst config. 1 → Burst mode 1
Description	Switch HART burst mode for burst message on
Selection	<ul style="list-style-type: none"> ■ Off ■ On

Burst command	
Navigation	 Application → HART output → Burst config. 1 → Burst command 1
Description	Select the HART command that is sent to the HART master

* Visibility depends on order options or device settings

Selection

- Primary variable (PV)
- Loop Current and Percent of Range
- Dynamic Variables
- Device variables with status
- Device variables
- Additional device status

Burst variable 0**Navigation**

Application → HART output → Burst config. 1 → Burst variable 0

Description

For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage 1 *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 1**Navigation**

Application → HART output → Burst config. 1 → Burst variable 1

Description

For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current *
- Terminal voltage 1 *
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)

* Visibility depends on order options or device settings

- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 2



Navigation

Application → HART output → Burst config. 1 → Burst variable 2

Description

For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current ^{*}
- Terminal voltage 1 ^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 3



Navigation

Application → HART output → Burst config. 1 → Burst variable 3

Description

For HART command 9 and 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current ^{*}
- Terminal voltage 1 ^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

* Visibility depends on order options or device settings

Burst variable 4**Navigation**

Application → HART output → Burst config. 1 → Burst variable 4

Description

For HART command 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current ^{*}
- Terminal voltage 1 ^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 5**Navigation**

Application → HART output → Burst config. 1 → Burst variable 5

Description

For HART command 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current ^{*}
- Terminal voltage 1 ^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 6**Navigation**

Application → HART output → Burst config. 1 → Burst variable 6

Description

For HART command 33, assign a HART device variable or process variable to burst variable

* Visibility depends on order options or device settings

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature^{*}
- Measured current^{*}
- Terminal voltage 1^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst variable 7**Navigation**

Application → HART output → Burst config. 1 → Burst variable 7

Description

For HART command 33, assign a HART device variable or process variable to burst variable

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Electronics temperature
- Measured current^{*}
- Terminal voltage 1^{*}
- Percent of range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Burst trigger mode**Navigation**

Application → HART output → Burst config. 1 → Trigger mode

Description

Select the event that triggers the burst message

Selection

- Continuous
- Window^{*}
- Rising^{*}
- Falling^{*}
- On change

* Visibility depends on order options or device settings

Burst trigger level**Navigation**

Application → HART output → Burst config. 1 → Trigger level

Description

Enter the burst trigger value that determines together with the option selected in 'Burst trigger mode' parameter the time of burst message

User entry

Signed floating-point number

Min. update period**Navigation**

Application → HART output → Burst config. 1 → Min. upd. per.

Description

Enter the minimum time span between two burst responses of one burst message

User entry

Positive integer

Max. update period**Navigation**

Application → HART output → Burst config. 1 → Max. upd. per.

Description

Enter the maximum time span between two burst responses of one burst message

User entry

Positive integer

"Information" submenu*Navigation*

Application → HART output → Information

Device ID**Navigation**

Application → HART output → Information → Device ID

Description

Shows the device ID for identifying the device in a HART network

User interface

Positive integer

Device type

Navigation  Application → HART output → Information → Device type

Description Shows the device type with which the measuring device is registered with the HART Communication Foundation

User interface 0 to 65 535

Device revision

Navigation  Application → HART output → Information → Device revision

Description Shows the device revision with which the device is registered with the HART Communication Foundation

User interface 0 to 255

HART short tag



Navigation  Application → HART output → Information → HART short tag

Description Defines the short tag for the measuring point.

Maximum length: 8 characters
Allowed characters: A-Z, 0-9, certain special characters

User entry Character string comprising numbers, letters and special characters (8)

HART revision

Navigation  Application → HART output → Information → HART revision

User interface 5 to 7

HART descriptor



Navigation  Application → HART output → Information → HART descriptor

Description Use this function to define a description for the measuring point.

Maximum length: 16 characters
Allowed characters: A-Z, 0-9, certain special characters

User entry	Character string comprising numbers, letters and special characters (16)
------------	--

HART message []

Navigation  Application → HART output → Information → HART message

Description Use this function to define a HART message which is sent via the HART protocol when requested by the master.

Maximum length: 32 characters

Allowed characters: A-Z, 0-9, certain special characters

User entry	Character string comprising numbers, letters and special characters (32)
------------	--

HART date code []

Navigation  Application → HART output → Information → HART date code

Description Enter date of the last configuration change. Use this format yyyy-mm-dd

User entry	Character string comprising numbers, letters and special characters (10)
------------	--

3.4 "System" menu

Navigation  System

3.4.1 "Device management" submenu

Navigation  System → Device manag.

Device tag



Navigation   System → Device manag. → Device tag

Description Enter a unique name for the measuring point to identify the device quickly within the plant.

User entry Character string comprising numbers, letters and special characters (32)

Locking status

Navigation   System → Device manag. → Locking status

Description Indicates the type of locking.

'Hardware locked' (HW)

The device is locked by the 'WP' switch on the main electronics module. To unlock, set the switch into the OFF position.

'Safety locked' (SW)

Unlock the device by entering the appropriate access code in 'Enter safety unlocking code'.

'Temporarily locked' (SW)

The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.

User interface

- Hardware locked
- Safety locked
- Temporarily locked

Configuration counter

Navigation
  System → Device manag. → Config. counter
Description

Displays the counter for changes to the device parameters.

Additional information:

- If the value for a static parameter is changed when optimizing or configuring the parameter, the counter is incremented by 1. This is to enable tracking different parameter versions.
- When multiple parameters are changed simultaneously, e.g. when loading parameters into the device from an external source such as FieldCare, the counter may display a higher value. The counter cannot be reset, nor is it reset to a default value on performing a device reset.
- Once the counter has reached the value 65535, it restarts at 0.

User interface

0 to 65 535

Reset device

**Navigation**
  System → Device manag. → Reset device
Description

Reset the device configuration - either entirely or in part - to a defined state

Selection

- Cancel
- To fieldbus defaults ^{**}
- To factory defaults ^{*}
- To delivery settings ^{*}
- Restart device

3.4.2 "User management" submenu

Navigation  System → User manag.

User role

Navigation
  System → User manag. → User role
Description

Shows the access authorization to the parameters via the operating tool

^{**} Visibility depends on communication

^{*} Visibility depends on order options or device settings

User interface

- Operator
- Maintenance
- Expert
- Production
- Development

"Change user role" wizard*Navigation*

System → User manag. → Change user role

Enter access code**Navigation**

System → User manag. → Change user role → Ent. access code

Description

For authorized service personnel only.

User entry

0 to 9 999

"Change user role" wizard*Navigation*

System → User manag. → Change user role

Start**Navigation**

System → User manag. → Change user role → Start

User interface

Character string comprising numbers, letters and special characters

Password**Navigation**

System → User manag. → Change user role → Password

Description

Enter the password for the 'Maintenance' user role to get access to the functionality of this role.

User entry

Character string comprising numbers, letters and special characters (16)

Status password entry

Navigation  System → User manag. → Change user role → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Define password" wizard

Navigation  System → User manag. → Define password

Start

Navigation  System → User manag. → Define password → Start

User interface Character string comprising numbers, letters and special characters

New password

Navigation  System → User manag. → Define password → New password

Description Define the new 'Maintenance' password.
A new password is valid after it has been confirmed within the 'Confirm new password' parameter.
Any valid password consists of 4 to 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (16)

Status password entry

Navigation   System → User manag. → Define password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

Confirm new password**Navigation**

System → User manag. → Define password → Conf. new passw.

Description

Enter the new password again to confirm.

User entry

Character string comprising numbers, letters and special characters (16)

"Change password" wizard

Navigation System → User manag. → Change password

Start**Navigation**

System → User manag. → Change password → Start

User interface

Character string comprising numbers, letters and special characters

Old password**Navigation**

System → User manag. → Change password → Old password

Description

Enter the current password, to subsequently change the existing password.

User entry

Character string comprising numbers, letters and special characters (16)

Status password entry

Navigation  System → User manag. → Change password → Status pw entry

Description Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

New password

Navigation  System → User manag. → Change password → New password

Description Define the new 'Maintenance' password.
A new password is valid after it has been confirmed within the 'Confirm new password' parameter.
Any valid password consists of 4 to 16 characters and can contain letters and numbers.

User entry Character string comprising numbers, letters and special characters (16)

Confirm new password

Navigation  System → User manag. → Change password → Conf. new passw.

Description Enter the new password again to confirm.

User entry Character string comprising numbers, letters and special characters (16)

"Delete password" wizard*Navigation*

System → User manag. → Delete password

Start**Navigation**

System → User manag. → Delete password → Start

User interface

Character string comprising numbers, letters and special characters

Old password**Navigation**

System → User manag. → Delete password → Old password

Description

Enter the current password, to subsequently change the existing password.

User entry

Character string comprising numbers, letters and special characters (16)

Status password entry**Navigation**

System → User manag. → Delete password → Status pw entry

Description

Use this function to display the status of the password verification.

User interface

■ -----

- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Reset password" wizard*Navigation*

System → User manag. → Reset password

Start**Navigation**

System → User manag. → Reset password → Start

User interface

Character string comprising numbers, letters and special characters

Reset password**Navigation**

System → User manag. → Reset password → Reset password

Description

Enter a code to reset the current 'Maintenance' password.
The code is delivered by your local support.

User entry

Character string comprising numbers, letters and special characters (16)

Status password entry**Navigation**

System → User manag. → Reset password → Status pw entry

Description

Use this function to display the status of the password verification.

User interface

- -----
- Wrong password
- Password rule violated
- Password accepted
- Permission denied
- Confirm PW mismatch
- Reset password accepted
- Invalid user role
- Wrong sequence of entry

"Logout" wizard*Navigation*

System → User manag. → Logout

Start**Navigation**

System → User manag. → Logout → Start

User interface

Character string comprising numbers, letters and special characters

User role**Navigation**

System → User manag. → Logout → User role

Description

Shows the access authorization to the parameters via the operating tool

User interface

- Operator
- Maintenance
- Expert
- Production
- Development

3.4.3 "Bluetooth configuration" submenu*Navigation*

System → Bluetooth conf.

Bluetooth activation**Navigation**

System → Bluetooth conf. → Bluetooth active

Description

If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool. Reactivating via the SmartBlue app is not possible.

Selection

- Disable
- Enable

3.4.4 "Display" submenu

Navigation  System → Display

Language

Navigation   System → Display → Language

Description Set display language

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Format display

Navigation   System → Display → Format display

Description Select how measured values are shown on the display

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values

Value 1 display

Navigation   System → Display → Value 1 display

Description Select the measured value that is shown on the local display

* Visibility depends on order options or device settings

Selection

- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Current output
- Terminal voltage

Decimal places 1**Navigation**

System → Display → Decimal places 1

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Value 2 display**Navigation**

System → Display → Value 2 display

Description

Select the measured value that is shown on the local display

Selection

- None
- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Current output
- Terminal voltage

Decimal places 2**Navigation**

System → Display → Decimal places 2

Description

This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Value 3 display

Navigation System → Display → Value 3 display

Description Select the measured value that is shown on the local display

Selection

- None
- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Current output
- Terminal voltage

Decimal places 3

Navigation System → Display → Decimal places 3

Description This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Value 4 display

Navigation System → Display → Value 4 display

Description Select the measured value that is shown on the local display

Selection

- None
- Level limit detection
- Sensor frequency
- Fork state
- Sensor temperature
- Current output
- Terminal voltage

Decimal places 4

Navigation System → Display → Decimal places 4

Description This selection does not affect the measurement and calculation accuracy of the device.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Contrast display

Navigation System → Display → Contrast display**Description**

Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)

User entry

20 to 80 %

3.4.5 "Geolocation" submenu

Navigation System → Geolocation

Process Unit Tag**Navigation** System → Geolocation → Process Unit Tag**Description**

Enter the process unit in which the device is installed.

User entry

Character string comprising numbers, letters and special characters (32)

Location Description**Navigation** System → Geolocation → Location Descr.**Description**

Use this function to enter a description of the location so that the device can be located in the plant.

User entry

Character string comprising numbers, letters and special characters (32)

Longitude**Navigation** System → Geolocation → Longitude**Description**

Use this function to enter the longitude coordinates that describe the device location.

User entry -180 to 180 °

Latitude

Navigation System → Geolocation → Latitude

Description Use this function to enter the latitude coordinates that describe the device location.

User entry -5 156.62015616066 to 5 156.62015616066 °

Altitude

Navigation System → Geolocation → Altitude

Description Use this function to enter the altitude data that describe the device location.

User entry Signed floating-point number

Location method

Navigation System → Geolocation → Location method

Description Use this function to select the data format for specifying the geographic location. The codes for specifying the location are based on the US National Marine Electronics Association (NMEA) Standard NMEA 0183.

Selection

- No fix
- GPS or Standard Positioning Service fix
- Differential GPS fix
- Precise positioning service (PPS) fix
- Real Time Kinetic (RTK) fixed solution
- Real Time Kinetic (RTK) float solution
- Estimated dead reckoning
- Manual input mode
- Simulation Mode

3.4.6 "Information" submenu

Navigation

 System → Information

Device name

Navigation

 System → Information → Device name

Description

Use this function to display the device name. It can also be found on the nameplate.

User interface

Character string comprising numbers, letters and special characters

Manufacturer

Navigation

 System → Information → Manufacturer

User interface

Character string comprising numbers, letters and special characters

Serial number

Navigation

 System → Information → Serial number

Description

The serial number is a unique alphanumerical code identifying the device.
It is printed on the nameplate.

In combination with the Operations app it allows to access all device related documentation.

User interface

Character string comprising numbers, letters and special characters

Order code



Navigation

 System → Information → Order code

Description

Shows the device order code.

User interface

Character string comprising numbers, letters and special characters

Firmware version

Navigation  System → Information → Firmware version

Description Displays the device firmware version installed.

User interface Character string comprising numbers, letters and special characters

Hardware version

Navigation  System → Information → Hardware version

Description Character string comprising numbers, letters and special characters

Extended order code 1 

Navigation  System → Information → Ext. order cd. 1

Description The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface Character string comprising numbers, letters and special characters

Extended order code 2 

Navigation  System → Information → Ext. order cd. 2

Description The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface Character string comprising numbers, letters and special characters

Extended order code 3 

Navigation  System → Information → Ext. order cd. 3

Description The extended order code is an alphanumeric code containing all information to identify the device and its options.

User interface Character string comprising numbers, letters and special characters

3.4.7 "Software configuration" submenu

Navigation

 System → Softw. config.

CRC device configuration

Navigation

  System → Softw. config. → CRC device conf.

Description

CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.

User interface

0 to 65 535

Stored CRC device configuration

Navigation

  System → Softw. config. → Stored CRC conf.

Description

Stored CRC after the last safety lock. Factory delivery is 65535 means that the device has not yet been safety locked.

User interface

0 to 65 535

Timestamp stored CRC device config.

Navigation

  System → Softw. config. → TS stored CRC

Description

Gives the time stamp when the CRC was last stored following completion of the safety lock wizard.

User interface

Character string comprising numbers, letters and special characters

Activate SW option



Navigation

  System → Softw. config. → Activate SW opt.

Description

Enter the application package code or code of another re-ordered functionality to enable it

User entry

Positive integer

Software option overview

Navigation	 System → Softw. config. → SW option overv.
Description	Shows all enabled software options
User interface	<ul style="list-style-type: none">▪ SIL▪ WHG▪ Heartbeat Verification▪ Heartbeat Monitoring

Index

0 ... 9	Configuration counter (Parameter)	71
49 Corrosion warning (Parameter)	45	
49 Diagnostic behavior (Parameter)	46	
49 Event category (Parameter)	47	
806 Alarm delay (Parameter)	42	
806 Diagnostic behavior (Parameter)	47	
806 Event category (Parameter)	47	
825 Electronics temperature (Parameter)	46	
826 Sensor temperature (Parameter)	46	
900 Alarm delay (Parameter)	43	
900 Diagnostic behavior (Parameter)	48	
900 Event category (Parameter)	48	
900 Process alert frequency too low (Parameter)	43	
901 Alarm delay (Parameter)	44	
901 Diagnostic behavior (Parameter)	48	
901 Event category (Parameter)	49	
901 Process alert frequency too high (Parameter)	44	
A		
Activate SW option (Parameter)	86	
Active diagnostics (Parameter)	29	
Active diagnostics (Submenu)	29	
Altitude (Parameter)	83	
Application (Menu)	50	
Assign PV (Parameter)	56, 60	
Assign QV (Parameter)	61	
Assign SV (Parameter)	60	
Assign TV (Parameter)	61	
B		
Baseline status (Parameter)	41	
Bluetooth activation (Parameter)	78	
Bluetooth configuration (Submenu)	78	
Burst command 1 (Parameter)	62	
Burst configuration 1 (Submenu)	62	
Burst mode 1 (Parameter)	62	
Burst trigger level (Parameter)	67	
Burst trigger mode (Parameter)	66	
Burst variable 0 (Parameter)	63	
Burst variable 1 (Parameter)	63	
Burst variable 2 (Parameter)	64	
Burst variable 3 (Parameter)	64	
Burst variable 4 (Parameter)	65	
Burst variable 5 (Parameter)	65	
Burst variable 6 (Parameter)	65	
Burst variable 7 (Parameter)	66	
C		
Change password (Wizard)	74	
Change user role (Wizard)	72	
Character test string (Parameter)	22	
Clamping voltage lower threshold (Parameter)	42	
Clamping voltage upper threshold (Parameter)	42	
Code incorrect (Parameter)	27	
Commissioning (Wizard)	19	
Configuration (Submenu)	58	
D		
Damping (Parameter)	53	
Date 1 (Parameter)	38	
Date 2 (Parameter)	38	
Date 3 (Parameter)	38	
Date 4 (Parameter)	38	
Date 5 (Parameter)	39	
Date 6 (Parameter)	39	
Date 7 (Parameter)	39	
Date 8 (Parameter)	39	
Date 9 (Parameter)	39	
Date 10 (Parameter)	39	
Date 11 (Parameter)	40	
Date 12 (Parameter)	40	
Date 13 (Parameter)	40	
Date 14 (Parameter)	40	
Date 15 (Parameter)	40	
Date 16 (Parameter)	40	
Date/time Heartbeat Verification (Parameter)	34	
Date/time proof test (Parameter)	44	
Decimal places 1 (Parameter)	80	
Decimal places 2 (Parameter)	80	
Decimal places 3 (Parameter)	81	
Decimal places 4 (Parameter)	81	
Define password (Wizard)	73	
Delete password (Wizard)	76	
Density setting (Parameter)	20, 24, 52	
Description of device parameters	17	
Device ID (Parameter)	67	
Device management (Submenu)	70	
Device name (Parameter)	23, 84	
Device revision (Parameter)	68	
Device tag (Parameter)	22, 59, 70	
Device type (Parameter)	68	
Diagnostic event category (Parameter)	33	
Diagnostic event simulation (Parameter)	33	
Diagnostic settings (Submenu)	45	
Diagnostics (Menu)	29	
Display (Submenu)	17, 79	
Document		
Explanation of the structure of a parameter description	3	
Function	3	
Structure	3	
Symbols used	4	
Target group	3	
Using the document	3	

Document function	3
E	
Electronics temperature (Parameter)	51
Enter access code (Parameter)	72
Enter safety locking code (Parameter)	22
Enter safety unlocking code (Parameter)	27
Extended order code 1 (Parameter)	85
Extended order code 2 (Parameter)	85
Extended order code 3 (Parameter)	85
F	
Failure behavior current output (Parameter)	21, 25, 57
Failure current (Parameter)	57
Firmware version (Parameter)	85
Fork state (Parameter)	50
Fork state simulation value (Parameter)	33
Format display (Parameter)	79
Frequency at delivery status (Parameter)	55
Frequency history (Submenu)	35
Frequency max (Parameter)	30
Frequency min (Parameter)	30
Frequency simulation value (Parameter)	33
Function see Parameters	
G	
Geolocation (Submenu)	82
Guidance (Menu)	19
H	
Hardware version (Parameter)	85
HART address (Parameter)	58
HART date code (Parameter)	69
HART descriptor (Parameter)	68
HART message (Parameter)	69
HART output (Submenu)	58, 60
HART revision (Parameter)	68
HART short tag (Parameter)	58, 68
Heartbeat Technology (Submenu)	34
Heartbeat Verification (Submenu)	34
High alert value (Parameter)	44
I	
Information (Submenu)	67, 84
L	
Language (Parameter)	17, 79
Latitude (Parameter)	83
Location Description (Parameter)	82
Location method (Parameter)	83
Locking status (Parameter)	26, 28, 70
Logout (Wizard)	78
Longitude (Parameter)	82
Loop current mode (Parameter)	59
Loop diagnostics (Parameter)	42
Loop diagnostics (Submenu)	41
Low alert value (Parameter)	43
Lower range value output (Parameter)	20, 26, 57
Lower switching point at density (Parameter)	55

M	
Manufacturer (Parameter)	84
Max. update period (Parameter)	67
Maximum electronics temperature (Parameter)	31
Maximum sensor temperature (Parameter)	32
Maximum terminal voltage (Parameter)	31
Measured values (Submenu)	50
Measuring Units (Submenu)	51
Menu Application	50
Diagnostics	29
Guidance	19
System	70
Min. update period (Parameter)	67
Minimum electronics temperature (Parameter)	31
Minimum sensor temperature (Parameter)	31
Minimum terminal voltage (Parameter)	31
Minimum/maximum values (Submenu)	30
Mode of operation (Parameter)	19, 52
N	
New password (Parameter)	73, 75
No. of preambles (Parameter)	59
O	
Old password (Parameter)	74, 76
Operating time (Parameter)	24, 30
Operating time (Verification) (Parameter)	34
Operating time from restart (Parameter)	30
Order code (Parameter)	84
Output current (Parameter)	58
Overall result (Parameter)	35
P	
Parameters Structure of a parameter description	3
Password (Parameter)	72
Previous diagnostics (Parameter)	29
Primary variable (PV) (Parameter)	60
Process (Submenu)	47
Process Unit Tag (Parameter)	82
Process window (Submenu)	43
Proof test (Submenu)	44
Proof test via Bluetooth allowed? (Parameter)	21
Properties (Submenu)	45
Q	
Quaternary variable (QV) (Parameter)	62
R	
Rebuild baseline (Parameter)	41
Reset device (Parameter)	71
Reset password (Parameter)	77
Reset password (Wizard)	77
S	
Safety function (Parameter)	19, 24, 52
Safety lock (Wizard)	21
Safety unlock (Wizard)	27
Secondary variable (SV) (Parameter)	61

Sensor (Submenu)	46, 52
Sensor calibration (Submenu)	55
Sensor configuration (Submenu)	52
Sensor frequency (Parameter)	43, 50
Sensor frequency 1 (Parameter)	35
Sensor frequency 2 (Parameter)	35
Sensor frequency 3 (Parameter)	36
Sensor frequency 4 (Parameter)	36
Sensor frequency 5 (Parameter)	36
Sensor frequency 6 (Parameter)	36
Sensor frequency 7 (Parameter)	36
Sensor frequency 8 (Parameter)	36
Sensor frequency 9 (Parameter)	37
Sensor frequency 10 (Parameter)	37
Sensor frequency 11 (Parameter)	37
Sensor frequency 12 (Parameter)	37
Sensor frequency 13 (Parameter)	37
Sensor frequency 14 (Parameter)	37
Sensor frequency 15 (Parameter)	38
Sensor frequency 16 (Parameter)	38
Sensor temperature (Parameter)	51
Serial number (Parameter)	23, 84
SIL status (Parameter)	22
Simulation (Parameter)	32
Simulation (Submenu)	32
Software configuration (Submenu)	86
Software option overview (Parameter)	87
Start (Parameter)	72, 73, 74, 76, 77, 78
Start verification (Parameter)	34
Status (Parameter)	35
Status password entry (Parameter)	73, 75, 76, 77
Stored covered frequency (Parameter)	54
Stored CRC device configuration (Parameter)	23, 86
Stored frequency (Submenu)	54
Stored uncovered frequency (Parameter)	54
Submenu	
Active diagnostics	29
Bluetooth configuration	78
Burst configuration 1	62
Configuration	58
Current output	56
Device management	70
Diagnostic settings	45
Display	17, 79
Frequency history	35
Geolocation	82
HART output	58, 60
Heartbeat Technology	34
Heartbeat Verification	34
Information	67, 84
Loop diagnostics	41
Measured values	50
Measuring Units	51
Minimum/maximum values	30
Process	47
Process window	43
Proof test	44
Properties	45
Sensor	46, 52

Sensor calibration	55
Sensor configuration	52
Simulation	32
Software configuration	86
Stored frequency	54
User management	17, 71
Switching delay covered to uncovered (Parameter)	25, 54
Switching delay uncovered to covered (Parameter)	24, 25, 53
System (Menu)	70

T

Target group	3
Temperature unit (Parameter)	19, 51
Terminal current (Parameter)	50, 58
Terminal voltage 1 (Parameter)	42, 50
Tertiary variable (TV) (Parameter)	61
Time stamp of last proof test (Parameter)	45
Timestamp (Parameter)	29
Timestamp stored CRC device config. (Parameter)	24, 86
Tolerated deviation +/- (Parameter)	41

U

Upper alarm frequency (Parameter)	56
Upper range value output (Parameter)	20, 26, 57
Upper switching point at density (Parameter)	55
Upper warning frequency (Parameter)	45, 55
User management (Submenu)	17, 71
User role (Parameter)	17, 71, 78

V

Value 1 display (Parameter)	79
Value 2 display (Parameter)	80
Value 3 display (Parameter)	81
Value 4 display (Parameter)	81
Value current output (Parameter)	32

W

Wizard

Change password	74
Change user role	72
Commissioning	19
Define password	73
Delete password	76
Logout	78
Reset password	77
Safety lock	21
Safety unlock	27



71550951

www.addresses.endress.com
