


Operating Instructions Proline Promag W 400 EtherNet/IP

Electromagnetic flowmeter

EtherNet/IP[®]



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document	6		
1.1	Document function	6		
1.2	Symbols	6		
1.2.1	Safety symbols	6		
1.2.2	Electrical symbols	6		
1.2.3	Communication symbols	6		
1.2.4	Tool symbols	7		
1.2.5	Symbols for certain types of information	7		
1.2.6	Symbols in graphics	7		
1.3	Documentation	8		
1.3.1	Standard documentation	8		
1.3.2	Supplementary device-dependent documentation	8		
1.4	Registered trademarks	8		
2	Safety instructions	9		
2.1	Requirements for the personnel	9		
2.2	Designated use	9		
2.3	Workplace safety	10		
2.4	Operational safety	10		
2.5	Product safety	10		
2.6	IT security	11		
2.7	Device-specific IT security	11		
2.7.1	Protecting access via a password	11		
2.7.2	Access via Web server	12		
3	Product description	13		
3.1	Product design	13		
4	Incoming acceptance and product identification	14		
4.1	Incoming acceptance	14		
4.2	Product identification	14		
4.2.1	Transmitter nameplate	15		
4.2.2	Sensor nameplate	15		
4.2.3	Symbols on measuring device	16		
5	Storage and transport	17		
5.1	Storage conditions	17		
5.2	Transporting the product	17		
5.2.1	Measuring devices without lifting lugs	17		
5.2.2	Measuring devices with lifting lugs	18		
5.2.3	Transporting with a fork lift	18		
5.3	Packaging disposal	18		
6	Installation	19		
6.1	Installation conditions	19		
6.1.1	Mounting location	19		
6.1.2	Orientation	21		
6.1.3	Inlet and outlet runs	23		
6.1.4	Dimensions	25		
6.1.5	Environment and process requirements	25		
6.1.6	Special mounting instructions	27		
6.2	Mounting the measuring device	28		
6.2.1	Required tool	28		
6.2.2	Preparing the measuring device	29		
6.2.3	Mounting the sensor	29		
6.2.4	Mounting the transmitter of the remote version	36		
6.2.5	Turning the transmitter housing	37		
6.2.6	Turning the display module	39		
6.3	Post-installation check	40		
7	Electrical connection	41		
7.1	Electrical safety	41		
7.2	Connecting requirements	41		
7.2.1	Required tools	41		
7.2.2	Requirements for connecting cable	41		
7.2.3	Terminal assignment	43		
7.2.4	Pin assignment, device plug	44		
7.2.5	Preparing the measuring device	44		
7.2.6	Preparing the connecting cable for the remote version	44		
7.3	Connecting the measuring device	46		
7.3.1	Connecting the remote version	46		
7.3.2	Connecting the transmitter	49		
7.3.3	Ensuring potential equalization	52		
7.4	Special connection instructions	56		
7.4.1	Connection examples	56		
7.5	Hardware settings	56		
7.5.1	Setting the device address	56		
7.6	Ensuring the degree of protection	57		
7.6.1	Degree of protection IP66/67, Type 4X enclosure	57		
7.6.2	Degree of protection IP68, Type 6P enclosure, with "Cust-potted" option	58		
7.7	Post-connection check	58		
8	Operation methods	59		
8.1	Overview of operation methods	59		
8.2	Structure and function of the operating menu	60		
8.2.1	Structure of the operating menu	60		
8.2.2	Operating philosophy	61		
8.3	Access to the operating menu via the local display	62		
8.3.1	Operational display	62		
8.3.2	Navigation view	64		
8.3.3	Editing view	66		
8.3.4	Operating elements	67		
8.3.5	Opening the context menu	68		
8.3.6	Navigating and selecting from list	70		

8.3.7	Calling the parameter directly	70	10.3	Configuring the device address via software	113
8.3.8	Calling up help text	71	10.3.1	Ethernet network and web server	113
8.3.9	Changing the parameters	72	10.4	Setting the operating language	113
8.3.10	User roles and related access authorization	73	10.5	Configuring the measuring device	114
8.3.11	Disabling write protection via access code	73	10.5.1	Defining the tag name	115
8.3.12	Enabling and disabling the keypad lock	74	10.5.2	Setting the system units	116
8.4	Access to the operating menu via the Web browser	74	10.5.3	Configuring the communication interface	117
8.4.1	Function scope	74	10.5.4	Configuring the local display	118
8.4.2	Prerequisites	74	10.5.5	Configuring the low flow cut off	120
8.4.3	Establishing a connection	76	10.5.6	Configuring empty pipe detection	121
8.4.4	Logging on	78	10.6	Advanced settings	122
8.4.5	User interface	79	10.6.1	Using the parameter to enter the access code	123
8.4.6	Disabling the Web server	80	10.6.2	Carrying out a sensor adjustment	123
8.4.7	Logging out	81	10.6.3	Configuring the totalizer	123
8.5	Access to the operating menu via the operating tool	81	10.6.4	Carrying out additional display configurations	125
8.5.1	Connecting the operating tool	81	10.6.5	Performing electrode cleaning	128
8.5.2	FieldCare	83	10.6.6	WLAN configuration	128
8.5.3	DeviceCare	84	10.6.7	Using parameters for device administration	130
8.5.4	Field Xpert SMT70, SMT77	85	10.7	Simulation	132
9	System integration	86	10.8	Protecting settings from unauthorized access	133
9.1	Overview of device description files	86	10.8.1	Write protection via access code	133
9.1.1	Current version data for the device	86	10.8.2	Write protection via write protection switch	134
9.1.2	Operating tools	86	11	Operation	136
9.2	Overview of system files	86	11.1	Read out and modify current Ethernet settings	136
9.3	Integrating the measuring device in the system	87	11.2	Reading the device locking status	136
9.4	Implicit data transmission	87	11.3	Adjusting the operating language	137
9.4.1	Block model	87	11.4	Configuring the display	137
9.4.2	Pre-defined connections	88	11.5	Reading measured values	137
9.4.3	Permanently assigned input group	89	11.5.1	Process variables	137
9.4.4	Configurable input group	90	11.5.2	"Totalizer" submenu	138
9.4.5	Permanently assigned output group	91	11.6	Adapting the measuring device to the process conditions	139
9.4.6	Permanently assigned configuration	94	11.7	Performing a totalizer reset	139
9.4.7	Permanently assigned volume flow	98	11.7.1	Function scope of the "Control Totalizer" parameter	139
9.4.8	Permanently assigned default values	99	11.7.2	Function scope of the "Reset all totalizers" parameter	140
9.4.9	Dummy Assembly	99	11.8	Showing data logging	140
9.4.10	Units	100	12	Diagnostics and troubleshooting	143
9.5	System integration following device/transmitter replacement	102	12.1	General troubleshooting	143
9.5.1	Integration with Premium Driver AOP (add-on profile)	102	12.2	Diagnostic information via light emitting diodes	145
9.5.2	Integration with Electronic Data Sheet (EDS)	103	12.2.1	Transmitter	145
9.6	Diagnostics via EtherNet/IP	104	12.3	Diagnostic information on local display	146
9.6.1	Diagnostic information (Assem100)	104	12.3.1	Diagnostic message	146
9.6.2	Diagnostic information (Assem120, 121, 126, 127)	108	12.3.2	Calling up remedial measures	148
9.6.3	Information events	111	12.4	Diagnostic information in the Web browser	148
10	Commissioning	113	12.4.1	Diagnostic options	148
10.1	Function check	113	12.4.2	Calling up remedy information	149
10.2	Switching on the measuring device	113			

12.5	Diagnostic information in FieldCare or DeviceCare	149	16.4	Output	179
12.5.1	Diagnostic options	149	16.5	Power supply	181
12.5.2	Calling up remedy information	150	16.6	Performance characteristics	182
12.6	Diagnostic information via communication interface	151	16.7	Installation	184
12.6.1	Reading out diagnostic information	151	16.8	Environment	185
12.7	Adapting the diagnostic information	151	16.9	Process	187
12.7.1	Adapting the diagnostic behavior ...	151	16.10	Mechanical construction	189
12.8	Overview of diagnostic information	152	16.11	Human interface	199
12.8.1	Diagnostic of sensor	152	16.12	Certificates and approvals	202
12.8.2	Diagnostic of electronic	153	16.13	Application packages	203
12.8.3	Diagnostic of configuration	157	16.14	Accessories	204
12.8.4	Diagnostic of process	159	16.15	Supplementary documentation	204
12.9	Pending diagnostic events	161			
12.10	Diagnostic list	162	Index	206	
12.11	Event logbook	163			
12.11.1	Reading out the event logbook	163			
12.11.2	Filtering the event logbook	164			
12.11.3	Overview of information events	164			
12.12	Resetting the measuring device	165			
12.12.1	Function scope of the "Device reset" parameter	165			
12.13	Device information	165			
12.14	Firmware history	167			
13	Maintenance	168			
13.1	Maintenance tasks	168			
13.1.1	Exterior cleaning	168			
13.1.2	Interior cleaning	168			
13.2	Measuring and test equipment	168			
13.3	Endress+Hauser services	168			
14	Repair	169			
14.1	General information	169			
14.1.1	Repair and conversion concept	169			
14.1.2	Notes for repair and conversion	169			
14.2	Spare parts	169			
14.3	Endress+Hauser services	169			
14.4	Return	169			
14.5	Disposal	170			
14.5.1	Removing the measuring device	170			
14.5.2	Disposing of the measuring device ..	170			
15	Accessories	171			
15.1	Device-specific accessories	171			
15.1.1	For the transmitter	171			
15.1.2	For the sensor	171			
15.2	Communication-specific accessories	171			
15.3	Service-specific accessories	172			
15.4	System components	173			
16	Technical data	174			
16.1	Application	174			
16.2	Function and system design	174			
16.3	Input	174			

1 About this document

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.






CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.




NOTICE



This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols




Symbol	Meaning
	Direct current
	Alternating current
	Direct current and alternating current
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective Earth (PE) A terminal which must be connected to ground prior to establishing any other connections. The ground terminals are situated inside and outside the device: <ul style="list-style-type: none"> ▪ Inner ground terminal: Connects the protective earth to the mains supply. ▪ Outer ground terminal: Connects the device to the plant grounding system.

1.2.3 Communication symbols













Symbol	Meaning
	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
	Bluetooth Wireless data transmission between devices over a short distance.
	LED Light emitting diode is off.

Symbol	Meaning
	LED Light emitting diode is on.
	LED Light emitting diode is flashing.






1.2.4 Tool symbols



Symbol	Meaning
	Torx screwdriver
	Phillips head screwdriver
	Open-ended wrench

1.2.5 Symbols for certain types of information


Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
	Series of steps
	Result of a step
	Help in the event of a problem
	Visual inspection

1.2.6 Symbols in graphics

Symbol	Meaning
	Item numbers
	Series of steps
	Views
	Sections
	Hazardous area

Symbol	Meaning
	Safe area (non-hazardous area)
	Flow direction

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code on the nameplate

 Detailed list of the individual documents along with the documentation code
→  204

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Getting the 1st measured value quickly - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device. <ul style="list-style-type: none"> ▪ Incoming acceptance and product identification ▪ Storage and transport ▪ Installation
Transmitter Brief Operating Instructions	Getting the 1st measured value quickly - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value). <ul style="list-style-type: none"> ▪ Product description ▪ Installation ▪ Electrical connection ▪ Operation options ▪ System integration ▪ Commissioning ▪ Diagnostic information
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

EtherNet/IP™

Trademark of ODVA, Inc.

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Are authorized by the plant owner/operator.
- ▶ Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use


Application and media


The measuring device described in this manual is intended only for the flow measurement of liquids with a minimum conductivity of 5 µS/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Keep within the specified pressure and temperature range.
- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ▶ If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation. →  8
- ▶ Protect the measuring device permanently against corrosion from environmental influences.

 The measuring device is optionally tested in accordance with OIML R49: 2006 and has an EC type-examination certificate according to Measuring Instruments Directive 2004/22/EC (MID) for service subject to legal metrological control ("custody transfer") for cold water (Annex MI-001).

The permitted medium temperature in these applications is
0 to +50 °C (+32 to +122 °F).

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

⚠ WARNING**Danger of breakage due to corrosive or abrasive fluids and ambient conditions!**

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

NOTICE**Verification for borderline cases:**

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks**⚠ WARNING**

If the temperature of the media or electronics unit is high or low, this may cause the surfaces of the device to become hot or cold. This poses a risk of burns or frostbite!

- ▶ In the case of hot or cold medium temperatures, install appropriate protection against contact.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ Due to the increased risk of electric shock, wear suitable gloves.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

Furthermore, the device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards.

By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK:

Endress+Hauser Ltd.

Floats Road

Manchester M23 9NF

United Kingdom

www.uk.endress.com

2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security


The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section.

2.7.1 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.


- **User-specific access code**
Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.
- **WLAN passphrase**
The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.

User-specific access code


Write access to the device parameters via the local display or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code (→  133).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).


WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface (→  82), which can be ordered as an optional extra, is protected by


the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter (→  130).

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see the "Write protection via access code" section →  133

2.7.2 Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server (→  74). The connection is via the service interface (CDI-RJ45), signal transmission connection for EtherNet/IP (RJ45 plug) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.



For detailed information on device parameters, see:

The "Description of Device Parameters" document →  205.


3 Product description

The device consists of a transmitter and a sensor.


Two device versions are available:

- Compact version - transmitter and sensor form a mechanical unit.
- Remote version - transmitter and sensor are mounted in separate locations.

3.1 Product design



A0017218

 1 Important components of the compact version

- 1 Display module
- 2 Smart sensor electronics module
- 3 HistoROM DAT (plug-in memory)
- 4 Main electronics module
- 5 Terminals (screw terminals, some available as plug-in terminals) or fieldbus connectors
- 6 Transmitter housing, compact version
- 7 Cable glands
- 8 Sensor, compact version

4 Incoming acceptance and product identification

4.1 Incoming acceptance

					Are the order codes on the delivery note (1) and the product sticker (2) identical?
					Are the goods undamaged?
			+		Do the nameplate data match the ordering information on the delivery note?
			Is the envelope present with accompanying documents?		



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section → 15.

4.2 Product identification


The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial numbers from the nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations App* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations App*: all the information about the device is displayed.


For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" →  8 and "Supplementary device-dependent documentation" →  8
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Transmitter nameplate



A0017346

 2 Example of a transmitter nameplate

- 1 Place of manufacture
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Permitted ambient temperature (T_a)
- 7 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 8 Degree of protection
- 9 Permitted temperature range for cable
- 10 2-D matrix code
- 11 Date of manufacture: year-month
- 12 CE mark, RCM-Tick mark
- 13 Electrical connection data, e.g. available inputs and outputs, supply voltage

4.2.2 Sensor nameplate






Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

4.2.3 Symbols on measuring device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. To determine the nature of the potential hazard and the measures required to avoid it, consult the documentation accompanying the measuring device.
	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- ▶ Store in the original packaging to ensure protection from shock.
- ▶ Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- ▶ Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the liner.
- ▶ Store in a dry and dust-free place.
- ▶ Do not store outdoors.


Storage temperature →  185

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0029252

 Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0029214

5.2.2 Measuring devices with lifting lugs

⚠ CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.


5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

⚠ CAUTION

Risk of damaging the magnetic coil

- ▶ If transporting by forklift, do not lift the sensor by the metal casing.
- ▶ This would buckle the casing and damage the internal magnetic coils.



A0029319

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:


- Outer packaging of device
 - Polymer stretch wrap, complying with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material
 - Paper pads

6 Installation

6.1 Installation conditions


6.1.1 Mounting location

- Do not install the device at the highest point of the pipe.
- Do not install the device upstream from a free pipe outlet in a down pipe.



A0042131


The device should ideally be installed in an ascending pipe.



A0042317

Installation near valves

Install the device in the direction of flow upstream from the valve.



A0041091


Installation upstream from a down pipe

NOTICE

Negative pressure in the measuring pipe can damage the liner!

- If installing upstream from down pipes with a length $h \geq 5 \text{ m}$ (16.4 ft), install a siphon with a vent valve downstream from the device.

i This arrangement prevents the stoppage of liquid flow and the formation of air pockets.




A0028981

- 1 Vent valve
2 Pipe siphon
h Length of down pipe

Installation with partially filled pipes

- Partially filled pipes with a gradient require a drain-type configuration.
- The installation of a cleaning valve is recommended.



A0041088


- i** No inlet and outlet runs for devices with the order code for "Design": Option C, H, I, J or K.

Installation near pumps

NOTICE

Negative pressure in the measuring pipe can damage the liner!

- In order to maintain the system pressure, install the device in the flow direction downstream from the pump.
- Install pulsation dampers if reciprocating, diaphragm or peristaltic pumps are used.



A0041083

- i**
 - Information on the liner's resistance to partial vacuum → 187
 - Information on the measuring system's resistance to vibration and shock → 186

Installation of very heavy devices


Support required for nominal diameters of $DN \geq 350$ mm (14 in).

NOTICE

Damage to the device!

If incorrect support is provided, the sensor housing could buckle and the internal magnetic coils could be damaged.

- Only provide supports at the pipe flanges.



A0041087


Installation in event of pipe vibrations

A remote version is recommended in the event of strong pipe vibrations.



NOTICE

Pipe vibrations can damage the device!

- ▶ Do not expose the device to strong vibrations.
- ▶ Support the pipe and fix it in place.
- ▶ Support the device and fix it in place.
- ▶ Mount the sensor and transmitter separately.







A0041092

 Information on the measuring system's resistance to vibration and shock →  186

6.1.2 Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orientation		Recommendation
Vertical orientation	 A0015591	✓✓
Horizontal orientation, transmitter at top	 A0015589	✓✓ ¹⁾
Horizontal orientation, transmitter at bottom	 A0015590	✓✓ ^{2) 3)} ✗ ⁴⁾
Horizontal orientation, transmitter at side	 A0015592	✗

- 1)
- Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2)
- Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- 3)
- To prevent the electronics module from overheating in the case of a sharp rise in temperature (e.g. CIP or SIP processes), install the device with the transmitter component pointing downwards.
- 4)
- With the empty pipe detection function switched on: empty pipe detection only works if the transmitter housing is pointing upwards.


Vertical

Optimum for self-emptying pipe systems and for use in conjunction with empty pipe detection.



Horizontal

- Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the measuring electrodes by entrained air bubbles.
- Empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.



- 1
- EPD electrode for empty pipe detection
- 2
- Measuring electrodes for signal detection
- 3
- Reference electrode for potential equalization

6.1.3 Inlet and outlet runs


Installation with inlet and outlet runs

Installation requires inlet and outlet runs: devices with the order code for "Design", option D, E, F and G.


Installation with elbows, pumps or valves

To avoid a vacuum and to maintain the specified level of accuracy, install the device upstream from assemblies that produce turbulence (e.g. valves, T-sections) and downstream from pumps, wherever possible.

Maintain straight, unimpeded inlet and outlet runs.



A0028997



A0042132

Installation without inlet and outlet runs

Depending on the device design and installation location, the inlet and outlet runs can be reduced or omitted entirely.



Maximum measured error

When the device is installed with the inlet and outlet runs described, a maximum measured error of $\pm 0.5\%$ of the reading $\pm 1\text{ mm/s}$ (0.04 in/s) can be guaranteed.

Devices and possible order options


Order code for "Design"		
Option	Description	Design
C	Fixed flange, constricted measuring tube, 0 x DN inlet/outlet runs	Constricted measuring tube ¹⁾
H	Lap joint flange, 0 x DN inlet/outlet runs	Full Bore ²⁾
I	Fixed flange, 0 x DN inlet/outlet runs	

Order code for "Design"		
Option	Description	Design
J	Fixed flange, short installed length, 0 x DN inlet/ outlet runs	
K	Fixed flange, long installed length, 0 x DN inlet/ outlet runs	

- 1) "Constricted measuring tube" stands for a reduction of the internal diameter of the measuring tube. The reduced internal diameter causes a higher flow velocity inside the measuring tube.
- 2) "Full Bore" stands for the full diameter of the measuring tube. There is no pressure loss with a full diameter.

Installation before or after bends


Installation without inlet and outlet runs is possible: devices with the order code for "Design", option C, H, I, J and K.



Installation downstream of pumps

Installation without inlet and outlet runs is possible: devices with the order code for "Design", option C, H and I.


i In the case of devices with the order code for "Design", option J and K, an inlet run of only $\geq 2 \times \text{DN}$ must be taken into consideration.



Installation upstream of valves

Installation without inlet and outlet runs is possible: devices with the order code for "Design", option C, H and I.

i In the case of devices with the order code for "Design", option J and K, an outlet run of only $\geq 1 \times \text{DN}$ must be taken into consideration.




Installation downstream of valves

Installation without inlet and outlet runs is possible if the valve is 100% open during operation: devices with the order code for "Design", option C, H and I.



In the case of devices with the order code for "Design", option J and K, an inlet run of only $\geq 2 \times \text{DN}$ must be taken into consideration if the valve is 100% open during operation.



6.1.4 Dimensions



For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section → 204

6.1.5 Environment and process requirements

Ambient temperature range

Transmitter	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to +60 °C (-4 to +140 °F), the legibility of the local display may be impaired at temperatures outside the temperature range.
Sensor	<ul style="list-style-type: none"> ■ Process connection material, carbon steel: -10 to +60 °C (+14 to +140 °F) ■ Process connection material, stainless steel: -40 to +60 °C (-40 to +140 °F) <p>If both the ambient and the medium temperatures are high, mount the sensor separately from the transmitter.</p>
Liner	Do not exceed or fall below the permitted temperature range of the liner → 187.

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.
- If the compact version of the device is insulated at low temperatures, the insulation must also include the device neck.
- Protect the display against impact.
- Protect the display from abrasion, e.g. caused by sand in desert areas.



Display guard available as an accessory → 171.

Temperature tables



Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

System pressure

Installation near pumps → 20

Vibrations

Installation in event of pipe vibrations → 21


Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



The nomogram only applies to liquids with a viscosity similar to that of water.


1. Calculate the ratio of the diameters d/D .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.



A0029002

Length of connecting cable

To obtain correct measurement results, observe the permitted connecting cable length of L_{\max} . This length is determined by the conductivity of the fluid. If measuring liquids in general: 5 $\mu\text{S}/\text{cm}$



A0016539

3 Permitted length of connecting cable

Colored area = permitted range

L_{max} = length of connecting cable in [m] ([ft])

[$\mu\text{S}/\text{cm}$] = fluid conductivity

6.1.6 Special mounting instructions

Display guard

- To ensure that the optional display guard can be easily opened, maintain the following minimum head clearance: 350 mm (13.8 in)

Immersion in water

- i** Only the remote version of the device with IP68 protection, Type 6P is suitable for underwater use: order code for "Sensor option", options CB, CC, CD, CE and CQ.
- Pay attention to regional installation instructions.

NOTICE

If the maximum water depth and operating duration is exceeded, this can damage the device!

- Observe the maximum water depth and operating duration.

Order code for "Sensor option", options CB, CC


- For the operation of the device under water
- Operating duration at a maximum depth of:
 - 3 m (10 ft): permanent use
 - 10 m (30 ft): maximum 48 hours

Order code for "Sensor option", option CQ "Temporarily water-proof"

- For the temporary operation of the device under non-corrosive water
- Operating duration at a maximum depth of:
 - 3 m (10 ft): maximum 168 hours

Order code for "Sensor option", options CD, CE

- For the operation of the device under water and in saline water
- Operating duration at a maximum depth of:
 - 3 m (10 ft): permanent use
 - 10 m (30 ft): maximum 48 hours




A0042412

Use in buried applications

- i** ■ Only the remote version of the device with IP68 protection is suitable for use in buried applications: order code for "Sensor option", options CD and CE.
- Pay attention to regional installation instructions.

Order code for "Sensor option", options CD, CE

For the use of the device in buried applications.



A0042646

6.2 Mounting the measuring device

6.2.1 Required tool

For transmitter

- Torque wrench
- For wall mounting:
Open-ended wrench for hexagonal screw max. M5
- For pipe mounting:
 - Open-ended wrench AF 8
 - Phillips head screwdriver PH 2
- For turning the transmitter housing (compact version):
 - Phillips head screwdriver PH 2
 - Torx screwdriver TX 20
 - Open-ended wrench AF 7

For sensor

For flanges and other process connections: use a suitable mounting tool

6.2.2 Preparing the measuring device


1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the sensor

⚠ WARNING

Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
 - ▶ Ensure that the seals are clean and undamaged.
 - ▶ Secure the seals correctly.
1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
 2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
 3. If using ground disks, comply with the Installation Instructions provided.
 4. Observe required screw tightening torques → 30.
 5. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



A0029263

Mounting the seals

⚠ CAUTION

An electrically conductive layer could form on the inside of the measuring tube!

Risk of measuring signal short circuit.

- ▶ Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

1. Make sure that the seals do not protrude into the piping cross-section.
2. For DIN flanges: only use seals according to DIN EN 1514-1.
3. For a "hard rubber" liner: additional seals are **always** required.
4. For a "polyurethane" liner: additional seals are generally **not** required.

Mounting the ground cable/ground disks

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks .

Screw tightening torques

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.



Nominal screw tightening torques → 35

Maximum screw tightening torques

Maximum screw tightening torques for EN 1092-1 (DIN 2501)

Nominal diameter		Pressure rating [bar]	Screws [mm]	Flange thickness [mm]	Max. screw tightening torque [Nm]		
[mm]	[in]				HG	PUR	PTFE
25	1	PN 40	4 × M12	18	–	15	26
32	–	PN 40	4 × M16	18	–	24	41
40	1 ½	PN 40	4 × M16	18	–	31	52
50	2	PN 40	4 × M16	20	48	40	65
65 ¹⁾	–	PN 16	8 × M16	18	32	27	44
65	–	PN 40	8 × M16	22	32	27	44
80	3	PN 16	8 × M16	20	40	34	53
		PN 40	8 × M16	24	40	34	53
100	4	PN 16	8 × M16	20	43	36	57
		PN 40	8 × M20	24	59	50	79
125	–	PN 16	8 × M16	22	56	48	75
		PN 40	8 × M24	26	83	71	112
150	6	PN 16	8 × M20	22	74	63	99
		PN 40	8 × M24	28	104	88	137
200	8	PN 10	8 × M20	24	106	91	141
		PN 16	12 × M20	24	70	61	94
		PN 25	12 × M24	30	104	92	139
250	10	PN 10	12 × M20	26	82	71	110
		PN 16	12 × M24	26	98	85	132
		PN 25	12 × M27	32	150	134	201
300	12	PN 10	12 × M20	26	94	81	126
		PN 16	12 × M24	28	134	118	179
		PN 25	16 × M27	34	153	138	204
350	14	PN 6	12 × M20	22	111	120	–
		PN 10	16 × M20	26	112	118	–
		PN 16	16 × M24	30	152	165	–
		PN 25	16 × M30	38	227	252	–
400	16	PN 6	16 × M20	22	90	98	–
		PN 10	16 × M24	26	151	167	–
		PN 16	16 × M27	32	193	215	–
		PN 25	16 × M33	40	289	326	–
450	18	PN 6	16 × M20	22	112	126	–

Nominal diameter		Pressure rating	Screws	Flange thickness	Max. screw tightening torque [Nm]		
[mm]	[in]	[bar]	[mm]	[mm]	HG	PUR	PTFE
		PN 10	20 × M24	28	153	133	–
		PN 16	20 × M27	40	198	196	–
		PN 25	20 × M33	46	256	253	–
500	20	PN 6	20 × M20	24	119	123	–
		PN 10	20 × M24	28	155	171	–
		PN 16	20 × M30	34	275	300	–
		PN 25	20 × M33	48	317	360	–
600	24	PN 6	20 × M24	30	139	147	–
		PN 10	20 × M27	28	206	219	–
600	24	PN 16	20 × M33	36	415	443	–
600	24	PN 25	20 × M36	58	431	516	–
700	28	PN 6	24 × M24	24	148	139	–
		PN 10	24 × M27	30	246	246	–
		PN 16	24 × M33	36	278	318	–
		PN 25	24 × M39	46	449	507	–
800	32	PN 6	24 × M27	24	206	182	–
		PN 10	24 × M30	32	331	316	–
		PN 16	24 × M36	38	369	385	–
		PN 25	24 × M45	50	664	721	–
900	36	PN 6	24 × M27	26	230	637	–
		PN 10	28 × M30	34	316	307	–
		PN 16	28 × M36	40	353	398	–
		PN 25	28 × M45	54	690	716	–
1000	40	PN 6	28 × M27	26	218	208	–
		PN 10	28 × M33	34	402	405	–
		PN 16	28 × M39	42	502	518	–
		PN 25	28 × M52	58	970	971	–
1200	48	PN 6	32 × M30	28	319	299	–
		PN 10	32 × M36	38	564	568	–
		PN 16	32 × M45	48	701	753	–
1400	–	PN 6	36 × M33	32	430	–	–
		PN 10	36 × M39	42	654	–	–
		PN 16	36 × M45	52	729	–	–
1600	–	PN 6	40 × M33	34	440	–	–
		PN 10	40 × M45	46	946	–	–
		PN 16	40 × M52	58	1007	–	–
1800	72	PN 6	44 × M36	36	547	–	–
		PN 10	44 × M45	50	961	–	–
		PN 16	44 × M52	62	1108	–	–
2000	–	PN 6	48 × M39	38	629	–	–
		PN 10	48 × M45	54	1047	–	–

Nominal diameter		Pressure rating	Screws	Flange thickness	Max. screw tightening torque [Nm]		
[mm]	[in]	[bar]	[mm]	[mm]	HG	PUR	PTFE
		PN 16	48 × M56	66	1324	–	–
2200	–	PN 6	52 × M39	42	698	–	–
		PN 10	52 × M52	58	1217	–	–
2400	–	PN 6	56 × M39	44	768	–	–
		PN 10	56 × M52	62	1229	–	–

1) Sizing as per EN 1092-1 (not DIN 2501)

Maximum screw tightening torques for ASME B16.5

Nominal diameter		Pressure rating	Screws	Max. screw tightening torque			
[mm]	[in]	[psi]	[in]	HG		PUR	
				[Nm]	[lbf · ft]	[Nm]	[lbf · ft]
25	1	Class 150	4 × ½	–	–	7	5
25	1	Class 300	4 × 5/8	–	–	8	6
40	1 ½	Class 150	4 × ½	–	–	10	7
40	1 ½	Class 300	4 × ¾	–	–	15	11
50	2	Class 150	4 × 5/8	35	26	22	16
50	2	Class 300	8 × 5/8	18	13	11	8
80	3	Class 150	4 × 5/8	60	44	43	32
80	3	Class 300	8 × ¾	38	28	26	19
100	4	Class 150	8 × 5/8	42	31	31	23
100	4	Class 300	8 × ¾	58	43	40	30
150	6	Class 150	8 × ¾	79	58	59	44
150	6	Class 300	12 × ¾	70	52	51	38
200	8	Class 150	8 × ¾	107	79	80	59
250	10	Class 150	12 × 7/8	101	74	75	55
300	12	Class 150	12 × 7/8	133	98	103	76
350	14	Class 150	12 × 1	135	100	158	117
400	16	Class 150	16 × 1	128	94	150	111
450	18	Class 150	16 × 1 1/8	204	150	234	173
500	20	Class 150	20 × 1 1/8	183	135	217	160
600	24	Class 150	20 × 1 ¼	268	198	307	226

Maximum screw tightening torques for JIS B2220

Nominal diameter	Pressure rating	Screws	Max. screw tightening torque [Nm]	
[mm]	[bar]	[mm]	HG	PUR
25	10K	4 × M16	–	19
25	20K	4 × M16	–	19
32	10K	4 × M16	–	22
32	20K	4 × M16	–	22
40	10K	4 × M16	–	24

Nominal diameter [mm]	Pressure rating [bar]	Screws [mm]	Max. screw tightening torque [Nm]	
			HG	PUR
40	20K	4 × M16	–	24
50	10K	4 × M16	40	33
50	20K	8 × M16	20	17
65	10K	4 × M16	55	45
65	20K	8 × M16	28	23
80	10K	8 × M16	29	23
80	20K	8 × M20	42	35
100	10K	8 × M16	35	29
100	20K	8 × M20	56	48
125	10K	8 × M20	60	51
125	20K	8 × M22	91	79
150	10K	8 × M20	75	63
150	20K	12 × M22	81	72
200	10K	12 × M20	61	52
200	20K	12 × M22	91	80
250	10K	12 × M22	100	87
250	20K	12 × M24	159	144
300	10K	16 × M22	74	63
300	20K	16 × M24	138	124

Maximum screw tightening torques for AWWA C207, Class D

Nominal diameter		Screws [in]	Max. screw tightening torque			
			HG		PUR	
[mm]	[in]		[Nm]	[lbf · ft]	[Nm]	[lbf · ft]
700	28	28 × 1 ¼	247	182	292	215
750	30	28 × 1 ¼	287	212	302	223
800	32	28 × 1 ½	394	291	422	311
900	36	32 × 1 ½	419	309	430	317
1000	40	36 × 1 ½	420	310	477	352
–	42	36 × 1 ½	528	389	518	382
–	48	44 × 1 ½	552	407	531	392
–	54	44 × 1 ¾	730	538	–	–
–	60	52 × 1 ¾	758	559	–	–
–	66	52 × 1 ¾	946	698	–	–
–	72	60 × 1 ¾	975	719	–	–
–	78	64 × 2	853	629	–	–
–	84	64 × 2	931	687	–	–
–	90	64 × 2 ¼	1048	773	–	–

Maximum screw tightening torques for AS 2129, Table E

Nominal diameter [mm]	Screws [mm]	Max. screw tightening torque [Nm]	
		HG	PUR
50	4 × M16	32	–
80	4 × M16	49	–
100	8 × M16	38	–
150	8 × M20	64	–
200	8 × M20	96	–
250	12 × M20	98	–
300	12 × M24	123	–
350	12 × M24	203	–
400	12 × M24	226	–
450	16 × M24	226	–
500	16 × M24	271	–
600	16 × M30	439	–
700	20 × M30	355	–
750	20 × M30	559	–
800	20 × M30	631	–
900	24 × M30	627	–
1000	24 × M30	634	–
1200	32 × M30	727	–

Maximum screw tightening torques for AS 4087, PN 16

Nominal diameter [mm]	Screws [mm]	Max. screw tightening torque [Nm]	
		HG	PUR
50	4 × M16	32	–
80	4 × M16	49	–
100	4 × M16	76	–
150	8 × M20	52	–
200	8 × M20	77	–
250	8 × M20	147	–
300	12 × M24	103	–
350	12 × M24	203	–
375	12 × M24	137	–
400	12 × M24	226	–
450	12 × M24	301	–
500	16 × M24	271	–
600	16 × M27	393	–
700	20 × M27	330	–
750	20 × M30	529	–
800	20 × M33	631	–
900	24 × M33	627	–

Nominal diameter [mm]	Screws [mm]	Max. screw tightening torque [Nm]	
		HG	PUR
1000	24 × M33	595	–
1200	32 × M33	703	–

Nominal screw tightening torques

Nominal screw tightening torques for EN 1092-1 (DIN 2501); calculated according to EN 1591-1:2014 for flanges according to EN 1092-1:2013

Nominal diameter [mm] [in]		Pressure rating [bar]	Screws [mm]	Flange thickness [mm]	Nom. screw tightening torque [Nm]		
					HG	PUR	PTFE
1000	40	PN 6	28 × M27	38	175	185	–
		PN 10	28 × M33	44	350	360	–
		PN 16	28 × M39	59	630	620	–
		PN 25	28 × M52	63	1300	1290	–
1200	48	PN 6	32 × M30	42	235	250	–
		PN 10	32 × M36	55	470	480	–
		PN 16	32 × M45	78	890	900	–
1400	–	PN 6	36 × M33	56	300	–	–
		PN 10	36 × M39	65	600	–	–
		PN 16	36 × M45	84	1050	–	–
1600	–	PN 6	40 × M33	63	340	–	–
		PN 10	40 × M45	75	810	–	–
		PN 16	40 × M52	102	1420	–	–
1800	72	PN 6	44 × M36	69	430	–	–
		PN 10	44 × M45	85	920	–	–
		PN 16	44 × M52	110	1600	–	–
2000	–	PN 6	48 × M39	74	530	–	–
		PN 10	48 × M45	90	1040	–	–
		PN 16	48 × M56	124	1900	–	–
2200	–	PN 6	52 × M39	81	580	–	–
		PN 10	52 × M52	100	1290	–	–
2400	–	PN 6	56 × M39	87	650	–	–
		PN 10	56 × M52	110	1410	–	–

Nominal screw tightening torques for JIS B2220

Nominal diameter [mm]	Pressure rating [bar]	Screws [mm]	Nom. screw tightening torque [Nm]	
			HG	PUR
350	10K	16 × M22	109	109
	20K	16 × M30×3	217	217
400	10K	16 × M24	163	163
	20K	16 × M30×3	258	258
450	10K	16 × M24	155	155

Nominal diameter [mm]	Pressure rating [bar]	Screws [mm]	Nom. screw tightening torque [Nm]	
			HG	PUR
	20K	16 × M30×3	272	272
500	10K	16 × M24	183	183
	20K	16 × M30×3	315	315
600	10K	16 × M30	235	235
	20K	16 × M36×3	381	381
700	10K	16 × M30	300	300
750	10K	16 × M30	339	339

6.2.4 Mounting the transmitter of the remote version

⚠ CAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature .
- ▶ If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

⚠ CAUTION


Excessive force can damage the housing!

- ▶ Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

Wall mounting



4 Engineering unit mm (in)

A0020523

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw the securing screws in slightly.

4. Fit the transmitter housing over the securing screws and mount in place.
5. Tighten the securing screws.


Post mounting

⚠ WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)




A0029051

5 Engineering unit mm (in)


6.2.5 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




A0032086


1. Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque → 39).
2. Open the housing cover.
3. Unlock the display module.
4. Remove the display module.



5. Loosen the fixing screws of the smart sensor electronics module (when reassembling, pay attention to the tightening torque → 39).
6. Remove the smart sensor electronics module (when reassembling, pay attention to the coding of the plug → 39).



7. Loosen the fixing screws of the main electronics module (when reassembling, pay attention to the tightening torque → 39).
8. Remove the main electronics module.



9. Loosen the fixing screws of the transmitter housing (when reassembling, pay attention to the tightening torque → 39).
10. Lift the transmitter housing.
11. Turn the housing to the desired position in increments of 90°.

Reassembling the transmitter housing

⚠ WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)


Step → 37	Fixing screw	Tightening torques for housing made of:	
		Aluminum	Plastic
1	Housing cover	2.5 Nm (1.8 lbf ft)	1 Nm (0.7 lbf ft)
5	Smart sensor electronics module	0.6 Nm (0.4 lbf ft)	
7	Main electronics module	1.5 Nm (1.1 lbf ft)	
9/10	Transmitter housing	5.5 Nm (4.1 lbf ft)	

NOTICE

Plug of the smart sensor electronics module connected incorrectly!

No measuring signal is output.

- Plug in the plug of the smart sensor electronics module as per the coding.




A0021585

- Reverse the procedure to reassemble the measuring device.

6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.



A0032091

1. Loosen the fixing screws of the housing cover.
2. Open the housing cover.
3. Unlock the display module.
4. Pull out the display module and turn it to the desired position in increments of 90°.

Mounting the transmitter housing

WARNING







Excessive tightening torque applied to the fixing screws!

Damage to the transmitter.

- Tighten the fixing screws with the specified torques.

1. Insert the display module and lock it when doing so.
2. Close the housing cover.
3. Tighten the fixing screws of the housing cover: tightening torque for aluminum housing 2.5 Nm (1.8 lbf ft) – plastic housing 1 Nm (0.7 lbf ft).

6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ■ Process temperature →  187 ■ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) →  204 ■ Ambient temperature →  25 ■ Measuring range →  174 	<input type="checkbox"/>
Has the correct orientation been selected for the sensor →  21 ? <ul style="list-style-type: none"> ■ According to sensor type ■ According to medium temperature ■ According to medium properties (outgassing, with entrained solids) 	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the actual direction of flow of the fluid through the piping →  21?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Have the fixing screws been tightened with the correct tightening torque?	<input type="checkbox"/>

7 Electrical connection

NOTICE

The measuring device does not have an internal circuit breaker.

- For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 16 A) should be integrated into the system installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- Torque wrench
- For cable entries: Use corresponding tools
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule

7.2.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

EtherNet/IP

The standard ANSI/TIA/EIA-568-B.2 Annex specifies CAT 5 as the minimum category for a cable used for EtherNet/IP. CAT 5e and CAT 6 are recommended.



For more information on planning and installing EtherNet/IP networks, please refer to the "Media Planning and Installation Manual. EtherNet/IP" of ODVA Organization


Connecting cable for remote version

Electrode cable

Standard cable	3 × 0.38 mm ² (20 AWG) with common, braided copper shield (ϕ ~9.5 mm (0.37 in)) and individual shielded cores
Cable for empty pipe detection (EPD)	4 × 0.38 mm ² (20 AWG) with common, braided copper shield (ϕ ~9.5 mm (0.37 in)) and individual shielded cores
Conductor resistance	≤ 50 Ω/km (0.015 Ω/ft)
Capacitance: core/shield	≤ 420 pF/m (128 pF/ft)
Operating temperature	–20 to +80 °C (–4 to +176 °F)

Coil current cable

Standard cable	3 ×0.75 mm ² (18 AWG) with common, braided copper shield (ϕ ~9 mm (0.35 in))
Conductor resistance	≤37 Ω/km (0.011 Ω/ft)
Capacitance: core/core, shield grounded	≤120 pF/m (37 pF/ft)
Operating temperature	−20 to +80 °C (−4 to +176 °F)
Test voltage for cable insulation	≤ AC 1433 V rms 50/60 Hz or ≥ DC 2026 V



A0029151

6 Cable cross-section

- a Electrode cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Armored connecting cable

Armored connecting cables with an additional, reinforcing metal braid should be used:

- When laying the cable directly in the ground
- Where there is a risk of damage from rodents
- Use as per IP68 degree of protection

Operation in environments with strong electrical interference

The measuring system meets the general safety requirements → 203 and EMC specifications → 187.

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.

Cable diameter

- Cable glands supplied:
 - For standard cable: M20 × 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
 - For reinforced cable: M20 × 1.5 with cable ϕ 9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

7.2.3 Terminal assignment

Transmitter

The transmitter can be ordered with terminals or a device plug.

Connection methods available		Possible options for order code "Electrical connection"
Outputs	Power supply	
EtherNet/IP (RJ45 plug)	Terminals	Option D: thread NPT ½"
Device plug → 44	Terminals	<ul style="list-style-type: none"> Option L: plug M12x1 + thread NPT ½" Option N: plug M12x1 + coupling M20 Option P: plug M12x1 + thread G ½" Option U: plug M12x1 + thread M20


Supply voltage

Order code "Power supply"	Terminal numbers	terminal voltage		Frequency range
Option L (wide range power unit)	1 (L+/L), 2 (L-/N)	DC 24 V	±25%	–
		AC 24 V	±25%	50/60 Hz, ±4 Hz
		AC 100 to 240 V	–15 to +10%	50/60 Hz, ±4 Hz

EtherNet/IP signal transmission

Order code for "Output"	Connection via
Option N	EtherNet/IP: RJ45 or M12 plug

Remote version



7 Remote version terminal assignment

- A Transmitter wall-mount housing
 B Sensor connection housing
 1 Electrode cable
 2 Coil current cable
 n.c. Not connected, insulated cable shields


Terminal No. and cable colors: 6/5 = brown; 7/8 = white; 4 = green; 36/37 = yellow

7.2.4 Pin assignment, device plug

i Order codes for the M12x1 plugs, see the "Order code for electrical connection" column: EtherNet/IP → 43

EtherNet/IP

Device plug for signal transmission (device side)

	Pin	Assignment		Coding	Plug/socket
	1	+	Tx	D	Socket
	2	+	Rx		
	3	-	Tx		
	4	-	Rx		

7.2.5 Preparing the measuring device

Carry out the steps in the following order:

1. Mount the sensor and transmitter.
2. Connection housing, sensor: Connect connecting cable.
3. Transmitter: Connect connecting cable.
4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

► Use suitable cable glands corresponding to the degree of protection.



1. Remove dummy plug if present.
2. If the measuring device is supplied without cable glands:
Provide suitable cable gland for corresponding connecting cable.
3. If the measuring device is supplied with cable glands:
Observe requirements for connecting cables → 41.

7.2.6 Preparing the connecting cable for the remote version



When terminating the connecting cable, pay attention to the following points:

1. In the case of the electrode cable:
Make sure that the ferrules do not touch the core shields on the sensor side.
Minimum distance = 1 mm (exception: green "GND" cable)
2. In the case of the coil current cable:
Insulate one core of the three-core cable at the level of the core reinforcement. You only require two cores for the connection.
3. For cables with fine-wire cores (stranded cables):
Fit the cores with ferrules.

Transmitter

Electrode cable	Coil current cable
<div><p>Diagram showing the electrode cable connection. The top part shows the cable entering the transmitter with dimensions: 100 (3.94)*, 80 (3.15), 50 (1.97), 17 (0.67), and 8 (0.31). The bottom part shows the termination of the fine-wire cores with ferrules, labeled 1 (Red ferrules, ϕ 1.0 mm (0.04 in)) and 2 (White ferrules, ϕ 0.5 mm (0.02 in)). The termination points are labeled A (Termination of the cables) and B (Termination of the fine-wire cores with ferrules). The diagram also shows a GND connection.</p><p>8 Engineering unit mm (in)</p><p>A0032093</p></div>	<div><p>Diagram showing the coil current cable connection. The top part shows the cable entering the transmitter with dimensions: 90 (3.54)*, 70 (2.76), 50 (1.97), 8 (0.31), and 10 (0.39). The bottom part shows the termination of the fine-wire cores with ferrules, labeled 1 (Red ferrules, ϕ 1.0 mm (0.04 in)) and 2 (White ferrules, ϕ 0.5 mm (0.02 in)). The termination points are labeled A (Termination of the cables) and B (Termination of the fine-wire cores with ferrules). The diagram also shows a GND connection.</p><p>9 Engineering unit mm (in)</p><p>A0032096</p></div>
<p>A = Termination of the cables B = Termination of the fine-wire cores with ferrules 1 = Red ferrules, ϕ 1.0 mm (0.04 in) 2 = White ferrules, ϕ 0.5 mm (0.02 in) * = Stripping only for reinforced cables</p>	

Sensor

Electrode cable	Coil current cable
 <p>A</p> <p>B</p> <p>1</p> <p>2</p> <p>2</p> <p>2</p> <p>1</p> <p>GND</p> <p>$\geq 1 (0.04)$</p> <p>A0032100</p>	 <p>A</p> <p>B</p> <p>1</p> <p>1</p> <p>1</p> <p>A0032101</p>
<p>A = Termination of the cables B = Termination of the fine-wire cores with ferrules 1 = Red ferrules, ϕ 1.0 mm (0.04 in) 2 = White ferrules, ϕ 0.5 mm (0.02 in) * = Stripping only for reinforced cables</p>	

7.3 Connecting the measuring device

⚠ WARNING

Risk of electric shock! Components carry dangerous voltages!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Observe grounding concept of the plant.
- ▶ Never mount or wire the measuring device while it is connected to the supply voltage.
- ▶ Before the supply voltage is applied, connect the protective ground to the measuring device.

7.3.1 Connecting the remote version

⚠ WARNING

Risk of damaging the electronic components!


- ▶ Connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.
- ▶ Ground the connection housing of the sensor via the external screw terminal.

The following procedure (in the action sequence given) is recommended for the remote version:


1. Mount the sensor and transmitter.
2. Connect the connecting cable for the remote version.

3. Connect the transmitter.

Connecting the connecting cable to the sensor connection housing



A0032103



 10 Sensor: connection module

1. Loosen the securing clamp of the housing cover.
2. Unscrew and lift off the housing cover.
3. **NOTICE**

For conduit extensions:

- Fit O-ring on cable and push it back sufficiently. When inserting the cable, the O-ring must be located outside the conduit extension.

Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.


4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules
→  44.
5. Connect the cable in accordance with the terminal assignment →  43.
6. Firmly tighten the cable glands.
7. **WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

- Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the procedure to reassemble the sensor.

Connecting the connecting cable to the transmitter



A0032102

11 Transmitter: main electronics module with terminals

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules
→ 44.
5. Connect the cable in accordance with the terminal assignment → 43.
6. Firmly tighten the cable glands.
7. **⚠ WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

- Screw in the screw without using any lubricant.

Reverse the removal procedure to reassemble the transmitter.

7.3.2 Connecting the transmitter


⚠ WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

- Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Tightening torques for plastic housing


Housing cover fixing screw	1 Nm (0.7 lbf ft)
Cable entry	5 Nm (3.7 lbf ft)
Ground terminal	2.5 Nm (1.8 lbf ft)



12 Connecting the supply voltage and EtherNet/IP

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cables according to the terminal assignment → 43 . For supply voltage: open the shock protection cover.
6. Firmly tighten the cable glands.


Connecting the supply voltage



A0038184

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Open the shock protection cover.
4. Release the cable gland.
5. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
6. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
7. Connect the protective ground.
8. Connect the cable in accordance with the terminal assignment → 43.
9. Firmly tighten the cable gland.

Mounting the RJ45 connector



A0038185

1. Release the cable gland.
2. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
3. Strip the cable and cable ends and connect to the RJ45 connector.
4. Plug in the RJ45 connector.
5. Firmly tighten the cable gland.

Reassembling the transmitter

1. Close the shock protection cover.
2. Close the housing cover.
3. **⚠ WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

- Screw in the screw without using any lubricant.

Tighten the 4 fixing screws on the housing cover.



7.3.3 Ensuring potential equalization


Introduction

Correct potential equalization (equipotential bonding) is a prerequisite for stable and reliable flow measurement. Inadequate or incorrect potential equalization can result in device failure and present a safety hazard.

The following requirements must be observed to ensure correct, trouble-free measurement:

- The principle that the medium, the sensor and the transmitter must be at the same electrical potential applies.
- Take in-company grounding guidelines, materials and the grounding conditions and potential conditions of the pipe into consideration.
- Any necessary potential equalization connections must be established by ground cables with a minimum cross-section of 6 mm² (0.0093 in²).
- For remote device versions, the ground terminal in the example always refers to the sensor and not to the transmitter.

 You can order accessories like ground cables and ground disks from Endress+Hauser
→  171

 For devices intended for use in hazardous locations, observe the instructions in the Ex documentation (XA).

Abbreviations used

- PE (Protective Earth): potential at the protective earth terminals of the device
- P_P (Potential Pipe): potential of the pipe, measured at the flanges
- P_M (Potential Medium): potential of the medium


Connection examples for standard situations

Unlined and grounded metal pipe

- Potential equalization is via the measuring pipe.
- The medium is set to ground potential.

Starting conditions:

- Pipes are correctly grounded on both sides.
- Pipes are conductive and at the same electrical potential as the medium



A0044854


- Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.

Unlined metal pipe

- Potential equalization is via the ground terminal and pipe flanges.
- The medium is set to ground potential.

Starting conditions:

- Pipes are not sufficiently grounded.
- Pipes are conductive and at the same electrical potential as the medium



A0042089


1. Connect both sensor flanges to the pipe flange via a ground cable and ground them.
 2. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.
- i**
- For $DN \leq 300$ (12"): Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws.
 - For $DN \geq 350$ (14"): Mount the ground cable directly on the metal transport bracket. Observe screw tightening torques: see the Brief Operating Instructions for the sensor.

Plastic pipe or pipe with insulating liner

- Potential equalization is via the ground terminal and ground disks.
- The medium is set to ground potential.

Starting conditions:

- The pipe has an insulating effect.
- Low-impedance medium grounding close to the sensor is not guaranteed.
- Equalizing currents through the medium cannot be ruled out.



A0044856

1. Connect the ground disks to the ground terminal of the connection housing of the transmitter or sensor via the ground cable.
2. Connect the connection to ground potential.

Connection example with the potential of the medium not equal to the protective ground


In these cases, the medium potential can differ from the potential of the device.

Metal, ungrounded pipe

The sensor and transmitter are installed in a way that provides electrical insulation from PE, e.g. applications for electrolytic processes or systems with cathodic protection.

Starting conditions:

- Unlined metal pipe
- Pipes with an electrically conductive liner



1. Connect the pipe flanges and transmitter via the ground cable.
2. Route the shielding of the signal lines via a capacitor (recommended value 1.5µF/ 50V).
3. Device connected to power supply such that it is floating in relation to the protective earth (isolation transformer). This measure is not required in the case of 24V DC supply voltage without PE (= SELV power unit).

Connection examples with the potential of medium not equal to protective earth with the "Measurement isolated from ground" option

In these cases, the medium potential can differ from the potential of the device.

Introduction

The "Measurement isolated from ground" option enables the galvanic isolation of the measuring system from the device potential. This minimizes harmful equalizing currents caused by differences in potential between the medium and the device. The "Measurement isolated from ground" option is optionally available: order code for "Sensor option", option CV

Operating conditions for the use of the "Measurement isolated from ground" option

Device version	Compact version and remote version (length of connecting cable ≤ 10 m)
Differences in voltage between medium potential and device potential	As small as possible, usually in the mV range
Alternating voltage frequencies in the medium or at ground potential (PE)	Below typical power line frequency in the country

i To achieve the specified conductivity measuring accuracy, a conductivity calibration is recommended when the device is installed.


A full pipe adjustment is recommended when the device is installed.

Plastic pipe

Sensor and transmitter are correctly grounded. A difference in potential can occur between the medium and protective earth. Potential equalization between P_M and PE via the reference electrode is minimized with the "Measurement isolated from ground" option.

Starting conditions:

- The pipe has an insulating effect.
- Equalizing currents through the medium cannot be ruled out.




1. Use the "Measurement isolated from ground" option, while observing the operating conditions for measurement isolated from ground.
2. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.

Metal, ungrounded pipe with insulating liner

The sensor and transmitter are installed in a way that provides electrical insulation from PE. The medium and pipe have different potentials. The "Measurement isolated from ground" option minimizes harmful equalizing currents between P_M and P_p via the reference electrode.

Starting conditions:

- Metal pipe with insulating liner
- Equalizing currents through the medium cannot be ruled out.




1. Connect the pipe flanges and transmitter via the ground cable.
2. Route the shielding of the signal cables via a capacitor (recommended value $1.5\mu F/50V$).
3. Device connected to power supply such that it is floating in relation to the protective earth (isolation transformer). This measure is not required in the case of 24V DC supply voltage without PE (= SELV power unit).
4. Use the "Measurement isolated from ground" option, while observing the operating conditions for measurement isolated from ground.

7.4 Special connection instructions

7.4.1 Connection examples

EtherNet/IP



13 Connection example for EtherNet/IP

- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications
- 4 Device plug
- 5 Transmitter

7.5 Hardware settings

7.5.1 Setting the device address

EtherNet/IP

The IP address of the measuring device can be configured for the network via DIP switches.


Addressing data

IP address and configuration options			
1st octet	2nd octet	3rd octet	4th octet
192.	168.	1.	XXX
↓		↓	
Can only be configured via software addressing		Can be configured via software addressing and hardware addressing	

IP address range	1 to 254 (4th octet)
IP address broadcast	255
Addressing mode ex works	Software addressing; all DIP switches for hardware addressing are set to OFF.
IP address ex works	DHCP server active

i For device addressing via software

Setting the address



A0021322

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Set the desired IP address using the corresponding DIP switches on the I/O electronics module.
 - ↳ Hardware addressing with the configured IP address is enabled after 10 s.
4. Reverse the removal procedure to reassemble the transmitter.


7.6 Ensuring the degree of protection

7.6.1 Degree of protection IP66/67, Type 4X enclosure

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0029278

5. Insert dummy plugs (corresponding to the housing degree of protection) into unused cable entries.


NOTICE

Standard dummy plugs used for transportation do not have the appropriate degree of protection and can result in damage to the device!

- ▶ Use suitable dummy plugs corresponding to the degree of protection.

7.6.2 Degree of protection IP68, Type 6P enclosure, with "Cust-potted" option





Depending on the version, the sensor meets all the requirements of IP68 degree of protection, Type 6P enclosure →  185 and can be used as a remote version →  27.

The degree of protection of the transmitter is always only IP66/67, Type 4X enclosure and the transmitter must therefore be treated accordingly →  57.

To guarantee IP68 degree of protection, Type 6P enclosure for the "Cust-potted" options, carry out the following steps after the electrical connection:


1. Firmly tighten the cable glands (torque: 2 to 3.5 Nm) until there is no gap between the bottom of the cover and the housing support surface.
2. Firmly tighten the union nut of the cable glands.
3. Pot the field housing with a potting compound.
4. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
5. Tighten all housing screws and screw covers (torque: 20 to 30 Nm).

7.7 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Do the cables used meet the requirements →  41?	<input type="checkbox"/>
Do the cables have adequate strain relief?	<input type="checkbox"/>
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" →  57?	<input type="checkbox"/>
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate →  181?	<input type="checkbox"/>
Is the terminal assignment correct →  43?	<input type="checkbox"/>
If supply voltage is present, do values appear on the display module?	<input type="checkbox"/>
Is the potential equalization established correctly ?	<input type="checkbox"/>
Are all housing covers installed and the screws tightened with the correct tightening torque?	<input type="checkbox"/>

8 Operation methods

8.1 Overview of operation methods





- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Control system (e.g. PLC)





For custody transfer, once the device has been put into circulation or sealed, its operation is restricted.

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu for experts, see the "Description of Device Parameters" document supplied with the device →  205



 14 Schematic structure of the operating menu

A0018237-EN

8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.




For custody transfer, once the device has been put into circulation or sealed, its operation is restricted.

Menu/parameter		User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: <ul style="list-style-type: none"> ■ Configuration of the operational display ■ Reading measured values 	<ul style="list-style-type: none"> ■ Defining the operating language ■ Defining the Web server operating language ■ Resetting and controlling totalizers
Operation			<ul style="list-style-type: none"> ■ Configuring the operational display (e.g. display format, display contrast) ■ Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: Configuration of the measurement	Wizards for fast commissioning: <ul style="list-style-type: none"> ■ Setting the system units ■ Setting the input ■ Configuring the outputs ■ Configuration of the operational display ■ Defining the output conditioning ■ Setting the low flow cut off ■ Configuring empty pipe detection Advanced setup <ul style="list-style-type: none"> ■ For more customized configuration of the measurement (adaptation to special measuring conditions) ■ Configuration of totalizers ■ Configuration of electrode cleaning (optional) ■ Configuring the WLAN settings ■ Administration (define access code, reset measuring device)
Diagnostics			Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ■ Diagnostic list Contains up to 5 currently pending diagnostic messages. ■ Event logbook Contains event messages that have occurred. ■ Device information Contains information for identifying the device. ■ Measured values Contains all current measured values. ■ Data logging submenu with "Extended HistoROM" order option Storage and visualization of measured values ■ Heartbeat The functionality of the device is checked on demand and the verification results are documented. ■ Simulation Is used to simulate measured values or output values.

Menu/parameter		User role and tasks	Content/meaning
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none">▪ Commissioning measurements under difficult conditions▪ Optimal adaptation of the measurement to difficult conditions▪ Detailed configuration of the communication interface▪ Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none">▪ System Contains all higher-order device parameters which do not concern the measurement or the communication interface.▪ Sensor Configuration of the measurement.▪ Input Configuring the status input.▪ Output Configuration of the analog current outputs as well as the pulse/frequency and switch output.▪ Communication Configuration of the digital communication interface and the Web server.▪ Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer).▪ Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



- 1 Operational display
- 2 Device tag → 115
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements → 67

Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 146
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- Diagnostic behavior → 147
 - ☒: Alarm
 - ⚠: Warning
 - 🔒: Locking (the device is locked via the hardware)
 - ↔: Communication (communication via remote operation is active)


Display area

In the display area, each measured value is prefaced by certain symbol types for further description:

Measured variable


↓

Example




Measurement channel number

↓











Diagnostic behavior

↓




Appears only if a diagnostics event is present for this measured variable.


Measured variables



Symbol	Meaning
	Volume flow
	Conductivity
	Mass flow
	Totalizer  The measurement channel number indicates which of the three totalizers is displayed.
	Output  The measurement channel number indicates which of the outputs is displayed.
	Status input

Measurement channel numbers


Symbol	Meaning
	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable.
For information on the symbols →  147

 The number and display format of the measured values can be configured via the **Format display** parameter (→  119).

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:

	<div><div>■ In the submenu: Display symbol for menu</div><div>■ In the wizard: Display symbol for wizard</div></div>	<div>Omission symbol for operating menu levels in between</div>	<div>Name of current</div> <div>■ Submenu</div> <div>■ Wizard</div> <div>■ Parameters</div>
	↓	↓	↓
Examples	<div><div></div><div></div></div>	<div><div>/ .. /</div><div>/ .. /</div></div>	<div><div>Display</div><div>Display</div></div>

For more information about the icons in the menu, refer to the "Display area" section → 65





Status area

The following appears in the status area of the navigation view in the top right corner:





- In the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
 - In the wizard
 - If a diagnostic event is present, the diagnostic behavior and status signal
- For information on the diagnostic behavior and status signal → 146
■ For information on the function and entry of the direct access code → 70

Display area


Menus

Symbol	Meaning
	Operation Appears: <ul style="list-style-type: none"> In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu
	Setup Appears: <ul style="list-style-type: none"> In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
	Diagnostics Appears: <ul style="list-style-type: none"> In the menu next to the "Diagnostics" selection At the left in the navigation path in the Diagnostics menu
	Expert Appears: <ul style="list-style-type: none"> In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu




Submenus, wizards, parameters

Symbol	Meaning
	Submenu
	Wizard
	Parameters within a wizard  No display symbol exists for parameters in submenus.

Locking

Symbol	Meaning
	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> By a user-specific access code By the hardware write protection switch

Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
	Confirms the parameter value and switches to the next parameter.
	Opens the editing view of the parameter.

8.3.3 Editing view

1

20

2

0

1

2

3

4

5

6

7

8

9

-

.

←

C

X

✓

3

4

-

+

E

A0013941

1

User

2

ABC

DEFG

HIJK

LMNO

PQRS

TUVW

XYZ

↔C↔

Aa1@

C

X

✓

3

4

-

+

E

A0013999

1 Editing view

2 Display area of the entered values

3 Input mask

4 Operating elements → 67

Input mask









The following input symbols are available in the input mask of the numeric and text editor:


Numeric editor





Symbol	Meaning
<div>0</div> <div>...</div> <div>9</div>	Selection of numbers from 0 to 9.
<div>.</div>	Inserts decimal separator at the input position.
<div>-</div>	Inserts minus sign at the input position.
<div>✓</div>	Confirms selection.
<div>←</div>	Moves the input position one position to the left.
<div>X</div>	Exits the input without applying the changes.
<div>C</div>	Clears all entered characters.

Text editor



Symbol	Meaning
<div>Aa1@</div>	<div>Toggle</div> <ul style="list-style-type: none">Between upper-case and lower-case lettersFor entering numbersFor entering special characters
<div>ABC</div> <div>...</div> <div>XYZ</div>	Selection of letters from A to Z.




 ... 	Selection of letters from a to z.
 ... 	Selection of special characters.
	Confirms selection.
	Switches to the selection of the correction tools.
	Exits the input without applying the changes.
	Clears all entered characters.

Correction symbols under

Symbol	Meaning
	Clears all entered characters.
	Moves the input position one position to the right.
	Moves the input position one position to the left.
	Deletes one character immediately to the left of the input position.

8.3.4 Operating elements

Key	Meaning
	Minus key <i>In menu, submenu</i> Moves the selection bar upwards in a picklist. <i>With a wizard</i> Confirms the parameter value and goes to the previous parameter. <i>For text and numeric editor</i> In the input mask, moves the selection bar to the left (backwards).
	Plus key <i>In menu, submenu</i> Moves the selection bar downwards in a picklist. <i>With a wizard</i> Confirms the parameter value and goes to the next parameter. <i>For text and numeric editor</i> In the input mask, moves the selection bar to the right (forwards).

Key	Meaning
	<p>Enter key</p> <p><i>For operational display</i> Pressing the key for 2 s opens the context menu including the selection for activating the keypad lock.</p> <p><i>In menu, submenu</i></p> <ul style="list-style-type: none">Pressing the key briefly:<ul style="list-style-type: none">Opens the selected menu, submenu or parameter.Starts the wizard.If help text is open, closes the help text of the parameter.Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. <p><i>With a wizard</i> Opens the editing view of the parameter.</p> <p><i>For text and numeric editor</i></p> <ul style="list-style-type: none">Pressing the key briefly:<ul style="list-style-type: none">Opens the selected group.Carries out the selected action.Pressing the key for 2 s confirms the edited parameter value.
	<p>Escape key combination (press keys simultaneously)</p> <p><i>In menu, submenu</i></p> <ul style="list-style-type: none">Pressing the key briefly:<ul style="list-style-type: none">Exits the current menu level and takes you to the next level up.If help text is open, closes the help text of the parameter.Pressing the key for 2 s returns you to the operational display ("home position"). <p><i>With a wizard</i> Exits the wizard and takes you to the next level up.</p> <p><i>For text and numeric editor</i> Closes the text or numeric editor without applying changes.</p>
	<p>Minus/Plus/Enter key combination (press and hold down the keys simultaneously)</p> <p><i>For operational display</i> Enables or disables the keypad lock (only SD02 display module).</p>



8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:



- Setup
- Simulation

Calling up and closing the context menu

The user is in the operational display.



1. Press the  and  keys for longer than 3 seconds.
 - ↳ The context menu opens.



2. Press  +  simultaneously.
 - ↳ The context menu is closed and the operational display appears.

Calling up the menu via the context menu

1. Open the context menu.


2. Press  to navigate to the desired menu.
3. Press  to confirm the selection.
 - ↳ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

 For an explanation of the navigation view with symbols and operating elements
→  64

Example: Setting the number of displayed measured values to "2 values"




A0029562-EN

8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path
Expert → Direct access

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter **"914"** instead of **"00914"**
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter **00914** → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter **00914-2** → **Assign process variable** parameter



For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device


8.3.8 Calling up help text

Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press for 2 s.
↳ The help text for the selected parameter opens.




15 Example: Help text for parameter "Enter access code"

2. Press + simultaneously.
↳ The help text is closed.

8.3.9 Changing the parameters

i For a description of the editing view - consisting of the text editor and numeric editor - with symbols → 66, for a description of the operating elements → 67

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102




A0029563-EN

A message is displayed if the value entered is outside the permitted value range.

<div> <div>Ent. access code</div> <div>Invalid or out of range input value</div> <div>Min:0</div> <div>Max:9999</div> </div>
--

A0014049-EN

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access →  133.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- Define the access code.
 - ↳ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	✓	✓
After an access code has been defined.	✓	✓ ¹⁾

- 1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role



Access code status	Read access	Write access
After an access code has been defined.	✓	-- ¹⁾


- 1) Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section





The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display

8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation →  133.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter (→  123) via the respective access option.


1. After you press , the input prompt for the access code appears.
2. Enter the access code.
 - ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock



The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.


The keypad lock is switched on and off via the context menu.

Switching on the keypad lock



-  The keypad lock is switched on automatically:
- If the device has not been operated via the display for > 1 minute.
 - Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.
Press the  and  keys for 3 seconds.
↳ A context menu appears.
2. In the context menu select the **Keylock on** option.
↳ The keypad lock is switched on.

-  If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.



Switching off the keypad lock

- The keypad lock is switched on.
Press the  and  keys for 3 seconds.
↳ The keypad lock is switched off.

8.4 Access to the operating menu via the Web browser

8.4.1 Function scope

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45) . The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed, allowing users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.



-  For additional information on the Web server, refer to the Special Documentation for the device →  205

8.4.2 Prerequisites



Computer hardware

Hardware	Interface	
	CDI-RJ45	WLAN
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.
Connection	Standard Ethernet cable with RJ45 connector.	Connection via Wireless LAN.
Screen	Recommended size: ≥12" (depends on the screen resolution)	



Computer software













Software	Interface	
	CDI-RJ45	WLAN
Recommended operating systems	<ul style="list-style-type: none"> Microsoft Windows 8 or higher. Mobile operating systems: <ul style="list-style-type: none"> iOS Android  Microsoft Windows XP is supported.  Microsoft Windows 7 is supported. 	
Web browsers supported	<ul style="list-style-type: none"> Microsoft Internet Explorer 8 or higher Microsoft Edge Mozilla Firefox Google Chrome Safari 	

Computer settings




Settings	Interface	
	CDI-RJ45	WLAN
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).	
Proxy server settings of the Web browser	The Web browser setting <i>Use a Proxy Server for Your LAN</i> must be deselected .	
JavaScript	<p>JavaScript must be enabled.</p> <p> If JavaScript cannot be enabled: enter <code>http://192.168.1.212/basic.html</code> in the address line of the Web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.</p> <p> When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under Internet options.</p>	
Network connections	Only the active network connections to the measuring device should be used.	
	Switch off all other network connections such as WLAN.	Switch off all other network connections.

In the event of connection problems: →  144*Measuring device: Via CDI-RJ45 service interface*

Device	CDI-RJ45 service interface
Measuring device	The measuring device has an RJ45 interface.
Web server	<p>Web server must be enabled; factory setting: ON</p> <p> For information on enabling the Web server →  80</p>
IP address	<p>If the IP address of the device is not known:</p> <ul style="list-style-type: none"> The IP address can be read out via local operation: Diagnostics → Device information → IP address Communication with the Web server can be established via the default IP address 192.168.1.212. <p>The DHCP function is enabled in the device at the factory, i.e. the device expects an IP address to be assigned by the network. This function can be disabled and the device can be set to the default IP address 192.168.1.212: set DIP switch No. 2 from OFF → ON.</p>

Device	CDI-RJ45 service interface
	<div><div><div><div>ON OFF</div><div>2  IP 192.168.1.212</div><div>1  Write protection</div><div>4  128</div><div>3  64</div><div>2  32</div><div>1  16</div><div>4  8</div><div>3  4</div><div>2  2</div><div>1  1</div></div><div>IP Address setting (last octet)</div><div></div></div><div><div></div><div><ul style="list-style-type: none">Once the DIP switch has been activated, the device must be restarted before the device uses the default IP address.If the default IP address is used (top DIP switch No. 2 = ON), there is no connection to the EtherNet/IP network.</div></div></div>

Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna: Transmitter with integrated WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ON <div><div></div><div>For information on enabling the Web server →  80</div></div>
IP address	<p>If the IP address of the device is not known:</p> <ul style="list-style-type: none">The IP address can be read out via local operation: Diagnostics → Device information → IP addressCommunication with the Web server can be established via the default IP address 192.168.1.212. The DHCP function is enabled in the device at the factory, i.e. the device expects an IP address to be assigned by the network. This function can be disabled and the device can be set to the default IP address 192.168.1.212: set DIP switch No. 2 from OFF → ON. <div><div></div><div><ul style="list-style-type: none">Once the DIP switch has been activated, the device must be restarted before the device uses the default IP address.If the default IP address is used (top DIP switch No. 2 = ON), there is no connection to the EtherNet/IP network.</div></div>


8.4.3 Establishing a connection

Via service interface (CDI-RJ45)

Preparing the measuring device

Configuring the Internet protocol of the computer

The IP address can be assigned to the measuring device in a variety of ways:

- Dynamic Host Configuration Protocol (DHCP), factory setting:
The IP address is automatically assigned to the measuring device by the automation system (DHCP server).
- Hardware addressing:
The IP address is set via DIP switches .
- Software addressing:
The IP address is entered via the **IP address** parameter (→  118) .
- DIP switch for "Default IP address":
To establish the network connection via the service interface (CDI-RJ45): the fixed IP address 192.168.1.212 is used .

The measuring device works with the Dynamic Host Configuration Protocol (DHCP), on leaving the factory, i.e. the IP address of the measuring device is automatically assigned by the automation system (DHCP server).

To establish a network connection via the service interface (CDI-RJ45): set the "Default IP address" DIP switch to **ON**. The measuring device then has the fixed IP address: 192.168.1.212. This address can now be used to establish the network connection.

1. Via DIP switch 2, activate the default IP address 192.168.1.212: .
2. Switch on the measuring device.
3. Connect to the computer using a cable .
4. If a 2nd network card is not used, close all the applications on the notebook.
 - ↳ Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
5. Close any open Internet browsers.
6. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 → e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

- Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH_Promag__A802000).
2. If necessary, select the WPA2 encryption method.

3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - ↳ LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.

i The serial number can be found on the nameplate.

i To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the SSID name to the measuring point (e.g. tag name) as it is displayed as the WLAN network.

Disconnecting

- ▶ After configuring the device:
Terminate the WLAN connection between the operating unit and measuring device.

Starting the Web browser

1. Start the Web browser on the computer.
2. Enter the IP address of the Web server in the address line of the Web browser:
192.168.1.212
 - ↳ The login page appears.

The screenshot shows the login page of the Proline Promag W 400 EtherNet/IP. It features a top section with a device picture (1), input fields for device name (2), device tag (3), and status signal (4), and a section for current measured values (5) including volume flow, mass flow, and conductivity. Below this is a language selection dropdown (6) set to English. The main section is titled 'Login' and contains an 'Access status' indicator, a 'Maintenance' link (7), an 'Enter access code' field (8) with an information icon, a 'Login' button (9), and a 'Reset access code' button (10).

A0029417

- 1 Picture of device
- 2 Device name
- 3 Device tag
- 4 Status signal
- 5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code (→ 132)


i If a login page does not appear, or if the page is incomplete → 144

8.4.4 Logging on


1. Select the preferred operating language for the Web browser.

2. Enter the user-specific access code.
3. Press **OK** to confirm your entry.

Access code	0000 (factory setting); can be changed by customer
-------------	--

 If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


8.4.5 User interface




- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal →  149
- Current measured values

Function row

Functions	Meaning
Measured values	Displays the measured values of the device
Menu	<ul style="list-style-type: none"> ■ Access to the operating menu from the measuring device ■ The structure of the operating menu is the same as for the local display  For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	Data exchange between PC and measuring device: <ul style="list-style-type: none"> ■ Device configuration: <ul style="list-style-type: none"> ■ Load settings from the device (XML format, save configuration) ■ Save settings to the device (XML format, restore configuration) ■ Logbook - Export Event logbook (.csv file) ■ Documents - Export documents: <ul style="list-style-type: none"> ■ Export backup data record (.csv file, create documentation of the measuring point configuration) ■ Verification report (PDF file, only available with the "Heartbeat Verification" application package) ■ File for system integration - If using fieldbuses, upload device drivers for system integration from the measuring device: EtherNet/IP: EDS file

Functions	Meaning
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the measuring device: <ul style="list-style-type: none"> ■ Network settings (e.g. IP address, MAC address) ■ Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu → Communication → Web server

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	On

Function scope of the "Web server functionality" parameter

Option	Description
Off	<ul style="list-style-type: none"> ■ The web server is completely disabled. ■ Port 80 is locked.
On	<ul style="list-style-type: none"> ■ The complete functionality of the web server is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

i Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.
↳ The home page with the Login box appears.

2. Close the Web browser.

3. If no longer needed:
Reset modified properties of the Internet protocol (TCP/IP) →  76.

i If communication with the Web server was established via the default IP address 192.168.1.212, DIP switch No. 10 must be reset (from **ON** → **OFF**). Afterwards, the IP address of the device is active again for network communication.

8.5 Access to the operating menu via the operating tool


The structure of the operating menu in the operating tools is identical to operation via the local display.


8.5.1 Connecting the operating tool

Via EtherNet/IP network

This communication interface is available in device versions with EtherNet/IP.


Star topology



 16 Options for remote operation via EtherNet/IP network: star topology

- 1 Automation system, e.g. "RSLogix" (Rockwell Automation)
- 2 Workstation for measuring device operation: with Custom Add-On Profile for "RSLogix 5000" (Rockwell Automation) or with Electronic Data Sheet (EDS)
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare) with COM DTM "CDI Communication TCP/IP"
- 4 Ethernet switch
- 5 Measuring device

Via service interface (CDI-RJ45)




17 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version:
 Order code for "Display", option BA "WLAN":
 4-line, illuminated, graphic display; touch control + WLAN



- 1 Transmitter with integrated WLAN antenna
- 2 LED lit constantly: WLAN reception is enabled on measuring device
- 3 LED flashing: WLAN connection established between operating unit and measuring device
- 4 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 5 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 6 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz) <ul style="list-style-type: none"> Access point with DHCP server (default setting) Network
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antenna	Internal antenna
Range	Typically 10 m (32 ft)

*Configuring the Internet protocol of the mobile terminal***NOTICE**

If the WLAN connection is lost during the configuration, settings made may be lost.

- Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

- Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:
Select the measuring device using the SSID (e.g. EH_Promag__A802000).
2. If necessary, select the WPA2 encryption method.
3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
↳ LED on display module flashes: it is now possible to operate the measuring device with the Web browser, FieldCare or DeviceCare.



The serial number can be found on the nameplate.



To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the SSID name to the measuring point (e.g. tag name) as it is displayed as the WLAN network.

Disconnecting

- After configuring the device:
Terminate the WLAN connection between the operating unit and measuring device.

8.5.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

CDI-RJ45 service interface

Typical functions:

- Parameterization of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information →  86


Establishing a connection

1. Start FieldCare and launch the project.
2. In the network: Add a device.
↳ The **Add device** window opens.
3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
↳ The **CDI Communication TCP/IP (Configuration)** window opens.
6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
7. Establish the online connection to the device.




For additional information, see Operating Instructions BA00027S and BA00059S

User interface



A0008200

- 1 Device name
- 2 Tag name
- 3 Status area with status signal →  149
- 4 Display area for current measured values
- 5 Edit bar with additional functions
- 6 Navigation area with operating menu structure

8.5.3 DeviceCare

Function scope

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure IN01047S

Source for device description files

See information →  86

8.5.4 Field Xpert SMT70, SMT77**Field Xpert SMT70**

The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.

This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.



- Technical Information TI01342S
- Operating Instructions BA01709S
- Product page: www.endress.com/smt70



Source for device description files: →  86


Field Xpert SMT77

The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.



- Technical Information TI01418S
- Operating Instructions BA01923S
- Product page: www.endress.com/smt77



Source for device description files: →  86

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	02.00.zz
Release date of firmware version	11.2021
Manufacturer ID	0x49E
Device type ID	0x1069
Device revision	4
Device profile	Generic device (product type: 0x2B)



- Protocol-specific data → 180
- Firmware versions of the device → 167

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via Service interface (CDI-RJ45)	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> ▪ www.endress.com → Download Area ▪ CD-ROM (contact Endress+Hauser) ▪ DVD (contact Endress+Hauser)
DeviceCare	<ul style="list-style-type: none"> ▪ www.endress.com → Download Area ▪ CD-ROM (contact Endress+Hauser) ▪ DVD (contact Endress+Hauser)

9.2 Overview of system files

System files	Version	Description	How to acquire
Electronic Data Sheet (EDS system file)	<ul style="list-style-type: none"> ▪ Major revision 4 ▪ Minor revision 1 	Certified in accordance with the following ODVA guidelines: <ul style="list-style-type: none"> ▪ Conformance test ▪ Performance test ▪ PlugFest Embedded EDS Support (File Object 0x37)	<ul style="list-style-type: none"> ▪ www.endress.com → Download Area ▪ EDS system file integrated in the device: can be downloaded via the web browser
Add-on Profile	<ul style="list-style-type: none"> ▪ Major revision 4 ▪ Minor revision 1 	System file for "Studio 5000" software (Rockwell Automation) Add new module: <ul style="list-style-type: none"> ▪ Promag_400 Revision 2 = Assembly 101...104 ▪ Promag_400_V02 Revision 4 = Assembly 120...127 	www.endress.com → Download Area

9.3 Integrating the measuring device in the system



For detailed information on system integration, see the Operating Instructions for the device

A detailed description of how to integrate the device into an automation system (e.g. from Rockwell Automation) is available as a separate document:

www.endress.com → Select your country → Solutions → Fieldbus planning
→ Fieldbus technologies → EtherNet/IP

9.4 Implicit data transmission

Implicit data transmission when using the device master file (GSD).

9.4.1 Block model

The block model shows which input and output data the measuring device makes available for implicit messaging. Implicit data exchange is performed using an EtherNet/IP scanner, e.g. a distributed control system etc.

Measuring device							Control system
Transducer Block	Name	Assembly	Byte	Hex	Description		EtherNet/IP
	Legacy ¹⁾ Input Assembly Fix ²⁾	100	32	0x64	→ 89	Permanently assigned input group	→
	Legacy Input Assembly Configurable ²⁾	101	88	0x65	→ 90	Configurable input group	→
	Legacy Output Assembly Fix ²⁾	102	56	0x66	→ 91	Permanently assigned output group	←
	Legacy Configuration Assembly ²⁾	104	398	0x68	→ 94	Permanently assigned configuration	
	Dummy Configuration Assembly	105	0	0x69	→ 99	"Configuration Assembly" placeholder if a permanently assigned Configuration Assembly is not used	
	Dummy Output Assembly Fix	199	0	0xC7	→ 99	"Output Assembly Fix" placeholder if a permanently assigned output group is not defined	
	Input Assembly Fix ³⁾	120	56	0x78	→ 89	Permanently assigned input group	→
	Input Assembly Configurable ³⁾	121	128	0x79	→ 90	Configurable input group	→
	Output Assembly Fix ³⁾	122	56	0x7A	→ 92	Permanently assigned output group	←
	Configuration Assembly ³⁾	124	186	0x7C	→ 96	Permanently assigned configuration	
	Volume Flow Extended Fix Input ³⁾	126	72	0x7E	→ 98	Permanently assigned volume flow	→
	Volume Flow Universal Fix Input ³⁾	127	40	0x7F	→ 99	Permanently assigned input group for electromagnetic default values	→

1) Legacy Assembly: Assembly for devices with Device Revision 1 or 2 that continue to be used for compatibility reasons

2) Assembly can be used by devices with Device Revision 2 and 4

3) Assembly can be used by devices with Device Revision 4


9.4.2 Pre-defined connections

No.	Name	O → T (Output)	T → O (Input)	Configuration
1	Legacy Fix Input/Output + Config Assembly	Assem102	Assem100	Assem104
2	Legacy Fix Input + Config Assembly	–	Assem100	Assem104
3	Legacy Configurable Input + Fix Output + Config Assembly	Assem102	Assem101	Assem104
4	Legacy Configurable Input + Config Assembly	–	Assem101	Assem104
5	Legacy Fix Input/Output	Assem102	Assem100	–
6	Legacy Fix Input	–	Assem100	–
7	Legacy Configurable Input + Fix Output	Assem102	Assem101	–
8	Legacy Configurable Input	–	Assem101	–
9	Fix Input/Output + Config Assembly	Assem122	Assem120	Assem124
10	Fix Input + Config Assembly	–	Assem120	Assem124
11	Configurable Input + Fix Output + Config Assembly	Assem122	Assem121	Assem124
12	Configurable Input + Config Assembly	–	Assem121	Assem124
13	Volume Flow Extended + Fix Output + Config Assembly	Assem122	Assem126	Assem124
14	Volume Flow Extended + Config Assembly	–	Assem126	Assem124
15	Volume Flow Universal + Fix Output + Config Assembly	Assem122	Assem127	Assem124
16	Volume Flow Universal + Config Assembly	–	Assem127	Assem124
17	Fix Input/Fix Output	Assem122	Assem120	–
18	Fix Input	–	Assem120	–
18	Configurable Input + Fix Output	Assem122	Assem121	–
20	Configurable Input	–	Assem121	–
21	Volume Flow Extended + Fix Output	Assem122	Assem126	–
22	Volume Flow Extended	–	Assem126	–
23	Volume Flow Universal + Fix Output	Assem122	Assem127	–
24	Volume Flow Universal	–	Assem127	–


9.4.3 Permanently assigned input group

Output data from the device to the controller in predefined quantity and sequence.


Legacy Input Assembly Fix (Assem100), 32 byte

 Legacy Input Assembly Fix (Assem100) is supported by devices with Device Revision 2 and 4.


Byte	Description
1 to 4	File header (not visible)
5 to 6	Current diagnosis ¹⁾ : Diagnostic number
7	Current diagnosis: Status signal
8	Not used
9 to 12	Volume flow
13 to 16	Mass flow
17 to 20	Conductivity
21 to 24	Totalizer 1
25 to 28	Totalizer 2
29 to 32	Totalizer 3

1) Diagnostic information via EtherNet/IP →  104


Input Assembly Fix (Assem120) 56 byte

 Input Assembly Fix (Assem120) is supported by devices with Device Revision 4.

Byte	Description
1 to 4	File header (not visible)
5 to 6	Current diagnosis ¹⁾ : Diagnostic number
7	Current diagnosis: Status signal <ul style="list-style-type: none"> 0: Good 1: Failure 2: Function check 4: Maintenance required 8: Out of specification
8	Not used
9 to 16	Volume flow <p>Structure:</p> <ul style="list-style-type: none"> 4: Value 1: Status measured value ²⁾ 1: Padding 2: Unit ³⁾
17 to 24	Mass flow
25 to 32	Conductivity
33 to 40	Totalizer 1
41 to 48	Totalizer 2
49 to 56	Totalizer 3

1) Diagnostic information via EtherNet/IP →  108


2) Good (0x80), Uncertain (0x40) or Bad (0x0C)

3) Available units →  100

9.4.4 Configurable input group

User-configurable output data of the device to the controller. Some output data, such as Heartbeat Verification, are only optionally available.

Legacy Input Assembly Configurable (Assem101) 88 byte

 Legacy Input Assembly Configurable (Assem101) is supported by devices with Device Revision 2 and 4.

Description	Format
Input values 1 to 10	Real
Input values 11 to 20	Double integer


Possible input values

Possible input values 1 to 10		
<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow 	<ul style="list-style-type: none"> ■ Conductivity ■ Totalizer 1 ■ Totalizer 2 	<ul style="list-style-type: none"> ■ Totalizer 3 ■ Electronic temperature ■ Flow velocity

Possible input values 11 to 20		
<ul style="list-style-type: none"> ■ Off ■ Current diagnosis ■ Previous diagnosis ■ Mass flow unit ■ Volume flow unit 	<ul style="list-style-type: none"> ■ Temperature unit ■ Conductivity unit ■ Totalizer 1 unit ■ Totalizer 2 unit ■ Totalizer 3 unit 	<ul style="list-style-type: none"> ■ Flow velocity unit ■ Verification results ¹⁾ ■ Verification status ¹⁾


1) Only available with the Heartbeat Verification application package.

Input Assembly Configurable (Assem121) 128 byte

 Input Assembly Configurable (Assem121) is supported by devices with Device Revision 4.

Description	Format
Input values 1 to 10 Structure: <ul style="list-style-type: none"> ■ 4: Value ■ 1: Status measured value ¹⁾ ■ 1: Padding ■ 2: Unit ²⁾ 	Real
Input values 11 to 15 Structure: <ul style="list-style-type: none"> ■ 4: Value ³⁾ ■ 1: Status measured value ¹⁾ ■ 3: Padding 	Double integer

1) Good (0x80), Uncertain (0x40) or Bad (0x0C)

2) Available units →  100

3) The unit is determined by the assigned measured value.

Possible input values

Possible input values 1 to 10		
<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Conductivity ■ Corrected conductivity ■ Temperature 	<ul style="list-style-type: none"> ■ Flow velocity ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Electronic temperature ■ Buildup index value ¹⁾ 	<ul style="list-style-type: none"> ■ MonitoringCoilRiseTime ¹⁾ ■ MonitoringGroundPotential ¹⁾ ■ MonitoringNoise ¹⁾ ■ MIDTestPoint1 ■ MIDTestPoint2 ■ MIDTestPoint3

1) Only available with the Heartbeat Verification application package.


Possible input values 11 to 15		
<ul style="list-style-type: none"> ■ Off ■ Current diagnosis ■ Previous diagnosis 	<ul style="list-style-type: none"> ■ Low flow cut off ■ Buildup index value ¹⁾ 	<ul style="list-style-type: none"> ■ Verification results ¹⁾ ■ Verification status ¹⁾



1) Only available with the Heartbeat Verification application package.




9.4.5 Permanently assigned output group

Input data from the controller to the device in predefined quantity and sequence.

Legacy Output Assembly Fix (Assem102) 56 byte

 Legacy Input Assembly Fix (Assem102) is supported by devices with Device Revision 2 and 4.






Description	Byte	Bytes	Bit	Value/code: function/unit
Totalizer 1 control activation	1	1	1	<ul style="list-style-type: none"> ■ 0: Disable ■ 1: Enable
Totalizer 2 control activation			2	
Totalizer 3 control activation			3	
Reference density compensation activation			4	
Verification activation			5	–
Not used			6	
Not used			7	
Not used			8	–
Not used	2 to 4	3	–	
Totalizer 1 – control (integer)	5+6	2	<ul style="list-style-type: none"> ■ -32226: Totalize ■ -32490: Reset (0) + hold ■ -32228: Preset + hold ■ 198: Reset (0) + start totalization ■ 199: Preset + start totalization  Signed integers (16 bit)	
Not used	7+8	2	–	
Totalizer 2 – control (integer)	9+10	2	<ul style="list-style-type: none"> ■ -32226: Totalize ■ -32490: Reset (0) + hold ■ -32228: Preset + hold ■ 198: Reset (0) + start totalization ■ 199: Preset + start totalization  Signed integers (16 bit)	
Not used	11+12	2	–	

Description	Byte	Bytes	Bit	Value/code: function/unit
Totalizer 3 – control (integer)	13+14	2		<ul style="list-style-type: none"> ■ -32226: Totalize ■ -32490: Reset (0) + hold ■ -32228: Preset + hold ■ 198: Reset (0) + start totalization ■ 199: Preset + start totalization  Signed integers (16 bit)
Not used	15+16	2	–	
External density (real)	17 to 20	4		External reference density to field device in "IEEE 754" data format
External density unit (integer)	21+22	2		<ul style="list-style-type: none"> ■ 12040: g/cm³ ■ 2088: g/m³ ■ 2109: kg/dm³ ■ 12048: kg/l ■ 12039: kg/m³ ■ 2204: SD4°C ■ 2277: SD15°C ■ 2230: SD20°C ■ 2228: SG4°C ■ 2226: SG15°C ■ 2227: SG20°C ■ 12044: lb/ft³ ■ 12043: lb/gal (us) ■ 2174: lb/bbl (us;liq.) ■ 2173: lb/bbl (us;beer) ■ 2175: lb/bbl (us;oil) ■ 2176: lb/bbl (us;tank) ■ 2180: lb/gal (imp) ■ 2179: lb/bbl (imp;oil)  Signed integers (16 bit)
Not used	23+24	2	–	
Start verification (integer)	25+26	2		<ul style="list-style-type: none"> ■ -32713: Cancel ■ -32378: Start  Signed integers (16 bit)
Not used	27 to 56	30	–	

Output Assembly Fix (Assem122) 56 byte

 Output Assembly Fix (Assem122) is supported by devices with Device Revision 4.

Description	Byte	Bytes	Bit	Value/code: function/unit
Totalizer 1 control activation	1	1	1	<ul style="list-style-type: none"> ■ 0: Disable ■ 1: Enable
Totalizer 2 control activation			2	
Totalizer 3 control activation			3	
Reference density compensation activation			4	
Verification activation			5	
Empty pipe detection activation			6	
Reference temperature compensation			7	
Not used	2 to 4	3	8	–
Not used			–	

Description	Byte	Bytes	Bit	Value/code: function/unit
Totalizer 1 – control (integer)	5+6	2		<ul style="list-style-type: none"> ▪ -32226: Totalize ▪ -32608: Stop ▪ -32490: Reset (0) + hold ▪ -32228: Preset + hold ▪ 198: Reset (0) + start totalization ▪ 199: Preset + start totalization  Signed integers (16 bit)
Not used	7+8	2	–	
Totalizer 2 – control (integer)	9+10	2		<ul style="list-style-type: none"> ▪ -32226: Totalize ▪ -32608: Stop ▪ -32490: Reset (0) + hold ▪ -32228: Preset + hold ▪ 198: Reset (0) + start totalization ▪ 199: Preset + start totalization  Signed integers (16 bit)
Not used	11+12	2	–	
Totalizer 3 – control (integer)	13+14	2		<ul style="list-style-type: none"> ▪ -32226: Totalize ▪ -32608: Stop ▪ -32490: Reset (0) + hold ▪ -32228: Preset + hold ▪ 198: Reset (0) + start totalization ▪ 199: Preset + start totalization  Signed integers (16 bit)
Not used	15+16	2	–	
External density (real)	17+20	4		External reference density to field device in "IEEE 754" data format
External density unit (integer)	21+22	2		<ul style="list-style-type: none"> ▪ 12040: g/cm³ ▪ 2088: g/m³ ▪ 2109: kg/dm³ ▪ 12048: kg/l ▪ 12039: kg/m³ ▪ 2204: SD4°C ▪ 2277: SD15°C ▪ 2230: SD20°C ▪ 2228: SG4°C ▪ 2226: SG15°C ▪ 2227: SG20°C ▪ 12044: lb/ft³ ▪ 2173: lb/bbl (us;beer) ▪ 2174: lb/bbl (us;liq.) ▪ 2175: lb/bbl (us;oil) ▪ 2176: lb/bbl (us;tank) ▪ 12043: lb/gal (us) ▪ 2178: lb/bbl (imp; beer) ▪ 2179: lb/bbl (imp;oil) ▪ 2180: lb/gal (imp)  Signed integers (16 bit)
Not used	23+24	2	–	
Start verification (integer)	25+26	2		<ul style="list-style-type: none"> ▪ -32713: Cancel ▪ -32378: Start  Signed integers (16 bit)
Not used	27+28	2	–	
Empty pipe detection	29+30	2		<ul style="list-style-type: none"> ▪ 32823: Cancel ▪ 474: Empty pipe adjustment ▪ 476: Full pipe adjustment

Description	Byte	Bytes	Bit	Value/code: function/unit
Not used	31+32	2	–	
External temperature (real)	33 to 36	4	–	
External temperature unit (integer)	37+38	2		<ul style="list-style-type: none"> ■ 4608: °C ■ 4609: °F ■ 4610: K ■ 4611: °R
Not used	39+40	2	–	
Not used	41 to 56	16	–	

Use of the totalizer


Example: Reset totalizer 1 in Output Assembly Fix (Assem102).

1. Activation of totalizer control function:
In the 1st module (totalizer 1 control activation), send a 1 to the device.
2. Reset the totalizer:
In the 10th module (totalizer 1 – control (integer)), send a 198 to the device.

9.4.6 Permanently assigned configuration

Permanently assigned configuration from the controller to the device. Is used for the automated configuration of the device by the controller. This is performed after each device reboot, e.g. following a power failure or a device replacement.

Legacy Configuration Assembly (Assem104) 398 byte


 Legacy Configuration Assembly (Assem104) is supported by devices with Device Revision 2 and 4.

Byte	Bytes	Description
1 to 4	4	Not used
5	1	Write protection
6	1	Not used
7+8	2	Mass flow unit
9+10	2	Mass flow
11+12	2	Volume flow unit
13+14	2	Volume flow
15+16	2	Density unit
17+18	2	Temperature unit
19+20	2	Conductivity unit
21 to 46	26	Not used
47+48	2	Access code entry
49+50	2	Assign process variable totalizer 1
51+52	2	Totalizer 1 unit
53+54	2	Operating mode totalizer 1
55+56	2	Failsafe mode totalizer 1
57 to 60	4	Preset value totalizer 1
61+62	2	Control totalizer 1

Byte	Bytes	Description
63+64	2	Assign process variable totalizer 2
65+66	2	Totalizer 2 unit
67+68	2	Operating mode totalizer 2
69+70	2	Failsafe mode totalizer 2
71 to 74	4	Preset value totalizer 2
75+76	2	Control totalizer 2
77+78	2	Assign process variable totalizer 3
79+80	2	Totalizer 3 unit
81+82	2	Operating mode totalizer 3
83+84	2	Failsafe mode totalizer 3
85+88	2	Preset value totalizer 3
89+90	2	Control totalizer 3
91+92	2	Input Assembly Position 1
93+94	2	Input Assembly Position 2
95+96	2	Input Assembly Position 3
97+98	2	Input Assembly Position 4
99+100	2	Input Assembly Position 5
101+102	2	Input Assembly Position 6
103+104	2	Input Assembly Position 7
105+106	2	Input Assembly Position 8
107+108	2	Input Assembly Position 9
109+110	2	Input Assembly Position 10
111+112	2	Input Assembly Position 11
113+114	2	Input Assembly Position 12
115+116	2	Input Assembly Position 13
117+118	2	Input Assembly Position 14
119+120	2	Input Assembly Position 15
121+122	2	Input Assembly Position 16
123+124	2	Input Assembly Position 17
125+126	2	Input Assembly Position 18
127+128	2	Input Assembly Position 19
129+130	2	Input Assembly Position 20
131+132	2	Installation direction
133+134	2	Assign process variable
135+136	2	Empty pipe detection
137 to 140	4	On value low flow cut off
141 to 144	4	Off value low flow cut off
145 to 148	4	Pressure shock suppression
149 to 152	4	Response time empty pipe detection
153 to 156	4	Conductivity damping
157+158	2	Flow override
159+160	2	New adjustment empty pipe detection
161+162	2	Density source

Byte	Bytes	Description
163+164	2	Filter options
165 to 168	4	Switch point empty pipe detection
169 to 172	4	Fixed density
173	1	Flow damping
174 to 176	3	Not used
177 to 180	4	Alarm delay
181	1	Assign behavior of diagnostic no. 832
182	1	Assign behavior of diagnostic no. 833
183	1	Assign behavior of diagnostic no. 834
184	1	Assign behavior of diagnostic no. 835
185	1	Assign behavior of diagnostic no. 862
186	1	Assign behavior of diagnostic no. 531
187	1	Assign behavior of diagnostic no. 937
188	1	Assign behavior of diagnostic no. 302
189 to 398	210	Not used

Configuration Assembly (Assem124) 186 byte

 Configuration Assembly (Assem124) is supported by devices with Device Revision 4.

Byte	Bytes	Description
1 to 4	4	Not used
5	1	Write protection
6	1	Not used
7+8	2	Mass flow unit
9+10	2	Mass flow
11+12	2	Volume flow unit
13+14	2	Volume flow
15+16	2	Density unit
17+18	2	Temperature unit
19+20	2	Conductivity unit
21+22	2	Corrected volume flow unit
23+24	2	Corrected volume flow
25 to 26	2	Not used
27+28	2	Access code entry
29+30	2	Assign process variable totalizer 1
31+32	2	Totalizer 1 unit
33+34	2	Operating mode totalizer 1
35+36	2	Failsafe mode totalizer 1
37 to 40	4	Preset value totalizer 1
41+42	2	Control totalizer 1
43+44	2	Assign process variable totalizer 2
45+46	2	Totalizer 2 unit

Byte	Bytes	Description
47+48	2	Operating mode totalizer 2
49+50	2	Failsafe mode totalizer 2
51 to 54	4	Preset value totalizer 2
55+56	2	Control totalizer 2
57+58	2	Assign process variable totalizer 3
59+60	2	Totalizer 3 unit
61+62	2	Operating mode totalizer 3
63+64	2	Failsafe mode totalizer 3
65+68	2	Preset value totalizer 3
69+70	2	Control totalizer 3
71+72	2	Installation direction
73+74	2	Assign process variable
75+76	2	Empty pipe detection
77 to 80	4	On value low flow cut off
81 to 84	4	Off value low flow cut off
85 to 88	4	Pressure shock suppression
89 to 92	4	Response time empty pipe detection
93+94	2	Flow override
95+96	2	New adjustment empty pipe detection
97+98	2	Density source
99+100	2	Temperature source
101+102	2	Filter options
103+104	2	Conductivity measurement
105 to 108	4	Conductivity damping
109 to 112	4	Switch point empty pipe detection
113 to 116	4	Fixed density
117	1	Flow damping
118	1	Not used
119+120	2	Buildup index
121 to 124	4	Buildup limit
125 to 128	4	Hysteresis buildup limit
129	1	Buildup damping
130 to 132	3	Not used
133 to 136	4	Alarm delay
137	1	Assign behavior of diagnostic no. 832
138	1	Assign behavior of diagnostic no. 833
139	1	Assign behavior of diagnostic no. 834
140	1	Assign behavior of diagnostic no. 835
141	1	Assign behavior of diagnostic no. 862
142	1	Assign behavior of diagnostic no. 531
143	1	Assign behavior of diagnostic no. 937
144	1	Assign behavior of diagnostic no. 302
145+146	2	Assign behavior of diagnostic no. 43

Byte	Bytes	Description
147+148	2	Assign behavior of diagnostic no. 376
149+150	2	Assign behavior of diagnostic no. 377
151+152	2	Assign behavior of diagnostic no. 842
153+154	2	Assign behavior of diagnostic no. 938
155+156	2	Assign behavior of diagnostic no. 961
157+158	2	Input Assembly Position 1
159+160	2	Input Assembly Position 2
161+162	2	Input Assembly Position 3
163+164	2	Input Assembly Position 4
165+166	2	Input Assembly Position 5
167+168	2	Input Assembly Position 6
169+170	2	Input Assembly Position 7
171+172	2	Input Assembly Position 8
173+174	2	Input Assembly Position 9
175+176	2	Input Assembly Position 10
177+178	2	Input Assembly Position 11
179+180	2	Input Assembly Position 12
181+182	2	Input Assembly Position 13
183+184	2	Input Assembly Position 14
185+186	2	Input Assembly Position 15

9.4.7 Permanently assigned volume flow

Volume Flow Extended Fix Input (Assem126) 80 byte

Permanently assigned input values to the controller. Output data for the volume flow from the device to the controller in predefined quantity and sequence.



Volume Flow Extended (Assem126) is supported by devices with Device Revision 4.

Byte	Description
1 to 4	File header (not visible)
5 to 8	Current diagnosis ¹⁾
9 to 16	Volume flow Structure: <ul style="list-style-type: none"> ■ 4: Value ■ 1: Status measured value ²⁾ ■ 1: Padding ■ 2: Unit ³⁾
17 to 24	Corrected volume flow
25 to 32	Conductivity
33 to 40	Temperature
41 to 48	Totalizer 1
49 to 56	Totalizer 2


Byte	Description
47 to 64	Corrected conductivity
65 to 72	Buildup index value

- 1) Diagnostic information via EtherNet/IP → ⓘ 108
- 2) Good (0x80), Uncertain (0x40) or Bad (0x0C)
- 3) Available units → ⓘ 100

9.4.8 Permanently assigned default values

Volume Flow Universal Fix Input (Assem127) 40 byte

Permanently assigned input group to the controller for electromagnetic default values. Output data from the device to the controller in predefined quantity and sequence.

 Volume Flow Universal (Assem127) is supported by devices with Device Revision 4.

Byte	Description
1 to 4	File header (not visible)
5 to 8	Current diagnosis ¹⁾
9 to 16	Volume flow Structure: <ul style="list-style-type: none"> ■ 4: Value ■ 1: Status measured value ²⁾ ■ 1: Padding ■ 2: Unit ³⁾
17 to 24	Totalizer 1
25 to 32	Totalizer 2
33 to 40	Totalizer 3


- 1) Diagnostic information via EtherNet/IP → ⓘ 108
- 2) Good (0x80), Uncertain (0x40) or Bad (0x0C)
- 3) Available units → ⓘ 100

9.4.9 Dummy Assembly


If a connection is not complete, a Dummy Assembly is used to complete the connection.

Three assemblies are always used for a connection: Input Assembly, Output Assembly and Configuration Assembly. If a connection only consists of two assemblies, an additional Dummy Assembly is used to complete the connection.

Dummy Configuration Assembly (Assem105) 0 byte

 Dummy Configuration Assembly (Assem105) is supported by devices with Device Revision 4.

Dummy Output Assembly Fix (Assem199) 0 byte

 Dummy Output Assembly Fix (Assem199) is supported by devices with Device Revision 4.

9.4.10 Units

Volume flow units

2077	cm ³ /s	2095	hl/h	5128	gal/s (us)	2070	bbl/h (us;tank)
2076	cm ³ /min	2094	hl/d	5129	gal/min (us)	2069	bbl/d (us;tank)
2075	cm ³ /h	2135	l/s	5130	gal/h (us)	2107	gal/s (imp)
2074	cm ³ /d	2134	l/min	2087	gal/d (us)	2106	gal/min (imp)
2082	dm ³ /s	2133	l/h	2125	Mgal/s (us)	2105	gal/h (imp)
2081	dm ³ /min	2132	l/d	2124	Mgal/min (us)	2104	gal/d (imp)
2080	dm ³ /h	2052	af/s	2123	Mgal/h (us)	2130	Mgal/s (imp)
2079	dm ³ /d	2051	af/min	2122	Mgal/d (us)	2129	Mgal/min (imp)
5125	m ³ /s	2050	af/h	2063	bbl/s (us;liq.)	2128	Mgal/h (imp)
2086	m ³ /min	2049	af/d	2062	bbl/min (us;liq.)	2127	Mgal/d (imp)
2085	m ³ /h	2254	ft ³ /s	2061	bbl/h (us;liq.)	2304	bbl/s (imp;beer)
2084	m ³ /d	5122	ft ³ /min	2060	bbl/d (us;liq.)	2305	bbl/min (imp;beer)
5127	ml/s	2253	ft ³ /h	2058	bbl/s (us;beer)	2306	bbl/h (imp;beer)
5137	ml/min	2252	ft ³ /d	2057	bbl/min (us;beer)	2307	bbl/d (imp;beer)
5138	ml/h	2370	MMft ³ /s	2056	bbl/h (us;beer)	2102	bbl/s (imp;oil)
2143	ml/d	2369	MMft ³ /min	2055	bbl/d (us;beer)	2101	bbl/min (imp;oil)
5126	l/s	2368	MMft ³ /h	2067	bbl/s (us;oil)	2100	bbl/h (imp;oil)
5139	l/min	2366	MMft ³ /d	2066	bbl/min (us;oil)	2099	bbl/d (imp;oil)
5140	l/h	2164	fl oz/s (us)	2065	bbl/h (us;oil)	2302	kgal/s (us)
2120	l/d	2163	fl oz/min (us)	2064	bbl/d (us;oil)	2301	kgal/min (us)
2097	hl/s	2162	fl oz/h (us)	2072	bbl/s (us;tank)	2300	kgal/h (us)
2096	hl/min	2161	fl oz/d (us)	2071	bbl/min (us;tank)	2299	kgal/d (us)

Corrected volume flow units

2156	NI/s	2148	Nm ³ /d	2196	Sft ³ /h	2213	Sbbl/min (us;liq.)
2155	NI/min	2208	SI/s	2195	Sft ³ /d	2212	Sbbl/h (us;liq.)
2154	NI/h	5121	SI/min	2354	MMSft ³ /s	2211	Sbbl/d (us;liq.)
2153	NI/d	2207	SI/h	2353	MMSft ³ /min	2193	Sgal/s (imp)
2365	Nhl/s	2206	SI/d	2352	MMSft ³ /h	2192	Sgal/min (imp)
2364	Nhl/min	2203	Sm ³ /s	2351	MMSft ³ /d	2191	Sgal/h (imp)
2363	Nhl/h	2202	Sm ³ /min	2219	Sgal/s (us)	2190	Sgal/d (imp)
2362	Nhl/d	2201	Sm ³ /h	2218	Sgal/min (us)	2360	Sbbl/s (us;oil)
2151	Nm ³ /s	2200	Sm ³ /d	2217	Sgal/h (us)	2359	Sbbl/min (us;oil)
2150	Nm ³ /min	2198	Sft ³ /s	2216	Sgal/d (us)	2358	Sbbl/h (us;oil)
2149	Nm ³ /h	2197	Sft ³ /min	2214	Sbbl/s (us;liq.)	2357	Sbbl/d (us;oil)

Volume units

2073	cm ³	2131	MI Mega	2298	kgal (us)	2103	gal (imp)
2078	dcm ³	2048	af	2121	Mgal (us)	2126	Mgal (imp)
11777	m ³	11782	ft ³	11788	bbl (us;oil)	2303	bbl (imp;beer)
11779	ml	2367	MMft ³	2059	bbl (us;liq.)	2098	bbl (imp;oil)
11778	l	11787	fl oz (us)	2054	bbl (us;beer)		
2093	hl	11784	gal (us)	2068	bbl (us;tank)		

Corrected volume units

2152	NI	2205	SI	2350	MMSft ³	2356	Sbbl (us;oil)
2361	Mhl	2199	Sm ³	2215	Sgal (us)	2189	Sgal (imp)
2147	Nm ³	2194	Sft ³	2210	Sbbl (us;liq.)		

Mass flow units

5133	lb/h	2188	STon/s	2186	STon/h		
2177	lb/d	2187	STon/min	2185	STon/d		

Mass units

9473	g	9475	t	9477	lb		
9472	kg	9476	oz	9478	STon		

Density units

12040	g/cm ³	2204	SD4°C	2227	SG20°C	2175	lb/bbl (us;oil)
2088	g/m ³	2277	SD15°C	12044	lb/ft ³	2176	lb/bbl (us;tank)
12048	kg/l	2230	SD20°C	12043	lb/gal (us)	2180	lb/gal (imp)
2109	kg/dm ³	2228	SG4°C	2174	lb/bbl (us;liq.)	2178	lb/gal (imp/beer)
12039	kg/m ³	2226	SG15°C	2173	lb/bbl (us;beer)	2179	lb/gal (imp/oil)

Conductivity units

2271	nS/cm	2267	μS/mm	2275	S/cm	2263	MS/m
2265	μS/cm	2269	mS/cm	2276	S/m		
2266	μS/m	2270	mS/m	2262	kS/m		

Temperature units

4608	°C	4609	°F	4610	K	4611	°R
------	----	------	----	------	---	------	----

9.5 System integration following device/transmitter replacement

i Only concerns the replacement of devices or transmitters with Device Revision 2 with a device or transmitter with Device Revision 4.

The replacement of a device/transmitter with Device Revision 2 (Firmware Version 01.00.zz or 01.01.zz) with a device/transmitter with Device Revision 4 (Firmware Version from 02.00.zz) affects the compatibility of the data transmission:

- Implicit data transmission is also compatible following a device/transmitter replacement. The values are transmitted between the device and controller without restrictions and the existing assemblies continue to be used automatically.
- Explicit data transmission (using Class Instance Attribute addresses) is no longer compatible. The new device must be integrated into the controller manually.

Overview of compatibility in the event of a firmware version update

Firmware update		Compatibility during data transmission	
from version	to version	Implicit (cyclic)	Explicit (acyclic)
01.00.zz	01.01.zz	Compatible	Compatible
01.00.zz	From 02.00.zz	Compatible ¹⁾	Not compatible
01.01.zz	From 02.00.zz	Compatible ¹⁾	Not compatible

1) Compatible with connections 1 to 8 →  88


Due to the incompatibility of explicit data transmission, a series of steps must be performed manually to integrate the new device/transmitter into a programmable logic controller (PLC). A variety of options are available for this purpose, and differ depending on the PLC vendor:

- Integration with Premium Driver AOP (add-on profile):
Rockwell Automation
- Integration with Electronic Data Sheet (EDS):
Rockwell Automation, Schneider Electric, ABB, OMRON, BOSCH, Emerson etc.

i Before the new device/transmitter is integrated into a controller, the device must be updated to the latest firmware version (as of 02.yy.zz): please contact your Endress+Hauser service organization.


9.5.1 Integration with Premium Driver AOP (add-on profile)

- i** ▪ Integration with the Premium Driver AOP (add-on profile) is only possible for controllers made by Rockwell Automation.
- Update the firmware version of the device prior to integration.


1. Download the Premium Driver AOP (add-on profile) from the Endress+Hauser website to the programmable logic controller: www.endress.com → Downloads
2. Install the Premium Driver AOP (add-on profile).
3. Select the new device.
4. Integrate and configure the device: The input/output data and the device configuration (assemblies) are grouped into connections in various constellations and can be configured for digital transmission depending on the application →  87.

9.5.2 Integration with Electronic Data Sheet (EDS)


Provider: Rockwell Automation

-  ■ If integrating with the Premium Driver AOP (add-on profile), it is not necessary to additionally load the Electronic Data Sheet (EDS) →  102.
- Update the firmware version of the device prior to integration.



The Electronic Data Sheet (EDS) can be loaded directly from the device using RSLinx. RSLinx is Rockwell Automation's EtherNet/IP network scanner.

1. Run a device scan with RSLinx.
2. Select the new device from the list of results.
 - ↳ A pop-up window opens.
3. Select the Electronic Data Sheet (EDS).
4. Load the Electronic Data Sheet (EDS) from the device to the programmable logic controller.
5. Integrate and configure the device: The input/output data and the device configuration (assembly) are grouped into connections in various constellations and can be configured for digital transmission depending on the application →  87.


Provider: Schneider Electric, ABB, OMRON, BOSCH, Emerson etc.

-  ■ The Electronic Data Sheet (EDS) can be loaded directly from the device or from the Endress+Hauser website.
- Update the firmware version of the device prior to integration.

Loading the Electronic Data Sheet (EDS) directly from the device



1. Connect the computer with a web browser to the device via the RJ45 interface.
2. Open the integrated web server →  74.
3. Log in as maintenance: Maintenance Code 0000
4. Upload the Electronic Data Sheet (EDS) to the programmable logic controller via: Data management → Documents → Export EDS file
5. Integrate and configure the device: The input/output data and the device configuration (assemblies) are grouped into connections in various constellations and can be configured for digital transmission depending on the application →  87.

Loading the Electronic Data Sheet (EDS) from the Endress+Hauser website

1. Load the suitable Electronic Data Sheet (EDS) for the firmware version (e.g. 02.00.zz) from the Endress+Hauser website to the programmable logic controller:
www.endress.com → Downloads
2. Integrate and configure the device: The input/output data and the device configuration (assemblies) are grouped into connections in various constellations and can be configured for digital transmission depending on the application →  87.

9.6 Diagnostics via EtherNet/IP

9.6.1 Diagnostic information (Assem100)

 For additional information on diagnostics and troubleshooting, including the remedial measures for the individual diagnostics codes, see →  152.

Diagnostic number: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required (Namur NE107)



Current diagnostics information	Diagnostic number	Description
0	–	Device ok
16777265	F882	Input signal
16777276	F281	Electronic initialization
16777312	F437	Configuration incompatible
16777319	F242	Software incompatible
16777323	F252	Modules incompatible
16777337	F272	Main electronic failure
16777340	F270	Main electronic failure
16777341	F271	Main electronic failure
16777343	F270	Main electronic failure
16777344	F270	Main electronic failure
16777355	F410	Data transfer
16777368	F273	Main electronic failure
16777375	F270	Main electronic failure
16777376	F083	Memory content
16777409	F833	Electronic temperature too low
16777411	F832	Electronic temperature too high
16777413	F834	Process temperature too high
16777414	F835	Process temperature too low
16777429	F022	Sensor temperature
16777430	F022	Sensor temperature
16777441	F311	Electronic failure
16777445	F273	Main electronic failure
16777447	F082	Data storage
16777450	F190	Special event 1
16777483	F273	Main electronic failure
16777490	F390	Special event 2
16777497	F222	Electronic drift
16777500	F062	Sensor connection
16777508	F590	Special event 3
16777509	F990	Special event 4
16777545	F262	Module connection
16777546	F537	Configuration
16777547	F201	Device failure
16777563	F500	Electrode 1 potential exceeded

Current diagnostics information	Diagnostic number	Description
16777564	F500	Electrode 2 potential exceeded
16777565	F500	Electrode difference voltage too high
16777581	F382	Data storage
16777582	F383	Memory content
16777583	F283	Memory content
25165873	F882	Input signal
25165884	F281	Electronic initialization
25165920	F437	Configuration incompatible
25165927	F242	Software incompatible
25165931	F252	Modules incompatible
25165945	F272	Main electronic failure
25165948	F270	Main electronic failure
25165949	F271	Main electronic failure
25165963	F410	Data transfer
25165976	F273	Main electronic failure
25165984	F083	Memory content
25166017	F833	Electronic temperature too low
25166019	F832	Electronic temperature too high
25166021	F834	Process temperature too high
25166022	F835	Process temperature too low
25166037	F022	Sensor temperature
25166049	F311	Electronic failure
25166055	F082	Data storage
25166058	F190	Special event 1
25166098	F390	Special event 2
25166105	F222	Electronic drift
25166108	F062	Sensor connection
25166116	F590	Special event 3
25166117	F990	Special event 4
25166153	F262	Module connection
25166154	F537	Configuration
25166155	F201	Device failure
25166171	F500	Electrode 1 potential exceeded
25166189	F382	Data storage
25166190	F383	Memory content
25166191	F283	Memory content
33554536	C411	Up-/download active
33554537	C411	Up-/download active
33554540	C411	Up-/download active
33554576	C484	Failure mode simulation
33554579	C485	Process value simulation
33554580	C453	Flow override

Current diagnostics information	Diagnostic number	Description
33554625	C833	Electronic temperature too low
33554627	C832	Electronic temperature too high
33554629	C834	Process temperature too high
33554630	C835	Process temperature too low
33554778	C530	Electrode cleaning is running
33554782	C495	Diagnostic event simulation
33554926	C302	Device verification active
41943144	C411	Up-/download active
41943184	C484	Failure mode simulation
41943187	C485	Process value simulation
41943188	C453	Flow override
41943233	C833	Electronic temperature too low
41943235	C832	Electronic temperature too high
41943237	C834	Process temperature too high
41943238	C835	Process temperature too low
41943386	C530	Electrode cleaning is running
41943390	C495	Diagnostic event simulation
41943534	C302	Device verification active
67108970	M438	Dataset
67109057	M833	Electronic temperature too low
67109059	M832	Electronic temperature too high
67109061	M834	Process temperature too high
67109062	M835	Process temperature too low
67109090	M311	Electronic failure
75497578	M438	Dataset
75497665	M833	Electronic temperature too low
75497667	M832	Electronic temperature too high
75497669	M834	Process temperature too high
75497670	M835	Process temperature too low
134217873	S842	Process limit
134217874	S862	Pipe empty
134217921	S833	Electronic temperature too low
134217923	S832	Electronic temperature too high
134217925	S834	Process temperature too high
134217926	S835	Process temperature too low
134218011	S937	EMC interference
134218013	S004	Sensor
134218067	S043	Sensor short circuit
134218068	S937	EMC interference
134218071	S322	Electronic drift
134218072	S322	Electronic drift
134218091	S531	Empty pipe detection
142606481	S842	Process limit

Current diagnostics information	Diagnostic number	Description
142606482	S862	Pipe empty
142606529	S833	Electronic temperature too low
142606531	S832	Electronic temperature too high
142606533	S834	Process temperature too high
142606534	S835	Process temperature too low
142606619	S937	EMC interference
142606621	S004	Sensor
142606675	S043	Sensor short circuit
142606679	S322	Electronic drift
142606699	S531	Empty pipe detection
268435545	I1089	Power on
268435546	I1090	Configuration reset
268435547	I1091	Configuration changed
268435548	I1092	Trend data deleted
268435566	I1110	Write protection switch changed
268435593	I1137	Electronic changed
268435607	I1151	History reset
268435611	I1155	Reset electronic temperature
268435612	I1156	Memory error trend
268435613	I1157	Memory error event list
268435641	I1185	Display backup done
268435642	I1186	Restore via display done
268435643	I1187	Settings downloaded with display
268435644	I1188	Display data cleared
268435645	I1189	Backup compared
268435712	I1256	Display: access status changed
268435791	I1335	Firmware changed
268435807	I1351	Empty pipe detection adjustment failure
268435809	I1353	Empty pipe detection adjustment Ok
268435817	I1361	Wrong web server login
268435853	I1397	Fieldbus: access status changed
268435854	I1398	CDI: access status changed
268435900	I1444	Device verification passed
268435901	I1445	Device verification failed
268435913	I1457	Failed: Measured error verification
268435915	I1459	Failed: I/O module verification
268435917	I1461	Failed: Sensor verification
268435918	I1462	Failed: Sensor electronic module verific.

9.6.2 Diagnostic information (Assem120, 121, 126, 127)

 For additional information on diagnostics and troubleshooting, including the remedial measures for the individual diagnostics codes, see →  152.

Diagnostic number: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required (Namur NE107)

Current diagnostics information	Diagnostic number	Description
0	–	Device ok
65579	F043	Sensor short circuit
65618	F082	Memory
65619	F083	Memory content
65706	F170	Coil resistance
65716	F180	Temperature sensor defective
65717	F181	Sensor connection
65737	F201	Device fault
65778	F242	Software incompatible
65788	F252	Modules incompatible
65798	F262	Sensor electronic connection faulty
65806	F270	Main electronics failure
65807	F271	Main electronics failure
65808	F272	Main electronics failure
65809	F273	Main electronics failure
65811	F275	I/O module 1 defective
65812	F276	I/O module 1 faulty
65819	F283	Memory content
65867	F331	Firmware update failed
65868	F332	Writing to HistoROM backup failed
65897	F361	I/O module 1 faulty
65908	F372	Sensor electronics (ISEM) faulty
65909	F373	Sensor electronics (ISEM) faulty
65911	F375	I/O 1 communication failed
65912	F376	Sensor electronics (ISEM) faulty
65913	F377	Sensor electronics (ISEM) faulty
65918	F382	Memory
65919	F383	Memory content
65923	F387	HistoROM backup failed
65946	F410	Data transmission
65973	F437	Incompatible configuration
66048	F512	Sensor electronics (ISEM) faulty
66056	F520	I/O 1 hardware configuration invalid
66067	F531	Empty pipe adjustment faulty
66073	F537	Configuration
66339	F803	Current loop
66368	F832	Electronic temperature too high

Current diagnostics information	Diagnostic number	Description
66369	F833	Electronic temperature too low
66370	F834	Process temperature too high
66371	F835	Process temperature too low
66418	F882	Input signal
66473	F937	Sensor symmetry
66474	F938	EMC interference
66498	F962	Empty pipe
131115	C043	Sensor short circuit
131374	C302	Device verification active
131448	C376	Sensor electronics (ISEM) faulty
131449	C377	Sensor electronics (ISEM) faulty
131484	C412	Processing download
131503	C431	Trim 1
131525	C453	Flow override
131556	C484	Simulation failure mode
131557	C485	Measured variable simulation
131558	C486	Current input 1 simulation
131563	C491	Current output 1 simulation
131564	C492	Simulation frequency output 1
131565	C493	Simulation pulse output 1
131566	C494	Switch output simulation 1
131567	C495	Diagnostic event simulation
131568	C496	Simulation status input
131583	C511	ISEM settings faulty
131602	C530	Electrode cleaning is running
131603	C531	Empty pipe adjustment faulty
131666	C594	Relay output simulation
131904	C832	Electronic temperature too high
131905	C833	Electronic temperature too low
131906	C834	Process temperature too high
131907	C835	Process temperature too low
132009	C937	Sensor symmetry
132010	C938	EMC interference
132034	C962	Empty pipe
262187	M043	Sensor short circuit
262313	M169	Conductivity measurement failed
262447	M303	I/O 1 configuration changed
262455	M311	Electronics error
262474	M330	Flash file invalid
262520	M376	Sensor electronics (ISEM) faulty
262521	M377	Sensor electronics (ISEM) faulty
262582	M438	Dataset
262675	M531	Empty pipe adjustment faulty

Current diagnostics information	Diagnostic number	Description
262976	M832	Electronic temperature too high
262977	M833	Electronic temperature too low
262978	M834	Process temperature too high
262979	M835	Process temperature too low
263081	M937	Sensor symmetry
263082	M938	EMC interference
263106	M962	Empty pipe
524331	S043	Sensor short circuit
524664	S376	Sensor electronics (ISEM) faulty
524665	S377	Sensor electronics (ISEM) faulty
524729	S441	Current output 1
524730	S442	Frequency output 1
524731	S443	Pulse output 1
524732	S444	Current input 1
524819	S531	Empty pipe adjustment faulty
525120	M832	Electronic temperature too high
525121	M833	Electronic temperature too low
525122	M834	Process temperature too high
525123	M835	Process temperature too low
525130	S842	Process limit
525225	S937	Sensor symmetry
525226	S938	EMC interference
525249	S961	Electrode potential out of specification
525250	S962	Empty pipe
16843027	F275	I/O module 2 defective
16843028	F276	I/O module 2 faulty
16843113	F361	I/O module 2 faulty
16843127	F375	I/O 2 communication failed
16843272	F520	I/O 2 hardware configuration invalid
16908719	C431	Trim 2
16908774	C486	Current input 2 simulation
16908779	C491	Current output 2 simulation
16908780	C492	Simulation frequency output 2
16908781	C493	Simulation pulse output 2
16908782	C494	Switch output simulation 2
16908784	C496	Simulation status input
16908882	C594	Relay output simulation
17039663	M303	I/O 2 configuration changed
17301945	S441	Current output 2
17301946	S442	Frequency output 2
17301947	S443	Pulse output 2

Current diagnostics information	Diagnostic number	Description
17301948	S444	Current input 2
33620243	F275	I/O module 3 defective
33620244	F276	I/O module 3 faulty
33620329	F361	I/O module 3 faulty
33620343	F375	I/O 3 communication failed
33620488	F520	I/O 3 hardware configuration invalid
33685935	C431	Trim 3
33685990	C486	Current input 3 simulation
33685995	C491	Current output 3 simulation
33685996	C492	Simulation frequency output 3
33685997	C493	Simulation pulse output 3
33685998	C494	Switch output simulation 3
33686000	C496	Simulation status input
33686098	C594	Relay output simulation
33816879	M303	I/O 3 configuration changed
34079161	S441	Current output 3
34079162	S442	Frequency output 3
34079163	S443	Pulse output 3
34079164	S444	Current input 3
50397459	F275	I/O module 4 defective
50397460	F276	I/O module 4 faulty
50397545	F361	I/O module 4 faulty
50397559	F375	I/O 4 communication failed
50397704	F520	I/O 4 hardware configuration invalid
50594095	M303	I/O 4 configuration changed

9.6.3 Information events



Information events	Diagnostic code		Description
268435545	I	1089	Power on
268435546	I	1090	Configuration reset
268435547	I	1091	Configuration changed
268435548	I	1092	Trend data deleted
268435566	I	1110	Write protection switch changed
268435593	I	1137	Electronic changed
268435607	I	1151	History reset
268435611	I	1155	Reset electronic temperature
268435612	I	1156	Memory error trend
268435613	I	1157	Memory error event list
268435641	I	1185	Display backup done
268435642	I	1186	Restore via display done
268435643	I	1187	Settings downloaded with display

Information events	Diagnostic code		Description
268435644	I	1188	Display data cleared
268435645	I	1189	Backup compared
268435712	I	1256	Display: access status changed
268435791	I	1335	Firmware changed
268435807	I	1351	Empty pipe detection adjustment failure
268435809	I	1353	Empty pipe detection adjustment Ok
268435817	I	1361	Wrong web server login
268435853	I	1397	Fieldbus: access status changed
268435854	I	1398	CDI: access status changed
268435900	I	1444	Device verification passed
268435901	I	1445	Device verification failed
268435913	I	1457	Failed: Measured error verification
268435915	I	1459	Failed: I/O module verification
268435917	I	1461	Failed: Sensor verification
268435918	I	1462	Failed: Sensor electronic module verific. Sensor electr.

10 Commissioning



10.1 Function check

Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist →  40
- "Post-connection check" checklist →  58


10.2 Switching on the measuring device

- ▶ After a successful function check, switch on the measuring device.
 - ↳ After a successful startup, the local display switches automatically from the startup display to the operational display.



 If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" →  143.

10.3 Configuring the device address via software

10.3.1 Ethernet network and web server


The DHCP client functionality is enabled ex works and the IP address, subnet mask and default gateway are set automatically →  117.

Identification is via the MAC address of the device.

- 
 - If hardware addressing is active, software addressing is disabled.
 - If a switch is made to hardware addressing, the address configured via software addressing is retained for the first 9 places (the first three octets).
 - If the IP address of the device is not known, the device address currently configured can be read out →  136.

10.4 Setting the operating language


Factory setting: English or ordered local language



18 Taking the example of the local display

10.5 Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the **Setup** menu



19 Taking the example of the local display

Navigation
"Setup" menu

⚙ Setup

Device tag

→ 📄 115

▶ System units

→ 📄 116

▶ Communication

→ 📄 117

▶ Display

→ 📄 118

▶ Low flow cut off

→ 📄 120

▶ Empty pipe detection


→ 📄 121

▶ Advanced setup

→ 📄 122

10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



20 Header of the operational display with tag name

1 Tag name

 Enter the tag name in the "FieldCare" operating tool → 📄 84


Navigation
"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag 400








10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

 The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

Navigation

"Setup" menu → System units

► System units		
Volume flow unit	→ 	116
Volume unit	→ 	116
Conductivity unit	→ 	116
Temperature unit	→ 	116
Mass flow unit	→ 	117
Mass unit	→ 	117
Density unit	→ 	117

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	–	Select volume flow unit. <i>Effect</i> The selected unit applies for: ▪ Output ▪ Low flow cut off ▪ Simulation process variable	Unit choose list	Country-specific: ▪ l/h ▪ gal/min (us)
Volume unit	–	Select volume unit.	Unit choose list	Country-specific: ▪ m ³ ▪ gal (us)
Conductivity unit	The On option is selected in the Conductivity measurement parameter.	Select conductivity unit. <i>Effect</i> The selected unit applies for: Simulation process variable	Unit choose list	µS/cm
Temperature unit	–	Select temperature unit. <i>Effect</i> The selected unit applies for: ▪ Maximum value parameter ▪ Minimum value parameter	Unit choose list	Country-specific: ▪ °C ▪ °F

Parameter	Prerequisite	Description	Selection	Factory setting
Mass flow unit	–	Select mass flow unit. <i>Effect</i> The selected unit applies for: ▪ Output ▪ Low flow cut off ▪ Simulation process variable	Unit choose list	Country-specific: ▪ kg/h ▪ lb/min
Mass unit	–	Select mass unit.	Unit choose list	Country-specific: ▪ kg ▪ lb
Density unit	–	Select density unit. <i>Effect</i> The selected unit applies for: ▪ Output ▪ Simulation process variable	Unit choose list	Country-specific: ▪ kg/l ▪ lb/ft ³

10.5.3 Configuring the communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication

► Communication

MAC address

→ ⓘ 117

Hardware address mode

→ ⓘ 117

DHCP client

→ ⓘ 118

IP address

→ ⓘ 118


Subnet mask


→ ⓘ 118

Default gateway

→ ⓘ 118

Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry	Factory setting
MAC address	Displays the MAC address of the measuring device.  MAC = Media Access Control	Unique 12-digit character string comprising letters and numbers, e.g.: 00:07:05:10:01:5F	Each measuring device is given an individual address.
Hardware address mode	Select whether to restore network settings.	▪ Off ▪ On	Off

Parameter	Description	User interface / Selection / User entry	Factory setting
DHCP client	<p>Select to activate/deactivate DHCP client functionality.</p> <p>Effect</p> <p>If the DHCP client functionality of the web server is selected, the IP address, Subnet mask and Default gateway are set automatically.</p> <p> Identification is via the MAC address of the measuring device.</p> <ul style="list-style-type: none">▪ The IP address in the IP address parameter is ignored as long as the DHCP client parameter is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address in the parameter of the same name is only used if the DHCP client parameter is inactive.	<ul style="list-style-type: none">▪ Off▪ On	On
IP address	<p>IP address of the Web server integrated in the measuring device.</p> <p>If the DHCP client is switched off and write access is enabled, the IP address can also be entered.</p>	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	<p>Displays the subnet mask.</p> <p>If the DHCP client is switched off and write access is enabled, the Subnet mask can also be entered.</p>	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	<p>Displays the default gateway.</p> <p>If the DHCP client is switched off and write access is enabled, the Default gateway can also be entered.</p>	4 octet: 0 to 255 (in the particular octet)	0.0.0.0

10.5.4 **Configuring the local display**

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu → Display

► Display

Format display

→ ⓘ 119

Value 1 display

→ ⓘ 119

0% bargraph value 1

→ ⓘ 119

100% bargraph value 1




→ ⓘ 119

Value 2 display



→ ⓘ 119


Value 3 display

→ ⓘ 119

0% bargraph value 3	→  119
100% bargraph value 3	→  120
Value 4 display	→  120

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity* ■ Conductivity* ■ Corrected conductivity* ■ Electronics temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Noise* ■ Coil current shot time* ■ Reference electrode potential against PE* ■ Build-up index* ■ Test point 1 ■ Test point 2 ■ Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→  119)	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→  119)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bargraph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→  119)	None





* Visibility depends on order options or device settings

10.5.5 Configuring the low flow cut off




The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

Navigation


"Setup" menu → Low flow cut off

► Low flow cut off	
Assign process variable	→  120
On value low flow cutoff	→  120
Off value low flow cutoff	→  120
Pressure shock suppression	→  120

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	–	Select process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow 	Volume flow
On value low flow cutoff	A process variable is selected in the Assign process variable parameter (→  120).	Enter on value for low flow cut off.	Positive floating-point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter (→  120).	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	A process variable is selected in the Assign process variable parameter (→  120).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s






10.5.6 Configuring empty pipe detection

-  The measuring devices are calibrated with water (approx. 500 µS/cm) at the factory. For liquids with a lower conductivity, it is advisable to perform a new full pipe adjustment onsite.
- It is recommended to perform a new empty pipe adjustment onsite if a cable longer than 50 meters is used.


The **Empty pipe detection** wizard guides you systematically through all the parameters that have to be set for configuring empty pipe detection.

Navigation

"Setup" menu → Empty pipe detection

► Empty pipe detection		
Assign process variable	→ 	121
New adjustment	→ 	121
Progress	→ 	121
Switch point empty pipe detection	→ 	121
Response time empty pipe detection	→ 	121


Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Assign process variable	–	Switch empty pipe detection on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
New adjustment	The On option is selected in the Empty pipe detection parameter.	Select type of adjustment.	<ul style="list-style-type: none"> ■ Cancel ■ Empty pipe adjust ■ Full pipe adjust 	Cancel
Progress	The On option is selected in the Empty pipe detection parameter.	Shows the progress.	<ul style="list-style-type: none"> ■ Ok ■ Busy ■ Not ok 	–
Switch point empty pipe detection	The On option is selected in the Empty pipe detection parameter.	Enter hysteresis in %, below this value the measuring tube will detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	A process variable is selected in the Assign process variable parameter (→  121).	Enter the time before diagnostic message S862 'Pipe empty' is displayed for empty pipe detection.	0 to 100 s	1 s

10.6 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu



i The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

Navigation

"Setup" menu → Advanced setup

► Advanced setup	
Enter access code	→ 123
► Sensor adjustment	→ 123
► Totalizer 1 to n	→ 123
► Display	→ 125

▶ Electrode cleaning cycle	→ 128
▶ WLAN settings	→ 128
▶ Heartbeat setup	
▶ Administration	→ 130

10.6.1 Using the parameter to enter the access code

Navigation
"Setup" menu → Advanced setup

Parameter overview with brief description

Parameter	Description	User entry
Enter access code	Enter access code to disable write protection of parameters.	Max. 16-digit character string comprising numbers, letters and special characters

10.6.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation
"Setup" menu → Advanced setup → Sensor adjustment

▶ Sensor adjustment	
Installation direction	→ 123

Parameter overview with brief description




Parameter	Description	Selection	Factory setting
Installation direction	Select sign of flow direction.	■ Forward flow ■ Reverse flow	Forward flow

10.6.3 Configuring the totalizer




In the **"Totalizer 1 to n"** submenu the individual totalizer can be configured.

Navigation
"Setup" menu → Advanced setup → Totalizer 1 to n

▶ Totalizer 1 to n	
Assign process variable	→ 124

Unit totalizer 1 to n	→  124
Totalizer operation mode	→  124
Failure mode	→  124

Parameter overview with brief description





















Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	–	Select process variable for totalizer.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow 	Volume flow
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu.	Select the unit for the process variable of the totalizer.	Unit choose list	Country-specific: <ul style="list-style-type: none"> ■ l ■ gal (us)
Totalizer operation mode	A process variable is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	<ul style="list-style-type: none"> ■ Net flow total ■ Forward flow total ■ Reverse flow total 	Net flow total
Failure mode	A process variable is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu.	Select totalizer behavior in the event of a device alarm.	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value 	Stop

10.6.4 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu → Advanced setup → Display

► Display		
Format display	→ 	126
Value 1 display	→ 	126
0% bargraph value 1	→ 	126
100% bargraph value 1	→ 	126
Decimal places 1	→ 	126
Value 2 display	→ 	126
Decimal places 2	→ 	126
Value 3 display	→ 	126
0% bargraph value 3	→ 	126
100% bargraph value 3	→ 	126
Decimal places 3	→ 	127
Value 4 display	→ 	127
Decimal places 4	→ 	127
Display language	→ 	127
Display interval	→ 	127
Display damping	→ 	127
Header	→ 	127
Header text	→ 	127
Separator	→ 	127
Backlight	→ 	127

Parameter overview with brief description


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity* ■ Corrected conductivity* ■ Electronics temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Noise* ■ Coil current shot time* ■ Reference electrode potential against PE* ■ Build-up index* ■ Test point 1 ■ Test point 2 ■ Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is defined in the Value 1 display parameter.	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 119)	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 119)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter (→ 119)	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Display language	A local display is provided.	Set display language.	<ul style="list-style-type: none"> ■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ العربية (Arabic) * ■ Bahasa Indonesia ■ ภาษาไทย (Thai) * ■ tiếng Việt (Vietnamese) ■ čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	<ul style="list-style-type: none"> ■ Device tag ■ Free text 	Device tag
Header text	In the Header parameter, the Free text option is selected.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	-----
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	<ul style="list-style-type: none"> ■ . (point) ■ , (comma) 	. (point)
Backlight	A local display is provided.	Switch the local display backlight on and off.	<ul style="list-style-type: none"> ■ Disable ■ Enable 	Enable

* Visibility depends on order options or device settings

10.6.5 Performing electrode cleaning

The **Electrode cleaning circuit** wizard guides the user systematically through all the parameters that have to be set for configuring electrode cleaning.


 The wizard only appears if the device was ordered with an electrode cleaning circuit.

Navigation


"Setup" menu → Advanced setup → Electrode cleaning cycle

▶ Electrode cleaning cycle


Electrode cleaning cycle

→  128


ECC duration

→  128


ECC recovery time

→  128

ECC interval

→  128

ECC polarity

→  128
















Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning cycle	For the following order code: "Application package", option EC "ECC electrode cleaning"	Switch electrode cleaning on or off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
ECC duration	For the following order code: "Application package", option EC "ECC electrode cleaning"	Enter the duration of the electrode cleaning cycle.	0.01 to 30 s	2 s
ECC recovery time	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the recovery time after electrode cleaning to prevent interference. The output signal values will be frozen for the duration of the recovery.	1 to 600 s	5 s
ECC interval	For the following order code: "Application package", option EC "ECC electrode cleaning"	Enter the pause duration between electrode cleaning cycles.	0.5 to 168 h	0.7 h
ECC polarity	For the following order code: "Application package", option EC "ECC electrode cleaning"	Select the polarity of the electrode cleaning circuit.	<ul style="list-style-type: none"> ■ Positive ■ Negative 	Depends on the electrode material: <ul style="list-style-type: none"> ■ Tantalum: Negative option ■ Platinum, Alloy C22, stainless steel: Positive option

10.6.6 WLAN configuration



The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation
"Setup" menu → Advanced setup → WLAN settings

► WLAN settings		
WLAN	→ 	129
WLAN mode	→ 	129
SSID name	→ 	129
Network security	→ 	130
Security identification	→ 	130
User name	→ 	130
WLAN password	→ 	130
WLAN IP address	→ 	130
WLAN MAC address	→ 	130
WLAN passphrase	→ 	130
WLAN MAC address	→ 	130
Assign SSID name	→ 	130
SSID name	→ 	130
Connection state	→ 	130
Received signal strength	→ 	130

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN	–	Switch WLAN on and off.	<div><div></div> Disable</div> <div><div></div> Enable</div>	Enable
WLAN mode	–	Select WLAN mode.	WLAN access point	WLAN access point
SSID name	The client is activated.	Enter the user-defined SSID name (max. 32 characters).	–	–

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Network security	–	Select the security type of the WLAN network.	<ul style="list-style-type: none"> ■ Unsecured ■ WPA2-PSK ■ EAP-PEAP with MSCHAPv2 * ■ EAP-PEAP MSCHAPv2 no server authentic. * ■ EAP-TLS * 	WPA2-PSK
Security identification	–	Select security settings and download these settings via menu Data management > Security > WLAN.	<ul style="list-style-type: none"> ■ Trusted issuer certificate ■ Device certificate ■ Device private key 	–
User name	–	Enter user name.	–	–
WLAN password	–	Enter WLAN password.	–	–
WLAN IP address	–	Enter IP address of the WLAN interface of the device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters).  The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	Serial number of the measuring device (e.g. L100A802000)
WLAN MAC address	–	Enter MAC address of the WLAN interface of the device.	Unique 12-digit character string comprising letters and numbers	Each measuring device is given an individual address.
Assign SSID name	–	Select which name will be used for SSID: device tag or user-defined name.	<ul style="list-style-type: none"> ■ Device tag ■ User-defined 	User-defined
SSID name	<ul style="list-style-type: none"> ■ The User-defined option is selected in the Assign SSID name parameter. ■ The WLAN access point option is selected in the WLAN mode parameter. 	Enter the user-defined SSID name (max. 32 characters).  The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	
Connection state	–	Displays the connection status.	<ul style="list-style-type: none"> ■ Connected ■ Not connected 	Not connected
Received signal strength	–	Shows the received signal strength.	<ul style="list-style-type: none"> ■ Low ■ Medium ■ High 	High

* Visibility depends on order options or device settings

10.6.7 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu → Advanced setup → Administration

► Administration

► Define access code

► Reset access code

Device reset

→ 131

→ 131

→ 132

Using the parameter to define the access code

Navigation

"Setup" menu → Advanced setup → Administration → Define access code

► Define access code

Define access code

Confirm access code

→ 131

→ 131

Parameter overview with brief description

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code	Confirm the entered access code.	Max. 16-digit character string comprising numbers, letters and special characters

Using the parameter to reset the access code

Navigation

"Setup" menu → Advanced setup → Administration → Reset access code

► Reset access code


Operating time

Reset access code

→ 132

→ 132

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	–
Reset access code	Reset access code to factory settings.  For a reset code, contact your Endress+Hauser service organization. The reset code can only be entered via: <ul style="list-style-type: none"> ▪ Web browser ▪ DeviceCare, FieldCare (via CDI-RJ45 service interface) ▪ Fieldbus 	Character string comprising numbers, letters and special characters	0x00

Using the parameter to reset the device

Navigation

"Setup" menu → Advanced setup → Administration


Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul style="list-style-type: none"> ▪ Cancel ▪ To delivery settings ▪ Restart device ▪ Restore S-DAT backup * 	Cancel

* Visibility depends on order options or device settings






10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

-  The parameters displayed depend on:
- The selected device order
 - The set operating mode of the pulse/frequency/switch outputs

Navigation

"Diagnostics" menu → Simulation

► Simulation	
Assign simulation process variable	→  133
Process variable value	→  133
Device alarm simulation	→  133
Diagnostic event category	→  133
Diagnostic event simulation	→  133

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity* ■ Conductivity* ■ Corrected conductivity* ■ Temperature* 	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter (→ 133).	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Device alarm simulation	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
Diagnostic event category	–	Select a diagnostic event category.	<ul style="list-style-type: none"> ■ Sensor ■ Electronics ■ Configuration ■ Process 	Process
Diagnostic event simulation	–	Select a diagnostic event to simulate this event.	<ul style="list-style-type: none"> ■ Off ■ Diagnostic event picklist (depends on the category selected) 	Off

* Visibility depends on order options or device settings

10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:


- Write protection via access code for the local display and Web browser
- Write protection via write protection switch
- Write protection via keypad lock

10.8.1 Write protection via access code

The effects of the user-specific access code are as follows:




- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.

Defining the access code via local display

1. Navigate to the **Define access code** parameter (→ 131).
2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
3. Enter the access code again in the to confirm the code.
 - ↳ The -symbol appears in front of all write-protected parameters.


The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected

parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.


-  If parameter write protection is activated via an access code, it can also only be deactivated via this access code →  73.
- The user role with which the user is currently logged on via the local display →  73 is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display


Parameters which can always be modified via the local display



Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the Web browser

1. Navigate to the **Define access code** parameter (→  131).
2. Define a max. 16-digit numeric code as an access code.
3. Enter the access code again in the to confirm the code.
 - ↳ The Web browser switches to the login page.

 If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


-  If parameter write protection is activated via an access code, it can also only be deactivated via this access code →  73.
- The user role with which the user is currently logged on via Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling


10.8.2 Write protection via write protection switch


Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via EtherNet/IP protocol



1. Loosen the 4 fixing screws on the housing cover and open the housing cover.
2. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables the hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables the hardware write protection.
 - ↳ If the hardware write protection is enabled: The **Hardware locked** option is displayed in the **Locking status** parameter. In addition, on the local display the  symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled: No option is displayed in the **Locking status** parameter. On the local display, the  symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

3. **WARNING**

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.


- ▶ Tighten the fixing screws as per the tightening torque.

Reverse the removal procedure to reassemble the transmitter.

11 Operation

11.1 Read out and modify current Ethernet settings

If the Ethernet settings such as the IP address of the measuring device are unknown, they can be read out and modified as explained in the following example for an IP address.



A0023058

Prerequisite

- Software addressing is enabled: All the DIP switches for hardware addressing are set to **OFF**.
- Measuring device is switched on.



1. Set the DIP switch for "Default Ethernet network settings, IP 192.168.1.212" from **OFF** → **ON**.
2. Restart the device.
 - ↳ The device's Ethernet settings are reset to their factory settings:
IP address: 192.168.1.212; Subnet mask: 255.255.255.0; Default gateway: 192.168.1.212
3. Enter the default setting for the IP address in the address line of the Web browser.
4. Navigate to **IP address** parameter in the operating menu: Setup → Communication → IP address
 - ↳ The parameter displays the configured IP address.
5. Change the IP address of the device if necessary.
6. Set the DIP switch for "Default Ethernet network settings, IP 192.168.1.212" from **ON** → **OFF**.
7. Restart the device.
 - ↳ The modified IP address of the device is now enabled.

11.2 Reading the device locking status

Device active write protection: **Locking status** parameter

Operation → Locking status



Function scope of the "Locking status" parameter

Options	Description
None	The access status displayed in the Access status display parameter applies →  73. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool) →  134.
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.3 Adjusting the operating language





Detailed information:

- To configure the operating language →  113
- For information on the operating languages supported by the measuring device
→  199

11.4 Configuring the display

Detailed information:



- On the basic settings for the local display →  118
- On the advanced settings for the local display →  125

11.5 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

Navigation

"Diagnostics" menu → Measured values → Output values


► Measured values	
► Process variables	→  137
► Totalizer	→  138



11.5.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.




Navigation

"Diagnostics" menu → Measured values → Process variables

► Process variables	
Volume flow	→  138

Mass flow	→  138
Conductivity	→  138

Parameter overview with brief description



Parameter	Prerequisite	Description	User interface
Volume flow	–	Displays the volume flow that is currently measured. <i>Dependency</i> The unit is taken from the Volume flow unit parameter (→  116).	Signed floating-point number
Mass flow	–	Displays the mass flow that is currently calculated. <i>Dependency</i> The unit is taken from the Mass flow unit parameter (→  117).	Signed floating-point number
Conductivity	The On option is selected in the Conductivity measurement parameter.	Displays the conductivity that is currently measured. <i>Dependency</i> The unit is taken from the Conductivity unit parameter (→  116).	Signed floating-point number

11.5.2 "Totalizer" submenu



The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer



► Totalizer	
Totalizer value 1 to n	→  138
Totalizer overflow 1 to n	→  138

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	One of the following options is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu: <ul style="list-style-type: none"> Volume flow Mass flow Corrected volume flow 	Displays the current totalizer counter reading.	Signed floating-point number
Totalizer overflow 1 to n	One of the following options is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu: <ul style="list-style-type: none"> Volume flow Mass flow Corrected volume flow 	Displays the current totalizer overflow.	Integer with sign

11.6 Adapting the measuring device to the process conditions




The following are available for this purpose:

- Basic settings using the **Setup** menu (→  114)
- Advanced settings using the **Advanced setup** submenu (→  122)





11.7 Performing a totalizer reset

Navigation

"Operation" menu → Totalizer handling

► Totalizer handling	
Control Totalizer 1 to n	→  139
Preset value 1 to n	→  139
Reset all totalizers	→  139

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu.	Control totalizer value.	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold 	Totalize
Preset value 1 to n	A process variable is selected in the Assign process variable parameter (→  124) of the Totalizer 1 to n submenu.	Specify start value for totalizer. <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  124).	Signed floating-point number	0 l
Reset all totalizers	–	Reset all totalizers to 0 and start.	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize 	Cancel

11.7.1 Function scope of the "Control Totalizer" parameter



Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

11.7.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.


11.8 Showing data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.


-  Data logging is also available via:
 - Plant Asset Management Tool FieldCare →  83.
 - Web browser

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

-  If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

► Data logging

Assign channel 1


Assign channel 2


Assign channel 3


Assign channel 4


Logging interval


Clear logging data


→  141






→  141

→  142



→  142





→  142

→  142

Data logging	→  142
Logging delay	→  142
Data logging control	→  142
Data logging status	→  142
Entire logging duration	→  142
► Display channel 1	
► Display channel 2	
► Display channel 3	
► Display channel 4	

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity[*] ■ Corrected conductivity[*] ■ Temperature ■ Electronics temperature ■ Noise[*] ■ Coil current shot time[*] ■ Reference electrode potential against PE[*] ■ Build-up index[*] ■ Test point 1 ■ Test point 2 ■ Test point 3 	Off
Assign channel 2	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the Assign channel 1 parameter (→  141)	Off

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 3	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the Assign channel 1 parameter (→  141)	Off
Assign channel 4	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	For the picklist, see the Assign channel 1 parameter (→  141)	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3 600.0 s	1.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	<ul style="list-style-type: none"> ■ Cancel ■ Clear data 	Cancel
Data logging	–	Select the data logging method.	<ul style="list-style-type: none"> ■ Overwriting ■ Not overwriting 	Overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	<ul style="list-style-type: none"> ■ None ■ Delete + start ■ Stop 	None
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	<ul style="list-style-type: none"> ■ Done ■ Delay active ■ Active ■ Stopped 	Done
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating-point number	0 s

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting


For local display

Error	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage → 49.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	Main electronics module is defective.	Order spare part → 169.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	1. Check the connection of the electrode cable and correct if necessary. 2. Check the connection of the coil current cable and correct if necessary.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul style="list-style-type: none"> Set the display brighter by simultaneously pressing \oplus + \boxplus. Set the display darker by simultaneously pressing \ominus + \boxplus.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 169.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures → 152
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press 2 s \boxminus + \oplus ("home position"). 2. Press \boxplus . 3. Set the desired language in the Display language parameter (→ 127).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul style="list-style-type: none"> Check the cable and the connector between the main electronics module and display module. Order spare part → 169.

For output signals

Error	Possible causes	Solution
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 169.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct the parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data".

For access

Error	Possible causes	Remedial action
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position → 134.
No write access to parameters	Current user role has limited access authorization	1. Check user role → 73. 2. Enter correct customer-specific access code → 73.
No connection via EtherNet/IP	Device plug connected incorrectly	Check the pin assignment of the device plug .
No connection to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary → 80.
	Incorrect settings for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) → 76 → 76. 2. Check the network settings with the IT manager.
No connection to Web server	<ul style="list-style-type: none"> Incorrect IP address IP address is not known 	1. If addressing via hardware: open the transmitter and check the IP address configured (last octet). 2. Check the IP address of the measuring device with the network manager. 3. If the IP address is not known, set DIP switch no. 10 to ON, restart the device and enter the factory IP address 192.168.1.212.  EtherNet/IP communication is interrupted by enabling the DIP switch.
	Web browser setting "Use a Proxy Server for Your LAN" is enabled	Disable the use of the proxy server in the Web browser settings of the computer. Using the example of MS Internet Explorer: 1. Under <i>Control Panel</i> open <i>Internet options</i> . 2. Select the <i>Connections</i> tab and then double-click <i>LAN settings</i> . 3. In the <i>LAN settings</i> disable the use of the proxy server and select <i>OK</i> to confirm.
	Apart from the active network connection to the measuring device, other network connections are also being used.	<ul style="list-style-type: none"> Make sure that no other network connections are established by the computer (also no WLAN) and close other programs with network access on the computer. If using a docking station for notebooks, make sure that a network connection to another network is not active.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	1. Check cable connection and power supply. 2. Refresh the Web browser and restart if necessary.

Error	Possible causes	Remedial action
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	1. Use the correct Web browser version → 74. 2. Clear the Web browser cache and restart the Web browser.
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	<ul style="list-style-type: none"> JavaScript not enabled JavaScript cannot be enabled 	1. Enable JavaScript. 2. Enter http://192.168.1.212/basic.html as the IP address.
Operation with FieldCare or DeviceCare via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/DeviceCare access.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter



Different LEDs in the transmitter provide information on the device status.

LED	Color	Meaning
Supply voltage	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Device status	Green	Device status is ok
	Flashing red	A device error of diagnostic behavior "Warning" has occurred
	Red	A device error of diagnostic behavior "Alarm" has occurred
	Alternately flashing red/green	Boot loader is active
Network status	Off	Device has no EtherNet/IP address
	Green	Device's EtherNet/IP connection is active
	Flashing green	Device has EtherNet/IP address but no EtherNet/IP connection
	Red	EtherNet/IP address of the device has been assigned twice
	Flashing red	Device's EtherNet/IP connection is in timeout mode
Link/Activity	Orange	Link available but no activity
	Flashing orange	Activity present
Alarm	Green	Measuring device is ok
	Flashing green	Measuring device not configured
	Off	Firmware error
	Red	Main error
	Flashing red	Error
	Flashing red/green	Start measuring device




12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.


Operational display in alarm condition	Diagnostic message
	
<p>1 Status signal 2 Diagnostic behavior 3 Diagnostic behavior with diagnostic code 4 Short text 5 Operating elements</p>	

If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

-  Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:
- Via parameter →  161
 - Via submenus →  162



Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

-  The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
C	Function check The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
M	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior



Symbol	Meaning
	Alarm <ul style="list-style-type: none">■ Measurement is interrupted.■ Signal outputs and totalizers assume the defined alarm condition.■ A diagnostic message is generated.■ The background lighting changes to red.
	Warning <p>Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.</p>

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Key	Meaning
	Plus key <p><i>In a menu, submenu</i> Opens the message about remedy information.</p>
	Enter key <p><i>In a menu, submenu</i> Opens the operating menu.</p>

12.3.2 Calling up remedial measures



A0029431-EN

21 Message about remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

1. The user is in the diagnostic message.
Press **+** (ⓘ symbol).
↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with **+** or **-** and press **E**.
↳ The message about the remedial measures opens.
3. Press **-** + **+** simultaneously.
↳ The message about the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or **Previous diagnostics** parameter.

1. Press **E**.
↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press **-** + **+** simultaneously.
↳ The message for the remedial measures closes.

12.4 Diagnostic information in the Web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostics information → 147
- 3 Remedial measures with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 161
- Via submenu → 162

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
	Failure A device error has occurred. The measured value is no longer valid.
	Function check The device is in service mode (e.g. during a simulation).
	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
	Maintenance required Maintenance is required. The measured value is still valid.

i The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.


12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- 1 Status area with status signal → 146
- 2 Diagnostics information → 147
- 3 Remedial measures with service ID

i In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter → 161
- Via submenu → 162

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:


- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.



The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
↳ A tool tip with remedy information for the diagnostic event appears.

12.6 Diagnostic information via communication interface

12.6.1 Reading out diagnostic information

The current diagnostic event and associated diagnostic information can be read out: **Input Assembly Fix** →  89

Input Fix Assembly byte 1 to 8							
1	2	3	4	5	6	7	8
File header (not visible)				Diagnostic number →  104		Status signal →  89	–

12.7 Adapting the diagnostic information

12.7.1 Adapting the diagnostic behavior


Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.



Expert → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (Event list submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.8 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

 In the case of some items of diagnostic information, the diagnostic behavior can be changed. Adapting the diagnostic information →  151

12.8.1 Diagnostic of sensor

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
043	Sensor short circuit		1. Check sensor cable and sensor 2. Execute Heartbeat Verification 3. Replace sensor cable or sensor	0x8000153
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
082	Data storage		1. Check module connections 2. Change electronic modules	0x10000E7
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
083	Memory content		1. Restart device 2. Restore HistoROM S-DAT backup ('Device reset' parameter) 3. Replace HistoROM S-DAT	0x10000A0
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
168	Build-up limit exceeded		Clean measuring tube	0x40003D0
	Status signal	M		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
169	Conductivity measurement failed		1. Check grounding conditions 2. Deactivate conductivity measurement	0x400038A
	Status signal	M		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
170	Coil resistance		Check ambient and process temperature	<div><div>■ 0x10002D8</div><div>■ 0x10002D9</div></div>
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
180	Temperature sensor defective		1. Check sensor connections 2. Replace sensor cable or sensor 3. Turn off temperature measurement	■ 0x10000D5 ■ 0x10000D6
	Status signal	F		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
181	Sensor connection		1. Check sensor cable and sensor 2. Execute Heartbeat Verification 3. Replace sensor cable or sensor	■ 0x100011C ■ 0x10002E0
	Status signal	F		
	Diagnostic behavior	Alarm		

12.8.2 Diagnostic of electronic

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
201	Device failure		Restart device	0x100014B
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
242	Software incompatible		1. Check software 2. Flash or change main electronic module	0x1000067
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
252	Modules incompatible		1. Check electronic modules 2. Check if correct modules are available (e.g. NEx, Ex) 3. Replace electronic modules	0x100006B
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
252	Modules incompatible		1. Check if correct electronic module is plugged 2. Replace electronic module	0x10002C0
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
262	Sensor electronics connection faulty		1. Check/replace connection cable between sensor electronic module (ISEM) and main electr. 2. Check/replace module cartridge, ISEM, main electr.	0x1000149
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
270	Main electronics failure		Change main electronic module	<div><div>■ 0x100007C</div><div>■ 0x1000080</div><div>■ 0x100009F</div></div>
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
271	Main electronics failure		1. Restart device 2. Change main electronic module	0x100007D
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
272	Main electronics failure		Restart device	0x1000079
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
273	Main electronics failure		Change electronics	<div><div>■ 0x1000098</div><div>■ 0x10000E5</div></div>
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
275	I/O module defective		Change I/O module	0x100007A
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
276	I/O module faulty		1. Restart device 2. Change I/O module	■ 0x100007B ■ 0x1000081
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
283	Memory content		Reset device	0x10000E1
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
283	Memory content		Restart device	0x100016F
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
302	Device verification in progress		Device verification active, please wait.	0x20001EE
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
311	Electronic failure		1. Do not reset device 2. Contact service	0x40000E2
	Status signal	M		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
372	Sensor electronics (ISEM) faulty		1. Restart device 2. Check if failure recurs 3. Replace sensor electronic module (ISEM)	■ 0x10002CB ■ 0x10002CC ■ 0x10002CD ■ 0x10002CE ■ 0x10002CF ■ 0x10002D0
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
373	Sensor electronics (ISEM) faulty		Transfer data or reset device	0x10002D1
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
376	Sensor electronics (ISEM) faulty		1. Replace sensor electronic module (ISEM) 2. Turn off diagnostic message	■ 0x8000119 ■ 0x800016A ■ 0x80002DA ■ 0x80002DB ■ 0x80002DC ■ 0x80002DD ■ 0x80002DF
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
377	Sensor electronics (ISEM) faulty		1. Activate empty pipe detection 2. Check partial filled pipe and installation direction 3. Check sensor cabling 4. Deactivate diagnostics 377	0x80002DE
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
378	Supply voltage ISEM faulty		Check supply voltage to the ISEM	0x10003F0
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
382	Data storage		1. Insert T-DAT 2. Replace T-DAT	0x100016D
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
383	Memory content		1. Restart device 2. Delete T-DAT via 'Reset device' parameter 3. Replace T-DAT	0x100016E
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
387	HistoROM data faulty		Contact service organization	0x1000288
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
512	Sensor electronics (ISEM) faulty		1. Check ECC recovery time 2. Turn off ECC	0x1000120
	Status signal	F		
	Diagnostic behavior	Alarm		

12.8.3 Diagnostic of configuration

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
410	Data transfer		1. Check connection 2. Retry data transfer	0x100008B
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
412	Processing download		Download active, please wait	0x2000204
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
437	Configuration incompatible		Restart device	0x1000060
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
438	Dataset		1. Check data set file 2. Check device configuration 3. Up- and download new configuration	0x400006A
	Status signal	M		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
453	Flow override		Deactivate flow override	0x2000094
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
484	Failure mode simulation		Deactivate simulation	0x2000090
	Status signal	C		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
485	Measured variable simulation		Deactivate simulation	0x2000093
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
491	Current output 1 simulation		Deactivate simulation	0x200000E
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
495	Diagnostic event simulation		Deactivate simulation	0x200015E
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
511	ISEM settings faulty		1. Check measuring period and integration time 2. Check sensor properties	0x200031C
	Status signal	C		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
530	Electrode cleaning is running		Turn off ECC	0x200015A
	Status signal	C		
	Diagnostic behavior	Warning		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
531	Empty pipe adjustment faulty		Execute EPD adjustment	0x800016B
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
537	Configuration		1. Check IP addresses in network 2. Change IP address	0x100014A
	Status signal	F		
	Diagnostic behavior	Warning		

12.8.4 Diagnostic of process

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
832	Electronics temperature too high		Reduce ambient temperature	0x80000C3
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
833	Electronics temperature too low		Increase ambient temperature	0x80000C1
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
834	Process temperature too high		Reduce process temperature	0x80000C5
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
835	Process temperature too low		Increase process temperature	0x80000C6
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
842	Process limit		Low flow cut off active! 1. Check low flow cut off configuration	0x8000091
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
882	Input signal		1. Check input configuration 2. Check external device or process conditions	0x1000031
	Status signal	F		
	Diagnostic behavior	Alarm		

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
937	Sensor symmetry		1. Eliminate external magnetic field near sensor 2. Turn off diagnostic message	0x8000154
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
938	EMC interference		1. Check ambient conditions regarding EMC influence 2. Turn off diagnostic message	0x100011B
	Status signal	F		
	Diagnostic behavior [from the factory] ¹⁾	Alarm		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
961	Electrode potential out of specification		1. Check process conditions 2. Check ambient conditions	0x8000155
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

Diagnostic information			Remedy instructions	Coding of diagnostic information (hex)
No.	Short text			
962	Pipe empty		1. Perform full pipe adjustment 2. Perform empty pipe adjustment 3. Turn off empty pipe detection	0x8000092
	Status signal	S		
	Diagnostic behavior [from the factory] ¹⁾	Warning		

1) Diagnostic behavior can be changed.

12.9 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.




To call up the measures to rectify a diagnostic event:

- Via local display → 148
- Via web browser → 149
- Via "FieldCare" operating tool → 150
- Via "DeviceCare" operating tool → 150




Other pending diagnostic events can be displayed in the **Diagnostic list** submenu → 162

Navigation
"Diagnostics" menu




Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occurred diagnostic event along with its diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	–	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	–	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.10 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path
Diagnostics → Diagnostic list



A0014006-EN

22 Taking the example of the local display

i To call up the measures to rectify a diagnostic event:

- Via local display → 148
- Via web browser → 149
- Via "FieldCare" operating tool → 150
- Via "DeviceCare" operating tool → 150


12.11 Event logbook

12.11.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

Diagnostics menu → **Event logbook** submenu → Event list



A0014008-EN

23 Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events → 152
- Information events → 164

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ☹: Occurrence of the event
 - ☺: End of the event
- Information event
 - ☹: Occurrence of the event

i To call up the measures to rectify a diagnostic event:

- Via local display → 148
- Via web browser → 149
- Via "FieldCare" operating tool → 150
- Via "DeviceCare" operating tool → 150

i For filtering the displayed event messages → 164

12.11.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)


12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	HistoROM backup deleted
I1137	Electronics changed
I1151	History reset
I1155	Reset electronics temperature
I1156	Memory error trend
I1157	Memory error event list
I1256	Display: access status changed
I1335	Firmware changed
I1351	Empty pipe detection adjustment failure
I1353	Empty pipe detection adjustment ok
I1361	Web server: login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1443	Build-up thickness not determined
I1444	Device verification passed
I1445	Device verification failed
I1457	Measurement error verification failed
I1459	I/O module verification failed
I1461	Sensor verification failed
I1462	Sensor electronic module verific. failed
I1512	Download started
I1513	Download finished
I1514	Upload started

Info number	Info name
I1515	Upload finished
I1622	Calibration changed
I1624	All totalizers reset
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server: login successful
I1628	Display: login successful
I1629	CDI: login successful
I1631	Web server access changed
I1632	Display: login failed
I1633	CDI: login failed
I1634	Reset to factory settings
I1635	Reset to delivery settings
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1725	Sensor electronic module (ISEM) changed

12.12 Resetting the measuring device

Using the **Device reset** parameter (→  132) it is possible to reset the entire device configuration or some of the configuration to a defined state.

12.12.1 Function scope of the "Device reset" parameter



Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

12.13 Device information

The **Device information** submenu contains all parameters that display different information for device identification.






Navigation

"Diagnostics" menu → Device information

► Device information	
Device tag	→  166
Serial number	→  166

Firmware version	→ ⓘ 166
Device name	→ ⓘ 166
Order code	→ ⓘ 166
Extended order code 1	→ ⓘ 166
Extended order code 2	→ ⓘ 166
Extended order code 3	→ ⓘ 166
ENP version	→ ⓘ 166

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	–
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	–
Device name	Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter.	Max. 32 characters such as letters or numbers.	Promag 400 EIP
Order code	Shows the device order code.  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	–
Extended order code 1	Shows the 1st part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
Extended order code 3	Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00

12.14 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
02.2022	02.00.zz	Option 66	<ul style="list-style-type: none"> Web server: Extended function scope Heartbeat Technology: Extended function scope and extended report Buildup detection 	Operating Instructions	BA01214D/06/EN/07.21
07.2014	01.01.zz	Option 74	Update	Operating Instructions	BA01214D/06/EN/02.14
10.2013	01.00.zz	Option 77	Original firmware	Operating Instructions	BA01214D/06/EN/01.13



It is possible to flash the firmware to the current version or the previous version using the service interface.



For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

- In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
- Specify the following details:
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

WARNING

Cleaning agents can damage the plastic transmitter housing!

- ▶ Do not use high-pressure steam.
- ▶ Only use the permitted cleaning agents specified.

Permitted cleaning agents for the plastic transmitter housing


- Commercially available household cleaners
- Methyl alcohol or isopropyl alcohol
- Mild soap solutions

13.1.2 Interior cleaning

No interior cleaning is planned for the device.

13.2 Measuring and test equipment


Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: →  171 →  172

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General information

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- ▶ Carry out the repair according to the Installation Instructions.
- ▶ Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ▶ Document every repair and each conversion and enter them into the *W@M* life cycle management database and Netilion Analytics.


14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter (→  166) in the **Device information** submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the website for more information:
<http://www.endress.com/support/return-material>
2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to persons from process conditions!

- ▶ Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.
2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:




- ▶ Observe valid federal/national regulations.
- ▶ Ensure proper separation and reuse of the device components.

15 Accessories


Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories


15.1.1 For the transmitter




Accessories	Description
Promag 400 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: <ul style="list-style-type: none"> ▪ Approvals ▪ Output/input ▪ Display/operation ▪ Housing ▪ Software  For details, see Installation Instructions EA00104D
Display guard	Is used to protect the display against impact or scoring, for example from sand in desert areas.  Order number: 71228792  Installation Instructions EA01093D
Connecting cable for remote version	Coil current and electrode cables, various lengths, reinforced cables available on request.
Ground cable	Set, consisting of two ground cables for potential equalization.
Post mounting kit	Post mounting kit for transmitter.
Compact → Remote conversion kit	For converting a compact device version to a remote device version.
Conversion kit Promag 50/53 → Promag 400	For converting a Promag with transmitter 50/53 to a Promag 400.

15.1.2 For the sensor



Accessory	Description
Ground disks	Are used to ground the medium in lined measuring tubes to ensure proper measurement.  For details, see Installation Instructions EA00070D

15.2 Communication-specific accessories


Accessories	Description
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.  Technical Information TI405C/07

Fieldgate FXA42	<p>Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices</p>  <ul style="list-style-type: none"> ■ Technical Information TI01297S ■ Operating Instructions BA01778S ■ Product page: www.endress.com/fxa42
Field Xpert SMT70	<p>The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress.</p> <p>This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.</p>  <ul style="list-style-type: none"> ■ Technical Information TI01342S ■ Operating Instructions BA01709S ■ Product page: www.endress.com/smt70
Field Xpert SMT77	<p>The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.</p>  <ul style="list-style-type: none"> ■ Technical Information TI01418S ■ Operating Instructions BA01923S ■ Product page: www.endress.com/smt77

15.3 Service-specific accessories

Accessory	Description
Applicator	<p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> ■ Choice of measuring devices with industrial requirements ■ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. ■ Graphic illustration of the calculation results ■ Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. <p>Applicator is available:</p> <ul style="list-style-type: none"> ■ Via the Internet: https://portal.endress.com/webapp/applicator ■ As a downloadable DVD for local PC installation.
W@M	<p>W@M Life Cycle Management</p> <p>Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle.</p> <p>W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime.</p> <p>Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, see: www.endress.com/lifecyclemanagement</p>
FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p>  <ul style="list-style-type: none"> ■ Operating Instructions BA00027S and BA00059S
DeviceCare	<p>Tool for connecting and configuring Endress+Hauser field devices.</p>  <ul style="list-style-type: none"> ■ Innovation brochure IN01047S

15.4 System components

Accessories	Description
Memograph M graphic data manager	<p>The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <div><ul style="list-style-type: none">▪ Technical Information TI00133R▪ Operating Instructions BA00247R</div>

16 Technical data


16.1 Application

The measuring device is only suitable for the flow measurement of liquids with a minimum conductivity of 5 µS/cm.


Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of <i>Faraday's law of magnetic induction</i> .
Measuring system	<p>The device consists of a transmitter and a sensor.</p> <p>Two device versions are available:</p> <ul style="list-style-type: none">■ Compact version - transmitter and sensor form a mechanical unit.■ Remote version - transmitter and sensor are mounted in separate locations. <p>For information on the structure of the device →  13</p>

16.3 Input

Measured variable	<p>Direct measured variables</p> <ul style="list-style-type: none">■ Volume flow (proportional to induced voltage)■ Electrical conductivity <p> In custody transfer: only volume flow</p> <p>Calculated measured variables</p> <p>Mass flow</p>
-------------------	---

Measuring range	<p>Typically v = 0.01 to 10 m/s (0.03 to 33 ft/s) with the specified accuracy</p> <p>Electrical conductivity: ≥ 5 µS/cm for liquids in general</p> <p><i>Flow characteristic values in SI units: DN 25 to 125 mm (1 to 4 in)</i></p>
-----------------	--

Nominal diameter		Recommended flow	Factory settings		
[mm]	[in]	min./max. full scale value (v ~ 0.3...10 m/s) [dm³/min]	Full scale value current output (v ~ 2.5 m/s) [dm³/min]	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s) [dm³]	Low flow cut off (v ~ 0.04 m/s) [dm³/min]
25	1	9 to 300	75	0.5	1
32	–	15 to 500	125	1	2
40	1 ½	25 to 700	200	1.5	3

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3...10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
[mm]	[in]	[dm ³ /min]	[dm ³ /min]	[dm ³]	[dm ³ /min]
50	2	35 to 1 100	300	2.5	5
65	–	60 to 2 000	500	5	8
80	3	90 to 3 000	750	5	12
100	4	145 to 4 700	1 200	10	20
125	–	220 to 7 500	1 850	15	30

Flow characteristic values in SI units: DN 150 to 3 000 mm (6 to 120 in)

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3...10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
[mm]	[in]	[m ³ /h]	[m ³ /h]	[m ³]	[m ³ /h]
150	6	20 to 600	150	0.025	2.5
200	8	35 to 1 100	300	0.05	5
250	10	55 to 1 700	500	0.05	7.5
300	12	80 to 2 400	750	0.1	10
350	14	110 to 3 300	1 000	0.1	15
375	15	140 to 4 200	1 200	0.15	20
400	16	140 to 4 200	1 200	0.15	20
450	18	180 to 5 400	1 500	0.25	25
500	20	220 to 6 600	2 000	0.25	30
600	24	310 to 9 600	2 500	0.3	40
700	28	420 to 13 500	3 500	0.5	50
750	30	480 to 15 000	4 000	0.5	60
800	32	550 to 18 000	4 500	0.75	75
900	36	690 to 22 500	6 000	0.75	100
1000	40	850 to 28 000	7 000	1	125
–	42	950 to 30 000	8 000	1	125
1200	48	1 250 to 40 000	10 000	1.5	150
–	54	1 550 to 50 000	13 000	1.5	200
1400	–	1 700 to 55 000	14 000	2	225
–	60	1 950 to 60 000	16 000	2	250
1600	–	2 200 to 70 000	18 000	2.5	300
–	66	2 500 to 80 000	20 500	2.5	325
1800	72	2 800 to 90 000	23 000	3	350
–	78	3 300 to 100 000	28 500	3.5	450
2000	–	3 400 to 110 000	28 500	3.5	450
–	84	3 700 to 125 000	31 000	4.5	500

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3...10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
[mm]	[in]	[m³/h]	[m³/h]	[m³]	[m³/h]
2200	–	4 100 to 136 000	34 000	4.5	540
–	90	4 300 to 143 000	36 000	5	570
2400	–	4 800 to 162 000	40 000	5.5	650
–	96	5 000 to 168 000	42 000	6	675
–	102	5 700 to 190 000	47 500	7	750
2600	–	5 700 to 191 000	48 000	7	775
–	108	6 500 to 210 000	55 000	7	850
2800	–	6 700 to 222 000	55 500	8	875
–	114	7 100 to 237 000	59 500	8	950
3000	–	7 600 to 254 000	63 500	9	1 025
–	120	7 900 to 263 000	65 500	9	1 050

Flow characteristic values in SI units: DN 50 to 200 mm (2 to 8 in) for order code for "Design", option C "Fixed flange, constricted measuring tube, 0 x DN inlet/outlet runs"

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.12...5 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 4 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.01 m/s)
[mm]	[in]	[dm³/min]	[dm³/min]	[dm³]	[dm³/min]
50	2	15 to 600	300	1.25	1.25
65	–	25 to 1 000	500	2	2
80	3	35 to 1 500	750	3	3.25
100	4	60 to 2 400	1 200	5	4.75
125	–	90 to 3 700	1 850	8	7.5
150	6	145 to 5 400	2 500	10	11
200	8	220 to 9 400	5 000	20	19

Flow characteristic values in SI units: DN 250 to 300 mm (10 to 12 in) for order code for "Design", option C "Fixed flange, constricted measuring tube, 0 x DN inlet/outlet runs"

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.12...5 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 4 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.01 m/s)
[mm]	[in]	[m³/h]	[m³/h]	[m³]	[m³/h]
250	10	20 to 850	500	0.03	1.75
300	12	35 to 1 300	750	0.05	2.75

Flow characteristic values in US units: DN 1 to 48 in (25 to 1200 mm)

Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3...10 m/s)	Factory settings		
[in]	[mm]		Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
		[gal/min]	[gal/min]	[gal]	[gal/min]
1	25	2.5 to 80	18	0.2	0.25
–	32	4 to 130	30	0.2	0.5
1 ½	40	7 to 185	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
–	65	16 to 500	130	1	2
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4
–	125	60 to 1950	450	5	7
6	150	90 to 2650	600	5	12
8	200	155 to 4850	1200	10	15
10	250	250 to 7500	1500	15	30
12	300	350 to 10600	2400	25	45
14	350	500 to 15000	3600	30	60
15	375	600 to 19000	4800	50	60
16	400	600 to 19000	4800	50	60
18	450	800 to 24000	6000	50	90
20	500	1000 to 30000	7500	75	120
24	600	1400 to 44000	10500	100	180
28	700	1900 to 60000	13500	125	210
30	750	2150 to 67000	16500	150	270
32	800	2450 to 80000	19500	200	300
36	900	3100 to 100000	24000	225	360
40	1000	3800 to 125000	30000	250	480
42	–	4200 to 135000	33000	250	600
48	1200	5500 to 175000	42000	400	600

Flow characteristic values in US units: DN 54 to 120 in (1400 to 3000 mm)

Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3...10 m/s)	Factory settings		
[in]	[mm]		Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
		[Mgal/d]	[Mgal/d]	[Mgal]	[Mgal/d]
54	–	9 to 300	75	0.0005	1.3
–	1400	10 to 340	85	0.0005	1.3
60	–	12 to 380	95	0.0005	1.3
–	1600	13 to 450	110	0.0008	1.7
66	–	14 to 500	120	0.0008	2.2
72	1800	16 to 570	140	0.0008	2.6

Nominal diameter		Recommended flow	Factory settings		
[in]	[mm]	min./max. full scale value (v ~ 0.3...10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.04 m/s)
		[Mgal/d]	[Mgal/d]	[Mgal]	[Mgal/d]
78	–	18 to 650	175	0.0010	3.0
–	2000	20 to 700	175	0.0010	2.9
84	–	24 to 800	190	0.0011	3.2
–	2200	26 to 870	210	0.0012	3.4
90	–	27 to 910	220	0.0013	3.6
–	2400	31 to 1030	245	0.0014	4.0
96	–	32 to 1066	265	0.0015	4.0
102	–	34 to 1203	300	0.0017	5.0
–	2600	34 to 1212	305	0.0018	5.0
108	–	35 to 1300	340	0.0020	5.0
–	2800	42 to 1405	350	0.0020	6.0
114	–	45 to 1503	375	0.0022	6.0
–	3000	48 to 1613	405	0.0023	6.0
120	–	50 to 1665	415	0.0024	7.0

Flow characteristic values in US units: DN 2 to 12 in (50 to 300 mm) for order code for "Design", option C "Fixed flange, constricted measuring tube, 0 x DN inlet/outlet runs"

Nominal diameter		Recommended flow	Factory settings		
[in]	[mm]	min./max. full scale value (v ~ 0.12...5 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 4 Pulse/s at v ~ 2.5 m/s)	Low flow cut off (v ~ 0.01 m/s)
		[gal/min]	[gal/min]	[gal]	[gal/min]
2	50	4 to 160	75	0.3	0.35
–	65	7 to 260	130	0.5	0.6
3	80	10 to 400	200	0.8	0.8
4	100	16 to 650	300	1.2	1.25
–	125	24 to 1000	450	1.8	2
6	150	40 to 1400	600	2.5	3
8	200	60 to 2 500	1 200	5	5
10	250	90 to 3 700	1 500	6	8
12	300	155 to 5 700	2 400	9	12




Recommended measuring range



Flow limit → 188



For custody transfer, the applicable approval determines the permitted measuring range, the pulse value and the low flow cut off.

Operable flow range	<p>Over 1000 : 1</p> <p> For custody transfer, the operable flow range is 100 : 1 to 630 : 1, depending on the nominal diameter. Further details are specified by the applicable approval.</p>								
Input signal	<p>External measured values</p> <p> Various pressure transmitters and temperature measuring devices can be ordered from Endress+Hauser: see "Accessories" section →  173</p> <p>It is recommended to read in external measured values to calculate the following measured variables: Mass flow</p> <p><i>Digital communication</i></p> <p>The measured values are written from the automation system to the measuring device via EtherNet/IP.</p> <p>Status input</p> <table border="1"> <tr> <td>Maximum input values</td><td> <ul style="list-style-type: none"> ■ DC 30 V ■ 6 mA </td></tr> <tr> <td>Response time</td><td>Configurable: 5 to 200 ms</td></tr> <tr> <td>Input signal level</td><td> <ul style="list-style-type: none"> ■ Low signal (low): DC -3 to +5 V ■ High signal (high): DC 12 to 30 V </td></tr> <tr> <td>Assignable functions</td><td> <ul style="list-style-type: none"> ■ Off ■ Reset totalizers 1-3 separately ■ Reset all totalizers ■ Flow override </td></tr> </table>	Maximum input values	<ul style="list-style-type: none"> ■ DC 30 V ■ 6 mA 	Response time	Configurable: 5 to 200 ms	Input signal level	<ul style="list-style-type: none"> ■ Low signal (low): DC -3 to +5 V ■ High signal (high): DC 12 to 30 V 	Assignable functions	<ul style="list-style-type: none"> ■ Off ■ Reset totalizers 1-3 separately ■ Reset all totalizers ■ Flow override
Maximum input values	<ul style="list-style-type: none"> ■ DC 30 V ■ 6 mA 								
Response time	Configurable: 5 to 200 ms								
Input signal level	<ul style="list-style-type: none"> ■ Low signal (low): DC -3 to +5 V ■ High signal (high): DC 12 to 30 V 								
Assignable functions	<ul style="list-style-type: none"> ■ Off ■ Reset totalizers 1-3 separately ■ Reset all totalizers ■ Flow override 								

16.4 Output

Output signal	<p>EtherNet/IP</p> <table border="1"> <tr> <td>Standards</td><td>In accordance with IEEE 802.3</td></tr> </table>	Standards	In accordance with IEEE 802.3				
Standards	In accordance with IEEE 802.3						
Signal on alarm	<p>Depending on the interface, failure information is displayed as follows:</p> <p>EtherNet/IP</p> <table border="1"> <tr> <td>Device diagnostics</td><td>Device condition can be read out in Input Assembly</td></tr> </table> <p>Local display</p> <table border="1"> <tr> <td>Plain text display</td><td>With information on cause and remedial measures</td></tr> <tr> <td>Backlight</td><td>Red backlighting indicates a device error.</td></tr> </table>	Device diagnostics	Device condition can be read out in Input Assembly	Plain text display	With information on cause and remedial measures	Backlight	Red backlighting indicates a device error.
Device diagnostics	Device condition can be read out in Input Assembly						
Plain text display	With information on cause and remedial measures						
Backlight	Red backlighting indicates a device error.						

 Status signal as per NAMUR recommendation NE 107

Interface/protocol



- Via digital communication:
EtherNet/IP
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	---

Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	<p>Status indicated by various light emitting diodes</p> <p>The following information is displayed depending on the device version:</p> <ul style="list-style-type: none"> ■ Supply voltage active ■ Data transmission active ■ Device alarm/error has occurred ■ EtherNet/IP network available ■ EtherNet/IP connection established <p> Diagnostic information via light emitting diodes →  145</p>
--------------------	---

Low flow cut off The switch points for low flow cut off are user-selectable.

Galvanic isolation The following connections are galvanically isolated from each other:

- Outputs
- Power supply

Protocol-specific data**EtherNet/IP**

Protocol	<ul style="list-style-type: none"> ■ The CIP Networks Library Volume 1: Common Industrial Protocol ■ The CIP Networks Library Volume 2: EtherNet/IP Adaptation of CIP
Communication type	<ul style="list-style-type: none"> ■ 10Base-T ■ 100Base-TX
Device profile	Generic device (product type: 0x2B)
Manufacturer ID	0x49E
Device type ID	0x1069
Baud rates	Automatic 10/100 Mbit with half-duplex and full-duplex detection
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs
Supported CIP connections	Max. 3 connections
Explicit connections	Max. 5 connections
I/O connections	Max. 6 connections (scanner)
Configuration options for measuring device	<p>Configuration options for measuring device</p> <ul style="list-style-type: none"> ■ DIP switches on the electronics module for IP addressing ■ Manufacturer-specific software (FieldCare) ■ Custom Add-on Profile for Rockwell Automation control systems ■ Web browser ■ Electronic Data Sheet (EDS) integrated in the measuring device

EtherNet interface configuration options	Configuration of the EtherNet interface <ul style="list-style-type: none"> Speed: 10 MBit, 100 MBit, auto (factory setting) Duplex: half-duplex, full-duplex, auto (factory setting)
Device address configuration options	Configuration of the device address <ul style="list-style-type: none"> DIP switches on the electronics module for IP addressing (last octet) DHCP Manufacturer-specific software (FieldCare) Custom Add-on Profile for Rockwell Automation control systems Web browser EtherNet/IP tools, e.g. RSLinx (Rockwell Automation)
Device Level Ring (DLR)	No
Assembly	<ul style="list-style-type: none"> Legacy Input Assembly Fix (Assem 100) Legacy Input Assembly Configurable (Assem 101) Legacy Output Assembly Fix (Assem 102) Legacy Configuration Assembly (Assem 104) Input Assembly Fix (Assem 120) Input Assembly Configurable (Assem 121) Output Assembly Fix (Assem 122) Configuration Assembly (Assem 124) Volume Flow Extended Fix Input (Assem 126) Volume Flow Universal Fix Input (Assem 127) Dummy Output Assembly Fix (Assem 199)
Requested Packet Interval (RPI)	5 ms to 10 s (factory setting: 20 ms)
System integration	→ 86

16.5 Power supply

Terminal assignment → 43

Pin assignment, device plug → 44

Supply voltage **Transmitter**

Order code for "Power supply"	terminal voltage		Frequency range
Option L	DC 24 V	±25%	–
	AC 24 V	±25%	50/60 Hz, ±4 Hz
	AC 100 to 240 V	–15 to +10%	50/60 Hz, ±4 Hz


Power consumption

Order code for "Output"	Maximum power consumption
Option N: EtherNet/IP	30 VA/8 W

Current consumption **Transmitter**


Order code for "Power supply"	Maximum Current consumption	Maximum switch-on current
Option L: AC 100 to 240 V	145 mA	25 A (< 5 ms)
Option L: AC/DC 24 V	350 mA	27 A (< 5 ms)


Power supply failure	<ul style="list-style-type: none"> ■ Totalizers stop at the last value measured. ■ Depending on the device version, the configuration is retained in the device memory or in the pluggable data memory (HistoROM DAT). ■ Error messages (incl. total operated hours) are stored.
----------------------	---

Electrical connection	→  46
-----------------------	--

Potential equalization	→  52
------------------------	--


Terminals	<p>Transmitter</p> <ul style="list-style-type: none"> ■ Supply voltage cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) ■ Signal cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) ■ Electrode cable: spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) ■ Coil current cable: spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG) <p>Sensor connection housing</p> <p>Spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)</p>
-----------	--


Cable entries	<p>Cable entry thread</p> <ul style="list-style-type: none"> ■ M20 x 1.5 ■ Via adapter: <ul style="list-style-type: none"> ■ NPT ½" ■ G ½" <p>Cable gland</p> <ul style="list-style-type: none"> ■ For standard cable: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) ■ For armored cable: M20 × 1.5 with cable Ø 9.5 to 16 mm (0.37 to 0.63 in) <p> If metal cable entries are used, use a grounding plate.</p>
---------------	---

Cable specification	→  41
---------------------	--

16.6 Performance characteristics

Reference operating conditions	<ul style="list-style-type: none"> ■ Error limits following DIN EN 29104, in future ISO 20456 ■ Water, typically +15 to +45 °C (+59 to +113 °F); 0.5 to 7 bar (73 to 101 psi) ■ Data as indicated in the calibration protocol ■ Accuracy based on accredited calibration rigs according to ISO 17025
--------------------------------	--


Maximum measured error	<p>Error limits under reference operating conditions</p> <p><i>Volume flow</i></p> <ul style="list-style-type: none"> ■ ±0.5 % o.r. ± 1 mm/s (0.04 in/s) ■ Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s) <p> Fluctuations in the supply voltage do not have any effect within the specified range.</p>
------------------------	---



24 Maximum measured error in % o.r.

Flat Spec

For Flat Spec in the range $v_{0.5}$ ($v_{0.2}$) up to v_{\max} the measured error is constant.



25 Flat Spec in % o.r.

Flat Spec flow values 0.5 %

Nominal diameter		$v_{0.5}$		v_{\max}	
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]
25 to 600	1 to 24	0.5	1.64	10	32
50 to 300 ¹⁾	2 to 12	0.25	0.82	5	16

1) Order code for "Design", option C

Flat Spec flow values 0.2 %

Nominal diameter		$v_{0.2}$		v_{\max}	
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]
25 to 600	1 to 24	1.5	4.92	10	32
50 to 300 ¹⁾	2 to 12	0.6	1.97	4	13


1) Order code for "Design", option C

Electrical conductivity

The values apply for:

- Measurements at a reference temperature of 25 °C (77 °F)
At different temperatures, attention must be paid to the temperature coefficient of the medium (typically 2.1 %/K)
- Device version: compact version - transmitter and sensor form a mechanical unit
- Devices installed in a metal pipe or in a non-metal pipe with ground disks
- Devices whose potential equalization was performed according to the instructions in the associated Operating Instructions

Conductivity [μS/cm]	Measured error [%] o. r.
5 to 20	± 20%
20 to 20 000	± 10%
20 000 to 100 000	± 20%



26 Measured error




Repeatability	o.r. = of reading Volume flow max. ±0.1 % o.r. ± 0.5 mm/s (0.02 in/s) Electrical conductivity Max. ±5 % o.r.
---------------	--

Influence of ambient temperature	Current output o.r. = of reading <table><tr><td>Temperature coefficient</td><td>Max. ±0.005 % o.r./°C</td></tr></table> Pulse/frequency output <table><tr><td>Temperature coefficient</td><td>No additional effect. Included in accuracy.</td></tr></table>	Temperature coefficient	Max. ±0.005 % o.r./°C	Temperature coefficient	No additional effect. Included in accuracy.
Temperature coefficient	Max. ±0.005 % o.r./°C				
Temperature coefficient	No additional effect. Included in accuracy.				

16.7 Installation

Installation conditions	→ 19
-------------------------	------

16.8 Environment

Ambient temperature range	→  25
Storage temperature	<p>The storage temperature corresponds to the operating temperature range of the transmitter and the sensor →  25.</p> <ul style="list-style-type: none"> ■ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures. ■ Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner. ■ If protection caps or protective covers are mounted these should never be removed before installing the measuring device.
Atmosphere	<p>If a plastic transmitter housing is permanently exposed to certain steam and air mixtures, this can damage the housing.</p> <p> In cases of doubt, please contact the Sales Center.</p>
Degree of protection	<p>Transmitter</p> <ul style="list-style-type: none"> ■ IP66/67, type 4X enclosure ■ When housing is open: IP20, type 1 enclosure ■ Display module: IP20, type 1 enclosure <p>Sensor</p> <p><i>Compact and remote version</i></p> <p>IP66/67, type 4X enclosure</p> <p><i>Optionally available for compact and remote version:</i></p> <p>Order code for "Sensor option", option CA, C3</p> <ul style="list-style-type: none"> ■ IP66/67, type 4X enclosure ■ Fully welded, with protective coating as per EN ISO 12944 C5-M ■ For the operation of the device in corrosive environments <p><i>Optionally available for remote version:</i></p> <p>Order code for "Sensor option", option CB, CC</p> <ul style="list-style-type: none"> ■ IP68, type 6P enclosure ■ Fully welded, with protective coating as per EN ISO 12944 C5-M/Im1 and EN 60529 ■ For the operation of the device under water ■ Operating duration at a maximum depth of: <ul style="list-style-type: none"> ■ 3 m (10 ft): permanent use ■ 10 m (30 ft): maximum 48 hours <p>Order code for "Sensor option", option CQ</p> <ul style="list-style-type: none"> ■ IP68, type 6P, temporarily waterproof ■ Sensor with aluminum half-shell housing ■ For the temporary operation of the device under non-corrosive water ■ Operating duration at a maximum depth of: <ul style="list-style-type: none"> ■ 3 m (10 ft): maximum 168 hours

Order code for "Sensor option", option CD, CE

- IP68, type 6P enclosure
- Fully welded, with protective coating as per EN ISO 12944 Im2/Im3 and EN 60529
- For the operation of the device in buried applications
- For the operation of the device under water and in saline water
- Operating duration at a maximum depth of:
 - 3 m (10 ft): permanent use
 - 10 m (30 ft): maximum 48 hours

Vibration- and shock-resistance

Sinusoidal vibration according to IEC 60068-2-6

Compact version; order code for "Housing", option A "Compact, aluminum, coated"

- 2 to 8.4 Hz, 3.5 mm peak
- 8.4 to 2 000 Hz, 1 g peak

Compact version; order code for "Housing", option M "Compact, polycarbonate"

- 2 to 8.4 Hz, 7.5 mm peak
- 8.4 to 2 000 Hz, 2 g peak

Remote version; order code for "Housing", option N "Remote, polycarbonate" and option P "Remote, aluminum, coated"

- 2 to 8.4 Hz, 7.5 mm peak
- 8.4 to 2 000 Hz, 2 g peak

Vibration broad-band random, according to IEC 60068-2-64

Compact version; order code for "Housing", option A "Compact, aluminum, coated"

- 10 to 200 Hz, 0.003 g²/Hz
- 200 to 2 000 Hz, 0.001 g²/Hz
- Total: 1.54 g rms

Compact version; order code for "Housing", option M "Compact, polycarbonate"

- 10 to 200 Hz, 0.01 g²/Hz
- 200 to 2 000 Hz, 0.003 g²/Hz
- Total: 2.70 g rms

Remote version; order code for "Housing", option N "Remote, polycarbonate" and option P "Remote, aluminum, coated"

- 10 to 200 Hz, 0.01 g²/Hz
- 200 to 2 000 Hz, 0.003 g²/Hz
- Total: 2.70 g rms

Shock half-sine, according to IEC 60068-2-27


- Compact version; order code for "Housing", option A "Compact, aluminum, coated"
6 ms 30 g
- Compact version; order code for "Housing", option M "Compact, polycarbonate"
6 ms 50 g
- Remote version; order code for "Housing", option N "Remote, polycarbonate" and option P "Remote, aluminum, coated"
6 ms 50 g

Rough handling shocks according to IEC 60068-2-31

Mechanical load

- Protect the transmitter housing against mechanical effects, such as shock or impact; the use of the remote version is sometimes preferable.
- Never use the transmitter housing as a ladder or climbing aid.


Electromagnetic compatibility (EMC)

- As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)
 - Complies with emission limits for industry as per EN 55011 (Class A)
-  Details are provided in the Declaration of Conformity.

16.9 Process

Medium temperature range

- 0 to +80 °C (+32 to +176 °F) for hard rubber, DN 50 to 3000 (2 to 120")
- -20 to +50 °C (-4 to +122 °F) for polyurethane, DN 25 to 1200 (1 to 48")
- -20 to +90 °C (-4 to +194 °F) for PTFE, DN 25 to 300 (1 to 12")



A0038130

T_A Ambient temperature

T_F Medium temperature

1 Colored area: The ambient temperature range of -10 to -40 °C (+14 to -40 °F) and the medium temperature range of -10 to -20 °C (+14 to -4 °F) only apply for stainless flanges





The permitted fluid temperature in custody transfer is 0 to +50 °C (+32 to +122 °F).

Conductivity


≥5 μS/cm for liquids in general.



- Note that in the case of the remote version, the requisite minimum conductivity additionally depends on the length of the connecting cable →  26.
- Maximum measured error for electrical conductivity →  184.

Pressure-temperature ratings



For an overview of the pressure-temperature ratings for the process connections, see the Technical Information →  204

Pressure tightness

Liner: hard rubber

Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures:		
[mm]	[in]	+25 °C (+77 °F)	+50 °C (+122 °F)	+80 °C (+176 °F)
50 ... 3000	2 ... 120	0 (0)	0 (0)	0 (0)

Liner: polyurethane

Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures:	
[mm]	[in]	+25 °C (+77 °F)	+50 °C (+122 °F)
25 ... 1200	1 ... 48	0 (0)	0 (0)

Liner: PTFE


Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures:	
[mm]	[in]	+25 °C (+77 °F)	+90 °C (+194 °F)
25	1	0 (0)	0 (0)
40	2	0 (0)	0 (0)
50	2	0 (0)	0 (0)
65	2 ½	0 (0)	40 (0.58)
80	3	0 (0)	40 (0.58)
100	4	0 (0)	135 (2.0)
125	5	135 (2.0)	240 (3.5)
150	6	135 (2.0)	240 (3.5)
200	8	200 (2.9)	290 (4.2)
250	10	330 (4.8)	400 (5.8)
300	12	400 (5.8)	500 (7.3)

Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the medium:


- v < 2 m/s (6.56 ft/s): for abrasive media (e.g. potter's clay, lime milk, ore slurry)
- v > 2 m/s (6.56 ft/s): for media producing buildup (e.g. wastewater sludge)


 A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.

 For an overview of the full scale values for the measuring range, see the "Measuring range" section →  174


 For custody transfer, the applicable approval determines the permitted measuring range.

Pressure loss

- No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.
- Pressure losses for configurations incorporating adapters according to DIN EN 545 →  26



27 Pressure loss DN 50 to 80 (2 to 3") for order code for "Design", option C "Fixed flange, constricted measuring tube", 0 x DN inlet/outlet runs"



28 Pressure loss DN 100 to 300 (4 to 12") for order code for "Design", option C "Fixed flange, constricted measuring tube", 0 x DN inlet/outlet runs"

System pressure

Installation near pumps → 20

Vibrations

Installation in event of pipe vibrations → 21

16.10 Mechanical construction

Design, dimensions

For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section → 204

Weight

All values (weight exclusive of packaging material) refer to devices with flanges of the standard pressure rating.
The weight may be lower than indicated depending on the pressure rating and design.

Weight in SI units

Order code for "Design", option C, D, E, H, I : DN 25 to 400 mm (1 to 16 in)			
Nominal diameter		Reference values	
		EN (DIN), AS, JIS	
[mm]	[in]	Pressure rating	[kg]
25	1	PN 40	10
32	–	PN 40	11
40	1 ½	PN 40	12
50	2	PN 40	13
65	–	PN 16	13
80	3	PN 16	15
100	4	PN 16	18
125	–	PN 16	25
150	6	PN 16	31
200	8	PN 10	52
250	10	PN 10	81
300	12	PN 10	95
350	14	PN 6	106
375	15	PN 6	121
400	16	PN 6	121

Order code for "Design", option F, J: DN 450 to 2000 mm (18 to 78 in)			
Nominal diameter		Reference values	
		EN (DIN) (PN16)	AS (PN 16)
[mm]	[in]	[kg]	[kg]
450	18	142	138
500	20	182	186
600	24	227	266
700	28	291	369
–	30	–	447
800	32	353	524
900	36	444	704
1000	40	566	785
–	42	–	–
1200	48	843	1229
–	54	–	–
1400	–	1204	–
–	60	–	–
1600	–	1845	–
–	66	–	–

Order code for "Design", option F, J: DN 450 to 2 000 mm (18 to 78 in)			
Nominal diameter		Reference values	
		EN (DIN) (PN16)	AS (PN 16)
[mm]	[in]	[kg]	[kg]
1800	72	2 357	–
–	78	2 929	–
2000	–	2 929	–

Order code for "Design", option F, J: DN 2 200 to 3 000 mm (84 to 120 in)		
Nominal diameter		Reference values
		EN (DIN) (PN6)
[mm]	[in]	[kg]
–	84	–
2200	–	3 422
–	90	–
2400	–	4 094
–	96	–
–	102	–
2600	–	7 601.5
–	108	–
2800	–	9 466.5
–	114	–
3000	–	11 911
–	120	–

Order code for "Design", option G, K: DN 450 to 2 000 mm (18 to 78 in)		
Nominal diameter		Reference values
		EN (DIN) (PN 6)
[mm]	[in]	[kg]
450	18	161
500	20	156
600	24	208
700	28	304
–	30	–
800	32	357
900	36	485
1000	40	589
–	42	–
1200	48	850
–	54	850
1400	–	1 300
–	60	–
1600	–	1 845

Order code for "Design", option G, K: DN 450 to 2 000 mm (18 to 78 in)		
Nominal diameter		Reference values
[mm]	[in]	EN (DIN) (PN 6)
		[kg]
–	66	–
1800	72	2 357
–	78	2 929
2000	–	2 929

Weight in US units

Order code for "Design", option C, D, E, H, I: DN 1 to 16 in (25 to 400 mm)		
Nominal diameter		Reference values
[mm]	[in]	ASME (Class 150)
		[lb]
25	1	11
32	–	–
40	1 ½	15
50	2	20
65	–	–
80	3	31
100	4	42
125	–	–
150	6	73
200	8	115
250	10	198
300	12	284
350	14	379
375	15	–
400	16	448

Order code for "Design", option F, J: DN 18 to 120 in (450 to 3 000 mm)		
Nominal diameter		Reference values
[mm]	[in]	ASME (Class 150), AWWA (Class D)
		[lb]
450	18	421
500	20	503
600	24	666
700	28	587
–	30	701
800	32	845
900	36	1 036
1000	40	1 294
–	42	1 477
1200	48	1 987

Order code for "Design", option F, J: DN 18 to 120 in (450 to 3 000 mm)		
Nominal diameter		Reference values
		ASME (Class 150), AWWA (Class D)
[mm]	[in]	[lb]
–	54	2 807
1400	–	–
–	60	3 515
1600	–	–
–	66	4 699
1800	72	5 662
–	78	6 864
2000	–	6 864
–	84	8 280
2200	–	–
–	90	10 577
2400	–	–
–	96	15 574.6
–	102	18 023.9
2600	–	–
–	108	20 783.0
2800	–	–
–	114	24 060.2
3000	–	–
–	120	27 724.3

Order code for "Design", option G, K: DN 18 to 78 in (450 to 2 000 mm)		
Nominal diameter		Reference values
		ASME (Class 150), AWWA (Class D)
[mm]	[in]	[lb]
450	18	562
500	20	628
600	24	893
700	28	882
–	30	1 014
800	32	1 213
900	36	1 764
1000	40	1 984
–	42	2 426
1200	48	3 087
–	54	4 851
1400	–	–
–	60	5 954
1600	–	–
–	66	8 158

Order code for "Design", option G, K: DN 18 to 78 in (450 to 2000 mm)		
Nominal diameter		Reference values
		ASME (Class 150), AWWA (Class D)
[mm]	[in]	[lb]
1800	72	9040
–	78	10 143
2000	–	–

Measuring tube specification



The values are reference values and can vary depending on the pressure rating, design and order option.

Nominal diameter		Pressure rating				Measuring tube internal diameter					
		EN (DIN)	ASME AWWA	AS 2129 AS 4087	JIS	Hard rubber		Polyurethane		PTFE	
[mm]	[in]					[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	PN 40	Class 150	–	20K	–	–	24	0.93	25	1.00
32	–	PN 40	–	–	20K	–	–	32	1.28	34	1.34
40	1 ½	PN 40	Class 150	–	20K	–	–	38	1.51	40	1.57
50	2	PN 40	Class 150	Table E, PN 16	10K	50	1.98	50	1.98	52	2.04
50 ¹⁾	2	PN 40	Class 150	Table E, PN 16	10K	32	1.26	–	–	–	–
65	–	PN 16	–	–	10K	66	2.60	66	2.60	68	2.67
65 ¹⁾	–	PN 16	–	–	10K	38	1.50	–	–	–	–
80	3	PN 16	Class 150	Table E, PN 16	10K	79	3.11	79	3.11	80	3.15
80 ¹⁾	3	PN 16	Class 150	Table E, PN 16	10K	50	1.97	–	–	–	–
100	4	PN 16	Class 150	Table E, PN 16	10K	101	3.99	104	4.11	104	4.09
100 ¹⁾	4	PN 16	Class 150	Table E, PN 16	10K	66	2.60	–	–	–	–
125	–	PN 16	–	–	10K	127	4.99	130	5.11	129	5.08
125 ¹⁾	–	PN 16	–	–	10K	79	3.11	–	–	–	–
150	6	PN 16	Class 150	Table E, PN 16	10K	155	6.11	158	6.23	156	6.15
150 ¹⁾	6	PN 16	Class 150	Table E, PN 16	10K	102	4.02	–	–	–	–
200	8	PN 10	Class 150	Table E, PN 16	10K	204	8.02	207	8.14	202	7.96
200 ¹⁾	8	PN 16	Class 150	Table E, PN 16	10K	127	5.00	–	–	–	–
250	10	PN 10	Class 150	Table E, PN 16	10K	258	10.14	261	10.26	256	10.09
250 ¹⁾	10	PN 16	Class 150	Table E, PN 16	10K	156	6.14	–	–	–	–
300	12	PN 10	Class 150	Table E, PN 16	10K	309	12.15	312	12.26	306	12.03
300 ¹⁾	12	PN 16	Class 150	Table E, PN 16	10K	204	8.03	–	–	–	–
350	14	PN 10	Class 150	Table E, PN 16	10K	337	13.3	340	13.4	–	–
375	15	–	–	PN 16	10K	389	15.3	392	15.4	–	–
400	16	PN 10	Class 150	Table E, PN 16	10K	387	15.2	390	15.4	–	–
450	18	PN 10	Class 150	–	10K	436	17.2	439	17.3	–	–
500	20	PN 10	Class 150	Table E, PN 16	10K	487	19.2	490	19.3	–	–
600	24	PN 10	Class 150	Table E, PN 16	10K	585	23.0	588	23.1	–	–
700	28	PN 10	Class D	Table E, PN 16	10K	694	27.3	697	27.4	–	–
750	30	–	Class D	Table E, PN 16	10K	743	29.3	746	29.4	–	–

Nominal diameter		Pressure rating				Measuring tube internal diameter					
		EN (DIN)	ASME AWWA	AS 2129 AS 4087	JIS	Hard rubber		Polyurethane		PTFE	
[mm]	[in]					[mm]	[in]	[mm]	[in]	[mm]	[in]
800	32	PN 10	Class D	Table E, PN 16	–	794	31.3	797	31.4	–	–
900	36	PN 10	Class D	Table E, PN 16	–	895	35.2	898	35.4	–	–
1000	40	PN 6	Class D	Table E, PN 16	–	991	39.0	994	39.1	–	–
–	42	–	Class D	–	–	1043	41.1	1043	41.1	–	–
1200	48	PN 6	Class D	Table E, PN 16	–	1191	46.9	1197	47.1	–	–
–	54	–	Class D	–	–	1339	52.7	–	–	–	–
1400	–	PN 6	–	–	–	1402	55.2	–	–	–	–
–	60	–	Class D	–	–	1492	58.7	–	–	–	–
1600	–	PN 6	–	–	–	1600	63.0	–	–	–	–
–	66	–	Class D	–	–	1638	64.5	–	–	–	–
1800	72	PN 6	–	–	–	1786	70.3	–	–	–	–
–	78	–	Class D	–	–	1989	78.3	–	–	–	–
2000	–	PN 6	–	–	–	1989	78.3	–	–	–	–
–	84	–	Class D	–	–	2099	84.0	–	–	–	–
2200	–	PN 6	–	–	–	2194	87.8	–	–	–	–
–	90	–	Class D	–	–	2246	89.8	–	–	–	–
2400	–	PN 6	–	–	–	2391	94.1	–	–	–	–
–	96	–	Class D	–	–	2382	93.8	–	–	–	–
–	102	–	Class D	–	–	2533	99.7	–	–	–	–
2600	–	PN 6	–	–	–	2580	101.6	–	–	–	–
–	108	–	Class D	–	–	2683	105.6	–	–	–	–
2800	–	PN 6	–	–	–	2780	109.5	–	–	–	–
–	114	–	Class D	–	–	2832	111.5	–	–	–	–
3000	–	PN 6	–	–	–	2976	117.2	–	–	–	–
–	120	–	Class D	–	–	2980	117.3	–	–	–	–

1) Order code for "Design", option C

Materials

Transmitter housing

Compact version

- Order code for "Housing", option **A** "Compact, alu, coated": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option **M**: polycarbonate plastic
- Window material:
 - For order code for "Housing", option **A**: glass
 - For order code for "Housing", option **M**: plastic


Remote version (wall-mount housing)

- Order code for "Housing", option **P** "Remote, alu, coated":
Aluminum, AlSi10Mg, coated
- Order code for "Housing", option **N**: polycarbonate plastic
- Window material:
 - For order code for "Housing", option **P**: glass
 - For order code for "Housing", option **N**: plastic

Sensor connection housing

- Aluminum, AlSi10Mg, coated
- Polycarbonate plastic (only in conjunction with order code for "Sensor option", options CA, C3, CB, CC, CD, CD)

Cable entries/cable glands



A0020640

29 Possible cable entries/cable glands

- 1 Female thread M20 × 1.5
- 2 Cable gland M20 × 1.5
- 3 Adapter for cable entry with female thread G ½" or NPT ½"

Compact and remote versions and sensor connection housing

Cable entry/cable gland	Material
Cable gland M20 × 1.5	<ul style="list-style-type: none">■ Plastic■ Nickel-plated brass
Remote version: cable gland M20 × 1.5 Option of armored connecting cable	<ul style="list-style-type: none">■ Sensor connection housing: Nickel-plated brass■ Transmitter wall-mount housing: Plastic
Adapter for cable entry with female thread G ½" or NPT ½"	Nickel-plated brass

Device plug

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none">■ Socket: Stainless steel, 1.4404 (316L)■ Contact housing: Polyamide■ Contacts: Gold-plated brass

Remote version connecting cable

- UV rays can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Electrode and coil current cable:

- Standard cable: PVC cable with copper shield
- Armored cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor housing

- DN 25 to 300 (1 to 12")
 - Aluminum half-shell housing, aluminum, AlSi10Mg, coated
 - Fully welded carbon steel housing with protective varnish
- DN 350 to 3000 (14 to 120")
 - Fully welded carbon steel housing with protective varnish

Measuring tubes

- DN 25 to 600 (1 to 24")
 - Stainless steel: 1.4301, 1.4306, 304, 304L
- DN 700 to 3000 (28 to 120")
 - Stainless steel: 1.4301, 304



Liner

- DN 25 to 300 (1 to 12"): PTFE
- DN 25 to 1200 (1 to 48"): polyurethane
- DN 50 to 3000 (2 to 120"): hard rubber

Electrodes

- Stainless steel, 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

Process connections

-  For flanges made of carbon steel:
 - DN ≤ 300 (12"): with Al/Zn protective coating or protective varnish
 - DN ≥ 350 (14"): protective varnish
-  All carbon steel lap joint flanges are supplied with a hot-dip galvanized finish.

EN 1092-1 (DIN 2501)

Fixed flange

- Carbon steel:
 - DN ≤ 300: S235JRG2, S235JR+N, P245GH, A105, E250C
 - DN 350 to 3000: P245GH, S235JRG2, A105, E250C
- Stainless steel:
 - DN ≤ 300: 1.4404, 1.4571, F316L
 - DN 350 to 600: 1.4571, F316L, 1.4404
 - DN 700 to 1000: 1.4404, F316L

Lap joint flange

- Carbon steel DN ≤ 300: S235JRG2, A105, E250C
- Stainless steel DN ≤ 300: 1.4306, 1.4404, 1.4571, F316L

Lap joint flange, stamped plate

- Carbon steel DN ≤ 300: S235JRG2 similar to S235JR+AR or 1.0038
- Stainless steel DN ≤ 300: 1.4301 similar to 304

ASME B16.5

Fixed flange, lap joint flange

- Carbon steel: A105
- Stainless steel: F316L

JIS B2220

- Carbon steel: A105, A350 LF2
- Stainless steel: F316L

AWWA C207

Carbon steel: A105, P265GH, A181 Class 70, E250C, S275JR

AS 2129

Carbon steel: A105, E250C, P235GH, P265GH, S235JRG2

AS 4087

Carbon steel: A105, P265GH, S275JR

Seals

As per DIN EN 1514-1, form IBC

Accessories

Display guard

Stainless steel, 1.4301 (304L)

Ground disks

- Stainless steel, 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

Fitted electrodes

Measurement, reference and empty pipe detection electrodes available as standard with:

- 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Tantalum

Process connections

- EN 1092-1 (DIN 2501)
- ASME B16.5
- JIS B2220
- AS 2129 Table E
- AS 4087 PN 16
- AWWA C207 Class D



For information on the different materials used in the process connections → 197

Surface roughness

Electrodes with 1.4435 (316L); Alloy C22, 2.4602 (UNS N06022); tantalum:
< 0.5 µm (19.7 µin)

(All data relate to parts in contact with medium)

16.11 Human interface

Languages

Can be operated in the following languages:

- Via local operation:
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool:
English, German, French, Spanish, Italian, Chinese, Japanese
- Via Web browser
English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech, Swedish


Local operation

Via display module


Equipment:

- Standard features 4-line, illuminated, graphic display; touch control
- Order code for "Display; operation", option BA "WLAN" offers standard equipment features in addition to access via Web browser

 Information about WLAN interface →  82






A0032074

 30 Operation with touch control


Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to $+60$ °C (-4 to $+140$ °F)
The readability of the display may be impaired at temperatures outside the temperature range.


Operating elements

- External operation via touch control (3 optical keys) without opening the housing: , , 
- Operating elements also accessible in the various zones of the hazardous area

Remote operation



→  81

Service interface

→  82

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	<ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface ■ Ethernet-based fieldbus (EtherNet/IP) 	Special Documentation for the device
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	<ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface ■ Fieldbus protocol 	→  172
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	<ul style="list-style-type: none"> ■ CDI-RJ45 service interface ■ WLAN interface ■ Fieldbus protocol 	→  172

 Other operating tools based on FDT technology with a device driver such as DTM/iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:

- Field Device Manager (FDM) from Honeywell → www.honeywellprocess.com
- FieldMate from Yokogawa → www.yokogawa.com
- PACTWare → www.pactware.com


The related device description files are available: www.endress.com → Downloads



Web server

Thanks to the integrated Web server, the device can be operated and configured via a Web browser and via a service interface (CDI-RJ45). The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed, allowing users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration
- Visualize up to 1000 saved measured values (only available with the **Extended HistoROM** application package →  204)

 Web server special documentation →  205

HistoROM data management

The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	HistoROM backup	T-DAT	S-DAT
Available data	<ul style="list-style-type: none"> ■ Event logbook such as diagnostic events for example ■ Device firmware package ■ Driver for system integration for exporting via Web server, e.g.: EDS for EtherNet/IP 	<ul style="list-style-type: none"> ■ Measured value logging ("Extended HistoROM" order option) ■ Current parameter data record (used by firmware at run time) ■ Peakhold indicator (min/max values) ■ Totalizer values 	<ul style="list-style-type: none"> ■ Sensor data: nominal diameter etc. ■ Serial number ■ Calibration data ■ Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors

Data transmission

Manual

- Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)
- Transmission of the drivers for system integration via Web server, e.g.: EDS for EtherNet/IP

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:



- Record up to 1 000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Current certificates and approvals for the product are available via the Product Configurator at www.endress.com.

1. Select the product using the filters and search field.
2. Open the product page.

The **Configuration** button opens the Product Configurator.

CE mark	<p>The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
UKCA marking	<p>The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.</p> <p>Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com</p>
RCM mark	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Control Drawing" document. Reference is made to this document on the nameplate.</p>
Drinking water approval	<ul style="list-style-type: none"> ■ ACS ■ KTW/W270 ■ NSF 61 ■ WRAS BS 6920
EtherNet/IP certification	<p>The measuring device is certified and registered by the ODVA (Open Device Vendor Association). The measuring system meets all the requirements of the following specifications:</p> <ul style="list-style-type: none"> ■ Certified in accordance with the ODVA Conformance Test ■ EtherNet/IP Performance Test ■ EtherNet/IP PlugFest compliance ■ The device can also be operated with certified devices of other manufacturers (interoperability)
Radio approval	<p>The measuring device has radio approval.</p> <p> For detailed information regarding radio approval, see the Special Documentation →  205</p>

Measuring instrument approval	<p>The measuring device is (optionally) approved as a cold water meter (MI-001) for volume measurement in service subject to legal metrological control in accordance with the European Measuring Instruments Directive 2014/32/EU (MID).</p> <p>The measuring device is qualified to OIML R49: 2013.</p>
Other standards and guidelines	<ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosures (IP code) ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements ■ IEC/EN 61326-3-2 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). ■ ANSI/ISA-61010-1 (82.02.01) Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements ■ CAN/CSA-C22.2 No. 61010-1-12 Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements ■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment ■ NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics ■ NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices ■ NAMUR NE 107 Self-monitoring and diagnosis of field devices ■ NAMUR NE 131 Requirements for field devices for standard applications

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Cleaning	Package	Description
	Electrode cleaning circuit (ECC)	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe ₃ O ₄) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to avoid build-up of very conductive matter and thin layers (typical of magnetite).



Diagnostics functions

Package	Description
Extended HistoROM	<p>Comprises extended functions concerning the event log and the activation of the measured value memory.</p> <p>Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.</p> <p>Data logging (line recorder):</p> <ul style="list-style-type: none"> Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.


Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	<p>Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".</p> <ul style="list-style-type: none"> Functional testing in the installed state without interrupting the process. Traceable verification results on request, including a report. Simple testing process via local operation or other operating interfaces. Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications. Extension of calibration intervals according to operator's risk assessment. <p>Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to:</p> <ul style="list-style-type: none"> Draw conclusions - using these data and other information - about the impact process influences (such as corrosion, abrasion, buildup etc.) have on the measuring performance over time. Schedule servicing in time. Monitor the process or product quality, e.g. gas pockets.

16.14 Accessories

 Overview of accessories available for order →  171

16.15 Supplementary documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- Endress+Hauser Operations App: Enter the serial number from the nameplate or scan the matrix code on the nameplate

Standard documentation

Technical Information

Measuring device	Documentation code
Promag W 400	TI01046D

Brief Operating Instructions*Brief Operating Instructions for the sensor*

Measuring device	Documentation code
Proline Promag W	KA01266D

Brief Operating Instructions for the transmitter

Measuring device	Documentation code
Proline 400	KA01418D

Description of device parameters



Measuring device	Documentation code
Promag 400	GP01046D

Supplementary device-
dependent documentation

Special Documentation

Content	Documentation code
Web server	SD01814D
Heartbeat Verification + Monitoring application package	SD02570D
Display modules A309/A310	SD01793D

Installation Instructions

Content	Comment
Installation instructions for spare part sets and accessories	<ul style="list-style-type: none"> Access the overview of all the available spare part sets via <i>W@M Device Viewer</i> →  169 Accessories available for order with Installation Instructions →  171

Index

A

Access authorization to parameters	
Read access	73
Write access	73
Access code	73
Incorrect input	73
Adapters	26
Adapting the diagnostic behavior	151
Ambient temperature	
Influence	184
Ambient temperature range	25
Application	174
Applicator	174
Approvals	202

C

Cable entries	
Technical data	182
Cable entry	
Degree of protection	57
CE mark	10, 202
Certificates	202
Checklist	
Post-connection check	58
Post-installation check	40
Cleaning	
Exterior cleaning	168
Interior cleaning	168
Commissioning	113
Advanced settings	122
Configuring the measuring device	114
Conductivity	187
Connecting cable	41
Connecting the measuring device	46
Connection	
see Electrical connection	
Connection preparations	44
Connection tools	41
Context menu	
Calling up	68
Closing	68
Explanation	68
Current consumption	181

D

Date of manufacture	15
Declaration of Conformity	10
Define access code	133, 134
Degree of protection	57, 185
Design	
Measuring device	13
Designated use	9
Device components	13
Device description files	86
Device documentation	
Supplementary documentation	8

Device locking, status	136
Device name	
Sensor	15
Transmitter	15
Device profile	86
Device repair	169
Device revision	86
Device type ID	86
DeviceCare	84
Device description file	86
Diagnostic behavior	
Explanation	147
Symbols	147
Diagnostic information	
Communication interface	151
Design, description	147, 150
DeviceCare	149
FieldCare	149
Light emitting diodes	145
Local display	146
Overview	152
Remedial measures	152
Web browser	148
Diagnostic list	162
Diagnostic message	146
Diagnostics	
Symbols	146
Dimensions	25
DIP switch	
see Write protection switch	
Direct access	70
Direct access code	64
Disabling write protection	133
Display	
see Local display	
Display area	
For operational display	63
In the navigation view	65
Display values	
For locking status	136
Disposal	170
Document	
Function	6
Symbols	6
Document function	6
Down pipe	19
Drinking water approval	202

E

ECC	128
Electrical connection	
Degree of protection	57
Measuring device	41
Operating tools	
Via Ethernet network	81
Via service interface (CDI-RJ45)	82

Via WLAN interface	82
RSLogix 5000	81
Web server	82
WLAN interface	82
Electromagnetic compatibility	187
Enabling write protection	133
Enabling/disabling the keypad lock	74
Endress+Hauser services	
Maintenance	168
Repair	169
Environment	
Ambient temperature	25
Mechanical load	186
Storage temperature	185
Vibration- and shock-resistance	186
Error messages	
see Diagnostic messages	
EtherNet/IP	
Diagnostic information	151
EtherNet/IP certification	202
Event list	163
Event logbook	163
Ex approval	202
Extended order code	
Sensor	15
Transmitter	15
Exterior cleaning	168
F	
Field of application	
Residual risks	10
Field Xpert SMT70	85
Field Xpert SMT77	85
FieldCare	83
Device description file	86
Establishing a connection	84
Function	83
User interface	84
Filtering the event logbook	164
Firmware	
Release date	86
Version	86
Firmware history	167
Fitted electrodes	198
Fix assembly	151
Flow direction	21
Flow limit	188
Function check	113
Functions	
see Parameters	
G	
Galvanic isolation	180
H	
Hardware write protection	134
Heavy sensors	20
Help text	
Calling up	71

Closing	71
Explanation	71
I	
I/O electronics module	13, 49
Identifying the measuring device	14
Immersion in water	27
Installation conditions	27
Implicit data transmission	87
Incoming acceptance	14
Influence	
Ambient temperature	184
Information on the document	6
Inlet runs	23
Input	174
Input mask	66
Inspection	
Connection	58
Installation	40
Received goods	14
Installation	19
Installation conditions	
Adapters	26
Dimensions	25
Down pipe	19
Heavy sensors	20
Inlet and outlet runs	23
Length of connecting cable	26
Mounting location	19
Orientation	21
Partially filled pipe	20
System pressure	25, 189
Vibrations	25, 189
Interior cleaning	168
L	
Languages, operation options	199
Length of connecting cable	26
Line recorder	140
Local display	199
Editing view	66
Navigation view	64
see Diagnostic message	
see In alarm condition	
see Operational display	
Low flow cut off	180
M	
Main electronics module	13
Maintenance tasks	168
Manufacturer ID	86
Materials	195
Maximum measured error	182
Measured variables	
Calculated	174
Measured	174
see Process variables	
Measuring and test equipment	168

Measuring device		
Configuration	114	
Conversion	169	
Design	13	
Disposal	170	
Integrating via communication protocol	86	
Mounting the sensor	29	
Mounting the ground cable/ground disks	29	
Mounting the seals	29	
Screw tightening torques	30	
Screw tightening torques, maximum	30	
Screw tightening torques, nominal	35	
Preparing for electrical connection	44	
Preparing for mounting	29	
Removing	170	
Repairs	169	
Switch-on	113	
Measuring instrument approval	203	
Measuring principle	174	
Measuring range	174	
Measuring system	174	
Measuring tube specification	194	
Mechanical load	186	
Medium temperature range	187	
Menu		
Diagnostics	161	
Setup	114, 115	
Menus		
For measuring device configuration	114	
For specific settings	122	
Mounting dimensions		
see Dimensions		
Mounting location	19	
Mounting preparations	29	
Mounting tool	28	
N		
Nameplate		
Sensor	15	
Transmitter	15	
Navigation path (navigation view)	64	
Navigation view		
In the submenu	64	
In the wizard	64	
Numeric editor	66	
O		
Operable flow range	179	
Operating elements	67, 147	
Operating keys		
see Operating elements		
Operating menu		
Menus, submenus	60	
Structure	60	
Submenus and user roles	61	
Operating philosophy	61	
Operation	136	
Operation methods	59	
Operational display	62	
Operational safety	10	
Order code	15	
Orientation (vertical, horizontal)	21	
Outlet runs	23	
Output	179	
Output signal	179	
P		
Packaging disposal	18	
Parameter		
Changing	72	
Entering a value	72	
Parameter settings		
Administration (Submenu)	132	
Advanced setup (Submenu)	123	
Communication (Submenu)	117	
Data logging (Submenu)	140	
Define access code (Wizard)	131	
Device information (Submenu)	165	
Diagnostics (Menu)	161	
Display (Submenu)	125	
Display (Wizard)	118	
Electrode cleaning cycle (Submenu)	128	
Empty pipe detection (Wizard)	121	
Low flow cut off (Wizard)	120	
Process variables (Submenu)	137	
Reset access code (Submenu)	131	
Sensor adjustment (Submenu)	123	
Setup (Menu)	115	
Simulation (Submenu)	132	
System units (Submenu)	116	
Totalizer (Submenu)	138	
Totalizer 1 to n (Submenu)	123	
Totalizer handling (Submenu)	139	
Web server (Submenu)	80	
WLAN settings (Wizard)	128	
Partially filled pipe	20	
Performance characteristics	182	
Post-connection check (checklist)	58	
Post-installation check	113	
Post-installation check (checklist)	40	
Potential equalization	52	
Power consumption	181	
Power supply failure	182	
Pressure loss	188	
Pressure tightness	187	
Pressure-temperature ratings	187	
Process conditions		
Conductivity	187	
Flow limit	188	
Medium temperature	187	
Pressure loss	188	
Pressure tightness	187	
Process connections	198	
Product safety	10	
Protecting parameter settings	133	
R		
Radio approval	202	

- RCM mark 202
- Read access 73
- Reading measured values 137
- Reading out diagnostic information, EtherNet/IP . . . 151
- Recalibration 168
- Reference operating conditions 182
- Registered trademarks 8
- Remedial measures
 - Calling up 148
 - Closing 148
- Remote operation 199
- Remote version
 - Connecting the signal cables 46
- Repair 169
 - Notes 169
- Repair of a device 169
- Repeatability 184
- Replacement
 - Device components 169
- Requirements for personnel 9
- Return 169
- S**
- Safety 9
- Screw tightening torques 30
 - Maximum 30
 - Nominal 35
- Sensor
 - Mounting 29
- Serial number 15
- Setting the operating language 113
- Settings
 - Adapting the measuring device to the process conditions 139
 - Administration 130
 - Advanced display configurations 125
 - Communication interface 117
 - Device reset 165
 - Electrode cleaning circuit (ECC) 128
 - Empty pipe detection (EPD) 121
 - Local display 118
 - Low flow cut off 120
 - Operating language 113
 - Resetting the totalizer 139
 - Sensor adjustment 123
 - Simulation 132
 - System units 116
 - Tag name 115
 - Totalizer 123
 - Totalizer reset 139
 - WLAN 128
- Showing data logging 140
- Signal on alarm 179
- Software release 86
- Spare part 169
- Spare parts 169
- Special connection instructions 56
- Standards and guidelines 203
- Status area
 - For operational display 62
 - In the navigation view 64
- Status signals 146, 149
- Storage concept 201
- Storage conditions 17
- Storage temperature 17
- Storage temperature range 185
- Structure
 - Operating menu 60
- Submenu
 - Administration 130, 132
 - Advanced setup 122, 123
 - Communication 117
 - Data logging 140
 - Device information 165
 - Display 125
 - Electrode cleaning cycle 128
 - Event list 163
 - Output values 137
 - Overview 61
 - Process variables 137
 - Reset access code 131
 - Sensor adjustment 123
 - Simulation 132
 - System units 116
 - Totalizer 138
 - Totalizer 1 to n 123
 - Totalizer handling 139
 - Web server 80
- Supplementary documentation 204
- Supply voltage 181
- Surface roughness 198
- Symbols
 - For communication 62
 - For correction 66
 - For diagnostic behavior 62
 - For locking 62
 - For measured variable 63
 - For measurement channel number 63
 - For menus 65
 - For parameters 65
 - For status signal 62
 - For submenu 65
 - For wizard 65
 - In the status area of the local display 62
 - In the text and numeric editor 66
- System design
 - Measuring system 174
 - see Measuring device design
- System file
 - Release date 86
 - Source 86
 - Version 86
- System integration 86
- System pressure 25, 189
- T**
- Technical data, overview 174

Temperature range		
Ambient temperature range for display	199	
Storage temperature	17	
Terminal assignment	43, 46, 49	
Terminals	182	
Text editor	66	
Tool		
For mounting	28	
Tool tip		
see Help text		
Tools		
Electrical connection	41	
Transport	17	
Totalizer		
Configuring	123	
Transmitter		
Connecting the signal cables	49	
Turning the display module	39	
Turning the housing	37	
Transporting the measuring device	17	
Troubleshooting		
General	143	
Turning the display module	39	
Turning the electronics housing		
see Turning the transmitter housing		
Turning the transmitter housing	37	
U		
UKCA marking	202	
Use in buried applications	28	
Installation conditions	28	
Use in saline water	27	
Use of the measuring device		
Borderline cases	9	
Incorrect use	9	
see Designated use		
User interface		
Current diagnostic event	161	
Previous diagnostic event	161	
User roles	61	
V		
Version data for the device	86	
Vibration- and shock-resistance	186	
Vibrations	25, 189	
W		
W@M	168, 169	
W@M Device Viewer	14, 169	
Weight		
Transport (notes)	17	
Wizard		
Define access code	131	
Display	118	
Empty pipe detection	121	
Low flow cut off	120	
WLAN settings	128	
WLAN settings	128	
Workplace safety	10	
Write access	73	
Write protection		
Via access code	133	
Via write protection switch	134	
Write protection switch	134	



71541968

www.addresses.endress.com
