

Description of Device Parameters

Proline Promag 400

PROFIBUS DP

Electromagnetic flowmeter




Table of contents

1 About this document	4		
1.1 Document function	4	3.9.4 "Main electronic module + I/O module 1" submenu	171
1.2 Target group	4	3.9.5 "Sensor electronic module (ISEM)" submenu	172
1.3 Using this document	4	3.9.6 "Display module" submenu	173
1.3.1 Information on the document structure	4	3.9.7 "Min/max values" submenu	174
1.3.2 Structure of a parameter description ..	6	3.9.8 "Data logging" submenu	176
1.4 Symbols used	6	3.9.9 "Heartbeat" submenu	184
1.4.1 Symbols for certain types of information	6	3.9.10 "Simulation" submenu	184
1.5 Documentation	7		
1.5.1 Standard documentation	7		
1.5.2 Supplementary device-dependent documentation	7		
2 Overview of the Expert operating menu	8		
3 Description of device parameters ...	11		
3.1 "System" submenu	14	4 Country-specific factory settings ..	187
3.1.1 "Display" submenu	14	4.1 SI units	187
3.1.2 "Diagnostic handling" submenu	27	4.1.1 System units	187
3.1.3 "Administration" submenu	34	4.1.2 Full scale values	187
3.2 "Sensor" submenu	39	4.1.3 Switch-on point low flow cut off	188
3.2.1 "Measured values" submenu	40	4.2 US units	189
3.2.2 "System units" submenu	44	4.2.1 System units	189
3.2.3 "Process parameters" submenu	51	4.2.2 Full scale values	189
3.2.4 "External compensation" submenu ...	67	4.2.3 Switch-on point low flow cut off ...	190
3.2.5 "Sensor adjustment" submenu	69		
3.2.6 "Calibration" submenu	76		
3.3 "Communication" submenu	78		
3.3.1 "PROFIBUS DP configuration" submenu	78	5 Explanation of abbreviated units ..	192
3.3.2 "PROFIBUS DP info" submenu	80	5.1 SI units	192
3.3.3 "Physical block" submenu	82	5.2 US units	192
3.3.4 "Address shifting configuration" submenu	91	5.3 Imperial units	193
3.3.5 "Web server" submenu	91		
3.3.6 "WLAN settings" wizard	95		
3.4 "Analog inputs" submenu	101	Index	194
3.4.1 "Analog input 1 to n" submenu	101		
3.5 "Discrete inputs" submenu	115		
3.5.1 "Discrete input 1 to n" submenu	115		
3.6 "Analog outputs" submenu	122		
3.6.1 "Analog output 1 to n" submenu	122		
3.7 "Discrete outputs" submenu	134		
3.7.1 "Discrete output 1 to n" submenu ...	134		
3.8 "Application" submenu	144		
3.8.1 "Totalizer 1 to n" submenu	145		
3.9 "Diagnostics" submenu	158		
3.9.1 "Diagnostic list" submenu	161		
3.9.2 "Event logbook" submenu	166		
3.9.3 "Device information" submenu	168		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
Navigation path to the parameter via the operating tool
The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Promag D 400	BA01232D
Promag L 400	BA01233D
Promag W 400	BA01234D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Content	Documentation code
Heartbeat Verification + Monitoring application package	SD02569D
Display modules A309/A310	SD01793D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access status (0005)	→ 13
Enter access code (0003)	→ 14
 System	→ 14
► Display	→ 14
► Diagnostic handling	→ 27
► Administration	→ 34
 Sensor	→ 39
► Measured values	→ 40
► System units	→ 44
► Process parameters	→ 51
► External compensation	→ 67
► Sensor adjustment	→ 69
► Calibration	→ 76
 Communication	→ 78
► PROFIBUS DP configuration	→ 78
► PROFIBUS DP info	→ 80
► Physical block	→ 82
► Address shifting configuration	→ 91

▶ Web server	→ 91
▶ WLAN settings	→ 95
▶ Analog inputs	→ 101
▶ Analog input 1 to n	→ 101
▶ Discrete inputs	→ 115
▶ Discrete input 1 to n	→ 115
▶ Analog outputs	→ 122
▶ Analog output 1 to n	→ 122
▶ Discrete outputs	→ 134
▶ Discrete output 1 to n	→ 134
▶ Application	→ 144
Reset all totalizers (2806)	→ 144
▶ Totalizer 1 to n	→ 145
▶ Diagnostics	→ 158
Actual diagnostics (0691)	→ 159
Previous diagnostics (0690)	→ 160
Operating time from restart (0653)	→ 161
Operating time (0652)	→ 161
▶ Diagnostic list	→ 161
▶ Event logbook	→ 166
▶ Device information	→ 168
▶ Main electronic module	→ 171
▶ Sensor electronic module (ISEM)	→ 172
▶ Display module	→ 173
▶ Min/max values	→ 174

► Data logging	→ 176
► Heartbeat Technology	→ 184
► Simulation	→ 184

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Navigation

 Expert

 Expert	
Direct access (0106)	→  11
Locking status (0004)	→  12
Access status (0005)	→  13
Enter access code (0003)	→  14
▶ System	→  14
▶ Sensor	→  39
▶ Communication	→  78
▶ Analog inputs	→  101
▶ Discrete inputs	→  115
▶ Analog outputs	→  122
▶ Discrete outputs	→  134
▶ Application	→  144
▶ Diagnostics	→  158

Direct access



Navigation

 Expert → Direct access (0106)

Description


Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.

User entry

0 to 65 535

Additional information*User entry*

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter **"914"** instead of **"00914"**
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter **00914** → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter **00914-2** → **Assign process variable** parameter

Locking status

Navigation

Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7

Selection

Options	Description
None	The access status displayed in the Access status display parameter (→  13) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked (priority 2)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status display

Navigation	 Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→ 14).</p> <p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device → 7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → 7</p>

Access status

Navigation	 Expert → Access status (0005)
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance

Additional information*Description*

 Access authorization can be modified via the **Enter access code** parameter
(→ [14](#)).

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

Enter access code**Navigation**

 Expert → Ent. access code (0003)

Description

Use this function to enter the user-specific release code to remove parameter write protection.


User entry

Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation


 Expert → System



3.1.1 "Display" submenu

Navigation

 Expert → System → Display



0% bargraph value 1 (0123)	→ 18
100% bargraph value 1 (0125)	→ 19
Decimal places 1 (0095)	→ 19
Value 2 display (0108)	→ 20
Decimal places 2 (0117)	→ 20
Value 3 display (0110)	→ 21
0% bargraph value 3 (0124)	→ 21
100% bargraph value 3 (0126)	→ 22
Decimal places 3 (0118)	→ 22
Value 4 display (0109)	→ 22
Decimal places 4 (0119)	→ 23
Display interval (0096)	→ 23
Display damping (0094)	→ 24
Header (0097)	→ 24
Header text (0112)	→ 25
Separator (0101)	→ 26
Contrast display (0105)	→ 26
Backlight (0111)	→ 26

Display language

Navigation

Expert → System → Display → Display language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français

- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting

English (alternatively, the ordered language is preset in the device)

Format display**Navigation**
 Expert → System → Display → Format display (0098)
Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 22) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 23).


* Visibility depends on order options or device settings

Possible measured values shown on the local display:


"1 value, max. size" option




"1 bargraph + 1 value" option




"2 values" option



"1 value large + 2 values" option



"4 values" option



Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none">■ Volume flow■ Mass flow■ Corrected volume flow■ Flow velocity *■ Conductivity *■ Corrected conductivity *■ Totalizer 1■ Totalizer 2■ Totalizer 3■ Electronics temperature■ Noise *■ Coil current shot time *■ Reference electrode potential against PE *■ Build-up measured value *■ Test point 1■ Test point 2■ Test point 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 44).</p>

0% bargraph value 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 44).</p>

100% bargraph value 1



Navigation	 Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 187
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 44).</p>

Decimal places 1



Navigation	 Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is defined in the Value 1 display parameter (→ 18).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none"> ■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX
Factory setting	X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ 18)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 44).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 18)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 44).

0% bargraph value 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 21).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Description</i> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 44).

100% bargraph value 3



Navigation

Expert → System → Display → 100% bargraph 3 (0126)

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information

Description

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 44).

Decimal places 3



Navigation

Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 21).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information

Description

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display



Navigation

Expert → System → Display → Value 4 display (0109)

Prerequisite

A local display is provided.

Description	Use this function to select one of the measured values shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 18)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 44).</p>

Decimal places 4



Navigation	 Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (→ 22).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	<ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Display interval

Navigation	 Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 22) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Display damping



Navigation

Expert → System → Display → Display damping (0094)

Prerequisite

A local display is provided.

Description

Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

0.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

Header



Navigation

Expert → System → Display → Header (0097)

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection

- Device tag
- Free text


Factory setting

Device tag

1) proportional transmission behavior with first order delay

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 168).
- Free text
Is defined in the **Header text** parameter (→ 25).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 24), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation Expert → System → Display → Separator (0101)

Prerequisite A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting 50 %

Backlight

Navigation Expert → System → Display → Backlight (0111)

Prerequisite A local display is provided.

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Enable

Access status display

Navigation Expert → System → Display → Access stat.disp (0091)


Prerequisite A local display is provided.

Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  14).</p> <p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

3.1.2 "Diagnostic handling" submenu

Navigation

 Expert → System → Diagn. handling



Alarm delay

Navigation

 Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

 The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- 190 Special event 1
- 832 Electronics temperature too high
- 833 Electronics temperature too low
- 862 Pipe empty
- 990 Special event 4

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 28).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The output of measured values via PROFIBUS and totalizers is not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is only displayed in the Event logbook submenu (→ 166) (Event list submenu (→ 166)) and is not displayed in alternating sequence with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

 For a list of all the diagnostic events, see the Operating Instructions for the device
→ 7

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

► Diagnostic behavior

Assign behavior of diagnostic no. 043 (0650)	→ 29
Assign behavior of diagnostic no. 302 (0739)	→ 30
Assign behavior of diagnostic no. 376 (0645)	→ 30
Assign behavior of diagnostic no. 377 (0777)	→ 30
Assign behavior of diagnostic no. 531 (0741)	→ 31

Assign behavior of diagnostic no. 832 (0681)	→ 31
Assign behavior of diagnostic no. 833 (0682)	→ 31
Assign behavior of diagnostic no. 834 (0700)	→ 32
Assign behavior of diagnostic no. 835 (0702)	→ 32
Assign behavior of diagnostic no. 842 (0638)	→ 32
Assign behavior of diagnostic no. 962 (0745)	→ 33
Assign behavior of diagnostic no. 937 (0743)	→ 33
Assign behavior of diagnostic no. 938 (0642)	→ 33
Assign behavior of diagnostic no. 961 (0736)	→ 34

Assign behavior of diagnostic no. 043 (Sensor short circuit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 043 (0650)

Description

Use this function to change the diagnostic behavior of the **043 Sensor short circuit** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 302 (Device verification active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0739)

Description

Use this function to change the diagnostic behavior of the **302 Device verification active** diagnostic message.

Selection

- Alarm
- Warning

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 376 (Sensor electronics (ISEM) faulty)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 376 (0645)

Description

Use this function to change the diagnostic behavior of the **376 Sensor electronics (ISEM) faulty** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 377 (Sensor electronics (ISEM) faulty)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 377 (0777)

Description

Use this function to change the diagnostic behavior of the **377 Sensor electronics (ISEM) faulty** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 531 (Empty pipe detection)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531 (0741)
Description	Use this function to change the diagnostic behavior of the 531 Empty pipe detection diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 832 (Electronics temperature too high)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0681)
Description	Use this function to change the diagnostic behavior of the 832 Electronics temperature too high diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Logbook entry only
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 833 (Electronics temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0682)
Description	Use this function to change the diagnostic behavior of the 833 Electronics temperature too low diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Logbook entry only
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 834 (Process temperature too high)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0700)

Description

Use this function to change the diagnostic behavior of the **834 Process temperature too high** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 835 (Process temperature too low)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0702)

Description

Use this function to change the diagnostic behavior of the **835 Process temperature too low** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 842**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)

Description

Change behavior of diagnostic event with diagnostic number 842 'Process limit'.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Off

Assign behavior of diagnostic no. 962 (Pipe empty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 962 (0745)
Description	Use this function to change the diagnostic behavior of the 862 Pipe empty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 937 (EMC interference)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937 (0743)
Description	Use this function to change the diagnostic behavior of the 937 EMC interference diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 938 (EMC interference)




Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 938 (0642)
Description	Use this function to change the diagnostic behavior of the 938 EMC interference diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Alarm
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 961

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 961 (0736)
Description	Select diagnostic behavior for the selected diagnostic number.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Alarm

3.1.3 "Administration" submenu*Navigation*

Expert → System → Administration


**"Define access code" wizard**

The **Define access code** wizard (→ 34) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (→ 37) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code



Define access code

Navigation Expert → System → Administration → Def. access code → Def. access code

Description Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry 0 to 9 999

Factory setting 0

Additional information *Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 14).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code

Navigation Expert → System → Administration → Def. access code → Confirm code

Description Enter the defined release code a second time to confirm the release code.

User entry 0 to 9 999

Factory setting 0

"Reset access code" submenu

Navigation Expert → System → Administration → Reset acc. code

Reset access code

Operating time (0652)	→ 36
Reset access code (0024)	→ 36

Operating time

Navigation Expert → System → Administration → Reset acc. code → Operating time (0652)

Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

Reset access code

Navigation Expert → System → Administration → Reset acc. code → Reset acc. code (0024)

Description Use this function to enter a reset code to reset the user-specific access codes to the factory setting .

User entry Character string comprising numbers, letters and special characters

Factory setting 0x00

Additional information *Description*

For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via CDI RJ45 interface)
- Fieldbus

Additional parameters in the "Administration" submenu

Define access code


Navigation

Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information
Description

The write protection affects all parameters in the document marked with the symbol.

- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 14).
- If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Device reset


Navigation

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *

Factory setting

Cancel

* Visibility depends on order options or device settings

Activate SW option**Navigation**

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→ 39).
 - ↳ The new software option is active if it is displayed.
 - ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Web browser

Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation	  Expert → System → Administration → SW option overv. (0015)
Description	Displays all the software options that are enabled in the device.
User interface	<ul style="list-style-type: none"> ▪ Extended HistoROM ▪ Electrode cleaning circuit ▪ Heartbeat Verification ▪ Build-up index ▪ Heartbeat Monitoring
Additional information	<p><i>Description</i></p> <p>Displays all the options that are available if ordered by the customer.</p> <p><i>"Extended HistoROM" option</i></p> <p>Order code for "Application package", option EA "Extended HistoROM"</p> <p><i>"Electrode cleaning circuit" option</i></p> <p> Only available for Promag L and W.</p> <p>Order code for "Application package", option EC "ECC electrode cleaning"</p> <p><i>"Heartbeat Verification" option and "Heartbeat Monitoring" option</i></p> <p>Order code for "Application package", option EB "Heartbeat Verification + Monitoring"</p>

3.2 "Sensor" submenu

Navigation


  Expert → Sensor

 Sensor	
 Measured values	→  40
 System units	→  44
 Process parameters	→  51
 External compensation	→  67
 Sensor adjustment	→  69
 Calibration	→  76

3.2.1 "Measured values" submenu

Navigation


Expert → Sensor → Measured val.



"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.



Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description

Displays the volume flow that is currently measured.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Volume flow unit** parameter (→ 44)

Mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)
Description	Displays the mass flow that is currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→ 47)

Corrected volume flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1851)
Description	Displays the corrected volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Corrected volume flow unit parameter (→ 49)

Flow velocity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Flow velocity (1854)
Description	Displays the flow velocity that is currently calculated.
User interface	Signed floating-point number

Conductivity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Conductivity (1850)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Displays the conductivity that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→ 46)

Corrected conductivity

Navigation   Expert → Sensor → Measured val. → Process variab. → CorrConductivity (1853)

Prerequisite The following conditions are met:
■ The **On** option is selected in the **Conductivity measurement** parameter (→ [55](#)).
■ The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ [68](#)).

Description Displays the conductivity that is currently corrected.

User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Conductivity unit** parameter (→ [46](#))

Temperature

Navigation   Expert → Sensor → Measured val. → Process variab. → Temperature (1852)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ [68](#)).

Description Displays the temperature that is currently calculated.

User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [47](#))

Density


Navigation   Expert → Sensor → Measured val. → Process variab. → Density (1857)

Description Displays the current fixed density or density read in from an external device.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Density unit** parameter (→ [48](#))

"Totalizer" submenu*Navigation*
 Expert → Sensor → Measured val. → Totalizer
**Out value 1 to n****Navigation**
 Expert → Sensor → Measured val. → Totalizer → Out value 1 to n (3827-1 to n)
Prerequisite

The **Auto** option is selected in the **Target mode** parameter (→ 151).

Description

Displays the current reading for totalizer 1-3.

User interface

Signed floating-point number

Additional information*Description*

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 149).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 148).

Dependency

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Totalizer status (Hex) 1 to n**Navigation**
 Expert → Sensor → Measured val. → Totalizer → Status (Hex) 1 to n (3825-1 to n)
Prerequisite

In **Target mode** parameter (→ 151), the **Auto** option is selected.

Description

Displays the status value (hex) of the particular totalizer.

User interface

0 to 0xFF

Totalizer status 1 to n

Navigation  Expert → Sensor → Measured val. → Totalizer → Tot. status 1 to n (3826–1 to n)

Description Displays the status of the particular totalizer.

User interface

- Good
- Uncertain
- Bad

3.2.2 "System units" submenu

Navigation  Expert → Sensor → System units

► System units	
Volume flow unit (0553)	→  44
Volume unit (0563)	→  46
Conductivity unit (0582)	→  46
Temperature unit (0557)	→  47
Mass flow unit (0554)	→  47
Mass unit (0574)	→  48
Density unit (0555)	→  48
Corrected volume flow unit (0558)	→  49
Corrected volume unit (0575)	→  50
Date/time format (2812)	→  51

Volume flow unit



Navigation  Expert → Sensor → System units → Volume flow unit (0553)

Description Use this function to select the unit for the volume flow.

Selection	SI units	US units	Imperial units
■ cm ³ /s	■ af/s	■ gal/s (imp)	
■ cm ³ /min	■ af/min	■ gal/min (imp)	
■ cm ³ /h	■ af/h	■ gal/h (imp)	
■ cm ³ /d	■ af/d	■ gal/d (imp)	
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)	
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)	
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)	
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)	
■ m ³ /s	■ kft ³ /s	■ bbl/s (imp;beer)	
■ m ³ /min	■ kft ³ /min	■ bbl/min (imp;beer)	
■ m ³ /h	■ kft ³ /h	■ bbl/h (imp;beer)	
■ m ³ /d	■ kft ³ /d	■ bbl/d (imp;beer)	
■ ml/s	■ MMft ³ /s	■ bbl/s (imp;oil)	
■ ml/min	■ MMft ³ /min	■ bbl/min (imp;oil)	
■ ml/h	■ MMft ³ /h	■ bbl/h (imp;oil)	
■ ml/d	■ Mft ³ /d	■ bbl/d (imp;oil)	
■ l/s	■ fl oz/s (us)		
■ l/min	■ fl oz/min (us)		
■ l/h	■ fl oz/h (us)		
■ l/d	■ fl oz/d (us)		
■ hl/s	■ gal/s (us)		
■ hl/min	■ gal/min (us)		
■ hl/h	■ gal/h (us)		
■ hl/d	■ gal/d (us)		
■ Ml/s	■ Mgal/s (us)		
■ Ml/min	■ Mgal/min (us)		
■ Ml/h	■ Mgal/h (us)		
■ Ml/d	■ Mgal/d (us)		
	■ bbl/s (us;liq.)		
	■ bbl/min (us;liq.)		
	■ bbl/h (us;liq.)		
	■ bbl/d (us;liq.)		
	■ bbl/s (us;beer)		
	■ bbl/min (us;beer)		
	■ bbl/h (us;beer)		
	■ bbl/d (us;beer)		
	■ bbl/s (us;oil)		
	■ bbl/min (us;oil)		
	■ bbl/h (us;oil)		
	■ bbl/d (us;oil)		
	■ bbl/s (us;tank)		
	■ bbl/min (us;tank)		
	■ bbl/h (us;tank)		
	■ bbl/d (us;tank)		
	■ kgal/s (us)		
	■ kgal/min (us)		
	■ kgal/h (us)		
	■ kgal/d (us)		
Factory setting	Country-specific: ■ l/h ■ gal/min (us)		

Additional information*Effect*

The selected unit applies for:
Volume flow parameter (→  40)

Selection

 For an explanation of the abbreviated units: →  192

Volume unit**Navigation**

  Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- Mft³
- Mft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- gal (us)

Additional information*Selection*

 For an explanation of the abbreviated units: →  192

Conductivity unit**Navigation**

  Expert → Sensor → System units → Conductiv. unit (0582)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→  55) parameter.

Description

Use this function to select the unit for the conductivity.

Selection	<i>SI units</i>
	▪ nS/cm
	▪ μ S/cm
	▪ μ S/m
	▪ μ S/mm
	▪ mS/m
	▪ mS/cm
	▪ S/cm
	▪ S/m
	▪ kS/m
	▪ MS/m

Factory setting	μ S/cm
------------------------	------------

Additional information	<i>Effect</i>
	The selected unit applies for: Conductivity parameter (→ 41)

Selection

 For an explanation of the abbreviated units: → 192

Temperature unit 

Navigation	 Expert → Sensor → System units → Temperature unit (0557)
-------------------	--

Description	Use this function to select the unit for the temperature.
--------------------	---

Selection	<i>SI units</i>	<i>US units</i>
	▪ °C	▪ °F
	▪ K	▪ °R

Factory setting	Country-specific:
	▪ °C
	▪ °F

Additional information	<i>Effect</i>
	The selected unit applies for:
	▪ Maximum value parameter (→ 175) ▪ Minimum value parameter (→ 175)

Selection

 For an explanation of the abbreviated units: → 192

Mass flow unit 

Navigation	 Expert → Sensor → System units → Mass flow unit (0554)
-------------------	--

Description	Use this function to select the unit for the mass flow.
--------------------	---

Selection	<i>SI units</i>	<i>US units</i>
	▪ g/s	▪ oz/s
	▪ g/min	▪ oz/min
	▪ g/h	▪ oz/h
	▪ g/d	▪ oz/d
	▪ kg/s	▪ lb/s
	▪ kg/min	▪ lb/min
	▪ kg/h	▪ lb/h
	▪ kg/d	▪ lb/d
	▪ t/s	▪ STon/s
	▪ t/min	▪ STon/min
	▪ t/h	▪ STon/h
	▪ t/d	▪ STon/d
Factory setting	Country-specific:	
	▪ kg/h	
	▪ lb/min	
Additional information	<i>Effect</i>	
	The selected unit applies for:	
	Mass flow parameter (→  41)	
	<i>Selection</i>	
	 For an explanation of the abbreviated units: →  192	

Mass unit	
Navigation	  Expert → Sensor → System units → Mass unit (0574)
Description	Use this function to select the unit for the mass.
Selection	<i>SI units</i>
	▪ g
	▪ kg
	▪ t
<i>US units</i>	
	▪ oz
	▪ lb
	▪ STon
Factory setting	Country-specific:
	▪ kg
	▪ lb
Additional information	<i>Selection</i>
	 For an explanation of the abbreviated units: →  192

Density unit	
Navigation	  Expert → Sensor → System units → Density unit (0555)
Description	Use this function to select the unit for the density.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ g/cm ³	■ lb/ft ³	■ lb/gal (imp)
	■ g/m ³	■ lb/gal (us)	■ lb/bbl (imp;beer)
	■ kg/l	■ lb/bbl (us;liq.)	■ lb/bbl (imp;oil)
	■ kg/dm ³	■ lb/bbl (us;beer)	
	■ kg/m ³	■ lb/bbl (us;oil)	
	■ SD4°C	■ lb/bbl (us;tank)	
	■ SD15°C		
	■ SD20°C		
	■ SG4°C		
	■ SG15°C		
	■ SG20°C		
Factory setting	Country-specific:		
	■ kg/l		
	■ lb/ft ³		
Additional information	<i>Effect</i>		
	The selected unit applies for:		
	■ External density parameter (→ 67)		
	■ Fixed density parameter (→ 68)		
	<i>Selection</i>		
	■ SD = specific density		
	The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).		
	■ SG = specific gravity		
	The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).		
	 For an explanation of the abbreviated units: → 192		

Corrected volume flow unit 

Navigation

 Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection

SI units

- NI/s
- NI/min
- NI/h
- NI/d
- Nhl/s
- Nhl/min
- Nhl/h
- Nhl/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sl/s
- Sl/min
- Sl/h
- Sl/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- MSft³/s
- MSft³/min
- MSft³/h
- MSft³/D
- MMSft³/s
- MMSft³/min
- MMSft³/h
- MMSft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- Sbbl/s (us;oil)
- Sbbl/min (us;oil)
- Sbbl/h (us;oil)
- Sbbl/d (us;oil)

Imperial units

- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting

Country-specific:

- NI/h
- Sft³/h

Additional information*Selection*
 For an explanation of the abbreviated units: → [192](#)
Corrected volume unit**Navigation**
 Expert → Sensor → System units → Corr. vol. unit (0575)
Description

Use this function to select the unit for the corrected volume.

Selection

SI units

- NI
- Nhl
- Nm³
- Sl
- Sm³

US units

- Sft³
- MSft³
- MMSft³
- Sgal (us)
- Sbbl (us;liq.)
- Sbbl (us;oil)

Imperial units

- Sgal (imp)

Factory setting

Country-specific:

- Nm³
- Sft³

Additional information*Selection*

For an explanation of the abbreviated units: → [192](#)

Date/time format**Navigation**

Expert → Sensor → System units → Date/time format (2812)

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

For an explanation of the abbreviated units: → [192](#)

3.2.3 "Process parameters" submenu*Navigation*

Expert → Sensor → Process param.

▶ Process parameters	
Filter options (6710)	→ 52
Flow damping (6661)	→ 54
Flow override (1839)	→ 54
Conductivity measurement (6514)	→ 55
Conductivity damping (1803)	→ 55
Conductivity temperature coefficient (1891)	→ 56
Temperature damping (1886)	→ 56
Reference density (1885)	→ 56
▶ Low flow cut off	
	→ 57

▶ Empty pipe detection	→ 59
▶ Electrode cleaning circuit	→ 62
▶ Build-up index	→ 64

Filter options**Navigation**

Expert → Sensor → Process param. → Filter options (6710)

Description

Use this function to select a filter option.

Selection

- Adaptive
- Adaptive CIP on
- Dynamic
- Dynamic CIP on
- Binomial
- Binomial CIP on

Factory setting

Binomial

Additional information*Description*

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects

the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

Selection

■ **Standard**

- Strong flow damping with a short output signal response time.
- Some time is needed before a stable output signal can be generated.
- Not suitable for pulsating flow as the average flow can be different here.

■ **Dynamic**

- Average flow damping with a delayed output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **Binomial**

- Weak flow damping with a short output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **CIP**

- This filter makes the **Standard** and **Dynamic** filter options additionally available.
- If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
- If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

Examples

Possible applications for the filters

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Pulsating flow (flow is negative intermittently)	---	---	++	--	++
Flow changes frequently (flow is dynamic)	-	--	++	-	++
Clear signal, fast control loop (< 1 s)	--	--	+ ¹⁾		++
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	----
Permanently bad signal	++	--	-	---	-
Short and severe signal distortion after a while		++		++	
Replacement of a Promag 50/53: system damping Promag 400 = 0.5 * system damping Promag 50/53					+++
Replacement of a Promag 10: system damping Promag 400 = system damping Promag 10 + 2			+++		
For a stable flow signal (no other requirements)	+++				

1) Value of flow damping < 6

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping (6661)

Description

Use this function to enter a value for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

4

Additional information

Input range 0 to 15

- Value = 0: no damping
- Value = 1: minor damping
- Value = 15: strong damping

i ▪ The damping depends on the measuring period and the filter type selected.
▪ An increase or decrease in the damping depends on the application.

Effect

i The damping affects the following variables of the device:

- Outputs
- Low flow cut off → [57](#)
- Totalizers → [145](#)

Flow override



Navigation

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

i This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The **453 Flow override** diagnostic message is output.
- Output values
 - Output: value at zero flow
 - Temperature: continues to be output
 - Totalizers 1-3: stop being totalized

i The **Flow override** option can also be activated in the **Status input** submenu: **Assign status input** parameter.

Conductivity measurement

Navigation Expert → Sensor → Process param. → Conduct. measur. (6514)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 55) parameter.

Description Use this function to enable and disable conductivity measurement.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.

Conductivity damping

Navigation Expert → Sensor → Process param. → Conduct. damping (1803)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 55).

Description Use this function to enter a time constant for conductivity damping (PT1 element).

User entry 0 to 999.9 s

Factory setting 0 s

Additional information *Description*

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if 0 is entered (factory setting).

2) Proportional behavior with first-order lag

Conductivity temperature coefficient



Navigation Expert → Sensor → Process param. → Cond. temp.coeff (1891)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Use this function to enter the temperature coefficient for the conductivity.

User entry Signed floating-point number

Factory setting 2.1 %/K

Temperature damping



Navigation Expert → Sensor → Process param. → Temp. damping (1886)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Use this function to enter the time constant for temperature damping.

User entry 0 to 999.9 s

Factory setting 0 s

Reference density



Navigation Expert → Sensor → Process param. → Ref.density (1885)

Description Use this function to enter a fixed value for the reference density.

User entry Positive floating-point number

Factory setting Country-specific:

- 1 kg/l
- 1 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 48)

"Low flow cut off" submenu**Navigation**
 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign process variable (1837)	→  57
On value low flow cutoff (1805)	→  57
Off value low flow cutoff (1804)	→  58
Pressure shock suppression (1806)	→  58

Assign process variable**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

On value low flow cutoff**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→  57).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  58.

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter →  188

Additional information

Dependency

 The unit depends on the process variable selected in the **Assign process variable** parameter (→  57).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 57).

Description

Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 57.

User entry


0 to 100.0 %

Factory setting

50 %

Additional information

Example



A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pressure shock suppression**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 57).

Description

Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry

0 to 100 s

Factory setting

0 s

Additional information

Description

Pressure shock suppression is enabled


- Prerequisite:
Flow rate < on-value of low flow cut off
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.




A0012888

- Q Flow
 t Time
 A Drip
 B Pressure shock
 C Pressure shock suppression active as per the time entered
 D Pressure shock suppression inactive
 1 Valve closes
 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
 3 The time entered has elapsed: pressure shock suppression is deactivated
 4 The actual flow value is processed again and output
 5 On-value for low flow cut off
 6 Off-value for low flow cut off

"Empty pipe detection" submenu

Navigation

Expert → Sensor → Process param. → Empty pipe det.



Response time empty pipe detection (1859)	→ 60
New adjustment (6560)	→ 61
Progress (6571)	→ 61
Empty pipe adjust value (6527)	→ 61
Full pipe adjust value (6548)	→ 62
Measured value EPD (6559)	→ 62

Assign process variable



Navigation Expert → Sensor → Process param. → Empty pipe det. → Assign variable (1860)

Description Use this function to switch empty pipe detection on and off.

Selection

- Off
- On

Factory setting Off

Switch point empty pipe detection



Navigation Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD (6562)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ 60).

Description Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.

User entry 0 to 100 %

Factory setting 50 %

Response time empty pipe detection



Navigation Expert → Sensor → Process param. → Empty pipe det. → Response time (1859)

Prerequisite A process variable is selected in the **Assign process variable** parameter (→ 60).

Description Use this function to enter the minimum length of time (debouncing time) the signal must be present for the **△S862 Pipe empty** diagnostic message to be triggered if the measuring pipe is empty or partially full.

User entry 0 to 100 s

Factory setting 1 s

New adjustment



Navigation Expert → Sensor → Process param. → Empty pipe det. → New adjustment (6560)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ 60).

Description For selecting whether to perform an empty pipe or full pipe adjustment.

Selection

- Cancel
- Empty pipe adjust
- Full pipe adjust

Factory setting Cancel

Progress



Navigation Expert → Sensor → Process param. → Empty pipe det. → Progress (6571)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ 60).

Description Use this function to view the progress.

User interface

- Ok
- Busy
- Not ok

Empty pipe adjust value



Navigation Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value (6527)

Prerequisite

- In the **Empty pipe detection** parameter (→ 60), the **On** option is selected.
- Adjustment value > full pipe value.

Description Displays the adjustment value when the measuring pipe is empty.

User interface Positive floating-point number

Full pipe adjust value

Navigation Expert → Sensor → Process param. → Empty pipe det. → Full pipe value (6548)

Prerequisite

- In the **Empty pipe detection** parameter (→ 60), the **On** option is selected.
- Adjustment value < empty pipe value.

Description Displays the adjustment value when the measuring pipe is full.

User interface Positive floating-point number

Measured value EPD

Navigation Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD (6559)

Prerequisite In the **Empty pipe detection** parameter (→ 60), the **On** option is selected.

Description Displays the current measured value.

User interface Positive floating-point number

"Electrode cleaning circuit" submenu

Navigation

Expert → Sensor → Process param. → ECC

► Electrode cleaning circuit	
Electrode cleaning circuit (6528)	→ 63
ECC duration (6555)	→ 63
ECC recovery time (6556)	→ 63
ECC cleaning cycle (6557)	→ 64
ECC polarity (6631)	→ 64

Electrode cleaning circuit

Navigation Expert → Sensor → Process param. → ECC → ECC (6528)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enable and disable cyclic electrode cleaning.

Selection

- Off
- On

Factory setting Off

Additional information Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits developing in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.

ECC duration

Navigation Expert → Sensor → Process param. → ECC → ECC duration (6555)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enter the duration of electrode cleaning in seconds.

User entry 0.01 to 30 s

Factory setting 2 s

ECC recovery time

Navigation Expert → Sensor → Process param. → ECC → ECC recov. time (6556)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.

User entry 1 to 600 s

Factory setting 5 s

ECC cleaning cycle**Navigation**

Expert → Sensor → Process param. → ECC → ECC clean. cycle (6557)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enter the pause duration until the next electrode cleaning.

User entry

0.5 to 168 h

Factory setting

0.7 h

ECC polarity**Navigation**

Expert → Sensor → Process param. → ECC → ECC polarity (6631)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Displays the polarity of the electrode cleaning circuit.

User interface

- Positive
- Negative

Factory setting

Depends on the electrode material:

- Tantalum: **Negative** option
- Platinum, Alloy C22, stainless steel: **Positive** option

"Coating detection" submenu

Build-up detection is only available:

- In conjunction with the Promag W sensor
- In the compact device version (transmitter and sensor form a mechanical unit)
- For detailed information on build-up detection: see the Special Documentation for the **Heartbeat Verification + Monitoring** application package → 7

Navigation

Expert → Sensor → Process param. → Build-up detect.

Build-up index	
Build-up detection	→ 65
Build-up detection damping	→ 65
Build-up index	→ 65

Build-up limit	→  66
Build-up limit hysteresis	→  66

Build-up detection

Navigation	  Expert → Sensor → Process param. → Build-up index → Build-up detect. (6734)
Description	Select mode for build-up index.
Selection	<ul style="list-style-type: none"> ■ Off ■ Slow ■ Standard ■ Fast
Factory setting	Off

Build-up detection damping

Navigation	  Expert → Sensor → Process param. → Build-up index → Build-up damping (6840)
Description	Enter damping value for build-up index. Damping value: <ul style="list-style-type: none"> ■ 0 = minimum damping ■ 15 = maximum damping The damping value should only be increased if the measured value is unstable.
User entry	0 to 15
Factory setting	0

Build-up index

Navigation	  Expert → Sensor → Process param. → Build-up index → Build-up index (12111)
Description	Shows current build-up measured value.
User interface	0.0 to 100.0 %
Factory setting	0.0 %
Additional information	The formation of build-up is output as a percentage in the Build-up index value (→  65) parameter. The higher the percentage, the thicker the build-up.

Build-up index value (\rightarrow 65) = 0%

- No build-up present
- Measuring tube as-delivered state (initial value)
- Measuring tube was cleaned thoroughly after formation of build-up

Build-up index value (\rightarrow 65) = 100%

- Value for the maximum measurable build-up thickness
- The thickness of the build-up at 100% varies depending on the process
- A value of 100% should not be equated with a blocked measuring tube

The percentage indicated in the Build-up index value (\rightarrow 65) parameter does not provide direct information about the absolute thickness or the composition of the build-up. Therefore, to make optimum use of the build-up detection function, it is necessary to first compare the formation of build-up in the process, as known from experience, with the associated Build-up index value (\rightarrow 65). The aim is to determine the Build-up index value (\rightarrow 65) at the time the cleaning is usually performed.

On the basis of the Build-up index value (\rightarrow 65) during cleaning, it is possible to make a valid assessment of the condition inside the measuring tube and to plan the cleaning using the build-up limit and build-up detection hysteresis parameters.

In addition, conclusions about possible effects on neighboring processes can be drawn from the Build-up index value (\rightarrow 65).

Build-up limit

Navigation  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up index \rightarrow Build-up limit (6466)

Description Enter limit value for the build-up index.

User entry 0 to 100 %

Factory setting 50 %

Build-up limit hysteresis

Navigation  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up index \rightarrow Buildup lim.hyst (6467)

Description Enter hysteresis for build-up limit value.

If the value for build-up detection hysteresis is higher than the Build-up limit (\rightarrow 66), the "Build-up detected" diagnostic information is not reset until the measuring tube has been cleaned and a restart has been performed.

User entry 0 to 100 %

Factory setting 20 %

3.2.4 "External compensation" submenu

Navigation

Expert → Sensor → External comp.

► External compensation	
Density source (6615)	→ 67
Fixed density (6623)	→ 68
External density (6630)	→ 67
Temperature source (6712)	→ 68
External temperature (6673)	→ 68
Reference temperature (1816)	→ 69

Density source



Navigation

Expert → Sensor → External comp. → Density source (6615)

Description

Use this function to select the density source.

Selection

- Fixed density
- External density

Factory setting

Fixed density

External density

Navigation

Expert → Sensor → External comp. → External density (6630)

Prerequisite

The **External density** option is selected in the **Density source** parameter (→ 67).

Description

Displays the density read in from the external device.

User entry

Positive floating-point number

Additional information

Dependency

The unit is taken from the **Density unit** parameter (→ 48)

Fixed density

Navigation Expert → Sensor → External comp. → Fixed density (6623)

Prerequisite The **Fixed density** option is selected in the **Density source** parameter (→ 67).

Description Use this function to enter a fixed value for the density.

User entry Positive floating-point number

Factory setting Depends on country:

- 1 000 kg/m³
- 62 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 48)

Temperature source

Navigation Expert → Sensor → External comp. → Temp. source (6712)

Description Use this function to select the temperature source.

Selection

- Internal temperature sensor *
- Off
- External value

Factory setting Off

External temperature

Navigation Expert → Sensor → External comp. → External temp. (6673)

Prerequisite The **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Displays the temperature read in from the external device.

User entry Floating point number with sign

Additional information *Dependency*

The unit is taken from the **Temperature unit** parameter (→ 47)

* Visibility depends on order options or device settings

Reference temperature**Navigation**

Expert → Sensor → External comp. → Ref. temperature (1816)

Prerequisite

The **Fixed density** option or **External density** option are selected in the **Density source** parameter (→ 67).

Description

Use this function to enter a reference temperature for calculating the reference density.

User interface

-273.15 to 99 999 °C

Factory setting

Country-specific:

- +20 °C
- +68 °F

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ 47)

Reference density calculation

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_N : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

3.2.5 "Sensor adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm.

Sensor adjustment	
Installation direction (1809)	→ 70
Integration time (6533)	→ 70
Measuring period (6536)	→ 70
Process variable adjustment	
	→ 70

Installation direction

Navigation Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description Use this function to change the sign of the medium flow direction.

Selection

- Forward flow
- Reverse flow

Factory setting Forward flow

Additional information *Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time

Navigation Expert → Sensor → Sensor adjustm. → Integration time (6533)

Description Displays the duration of the integration time.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 1 to 65 ms

Measuring period

Navigation Expert → Sensor → Sensor adjustm. → Measuring period (6536)


Description Display the time of a full measuring period.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 2 to 1000 ms

"Process variable adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust



Volume flow factor (1832)	→ 71
Mass flow offset (1841)	→ 72
Mass flow factor (1846)	→ 72
Conductivity offset (1848)	→ 73
Conductivity factor (1849)	→ 73
Corrected volume flow offset (1866)	→ 73
Corrected volume flow factor (1867)	→ 74
Temperature offset (1868)	→ 74
Temperature factor (1869)	→ 74
Corrected conductivity offset (1870)	→ 75
Corrected conductivity factor (1871)	→ 75
Flow velocity offset (1879)	→ 75
Flow velocity factor (1880)	→ 76

Volume flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Volume flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/s

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)

Description

Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description

Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.

User entry

Signed floating-point number

Factory setting

0 kg/s

Additional information*Description*

Corrected value = (factor × value) + offset

Conductivity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset (1848)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor (1849)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected volume flow offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1866)
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected volume flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1867)
Description	Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1868)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1869)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.offset (1870)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55) parameter.
Description	Use this function to enter the zero point shift to trim the corrected conductivity. The conductivity unit on which the shift is based is µS/cm.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.factor (1871)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55) parameter.
Description	Use this function to enter a quantity factor for the corrected conductivity. In each case, this factor refers to the conductivity in µS/cm.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Flow velocity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. offset (1879)
Description	Use this function to enter the zero point shift for the flow velocity trim. The flow velocity unit on which the shift is based is m/s.
User entry	Signed floating-point number
Factory setting	0 m/s

Additional information*Description*

Corrected value = (factor × value) + offset

Flow velocity factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. factor (1880)

Description

Use this function to enter a quantity factor (without time) for the flow velocity. This multiplication factor is applied over the flow velocity range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu**Navigation**

Expert → Sensor → Calibration

► Calibration	
Nominal diameter (2807)	→ 76
Calibration factor (6522)	→ 77
Zero point (6546)	→ 77
Conductivity calibration factor (6718)	→ 77

Nominal diameter**Navigation**

Expert → Sensor → Calibration → Nominal diameter (2807)

Description

Displays the nominal diameter of the sensor.

User interface

DNxx / x"

Factory setting

Depends on the size of the sensor

Additional information*Description*

The value is also specified on the sensor nameplate.

Calibration factor

Navigation

Expert → Sensor → Calibration → Cal. factor (6522)

Description

Displays the current calibration factor for the sensor.

User interface

Positive floating-point number

Factory setting

Depends on nominal diameter and calibration.

Zero point

**Navigation**

Expert → Sensor → Calibration → Zero point (6546)

Description

This function shows the zero point correction value for the sensor.

User interface

Signed floating-point number

Factory setting

Depends on nominal diameter and calibration

Conductivity calibration factor

**Navigation**

Expert → Sensor → Calibration → Cond. cal. fact. (6718)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 55) parameter.

Description

Displays the calibration factor for the conductivity measurement.

User interface

0.01 to 10 000

3.3 "Communication" submenu

Navigation

Expert → Communication

▶ Communication	
▶ PROFIBUS DP configuration	→ 78
▶ PROFIBUS DP info	→ 80
▶ Physical block	→ 82
▶ Address shifting configuration	→ 91
▶ Web server	→ 91
▶ WLAN settings	→ 95

3.3.1 "PROFIBUS DP configuration" submenu

Navigation

Expert → Communication → PROFIBUS DP conf

▶ PROFIBUS DP configuration	
Address mode (1468)	→ 78
Device address (1462)	→ 79
Ident number selector (1461)	→ 79

Address mode

Navigation

Expert → Communication → PROFIBUS DP conf → Address mode (1468)

Description

Displays the configured address mode.

User interface

- Hardware
- Software

Factory setting

Software

Additional information

Description

For detailed information, see the "Setting the device address" section of the Operating Instructions.

Device address

Navigation Expert → Communication → PROFIBUS DP conf → Device address (1462)

Description Use this function to enter the device address.

User entry 0 to 126

Factory setting 126

Additional information *Description*

The address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.

Displays the configured address mode: **Address mode** parameter (→ 78)

Ident number selector

Navigation Expert → Communication → PROFIBUS DP conf → Ident num select (1461)

Description Use this function to select the device master file (GSD).

Selection

- Automatic mode
- Manufacturer
- Promag 50 (0x1546)
- Promag 53 (0x1526)
- Profile
- 1 AI, 1 Totalizer (0x9740)
- 2 AI, 1 Totalizer (0x9741)

Factory setting Automatic mode

Additional information *Description*

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

Bus termination

Navigation Expert → Communication → PROFIBUS DP conf → Bus termination (1431)

User interface


- Off
- On

Factory setting Off

3.3.2 "PROFIBUS DP info" submenu

Navigation

Expert → Communication → PROFIBUS DP info



Status PROFIBUS Master Config

Navigation

Expert → Communication → PROFIBUS DP info → Stat Master Conf (1465)

Description

For displaying the status of the PROFIBUS Master configuration.

User interface

- Active
- Not active

Factory setting

Not active

PROFIBUS ident number

Navigation

Expert → Communication → PROFIBUS DP info → Ident number (1464)

Description

For displaying the PROFIBUS identification number.

User interface

0 to FFFF

Factory setting

0x1562

Profile version

Navigation	 Expert → Communication → PROFIBUS DP info → Profile version (1463)
Description	Displays the profile version.
User interface	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	3.02

Baudrate

Navigation	 Expert → Communication → PROFIBUS DP info → Baudrate (1504)
Description	Displays the transmission rate.
User interface	<ul style="list-style-type: none">■ Not available■ 9.6 kBaud■ 19.2 kBaud■ 45.45 kBaud■ 93.75 kBaud■ 187.5 kBaud■ 500 kBaud■ 1.5 MBaud■ 3 MBaud■ 6 MBaud■ 12 MBaud
Factory setting	9.6 kBaud

Master availability

Navigation	 Expert → Communication → PROFIBUS DP info → Master avail. (1517)
Description	Displays whether or not a PROFIBUS master is present in the network.
User interface	<ul style="list-style-type: none">■ No■ Yes
Factory setting	No

3.3.3 "Physical block" submenu

Navigation

Expert → Communication → Physical block

► Physical block	
Device tag (1496)	→ 83
Static revision (1495)	→ 83
Strategy (1494)	→ 83
Alert key (1473)	→ 84
Target mode (1497)	→ 84
Mode block actual (1472)	→ 84
Mode block permitted (1493)	→ 84
Mode block normal (1492)	→ 85
Alarm summary (1474)	→ 85
Software revision (1478)	→ 86
Hardware revision (1479)	→ 86
Manufacturer ID (1502)	→ 86
Device ID (1480)	→ 86
Serial number (1481)	→ 87
Diagnostics (1482)	→ 87
Diagnostics mask (1484)	→ 87
Device certification (1486)	→ 88
Factory reset (1488)	→ 88
Descriptor (1489)	→ 89
Device message (1490)	→ 89
Device install date (1491)	→ 89
Ident number selector (1461)	→ 89

Hardware lock (1499)	→ 90
Feature supported (1477)	→ 90
Feature enabled (1476)	→ 90
Condensed status diagnostic (1500)	→ 91

Device tag**Navigation** Expert → Communication → Physical block → Device tag (1496)**Description** Use this function to enter the name for the measuring point.**User entry** Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).**Factory setting** Promag 400 DP

Static revision**Navigation** Expert → Communication → Physical block → Static revision (1495)**Description** Displays the event counter: every write access to a static block parameter is counted.**User interface** 0 to FFFF**Additional information** *Description*

Static parameters are parameters that are not changed by the process.

Strategy**Navigation** Expert → Communication → Physical block → Strategy (1494)**Description** Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.**User entry** 0 to FFFF**Factory setting** 0

Alert key**Navigation**

Expert → Communication → Physical block → Alert key (1473)

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

Expert → Communication → Physical block → Target mode (1497)

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Out of service

Mode block actual**Navigation**

Expert → Communication → Physical block → Mode block act (1472)

Description

Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 84).

User interface

- Auto
- Out of service

Additional information**Description**

A comparison of the current mode with the target mode (**Target mode** parameter (→ 84)) indicates whether it was possible to reach the target mode.

Mode block permitted**Navigation**

Expert → Communication → Physical block → Mode block perm (1493)

Description

Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 84) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface	0 to 255
----------------	----------

Mode block normal

Navigation	 Expert → Communication → Physical block → Mode blk norm (1492)
------------	--

Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
-------------	--

User interface	<ul style="list-style-type: none"> ■ Auto ■ Out of service
----------------	--

Alarm summary

Navigation	 Expert → Communication → Physical block → Alarm summary (1474)
------------	--

Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
-------------	---

User interface	<ul style="list-style-type: none"> ■ Discrete alarm ■ Alarm state HiHi limit ■ Alarm state Hi limit ■ Alarm state LoLo limit ■ Alarm state Lo limit ■ Update Event
----------------	--

Additional information	<p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Physical Block function block.</p>
------------------------	--

User interface

<ul style="list-style-type: none"> ■ Discrete alarm Alarm or warning message with a discrete value. ■ Alarm state HiHi limit Upper alarm limit ■ Alarm state Hi limit Upper warning limit ■ Alarm state LoLo limit Lower alarm limit ■ Alarm state Lo limit Lower warning limit ■ Update Event This option constitutes a special alarm that is triggered if a static parameter is changed. If such a parameter is modified, the associated bit is set in the Alarm summary parameter (→ 85), the output of the block switches to "GOOD (NC) Active Update Event" (if the current status has a lower priority than this), and the block remains in this state for a duration of 10 s. The block then reverts to the normal state (the output has the last status and the Update Event option bit in the Alarm summary parameter (→ 85) is deleted again).

Software revision

Navigation  Expert → Communication → Physical block → Software rev. (1478)

Description Displays the firmware version of the measuring device.

User interface Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Hardware revision

Navigation  Expert → Communication → Physical block → Hardware rev. (1479)

Description Displays the hardware revision of the measuring device.

User interface Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Manufacturer ID

Navigation  Expert → Communication → Physical block → Manufacturer ID (1502)

Description Displays the manufacturer ID with which the measuring device has been registered with the PNO (PROFIBUS User Organization).

User interface 0 to FFFF

Factory setting 0x11

Device ID

Navigation  Expert → Communication → Physical block → Device ID (1480)

Description Displays the device ID for identifying the measuring device in a PROFIBUS network.

User interface Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Promag 400 DP

Serial number

Navigation	  Expert → Communication → Physical block → Serial number (1481)
Description	Displays the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Additional information	<i>Description</i>  Uses of the serial number <ul style="list-style-type: none">■ To identify the measuring device quickly, e.g. when contacting Endress+Hauser.■ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Diagnostics

Navigation	  Expert → Communication → Physical block → Diagnostics (1482)
Description	Displays the diagnostic messages.
User interface	<ul style="list-style-type: none">■ Hardware failure electronics■ Hardware failure mechanics■ Temperature motor■ Electronic temperature■ Memory checksum error■ Measurement error■ Device not initialized■ Initialization error■ Zero point error■ Power supply■ Configuration invalid■ On warmstart■ On coldstart■ Maintenance required■ Characterization invalid■ Ident number violation■ More information available■ Maintenance alarm■ Maintenance demanded■ Function check or simulation■ Invalid process condition

Diagnostics mask

Navigation	  Expert → Communication → Physical block → Diagnostics mask (1484)
Description	Displays the diagnostic messages supported by the measuring device.

User interface

- Hardware failure electronics
- Hardware failure mechanics
- Temperature motor
- Electronic temperature
- Memory checksum error
- Measurement error
- Device not initialized
- Initialization error
- Zero point error
- Power supply
- Configuration invalid
- On warmstart
- On coldstart
- Maintenance required
- Characterization invalid
- Ident number violation
- More information available
- Maintenance alarm
- Maintenance demanded
- Function check or simulation
- Invalid process condition

Device certification

Navigation Expert → Communication → Physical block → Device certific. (1486)**Description**

Displays certificates of the measuring device, e.g. Ex certificate.

User interface

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory reset

**Navigation** Expert → Communication → Physical block → Factory reset (1488)**Description**

Use this function to reset a certain set of parameters in a block.

Selection

- to defaults *
- warmstart device
- reset bus address
- Cancel

Factory setting

Cancel

* Visibility depends on order options or device settings

Descriptor**Navigation**

Expert → Communication → Physical block → Descriptor (1489)

Description

Use this function to enter a user-specific string to describe the device within the application.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Device message**Navigation**

Expert → Communication → Physical block → Device message (1490)

Description

Use this function to enter a user-definable message (a string) to describe the device within the application or in the plant.

User entry

Max. 32 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Device install date**Navigation**

Expert → Communication → Physical block → Device inst.date (1491)

Description

Use this function to enter the date of installation of the device.

User entry

Max. 16 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Ident number selector**Navigation**

Expert → Communication → Physical block → Ident num select (1461)

Description

Use this function to select the device master file (GSD).

Selection

- Automatic mode
- Manufacturer
- Promag 50 (0x1546)
- Promag 53 (0x1526)
- Profile
- 1 AI, 1 Totalizer (0x9740)
- 2 AI, 1 Totalizer (0x9741)

Factory setting

Automatic mode

Additional information*Description*

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data

volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

Hardware lock

Navigation  Expert → Communication → Physical block → Hardware lock (1499)

Description Displays the hardware write protection.

User interface

- Unprotected
- Protected

Additional information *Description*

Indicates whether it is possible to write-access the measuring device via PROFIBUS (acyclic data transmission, e.g. via the "FieldCare" operating program).

 For detailed information on hardware write protection, see the "Write protection via write protection switch" section of the Operating Instructions.

User interface

- Unprotected
Write access via PROFIBUS is possible (acyclic data transmission).
- Protected
Write access via PROFIBUS is locked (acyclic data transmission).

Feature supported

Navigation  Expert → Communication → Physical block → Feature support (1477)

Description Displays the PROFIBUS features that are supported by the measuring device.

User interface

- Condensed status
- Classic status diagnosis
- Data exchange broadcast
- MS1 application relationship
- PROFIsafe communication

Feature enabled

Navigation  Expert → Communication → Physical block → Feature enabled (1476)

Description Displays the PROFIBUS features that are enabled in the measuring device.

User interface

- Condensed status
- Classic status diagnosis
- Data exchange broadcast
- MS1 application relationship
- PROFIsafe communication

Condensed status diagnostic

Navigation Expert → Communication → Physical block → Condensed status (1500)

Description Use this function to switch the condensed status diagnostic on and off.

Selection

- Off
- On

Factory setting On

3.3.4 "Address shifting configuration" submenu

For detailed information on acyclic communication, see the "System integration" – "Address shifting configuration" section of the Operating Instructions for the device
→ 7

Navigation Expert → Communication → Addr.shift conf.

► Address shifting configuration

Slot shifting 1...16

Index shifting 1...16

3.3.5 "Web server" submenu

Navigation Expert → Communication → Web server

► Web server

Web server language (7221) → 92

MAC address (7214) → 92

DHCP client (7212) → 93

IP address (7209) → 93

Subnet mask (7211)	→ 93
Default gateway (7210)	→ 94
Web server functionality (7222)	→ 94
Login page (7273)	→ 94

Web server language

Navigation Expert → Communication → Web server → Webserv.language (7221)

Description Use this function to select the Web server language setting.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting

English

MAC address

Navigation Expert → Communication → Web server → MAC Address (7214)

Description Displays the MAC³⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

Factory setting Each measuring device is given an individual address.

* Visibility depends on order options or device settings

3) Media Access Control

Additional information*Example*

For the display format
00:07:05:10:01:5F

DHCP client**Navigation**

Expert → Communication → Web server → DHCP client (7212)

Description

Use this function to activate and deactivate the DHCP client functionality.

Selection

- Off
- On

Factory setting

On

Additional information*Effect*

If the DHCP client functionality of the web server is selected, the IP address (→ 93), Subnet mask (→ 93) and Default gateway (→ 94) are set automatically.



- Identification is via the MAC address of the measuring device.
- The IP address (→ 93) in the **IP address** parameter (→ 93) is ignored as long as the **DHCP client** parameter (→ 93) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→ 93) in the parameter of the same name is only used if the **DHCP client** parameter (→ 93) is inactive.

IP address**Navigation**

Expert → Communication → Web server → IP address (7209)

Description

Display or enter the IP address of the Web server integrated in the measuring device.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

192.168.1.212

Subnet mask**Navigation**

Expert → Communication → Web server → Subnet mask (7211)

Description

Display or enter the subnet mask.

User entry

4 octet: 0 to 255 (in the particular octet)

Factory setting

255.255.255.0

Default gateway**Navigation**

Expert → Communication → Web server → Default gateway (7210)

DescriptionDisplay or enter the Default gateway (→ [94](#)).**User entry**

4 octet: 0 to 255 (in the particular octet)

Factory setting

0.0.0.0

Web server functionality**Navigation**

Expert → Communication → Web server → Webserver funct. (7222)

Description

Use this function to switch the Web server on and off.

Selection

- Off
- On

Factory setting

On

Additional information**Description**

Once disabled, the Web server functionality can only be re-enabled via or the operating tool FieldCare.

Selection

Option	Description
Off	<ul style="list-style-type: none">▪ The web server is completely disabled.▪ Port 80 is locked.
On	<ul style="list-style-type: none">▪ The complete functionality of the web server is available.▪ JavaScript is used.▪ The password is transferred in an encrypted state.▪ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Expert → Communication → Web server → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.3.6 "WLAN settings" wizard

Navigation

Expert → Communication → WLAN settings

► WLAN settings	
WLAN (2702)	→ 96
WLAN mode (2717)	→ 96
SSID name (2714)	→ 96
Network security (2705)	→ 96
Security identification (2718)	→ 97
User name (2715)	→ 97
WLAN password (2716)	→ 97
WLAN IP address (2711)	→ 98
WLAN MAC address (2703)	→ 98
WLAN subnet mask (2709)	→ 98
WLAN MAC address (2703)	→ 98
WLAN passphrase (2706)	→ 98
WLAN MAC address (2703)	→ 98
Assign SSID name (2708)	→ 99
SSID name (2707)	→ 99
2.4 GHz WLAN channel (2704)	→ 99
Select antenna (2713)	→ 100
Connection state (2722)	→ 100
Received signal strength (2721)	→ 100
WLAN IP address (2711)	→ 98
Gateway IP address (2719)	→ 101
IP address domain name server (2720)	→ 101

WLAN

Navigation Expert → Communication → WLAN settings → WLAN (2702)

Description Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting Enable

WLAN mode

Navigation Expert → Communication → WLAN settings → WLAN mode (2717)

Description Use this function to select the WLAN mode.

Selection WLAN access point

Factory setting WLAN access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection	<ul style="list-style-type: none"> ■ Unsecured ■ WPA2-PSK ■ EAP-PEAP with MSCHAPv2 * ■ EAP-PEAP MSCHAPv2 no server authentic. * ■ EAP-TLS
Factory setting	WPA2-PSK
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Unsecured Access the WLAN connection without identification. ■ WPA2-PSK Access the WLAN connection with a network key.

Security identification

Navigation	 Expert → Communication → WLAN settings → Sec. identific. (2718)
Description	Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).
User interface	<ul style="list-style-type: none"> ■ Trusted issuer certificate ■ Device certificate ■ Device private key

User name



Navigation	 Expert → Communication → WLAN settings → User name (2715)
Description	Use this function to enter the username of the WLAN network.
User entry	–
Factory setting	–

WLAN password



Navigation	 Expert → Communication → WLAN settings → WLAN password (2716)
Description	Use this function to enter the WLAN password for the WLAN network.
User entry	–
Factory setting	–

* Visibility depends on order options or device settings

WLAN IP address

Navigation	Expert → Communication → WLAN settings → WLAN IP address (2711)
Description	Use this function to enter the IP address of the measuring device's WLAN connection.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	192.168.1.212

WLAN MAC address

Navigation	Expert → Communication → WLAN settings → WLAN MAC address (2703)
Description	Displays the MAC ⁴⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format 00:07:05:10:01:5F

WLAN subnet mask

Navigation	Expert → Communication → WLAN settings → WLAN subnet mask (2709)
Description	Use this function to enter the subnet mask.
User entry	4 octet: 0 to 255 (in the particular octet)
Factory setting	255.255.255.0

WLAN passphrase

Navigation	Expert → Communication → WLAN settings → WLAN passphrase (2706)
Prerequisite	The WPA2-PSK option is selected in the Security type parameter (→ 96).
Description	Use this function to enter the network key.

4) Media Access Control

User entry	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)
Factory setting	Serial number of the measuring device (e.g. L100A802000)

Assign SSID name

Navigation	Expert → Communication → WLAN settings → Assign SSID name (2708)
Description	Use this function to select which name is used for the SSID ⁵⁾ .
Selection	<ul style="list-style-type: none"> ■ Device tag ■ User-defined
Factory setting	User-defined
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Device tag The device tag name is used as the SSID. ■ User-defined A user-defined name is used as the SSID.

SSID name

Navigation	Expert → Communication → WLAN settings → SSID name (2707)
Prerequisite	<ul style="list-style-type: none"> ■ The User-defined option is selected in the Assign SSID name parameter (→ 99). ■ The WLAN access point option is selected in the WLAN mode parameter (→ 96).
Description	Use this function to enter a user-defined SSID name.
User entry	Max. 32-digit character string comprising numbers, letters and special characters
Factory setting	

2.4 GHz WLAN channel

Navigation	Expert → Communication → WLAN settings → WLAN channel (2704)
Description	Use this function to enter the 2.4 GHz WLAN channel.
User entry	1 to 11
Factory setting	6

5) Service Set Identifier

Additional information*Description*

- It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.
- If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna**Navigation**

Expert → Communication → WLAN settings → Select antenna (2713)

Description

Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting

Internal antenna

Connection state**Navigation**

Expert → Communication → WLAN settings → Connection state (2722)

Description

The connection status is displayed.

User interface

- Connected
- Not connected

Factory setting

Not connected

Received signal strength**Navigation**

Expert → Communication → WLAN settings → Rec.sig.strength (2721)

Description

Displays the signal strength received.

User interface

- Low
- Medium
- High

Factory setting

High

Gateway IP address


Navigation	Expert → Communication → WLAN settings → Gateway IP addr. (2719)
Description	Use this function to enter the IP address of the gateway.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212

IP address domain name server

Navigation	Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212


3.4 "Analog inputs" submenu

Navigation  Expert → Analog inputs



3.4.1 "Analog input 1 to n" submenu

Navigation  Expert → Analog inputs → Analog input 1 to n



Out status (1564-1 to n)	→ 104
Out status (1549-1 to n)	→ 104

Channel**Navigation**

Expert → Analog inputs → Analog input 1 to n → Channel (1561-1 to n)

Description

For selecting the process variable.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronics temperature
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up index *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Volume flow

PV filter time**Navigation**

Expert → Analog inputs → Analog input 1 to n → PV filter time (1524-1 to n)

Description

Use this function to enter a time to suppress signal peaks. During the specified time the Analog input does not respond to an erratic increase in the process variable.

User entry

Positive floating-point number

Factory setting

0

* Visibility depends on order options or device settings

Fail-safe type

Navigation Expert → Analog inputs → Analog input 1 to n → Fail-safe type (1525–1 to n)

Description Use this function to select the failure mode.

- Selection**
- Fail-safe value
 - Fallback value
 - Off

Factory setting Off

Additional information *Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail-safe value
A substitute value is used. This is specified in the **Fail-safe value** parameter (→ 103).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail-safe value

Navigation Expert → Analog inputs → Analog input 1 to n → Fail-safe value (1526–1 to n)

Prerequisite In **Fail-safe type** parameter (→ 103), the **Fail-safe value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 103)) in the event of an error.

User entry Signed floating-point number

Factory setting 0

Out value

Navigation Expert → Analog inputs → Analog input 1 to n → Out value (1552–1 to n)

Prerequisite In **Target mode** parameter (→ 105), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface Signed floating-point number

Out status

Navigation   Expert → Analog inputs → Analog input 1 to n → Out status (1564–1 to n)

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation   Expert → Analog inputs → Analog input 1 to n → Out status (1549–1 to n)

Prerequisite In **Target mode** parameter (→  105), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description 

Navigation  Expert → Analog inputs → Analog input 1 to n → Tag description (1562–1 to n)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Analog inputs → Analog input 1 to n → Static revision (1560–1 to n)

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy

Navigation Expert → Analog inputs → Analog input 1 to n → Strategy (1559–1 to n)

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation Expert → Analog inputs → Analog input 1 to n → Alert key (1522–1 to n)

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Analog inputs → Analog input 1 to n → Target mode (1563–1 to n)

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block actual

Navigation Expert → Analog inputs → Analog input 1 to n → Mode block act (1521–1 to n)

Description Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 105).

User interface

- Auto
- Man
- Out of service

Additional information*Description*

A comparison of the current mode with the target mode (**Target mode** parameter (→ 105)) indicates whether it was possible to reach the target mode.

Mode block permitted**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Mode block perm (1553-1 to n)

Description

Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 105) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode block normal**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Mode blk norm (1546-1 to n)

Description

Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary**Navigation**

█ Expert → Analog inputs → Analog input 1 to n → Alarm summary (1537-1 to n)

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Inputs function block.

Batch ID

Navigation Expert → Analog inputs → Analog input 1 to n → Batch ID (1533–1 to n)

Description Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry Positive integer

Batch operation

Navigation Expert → Analog inputs → Analog input 1 to n → Batch operation (1534–1 to n)

Description Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch phase

Navigation Expert → Analog inputs → Analog input 1 to n → Batch phase (1535–1 to n)

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe Unit Procedure

Navigation Expert → Analog inputs → Analog input 1 to n → Batch Recipe (1536–1 to n)

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information	Description
	 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PV scale lower range 

Navigation	 Expert → Analog inputs → Analog input 1 to n → PVscale lo range (1554-1 to n)
Description	Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.
User entry	Signed floating-point number
Factory setting	0

PV scale upper range 

Navigation	 Expert → Analog inputs → Analog input 1 to n → PVscale up range (1555-1 to n)
Description	Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.
User entry	Signed floating-point number
Factory setting	100.0

Out scale lower range 

Navigation	 Expert → Analog inputs → Analog input 1 to n → Out scale low (1548-1 to n)
Description	Use this function to enter the lower value range for the output value in system units.
User entry	Signed floating-point number
Factory setting	0

Out scale upper range 

Navigation	 Expert → Analog inputs → Analog input 1 to n → Out scale up (1551-1 to n)
Description	Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number

Factory setting 100.0

Lin type

Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Lin type (1523–1 to n)

Description Use this function to switch off the linearization type for the input value.

Selection Off

Factory setting Off

Out unit

Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Out unit (1550–1 to n)

Description Use this function to enter a numerical code (hex) for the system unit.

User entry 0 to 65 535

Factory setting 1 997

Out decimal point

Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Out dec_point (1547–1 to n)

Description Use this function to enter the maximum number of decimal places that are displayed for the output value.

User entry 0 to 7

Factory setting 0

Alarm hysteresis

Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Alarm hysteresis (1527–1 to n)

Description Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry Signed floating-point number

Factory setting 0

Hi Hi Lim



Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Hi Hi Lim (1528–1 to n)

Description Use this function to enter the value for the upper alarm limit (**Hi Hi alarm value** parameter (→ ☐ 111)).

User entry Signed floating-point number

Factory setting Positive floating-point number

Additional information *Description*

i If the output value Out value (→ ☐ 103) exceeds this limit value, the **Hi Hi alarm state** parameter (→ ☐ 112) is output.

User entry

i The value is entered in the defined units (**Out unit** parameter (→ ☐ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ ☐ 108) and **Out scale upper range** parameter (→ ☐ 108).

Hi Lim



Navigation ☐ Expert → Analog inputs → Analog input 1 to n → Hi Lim (1529–1 to n)

Description Use this function to enter the value for the upper warning limit (**Hi alarm value** parameter (→ ☐ 112)).

User entry Signed floating-point number

Factory setting Positive floating-point number

Additional information *Description*

i If the output value Out value (→ ☐ 103) exceeds this limit value, the **Hi alarm state** parameter (→ ☐ 112) is output.

User entry

i The value is entered in the defined units (**Out unit** parameter (→ ☐ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ ☐ 108) and **Out scale upper range** parameter (→ ☐ 108).

Lo Lim

Navigation Expert → Analog inputs → Analog input 1 to n → Lo Lim (1530–1 to n)

Description Use this function to enter the value for the lower warning limit (**Lo alarm value** parameter (→ [112](#))).

User entry Signed floating-point number

Factory setting Negative floating-point number

Additional information *Description*

If the output value Out value (→ [103](#)) exceeds this limit value, the **Lo alarm state** parameter (→ [113](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [109](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [108](#)) and **Out scale upper range** parameter (→ [108](#)).

Lo Lo Lim

Navigation Expert → Analog inputs → Analog input 1 to n → Lo Lo Lim (1531–1 to n)

Description Use this function to enter the value for the lower alarm limit (**Lo Lo alarm value** parameter (→ [113](#))).

User entry Signed floating-point number

Factory setting Negative floating-point number

Additional information *Description*

If the output value Out value (→ [103](#)) exceeds this limit value, the **Lo Lo alarm state** parameter (→ [113](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [109](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [108](#)) and **Out scale upper range** parameter (→ [108](#)).

Hi Hi alarm value

Navigation Expert → Analog inputs → Analog input 1 to n → HiHi alarm value (1541–1 to n)

Description Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ [110](#))).

User interface	Signed floating-point number
----------------	------------------------------

Hi Hi alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → HiHi alarm state (1540–1 to n)
Description	Displays the status for the upper alarm limit value (Hi Hi Lim parameter (→  110)).
User interface	<ul style="list-style-type: none">■ No alarm■ Alarm state HiHi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to n → Hi alarm value (1539–1 to n)
Description	Displays the alarm value for the upper warning limit value (Hi Lim parameter (→  110)).
User interface	Signed floating-point number

Hi alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → Hi alarm state (1538–1 to n)
Description	Displays the status for the upper warning limit value (Hi Lim parameter (→  110)).
User interface	<ul style="list-style-type: none">■ No warning■ Alarm state Hi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to n → Lo alarm value (1543–1 to n)
Description	Displays the alarm value for the lower warning limit value (Lo Lim parameter (→  111)).

User interface	Signed floating-point number
----------------	------------------------------

Lo alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → Lo alarm state (1542–1 to n)
Description	Displays the status for the lower warning limit value (Lo Lim parameter (→  111)).
User interface	<ul style="list-style-type: none"> ■ No warning ■ Alarm state Lo limit
Additional information	<p><i>User interface</i></p>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo Lo alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to n → LoLo alarm value (1545–1 to n)
Description	Displays the alarm value for the lower alarm limit value (Lo Lo Lim parameter (→  111)).
User interface	Signed floating-point number

Lo Lo alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to n → LoLo alarm state (1544–1 to n)
Description	Displays the status for the lower alarm limit value (Lo Lo Lim parameter (→  111)).
User interface	<ul style="list-style-type: none"> ■ No alarm ■ Alarm state LoLo limit
Additional information	<p><i>User interface</i></p>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Simulate enabled

Navigation	 Expert → Analog inputs → Analog input 1 to n → Simulate enabled (1556–1 to n)
Description	Use this function to enable or disable block simulation.

Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value █

Navigation	 Expert → Analog inputs → Analog input 1 to n → Simulate value (1558–1 to n)
Description	Use this function to enter a simulation value for the block.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status █

Navigation	 Expert → Analog inputs → Analog input 1 to n → Simulate status (1557–1 to n)
Description	Use this function to enter a simulation status for the block.
User entry	0 to 255
Factory setting	0
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Out unit text █

Navigation	 Expert → Analog inputs → Analog input 1 to n → Out unit text (1532–1 to n)
Description	Use this function to enter the out unit text: if a specific out unit does not appear in the code list, the user can enter the specific text. The unit code is then equivalent to the definition provided here.


User entry Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting NoUnit

3.5 "Discrete inputs" submenu

Navigation


Expert → Discrete inputs



3.5.1 "Discrete input 1 to n" submenu

Navigation

Expert → Discrete inputs → Discrete input 1 to n



Channel



Navigation Expert → Discrete inputs → Discrete input 1 to n → Channel (2187-1 to n)

Description Use this function to assign a measured variable to the particular function block.

Selection

- Empty pipe detection
- Low flow cut off
- Verification status *
- Build-up detection *

* Visibility depends on order options or device settings

Factory setting	Empty pipe detection
------------------------	----------------------

Invert	
---------------	---

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Invert (2188–1 to n)
-------------------	---

Description	Use this function to invert the input signal.
--------------------	---

Selection	<ul style="list-style-type: none">■ Off■ On
------------------	--

Factory setting	Off
------------------------	-----

Fail-safe type	
-----------------------	---

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Fail-safe type (2189–1 to n)
-------------------	---

Description	Use this function to select the failure mode.
--------------------	---

Selection	<ul style="list-style-type: none">■ Fail-safe value■ Fallback value■ Off
------------------	--

Factory setting	Off
------------------------	-----

Additional information	<i>Selection</i>
-------------------------------	------------------

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail-safe value
 - A substitute value is used. This is specified in the **Fail-safe value** parameter (→ 116).
- Fallback value
 - If the value was good at one point, then this last valid value is used.
- Off
 - The system continues to use the bad value.

Fail-safe value	
------------------------	---

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Fail-safe value (2190–1 to n)
-------------------	--

Prerequisite	In Fail-safe type parameter (→ 116), the Fail-safe value option is selected.
---------------------	--

Description	Use this function to enter a failure value. The value entered is displayed as the output value (Out value parameter (→ 117)) in the event of an error.
--------------------	--

User entry	0 to 255
-------------------	----------

Factory setting 0

Out value

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out value (2194–1 to n)

Prerequisite In **Target mode** parameter (→ 118), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface 0 to 255

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status (2203–1 to n)

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Out status (2193–1 to n)

Prerequisite In **Target mode** parameter (→ 118), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description

Navigation  Expert → Discrete inputs → Discrete input 1 to n → Tag description (2201–1 to n)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Static revision (2200–1 to n)
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Strategy

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Strategy (2199–1 to n)
Description	Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert key

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Alert key (2182–1 to n)
Description	Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	0

Target mode

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Target mode (2202–1 to n)
Description	Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service

Mode block actual

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Mode block act (2181–1 to n)
Description	Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 118).
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service
Additional information	<p><i>Description</i></p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 118)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Mode block perm (2195–1 to n)
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 118) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Mode blk norm (2192–1 to n)
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service

Alarm summary

Navigation	 Expert → Discrete inputs → Discrete input 1 to n → Alarm summary (2191–1 to n)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Inputs function block.

Batch ID**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Batch ID (2183–1 to n)

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Batch operation (2184–1 to n)

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to n → Batch phase (2185–1 to n)

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe Unit Procedure

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Batch Recipe (2186–1 to n)
Description	Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).
User entry	0 to 65 535
Factory setting	0
Additional information	<i>Description</i> The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Simulate enabled

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Simulate enabled (2196–1 to n)
Description	Use this function to enable or disable block simulation.
Selection	■ Disable ■ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value

Navigation	Expert → Discrete inputs → Discrete input 1 to n → Simulate value (2198–1 to n)
Description	Use this function to enter a simulation value for the block.
User entry	0 to 255
Factory setting	0
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status

Navigation Expert → Discrete inputs → Discrete input 1 to n → Simulate status (2197–1 to n)

Description Use this function to enter a simulation status for the block.

User entry 0 to 255


Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.


3.6 "Analog outputs" submenu

Navigation Expert → Analog outputs



3.6.1 "Analog output 1 to n" submenu

Navigation Expert → Analog outputs → Analog output 1 to n



Set point value

Navigation	Expert → Analog outputs → Analog output 1 to n → Set point val (1661–1 to n)
Description	Use this function to enter an analog set point.
User entry	Signed floating-point number
Factory setting	0

Set point status

Navigation	Expert → Analog outputs → Analog output 1 to n → Set point status (1660–1 to n)
Description	Use this function to enter a status for the analog set point.
User entry	0 to 255
Factory setting	0

Fail-safe time

Navigation	Expert → Analog outputs → Analog output 1 to n → Fail-safe time (1635–1 to n)
Description	Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.
User entry	0 to 999.0
Factory setting	0
Additional information	<i>User entry</i> NOTE! If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.). ► Check in advance to ensure that the safety-specific requirements of the process would permit this. ► If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail-safe type

Navigation Expert → Analog outputs → Analog output 1 to n → Fail-safe type (1636-1 to n)

Description Use this function to select the failure mode.

Selection

- Fail-safe value
- Fallback value
- Off

Factory setting Fallback value

Additional information *Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail-safe value
A substitute value is used. This is specified in the **Fail-safe value** parameter (→ 124).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail-safe value

Navigation Expert → Analog outputs → Analog output 1 to n → Fail-safe value (1637-1 to n)

Prerequisite In **Fail-safe type** parameter (→ 124), the **Fallback value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 124)) in the event of an error.

User entry Signed floating-point number

Factory setting 0

Out value

Navigation Expert → Analog outputs → Analog output 1 to n → Out value (1647-1 to n)

Prerequisite In **Target mode** parameter (→ 126), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface Signed floating-point number

Out status

Navigation	  Expert → Analog outputs → Analog output 1 to n → Out status (1669–1 to n)
Description	Displays the current output status (Good, Bad, Uncertain).
User interface	<ul style="list-style-type: none">■ Good■ Uncertain■ Bad

Out status

Navigation	  Expert → Analog outputs → Analog output 1 to n → Out status (1645–1 to n)
Prerequisite	In Target mode parameter (→ 126), the Auto option is selected.
Description	Displays the current output status (hex value).
User interface	0 to 0xFF

Tag description

Navigation	 Expert → Analog outputs → Analog output 1 to n → Tag description (1667–1 to n)
Description	Use this function to enter a string to identify the block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	 Expert → Analog outputs → Analog output 1 to n → Static revision (1666–1 to n)
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Strategy**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Strategy (1665–1 to n)

Description

Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry

0 to FFFF

Factory setting

0

Alert key**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Alert key (1632–1 to n)

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Target mode (1668–1 to n)

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Mode block actual**Navigation**

█ Expert → Analog outputs → Analog output 1 to n → Mode block act (1631–1 to n)

Description

Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ [126](#)).

User interface	<ul style="list-style-type: none"> ■ Auto ■ Local override ■ Man ■ Out of service ■ Remote Cascaded
Additional information	<p><i>Description</i></p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 126)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Analog outputs → Analog output 1 to n → Mode block perm (1648-1 to n)
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 126) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Analog outputs → Analog output 1 to n → Mode blk norm (1643-1 to n)
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none"> ■ Auto ■ Local override ■ Man ■ Out of service ■ Remote Cascaded

Alarm summary

Navigation	 Expert → Analog outputs → Analog output 1 to n → Alarm summary (1642-1 to n)
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none"> ■ Discrete alarm ■ Alarm state HiHi limit ■ Alarm state Hi limit ■ Alarm state LoLo limit ■ Alarm state Lo limit ■ Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Outputs function block.

Batch ID**Navigation**

Expert → Analog outputs → Analog output 1 to n → Batch ID (1633–1 to n)

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

Expert → Analog outputs → Analog output 1 to n → Batch operation (1639–1 to n)

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase**Navigation**

Expert → Analog outputs → Analog output 1 to n → Batch phase (1640–1 to n)

Description

Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch Recipe Unit Procedure**Navigation**

Expert → Analog outputs → Analog output 1 to n → Batch Recipe (1641–1 to n)

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information *Description*



The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PV scale lower range



Navigation ☐ Expert → Analog outputs → Analog output 1 to n → PVscale lo range (1651–1 to n)

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PV scale upper range



Navigation ☐ Expert → Analog outputs → Analog output 1 to n → PVscale up range (1652–1 to n)

Description Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 100.0

Readback value

Navigation ☐ Expert → Analog outputs → Analog output 1 to n → Readback value (1659–1 to n)

Description Displays the readback value. The readback value indicates the current position of the control element within the travel range (between the open and close position) in PV scale units.

User interface Signed floating-point number

Readback status

Navigation	 Expert → Analog outputs → Analog output 1 to n → Readback status (1658-1 to n)
Description	Displays the readback status. The readback status contains the status information of the slave.
User interface	0 to 255

RCAS in value



Navigation	 Expert → Analog outputs → Analog output 1 to n → RCAS in value (1655-1 to n)
Description	Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade RCAS in value parameter (→  130). The normal algorithm calculates the output value of the block on the basis of this set point.
User entry	Signed floating-point number
Factory setting	0

RCAS in status



Navigation	 Expert → Analog outputs → Analog output 1 to n → RCAS in status (1654-1 to n)
Description	Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→  130).
User entry	0 to 255
Factory setting	0

Input channel



Navigation	 Expert → Analog outputs → Analog output 1 to n → Input channel (1670-1 to n)
Description	Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.
Selection	None
Factory setting	None

Output channel

Navigation	Expert → Analog outputs → Analog output 1 to n → Output channel (1671-1 to n)
Description	Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.
Selection	<ul style="list-style-type: none">■ External temperature■ External density
Factory setting	External density

RCAS out value

Navigation	Expert → Analog outputs → Analog output 1 to n → RCAS out value (1657-1 to n)
Description	Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.
User interface	Signed floating-point number

RCAS out status

Navigation	Expert → Analog outputs → Analog output 1 to n → RCAS out status (1656-1 to n)
Description	Displays the RCAS out status. Displays the status of the set point.
User interface	0 to 0xFF

Position value

Navigation	Expert → Analog outputs → Analog output 1 to n → Pos value (1650-1 to n)
Description	Displays the current value of the positioner.
User interface	0 to 255

Position status

Navigation	Expert → Analog outputs → Analog output 1 to n → Position status (1649–1 to n)
Description	Displays the current status of the positioner.
User interface	0 to 255

Setpoint deviation

Navigation	Expert → Analog outputs → Analog output 1 to n → Setp. deviation (1653–1 to n)
Description	Displays the deviation between the set point (Set point value parameter (→ 123)) and the actual value (Readback value parameter (→ 129)).
User interface	Signed floating-point number

Simulate enabled

Navigation	Expert → Analog outputs → Analog output 1 to n → Simulate enabled (1662–1 to n)
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">▪ Disable▪ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value

Navigation	Expert → Analog outputs → Analog output 1 to n → Simulate value (1664–1 to n)
Description	Use this function to enter a simulation value.
User entry	Signed floating-point number
Factory setting	0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status

Navigation Expert → Analog outputs → Analog output 1 to n → Simulate status (1663-1 to n)

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Increase close

Navigation Expert → Analog outputs → Analog output 1 to n → Increase close (1638-1 to n)

Description Use this function to enter the effective direction of the positioner in automatic mode.

User entry 0 to 255

Factory setting 0

Out scale upper range

Navigation Expert → Analog outputs → Analog output 1 to n → Out scale up (1646-1 to n)

Description Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number


Factory setting 100.0

Out scale lower range

Navigation	█ Expert → Analog outputs → Analog output 1 to n → Out scale low (1644–1 to n)
Description	Use this function to enter the lower value range for the output value in system units.
User entry	Signed floating-point number
Factory setting	0


3.7 "Discrete outputs" submenu

Navigation █ █ Expert → Discrete outputs



3.7.1 "Discrete output 1 to n" submenu

Navigation █ █ Expert → Discrete outputs → Discr. out. 1 to n



Set point value

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Set point val (1715–1 to n)
Description	Use this function to enter an analog set point.
User entry	0 to 255
Factory setting	0

Set point status

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Set point status (1714–1 to n)
Description	Use this function to enter a status for the analog set point.
User entry	0 to 255
Factory setting	0

Invert

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Invert (1692–1 to n)
Description	Use this function to switch inversion on and off. Specifies whether the set point should be inverted before the value is set as the output value or the RCAS value (in the automatic mode).
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off

Fail-safe time

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Fail-safe time (1697–1 to n)
Description	Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.
User entry	Signed floating-point number
Factory setting	0

Additional information*User entry***NOTE!**

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- Check in advance to ensure that the safety-specific requirements of the process would permit this.
- If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail-safe type**Navigation** Expert → Discrete outputs → Discr. out. 1 to n → Fail-safe type (1696–1 to n)**Description**

Use this function to select the failure mode.

Selection

- Fail-safe value
- Fallback value
- Off

Factory setting

Fallback value

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail-safe value
 - A substitute value is used. This is specified in the **Fail-safe value** parameter (→ 136).
- Fallback value
 - If the value was good at one point, then this last valid value is used.
- Off
 - The system continues to use the bad value.

Fail-safe value**Navigation** Expert → Discrete outputs → Discr. out. 1 to n → Fail-safe value (1693–1 to n)**Prerequisite**

In **Fail-safe type** parameter (→ 136), the **Fail-safe value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 137)) in the event of an error.

User entry

0 to 255

Factory setting

0

Out value

Navigation	  Expert → Discrete outputs → Discr. out. 1 to n → Out value (1704-1 to n)
Prerequisite	In Target mode parameter (→ 138), the Auto option is selected.
Description	Displays the analog value which is calculated when the function is executed.
User interface	0 to 255

Out status

Navigation	  Expert → Discrete outputs → Discr. out. 1 to n → Out status (1723-1 to n)
Description	Displays the current output status (Good, Bad, Uncertain).
User interface	<ul style="list-style-type: none">■ Good■ Uncertain■ Bad

Out status

Navigation	  Expert → Discrete outputs → Discr. out. 1 to n → Out status (1703-1 to n)
Prerequisite	In Target mode parameter (→ 138), the Auto option is selected.
Description	Displays the current output status (hex value).
User interface	0 to 0xFF

Tag description



Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Tag description (1721-1 to n)
Description	Use this function to enter a string to identify the block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Static revision (1720–1 to n)
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Strategy

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Strategy (1719–1 to n)
Description	Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert key

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Alert key (1694–1 to n)
Description	Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	0

Target mode

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Target mode (1722–1 to n)
Description	Displays the Target mode: The target mode specifies which mode of operation is used for this function block. This mode is generally set by a control application.

User interface	<ul style="list-style-type: none"> ■ Local override ■ Remote Cascaded ■ Man ■ Out of service ■ Auto
-----------------------	--

Mode block actual

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Mode block act (1691–1 to n)
Description	Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 138).
User interface	<ul style="list-style-type: none"> ■ Local override ■ Remote Cascaded ■ Man ■ Out of service ■ Auto
Additional information	<p>Description</p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 138)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Mode block perm (1705–1 to n)
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 138) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Mode blk norm (1702–1 to n)
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Local override
- Remote Cascaded
- Man
- Out of service
- Auto

Alarm summary**Navigation**

 Expert → Discrete outputs → Discr. out. 1 to n → Alarm summary (1701–1 to n)

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information*Description*

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Outputs function block.

Batch ID**Navigation**

 Expert → Discrete outputs → Discr. out. 1 to n → Batch ID (1695–1 to n)

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation**Navigation**

 Expert → Discrete outputs → Discr. out. 1 to n → Batch operation (1698–1 to n)

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Batch phase (1699–1 to n)
Description	Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch Recipe Unit Procedure

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Batch Recipe (1700–1 to n)
Description	Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).
User entry	0 to 65 535
Factory setting	0
Additional information	<i>Description</i> The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Readback value

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Readback value (1713–1 to n)
Description	Displays the readback value. The readback value indicates the current position of the control element and the element's sensors.
User interface	0 to 255

Readback status

Navigation	Expert → Discrete outputs → Discr. out. 1 to n → Readback status (1712–1 to n)
Description	Displays the readback status. Displays the status of the readback value.
User interface	0 to 255

RCAS in value

Navigation Expert → Discrete outputs → Discr. out. 1 to n → RCAS in value (1707–1 to n)

Description Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade **RCAS in value** parameter (→ 142). The normal algorithm calculates the output value of the block on the basis of this set point.

User entry 0 to 255

Factory setting 0

RCAS in status

Navigation Expert → Discrete outputs → Discr. out. 1 to n → RCAS in status (1706–1 to n)

Description Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→ 142).

User entry 0 to 255

Factory setting 0

Input channel

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Input channel (1724–1 to n)

Description Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.

Selection None

Factory setting None

Output channel

Navigation Expert → Discrete outputs → Discr. out. 1 to n → Output channel (1725–1 to n)

Description Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.

Selection

- Flow override
- Start verification *

* Visibility depends on order options or device settings

Factory setting	Flow override
------------------------	---------------

RCAS out value

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → RCAS out value (1711-1 to n)
Description	Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.
User interface	0 to 255

RCAS out status

Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → RCAS out status (1708-1 to n)
Description	Displays the RCAS out status. Displays the status of the set point.
User interface	0 to 255

Simulate enabled



Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Simulate enabled (1716-1 to n)
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">▪ Disable▪ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value



Navigation	 Expert → Discrete outputs → Discr. out. 1 to n → Simulate value (1718-1 to n)
Description	Use this function to enter a simulation value.
User entry	0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status



Navigation Expert → Discrete outputs → Discr. out. 1 to n → Simulate status (1717-1 to n)

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0


Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

3.8 "Application" submenu

Navigation

Expert → Application



Reset all totalizers

Navigation

Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information*Selection*

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totaled.

3.8.1 "Totalizer 1 to n" submenu*Navigation*

Expert → Application → Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable (3808-1 to n)	→ 145
Unit totalizer (3835-1 to n)	→ 146
Control Totalizer 1 to n (3830-1 to n)	→ 147
Preset value 1 to n (3829-1 to n)	→ 148
Totalizer operation mode (3823-1 to n)	→ 148
Failure mode (3810-1 to n)	→ 149
Out value 1 to n (3827-1 to n)	→ 149
Totalizer status 1 to n (3826-1 to n)	→ 150
Totalizer status (Hex) 1 to n (3825-1 to n)	→ 150

Assign process variable**Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (3808-1 to n)

Description

Use this function to select a process variable for Totalizer 1 to n.

Selection

- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

Additional information**Description**

If the option selected is changed, the device resets the totalizer to 0.

Unit totalizer**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer (3835–1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 145):

- Volume flow
- Mass flow

Description

Use this function to select the process variable of a totalizer.

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 44).

Selection*SI units*

- g *
- kg *
- t *

US units

- oz *
- lb *
- STon *

* Visibility depends on order options or device settings

or

SI units

- cm³ *
- dm³ *
- m³ *
- ml *
- l *
- hl *
- Ml Mega *

US units

- af *
- ft³ *
- Mft³ *
- Mft³ *
- fl oz (us) *
- gal (us) *
- kgal (us) *
- Mgal (us) *
- bbl (us;liq.) *
- bbl (us;beer) *
- bbl (us;oil) *
- bbl (us;tank) *

Imperial units

- gal (imp) *
- Mgal (imp) *
- bbl (imp;beer) *
- bbl (imp;oil) *

* Visibility depends on order options or device settings

or

SI units

- NI *
- Nhl *
- Nm³ *
- Sl *
- Sm³ *

US units

- Sft³ *
- MSft³ *
- MMSft³ *
- Sgal (us) *
- Sbbl (us;liq.) *
- Sbbl (us;oil) *

Imperial units

- Sgal (imp) *

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ m ³ ■ ft ³
Additional information	<p><i>Selection</i></p> <p>The selection is independent of the process variable selected in the Assign process variable parameter (→ 145).</p> <p><i>Dependency</i></p> <p>The following parameters depend on the option selected:</p> <ul style="list-style-type: none"> ■ Alarm hysteresis parameter (→ 154) ■ Hi Hi Lim parameter (→ 154) ■ Hi Lim parameter (→ 155) ■ Lo Lim parameter (→ 155) ■ Lo Lo Lim parameter (→ 156) ■ Totalizer value parameter (→ 43) ■ Preset value parameter (→ 148)

Control Totalizer 1 to n

Navigation	 Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (3830-1 to n)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 145): ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to select the control of totalizer value 1-3.
Selection	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold
Factory setting	Totalize
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Totalize The totalizer is started or continues totalizing with the current counter reading. ■ Reset + hold The totaling process is stopped and the totalizer is reset to 0. ■ Preset + hold The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.

Preset value 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Preset value 1 to n (3829–1 to n)

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→  145):
■ Volume flow
■ Mass flow

Description Use this function to enter an initial value for the specific totalizer.

User entry Signed floating-point number

Factory setting Country-specific:
■ m³
■ ft³

Additional information *User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→  146).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Totalizer operation mode



Navigation  Expert → Application → Totalizer 1 to n → Operation mode (3823–1 to n)

Prerequisite In the **Assign process variable** parameter (→  145), one of the following options is selected:
■ Volume flow
■ Mass flow

Description Use this function to select how the totalizer summates the flow.

Selection
■ Net flow total
■ Forward flow total
■ Reverse flow total
■ Last valid value

Factory setting Net flow total

Additional information*Selection*

- Net flow total
Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow against the forward flow direction is totalized (= reverse flow total).
- Last valid value
The value is frozen. Totaling is stopped.

Failure mode**Navigation**

Expert → Application → Totalizer 1 to n → Failure mode (3810-1 to n)

Prerequisite

In the **Assign process variable** parameter (→ 145), one of the following options is selected:

- Volume flow
- Mass flow

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Actual value

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

- Stop
Totalizing is stopped when a device alarm occurs.
- Actual value
The totalizer continues to count based on the current measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

Out value 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Out value 1 to n (3827-1 to n)

Prerequisite

The **Auto** option is selected in the **Target mode** parameter (→ 151).

Description

Displays the current reading for totalizer 1-3.

User interface Signed floating-point number

Additional information *Description*

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 149).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 148).

Dependency

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Totalizer status 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Tot. status 1 to n (3826–1 to n)

Description Displays the status of the particular totalizer.

User interface

- Good
- Uncertain
- Bad

Totalizer status (Hex) 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Status (Hex) 1 to n (3825–1 to n)

Prerequisite In **Target mode** parameter (→ 151), the **Auto** option is selected.

Description Displays the status value (hex) of the particular totalizer.

User interface 0 to 0xFF

Tag description



Navigation  Expert → Application → Totalizer 1 to n → Tag description (3833–1 to n)

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	 Expert → Application → Totalizer 1 to n → Static revision (3832–1 to n)
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<p><i>Description</i></p>  Static parameters are parameters that are not changed by the process.

Strategy



Navigation	 Expert → Application → Totalizer 1 to n → Strategy (3831–1 to n)
Description	Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert key



Navigation	 Expert → Application → Totalizer 1 to n → Alert key (3803–1 to n)
Description	Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	0

Target mode



Navigation	 Expert → Application → Totalizer 1 to n → Target mode (3834–1 to n)
Description	Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.
User interface	<ul style="list-style-type: none"> ▪ Auto ▪ Man ▪ Out of service

Mode block actual

Navigation  Expert → Application → Totalizer 1 to n → Mode block act (3801–1 to n)

Description Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→  151).

User interface

- Auto
- Man
- Out of service

Additional information *Description*
 A comparison of the current mode with the target mode (**Target mode** parameter (→  151)) indicates whether it was possible to reach the target mode.

Mode block permitted

Navigation  Expert → Application → Totalizer 1 to n → Mode block perm (3828–1 to n)

Description Displays the Mode block permitted: This defines which modes of operation in the Target mode (→  151) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface 0 to 255

Mode block normal

Navigation  Expert → Application → Totalizer 1 to n → Mode blk norm (3824–1 to n)

Description Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary

Navigation  Expert → Application → Totalizer 1 to n → Alarm summary (3809–1 to n)

Description Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alarm state HiHi limit■ Alarm state Hi limit■ Alarm state LoLo limit■ Alarm state Lo limit■ Update Event
Additional information	<p>Description</p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Totalizer function block.</p>

Batch ID	
Navigation	 Expert → Application → Totalizer 1 to n → Batch ID (3804-1 to n)
Description	Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.
User entry	Positive integer
Factory setting	0

Batch operation	
Navigation	 Expert → Application → Totalizer 1 to n → Batch operation (3805-1 to n)
Description	Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch phase	
Navigation	 Expert → Application → Totalizer 1 to n → Batch phase (3806-1 to n)
Description	Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch Recipe Unit Procedure**Navigation**

█ Expert → Application → Totalizer 1 to n → Batch Recipe (3807–1 to n)

Description

Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry

0 to 65 535

Factory setting

0

Additional information*Description*

i The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Alarm hysteresis**Navigation**

█ Expert → Application → Totalizer 1 to n → Alarm hysteresis (3802–1 to n)

Description

Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry

Signed floating-point number

Factory setting

0 m³

Additional information*User entry*

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Hi Hi Lim**Navigation**

█ Expert → Application → Totalizer 1 to n → Hi Hi Lim (3815–1 to n)

Description

Use this function to enter the value for the upper alarm limit of the totalizer (**Hi Hi alarm value** parameter (→ 156)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

If the output value Out value (→ 103) exceeds this limit value, the **Hi alarm state** parameter (→ 157) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ 108) and **Out scale upper range** parameter (→ 108).



The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Hi Lim**Navigation**

Expert → Application → Totalizer 1 to n → Hi Lim (3816–1 to n)

Description

Use this function to enter the value for the upper warning limit of the totalizer (**Hi alarm value** parameter (→ 157)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

If the output value Out value (→ 103) exceeds this limit value, the **Hi alarm state** parameter (→ 157) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ 108) and **Out scale upper range** parameter (→ 108).



The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Lo Lim**Navigation**

Expert → Application → Totalizer 1 to n → Lo Lim (3819–1 to n)

Description

Use this function to enter the value for the lower warning limit of the totalizer (**Lo alarm value** parameter (→ 157)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

 If the output value Out value (→ 103) exceeds this limit value, the **Lo alarm state** parameter (→ 158) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ 108) and **Out scale upper range** parameter (→ 108).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Lo Lo Lim**Navigation**

 Expert → Application → Totalizer 1 to n → Lo Lo Lim (3822–1 to n)

Description

Use this function to enter the value for the lower alarm limit of the totalizer (**Lo Lo alarm value** parameter (→ 158)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

 If the output value Out value (→ 103) exceeds this limit value, the **Lo Lo alarm state** parameter (→ 158) is output.

User entry

 The value is entered in the defined units (**Out unit** parameter (→ 109)) and must be in the range defined in the **Out scale lower range** parameter (→ 108) and **Out scale upper range** parameter (→ 108).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 146).

Hi Hi alarm value**Navigation**

 Expert → Application → Totalizer 1 to n → HiHi alarm value (3814–1 to n)

Description

Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ 154)).

User interface

Signed floating-point number

Hi Hi alarm state

Navigation	 Expert → Application → Totalizer 1 to n → HiHi alarm state (3813-1 to n)
Description	Displays the status for the upper alarm limit value (Hi Hi Lim parameter (→  154)).
User interface	<ul style="list-style-type: none">■ No alarm■ Alarm state HiHi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation	 Expert → Application → Totalizer 1 to n → Hi alarm value (3812-1 to n)
Description	Displays the warning value for the upper warning limit value (Hi Lim parameter (→  155)).
User interface	Signed floating-point number

Hi alarm state

Navigation	 Expert → Application → Totalizer 1 to n → Hi alarm state (3811-1 to n)
Description	Displays the status for the upper warning limit value (Hi Lim parameter (→  155)).
User interface	<ul style="list-style-type: none">■ No warning■ Alarm state Hi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation	 Expert → Application → Totalizer 1 to n → Lo alarm value (3818-1 to n)
Description	Displays the warning value for the lower warning limit value (Lo Lim parameter (→  155)).
User interface	Signed floating-point number

Lo alarm state

Navigation  Expert → Application → Totalizer 1 to n → Lo alarm state (3817-1 to n)

Description Displays the status for the lower warning limit value (**Lo Lim** parameter (→  155)).

User interface

- No warning
- Alarm state Lo limit

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo Lo alarm value

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm value (3821-1 to n)

Description Displays the alarm value for the lower alarm limit value (**Lo Lo Lim** parameter (→  156)).

User interface Signed floating-point number

Lo Lo alarm state

Navigation  Expert → Application → Totalizer 1 to n → LoLo alarm state (3820-1 to n)

Description Displays the status for the lower alarm limit value (**Lo Lo Lim** parameter (→  156)).

User interface

- No alarm
- Alarm state LoLo limit


Additional information *User interface*

 The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

3.9 "Diagnostics" submenu

Navigation

  Expert → Diagnostics



Previous diagnostics (0690)	→ 160
Operating time from restart (0653)	→ 161
Operating time (0652)	→ 161
► Diagnostic list	→ 161
► Event logbook	→ 166
► Device information	→ 168
► Main electronic module	→ 171
► Sensor electronic module (ISEM)	→ 172
► Display module	→ 173
► Min/max values	→ 174
► Data logging	→ 176
► Heartbeat Technology	→ 184
► Simulation	→ 184

Actual diagnostics

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

- Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 161).
- Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Example

For the display format:

F271 Main electronics failure

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

Display

 The diagnostic message can be viewed via the **Actual diagnostics** parameter
(→  159).

Example

For the display format:
24d12h13m00s

Previous diagnostics

Navigation

 Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite

Two diagnostic events have already occurred.

Description

Displays the diagnostic message that occurred before the current message.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:
☒F271 Main electronics failure

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the last diagnostic message before the current message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Previous diagnostics** parameter
 (→ [160](#)).

Example

For the display format:

24d12h13m00s

Operating time from restart**Navigation**

Expert → Diagnostics → Time fr. restart (0653)

Description

Use this function to display the time the device has been in operation since the last device restart.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Operating time**Navigation**

Expert → Diagnostics → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.9.1 "Diagnostic list" submenu*Navigation*

Expert → Diagnostics → Diagnostic list

Diagnostic list	
Diagnostics 1 (0692)	→ 162
Diagnostics 2 (0693)	→ 162
Diagnostics 3 (0694)	→ 163
Diagnostics 4 (0695)	→ 164
Diagnostics 5 (0696)	→ 165

Diagnostics 1

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Displays the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: <ul style="list-style-type: none">▪  ΔS442 Frequency output▪  F276 I/O module failure

Timestamp

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 1 parameter (→  162).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 2

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→  162).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 3

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  163). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Examples</i> For the display format: ■ Δ S442 Frequency output ■ \otimes F276 I/O module failure

Timestamp 4

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fourth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 164).

Example

For the display format:
24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 5

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ 165).

Example


For the display format:
24d12h13m00s

3.9.2 "Event logbook" submenu

Viewing event messages

Event messages are displayed in chronological order. The event history includes both diagnostic events and information events. The symbol in front of the timestamp indicates whether the event has started or ended.

Navigation  Expert → Diagnostics → Event logbook



Filter options



Navigation

 Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information

Description

 The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

"Event list" submenu

 The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation Expert → Diagnostics → Event logbook → Event list Event list

Event list

→  167**Event list****Navigation** Expert → Diagnostics → Event logbook → Event list**Description**Displays the history of event messages of the category selected in the **Filter options** parameter (→  166).**User interface**

- For a "Category I" event message

Information event, short message, symbol for event recording and operating time when error occurred

- For a "Category F, C, S, M" event message (status signal)

Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

-  Occurrence of the event
-  End of the event

Examples

For the display format:

- I1091 Configuration modified
 24d12h13m00s
-  Frequency output
 01d04h12min30s

Additional information, such as remedial measures, can be retrieved via the  key.*HistoROM*

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

To order the **Extended HistoROM** application package, see the "Application packages" section of the "Technical Information" document

3.9.3 "Device information" submenu

Navigation

Expert → Diagnostics → Device info

► Device information	
Device tag (0011)	→ 168
Serial number (0009)	→ 169
Firmware version (0010)	→ 169
Device name (0013)	→ 169
Order code (0008)	→ 169
Extended order code 1 (0023)	→ 170
Extended order code 2 (0021)	→ 170
Extended order code 3 (0022)	→ 170
ENP version (0012)	→ 171

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

- none -

Additional information

User interface



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation  Expert → Diagnostics → Device info → Serial number (0009)**Description**

Displays the serial number of the measuring device.



The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation  Expert → Diagnostics → Device info → Firmware version (0010)**Description**

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name

Navigation  Expert → Diagnostics → Device info → Device name (0013)**Description**

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Factory setting

Promag 400 DP

Order code

**Navigation**  Expert → Diagnostics → Device info → Order code (0008)**Description**

Displays the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information *Description*

i The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

i **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1



Navigation

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information

Description

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

i The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2



Navigation

Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 170)

Extended order code 3



Navigation

Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface Character string

Additional information For additional information, see **Extended order code 1** parameter (→ 170)

ENP version

Navigation  Expert → Diagnostics → Device info → ENP version (0012)

Description Displays the version of the electronic nameplate.

User interface Character string


Factory setting 2.02.00

Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.9.4 "Main electronic module + I/O module 1" submenu

Navigation  Expert → Diagnostics → Mainboard module



Software revision

Navigation  Expert → Diagnostics → Main elec. mod. → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation   Expert → Diagnostics → Main elec. mod. → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision


Navigation   Expert → Diagnostics → Main elec. mod. → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.9.5 "Sensor electronic module (ISEM)" submenu

Navigation   Expert → Diagnostics → Sens. electronic



Software revision

Navigation   Expert → Diagnostics → Sens. electronic → Software rev. (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software


Navigation	  Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader revision

Navigation	  Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)
Description	Use this function to display the bootloader revision of the software.
User interface	Positive integer

3.9.6 "Display module" submenu

Navigation   Expert → Diagnostics → Display module



Software revision

Navigation	  Expert → Diagnostics → Display module → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

Build no. software

Navigation   Expert → Diagnostics → Display module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision


Navigation   Expert → Diagnostics → Display module → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer


3.9.7 "Min/max values" submenu

Navigation   Expert → Diagnostics → Min/max val.



"Main electronics temperature" submenu

Navigation   Expert → Diagnostics → Min/max val. → Main elect.temp.



Minimum value


Navigation	Diagram Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (6547)
Description	Displays the lowest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i> The unit is taken from the Temperature unit parameter (→  47)

Maximum value

Navigation	Diagram Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (6545)
Description	Displays the highest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i> The unit is taken from the Temperature unit parameter (→  47)

"Medium temperature" submenu

Navigation Diagram Expert → Diagnostics → Min/max val. → Medium temp.



Minimum value

Navigation	Diagram Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (6681)
Description	Displays the lowest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ 47)

Maximum value

Navigation  Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (6680)

Description Displays the highest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ 47)

3.9.8 "Data logging" submenu

Navigation  Expert → Diagnostics → Data logging

► Data logging	
Assign channel 1 (0851)	→ 177
Assign channel 2 (0852)	→ 178
Assign channel 3 (0853)	→ 178
Assign channel 4 (0854)	→ 178
Logging interval (0856)	→ 179
Clear logging data (0855)	→ 179
Data logging (0860)	→ 180
Logging delay (0859)	→ 180
Data logging control (0857)	→ 180
Data logging status (0858)	→ 181
Entire logging duration (0861)	→ 181

▶ Display channel 1	→ 182
▶ Display channel 2	→ 183
▶ Display channel 3	→ 183
▶ Display channel 4	→ 184

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description

Use this function to select a process variable for the data logging channel.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity *
- Conductivity *
- Corrected conductivity *
- Temperature
- Electronics temperature
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up measured value *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Off

Additional information

Description

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The log contents are cleared if the option selected is changed.

* Visibility depends on order options or device settings

Assign channel 2



Navigation	Expert → Diagnostics → Data logging → Assign chan. 2 (0852)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 39).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 177)
Factory setting	Off

Assign channel 3



Navigation	Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 39).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 177)
Factory setting	Off

Assign channel 4



Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 39).
Description	Use this function to select a process variable for the data logging channel.
Selection	For the picklist, see the Assign channel 1 parameter (→ 177)
Factory setting	Off

Logging interval



Navigation Expert → Diagnostics → Data logging → Logging interval (0856)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description Use this function to enter the logging interval T_{\log} for data logging.

User entry 0.1 to 3 600.0 s

Factory setting 1.0 s

Additional information*Description*

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data



Navigation Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting Cancel

Additional information*Selection*

■ Cancel

The data is not cleared. All the data is retained.

■ Clear data

The logging data is cleared. The logging process starts from the beginning.

Data logging**Navigation**

Expert → Diagnostics → Data logging → Data logging (0860)

Description

Use this function to select the data logging method.

Selection

- Overwriting
- Not overwriting

Factory setting

Overwriting

Additional information*Selection*

■ Overwriting

The device memory applies the FIFO principle.

■ Not overwriting

Data logging is canceled if the measured value memory is full (single shot).

Logging delay**Navigation**

Expert → Diagnostics → Data logging → Logging delay (0859)

Prerequisite

In the **Data logging** parameter (→ 180), the **Not overwriting** option is selected.

Description

Use this function to enter the time delay for measured value logging.

User entry

0 to 999 h

Factory setting

0 h

Additional information*Description*

Once measured value logging has been started with the **Data logging control** parameter (→ 180), the device does not save any data for the duration of the time delay entered.

Data logging control**Navigation**

Expert → Diagnostics → Data logging → Data log.control (0857)

Prerequisite

In the **Data logging** parameter (→ 180), the **Not overwriting** option is selected.

Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none"> ▪ None ▪ Delete + start ▪ Stop
Factory setting	None
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ None Initial measured value logging status. ▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again. ▪ Stop Measured value logging is stopped.

Data logging status

Navigation	  Expert → Diagnostics → Data logging → Data log. status (0858)
Prerequisite	In the Data logging parameter (→ 180), the Not overwriting option is selected.
Description	Displays the measured value logging status.
User interface	<ul style="list-style-type: none"> ▪ Done ▪ Delay active ▪ Active ▪ Stopped
Factory setting	Done
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Done Measured value logging has been performed and completed successfully. ▪ Delay active Measured value logging has been started but the logging interval has not yet elapsed. ▪ Active The logging interval has elapsed and measured value logging is active. ▪ Stopped Measured value logging is stopped.

Entire logging duration


Navigation	  Expert → Diagnostics → Data logging → Logging duration (0861)
Prerequisite	In the Data logging parameter (→ 180), the Not overwriting option is selected.
Description	Displays the total logging duration.

User interface Positive floating-point number

Factory setting 0 s

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite The **Extended HistoROM** application package is available.


 The software options currently enabled are displayed in the **Software option overview** parameter (→  39).

One of the following options is selected in the **Assign channel 1** parameter (→  177):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature
- Electronics temperature

Description Displays the measured value trend for the logging channel in the form of a chart.

Additional information *Description*



A0094352

 2 Chart of a measured value trend

* Visibility depends on order options or device settings

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 2



Display channel 2

Navigation



Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is defined in the **Assign channel 2** parameter.

Description

See the **Display channel 1** parameter → 182

"Display channel 3" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign channel 3** parameter.


Description

See the **Display channel 1** parameter → 182

"Display channel 4" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation

Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign channel 4** parameter.

Description

See the **Display channel 1** parameter → [182](#)

3.9.9 "Heartbeat" submenu

For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → [7](#)

Navigation


Expert → Diagnostics → HBT



3.9.10 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation



Assign simulation process variable**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature*

Factory setting

Off

Additional information*Description*

The simulation value of the process variable selected is defined in the **Process variable value** parameter (→ 185).

Process variable value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

A process variable is selected in the **Assign simulation process variable** parameter (→ 185).

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 44).

* Visibility depends on order options or device settings

Device alarm simulation

Navigation Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category

Navigation Expert → Diagnostics → Simulation → Event category (0738)

Description Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (→ 186).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting Process

Diagnostic event simulation

Navigation Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→ 186).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h option
Volume	m ³ option
Conductivity	µS/cm
Temperature	°C option
Mass flow	kg/h option
Mass	kg option
Density	kg/l option

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
150	150
200	300
250	500
300	750
350	1000
375	1200
400	1200
500	2000
600	2500
700	3500
750	4000
800	4500

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
900	6000
1000	7000
1200	10000
1400	14000
1600	18000
1800	23000
2000	28500
2200	34000
2400	40000
2600	48000
2800	55500
3000	63500

4.1.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	(v ~ 0.04 m/s) [dm ³ /min]
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
150	2.5
200	5
250	7.5
300	10
350	15
375	20
400	20
450	25
500	30
600	40
700	50
750	60
800	75

Nominal diameter [mm]	(v ~ 0.04 m/s) [m³/h]
900	100
1000	125
1200	150
1400	225
1600	300
1800	350
2000	450
2200	540
2400	650
2600	775
2800	875
3000	1025

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us) option
Volume	gal (us) option
Temperature	°F option
Mass flow	lb/min option
Mass	lb option
Density	lb/ft³ option

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1	18
1½	50
2	75
3	200
4	300
6	600
8	1200
10	1500
12	2400
14	3600
15	4800

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
16	4800
18	6000
20	7500
24	10500
28	13500
30	16500
32	19500
36	24000
40	30000
42	33000
48	42000

Nominal diameter [in]	(v ~ 2.5 m/s) [Mgal/d]
54	75
60	95
66	120
72	140
78	175
84	190
90	220
96	265
102	300
108	340
114	375
120	415

4.2.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1	0.25
1½	0.75
2	1.25
3	2.5
4	4
6	12
8	15
10	30
12	45
14	60

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
15	60
16	60
18	90
20	120
24	180
28	210
30	270
32	300
36	360
40	480
42	600
48	600

Nominal diameter [in]	(v ~ 0.04 m/s) [Mgal/d]
54	1.3
60	1.3
66	2.2
72	2.6
78	3.0
84	3.2
90	3.6
96	4.0
102	5.0
108	5.0
114	6.0
120	7.0

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano-, Micro-, Milli-, Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro-, Milli-, Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot

Process variable	Units	Explanation
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9	
0% bargraph value 1 (Parameter)	18
0% bargraph value 3 (Parameter)	21
2.4 GHz WLAN channel (Parameter)	99
100% bargraph value 1 (Parameter)	19
100% bargraph value 3 (Parameter)	22
A	
Access status (Parameter)	13
Access status display (Parameter)	13, 26
Activate SW option (Parameter)	38
Actual diagnostics (Parameter)	159
Address mode (Parameter)	78
Address shifting configuration (Submenu)	91
Administration (Submenu)	34
Alarm delay (Parameter)	27
Alarm hysteresis (Parameter)	109, 154
Alarm summary (Parameter)	85, 106, 119, 127, 140, 152
Alert key (Parameter)	84, 105, 118, 126, 138, 151
Analog input 1 to n (Submenu)	101
Analog inputs (Submenu)	101
Analog output 1 to n (Submenu)	122
Analog outputs (Submenu)	122
Application (Submenu)	144
Assign behavior of diagnostic no. 043 (Parameter)	29
Assign behavior of diagnostic no. 302 (Parameter)	30
Assign behavior of diagnostic no. 376 (Parameter)	30
Assign behavior of diagnostic no. 377 (Parameter)	30
Assign behavior of diagnostic no. 531 (Parameter)	31
Assign behavior of diagnostic no. 832 (Parameter)	31
Assign behavior of diagnostic no. 833 (Parameter)	31
Assign behavior of diagnostic no. 834 (Parameter)	32
Assign behavior of diagnostic no. 835 (Parameter)	32
Assign behavior of diagnostic no. 842 (Parameter)	32
Assign behavior of diagnostic no. 937 (Parameter)	33
Assign behavior of diagnostic no. 938 (Parameter)	33
Assign behavior of diagnostic no. 961 (Parameter)	34
Assign behavior of diagnostic no. 962 (Parameter)	33
Assign channel 1 (Parameter)	177
Assign channel 2 (Parameter)	178
Assign channel 3 (Parameter)	178
Assign channel 4 (Parameter)	178
Assign process variable (Parameter)	57, 60, 145
Assign simulation process variable (Parameter)	185
Assign SSID name (Parameter)	99
B	
Backlight (Parameter)	26
Batch ID (Parameter)	107, 120, 128, 140, 153
Batch operation (Parameter)	107, 120, 128, 140, 153
Batch phase (Parameter)	107, 120, 128, 141, 153
Batch Recipe Unit Procedure (Parameter)	107, 121, 128, 141, 154
Baudrate (Parameter)	81
Bootloader revision (Parameter)	173, 174
Build no. software (Parameter)	173, 174
Build-up detection (Submenu)	64
Bus termination (Parameter)	79
C	
Calibration (Submenu)	76
Calibration factor (Parameter)	77
Channel (Parameter)	102, 115
Clear logging data (Parameter)	179
Communication (Submenu)	78
Condensed status diagnostic (Parameter)	91
Conductivity (Parameter)	41
Conductivity calibration factor (Parameter)	77
Conductivity damping (Parameter)	55
Conductivity factor (Parameter)	73
Conductivity measurement (Parameter)	55
Conductivity offset (Parameter)	73
Conductivity temperature coefficient (Parameter)	56
Conductivity unit (Parameter)	46
Confirm access code (Parameter)	35
Connection state (Parameter)	100
Contrast display (Parameter)	26
Control Totalizer 1 to n (Parameter)	147
Corrected conductivity (Parameter)	42
Corrected conductivity factor (Parameter)	75
Corrected conductivity offset (Parameter)	75
Corrected volume flow (Parameter)	41
Corrected volume flow factor (Parameter)	74
Corrected volume flow offset (Parameter)	73
Corrected volume flow unit (Parameter)	49
Corrected volume unit (Parameter)	50
D	
Data logging (Parameter)	180
Data logging (Submenu)	176
Data logging control (Parameter)	180
Data logging status (Parameter)	181
Date/time format (Parameter)	51
Decimal places 1 (Parameter)	19
Decimal places 2 (Parameter)	20
Decimal places 3 (Parameter)	22
Decimal places 4 (Parameter)	23
Default gateway (Parameter)	94
Define access code (Parameter)	35, 37
Define access code (Wizard)	34
Density (Parameter)	42
Density source (Parameter)	67
Density unit (Parameter)	48
Descriptor (Parameter)	89
Device address (Parameter)	79
Device alarm simulation (Parameter)	186
Device certification (Parameter)	88
Device ID (Parameter)	86
Device information (Submenu)	168
Device install date (Parameter)	89
Device message (Parameter)	89

Device name (Parameter)	169	Assign behavior of diagnostic no. 962 (0745)	33
Device reset (Parameter)	37	Assign channel 1 (0851)	177
Device tag (Parameter)	83, 168	Assign channel 2 (0852)	178
DHCP client (Parameter)	93	Assign channel 3 (0853)	178
Diagnostic behavior (Submenu)	28	Assign channel 4 (0854)	178
Diagnostic event category (Parameter)	186	Assign process variable	
Diagnostic event simulation (Parameter)	186	Totalizer 1 to n (3808-1 to n)	145
Diagnostic handling (Submenu)	27	Assign process variable (1837)	57
Diagnostic list (Submenu)	161	Assign process variable (1860)	60
Diagnostics (Parameter)	87	Assign simulation process variable (1810)	185
Diagnostics (Submenu)	158	Assign SSID name (2708)	99
Diagnostics 1 (Parameter)	162	Backlight (0111)	26
Diagnostics 2 (Parameter)	162	Batch ID	
Diagnostics 3 (Parameter)	163	Analog input 1 to n (1533-1 to n)	107
Diagnostics 4 (Parameter)	164	Analog output 1 to n (1633-1 to n)	128
Diagnostics 5 (Parameter)	165	Discrete input 1 to n (2183-1 to n)	120
Diagnostics mask (Parameter)	87	Discrete output 1 to n (1695-1 to n)	140
Direct access		Totalizer 1 to n (3804-1 to n)	153
0% bargraph value 1 (0123)	18	Batch operation	
0% bargraph value 3 (0124)	21	Analog input 1 to n (1534-1 to n)	107
2.4 GHz WLAN channel (2704)	99	Analog output 1 to n (1639-1 to n)	128
100% bargraph value 1 (0125)	19	Discrete input 1 to n (2184-1 to n)	120
100% bargraph value 3 (0126)	22	Discrete output 1 to n (1698-1 to n)	140
Access status (0005)	13	Totalizer 1 to n (3805-1 to n)	153
Access status display (0091)	13, 26	Batch phase	
Activate SW option (0029)	38	Analog input 1 to n (1535-1 to n)	107
Actual diagnostics (0691)	159	Analog output 1 to n (1640-1 to n)	128
Address mode (1468)	78	Discrete input 1 to n (2185-1 to n)	120
Alarm delay (0651)	27	Discrete output 1 to n (1699-1 to n)	141
Alarm hysteresis		Totalizer 1 to n (3806-1 to n)	153
Analog input 1 to n (1527-1 to n)	109	Batch Recipe Unit Procedure	
Totalizer 1 to n (3802-1 to n)	154	Analog input 1 to n (1536-1 to n)	107
Alarm summary		Analog output 1 to n (1641-1 to n)	128
Analog input 1 to n (1537-1 to n)	106	Discrete input 1 to n (2186-1 to n)	121
Analog output 1 to n (1642-1 to n)	127	Discrete output 1 to n (1700-1 to n)	141
Discrete input 1 to n (2191-1 to n)	119	Totalizer 1 to n (3807-1 to n)	154
Discrete output 1 to n (1701-1 to n)	140	Baudrate (1504)	81
Totalizer 1 to n (3809-1 to n)	152	Bootloader revision (0073)	173, 174
Alarm summary (1474)	85	Build no. software (0079)	173, 174
Alert key		Bus termination (1431)	79
Analog input 1 to n (1522-1 to n)	105	Calibration factor (6522)	77
Analog output 1 to n (1632-1 to n)	126	Channel	
Discrete input 1 to n (2182-1 to n)	118	Analog input 1 to n (1561-1 to n)	102
Discrete output 1 to n (1694-1 to n)	138	Discrete input 1 to n (2187-1 to n)	115
Totalizer 1 to n (3803-1 to n)	151	Clear logging data (0855)	179
Alert key (1473)	84	Condensed status diagnostic (1500)	91
Assign behavior of diagnostic no. 043 (0650)	29	Conductivity (1850)	41
Assign behavior of diagnostic no. 302 (0739)	30	Conductivity calibration factor (6718)	77
Assign behavior of diagnostic no. 376 (0645)	30	Conductivity damping (1803)	55
Assign behavior of diagnostic no. 377 (0777)	30	Conductivity factor (1849)	73
Assign behavior of diagnostic no. 531 (0741)	31	Conductivity measurement (6514)	55
Assign behavior of diagnostic no. 832 (0681)	31	Conductivity offset (1848)	73
Assign behavior of diagnostic no. 833 (0682)	31	Conductivity temperature coefficient (1891)	56
Assign behavior of diagnostic no. 834 (0700)	32	Conductivity unit (0582)	46
Assign behavior of diagnostic no. 835 (0702)	32	Connection state (2722)	100
Assign behavior of diagnostic no. 842 (0638)	32	Contrast display (0105)	26
Assign behavior of diagnostic no. 937 (0743)	33	Control Totalizer 1 to n (3830-1 to n)	147
Assign behavior of diagnostic no. 938 (0642)	33	Corrected conductivity (1853)	42
Assign behavior of diagnostic no. 961 (0736)	34	Corrected conductivity factor (1871)	75

Corrected conductivity offset (1870)	75
Corrected volume flow (1851)	41
Corrected volume flow factor (1867)	74
Corrected volume flow offset (1866)	73
Corrected volume flow unit (0558)	49
Corrected volume unit (0575)	50
Data logging (0860)	180
Data logging control (0857)	180
Data logging status (0858)	181
Date/time format (2812)	51
Decimal places 1 (0095)	19
Decimal places 2 (0117)	20
Decimal places 3 (0118)	22
Decimal places 4 (0119)	23
Default gateway (7210)	94
Define access code	37
Density (1857)	42
Density source (6615)	67
Density unit (0555)	48
Descriptor (1489)	89
Device address (1462)	79
Device alarm simulation (0654)	186
Device certification (1486)	88
Device ID (1480)	86
Device install date (1491)	89
Device message (1490)	89
Device name (0013)	169
Device reset (0000)	37
Device tag (0011)	168
Device tag (1496)	83
DHCP client (7212)	93
Diagnostic event category (0738)	186
Diagnostic event simulation (0737)	186
Diagnostics (1482)	87
Diagnostics 1 (0692)	162
Diagnostics 2 (0693)	162
Diagnostics 3 (0694)	163
Diagnostics 4 (0695)	164
Diagnostics 5 (0696)	165
Diagnostics mask (1484)	87
Direct access (0106)	11
Display damping (0094)	24
Display interval (0096)	23
Display language (0104)	15
ECC cleaning cycle (6557)	64
ECC duration (6555)	63
ECC polarity (6631)	64
ECC recovery time (6556)	63
Electrode cleaning circuit (6528)	63
Empty pipe adjust value (6527)	61
ENP version (0012)	171
Enter access code (0003)	14
Entire logging duration (0861)	181
Extended order code 1 (0023)	170
Extended order code 2 (0021)	170
Extended order code 3 (0022)	170
External density (6630)	67
External temperature (6673)	68
Factory reset (1488)	88

Fail-safe time	
Analog output 1 to n (1635–1 to n)	123
Discrete output 1 to n (1697–1 to n)	135
Fail-safe type	
Analog input 1 to n (1525–1 to n)	103
Analog output 1 to n (1636–1 to n)	124
Discrete input 1 to n (2189–1 to n)	116
Discrete output 1 to n (1696–1 to n)	136
Fail-safe value	
Analog input 1 to n (1526–1 to n)	103
Analog output 1 to n (1637–1 to n)	124
Discrete input 1 to n (2190–1 to n)	116
Discrete output 1 to n (1693–1 to n)	136
Failure mode	
Totalizer 1 to n (3810–1 to n)	149
Feature enabled (1476)	90
Feature supported (1477)	90
Filter options (0705)	166
Filter options (6710)	52
Firmware version (0010)	169
Fixed density (6623)	68
Flow damping (6661)	54
Flow override (1839)	54
Flow velocity (1854)	41
Flow velocity factor (1880)	76
Flow velocity offset (1879)	75
Format display (0098)	16
Full pipe adjust value (6548)	62
Gateway IP address (2719)	101
Hardware lock (1499)	90
Hardware revision (1479)	86
Header (0097)	24
Header text (0112)	25
Hi alarm state	
Analog input 1 to n (1538–1 to n)	112
Totalizer 1 to n (3811–1 to n)	157
Hi alarm value	
Analog input 1 to n (1539–1 to n)	112
Totalizer 1 to n (3812–1 to n)	157
Hi Hi alarm state	
Analog input 1 to n (1540–1 to n)	112
Totalizer 1 to n (3813–1 to n)	157
Hi Hi alarm value	
Analog input 1 to n (1541–1 to n)	111
Totalizer 1 to n (3814–1 to n)	156
Hi Lim	
Analog input 1 to n (1528–1 to n)	110
Totalizer 1 to n (3815–1 to n)	154
Hi Lim	
Analog input 1 to n (1529–1 to n)	110
Totalizer 1 to n (3816–1 to n)	155
Ident number selector (1461)	79, 89
Increase close	
Analog output 1 to n (1638–1 to n)	133
Input channel	
Analog output 1 to n (1670–1 to n)	130
Discrete output 1 to n (1724–1 to n)	142
Installation direction (1809)	70
Integration time (6533)	70

Invert	
Discrete input 1 to n (2188-1 to n)	116
Discrete output 1 to n (1692-1 to n)	135
IP address (7209)	93
IP address domain name server (2720)	101
Lin type	
Analog input 1 to n (1523-1 to n)	109
Lo alarm state	
Analog input 1 to n (1542-1 to n)	113
Totalizer 1 to n (3817-1 to n)	158
Lo alarm value	
Analog input 1 to n (1543-1 to n)	112
Totalizer 1 to n (3818-1 to n)	157
Lo Lim	
Analog input 1 to n (1530-1 to n)	111
Totalizer 1 to n (3819-1 to n)	155
Lo Lo alarm state	
Analog input 1 to n (1544-1 to n)	113
Totalizer 1 to n (3820-1 to n)	158
Lo Lo alarm value	
Analog input 1 to n (1545-1 to n)	113
Totalizer 1 to n (3821-1 to n)	158
Lo Lo Lim	
Analog input 1 to n (1531-1 to n)	111
Totalizer 1 to n (3822-1 to n)	156
Locking status (0004)	12
Logging delay (0859)	180
Logging interval (0856)	179
Login page (7273)	94
MAC address (7214)	92
Manufacturer ID (1502)	86
Mass flow (1847)	41
Mass flow factor (1846)	72
Mass flow offset (1841)	72
Mass flow unit (0554)	47
Mass unit (0574)	48
Master availability (1517)	81
Maximum value (6545)	175
Maximum value (6680)	176
Measured value EPD (6559)	62
Measuring period (6536)	70
Minimum value (6547)	175
Minimum value (6681)	175
Mode block actual	
Analog input 1 to n (1521-1 to n)	105
Analog output 1 to n (1631-1 to n)	126
Discrete input 1 to n (2181-1 to n)	119
Discrete output 1 to n (1691-1 to n)	139
Totalizer 1 to n (3801-1 to n)	152
Mode block actual (1472)	84
Mode block normal	
Analog input 1 to n (1546-1 to n)	106
Analog output 1 to n (1643-1 to n)	127
Discrete input 1 to n (2192-1 to n)	119
Discrete output 1 to n (1702-1 to n)	139
Totalizer 1 to n (3824-1 to n)	152
Mode block normal (1492)	85
Mode block permitted	
Analog input 1 to n (1553-1 to n)	106
Analog output 1 to n (1648-1 to n)	127
Discrete input 1 to n (2195-1 to n)	119
Discrete output 1 to n (1705-1 to n)	139
Totalizer 1 to n (3828-1 to n)	152
Mode block permitted (1493)	84
Network security (2705)	96
New adjustment (6560)	61
Nominal diameter (2807)	76
Off value low flow cutoff (1804)	58
On value low flow cutoff (1805)	57
Operating time (0652)	36, 161
Operating time from restart (0653)	161
Order code (0008)	169
Out decimal point	
Analog input 1 to n (1547-1 to n)	109
Out scale lower range	
Analog input 1 to n (1548-1 to n)	108
Analog output 1 to n (1644-1 to n)	134
Out scale upper range	
Analog input 1 to n (1551-1 to n)	108
Analog output 1 to n (1646-1 to n)	133
Out status	
Analog input 1 to n (1549-1 to n)	104
Analog input 1 to n (1564-1 to n)	104
Analog output 1 to n (1645-1 to n)	125
Analog output 1 to n (1669-1 to n)	125
Discrete input 1 to n (2193-1 to n)	117
Discrete input 1 to n (2203-1 to n)	117
Discrete output 1 to n (1703-1 to n)	137
Discrete output 1 to n (1723-1 to n)	137
Out unit	
Analog input 1 to n (1550-1 to n)	109
Out unit text	
Analog input 1 to n (1532-1 to n)	114
Out value	
Analog input 1 to n (1552-1 to n)	103
Analog output 1 to n (1647-1 to n)	124
Discrete input 1 to n (2194-1 to n)	117
Discrete output 1 to n (1704-1 to n)	137
Out value 1 to n (3827-1 to n)	43, 149
Output channel	
Analog output 1 to n (1671-1 to n)	131
Discrete output 1 to n (1725-1 to n)	142
Position status	
Analog output 1 to n (1649-1 to n)	132
Position value	
Analog output 1 to n (1650-1 to n)	131
Preset value 1 to n (3829-1 to n)	148
Pressure shock suppression (1806)	58
Previous diagnostics (0690)	160
Process variable value (1811)	185
PROFIBUS ident number (1464)	80
Profile version (1463)	81
Progress (6571)	61
PV filter time	
Analog input 1 to n (1524-1 to n)	102
PV scale lower range	
Analog input 1 to n (1554-1 to n)	108
Analog output 1 to n (1651-1 to n)	129

PV scale upper range	96
Analog input 1 to n (1555-1 to n)	108
Analog output 1 to n (1652-1 to n)	129
RCAS in status	
Analog output 1 to n (1654-1 to n)	130
Discrete output 1 to n (1706-1 to n)	142
RCAS in value	
Analog output 1 to n (1655-1 to n)	130
Discrete output 1 to n (1707-1 to n)	142
RCAS out status	
Analog output 1 to n (1656-1 to n)	131
Discrete output 1 to n (1708-1 to n)	143
RCAS out value	
Analog output 1 to n (1657-1 to n)	131
Discrete output 1 to n (1711-1 to n)	143
Readback status	
Analog output 1 to n (1658-1 to n)	130
Discrete output 1 to n (1712-1 to n)	141
Readback value	
Analog output 1 to n (1659-1 to n)	129
Discrete output 1 to n (1713-1 to n)	141
Received signal strength (2721)	100
Reference density (1885)	56
Reference temperature (1816)	69
Reset access code (0024)	36
Reset all totalizers (2806)	144
Response time empty pipe detection (1859)	60
Security identification (2718)	97
Select antenna (2713)	100
Separator (0101)	26
Serial number (0009)	169
Serial number (1481)	87
Set point status	
Analog output 1 to n (1660-1 to n)	123
Discrete output 1 to n (1714-1 to n)	135
Set point value	
Analog output 1 to n (1661-1 to n)	123
Discrete output 1 to n (1715-1 to n)	135
Setpoint deviation	
Analog output 1 to n (1653-1 to n)	132
Simulate enabled	
Analog input 1 to n (1556-1 to n)	113
Analog output 1 to n (1662-1 to n)	132
Discrete input 1 to n (2196-1 to n)	121
Discrete output 1 to n (1716-1 to n)	143
Simulate status	
Analog input 1 to n (1557-1 to n)	114
Analog output 1 to n (1663-1 to n)	133
Discrete input 1 to n (2197-1 to n)	122
Discrete output 1 to n (1717-1 to n)	144
Simulate value	
Analog input 1 to n (1558-1 to n)	114
Analog output 1 to n (1664-1 to n)	132
Discrete input 1 to n (2198-1 to n)	121
Discrete output 1 to n (1718-1 to n)	143
Software option overview (0015)	39
Software revision (0072)	172, 173
Software revision (1478)	86
SSID name (2707)	99
SSID name (2714)	96
Static revision	
Analog input 1 to n (1560-1 to n)	104
Analog output 1 to n (1666-1 to n)	125
Discrete input 1 to n (2200-1 to n)	118
Discrete output 1 to n (1720-1 to n)	138
Totalizer 1 to n (3832-1 to n)	151
Static revision (1495)	83
Status PROFIBUS Master Config (1465)	80
Strategy	
Analog input 1 to n (1559-1 to n)	105
Analog output 1 to n (1665-1 to n)	126
Discrete input 1 to n (2199-1 to n)	118
Discrete output 1 to n (1719-1 to n)	138
Totalizer 1 to n (3831-1 to n)	151
Strategy (1494)	83
Subnet mask (7211)	93
Switch point empty pipe detection (6562)	60
Tag description	
Analog input 1 to n (1562-1 to n)	104
Analog output 1 to n (1667-1 to n)	125
Discrete input 1 to n (2201-1 to n)	117
Discrete output 1 to n (1721-1 to n)	137
Totalizer 1 to n (3833-1 to n)	150
Target mode	
Analog input 1 to n (1563-1 to n)	105
Analog output 1 to n (1668-1 to n)	126
Discrete input 1 to n (2202-1 to n)	118
Discrete output 1 to n (1722-1 to n)	138
Totalizer 1 to n (3834-1 to n)	151
Target mode (1497)	84
Temperature (1852)	42
Temperature damping (1886)	56
Temperature factor (1869)	74
Temperature offset (1868)	74
Temperature source (6712)	68
Temperature unit (0557)	47
Timestamp	160, 162, 163, 164, 165
Totalizer operation mode	
Totalizer 1 to n (3823-1 to n)	148
Totalizer status (Hex) 1 to n (3825-1 to n)	43, 150
Totalizer status 1 to n (3826-1 to n)	44, 150
Unit totalizer	
Totalizer 1 to n (3835-1 to n)	146
User name (2715)	97
Value 1 display (0107)	18
Value 2 display (0108)	20
Value 3 display (0110)	21
Value 4 display (0109)	22
Volume flow (1838)	40
Volume flow factor (1832)	71
Volume flow offset (1831)	72
Volume flow unit (0553)	44
Volume unit (0563)	46
Web server functionality (7222)	94
Web server language (7221)	92
WLAN (2702)	96
WLAN IP address (2711)	98
WLAN MAC address (2703)	98

WLAN mode (2717)	96	Failure mode (Parameter)	149
WLAN passphrase (2706)	98	Feature enabled (Parameter)	90
WLAN password (2716)	97	Feature supported (Parameter)	90
WLAN subnet mask (2709)	98	Filter options (Parameter)	52, 166
Zero point (6546)	77	Firmware version (Parameter)	169
Direct access (Parameter)	11	Fixed density (Parameter)	68
Discrete input 1 to n (Submenu)	115	Flow damping (Parameter)	54
Discrete inputs (Submenu)	115	Flow override (Parameter)	54
Discrete output 1 to n (Submenu)	134	Flow velocity (Parameter)	41
Discrete outputs (Submenu)	134	Flow velocity factor (Parameter)	76
Display (Submenu)	14	Flow velocity offset (Parameter)	75
Display channel 1 (Submenu)	182	Format display (Parameter)	16
Display channel 2 (Submenu)	183	Full pipe adjust value (Parameter)	62
Display channel 3 (Submenu)	183	Function see Parameter	
Display channel 4 (Submenu)	184		
Display damping (Parameter)	24	G	
Display interval (Parameter)	23	Gateway IP address (Parameter)	101
Display language (Parameter)	15		
Display module (Submenu)	173	H	
Document		Hardware lock (Parameter)	90
Explanation of the structure of a parameter		Hardware revision (Parameter)	86
description	6	Header (Parameter)	24
Function	4	Header text (Parameter)	25
Structure	4	Heartbeat Technology (Submenu)	184
Symbols used	6	Hi alarm state (Parameter)	112, 157
Target group	4	Hi alarm value (Parameter)	112, 157
Using the document	4	Hi Hi alarm state (Parameter)	112, 157
Document function	4	Hi Hi alarm value (Parameter)	111, 156
E		Hi Lim (Parameter)	110, 154
ECC cleaning cycle (Parameter)	64	Hi Lim (Parameter)	110, 155
ECC duration (Parameter)	63		
ECC polarity (Parameter)	64	I	
ECC recovery time (Parameter)	63	Ident number selector (Parameter)	79, 89
Electrode cleaning circuit (Parameter)	63	Increase close (Parameter)	133
Electrode cleaning circuit (Submenu)	62	Input channel (Parameter)	130, 142
Empty pipe adjust value (Parameter)	61	Installation direction (Parameter)	70
Empty pipe detection (Submenu)	59	Integration time (Parameter)	70
ENP version (Parameter)	171	Invert (Parameter)	116, 135
Enter access code (Parameter)	14	IP address (Parameter)	93
Entire logging duration (Parameter)	181	IP address domain name server (Parameter)	101
Event list (Submenu)	166		
Event logbook (Submenu)	166	L	
Expert (Menu)	11	Lin type (Parameter)	109
Extended order code 1 (Parameter)	170	Lo alarm state (Parameter)	113, 158
Extended order code 2 (Parameter)	170	Lo alarm value (Parameter)	112, 157
Extended order code 3 (Parameter)	170	Lo Lim (Parameter)	111, 155
External compensation (Submenu)	67	Lo Lo alarm state (Parameter)	113, 158
External density (Parameter)	67	Lo Lo alarm value (Parameter)	113, 158
External temperature (Parameter)	68	Lo Lo Lim (Parameter)	111, 156
F		Locking status (Parameter)	12
Factory reset (Parameter)	88	Logging delay (Parameter)	180
Factory settings	187	Logging interval (Parameter)	179
SI units	187	Login page (Parameter)	94
US units	189	Low flow cut off (Submenu)	57
Fail-safe time (Parameter)	123, 135		
Fail-safe type (Parameter)	103, 116, 124, 136	M	
Fail-safe value (Parameter)	103, 116, 124, 136	MAC address (Parameter)	92

Manufacturer ID (Parameter)	86
Mass flow (Parameter)	41
Mass flow factor (Parameter)	72
Mass flow offset (Parameter)	72
Mass flow unit (Parameter)	47
Mass unit (Parameter)	48
Master availability (Parameter)	81
Maximum value (Parameter)	175, 176
Measured value EPD (Parameter)	62
Measured values (Submenu)	40
Measuring period (Parameter)	70
Medium temperature (Submenu)	175
Menu	
Expert	11
Min/max values (Submenu)	174
Minimum value (Parameter)	175
Mode block actual (Parameter)	84, 105, 119, 126, 139, 152
Mode block normal (Parameter)	85, 106, 119, 127, 139, 152
Mode block permitted (Parameter)	84, 106, 119, 127, 139, 152

N

Network security (Parameter)	96
New adjustment (Parameter)	61
Nominal diameter (Parameter)	76

O

Off value low flow cutoff (Parameter)	58
On value low flow cutoff (Parameter)	57
Operating time (Parameter)	36, 161
Operating time from restart (Parameter)	161
Order code (Parameter)	169
Out decimal point (Parameter)	109
Out scale lower range (Parameter)	108, 134
Out scale upper range (Parameter)	108, 133
Out status (Parameter)	104, 117, 125, 137
Out unit (Parameter)	109
Out unit text (Parameter)	114
Out value (Parameter)	103, 117, 124, 137
Out value 1 to n (Parameter)	43, 149
Output channel (Parameter)	131, 142

P

Parameter	
Structure of a parameter description	6
Physical block (Submenu)	82
Position status (Parameter)	132
Position value (Parameter)	131
Preset value 1 to n (Parameter)	148
Pressure shock suppression (Parameter)	58
Previous diagnostics (Parameter)	160
Process parameters (Submenu)	51
Process variable adjustment (Submenu)	70
Process variable value (Parameter)	185
Process variables (Submenu)	40
PROFIBUS DP configuration (Submenu)	78
PROFIBUS DP info (Submenu)	80

PROFIBUS ident number (Parameter)	80
Profile version (Parameter)	81
Progress (Parameter)	61
PV filter time (Parameter)	102
PV scale lower range (Parameter)	108, 129
PV scale upper range (Parameter)	108, 129

R

RCAS in status (Parameter)	130, 142
RCAS in value (Parameter)	130, 142
RCAS out status (Parameter)	131, 143
RCAS out value (Parameter)	131, 143
Readback status (Parameter)	130, 141
Readback value (Parameter)	129, 141
Received signal strength (Parameter)	100
Reference density (Parameter)	56
Reference temperature (Parameter)	69
Reset access code (Parameter)	36
Reset access code (Submenu)	35
Reset all totalizers (Parameter)	144
Response time empty pipe detection (Parameter)	60

S

Security identification (Parameter)	97
Select antenna (Parameter)	100
Sensor (Submenu)	39
Sensor adjustment (Submenu)	69
Sensor electronic module (ISEM) (Submenu)	172
Separator (Parameter)	26
Serial number (Parameter)	87, 169
Set point status (Parameter)	123, 135
Set point value (Parameter)	123, 135
Setpoint deviation (Parameter)	132
Simulate enabled (Parameter)	113, 121, 132, 143
Simulate status (Parameter)	114, 122, 133, 144
Simulate value (Parameter)	114, 121, 132, 143
Simulation (Submenu)	184
Software option overview (Parameter)	39
Software revision (Parameter)	86, 172, 173
SSID name (Parameter)	96, 99
Static revision (Parameter)	83, 104, 118, 125, 138, 151
Status PROFIBUS Master Config (Parameter)	80
Strategy (Parameter)	83, 105, 118, 126, 138, 151

Submenu

Address shifting configuration	91
Administration	34
Analog input 1 to n	101
Analog inputs	101
Analog output 1 to n	122
Analog outputs	122
Application	144
Build-up detection	64
Calibration	76
Communication	78
Data logging	176
Device information	168
Diagnostic behavior	28
Diagnostic handling	27
Diagnostic list	161

Diagnostics	158	Totalizer status 1 to n (Parameter)	44, 150
Discrete input 1 to n	115		
Discrete inputs	115		
Discrete output 1 to n	134		
Discrete outputs	134		
Display	14		
Display channel 1	182		
Display channel 2	183		
Display channel 3	183		
Display channel 4	184		
Display module	173		
Electrode cleaning circuit	62		
Empty pipe detection	59		
Event list	166		
Event logbook	166		
External compensation	67		
Heartbeat Technology	184		
Low flow cut off	57		
Main electronics temperature	174		
Mainboard module	171		
Measured values	40		
Medium temperature	175		
Min/max values	174		
Physical block	82		
Process parameters	51		
Process variable adjustment	70		
Process variables	40		
PROFIBUS DP configuration	78		
PROFIBUS DP info	80		
Reset access code	35		
Sensor	39		
Sensor adjustment	69		
Sensor electronic module (ISEM)	172		
Simulation	184		
System	14		
System units	44		
Totalizer	43		
Totalizer 1 to n	145		
Web server	91		
Subnet mask (Parameter)	93		
Switch point empty pipe detection (Parameter)	60		
System (Submenu)	14		
System units (Submenu)	44		
T			
Tag description (Parameter)	104, 117, 125, 137, 150		
Target group	4		
Target mode (Parameter)	84, 105, 118, 126, 138, 151		
Temperature (Parameter)	42		
Temperature damping (Parameter)	56		
Temperature factor (Parameter)	74		
Temperature offset (Parameter)	74		
Temperature source (Parameter)	68		
Temperature unit (Parameter)	47		
Timestamp (Parameter)	160, 162, 163, 164, 165		
Totalizer (Submenu)	43		
Totalizer 1 to n (Submenu)	145		
Totalizer operation mode (Parameter)	148		
Totalizer status (Hex) 1 to n (Parameter)	43, 150		
U			
Unit totalizer (Parameter)	146		
User name (Parameter)	97		
V			
Value 1 display (Parameter)	18		
Value 2 display (Parameter)	20		
Value 3 display (Parameter)	21		
Value 4 display (Parameter)	22		
Volume flow (Parameter)	40		
Volume flow factor (Parameter)	71		
Volume flow offset (Parameter)	72		
Volume flow unit (Parameter)	44		
Volume unit (Parameter)	46		
W			
Web server (Submenu)	91		
Web server functionality (Parameter)	94		
Web server language (Parameter)	92		
Wizard			
Define access code	34		
WLAN settings	95		
WLAN (Parameter)	96		
WLAN IP address (Parameter)	98		
WLAN MAC address (Parameter)	98		
WLAN mode (Parameter)	96		
WLAN passphrase (Parameter)	98		
WLAN password (Parameter)	97		
WLAN settings (Wizard)	95		
WLAN subnet mask (Parameter)	98		
Z			
Zero point (Parameter)	77		



71535815

www.addresses.endress.com
