

Description of Device Parameters

Proline Promag 400

EtherNet/IP

Electromagnetic flowmeter




Table of contents

1 About this document	4	4 Country-specific factory settings ..	138
1.1 Document function	4	4.1 SI units	138
1.2 Target group	4	4.1.1 System units	138
1.3 Using this document	4	4.1.2 Full scale values	138
1.3.1 Information on the document structure	4	4.1.3 Switch-on point low flow cut off	139
1.3.2 Structure of a parameter description ..	6	4.2 US units	140
1.4 Symbols used	6	4.2.1 System units	140
1.4.1 Symbols for certain types of information	6	4.2.2 Full scale values	140
1.4.2 Symbols in graphics	7	4.2.3 Switch-on point low flow cut off	141
1.5 Documentation	7	5 Explanation of abbreviated units ..	143
1.5.1 Standard documentation	7	5.1 SI units	143
1.5.2 Supplementary device-dependent documentation	7	5.2 US units	143
2 Overview of the Expert operating menu	8	5.3 Imperial units	144
3 Description of the device parameters	10	Index	145
3.1 "System" submenu	13		
3.1.1 "Display" submenu	13		
3.1.2 "Diagnostic handling" submenu	26		
3.1.3 "Administration" submenu	33		
3.2 "Sensor" submenu	38		
3.2.1 "Measured values" submenu	39		
3.2.2 "System units" submenu	43		
3.2.3 "Process parameters" submenu	51		
3.2.4 "External compensation" submenu	67		
3.2.5 "Sensor adjustment" submenu	69		
3.2.6 "Calibration" submenu	76		
3.3 "Communication" submenu	78		
3.3.1 "Configuration" submenu	78		
3.3.2 "WLAN settings" wizard	97		
3.4 "Application" submenu	104		
3.4.1 "Totalizer 1 to n" submenu	105		
3.5 "Diagnostics" submenu	109		
3.5.1 "Diagnostic list" submenu	112		
3.5.2 "Event logbook" submenu	116		
3.5.3 "Device information" submenu	118		
3.5.4 "Main electronic module + I/O module 1" submenu	122		
3.5.5 "Sensor electronic module (ISEM)" submenu	123		
3.5.6 "Display module" submenu	124		
3.5.7 "Data logging" submenu	125		
3.5.8 "Min/max values" submenu	133		
3.5.9 "Heartbeat" submenu	135		
3.5.10 "Simulation" submenu	135		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



Navigation path to the parameter via the local display (direct access code) or web browser
 Navigation path to the parameter via the operating tool
 The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Promag D 400	BA01212D
Promag L 400	BA01213D
Promag W 400	BA01214D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Content	Documentation code
Heartbeat Verification + Monitoring application package	SD02570D
Display modules A309/A310	SD01793D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

⚡ Expert	
Direct access (0106)	→ ↗ 10
Locking status (0004)	→ ↗ 11
User role (0005)	→ ↗ 12
Enter access code (0003)	→ ↗ 12
▶ System	→ ↗ 13
▶ Display	→ ↗ 13
▶ Diagnostic handling	→ ↗ 26
▶ Administration	→ ↗ 33
▶ Sensor	→ ↗ 38
▶ Measured values	→ ↗ 39
▶ System units	→ ↗ 43
▶ Process parameters	→ ↗ 51
▶ External compensation	→ ↗ 67
▶ Sensor adjustment	→ ↗ 69
▶ Calibration	→ ↗ 76
▶ Communication	→ ↗ 78
▶ Configuration	→ ↗ 78
▶ WLAN settings	→ ↗ 97

▶ Application	→ 104
Reset all totalizers (2806)	→ 104
▶ Totalizer 1 to n	→ 105
▶ Diagnostics	→ 109
Actual diagnostics (0691)	→ 110
Previous diagnostics (0690)	→ 110
Operating time from restart (0653)	→ 111
Operating time (0652)	→ 111
▶ Diagnostic list	→ 112
▶ Event logbook	→ 116
▶ Device information	→ 118
▶ Main electronic module	→ 122
▶ Sensor electronic module (ISEM)	→ 123
▶ Display module	→ 124
▶ Data logging	→ 125
▶ Min/max values	→ 133
▶ Heartbeat Technology	→ 135
▶ Simulation	→ 135

3 Description of the device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
User role (0005)	→ 12
Enter access code (0003)	→ 12
▶ System	→ 13
▶ Sensor	→ 38
▶ Communication	→ 78
▶ Application	→ 104
▶ Diagnostics	→ 109

Direct access



Navigation

Expert → Direct access (0106)

Description

Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.


User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



A0029414

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter **"914"** instead of **"00914"**
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter **00914** → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter **00914-2** → **Assign process variable** parameter

Locking status

Navigation  Expert → Locking status (0004)

Description Displays the active write protection.

User interface

- Hardware locked
- Temporarily locked

Additional information *User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7

Selection

Options	Description
None	The access status displayed in the Access status display parameter (→  11) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked (priority 2)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status display

Navigation  Expert → Access stat.disp (0091)

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.

User interface

- Operator
- Maintenance

Factory setting	Operator
Additional information	<i>Description</i>
<p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p>	
<p> Access authorization can be modified via the Enter access code parameter →  12).</p>	
<p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p>	
<p> If additional write protection is active, this restricts the current access authorization even further.</p>	
<p><i>User interface</i></p>	
<p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>	

User role

Navigation	  Expert → User role (0005)
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance
Additional information	<i>Description</i>
<p> Access authorization can be modified via the Enter access code parameter →  12).</p>	
<p> If additional write protection is active, this restricts the current access authorization even further.</p>	
<p><i>User interface</i></p>	
<p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>	

Enter access code

Navigation	  Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection.

User entry

Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation Expert → System

▶ System	
▶ Display	→  13
▶ Diagnostic handling	→  26
▶ Administration	→  33

3.1.1 "Display" submenu

Navigation Expert → System → Display

▶ Display	
Display language (0104)	→  14
Format display (0098)	→  15
Value 1 display (0107)	→  17
0% bargraph value 1 (0123)	→  17
100% bargraph value 1 (0125)	→  18
Decimal places 1 (0095)	→  18
Value 2 display (0108)	→  19
Decimal places 2 (0117)	→  19
Value 3 display (0110)	→  20
0% bargraph value 3 (0124)	→  20
100% bargraph value 3 (0126)	→  21
Decimal places 3 (0118)	→  21
Value 4 display (0109)	→  21

Decimal places 4 (0119)	→ 22
Display interval (0096)	→ 22
Display damping (0094)	→ 23
Header (0097)	→ 23
Header text (0112)	→ 24
Separator (0101)	→ 25
Contrast display (0105)	→ 25
Backlight (0111)	→ 25

Display language

Navigation

Expert → System → Display → Display language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic)^{*}
- Bahasa Indonesia
- ລາວ (Thai)^{*}
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting

English (alternatively, the ordered language is preset in the device)

* Visibility depends on order options or device settings

Format display

Navigation

Expert → System → Display → Format display (0098)

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→ 22).


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option




A0013098

"2 values" option




A0013100

"1 value large + 2 values" option



A0013102

"4 values" option



A0013103

Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity* ■ Conductivity* ■ Corrected conductivity* ■ Electronics temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Noise* ■ Coil current shot time* ■ Reference electrode potential against PE* ■ Build-up index* ■ Test point 1 ■ Test point 2 ■ Test point 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 43).</p>

0% bargraph value 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 43).</p>

100% bargraph value 1



Navigation	  Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 138
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 43).</p>

Decimal places 1



Navigation	  Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is defined in the Value 1 display parameter (→ 17).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 19).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 17)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 43).

0% bargraph value 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 43).

100% bargraph value 3

Navigation	Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 43).</p>

Decimal places 3

Navigation	Expert → System → Display → Decimal places 3 (0118)
Prerequisite	A measured value is specified in the Value 3 display parameter (→ 20).
Description	Use this function to select the number of decimal places for measured value 3.
Selection	<ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX
Factory setting	X.XX
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 4 display

Navigation	Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Decimal places 4



Navigation Expert → System → Display → Decimal places 4 (0119)

Prerequisite A measured value is specified in the **Value 4 display** parameter (→ 21).

Description Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation Expert → System → Display → Display interval (0096)

Prerequisite A local display is provided.

Description Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ■ The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

Display damping



Navigation  Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

 Damping is switched off if 0 is entered (factory setting).

Header



Navigation  Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting Device tag

1) proportional transmission behavior with first order delay

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 119).
- Free text
Is defined in the **Header text** parameter (→ 24).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 23), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation	Expert → System → Display → Separator (0101)
Prerequisite	A local display is provided.
Description	Use this function to select the decimal separator.
Selection	<ul style="list-style-type: none">■ . (point)■ , (comma)
Factory setting	. (point)

Contrast display

Navigation	Expert → System → Display → Contrast display (0105)
Prerequisite	A local display is provided.
Description	Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).
User entry	20 to 80 %
Factory setting	50 %

Backlight

Navigation	Expert → System → Display → Backlight (0111)
Prerequisite	A local display is provided.
Description	Use this function to switch the backlight of the local display on and off.
Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Enable


Access status display

Navigation	Expert → System → Display → Access stat.disp (0091)
Prerequisite	A local display is provided.

Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  12).</p> <p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

3.1.2 "Diagnostic handling" submenu

Navigation

 Expert → System → Diagn. handling

Alarm delay



Navigation

 Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

 The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- 190 Special event 1
- 832 Electronics temperature too high
- 833 Electronics temperature too low
- 862 Pipe empty

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ [27](#)).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 116) (Event list submenu (→ 117)) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

 For a list of all the diagnostic events, see the Operating Instructions for the device
→ [7](#)

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

► Diagnostic behavior	
Assign behavior of diagnostic no. 043 (0650)	→ 28
Assign behavior of diagnostic no. 302 (0739)	→ 28
Assign behavior of diagnostic no. 376 (0645)	→ 29
Assign behavior of diagnostic no. 377 (0777)	→ 29
Assign behavior of diagnostic no. 531 (0741)	→ 29
Assign behavior of diagnostic no. 832 (0681)	→ 30

Assign behavior of diagnostic no. 833 (0682)	→ 30
Assign behavior of diagnostic no. 834 (0700)	→ 31
Assign behavior of diagnostic no. 835 (0702)	→ 31
Assign behavior of diagnostic no. 842 (0638)	→ 31
Assign behavior of diagnostic no. 962 (0745)	→ 32
Assign behavior of diagnostic no. 937 (0743)	→ 32
Assign behavior of diagnostic no. 938 (0642)	→ 32
Assign behavior of diagnostic no. 961 (0736)	→ 33

Assign behavior of diagnostic no. 043 (Sensor short circuit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 043 (0650)

Description

Use this function to change the diagnostic behavior of the **043 Sensor short circuit** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 302 (Device verification active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0739)

Description

Use this function to change the diagnostic behavior of the **302 Device verification active** diagnostic message.

Selection	<ul style="list-style-type: none">■ Alarm■ Warning
Factory setting	Warning
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 376 (Sensor electronics (ISEM) faulty)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 376 (0645)
Description	Use this function to change the diagnostic behavior of the 376 Sensor electronics (ISEM) faulty diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 377 (Sensor electronics (ISEM) faulty)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 377 (0777)
Description	Use this function to change the diagnostic behavior of the 377 Sensor electronics (ISEM) faulty diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 531 (Empty pipe detection)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531 (0741)
Description	Use this function to change the diagnostic behavior of the 531 Empty pipe detection diagnostic message.

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 832 (Electronics temperature too high)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0681)
Description	Use this function to change the diagnostic behavior of the 832 Electronics temperature too high diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Logbook entry only
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 833 (Electronics temperature too low)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0682)
Description	Use this function to change the diagnostic behavior of the 833 Electronics temperature too low diagnostic message.
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Logbook entry only
Additional information	 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 834 (Process temperature too high)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0700)
Description	Use this function to change the diagnostic behavior of the 834 Process temperature too high diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 835 (Process temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0702)
Description	Use this function to change the diagnostic behavior of the 835 Process temperature too low diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 842



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)
Description	Change behavior of diagnostic event with diagnostic number 842 'Process limit'.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Off

Assign behavior of diagnostic no. 962 (Pipe empty)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 962 (0745)

Description

Use this function to change the diagnostic behavior of the **862 Pipe empty** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 937 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937 (0743)

Description

Use this function to change the diagnostic behavior of the **937 EMC interference** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 938 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 938 (0642)

Description

Use this function to change the diagnostic behavior of the **938 EMC interference** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional information


Detailed description of the options available for selection:

Assign behavior of diagnostic no. 961

Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 961 (0736)
Description	Select diagnostic behavior for the selected diagnostic number.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Alarm

3.1.3 "Administration" submenu*Navigation*

Expert → System → Administration


**"Define access code" wizard**

The **Define access code** wizard (→ 33) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (→ 36) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code



Define access code



Navigation

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry

0 to 9 999

Factory setting

0

Additional information

Description

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 12).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code



Navigation

Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

0 to 9 999

Factory setting

0

"Reset access code" submenu

Navigation

Expert → System → Administration → Reset acc. code

Reset access code

Operating time (0652)	→ 35
Reset access code (0024)	→ 35

Operating time

Navigation	Expert → System → Administration → Reset acc. code → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

Reset access code

Navigation	Expert → System → Administration → Reset acc. code → Reset acc. code (0024)
Description	Use this function to enter a reset code to reset the user-specific access codes to the factory setting .
User entry	Character string comprising numbers, letters and special characters
Factory setting	0x00
Additional information	<i>Description</i> For a reset code, contact your Endress+Hauser service organization. <i>User entry</i> The reset code can only be entered via: ■ Web browser ■ DeviceCare, FieldCare (via CDI RJ45 interface) ■ Fieldbus

Additional parameters in the "Administration" submenu**Define access code****Navigation**

Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information**Description**

The write protection affects all parameters in the document marked with the symbol.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 12).

If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Device reset**Navigation**

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device
- Restore S-DAT backup *

Factory setting

Cancel

* Visibility depends on order options or device settings

Activate SW option**Navigation**

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→ 38).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

Web browser

Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation  Expert → System → Administration → SW option overv. (0015)

Description Displays all the software options that are enabled in the device.

- User interface**
- Extended HistoROM
 - Electrode cleaning circuit
 - Heartbeat Verification
 - Build-up index
 - Heartbeat Monitoring

Additional information *Description*
Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"Electrode cleaning circuit" option

 Only available for Promag L and W.



Order code for "Application package", option EC "ECC electrode cleaning"

"Heartbeat Verification" option and "Heartbeat Monitoring" option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

3.2 "Sensor" submenu


Navigation  Expert → Sensor

 Sensor	
 Measured values	→  39
 System units	→  43
 Process parameters	→  51
 External compensation	→  67
 Sensor adjustment	→  69
 Calibration	→  76

3.2.1 "Measured values" submenu

Navigation


Expert → Sensor → Measured val.



"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.



Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description

Displays the volume flow that is currently measured.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Volume flow unit** parameter (→ 44)

Mass flow

Navigation	  Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)
Description	Displays the mass flow that is currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→ 48)

Corrected volume flow

Navigation	  Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1851)
Description	Displays the corrected volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Corrected volume flow unit parameter (→ 50)

Flow velocity

Navigation	  Expert → Sensor → Measured val. → Process variab. → Flow velocity (1854)
Description	Displays the flow velocity that is currently calculated.
User interface	Signed floating-point number

Conductivity

Navigation	  Expert → Sensor → Measured val. → Process variab. → Conductivity (1850)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Displays the conductivity that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→ 46)

Corrected conductivity

Navigation	  Expert → Sensor → Measured val. → Process variab. → CorrConductivity (1853)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ The On option is selected in the Conductivity measurement parameter (→ 55).■ The Internal temperature sensor option or the External value option is selected in the Temperature source parameter (→ 68).
Description	Displays the conductivity that is currently corrected.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→ 46)

Temperature


Navigation	  Expert → Sensor → Measured val. → Process variab. → Temperature (1852)
Prerequisite	The Internal temperature sensor option or the External value option is selected in the Temperature source parameter (→ 68).
Description	Displays the temperature that is currently calculated.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→ 47)

Density

Navigation	  Expert → Sensor → Measured val. → Process variab. → Density (1857)
Description	Displays the current fixed density or density read in from an external device.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Density unit parameter (→ 49)

"Totalizer" submenu*Navigation*

Expert → Sensor → Measured val. → Totalizer

**Totalizer value 1 to n****Navigation**

Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911-1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [105](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Displays the current totalizer counter reading.

User interface

Signed floating-point number

Additional information*Description*

As the operating tool can only display a maximum of 7 digits, if the display range is exceeded the current counter reading is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to n** parameter.

In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ [108](#)).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ [107](#)).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [105](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: $1968\,457 \text{ m}^3$
- Value in the **Totalizer overflow 1** parameter: $1 \cdot 10^7$ (1 overflow) = $10\,000\,000 \text{ m}^3$
- Current totalizer reading: $11\,968\,457 \text{ m}^3$

Totalizer overflow 1 to n**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910-1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [105](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to n** parameter.

User interface

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [105](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m³
- Value in the **Totalizer overflow 1** parameter: 2 · 10⁷ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

3.2.2 "System units" submenu*Navigation*

Expert → Sensor → System units

System units	
Volume flow unit (0553)	→ 44
Volume unit (0563)	→ 46
Conductivity unit (0582)	→ 46
Temperature unit (0557)	→ 47
Mass flow unit (0554)	→ 48
Mass unit (0574)	→ 48

Density unit (0555)	→ 49
Corrected volume flow unit (0558)	→ 50
Corrected volume unit (0575)	→ 50
Date/time format (2812)	→ 51

Volume flow unit**Navigation**

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ /s	■ af/s	■ gal/s (imp)	
■ cm ³ /min	■ af/min	■ gal/min (imp)	
■ cm ³ /h	■ af/h	■ gal/h (imp)	
■ cm ³ /d	■ af/d	■ gal/d (imp)	
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)	
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)	
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)	
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)	
■ m ³ /s	■ MMft ³ /s	■ bbl/s (imp;beer)	
■ m ³ /min	■ MMft ³ /min	■ bbl/min (imp;beer)	
■ m ³ /h	■ MMft ³ /h	■ bbl/h (imp;beer)	
■ m ³ /d	■ Mft ³ /d	■ bbl/d (imp;beer)	
■ ml/s	■ fl oz/s (us)	■ bbl/s (imp;oil)	
■ ml/min	■ fl oz/min (us)	■ bbl/min (imp;oil)	
■ ml/h	■ fl oz/h (us)	■ bbl/h (imp;oil)	
■ ml/d	■ fl oz/d (us)	■ bbl/d (imp;oil)	
■ l/s	■ gal/s (us)		
■ l/min	■ gal/min (us)		
■ l/h	■ gal/h (us)		
■ l/d	■ gal/d (us)		
■ hl/s	■ Mgal/s (us)		
■ hl/min	■ Mgal/min (us)		
■ hl/h	■ Mgal/h (us)		
■ hl/d	■ Mgal/d (us)		
■ Ml/s	■ bbl/s (us;liq.)		
■ Ml/min	■ bbl/min (us;liq.)		
■ Ml/h	■ bbl/h (us;liq.)		
■ Ml/d	■ bbl/d (us;liq.)		
	■ bbl/s (us;beer)		
	■ bbl/min (us;beer)		
	■ bbl/h (us;beer)		
	■ bbl/d (us;beer)		
	■ bbl/s (us;oil)		
	■ bbl/min (us;oil)		
	■ bbl/h (us;oil)		
	■ bbl/d (us;oil)		
	■ bbl/s (us;tank)		
	■ bbl/min (us;tank)		
	■ bbl/h (us;tank)		
	■ bbl/d (us;tank)		
	■ kgal/s (us)		
	■ kgal/min (us)		
	■ kgal/h (us)		
	■ kgal/d (us)		
Factory setting	Country-specific: ■ l/h ■ gal/min (us)		

Additional information*Effect*

The selected unit applies for:

Volume flow parameter (→  39)

Selection

 For an explanation of the abbreviated units: →  143

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Volume unit**Navigation**

  Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- Mft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- gal (us)

Additional information*Selection*

 For an explanation of the abbreviated units: →  143

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Conductivity unit**Navigation**

  Expert → Sensor → System units → Conductiv. unit (0582)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→  55) parameter.

Description Use this function to select the unit for the conductivity.

Selection

SI units

- nS/cm
- μ S/cm
- μ S/m
- μ S/mm
- mS/m
- mS/cm
- S/cm
- S/m
- kS/m
- MS/m

Factory setting μ S/cm

Additional information *Effect*
The selected unit applies for:
Conductivity parameter (→ 40)

Selection

 For an explanation of the abbreviated units: → 143



Temperature unit

Navigation  Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	■ °R

Factory setting Country-specific:
■ °C
■ °F

Additional information *Effect*
The selected unit applies for:
■ **Maximum value** parameter (→ 133)
■ **Minimum value** parameter (→ 133)

Selection

 For an explanation of the abbreviated units: → 143

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Effect*

The selected unit applies for:

Mass flow parameter (→ 40)

Selection

For an explanation of the abbreviated units: → 143

Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter.

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → [143](#)

Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter.

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Effect*

The selected unit applies for:

- **External density** parameter (→ [67](#))
- **Fixed density** parameter (→ [68](#))

Selection

- SD = specific density

The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

- SG = specific gravity

The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).



For an explanation of the abbreviated units: → [143](#)

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- Nl/s
- Nl/min
- Nl/h
- Nl/d
- Nhl/s
- Nhl/min
- Nhl/h
- Nhl/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sl/s
- Sl/min
- Sl/h
- Sl/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- MMSft³/s
- MMSft³/min
- MMSft³/h
- MMSft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)
- Sbbl/s (us;oil)
- Sbbl/min (us;oil)
- Sbbl/h (us;oil)
- Sbbl/d (us;oil)

Factory setting

Country-specific:

- Nl/h
- Sft³/h

Additional information*Selection*

For an explanation of the abbreviated units: → 143

Corrected volume unit**Navigation**

Expert → Sensor → System units → Corr. vol. unit (0575)

Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- Nl
- Nhl
- Nm³
- Sl
- Sm³

US units

- Sft³
- MMSft³
- Sgal (us)
- Sbbl (us;liq.)
- Sbbl (us;oil)

Imperial units

- Sgal (imp)

Factory setting Country-specific:
 ■ Nm³
 ■ Sft³

Additional information *Selection*



For an explanation of the abbreviated units: → [143](#)



Date/time format

Navigation Expert → Sensor → System units → Date/time format (2812)

Description Use this function to select the desired time format for calibration history.

Selection
 ■ dd.mm.yy hh:mm
 ■ dd.mm.yy hh:mm am/pm
 ■ mm/dd/yy hh:mm
 ■ mm/dd/yy hh:mm am/pm

Factory setting dd.mm.yy hh:mm

Additional information *Selection*



For an explanation of the abbreviated units: → [143](#)



3.2.3 "Process parameters" submenu

Navigation

Expert → Sensor → Process param.

▶ Process parameters	
Filter options (6710)	→ 52
Flow damping (6661)	→ 54
Flow override (1839)	→ 54
Conductivity measurement (6514)	→ 55
Conductivity damping (1803)	→ 55
Conductivity temperature coefficient (1891)	→ 56
Temperature damping (1886)	→ 56

Reference density (1885)	→ 56
► Low flow cut off	→ 57
► Empty pipe detection	→ 59
► Electrode cleaning circuit	→ 62
► Build-up index	→ 64

Filter options



Navigation

Expert → Sensor → Process param. → Filter options (6710)

Description

Use this function to select a filter option.

Selection

- Adaptive
- Adaptive CIP on
- Dynamic
- Dynamic CIP on
- Binomial
- Binomial CIP on

Factory setting

Binomial

Additional information

Description

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects

the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

Selection

■ **Standard**

- Strong flow damping with a short output signal response time.
- Some time is needed before a stable output signal can be generated.
- Not suitable for pulsating flow as the average flow can be different here.

■ **Dynamic**

- Average flow damping with a delayed output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **Binomial**

- Weak flow damping with a short output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **CIP**

- This filter makes the **Standard** and **Dynamic** filter options additionally available.
- If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
- If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

Examples

Possible applications for the filters

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Pulsating flow (flow is negative intermittently)	---	---	++	--	++
Flow changes frequently (flow is dynamic)	-	--	++	-	++
Clear signal, fast control loop (< 1 s)	--	--	+ ¹⁾		++
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	----
Permanently bad signal	++	--	-	---	-
Short and severe signal distortion after a while		++		++	
Replacement of a Promag 50/53: system damping Promag 400 = 0.5 * system damping Promag 50/53					+++
Replacement of a Promag 10: system damping Promag 400 = system damping Promag 10 + 2			+++		
For a stable flow signal (no other requirements)	+++				

1) Value of flow damping < 6

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping (6661)

Description

Use this function to enter a value for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

4

Additional information

Input range 0 to 15

- Value = 0: no damping
- Value = 1: minor damping
- Value = 15: strong damping

i ▪ The damping depends on the measuring period and the filter type selected.
▪ An increase or decrease in the damping depends on the application.

Effect

i The damping affects the following variables of the device:

- Outputs
- Low flow cut off → [57](#)
- Totalizers → [105](#)

Flow override



Navigation

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

i This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The **453 Flow override** diagnostic message is output.
- Output values
 - Output: value at zero flow
 - Temperature: continues to be output
 - Totalizers 1-3: stop being totalized

i The **Flow override** option can also be activated in the **Status input** submenu: **Assign status input** parameter.

Conductivity measurement

Navigation Expert → Sensor → Process param. → Conduct. measur. (6514)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 55) parameter.

Description Use this function to enable and disable conductivity measurement.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.

Conductivity damping

Navigation Expert → Sensor → Process param. → Conduct. damping (1803)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 55).

Description Use this function to enter a time constant for conductivity damping (PT1 element).

User entry 0 to 999.9 s

Factory setting 0 s

Additional information *Description*

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if 0 is entered (factory setting).

2) Proportional behavior with first-order lag

Conductivity temperature coefficient



Navigation Expert → Sensor → Process param. → Cond. temp.coeff (1891)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Use this function to enter the temperature coefficient for the conductivity.

User entry Signed floating-point number

Factory setting 2.1 %/K

Temperature damping



Navigation Expert → Sensor → Process param. → Temp. damping (1886)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Use this function to enter the time constant for temperature damping.

User entry 0 to 999.9 s

Factory setting 0 s

Reference density



Navigation Expert → Sensor → Process param. → Ref.density (1885)

Description Use this function to enter a fixed value for the reference density.

User entry Positive floating-point number

Factory setting Country-specific:

- 1 kg/l
- 1 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 49)

"Low flow cut off" submenu**Navigation**
 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign process variable (1837)	→  57
On value low flow cutoff (1805)	→  57
Off value low flow cutoff (1804)	→  58
Pressure shock suppression (1806)	→  58

Assign process variable**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

On value low flow cutoff**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→  57).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  58.

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter →  139

Additional information

Dependency

 The unit depends on the process variable selected in the **Assign process variable** parameter (→  57).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 57).

Description

Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 57.

User entry


0 to 100.0 %

Factory setting

50 %

Additional information

Example



A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pressure shock suppression**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 57).

Description

Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry

0 to 100 s

Factory setting

0 s

Additional information

Description

Pressure shock suppression is enabled


- Prerequisite:
Flow rate < on-value of low flow cut off
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.




A0012888

- Q Flow
 t Time
 A Drip
 B Pressure shock
 C Pressure shock suppression active as per the time entered
 D Pressure shock suppression inactive
 1 Valve closes
 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
 3 The time entered has elapsed: pressure shock suppression is deactivated
 4 The actual flow value is processed again and output
 5 On-value for low flow cut off
 6 Off-value for low flow cut off

"Empty pipe detection" submenu

Navigation

Expert → Sensor → Process param. → Empty pipe det.



Response time empty pipe detection (1859)	→ 60
New adjustment (6560)	→ 61
Progress (6571)	→ 61
Empty pipe adjust value (6527)	→ 61
Full pipe adjust value (6548)	→ 62
Measured value EPD (6559)	→ 62

Assign process variable



Navigation Expert → Sensor → Process param. → Empty pipe det. → Assign variable (1860)

Description Use this function to switch empty pipe detection on and off.

Selection

- Off
- On

Factory setting Off

Switch point empty pipe detection



Navigation Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD (6562)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ 60).

Description Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.

User entry 0 to 100 %

Factory setting 50 %

Response time empty pipe detection



Navigation Expert → Sensor → Process param. → Empty pipe det. → Response time (1859)

Prerequisite A process variable is selected in the **Assign process variable** parameter (→ 60).

Description Use this function to enter the minimum length of time (debouncing time) the signal must be present for the **△S862 Pipe empty** diagnostic message to be triggered if the measuring pipe is empty or partially full.

User entry 0 to 100 s

Factory setting 1 s

New adjustment



Navigation Expert → Sensor → Process param. → Empty pipe det. → New adjustment (6560)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [60](#)).

Description For selecting whether to perform an empty pipe or full pipe adjustment.

Selection

- Cancel
- Empty pipe adjust
- Full pipe adjust

Factory setting Cancel

Progress



Navigation Expert → Sensor → Process param. → Empty pipe det. → Progress (6571)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [60](#)).

Description Use this function to view the progress.

User interface

- Ok
- Busy
- Not ok

Empty pipe adjust value



Navigation Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value (6527)

Prerequisite

- In the **Empty pipe detection** parameter (→ [60](#)), the **On** option is selected.
- Adjustment value > full pipe value.

Description Displays the adjustment value when the measuring pipe is empty.

User interface Positive floating-point number

Full pipe adjust value

Navigation Expert → Sensor → Process param. → Empty pipe det. → Full pipe value (6548)

Prerequisite

- In the **Empty pipe detection** parameter (→ 60), the **On** option is selected.
- Adjustment value < empty pipe value.

Description Displays the adjustment value when the measuring pipe is full.

User interface Positive floating-point number

Measured value EPD

Navigation Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD (6559)

Prerequisite In the **Empty pipe detection** parameter (→ 60), the **On** option is selected.

Description Displays the current measured value.

User interface Positive floating-point number

"Electrode cleaning circuit" submenu

Navigation

Expert → Sensor → Process param. → ECC

► Electrode cleaning circuit	
Electrode cleaning cycle (6528)	→ 63
ECC duration (6555)	→ 63
ECC recovery time (6556)	→ 63
ECC interval (6557)	→ 64
ECC polarity (6631)	→ 64

Electrode cleaning cycle



Navigation Expert → Sensor → Process param. → ECC → Elec. clean cycl (6528)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enable and disable cyclic electrode cleaning.

Selection
■ Off
■ On

Factory setting Off

Additional information Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits developing in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.

ECC duration



Navigation Expert → Sensor → Process param. → ECC → ECC duration (6555)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enter the duration of electrode cleaning in seconds.

User entry 0.01 to 30 s

Factory setting 2 s

ECC recovery time



Navigation Expert → Sensor → Process param. → ECC → ECC recov. time (6556)

Prerequisite For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.

User entry 1 to 600 s

Factory setting 5 s

ECC interval**Navigation**

Expert → Sensor → Process param. → ECC → ECC interval (6557)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enter the pause duration until the next electrode cleaning.

User entry

0.5 to 168 h

Factory setting

0.7 h

ECC polarity**Navigation**

Expert → Sensor → Process param. → ECC → ECC polarity (6631)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Displays the polarity of the electrode cleaning circuit.

User interface

- Positive
- Negative

Factory setting

Depends on the electrode material:

- Tantalum: **Negative** option
- Platinum, Alloy C22, stainless steel: **Positive** option

"Coating detection" submenu

Build-up detection is only available:

- In conjunction with the Promag W sensor
- In the compact device version (transmitter and sensor form a mechanical unit)
- For detailed information on build-up detection: see the Special Documentation for the **Heartbeat Verification + Monitoring** application package → 7

Navigation

Expert → Sensor → Process param. → Build-up detect.

Build-up index	
Build-up index	→ 65
Build-up index damping	→ 65
Build-up index value	→ 65

Build-up limit	→ 66
Build-up limit hysteresis	→ 66

Build-up index

Navigation	Expert → Sensor → Process param. → Build-up index (6734)
Description	Select mode for build-up index.
Selection	<ul style="list-style-type: none"> ■ Off ■ Slow ■ Standard ■ Fast
Factory setting	Off

Build-up index damping

Navigation	Expert → Sensor → Process param. → Build-up index → BuildUpIndexDamp (6840)
Description	Enter damping value for build-up index. Damping value: <ul style="list-style-type: none"> ■ 0 = minimum damping ■ 15 = maximum damping The damping value should only be increased if the measured value is unstable.
User entry	0 to 15
Factory setting	0

Build-up index value

Navigation	Expert → Sensor → Process param. → Build-up index → Build-up value (12111)
Description	Shows current build-up index value.
User interface	0.0 to 100.0 %
Factory setting	0.0 %
Additional information	The formation of build-up is output as a percentage in the Build-up index value (→ 65) parameter. The higher the percentage, the thicker the build-up.

Build-up index value (\rightarrow 65) = 0%

- No build-up present
- Measuring tube as-delivered state (initial value)
- Measuring tube was cleaned thoroughly after formation of build-up

Build-up index value (\rightarrow 65) = 100%

- Value for the maximum measurable build-up thickness
- The thickness of the build-up at 100% varies depending on the process
- A value of 100% should not be equated with a blocked measuring tube

The percentage indicated in the Build-up index value (\rightarrow 65) parameter does not provide direct information about the absolute thickness or the composition of the build-up. Therefore, to make optimum use of the build-up detection function, it is necessary to first compare the formation of build-up in the process, as known from experience, with the associated Build-up index value (\rightarrow 65). The aim is to determine the Build-up index value (\rightarrow 65) at the time the cleaning is usually performed.

On the basis of the Build-up index value (\rightarrow 65) during cleaning, it is possible to make a valid assessment of the condition inside the measuring tube and to plan the cleaning using the build-up limit and build-up detection hysteresis parameters.

In addition, conclusions about possible effects on neighboring processes can be drawn from the Build-up index value (\rightarrow 65).

Build-up limit

Navigation  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up index \rightarrow Build-up limit (6466)

Description Enter limit value for the build-up index.

User entry 0 to 100 %

Factory setting 50 %

Build-up limit hysteresis

Navigation  Expert \rightarrow Sensor \rightarrow Process param. \rightarrow Build-up index \rightarrow BuildUpLimitHyst (6467)

Description Enter hysteresis for build-up limit value.

If the value for build-up detection hysteresis is higher than the Build-up limit (\rightarrow 66), the "Build-up detected" diagnostic information is not reset until the measuring tube has been cleaned and a restart has been performed.

User entry 0 to 100 %

Factory setting 20 %

3.2.4 "External compensation" submenu

Navigation

Expert → Sensor → External comp.

► External compensation	
Density source (6615)	→ 67
Fixed density (6623)	→ 68
External density (6630)	→ 67
Temperature source (6712)	→ 68
External temperature (6673)	→ 68
Reference temperature (1816)	→ 69

Density source



Navigation

Expert → Sensor → External comp. → Density source (6615)

Description

Use this function to select the density source.

Selection

- Fixed density
- External density

Factory setting

Fixed density

External density

Navigation

Expert → Sensor → External comp. → External density (6630)

Prerequisite

The **External density** option is selected in the **Density source** parameter (→ [67](#)).

Description

Displays the density read in from the external device.

User entry

Positive floating-point number

Additional information

Dependency

The unit is taken from the **Density unit** parameter (→ [49](#))

Fixed density

Navigation Expert → Sensor → External comp. → Fixed density (6623)

Prerequisite The **Fixed density** option is selected in the **Density source** parameter (→ 67).

Description Use this function to enter a fixed value for the density.

User entry Positive floating-point number

Factory setting Depends on country:

- 1 000 kg/m³
- 62 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 49)

Temperature source

Navigation Expert → Sensor → External comp. → Temp. source (6712)

Description Use this function to select the temperature source.

Selection

- Internal temperature sensor *
- Off
- External value

Factory setting Off

External temperature

Navigation Expert → Sensor → External comp. → External temp. (6673)

Prerequisite The **External value** option is selected in the **Temperature source** parameter (→ 68).

Description Displays the temperature read in from the external device.

User entry Floating point number with sign

Additional information *Dependency*

The unit is taken from the **Temperature unit** parameter (→ 47)

* Visibility depends on order options or device settings

Reference temperature**Navigation**

Expert → Sensor → External comp. → Ref. temperature (1816)

Prerequisite

The **Fixed density** option or **External density** option are selected in the **Density source** parameter (→ 67).

Description

Use this function to enter a reference temperature for calculating the reference density.

User interface

-273.15 to 99 999 °C

Factory setting

Country-specific:

- +20 °C
- +68 °F

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ 47)

Reference density calculation

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_N : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

3.2.5 "Sensor adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm.

► Sensor adjustment

Installation direction (1809)

→ 70

Integration time (6533)

→ 70

Measuring period (6536)

→ 70

► Process variable adjustment

→ 70

Installation direction

Navigation Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description Use this function to change the sign of the medium flow direction.

Selection

- Forward flow
- Reverse flow

Factory setting Forward flow

Additional information *Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time

Navigation Expert → Sensor → Sensor adjustm. → Integration time (6533)

Description Displays the duration of the integration time.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 1 to 65 ms

Measuring period

Navigation Expert → Sensor → Sensor adjustm. → Measuring period (6536)

Description Display the time of a full measuring period.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 2 to 1000 ms

"Process variable adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust

► Process variable adjustment

Volume flow offset (1831)

→ 72

Volume flow factor (1832)	→ 71
Mass flow offset (1841)	→ 72
Mass flow factor (1846)	→ 72
Conductivity offset (1848)	→ 73
Conductivity factor (1849)	→ 73
Corrected volume flow offset (1866)	→ 73
Corrected volume flow factor (1867)	→ 74
Temperature offset (1868)	→ 74
Temperature factor (1869)	→ 74
Corrected conductivity offset (1870)	→ 75
Corrected conductivity factor (1871)	→ 75
Flow velocity offset (1879)	→ 75
Flow velocity factor (1880)	→ 76

Volume flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Volume flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/s

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)

Description

Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description

Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.

User entry

Signed floating-point number

Factory setting

0 kg/s

Additional information*Description*

Corrected value = (factor × value) + offset

Conductivity offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset (1848)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Conductivity factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor (1849)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55).
Description	Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Corrected volume flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1866)
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Corrected volume flow factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1867)
Description	Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1868)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1869)
Prerequisite	The temperature is read into the flowmeter from an external device.
Description	Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.offset (1870)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55) parameter.
Description	Use this function to enter the zero point shift to trim the corrected conductivity. The conductivity unit on which the shift is based is µS/cm.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.factor (1871)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 55) parameter.
Description	Use this function to enter a quantity factor for the corrected conductivity. In each case, this factor refers to the conductivity in µS/cm.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Flow velocity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. offset (1879)
Description	Use this function to enter the zero point shift for the flow velocity trim. The flow velocity unit on which the shift is based is m/s.
User entry	Signed floating-point number
Factory setting	0 m/s

Additional information*Description*

Corrected value = (factor × value) + offset

Flow velocity factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. factor (1880)

Description

Use this function to enter a quantity factor (without time) for the flow velocity. This multiplication factor is applied over the flow velocity range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu

Navigation

Expert → Sensor → Calibration

▶ Calibration	
Nominal diameter (2807)	→ 76
Calibration factor (6522)	→ 77
Zero point (6546)	→ 77
Conductivity calibration factor (6718)	→ 77

Nominal diameter**Navigation**

Expert → Sensor → Calibration → Nominal diameter (2807)

Description

Displays the nominal diameter of the sensor.

User interface

DNxx / x"

Factory setting

Depends on the size of the sensor

Additional information*Description*

The value is also specified on the sensor nameplate.

Calibration factor

Navigation

Expert → Sensor → Calibration → Cal. factor (6522)

Description

Displays the current calibration factor for the sensor.

User interface

Positive floating-point number

Factory setting

Depends on nominal diameter and calibration.

Zero point

**Navigation**

Expert → Sensor → Calibration → Zero point (6546)

Description

This function shows the zero point correction value for the sensor.

User interface

Signed floating-point number

Factory setting

Depends on nominal diameter and calibration

Conductivity calibration factor

**Navigation**

Expert → Sensor → Calibration → Cond. cal. fact. (6718)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 55) parameter.

Description

Displays the calibration factor for the conductivity measurement.

User interface

0.01 to 10 000

3.3 "Communication" submenu

Navigation

Expert → Communication

▶ Communication	
▶ Configuration	→ 78
▶ WLAN settings	→ 97

3.3.1 "Configuration" submenu

Navigation

Expert → Communication → Configuration

▶ Configuration	
▶ Configurable input assembly 101	→ 82
▶ Configurable input assembly 121	→ 89
Web server language (7221)	→ 78
MAC address (7214)	→ 79
Hardware address mode (7401)	→ 79
DHCP client (7212)	→ 80
IP address (7209)	→ 80
Subnet mask (7211)	→ 81
Default gateway (7210)	→ 81
Web server functionality (7222)	→ 81
Login page (7273)	→ 82

Web server language

Navigation

Expert → Communication → Configuration → Webserv.language (7221)

Description

Use this function to select the Web server language setting.

Selection	<ul style="list-style-type: none"> ■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ العربية (Arabic) * ■ Bahasa Indonesia ■ ภาษาไทย (Thai) * ■ tiếng Việt (Vietnamese) ■ čeština (Czech)
Factory setting	English

MAC address

Navigation	 Expert → Communication → Configuration → MAC Address (7214)
Description	Displays the MAC ³⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<p><i>Example</i></p> <p>For the display format 00:07:05:10:01:5F</p>

Hardware address mode

Navigation	 Expert → Communication → Configuration → HardwareAddrMode (7401)
Description	Displays the use of default network settings.
User interface	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

* Visibility depends on order options or device settings
3) Media Access Control

Additional information *User interface*

The **On** option is displayed as soon as the last octet of the IP address is set via DIP switches.

DHCP client**Navigation** Expert → Communication → Configuration → DHCP client (7212)**Description** Use this function to activate and deactivate the DHCP client functionality.**Selection**

- Off
- On

Factory setting On**Additional information** *Effect*

If the DHCP client functionality of the web server is selected, the IP address (→ 80), Subnet mask (→ 81) and Default gateway (→ 81) are set automatically.



- Identification is via the MAC address of the measuring device.
- The IP address (→ 80) in the **IP address** parameter (→ 80) is ignored as long as the **DHCP client** parameter (→ 80) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→ 80) in the parameter of the same name is only used if the **DHCP client** parameter (→ 80) is inactive.

IP address**Navigation** Expert → Communication → Configuration → IP address (7209)**Description** Display or enter the IP address of the Web server integrated in the measuring device.**User entry** 4 octet: 0 to 255 (in the particular octet)**Factory setting** 192.168.1.212**Additional information** *User entry*

The IP address can be write-accessed only if the DHCP client (→ 80) is disabled. If one of the 8 DIP switches for setting the last octet is not equal to 0, its value is used for the last octet and also displayed. The IP address cannot then be write-accessed. If an IP address was set using the DIP switches, the last address to be set is retained even after the DIP switches have been disabled. However, it can be changed again in this parameter.

Subnet mask

Navigation Expert → Communication → Configuration → Subnet mask (7211)

Description Display or enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

Default gateway

Navigation Expert → Communication → Configuration → Default gateway (7210)

Description Display or enter the Default gateway (→ [81](#)).

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 0.0.0.0

Web server functionality

Navigation Expert → Communication → Configuration → Webserver funct. (7222)

Description Use this function to switch the Web server on and off.

Selection

- Off
- On

Factory setting On

Additional information *Description*



Once disabled, the Web server functionality can only be re-enabled via or the operating tool FieldCare.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ■ The web server is completely disabled. ■ Port 80 is locked.
On	<ul style="list-style-type: none"> ■ The complete functionality of the web server is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Expert → Communication → Configuration → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

Capability flags**Navigation**

Expert → Communication → Configuration → Capability flags (7439)

Description

Displays the DLR (Device Level Ring) properties of the device.

User interface

- Announce-based ring node
- Beacon-based ring node
- Supervisor capable
- Redundant gateway capable
- Flush table frame capable

Factory setting

Beacon-based ring node

User description**Navigation**

Expert → Communication → Configuration → User description (7432)

Description

Use this function to enter the user-defined device name and location (separated by a semicolon).

User entry

Character string comprising numbers, letters and special characters (128)

Factory setting

description;location

"Configurable input assembly" submenu**Navigation**

Expert → Communication → Configuration → Input assembly

▶ Configurable input assembly 101

Input assembly position 1 (7402)

→ 83

Input assembly position 2 (7413)	→ 84
Input assembly position 3 (7415)	→ 84
Input assembly position 4 (7416)	→ 84
Input assembly position 5 (7417)	→ 85
Input assembly position 6 (7418)	→ 85
Input assembly position 7 (7419)	→ 85
Input assembly position 8 (7420)	→ 85
Input assembly position 9 (7421)	→ 86
Input assembly position 10 (7403)	→ 86
Input assembly position 11 (7404)	→ 86
Input assembly position 12 (7405)	→ 87
Input assembly position 13 (7406)	→ 87
Input assembly position 14 (7407)	→ 87
Input assembly position 15 (7408)	→ 87
Input assembly position 16 (7409)	→ 88
Input assembly position 17 (7410)	→ 88
Input assembly position 18 (7411)	→ 88
Input assembly position 19 (7412)	→ 88
Input assembly position 20 (7414)	→ 89

Input assembly position 1



Navigation

Expert → Communication → Configuration → InputAssemb.101 → Position 1 (7402)

Description

Use this function to select a process variable for input value 1.

Selection

- Off
- Mass flow
- Volume flow

- Conductivity *
- Velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature

Factory setting Volume flow

Input assembly position 2



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 2 (7413)
Description	Use this function to select a process variable for input value 2.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Mass flow

Input assembly position 3



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 3 (7415)
Description	Use this function to select a process variable for input value 3.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Velocity

Input assembly position 4



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 4 (7416)
Description	Use this function to select a process variable for input value 4.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Totalizer 1

* Visibility depends on order options or device settings

Input assembly position 5

Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 5 (7417)
Description	Use this function to select a process variable for input value 5.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Totalizer 2

Input assembly position 6

Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 6 (7418)
Description	Use this function to select a process variable for input value 6.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Totalizer 3

Input assembly position 7

Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 7 (7419)
Description	Use this function to select a process variable for input value 7.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Electronics temperature

Input assembly position 8

Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 8 (7420)
Description	Use this function to select a process variable for input value 8.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Off

Input assembly position 9



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 9 (7421)
Description	Use this function to select a process variable for input value 9.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)
Factory setting	Off

Input assembly position 10



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 10 (7403)
Description	Use this function to select a process variable for input value 10.
Selection	Picklist, see Input assembly position 1 parameter (→ 83)

Input assembly position 11



Navigation	Expert → Communication → Configuration → InputAssemb.101 → Position 11 (7404)
Description	Use this function to select a process variable for input value 11.
Selection	<ul style="list-style-type: none">▪ Off▪ Actual diagnostics▪ Previous diagnostics▪ Mass flow unit▪ Volume flow unit▪ Temperature unit [*]▪ Conductivity unit [*]▪ Unit totalizer 1▪ Unit totalizer 2▪ Unit totalizer 3▪ Velocity unit▪ Verification results [*]▪ Verification status [*]
Factory setting	Volume flow unit

* Visibility depends on order options or device settings

Input assembly position 12

Navigation   Expert → Communication → Configuration → InputAssemb.101 → Position 12 (7405)

Description Use this function to select a process variable for input value 12.

Selection Picklist, see **Input assembly position 11** parameter (→  86)

Factory setting Mass flow unit

Input assembly position 13

Navigation   Expert → Communication → Configuration → InputAssemb.101 → Position 13 (7406)

Description Use this function to select a process variable for input value 13.

Selection Picklist, see **Input assembly position 11** parameter (→  86)

Factory setting Velocity unit

Input assembly position 14

Navigation   Expert → Communication → Configuration → InputAssemb.101 → Position 14 (7407)

Description Use this function to select a process variable for input value 14.

Selection Picklist, see **Input assembly position 11** parameter (→  86)

Factory setting Unit totalizer 1

Input assembly position 15

Navigation   Expert → Communication → Configuration → InputAssemb.101 → Position 15 (7408)

Description Use this function to select a process variable for input value 15.

Selection Picklist, see **Input assembly position 11** parameter (→  86)

Factory setting Unit totalizer 2

Input assembly position 16

Navigation Expert → Communication → Configuration → InputAssemb.101 → Position 16 (7409)

Description Use this function to select a process variable for input value 16.

Selection Picklist, see **Input assembly position 11** parameter (→ 86)

Factory setting Unit totalizer 3

Input assembly position 17

Navigation Expert → Communication → Configuration → InputAssemb.101 → Position 17 (7410)

Description Use this function to select a process variable for input value 17.

Selection Picklist, see **Input assembly position 11** parameter (→ 86)

Factory setting Temperature unit

Input assembly position 18

Navigation Expert → Communication → Configuration → InputAssemb.101 → Position 18 (7411)

Description Use this function to select a process variable for input value 18.

Selection Picklist, see **Input assembly position 11** parameter (→ 86)

Factory setting Off

Input assembly position 19

Navigation Expert → Communication → Configuration → InputAssemb.101 → Position 19 (7412)

Description Use this function to select a process variable for input value 19.

Selection Picklist, see **Input assembly position 11** parameter (→ 86)

Factory setting Off

Input assembly position 20**Navigation**

Expert → Communication → Configuration → InputAssemb.101 → Position 20 (7414)

Description

Use this function to select a process variable for input value 20.

Selection

Picklist, see **Input assembly position 11** parameter (→ 86)

Factory setting

Off

"Configurable input assembly 121" submenu*Navigation*

Expert → Communication → Configuration → InputAssemb.121

► Configurable input assembly 121	
Input assembly position 1 (7434)	→ 90
Input assembly position 2 (7435)	→ 90
Input assembly position 3 (7436)	→ 91
Input assembly position 4 (7437)	→ 91
Input assembly position 5 (7438)	→ 92
Input assembly position 6 (7440)	→ 92
Input assembly position 7 (7441)	→ 93
Input assembly position 8 (7442)	→ 94
Input assembly position 9 (7443)	→ 94
Input assembly position 10 (7444)	→ 95
Input assembly position 11 (7445)	→ 95
Input assembly position 12 (7446)	→ 96
Input assembly position 13 (7447)	→ 96
Input assembly position 14 (7448)	→ 97
Input assembly position 15 (7449)	→ 97

Input assembly position 1

Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 1 (7434)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none">■ Off■ Mass flow■ Volume flow■ Corrected volume flow■ Conductivity *■ Corrected conductivity *■ Flow velocity■ Totalizer 1■ Totalizer 2■ Totalizer 3■ Electronics temperature■ Temperature *■ Build-up index *■ Reference electrode potential against PE *■ Coil current shot time *■ Noise *■ Test point 1■ Test point 2■ Test point 3
Factory setting	Volume flow

Input assembly position 2

Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 2 (7435)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none">■ Off■ Mass flow■ Volume flow■ Corrected volume flow■ Conductivity *■ Corrected conductivity *■ Flow velocity■ Totalizer 1■ Totalizer 2■ Totalizer 3■ Electronics temperature■ Temperature *■ Build-up index *■ Reference electrode potential against PE *■ Coil current shot time *■ Noise *

* Visibility depends on order options or device settings

- Test point 1
- Test point 2
- Test point 3

Factory setting Mass flow

Input assembly position 3



Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 3 (7436)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Conductivity [*] ■ Corrected conductivity [*] ■ Flow velocity ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Electronics temperature ■ Temperature [*] ■ Build-up index [*] ■ Reference electrode potential against PE [*] ■ Coil current shot time [*] ■ Noise [*] ■ Test point 1 ■ Test point 2 ■ Test point 3
Factory setting	Flow velocity

Input assembly position 4



Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 4 (7437)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Conductivity [*] ■ Corrected conductivity [*] ■ Flow velocity ■ Totalizer 1

* Visibility depends on order options or device settings

- Totalizer 2
- Totalizer 3
- Electronics temperature
- Temperature^{*}
- Build-up index^{*}
- Reference electrode potential against PE^{*}
- Coil current shot time^{*}
- Noise^{*}
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 1

Input assembly position 5**Navigation**

Expert → Communication → Configuration → InputAssemb.121 → Position 5 (7438)

Description

Select process variable for input value.

Selection

- Off
- Mass flow
- Volume flow
- Corrected volume flow
- Conductivity^{*}
- Corrected conductivity^{*}
- Flow velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature
- Temperature^{*}
- Build-up index^{*}
- Reference electrode potential against PE^{*}
- Coil current shot time^{*}
- Noise^{*}
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 2

Input assembly position 6**Navigation**

Expert → Communication → Configuration → InputAssemb.121 → Position 6 (7440)

Description

Select process variable for input value.

* Visibility depends on order options or device settings

Selection

- Off
- Mass flow
- Volume flow
- Corrected volume flow
- Conductivity *
- Corrected conductivity *
- Flow velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature *
- Temperature *
- Build-up index *
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Totalizer 3

Input assembly position 7**Navigation**

Expert → Communication → Configuration → InputAssemb.121 → Position 7 (7441)

Description

Select process variable for input value.

Selection

- Off
- Mass flow
- Volume flow
- Corrected volume flow
- Conductivity *
- Corrected conductivity *
- Flow velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature *
- Temperature *
- Build-up index *
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Test point 1
- Test point 2
- Test point 3

Factory setting

Electronics temperature

* Visibility depends on order options or device settings

Input assembly position 8

Navigation Expert → Communication → Configuration → InputAssemb.121 → Position 8 (7442)

Description Select process variable for input value.

Selection

- Off
- Mass flow
- Volume flow
- Corrected volume flow
- Conductivity *
- Corrected conductivity *
- Flow velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature
- Temperature *
- Build-up index *
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Test point 1
- Test point 2
- Test point 3

Factory setting Corrected volume flow

Input assembly position 9

Navigation Expert → Communication → Configuration → InputAssemb.121 → Position 9 (7443)

Description Select process variable for input value.

Selection

- Off
- Mass flow
- Volume flow
- Corrected volume flow
- Conductivity *
- Corrected conductivity *
- Flow velocity
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Electronics temperature
- Temperature *
- Build-up index *
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *

* Visibility depends on order options or device settings

	<ul style="list-style-type: none"> ■ Test point 1 ■ Test point 2 ■ Test point 3
Factory setting	Off
Input assembly position 10	
Navigation	 Expert → Communication → Configuration → InputAssemb.121 → Position 10 (7444)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Conductivity * ■ Corrected conductivity * ■ Flow velocity ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Electronics temperature ■ Temperature * ■ Build-up index * ■ Reference electrode potential against PE * ■ Coil current shot time * ■ Noise * ■ Test point 1 ■ Test point 2 ■ Test point 3
Factory setting	Off

Input assembly position 11	
Navigation	 Expert → Communication → Configuration → InputAssemb.121 → Position 11 (7445)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ■ Off ■ Actual diagnostics ■ Previous diagnostics ■ Low flow cut off ■ Verification results *

* Visibility depends on order options or device settings

- Verification status *
- Build-up index *
- Empty pipe detection

Factory setting Actual diagnostics

Input assembly position 12



Navigation Expert → Communication → Configuration → InputAssemb.121 → Position 12 (7446)

Description Select process variable for input value.

- Selection**
- Off
 - Actual diagnostics
 - Previous diagnostics
 - Low flow cut off
 - Verification results *
 - Verification status *
 - Build-up index *
 - Empty pipe detection

Factory setting Previous diagnostics

Input assembly position 13



Navigation Expert → Communication → Configuration → InputAssemb.121 → Position 13 (7447)

Description Select process variable for input value.

- Selection**
- Off
 - Actual diagnostics
 - Previous diagnostics
 - Low flow cut off
 - Verification results *
 - Verification status *
 - Build-up index *
 - Empty pipe detection

Factory setting Verification status

* Visibility depends on order options or device settings

Input assembly position 14


Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 14 (7448)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Actual diagnostics ▪ Previous diagnostics ▪ Low flow cut off ▪ Verification results * ▪ Verification status * ▪ Build-up index * ▪ Empty pipe detection
Factory setting	Verification results

Input assembly position 15

Navigation	Expert → Communication → Configuration → InputAssemb.121 → Position 15 (7449)
Description	Select process variable for input value.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Actual diagnostics ▪ Previous diagnostics ▪ Low flow cut off ▪ Verification results * ▪ Verification status * ▪ Build-up index * ▪ Empty pipe detection
Factory setting	Off

3.3.2 "WLAN settings" wizard*Navigation*

Expert → Communication → WLAN settings



* Visibility depends on order options or device settings

SSID name (2714)	→ 99
Network security (2705)	→ 99
Security identification (2718)	→ 100
User name (2715)	→ 100
WLAN password (2716)	→ 100
WLAN IP address (2711)	→ 100
WLAN MAC address (2703)	→ 101
WLAN subnet mask (2709)	→ 101
WLAN MAC address (2703)	→ 101
WLAN passphrase (2706)	→ 101
WLAN MAC address (2703)	→ 101
Assign SSID name (2708)	→ 102
SSID name (2707)	→ 102
2.4 GHz WLAN channel (2704)	→ 102
Select antenna (2713)	→ 103
Connection state (2722)	→ 103
Received signal strength (2721)	→ 103
WLAN IP address (2711)	→ 100
Gateway IP address (2719)	→ 103
IP address domain name server (2720)	→ 104

WLAN**Navigation**

Expert → Communication → WLAN settings → WLAN (2702)

Description

Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting

Enable

WLAN mode



Navigation

Expert → Communication → WLAN settings → WLAN mode (2717)

Description

Use this function to select the WLAN mode.

Selection

WLAN access point

Factory setting

WLAN access point

SSID name



Navigation

Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite

The client is activated.

Description

Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry

–

Factory setting

–

Network security



Navigation

Expert → Communication → WLAN settings → Network security (2705)

Description

Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting

WPA2-PSK

* Visibility depends on order options or device settings

Additional information*Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.

Security identification

Navigation  Expert → Communication → WLAN settings → Sec. identific. (2718)**Description**

Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

User interface

- Trusted issuer certificate
- Device certificate
- Device private key

User name

**Navigation**  Expert → Communication → WLAN settings → User name (2715)**Description**

Use this function to enter the username of the WLAN network.

User entry

–

Factory setting

–

WLAN password

**Navigation**  Expert → Communication → WLAN settings → WLAN password (2716)**Description**

Use this function to enter the WLAN password for the WLAN network.

User entry

–

Factory setting

–

WLAN IP address

**Navigation**  Expert → Communication → WLAN settings → WLAN IP address (2711)**Description**

Use this function to enter the IP address of the measuring device's WLAN connection.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 192.168.1.212

WLAN MAC address

Navigation  Expert → Communication → WLAN settings → WLAN MAC address (2703)

Description Displays the MAC⁴⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

Factory setting Each measuring device is given an individual address.

Additional information *Example*

For the display format

00:07:05:10:01:5F

WLAN subnet mask



Navigation  Expert → Communication → WLAN settings → WLAN subnet mask (2709)

Description Use this function to enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

WLAN passphrase



Navigation  Expert → Communication → WLAN settings → WLAN passphrase (2706)

Prerequisite The **WPA2-PSK** option is selected in the **Security type** parameter (→  99).

Description Use this function to enter the network key.

User entry 8 to 32-digit character string comprising numbers, letters and special characters (without spaces)

Factory setting Serial number of the measuring device (e.g. L100A802000)

4) Media Access Control

Assign SSID name

Navigation Expert → Communication → WLAN settings → Assign SSID name (2708)

Description Use this function to select which name is used for the SSID⁵⁾.

Selection

- Device tag
- User-defined

Factory setting User-defined

Additional information *Selection*

- Device tag
The device tag name is used as the SSID.
- User-defined
A user-defined name is used as the SSID.

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2707)

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (→ 102).
- The **WLAN access point** option is selected in the **WLAN mode** parameter (→ 99).

Description Use this function to enter a user-defined SSID name.

User entry Max. 32-digit character string comprising numbers, letters and special characters

Factory setting

2.4 GHz WLAN channel

Navigation Expert → Communication → WLAN settings → WLAN channel (2704)

Description Use this function to enter the 2.4 GHz WLAN channel.

User entry 1 to 11

Factory setting 6

Additional information *Description*



- It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.
- If just one measuring device is in use, it is recommended to keep the factory setting.

5) Service Set Identifier

Select antenna

Navigation Expert → Communication → WLAN settings → Select antenna (2713)

Description Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting Internal antenna

Connection state

Navigation Expert → Communication → WLAN settings → Connection state (2722)

Description The connection status is displayed.

User interface

- Connected
- Not connected

Factory setting Not connected

Received signal strength

Navigation Expert → Communication → WLAN settings → Rec.sig.strength (2721)

Description Displays the signal strength received.

User interface

- Low
- Medium
- High

Factory setting High

Gateway IP address

Navigation Expert → Communication → WLAN settings → Gateway IP addr. (2719)


Description Use this function to enter the IP address of the gateway.

User interface Character string comprising numbers, letters and special characters

Factory setting 192.168.1.212

IP address domain name server

Navigation	 Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212

3.4 "Application" submenuNavigation  Expert → Application**Reset all totalizers**Navigation  Expert → Application → Reset all tot. (2806)


Description	Use this function to reset all totalizers to the value 0 and restart the totaling process. This deletes all the flow values previously totalized.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Reset + totalize
Factory setting	Cancel
Additional information	<i>Selection</i>

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.4.1 "Totalizer 1 to n" submenu

Navigation

Expert → Application → Totalizer 1 to n



Assign process variable



Navigation

Expert → Application → Totalizer 1 to n → Assign variable (0914-1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

Additional information

Description

If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only the **Assign process variable** parameter (→ 105) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Unit totalizer 1 to n



Navigation

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 105) of the **Totalizer 1 to n** submenu.

Description Use this function to select the process variable unit for the Totalizer 1 to n (→  105).

Selection

- | | |
|--|--|
| <i>SI units</i>
<input type="checkbox"/> g *
<input type="checkbox"/> kg *
<input type="checkbox"/> t | <i>US units</i>
<input type="checkbox"/> oz *
<input type="checkbox"/> lb *
<input type="checkbox"/> STon * |
|--|--|

* Visibility depends on order options or device settings

or

- | | | |
|--|--|---|
| <i>SI units</i>
<input type="checkbox"/> cm ³ *
<input type="checkbox"/> dm ³ *
<input type="checkbox"/> m ³ *
<input type="checkbox"/> ml *
<input type="checkbox"/> l *
<input type="checkbox"/> hl *
<input type="checkbox"/> Ml Mega * | <i>US units</i>
<input type="checkbox"/> af *
<input type="checkbox"/> ft ³ *
<input type="checkbox"/> Mft ³ *
<input type="checkbox"/> fl oz (us) *
<input type="checkbox"/> gal (us) *
<input type="checkbox"/> kgal (us) *
<input type="checkbox"/> Mgal (us) *
<input type="checkbox"/> bbl (us;liq.) *
<input type="checkbox"/> bbl (us;beer) *
<input type="checkbox"/> bbl (us;oil)
<input type="checkbox"/> bbl (us;tank) * | <i>Imperial units</i>
<input type="checkbox"/> gal (imp) *
<input type="checkbox"/> Mgal (imp) *
<input type="checkbox"/> bbl (imp;beer) *
<input type="checkbox"/> bbl (imp;oil) |
|--|--|---|

* Visibility depends on order options or device settings

or

- | | | |
|---|--|--|
| <i>SI units</i>
<input type="checkbox"/> NI *
<input type="checkbox"/> Nhl *
<input type="checkbox"/> Nm ³ *
<input type="checkbox"/> Sl *
<input type="checkbox"/> Sm ³ * | <i>US units</i>
<input type="checkbox"/> Sft ³ *
<input type="checkbox"/> MMSft ³ *
<input type="checkbox"/> Sgal (us) *
<input type="checkbox"/> Sbbl (us;liq.) *
<input type="checkbox"/> Sbbl (us;oil) | <i>Imperial units</i>
<input type="checkbox"/> Sgal (imp) * |
|---|--|--|

* Visibility depends on order options or device settings

or

Other units
None *

* Visibility depends on order options or device settings

Factory setting

Country-specific:

- l
- gal (us)

Additional information**Description**

 The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→  43).

Selection

The selection is dependent on the process variable selected in the **Assign process variable** parameter (→  105).

Totalizer operation mode**Navigation**

Expert → Application → Totalizer 1 to n → Operation mode (0908-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 105) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total

Factory setting

Net flow total

Additional information*Selection*

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 105) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize
- Hold

Factory setting

Totalize

Additional information*Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.

Options	Description
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

Preset value 1 to n

Navigation

Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 105) of the **Totalizer 1 to n** submenu.

Description

Use this function to enter a start value for the Totalizer 1 to n.

User entry

Signed floating-point number

Factory setting

0.1

Additional information

User entry

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 105).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode



Navigation

Expert → Application → Totalizer 1 to n → Failure mode (0901–1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 105) of the **Totalizer 1 to n** submenu.

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Stop

Additional information*Description*

This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

■ Stop

The totalizer is stopped in the event of a device alarm.

■ Actual value

The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored.

■ Last valid value

The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.5 "Diagnostics" submenu

Navigation

Expert → Diagnostics

► Diagnostics	
Actual diagnostics (0691)	→ 110
Previous diagnostics (0690)	→ 110
Operating time from restart (0653)	→ 111
Operating time (0652)	→ 111
► Diagnostic list	→ 112
► Event logbook	→ 116
► Device information	→ 118
► Main electronic module	→ 122
► Sensor electronic module (ISEM)	→ 123
► Display module	→ 124
► Data logging	→ 125
► Min/max values	→ 133
► Heartbeat Technology	→ 135
► Simulation	→ 135

Actual diagnostics

Navigation	  Expert → Diagnostics → Actual diagnos. (0691)
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Additional pending diagnostic messages can be viewed in the Diagnostic list submenu (→  112).  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. <i>Example</i> For the display format:  F271 Main electronics failure

Timestamp

Navigation	  Expert → Diagnostics → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Actual diagnostics parameter (→  110). <i>Example</i> For the display format: 24d12h13m00s

Previous diagnostics

Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Example

For the display format:

F271 Main electronics failure

Timestamp**Navigation**

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the last diagnostic message before the current message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Previous diagnostics** parameter
(→ 110).

Example

For the display format:

24d12h13m00s

Operating time from restart**Navigation**

Expert → Diagnostics → Time fr. restart (0653)

Description

Use this function to display the time the device has been in operation since the last device restart.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Operating time**Navigation**

Expert → Diagnostics → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)


Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.5.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

i Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 1

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*



The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 112).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

Description Displays the current diagnostics message with the second-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*



Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- AS442 Frequency output
- F276 I/O module failure

Timestamp 2

Navigation Expert → Diagnostics → Diagnostic list → Timestamp

Description Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*



The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 113).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Displays the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: ■ △S442 Frequency output ■ ✗F276 I/O module failure

Timestamp 3

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  114).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 4

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (→  114).

Example

For the display format:
24d12h13m00s

Diagnostics 5

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 5

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

Display

 The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ 115).

Example

For the display format:
24d12h13m00s


3.5.2 "Event logbook" submenu

Viewing event messages

Event messages are displayed in chronological order. The event history includes both diagnostic events and information events. The symbol in front of the timestamp indicates whether the event has started or ended.

Navigation

Expert → Diagnostics → Event logbook



Filter options



Navigation

Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection


- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting	All
Additional information	<p><i>Description</i></p> <p>i The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:</p> <ul style="list-style-type: none"> ■ F = Failure ■ C = Function Check ■ S = Out of Specification ■ M = Maintenance Required

"Event list" submenu

i The **Event list** submenu is only displayed if operating via the local display. If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module. If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation Expert → Diagnostics → Event logbook → Event list



Event list

Navigation	Expert → Diagnostics → Event logbook → Event list
Description	Displays the history of event messages of the category selected in the Filter options parameter (→ 116).
User interface	<ul style="list-style-type: none"> ■ For a "Category I" event message Information event, short message, symbol for event recording and operating time when error occurred ■ For a "Category F, C, S, M" event message (status signal) Diagnostics code, short message, symbol for event recording and operating time when error occurred
Additional information	<p><i>Description</i></p> <p>A maximum of 20 event messages are displayed in chronological order.</p>

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊖: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ΔS442 Frequency output
⊖ 01d04h12min30s

 Additional information, such as remedial measures, can be retrieved via the  key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **Extended HistoROM** application package, see the "Application packages" section of the "Technical Information" document

3.5.3 "Device information" submenu

Navigation

 Expert → Diagnostics → Device info

► Device information	
Device tag (0011)	→  119
Serial number (0009)	→  119
Firmware version (0010)	→  119
Device name (0013)	→  120
Order code (0008)	→  120
Extended order code 1 (0023)	→  120
Extended order code 2 (0021)	→  121
Extended order code 3 (0022)	→  121
Configuration counter (2751)	→  121
ENP version (0012)	→  121

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag

Additional information

User interface



1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation

Expert → Diagnostics → Device info → Serial number (0009)

Description

Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information

Description

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation

Expert → Diagnostics → Device info → Firmware version (0010)

Description

Displays the device firmware version installed.

User interface

Character string in the format xx.yy.zz

Additional information*Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name**Navigation**

Expert → Diagnostics → Device info → Device name (0013)

Description

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface

Max. 32 characters such as letters or numbers.

Factory setting

Promag 400 EIP

Order code**Navigation**

Expert → Diagnostics → Device info → Order code (0008)

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.



The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 120)

Extended order code 3**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 120)

Configuration counter**Navigation**

Expert → Diagnostics → Device info → Config. counter (2751)

Description

Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface

0 to 65 535

ENP version**Navigation**

Expert → Diagnostics → Device info → ENP version (0012)

Description

Displays the version of the electronic nameplate.

User interface

Character string

Factory setting 2.02.00


Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.5.4 "Main electronic module + I/O module 1" submenu

Navigation

Expert → Diagnostics → Mainboard module



Firmware version

Navigation

Expert → Diagnostics → Main elec. mod. → Firmware version (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. software

Navigation

Expert → Diagnostics → Main elec. mod. → Build no. softw. (0079)

Description

Use this function to display the software build number of the module.

User interface

Positive integer

Bootloader revision

Navigation

Expert → Diagnostics → Main elec. mod. → Bootloader rev. (0073)

Description


Use this function to display the bootloader revision of the software.

User interface Positive integer

3.5.5 "Sensor electronic module (ISEM)" submenu

Navigation

Expert → Diagnostics → Sens. electronic



Firmware version

Navigation Expert → Diagnostics → Sens. electronic → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.5.6 "Display module" submenu

Navigation

Expert → Diagnostics → Display module



Firmware version

Navigation

Expert → Diagnostics → Display module → Firmware version (0072)

Description

Use this function to display the software revision of the module.

User interface

Positive integer

Build no. software

Navigation

Expert → Diagnostics → Display module → Build no. softw. (0079)

Description

Use this function to display the software build number of the module.

User interface

Positive integer

Bootloader revision

Navigation

Expert → Diagnostics → Display module → Bootloader rev. (0073)

Description

Use this function to display the bootloader revision of the software.

User interface

Positive integer

3.5.7 "Data logging" submenu

Navigation

Expert → Diagnostics → Data logging

▶ Data logging	
Assign channel 1	→ 125
Assign channel 2	→ 126
Assign channel 3	→ 127
Assign channel 4	→ 127
Logging interval	→ 127
Clear logging data	→ 128
Data logging	→ 128
Logging delay	→ 129
Data logging control	→ 129
Data logging status	→ 130
Entire logging duration	→ 130
▶ Display channel 1	→ 130
▶ Display channel 2	→ 131
▶ Display channel 3	→ 132
▶ Display channel 4	→ 132

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

Description

Use this function to assign a process variable to the logging channel.

Selection	<ul style="list-style-type: none"> ▪ Off ▪ Volume flow ▪ Mass flow ▪ Corrected volume flow ▪ Flow velocity* ▪ Conductivity* ▪ Corrected conductivity* ▪ Temperature ▪ Electronics temperature ▪ Noise* ▪ Coil current shot time* ▪ Reference electrode potential against PE* ▪ Build-up index ▪ Test point 1 ▪ Test point 2 ▪ Test point 3
Factory setting	Off
Additional information	<p><i>Description</i></p> <p>A total of 1000 measured values can be logged. This means:</p> <ul style="list-style-type: none"> ▪ 1000 data points if 1 logging channel is used ▪ 500 data points if 2 logging channels are used ▪ 333 data points if 3 logging channels are used ▪ 250 data points if 4 logging channels are used <p>Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).</p> <p> The log contents are cleared if the option selected is changed.</p>

Assign channel 2	
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)
Prerequisite	The Extended HistoROM application package is available.
	 The software options currently enabled are displayed in the Software option overview parameter (→  38).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→  125)
Factory setting	Off

* Visibility depends on order options or device settings

Assign channel 3

Navigation	Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 38).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→ 125)
Factory setting	Off

Assign channel 4

Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 38).
Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→ 125)
Factory setting	Off

Logging interval

Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 38).
Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	0.1 to 3 600.0 s
Factory setting	1.0 s

Additional information*Description*

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

 The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data**Navigation**

 Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  38).

Description

Use this function to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information*Options*

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

Data logging**Navigation**

 Expert → Diagnostics → Data logging → Data logging (0860)

Description

Use this function to select the data logging method.

Selection

- Overwriting
- Not overwriting

Factory setting	Overwriting
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">▪ Overwriting The device memory applies the FIFO principle.▪ Not overwriting Data logging is canceled if the measured value memory is full (single shot).

Logging delay



Navigation	Expert → Diagnostics → Data logging → Logging delay (0859)
Prerequisite	In the Data logging parameter (→ 128), the Not overwriting option is selected.
Description	Use this function to enter the time delay for measured value logging.
User entry	0 to 999 h
Factory setting	0 h
Additional information	<p><i>Description</i></p> <p>Once measured value logging has been started with the Data logging control parameter (→ 129), the device does not log any data for the duration of the time delay entered.</p>

Data logging control



Navigation	Expert → Diagnostics → Data logging → Data log.control (0857)
Prerequisite	In the Data logging parameter (→ 128), the Not overwriting option is selected.
Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none">▪ None▪ Delete + start▪ Stop
Factory setting	None
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">▪ None Initial measured value logging status.▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again.▪ Stop Measured value logging is stopped.

Data logging status

Navigation  Expert → Diagnostics → Data logging → Data log. status (0858)

Prerequisite In the **Data logging** parameter (→ 128), the **Not overwriting** option is selected.

Description Displays the measured value logging status.

User interface

- Done
- Delay active
- Active
- Stopped

Factory setting Done

Additional information *Options*

- Done
Measured value logging has been performed and completed successfully.
- Delay active
Measured value logging has been started but the logging interval has not yet elapsed.
- Active
The logging interval has elapsed and measured value logging is active.
- Stopped
Measured value logging is stopped.

Entire logging duration

Navigation  Expert → Diagnostics → Data logging → Logging duration (0861)

Prerequisite In the **Data logging** parameter (→ 128), the **Not overwriting** option is selected.

Description Displays the total logging duration.

User interface Positive floating-point number

Factory setting 0 s

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation

Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

In the **Assign channel 1** parameter (→ 125), one of the following options is selected:


- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature
- Electronics temperature

Description

Displays the measured value history for the logging channel in the form of a diagram.

Additional information

Description



2 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation

Expert → Diagnostics → Data logging → Displ.channel 2



* Visibility depends on order options or device settings

Display channel 2

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 2
Prerequisite	A process variable is determined in the Assign channel 2 parameter.
Description	See the Display channel 1 parameter

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3




Display channel 3

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 3
Prerequisite	A process variable is determined in the Assign channel 3 parameter.
Description	See the Display channel 1 parameter

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4


Navigation	 Expert → Diagnostics → Data logging → Displ.channel 4
Prerequisite	A process variable is determined in the Assign channel 4 parameter.

Description	See the Display channel 1 parameter
--------------------	--

3.5.8 "Min/max values" submenu

Navigation


Expert → Diagnostics → Min/max val.



"Main electronics temperature" submenu

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp.



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (6547)

Description

Displays the lowest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ 47)

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (6545)

Description

Displays the highest previously measured temperature value of the main electronics module.


User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [47](#))

"Medium temperature" submenu

Navigation  Expert → Diagnostics → Min/max val. → Medium temp.



Minimum value

Navigation  Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (6681)

Description Displays the lowest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [47](#))

Maximum value

Navigation  Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (6680)

Description Displays the highest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [47](#))

3.5.9 "Heartbeat" submenu



For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → [7](#)

Navigation



Expert → Diagnostics → HBT

► Heartbeat Technology

3.5.10 "Simulation" submenu

Navigation



Expert → Diagnostics → Simulation

► Simulation

Assign simulation process variable
(1810)

→ [135](#)

Process variable value (1811)

→ [136](#)

Device alarm simulation (0654)

→ [136](#)

Diagnostic event category (0738)

→ [136](#)

Diagnostic event simulation (0737)

→ [137](#)

Assign simulation process variable



Navigation



Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature*

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Description*

The simulation value of the process variable selected is defined in the **Process variable value** parameter (→ 136).

Process variable value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

A process variable is selected in the **Assign simulation process variable** parameter (→ 135).

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Device alarm simulation**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category**Navigation**

Expert → Diagnostics → Simulation → Event category (0738)

Description

Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (→ 137).

Selection	<ul style="list-style-type: none">■ Sensor■ Electronics■ Configuration■ Process
------------------	--

Factory setting	Process
------------------------	---------

Diagnostic event simulation



Navigation	Expert → Diagnostics → Simulation → Diag. event sim. (0737)
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	<ul style="list-style-type: none">■ Off■ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 136).</p>

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h option
Volume	m ³ option
Conductivity	µS/cm
Temperature	°C option
Mass flow	kg/h option
Mass	kg option
Density	kg/l option

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
150	150
200	300
250	500
300	750
350	1000
375	1200
400	1200
500	2 000
600	2 500
700	3 500
750	4 000
800	4 500

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
900	6000
1000	7000
1200	10000
1400	14000
1600	18000
1800	23000
2000	28500
2200	34000
2400	40000
2600	48000
2800	55500
3000	63500

4.1.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	(v ~ 0.04 m/s) [dm ³ /min]
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
150	2.5
200	5
250	7.5
300	10
350	15
375	20
400	20
450	25
500	30
600	40
700	50
750	60
800	75

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
900	100
1000	125
1200	150
1400	225
1600	300
1800	350
2000	450
2200	540
2400	650
2600	775
2800	875
3000	1025

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us) option
Volume	gal (us) option
Temperature	°F option
Mass flow	lb/min option
Mass	lb option
Density	lb/ft ³ option

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1	18
1½	50
2	75
3	200
4	300
6	600
8	1200
10	1500
12	2400
14	3600
15	4800

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
16	4800
18	6000
20	7500
24	10500
28	13500
30	16500
32	19500
36	24000
40	30000
42	33000
48	42000

Nominal diameter [in]	(v ~ 2.5 m/s) [Mgal/d]
54	75
60	95
66	120
72	140
78	175
84	190
90	220
96	265
102	300
108	340
114	375
120	415

4.2.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1	0.25
1½	0.75
2	1.25
3	2.5
4	4
6	12
8	15
10	30
12	45
14	60

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
15	60
16	60
18	90
20	120
24	180
28	210
30	270
32	300
36	360
40	480
42	600
48	600

Nominal diameter [in]	(v ~ 0.04 m/s) [Mgal/d]
54	1.3
60	1.3
66	2.2
72	2.6
78	3.0
84	3.2
90	3.6
96	4.0
102	5.0
108	5.0
114	6.0
120	7.0

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano-, Micro-, Milli-, Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro-, Milli-, Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
	Ml/s, Ml/min, Ml/h, Ml/d	Megaliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot

Process variable	Units	Explanation
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon (us)
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

- 0% bargraph value 1 (Parameter) 17
- 0% bargraph value 3 (Parameter) 20
- 2.4 GHz WLAN channel (Parameter) 102
- 100% bargraph value 1 (Parameter) 18
- 100% bargraph value 3 (Parameter) 21

A

- Access status display (Parameter) 11, 25
- Activate SW option (Parameter) 37
- Actual diagnostics (Parameter) 110
- Administration (Submenu) 33
- Alarm delay (Parameter) 26
- Application (Submenu) 104
- Assign behavior of diagnostic no. 043 (Parameter) 28
- Assign behavior of diagnostic no. 302 (Parameter) 28
- Assign behavior of diagnostic no. 376 (Parameter) 29
- Assign behavior of diagnostic no. 377 (Parameter) 29
- Assign behavior of diagnostic no. 531 (Parameter) 29
- Assign behavior of diagnostic no. 832 (Parameter) 30
- Assign behavior of diagnostic no. 833 (Parameter) 30
- Assign behavior of diagnostic no. 834 (Parameter) 31
- Assign behavior of diagnostic no. 835 (Parameter) 31
- Assign behavior of diagnostic no. 842 (Parameter) 31
- Assign behavior of diagnostic no. 937 (Parameter) 32
- Assign behavior of diagnostic no. 938 (Parameter) 32
- Assign behavior of diagnostic no. 961 (Parameter) 33
- Assign behavior of diagnostic no. 962 (Parameter) 32
- Assign channel 1 (Parameter) 125
- Assign channel 2 (Parameter) 126
- Assign channel 3 (Parameter) 127
- Assign channel 4 (Parameter) 127
- Assign process variable (Parameter) 57, 60, 105
- Assign simulation process variable (Parameter) 135
- Assign SSID name (Parameter) 102

B

- Backlight (Parameter) 25
- Bootloader revision (Parameter) 123, 124
- Build no. software (Parameter) 123, 124
- Build-up detection (Submenu) 64

C

- Calibration (Submenu) 76
- Calibration factor (Parameter) 77
- Capability flags (Parameter) 82
- Clear logging data (Parameter) 128
- Communication (Submenu) 78
- Conductivity (Parameter) 40
- Conductivity calibration factor (Parameter) 77
- Conductivity damping (Parameter) 55
- Conductivity factor (Parameter) 73
- Conductivity measurement (Parameter) 55
- Conductivity offset (Parameter) 73
- Conductivity temperature coefficient (Parameter) 56
- Conductivity unit (Parameter) 46

- Configurable input assembly (Submenu) 82
- Configurable input assembly 121 (Submenu) 89
- Configuration (Submenu) 78
- Configuration counter (Parameter) 121
- Confirm access code (Parameter) 34
- Connection state (Parameter) 103
- Contrast display (Parameter) 25
- Control Totalizer 1 to n (Parameter) 107
- Corrected conductivity (Parameter) 41
- Corrected conductivity factor (Parameter) 75
- Corrected conductivity offset (Parameter) 75
- Corrected volume flow (Parameter) 40
- Corrected volume flow factor (Parameter) 74
- Corrected volume flow offset (Parameter) 73
- Corrected volume flow unit (Parameter) 50
- Corrected volume unit (Parameter) 50

D

- Data logging (Parameter) 128
- Data logging (Submenu) 125
- Data logging control (Parameter) 129
- Data logging status (Parameter) 130
- Date/time format (Parameter) 51
- Decimal places 1 (Parameter) 18
- Decimal places 2 (Parameter) 19
- Decimal places 3 (Parameter) 21
- Decimal places 4 (Parameter) 22
- Default gateway (Parameter) 81
- Define access code (Parameter) 34, 36
- Define access code (Wizard) 33
- Density (Parameter) 41
- Density source (Parameter) 67
- Density unit (Parameter) 49
- Device alarm simulation (Parameter) 136
- Device information (Submenu) 118
- Device name (Parameter) 120
- Device reset (Parameter) 36
- Device tag (Parameter) 119
- DHCP client (Parameter) 80
- Diagnostic behavior (Submenu) 27
- Diagnostic event category (Parameter) 136
- Diagnostic event simulation (Parameter) 137
- Diagnostic handling (Submenu) 26
- Diagnostic list (Submenu) 112
- Diagnostics (Submenu) 109
- Diagnostics 1 (Parameter) 112
- Diagnostics 2 (Parameter) 113
- Diagnostics 3 (Parameter) 114
- Diagnostics 4 (Parameter) 114
- Diagnostics 5 (Parameter) 115
- Direct access
- 0% bargraph value 1 (0123) 17
- 0% bargraph value 3 (0124) 20
- 2.4 GHz WLAN channel (2704) 102
- 100% bargraph value 1 (0125) 18
- 100% bargraph value 3 (0126) 21

Access status display (0091)	11, 25	Decimal places 2 (0117)	19
Activate SW option (0029)	37	Decimal places 3 (0118)	21
Actual diagnostics (0691)	110	Decimal places 4 (0119)	22
Alarm delay (0651)	26	Default gateway (7210)	81
Assign behavior of diagnostic no. 043 (0650)	28	Define access code	36
Assign behavior of diagnostic no. 302 (0739)	28	Density (1857)	41
Assign behavior of diagnostic no. 376 (0645)	29	Density source (6615)	67
Assign behavior of diagnostic no. 377 (0777)	29	Density unit (0555)	49
Assign behavior of diagnostic no. 531 (0741)	29	Device alarm simulation (0654)	136
Assign behavior of diagnostic no. 832 (0681)	30	Device name (0013)	120
Assign behavior of diagnostic no. 833 (0682)	30	Device reset (0000)	36
Assign behavior of diagnostic no. 834 (0700)	31	Device tag (0011)	119
Assign behavior of diagnostic no. 835 (0702)	31	DHCP client (7212)	80
Assign behavior of diagnostic no. 842 (0638)	31	Diagnostic event category (0738)	136
Assign behavior of diagnostic no. 937 (0743)	32	Diagnostic event simulation (0737)	137
Assign behavior of diagnostic no. 938 (0642)	32	Diagnostics 1 (0692)	112
Assign behavior of diagnostic no. 961 (0736)	33	Diagnostics 2 (0693)	113
Assign behavior of diagnostic no. 962 (0745)	32	Diagnostics 3 (0694)	114
Assign channel 1 (0851)	125	Diagnostics 4 (0695)	114
Assign channel 2 (0852)	126	Diagnostics 5 (0696)	115
Assign channel 3 (0853)	127	Direct access (0106)	10
Assign channel 4 (0854)	127	Display damping (0094)	23
Assign process variable		Display interval (0096)	22
Totalizer 1 to n (0914-1 to n)	105	Display language (0104)	14
Assign process variable (1837)	57	ECC duration (6555)	63
Assign process variable (1860)	60	ECC interval (6557)	64
Assign simulation process variable (1810)	135	ECC polarity (6631)	64
Assign SSID name (2708)	102	ECC recovery time (6556)	63
Backlight (0111)	25	Electrode cleaning cycle (6528)	63
Bootloader revision (0073)	123, 124	Empty pipe adjust value (6527)	61
Build no. software (0079)	123, 124	ENP version (0012)	121
Calibration factor (6522)	77	Enter access code (0003)	12
Capability flags (7439)	82	Entire logging duration (0861)	130
Clear logging data (0855)	128	Extended order code 1 (0023)	120
Conductivity (1850)	40	Extended order code 2 (0021)	121
Conductivity calibration factor (6718)	77	Extended order code 3 (0022)	121
Conductivity damping (1803)	55	External density (6630)	67
Conductivity factor (1849)	73	External temperature (6673)	68
Conductivity measurement (6514)	55	Failure mode	
Conductivity offset (1848)	73	Totalizer 1 to n (0901-1 to n)	108
Conductivity temperature coefficient (1891)	56	Filter options (0705)	116
Conductivity unit (0582)	46	Filter options (6710)	52
Configuration counter (2751)	121	Firmware version (0010)	119
Connection state (2722)	103	Firmware version (0072)	123, 124
Contrast display (0105)	25	Fixed density (6623)	68
Control Totalizer 1 to n (0912-1 to n)	107	Flow damping (6661)	54
Corrected conductivity (1853)	41	Flow override (1839)	54
Corrected conductivity factor (1871)	75	Flow velocity (1854)	40
Corrected conductivity offset (1870)	75	Flow velocity factor (1880)	76
Corrected volume flow (1851)	40	Flow velocity offset (1879)	75
Corrected volume flow factor (1867)	74	Format display (0098)	15
Corrected volume flow offset (1866)	73	Full pipe adjust value (6548)	62
Corrected volume flow unit (0558)	50	Gateway IP address (2719)	103
Corrected volume unit (0575)	50	Hardware address mode (7401)	79
Data logging (0860)	128	Header (0097)	23
Data logging control (0857)	129	Header text (0112)	24
Data logging status (0858)	130	Input assembly position 1 (7434)	90
Date/time format (2812)	51	Input assembly position 2 (7435)	90
Decimal places 1 (0095)	18	Input assembly position 3 (7436)	91

Input assembly position 4 (7437)	91
Input assembly position 5 (7438)	92
Input assembly position 6 (7440)	92
Input assembly position 7 (7441)	93
Input assembly position 8 (7442)	94
Input assembly position 9 (7443)	94
Input assembly position 10 (7444)	95
Input assembly position 11 (7445)	95
Input assembly position 12 (7446)	96
Input assembly position 13 (7447)	96
Input assembly position 14 (7448)	97
Input assembly position 15 (7449)	97
Installation direction (1809)	70
Integration time (6533)	70
IP address (7209)	80
IP address domain name server (2720)	104
Locking status (0004)	11
Logging delay (0859)	129
Logging interval (0856)	127
Login page (7273)	82
MAC address (7214)	79
Mass flow (1847)	40
Mass flow factor (1846)	72
Mass flow offset (1841)	72
Mass flow unit (0554)	48
Mass unit (0574)	48
Maximum value (6545)	133
Maximum value (6680)	134
Measured value EPD (6559)	62
Measuring period (6536)	70
Minimum value (6547)	133
Minimum value (6681)	134
Network security (2705)	99
New adjustment (6560)	61
Nominal diameter (2807)	76
Off value low flow cutoff (1804)	58
On value low flow cutoff (1805)	57
Operating time (0652)	35, 111
Operating time from restart (0653)	111
Order code (0008)	120
Preset value 1 to n (0913–1 to n)	108
Pressure shock suppression (1806)	58
Previous diagnostics (0690)	110
Process variable value (1811)	136
Progress (6571)	61
Received signal strength (2721)	103
Reference density (1885)	56
Reference temperature (1816)	69
Reset access code (0024)	35
Reset all totalizers (2806)	104
Response time empty pipe detection (1859)	60
Security identification (2718)	100
Select antenna (2713)	103
Separator (0101)	25
Serial number (0009)	119
Software option overview (0015)	38
SSID name (2707)	102
SSID name (2714)	99
Subnet mask (7211)	81
Switch point empty pipe detection (6562)	60
Temperature (1852)	41
Temperature damping (1886)	56
Temperature factor (1869)	74
Temperature offset (1868)	74
Temperature source (6712)	68
Temperature unit (0557)	47
Timestamp	110, 111, 112, 113, 114, 115, 116
Totalizer operation mode	
Totalizer 1 to n (0908–1 to n)	107
Totalizer overflow 1 to n (0910–1 to n)	43
Totalizer value 1 to n (0911–1 to n)	42
Unit totalizer 1 to n (0915–1 to n)	105
User description (7432)	82
User name (2715)	100
User role (0005)	12
Value 1 display (0107)	17
Value 2 display (0108)	19
Value 3 display (0110)	20
Value 4 display (0109)	21
Volume flow (1838)	39
Volume flow factor (1832)	71
Volume flow offset (1831)	72
Volume flow unit (0553)	44
Volume unit (0563)	46
Web server functionality (7222)	81
Web server language (7221)	78
WLAN (2702)	98
WLAN IP address (2711)	100
WLAN MAC address (2703)	101
WLAN mode (2717)	99
WLAN passphrase (2706)	101
WLAN password (2716)	100
WLAN subnet mask (2709)	101
Zero point (6546)	77
Direct access (Parameter)	10
Display (Submenu)	13
Display channel 1 (Submenu)	130
Display channel 2 (Submenu)	131
Display channel 3 (Submenu)	132
Display channel 4 (Submenu)	132
Display damping (Parameter)	23
Display interval (Parameter)	22
Display language (Parameter)	14
Display module (Submenu)	124
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4
Document function	4
E	
ECC duration (Parameter)	63
ECC interval (Parameter)	64
ECC polarity (Parameter)	64

ECC recovery time (Parameter)	63
Electrode cleaning circuit (Submenu)	62
Electrode cleaning cycle (Parameter)	63
Empty pipe adjust value (Parameter)	61
Empty pipe detection (Submenu)	59
ENP version (Parameter)	121
Enter access code (Parameter)	12
Entire logging duration (Parameter)	130
Event list (Submenu)	117
Event logbook (Submenu)	116
Extended order code 1 (Parameter)	120
Extended order code 2 (Parameter)	121
Extended order code 3 (Parameter)	121
External compensation (Submenu)	67
External density (Parameter)	67
External temperature (Parameter)	68

F

Factory settings	138
SI units	138
US units	140
Failure mode (Parameter)	108
Filter options (Parameter)	52, 116
Firmware version (Parameter)	119, 123, 124
Fixed density (Parameter)	68
Flow damping (Parameter)	54
Flow override (Parameter)	54
Flow velocity (Parameter)	40
Flow velocity factor (Parameter)	76
Flow velocity offset (Parameter)	75
Format display (Parameter)	15
Full pipe adjust value (Parameter)	62
Function see Parameter	

G

Gateway IP address (Parameter)	103
--	-----

H

Hardware address mode (Parameter)	79
Header (Parameter)	23
Header text (Parameter)	24
Heartbeat Technology (Submenu)	135

I

Input assembly position 1 (Parameter)	90
Input assembly position 2 (Parameter)	90
Input assembly position 3 (Parameter)	91
Input assembly position 4 (Parameter)	91
Input assembly position 5 (Parameter)	92
Input assembly position 6 (Parameter)	92
Input assembly position 7 (Parameter)	93
Input assembly position 8 (Parameter)	94
Input assembly position 9 (Parameter)	94
Input assembly position 10 (Parameter)	95
Input assembly position 11 (Parameter)	95
Input assembly position 12 (Parameter)	96
Input assembly position 13 (Parameter)	96
Input assembly position 14 (Parameter)	97
Input assembly position 15 (Parameter)	97

Installation direction (Parameter)	70
Integration time (Parameter)	70
IP address (Parameter)	80
IP address domain name server (Parameter)	104

L

Locking status (Parameter)	11
Logging delay (Parameter)	129
Logging interval (Parameter)	127
Login page (Parameter)	82
Low flow cut off (Submenu)	57

M

MAC address (Parameter)	79
Main electronics temperature (Submenu)	133
Mainboard module (Submenu)	122
Mass flow (Parameter)	40
Mass flow factor (Parameter)	72
Mass flow offset (Parameter)	72
Mass flow unit (Parameter)	48
Mass unit (Parameter)	48
Maximum value (Parameter)	133, 134
Measured value EPD (Parameter)	62
Measured values (Submenu)	39
Measuring period (Parameter)	70
Medium temperature (Submenu)	134
Min/max values (Submenu)	133
Minimum value (Parameter)	133, 134

N

Network security (Parameter)	99
New adjustment (Parameter)	61
Nominal diameter (Parameter)	76

O

Off value low flow cutoff (Parameter)	58
On value low flow cutoff (Parameter)	57
Operating time (Parameter)	35, 111
Operating time from restart (Parameter)	111
Order code (Parameter)	120

P

Parameter Structure of a parameter description	6
Preset value 1 to n (Parameter)	108
Pressure shock suppression (Parameter)	58
Previous diagnostics (Parameter)	110
Process parameters (Submenu)	51
Process variable adjustment (Submenu)	70
Process variable value (Parameter)	136
Process variables (Submenu)	39
Progress (Parameter)	61

R

Received signal strength (Parameter)	103
Reference density (Parameter)	56
Reference temperature (Parameter)	69
Reset access code (Parameter)	35
Reset access code (Submenu)	34
Reset all totalizers (Parameter)	104

Response time empty pipe detection (Parameter)	60
S	
Security identification (Parameter)	100
Select antenna (Parameter)	103
Sensor (Submenu)	38
Sensor adjustment (Submenu)	69
Sensor electronic module (ISEM) (Submenu)	123
Separator (Parameter)	25
Serial number (Parameter)	119
Simulation (Submenu)	135
Software option overview (Parameter)	38
SSID name (Parameter)	99, 102
Submenu	
Administration	33
Application	104
Build-up detection	64
Calibration	76
Communication	78
Configurable input assembly	82
Configurable input assembly 121	89
Configuration	78
Data logging	125
Device information	118
Diagnostic behavior	27
Diagnostic handling	26
Diagnostic list	112
Diagnostics	109
Display	13
Display channel 1	130
Display channel 2	131
Display channel 3	132
Display channel 4	132
Display module	124
Electrode cleaning circuit	62
Empty pipe detection	59
Event list	117
Event logbook	116
External compensation	67
Heartbeat Technology	135
Low flow cut off	57
Main electronics temperature	133
Mainboard module	122
Measured values	39
Medium temperature	134
Min/max values	133
Process parameters	51
Process variable adjustment	70
Process variables	39
Reset access code	34
Sensor	38
Sensor adjustment	69
Sensor electronic module (ISEM)	123
Simulation	135
System	13
System units	43
Totalizer	42
Totalizer 1 to n	105
Subnet mask (Parameter)	81

Switch point empty pipe detection (Parameter)	60
System (Submenu)	13
System units (Submenu)	43

T

Target group	4
Temperature (Parameter)	41
Temperature damping (Parameter)	56
Temperature factor (Parameter)	74
Temperature offset (Parameter)	74
Temperature source (Parameter)	68
Temperature unit (Parameter)	47
Timestamp (Parameter)	110, 111, 112, 113, 114, 115, 116
Totalizer (Submenu)	42
Totalizer 1 to n (Submenu)	105
Totalizer operation mode (Parameter)	107
Totalizer overflow 1 to n (Parameter)	43
Totalizer value 1 to n (Parameter)	42

U

Unit totalizer 1 to n (Parameter)	105
User description (Parameter)	82
User name (Parameter)	100
User role (Parameter)	12

V

Value 1 display (Parameter)	17
Value 2 display (Parameter)	19
Value 3 display (Parameter)	20
Value 4 display (Parameter)	21
Volume flow (Parameter)	39
Volume flow factor (Parameter)	71
Volume flow offset (Parameter)	72
Volume flow unit (Parameter)	44
Volume unit (Parameter)	46

W

Web server functionality (Parameter)	81
Web server language (Parameter)	78
Wizard	
Define access code	33
WLAN settings	97
WLAN (Parameter)	98
WLAN IP address (Parameter)	100
WLAN MAC address (Parameter)	101
WLAN mode (Parameter)	99
WLAN passphrase (Parameter)	101
WLAN password (Parameter)	100
WLAN settings (Wizard)	97
WLAN subnet mask (Parameter)	101

Z

Zero point (Parameter)	77
----------------------------------	----



71541969

www.addresses.endress.com
