

Description of Device Parameters

Proline Promag 400

Modbus RS485

Electromagnetic flowmeter




Table of contents

1 About this document	4		
1.1 Document function	4	3.6.8 "Data logging" submenu	150
1.2 Target group	4	3.6.9 "Min/max values" submenu	158
1.3 Using this document	4	3.6.10 "Heartbeat" submenu	160
1.3.1 Information on the document structure	4	3.6.11 "Simulation" submenu	160
1.4 Symbols used	6		
1.4.1 Symbols for certain types of information	6	4 Country-specific factory settings ..	167
1.4.2 Symbols in graphics	7	4.1 SI units	167
1.5 Documentation	7	4.1.1 System units	167
1.5.1 Standard documentation	7	4.1.2 Full scale values	167
1.5.2 Supplementary device-dependent documentation	7	4.1.3 Switch-on point low flow cut off	168
2 Overview of the Expert operating menu	8	4.2 US units	169
3 Description of Device Parameters ...	10	4.2.1 System units	169
3.1 "System" submenu	13	4.2.2 Full scale values	169
3.1.1 "Display" submenu	13	4.2.3 Switch-on point low flow cut off	170
3.1.2 "Diagnostic handling" submenu	26		
3.1.3 "Administration" submenu	34		
3.2 "Sensor" submenu	40	5 Explanation of abbreviated units ..	172
3.2.1 "Measured values" submenu	40	5.1 SI units	172
3.2.2 "System units" submenu	47	5.2 US units	172
3.2.3 "Process parameters" submenu	55	5.3 Imperial units	173
3.2.4 "External compensation" submenu	71		
3.2.5 "Sensor adjustment" submenu	73		
3.2.6 "Calibration" submenu	80	6 Modbus RS485 register information	174
3.3 "Output" submenu	81	6.1 Notes	174
3.3.1 "Current output 1" submenu	82	6.1.1 Structure of the register information	174
3.3.2 "Pulse/frequency/switch output 1 to n" submenu	94	6.1.2 Address model	174
3.4 "Communication" submenu	112	6.2 Overview of the Expert operating menu	175
3.4.1 "Modbus configuration" submenu	113	6.3 Register information	181
3.4.2 "Modbus information" submenu	117	6.3.1 "System" submenu	182
3.4.3 "Modbus data map" submenu	118	6.3.2 "Sensor" submenu	185
3.4.4 "Web server" submenu	119	6.3.3 "Communication" submenu	191
3.4.5 "WLAN settings" wizard	122	6.3.4 "Application" submenu	193
3.5 "Application" submenu	129	6.3.5 "Diagnostics" submenu	194
3.5.1 "Totalizer 1 to n" submenu	129		
3.5.2 "Custody transfer" submenu	134		
3.6 "Diagnostics" submenu	134	Index	197
3.6.1 "Diagnostic list" submenu	137		
3.6.2 "Event logbook" submenu	141		
3.6.3 "Custody transfer logbook" submenu	143		
3.6.4 "Device information" submenu	143		
3.6.5 "Main electronic module + I/O module 1" submenu	147		
3.6.6 "Sensor electronic module (ISEM)" submenu	148		
3.6.7 "Display module" submenu	149		

1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.

It is used to perform tasks that require detailed knowledge of the function of the device:

- Commissioning measurements under difficult conditions
- Optimal adaptation of the measurement to difficult conditions
- Detailed configuration of the communication interface
- Error diagnostics in difficult cases


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8), which is displayed when the "**Maintenance**" user role is enabled.



1 Sample graphic for the schematic layout of the operating menu



Additional information regarding:

- The arrangement of the parameters according to the menu structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu with a brief description: Operating Instructions → 7
- Operating concept of the operating menus: Operating Instructions → 7

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name

Write-protected parameter = 

Navigation



- Navigation path to the parameter via the local display (direct access code) or web browser
- Navigation path to the parameter via the operating tool
- The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.

Prerequisite

The parameter is only available under these specific conditions

Description

Description of the parameter function

Selection

List of the individual options for the parameter

- Option 1
- Option 2

User entry

Input range for the parameter

User interface

Display value/data for the parameter

Factory setting

Default setting ex works

Additional information

Additional explanations (e.g. in examples):

- On individual options
- On display values/data
- On the input range
- On the factory setting
- On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

1.5 Documentation

1.5.1 Standard documentation

Operating Instructions

Measuring device	Documentation code
Promag D 400	BA01229D
Promag L 400	BA01230D
Promag W 400	BA01231D

1.5.2 Supplementary device-dependent documentation

Special Documentation

Content	Documentation code
Heartbeat Verification + Monitoring application package	SD02568D
Display modules A309/A310	SD01793D
Information on Custody Transfer Measurement	SD02561D

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
User role (0005)	→ 12
Enter access code (0003)	→ 13
 System	→ 13
▶ Display	→ 13
▶ Diagnostic handling	→ 26
▶ Administration	→ 34
 Sensor	→ 40
▶ Measured values	→ 40
▶ System units	→ 47
▶ Process parameters	→ 55
▶ External compensation	→ 71
▶ Sensor adjustment	→ 73
▶ Calibration	→ 80
 Output	→ 81
▶ Current output 1	→ 82
▶ Pulse/frequency/switch output 1 to n	→ 94
 Communication	→ 112
▶ Modbus configuration	→ 113
▶ Modbus information	→ 117

▶ Modbus data map	→ 118
▶ Web server	→ 119
▶ WLAN settings	→ 122
▶ Application	→ 129
Reset all totalizers (2806)	→ 129
▶ Totalizer 1 to n	→ 129
▶ Custody transfer	→ 134
▶ Diagnostics	→ 134
Actual diagnostics (0691)	→ 135
Previous diagnostics (0690)	→ 135
Operating time from restart (0653)	→ 136
Operating time (0652)	→ 136
▶ Diagnostic list	→ 137
▶ Event logbook	→ 141
▶ Custody transfer logbook	→ 143
▶ Device information	→ 143
▶ Main electronic module	→ 147
▶ Sensor electronic module (ISEM)	→ 148
▶ Display module	→ 149
▶ Data logging	→ 150
▶ Min/max values	→ 158
▶ Heartbeat Technology	→ 160
▶ Simulation	→ 160

3 Description of Device Parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Navigation

Expert

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
User role (0005)	→ 12
Enter access code (0003)	→ 13
▶ System	→ 13
▶ Sensor	→ 40
▶ Output	→ 81
▶ Communication	→ 112
▶ Application	→ 129
▶ Diagnostics	→ 134

Direct access

Navigation

Expert → Direct access (0106)

Description


Use this function to enter the access code to enable direct access to the desired parameter via the local display. A parameter number is assigned to each parameter for this purpose.

User entry

0 to 65 535

Additional information*User entry*

The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.
Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
Example: Enter 00914 → **Assign process variable** parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.
Example: Enter 00914-2 → **Assign process variable** parameter

Locking status

Navigation

Expert → Locking status (0004)

Description

Displays the active write protection.

User interface

- Hardware locked
- CT active - defined parameters
- CT active - all parameters
- Temporarily locked

Additional information

User interface

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.

Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

Selection

Options	Description
None	The access status displayed in the Access status display parameter (→ 12) applies. Only appears on local display.
Hardware locked (priority 1)	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked (priority 2)	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status display

Navigation	  Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  13).</p> <p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

User role

Navigation	  Expert → User role (0005)
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance

Additional information*Description*

 Access authorization can be modified via the **Enter access code** parameter
→ [13](#).

 If additional write protection is active, this restricts the current access authorization even further.

User interface

 Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device → [7](#)

Enter access code**Navigation**

 Expert → Ent. access code (0003)

Description

Use this function to enter the user-specific release code to remove parameter write protection.


User entry

Max. 16-digit character string comprising numbers, letters and special characters

3.1 "System" submenu

Navigation


 Expert → System



3.1.1 "Display" submenu

Navigation

 Expert → System → Display



0% bargraph value 1 (0123)	→ 17
100% bargraph value 1 (0125)	→ 18
Decimal places 1 (0095)	→ 18
Value 2 display (0108)	→ 19
Decimal places 2 (0117)	→ 19
Value 3 display (0110)	→ 20
0% bargraph value 3 (0124)	→ 20
100% bargraph value 3 (0126)	→ 21
Decimal places 3 (0118)	→ 21
Value 4 display (0109)	→ 21
Decimal places 4 (0119)	→ 22
Display interval (0096)	→ 22
Display damping (0094)	→ 23
Header (0097)	→ 23
Header text (0112)	→ 24
Separator (0101)	→ 25
Contrast display (0105)	→ 25
Backlight (0111)	→ 25

Display language

Navigation

Expert → System → Display → Display language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch
- Français

- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ລາວ/ໄທ (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

Factory setting	English (alternatively, the ordered language is preset in the device)
------------------------	---

Format display

Navigation	 Expert → System → Display → Format display (0098)
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values
Factory setting	1 value, max. size
Additional information	<p><i>Description</i></p> <p>The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.</p> <p> ■ The Value 1 display parameter (→ 17) to Value 4 display parameter (→ 21) are used to specify which measured values are shown on the local display and in what order.</p> <p>■ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the Display interval parameter (→ 22).</p>

* Visibility depends on order options or device settings


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option




A0013098

"2 values" option




A0013100

"1 value large + 2 values" option



A0013102

"4 values" option



A0013103

Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity* ■ Conductivity* ■ Corrected conductivity* ■ Electronics temperature ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Current output 1 ■ Noise* ■ Coil current shot time* ■ Reference electrode potential against PE* ■ Build-up index* ■ Test point 1 ■ Test point 2 ■ Test point 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

0% bargraph value 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

100% bargraph value 1



Navigation	  Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 167
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

Decimal places 1



Navigation	  Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is defined in the Value 1 display parameter (→ 17).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none">■ X■ X.X■ X.XX■ X.XXX■ X.XXXX
Factory setting	X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 19).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values shown on the local display.
Selection	For the picklist, see the Value 1 display parameter (→ 17)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 47).

0% bargraph value 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 l/h ■ 0 gal/min (us)
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 47).

100% bargraph value 3

Navigation	Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	A selection was made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	0
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 47).</p>

Decimal places 3

Navigation	Expert → System → Display → Decimal places 3 (0118)
Prerequisite	A measured value is specified in the Value 3 display parameter (→ 20).
Description	Use this function to select the number of decimal places for measured value 3.
Selection	<ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX
Factory setting	X.XX
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 4 display

Navigation	Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.

Description Use this function to select one of the measured values shown on the local display.

Selection For the picklist, see the **Value 1 display** parameter (→ 17)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

Decimal places 4



Navigation Expert → System → Display → Decimal places 4 (0119)

Prerequisite A measured value is specified in the **Value 4 display** parameter (→ 21).

Description Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation Expert → System → Display → Display interval (0096)

Prerequisite A local display is provided.

Description Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ■ The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

Display damping



Navigation  Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter a time constant for the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

Use this function to enter a time constant (PT1 element¹⁾) for display damping:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

 Damping is switched off if 0 is entered (factory setting).

Header



Navigation  Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting Device tag

1) proportional transmission behavior with first order delay

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 144).
- Free text
Is defined in the **Header text** parameter (→ 24).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite

In the **Header** parameter (→ 23), the **Free text** option is selected.

Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0029422

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator

Navigation	Expert → System → Display → Separator (0101)
Prerequisite	A local display is provided.
Description	Use this function to select the decimal separator.
Selection	<ul style="list-style-type: none">■ . (point)■ , (comma)
Factory setting	. (point)

Contrast display

Navigation	Expert → System → Display → Contrast display (0105)
Prerequisite	A local display is provided.
Description	Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).
User entry	20 to 80 %
Factory setting	50 %

Backlight

Navigation	Expert → System → Display → Backlight (0111)
Prerequisite	A local display is provided.
Description	Use this function to switch the backlight of the local display on and off.
Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Enable


Access status display

Navigation	Expert → System → Display → Access stat.disp (0091)
Prerequisite	A local display is provided.

Description	Displays the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  13).</p> <p> For information about the Enter access code parameter: see the "Disabling write protection via the access code" section of the Operating Instructions for the device →  7</p> <p> If additional write protection is active, this restricts the current access authorization even further.</p> <p><i>User interface</i></p> <p> Detailed information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device →  7</p>

3.1.2 "Diagnostic handling" submenu

Navigation  Expert → System → Diagn. handling



Alarm delay



Navigation

 Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

 The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

Additional information*Result*

This setting affects the following diagnostic messages:

- 190 Special event 1
- 832 Electronics temperature too high
- 833 Electronics temperature too low
- 862 Pipe empty
- 990 Special event 4

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ [27](#)).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The measured value output via Modbus RS485 and the totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The measured value output via Modbus RS485 and the totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 141) (Event list submenu (→ 142)) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

 For a list of all the diagnostic events, see the Operating Instructions for the device
→ [7](#)

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

 **Diagnostic behavior**

Assign behavior of diagnostic no. 043 (0650)	→ 28
Assign behavior of diagnostic no. 302 (0739)	→ 29
Assign behavior of diagnostic no. 376 (0645)	→ 29
Assign behavior of diagnostic no. 377 (0777)	→ 29
Assign behavior of diagnostic no. 531 (0741)	→ 31

Assign behavior of diagnostic no. 832 (0681)	→ 31
Assign behavior of diagnostic no. 833 (0682)	→ 31
Assign behavior of diagnostic no. 834 (0700)	→ 32
Assign behavior of diagnostic no. 835 (0702)	→ 32
Assign behavior of diagnostic no. 842 (0638)	→ 33
Assign behavior of diagnostic no. 962 (0745)	→ 33
Assign behavior of diagnostic no. 937 (0743)	→ 33
Assign behavior of diagnostic no. 938 (0642)	→ 34
Assign behavior of diagnostic no. 961 (0736)	→ 34

Assign behavior of diagnostic no. 043 (Sensor short circuit)



Navigation

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 043 (0650)

Description

Use this function to change the diagnostic behavior of the **043 Sensor short circuit** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 302 (Device verification active)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302 (0739)
Description	Use this function to change the diagnostic behavior of the 302 Device verification active diagnostic message.
Selection	<ul style="list-style-type: none">▪ Alarm▪ Warning
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 376 (Sensor electronics (ISEM) faulty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 376 (0645)
Description	Use this function to change the diagnostic behavior of the 376 Sensor electronics (ISEM) faulty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 377 (Sensor electronics (ISEM) faulty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 377 (0777)
Description	Use this function to change the diagnostic behavior of the 377 Sensor electronics (ISEM) faulty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 441 (Current output 1)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)

Description

Use this function to change the diagnostic behavior of the **441 Current output 1** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 442 (Frequency output 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the **442 Frequency output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 443 (Pulse output 1 to n)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the **443 Pulse output 1 to n** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  Detailed description of the options available for selection:

Assign behavior of diagnostic no. 531 (Empty pipe detection)



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531 (0741)

Description Use this function to change the diagnostic behavior of the **531 Empty pipe detection** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  Detailed description of the options available for selection:

Assign behavior of diagnostic no. 832 (Electronics temperature too high)



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0681)

Description Use this function to change the diagnostic behavior of the **832 Electronics temperature too high** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Logbook entry only

Additional information  Detailed description of the options available for selection:

Assign behavior of diagnostic no. 833 (Electronics temperature too low)



Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0682)

Description Use this function to change the diagnostic behavior of the **833 Electronics temperature too low** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Logbook entry only

Additional information

 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 834 (Process temperature too high)**Navigation**

  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0700)

Description

Use this function to change the diagnostic behavior of the **834 Process temperature too high** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 835 (Process temperature too low)**Navigation**

  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0702)

Description

Use this function to change the diagnostic behavior of the **835 Process temperature too low** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

 Detailed description of the options available for selection:

Assign behavior of diagnostic no. 842



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 842 (0638)
Description	Change behavior of diagnostic event with diagnostic number 842 'Process limit'.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Off

Assign behavior of diagnostic no. 962 (Pipe empty)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 962 (0745)
Description	Use this function to change the diagnostic behavior of the 862 Pipe empty diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 937 (EMC interference)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937 (0743)
Description	Use this function to change the diagnostic behavior of the 937 EMC interference diagnostic message.
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	Detailed description of the options available for selection:

Assign behavior of diagnostic no. 938 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 938 (0642)

Description

Use this function to change the diagnostic behavior of the **938 EMC interference** diagnostic message.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional information

Detailed description of the options available for selection:

Assign behavior of diagnostic no. 961**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 961 (0736)

Description

Select diagnostic behavior for the selected diagnostic number.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

3.1.3 "Administration" submenu

Navigation

Expert → System → Administration

► Administration	
► Define access code	→ 35
► Reset access code	→ 36
Device reset (0000)	→ 37
Activate SW option (0029)	→ 38
Software option overview (0015)	→ 39


"Define access code" wizard

i The **Define access code** wizard (→ 35) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (→ 37) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation

Expert → System → Administration → Def. access code

**Define access code****Navigation**

Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry 0 to 9 999

Factory setting 0

Additional information *Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

i Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).

i If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting


If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code

Navigation	Expert → System → Administration → Def. access code → Confirm code
Description	Enter the defined release code a second time to confirm the release code.
User entry	0 to 9 999
Factory setting	0

"Reset access code" submenu

Navigation Expert → System → Administration → Reset acc. code

**Operating time**

Navigation	Expert → System → Administration → Reset acc. code → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

Reset access code

Navigation	Expert → System → Administration → Reset acc. code → Reset acc. code (0024)
Description	Use this function to enter a reset code to reset the user-specific access codes to the factory setting .
User entry	Character string comprising numbers, letters and special characters
Factory setting	0x00

Additional information*Description*

For a reset code, contact your Endress+Hauser service organization.

User entry

The reset code can only be entered via:

- Web browser
- DeviceCare, FieldCare (via CDI RJ45 interface)
- Fieldbus

Additional parameters in the "Administration" submenu**Define access code****Navigation**

Expert → System → Administration → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the symbol.



Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).



If you lose the access code, please contact your Endress+Hauser sales organization.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Device reset**Navigation**

Expert → System → Administration → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ To delivery settings ▪ Restart device ▪ Restore S-DAT backup *
------------------	--

Factory setting	Cancel
------------------------	--------

Activate SW option

Navigation Expert → System → Administration → Activate SW opt. (0029)

Description Use this function to enter an activation code to enable an additional, ordered software option.

User entry Max. 10-digit string consisting of numbers.

Factory setting Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- ▶ Before you enter a new activation code, make a note of the current activation code .
- ▶ Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- ▶ Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→ 39).
 - ↳ The new software option is active if it is displayed.
 - ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- ▶ If the code entered is incorrect or invalid, enter the old activation code .

* Visibility depends on order options or device settings

- ▶ Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option **EA** "Extended HistoROM"

-  The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Web browser

-  Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation

 Expert → System → Administration → SW option overv. (0015)

Description

Displays all the software options that are enabled in the device.

User interface

- Extended HistoROM
- 4-20mA,2x pulse/freq./switch output
- 4-20mA, switch/certified pulse output
- Electrode cleaning circuit
- Heartbeat Verification
- Custody transfer
- Build-up index
- Heartbeat Monitoring

Additional information

Description

Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"Electrode cleaning circuit" option

-  Only available for Promag L and W.

Order code for "Application package", option **EC** "ECC electrode cleaning"


"Heartbeat Verification" option and "Heartbeat Monitoring" option

Order code for "Application package", option **EB** "Heartbeat Verification + Monitoring"

3.2 "Sensor" submenu

Navigation


Expert → Sensor



3.2.1 "Measured values" submenu

Navigation


Expert → Sensor → Measured val.



"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.



Temperature (1852)	→ 42
Density (1857)	→ 43

Volume flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)
Description	Displays the volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Volume flow unit parameter (→ 48)

Mass flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)
Description	Displays the mass flow that is currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Mass flow unit parameter (→ 52)

Corrected volume flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1851)
Description	Displays the corrected volume flow that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Corrected volume flow unit parameter (→ 54)

Flow velocity

Navigation	  Expert → Sensor → Measured val. → Process variab. → Flow velocity (1854)
Description	Displays the flow velocity that is currently calculated.
User interface	Signed floating-point number

Conductivity

Navigation	  Expert → Sensor → Measured val. → Process variab. → Conductivity (1850)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 59).
Description	Displays the conductivity that is currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→ 50)

Corrected conductivity

Navigation	  Expert → Sensor → Measured val. → Process variab. → CorrConductivity (1853)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">▪ The On option is selected in the Conductivity measurement parameter (→ 59).▪ The Internal temperature sensor option or the External value option is selected in the Temperature source parameter (→ 72).
Description	Displays the conductivity that is currently corrected.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Conductivity unit parameter (→ 50)

Temperature

Navigation	  Expert → Sensor → Measured val. → Process variab. → Temperature (1852)
Prerequisite	The Internal temperature sensor option or the External value option is selected in the Temperature source parameter (→ 72).

Description Displays the temperature that is currently calculated.

User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [51](#))

Density

Navigation  Expert → Sensor → Measured val. → Process variab. → Density (1857)

Description Displays the current fixed density or density read in from an external device.


User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Density unit** parameter (→ [53](#))

"Totalizer" submenu

Navigation  Expert → Sensor → Measured val. → Totalizer



Totalizer value 1 to n



Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to n (0911-1 to n)

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ [130](#)) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description Displays the current totalizer counter reading.

User interface Signed floating-point number

Additional information*Description*

As the operating tool can only display a maximum of 7 digits, if the display range is exceeded the current counter reading is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to n** parameter.

-  In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 133).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 131).

-  The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 130).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m³
- Value in the **Totalizer overflow 1** parameter: $1 \cdot 10^7$ (1 overflow) = 10 000 000 m³
- Current totalizer reading: 11 968 457 m³

Totalizer overflow 1 to n**Navigation**

 Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to n (0910–1 to n)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 130) of the **Totalizer 1 to n** submenu:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading exceeds 7 digits, which is the maximum value range that can be displayed by the operating tool, the value above this range is output as an overflow.

The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to n** parameter.

User interface

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [130](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m³
- Value in the **Totalizer overflow 1** parameter: $2 \cdot 10^7$ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

"Output values" submenu

Navigation

  Expert → Sensor → Measured val. → Output values

 Output values	
Output current 1 (0361-1)	→ 45
Measured current 1 (0366-1)	→ 46
Pulse output 1 (0456-1)	→ 46
Output frequency 1 (0471-1)	→ 47
Switch state 1 (0461-1)	→ 47
Output frequency 2 (0471-2)	→ 47
Pulse output 2 (0456-2)	→ 46
Switch state 2 (0461-2)	→ 47

Output current 1

Navigation

  Expert → Sensor → Measured val. → Output values → Output curr. 1 (0361-1)

Description

Displays the current value currently calculated for the current output.

User interface


0 to 22.5 mA

Measured current 1

Navigation	Expert → Sensor → Measured val. → Output values → Measur. curr. 1 (0366-1)
Description	Displays the actual measured value of the output current.
User interface	0 to 30 mA

Pulse output 1 to n

Navigation	Expert → Sensor → Measured val. → Output values → Pulse output 1 (0456-1) Expert → Sensor → Measured val. → Output values → Pulse output 2 (0456-2)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 95) parameter.
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <ul style="list-style-type: none"> ■ The pulse output is an open collector output. ■ This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. ■ The Value per pulse parameter (→ 97) and Pulse width parameter (→ 98) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC Normally closed
 NO Normally opened

A0028726

The output behavior can be reversed via the **Invert output signal** parameter (→ 112) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 99)) can be configured.

Output frequency 1 to n

Navigation	█ █ Expert → Sensor → Measured val. → Output values → Output freq. 1 (0471-1) █ █ Expert → Sensor → Measured val. → Output values → Output freq. 2 (0471-2)
Prerequisite	In the Operating mode parameter (→ 95), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 12 500.0 Hz

Switch state 1 to n

Navigation	█ █ Expert → Sensor → Measured val. → Output values → Switch state 1 (0461-1) █ █ Expert → Sensor → Measured val. → Output values → Switch state 2 (0461-2)
Prerequisite	In the Operating mode parameter (→ 95), the Switch option is selected.
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation █ █ Expert → Sensor → System units

► System units	
Volume flow unit (0553)	→ 48
Volume unit (0563)	→ 50
Conductivity unit (0582)	→ 50
Temperature unit (0557)	→ 51
Mass flow unit (0554)	→ 52

Mass unit (0574)	→ 52
Density unit (0555)	→ 53
Corrected volume flow unit (0558)	→ 54
Corrected volume unit (0575)	→ 54
Date/time format (2812)	→ 55

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ /s	■ af/s	■ gal/s (imp)	
■ cm ³ /min	■ af/min	■ gal/min (imp)	
■ cm ³ /h	■ af/h	■ gal/h (imp)	
■ cm ³ /d	■ af/d	■ gal/d (imp)	
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)	
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)	
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)	
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)	
■ m ³ /s	■ MMft ³ /s	■ bbl/s (imp;beer)	
■ m ³ /min	■ MMft ³ /min	■ bbl/min (imp;beer)	
■ m ³ /h	■ MMft ³ /h	■ bbl/h (imp;beer)	
■ m ³ /d	■ Mft ³ /d	■ bbl/d (imp;beer)	
■ ml/s	■ fl oz/s (us)	■ bbl/s (imp;oil)	
■ ml/min	■ fl oz/min (us)	■ bbl/min (imp;oil)	
■ ml/h	■ fl oz/h (us)	■ bbl/h (imp;oil)	
■ ml/d	■ fl oz/d (us)	■ bbl/d (imp;oil)	
■ l/s	■ gal/s (us)		
■ l/min	■ gal/min (us)		
■ l/h	■ gal/h (us)		
■ l/d	■ gal/d (us)		
■ hl/s	■ Mgal/s (us)		
■ hl/min	■ Mgal/min (us)		
■ hl/h	■ Mgal/h (us)		
■ hl/d	■ Mgal/d (us)		
■ Ml/s	■ bbl/s (us;liq.)		
■ Ml/min	■ bbl/min (us;liq.)		
■ Ml/h	■ bbl/h (us;liq.)		
■ Ml/d	■ bbl/d (us;liq.)		
	■ bbl/s (us;beer)		
	■ bbl/min (us;beer)		
	■ bbl/h (us;beer)		
	■ bbl/d (us;beer)		
	■ bbl/s (us;oil)		
	■ bbl/min (us;oil)		
	■ bbl/h (us;oil)		
	■ bbl/d (us;oil)		
	■ bbl/s (us;tank)		
	■ bbl/min (us;tank)		
	■ bbl/h (us;tank)		
	■ bbl/d (us;tank)		
	■ kgal/s (us)		
	■ kgal/min (us)		
	■ kgal/h (us)		
	■ kgal/d (us)		
Factory setting	Country-specific: ■ l/h ■ gal/min (us)		

Additional information*Effect*

The selected unit applies for:

Volume flow parameter (→ [41](#))

Selection

 For an explanation of the abbreviated units: → [172](#)

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Volume unit**Navigation**

 Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- Mft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- gal (us)

Additional information*Selection*

 For an explanation of the abbreviated units: → [172](#)

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter.

Conductivity unit**Navigation**

 Expert → Sensor → System units → Conductiv. unit (0582)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ [59](#)) parameter.

Description Use this function to select the unit for the conductivity.

Selection

SI units

- nS/cm
- μ S/cm
- μ S/m
- μ S/mm
- mS/m
- mS/cm
- S/cm
- S/m
- kS/m
- MS/m

Factory setting μ S/cm

Additional information *Effect*
The selected unit applies for:
Conductivity parameter (→ 42)

Selection

 For an explanation of the abbreviated units: → 172



Temperature unit

Navigation  Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	■ °R

Factory setting Country-specific:
■ °C
■ °F

Additional information *Effect*
The selected unit applies for:
■ **Maximum value** parameter (→ 158)
■ **Minimum value** parameter (→ 158)

Selection

 For an explanation of the abbreviated units: → 172

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Effect*

The selected unit applies for:

Mass flow parameter (→ 41)

Selection

For an explanation of the abbreviated units: → 172

Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter.

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → [172](#)

Customer-specific units

The unit for the customer-specific mass is specified in the **User mass text** parameter.

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/l
- kg/dm³
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Effect*

The selected unit applies for:

- **External density** parameter (→ [71](#))
- **Fixed density** parameter (→ [72](#))

Selection

- SD = specific density

The specific density is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

- SG = specific gravity

The specific gravity is the ratio of the medium density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).



For an explanation of the abbreviated units: → [172](#)

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NI/s
- NI/min
- NI/h
- NI/d
- Nhl/s
- Nhl/min
- Nhl/h
- Nhl/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sl/s
- Sl/min
- Sl/h
- Sl/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d
- MMSft³/s
- MMSft³/min
- MMSft³/h
- MMSft³/d
- Sgal/s (us)
- Sgal/min (us)
- Sgal/h (us)
- Sgal/d (us)
- Sbbl/s (us;liq.)
- Sbbl/min (us;liq.)
- Sbbl/h (us;liq.)
- Sbbl/d (us;liq.)
- Sbbl/s (us;oil)
- Sbbl/min (us;oil)
- Sbbl/h (us;oil)
- Sbbl/d (us;oil)

Imperial units

- Sgal/s (imp)
- Sgal/min (imp)
- Sgal/h (imp)
- Sgal/d (imp)

Factory setting

Country-specific:

- NI/h
- Sft³/h

Additional information*Selection*

For an explanation of the abbreviated units: → 172

Corrected volume unit**Navigation**

Expert → Sensor → System units → Corr. vol. unit (0575)

Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- NI
- Nhl
- Nm³
- Sl
- Sm³

US units

- Sft³
- MMSft³
- Sgal (us)
- Sbbl (us;liq.)
- Sbbl (us;oil)

Imperial units

- Sgal (imp)

Factory setting

Country-specific:

- Nm³
- Sft³

Additional information*Selection*

For an explanation of the abbreviated units: → [172](#)

Date/time format**Navigation**

Expert → Sensor → System units → Date/time format (2812)

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

For an explanation of the abbreviated units: → [172](#)

3.2.3 "Process parameters" submenu*Navigation*

Expert → Sensor → Process param.

► Process parameters	
Filter options (6710)	→ 56
Flow damping (6661)	→ 58
Flow override (1839)	→ 58
Conductivity measurement (6514)	→ 59
Conductivity damping (1803)	→ 59
Conductivity temperature coefficient (1891)	→ 60
Temperature damping (1886)	→ 60
Reference density (1885)	→ 60
► Low flow cut off	
	→ 61

► Empty pipe detection	→ 63
► Electrode cleaning circuit	→ 66
► Build-up index	→ 68

Filter options**Navigation**

Expert → Sensor → Process param. → Filter options (6710)

Description

Use this function to select a filter option.

Selection

- Adaptive
- Adaptive CIP on
- Dynamic
- Dynamic CIP on
- Binomial
- Binomial CIP on

Factory setting

Binomial

Additional information*Description*

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects

the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

Selection

■ **Standard**

- Strong flow damping with a short output signal response time.
- Some time is needed before a stable output signal can be generated.
- Not suitable for pulsating flow as the average flow can be different here.

■ **Dynamic**

- Average flow damping with a delayed output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **Binomial**

- Weak flow damping with a short output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

■ **CIP**

- This filter makes the **Standard** and **Dynamic** filter options additionally available.
- If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
- If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

Examples

Possible applications for the filters

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Pulsating flow (flow is negative intermittently)	---	---	++	--	++
Flow changes frequently (flow is dynamic)	-	--	++	-	++
Clear signal, fast control loop (< 1 s)	--	--	+ ¹⁾		++
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	---
Permanently bad signal	++	--	-	---	-
Short and severe signal distortion after a while		++		++	
Replacement of a Promag 50/53: system damping Promag 400 = 0.5 * system damping Promag 50/53					+++
Replacement of a Promag 10: system damping Promag 400 = system damping Promag 10 + 2			+++		
For a stable flow signal (no other requirements)	+++				

1) Value of flow damping < 6

Flow damping**Navigation**

Expert → Sensor → Process param. → Flow damping (6661)

Description

Use this function to enter a value for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

4

Additional information

Input range 0 to 15

- Value = 0: no damping
- Value = 1: minor damping
- Value = 15: strong damping

▪ The damping depends on the measuring period and the filter type selected.
▪ An increase or decrease in the damping depends on the application.

Effect

The damping affects the following variables of the device:

- Outputs → [81](#)
- Low flow cut off → [61](#)
- Totalizers → [129](#)

Flow override**Navigation**

Expert → Sensor → Process param. → Flow override (1839)

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information

Result

This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**

- The **453 Flow override** diagnostic message is output.
- Output values
 - Output: value at zero flow
 - Temperature: continues to be output
 - Totalizers 1-3: stop being totalized

The **Flow override** option can also be activated in the **Status input** submenu: **Assign status input** parameter.

Conductivity measurement



Navigation Expert → Sensor → Process param. → Conduct. measur. (6514)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 59) parameter.

Description Use this function to enable and disable conductivity measurement.

Selection

- Off
- On

Factory setting Off

Additional information *Description*

For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.

Conductivity damping



Navigation Expert → Sensor → Process param. → Conduct. damping (1803)

Prerequisite The **On** option is selected in the **Conductivity measurement** parameter (→ 59).

Description Use this function to enter a time constant for conductivity damping (PT1 element).

User entry 0 to 999.9 s

Factory setting 0 s

Additional information *Description*

The damping is performed by a PT1 element²⁾.

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Damping is switched off if 0 is entered (factory setting).

2) Proportional behavior with first-order lag

Conductivity temperature coefficient



Navigation Expert → Sensor → Process param. → Cond. temp.coeff (1891)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 72).

Description Use this function to enter the temperature coefficient for the conductivity.

User entry Signed floating-point number

Factory setting 2.1 %/K

Temperature damping



Navigation Expert → Sensor → Process param. → Temp. damping (1886)

Prerequisite The **Internal temperature sensor** option or the **External value** option is selected in the **Temperature source** parameter (→ 72).

Description Use this function to enter the time constant for temperature damping.

User entry 0 to 999.9 s

Factory setting 0 s

Reference density



Navigation Expert → Sensor → Process param. → Ref.density (1885)

Description Use this function to enter a fixed value for the reference density.

User entry Positive floating-point number

Factory setting Country-specific:

- 1 kg/l
- 1 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 53)

"Low flow cut off" submenu**Navigation**
 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off	
Assign process variable (1837)	→  61
On value low flow cutoff (1805)	→  61
Off value low flow cutoff (1804)	→  62
Pressure shock suppression (1806)	→  62

Assign process variable**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

On value low flow cutoff**Navigation**
 Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite

A process variable is selected in the **Assign process variable** parameter (→  61).

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  62.

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter →  168

Additional information

Dependency

 The unit depends on the process variable selected in the **Assign process variable** parameter (→  61).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 61).

Description

Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 61.

User entry


0 to 100.0 %

Factory setting

50 %

Additional information

Example



A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pressure shock suppression**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup. (1806)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 61).

Description

Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry

0 to 100 s

Factory setting

0 s

Additional information

Description

Pressure shock suppression is enabled


- Prerequisite:
Flow rate < on-value of low flow cut off
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.




- Q Flow
 t Time
 A Drip
 B Pressure shock
 C Pressure shock suppression active as per the time entered
 D Pressure shock suppression inactive
 1 Valve closes
 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
 3 The time entered has elapsed: pressure shock suppression is deactivated
 4 The actual flow value is processed again and output
 5 On-value for low flow cut off
 6 Off-value for low flow cut off

"Empty pipe detection" submenu

Navigation

Expert → Sensor → Process param. → Empty pipe det.



Response time empty pipe detection (1859)	→ 64
New adjustment (6560)	→ 65
Progress (6571)	→ 65
Empty pipe adjust value (6527)	→ 65
Full pipe adjust value (6548)	→ 66
Measured value EPD (6559)	→ 66

Assign process variable



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Assign variable (1860)
Description	Use this function to switch empty pipe detection on and off.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off

Switch point empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD (6562)
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 64).
Description	Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.
User entry	0 to 100 %
Factory setting	50 %

Response time empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Response time (1859)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 64).

Description Use this function to enter the minimum length of time (debouncing time) the signal must be present for the **△S862 Pipe empty** diagnostic message to be triggered if the measuring pipe is empty or partially full.

User entry 0 to 100 s

Factory setting 1 s

New adjustment



Navigation Expert → Sensor → Process param. → Empty pipe det. → New adjustment (6560)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [64](#)).

Description For selecting whether to perform an empty pipe or full pipe adjustment.

Selection

- Cancel
- Empty pipe adjust
- Full pipe adjust

Factory setting Cancel

Progress



Navigation Expert → Sensor → Process param. → Empty pipe det. → Progress (6571)

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [64](#)).

Description Use this function to view the progress.

User interface

- Ok
- Busy
- Not ok

Empty pipe adjust value



Navigation Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value (6527)

Prerequisite

- In the **Empty pipe detection** parameter (→ [64](#)), the **On** option is selected.
- Adjustment value > full pipe value.

Description Displays the adjustment value when the measuring pipe is empty.

User interface Positive floating-point number

Full pipe adjust value

Navigation Expert → Sensor → Process param. → Empty pipe det. → Full pipe value (6548)

Prerequisite

- In the **Empty pipe detection** parameter (→ 64), the **On** option is selected.
- Adjustment value < empty pipe value.

Description Displays the adjustment value when the measuring pipe is full.

User interface Positive floating-point number

Measured value EPD

Navigation Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD (6559)

Prerequisite In the **Empty pipe detection** parameter (→ 64), the **On** option is selected.

Description Displays the current measured value.

User interface Positive floating-point number

"Electrode cleaning circuit" submenu

Navigation

Expert → Sensor → Process param. → ECC

► Electrode cleaning circuit	
Electrode cleaning cycle (6528)	→ 67
ECC duration (6555)	→ 67
ECC recovery time (6556)	→ 67
ECC interval (6557)	→ 68
ECC polarity (6631)	→ 68

Electrode cleaning cycle

**Navigation** Expert → Sensor → Process param. → ECC → Elec. clean cycl (6528)**Prerequisite** For the following order code:
"Application package", option **EC** "ECC electrode cleaning"**Description** Use this function to enable and disable cyclic electrode cleaning.**Selection**

- Off
- On

Factory setting Off**Additional information** Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits developing in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation.

ECC duration

**Navigation** Expert → Sensor → Process param. → ECC → ECC duration (6555)**Prerequisite** For the following order code:
"Application package", option **EC** "ECC electrode cleaning"**Description** Use this function to enter the duration of electrode cleaning in seconds.**User entry** 0.01 to 30 s**Factory setting** 2 s

ECC recovery time

**Navigation** Expert → Sensor → Process param. → ECC → ECC recov. time (6556)**Prerequisite** For the following order code:
"Application package", option **EC** "ECC electrode cleaning"**Description** Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.**User entry** 1 to 600 s**Factory setting** 5 s

ECC interval**Navigation**

Expert → Sensor → Process param. → ECC → ECC interval (6557)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Use this function to enter the pause duration until the next electrode cleaning.

User entry

0.5 to 168 h

Factory setting

0.7 h

ECC polarity**Navigation**

Expert → Sensor → Process param. → ECC → ECC polarity (6631)

Prerequisite

For the following order code:
"Application package", option **EC** "ECC electrode cleaning"

Description

Displays the polarity of the electrode cleaning circuit.

User interface

- Positive
- Negative

Factory setting

Depends on the electrode material:

- Tantalum: **Negative** option
- Platinum, Alloy C22, stainless steel: **Positive** option

"Coating detection" submenu

Build-up detection is only available:

- In conjunction with the Promag W sensor
- In the compact device version (transmitter and sensor form a mechanical unit)
- For detailed information on build-up detection: see the Special Documentation for the **Heartbeat Verification + Monitoring** application package → 7

Navigation

Expert → Sensor → Process param. → Build-up detect.

Build-up index	
Build-up index	→ 69
Build-up index damping	→ 69
Build-up index value	→ 69

Build-up limit	→ 70
Build-up limit hysteresis	→ 70

Build-up index

Navigation	Expert → Sensor → Process param. → Build-up index (6734)
Description	Select mode for build-up index.
Selection	<ul style="list-style-type: none"> ■ Off ■ Slow ■ Standard ■ Fast
Factory setting	Off

Build-up index damping

Navigation	Expert → Sensor → Process param. → Build-up index → BuildUpIndexDamp (6840)
Description	Enter damping value for build-up index. Damping value: <ul style="list-style-type: none"> ■ 0 = minimum damping ■ 15 = maximum damping The damping value should only be increased if the measured value is unstable.
User entry	0 to 15
Factory setting	0

Build-up index value

Navigation	Expert → Sensor → Process param. → Build-up index → Build-up value (12111)
Description	Shows current build-up index value.
User interface	0.0 to 100.0 %
Factory setting	0.0 %
Additional information	The formation of build-up is output as a percentage in the Build-up index value (→ 69) parameter. The higher the percentage, the thicker the build-up.

Build-up index value (→ 69) = 0%

- No build-up present
- Measuring tube as-delivered state (initial value)
- Measuring tube was cleaned thoroughly after formation of build-up

Build-up index value (→ 69) = 100%

- Value for the maximum measurable build-up thickness
- The thickness of the build-up at 100% varies depending on the process
- A value of 100% should not be equated with a blocked measuring tube

The percentage indicated in the Build-up index value (→ 69) parameter does not provide direct information about the absolute thickness or the composition of the build-up. Therefore, to make optimum use of the build-up detection function, it is necessary to first compare the formation of build-up in the process, as known from experience, with the associated Build-up index value (→ 69). The aim is to determine the Build-up index value (→ 69) at the time the cleaning is usually performed.

On the basis of the Build-up index value (→ 69) during cleaning, it is possible to make a valid assessment of the condition inside the measuring tube and to plan the cleaning using the build-up limit and build-up detection hysteresis parameters.

In addition, conclusions about possible effects on neighboring processes can be drawn from the Build-up index value (→ 69).

Build-up limit

Navigation  Expert → Sensor → Process param. → Build-up index → Build-up limit (6466)

Description Enter limit value for the build-up index.

User entry 0 to 100 %

Factory setting 50 %

Build-up limit hysteresis

Navigation  Expert → Sensor → Process param. → Build-up index → BuildUpLimitHyst (6467)

Description Enter hysteresis for build-up limit value.

If the value for build-up detection hysteresis is higher than the Build-up limit (→ 70), the "Build-up detected" diagnostic information is not reset until the measuring tube has been cleaned and a restart has been performed.

User entry 0 to 100 %

Factory setting 20 %

3.2.4 "External compensation" submenu

Navigation

Expert → Sensor → External comp.

► External compensation	
Density source (6615)	→ 71
Fixed density (6623)	→ 72
External density (6630)	→ 71
Temperature source (6712)	→ 72
External temperature (6673)	→ 72
Reference temperature (1816)	→ 73

Density source



Navigation

Expert → Sensor → External comp. → Density source (6615)

Description

Use this function to select the density source.

Selection

- Fixed density
- External density

Factory setting

Fixed density

External density

Navigation

Expert → Sensor → External comp. → External density (6630)

Prerequisite

The **External density** option is selected in the **Density source** parameter (→ [71](#)).

Description

Use this function to enter the density read in from the external device.

User entry

Positive floating-point number

Factory setting

0 kg/l

Additional information

Dependency

The unit is taken from the **Density unit** parameter (→ [53](#))

Fixed density

Navigation Expert → Sensor → External comp. → Fixed density (6623)

Prerequisite The **Fixed density** option is selected in the **Density source** parameter (→ 71).

Description Use this function to enter a fixed value for the density.

User entry Positive floating-point number

Factory setting Depends on country:

- 1 000 kg/m³
- 62 lb/ft³

Additional information *Dependency*

The unit is taken from the **Density unit** parameter (→ 53)

Temperature source

Navigation Expert → Sensor → External comp. → Temp. source (6712)

Description Use this function to select the temperature source.

Selection

- Internal temperature sensor *
- Off
- External value

Factory setting Off

External temperature

Navigation Expert → Sensor → External comp. → External temp. (6673)

Prerequisite The **External value** option is selected in the **Temperature source** parameter (→ 72).

Description Use this function to enter the temperature read in from the external device.

User entry Floating point number with sign

Factory setting -273.15 °C

Additional information *Dependency*

The unit is taken from the **Temperature unit** parameter (→ 51)

* Visibility depends on order options or device settings

Reference temperature

Navigation	Expert → Sensor → External comp. → Ref. temperature (1816)
Prerequisite	The Fixed density option or External density option are selected in the Density source parameter (→ 71).
Description	Use this function to enter a reference temperature for calculating the reference density.
User interface	-273.15 to 99 999 °C
Factory setting	Country-specific: ■ +20 °C ■ +68 °F
Additional information	<p><i>Dependency</i></p> <p> The unit is taken from the Temperature unit parameter (→ 51)</p> <p><i>Reference density calculation</i></p>

$$\rho_n = \rho \cdot (1 + \alpha \cdot \Delta t + \beta \cdot \Delta t^2)$$

A0023403

- ρ_N : reference density
- ρ : fluid density currently measured
- t : fluid temperature currently measured
- t_N : reference temperature at which the reference density is calculated (e.g. 20 °C)
- Δt : $t - t_N$
- α : linear expansion coefficient of the fluid, unit = [1/K]; K = Kelvin
- β : square expansion coefficient of the fluid, unit = [1/K²]

3.2.5 "Sensor adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm.

► Sensor adjustment	
Installation direction (1809)	→ 74
Integration time (6533)	→ 74
Measuring period (6536)	→ 74
► Process variable adjustment	
→ 74	

Installation direction

Navigation Expert → Sensor → Sensor adjustm. → Install. direct. (1809)

Description Use this function to change the sign of the medium flow direction.

Selection

- Forward flow
- Reverse flow

Factory setting Forward flow

Additional information *Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time

Navigation Expert → Sensor → Sensor adjustm. → Integration time (6533)

Description Displays the duration of the integration time.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 1 to 65 ms

Measuring period

Navigation Expert → Sensor → Sensor adjustm. → Measuring period (6536)


Description Display the time of a full measuring period.

The duration of the measuring period should always be longer than the duration of the integration time.

User interface 2 to 1000 ms

"Process variable adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust



Volume flow factor (1832)	→ 75
Mass flow offset (1841)	→ 76
Mass flow factor (1846)	→ 76
Conductivity offset (1848)	→ 77
Conductivity factor (1849)	→ 77
Corrected volume flow offset (1866)	→ 77
Corrected volume flow factor (1867)	→ 78
Temperature offset (1868)	→ 78
Temperature factor (1869)	→ 78
Corrected conductivity offset (1870)	→ 79
Corrected conductivity factor (1871)	→ 79
Flow velocity offset (1879)	→ 79
Flow velocity factor (1880)	→ 80

Volume flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Volume flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/s

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1846)

Description

Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1841)

Description

Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.

User entry

Signed floating-point number

Factory setting

0 kg/s

Additional information*Description*

Corrected value = (factor × value) + offset

Conductivity offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset (1848)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 59).
Description	Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Conductivity factor

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor (1849)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 59).
Description	Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Corrected volume flow offset

Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1866)
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s
Additional information	<p><i>Description</i></p> Corrected value = (factor × value) + offset

Corrected volume flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1867)

Description

Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Temperature offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1868)

Prerequisite

The temperature is read into the flowmeter from an external device.

Description

Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.

User entry

Signed floating-point number

Factory setting

0 K

Additional information*Description*

Corrected value = (factor × value) + offset

Temperature factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1869)

Prerequisite

The temperature is read into the flowmeter from an external device.

Description

Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Corrected conductivity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.offset (1870)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 59) parameter.
Description	Use this function to enter the zero point shift to trim the corrected conductivity. The conductivity unit on which the shift is based is µS/cm.
User entry	Signed floating-point number
Factory setting	0 S/m
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr.cond.factor (1871)
Prerequisite	The On option is selected in the Conductivity measurement parameter (→ 59) parameter.
Description	Use this function to enter a quantity factor for the corrected conductivity. In each case, this factor refers to the conductivity in µS/cm.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Flow velocity offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. offset (1879)
Description	Use this function to enter the zero point shift for the flow velocity trim. The flow velocity unit on which the shift is based is m/s.
User entry	Signed floating-point number
Factory setting	0 m/s

Additional information*Description*

Corrected value = (factor × value) + offset

Flow velocity factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Flow vel. factor (1880)

Description

Use this function to enter a quantity factor (without time) for the flow velocity. This multiplication factor is applied over the flow velocity range.

User entry

Positive floating-point number

Factory setting


1

Additional information*Description*

Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu**Navigation**

Expert → Sensor → Calibration

**Nominal diameter****Navigation**

Expert → Sensor → Calibration → Nominal diameter (2807)

Description

Displays the nominal diameter of the sensor.

User interface

DNxx / x"

Factory setting

Depends on the size of the sensor

Additional information*Description*

The value is also specified on the sensor nameplate.

Calibration factor**Navigation**

Expert → Sensor → Calibration → Cal. factor (6522)

Description

Displays the current calibration factor for the sensor.

User interface

Positive floating-point number

Factory setting

Depends on nominal diameter and calibration.

Zero point**Navigation**

Expert → Sensor → Calibration → Zero point (6546)

Description

This function shows the zero point correction value for the sensor.

User interface

Signed floating-point number

Factory setting

Depends on nominal diameter and calibration

Conductivity calibration factor**Navigation**

Expert → Sensor → Calibration → Cond. cal. fact. (6718)

Prerequisite

The **On** option is selected in the **Conductivity measurement** parameter (→ 59) parameter.

Description

Displays the calibration factor for the conductivity measurement.

User interface

0.01 to 10 000

3.3 "Output" submenu

Navigation

Expert → Output

► Output

▶ Current output 1	→ 82
▶ Pulse/frequency/switch output 1 to n	→ 94

3.3.1 "Current output 1" submenu

Navigation

Expert → Output → Curr.output 1

▶ Current output 1	
Process variable current output (0359-1)	→ 82
Current range output (0353-1)	→ 83
Fixed current (0365-1)	→ 84
Lower range value output (0367-1)	→ 84
Upper range value output (0372-1)	→ 86
Measuring mode current output (0351-1)	→ 87
Damping current output (0363-1)	→ 91
Failure behavior current output (0364-1)	→ 92
Failure current (0352-1)	→ 93
Output current 1 (0361-1)	→ 93
Measured current 1 (0366-1)	→ 94

Process variable current output



Navigation

Expert → Output → Curr.output 1 → Proc.var. outp (0359-1)

Description

Use this function to select a process variable for the current output.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity

- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronics temperature
- Reference electrode potential against PE *
- Coil current shot time *
- Noise *
- Build-up index *
- Test point 1
- Test point 2
- Test point 3

Factory setting Volume flow

Current range output



Navigation

Expert → Output → Curr.output 1 → Curr.range out (0353–1)

Description

Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

Selection

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)
- Fixed value

Factory setting

Country-specific:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)

Additional information

Description

- i**
- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 92).
 - If the measured value is outside the measuring range, the **△S441 Current output 1** diagnostic message is displayed.
 - The measuring range is specified via the **0/4 mA value** parameter (→ 84) and **20 mA value** parameter (→ 86).


"Fixed current" option

The current value is set via the **Fixed current** parameter (→ 84).

Example

Shows the relationship between the current range for the output of the process value and the lower and upper alarm levels:

* Visibility depends on order options or device settings



- 1 Current range for process value
 2 Lower level for signal on alarm
 3 Upper level for signal on alarm

Selection

Selection	1	2	3
4...20 mA NE (3.8...20.5 mA)	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US (3.9...20.8 mA)	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA (4... 20.5 mA)	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
0...20 mA (0... 20.5 mA)	0 to 20.5 mA	< 0 mA	> 21.95 mA

i If the flow exceeds or falls below the upper or lower signal on alarm level, the **△S441 Current output 1** diagnostic message is displayed.

Fixed current



Navigation

Expert → Output → Curr.output 1 → Fixed current (0365-1)

Prerequisite

The **Fixed current** option is selected in the **Current span** parameter (→ 83).

Description

Use this function to enter a constant current value for the current output.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Lower range value output



Navigation

Expert → Output → Curr.output 1 → Low.range outp (0367-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 83):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a value for the 0/4 mA current.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 l/h
- 0 gal/min (us)

Additional information*Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 82). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 86).

Dependency

 The unit depends on the process variable selected in the **Assign current output** parameter (→ 82).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 83)
- Measuring mode (→ 87)
- Failure mode (→ 92)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measurement mode with **Forward flow** option

- **0/4 mA value** parameter (→ 84) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 86) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow



Q Flow


I Current

1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **0/4 mA value** parameter (→ 84) and **20 mA value** parameter (→ 86). If the effective flow exceeds or falls below this operational range, the **△S441 Current output 1** diagnostic message is displayed.

Configuration example B

Measurement mode with **Forward/Reverse flow** option



A0013758

- I Current
- Q Flow
- 1 Value assigned to the 0/4 mA current
- 2 Forward flow
- 3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 84) and **20 mA value** parameter (→ 86) must have the same algebraic sign. The value for the **20 mA value** parameter (→ 86) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 86) (e.g. flow).

Configuration example C

Measurement mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s → 87.

Upper range value output



Navigation

Expert → Output → Curr.output 1 → Upp.range outp (0372-1)

Prerequisite

In the **Current span** parameter (→ 83), one of the following options is selected:

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a value for the 20 mA current.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → 167

Additional information

Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 82). In addition, the value can be greater

than or smaller than the value assigned for the 0/4 mA current in the **0/4 mA value** parameter (→ 84).

Dependency

 The unit depends on the process variable selected in the **Assign current output** parameter (→ 82).

Example

- Value assigned to 0/4 mA = -250 m³/h
- Value assigned to 20 mA = +750 m³/h
- Calculated current value = 8 mA (at zero flow)

If the **Forward/Reverse flow** option is selected in the **Measuring mode** parameter (→ 87), different signs cannot be entered for the values of the **0/4 mA value** parameter (→ 84) and **20 mA value** parameter (→ 86). The **△S441 Current output 1** diagnostic message is displayed.

Configuration examples

 Observe the configuration examples for the **0/4 mA value** parameter (→ 84).

Measuring mode current output



Navigation

 Expert → Output → Curr.output 1 → Meas.mode outp (0351-1)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 82):

- Volume flow
- Mass flow
- Flow velocity

One of the following options is selected in the **Current span** parameter (→ 83):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to select the measuring mode for the current output.

Selection

- Forward flow
- Forward/Reverse flow *
- Reverse flow compensation

Factory setting

Forward flow

Additional information

Description

 The process variable that is assigned to the current output via the **Assign current output** parameter (→ 82) is displayed below the parameter.

"Forward flow" option


The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 0/4 mA and 20 mA current value.

* Visibility depends on order options or device settings

The flow components outside the scaled measuring range are taken into account for signal output as follows:

- Both values are defined such that they are not equal to zero flow e.g.:
 - 0/4 mA current value = $-5 \text{ m}^3/\text{h}$
 - 20 mA current value = $10 \text{ m}^3/\text{h}$
- If the effective flow exceeds or falls below this measuring range, the **△S441 Current output 1** diagnostic message is displayed.

"Forward/Reverse flow" option



A0013758

- | | |
|---|--------------------------------------|
| I | Current |
| Q | Flow |
| 1 | Value assigned to the 0/4 mA current |
| 2 | Forward flow |
| 3 | Reverse flow |

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **0/4 mA value** parameter (→ 84) and **20 mA value** parameter (→ 86) must have the same sign.
- The value for the **20 mA value** parameter (→ 86) (e.g. reverse flow) corresponds to the mirrored value for the **20 mA value** parameter (→ 86) (e.g. forward flow).

"Reverse flow compensation" option

The **Reverse flow compensation** option is primarily used to compensate for abrupt reverse flow that can occur with positive displacement pumps as a result of wear or high viscosity. The reverse flow is recorded in a buffer memory and offset against the next forward flow.

If buffering cannot be processed within approx. 60 s, the **△S441 Current output 1** diagnostic message is displayed.


In the event of prolonged and undesired reverse flow, flow values can accumulate in the buffer memory. Due to the configuration of the current output, these values are not factored in, however, i.e. there is no compensation for the reverse flow.

If this option is set, the measuring device does not smoothen the flow signal. The flow signal is not attenuated.

Examples of how the current output behaves

Example 1


Defined measuring range: lower range value and upper range value with the **same** sign

**Fig 2 Measuring range***I Current**Q Flow*


1 Lower range value (value assigned to 0/4 mA current)

2 Upper range value (value assigned to 20 mA current)


With the following flow response:

**Fig 3 Flow response***Q Flow**t Time*With **Forward flow** option


The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output:.

*I Current**t Time*With **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.

*I Current**t Time*With **Reverse flow compensation** option


Flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.



I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Example 2


Defined measuring range: lower range value and upper range value with **different signs**



■ 4 Measuring range

I Current
 Q Flow
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)


With flow a (\rightarrow) outside, b ($- -$) inside the measuring range



Q Flow
 t Time
 1 Lower range value (value assigned to 0/4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

- a (\rightarrow): The flow components outside the scaled measuring range cannot be taken into account for signal output.
The **△S441 Current output 1** diagnostic message is output.
- b ($- -$): The current output signal is proportional to the process variable assigned.



A0028100


I Current
 t Time

With Forward/Reverse flow option

This option cannot be selected here since the values for the **0/4 mA value** parameter (\rightarrow 84) and **20 mA value** parameter (\rightarrow 86) have different algebraic signs.

With Reverse flow compensation option

Flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.



A0028101

I Current
 t Time
 S Flow components saved
 A Balancing of saved flow components

Damping current output



Navigation

Expert → Output → Curr.output 1 → Damp.curr.outp (0363-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (\rightarrow 82) and one of the following options is selected in the **Current span** parameter (\rightarrow 83):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to enter a time constant for the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

1.0 s

Additional information*User entry*

Use this function to enter a time constant (PT1 element³⁾) for current output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

 Damping is switched off if **0** is entered (factory setting).

Failure behavior current output**Navigation**

  Expert → Output → Curr.output 1 → Fail.behav.out (0364-1)

Prerequisite

A process variable is selected in the **Assign current output** parameter (→ 82) and one of the following options is selected in the **Current span** parameter (→ 83):

- 4...20 mA NE (3.8...20.5 mA)
- 4...20 mA US (3.9...20.8 mA)
- 4...20 mA (4... 20.5 mA)
- 0...20 mA (0... 20.5 mA)

Description

Use this function to select the value of the current output in the event of a device alarm.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Fixed value

Factory setting

Max.

3) proportional transmission behavior with first order delay

Additional information*Description*

 This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  83).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  83).

"Last valid value" option

The current output adopts the last measured value that was valid before the device alarm occurred.

"Actual value" option

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

"Defined value" option

The current output adopts a defined measured value.

 The measured value is defined via the **Failure current** parameter (→  93).

Failure current**Navigation**

 Expert → Output → Curr.output 1 → Fail. current (0352-1)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (→  92).

Description

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

User entry

0 to 22.5 mA

Factory setting

22.5 mA

Output current 1**Navigation**

 Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)

Description

Displays the current value currently calculated for the current output.

User interface

0 to 22.5 mA

Measured current 1

Navigation   Expert → Output → Curr.output 1 → Measur. curr. 1 (0366-1)

Description Displays the actual measured value of the output current.

User interface 0 to 30 mA

3.3.2 "Pulse/frequency/switch output 1 to n" submenu

Navigation   Expert → Output → PFS output 1 to n

► Pulse/frequency/switch output 1 to n	
Operating mode (0469-1 to n)	→  95
Assign pulse output 1 to n (0460-1 to n)	→  97
Pulse scaling (0455-1 to n)	→  97
Pulse width (0452-1 to n)	→  98
Measuring mode (0457-1 to n)	→  99
Failure mode (0480-1 to n)	→  99
Pulse output 1 to n (0456-1 to n)	→  100
Assign frequency output (0478-1 to n)	→  101
Minimum frequency value (0453-1 to n)	→  101
Maximum frequency value (0454-1 to n)	→  101
Measuring value at minimum frequency (0476-1 to n)	→  102
Measuring value at maximum frequency (0475-1 to n)	→  102
Measuring mode (0479-1 to n)	→  103
Damping output 1 to n (0477-1 to n)	→  103

Response time (0491-1 to n)	→ 104
Failure mode (0451-1 to n)	→ 104
Failure frequency (0474-1 to n)	→ 105
Output frequency 1 to n (0471-1 to n)	→ 105
Switch output function (0481-1 to n)	→ 105
Assign diagnostic behavior (0482-1 to n)	→ 106
Assign limit (0483-1 to n)	→ 107
Switch-on value (0466-1 to n)	→ 109
Switch-off value (0464-1 to n)	→ 109
Assign flow direction check (0484-1 to n)	→ 110
Assign status (0485-1 to n)	→ 110
Switch-on delay (0467-1 to n)	→ 110
Switch-off delay (0465-1 to n)	→ 111
Failure mode (0486-1 to n)	→ 111
Switch state 1 to n (0461-1 to n)	→ 111
Invert output signal (0470-1 to n)	→ 112

Operating mode



Navigation

Expert → Output → PFS output 1 to n → Operating mode (0469-1 to n)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse *
- Frequency *
- Switch *

Factory setting

Pulse

* Visibility depends on order options or device settings

Additional information**"Pulse" option**

Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass or volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s




Fig. 5 Quantity-dependent pulse (pulse value) with configurable pulse width

B Pulse width entered

P Pauses between the individual pulses

"Frequency" option

Flow-dependent frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as mass flow, volume flow, flow velocity, conductivity or electronic temperature.

Example

- Flow approx. 100 g/s
- Max. frequency 10 kHz
- Flow at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz





Fig. 6 Flow-dependent frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




A0026884

图 7 No alarm, high level

Example

Alarm response in case of alarm



A0026885

图 8 Alarm, low level

Assign pulse output 1 to n**Navigation**

图 2 Expert → Output → PFS output 1 to n → Assign pulse 1 to n (0460-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 图 95).**Description**

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Off

Pulse scaling**Navigation**

图 2 Expert → Output → PFS output 1 to n → Pulse scaling (0455-1 to n)

PrerequisiteThe **Pulse** option is selected in the **Operating mode** parameter (→ 图 95) and a process variable is selected in the **Assign pulse output** parameter (→ 图 97).**Description**

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating point number

Factory setting

Depends on country and nominal diameter

Additional information*User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width**Navigation**

Expert → Output → PFS output 1 to n → Pulse width (0452-1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 95) and a process variable is selected in the **Assign pulse output** parameter (→ 97).

Description

Use this function to enter the duration of the output pulse.

User entry


0.05 to 2 000 ms

Factory setting

100 ms

Additional information*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the **443 Pulse output 1 to n** diagnostic message.



B Pulse width entered

P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max} = 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max} = 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Measuring mode

Navigation Expert → Output → PFS output 1 to n → Measuring mode (0457–1 to n)

Prerequisite In the **Operating mode** parameter (→ 95), the **Pulse** option is selected, and one of the following options is selected in the **Assign pulse output** parameter (→ 97):

- Mass flow
- Volume flow

Description Use this function to select the measuring mode for the pulse output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow
- Reverse flow compensation

Factory setting Forward flow

Additional information *Selection*

- Forward flow
Positive flow is output, negative flow is not output.
- Forward/Reverse flow
Positive and negative flow are output (absolute value), but a distinction is not made between positive and negative flow.
- Reverse flow
Negative flow is output, positive flow is not output.
- Reverse flow compensation
The flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 s.

Failure mode

Navigation Expert → Output → PFS output 1 to n → Failure mode (0480–1 to n)

Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (→ 95) and a process variable is selected in the **Assign pulse output** parameter (→ 97).

Description Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

*Selection***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Pulse output 1 to n (0456–1 to n)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 95) parameter.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 97) and **Pulse width** parameter (→ 98) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 112) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 99)) can be configured.

Assign frequency output

Navigation Expert → Output → PFS output 1 to n → Assign freq. (0478–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ [95](#)).

Description Use this function to select the process variable for the frequency output.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature*
- Electronics temperature
- Noise*
- Coil current shot time*
- Reference electrode potential against PE*
- Build-up index*
- Test point 1
- Test point 2
- Test point 3

Factory setting Off

Minimum frequency value

Navigation Expert → Output → PFS output 1 to n → Min. freq. value (0453–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ [95](#)) and a process variable is selected in the **Assign frequency output** parameter (→ [101](#)).

Description Use this function to enter the minimum frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 0.0 Hz

Maximum frequency value

Navigation Expert → Output → PFS output 1 to n → Max. freq. value (0454–1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ [95](#)) and a process variable is selected in the **Assign frequency output** parameter (→ [101](#)).

* Visibility depends on order options or device settings

Description Use this function to enter the end value frequency.

User entry 0.0 to 10 000.0 Hz

Factory setting 10 000.0 Hz

Measuring value at minimum frequency



Navigation Expert → Output → PFS output 1 to n → Val. at min.freq (0476-1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 95) and a process variable is selected in the **Assign frequency output** parameter (→ 101).

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Dependency*

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 101).

Measuring value at maximum frequency



Navigation Expert → Output → PFS output 1 to n → Val. at max.freq (0475-1 to n)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 95) and a process variable is selected in the **Assign frequency output** parameter (→ 101).

Description Use this function to enter the measured value for the end value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 101).

Measuring mode**Navigation**

Expert → Output → PFS output 1 to n → Measuring mode (0479–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 95), the **Frequency** option is selected, and one of the following options is selected in the **Assign frequency output** parameter (→ 101):

- Volume flow
- Mass flow
- Flow velocity
- Conductivity*
- Electronics temperature

Description

Use this function to select the measuring mode for the frequency output.

Selection

- Forward flow
- Forward/Reverse flow
- Reverse flow compensation

Factory setting

Forward flow

Damping output 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Damping out. 1 to n (0477–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 95), the **Frequency** option is selected, and one of the following options is selected in the **Assign frequency output** parameter (→ 101):

- Volume flow
- Mass flow
- Flow velocity
- Conductivity*
- Electronics temperature

Description

Use this function to enter a time constant for the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

0.0 s

Additional information

User entry

Use this function to enter a time constant (PT1 element⁴⁾) for frequency output damping:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.



Damping is switched off if **0** is entered (factory setting).

* Visibility depends on order options or device settings

4) proportional transmission behavior with first order delay

The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time

Navigation	Expert → Output → PFS output 1 to n → Response time (0491–1 to n)
Prerequisite	In the Operating mode parameter (→ 95), the Frequency option is selected, and one of the following options is selected in the Assign frequency output parameter (→ 101): <ul style="list-style-type: none"> ▪ Volume flow ▪ Mass flow ▪ Flow velocity ▪ Conductivity * ▪ Electronics temperature
Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<p><i>Description</i></p> <p> The response time is made up of the time specified for the following dampings:</p> <ul style="list-style-type: none"> ▪ Damping of pulse/frequency/switch output → 91 and ▪ Depending on the measured variable assigned to the output. Flow damping

Failure mode



Navigation	Expert → Output → PFS output 1 to n → Failure mode (0451–1 to n)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 95) and a process variable is selected in the Assign frequency output parameter (→ 101).
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ▪ Actual value ▪ Defined value ▪ 0 Hz
Factory setting	0 Hz

* Visibility depends on order options or device settings

Additional information*Selection*

■ Actual value

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

■ Defined value

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→ 105) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

■ 0 Hz

In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Failure frequency**Navigation**

Expert → Output → PFS output 1 to n → Failure freq. (0474-1 to n)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 95) and a process variable is selected in the **Assign frequency output** parameter (→ 101).

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 12 500.0 Hz

Factory setting

0.0 Hz

Output frequency 1 to n**Navigation**

Expert → Output → PFS output 1 to n → Output freq. 1 to n (0471-1 to n)

Prerequisite

In the **Operating mode** parameter (→ 95), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 12 500.0 Hz

Switch output function**Navigation**

Expert → Output → PFS output 1 to n → Switch out funct (0481-1 to n)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 95) parameter.

Description Use this function to select a function for the switch output.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Flow direction check
- Status

Factory setting Off

Additional information

Selection

- Off
The switch output is permanently switched off (open, non-conductive).
- On
The switch output is permanently switched on (closed, conductive).
- Diagnostic behavior
Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.
- Limit
Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.
- Flow direction check
Indicates the flow direction (forward or reverse flow).
- Status
Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior



Navigation

☒ ☒ Expert → Output → PFS output 1 to n → Assign diag. beh (0482-1 to n)

Prerequisite

- In the **Operating mode** parameter (→ 95), the **Switch** option is selected.
- In the **Switch output function** parameter (→ 105), the **Diagnostic behavior** option is selected.

Description

Use this function to select the diagnostic event category that is displayed for the switch output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting Alarm

Additional information*Description*

If no diagnostic event is pending, the switch output is closed and conductive.

Selection

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output 1 to n → Assign limit (0483–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 95).
- The **Limit** option is selected in the **Switch output function** parameter (→ 105).

Description

Use this function to select a process variable for the limit function.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Temperature*
- Electronics temperature

Factory setting


Volume flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive

* Visibility depends on order options or device settings




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



A0026893

- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value

Navigation Expert → Output → PFS output 1 to n → Switch-on value (0466–1 to n)

Prerequisite ■ The **Switch** option is selected in the **Operating mode** parameter (→ 95).
■ The **Limit** option is selected in the **Switch output function** parameter (→ 105).

Description Use this function to enter the measured value for the switch-on point.

User entry Signed floating-point number

Factory setting Country-specific:
■ 0 l/h
■ 0 gal/min (us)

Additional information *Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 107).

Switch-off value

Navigation Expert → Output → PFS output 1 to n → Switch-off value (0464–1 to n)

Prerequisite ■ The **Switch** option is selected in the **Operating mode** parameter (→ 95).
■ The **Limit** option is selected in the **Switch output function** parameter (→ 105).

Description Use this function to enter the measured value for the switch-off point.

User entry Signed floating-point number

Factory setting Country-specific:
■ 0 l/h
■ 0 gal/min (us)

Additional information *Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 107).

Assign flow direction check

Navigation Expert → Output → PFS output 1 to n → Assign dir.check (0484-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [95](#)).
- The **Flow direction check** option is selected in the **Switch output function** parameter (→ [105](#)).

Description Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting Volume flow

Assign status

Navigation Expert → Output → PFS output 1 to n → Assign status (0485-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [95](#)).
- The **Status** option is selected in the **Switch output function** parameter (→ [105](#)).

Description Use this function to select a device status for the switch output.

Selection

- Empty pipe detection
- Low flow cut off
- Build-up index *

Factory setting Empty pipe detection

Additional information *Options*
If empty pipe detection or low flow cut off are enabled, the output is conductive.
Otherwise, the switch output is non-conductive.

Switch-on delay

Navigation Expert → Output → PFS output 1 to n → Switch-on delay (0467-1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [95](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [105](#)).

Description Use this function to enter a delay time for switching on the switch output.

User entry 0.0 to 100.0 s

* Visibility depends on order options or device settings

Factory setting	0.0 s
------------------------	-------

Switch-off delay

Navigation Expert → Output → PFS output 1 to n → Switch-off delay (0465–1 to n)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [95](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [105](#)).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode

Navigation Expert → Output → PFS output 1 to n → Failure mode (0486–1 to n)

Description Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting Open

Additional information *Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch state 1 to n

Navigation Expert → Output → PFS output 1 to n → Switch state 1 to n (0461–1 to n)

Prerequisite The **Switch** option is selected in the **Operating mode** parameter (→ [95](#)).

Description Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal**Navigation**

Expert → Output → PFS output 1 to n → Invert outp.sig. (0470-1 to n)

Description

Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting


No

Additional information*Selection*

No option (passive - negative)




Yes option (passive - positive)



3.4 "Communication" submenu

Navigation

Expert → Communication



► Modbus data map	→ 118
► Web server	→ 119
► WLAN settings	→ 122

3.4.1 "Modbus configuration" submenu

Navigation

Expert → Communication → Modbus config.

► Modbus configuration	
Bus address	→ 113
Baudrate	→ 113
Data transfer mode	→ 114
Parity	→ 114
Byte order	→ 115
Telegram delay	→ 116
Failure mode	→ 116
Fieldbus writing access	→ 117

Bus address



Navigation

Expert → Communication → Modbus config. → Bus address (7112)

Description

For entering the device address.

User entry

1 to 247

Factory setting

247

Baudrate



Navigation

Expert → Communication → Modbus config. → Baudrate (7111)

Description

Use this function to select a transmission rate.

Selection

- 1200 BAUD
- 2400 BAUD
- 4800 BAUD
- 9600 BAUD
- 19200 BAUD
- 38400 BAUD
- 57600 BAUD
- 115200 BAUD

Factory setting

19200 BAUD

Data transfer mode**Navigation**

Expert → Communication → Modbus config. → Data trans. mode (7115)

Description

Use this function to select the data transmission mode.

Selection

- ASCII
- RTU

Factory setting

RTU

Additional information*Options*

- ASCII
Transmission of data in the form of readable ASCII characters. Error protection via LRC.
- RTU
Transmission of data in binary form. Error protection via CRC16.

Parity**Navigation**

Expert → Communication → Modbus config. → Parity (7122)

Description

Use this function to select the parity bit.

Selection

- Odd
- Even
- None / 1 stop bit
- None / 2 stop bits

Factory setting

Even

Additional information*Options*

Picklist **ASCII** option:

- 0 = **Even** option
- 1 = **Odd** option

Picklist **RTU option**:

- 0 = **Even** option
- 1 = **Odd** option
- 2 = **None / 1 stop bit** option
- 3 = **None / 2 stop bits** option

Byte order



Navigation

Expert → Communication → Modbus config. → Byte order (7113)

Description

Use this function to select the sequence in which the bytes are transmitted. The transmission sequence must be coordinated with the Modbus master.

Selection

- 0-1-2-3
- 3-2-1-0
- 1-0-3-2
- 2-3-0-1

Factory setting 1-0-3-2

Additional information

Description

The byte sequence is not standardized by the Modbus protocol. However, if the host system and the measuring device do not use the same byte sequence, correct data exchange is not possible.

Changing the byte sequence in the host system often requires extensive knowledge and significant programming efforts. Endress+Hauser introduced the **Byte order** parameter (→ 115) for this reason.

This makes it possible to use the standard settings of the host system and change the byte sequence on the measuring device by trial and error. If correct data exchange cannot be achieved by changing the byte sequence, the settings for the byte sequence of the host system must be adapted accordingly.

Byte transmission sequence

Byte addressing, i.e. the transmission sequence of the bytes, is not specified in the Modbus specification. For this reason, it is important to coordinate or match the addressing method between the master and slave during commissioning. This can be configured in the measuring device using the **Byte order** parameter (→ 115).

The bytes are transmitted depending on the selection in the **Byte order** parameter (→ 115):

FLOAT				
	Sequence			
Options	1.	2.	3.	4.
1 - 0 - 3 - 2 *	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)
0 - 1 - 2 - 3	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)
2 - 3 - 0 - 1	Byte 2 (EMMMMMMM)	Byte 3 (SEEEEEEE)	Byte 0 (MMMMMMMM)	Byte 1 (MMMMMMMM)

3 - 2 - 1 - 0	Byte 3 (SEEEEEEE)	Byte 2 (EMMMMMMM)	Byte 1 (MMMMMMMM)	Byte 0 (MMMMMMMM)
* = factory setting, S = sign, E = exponent, M = mantissa				

INTEGER		
Sequence		
Options	1.	2.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 1 (MSB)	Byte 0 (LSB)
0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 0 (LSB)	Byte 1 (MSB)
* = factory setting, MSB = most significant byte, LSB = least significant byte		

STRING					
Presentation taking the example of a device parameter with a data length of 18 bytes.					
Sequence					
Options	1.	2.	...	17.	18.
1 - 0 - 3 - 2 * 3 - 2 - 1 - 0	Byte 17 (MSB)	Byte 16	...	Byte 1	Byte 0 (LSB)
0 - 1 - 2 - 3 2 - 3 - 0 - 1	Byte 16	Byte 17 (MSB)	...	Byte 0 (LSB)	Byte 1
* = factory setting, MSB = most significant byte, LSB = least significant byte					

Telegram delay



Navigation

Expert → Communication → Modbus config. → Telegram delay (7146)

Description

Use this function to enter a delay time after which the measuring device replies to the request telegram of the Modbus master. This allows communication to be adapted to slow Modbus RS485 masters.

User entry

0 to 100 ms

Factory setting

6 ms

Failure mode



Navigation

Expert → Communication → Modbus config. → Failure mode (7116)

Description

Use this function to select the measured value output in the event of a diagnostic message via Modbus communication.

Selection

- NaN value
- Last valid value

Factory setting

NaN value

Additional information*Options*

- NaN value
The device outputs the NaN value⁵⁾.
- Last valid value
The device outputs the last valid measured value before the fault occurred.

 This effect of this parameter depends on the option selected in the **Assign diagnostic behavior** parameter.

Fieldbus writing access**Navigation**

 Expert → Communication → Modbus config. → Fieldb.writ.acc. (7156)

Description

Use this function to restrict access to the measuring device via fieldbus (Modbus protocol).

Selection

- Read + write
- Read only

Factory setting

Read + write

Additional information*Description*

If read and/or write protection is enabled, the parameter can only be controlled and reset via local operation. Access is no longer possible via operating tools.

 This does not affect cyclic measured value transmission to the higher-order system, which is always guaranteed.

Selection

- Read + write
The parameters are read and write parameters.
- Read only
The parameters are read only parameters.

3.4.2 "Modbus information" submenu*Navigation*

 Expert → Communication → Modbus info

 **Modbus information**

Device ID (7153)	→  118
Device revision (7154)	→  118

5) Not a Number

Device ID

Navigation   Expert → Communication → Modbus info → Device ID (7153)

Description Displays the device ID for identifying the measuring device.

User interface 4-digit hexadecimal number

Device revision


Navigation   Expert → Communication → Modbus info → Device revision (7154)

Description Displays the device revision.

User interface 4-digit hexadecimal number

3.4.3 "Modbus data map" submenu

Navigation  Expert → Communication → Modbus data map



Scan list register 0 to 15



Navigation   Expert → Communication → Modbus data map → Scan list reg.0 to 15 (7114)

Description Use this function to enter the scan list register. By entering the register address (1-based), up to 16 device parameters can be grouped by assigning them to the scan list registers 0 to 15. The data of the device parameters assigned here are read out via the register addresses 5051 to 5081.

User entry 1 to 65 535

Factory setting 1

3.4.4 "Web server" submenu

Navigation

Expert → Communication → Web server

▶ Web server	
Web server language (7221)	→ 119
MAC address (7214)	→ 120
DHCP client (7212)	→ 120
IP address (7209)	→ 120
Subnet mask (7211)	→ 121
Default gateway (7210)	→ 121
Web server functionality (7222)	→ 121
Login page (7273)	→ 122

Web server language

Navigation

Expert → Communication → Web server → Webserv.language (7221)

Description

Use this function to select the Web server language setting.

Selection

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- русский язык (Russian)
- Svenska
- Türkçe
- 中文 (Chinese)
- 日本語 (Japanese)
- 한국어 (Korean)
- العربية (Arabic) *
- Bahasa Indonesia
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese)
- čeština (Czech)

* Visibility depends on order options or device settings

Factory setting English

MAC address

Navigation	  Expert → Communication → Web server → MAC Address (7214)
Description	Displays the MAC ⁶⁾ address of the measuring device.
User interface	Unique 12-digit character string comprising letters and numbers
Factory setting	Each measuring device is given an individual address.
Additional information	<i>Example</i> For the display format 00:07:05:10:01:5F

DHCP client



Navigation	  Expert → Communication → Web server → DHCP client (7212)
Description	Use this function to activate and deactivate the DHCP client functionality.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	On
Additional information	<i>Effect</i> If the DHCP client functionality of the web server is selected, the IP address (→  120), Subnet mask (→  121) and Default gateway (→  121) are set automatically.  ▪ Identification is via the MAC address of the measuring device. ▪ The IP address (→  120) in the IP address parameter (→  120) is ignored as long as the DHCP client parameter (→  120) is active. This is also the case, in particular, if the DHCP server cannot be reached. The IP address (→  120) in the parameter of the same name is only used if the DHCP client parameter (→  120) is inactive.

IP address



Navigation	  Expert → Communication → Web server → IP address (7209)
Description	Display or enter the IP address of the Web server integrated in the measuring device.

6) Media Access Control

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 192.168.1.212

Subnet mask



Navigation Expert → Communication → Web server → Subnet mask (7211)

Description Display or enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

Default gateway



Navigation Expert → Communication → Web server → Default gateway (7210)

Description Display or enter the Default gateway (→ 121).

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 0.0.0.0

Web server functionality



Navigation Expert → Communication → Web server → Webserver funct. (7222)

Description Use this function to switch the Web server on and off.

Selection
■ Off
■ On

Factory setting On

Additional information*Description*

Once disabled, the Web server functionality can only be re-enabled via or the operating tool FieldCare.

Selection

Option	Description
Off	<ul style="list-style-type: none"> ■ The web server is completely disabled. ■ Port 80 is locked.
On	<ul style="list-style-type: none"> ■ The complete functionality of the web server is available. ■ JavaScript is used. ■ The password is transferred in an encrypted state. ■ Any change to the password is also transferred in an encrypted state.

Login page**Navigation**

Expert → Communication → Web server → Login page (7273)

Description

Use this function to select the format of the login page.

Selection

- Without header
- With header

Factory setting

With header

3.4.5 "WLAN settings" wizard*Navigation*

Expert → Communication → WLAN settings

► WLAN settings

WLAN (2702)	→ 123
WLAN mode (2717)	→ 123
SSID name (2714)	→ 124
Network security (2705)	→ 124
Security identification (2718)	→ 124
User name (2715)	→ 125
WLAN password (2716)	→ 125
WLAN IP address (2711)	→ 125

WLAN MAC address (2703)	→ 125
WLAN subnet mask (2709)	→ 126
WLAN MAC address (2703)	→ 125
WLAN passphrase (2706)	→ 126
WLAN MAC address (2703)	→ 125
Assign SSID name (2708)	→ 126
SSID name (2707)	→ 127
2.4 GHz WLAN channel (2704)	→ 127
Select antenna (2713)	→ 127
Connection state (2722)	→ 128
Received signal strength (2721)	→ 128
WLAN IP address (2711)	→ 125
Gateway IP address (2719)	→ 128
IP address domain name server (2720)	→ 128

WLAN

**Navigation**

Expert → Communication → WLAN settings → WLAN (2702)

Description

Use this function to enable and disable the WLAN connection.

Selection

- Disable
- Enable

Factory setting

Enable

WLAN mode

**Navigation**

Expert → Communication → WLAN settings → WLAN mode (2717)

Description

Use this function to select the WLAN mode.

Selection WLAN access point

Factory setting WLAN access point

SSID name

Navigation Expert → Communication → WLAN settings → SSID name (2714)

Prerequisite The client is activated.

Description Use this function to enter the user-defined SSID name (max. 32 characters) of the WLAN network.

User entry –

Factory setting –

Network security

Navigation Expert → Communication → WLAN settings → Network security (2705)

Description Use this function to select the type of security for the WLAN interface.

Selection

- Unsecured
- WPA2-PSK
- EAP-PEAP with MSCHAPv2 *
- EAP-PEAP MSCHAPv2 no server authentic. *
- EAP-TLS *

Factory setting WPA2-PSK

Additional information *Selection*

- Unsecured
Access the WLAN connection without identification.
- WPA2-PSK
Access the WLAN connection with a network key.

Security identification

Navigation Expert → Communication → WLAN settings → Sec. identific. (2718)

Description Use this function to select the security settings (download via the menu: Data Management > Security > Download WLAN).

* Visibility depends on order options or device settings

User interface	<ul style="list-style-type: none"> ■ Trusted issuer certificate ■ Device certificate ■ Device private key
-----------------------	--

User name

Navigation	Expert → Communication → WLAN settings → User name (2715)
-------------------	---

Description Use this function to enter the username of the WLAN network.

User entry –

Factory setting –

WLAN password

Navigation	Expert → Communication → WLAN settings → WLAN password (2716)
-------------------	---

Description Use this function to enter the WLAN password for the WLAN network.

User entry –

Factory setting –

WLAN IP address

Navigation	Expert → Communication → WLAN settings → WLAN IP address (2711)
-------------------	---

Description Use this function to enter the IP address of the measuring device's WLAN connection.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 192.168.1.212

WLAN MAC address

Navigation	Expert → Communication → WLAN settings → WLAN MAC address (2703)
-------------------	--

Description Displays the MAC⁷⁾ address of the measuring device.

User interface Unique 12-digit character string comprising letters and numbers

7) Media Access Control

Factory setting Each measuring device is given an individual address.

Additional information *Example*

For the display format
00:07:05:10:01:5F

WLAN subnet mask



Navigation Expert → Communication → WLAN settings → WLAN subnet mask (2709)

Description Use this function to enter the subnet mask.

User entry 4 octet: 0 to 255 (in the particular octet)

Factory setting 255.255.255.0

WLAN passphrase



Navigation Expert → Communication → WLAN settings → WLAN passphrase (2706)

Prerequisite The **WPA2-PSK** option is selected in the **Security type** parameter (→ 124).

Description Use this function to enter the network key.

User entry 8 to 32-digit character string comprising numbers, letters and special characters (without spaces)

Factory setting Serial number of the measuring device (e.g. L100A802000)

Assign SSID name



Navigation Expert → Communication → WLAN settings → Assign SSID name (2708)

Description Use this function to select which name is used for the SSID⁸⁾.

Selection

- Device tag
- User-defined

Factory setting User-defined

8) Service Set Identifier

Additional information*Selection*

- Device tag
The device tag name is used as the SSID.
- User-defined
A user-defined name is used as the SSID.

SSID name**Navigation**

Expert → Communication → WLAN settings → SSID name (2707)

Prerequisite

- The **User-defined** option is selected in the **Assign SSID name** parameter (→ 126).
- The **WLAN access point** option is selected in the **WLAN mode** parameter (→ 123).

Description

Use this function to enter a user-defined SSID name.

User entry

Max. 32-digit character string comprising numbers, letters and special characters

Factory setting**2.4 GHz WLAN channel****Navigation**

Expert → Communication → WLAN settings → WLAN channel (2704)

Description

Use this function to enter the 2.4 GHz WLAN channel.

User entry

1 to 11

Factory setting

6

Additional information*Description*

-
- It is only necessary to enter a 2.4 GHz WLAN channel if multiple WLAN devices are in use.
 - If just one measuring device is in use, it is recommended to keep the factory setting.

Select antenna**Navigation**

Expert → Communication → WLAN settings → Select antenna (2713)

Description

Use this function to select whether the external or internal antenna is used for reception.

Selection

- External antenna
- Internal antenna

Factory setting

Internal antenna

Connection state

Navigation	 Expert → Communication → WLAN settings → Connection state (2722)
Description	The connection status is displayed.
User interface	<ul style="list-style-type: none">■ Connected■ Not connected
Factory setting	Not connected

Received signal strength

Navigation	  Expert → Communication → WLAN settings → Rec.sig.strength (2721)
Description	Displays the signal strength received.
User interface	<ul style="list-style-type: none">■ Low■ Medium■ High
Factory setting	High

Gateway IP address

Navigation	  Expert → Communication → WLAN settings → Gateway IP addr. (2719)
Description	Use this function to enter the IP address of the gateway.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212


IP address domain name server

Navigation	  Expert → Communication → WLAN settings → IP address DNS (2720)
Description	Use this function to enter the IP address of the domain name server.
User interface	Character string comprising numbers, letters and special characters
Factory setting	192.168.1.212

3.5 "Application" submenu

Navigation

◀ ▶ Expert → Application



Reset all totalizers

Navigation

◀ ▶ Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information


Selection

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

3.5.1 "Totalizer 1 to n" submenu

Navigation

◀ ▶ Expert → Application → Totalizer 1 to n



Control Totalizer 1 to n (0912-1 to n)	→ 132
Preset value 1 to n (0913-1 to n)	→ 133
Failure mode (0901-1 to n)	→ 133

Assign process variable**Navigation**

Expert → Application → Totalizer 1 to n → Assign variable (0914-1 to n)

Description

Use this function to select a process variable for the Totalizer 1 to n.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

Additional information*Description*

If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only the **Assign process variable** parameter (→ 130) is still displayed in the **Totalizer 1 to n** submenu. All other parameters in the submenu are hidden.

Unit totalizer 1 to n**Navigation**

Expert → Application → Totalizer 1 to n → Unit totalizer 1 to n (0915-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 130) of the **Totalizer 1 to n** submenu.

Description

Use this function to select the process variable unit for the Totalizer 1 to n (→ 129).

Selection

- SI units*
- g *
 - kg *
 - t *

- US units*
- oz *
 - lb *
 - STon *

* Visibility depends on order options or device settings

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ *	■ af*	■ gal (imp)*
■ dm ³ *	■ ft ³ *	■ Mgal (imp)*
■ m ³ *	■ Mft ³ *	■ bbl (imp;beer)*
■ ml*	■ fl oz (us)*	■ bbl (imp;oil)*
■ l*	■ gal (us)*	
■ hl*	■ kgal (us)*	
■ Ml Mega*	■ Mgal (us)*	
	■ bbl (us;liq.)*	
	■ bbl (us;beer)*	
	■ bbl (us;oil)*	
	■ bbl (us;tank)*	

* Visibility depends on order options or device settings

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ NI*	■ Sft ³ *	Sgal (imp)*
■ Nhl*	■ MMSft ³ *	
■ Nm ³ *	■ Sgal (us)*	
■ SI*	■ Sbbl (us;liq.)*	
■ Sm ³ *	■ Sbbl (us;oil)*	

* Visibility depends on order options or device settings

or

Other units

None*

* Visibility depends on order options or device settings

Factory setting

Country-specific:

- l
- gal (us)

Additional information

Description

 The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ 47).

Selection

The selection is dependent on the process variable selected in the **Assign process variable** parameter (→ 130).

Totalizer operation mode



Navigation

Expert → Application → Totalizer 1 to n → Operation mode (0908-1 to n)

Prerequisite

A process variable is selected in the **Assign process variable** parameter (→ 130) of the **Totalizer 1 to n** submenu.

Description Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total

Factory setting Net flow total

Additional information

Selection

- Net flow total
Flow values in the forward and reverse flow direction are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow in the reverse flow direction is totalized (= reverse flow quantity).

Control Totalizer 1 to n

Navigation  Expert → Application → Totalizer 1 to n → Control Tot. 1 to n (0912-1 to n)

Prerequisite A process variable is selected in the **Assign process variable** parameter (→  130) of the **Totalizer 1 to n** submenu.

Description Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize
- Hold

Factory setting Totalize

Additional information *Selection*

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value from the Preset value parameter and the totaling process is restarted.

Preset value 1 to n

Navigation	 Expert → Application → Totalizer 1 to n → Preset value 1 to n (0913-1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 130) of the Totalizer 1 to n submenu.
Description	Use this function to enter a start value for the Totalizer 1 to n.
User entry	Signed floating-point number
Factory setting	0.1
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 130).</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Failure mode

Navigation	 Expert → Application → Totalizer 1 to n → Failure mode (0901-1 to n)
Prerequisite	A process variable is selected in the Assign process variable parameter (→ 130) of the Totalizer 1 to n submenu.
Description	Use this function to select how a totalizer behaves in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value
Factory setting	Stop
Additional information	<p><i>Description</i></p> <p> This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Stop The totalizer is stopped in the event of a device alarm. ■ Actual value The totalizer continues to count based on the actual (current) measured value; the device alarm is ignored. ■ Last valid value The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.5.2 "Custody transfer" submenu

 Only available for Promag W.

 For detailed information on the parameter descriptions for custody transfer measurement, see the Special Documentation for the device → [7](#)

Navigation

 Expert → Application → Custody transfer

▶ Custody transfer

3.6 "Diagnostics" submenu

Navigation

 Expert → Diagnostics

▶ Diagnostics

Actual diagnostics

→ [135](#)

Timestamp

→ [135](#)

Previous diagnostics

→ [135](#)

Timestamp

→ [136](#)

Operating time from restart

→ [136](#)

Operating time

→ [136](#)

▶ Diagnostic list

→ [137](#)

▶ Custody transfer logbook

→ [143](#)

▶ Device information

→ [143](#)

▶ Main electronic module

→ [147](#)

▶ Sensor electronic module (ISEM)

→ [148](#)

▶ Display module

→ [149](#)

▶ Data logging

→ [150](#)

▶ Min/max values

→ [158](#)

▶ Heartbeat Technology

→ [160](#)

▶ Simulation

→ [160](#)

Actual diagnostics

Navigation	  Expert → Diagnostics → Actual diagnos. (0691)
Prerequisite	A diagnostic event has occurred.
Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>Display</i></p>  Additional pending diagnostic messages can be viewed in the Diagnostic list submenu (→  137).
	 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<p><i>Example</i></p> <p>For the display format: ☒F271 Main electronics failure</p>

Timestamp

Navigation	 Expert → Diagnostics → Timestamp
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p>  The diagnostic message can be viewed via the Actual diagnostics parameter (→  135).
	<p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Previous diagnostics

Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Example

For the display format:

 F271 Main electronics failure

Timestamp**Navigation**

 Expert → Diagnostics → Timestamp

Description

Displays the operating time when the last diagnostic message before the current message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Previous diagnostics** parameter (→  135).

Example

For the display format:

24d12h13m00s

Operating time from restart**Navigation**

  Expert → Diagnostics → Time fr. restart (0653)

Description

Use this function to display the time the device has been in operation since the last device restart.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Operating time**Navigation**

  Expert → Diagnostics → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface


Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.6.1 "Diagnostic list" submenu

Navigation
 Expert → Diagnostics → Diagnostic list



Diagnostic Item	Page Number
Diagnostics 1 (0692)	→ 137
Diagnostics 2 (0693)	→ 138
Diagnostics 3 (0694)	→ 139
Diagnostics 4 (0695)	→ 139
Diagnostics 5 (0696)	→ 140

Diagnostics 1

Navigation
 Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 1

Navigation
 Expert → Diagnostics → Diagnostic list → Timestamp
Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

 The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 137).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

Description Displays the current diagnostics message with the second-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:
■  S442 Frequency output
■  F276 I/O module failure

Timestamp 2

Navigation  Expert → Diagnostics → Diagnostic list → Timestamp

Description Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 138).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Displays the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: <ul style="list-style-type: none">▪  S442 Frequency output▪  F276 I/O module failure

Timestamp 3

Navigation	  Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the third-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  139).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Displays the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 4

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 139).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp 5

Navigation	Diagram: Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the fifth-highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>Display</i></p> <p> The diagnostic message can be viewed via the Diagnostics 5 parameter (→ 140).</p>
	<p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>


3.6.2 "Event logbook" submenu

Viewing event messages

Event messages are displayed in chronological order. The event history includes both diagnostic events and information events. The symbol in front of the timestamp indicates whether the event has started or ended.

Navigation

Diagram: Expert → Diagnostics → Event logbook

**Filter options**

Navigation	Diagram: Expert → Diagnostics → Event logbook → Filter options (0705)
Description	Use this function to select the category whose event messages are displayed in the event list of the local display.
Selection	<ul style="list-style-type: none"> ■ All ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Information (I)

Factory setting All

Additional information *Description*

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required


"Event list" submenu

i The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation   Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

 Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→  141).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information

Description

A maximum of 20 event messages are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ΔS442 Frequency output
⊖ 01d04h12min30s

 Additional information, such as remedial measures, can be retrieved via the  key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **Extended HistoROM** application package, see the "Application packages" section of the "Technical Information" document

3.6.3 "Custody transfer logbook" submenu

 Only available for Promag W.

 For detailed information on the parameter descriptions for custody transfer measurement, see the Special Documentation for the device →  7

Navigation

  Expert → Diagnostics → Cust.transf.log.

 Custody transfer logbook

3.6.4 "Device information" submenu

Navigation

  Expert → Diagnostics → Device info

 Device information

Device tag

→  144

Serial number

→  144

Firmware version

→  145

Device name

→  145

Order code

→  145

Extended order code 1

→  146

Extended order code 2

→  146

Extended order code 3	→ 146
Configuration counter	→ 146
ENP version	→ 147

Device tag

Navigation

  Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag

Additional information

User interface



A0029422

1 Position of the header text on the display

The number of characters displayed depends on the characters used.

Serial number

Navigation

  Expert → Diagnostics → Device info → Serial number (0009)

Description

Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information

Description

Uses of the serial number

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation	 Expert → Diagnostics → Device info → Firmware version (0010)
Description	Displays the device firmware version installed.
User interface	Character string in the format xx.yy.zz
Additional information	<p><i>Display</i></p>  The Firmware version is also located: <ul style="list-style-type: none"> ▪ On the title page of the Operating instructions ▪ On the transmitter nameplate

Device name

Navigation	 Expert → Diagnostics → Device info → Device name (0013)
Description	Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.
User interface	Max. 32 characters such as letters or numbers.
Factory setting	Promag 400 MB

Order code



Navigation	 Expert → Diagnostics → Device info → Order code (0008)
Description	Displays the device order code.
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).
Additional information	<p><i>Description</i></p>  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field. The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.
	<p> Uses of the order code</p> <ul style="list-style-type: none"> ▪ To order an identical spare device. ▪ To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information**Description**

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

Displays the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 146)

Extended order code 3**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

Displays the third part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→ 146)

Configuration counter**Navigation**

Expert → Diagnostics → Device info → Config. counter (2751)

Description

Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface


0 to 65 535

ENP version

Navigation	  Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
User interface	Character string
Factory setting	2.02.00
Additional information	<p><i>Description</i></p> <p>This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.</p>

3.6.5 "Main electronic module + I/O module 1" submenu

Navigation   Expert → Diagnostics → Mainboard module

**Firmware version**

Navigation	  Expert → Diagnostics → Main elec. mod. → Firmware version (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

Build no. software

Navigation	  Expert → Diagnostics → Main elec. mod. → Build no. softw. (0079)
Description	Use this function to display the software build number of the module.
User interface	Positive integer

Bootloader revision


Navigation   Expert → Diagnostics → Main elec. mod. → Bootloader rev. (0073)

Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.6.6 "Sensor electronic module (ISEM)" submenu

Navigation   Expert → Diagnostics → Sens. electronic



Firmware version

Navigation   Expert → Diagnostics → Sens. electronic → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation   Expert → Diagnostics → Sens. electronic → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision

Navigation  Expert → Diagnostics → Sens. electronic → Bootloader rev. (0073)


Description Use this function to display the bootloader revision of the software.

User interface Positive integer

3.6.7 "Display module" submenu

Navigation

 Expert → Diagnostics → Display module



Firmware version

Navigation  Expert → Diagnostics → Display module → Firmware version (0072)

Description Use this function to display the software revision of the module.

User interface Positive integer

Build no. software

Navigation  Expert → Diagnostics → Display module → Build no. softw. (0079)

Description Use this function to display the software build number of the module.

User interface Positive integer

Bootloader revision**Navigation**  Expert → Diagnostics → Display module → Bootloader rev. (0073)**Description**

Use this function to display the bootloader revision of the software.

User interface

Positive integer

3.6.8 "Data logging" submenu*Navigation*  Expert → Diagnostics → Data logging

 Data logging	
Assign channel 1	→  151
Assign channel 2	→  151
Assign channel 3	→  152
Assign channel 4	→  152
Logging interval	→  152
Clear logging data	→  153
Data logging	→  153
Logging delay	→  154
Data logging control	→  154
Data logging status	→  155
Entire logging duration	→  155
 Display channel 1	→  155
 Display channel 2	→  156
 Display channel 3	→  157
 Display channel 4	→  157

Assign channel 1

Navigation Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description Use this function to assign a process variable to the logging channel.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature
- Electronics temperature
- Current output 1
- Noise *
- Coil current shot time *
- Reference electrode potential against PE *
- Build-up index *
- Test point 1
- Test point 2
- Test point 3

Factory setting Off

Additional information *Description*

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The log contents are cleared if the option selected is changed.

Assign channel 2

Navigation Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

* Visibility depends on order options or device settings

Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→ 151)
Factory setting	Off

Assign channel 3



Navigation Expert → Diagnostics → Data logging → Assign chan. 3 (0853)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→ 151)
Factory setting	Off

Assign channel 4



Navigation Expert → Diagnostics → Data logging → Assign chan. 4 (0854)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description	Use this function to assign a process variable to the logging channel.
Selection	For the picklist, see Assign channel 1 parameter (→ 151)
Factory setting	Off

Logging interval



Navigation Expert → Diagnostics → Data logging → Logging interval (0856)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 39).

Description	Use this function to enter the logging interval T_{log} for data logging.
User entry	0.1 to 3 600.0 s

Factory setting	1.0 s
------------------------	-------

Additional information	<i>Description</i>
-------------------------------	--------------------

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

 The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data



Navigation	 Expert → Diagnostics → Data logging → Clear logging (0855)
-------------------	--

Prerequisite	The Extended HistoROM application package is available.
---------------------	--

 The software options currently enabled are displayed in the **Software option overview** parameter (→  39).

Description	Use this function to clear the entire logging data.
--------------------	---

Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Clear data
------------------	--

Factory setting	Cancel
------------------------	--------

Additional information	<i>Options</i> <ul style="list-style-type: none"> ▪ Cancel The data is not cleared. All the data is retained. ▪ Clear data The logging data is cleared. The logging process starts from the beginning.
-------------------------------	--

Data logging



Navigation	 Expert → Diagnostics → Data logging → Data logging (0860)
-------------------	---

Description	Use this function to select the data logging method.
--------------------	--

Selection	<ul style="list-style-type: none">▪ Overwriting▪ Not overwriting
Factory setting	Overwriting
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">▪ Overwriting The device memory applies the FIFO principle.▪ Not overwriting Data logging is canceled if the measured value memory is full (single shot).

Logging delay



Navigation	Expert → Diagnostics → Data logging → Logging delay (0859)
Prerequisite	In the Data logging parameter (→ 153), the Not overwriting option is selected.
Description	Use this function to enter the time delay for measured value logging.
User entry	0 to 999 h
Factory setting	0 h
Additional information	<p><i>Description</i></p> <p>Once measured value logging has been started with the Data logging control parameter (→ 154), the device does not log any data for the duration of the time delay entered.</p>

Data logging control



Navigation	Expert → Diagnostics → Data logging → Data log.control (0857)
Prerequisite	In the Data logging parameter (→ 153), the Not overwriting option is selected.
Description	Use this function to start and stop measured value logging.
Selection	<ul style="list-style-type: none">▪ None▪ Delete + start▪ Stop
Factory setting	None
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">▪ None Initial measured value logging status.▪ Delete + start All the measured values recorded for all the channels are deleted and measured value logging starts again.▪ Stop Measured value logging is stopped.

Data logging status

Navigation	 Expert → Diagnostics → Data logging → Data log. status (0858)
Prerequisite	In the Data logging parameter (→ 153), the Not overwriting option is selected.
Description	Displays the measured value logging status.
User interface	<ul style="list-style-type: none"> ■ Done ■ Delay active ■ Active ■ Stopped
Factory setting	Done
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none"> ■ Done Measured value logging has been performed and completed successfully. ■ Delay active Measured value logging has been started but the logging interval has not yet elapsed. ■ Active The logging interval has elapsed and measured value logging is active. ■ Stopped Measured value logging is stopped.

Entire logging duration

Navigation	 Expert → Diagnostics → Data logging → Logging duration (0861)
Prerequisite	In the Data logging parameter (→ 153), the Not overwriting option is selected.
Description	Displays the total logging duration.
User interface	Positive floating-point number
Factory setting	0 s

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1



Display channel 1

Navigation

  Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  39).

In the **Assign channel 1** parameter (→  151), one of the following options is selected:


- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature
- Electronics temperature
- Current output 1

Description

Displays the measured value history for the logging channel in the form of a diagram.

Additional information

Description



A0034352

 9 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation

  Expert → Diagnostics → Data logging → Displ.channel 2



* Visibility depends on order options or device settings

Display channel 2

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite A process variable is determined in the **Assign channel 2** parameter.

Description See the **Display channel 1** parameter

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite A process variable is determined in the **Assign channel 3** parameter.

Description See the **Display channel 1** parameter

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite A process variable is determined in the **Assign channel 4** parameter.


Description

See the **Display channel 1** parameter

3.6.9 "Min/max values" submenu

Navigation


Expert → Diagnostics → Min/max val.



"Main electronics temperature" submenu

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp.



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (6547)

Description

Displays the lowest previously measured temperature value of the main electronics module.

User interface

Signed floating-point number

Additional information*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 51)

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (6545)

Description

Displays the highest previously measured temperature value of the main electronics module.

User interface Signed floating-point number


Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [51](#))

"Medium temperature" submenu

Navigation

 Expert → Diagnostics → Min/max val. → Medium temp.



Minimum value

Navigation  Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (6681)

Description Displays the lowest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [51](#))

Maximum value

Navigation  Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (6680)

Description Displays the highest previously measured medium temperature value.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [51](#))

3.6.10 "Heartbeat" submenu



For detailed information on the parameter descriptions for the **Heartbeat Verification+Monitoring** application package, refer to the Special Documentation for the device → [7](#)

Navigation



Expert → Diagnostics → HBT




3.6.11 "Simulation" submenu

Navigation



Expert → Diagnostics → Simulation



Assign simulation process variable**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity*
- Conductivity*
- Corrected conductivity*
- Temperature*

Factory setting

Off

Additional information*Description*

The simulation value of the process variable selected is defined in the **Process variable value** parameter (→ 161).

Process variable value**Navigation**

Expert → Diagnostics → Simulation → Proc. var. value (1811)

Prerequisite

A process variable is selected in the **Assign simulation process variable** parameter (→ 161).

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 47).

* Visibility depends on order options or device settings

Current output 1 simulation



Navigation

Expert → Diagnostics → Simulation → Curr.outp 1 sim. (0354–1)

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is specified in the **Value current output 1** parameter (→ 162).

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value current output 1



Navigation

Expert → Diagnostics → Simulation → Curr.outp val. (0355)

Expert → Diagnostics → Simulation → Value curr.out 1 (0355–1)

Prerequisite

In the **Current output 1 simulation** parameter, the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

0 to 22.5 mA

Additional information

User entry

The value must be entered with a period (.) as the separator.

Frequency output 1 to n simulation



Navigation

Expert → Diagnostics → Simulation → Freq.outp 1 to n sim. (0472–1 to n)

Prerequisite

In the **Operating mode** parameter (→ 95), the **Frequency** option is selected.

Description	Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p>  The desired simulation value is defined in the Frequency value 1 to n parameter.
	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ On Frequency simulation is active.

Frequency output 1 to n value



Navigation	 Expert → Diagnostics → Simulation → Freq.outp 1 to n val. (0473-1 to n)
Prerequisite	In the Frequency simulation 1 to n parameter, the On option is selected.
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.
User entry	0.0 to 12 500.0 Hz

Pulse output simulation 1 to n



Navigation	 Expert → Diagnostics → Simulation → Puls.outp.sim. 1 to n (0458-1 to n)
Prerequisite	In the Operating mode parameter (→ 95), the Pulse option is selected.
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Fixed value ▪ Down-counting value
Factory setting	Off

Additional information*Description*

The desired simulation value is defined in the **Pulse value 1 to n** parameter.

Selection

- Off

Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Fixed value

Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 98).

- Down-counting value

The pulses specified in the **Pulse value** parameter (→ 164) are output.

Pulse value 1 to n**Navigation**

Expert → Diagnostics → Simulation → Pulse value 1 to n (0459-1 to n)

Prerequisite

In the **Pulse output simulation 1 to n** parameter, the **Down-counting value** option is selected.

Description

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry

0 to 65 535

Switch output simulation 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch sim. 1 to n (0462-1 to n)

Prerequisite

In the **Operating mode** parameter (→ 95), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The desired simulation value is defined in the **Switch state 1 to n** parameter.

Selection

- Off

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- On

Switch simulation is active.

Switch state 1 to n**Navigation**

Expert → Diagnostics → Simulation → Switch state 1 to n (0463-1 to n)

Description

Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.

Selection

- Open
- Closed

Additional information*Selection*

- Open

Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.

- Closed

Switch simulation is active.

Device alarm simulation**Navigation**

Expert → Diagnostics → Simulation → Dev. alarm sim. (0654)

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category

Navigation Expert → Diagnostics → Simulation → Event category (0738)

Description Use this function to select the category of the diagnostic events that are displayed for the simulation in the **Diagnostic event simulation** parameter (→ 166).

Selection

- Sensor
- Electronics
- Configuration
- Process

Factory setting Process

Diagnostic event simulation

Navigation Expert → Diagnostics → Simulation → Diag. event sim. (0737)

Description Use this function to select a diagnostic event for the simulation process that is activated.

Selection

- Off
- Diagnostic event picklist (depends on the category selected)

Factory setting Off

Additional information *Description*

For the simulation, you can choose from the diagnostic events of the category selected in the **Diagnostic event category** parameter (→ 166).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h option
Volume	m ³ option
Conductivity	µS/cm
Temperature	°C option
Mass flow	kg/h option
Mass	kg option
Density	kg/l option

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
150	150
200	300
250	500
300	750
350	1000
375	1200
400	1200
500	2000
600	2500
700	3500
750	4000
800	4500

Nominal diameter [mm]	(v ~ 2.5 m/s) [m ³ /h]
900	6000
1000	7000
1200	10000
1400	14000
1600	18000
1800	23000
2000	28500
2200	34000
2400	40000
2600	48000
2800	55500
3000	63500

4.1.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	(v ~ 0.04 m/s) [dm ³ /min]
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
150	2.5
200	5
250	7.5
300	10
350	15
375	20
400	20
450	25
500	30
600	40
700	50
750	60
800	75

Nominal diameter [mm]	(v ~ 0.04 m/s) [m³/h]
900	100
1000	125
1200	150
1400	225
1600	300
1800	350
2000	450
2200	540
2400	650
2600	775
2800	875
3000	1025

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us) option
Volume	gal (us) option
Temperature	°F option
Mass flow	lb/min option
Mass	lb option
Density	lb/ft³ option

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1	18
1½	50
2	75
3	200
4	300
6	600
8	1200
10	1500
12	2400
14	3600
15	4800

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
16	4800
18	6000
20	7500
24	10500
28	13500
30	16500
32	19500
36	24000
40	30000
42	33000
48	42000

Nominal diameter [in]	(v ~ 2.5 m/s) [Mgal/d]
54	75
60	95
66	120
72	140
78	175
84	190
90	220
96	265
102	300
108	340
114	375
120	415

4.2.3 Switch-on point low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1	0.25
1½	0.75
2	1.25
3	2.5
4	4
6	12
8	15
10	30
12	45
14	60

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
15	60
16	60
18	90
20	120
24	180
28	210
30	270
32	300
36	360
40	480
42	600
48	600

Nominal diameter [in]	(v ~ 0.04 m/s) [Mgal/d]
54	1.3
60	1.3
66	2.2
72	2.6
78	3.0
84	3.2
90	3.6
96	4.0
102	5.0
108	5.0
114	6.0
120	7.0

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano-, Micro-, Milli-, Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro-, Milli-, Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot

Process variable	Units	Explanation
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

6 Modbus RS485 register information

6.1 Notes

6.1.1 Structure of the register information

The individual parts of a parameter description are described in the following section:

Navigation: navigation path to the parameter					
Parameter	Register	Data type	Access type	User interface/ Selection/User entry	→ 
Name of parameter	Indicated in decimal numerical format	<ul style="list-style-type: none"> ■ Float length = 4 byte ■ Integer length = 2 byte ■ String length, depending on parameter 	Possible type of access to parameter: <ul style="list-style-type: none"> ■ Read access via function codes 03, 04 or 23 ■ Write access via function codes 06, 16 or 23 	Options List of the individual options for the parameter <ul style="list-style-type: none"> ■ Option 1 ■ Option 2 ■ Option 3 ⁽⁺⁾  ⁽⁺⁾ = Factory setting depends on country, order options or device settings User entry Specific value or input range for the parameter	Page number information and cross-reference to the standard parameter description

NOTICE

If non-volatile device parameters are modified via the MODBUS RS485 function codes 06, 16 or 23, the change is saved in the EEPROM of the measuring device.

The number of writes to the EEPROM is technically restricted to a maximum of 1 million.

- ▶ Make sure to comply with this limit since, if it is exceeded, data loss and measuring device failure will result.
- ▶ Avoid constantly writing non-volatile device parameters via the MODBUS RS485.

6.1.2 Address model

The Modbus RS485 register addresses of the measuring device are implemented in accordance with the "Modbus Applications Protocol Specification V1.1".

In addition, systems are used that work with the register address model "Modicon Modbus Protocol Reference Guide (PI-MBUS-300 Rev. J)".

Depending on the function code used, a number is added at the start of the register address with this specification:

- "3" → "Read" access
- "4" → "Write" access

Function code	Access type	Register in accordance with "Modbus Applications Protocol Specification"	Register in accordance with "Modicon Modbus Protocol Reference Guide"
03 04 23	Read	XXXX Example: mass flow = 2007	3XXXX Example: mass flow = 32007
06 16 23	Write	XXXX Example: reset totalizer = 6401	4XXXX Example: reset totalizer = 46401

6.2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

► Expert	
Direct access (0106)	→ 181
Locking status (0004)	→ 181
Access status display (0091)	→ 181
Access status tooling (0005)	→ 181
Enter access code (0003)	→ 181
► System	→ 182
► Display	→ 182
Display language (0104)	→ 182
Format display (0098)	→ 182
Value 1 display (0107)	→ 182
0% bargraph value 1 (0123)	→ 182
100% bargraph value 1 (0125)	→ 182
Decimal places 1 (0095)	→ 182
Value 2 display (0108)	→ 182
Decimal places 2 (0117)	→ 182
Value 3 display (0110)	→ 183
0% bargraph value 3 (0124)	→ 183
100% bargraph value 3 (0126)	→ 183
Decimal places 3 (0118)	→ 183
Value 4 display (0109)	→ 183
Decimal places 4 (0119)	→ 183

Display interval (0096)	→ 183
Display damping (0094)	→ 183
Header (0097)	→ 183
Header text (0112)	→ 183
Separator (0101)	→ 183
Contrast display (0105)	→ 183
Backlight (0111)	→ 183
Access status display (0091)	→ 183
► Diagnostic handling	→ 183
Alarm delay (0651)	→ 183
► Diagnostic behavior	→ 183
► Administration	→ 184
► Define access code	→ 184
Device reset (0000)	→ 184
Activate SW option (0029)	→ 184
Software option overview (0015)	→ 184
► Sensor	→ 185
► Measured values	→ 185
► Process variables	→ 185
► Totalizer	→ 185
► System units	→ 186
Volume flow unit (0553)	→ 186
Volume unit (0563)	→ 187
Conductivity unit (0582)	→ 187
Temperature unit (0557)	→ 187

Mass flow unit (0554)	→ 188
Mass unit (0574)	→ 188
Density unit (0555)	→ 188
Date/time format (2812)	→ 188
► User-specific units	→ 188
► Process parameters	→ 189
Filter options (6710)	→ 189
Flow damping (6661)	→ 189
Flow override (1839)	→ 189
Conductivity damping (1803)	→ 189
Conductivity measurement (6514)	→ 189
► Low flow cut off	→ 189
► Empty pipe detection	→ 189
► Electrode cleaning circuit	→ 190
► External compensation	→ 190
Density source (6615)	→ 190
External density (6630)	→ 190
Fixed density (6623)	→ 190
► Sensor adjustment	→ 190
Installation direction (1809)	→ 190
Integration time (6533)	→ 190
Measuring period (6536)	→ 190
► Process variable adjustment	→ 190
► Calibration	→ 191
Nominal diameter (2807)	→ 191

Calibration factor (6522)	→ 191
Zero point (6546)	→ 191
Conductivity calibration factor (6718)	→ 191
► Communication	→ 191
► Modbus configuration	→ 191
Bus address (7112)	→ 191
Baudrate (7111)	→ 191
Data transfer mode (7115)	→ 191
Parity (7122)	→ 191
Byte order (7113)	→ 191
Telegram delay (7146)	→ 191
Failure mode (7116)	→ 191
► Modbus information	→ 191
Device ID (7153)	→ 191
Device revision (7154)	→ 191
► Modbus data map	→ 192
Scan list register 0 to 15 (7114)	→ 192
► Web server	→ 192
Web server language (7221)	→ 192
MAC address (7214)	→ 192
IP address (7209)	→ 192
Subnet mask (7211)	→ 192
Default gateway (7210)	→ 192
Web server functionality (7222)	→ 192

► Application

→ 193

Reset all totalizers (2806)

→ 193

► Totalizer 1 to n

→ 193

Assign process variable (0914-1 to n)

→ 193

Unit totalizer (0915-1 to n)

→ 193

Totalizer operation mode
(0908-1 to n)

→ 193

Control Totalizer 1 to n (0912-1 to n)

→ 193

Preset value 1 to n (0913-1 to n)

→ 194

Failure mode (0901-1 to n)

→ 194

► Diagnostics

→ 194

Actual diagnostics (0691)

→ 194

Previous diagnostics (0690)

→ 194

Operating time from restart (0653)

→ 194

Operating time (0652)

→ 194

► Diagnostic list

→ 194

Diagnostics 1 (0692)

→ 194

Timestamp (0683)

→ 194

Diagnostics 2 (0693)

→ 194

Timestamp (0684)

→ 194

Diagnostics 3 (0694)

→ 194

Timestamp (0685)

→ 194

Diagnostics 4 (0695)

→ 194

Timestamp (0686)

→ 194

Diagnostics 5 (0696)	→ 194
Timestamp (0687)	→ 194
► Event logbook	→ 195
Filter options (0705)	→ 195
► Event list	→ 195
► Device information	→ 195
Device tag (0011)	→ 195
Serial number (0009)	→ 195
Firmware version (0010)	→ 195
Device name (0013)	→ 195
Order code (0008)	→ 195
Extended order code 1 (0023)	→ 195
Extended order code 2 (0021)	→ 195
Extended order code 3 (0022)	→ 195
Configuration counter (2751)	→ 195
ENP version (0012)	→ 195
► Data logging	→ 195
Assign channel 1 (0851)	→ 195
Assign channel 2 (0852)	→ 195
Assign channel 3 (0853)	→ 195
Assign channel 4 (0854)	→ 195
Logging interval (0856)	→ 195
Clear logging data (0855)	→ 195

► Min/max values	→ 195
Reset min/max values (6541)	→ 195
► Main electronics temperature	→ 196
► Simulation	→ 196
Assign simulation process variable (1810)	→ 196
Process variable value (1811)	→ 196
Device alarm simulation (0654)	→ 196
Diagnostic event category (0738)	→ 196
Diagnostic event simulation (0737)	→ 196

6.3 Register information

Navigation: Expert					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Direct access (0106)	3878	Integer	Read / Write	0 to 65535	10
Locking status (0004)	4918	Integer	Read	256 = Hardware locked 512 = Temporarily locked 2048 = CT active - defined parameters 32768 = CT active - all parameters	11
Access status display (0091)	--	Integer	Read	■ Operator ■ Maintenance	12
Access status tooling (0005)	2178	Integer	Read	0 = Operator 1 = Maintenance	12
Enter access code (0003)	2177	Integer	Read / Write	Max. 16-digit character string comprising numbers, letters and special characters	13

6.3.1 "System" submenu

"Display" submenu

Navigation: Expert → System → Display					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Display language (0104)	3673	Integer	Read / Write	0 = English 1 = Deutsch 2 = Français 3 = Español 4 = Italiano 5 = Nederlands 8 = Svenska 10 = Bahasa Indonesia 11 = 日本語 (Japanese) 12 = Portuguesa 13 = Polski 14 = русский язык (Russian) 15 = čeština (Czech) 16 = 中文 (Chinese) 17 = ภาษาไทย (Thai) * 18 = Türkçe 19 = tiếng Việt (Vietnamese) 20 = 한국어 (Korean) 21 = العربية (Arabic) *	14
Format display (0098)	3625	Integer	Read / Write	0 = 1 value, max. size 1 = 1 bargraph + 1 value 2 = 2 values 3 = 1 value large + 2 values 4 = 4 values	15
Value 1 display (0107)	3963	Integer	Read / Write	1 = Volume flow 2 = Mass flow 2 = Conductivity * 3 = Corrected volume flow * 5 = Corrected conductivity * 16 = Totalizer 1 17 = Totalizer 2 18 = Totalizer 3 37 = Flow velocity 39 = Electronics temperature 40 = Noise * 41 = Coil current shot time * 42 = Reference electrode potential against PE * 45 = Build-up index * 51 = Test point 1 52 = Test point 2 53 = Test point 3 121 = Current output 1	17
0% bargraph value 1 (0123)	4136 to 4137	Float	Read / Write	Signed floating-point number	17
100% bargraph value 1 (0125)	4142 to 4143	Float	Read / Write	Signed floating-point number	18
Decimal places 1 (0095)	3365	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = xxxxx	18
Value 2 display (0108)	3964	Integer	Read / Write	For the picklist, see the Value 1 display parameter (→ 17)	19
Decimal places 2 (0117)	4049	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = xxxxx	19

Navigation: Expert → System → Display					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Value 3 display (0110)	3966	Integer	Read / Write	For the picklist, see the Value 1 display parameter (→ 17)	20
0% bargraph value 3 (0124)	4138 to 4139	Float	Read / Write	Signed floating-point number	20
100% bargraph value 3 (0126)	4140 to 4141	Float	Read / Write	Signed floating-point number	21
Decimal places 3 (0118)	4050	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = xxxxx	21
Value 4 display (0109)	3965	Integer	Read / Write	For the picklist, see the Value 1 display parameter (→ 17)	21
Decimal places 4 (0119)	4051	Integer	Read / Write	0 = x 1 = x.x 2 = x.xx 3 = x.xxx 4 = xxxxx	22
Display interval (0096)	3604 to 3605	Float	Read / Write	1 to 10 s	22
Display damping (0094)	3554 to 3555	Float	Read / Write	0.0 to 999.9 s	23
Header (0097)	3624	Integer	Read / Write	0 = Device tag 1 = Free text	23
Header text (0112)	3968 to 3973	String	Read / Write	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	24
Separator (0101)	3671	Integer	Read / Write	▪ . (point) ▪ , (comma)	25
Contrast display (0105)	3674 to 3675	Float	Read / Write	20 to 80 %	25
Backlight (0111)	3967	Integer	Read / Write	0 = Disable 1 = Enable	25
Access status display (0091)	--	Integer	Read	▪ Operator ▪ Maintenance	25

* Visibility depends on order options or device settings

"Diagnostic handling" submenu

Navigation: Expert → System → Diagnostic handling					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Alarm delay (0651)	6808 to 6809	Float	Read / Write	0 to 60 s	26

"Diagnostic behavior" submenu

Navigation: Expert → System → Diagnostic handling → Diagnostic behavior					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign behavior of diagnostic no. 531 (0741)	2397	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	31
Assign behavior of diagnostic no. 832 (0681)	2759	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	31

Navigation: Expert → System → Diagnostic handling → Diagnostic behavior					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign behavior of diagnostic no. 833 (0682)	2762	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	31
Assign behavior of diagnostic no. 862 (0745)	2097	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	33
Assign behavior of diagnostic no. 937 (0743)	2396	Integer	Read / Write	0 = Off 1 = Logbook entry only 2 = Warning 3 = Alarm	33
Assign behavior of diagnostic no. 302 (0739)	2312	Integer	Read / Write	2 = Warning 3 = Alarm	29

"Administration" submenu

Navigation: Expert → System → Administration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Device reset (0000)	6817	Integer	Read / Write	0 = Cancel 1 = Restart device 2 = To delivery settings 25 = Restore S-DAT backup *	37
Activate SW option (0029)	2795	Integer	Read / Write	Max. 10-digit string consisting of numbers.	38
Software option overview (0015)	2902	Integer	Read	1 = Extended HistoROM 8 = 4-20mA,2x pulse/freq./switch output 16 = 4-20mA, switch/certified pulse output 32 = Electrode cleaning circuit 128 = Custody transfer 512 = Build-up index 16384 = Heartbeat Monitoring 32768 = Heartbeat Verification	39

* Visibility depends on order options or device settings

"Define access code" wizard

Navigation: Expert → System → Administration → Define access code					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Define access code	--	Integer	Read / Write	0 to 9999	35
Confirm access code	--	Integer	Read / Write	0 to 9999	36

6.3.2 "Sensor" submenu

"Measured values" submenu

"Process variables" submenu

Navigation: Expert → Sensor → Measured values → Process variables					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Volume flow (1838)	3874 to 3875	Float	Read	Signed floating-point number	41
Mass flow (1847)	3876 to 3877	Float	Read	Signed floating-point number	41
Conductivity (1850)	2013 to 2014	Float	Read	Signed floating-point number	42

"Totalizer" submenu

Navigation: Expert → Sensor → Measured values → Totalizer					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Totalizer value 1 to n (0911–1 to n)	1: 2610 to 2611 2: 2810 to 2811 3: 3010 to 3011	Float	Read	Signed floating-point number	43
Totalizer overflow 1 to n (0910–1 to n)	1: 2612 to 2613 2: 2812 to 2813 3: 3012 to 3013	Float	Read	Integer with sign	44

"System units" submenu

Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→ 
Volume flow unit (0553)	2103	Integer	Read / Write	0 = cm ³ /s 1 = cm ³ /min 2 = cm ³ /h 3 = cm ³ /d 4 = dm ³ /s 5 = dm ³ /min 6 = dm ³ /h 7 = dm ³ /d 8 = m ³ /s 9 = m ³ /min 10 = m ³ /h 11 = m ³ /d 12 = ml/s 13 = ml/min 14 = ml/h 15 = ml/d 16 = l/s 17 = l/min 18 = l/h^(*) 19 = l/d 20 = hl/s 21 = hl/min 22 = hl/h 23 = hl/d 24 = Ml/s 25 = Ml/min 26 = Ml/h 27 = Ml/d 32 = af/s 33 = af/min 34 = af/h 35 = af/d 36 = ft ³ /s 37 = ft ³ /min 38 = ft ³ /h 39 = ft ³ /d 40 = fl oz/s (us) 41 = fl oz/min (us) 42 = fl oz/h (us) 43 = fl oz/d (us) 44 = gal/s (us) 45 = gal/min (us) 46 = gal/h (us) 47 = gal/d (us) 48 = Mgal/s (us) 49 = Mgal/min (us) 50 = Mgal/h (us) 51 = Mgal/d (us) 52 = bbl/s (us;liq.) 53 = bbl/min (us;liq.) 54 = bbl/h (us;liq.) 55 = bbl/d (us;liq.) 56 = bbl/s (us;beer) 57 = bbl/min (us;beer) 58 = bbl/h (us;beer) 59 = bbl/d (us;beer) 60 = bbl/s (us;oil) 61 = bbl/min (us;oil) 62 = bbl/h (us;oil) 63 = bbl/d (us;oil) 64 = bbl/s (us;tank) 65 = bbl/min (us;tank) 66 = bbl/h (us;tank) 67 = bbl/d (us;tank) 68 = gal/s (imp)	48

Navigation: Expert → Sensor → System units					→
Parameter	Register	Data type	Access	Selection / User entry / User interface	
				69 = gal/min (imp) 70 = gal/h (imp) 71 = gal/d (imp) 72 = Mgal/s (imp) 73 = Mgal/min (imp) 74 = Mgal/h (imp) 75 = Mgal/d (imp) 76 = bbl/s (imp;beer) 77 = bbl/min (imp;beer) 78 = bbl/h (imp;beer) 79 = bbl/d (imp;beer) 80 = bbl/s (imp;oil) 81 = bbl/min (imp;oil) 82 = bbl/h (imp;oil) 83 = bbl/d (imp;oil) 88 = kgal/s (us) 89 = kgal/min (us) 90 = kgal/h (us) 91 = kgal/d (us) 92 = MMft³/s 93 = MMft³/min 94 = MMft³/h 96 = Mft³/d	
Volume unit (0563)	2104	Integer	Read / Write	0 = cm³ 1 = dm³ 2 = m³ (*) 3 = ml 4 = l 5 = hl 6 = Ml Mega 8 = af 9 = ft³ 10 = fl oz (us) 11 = gal (us) 12 = Mgal (us) 13 = bbl (us;liq.) 14 = bbl (us;beer) 15 = bbl (us;oil) 16 = bbl (us;tank) 17 = gal (imp) 18 = Mgal (imp) 19 = bbl (imp;beer) 20 = bbl (imp;oil) 22 = kgal (us) 23 = Mft³	50
Conductivity unit (0582)	2121	Integer	Read / Write	1 = MS/m 2 = kS/m 3 = S/m 4 = S/cm 5 = mS/m 6 = mS/cm 7 = µS/m 8 = µS/cm 9 = µS/mm 10 = nS/cm	50
Temperature unit (0557)	2109	Integer	Read / Write	0 = °C (*) 1 = K 2 = °F 3 = °R	51

Navigation: Expert → Sensor → System units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Mass flow unit (0554)	2101	Integer	Read / Write	0 = g/s 1 = g/min 2 = g/h 3 = g/d 4 = kg/s 5 = kg/min 6 = kg/h⁽⁺⁾ 7 = kg/d 8 = t/s 9 = t/min 10 = t/h 11 = t/d 12 = oz/s 13 = oz/min 14 = oz/h 15 = oz/d 16 = lb/s 17 = lb/min 18 = lb/h 19 = lb/d 20 = STon/s 21 = STon/min 22 = STon/h 23 = STon/d	52
Mass unit (0574)	2102	Integer	Read / Write	50 = g 51 = kg⁽⁺⁾ 52 = t 53 = oz 54 = lb 55 = STon	52
Density unit (0555)	2107	Integer	Read / Write	0 = g/cm ³ 2 = kg/dm ³ 3 = kg/l⁽⁺⁾ 4 = kg/m ³ 5 = SD4°C 6 = SD15°C 7 = SD20°C 8 = SG4°C 9 = SG15°C 10 = SG20°C 11 = lb/ft ³ 12 = lb/gal (us) 13 = lb/bbl (us;liq.) 14 = lb/bbl (us;beer) 15 = lb/bbl (us;oil) 16 = lb/bbl (us;tank) 17 = lb/gal (imp) 18 = lb/bbl (imp;beer) 19 = lb/bbl (imp;oil) 21 = g/m ³	53
Date/time format (2812)	2150	Integer	Read / Write	0 = dd.mm.yy hh:mm 1 = mm/dd/yy hh:mm am/pm 2 = dd.mm.yy hh:mm am/pm 3 = mm/dd/yy hh:mm	55

"User-specific units" submenu

Navigation: Expert → Sensor → System units → User-specific units					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
User volume text (0567)	--	String	Read / Write		
User volume offset (0569)	--	Float	Read / Write		

Navigation: Expert → Sensor → System units → User-specific units				
Parameter	Register	Data type	Access	Selection / User entry / User interface
User volume factor (0568)	--	Float	Read / Write	
User mass text (0560)	--	String	Read / Write	
User mass offset (0562)	--	Float	Read / Write	
User mass factor (0561)	--	Float	Read / Write	

"Process parameters" submenu

Navigation: Expert → Sensor → Process parameters					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Filter options (6710)	2273	Integer	Read / Write	1 = Adaptive 2 = Adaptive CIP on 3 = Dynamic 4 = Dynamic CIP on 5 = Binomial 6 = Binomial CIP on	56
Flow damping (6661)	2274	Integer	Read / Write	0 to 15	58
Flow override (1839)	5503	Integer	Read / Write	0 = Off 1 = On	58
Conductivity damping (1803)	5508 to 5509	Float	Read / Write	0 to 999.9 s	59
Conductivity measurement (6514)	2268	Integer	Read / Write	0 = Off 1 = On	59

"Low flow cut off" submenu

Navigation: Expert → Sensor → Process parameters → Low flow cut off					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign process variable (1837)	5101	Integer	Read / Write	0 = Off 1 = Volume flow 2 = Mass flow 3 = Corrected volume flow	61
On value low flow cutoff (1805)	5138 to 5139	Float	Read / Write	Positive floating-point number	61
Off value low flow cutoff (1804)	5104 to 5105	Float	Read / Write	0 to 100.0 %	62
Pressure shock suppression (1806)	5140 to 5141	Float	Read / Write	0 to 100 s	62

"Empty pipe detection" submenu

Navigation: Expert → Sensor → Process parameters → Empty pipe detection					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Empty pipe detection (1860)	5106	Integer	Read / Write	0 = Off 1 = On	64
Switch point empty pipe detection (6562)	2890 to 2891	Float	Read / Write	0 to 100 %	64
Response time empty pipe detection (1859)	5108 to 5109	Float	Read / Write	0 to 100 s	64
Empty pipe adjust value (6527)	2181 to 2182	Float	Read	Positive floating-point number	65
Full pipe adjust value (6548)	2832 to 2833	Float	Read	Positive floating-point number	66
Measured value EPD (6559)	2298 to 2299	Float	Read	Positive floating-point number	66

"Empty pipe adjust" wizard

Navigation: Expert → Sensor → Process parameters → Empty pipe detection → Empty pipe adjust					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
New adjustment (6560)	--	Integer	Read / Write		
Progress (6571)	--	Integer	Read		

"Electrode cleaning circuit" submenu

Navigation: Expert → Sensor → Process parameters → Electrode cleaning circuit					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Electrode cleaning circuit (6528)	2280	Integer	Read / Write	0 = Off 1 = On	67
ECC duration (6555)	2330 to 2331	Float	Read / Write	0.01 to 30 s	67
ECC recovery time (6556)	2332 to 2333	Float	Read / Write	1 to 600 s	67
ECC cleaning cycle (6557)	2328 to 2329	Float	Read / Write	0.5 to 168 h	68
ECC polarity (6631)	2334	Integer	Read	0 = Positive 1 = Negative	68

"External compensation" submenu

Navigation: Expert → Sensor → External compensation					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Density source (6615)	2497	Integer	Read / Write	0 = Fixed density 1 = External density	71
External density (6630)	2117 to 2118	Float	Read	Positive floating-point number	71
Fixed density (6623)	2830 to 2831	Float	Read / Write	Positive floating-point number	72

"Sensor adjustment" submenu

Navigation: Expert → Sensor → Sensor adjustment					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Installation direction (1809)	5501	Integer	Read / Write	0 = Forward flow 1 = Reverse flow	74
Integration time (6533)	2260 to 2261	Float	Read	1 to 65 ms	74
Measuring period (6536)	2852 to 2853	Float	Read	2 to 1000 ms	74

"Process variable adjustment" submenu

Navigation: Expert → Sensor → Sensor adjustment → Process variable adjustment					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Volume flow offset (1831)	5521 to 5522	Float	Read / Write	Signed floating-point number	76
Volume flow factor (1832)	5519 to 5520	Float	Read / Write	Positive floating-point number	75
Mass flow offset (1841)	5525 to 5526	Float	Read / Write	Signed floating-point number	76
Mass flow factor (1846)	5523 to 5524	Float	Read / Write	Positive floating-point number	76
Conductivity offset (1848)	5529 to 5530	Float	Read / Write	Signed floating-point number	77
Conductivity factor (1849)	5527 to 5528	Float	Read / Write	Positive floating-point number	77

"Calibration" submenu

Navigation: Expert → Sensor → Calibration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Nominal diameter (2807)	2048 to 2057	String	Read	DNxx / x"	80
Calibration factor (6522)	2313 to 2314	Float	Read	Positive floating-point number	81
Zero point (6546)	2870 to 2871	Float	Read	Signed floating-point number	81
Conductivity calibration factor (6718)	19806 to 19807	Float	Read	0.01 to 10 000	81

6.3.3 "Communication" submenu**"Modbus configuration" submenu**

Navigation: Expert → Communication → Modbus configuration					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Bus address (7112)	4910	Integer	Read / Write	1 to 247	113
Baudrate (7111)	4912	Integer	Read / Write	0 = 1200 BAUD 1 = 2400 BAUD 2 = 4800 BAUD 3 = 9600 BAUD 4 = 19200 BAUD 5 = 38400 BAUD 6 = 57600 BAUD 7 = 115200 BAUD	113
Data transfer mode (7115)	4913	Integer	Read / Write	0 = RTU 1 = ASCII	114
Parity (7122)	4914	Integer	Read / Write	0 = Even 1 = Odd 2 = None / 2 stop bits 3 = None / 1 stop bit	114
Byte order (7113)	4915	Integer	Read / Write	0 = 0-1-2-3 1 = 3-2-1-0 2 = 2-3-0-1 3 = 1-0-3-2	115
Telegram delay (7146)	4916 to 4917	Float	Read / Write	0 to 100 ms	116
Failure mode (7116)	4920	Integer	Read / Write	1 = Last valid value 255 = NaN value	116

"Modbus information" submenu

Navigation: Expert → Communication → Modbus information					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Device ID (7153)	2547	Integer	Read	4-digit hexadecimal number	118
Device revision (7154)	4481	Integer	Read	4-digit hexadecimal number	118

"Modbus data map" submenu

Navigation: Expert → Communication → Modbus data map					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Scan list register 0 to 15 (7114)	0: 5001 1: 5002 2: 5003 3: 5004 4: 5005 5: 5006 6: 5007 7: 5008 8: 5009 9: 5010 10: 5011 11: 5012 12: 5013 13: 5014 14: 5015 15: 5016	Integer	Read / Write	1 to 65 535	118

"Web server" submenu

Navigation: Expert → Communication → Web server					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Web server language (7221)	4219	Integer	Read / Write	0 = English 1 = Deutsch 2 = Français 3 = Español 4 = Italiano 5 = Nederlands 8 = Svenska 10 = Bahasa Indonesia 11 = 日本語 (Japanese) 12 = Portuguesa 13 = Polski 14 = русский язык (Russian) 15 = čeština (Czech) 16 = 中文 (Chinese)* 17 = ภาษาไทย (Thai)* 18 = Türkçe 19 = tiếng Việt (Vietnamese) 20 = 한국어 (Korean) 21 = العربية (Arabic)*	119
MAC address (7214)	4210 to 4218	String	Read	Unique 12-digit character string comprising letters and numbers	120
IP address (7209)	4155 to 4162	String	Read	4 octet: 0 to 255 (in the particular octet)	120
Subnet mask (7211)	4163 to 4170	String	Read	4 octet: 0 to 255 (in the particular octet)	121
Default gateway (7210)	4171 to 4178	String	Read	4 octet: 0 to 255 (in the particular octet)	121
Web server functionality (7222)	4220	Integer	Read / Write	0 = Off 1 = On	121

* Visibility depends on order options or device settings

6.3.4 "Application" submenu

Navigation: Expert → Application					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Reset all totalizers (2806)	2609	Integer	Read / Write	0 = Cancel 1 = Reset + totalize	129

"Totalizer 1 to n" submenu

Navigation: Expert → Application → Totalizer 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign process variable (0914-1 to n)	1: 2601 2: 2801 3: 3001	Integer	Read / Write	0 = Off 1 = Volume flow 2 = Mass flow 3 = Corrected volume flow	130
Unit totalizer (0915-1 to n)	1: 4604 2: 4605 3: 4606	Integer	Read / Write	0 = cm ³ * 1 = dm ³ * 2 = m ³ * 3 = ml* 4 = l* 5 = hl* 6 = Ml Mega* 8 = af* 9 = ft ³ * 10 = fl oz (us)* 11 = gal (us)* 12 = Mgal (us)* 13 = bbl (us;liq.)* 14 = bbl (us;beer)* 15 = bbl (us;oil)* 16 = bbl (us;tank)* 17 = gal (imp)* 18 = Mgal (imp)* 19 = bbl (imp;beer)* 20 = bbl (imp;oil)* 22 = kgal (us)* 23 = Mft ³ * 50 = g* 51 = kg* 52 = t* 53 = oz* 54 = lb* 55 = STon* 100 = NI* 101 = Nm ³ * 102 = Sm ³ * 103 = Sft ³ * 104 = Sl* 105 = Sgal (us)* 106 = Sbbl (us;liq.)* 107 = Sgal (imp)* 108 = Sbbl (us;oil)* 109 = MMSft ³ * 110 = Nhl* 251 = None*	130
Totalizer operation mode (0908-1 to n)	1: 2605 2: 2805 3: 3005	Integer	Read / Write	0 = Net flow total 1 = Forward flow total 2 = Reverse flow total	131
Control Totalizer 1 to n (0912-1 to n)	1: 2608 2: 2808 3: 3008	Integer	Read / Write	0 = Totalize 1 = Reset + totalize 2 = Preset + hold 3 = Reset + hold 4 = Preset + totalize 5 = Hold	132

Navigation: Expert → Application → Totalizer 1 to n					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Preset value 1 to n (0913-1 to n)	1: 2590 to 2591 2: 2592 to 2593 3: 2594 to 2595	Float	Read / Write	Signed floating-point number	133
Failure mode (0901-1 to n)	1: 2606 2: 2806 3: 3006	Integer	Read / Write	0 = Stop 1 = Actual value 2 = Last valid value	133

* Visibility depends on order options or device settings

6.3.5 "Diagnostics" submenu

Navigation: Expert → Diagnostics					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Actual diagnostics (0691)	2732	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	135
Previous diagnostics (0690)	2734	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	135
Operating time from restart (0653)	2624	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	136
Operating time (0652)	--	String	Read		

"Diagnostic list" submenu

Navigation: Expert → Diagnostics → Diagnostic list					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Diagnostics 1 (0692)	2736	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	137
Timestamp (0683)	2710	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	137
Diagnostics 2 (0693)	2738	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	138
Timestamp (0684)	2701	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	138
Diagnostics 3 (0694)	2740	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	139
Timestamp (0685)	2692	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	139
Diagnostics 4 (0695)	2742	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	139
Timestamp (0686)	2683	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	140
Diagnostics 5 (0696)	2744	Integer	Read	Symbol for diagnostic behavior, diagnostic code and short message.	140
Timestamp (0687)	2675	String	Read	Days (d), hours (h), minutes (m) and seconds (s)	141

"Event logbook" submenu

Navigation: Expert → Diagnostics → Event logbook					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Filter options (0705)	4596	Integer	Read / Write	0 = Failure (F) 4 = Maintenance required (M) 8 = Function check (C) 12 = Out of specification (S) 16 = Information (I) 255 = All	141

"Event list" submenu**"Device information" submenu**

Navigation: Expert → Diagnostics → Device information					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Device tag (0011)	2026 to 2041	String	Read	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	144
Serial number (0009)	7003 to 7008	String	Read	Max. 11-digit character string comprising letters and numbers.	144
Firmware version (0010)	7277 to 7280	String	Read	Character string in the format xx.yy.zz	145
Device name (0013)	7263 to 7270	String	Read	Max. 32 characters such as letters or numbers.	145
Order code (0008)	2058 to 2067	String	Read	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	145
Extended order code 1 (0023)	2212 to 2221	String	Read	Character string	146
Extended order code 2 (0021)	2222 to 2231	String	Read	Character string	146
Extended order code 3 (0022)	2232 to 2241	String	Read	Character string	146
Configuration counter (2751)	4818	Integer	Read	0 to 65 535	146
ENP version (0012)	4003 to 4010	String	Read	Character string	147

"Data logging" submenu

Navigation: Expert → Diagnostics → Data logging					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign channel 1 (0851)	--	Integer	Read / Write		
Assign channel 2 (0852)	--	Integer	Read / Write		
Assign channel 3 (0853)	--	Integer	Read / Write		
Assign channel 4 (0854)	--	Integer	Read / Write		
Logging interval (0856)	--	Float	Read / Write		
Clear logging data (0855)	--	Integer	Read / Write		

"Min/max values" submenu

Navigation: Expert → Diagnostics → Min/max values					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Reset min/max values (6541)	--	Integer	Read / Write		

"Main electronics temperature" submenu

Navigation: Expert → Diagnostics → Min/max values → Main electronics temperature					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Minimum value (6547)	2292 to 2293	Float	Read	Signed floating-point number	158
Maximum value (6545)	2294 to 2295	Float	Read	Signed floating-point number	158

"Simulation" submenu

Navigation: Expert → Diagnostics → Simulation					
Parameter	Register	Data type	Access	Selection / User entry / User interface	→
Assign simulation process variable (1810)	6813	Integer	Read / Write	0 = Off 1 = Volume flow 2 = Mass flow 2 = Conductivity * 3 = Corrected volume flow 5 = Corrected conductivity * 7 = Temperature * 37 = Flow velocity	161
Process variable value (1811)	6814 to 6815	Float	Read / Write	Depends on the process variable selected	161
Device alarm simulation (0654)	6812	Integer	Read / Write	0 = Off 1 = On	165
Diagnostic event category (0738)	4261	Integer	Read / Write	0 = Sensor 1 = Electronics 2 = Configuration 3 = Process	166
Diagnostic event simulation (0737)	4259	Integer	Read / Write	■ Off ■ Diagnostic event picklist (depends on the category selected)	166

* Visibility depends on order options or device settings

Index

0 ... 9

- 0% bargraph value 1 (Parameter) 17
- 0% bargraph value 3 (Parameter) 20
- 2.4 GHz WLAN channel (Parameter) 127
- 100% bargraph value 1 (Parameter) 18
- 100% bargraph value 3 (Parameter) 21

A

- Access status display (Parameter) 12, 25
- Activate SW option (Parameter) 38
- Actual diagnostics (Parameter) 135
- Administration (Submenu) 34
- Alarm delay (Parameter) 26
- Application (Submenu) 129
- Assign behavior of diagnostic no. 043 (Parameter) 28
- Assign behavior of diagnostic no. 302 (Parameter) 29
- Assign behavior of diagnostic no. 376 (Parameter) 29
- Assign behavior of diagnostic no. 377 (Parameter) 29
- Assign behavior of diagnostic no. 441 (Parameter) 30
- Assign behavior of diagnostic no. 442 (Parameter) 30
- Assign behavior of diagnostic no. 443 (Parameter) 30
- Assign behavior of diagnostic no. 531 (Parameter) 31
- Assign behavior of diagnostic no. 832 (Parameter) 31
- Assign behavior of diagnostic no. 833 (Parameter) 31
- Assign behavior of diagnostic no. 834 (Parameter) 32
- Assign behavior of diagnostic no. 835 (Parameter) 32
- Assign behavior of diagnostic no. 842 (Parameter) 33
- Assign behavior of diagnostic no. 937 (Parameter) 33
- Assign behavior of diagnostic no. 938 (Parameter) 34
- Assign behavior of diagnostic no. 961 (Parameter) 34
- Assign behavior of diagnostic no. 962 (Parameter) 33
- Assign channel 1 (Parameter) 151
- Assign channel 2 (Parameter) 151
- Assign channel 3 (Parameter) 152
- Assign channel 4 (Parameter) 152
- Assign diagnostic behavior (Parameter) 106
- Assign flow direction check (Parameter) 110
- Assign frequency output (Parameter) 101
- Assign limit (Parameter) 107
- Assign process variable (Parameter) 61, 64, 130
- Assign pulse output 1 to n (Parameter) 97
- Assign simulation process variable (Parameter) 161
- Assign SSID name (Parameter) 126
- Assign status (Parameter) 110

B

- Backlight (Parameter) 25
- Baudrate (Parameter) 113
- Bootloader revision (Parameter) 149, 150
- Build no. software (Parameter) 148, 149
- Build-up detection (Submenu) 68
- Bus address (Parameter) 113
- Byte order (Parameter) 115

C

- Calibration (Submenu) 80

- Calibration factor (Parameter) 81
- Clear logging data (Parameter) 153
- Communication (Submenu) 112
- Conductivity (Parameter) 42
- Conductivity calibration factor (Parameter) 81
- Conductivity damping (Parameter) 59
- Conductivity factor (Parameter) 77
- Conductivity measurement (Parameter) 59
- Conductivity offset (Parameter) 77
- Conductivity temperature coefficient (Parameter) 60
- Conductivity unit (Parameter) 50
- Configuration counter (Parameter) 146
- Confirm access code (Parameter) 36
- Connection state (Parameter) 128
- Contrast display (Parameter) 25
- Control Totalizer 1 to n (Parameter) 132
- Corrected conductivity (Parameter) 42
- Corrected conductivity factor (Parameter) 79
- Corrected conductivity offset (Parameter) 79
- Corrected volume flow (Parameter) 41
- Corrected volume flow factor (Parameter) 78
- Corrected volume flow offset (Parameter) 77
- Corrected volume flow unit (Parameter) 54
- Corrected volume unit (Parameter) 54
- Current output 1 (Submenu) 82
- Current output 1 simulation (Parameter) 162
- Current output value (Parameter) 162
- Current range output (Parameter) 83
- Custody transfer (Submenu) 134
- Custody transfer logbook (Submenu) 143

D

- Damping current output (Parameter) 91
- Damping output 1 to n (Parameter) 103
- Data logging (Parameter) 153
- Data logging (Submenu) 150
- Data logging control (Parameter) 154
- Data logging status (Parameter) 155
- Data transfer mode (Parameter) 114
- Date/time format (Parameter) 55
- Decimal places 1 (Parameter) 18
- Decimal places 2 (Parameter) 19
- Decimal places 3 (Parameter) 21
- Decimal places 4 (Parameter) 22
- Default gateway (Parameter) 121
- Define access code (Parameter) 35, 37
- Define access code (Wizard) 35
- Density (Parameter) 43
- Density source (Parameter) 71
- Density unit (Parameter) 53
- Device alarm simulation (Parameter) 165
- Device ID (Parameter) 118
- Device information (Submenu) 143
- Device name (Parameter) 145
- Device reset (Parameter) 37
- Device revision (Parameter) 118

Device tag (Parameter)	144	Assign process variable (1860)	64
DHCP client (Parameter)	120	Assign pulse output 1 to n (0460–1 to n)	97
Diagnostic behavior (Submenu)	27	Assign simulation process variable (1810)	161
Diagnostic event category (Parameter)	166	Assign SSID name (2708)	126
Diagnostic event simulation (Parameter)	166	Assign status	
Diagnostic handling (Submenu)	26	Pulse/frequency/switch output 1 to n (0485–1 to n)	110
Diagnostic list (Submenu)	137	Backlight (0111)	25
Diagnostics (Submenu)	134	Baudrate (7111)	113
Diagnostics 1 (Parameter)	137	Bootloader revision (0073)	149, 150
Diagnostics 2 (Parameter)	138	Build no. software (0079)	148, 149
Diagnostics 3 (Parameter)	139	Bus address (7112)	113
Diagnostics 4 (Parameter)	139	Byte order (7113)	115
Diagnostics 5 (Parameter)	140	Calibration factor (6522)	81
Direct access		Clear logging data (0855)	153
0% bargraph value 1 (0123)	17	Conductivity (1850)	42
0% bargraph value 3 (0124)	20	Conductivity calibration factor (6718)	81
2.4 GHz WLAN channel (2704)	127	Conductivity damping (1803)	59
100% bargraph value 1 (0125)	18	Conductivity factor (1849)	77
100% bargraph value 3 (0126)	21	Conductivity measurement (6514)	59
Access status display (0091)	12, 25	Conductivity offset (1848)	77
Activate SW option (0029)	38	Conductivity temperature coefficient (1891)	60
Actual diagnostics (0691)	135	Conductivity unit (0582)	50
Alarm delay (0651)	26	Configuration counter (2751)	146
Assign behavior of diagnostic no. 043 (0650)	28	Connection state (2722)	128
Assign behavior of diagnostic no. 302 (0739)	29	Contrast display (0105)	25
Assign behavior of diagnostic no. 376 (0645)	29	Control Totalizer 1 to n (0912–1 to n)	132
Assign behavior of diagnostic no. 377 (0777)	29	Corrected conductivity (1853)	42
Assign behavior of diagnostic no. 441 (0657)	30	Corrected conductivity factor (1871)	79
Assign behavior of diagnostic no. 442 (0658)	30	Corrected conductivity offset (1870)	79
Assign behavior of diagnostic no. 443 (0659)	30	Corrected volume flow (1851)	41
Assign behavior of diagnostic no. 531 (0741)	31	Corrected volume flow factor (1867)	78
Assign behavior of diagnostic no. 832 (0681)	31	Corrected volume flow offset (1866)	77
Assign behavior of diagnostic no. 833 (0682)	31	Corrected volume flow unit (0558)	54
Assign behavior of diagnostic no. 834 (0700)	32	Corrected volume unit (0575)	54
Assign behavior of diagnostic no. 835 (0702)	32	Current output 1 simulation (0354–1)	162
Assign behavior of diagnostic no. 842 (0638)	33	Current output value (0355)	162
Assign behavior of diagnostic no. 937 (0743)	33	Current range output	
Assign behavior of diagnostic no. 938 (0642)	34	Current output 1 (0353–1)	83
Assign behavior of diagnostic no. 961 (0736)	34	Damping current output	
Assign behavior of diagnostic no. 962 (0745)	33	Current output 1 (0363–1)	91
Assign channel 1 (0851)	151	Damping output 1 to n (0477–1 to n)	103
Assign channel 2 (0852)	151	Data logging (0860)	153
Assign channel 3 (0853)	152	Data logging control (0857)	154
Assign channel 4 (0854)	152	Data logging status (0858)	155
Assign diagnostic behavior		Data transfer mode (7115)	114
Pulse/frequency/switch output 1 to n (0482–1 to n)	106	Date/time format (2812)	55
Assign flow direction check		Decimal places 1 (0095)	18
Pulse/frequency/switch output 1 to n (0484–1 to n)	110	Decimal places 2 (0117)	19
Assign frequency output		Decimal places 3 (0118)	21
Pulse/frequency/switch output 1 to n (0478–1 to n)	101	Decimal places 4 (0119)	22
Assign limit		Default gateway (7210)	121
Pulse/frequency/switch output 1 to n (0483–1 to n)	107	Define access code	37
Assign process variable		Density (1857)	43
Totalizer 1 to n (0914–1 to n)	130	Density source (6615)	71
Assign process variable (1837)	61	Density unit (0555)	53
		Device alarm simulation (0654)	165
		Device ID (7153)	118
		Device name (0013)	145

Device reset (0000)	37
Device revision (7154)	118
Device tag (0011)	144
DHCP client (7212)	120
Diagnostic event category (0738)	166
Diagnostic event simulation (0737)	166
Diagnostics 1 (0692)	137
Diagnostics 2 (0693)	138
Diagnostics 3 (0694)	139
Diagnostics 4 (0695)	139
Diagnostics 5 (0696)	140
Direct access (0106)	10
Display damping (0094)	23
Display interval (0096)	22
Display language (0104)	14
ECC duration (6555)	67
ECC interval (6557)	68
ECC polarity (6631)	68
ECC recovery time (6556)	67
Electrode cleaning cycle (6528)	67
Empty pipe adjust value (6527)	65
ENP version (0012)	147
Enter access code (0003)	13
Entire logging duration (0861)	155
Extended order code 1 (0023)	146
Extended order code 2 (0021)	146
Extended order code 3 (0022)	146
External density (6630)	71
External temperature (6673)	72
Failure behavior current output	
Current output 1 (0364-1)	92
Failure current	
Current output 1 (0352-1)	93
Failure frequency	
Pulse/frequency/switch output 1 to n (0474-1 to n)	105
Failure mode	
Pulse/frequency/switch output 1 to n (0451-1 to n)	104
Pulse/frequency/switch output 1 to n (0480-1 to n)	99
Pulse/frequency/switch output 1 to n (0486-1 to n)	111
Totalizer 1 to n (0901-1 to n)	133
Failure mode (7116)	116
Fieldbus writing access (7156)	117
Filter options (0705)	141
Filter options (6710)	56
Firmware version (0010)	145
Firmware version (0072)	148, 149
Fixed current	
Current output 1 (0365-1)	84
Fixed density (6623)	72
Flow damping (6661)	58
Flow override (1839)	58
Flow velocity (1854)	42
Flow velocity factor (1880)	80
Flow velocity offset (1879)	79
Format display (0098)	15
Frequency output 1 to n simulation (0472-1 to n)	162
Frequency output 1 to n value (0473-1 to n)	163
Full pipe adjust value (6548)	66
Gateway IP address (2719)	128
Header (0097)	23
Header text (0112)	24
Installation direction (1809)	74
Integration time (6533)	74
Invert output signal	
Pulse/frequency/switch output 1 to n (0470-1 to n)	112
IP address (7209)	120
IP address domain name server (2720)	128
Locking status (0004)	11
Logging delay (0859)	154
Logging interval (0856)	152
Login page (7273)	122
Lower range value output	
Current output 1 (0367-1)	84
MAC address (7214)	120
Mass flow (1847)	41
Mass flow factor (1846)	76
Mass flow offset (1841)	76
Mass flow unit (0554)	52
Mass unit (0574)	52
Maximum frequency value	
Pulse/frequency/switch output 1 to n (0454-1 to n)	101
Maximum value (6545)	158
Maximum value (6680)	159
Measured current 1 (0366-1)	46, 94
Measured value EPD (6559)	66
Measuring mode	
Pulse/frequency/switch output 1 to n (0457-1 to n)	99
Pulse/frequency/switch output 1 to n (0479-1 to n)	103
Measuring mode current output	
Current output 1 (0351-1)	87
Measuring period (6536)	74
Measuring value at maximum frequency	
Pulse/frequency/switch output 1 to n (0475-1 to n)	102
Measuring value at minimum frequency	
Pulse/frequency/switch output 1 to n (0476-1 to n)	102
Minimum frequency value	
Pulse/frequency/switch output 1 to n (0453-1 to n)	101
Minimum value (6547)	158
Minimum value (6681)	159
Network security (2705)	124
New adjustment (6560)	65
Nominal diameter (2807)	80
Off value low flow cutoff (1804)	62
On value low flow cutoff (1805)	61

Operating mode	Switch-off value
Pulse/frequency/switch output 1 to n (0469-1 to n)	Pulse/frequency/switch output 1 to n (0464-1 to n)
Operating time (0652)	109
Operating time from restart (0653)	Switch-on delay
Order code (0008)	Pulse/frequency/switch output 1 to n (0467-1 to n)
Output current 1 (0361-1)	110
Output frequency 1 (0471-1)	Switch-on value
Output frequency 1 to n (0471-1 to n)	Pulse/frequency/switch output 1 to n (0466-1 to n)
Output frequency 2 (0471-2)	109
Parity (7122)	Telegram delay (7146)
Preset value 1 to n (0913-1 to n)	116
Pressure shock suppression (1806)	Temperature (1852)
Previous diagnostics (0690)	42
Process variable current output	Temperature damping (1886)
Current output 1 (0359-1)	60
Process variable value (1811)	Temperature factor (1869)
Progress (6571)	78
Pulse output 1 (0456-1)	Temperature offset (1868)
Pulse output 1 to n (0456-1 to n)	78
Pulse output 2 (0456-2)	Temperature source (6712)
Pulse output simulation 1 to n (0458-1 to n)	72
Pulse scaling	Temperature unit (0557)
Pulse/frequency/switch output 1 to n (0455-1 to n)	51
Pulse value 1 to n (0459-1 to n)	Timestamp
Pulse width	135, 136, 137, 138, 139, 140, 141
Pulse/frequency/switch output 1 to n (0452-1 to n)	Totalizer operation mode
Received signal strength (2721)	Totalizer 1 to n (0908-1 to n)
Reference density (1885)	131
Reference temperature (1816)	Totalizer overflow 1 to n (0910-1 to n)
Reset access code (0024)	44
Reset all totalizers (2806)	Totalizer value 1 to n (0911-1 to n)
Response time	43
Pulse/frequency/switch output 1 to n (0491-1 to n)	Unit totalizer 1 to n (0915-1 to n)
Response time empty pipe detection (1859)	130
Scan list register 0 to 15 (7114)	Upper range value output
Security identification (2718)	Current output 1 (0372-1)
Select antenna (2713)	86
Separator (0101)	User name (2715)
Serial number (0009)	125
Software option overview (0015)	User role (0005)
SSID name (2707)	12
SSID name (2714)	Value 1 display (0107)
Subnet mask (7211)	17
Switch output function	Value 2 display (0108)
Pulse/frequency/switch output 1 to n (0481-1 to n)	19
Switch output simulation 1 to n (0462-1 to n)	Value 3 display (0110)
Switch point empty pipe detection (6562)	20
Switch state 1 (0461-1)	Value 4 display (0109)
Switch state 1 to n (0461-1 to n)	21
Switch state 1 to n (0463-1 to n)	Value current output 1 (0355-1)
Switch state 2 (0461-2)	162
Switch-off delay	Volume flow (1838)
Pulse/frequency/switch output 1 to n (0465-1 to n)	41
Display (Submenu)	Volume flow factor (1832)
Display channel 1 (Submenu)	75
Display channel 2 (Submenu)	Volume flow offset (1831)
Display channel 3 (Submenu)	76
Display channel 4 (Submenu)	Volume flow unit (0553)
Display damping (Parameter)	48
Display interval (Parameter)	Volume unit (0563)
Display language (Parameter)	50
Display module (Submenu)	Web server functionality (7222)
Document	121
Explanation of the structure of a parameter description	119

Function	4	Heartbeat Technology (Submenu)	160	
Structure	4			
Symbols used	6			
Target group	4			
Using the document	4			
Document function	4			
E				
ECC duration (Parameter)	67			
ECC interval (Parameter)	68			
ECC polarity (Parameter)	68			
ECC recovery time (Parameter)	67			
Electrode cleaning circuit (Submenu)	66			
Electrode cleaning cycle (Parameter)	67			
Empty pipe adjust value (Parameter)	65			
Empty pipe detection (Submenu)	63			
ENP version (Parameter)	147			
Enter access code (Parameter)	13			
Entire logging duration (Parameter)	155			
Event list (Submenu)	142			
Event logbook (Submenu)	141			
Expert (Menu)	10			
Extended order code 1 (Parameter)	146			
Extended order code 2 (Parameter)	146			
Extended order code 3 (Parameter)	146			
External compensation (Submenu)	71			
External density (Parameter)	71			
External temperature (Parameter)	72			
F				
Factory settings	167			
SI units	167			
US units	169			
Failure behavior current output (Parameter)	92			
Failure current (Parameter)	93			
Failure frequency (Parameter)	105			
Failure mode (Parameter)	99, 104, 111, 116, 133			
Fieldbus writing access (Parameter)	117			
Filter options (Parameter)	56, 141			
Firmware version (Parameter)	145, 148, 149			
Fixed current (Parameter)	84			
Fixed density (Parameter)	72			
Flow damping (Parameter)	58			
Flow override (Parameter)	58			
Flow velocity (Parameter)	42			
Flow velocity factor (Parameter)	80			
Flow velocity offset (Parameter)	79			
Format display (Parameter)	15			
Frequency output 1 to n simulation (Parameter)	162			
Frequency output 1 to n value (Parameter)	163			
Full pipe adjust value (Parameter)	66			
Function				
see Parameter				
G				
Gateway IP address (Parameter)	128			
H				
Header (Parameter)	23			
Header text (Parameter)	24			
I				
Installation direction (Parameter)	74			
Integration time (Parameter)	74			
Invert output signal (Parameter)	112			
IP address (Parameter)	120			
IP address domain name server (Parameter)	128			
L				
Locking status (Parameter)	11			
Logging delay (Parameter)	154			
Logging interval (Parameter)	152			
Login page (Parameter)	122			
Low flow cut off (Submenu)	61			
Lower range value output (Parameter)	84			
M				
MAC address (Parameter)	120			
Main electronics temperature (Submenu)	158			
Mainboard module (Submenu)	147			
Mass flow (Parameter)	41			
Mass flow factor (Parameter)	76			
Mass flow offset (Parameter)	76			
Mass flow unit (Parameter)	52			
Mass unit (Parameter)	52			
Maximum frequency value (Parameter)	101			
Maximum value (Parameter)	158, 159			
Measured current 1 (Parameter)	46, 94			
Measured value EPD (Parameter)	66			
Measured values (Submenu)	40			
Measuring mode (Parameter)	99, 103			
Measuring mode current output (Parameter)	87			
Measuring period (Parameter)	74			
Measuring value at maximum frequency (Parameter)	102			
Measuring value at minimum frequency (Parameter)	102			
Medium temperature (Submenu)	159			
Menu				
Expert	10			
Min/max values (Submenu)	158			
Minimum frequency value (Parameter)	101			
Minimum value (Parameter)	158, 159			
Modbus configuration (Submenu)	113			
Modbus data map (Submenu)	118			
Modbus information (Submenu)	117			
N				
Network security (Parameter)	124			
New adjustment (Parameter)	65			
Nominal diameter (Parameter)	80			
O				
Off value low flow cutoff (Parameter)	62			
On value low flow cutoff (Parameter)	61			
Operating mode (Parameter)	95			
Operating time (Parameter)	36, 136			
Operating time from restart (Parameter)	136			
Order code (Parameter)	145			

Output (Submenu)	81
Output current 1 (Parameter)	45, 93
Output frequency 1 (Parameter)	47
Output frequency 1 to n (Parameter)	105
Output frequency 2 (Parameter)	47
Output values (Submenu)	45

P

Parameter

Structure of a parameter description	6
Parity (Parameter)	114
Preset value 1 to n (Parameter)	133
Pressure shock suppression (Parameter)	62
Previous diagnostics (Parameter)	135
Process parameters (Submenu)	55
Process variable adjustment (Submenu)	74
Process variable current output (Parameter)	82
Process variable value (Parameter)	161
Process variables (Submenu)	40
Progress (Parameter)	65
Pulse output 1 (Parameter)	46
Pulse output 1 to n (Parameter)	100
Pulse output 2 (Parameter)	46
Pulse output simulation 1 to n (Parameter)	163
Pulse scaling (Parameter)	97
Pulse value 1 to n (Parameter)	164
Pulse width (Parameter)	98
Pulse/frequency/switch output 1 to n (Submenu)	94

R

Received signal strength (Parameter)	128
Reference density (Parameter)	60
Reference temperature (Parameter)	73
Reset access code (Parameter)	36
Reset access code (Submenu)	36
Reset all totalizers (Parameter)	129
Response time (Parameter)	104
Response time empty pipe detection (Parameter)	64

S

Scan list register 0 to 15 (Parameter)	118
Security identification (Parameter)	124
Select antenna (Parameter)	127
Sensor (Submenu)	40
Sensor adjustment (Submenu)	73
Sensor electronic module (ISEM) (Submenu)	148
Separator (Parameter)	25
Serial number (Parameter)	144
Simulation (Submenu)	160
Software option overview (Parameter)	39
SSID name (Parameter)	124, 127
Submenu	
Administration	34
Application	129
Build-up detection	68
Calibration	80
Communication	112
Current output 1	82
Custody transfer	134

Custody transfer logbook	143
Data logging	150
Device information	143
Diagnostic behavior	27
Diagnostic handling	26
Diagnostic list	137
Diagnostics	134
Display	13
Display channel 1	155
Display channel 2	156
Display channel 3	157
Display channel 4	157
Display module	149
Electrode cleaning circuit	66
Empty pipe detection	63
Event list	142
Event logbook	141
External compensation	71
Heartbeat Technology	160
Low flow cut off	61
Main electronics temperature	158
Mainboard module	147
Measured values	40
Medium temperature	159
Min/max values	158
Modbus configuration	113
Modbus data map	118
Modbus information	117
Output	81
Output values	45
Process parameters	55
Process variable adjustment	74
Process variables	40
Pulse/frequency/switch output 1 to n	94
Reset access code	36
Sensor	40
Sensor adjustment	73
Sensor electronic module (ISEM)	148
Simulation	160
System	13
System units	47
Totalizer	43
Totalizer 1 to n	129
Web server	119
Subnet mask (Parameter)	121
Switch output function (Parameter)	105
Switch output simulation 1 to n (Parameter)	164
Switch point empty pipe detection (Parameter)	64
Switch state 1 (Parameter)	47
Switch state 1 to n (Parameter)	111, 165
Switch state 2 (Parameter)	47
Switch-off delay (Parameter)	111
Switch-off value (Parameter)	109
Switch-on delay (Parameter)	110
Switch-on value (Parameter)	109
System (Submenu)	13
System units (Submenu)	47

T

Target group	4
Telegram delay (Parameter)	116
Temperature (Parameter)	42
Temperature damping (Parameter)	60
Temperature factor (Parameter)	78
Temperature offset (Parameter)	78
Temperature source (Parameter)	72
Temperature unit (Parameter)	51
Timestamp (Parameter)	
.	135, 136, 137, 138, 139, 140, 141
Totalizer (Submenu)	43
Totalizer 1 to n (Submenu)	129
Totalizer operation mode (Parameter)	131
Totalizer overflow 1 to n (Parameter)	44
Totalizer value 1 to n (Parameter)	43

U

Unit totalizer 1 to n (Parameter)	130
Upper range value output (Parameter)	86
User name (Parameter)	125
User role (Parameter)	12

V

Value 1 display (Parameter)	17
Value 2 display (Parameter)	19
Value 3 display (Parameter)	20
Value 4 display (Parameter)	21
Value current output 1 (Parameter)	162
Volume flow (Parameter)	41
Volume flow factor (Parameter)	75
Volume flow offset (Parameter)	76
Volume flow unit (Parameter)	48
Volume unit (Parameter)	50

W

Web server (Submenu)	119
Web server functionality (Parameter)	121
Web server language (Parameter)	119
Wizard	
Define access code	35
WLAN settings	122
WLAN (Parameter)	123
WLAN IP address (Parameter)	125
WLAN MAC address (Parameter)	125
WLAN mode (Parameter)	123
WLAN passphrase (Parameter)	126
WLAN password (Parameter)	125
WLAN settings (Wizard)	122
WLAN subnet mask (Parameter)	126

Z

Zero point (Parameter)	81
----------------------------------	----



71538157

www.addresses.endress.com
