
KA01494D/06/EN/02.22-00

71552847 2022-01-15

Brief Operating Instructions **Proline 800**

with electromagnetic sensor Modbus RS485




These instructions are Brief Operating Instructions; they are **not** a substitute for the Operating Instructions pertaining to the device.

Brief Operating Instructions part 2 of 2: Transmitter Contain information about the transmitter.

Brief Operating Instructions part 1 of 2: Sensor $\rightarrow \implies 3$





Brief Operating Instructions for flowmeter

The device consists of a transmitter and a sensor.

The process of commissioning these two components is described in two separate manuals that together form the Brief Operating Instructions for the flowmeter:

- Brief Operating Instructions Part 1: Sensor
- Brief Operating Instructions Part 2: Transmitter

Please refer to both parts of the Brief Operating Instructions when commissioning the device, as the contents of the manuals complement one another:

Brief Operating Instructions Part 1: Sensor

The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device.

- Incoming acceptance and product identification
- Storage and transport
- Installation

Brief Operating Instructions Part 2: Transmitter

The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value).

- Product description
- Installation
- Electrical connection
- Operation options
- System integration
- Commissioning
- Diagnostic information

Additional device documentation



These Brief Operating Instructions are **Brief Operating Instructions Part 2: Transmitter**.

The "Brief Operating Instructions Part 1: Sensor" are available via:

- Internet: www.endress.com/deviceviewer
- Smart phone/tablet: Endress+Hauser Operations App

Detailed information about the device can be found in the Operating Instructions and the other documentation:

- Internet: www.endress.com/deviceviewer
- Smart phone/tablet: Endress+Hauser Operations App

Table of contents

1	About this document	5
1.1	Symbols used	5
2	Safety instructions	7
2.1	Requirements for the personnel	7
2.2	Intended use	7
2.3	Workplace safety	
2.4	Operational safety	
2.5 2.6	Product safety	
2.0 2.7	IT security Device-specific IT security	9
3	Product description	9
	•	
4	Mounting	9
4.1	Mounting the measuring device	10
4.2	Transmitter post-installation check	16
5	Electrical connection 1	7
5.1	Electrical safety	17
5.2	Connecting requirements	17
5.3	Connecting the measuring device	21
5.4	Power supply via battery packs Proline 800	
5.5	Power supply via battery packs, Proline 800 - Advanced	28
5.6 5.7	Connecting the pressure sensor, Proline 800 - Advanced Power supply via the external battery pack, Proline 800 - Advanced	5⊥ 21
5.8	Ensuring potential equalization	
5.9	Special connection instructions	
5.10	Ensuring potential equalization	
5.11	Post-connection check	40
6	Operation options	1
6.1	Overview of operation options	
6.2	Access to the operating menu via the SmartBlue app	
7	System integration	12
8	Commissioning	
o 8.1	Function check	
8.1 8.2	Function cneck 2 Preparatory steps 2	+2 42
8.3	Configuring the measuring device	43
8.4	Protecting settings from unauthorized access	43
9	Diagnostic information	5،
9.1	Diagnostic message	

1 About this document

1.1 Symbols used

1.1.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.1.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	Direct current	\sim	Alternating current
~	Direct current and alternating current	<u> </u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Symbol	Meaning
	Potential equalization connection (PE: protective earth) Ground terminals that must be connected to ground prior to establishing any other connections.
	The ground terminals are located on the interior and exterior of the device:Interior ground terminal: potential equalization is connected to the supply network.Exterior ground terminal: device is connected to the plant grounding system.

1.1.3 Communication-specific symbols

Symbol	Meaning	Symbol	Meaning
8	Bluetooth Wireless data transmission between devices over a short distance.		

1.1.4 Tool symbols

Symbol	Meaning	Symbol	Meaning
0	Torx screwdriver		Flat-blade screwdriver
•	Phillips head screwdriver	$\bigcirc \not \blacksquare$	Allen key
Ŕ	Open-ended wrench		

1.1.5 Symbols for certain types of information

Symbol	Meaning	Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.		Preferred Procedures, processes or actions that are preferred.
\mathbf{X}	Forbidden Procedures, processes or actions that are forbidden.	i	Tip Indicates additional information.
Ĩ	Reference to documentation		Reference to page
	Reference to graphic	1., 2., 3	Series of steps
4	Result of a step		Visual inspection

1.1.6 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3,	Item numbers	1., 2., 3	Series of steps
A, B, C, Views A-A, B-B, C-C, Se		Sections	
Hazardous area		×	Safe area (non-hazardous area)
≈➡	Flow direction		

2 Safety instructions

2.1 Requirements for the personnel

The personnel must fulfill the following requirements for its tasks:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids with a minimum conductivity of $20 \ \mu$ S/cm.

Measuring devices for use in applications where there is an increased risk due to process pressure are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified pressure and temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ► Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ► If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation.
- Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- ► Verify the compatibility of the process fluid with the sensor material.
- Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

 For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

WARNING

If the temperature of the media or electronics unit is high or low, this may cause the surfaces of the device to become hot or cold. This poses a risk of burns or frostbite!

► In the case of hot or cold medium temperatures, install appropriate protection against contact.

2.3 Workplace safety

For work on and with the device:

• Wear the required personal protective equipment according to national regulations.

For welding work on the piping:

• Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

• Due to the increased risk of electric shock, wear suitable gloves.

2.4 Operational safety

Risk of injury.

- Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet stateof-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

Furthermore, the device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards.

By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com

2.6 IT security

Our warranty is valid only if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the device and associated data transfer, must be implemented by the operators themselves in line with their security standards

2.7 **Device-specific IT security**

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly.



For detailed information on device-specific IT security, see the Operating Instructions for the device

3 Product description

The device consists of a transmitter and a sensor.

Proline Promag 800

Compact version - transmitter and sensor form a mechanical unit.

Proline Promag 800 - Advanced

Two device versions are available:

- Compact version transmitter and sensor form a mechanical unit.
- Remote version transmitter and sensor are mounted in separate locations.



For detailed information on the product description, see the Operating Instructions for the device $\rightarrow \square 3$

Mounting 4



For detailed information about mounting the sensor, see the Sensor Brief Operating Instructions $\rightarrow \cong 3$

4.1 Mounting the measuring device

4.1.1 Screw tightening torques

For detailed information on the screw tightening torques, see the "Mounting the sensor" section of the Brief Operating Instructions

4.1.2 Mounting the transmitter of the remote version, Proline 800 - Advanced

ACAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature .
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

ACAUTION


Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting

Wall mounting Proline 800 - Advanced




■ 1 Engineering unit mm (in)

WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.


► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)




2 Engineering unit mm (in)

4.1.3 Turning the transmitter housing, Proline 800 - Advanced


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




- **1.** Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque $\rightarrow \cong 15$).
- 2. Open the housing cover.




- 3. Open the display module.
- 4. Push the ribbon cable out of the holder.
- 5. Disconnect the plug.



- 6. Push the display module down gently at the hinge.
- 7. Pull the display module out of the holder.




8. Disconnect the plug of the electronics module.




A0042853


9. Release the screws on the electronics module.



10. Remove the electronics module.



- **11.** Loosen the fixing screws of the main electronics module (when reassembling, pay attention to the tightening torque $\rightarrow \cong 15$).
- **12.** Remove the main electronics module.



- 14. Lift the transmitter housing.
- **15.** Turn the housing to the desired position in increments of 90°.

Reassembling the transmitter housing


WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

▶ Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)

Step → 🗎 11	Fixing screw	Tightening torques
1	Housing cover	1 Nm (0.7 lbf ft)
9	Electronics module	0.6 Nm (0.4 lbf ft)
11	Main electronics module	1.5 Nm (1.1 lbf ft)
13	Transmitter housing	5.5 Nm (4.1 lbf ft)



▶ Reverse the procedure to reassemble the measuring device.

4.1.4 Mounting the external battery pack

The external battery pack is mounted in the same way as the remote version of the transmitter $\rightarrow \cong 10$.

4.2 Transmitter post-installation check

The post-installation check must always be performed after the following tasks:

- Mounting the transmitter housing:
 - Post mounting
 - Wall mounting
- Turning the transmitter housing

Is the device undamaged (visual inspection)?	
Turning the transmitter housing:Is the securing screw firmly tightened?Is the connection compartment cover screwed on tightly?Is the securing clamp tightened correctly?	
Post and wall mounting: Are the securing screws tightened securely?	

5 **Electrical connection**

NOTICE

In the device versions with a mains connection (order code for "Power supply" option K or S), the device does not have an internal circuit breaker to disconnect from the power supply network.

- ▶ For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.
- ► Although the measuring device is equipped with a fuse, additional overcurrent protection (maximum 16 A) should be integrated into the system installation.

5.1 **Electrical safety**

In accordance with applicable national regulations.

5.2 **Connecting requirements**

5.2.1 Required tool

- Torgue wrench
- For cable entries: use appropriate tool
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: flat blade screwdriver $\leq 3 \text{ mm} (0.12 \text{ in})$

5.2.2 **Requirements for connecting cable**

The connecting cables provided by the customer must fulfill the following requirements.

Permitted temperature range

- The installation quidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

Pulse /switch output

Standard installation cable is sufficient.

Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.



For detailed information about the specification of the connecting cable, see the Operating Instructions for the device.

Connecting cable for remote version

The remote version is connected via an electrode cable and a coil current cable.



For detailed information about the specification of the connecting cables, see the Operating Instructions for the device.

Armored connecting cable

Armored connecting cables with an additional, reinforcing metal braid should be used:

- When laying the cable directly in the ground
- Where there is a risk of damage from rodents
- If using the device below IP68 degree of protection

Operation in environments with strong electrical interference

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.



The selection of a sensor with a steel housing is recommended for use in the vicinity of electrical power supply lines with strong currents.

Cable diameter

- Cable glands supplied:
 - For standard cable: M20 \times 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
 - For reinforced cable: M20 × 1.5 with cable ϕ 9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

5.2.3 Terminal assignment

In addition to the inputs and outputs available, information on the terminal assignment for the electrical connection can be found on the connection nameplate on the main electronics module.

For detailed information on the terminal assignment, see the Operating Instructions for the device $\rightarrow \cong 3$

5.2.4 Shielding and grounding

Shielding and grounding concept

- 1. Maintain electromagnetic compatibility (EMC).
- 2. Pay attention to the protection of persons.
- 3. Comply with national installation regulations and guidelines.
- 4. Observe cable specifications .
- 5. Keep the stripped and twisted lengths of cable shield to the ground terminal as short as possible.
- 6. Shield cables fully.

Grounding of the cable shield

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

- Only ground the bus cable shield to either the local ground or the protective ground at one end.
- Insulate the shield that is not connected.

To comply with EMC requirements:

- 1. Ensure the cable shield is grounded to the potential matching line at multiple points.
- 2. Connect every local ground terminal to the potential matching line.

5.2.5 Requirements for the supply unit

Supply voltage

Order code "Power supply"	Terminal numbers	Terminal voltage		Frequency range
Option K		DC 24 V	-20 to +25 %	-
Option S (wide range power unit)	1 (L+/L), 2 (L-/N)	AC 100 to 240 V	-15 to +10 %	50/60 Hz, ±3 Hz

5.2.6 Preparing the measuring device

Carry out the steps in the following order:

- 1. Mount the sensor and transmitter.
- 2. Sensor connection housing: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.
- 4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.


- ► Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- 3. If the measuring device is supplied with cable glands: Observe requirements for connecting cables .

5.2.7 Preparing the connecting cable for the remote version


When terminating the connecting cable, pay attention to the following points:

- In the case of the electrode cable: Make sure that the ferrules do not touch the core shields on the sensor side. Minimum distance = 1 mm (exception: green "GND" cable)
- In the case of the coil current cable:
 Insulate one core of the three-core cable at the level of the core reinforcement. You only require two cores for the connection.
- 3. For cables with fine-wire cores (stranded cables): Fit the cores with ferrules.

Transmitter



Sensor



5.3 Connecting the measuring device

WARNING

Risk of electric shock! Components carry dangerous voltages!

- ► Have electrical connection work carried out by correspondingly trained specialists only.
- ► Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- Observe grounding concept of the plant.
- ► Never mount or wire the measuring device while it is connected to the supply voltage.
- Before the supply voltage is applied, connect the protective ground to the measuring device.

5.3.1 Connecting the remote version

WARNING

Risk of damaging electronic components!


- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

The following sequence of steps is recommended for the remote version:

- 1. Mount the sensor and transmitter.
- 2. Connect the connecting cable of the remote version.
- 3. Connect the transmitter.

Connecting the connecting cable to the sensor connection housing

Promag W



☑ 5 Sensor: connection module

- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew and lift off the housing cover.

3. NOTICE

For conduit extensions:

► Fit O-ring on cable and push it back sufficiently. When inserting the cable, the O-ring must be located outside the conduit extension.

Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.

- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules $\rightarrow \triangleq 20$.
- 5. Connect the cable according to the terminal assignment .
- 6. Firmly tighten the cable glands.


7. **WARNING**

Housing degree of protection may be voided due to insufficient sealing of the housing.

 Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the procedure to reassemble the sensor.

Attaching the connecting cable to the transmitter



6 Transmitter: main electronics module with terminals

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules $\rightarrow \cong 20$.
- 5. Connect the cable in accordance with the terminal assignment .
- 6. Firmly tighten the cable glands.

7. **A** WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

▶ Screw in the screw without using any lubricant.

Reverse the removal procedure to reassemble the transmitter.

5.3.2 Connecting the transmitter


WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

► Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Tightening torques for plastic housing

Housing cover fixing screw	1.3 Nm
Cable entry	4.5 to 5 Nm
Ground terminal	2.5 Nm



Connecting the supply voltage and Modbus RS485

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- **3.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.

- 5. Connect the cable in accordance with the terminal assignment . For supply voltage: open the shock protection cover.
- 6. Firmly tighten the cable glands.

Reassembling the transmitter

- 1. Close the shock protection cover.
- 2. Close the housing cover.
- 3. **WARNING**


Housing degree of protection may be voided due to insufficient sealing of the housing.

Screw in the screw without using any lubricant.

Tighten the 4 fixing screws on the housing cover.

5.4 Power supply via battery packs Proline 800


5.4.1 Battery pack arrangement



1 Battery pack


5.4.2 Inserting and connecting the battery pack

The device is delivered either with the batteries already installed, or enclosed separately, depending on national standards and guidelines. If the batteries are ready installed and connected when the device is delivered, make sure that the "B" switch is set to "On".




• Open electronics carrier cover.

► Switch "B" to "ON".




- ► Insert the plug of the battery and place the cable in the slot of the battery carrier, as shown in the graphic. Place battery in battery compartment.
- Close the cover of the electronics carrier.






- Place the cover on the transmitter housinig.
- ► Turn cover 1/4 to the right.



► Turn cover 1/4 to the left.

5.5 Power supply via battery packs, Proline 800 - Advanced

5.5.1 Battery pack arrangement



- 1 Battery pack 1
- 2 Battery pack 2
- 3 Buffer capacitor


5.5.2 Inserting and connecting buffer capacitors and battery packs

2 →

- The device is delivered either with the batteries already installed, or enclosed separately, depending on national standards and guidelines. If the batteries are inserted and connected upon delivery, to operate the device it is important to ensure that switch "B" is set to "ON" and the ribbon cable is connected to the electronics module.
- 1

The device starts once the buffer capacitor is connected. After 15 seconds, a measured value appears on the display.

Connect the battery packs immediately once the buffer capacitor has been connected.




 Open the connection compartment cover.




- Open the display module.
- A B Control of the second seco
- Set switch "B" to "ON".

 $3 \rightarrow$




 Remove the cover of the battery pack.




- ► Insert the buffer capacitor.
- Plug the buffer capacitor into connector 3.The device switches on. After 15 seconds, a measured value appears on the display.


A0043733




► Insert battery packs 1 and 2.

- Plug the connector of battery pack 1 into connector 1.Plug the connector of battery pack 2 into connector 2.








- ► Mount the cover of the battery pack.
- ► Close the display module.

► Close the connection compartment cover.


5.6 Connecting the pressure sensor, Proline 800 - Advanced



- A Plug for the pressure sensor on the housing of the compact transmitter
- *B Plug for the pressure sensor on the housing of the remote transmitter*
- Connect the pressure sensor to the plug indicated.

5.7 Power supply via the external battery pack, Proline 800 -Advanced

5.7.1 Connecting the external battery pack



- A Plug for the external battery pack
- ► Connect the external battery pack to the plug indicated.


5.7.2 Inserting batteries into the external battery pack

AWARNING

Batteries may explode if not handled properly!

- ► Do not recharge batteries.
- ► Do not open batteries.
- Do not expose batteries to naked flame.

Observe the specified temperature range of the batteries.



compartment cover.

compartment cover.

The device does not display the remaining capacity of the external batteries. The value on the display refers exclusively to the batteries fitted internally. If internal and external batteries are connected, the external batteries are used first of all, and then the internal batteries are used.

58 Ensuring potential equalization

ACAUTION


Insufficient or faulty potential equalization.

May destroy the electrodes and thus result in the complete failure of the device!

- Pay attention to in-house grounding concepts
- ► Take account of operating conditions like the pipe material and grounding
- ▶ Connect the medium, sensor and transmitter to the same electrical potential
- ▶ Use a ground cable with a minimum cross-section of 6 mm² (0.0093 in²) for potential matching connections

5.8.1 Connection example, standard scenario

Metal, grounded pipe



🖻 8 Potential equalization via measuring tube


5.8.2 Connection example in special situations

Unlined and ungrounded metal pipe

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present





9 Potential equalization via ground terminal and pipe flanges

- 1. Connect both sensor flanges to the pipe flange via a ground cable and ground them.
- 2. If $DN \le 300 (12")$: Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws.
- 3. If $DN \ge 350$ (14"): Mount the ground cable directly on the metal transport bracket. Observe screw tightening torques: see the Sensor Brief Operating Instructions.

4. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose.




Proline 800 - Advanced

In the case of remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

Pipe with insulating liner or plastic pipe

This connection method also applies in situations where:

- Standard company potential equalization cannot be guaranteed
- Equalizing currents can be expected



• Potential equalization via ground terminal and ground disks ($PE = P_{FL} = P_M$)

- 1. Connect the ground disks to the ground terminal via the ground cable.
- 2. Connect the ground disks to ground potential.


$$\blacktriangleright$$
 PE = P_{FL} = P_M

Pipe with a cathodic protection unit

This connection method is only used if the following two conditions are met:

- Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment

Ground cable	Copper wire, at least 6 mm^2 (0.0093 in^2)
--------------	---





Prerequisite: The sensor is installed in the pipe in a way that provides electrical insulation.

- 1. Connect the two flanges of the pipe to one another via a ground cable.
- 2. Connect the flange to the ground terminal via the ground cable.
- 3. Route the signal line shielding via a capacitor (recommended value $1.5 \,\mu$ F/50 V).
- 4. Connect the device to the optional power supply such that it is floating in relation to the ground potential (PE), (this step is not necessary if using a power supply without ground potential (PE)).
 - → $PE \neq P_{FL} = P_M$




Proline 800 - Advanced

In the case of remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

5.9 Special connection instructions

5.9.1 Connection examples


Pulseoutput



I1 Connection example for pulse output (passive)

- 1 Automation system with pulse input (e.g. PLC)
- 2 External DC power supply (e.g. 24 VDC)
- 3 Open collector pulse input of the transmitter: observe input values
- 4 Pull-up resistor (e.g. 10 kOhm)

Modbus RS485



I2 Connection example for Modbus RS485, non-hazardous area

- 1 Control system (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Distribution box (optional)
- 4 Transmitter

5.10 Ensuring potential equalization

5.10.1 Introduction

Correct potential equalization (equipotential bonding) is a prerequisite for stable and reliable flow measurement. Inadequate or incorrect potential equalization can result in device failure and present a safety hazard.

The following requirements must be observed to ensure correct, trouble-free measurement:

- The principle that the medium, the sensor and the transmitter must be at the same electrical potential applies.
- Take in-company grounding guidelines, materials and the grounding conditions and potential conditions of the pipe into consideration.
- The necessary potential equalization connections must be established using a ground cable with a minimum cross-section of 6 mm² (0.0093 in²).
- For remote device versions, the ground terminal in the example always refers to the sensor and not to the transmitter.

i

You can order accessories such as ground cables and ground disks directly from Endress +Hauser

Abbreviations used

- PE (Protective Earth): potential at the protective earth terminals of the device
- P_P (Potential Pipe): potential of the pipe, measured at the flanges
- P_M (Potential Medium): potential of the medium


5.10.2 Connection examples for standard situations

Unlined and grounded metal pipe

- Potential equalization is via the measuring pipe.
- The medium is set to ground potential.

Starting conditions:

- Pipes are correctly grounded on both sides.
- Pipes are conductive and at the same electrical potential as the medium




 Connect the connection housing of the transmitter or sensor to ground potential via the ground terminal provided for this purpose.

Metal pipe without liner

- Potential equalization is via the ground terminal and pipe flanges.
- The medium is set to ground potential.

Starting conditions:

- Pipes are not sufficiently grounded.
- Pipes are conductive and at the same electrical potential as the medium




- 1. Connect both sensor flanges to the pipe flange via a ground cable and ground them.
- 2. Connect the connection housing of the transmitter or sensor to ground potential via the ground terminal provided for this purpose.
- For $DN \le 300$ (12"): Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws.
 - For DN ≥ 350 (14"): Mount the ground cable directly on the metal transport bracket. Observe the screw tightening torques: see the Brief Operating Instructions for the sensor.

Plastic pipe or pipe with insulating liner

- Potential equalization is via the ground terminal and ground disks.
- The medium is set to ground potential.

Starting conditions:

- The pipe has an insulating effect.
- Low-impedance medium grounding close to the sensor is not guaranteed.
- Equalizing currents through the medium cannot be ruled out.



- 1. Connect the ground disks to the ground terminal of the transmitter or sensor connection housing via the ground cable.
- 2. Connect the connection to ground potential.

5.10.3 Connection example with the potential of medium not equal to protective ground


In these cases, the medium potential can differ from the potential of the device.

Metal, ungrounded pipe

The sensor and transmitter are installed in a way that provides electrical insulation from PE, e.g. applications for electrolytic processes or systems with cathodic protection.

Starting conditions:

- Unlined metal pipe
- Pipes with an electrically conductive liner



- 1. Connect the pipe flanges and transmitter via the ground cable.
- 2. Route the shielding of the signal lines via a capacitor (recommended value 1.5µF/50V).


3. Device connected to power supply such that it is floating in relation to the protective earth (isolation transformer). This measure is not required in the case of 24V DC supply voltage without PE (= SELV power unit).

5.11 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables comply with the requirements?	
Do the mounted cables have adequate strain relief?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" ?	
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	
Does the supply voltage match the specifications on the transmitter nameplate?	
Is the terminal assignment correct $\rightarrow \square$ 18?	
Is the terminal assignment or the pin assignment of the device plug correct?	
Batteries correctly inserted and secured?	
DIP switch in correct position?	
If supply voltage is present, do values appear on the display module? If power is supplied exclusively via the battery: does information appear on the display module when the module is touched?	
Is the potential equalization established correctly ?	
Are all housing covers installed and the screws tightened with the correct tightening torque?	

6 Operation options

6.1 Overview of operation options



- 1 Smartphone/tablet (via SmartBlue)
- 2 Computer (via Modbus)

For custody transfer, once the device has been put into circulation or sealed, its operation is restricted.

6.2 Access to the operating menu via the SmartBlue app

The device can be operated and configured via the SmartBlue app. In this case, the connection is established via the Bluetooth[®] wireless technology interface.

Supported functions

- Device selection in Live List and access to the device (login)
- Configuration of the device
- Access to measured values, device status and diagnostic information
- Data logger readout
- Certificate management
- Device software update
- Heartbeat report
- Parameter report

The SmartBlue app is available to download free of charge for Android devices (Google Playstore) and iOS devices (iTunes Apple Store): *Endress+Hauser SmartBlue*

Directly to the app with the QR code:



A0033202

- For energy-saving reasons, if the device is not powered by a power unit, it is only visible in the live list for 10 seconds every minute.
 - The device appears immediately in the live list if the local display is touched for 5 seconds.
 - The device with the highest signal strength appears at the very top of the live list.

Forgotten your password: contact Endress+Hauser Service.

7 System integration

For detailed information on system integration, see the Operating Instructions for the device $\rightarrow \cong 3$

- Overview of device description files:
 - Current version data for the device
 - Operating tools
- Compatibility with earlier model
- Modbus RS485 information
 - Function codes
 - Response time
 - Modbus data map

8 Commissioning

8.1 Function check

Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist
- "Post-connection check" checklist

8.2 Preparatory steps

The device can only be operated via the SmartBlue App.

8.2.1 Install the SmartBlue App

Download the SmartBlue App $\rightarrow \square 42$

8.2.2 Connect the SmartBlue App to the device



-

Connect the SmartBlue App to the devi

8.3 Configuring the measuring device

Complete this wizard to commission the device.

For each parameter, enter the appropriate value or select the appropriate option.

NOTE

If you exit the wizard before completing all required parameters, the changes you made will be saved. For this reason, the device may be in an undefined state! In this case, a reset to the default settings is recommended.

- 1. Open the **Guidance** menu.
- 2. Start the **Commissioning** wizard.
- **3.** Follow the instructions in the **SmartBlue App**.
 - └ The configuration is completed.

8.4 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code $\rightarrow \implies 43$

8.4.1 Write protection via access code


The effects of the user-specific access code are as follows:

Via the SmartBlue App, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.

Defining the access code via the SmartBlue App

- 1. Open the **System** menu.
- 2. Open the **User management** submenu.
- 3. Open the **Define access code** wizard.
- 4. Define a string, consisting of up to 4 numbers, for the access code.
 - └ The parameters are write-protected.
- If parameter write protection is activated via an access code, it can also only be deactivated via this access code .
 - The user role with which the user is currently logged on is indicated by the Access status parameter. Navigation path: System → User management → Access status

8.4.2 Write protection via write protection switch



 Information regarding the write protection switch is provided on the connection nameplate in the connection compartment cover.

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu to be locked.


The parameter values are now read only and cannot be edited any more.

The following parameters can always be modified even if parameter write protection is activated:

- Enter access code
- Contrast display
- Clientt ID

1. Set the write protection (WP) switch on the display module to the **ON** position.

→ Hardware write protection is enabled.
 In the Locking status parameter, the Hardware locked option is displayed.
 On the local display, the symbol appears in the header.



A0044218

2.

9 Diagnostic information

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display. The message about remedial measures can be called up from the diagnostic message, and contains important information on the fault.

9.1 Diagnostic message



Maintenance required

- Maintenance required.
- Output signal is still valid.

Out of specification

- Device is being operated outside the technical specification limits, e.g. outside the process temperature range.
 - Device is operated outside the configuration performed by the user, e.g. maximum flow rate.



Functional test

- Device is in the service mode, e.g. during a simulation.
- Output signal is temporarily invalid.

If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.



71552847

www.addresses.endress.com

