01.03.zz (Device firmware)

Products Solutions

Services

Operating Instructions **Levelflex FMP56, FMP57 HART**

Guided wave radar










Table of contents

1	Important document information 5		Mounting the measuring device	
1.1 1.2	Document function		6.2.1 Tools list	. 32
	1.2.2 Electrical symbols		version	37
1.3	certain types of information and graphics 6 Documentation	6.3	Post-installation check	
	1.3.2 Brief Operating Instructions (KA) 7	7	Electrical connection	
1.4 1.5	1.3.3 Safety Instructions (XA)	7.1	Connection conditions	4(. 46
2	Basic safety instructions 9		7.1.4 Power supply	48
2.1	Requirements for the personnel		7.1.5 Overvoltage protection	
2.3 2.4	Occupational safety		cover	
2.5	Product safety		7.2.2 Connecting	
	2.5.2 EAC conformity 10	7.0	cover	
3	Product description	7.3	Post-connection check	54
3.1	Product design	8	Operation options	55
	3.1.1 Levelflex FMP56/FMP57	8.1	Overview	55
4	Incoming acceptance and product		operating module FHX50	. 56
	identification		8.1.3 Operation via Bluetooth® wireless technology	57
4.1 4.2	Incoming acceptance 13 Product identification 13 4.2.1 Nameplate 14	8.2	8.1.4 Remote operation	58
5	Storage, transport		8.2.1 Structure of the operating menu 8.2.2 User roles and related access	
ر 5.1	Storage temperature		authorization	61
5.2	Transporting the product to the measuring	0 2	8.2.3 Data access - Security	
_	point	8.3	Display and operating module	66
6	Installation		8.3.3 Enter numbers and text	70
6.1	Installation conditions		8.3.4 Opening the context menu	
	probe 20	9	Device integration via the HART	
	6.1.4 Information concerning the process connection		protocol	74
	6.1.5 Securing the probe	9.1 9.2	Overview of the Device Description files (DD). HART device variables and measuring values.	74 74

10	Commissioning via SmartBlue	
	(App)	75
10.1	Requirements	75
10.2	SmartBlue App	75 75
10.3	Envelope curve display in SmartBlue	75
11	Commissioning using the	
	Commissioning Wizard	77
12	Commissioning via operating	
	menu	78
12.1	Function check	78
12.2	Setting the operating language	78
12.3	Configuring level measurement	79
12.4 12.5	Recording the reference envelope curve	81
12.5	Configuring the local display	82
	level measurements	82
	12.5.2 Adjusting the local display	82
12.6	Configuring the current outputs	83
	12.6.1 Factor setting of current outputs for	0.2
	level measurements	83 83
12.7	Configuration management	84
12.8	Protecting settings from unauthorized access.	85
13	Diagnostics and troubleshooting	86
13.1	General troubleshooting	86
	13.1.1 General errors	86
	13.1.2 Error - SmartBlue operation	88
13.2	13.1.3 Parameter configuration errors Diagnostic information on local display	89 90
13.4	13.2.1 Diagnostic message	90
	13.2.2 Calling up remedial measures	92
13.3	Diagnostic event in the operating tool	93
13.4	Diagnostic list	94
13.5 13.6	List of diagnostic events	95 97
15.0	Event logbook	97
	13.6.2 Filtering the event logbook	97
	13.6.3 Overview of information events	97
13.7	Firmware history	99
14	Maintenance 1	L 00
14.1	Exterior cleaning	100
15	Repair	L 01
15.1		101
	1 1	101
	1	101
	1 3	101 101
15.2	1 3	101
15.3	1 1	102

15.4	Disposal	102
16	Accessories	103
16.1	Device-specific accessories	103
	16.1.1 Weather protection cover16.1.2 Mounting bracket for electronics	103
	housing	104
	16.1.3 Rod extension / centering device	105
	16.1.4 Mounting kit, insulated	106
	16.1.5 Remote display FHX50	107
	16.1.6 Overvoltage protection	108 109
16.2	Communication-specific accessories	1109
16.3	Service-specific accessories	110
16.4	System components	111
10.1	System components	111
17	Operating menu	112
17.1	Overview of the operating menu (SmartBlue)	112
17.2	Overview of the operating menu (display	
	module)	117
17.3	Overview of the operating menu (operating	
	tool)	124
17.4	"Setup" menu	130
	17.4.1 "Mapping" wizard	136
	17.4.2 "Advanced setup" submenu	137
17.5	"Diagnostics" menu	184
	17.5.1 "Diagnostic list" submenu	186
	17.5.2 "Event logbook" submenu	187
	17.5.3 "Device information" submenu	188
	17.5.4 "Measured values" submenu	191
	17.5.5 "Data logging" submenu	193
	17.5.6 "Simulation" submenu	196
	17.5.7 "Device check" submenu	201
	17.5.8 "Heartbeat" submenu	203
Indes	7	204

1 Important document information

1.1 Document function

These Operating Instructions provide all of the information that is required in various phases of the life cycle of the device including:

- Product identification
- Incoming acceptance
- Storage
- Installation
- Connection
- Operation
- Commissioning
- Troubleshooting
- Maintenance
- Disposal

1.2 Document conventions

1.2.1 Safety symbols

⚠ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols



Alternating current



Direct current and alternating current

Direct current



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols



Phillips head screwdriver



Flat blade screwdriver



Torx screwdriver

06

Allen key

Ø.

Open-ended wrench

1.2.4 Symbols for certain types of information and graphics

✓ Permitted

Procedures, processes or actions that are permitted

✓ ✓ Preferred

Procedures, processes or actions that are preferred

X Forbidden

Procedures, processes or actions that are forbidden

11 Tip

Indicates additional information

Reference to documentation

 \blacksquare

Reference to graphic



Notice or individual step to be observed

1., 2., 3.

Series of steps

Result of a step

(

Visual inspection

Operation via operating tool

Write-protected parameter

1, 2, 3, ...

Item numbers

A, B, C, ...

Views

$\triangle \rightarrow \square$ Safety instructions

Observe the safety instructions contained in the associated Operating Instructions

□ Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

1.3 Documentation

The following documentation types are available in the Downloads area of the Endress +Hauser website (www.endress.com/downloads):



For an overview of the scope of the associated Technical Documentation, refer to the following:

- W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2D matrix code (QR code) on the nameplate

1.3.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.3.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.



The nameplate indicates the Safety Instructions (XA) that are relevant to the device.

1.4 Terms and abbreviations

ВА

Document type "Operating Instructions"

KA

Document type "Brief Operating Instructions"

TI

Document type "Technical Information"

SD

Document type "Special Documentation"

XA

Document type "Safety Instructions"

PN

Nominal pressure

MWP

MWP (Maximum working pressure/max. process pressure) The MWP can also be found on the nameplate.

ToF

Time of Flight

FieldCare

Scalable software tool for device configuration and integrated plant asset management solutions

DeviceCare

Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices

DTM

Device Type Manager

DD

Device Description for HART communication protocol

ε_r (Dk value)

Relative dielectric constant

PI.C

Programmable logic controller (PLC)

CDI

Common Data Interface

Operating tool

The term "operating tool" is used in place of the following operating software:

- FieldCare / DeviceCare, for operation via HART communication and PC
- SmartBlue (app), for operation using an Android or iOS smartphone or tablet

BD

Blocking Distance; no signals are analyzed within the BD.

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

PFS

Pulse Frequency Status (Switch output)

1.5 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

Bluetooth®

The $Bluetooth^{@}$ word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple[®]

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ®, VITON®

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

TEFLON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use

Application and media

The measuring device described in this manual is intended only for the level measurement of bulk solids. Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

If the limit values specified in the "Technical data" and the conditions listed in the manual and additional documentation are observed, the measuring device may be used for the following measurements only:

- ► Measured process variables: level
- ► Calculable process variables: volume or mass in any shape of vessel (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Use the measuring device only for media to which the process-wetted materials have an adequate level of resistance.
- Observe the limit values in "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-designated use.

Clarification of borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies contained therein (e.g. display module, main electronics module and I/O electronics module) may rise up to 80 $^{\circ}\text{C}$ (176 $^{\circ}\text{F}$). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► In the event of elevated medium temperatures, ensure protection against contact to prevent burns.

2.3 Occupational safety

When working on and with the device:

Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Risk of injury!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ► The operator is responsible for interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories from the manufacturer.

Hazardous area

To eliminate the risk of danger to persons or the facility when the device is used in the approval-related area (e.g. explosion protection, pressure equipment safety):

- ► Check the nameplate to verify if the device ordered can be put to its intended use in the approval-related area.
- ▶ Observe the specifications in the separate supplementary documentation that is an integral part of this manual.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

▶ If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 **CE mark**

The measuring system meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity


The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the EAC mark.

Product description 3

Product design 3.1


3.1.1 Levelflex FMP56/FMP57



№ 1 Design of the Levelflex

- Electronics housing
- Process connection (here as an example: flange)
- Rope probe End-of-probe weight
- Rod probe

3.1.2 **Electronics housing**



₽ 2 Design of the electronics housing

- ${\it Electronics\ compartment\ cover}$
- Display module 2
- Main electronics module 3
- Cable glands (1 or 2, depending on instrument version)
- Nameplate
 I/O electronics module
- Terminals (pluggable spring terminals)
 Connection compartment cover
- Grounding terminal

12

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Upon receipt of the goods check the following:


- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): Are the Safety Instructions (XA) present?
- If one of these conditions is not satisfied, contact your Endress+Hauser Sales Center.

4.2 Product identification

The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in W@M Device Viewer
 (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

4.2.1 Nameplate



■ 3 Nameplate of the Levelflex; Dimensions: mm (in)

- 1 Device name
- 2 Address of manufacturer
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference distance
- 8 Certificate symbol
- 9 Certificate and approval relevant data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Material in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the thread of the cable glands
- 24 Length of probe
- 25 Signal outputs
- 26 Operating voltage

Only 33 digits of the extended order code can be indicated on the nameplate. If the extended order code exceeds 33 digits, the rest will not be shown. However, the complete extended order code can be viewed in the operating menu of the device in the **Extended order code 1 to 3** parameter.

5 Storage, transport

5.1 Storage temperature

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use original packaging.


5.2 Transporting the product to the measuring point

WARNING

Housing or rod may become damaged or pull off.

Risk of injury!


- ► Transport the measuring device to the measuring point in its original packaging or by the process connection.
- Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or probe. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.
- ► Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs) (IEC 61010).



6 Installation

6.1 Installation conditions

6.1.1 Suitable mounting position



 \blacksquare 4 Installation conditions for Levelflex

Spacing requirements when mounting

- Distance (A) between the vessel wall and rod and rope probes:
 - For smooth metallic walls: > 50 mm (2 in)
 - For plastic walls: > 300 mm (12 in) to metallic parts outside the vessel
 - For concrete walls: > 500 mm (20 in), otherwise the permitted measuring range may be reduced.
- ullet Distance (B) between rod probes and internal fittings (3): > 300 mm (12 in)
- When using more than one Levelflex:
 Minimum distance between the sensor axes: 100 mm (3.94 in)
- Distance (C) from the end of the probe to the bottom of the vessel:
 - Rope probe: > 150 mm (6 in)
 - Rod probe: > 10 mm (0.4 in)


Additional conditions

- When mounting outdoors, a weather protection cover (1) can be used to protect the device against extreme weather conditions.
- In metallic vessels, preferably do not mount the probe in the center of the vessel (2), as
 this would lead to increased interference echoes.
 If a central mounting position cannot be avoided, it is essential to perform interference
 echo suppression (mapping) after commissioning the device.
- Do not mount the probe in the filling curtain (3).
- Avoid buckling the rope probe during installation or operation (e.g. as a result of product movement against silo wall) by selecting a suitable mounting location.
- The probe must be checked regularly for damage during operation.
- In the case of freely suspended rope probes (probe end not fixed at the bottom), the distance between the probe rope and internal fittings, which can change due to the movement of the product, must never be less than 300 mm (12 in). Occasional contact between the probe end weight and the cone of the vessel, however, does not influence the measurement provided that the dielectric constant is at least DC = 1.8.
- When the housing is mounted in a recess (e.g. in a concrete ceiling), observe a minimum distance of 100 mm (4 in) between the cover of the connection compartment/electronics compartment and the wall. Otherwise the connection compartment/electronics compartment will not be accessible after installation.

6.1.2 Mounting under confined conditions

Mounting with remote probe

The device version with a remote probe is suitable for applications with restricted mounting space. In this case, the electronics housing is mounted at a separate position from the probe.



A001479

- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered
- Product structure, feature 600 "Probe design":
 - Version MB "Sensor remote, 3m cable"
 - Version MC "Sensor remote, 6m cable"
 - Version MD "Sensor remote. 9m cable"
- The connecting cable is included in the delivery with these versions. Minimum bending radius: 100 mm (4 inch)
- The mounting bracket for the electronics housing is included in the delivery with these versions. Mounting options:
 - Wall mounting
 - Mounting on DN32 to DN50 (1-1/4 to 2 inch) post or pipe
- The connection cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

6.1.3 Notes on the mechanical load of the probe

Tensile load

Bulk solids exert tensile forces on rope probes which increase with:

- The probe length, i.e. the maximum cover
- The bulk density of the product
- The silo diameter and
- The diameter of the probe rope

As the tensile forces also depend greatly on the flowability of the product, a higher safety factor is necessary for highly viscous products and if there is a risk of cornice buildup. In critical cases it is better to use a 6 mm (0.24 in) rope instead of a 4 mm (0.16 in) one.


The same forces also act on the silo ceiling. The tensile forces on a fixed rope are always greater, but cannot be calculated. Observe the tensile loading capacity of the probes.

Ways to reduce the tensile forces:

- Shorten the probe.
- If the maximum tensile load is exceeded, check whether it would be possible to use a non-contact ultrasonic or level radar device.

The following diagrams show typical loads for common bulk solids as reference values. The calculation was performed for the following conditions:


- Calculation according to DIN 1055, Part 6 for the cylindrical part of the silo
- Suspended probe (probe end not fixed at the bottom)
- Free-flowing bulk solid, i.e. mass flow. A calculation for core flow is not possible. In the event of collapsing cornices, considerably higher loads can occur.
- The specification for tensile forces contains safety factor 2 (in addition to the safety factors already contained in DIN 1055), which compensates for the normal fluctuation range in pourable bulk solids.



 \blacksquare 5 Silica sand in metal silo with smooth walls; tensile load as a function of level L for rope diameters 6 mm (0.24 in) and 4 mm (0.16 in)


- A Silo diameter 12 m (40 ft)
- B Silo diameter 9 m (30 ft)
- C Silo diameter 6 m (20 ft)
- D Silo diameter 3 m (10 ft)

20



№ 6 Polyethylene pellets in metal silo with smooth walls; tensile load as a function of level L for rope diameters 6 mm (0.24 in) and 4 mm (0.16 in)

- Silo diameter 12 m (40 ft) Α
- Silo diameter 9 m (30 ft) В
- С Silo diameter 6 m (20 ft)
- D Silo diameter 3 m (10 ft)




₽ 7 Wheat in metal silo with smooth walls; tensile load as a function of level L for rope diameters 6 mm (0.24 in) and 4 mm (0.16 in)

- Α Silo diameter 12 m (40 ft)
- Silo diameter 9 m (30 ft) В
- С Silo diameter 6 m (20 ft)
- D Silo diameter 3 m (10 ft)

21 Endress+Hauser

A0017172



 \blacksquare 8 Cement in metal silo with smooth walls; tensile load as a function of level L for rope diameters 6 mm (0.24 in) and 4 mm (0.16 in)

- A Silo diameter 12 m (40 ft)
- B Silo diameter 9 m (30 ft)
- C Silo diameter 6 m (20 ft)
- D Silo diameter 3 m (10 ft)

Tensile loading capacity of rope probe and breaking load (silo ceiling)

The ceiling of the silo must be designed to withstand the maximum breaking load.

FMP56

Rope 4mm (1/6") 316

- Tensile loading capacity 12 kN
- Max. breaking load 20 kN

Rope 6mm (1/4") PA>steel

- Tensile loading capacity12 kN
- Max. breaking load 20 kN

FMP57

Rope 4mm (1/6") 316

- Tensile loading capacity 12 kN
- Max. breaking load 20 kN

Rope 6mm (1/4") 316

- Tensile loading capacity 30 kN
- Max. breaking load 42 kN

Rope 6mm (1/4") PA>steel

- Tensile loading capacity 12 kN
- Max. breaking load 20 kN

Rope 8mm (1/3") PA>steel

- Tensile loading capacity 30 kN
- Max. breaking load 42 kN

22

Lateral loading capacity (flexural strength) of rod probes

FMP57


Rod 16mm (0.63") 316L 30 Nm

6.1.4 Information concerning the process connection



Probes are mounted on the process connection with threaded connections or flanges. If there is the danger with this installation that the probe end moves so much that it occasionally touches the vessel floor or cone, the probe may need to be shortened at the lower end and fixed in place.

Threaded connection



€ 9 Mounting with threaded connection; flush with the vessel ceiling


Seal

The thread and the type of seal comply with DIN 3852 Part 1, screwed plug, form A. The following types of sealing ring can be used:

- For thread G3/4": According to DIN 7603 with dimensions 27 mm × 32 mm
- For thread G1/-1/2": According to DIN 7603 with dimensions 48 mm × 55 mm

Use a sealing ring according to this standard in form A, C or D and of a material that offers appropriate resistance for the application.

Nozzle mounting



Length of the centering rod or the rigid part of the rope probe

FMP56

Rope, Ø 4 mm (0.16 in)

Length H: 120 mm (4.7 in)

FMP57

Rope, Ø 4 mm (0.16 in)

Length H:

94 mm (3.7 in)

Rope, Ø 6 mm (0.24 in)

Length H: 135 mm (5.3 in)

 Permissible nozzle diameter: ≤ 150 mm (6 in) For larger diameters, the near-range measuring capability may be reduced. For large nozzles, see the section "Mounting in nozzles ≥ DN300"

- Permissible nozzle height: ≤ 150 mm (6 in) For larger heights, the near-range measuring capability may be reduced. Larger nozzle heights are possible in special cases (on request), see section "Rod extension/centering device HMP40 for FMP57".
- The end of the nozzle should be flush with the tank ceiling in order to avoid ringing effects.
- In thermally insulated vessels, the nozzle should also be insulated in order to prevent condensate formation.

Rod extension/centering device HMP40 for FMP57


For FMP57 with rope probes, the rod extension/centering device HMP40 is available as an accessory. It must be used if the probe rope would otherwise come into contact with the lower edge of the nozzle.

This accessory consists of the extension rod, corresponding to the nozzle height, on which a centering disk is also mounted if the nozzles are narrow or when used in bulk solids. We deliver this component separately from the device. Please order a correspondingly shorter probe length.

Only use centering disks with small diameters (DN40 and DN50) if there is no significant build-up in the nozzle above the disk. The nozzle must not become cloqged with product.

Mounting in nozzles ≥ DN300


If installation in nozzles ≥ 300 mm (12 in) is unavoidable, installation must be carried out in accordance with the following diagram in order to avoid interference signals in the near range.



- Lower edge of the nozzle
- Approximately flush with the lower edge of the nozzle (±50 mm)
- Plate, nozzle \varnothing 300 mm (12 in) = plate \varnothing 280 mm (11 in); nozzle \varnothing \geq 400 mm (16 in) = plate \varnothing \geq 350 mm (14 in)
- Pipe Ø 150 to 180 mm

6.1.5 Securing the probe

Securing rope probes



A001260

- A Rope sag: $\geq 10 \text{ mm/}(1 \text{ m probe length}) [0.12 \text{ in/}(1 \text{ ft probe length})]$
- B Reliably grounded end of probe
- C Reliably insulated end of probe
- 1 Fastener in female thread of probe end weight
- 2 Insulated fastening kit
- The end of the rope probe must be secured (fixed down) under the following conditions:
 - If the probe would otherwise temporarily come into contact with the vessel wall, the cone, internal fittings/beams or another part of the installation
 - If the probe would otherwise get closer than 0.5 m (1.6 ft) to a concrete wall.
- A female thread is provided in the probe weight to secure the end of the probe:
 - Rope 4 mm (1/6"), 316: M 14
 - Rope 6 mm (1/4"), 316: M 20
 - Rope 6 mm (1/4"), PA>steel: M14
 - Rope 8mm (1/3"), PA>steel: M20
- Far higher tensile loads occur on the probe when it is secured (fixed down). Therefore, preferably use the 6 mm (1/4") rope probe.
- When fixed down, the end of the probe must be either reliably grounded or reliably insulated. Use an insulated fastening kit if it is not otherwise possible to secure the probe with a reliably insulated connection.
- If grounded fastening is used, the search for a positive probe end echo must be activated. Otherwise, automatic probe length correction is not possible.

Navigation: Expert \rightarrow Sensor \rightarrow EOP evaluation \rightarrow EOP search mode Setting: **Positive FOP** option

Setting: **Positive EOP** option


■ To prevent an extremely high tensile load (e.g. due to thermal expansion) and the risk of the rope breaking, the rope must be slack. Required sag: $\geq 10 \text{ mm/}(1 \text{ m rope length})$ [0.12 in/(1 ft rope length)].

Pay attention to the tensile loading capacity of rope probes.

26

Securing rod probes

- For WHG approval: A support is required for probe lengths \geq 3 m (10 ft).
- In general, rod probes must be secured in the event of horizontal flow (e.g. from an agitator) or strong vibrations.
- Only secure rod probes directly at the end of the probe.



Unit of measurement mm (in)

- 1 Probe rod, uncoated
- 2 Sleeve with narrow bore to ensure electrical contact between the sleeve and the rod.
- 3 Short metal pipe, e.g. welded in place
- 4 Probe rod, coated
- 5 Plastic sleeve, e.g. PTFE, PEEK, PPS
- 6 Short metal pipe, e.g. welded in place

NOTICE

Poor grounding of the probe end may cause incorrect measurements.

► Use a sleeve with a narrow bore to ensure good electrical contact between the sleeve and the probe rod.

NOTICE


Welding can damage the main electronics module.

▶ Before welding: Ground the probe rod and remove the electronics.

6.1.6 Special installation situations

Concrete silos

Installation in a thick concrete ceiling, for example, should be flush with the lower edge. Alternatively, the probe can also be installed in a pipe that must not protrude over the lower edge of the silo ceiling. The pipe should be as short as possible. For installation suggestions, see the diagram below.




A001413

- 1 Metal plate
- 2 Metal pipe
- 3 Rod extension/centering device HMP40 (see "Accessories")
- Installation with rod extension/centering device (accessory):

Strong dust generation can lead to build-up behind the centering disk. This can result in interference reflections. For other installation options, please contact Endress +Hauser.

28


Mounting from the side



A0014140

- If installation from above is not possible, the device can also be mounted from the side
- Always secure the rope probe in this case
- Support the rod and coax probe if the lateral load-bearing capacity is exceeded
- Only secure rod probes at the end of the probe

Non-metal vessels




- 1 Non-metal vessel
- 2 Metal sheet or metal flange

To ensure good measurement results when mounting on non-metal vessels

- Use a device with a metal flange (minimum size DN50/2").
- Alternatively: at the process connection, mount a metal sheet with a diameter of at least 200 mm (8 in) at a right angle to the probe.


Vessel with thermal insulation

If process temperatures are high, the device must be included in normal vessel insulation (1) in order to prevent the electronics heating up as a result of thermal radiation or convection. The insulation may not go beyond the points labeled "MAX" in the drawings.



■ 10 Process connection with thread

- 1 Vessel insulation
- 2 Compact device
- 3 Sensor, remote



■ 11 Process connection with flange - FMP57

- Vessel insulation
- 2 Compact device
- 3 Sensor, remote

6.2 Mounting the measuring device

6.2.1 Tools list



- To shorten rope probes: use a saw or bolt cutters
- To shorten rod or coax probes: use a saw
- For flanges and other process connections, use an appropriate mounting tool


6.2.2 Shortening the probe

Shortening rod probes

Rod probes must be shortened if the distance to the vessel base or outlet cone is less than 10 mm (0.4 in). To shorten, saw off the bottom end of the rod probe.

Shortening rope probes

Rope probes must be shortened if the distance to the vessel base or outlet cone is less than 150 mm (6 in).



A0021693

Rope material 316

- A:
- 4 mm (0.16 in)
- B:
 - 40 mm (1.6 in)
- C:
 - 3 mm; 5 Nm (3.69 lbf ft)

Rope material 316

■ A:

6 mm (0.24 in)

■ B:

55 mm (2.2 in)

■ C:

4 mm; 15 Nm (11.06 lbf ft)

Rope material PA > steel

■ A:

6 mm (0.24 in)

■ B:

40 mm (1.6 in)

■ C:

3 mm; 5 Nm (3.69 lbf ft)

Rope material PA > steel

■ A:

8 mm (0.31 in)

■ B:

55 mm (2.2 in)

■ C:


4 mm; 15 Nm (11.06 lbf ft)

- 1. Using an Allen key, loosen the set screws on the rope weight. Note: The setscrews have a clamping coating in order to prevent them from becoming loose accidentally. A higher torque is therefore required to loosen the screws.
- 2. Remove the released rope from the weight.
- 3. Measure off the new rope length.
- 4. At the point to be shortened, wrap adhesive tape around the rope to prevent it from fraying.
- 5. Saw off the rope at a right angle or cut it off with a bolt cutter.
- 6. Insert the rope completely into the weight.
- 7. Screw the setscrews back into place. Due to the clamping coating of the setscrews, it is not necessary to apply a locking compound.

Entering the new probe length

After shortening the probe:

1. Go to the **Probe settings** submenu and perform a probe length correction.




1 Field for the new probe length

For documentation purposes, enter the new probe length into the quick reference guide which can be found in the electronics housing behind the display module.

6.2.3 Mounting the device

Mounting devices with a threaded connection



A0012528

Screw the device with the threaded connection into a sleeve or flange and then secure it to the process vessel via the sleeve/flange.

- \mathbf{i}
- When screwing into place, turn by the hex bolt only:
 - Thread 3/4": 16 36 mm
 - Thread 1-1/2": 655 mm
- Maximum permissible tightening torque:
 - Thread 3/4": 45 Nm
 - Thread 1-1/2": 450 Nm
- Recommended torque when using the supplied aramid fiber seal and a process pressure of 40 bar (only FMP51, no seal is included with FMP54):
 - Thread 3/4": 25 Nm
 - Thread 1-1/2": 140 Nm
- When installing in metal vessels, ensure there is good metal contact between the process connection and the vessel.

Mounting devices with a flange


If a seal is used to mount the device, use uncoated metal screws to ensure good electrical contact between the process flange and the probe flange.

Mounting rope probes

NOTICE

Electrostatic discharge can damage the electronics.

• Ground the housing before lowering the rope probe into the vessel.



A0012529

Pay attention to the following when introducing the rope probe into the vessel:

- Uncoil the rope slowly and lower it carefully into the vessel.
- Make sure the rope does not bend or buckle.
- Avoid uncontrolled swinging of the weight, as this could damage internal fittings in the vessel.

Mounting rope probes in a partially filled silo

If a silo is retrofitted with a Levelflex, it is not always possible to empty the silo. If the vessel is at least 2/3 empty, it is possible to mount the rope probe even in a partially filled silo. In this case, if possible perform a visual inspection after mounting: the rope should not become tangled or knotted when the silo is emptied. The probe rope must hang fully extended before an accurate measurement can be performed.

6.2.4 Mounting the "Sensor, remote" version

This section only applies for devices with the version "Probe design" = "Sensor, remote" (feature 600, version MB/MC/MD).

The following is included in the delivery with the version "Probe design" = "Remote":

- The probe with process connection
- The electronics housing
- The mounting bracket for mounting the electronics housing on a wall or post
- The connection cable (length as ordered). The cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.


A CAUTION

Mechanical stress can damage the plugs of the connection cable or cause them to become loose.

- ► Mount the probe and the electronics housing securely before connecting the connecting cable.
- ► Lay the connecting cable in such a way that it is not exposed to mechanical stress. Minimum bending radius: 100 mm (4 in).
- ▶ When connecting the cable, connect the straight plug before you connect the angled plug. Torque for the union nuts of both plugs: 6 Nm.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

In the event of strong vibrations, a locking compound, e.g. Loctite 243, can also be used on the plug-in connectors.

Mounting the electronics housing




■ 12 Mounting the electronics housing with the mounting bracket. Unit of measurement mm (in)

A Wall mounting

B Post mounting

Connecting the connecting cable






- 2 13 Connecting the connecting cable. The cable can be connected in the following ways:. Unit of measurement mm (in)
- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered

6.2.5 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned:



- 1. Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- 3. Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).

6.2.6 Turning the display


Opening the cover



A0021430

- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the cover and check the cover seal, replace it if necessary.


Turning the display module



A0036401

- 1. Pull out the display module with a gentle rotational movement.
- **2.** Turn the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 3. Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

Closing the cover of the electronics compartment



A0021451

- 1. Screw down the cover of the electronics compartment.
- 2. Turn the securing clamp 90 ° clockwise and tighten the screw of the securing clamp of the electronics compartment cover with 3 mm using the Allen key (2.5 Nm).

6.3 Post-installation check

 \square Is the device properly secured?


□ Is the device undamaged (visual inspection)?
 □ Does the device comply with the measuring point specifications? ■ Process temperature ■ Process pressure ■ Ambient temperature range ■ Measuring range
☐ Are the measuring point identification and labeling correct (visual inspection)?
☐ Is the device adequately protected against precipitation and direct sunlight?
□Is the device adequately protected against impact?
□Are all mounting and safety screws securely tightened?

7 Electrical connection

7.1 Connection conditions


7.1.1 Terminal assignment

Terminal assignment 2-wire: 4-20 mA HART



- 🖪 14 🛮 Terminal assignment 2-wire: 4-20 mA HART
- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- $1 \qquad \textit{Connection 4-20 mA HART passive: terminals 1 and 2, without integrated overvoltage protection} \\$
- 2 Connection 4-20 mA HART passive: terminals 1 and 2, with integrated overvoltage protection
- 3 Terminal for cable screen

Block diagram 2-wire: 4-20 mA HART




■ 15 Block diagram 2-wire: 4-20 mA HART

- 1 Active barrier with power supply (e.g. RN221N); observe terminal voltage
- 2 HART communication resistor ($\geq 250~\Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display device; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device

40


Terminal assignment 2-wire: 4-20 mA HART, switch output



■ 16 Terminal assignment 2-wire: 4-20 mA HART, switch output

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection 4-20 mA HART passive: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection switch output (Open Collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection switch output (Open Collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection 4-20 mA HART passive: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable screen


Block diagram 2-wire: 4-20 mA HART, switch output



🖪 17 🛮 Block diagram 2-wire: 4-20 mA HART, switch output

- 1 Active barrier with power supply (e.g. RN221N); observe terminal voltage
- 2 HART communication resistor ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display device; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Switch output (Open Collector)


Terminal assignment 2-wire: 4-20 mA HART, 4-20 mA



■ 18 Terminal assignment 2-wire: 4-20 mA HART, 4-20 mA

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection current output 1, 4-20 mA HART passive: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection current output 2, 4-20 mA: terminals 3 and 4, without integrated overvoltage protection
- 3 Connection current output 2, 4-20 mA: terminals 3 and 4, with integrated overvoltage protection
- 4 Connection current output 1, 4-20 mA HART passive: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable screen


Block diagram 2-wire: 4-20 mA HART, 4-20 mA



🗷 19 Block diagram 2-wire: 4-20 mA HART, 4-20 mA

- 1 Active barrier with power supply (e.g. RN221N); observe terminal voltage
- 2 HART communication resistor ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display device; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Analog display device; observe maximum load
- 8 Active barrier with power supply (e.g. RN221N), current output 2; observe terminal voltage


Terminal assignment 4-wire: 4-20 mA HART (10.4 to 48 V_{DC})



Terminal assignment 4-wire: 4-20 mA HART (10.4 to 48 V_{DC})

- Connection 4-20 mA HART (active): terminals 3 and 4
- ${\it Connection supply voltage: terminals \ 1 \ and \ 2}$
- Terminal for cable screen


Block diagram 4-wire: 4-20 mA HART (10.4 to 48 V_{DC})



Block diagram 4-wire: 4-20 mA HART (10.4 to 48 V_{DC})

- Evaluation unit, e.g. PLC
- HART communication resistor ($\geq 250~\Omega$); observe maximum load 2
- Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- Analog display device; observe maximum load
- Cable screen; observe cable specification
- Measuring device
- Supply voltage; observe terminal voltage, observe cable specification

Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})



22 Terminal assignment 4-wire: 4-20 mA HART (90 to 253 V_{AC})


- 1 Connection 4-20 mA HART (active): terminals 3 and 4
- 2 Connection supply voltage: terminals 1 and 2
- 3 Terminal for cable screen

A CAUTION

To ensure electrical safety:

- ▶ Do not disconnect the protective connection.
- ▶ Disconnect the supply voltage before disconnecting the protective earth.
- Connect protective earth to the internal ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the external ground terminal.
- In order to ensure electromagnetic compatibility (EMC): Do **not** only ground the device via the protective earth conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

Block diagram 4-wire: 4-20 mA HART (90 to 253 V_{AC})




 \blacksquare 23 Block diagram 4-wire: 4-20 mA HART (90 to 253 V_{AC})


- 1 Evaluation unit, e.g. PLC
- 2 HART communication resistor ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display device; observe maximum load
- Cable scree; observe cable specification
- 6 Measuring device
- 7 Supply voltage; observe terminal voltage, observe cable specification

Connection examples for the switch output

For HART devices, the switch output is available as an option.



■ 24 Connection of a relay



25 Connection to a digital input

- 1 Pull-up resistor
- 2 Digital input

For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or pull-up resistor) of $< 1000 \Omega$.

7.1.2 Cable specification


- Devices without integrated overvoltage protection
 Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection
 Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_{IJ} \ge 60$ °C (140 °F): use cable for temperature $T_{IJ} + 20$ K.

HART

- A normal device cable suffices if only the analog signal is used.
- A shielded cable is recommended if using the HART protocol. Observe grounding concept of the plant.
- For 4-wire devices: Standard device cable is sufficient for the power line.


7.1.3 Device plugs

In device versions with a device plug (M12 or 7/8"), it is not necessary to open the housing in order to connect the signal cable.



■ 26 Pin assignment of M12 plug

- 1 Signal +
- 2 Not assigned
- 3 Signal –
- 4 Ground



■ 27 Pin assignment of 7/8" plug

- 1 Signal –
- 2 Signal +
- 3 Not assigned
- 4 Shielding


Endress+Hauser

47

7.1.4 Power supply

2-wire, 4-20mA HART, passive

2-wire; 4-20mA HART 1)



- 1) Feature 020 of the product structure: option \boldsymbol{A}
- 2) Feature 010 of the product structure
- For ambient temperatures $T_a \le -30$ °C (-22 °F) a minimum voltage of 14 V is required for the sartup of the device at the minimum error current (3,6 mA). For ambient temperatures $T_a \ge 60$ °C (140 °F) a minimum voltage of 12V is required for the sartup of the device at the minimum error current (3,6 mA). The startup current can be parametrized. If the device is operated with a fixed current $I \ge 4,5$ mA (HART multidrop mode), a voltage of $U \ge 11,5$ V is sufficient throughout the entire range of ambient temperatures.
- 4) If the Bluetooth modem is used, the minimum supply voltage increases by 2 $\,\mathrm{V}.$
- For ambient temperatures $T_a \le -20 \,^{\circ}\text{C}$ (-4 $^{\circ}\text{F}$) a minimum voltage of 16 V is required for the startup of the device at the minimum error current (3.6 mA).

48

2-wire; 4-20 mA HART, switch output 1)

"Approval" ²⁾	Terminal voltage U at the device	Maximum load R, depending on the supply voltage $\ensuremath{U_0}$ at the supply unit	
 Non-Ex Ex nA Ex nA[ia] Ex ic Ex ic[ia] Ex d[ia] / XP Ex ta / DIP CSA GP 	13.5 to 35 V ^{3) 4)}	R [Ω]	
■ Ex ia / IS ■ Ex ia + Ex d[ia] / IS + XP	13.5 to 30 V ^{3) 4)}	0 10 20 30 U ₀ [V] 13.5 24.5 35	

- 1) Feature 020 of the product structure: option B
- 2) Feature 010 of the product structure
- 3) For ambient temperatures $T_a \le -30$ °C (-22 °F) a minimum voltage of 16 V is required for the startup of the device at the minimum error current (3.6 mA).
- 4) If the Bluetooth modem is used, the minimum supply voltage increases by 2 V.

2-wire; 4-20mA HART, 4-20mA 1)

"Approval" ²⁾	Terminal voltage U at the device	Maximum load R, depending on the supply voltage $\ensuremath{\text{U}}_0$ at the supply unit
any	Channel 1:	
	13.5 to 30 V ^{3) 4) 5)}	R [Ω]
		0 10 20 30 U ₀ [V]
	Channel 2:	<u> </u>
	12 to 30 V	$R\left[\Omega ight]$
		500 10 12 20 30 U ₀ [V] A0022583

- 1) Feature 020 of the product structure: option C
- 2) Feature 010 of the product structure
- For ambient temperatures $T_a \le -30$ °C (-22 °F) a minimum voltage of 16 V is required for the startup of the device at the minimum error current (3.6 mA)
- 4) For ambient temperatures $T_a \le -40$ °C (-40 °F), the maximum terminal voltage must be restricted to U ≤ 28 V.
- 5) If the Bluetooth modem is used, the minimum supply voltage increases by 2 $\,\mathrm{V}.$

Polarity reversal protection	Yes
Admissible residual ripple at f = 0 to 100 Hz	$U_{SS} < 1 \text{ V}$
Admissible residual ripple at f = 100 to 10000 Hz	U _{SS} < 10 mV

50

4-wire, 4-20mA HART, active

"Power supply; Output" 1)	Terminal voltage	Maximum load R _{max}
K: 4-wire 90-253VAC; 4-20mA HART	90 to 253 V_{AC} (50 to 60 Hz), overvoltage category II	500 Ω
L: 4-wire 10,4-48VDC; 4-20mA HART	10.4 to 48 V _{DC}	

1) Feature 020 of the product structure

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse 8/20 μ s), an overvoltage protection module has to be installed.

Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	2 × 0.5 Ω max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 μs)	10 kA	

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.

External overvoltage protection module



For detailed information please refer to the following documents:

HAW562: TI01012KHAW569: TI01013K

7.2 Connecting the measuring device

A WARNING


Risk of explosion!

- ► Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ► Use specified cable glands only.
- ▶ Check to ensure that the power supply matches the information on the nameplate.
- ▶ Switch off the power supply before connecting the device.
- ► Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:

- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.


7.2.1 Opening connection compartment cover



A0021/490

- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° clockwise.
- 2. Afterwards unscrew connection compartment cover and check lid gasket, replace if necessary.


7.2.2 Connecting



■ 28 Dimensions: mm (in)

- 1. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- 3. Strip the cable ends over a length of 10 mm (0.4 in). In the case of stranded cables, also fit ferrules.
- 4. Firmly tighten the cable glands.

5. Connect the cable in accordance with the terminal assignment.




A0034682

6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

In the case of devices without integrated overvoltage protection, electrical connection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.




A001366

■ 29 Dimensions: mm (in)

To remove cables from the terminal:

- 1. Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

7.2.4 Closing connection compartment cover



A002149

- 1. Screw back firmly connection compartment cover.
- 2. Turning securing clamp 90 $^{\circ}$ counterclockwise and tighten the clamp with 2.5 Nm (1.84 lbf ft) again using the Allen key (3 mm).

7.3 Post-connection check

☐ Is the device or cable undamaged (visual inspection)?
\square Do the cables used comply with the requirements?
\square Do the mounted cables have adequate strain relief?
□Are all the cable glands installed, firmly tightened and leak-tight?
\square Does the supply voltage match the specifications on the nameplate?
\square Is the terminal assignment correct?
□If necessary, has a protective ground connection been established?
\square If supply voltage is present, is the device ready for operation and do values appear on the display module?
☐ Are all the housing covers installed and tightened?
☐ Is the securing clamp firmly tightened?


8 Operation options

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control	
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"	
Display elements	A-line display	4-line display white background lighting; switches to red in event of device error	
	Format for displaying measured variables and st	ratus variables can be individually configured	
	Permitted ambient temperature for the display: The readability of the display may be impaired a range.		
Operating elements	local operation with 3 push buttons $(\boxdot, \boxdot, \sqsubseteq)$	external operation via touch control; 3 optical keys: ⊕, ⊡, 區	
	Operating elements also accessible in various hazardous areas		
Additional functionality	Data backup function The device configuration can be saved in the display module.		
	Data comparison function The device configuration saved in the display moton configuration.	odule can be compared to the current device	
	Data transfer function The transmitter configuration can be transmitte	d to another device using the display module.	

Operation with remote display and operating module FHX50 8.1.2




■ 30 *FHX50* operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover Display and operating module SD02, push buttons; cover must be removed

8.1.3 Operation via Bluetooth® wireless technology

Requirements




■ 31 Device with Bluetooth module

- 1 Electronics housing of the device
- 2 Bluetooth module

This operation option is only available for devices with Bluetooth module. There are the following options:

- The device has been ordered with a Bluetooth module:
 Feature 610 "Accessory Mounted", option NF "Bluetooth"
- The Bluetooth module has been ordered as an accessory (ordering number: 71377355) and has been mounted. See Special Documentation SD02252F.

Operation via SmartBlue (app)




A003493

- 32 Operation via SmartBlue (app)
- 1 Transmitter power supply unit
- 2 Smartphone / tablet with SmartBlue (app)
- 3 Transmitter with Bluetooth module

8.1.4 Remote operation


Via HART protocol



■ 33 Options for remote operation via HART protocol

- 1 PLC (Programmable Logic Controller)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA191, FXA195 and Field Communicator 375, 475
- 4 Field Communicator 475
- 5 Computer with operating tool (e.g. DeviceCare/FieldCare, AMS Device Manager, SIMATIC PDM)
- 6 Commubox FXA191 (RS232) or FXA195 (USB)
- 7 Field Xpert SFX350/SFX370
- 8 VIATOR Bluetooth modem with connecting cable
- 9 Transmitter

DeviceCare/FieldCare via service interface (CDI)



■ 34 DeviceCare/FieldCare via service interface (CDI)

- 1 Service interface (CDI) of the instrument (= Endress+Hauser Common Data Interface)
- 2 Commubox FXA291
- 3 Computer with DeviceCare/FieldCare operating tool

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the local display.
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	When all these parameters have been assigned appropriate values, the measured should be completely configured in a standard application.
	Advanced setup	Contains further submenus and parameters: • to adapt the device to special measuring conditions. • to process the measured value (scaling, linearization). • to configure the signal output.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information needed to identify the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat 4)	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert ⁵⁾ Contains all parameters of the device (including those which are already contained	System	Contains all general device parameters which do not affect the measurement or the communication interface.
in one of the above submenus). This menu is organized according to the function blocks of the device.	Sensor	Contains all parameters needed to configure the measurement.
The parameters of the Expert menu are described in: GP01000F (HART)	Output	 Contains all parameters needed to configure the current output. Contains all parameters needed to configure the switch output (PFS).

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

- 1) If operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup \rightarrow Advanced setup → Display"

 Only if operating via an FDT/DTM system only available with local operation
- 2)
- 3)
- 4) 5) only available if operating via DeviceCare or FieldCare
 On entering the "Expert" menu, an access code is always requested. If a customer specific access code has not been defined, "0000" has to be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access $\rightarrow \triangleq 61$.

Access authorization to parameters

User role	Read access		Write	access
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	
Maintenance	V	V	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.



The user role with which the user is currently logged on is indicated by the **Access status display** parameter (for display operation) or **Access status tooling** parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the same code in **Confirm access code** parameter.
 - ► The 🗈-symbol appears in front of all write-protected parameters.

Define access code via operating tool (e.g. FieldCare)

- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - **▶** Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, they can always be modified, even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the measured value display mode from the navigation and editing view.



- If write access is activated via access code, it can be also be deactivated only via the access code → \(\begin{array}{c} \end{array} \) 62.
- \blacksquare In the "Description of Device Parameters" documents, each write-protected parameter is identified with the \blacksquare -symbol.

Disabling write protection via access code

If the \square -symbol appears on the local display in front of a parameter, the parameter is write-protected by a device-specific access code and its value cannot be changed at the moment using the local display $\rightarrow \square$ 61.

The locking of the write access via local operation can be disabled by entering the device-specific access code.

- 1. After you press E, the input prompt for the access code appears.
- 2. Enter the access code.
 - The \(\mathbb{O}\)-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Enter **0000**.
- 3. Repeat **0000** in **Confirm access code** parameter.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows write access to the entire operating menu - except for the **"Contrast display" parameter** - to be locked.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via service interface (CDI)
- Via HART protocol




1000/455

- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.



A0036086

- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If the hardware write protection is enabled: The Hardware locked option is displayed in the Locking status parameter. In addition, on the local display the
 ⑤-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If the hardware write protection is disabled: No option is displayed in the **Locking status** parameter. On the local display, the 🛍-symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

For the SD03 display only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock off** option.
 - ► The keypad lock is switched off.


Bluetooth® wireless technology

Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue app
- Only one point-to-point connection between one sensor and one smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display appearance



■ 35 Appearance of the display and operation module for on-site operation

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (1 bargraph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- Representation of a parameter (here: a parameter with selection list)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Selection list; \square marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

66

Display symbols for the submenus

Symbol	Meaning	
A0018367	Display/operat. Appears: In the main menu next to the "Display/operat." selection In the header on the left in the "Display/operat." menu	
A0018364	Setup Appears: In the main menu next to the "Setup" selection In the header on the left in the "Setup" menu	
A0018365	Expert Appears: In the main menu next to the "Expert" selection In the header on the left in the "Expert" menu	
A0018366	Diagnostics Appears: ■ In the main menu next to the "Diagnostics" selection ■ In the header on the left in the "Diagnostics" menu	

Status signals

Symbol	Meaning
A0032902	"Failure" A device error has occurred. The measured value is no longer valid.
C	"Function check" The device is in service mode (e.g. during a simulation).
S	 "Out of specification" The device is being operated: Outside its technical specifications (e.g. during warmup or cleaning processes) Outside the parameter configuration undertaken by the user (e.g. level outside of configured range)
N	"Maintenance required" Maintenance is required. The measured value is still valid.

Display symbols for locking status

Symbol	Meaning
A0013148	Read-only parameters The parameter shown is only for display purposes and cannot be edited.
	Device locked
A0013150	 In front of a parameter name: The device is locked via software and/or hardware. In the header of the measured value screen: The device is locked via hardware.


Measured value symbols

Symbol	Meaning	
Measured values		
~~	Level	
A0032892		
A0032893	Distance	
()	Current output	
A0032908		
(A)	Measured current	
A0032894		
(Terminal voltage	
A0032895		
.	Electronics or sensor temperature	
A0032896		
Measuring channels		
1	Measuring channel 1	
A0032897		
(2)	Measuring channel 2	
A0032898		
Status of the measured value		
A0018361	"Alarm" status Measurement is interrupted. The output assumes the defined alarm condition. A diagnostic message is generated.	
A0018360	"Warning" status The device continues to measure. A diagnostic message is generated.	

8.3.2 Operating elements

Key	Meaning
	Minus key
A0018330	For menu, submenu Moves the selection bar upwards in a picklist.
	For text and numeric editor In the input mask, moves the selection bar to the left (backwards).
	Plus key
+	For menu, submenu Moves the selection bar downwards in a picklist.
A0018329	For text and numeric editor In the input mask, moves the selection bar to the right (forwards).
	Enter key
A0018328	For measured value display ■ Pressing the key briefly opens the operating menu. ■ Pressing the key for 2 s opens the context menu.
	 For menu, submenu Pressing the key briefly Opens the selected menu, submenu or parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter.
	For text and numeric editor Pressing the key briefly Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
	Escape key combination (press keys simultaneously)
—++ A0032909	 For menu, submenu Pressing the key briefly Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the measured value display ("home position").
	For text and numeric editor Closes the text or numeric editor without applying changes.
—+E	Minus/Enter key combination (press and hold down the keys simultaneously)
	Reduces the contrast (brighter setting).
++E A0032911	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).

8.3.3 Enter numbers and text



Input mask


The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
0	Selection of numbers from 0 to 9.
9 A0013998	
A0016619	Inserts decimal separator at the input position.
A0016620	Inserts minus sign at the input position.
A0013985	Confirms selection.
A0016621	Moves the input position one position to the left.
X A0013986	Exits the input without applying the changes.
A0014040	Clears all entered characters.

Text editor

Symbol	Meaning
ABCXYZ	Selection of letters from A to Z
Aa1 @	Toggle Between upper-case and lower-case letters For entering numbers For entering special characters



Correction symbols under \nearrow

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
4	Moves the input position one position to the left.
A0018326	
₹ ×	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Envelope curve
- Keylock on

Calling up and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
 - └ The context menu opens.



A00378


- 2. Press \Box + \pm simultaneously.
 - └ The context menu is closed and the operational display appears.

Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - ► The selected menu opens.

8.3.5 Envelope curve display on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be shown on the display and operating module:



9 Device integration via the HART protocol

9.1 Overview of the Device Description files (DD)

HART

Manufacturer ID	0x11
Device type	0x1122
HART specification	7.0
DD files	For information and files see: www.endress.com www.fieldcommgroup.org

9.2 HART device variables and measuring values

On delivery the following measuring values are assigned to the HART device varaibles:

Device variables for level measurements

Device variable	Measuring value	
Primary variable (PV)	Level linearized	
Secondary variable (SV)	Unfiltered distance	
Tertiary variable (TV)	Absolute echo amplitude	
Quaternary variable (QV)	Relative echo amplitude	

The allocation of the measuring values to the device variables can be changed in the following submenu:

Expert \rightarrow Communication \rightarrow Output

74

10 Commissioning via SmartBlue (App)

10.1 Requirements

Device requirements

Commissioning via SmartBlue is only possible if a Bluetooth module is installed in the device.

System requirements

The SmartBlue App is available for download for mobile smartphone or tablet devices in the Google Play Store for Android, and in the App Store for iOS.

- iOS devices: iPhone 5S or higher from iOS11; iPad 5th Generation or higher from iOS11; iPod Touch 6th Generation or higher from iOS11
- Devices with Android: from Android 6.0 and Bluetooth® 4.0

Initial password

The ID number on the nameplate of the Bluetooth module is used as the initial password when establishing the connection for the first time.

It is important to note the following if the Bluetooth module is removed from one device and installed in another device: all log-in data are only stored in the Bluetooth module and not in the device. This also applies to the password changed by the user.

10.2 SmartBlue App

1. Scan the QR code or enter "SmartBlue" in the search field of the App Store.



A003918

■ 36 Download link


- 2. Start SmartBlue.
- 3. Select device from livelist displayed.
- 4. Enter the login data:
- 5. Tap the icons for more information.
- After logging in for the first time, change the password!

10.3 Envelope curve display in SmartBlue

Envelope curves can be displayed and recorded in SmartBlue.

In addition to the envelope curve, the following values are displayed:

- D = Distance
- L = Level
- A = Absolute amplitude
- With screenshots, the displayed section (zoom function) is saved
- With video sequences, the whole area without zoom function is saved all the time



🖪 37 Envelope curve display (sample) in SmartBlue for Android

- 1 Record video
- 2 Create screenshot
- 3 Display mapping menu
- 4 Start/stop video recording
- 5 Move time on time axis



■ 38 Envelope curve display (sample) in SmartBlue for iOS


- 1 Record video
- 2 Create screenshot
- 3 Display mapping menu
- 4 Start/stop video recording
- 5 Move time on time axis

76

11 Commissioning using the Commissioning Wizard

A Wizard is provided in FieldCare and DeviceCare ¹⁾ that guides the user through the initial commissioning process.

- 1. Connect the device with FieldCare or DeviceCare.
- 2. Open the device in FieldCare or DeviceCare.
 - ► The dashboard (homepage) of the device is displayed:



A0025866

- 1 "Commissioning" button calls up the wizard
- 3. Click "Commissioning" to launch the Wizard.
- 4. Enter the appropriate value in each parameter or select the appropriate option. These values are written directly to the device.
- 5. Click "Next" to go to the next page.
- 6. Once all the pages have been completed, click "Finish" to close the Wizard.
- If you cancel the Wizard before all the necessary parameters have been entered, the device may be in an undefined state. In such situations, it is advisable to reset the device to the factory default settings.

¹⁾ DeviceCare is available for download at www.software-products.endress.com. To download the software, it is necessary to register in the Endress +Hauser software portal.


12 Commissioning via operating menu

12.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:


12.2 Setting the operating language

Factory setting: English or ordered local language



■ 39 Using the example of the local display

12.3 Configuring level measurement



A001283

- $\blacksquare 40$ Configuration parameters for level measurement in bulk solids
- LN Probe length
- R Reference point of measurement
- D Distance
- L Level
- *E Empty calibration (= zero point)*
- F Full calibration (= span)
- If the ε_r value is lower than 7 in the case of rope probes, measurement is not possible in the area of the tensioning weight. The empty calibration E should not exceed LN 250 mm (LN 10 in) in these cases.
- 1. Setup → Device tag
 - ► Enter device tag.
- 2. Navigate to: Setup → Distance unit
 - ► Select the length unit.
- 3. Navigate to: Setup → Bin type
 - ► Select bin type.
- 4. Navigate to: Setup → Empty calibration
 - ► Specify empty distance E (Distance from the reference point R to 0% mark).
- 5. Navigate to: Setup → Full calibration
 - ► Specify full distance F (Distance from the 0% to 100%).
- 6. Navigate to: Setup → Level
 - □ Displays the measured level L.
- 7. Navigate to: Setup → Distance
 - → Displays the distance D between the reference point R and the level L.
- 8. Navigate to: Setup → Signal quality
 - ► Displays the signal quality of the analyzed level echo.
- 9. Operation via local display:
 - Navigate to: Setup \rightarrow Mapping \rightarrow Confirm distance
 - Compare the distance displayed with the actual value to start recording an interference echo map.

10. Operation via operating tool:

Navigate to: Setup → Confirm distance

Compare the distance displayed with the actual value to start recording an interference echo map.

12.4 Recording the reference envelope curve

After the measurement has been configured, it is recommended to record the current envelope curve as a reference envelope curve. This can then be used later for diagnostic purposes. The **Save reference curve** parameter is used to record the envelope curve.

Path in the menu

Expert \rightarrow Diagnostics \rightarrow Envelope diagnostics \rightarrow Save reference curve

Meaning of the options

- No
 - No action
- Yes

The current envelope curve is saved as a reference curve.

- This submenu is only visible for the "Service" user role in devices supplied with software version 01.00.zz or 01.01.zz.
- The reference envelope curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. The "Load Reference Curve" function in FieldCare is used for this.



■ 41 "Load Reference Curve" function

12.5 Configuring the local display

12.5.1 Factory setting of local display for level measurements

Parameters	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

12.5.2 Adjusting the local display

The local display can be adjusted in the following submenu: Setup \to Advanced setup \to Display

12.6 Configuring the current outputs

12.6.1 Factor setting of current outputs for level measurements

Current output	Assigned measured value	4mA value	20mA value
1	Level linearized	0% or the corresponding linearized value	100% or the corresponding linearized value
2 1)	Relative echo amplitude	0 mV	2 000 mV

¹⁾ for devices with two current outputs

12.6.2 Adjusting the current outputs

The current outputs can be adjusted in the following submenus:

Basic settings

Setup \rightarrow Advanced setup \rightarrow Current output 1 to 2

Advanced settings

Expert \rightarrow Output 1 to 2 \rightarrow Current output 1 to 2 See "Description of Device Parameters" GP01000F

12.7 Configuration management

After commissioning, it is possible to save the current device configuration, copy it to another measuring point or restore the previous device configuration. This can be done using the **Configuration management** parameter and its options.

Path in the menu

Setup → Advanced setup → Configuration backup display → Configuration management

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration is saved from the HistoROM (integrated in the device) to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration of the device is duplicated to another device using the display module. The following parameters, which characterize the individual measuring point are **not** transferred:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of the comparison is displayed in **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup copy is restored on a device other than the original device with the **Restore** option, individual device functions may no longer be available. In some cases it is also not possible to restore the original state by resetting to the "asdelivered" state.

The **Duplicate** option should always be used to transfer the configuration to a different device.

12.8 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in two ways:

- Locking via parameters (software locking)
- Locking via write protection switch (hardware locking)

13 Diagnostics and troubleshooting

13.1 General troubleshooting

13.1.1 General errors

Error	Possible cause	Solution	
Device does not respond.	Supply voltage does not match the value indicated on the nameplate.	Connect the correct voltage.	
	The polarity of the supply voltage is wrong.	Correct the polarity.	
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.	
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ± and E simultaneously. Decrease contrast by pressing □ and E simultaneously. 	
	The plug of the display cable is not connected correctly.	Connect the plug correctly.	
	Display is defective.	Replace display.	
"Communication error" is	Electromagnetic interference	Check grounding of the device.	
indicated on the display when starting the device or connecting the display.	Broken display cable or display plug.	Replace display.	
Duplication of parameters via display from one device to another not working. Only the "Save" and "Cancel" options are available.	Display with backup is not properly detected if a data backup was not carried out on the new device previously.	Connect display (with backup) and restart device.	
Output current <3.6 mA	Signal cable connection incorrect.	Check connection.	
	Electronics module is defective.	Replace electronics.	
HART communication does not function.	Communication resistor missing or incorrectly installed.	Install the communication resistor (250 Ω) correctly.	
	Commubox is connected incorrectly.	Connect Commubox correctly.	
	Commubox is not set to "HART".	Set Commubox selector switch to "HART".	
CDI communication does not work.			
Device measures incorrectly.	Parameter configuration error	Check and correct the parameter configuration.	
No communication with device via SmartBlue	No Bluetooth connection	Enable Bluetooth function on smartphone or tablet	
	The device is already connected with another smartphone/tablet	Disconnect the device from the other smartphone/tablet	
	Bluetooth module not connected	Connect Bluetooth module (see SD02252F).	
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of Bluetooth module) and change it	

Error	Possible cause	Solution
Device cannot be operated via SmartBlue	Incorrect password entered	Enter the correct password, paying attention to lower/upper case
Device cannot be operated via SmartBlue	Password forgotten	Contact Endress+Hauser Service (www.addresses.endress.com)

13.1.2 Error - SmartBlue operation

Error	Possible cause	Solution	
Device is not visible in the	No Bluetooth	Enable Bluetooth® function on smartphone or tablet	
live list	connection	Bluetooth® function of sensor disabled, perform recovery sequence	
Device is not visible in the live list	The device is already connected with another smartphone/tablet	Only one point-to-point connection is established between a sensor and a smartphone or tablet	
Device is visible in the live list but cannot be accessed via	Android end device	Is the location function enabled for the app, was it approved the first time?	
SmartBlue		GPS or positioning function must be activated for certain Android versions in conjunction with Bluetooth®	
		Activate GPS - close the app fully and restart - enable the positioning function for the app	
Device is visible in the live list but cannot be accessed via SmartBlue	Apple end device	Log in as standard Enter user name "admin" Enter initial password (ID of the Bluetooth module) paying attention to lower/upper case	
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of the Bluetooth module) and change; paying attention to lower/upper case	
Device cannot be operated via SmartBlue	Incorrect password entered	Enter correct password	
Device cannot be operated via SmartBlue	Password forgotten	Contact the Endress+Hauser Service department (www.addresses.endress.com)	

13.1.3 Parameter configuration errors


Parameter configuration errors for level measurements

Error	Possible cause	Solution	
Measured value incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	 Check and adjust Empty calibration parameter (→	
	If measured distance (Setup → Distance) does not match the real distance: Interference echo	Carry out mapping (Confirm distance parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
No change of measured value on filling/emptying	Interference echo	Carry out mapping (Confirm distance parameter ($\rightarrow \triangleq 134$)).	
	Buildup at the probe.	Clean the probe.	
	Error in the echo tracking.	Deactivate echo tracking (Expert → Sensor → Echo tracking → Evaluation mode = History off).	
Echo lost diagnostic message appears after switching on the supply voltage.	Noise level too high during initialization phase.	Enter Empty calibration parameter (→ 🖺 131) again.	
Device displays a level when the tank is empty.	Incorrect probe length	 Carry out probe length correction (Confirm probe length parameter (→ ≦ 160)). Carry out mapping over entire probe length while the tank is empty (Confirm distance parameter (→ ≦ 134)). 	
Wrong slope of the level throughout the complete measuring range	Wrong bin property selected.	Set Bin type parameter (→ 🖺 130) correctly.	

13.2 Diagnostic information on local display

13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


A0032902	"Failure (F)" option A device error is present. The measured value is no longer valid.
C	"Function check (C)" option The device is in service mode (e.g. during a simulation).
S	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration carried out by the user (e.g. level outside configured span)
M A0032905	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs take on the defined alarm condition. A diagnostic message is generated.
A	"Warning" status The device continues to measure. A diagnostic message is generated.

Diagnostics event and event text

The fault can be identified using the diagnostics event. The event text helps you by providing information about the fault. In addition, the corresponding symbol is displayed before the diagnostics event.



If two or more diagnostic messages are pending simultaneously, only the message with the highest priority is shown. Additional pending diagnostic messages can be shown in the **Diagnostic list** submenu.




Past diagnostic messages that are no longer pending are shown as follows:

- On the local display:
- in the **Event logbook** submenu
- In FieldCare: via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu		
+	Plus key Opens the message about the remedial measures.	
E	Enter key Opens the operating menu.	

13.2.2 Calling up remedial measures



A0029431-EN

- 42 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (①-Symbol).
 - **→ Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \blacksquare .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in **Diagnostic list** submenu or in **Previous diagnostics**.

- 1. Press E.
 - └─ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

92


13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)


A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
 - In the **Actual diagnostics** parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.




A tool tip with remedial measures for the diagnostic event appears.

B: Via the "Create documentation" function




Select the "Create documentation" function.



Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.



Select the "Load Eventlist" function.

The list of events, including remedy information, is shown in the "Data overview" window.

13.4 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

Diagnostics → Diagnostic list

Calling up and closing the remedial measures

- 1. Press E.
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

13.5 List of diagnostic events

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]	
Diagnostic of sensor					
003	Broken probe detected	1. Check map 2. Check sensor	F	Alarm	
046	Build-up detected	Clean sensor	F	Alarm	
104	HF cable	and check sealing 1. Dry HF cable connection 2. Change HF cable	F	Alarm	
105	HF cable	Tighten HF cable connection Check sensor Change HF cable	F	Alarm	
106	Sensor	Check sensor Check HF cable Contact service	F	Alarm	
Diagnostic of el	lectronic				
242	Software incompatible	Check software Flash or change main electronics module	F	Alarm	
252	Modules incompatible	Check if correct electronic modul is plugged Replace electronic module	F	Alarm	
261	Electronic modules	Restart device Check electronic modules Change I/O Modul or main electronics	F	Alarm	
262	Module connection	Check module connections Change electronic modules	F	Alarm	
270	Main electronic failure	Change main electronic module	F	Alarm	
271	Main electronic failure	Restart device Change main electronic module	F	Alarm	
272	Main electronic failure	Restart device Contact service	F	Alarm	
273	Main electronic failure	Emergency operation via display Change main electronics	F	Alarm	
275	I/O module defective	Change I/O module	F	Alarm	
276	I/O module faulty	1. Restart device	F	Alarm	
276	I/O module faulty	2. Change I/O module	F	Alarm	
282	Data storage	Restart device Contact service	F	Alarm	
283	Memory content	Transfer data or reset device Contact service	F	Alarm	
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	М	Warning	
Diagnostic of configuration					
410	Data transfer	Check connection Retry data transfer	F	Alarm	
411	Up-/download active	Up-/download active, please wait	С	Warning	
412	Processing download	Download active, please wait	С	Warning	

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
431	Trim 1 to 2	Carry out trim	С	Warning
435	Linearization	Check linearization table	F	Alarm
437	Configuration incompatible	Restart device Contact service	F	Alarm
438	Dataset	Check data set file Check device configuration Up- and download new configuration	М	Warning
441	Current output 1 to 2	Check process Check current output settings	S	Warning
484	Failure mode simulation	Deactivate simulation	С	Alarm
485	Simulation measured value	Deactivate simulation	С	Warning
491	Current output 1 to 2 simulation	Deactivate simulation	С	Warning
494	Switch output simulation	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation	Deactivate simulation	С	Warning
585	Simulation distance	Deactivate simulation	С	Warning
Diagnostic of pr	rocess	1		
801	Energy too low	Increase supply voltage	S	Warning
803	Current loop	Check wiring Change I/O module	F	Alarm
825	Operating temperature	Check ambient temperature	S	Warning
825	Operating temperature	2. Check process temperature	F	Alarm
921	Change of reference	Check reference configuration Check pressure Check sensor	S	Warning
936	EMC interference	Check installation on EMC	F	Alarm
941	Echo lost	Check parameter 'DC value'	F	Alarm 1)
942	In safety distance	Check level Check safety distance Reset self holding	S	Alarm 1)
943	In blocking distance	Reduced accuracy Check level	S	Warning
944	Level range	Reduced accuracy Level at process connection	S	Warning
950	Advanced diagnostic 1 to 2 occured	Maintain your diagnostic event	М	Warning 1)

¹⁾ Diagnostic behavior can be changed.

13.6 Event logbook

13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu ²⁾.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ①: Event has occurred
 - 🕒: Event has ended
- Information event
 - €: Event has occurred

Calling up and closing the remedial measures

- 1. Press E
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press □ + ± simultaneously.
 - ► The message about the remedial measures closes.

13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

13.6.3 Overview of information events

Info number	Info name
11000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed

²⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.


Info number	Info name		
I1092	Embedded HistoROM deleted		
I1110	Write protection switch changed		
I1137	Electronic changed		
I1151	History reset		
I1154	Reset terminal voltage min/max		
I1155	Reset electronic temperature		
I1156	Memory error trend		
I1157	Memory error event list		
I1184	Display connected		
I1185	Display backup done		
I1186	Restore via display done		
I1187	Settings downloaded with display		
I1188	Display data cleared		
I1189	Backup compared		
I1256	Display: access status changed		
I1264	Safety sequence aborted		
I1335	Firmware changed		
I1397	Fieldbus: access status changed		
I1398	CDI: access status changed		
I1512	Download started		
I1513	Download finished		
I1514	Upload started		
I1515	Upload finished		
I1554	Safety sequence started		
I1555	Safety sequence confirmed		
I1556	Safety mode off		

13.7 Firmware history

Date	Firmware version	Modifications	Documentation (FMP56, FMP57, HART)		
			Operating Instructions	Description of Device Parameters	Technical Information
07.2010	01.00.zz	Original software	BA01004F/00/EN/05.10	GP01000F/00/EN/05.10	TI01004F/00/EN/05.10
01.2011	01.01.zz	SIL integratedImprovements and bugfixesAdditional languages	 BA01004F/00/EN/10.10 BA01004F/00/EN/13.11 BA01004F/00/EN/14.12 	• GP01000F/00/EN/10.10 • GP01000F/00/EN/13.11	■ TI01004F/00/EN/10.10 ■ TI01004F/00/EN/13.11 ■ TI01004F/00/EN/14.12 ■ TI01004F/00/EN/15.12
02.2014	01.02.zz	 Support of SD03 Additional languages HistoROM functionality enhanced "Advanced Diagnostics" function block integrated Improvements and bugfixes 	BA01004F/00/EN/15.13BA01004F/00/EN/16.14	• GP01000F/00/EN/14.13 • GP01000F/00/EN/15.14	■ TI01004F/00/EN/16.13 ■ TI01004F/00/EN/17.14
04.2016	01.03.zz	 Update to HART 7 All 17 languages are available in the device Improvements and bugfixes 	 BA01004F/00/EN/17.16 BA01004F/00/EN/ 18.16 1) BA01004F/00/EN/ 20.18 2) 	GP01000F/00/EN/16.16	 TI01004F/00/EN/18.16 TI01004F/00/EN/20.16 ¹⁾ TI01004F/00/EN/22.18 ²⁾

¹⁾ Contains information on the Heartbeat wizards available in the current DTM version for DeviceCare and FieldCare.

²⁾ Contains information on the Bluetooth interface.



14 Maintenance

The measuring device requires no special maintenance.

14.1 Exterior cleaning

When exterior-cleaning the device, always use cleaning agents that do not attack the surface of the hosuing and the seals.

15 Repair

15.1 General notes

15.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs are carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

15.1.2 Repair of Ex-certified devices

When repairing Ex-certified devices, please also note the following:

- Only specialist personnel or Endress+Hauser-Service can carry out repairs to Ex certified devices.
- Relevant standards and national regulations as well as safety instructions (XA) and certificates must be observed.
- Only genuine Endress+Hauser spare parts may be used.
- When ordering spare parts, please check the device designation on the nameplate. Only identical parts may be used as replacements.
- Carry out repairs according to the instructions. Following a repair, the device must fulfill
 the requirements of the individual tests specified for that device.
- A certified device may be converted to another certified device version by Endress +Hauser Service only.
- All repairs and modifications must be documented.

15.1.3 Replacing electronics modules

When electronics modules have been replaced the device does not need to be recalibrated as the parameters are saved in the HistoROM inside the housing. It may be necessary when replacing the main electronics to record a new interference echo suppression.

15.1.4 Replacing a device

Once a complete device has been replaced, the parameters can be transferred back into the device using one of the following methods:


- Using the display module
 Prerequisite: The configuration of the old device was saved previously to the display module.
- Via FieldCare
 Prerequisite: The configuration of the old device was saved previously to the computer using FieldCare.

You can continue measuring without performing a new calibration. Only interference echo suppression may need to be carried out once again.

15.2 Spare parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- In the connection compartment cover of the device there is a spare part nameplate which contains the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL for the W@M Device Viewer (www.endress.com/deviceviewer):

 All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



A001497

■ 43 Example for spare part nameplate in the connection compartment cover

- Measuring device serial number:
 - Located on the device and spare part nameplate.
 - Can be read out via the "Serial number" parameter in the "Device information" submenu.

15.3 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the website for more information: http://www.endress.com/support/return-material
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

15.4 Disposal




If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to Endress+Hauser for disposal under the applicable conditions.


16 Accessories

16.1 Device-specific accessories


16.1.1 Weather protection cover




16.1.2 Mounting bracket for electronics housing




16.1.3 Rod extension / centering device



16.1.4 Mounting kit, insulated



16.1.5 Remote display FHX50




1) This range is valid if option JN "Ambient temperature transmitter -50 °C (-58 °F)" has been selected in ordering feature 580 "Test, Certificate". If the temperature is permanently below -40 °C (-40 °F), failure rates may be increased.

Accessories

16.1.6 Overvoltage protection

Overvoltage protection for 2-wire devices OVP10 (1-channel) OVP20 (2-channel)

Description



A0021734

Technical data

- Resistance per channel: 2 \times 0.5 Ω_{max}
- Threshold DC voltage: 400 to 700 V
- Threshold surge voltage: < 800 V
- Capacitance at 1 MHz: < 1.5 pF
- Nominal leakage current (8/20 μs): 10 kA
- Suitable for conductor cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)

Ordered with the device

Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, feature 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting.

Order numbers for retrofitting

- For 1-channel devices (feature 020, option A): OVP10: 71128617
- For 2-channel devices (feature 020, options B, C, E or G) OVP20: 71128619

Housing cover for retrofitting

In order to keep the necessary safety distances when using the surge arrester module, the housing cover also needs to be replaced when the device is retrofitted. Depending on the housing type, the suitable cover can be ordered using the following material number:

- Housing GT18: cover 71185516
- Housing GT19: cover 71185518
- Housing GT20: cover 71185517


Restrictions in case of retrofitting

The use of the OVP module may be restricted depending on the transmitter approval. A device may only be retrofitted with the OVP module if the option NA (overvoltage protection) is listed under Optional specifications in the Safety Instructions (XA) associated with the device.



For details, see SD01090F.

16.1.7 Bluetooth module for HART devices



16.2 Communication-specific accessories

Commubox FXA195 HART

For intrinsically safe HART communication with FieldCare via the USB interface



For details, see "Technical Information" TI00404F

Commubox FXA291

Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop Order number: 51516983



For details, see "Technical Information" TI00405C

HART Loop Converter HMX50

Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values

Order number: 71063562



For details, see "Technical Information" TI00429F and Operating Instructions BA00371F

WirelessHART adapter SWA70

- Is used for the wireless connection of field devices
- The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks



For details, see Operating Instructions BA00061S

Connect Sensor FXA30/FXA30B

Fully integrated, battery-powered gateway for simple applications with SupplyCare Hosting. Up to 4 field devices with 4 to 20 mA communication (FXA30/FXA30B), serial Modbus (FXA30B) or HART (FXA30B) can be connected. With its robust design and ability to run for years on the battery, it is ideal for remote monitoring in isolated locations. Version with LTE (USA, Canada and Mexico only) or 3G mobile transmission for worldwide communication.



For details, see "Technical Information" TIO1356S and Operating Instructions BA01710S.

Fieldgate FXA42

Fieldgates enable communication between connected 4 to 20 mA, Modbus RS485 and Modbus TCP devices and SupplyCare Hosting or SupplyCare Enterprise. The signals are transmitted either via Ethernet TCP/IP, WLAN or mobile communications (UMTS). Advanced automation capabilities are available, such as an integrated Web-PLC, OpenVPN and other functions.



For details, see "Technical Information" TIO1297S and Operating Instructions BA01778S.

SupplyCare Enterprise SCE30B

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

This Web-based software is installed on a local server and can also be visualized and operated with mobile terminals such as a smartphone or tablet.



For details, see Technical Information TIO1228S and Operating Instructions BA00055S

SupplyCare Hosting SCH30

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and

transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

SupplyCare Hosting is offered as a hosting service (Software as a Service, SaaS). In the Endress+Hauser portal, the user is provided with the data over the Internet.



For details, see Technical Information TIO1229S and Operating Instructions ${\tt BA00050S}$

Field Xpert SFX350

Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area**.



For details, see Operating Instructions BA01202S

Field Xpert SFX370

Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area** and the **Ex area**.



For details, see Operating Instructions BA01202S

16.3 Service-specific accessories

DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices



Technical Information TI01134S

FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



Technical Information TI00028S

16.4 System components

Memograph M graphic data manager

The Memograph M graphic data manager provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.



Technical Information TI00133R and Operating Instructions BA00247R

RN221N

Active barrier with power supply for safe separation of 4 to 20 mA standard signal circuits. Offers bidirectional HART transmission.



Technical Information TI00073R and Operating Instructions BA00202R

RN221

Supply unit for powering two 2-wire measuring devices solely in the non-Ex area. Bidirectional communication is possible via the HART communication jacks.



Technical Information TI00081R and Brief Operating Instructions KA00110R

17 Operating menu

17.1 Overview of the operating menu (SmartBlue)

Navigation SmartBlue

⊁ Setup		→ 🖺 130
Device tag		→ 🖺 130
Distance unit		→ 🖺 130
Bin type		→ 🖺 130
Empty calibration		→ 🖺 131
Full calibration		→ 🖺 131
Level		→ 🖺 132
Distance		→ 🖺 132
Signal quality		→ 🖺 133
Confirm distance		→ 🖺 134
Present mapping		→ 🖺 135
Mapping end point		→ 🖺 135
Record map		→ 🖺 135
► Advanced setup		→ 🖺 137
	Locking status	→ 🖺 137
	Access status tooling	→ 🖺 137
	Enter access code	→ 🖺 138
	▶ Level	→ 🖺 139
	Medium type	→ 🖺 139
	Medium property	→ 🖺 139
	Process property	→ 🖺 140


	Advanced process conditions		→ 🖺 141
	Level unit		→ 🖺 142
	Blocking distance		→ 🖺 142
	Level correction		→ 🖺 143
► Linearization			→ 🖺 145
	Linearization type		→ 🖺 147
	Unit after linearization		→ 🖺 148
	Free text		→ 🖺 149
	Level linearized		→ 🖺 150
	Maximum value		→ 1 50
	Diameter		→ 🖺 150
	Intermediate height		→ 🖺 151
	Table mode		→ 🖺 151
	Table number		→ 🖺 152
	Level		→ 🖺 152
	Level		→ 🖺 153
	Customer value		→ 🖺 153
	Activate table		→ 🖺 153
► Probe settings			→ 🗎 159
	Probe grounded		→ 🖺 159
	Present probe length		→ 🖺 159
	Confirm probe length		→ 🖺 160
► Safety settings		l	→ 🖺 154
	Output echo lost	1	→ 🗎 154
	Value echo lost		→ 🖺 154

		Ramp at echo lost	→ 🖺 155
		Blocking distance	→ 🖺 142
	► Current output	I to 2	→ 🖺 162
		Assign current output	→ 🖺 162
		Current span	→ 🖺 163
		Fixed current	→ 🖺 163
		Damping output	→ 🖺 164
		Failure mode	→ 🖺 164
		Failure current	→ 🖺 165
		Output current 1 to 2	→ 🖺 165
[► Switch output		→ 🖺 166
		Switch output function	→ 🖺 166
		Assign status	→ 🖺 167
		Assign limit	→ 🖺 167
		Assign diagnostic behavior	→ 🖺 167
		Switch-on value	→ 🖺 168
		Switch-on delay	→ 🖺 169
		Switch-off value	→ 🖺 169
		Switch-off delay	→ 🖺 170
		Failure mode	→ 🖺 170
		Switch status	→ 🖺 170
		Invert output signal	→ 🖺 170
억 Diagnostics			→ 🖺 184
Actual diagnostics			→ 🖺 184
Timestamp]	→ 🖺 184
		_	

Previous diagnost	ics	→ 🖺 184
Timestamp		→ 🖺 185
Operating time fr	om restart	→ 🖺 185
Operating time		→ 🖺 178
► Diagnostic list		→ 🗎 186
	Diagnostics 1 to 5	→ 🖺 186
	Timestamp 1 to 5	→ 🖺 186
► Measured valu	ies	→ 🖺 191
	Distance	→ 🖺 132
	Level linearized	→ 🖺 150
	Output current 1 to 2	→ 🖺 165
	Measured current 1	→ 🗎 192
	Terminal voltage 1	→ 🖺 192
► Device informa	ation	→ 🖺 188
	Device tag	→ 🖺 188
	Serial number	→ 🗎 188
	Firmware version	→ 🗎 188
	Device name	→ 🖺 188
	Order code	→ 🖺 189
	Extended order code 1 to 3	→ 🖺 189
	Device revision	→ 🖺 189
	Device ID	→ 🖺 189

	Device type	→ 🖺 190
	Manufacturer ID	→ 🖺 190
► Simulatio	n	→ 🖺 197
	Assign measurement variable	→ 🖺 198
	Process variable value	→ 🖺 198
	Current output 1 to 2 simulation	→ 🖺 198
	Value current output 1 to 2	→ 🖺 199
	Switch output simulation	→ 🖺 199
	Switch status	→ 🖺 199
	Device alarm simulation	→ 🖺 200

17.2 Overview of the operating menu (display module)



	Advanced process conditions	→ 🖺 141
	Level unit	→ 🖺 142
	Blocking distance	→ 🖺 142
	Level correction	→ 🖺 143
► Linearization		→ 🖺 145
	Linearization type	→ 🗎 147
	Unit after linearization	→ 🖺 148
	Free text	→ 🖺 149
	Maximum value	→ 🖺 150
	Diameter	→ 🖺 150
	Intermediate height	→ 🖺 151
	Table mode	→ 🖺 151
	▶ Edit table	
		1
	Level	
	Customer value	
	Activate table	→ 🖺 153
► Safety settings	S	→ 🖺 154
	Output echo lost	→ 🖺 154
	Value echo lost	→ 🖺 154
		-
	Ramp at echo lost	→ 🖺 155
	Blocking distance	→ 🗎 142
► SIL/WHG conf	irmation	→ 🖺 157
► Deactivate SIL	/WHG	→ 🖺 158
	Reset write protection	→ 🖺 158
	Code incorrect	→ 🖺 158

▶ Probe settings			→ 🖺 159
	Probe grounded		→ 🖺 159
	► Probe length co	rrection	→ 🖺 161
		Confirm probe length	→ 🗎 161
		Present probe length	→ 🖺 161
► Current output	1 to 2		→ 🖺 162
	Assign current outp	put	→ 🖺 162
	Current span		→ 🖺 163
	Fixed current		→ 🖺 163
	Damping output		→ 🖺 164
	Failure mode		→ 🖺 164
	Failure current		→ 🗎 165
	Output current 1 to	2	→ 🗎 165
► Switch output			→ 🖺 166
	Switch output funct	tion	→ 🖺 166
	Assign status		→ 🖺 167
	Assign limit		→ 🖺 167
	Assign diagnostic b	pehavior	→ 🖺 167
	Switch-on value		→ 🖺 168
	Switch-on delay		→ 🖺 169
	Switch-off value		→ 🖺 169
	Switch-off delay		→ 🖺 170
	Failure mode		→ 🖺 170
	Switch status		→ 🖺 170
	Invert output signa	1	→ 🖺 170

► Display		→ 🖺 172
	Language	→ 🖺 172
	Format display	→ 🖺 172
	Value 1 to 4 display	→ 🖺 174
	Decimal places 1 to 4	→ 🖺 174
	Display interval	→ 🗎 174
	Display damping	→ 🗎 175
	Header	→ 🗎 175
	Header text	→ 🖺 175
	Separator	→ 🖺 176
	Number format	→ 🖺 176
	Decimal places menu	→ 🖺 176
	Backlight	→ 🖺 176
	Contrast display	→ 🖺 177
► Configu	ration backup display	→ 🖺 178
	Operating time	→ 🖺 178
	Last backup	→ 🖺 178

		Configuration management	→ 🖺 178
		Comparison result	→ 🖺 179
	► Administration		→ 🖺 181
		▶ Define access code	→ 🖺 183
		Define access code	→ 🖺 183
		Confirm access code	→ 🖺 183
		Device reset	→ 🗎 181
억, Diagnostics			→ 🖺 184
Actual diagnostics			→ 🖺 184
Previous diagnostics			→ 🖺 184
Operating time from	restart		→ 🖺 185
Operating time			→ 🖺 178
▶ Diagnostic list			→ 🖺 186
	Diagnostics 1 to 5		→ 🖺 186
► Event logbook			→ 🖺 187
	Filter options		
	▶ Event list		→ 🖺 187
► Device information	on		→ 🖺 188
	Device tag		→ 🖺 188
	Serial number		→ 🖺 188
	Firmware version		→ 🖺 188
	Device name		→ 🖺 188
	Order code		→ 🖺 189
	Extended order code	e 1 to 3	→ 🖺 189
	Device revision		→ 🖺 189

	Device ID	→ 🖺 189
	Device type	→ 🖺 190
	Manufacturer ID	→ 🖺 190
► Measured value	es	→ 🖺 191
	Distance	→ 🖺 132
	Level linearized	→ 🖺 150
	Output current 1 to 2	→ 🖺 165
	Measured current 1	→ 🖺 192
	Terminal voltage 1	→ 🖺 192
▶ Data logging		→ 🖺 193
	Assign channel 1 to 4	→ 🖺 193
	Logging interval	→ 🖺 194
	Clear logging data	→ 🖺 194
	▶ Display channel 1 to 4	→ 🖺 195
► Simulation		→ 🖺 197
	Assign measurement variable	→ 🖺 198
	Process variable value	→ 🖺 198
	Current output 1 to 2 simulation	→ 🖺 198
	Value current output 1 to 2	→ 🖺 199
	Switch output simulation	→ 🖺 199
	Switch status	→ 🖺 199
	Device alarm simulation	→ 🖺 200
► Device check		→ 🖺 201
	Start device check	→ 🖺 201
	Result device check	→ 🖺 201

Last check time	→ 🖺 201
Level signal	→ 🖺 202
Launch signal	→ 🖺 202

17.3 Overview of the operating menu (operating tool)

		_
⊁ Setup		→ 🖺 130
Device tag		→ 🖺 130
Distance u	nit	→ 🖺 130
Bin type		→ 🖺 130
Empty cal	ibration	→ 🖺 131
Full calibr	ation	→ 🖺 131
Level		→ 🖺 132
Distance		→ 🖺 132
Signal qua	ality	→ 🖺 133
Confirm d	istance	→ 🖺 134
Present m	apping	→ 🖺 135
Mapping	end point	→ 🖺 135
Record ma	ар	→ 🖺 135
► Advance	ced setup	→ 🖺 137
	Locking status	→ 🖺 137
	Access status tooling	→ 🖺 137
	Enter access code	→ 🖺 138
	► Level	→ 🖺 139
	Medium type	→ 🖺 139
	Medium property	→ 🖺 139
	Process property	→ 🖺 140
	Advanced process conditions	→ 🖺 141
	Level unit	→ 🖺 142

	Blocking distance	→ 🖺 142
	Level correction	→ 🗎 143
► Linearization		→ 🖺 145
	Linearization type	→ 🖺 147
	Unit after linearization	→ 🖺 148
	Free text	→ 🖺 149
	Level linearized	→ 🖺 150
	Maximum value	→ 🖺 150
	Diameter	→ 🖺 150
	Intermediate height	→ 1 50
	Table mode	→ 🖺 151
	Table number	→ 🖺 152
	Level	→ 🖺 152
	Level	→ 🖺 153
	Customer value	→ 🖺 153
	Activate table	→ 🖺 153
► Safety settings		→ 🖺 154
	Output echo lost	→ 🖺 154
	Value echo lost	→ 🖺 154
	Ramp at echo lost	→ 🖺 155
	Blocking distance	→ 🖺 142
► SIL/WHG confin	mation	→ 🖺 157
► Deactivate SIL/	WHG	→ 🖺 158
	Reset write protection	→ 🖺 158
	Code incorrect	→ 🖺 158

N Post o settinos	S 150
▶ Probe settings	→ 🖺 159
Probe grounded	→ 🖺 159
Present probe length	→ 🖺 159
Confirm probe length	→ 🖺 160
► Current output 1 to 2	→ 🖺 162
Assign current output	→ 🖺 162
Current span	→ 🖺 163
Fixed current	→ 🖺 163
Damping output	→ 🖺 164
Failure mode	→ 🖺 164
Failure current	→ 🖺 165
Output current 1 to 2	→ 🖺 165
► Switch output	→ 🖺 166
Switch output function	→ 🖺 166
Assign status	→ 🖺 167
Assign limit	→ 🖺 167
Assign diagnostic behavior	→ 🖺 167
Switch-on value	→ 🖺 168
Switch-on delay	→ 🖺 169
Switch-off value	→ 🖺 169
Switch-off delay	→ 🖺 170
Failure mode	→ 🖺 170
Switch status	→ 🖺 170
Invert output signal	→ 1 70

	► Display		→ 🖺 172
		Language	→ 🖺 172
		Format display	→ 🖺 172
		Value 1 to 4 display	→ 🖺 174
		Decimal places 1 to 4	→ 🖺 174
		Display interval	→ 🖺 174
		Display damping	→ 🖺 175
		Header	→ 🖺 175
		Header text	→ 🖺 175
		Separator	→ 🖺 176
		Number format	→ 🖺 176
		Decimal places menu	→ 🖺 176
		Backlight	→ 🖺 176
		Contrast display	→ 🖺 177
	► Configuration b	ackup display	→ 🖺 178
		Operating time	→ 🖺 178
		Last backup	→ 🖺 178
		Configuration management	→ 🖺 178
		Backup state	→ 🖺 179
		Comparison result	→ 🖺 179
	► Administration		→ 🖺 181
		Define access code	
		Device reset	→ 🖺 181
억 Diagnostics]		→ 🖺 184
Actual diagnostics]	→ 🖺 184

Timestamp	→ 🗎 184
Imestanp	, □ 104
Previous diagnostics	→ 🖺 184
Timestamp	→ 🖺 185
- mostamp	107
Operating time from restart	→ 🖺 185
Operating time	→ 🖺 178
▶ Diagnostic list	→ 🖺 186
Diagnostics 1 to 5	→ 🖺 186
Timestamp 1 to 5	→ 🖺 186
▶ Device information	→ 🖺 188
Device tag	→ 🖺 188
Serial number	→ 🖺 188
Firmware version	→ 🖺 188
Device name	→ 🖺 188
Order code	→ 🖺 189
Extended order code 1 to 3	→ 🖺 189
Device revision	→ 🖺 189
Device ID	→ 🖺 189
Device type	→ 🖺 190
Manufacturer ID	→ 🖺 190
► Measured values	→ 🖺 191
Distance	→ 🖺 132
Level linearized	→ 🖺 150
Output current 1 to 2	→ 🖺 165
Measured current 1	→ 🖺 192
Terminal voltage 1	→ 🖺 192

► Data logging		→ 🖺 193
	Assign channel 1 to 4	→ 🖺 193
	Logging interval	→ 🖺 194
	Clear logging data	→ 🖺 194
▶ Simulation		→ 🖺 197
	Assign measurement variable	→ 🖺 198
	Process variable value	→ 🖺 198
	Current output 1 to 2 simulation	→ 🖺 198
	Value current output 1 to 2	→ 🖺 199
	Switch output simulation	→ 🖺 199
	Switch status	→ 🖺 199
	Device alarm simulation	→ 🖺 200
▶ Device check		→ 🖺 201
	Start device check	→ 🖺 201
	Result device check	→ 🖺 201
	Last check time	→ 🖺 201
	Level signal	→ 🖺 202
	Launch signal	→ 🖺 202
► Heartbeat		→ 🖺 203

"Setup" menu 17.4

• 📵 : Indicates navigation to the parameter via the display and operating module • 🖃 : Indicates navigation to the parameter via operating tools (e.g. FieldCare)

■ ② : Indicates parameters that can be locked via the access code.

Navigation ■ ■ Setup

Device tag		<u> </u>
Navigation		
Description	Enter a unique name for the measuring plant.	ng point to identify the device quickly within the
User entry	Character string comprising numbers,	letters and special characters (32)
Distance unit		☆
Navigation		
Description	Used for the basic calibration (Empty	/ Full).
Selection	SI units ■ mm ■ ft ■ m ■ in	S
Bin type		
Navigation		
Prerequisite	Medium type ($\rightarrow \triangleq 139$) = Solid	
Description	Specify bin type.	
Selection	ConcretePlastic woodMetallicAluminium	

Empty calibration


Navigation \blacksquare Setup \rightarrow Empty calibr.

Description Distance between process connection and minimum level (0%).

User entry Depending on the probe

Factory setting Depending on the probe

Additional information



■ 47 Empty calibration (E) for level measurements in bulk solids.

Full calibration


Navigation $\blacksquare \Box$ Setup \rightarrow Full calibr.

Description Distance between minimum level (0%) and maximum level (100%).

User entry Depending on the probe

Factory setting Depending on the probe

Additional information



■ 48 Full calibration (F) for level measurements in bulk solids

A0013191

Level


Navigation

Setup → Level

Description

Displays measured level $L_{\!\scriptscriptstyle L}$ (before linearization).

Additional information



■ 49 Level in case of bulk solid measurements

The unit is defined in the **Level unit** parameter ($\Rightarrow \triangleq 142$).


Distance

Navigation

Description

Displays the measured distance D_L between the reference point (lower edge of the flange or threaded connection) and the level.

Additional information



A0013201

50 Distance for bulk solid measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 130$).

Signal quality

Navigation

Description

Displays the signal quality of the evaluated echo.

Additional information

Meaning of the display options

Strong

The evaluated echo exceeds the threshold by at least 10 mV.

Medium

The evaluated echo exceeds the threshold by at least 5 mV.


Weak

The evaluated echo exceeds the threshold by less than 5 mV.

No signal

The device does not find a usable echo.

The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo ³⁾ or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets.



- F941, for Output echo lost (\rightarrow 🗎 154) = Alarm.
- S941, if another option has been selected in **Output echo lost** (→ 🖺 **154**).

³⁾ Of these two echos the one with the lower quality is indicated.

Confirm distance

Navigation

 \square Setup \rightarrow Confirm distance

Description

Specify, whether the measured distance matches the real distance.

Depending on the selection the device automatically sets the range of mapping.

Selection

- Manual map
- Distance ok
- Distance unknown
- Distance too small
- Distance too big
- Tank empty
- Delete map

Additional information

Meaning of the options

Manual map

To be selected if the range of mapping is to be defined manually in the **Mapping end point** parameter ($\rightarrow \implies 135$). In this case it is not necessary to confirm the distance.

Distance ok

To be selected if the measured distance matches the actual distance. The device performs a mapping.

■ Distance unknown

To be selected if the actual distance is unknown. A mapping can not be performed in this case.

■ Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

■ Distance too big ⁴⁾

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range.

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range minus **Map gap to LN**.

Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

- When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.
- If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.

Visibility depends on order options or device settings

e) Only available for "Expert → Sensor → Echo tracking → **Evaluation mode** parameter" = "Short time history" or "Long time history"

Present mapping Navigation □ Setup → Present mapping Description Indicates up to which distance a mapping has already been recorded. Mapping end point □ Navigation □ Setup → Map. end point Prerequisite Confirm distance (→ □ 134) = Manual map or Distance too small

User entry 0 to 200 000.0 m

Description

Additional information This parameter defines up to which distance the new mapping is to be recorded. The

distance is measured from the reference point, i.e. from the lower edge of the mounting

flange or the threaded connection.

Specify new end of the mapping.

For reference purposes the **Present mapping** parameter ($\rightarrow \implies 135$) is displayed together with this parameter. It indicates up to which distance a mapping has already been recorded.

Record map		
Navigation	Setup → Record map	
Prerequisite	Confirm distance (→ 🗎 134) = Manual map or Distance too small	
Description	Start recording of the map.	

Selection • No

Record mapDelete map

• Delete Illa

Additional information Meaning of the options

■ No

The map is not recorded.

Record map

The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing \square .

Delete map

The mapping (if one exists) is deleted and the device displays the recalculated measured distance and the mapping range. When operating via the local display, these values must be confirmed by pressing \square .

17.4.1 "Mapping" wizard

- The **Mapping** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the **Setup** menu (→ ≅ 130).
- In the **Mapping** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Navigation

■ Setup → Mapping

Confirm distance		
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🗎 134	
Mapping end point		<u> </u>
Navigation	Setup → Mapping → Map. end point	
Description	→ 🗎 135	
Record map		a
Navigation	Setup → Mapping → Record map	
Description	→ 🖺 135	
Distance		
Navigation	Setup → Mapping → Distance	
Description	→ 🖺 132	

17.4.2 "Advanced setup" submenu

Navigation \square Setup \rightarrow Advanced setup

Locking status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Locking status

Description Indicates the write protection with the highest priority that is currently active.

User interface ■ Hardware locked

- SIL locked
- CT active defined parameters
- WHG locked
- Temporarily locked

Additional information

Meaning and priorities of the types of write protection

■ Hardware locked (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.

SIL locked (priority 2)

The SIL mode is activated. Writing access to the relevant parameters is denied.

WHG locked (priority 3)

The WHG mode is activated. Writing access to the relevant parameters is denied.

Temporarily locked (priority 4)

Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.

On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

Access status tooling

Navigation \square Setup \rightarrow Advanced setup \rightarrow Access stat.tool

Description Shows the access authorization to the parameters via the operating tool.

Additional information

The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \implies 138)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 137$).

Access status display

Navigation

 \bigcirc Setup → Advanced setup → Access stat.disp

Prerequisite

The device has a local display.

Description

Indicates access authorization to parameters via local display.

Additional information

The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \implies 138)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \cong 137$).

Enter access code

Navigation

Description

Enter access code to disable write protection of parameters.

User entry

0 to 9999

Additional information

- If an incorrect access code is entered, the user retains his current access authorization.
- The write protection affects all parameters marked with the ♠-symbol in this document. On the local display, the ♠-symbol in front of a parameter indicates that the parameter is write-protected.
- If no key is pressed for 10 min, or the user switches from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after another 60 s.
- Please contact your Endress+Hauser Sales Center if you lose your access code.

"Level" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Level

Medium type

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium type

Description Specify type of medium.

User interface ■ Liquid ■ Solid

Factory setting FMP56, FMP57: **Solid**

Additional informationThis parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended **not**

to change the factory setting.

Medium property

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Medium property

Prerequisite EOP level evaluation ≠ Fix DC

Selection ■ Unknown ■ DC 1.4 ... 1.6

■ DC 1.6 ... 1.9

■ DC 1.9 ... 2.5

■ DC 2.5 ... 4

■ DC 4 ... 7

■ DC 7 ... 15

■ DC > 15

Factory setting Dependent on Medium type ($\rightarrow \triangle 139$) and Medium group.

Additional information

Dependency on "Medium type" and "Medium group"

Medium type (→ 🖺 139)	Medium group	Medium property
Solid		Unknown
Liquid	Water based (DC >= 4)	DC 4 7
	Others	Unknown

- For dielectric constants (DC values) of many media commonly used in various industries refer to:
 - the Endress+Hauser DC manual (CP01076F)
 - the Endress+Hauser "DC Values App" (available for Android and iOS)
- For **EOP level evaluation** = **Fix DC**, the exact dielectric constant has to be entered into the **DC value** parameter. Therefore, the **Medium property** parameter is not available in this case.

Process property	
------------------	--

Navigation

Description

Specify typical rate of level change.

Selection

For "Medium type" = "Liquid"

- Very fast > 10 m (400 in)/min
- Fast > 1 m (40 in)/min
- Standard < 1 m (40in) /min
- \blacksquare Medium < 10 cm (4in) /min
- Slow < 1 cm (0.4in) /min
- No filter / test

For "Medium type" = "Solid"

- Very fast > 100 m (333 ft) /h
- Fast > 10 m (33 ft) /h
- Standard < 10 m (33 ft) /h
- Medium < 1 m (3ft) /h
- Slow < 0.1 m (0.3ft) /h
- No filter / test

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

For "Operating mode" = "Level" and "Medium type" = "Liquid"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	14
Medium < 10 cm (4in) /min	39
Slow < 1 cm (0.4in) /min	76
No filter / test	< 1

For "Operating mode" = "Level" and "Medium type" = "Solid"

Process property	Step response time / s
Very fast > 100 m (333 ft) /h	37
Fast > 10 m (33 ft) /h	37
Standard < 10 m (33 ft) /h	74
Medium < 1 m (3ft) /h	146
Slow < 0.1 m (0.3ft) /h	290
No filter / test	< 1

For "Operating mode" = "Interface" or "Interface with capacitance"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	23
Medium < 10 cm (4in) /min	47
Slow < 1 cm (0.4in) /min	81
No filter / test	2.2

Advanced process conditions

A

Navigation

Description

Specify additional process conditions (if required).

Selection

- None
- Oil/Water condensate
- Probe near tank bottom
- Build up
- Foam (>5cm/0,16ft)

Additional information

Meaning of the options

Oil/Water condensate (only Medium type = Liquid)

Makes sure that in the case of two-phase media only the total level is detected (example: oil/condensate application).

■ Probe near tank bottom (only for Medium type = Liquid)

Improves the empty detection, especially if the probe is mounted close to the tank bottom.

Build up

Increases **EOP range upper area** in order to ensure a safe empty-detection even if the end-of-probe signal has shifted due to build-up.

Enables a safe empty-detection even if the end-of-probe signal has shifted due to build-up.

■ Foam (>5cm/0,16ft) (only for Medium type = Liquid)

Optimizes the signal evaluation in applications with foam formation.

 Level unit

 Navigation
 Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level unit

 Description
 Select level unit.

 Selection
 SI units
 US units

 \bullet %
 \bullet ft

 \bullet m
 \bullet in

 \bullet mm
 \bullet in

Additional information

The level unit may differ from the distance unit defined in the **Distance unit** parameter $(\rightarrow \implies 130)$:

- The unit defined in the **Distance unit** parameter is used for the basic calibration (**Empty calibration** ($\rightarrow \implies 131$) and **Full calibration** ($\rightarrow \implies 131$).
- The unit defined in the **Level unit** parameter is used to display the (unlinearized) level.

Blocking distance	
-------------------	--

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Blocking dist.

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting

- For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)
- For rod and rope probes above 8 m (26 ft): 0.025 * Sondenlänge


Additional information

Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- This behavior is only valid if the following two conditions are met:
 - Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
 - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

- A different behavior for signals in the blocking distance can be defined in the **Blocking distance evaluation mode** parameter.
- If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 51 Blocking distance (UB) for bulk solid measurements

Level correction


Navigation Setup \rightarrow Advanced setup \rightarrow Level \rightarrow Level correction

Description Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

Additional information The value specified in this parameter is added to the measured level (before linearization).

"Linearization" submenu



Linearization: Conversion of the level and, if applicable, interface into a volume or a weight; the **■** 52 conversion depends on the vessel shape

- 1 Selection of linearization type and unit
- Configuration of the linearization 2
- Α
- Linearization type ($\rightarrow \triangleq 147$) = None Linearization type ($\rightarrow \triangleq 147$) = Linear В
- Linearization type ($\rightarrow \square 147$) = Table С
- D *Linearization type* ($\rightarrow \equiv 147$) = *Pyramid bottom*
- Linearization type ($\rightarrow = 147$) = Conical bottom Ε
- F *Linearization type* ($\rightarrow \square 147$) = *Angled bottom*
- Linearization type ($\rightarrow = 147$) = Horizontal cylinder G
- *Linearization type* ($\rightarrow \equiv 147$) = *Sphere* Н
- For "Operating mode" = "Interface" or "Interface with capacitance": Interface before linearization (measured in Ι level unit)
- For "Operating mode" = "Interface" or "Interface with capacitance": Interface after linearization (corresponds to volume or weight)
- Level before linearization (measured in level unit) L
- Level linearized ($\rightarrow ext{ } extstyle extstyle 150$) (corresponds to volume or weight) L'
- Μ *Maximum value (→ 🖺 150)*
- d *Diameter (→ 🖺 150)*
- Intermediate height ($\rightarrow \equiv 151$) h

Structure of the submenu on the local display

Navigation Setup \rightarrow Advanced setup \rightarrow Linearization

► Linearization	
	Linearization type
	Unit after linearization
	Free text
	Maximum value
	Diameter
	Intermediate height
	Table mode
	► Edit table
	Level
	Customer value
	Activate table

Structure of the submenu in the operating tool (e.g. FieldCare)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization

► Linearization	
	Linearization type
	Unit after linearization
	Free text
	Level linearized
	Maximum value
	Diameter
	Intermediate height
	Table mode
	Table number
	Level
	Level
	Customer value
	Activate table

Description of the parameters

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Linearization

Linearization type

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Lineariz. type


Description Select linearization type.

Selection ■ None

Linear

- Table
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

Additional information



■ 53 Linearization types

- A None
- B Table
- C Pyramid bottom
- D Conical bottom
- E Angled bottom
- F Sphere
- G Horizontal cylinder

Meaning of the options

None

The level is output in the level unit without being converted (linearized) beforehand.

Linear

The output value (volume/weight) is proportional to the level L. This applies, for example, to vertical cylindrical tanks and silos. The following parameters must also be specified:

- **Maximum value** (→ 🖺 **150**): Maximum volume or weight

■ Table

The relationship between the measured level L and the output value (volume/weight) is defined by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight" respectively. The following parameters must also be defined:

- **■** Table mode (→ 🗎 151)
- For each table point: **Level** (\rightarrow 🖺 **152**)
- For each table point: Customer value (→

 153)

Pyramid bottom

The output value corresponds to the volume or weight in a silo with a pyramid bottom. The following parameters must also be defined:

- Maximum value (→ 🗎 150): Maximum volume or weight
- **Intermediate height (→** 🖺 **151)**: The height of the pyramid

Conical bottom

The output value corresponds to the volume or weight in a tank with a conical bottom. The following parameters must also be defined:

- **Maximum value** (→ 🗎 **150**): Maximum volume or weight
- **Intermediate height (→ 🖺 151)**: The height of the conical part

Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following parameters must also be defined:

- Maximum value (→ 🗎 150): Maximum volume or weight
- **Intermediate height (→** 🗎 **151)**: The height of the angled bottom

Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following parameters must also be defined:

- **Maximum value** (→ 🖺 **150**): Maximum volume or weight
- **■** Diameter (→ 🗎 150)

Sphere

The output value corresponds to the volume or weight in a spherical tank. The following parameters must also be defined:

- Maximum value (→ 🖺 150): Maximum volume or weight

Unit after linearization

Navigation

Prerequisite

Linearization type (→ 🖺 147) ≠ None

Description

Select the unit for the linearized value.

Selection

Selection/input (uint16)

- 1095 = [short Ton]
- 1094 = [lb]
- 1088 = [kg]
- 1092 = [Ton]
- 1048 = [US Gal.]
- 1049 = [Imp. Gal.]
- \bullet 1043 = [ft³]
- $1571 = [cm^3]$
- \bullet 1035 = [dm³]
- \blacksquare 1034 = [m³]
- 1038 = [l]
- 1041 = [hl]
- **1**342 = [%]
- 1010 = [m]
- 1012 = [mm]
- 1018 = [ft]
- 1019 = [inch]
- $\blacksquare 1351 = [1/s]$
- 1352 = [l/min]
- 1353 = [l/h]
- $-1347 = [m^3/s]$
- $1348 = [m^3/min]$
- $1349 = [m^3/h]$
- $1356 = [ft^3/s]$
- $1357 = [ft^3/min]$
- $1358 = [ft^3/h]$
- 1362 = [US Gal./s]
- 1363 = [US Gal./min]
- 1364 = [US Gal./h]
- 1367 = [Imp. Gal./s]
- 1358 = [Imp. Gal./min]
- 1359 = [Imp. Gal./h]
- \blacksquare 32815 = [Ml/s]
- \blacksquare 32816 = [Ml/min]
- 32817 = [Ml/h]
- 1355 = [Ml/d]

Additional information

The selected unit is only used for display purposes. The measured value is **not** converted on the basis of the selected unit.



Distance-to-distance linearization is also possible, i.e. a linearization from the level unit to another length unit. Select the **Linear** linearization mode for this purpose. To specify the new level unit, select the **Free text** option in the **Unit after linearization** parameter and enter the unit in the **Free text** parameter ($\rightarrow \implies 149$).

Free text

Navigation

Prerequisite

Unit after linearization (→ 🗎 148) = Free text

Description

Enter unit symbol.

User entry Up to 32 alphanumerical characters (letters, numbers, special characters)

Level linearized

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level linearized

Description Displays linearized level.

Additional information

The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 148$.

Maximum value

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Maximum value

Prerequisite Linearization type $(\rightarrow \ \ \ \ \ \ \ \ \ \ \)$ has one of the following values:

■ Linear

Pyramid bottomConical bottomAngled bottom

Horizontal cylinder

■ Sphere

Description Linearized value corresponding to a level of 100%.

User entry -50 000.0 to 50 000.0 %

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Diameter

Prerequisite Linearization type ($\rightarrow \triangle 147$) has one of the following values:

■ Horizontal cylinder

Sphere

Description Diameter of the cylindrical or spherical tank.

User entry 0 to 9 999.999 m

Additional information The unit is defined in the **Distance unit** parameter ($\rightarrow \implies 130$).

Intermediate height


Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Intermed. height

Pyramid bottomConical bottomAngled bottom

Description Height of the pyramid, conical or angled bottom.

User entry 0 to 200 m

Additional information



H Intermediate height

The unit is defined in the **Distance unit** parameter ($\rightarrow \equiv 130$).

Table mode

Table mode

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Table mode

Prerequisite Linearization type (→ 🗎 147) = Table

Description Select editing mode of the linearization table.

Selection • Manual

SemiautomaticClear table

■ Sort table

Additional information

Meaning of the options

Manual

The level and the associated linearized value are entered manually for each linearization point.

Semiautomatic

The level is measured by the device for each linearization point. The associated linearized value is entered manually.

Clear table

Deletes the existing linearization table.

Sort table

Rearranges the linerization points into an ascending order.

Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.
- Before entering a linearization table, the values for **Empty calibration** ($\Rightarrow \implies 131$) and **Full calibration** ($\Rightarrow \implies 131$) must be set correctly.

If values of the table need to be changed after the full or empty calibration have been changed, a correct evaluation is only ensured if the existing table is deleted and the complete table is entered again. To do so delete the existing table (**Table mode** $(\rightarrow B151) = Clear table$). Then enter a new table.

How to enter the table

■ Via FieldCare

The table points can be entered via the **Table number** (\rightarrow 🖺 **152**), **Level** (\rightarrow 🖺 **152**) and **Customer value** (\rightarrow 🖺 **153**) parameters. As an alternative, the graphic table editor may be used: Device Operation \rightarrow Device Functions \rightarrow Additional Functions \rightarrow Linearization (Online/Offline)

Via local display

Select the **Edit table** submenu to call up the graphic table editor. The table is displayed and can be edited line by line.

- The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter $(\Rightarrow \implies 142)$ beforehand.
- If a decreasing table is entered, the values for 20 mA and 4 mA of the current output are interchanged. That means: 20 mA refers to the lowest level, whereas 4 mA refers to the highest level.

Table number		
Navigation		
Prerequisite	Linearization type (→ 🗎 147) = Table	
Description	Select table point you are going to enter or change.	
User entry	1 to 32	
Level (Manual)		
Navigation		
Prerequisite	 Linearization type (→ 🗎 147) = Table Table mode (→ 🗎 151) = Manual 	

Enter level value of the table point (value before linearization).

Signed floating-point number

152

Description

User entry

Level (Semiautomatic)	
Navigation	
Prerequisite	 Linearization type (→ 🗎 147) = Table Table mode (→ 🖺 151) = Semiautomatic
Description	Displays measured level (value before linearization). This value is transmitted to the table.
Customer value	
Navigation	
Prerequisite	Linearization type (→ 🖺 147) = Table
Description	Enter linearized value for the table point.
User entry	Signed floating-point number
Activate table	
Navigation	
Prerequisite	Linearization type (→ 🗎 147) = Table
Description	Activate (enable) or deactivate (disable) the linearization table.

Selection

Meaning of the options

Disable

DisableEnable

The measured level is not linearized.

If **Linearization type** (\rightarrow \cong **147**) = **Table** at the same time, the device issues error message F435.

■ Enable

The measured level is linearized according to the table.

When editing the table, the **Activate table** parameter is automatically reset to **Disable** and must be reset to **Enable** after the table has been entered.

"Safety settings" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Safety sett.

Output echo lost

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Output echo lost

Description Output signal in case of a lost echo.

Selection • Last valid value

Ramp at echo lostValue echo lost

Alarm

Additional information Meaning of the options

Last valid value

The last valid value is kept in the case of a lost echo.

■ Ramp at echo lost ⁵⁾

In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the **Ramp at echo lost** parameter ($\rightarrow \implies 155$).

■ Value echo lost 5)

In the case of a lost echo the output assumes the value defined in the **Value echo lost** parameter ($\rightarrow \triangleq 154$).

Alarm

Value echo lost

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Value echo lost

Prerequisite Output echo lost $(\rightarrow \ \ \ \ \ \ \ \ \ \ \)$ = Value echo lost

Description Output value in case of a lost echo

User entry 0 to 200 000.0 %

Additional information Use the unit which has been defined for the measured value output:

154

Only visible if "Linearization type ($\rightarrow \implies 147$)" = "None"

Ramp at echo lost


Navigation Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Ramp echo lost

Prerequisite Output echo lost ($\rightarrow \triangleq 154$) = Ramp at echo lost

Description Slope of the ramp in the case of a lost echo

User entry Signed floating-point number

Additional information



- Delay time echo lost
- В Ramp at echo lost ($\rightarrow \square 155$) (positive value)
- Ramp at echo lost ($\rightarrow \equiv 155$) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuouly increased until it reaches 100%.

Blocking distance	

Navigation

Description Specify upper blocking distance UB.

0 to 200 m User entry

Factory setting • For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

• For rod and rope probes above 8 m (26 ft): 0.025 * Sondenlänge

Additional information


Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance

due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- This behavior is only valid if the following two conditions are met:
 - Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
 - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

- A different behavior for signals in the blocking distance can be defined in the **Blocking distance evaluation mode** parameter.
- If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 54 Blocking distance (UB) for bulk solid measurements

"SIL/WHG confirmation" wizard



The SIL/WHG confirmation wizard is only available for devices with SIL or WHG approval (Feature 590: "Additional Approval", option LA: "SIL" or LC: "WHG overfill prevention") which are currently **not** in the SIL- or WHG-locked state.

The **SIL/WHG** confirmation wizard is required to lock the device according to SIL or WHG. For details refer to the "Functional Safety Manual" of the respective device, which describes the locking procedure and the parameters of the sequence.

Navigation

"Deactivate SIL/WHG" wizard

Abort sequence


The **Deactivate SIL/WHG** wizard ($\rightarrow \implies 158$) is only visible if the device is SIL-locked or WHG-locked. For details refer to the "Functional Safety Manual" of the respective

Navigation

Reset write protection		
Navigation	⊗ Setup $→$ Advanced setup $→$ Deactiv. SIL/WHG $→$ Res. write prot.	
Description	Enter unlocking code.	
User entry	0 to 65 535	
Code incorrect		
Navigation		
Description	Indicates that a wrong unlocking code has been entered. Select procedure.	
Selection	■ Reenter code	

"Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** ($\rightarrow \implies 160$) = **Manual input** in order to enter the value manually.



- Delete the map using the **Record map** parameter ($\rightarrow \boxminus 135$) before performing the automatic probe length correction. After the probe length correction, a new map can be recorded using the **Record map** parameter ($\rightarrow \boxminus 135$).
- Alternative: Select Confirm probe length (→ 160) = Manual input and enter the probe length manually into the Present probe length parameter → 159.
- An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ($\rightarrow \implies 159$).

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Probe settings

Probe grounded		^
Navigation	$ □ $ Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Probe grounded	
Prerequisite	Operating mode = Level	
Description	Specify whether the probe is grounded.	
Selection	■ No ■ Yes	
Present probe length		<u></u>
Navigation		
Description	 In most cases: Displays the length of the probe according to the currently measured end-of-probe signal. For Confirm probe length (→ 🗎 160) = Manual input: Enter actual length of probe. 	
User entry	0 to 200 m	

Confirm probe length

Navigation

Description

Select, whether the value displayed in the **Present probe length** parameter $\rightarrow \triangleq 159$ matches the actual length of the probe. Based on this input, the device performs a probe length correction.

Selection

- Probe length OK
- Probe length too small
- Probe length too big
- Probe covered
- Manual input
- Probe length unknown

Additional information

Meaning of the options

■ Probe length OK

To be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.

■ Probe length too small

To be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the **Present probe length** parameter $\rightarrow \implies 159$. This procedure has to be repeated until the displayed value matches the actual length of the probe.

Probe length too big

To be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the **Present probe length** parameter $\rightarrow \implies 159$. This procedure has to be repeated until the displayed value matches the actual length of the probe.

■ Probe covered

To be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device quits the sequence.

Manual input

To be selected if no automatic probe length correction is to be performed. Instead, the actual length of the probe must be entered manually into the **Present probe length** parameter $\rightarrow \implies 159^{6}$.

■ Probe length unknown

To be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device quits the sequence.

⁶⁾ When operated via FieldCare, the Manual input option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited.

"Probe length correction" wizard

The **Probe length correction** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the probe length correction are located directly in the **Probe settings** submenu ($\rightarrow \blacksquare$ 159).

Navigation

Confirm probe length		Ê
Navigation		
Description	→ 🖺 160	
Present probe length		
Navigation		
Description	→ 🖺 159	

"Current output 1 to 2" submenu

The **Current output 2** submenu ($\rightarrow \triangleq 162$) is only available for devices with two current outputs.

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2

Assign current output 1 to 2

Navigation

Description

Select process variable for current output.

Selection

- Level linearized
- Distance
- Electronic temperature
- Relative echo amplitude
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2

Factory setting

For level measurements

- Current output 1: Level linearized
- Current output 2 7): Level linearized

Additional information

Definition of the current range for the process variables

Process variable	4 mA value	20 mA value
Level linearized	0 % ¹⁾ or the associated linearized value	$100~\%$ $^{2)}$ or the associated linearized value
Distance	0 (i.e. level is at the reference point)	Empty calibration (→ 🗎 131) (i.e. level is at 0 %)
Electronic temperature	−50 °C (−58 °F)	100 °C (212 °F)
Relative echo amplitude	0 mV	2 000 mV
Analog output adv. diagnostics 1/2	depending on the parametrization of the Advanced Diagnostics	

- 1) the 0% level is defined by **Empty calibration** parameter ($\rightarrow \implies 131$)
- 2) The 100% level is defined by **Full calibration** parameter ($\Rightarrow \implies 131$)

It may be necessary to adjust the 4mA and 20mA values to the application (especially in the case of the **Analog output adv. diagnostics 1/2** option).

This can be done by the following parameters:

- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow Turn down
- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow 4 mA value
- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow 20 mA value

⁷⁾ only for devices with two current outputs

Current span

Navigation \blacksquare □ Setup → Advanced setup → Curr.output 1 to 2 → Current span

Description Determines the current range used to transmit the measured value.

'4...20mA':

Measured variable: 4 ... 20 mA

'4...20mA NAMUR':

Measured variable: 3.8 ... 20.5 mA

'4...20mA US':

Measured variable: 3.9 ... 20.8 mA

'Fixed current':

Measured variable transmitted via HART only

Currents below 3.6 mA or above 21.95 mA can be used to signal an alarm.

Selection ■ 4...20 mA

■ 4...20 mA NAMUR


■ 4...20 mA US

■ Fixed current

Additional information

Meaning of the options

Option	Current range for process variable	Lower alarm signal level	Upper alarm signal level
420 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA US	3.9 to 20.8 mA	< 3.6 mA	> 21.95 mA
Fixed current	Constant current, defined in the Fixed current parameter ($\rightarrow \stackrel{ ext{le}}{=} 163$).		



- In the case of an error, the output current assumes the value defined in the **Failure mode** parameter ($\rightarrow \triangleq 164$).
- If the measured value is out of the measuring range, **Current output** diagnostic message is issued.
- 📭 In a HART multidrop loop only one device can use the analog current to transmit a signal. For all other devices one must set:
 - **■** Current span = Fixed current

Fixed current

Navigation

Current span ($\rightarrow \triangleq 163$) = Fixed current **Prerequisite**

Description Define constant value of the output current.

User entry 4 to 22.5 mA

Damping output

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2 \rightarrow Damping out.

Description Reaction time of the output signal on fluctuation in the measured value.

User entry 0.0 to 999.9 s

Additional information Fluctuations of the measured value affect the output current with an exponential delay,

the time constant τ of which is defined in this parameter. With a small time constant the output reacts immediately to changes of the measured value. With a big time constant the reaction of the output is more delayed. For $\tau = 0$ (factory setting) there is no damping.

Failure mode

Navigation Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2 \rightarrow Failure mode

Prerequisite Current span ($\rightarrow \triangleq 163$) \neq Fixed current

Description Defines which current the output assumes in the case of an error.

'Min.': < 3.6mA 'Max.': > 21.95mA

'Last valid value':

Last valid value before occurrence of the error.

'Actual value':

Output current is equal to the measured value; error is ignored.

'Defined value': User defined value.

Selection • Min.

Max.

■ Last valid value

Actual value

■ Defined value

Meaning of the options

Min.

The current output adopts the value of the lower alarm level according to the **Current span** parameter ($\rightarrow \implies 163$).

Max.

The current output adopts the value of the upper alarm level according to the **Current span** parameter ($\Rightarrow \triangleq 163$).

Last valid value

The current remains constant at the last value it hat before the error occurred.

Actual value

The output current follows the actual measured value; the error is ignored.

Defined value

The error behavior of other output channels is not influenced by these settings but is defined in separate parameters.

Failure current		
Navigation	Setup → Advanced setup → Curr.output 1 to 2 → Failure current	
Prerequisite	Failure mode (→ 🗎 164) = Defined value	
Description	Defines which current the output assumes in case of an error.	
User entry	3.59 to 22.5 mA	
Output current 1 to 2		
Navigation	Setup → Advanced setup → Curr.output 1 to 2 → Output curr. 1 to 2	
Description	Shows the actual calculated value of the output current.	

"Switch output" submenu

i

The **Switch output** submenu ($\rightarrow \triangleq 166$) is only visible for devices with switch output. ⁸⁾

Navigation

Switch output function

Navigation

Description

Defines the function of the switch output.

'Off'

The switch output is always open (non-conductive)

'On'

The switch output is always closed (conductive).

'Diagnostic behavior'

The switch output is normally closed and is only opened if a diagnostic event is present.

Limit

The switch output is normally closed and is only opened if a measured variable exceeds a defined limit.

'Digital output'

The switch output is controlled by one of the digital output blocks of the device.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Digital Output

Additional information

Meaning of the options

Off

The output is always open (non-conductive).

On

The output is always closed (conductive).

Diagnostic behavior

The output is normally closed and is only opened if a diagnostic event is present. The **Assign diagnostic behavior** parameter ($\rightarrow \implies 167$) determines for which type of event the output is opened.

Limit

The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters:

- **■** Switch-on value (→ 🗎 168)
- Digital Output

The switching state of the output tracks the output value of a DI function block. The function block is selected in the **Assign status** parameter ($\Rightarrow \implies 167$).

The **Off** and **On** options can be used to simulate the switch output.

⁸⁾ Ordering feature 020 "Power supply; Output", option B, E or G

Assign status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign status

Prerequisite Switch output function (→ 🗎 166) = Digital Output

Description Assigns a Discrete Output Block or an Advanced Diagnostic Block to the switch output.

Selection ■ Off

Digital output AD 1Digital output AD 2

Additional information The Digital output AD 1 and Digital output AD 2 options refer to the Advanced

Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the

switch output.

Assign limit

Navigation Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign limit

Prerequisite Switch output function ($\rightarrow \triangleq 166$) = Limit

Description Defines which process variable will be checked for limit violation.

Selection ■ Off

Level linearized

Distance

■ Interface linearized

• Interface distance *

Thickness upper layer *

■ Terminal voltage

■ Electronic temperature

Measured capacitance

■ Relative echo amplitude

Relative interface amplitude *

Absolute echo amplitude

Absolute interface amplitude *

Assign diagnostic behavior

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign diag. beh

Prerequisite Switch output function (→ 🗎 166) = Diagnostic behavior

Description Defines to which behavior of diagnostic events the switch output reacts.

^{*} Visibility depends on order options or device settings

Selection

- Alarm
- Alarm or warning
- Warning

Switch-on value

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-on value

Prerequisite Switch output function (→ 🗎 166) = Limit

Description Defines the switch-on point.

The output is closed if the assigned process variable rises above this point.


User entry Signed floating-point number

Additional information

The switching behavior depends on the relative position of the **Switch-on value** and **Switch-off value** parameters:

Switch-on value > Switch-off value

- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.




- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.

168



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on delay		
Navigation	$Setup \to Advanced \ setup \to Switch \ output \to Switch \text{-}on \ delay$	

Prerequisite ■ Switch output function (→ 🗎 166) = Limit ■ Assign limit (→ 🗎 167) ≠ Off

Description Defines the delay applied before the output is switched on.

User entry 0.0 to 100.0 s

Switch-off value	

Navigation Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off value

Prerequisite Switch output function (→ 🖺 166) = Limit

Description Defines the switch-off point.

The output is opened if the assigned process variable falls below this point.

User entry Signed floating-point number

Additional information The switching behavior depends on the relative position of the **Switch-on value** and

Switch-off value parameters; description: see the **Switch-on value** parameter

(→ 🖺 168).

Switch-off delay		
Navigation		
Prerequisite	 Switch output function (→ 🗎 166) = Limit Assign limit (→ 🖺 167) ≠ Off 	
Description	Defines the delay applied before the output is switched off.	
User entry	0.0 to 100.0 s	
Failure mode		
Navigation		
Prerequisite	Switch output function (→ 🗎 166) = Limit or Digital Output	
Description	Defines the state of the switch output in case of an error.	
Selection	Actual statusOpenClosed	
Additional information		
Switch status		
Navigation		
Description	Current status of the switch output.	
Invert output signal		
Navigation		
Description	'No' The switch output behaves as per its parameter setting. 'Yes'	
	The switching behavior is inverted as compared to its parameter setting.	

Selection

■ No ■ Yes

Meaning of the options

■ No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

"Display" submenu

The **Display** submenu is only visible if a display module is connected to the device.

Navigation

Language

Navigation

Description

Set display language.

Selection

- English
- Deutsch *
- Français
- Español
- Italiano
- Nederlands
- Portuguesa
- Polski
- **■** русский язык (Russian) *
- Svenska
- Türkçe
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
 Bahasa Indonesia *
- tiếng Việt (Vietnamese)
- čeština (Czech) *

Factory setting

The language selected in feature 500 of the product structure.

If no language has been selected: English

Additional information

Format display

Navigation

Description

Select how measured values are shown on the display.


Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values


Visibility depends on order options or device settings




■ 55 "Format display" = "1 value, max. size"




€ 56 "Format display" = "1 bargraph + 1 value"



₹ 57 "Format display" = "2 values"



₹ 58 "Format display" = "1 value large + 2 values"



"Format display" = "4 values"

- The Value 1 to 4 display \rightarrow \implies 174 parameters specify which measured values are shown on the display and in which order.
 - If more measured values are specified than the current display mode permits, the values alternate on the device display. The display time until the next change is configured in the **Display interval** parameter ($\rightarrow \implies 174$).

Value 1 to 4 display

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Value 1 display

Description Select the measured value that is shown on the local display.

Selection • Level linearized

Distance

- Interface linearized *
- Interface distance
- Thickness upper layer *
- Current output 1
- Measured current
- Current output 2
- Terminal voltage
- Electronic temperature
 Measured capacitance *
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2

Factory setting For level measurements

- Value 1 display: Level linearized
- Value 2 display: Distance
- Value 3 display: Current output 1
- Value 4 display: None

Decimal places 1 to 4

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Decimal places 1

Description This selection does not affect the measurement and calculation accuracy of the device.

Selection ■ x

■ X.X

X.XX

X.XXX

X.XXXX

Additional information The setting does not affect the measuring or computational accuracy of the device.

Display interval

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display interval

Description Set time measured values are shown on display if display alternates between values.

User entry 1 to 10 s

174

Visibility depends on order options or device settings

This parameter is only relevant if the number of selected measuring values exceeds the number of values the selected display format can display simultaneously.

Navigation Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display damping

Description Set display reaction time to fluctuations in the measured value.

User entry 0.0 to 999.9 s

Header


Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header

Description Select header contents on local display.

Selection ■ Device tag

■ Free text

Additional information



1 Position of the header text on the display

Meaning of the options

Device tag

Is defined in the **Device tag** parameter ($\rightarrow \triangleq 130$)

Free text

Is defined in the **Header text** parameter ($\rightarrow \implies 175$)

Header text

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header text

Prerequisite Header (→ 🗎 175) = Free text

Description Enter display header text.

User entry Character string comprising numbers, letters and special characters (12)

Additional information The number of characters which can be displayed depends on the characters used.

Separator		
Navigation		
Description	Select decimal separator for displaying numerical values.	
Selection	• . • ,	
Number format		
Navigation		
Description	Choose number format for the display.	
Selection	■ Decimal ■ ft-in-1/16"	
Additional information	The ft-in-1/16" option is only valid for distance units.	
Decimal places menu		
Navigation		
Description	Select number of decimal places for the representation of numbers within the operating menu.	
Selection	■ X ■ X.X ■ X.XXX ■ X.XXXX	
Additional information	 Is only valid for numbers in the operating menu (e.g. Empty calibration, Full calibration), but not for the measured value display. The number of decimal places for the measured value display is defined in the Decimal places 1 to 4 → 174 parameters. The setting does not affect the accuracy of the measurement or the calculations. 	
Backlight		
Navigation	Setup → Advanced setup → Display → Backlight	
Prerequisite	The device has the SD03 local display (with optical keys).	
Description	Switch the local display backlight on and off.	

Selection

DisableEnable

Additional information

Meaning of the options

Disable

Switches the backlight off.

■ Enable

Switches the backlight on.



Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Contrast display

Navigation Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

Factory setting Dependent on the display.

Additional information



Setting the contrast via push-buttons:

- Darker: press the 🗇 📵 buttons simultaneously.
- Brighter: press the 🖭 🖲 buttons simultaneously.

"Configuration backup display" submenu

i

This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Conf.backup disp

\sim		. •
()	perating	time

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

Last backup

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Last backup

Description Indicates when the last data backup was saved to the display module.

Configuration management

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Config. managem.

Description Select action for managing the device data in the display module.

Selection • Cancel

- Execute backup
- Restore
- Duplicate
- Compare
- Clear backup data

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ($\rightarrow \implies 179$).

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state	
Navigation	
Description	Displays which backup action is currently in progress.
Comparison result	
Navigation	
Description	Comparison between present device data and display backup.

Meaning of the display options

Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

■ No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

■ Dataset incompatible

The data sets are incompatible and can not be compared.

- To start the comparison, set **Configuration management** ($\rightarrow \equiv 178$) = **Compare**.
- If the transmitter configuration has been duplicated from a different device by Configuration management (→ 🗎 178) = Duplicate, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be Settings not identical.

"Administration" submenu

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration

Define access code	
--------------------	--

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Def. access code

Description Define release code for write access to parameters.

User entry 0 to 9 999

Additional information

- If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the configuration data of the device can then always be modified. The user is logged on in the *Maintenance* role.
- The write protection affects all parameters marked with the symbol in this document. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.
- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (\rightarrow) 138).
- Please contact your Endress+Hauser Sales Center if you lose your access code.
- For display operation: The new access code is only valid after it has been confirmed in the **Confirm access code** parameter ($\rightarrow \implies 183$).

Device reset	

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset

Description Reset the device configuration - either entirely or in part - to a defined state.

Selection • Cancel

■ To factory defaults

- To delivery settingsOf customer settings
- To transducer defaults
- Restart device

Additional information

Meaning of the options

Cancel

No action

To factory defaults

All parameters are reset to the order-code specific factory setting.

To delivery settings

All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered.

This option is only visible if customer specific settings have been ordered.

Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

■ To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

■ Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

User entry

"Define access code" wizard

The **Define access code** wizard is only available when operating via the local display. When operating via an operating tool, the **Define access code** parameter is located directly in the **Administration** submenu. The **Confirm access code** parameter is not available for operation via operating tool.

Navigation

0 to 9999

 $\mathsf{Setup} \to \mathsf{Advanced} \ \mathsf{setup} \to \mathsf{Administration} \to \mathsf{Def.} \ \mathsf{access} \ \mathsf{code}$

Define access code		
Navigation		
Description	→ 🖺 181	
Confirm access code		
Navigation		
Description	Confirm the entered access code.	

17.5 "Diagnostics" menu

Actual diagnostics Navigation \square Diagnostics \rightarrow Actual diagnos. Description Displays current diagnostic message. Additional information The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence Event text If several messages are active at the same time, the messages with the highest priority is displayed. Information on what is causing the message, and remedy measures, can be viewed via the (i) symbol on the display. **Timestamp** Navigation Diagnostics → Timestamp Description Displays the timestamp for the currently active diagnostic message. Previous diagnostics **Navigation** □ □ Diagnostics → Prev.diagnostics Description Displays the last diagnostic message which has been active before the current message. Additional information The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence The condition displayed may still apply. Information on what is causing the message, and remedy measures, can be viewed via the (i) symbol on the display.

Timestamp

Navigation □ Diagnostics → Timestamp

Description Shows the timestamp of the previous diagnostic message.

Operating time from restart

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Time fr. restart

Description Displays the time the device has been in operation since the last device restart.

Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

17.5.1 "Diagnostic list" submenu

Navigation \Box Diagnostics \rightarrow Diagnostic list

Diagnostics 1 to 5

Navigation \Box Diagnostics \rightarrow Diagnostic list \rightarrow Diagnostics 1

Description Display the current diagnostics messages with the highest to fifth-highest priority.

Additional information The display consists of:

- Symbol for event behaviorCode for diagnostic behavior
- Operating time of occurrence
- Event text

Timestamp 1 to 5

Navigation □ Diagnostics → Diagnostic list → Timestamp

Description Timestamp of the diagnostic message.

17.5.2 "Event logbook" submenu



The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Filter options	Î

Navigation

Description

Define which category of event messages is shown in the Events list submenu.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Additional information



- This parameter is only used for operation via the local display.
- The status signals are categorized according to NAMUR NE 107.

"Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ($\rightarrow \implies 187$). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- 🕒: Event has ended
- Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation \square Diagnostics \rightarrow Event logbook \rightarrow Event list

17.5.3 "Device information" submenu

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device info

Device tag

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device info \rightarrow Device tag

Description Enter the name for the measuring point.

User interface Character string comprising numbers, letters and special characters

Serial number

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device info \rightarrow Serial number

Description Shows the serial number of the measuring device.

Additional information

- Uses of the serial number
 - To identify the device quickly, e.g. when contacting Endress+Hauser.
 - To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer
- The serial number is also indicated on the nameplate.

Firmware version

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device info \rightarrow Firmware version

Description Shows the device firmware version installed.

User interface xx.yy.zz

Additional information

For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.

Device name

Navigation \square Diagnostics \rightarrow Device info \rightarrow Device name

Description Shows the name of the transmitter.

188

Order code

Navigation \blacksquare Diagnostics \rightarrow Device info \rightarrow Order code

Description Shows the device order code.

User interface Character string comprising numbers, letters and special characters

Additional information The order code is generated from the extended roder code, which defines all device

features of the product structure. In contrast, the device features can not be read directly

from the order code.

Extended order code 1 to 3

Navigation \blacksquare Diagnostics \rightarrow Device info \rightarrow Ext. order cd. 1

Description Display the three parts of the extended order code.

User interface Character string comprising numbers, letters and special characters

Additional information The extended order code indicates the version of all the features of the product structure

and thus uniquely identifies the device.

Device revision

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device info \rightarrow Device revision

Description Shows the device revision with which the device is registered with the HART

Communication Foundation.

Additional information The device revision is used to allocate the correct Device Description file (DD) to the device.

Device ID

Navigation \blacksquare Diagnostics \rightarrow Device info \rightarrow Device ID

Description Shows the device ID for identifying the device in a HART network.

Additional information In addition to the Device type and Manufacturer ID, the Device ID is part of the unique

device identification (Unique ID) which characterizes each HART device unambiguously.

Device type

Navigation \Box Diagnostics \rightarrow Device info \rightarrow Device type

Description Shows the device type with which the measuring device is registered with the HART

Communication Foundation.

Additional information

B #		•			TD
M	ลท	บหล	CTII	rer	11)

Navigation □□ Diagnostics → Device info → Manufacturer ID

Description Use this function to view the manufacturer ID with which the measuring device is

registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

17.5.4 "Measured values" submenu


Navigation \square Diagnostics \rightarrow Measured val.

Distance

Navigation \blacksquare Diagnostics \rightarrow Measured val. \rightarrow Distance

or threaded connection) and the level.

Additional information



 \blacksquare 60 Distance for bulk solid measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 130$).

Level linearized

Navigation □ Diagnostics → Measured val. → Level linearized

Description Displays linearized level.

Additional information The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 148$.

Output current 1 to 2

Navigation $\blacksquare \square$ Diagnostics \rightarrow Measured val. \rightarrow Output curr. 1 to 2

Description Shows the actual calculated value of the output current.

		_
Measured	current	1
MEasurea	current	_

Navigation \Box Diagnostics \rightarrow Measured val. \rightarrow Measur. curr. 1

Prerequisite Only available for current output 1

Description Shows the current value of the current output which is currently measured.

Terminal voltage 1

Navigation \blacksquare Diagnostics \rightarrow Measured val. \rightarrow Terminal volt. 1

Description Shows the current terminal voltage that is applied at the output.

17.5.5 "Data logging" submenu

Assign channel 1 to 4

193

Navigation

Description

Assign a process variable to logging channel.

Selection

- Off
- Level linearized
- Distance
- Unfiltered distance
- Interface linearized
- Interface distance
- Unfiltered interface distance
- Thickness upper layer *
- Current output 1
- Measured current
- Current output 2
- Terminal voltage
- Electronic temperature
- Measured capacitance
- Absolute echo amplitude
- Relative echo amplitude
- Absolute interface amplitude *
- Relative interface amplitude
- Absolute EOP amplitude
- EOP shift
- Noise of signal
- Calculated DC value ˆ
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2

Additional information

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The logged data are deleted if a new option is selected in this parameter.

^{*} Visibility depends on order options or device settings

Logging interval

Navigation □ Diagnostics → Data logging → Logging interval

Diagnostics → Data logging → Logging interval

Description Define the logging interval tlog for data logging. This value defines the time interval

between the individual data points in the memory.

User entry 1.0 to 3 600.0 s

Additional information This parameter defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log} :

■ If 1 logging channel is used: $T_{log} = 1000 \cdot t_{log}$

• If 2 logging channels are used: $T_{log} = 500 \cdot t_{log}$

■ If 3 logging channels are used: $T_{log} = 333 \cdot t_{log}$

• If 4 logging channels are used: $T_{log} = 250 \cdot t_{log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T $_{log}$ always remains in the memory (ring memory principle).

🊹 The logged data are deleted if this parameter is changed.

Example

When using 1 logging channel

- $T_{log} = 1000 \cdot 1 \text{ s} = 1000 \text{ s} \approx 16.5 \text{ min}$
- $T_{log} = 1000 \cdot 10 \text{ s} = 1000 \text{ s} \approx 2.75 \text{ h}$
- $T_{log} = 1000 \cdot 80 \text{ s} = 80000 \text{ s} \approx 22 \text{ h}$
- \bullet T_{log} = 1000 · 3600 s = 3600000 s ≈ 41 d

Clear logging data

Navigation □ Diagnostics → Data logging → Clear logging

■ Diagnostics → Data logging → Clear logging

Description Clear the entire logging data.


Selection • Cancel

■ Clear data

"Display channel 1 to 4" submenu

The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.
- To return to the operating menu, press \pm and \Box simultaneaously.

Navigation

□ Diagnostics → Data logging → Displ.channel 1 to 4

17.5.6 "Simulation" submenu


The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.

Conditions which can be simulated

Condition to be simulated	Associated parameters
Specific value of a process variable	 Assign measurement variable (→ 🗎 198) Process variable value (→ 🖺 198)
Specific value of the output current	 Current output simulation (→ 🖺 198) Value current output (→ 🖺 199)
Specific state of the switch output	 Switch output simulation (→ ☐ 199) Switch status (→ ☐ 199)
Existence of an alarm	Device alarm simulation ($\rightarrow \stackrel{ riangle}{ riangle}$ 200)
Existence of a specific diagnostic message	Diagnostic event simulation (→ 🖺 200)

Structure of the submenu

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation



Description of parameters

Navigation $\blacksquare \square$ Expert \rightarrow Diagnostics \rightarrow Simulation

Assign measurement variable

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Assign meas.var.

Description Defines the process variable to be simulated.

Selection ■ Off

- Level
- Interface *
- Thickness upper layer *Level linearizedInterface linearized

Thickness linearized

Additional information

- The value of the variable to be simulated is defined in the **Process variable value** parameter ($\rightarrow \cong 198$).
- If **Assign measurement variable** ≠ **Off**, a simulation is active. This is indicated by a diagnotic message of the *Function check (C)* category.

Process variable value

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Proc. var. value

Prerequisite Assign measurement variable (→ 🖺 198) ≠ Off

Description Defines the value of the selected variable.

The outputs assume values or states according to this value.

User entry Signed floating-point number

Additional information Downstream measured value processing and the signal output use this simulation value. In

this way, users can verify whether the measuring device has been configured correctly.

Current output 1 to 2 simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Curr.out. 1 to 2 sim.

Description Switch the simulation of the current output on and off.

198

Visibility depends on order options or device settings

Selection ■ Off

■ On

Additional information An active simulation is indicated by a diagnostic message of the *Function check (C)*

category.

Value current output 1 to 2

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Value curr.out 1 to 2

Prerequisite Current output simulation (→ 🗎 198) = On

Description Defines the value of the simulated output current.

User entry 3.59 to 22.5 mA

Additional information The current output assumes the value specified in this parameter. In this way, users can

verify the correct adjustment of the current output and the correct function of connected

control units.

Switch output simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch sim.

Description Switch the simulation of the switch output on and off.

Selection ■ Off

On

Switch status

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch status

Prerequisite Switch output simulation ($\rightarrow = 199$) = On

Description Current status of the switch output.

Selection • Open

Closed

Additional information

The switch status assumes the value defined in this parameter. This helps to check correct

operation of connected control units.

Device alarm simulation

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Dev. alarm sim.

Description Switch the device alarm on and off.

Selection ■ Off

■ On

Additional information When selecting the **On** option, the device generates an alarm. This helps to check the

correct output behavior of the device in the case of an alarm.

An active simulation is indicated by the **♦C484 Failure mode simulation** diagnostic

message.

Diagnostic event simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Diag. event sim.

Description Select the diagnostic event to be simulated.

Note:

To terminate the simulation, select 'Off'.

Additional information When operated via the local display, the selection list can be filtered according to the event

categories (**Diagnostic event category** parameter).

17.5.7 "Device check" submenu

Navigation \Box Diagnostics \rightarrow Device check

Start device check

Navigation \blacksquare Diagnostics \rightarrow Device check \rightarrow Start dev. check

Description Start a device check.

Selection ■ No

Yes

Additional information In the case of a lost echo a device check can not be performed.

Result device check

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device check \rightarrow Result dev.check

Description Displays the result of the device check.

Additional information Meaning of the display options

Installation ok

Measurement possible without restrictions.

Accuracy reduced

A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes.

■ Measurement capability reduced

A measurement is currently possible. However, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.

Check not done

No device check has been performed.

Last check time

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Last check time

Description Displays the operating time at which the last device check has been performed.

User interface Character string comprising numbers, letters and special characters

		-
Level	CIA	ทอเ
TCACI	SIU.	цаі

Navigation \blacksquare Diagnostics \rightarrow Device check \rightarrow Level signal

Prerequisite Device check has been performed.

Description Displays result of the device check for the level signal.

User interface ■ Check not done

Check not OKCheck OK

Additional information

For Level signal = Check not OK: Check the mounting position of the device and the

dielectric constant of the medium.

Launch signal

Navigation \Box Diagnostics \rightarrow Device check \rightarrow Launch signal

Prerequisite Device check has been performed.

Description Displays result of the display check for the launch signal.

User interface ■ Check not done

Check not OKCheck OK

Additional information

For **Launch signal** = **Check not OK**: Check the mounting position of the device. In non-

metallic vessels use a metal plate or a metal flange.

17.5.8 "Heartbeat" submenu

The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

Detailed description SD01872F

Navigation \square Diagnostics \rightarrow Heartbeat

Index

A	Deactivate SIL/WHG (Wizard) 158
Access authorization to parameters	Decimal places 1 (Parameter)
Read access 61	Decimal places menu (Parameter) 176
Write access	Define access code 61
Access code	Define access code (Parameter) 181, 183
Incorrect input 61	Define access code (Wizard)
Access status display (Parameter)	Designated use
Access status tooling (Parameter)	Device alarm simulation (Parameter) 200
Accessories	Device check (Submenu)
Communication-specific	Device Descriptions
Device-specific	Device ID (Parameter)
Service-specific	Device information (Submenu)
System components	Device name (Parameter)
Activate table (Parameter)	Device replacement
Actual diagnostics (Parameter)	Device reset (Parameter)
Administration (Submenu)	Device revision (Parameter)
Advanced process conditions (Parameter) 141	Device tag (Parameter)
Advanced setup (Submenu)	Device type (Parameter)
Application	Diagnostic event
Assign channel 1 to 4 (Parameter) 193	In the operating tool
Assign current output (Parameter) 162	Diagnostic event simulation (Parameter) 200
Assign diagnostic behavior (Parameter) 167	Diagnostic events
Assign limit (Parameter)	Diagnostic list
Assign measurement variable (Parameter) 198	Diagnostic list (Submenu)
Assign status (Parameter) 167	Diagnostic message
_	Diagnostics
В	Symbols
Backlight (Parameter)	Diagnostics (Menu)
Backup state (Parameter)	Diagnostics 1 (Parameter)
Bin type (Parameter)	Diagnostics event
Blocking distance (Parameter) 142, 155	Diameter (Parameter)
Bluetooth® wireless technology	DIP switch
C	see Write protection switch
C	Display (Submenu)
Cleaning	Display and operating module FHX50
Clear logging data (Parameter)	Display channel 1 to 4 (Submenu)
Code incorrect (Parameter)	Display damping (Parameter)
Comparison result (Parameter)	Display interval (Parameter)
Configuration backup display (Submenu)	Display module
Configuration management (Parameter)	Display symbols
Configuration of a level measurement	Disposal
Configuring level measurement	Distance (Parameter) 132, 136, 191
Confirm access code (Parameter)	Distance unit (Parameter)
Confirm distance (Parameter)	Document
Confirm probe length (Parameter) 160, 161	Function
Contract display (Pagements) 177	Document function
Contrast display (Parameter)	Е
Current output 1 to 2 (Submenu)	Electronics housing
Current output 1 to 2 simulation (Parameter) 198	5
Current span (Parameter)	Design
Customer value (Parameter)	Empty calibration (Parameter)
D	Enter access code (Parameter)
Damping output (Parameter)	Envelope curve display
Data logging (Submenu)	Event level
DD	Explanation
~~	Explanation

204

Symbols 90 Event list (Submenu) 187	Local display
Event logbook (Submenu)	Locking status
Events list	Locking status (Parameter)
Extended order code 1 (Parameter) 189	Logging interval (Parameter)
Exterior cleaning	
F	M Maintananga
Failure current (Parameter)	Maintenance
Failure mode (Parameter)	Manufacturer ID (Parameter)
FHX50	Mapping (Wizard)
Field of application	Mapping end point (Parameter)
Residual risks	Maximum value (Parameter)
Filter options (Parameter)	Measured current 1 (Parameter) 192
Filtering the event logbook	Measured value symbols 68
Firmware version (Parameter)	Measured values (Submenu) 191
Fixed current (Parameter)	Media
Flange	Medium property (Parameter)
Format display (Parameter)	Medium type (Parameter)
Free text (Parameter)	Menu 10/
Full calibration (Parameter)	Diagnostics
FV (HART device variable)	Setup
H	infounding position for level measurements
Hardware write protection 62	N
HART device variables	Non-metal vessels
HART protocol	Number format (Parameter) 176
HART-Integration	0
Header (Parameter)	0
Header text (Parameter)	Occupational safety
Heartbeat (Submenu)	Operating elements
Housing Design	Diagnostics message
Turning	Operating time (Parameter)
1 th ming	Operating time from restart (Parameter)
I	Operational safety
Input mask	Order code (Parameter)
Intermediate height (Parameter)	Output current 1 to 2 (Parameter) 165, 191
Invert output signal (Parameter)	Output echo lost (Parameter)
K	Overvoltage protection
	General information
Keypad lock Disabling	P
Switching on	Present mapping (Parameter)
Switching on	Present probe length (Parameter)
L	Previous diagnostics (Parameter)
Language (Parameter)	Probe grounded (Parameter)
Last backup (Parameter)	Probe length correction (Wizard) 161
Last check time (Parameter) 201	Probe settings (Submenu)
Launch signal (Parameter)	Process property (Parameter)
Level (Parameter)	Process variable value (Parameter)
Level (Submenu)	Product safety
Level correction (Parameter)	PV (HART device variable)
Level signal (Parameter)	R
Level unit (Parameter)	Ramp at echo lost (Parameter)
Linearization (Submenu)	Read access
Linearization type (Parameter)	Record map (Parameter) 135, 136
	Registered trademarks

Remedial measures	Linearization
Calling up	Measured values
Closing	Probe settings
Remote operation	Safety settings
Repair concept	Simulation
Replacing a device	Switch output
Requirements for personnel	SV (HART device variable)
Reset write protection (Parameter)	Switch output (Submenu)
Result device check (Parameter)	Switch output function (Parameter) 166
Return	Switch output simulation (Parameter)
Rod probe	Switch status (Parameter) 170, 199
Design	Switch-off delay (Parameter)
Rod probes	Switch-off value (Parameter)
Lateral loading capacity	Switch-on delay (Parameter)
Shortening	Switch-on value (Parameter) 168
Rope probe	Symbols For correction
Design	In the text and numeric editor
Rope probes Installation	
Shortening	System components
Shortening	Т
S	Table mode (Parameter)
Safety instructions	Table number (Parameter)
Basic	Terminal voltage 1 (Parameter)
Safety Instructions (XA)	Thermal insulation
Safety settings (Submenu)	Threaded connection
Securing rod probes	Timestamp (Parameter) 184, 185, 186
Securing rope probes	Tool
Separator (Parameter)	Transmitter
Serial number (Parameter)	Turning the display
Service interface (CDI)	Turning the display module
Setting the operating language	Transmitter housing
Settings	Turning
Managing the device configuration 84	Troubleshooting
Operating language	Turning the display
Setup (Menu)	Turning the display module
Signal quality (Parameter)	TV (HART device variable)
SIL/WHG confirmation (Wizard)	U
Simulation (Submenu)	_
Spare parts	Unit after linearization (Parameter)
Nameplate	Use of the measuring device
Start device check (Parameter)	see Designated use
Status signals	Using measuring devices Borderline cases
Submenu 191	Incorrect use
Administration	incorrect use
Advanced setup	V
Current output 1 to 2	Value 1 display (Parameter)
Data logging	Value current output 1 to 2 (Parameter) 199
Device check	Value echo lost (Parameter)
Device information	
Diagnostic list	W
Display	Wizard
Display channel 1 to 4	Deactivate SIL/WHG
Event list	Define access code
Event logbook	Mapping
Events list	Probe length correction
Heartbeat	SIL/WHG confirmation
Level	Write access

206

Write protection	
Via access code 6	1
Via write protection switch 62	2
Write protection switch 62	2



www.addresses.endress.com