71574894 2022-08-01 Valid as of version 01.06.zz (Device firmware)

BA01392D/06/EN/04.22-00

Operating Instructions **Proline Promag H 300**

Electromagnetic flowmeter HART







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document	6
1.1 1.2 1.3 1.4	Document functionSymbols1.2.1Safety symbols1.2.2Electrical symbols1.2.3Communication-specific symbols1.2.4Tool symbols1.2.5Symbols for certain types of information1.2.6Symbols in graphicsDocumentation1.3.1Document functionRegistered trademarks	6 6 6 7 7 8 8 8
2	Safety instructions	9
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Operational safetyProduct safetyIT securityIT securityDevice-specific IT security2.7.1Protecting access via hardware write protection2.7.2Protecting access via a password2.7.3Access via Web server2.7.4Access via Service interface (CDI-	9 9 10 10 10 11 11 11 12 13 13
3	Product description 1	ι4
3.1	Product design	14
4 4.1 4.2	Incoming acceptanceProduct identification4.2.1Transmitter nameplate4.2.2Sensor nameplate	L5 15 16 17 18
5 5.1 5.2	Storage conditions Transporting the product 5.2.1 Measuring devices without lifting lugs 5.2.2 Measuring devices with lifting lugs 5.2.3 Transporting with a fork lift	L 9 19 19 19 20 20
5.3	Packaging disposal	20

6	Mounting	20
6.1	Mounting requirements	20
	6.1.1 Mounting position	20
	6.1.2 Environment and process	
	requirements	25
	6.1.3 Special mounting instructions	26
6.2	Mounting the measuring device	26
	6.2.1 Required tools	26
	6.2.2 Preparing the measuring device	27
	6.2.3 Turning the transmitter housing	27
	6.2.4 Turning the display module	28
6.3	Post-installation check	28
7	Electrical connection	29
7.1	Electrical safety	29
7.2	Connecting requirements	29
7.2	7.2.1 Required tools	29
	7.2.2 Requirements for connecting cable	29
	7.2.3 Terminal assignment	32
	7.2.4 Preparing the measuring device	32
7.3	Connecting the measuring device	32
	7.3.1 Connecting the transmitter	32
	7.3.2 Connecting the remote display and	22
	operating module DKX001	35
7.4	Ensuring potential equalization	35
	7.4.1 Requirements	35
	7.4.2 Connection example, standard	
	scenario	35
	7.4.3 Connection example in special	
	situations	36
7.5	Special connection instructions	37
	7.5.1 Connection examples	37
7.6	Ensuring the degree of protection	41
7.7	Post-connection check	42
8	Operation options	43
8.1	Overview of operation options	43
8.2	Structure and function of the operating	
	menu	44
	8.2.1 Structure of the operating menu	44
8.3	8.2.2 Operating philosophy Access to the operating menu via the local	45
	display	46
	8.3.1 Operational display	46
	8.3.2 Navigation view	47
	8.3.3 Editing view	49
	8.3.4 Operating elements	51
	8.3.5 Opening the context menu	51
	8.3.6 Navigating and selecting from list	53
	8.3.7 Calling the parameter directly	53
	8.3.8 Calling up help text	54
	8.3.9 Changing the parameters	54
	8.3.10 User roles and related access	
	authorization	55

	8.3.11	Disabling write protection via access	
		code	55
	8.3.12	Enabling and disabling the keypad	
		lock	56
8.4	Access	to the operating menu via the Web	
		r	56
	8.4.1	Function scope	56
	8.4.2	Requirements	57
	8.4.3	Establishing a connection	58
	8.4.4	Logging on	60
	8.4.5	User interface	61
	8.4.6	Disabling the Web server	62
	8.4.7	Logging out	62
8.5	e · · · · ·	to the operating menu via the	02
0.7		ng tool	63
	8.5.1	Connecting the operating tool	63
	8.5.1 8.5.2		66
		Field Xpert SFX350, SFX370	
	8.5.3	FieldCare	66
	8.5.4	DeviceCare	68
	8.5.5	AMS Device Manager	68
	8.5.6	SIMATIC PDM	69
	8.5.7	Field Communicator 475	69
-	_		
9	Syster	n integration	70
9.1	Overvie	w of device description files	70
	9.1.1	Current version data for the device	70
	9.1.2	Operating tools	70
9.2	Measur	red variables via HART protocol	70
9.3		ettings	72
	Ould b		
	Other 3	ctungs	, 2
		2	
10	Comm	nissioning	75
10 10.1	Comm Functio	nissioning	75 75
10 10.1 10.2	Comm Functio Switchin	nissioning n check ng on the measuring device	75 75 75
10 10.1 10.2 10.3	Comm Functio Switchin Setting	nissioning n check ng on the measuring device the operating language	75 75 75 75
10 10.1 10.2	Comm Functio Switchin Setting Configu	nissioning n check ng on the measuring device the operating language uring the measuring device	75 75 75 75 75
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name	75 75 75 75 75 75
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Setting the system units	75 75 75 75 75 77 77
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Setting the system units Displaying the I/O configuration	75 75 75 75 77 77 77
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4	n check	75 75 75 75 77 77 79 80
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5	n check	75 75 75 75 77 77 79 80 80
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6	n check	75 75 75 75 77 77 79 80
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Setting the system units Displaying the I/O configuration Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/	75 75 75 75 77 77 79 80 80 82
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Setting the system units Displaying the I/O configuration Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output	75 75 75 75 77 77 79 80 80
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Setting the system units Setting the system units Displaying the I/O configuration Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/	75 75 75 75 77 77 79 80 80 82
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Setting the system units Displaying the I/O configuration Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output	75 75 75 75 77 77 79 80 80 80 82
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.8	n check	75 75 75 75 77 77 79 80 80 80 82 85 91
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10	n check	75 75 75 75 77 77 80 80 80 82 85 91 93
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.11	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Displaying the I/O configuration Configuring the status input Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output Configuring the local display Configuring the low flow cut off Configuring empty pipe detection	75 75 75 75 77 77 80 80 80 82 85 91 93 94
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.11 10.4.12	n check	75 75 75 75 77 77 79 80 80 80 82 85 91 93 94 94
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.11 10.4.12 10.4.13	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Setting the system units Displaying the tag name Setting the system units Displaying the tag name Configuring the status input Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output Configuring the local display Configuring the low flow cut off Configuring the low flow cut off Configuring the HART input Configuring the relay output Configuring the double pulse output	75 75 75 75 77 77 79 80 80 82 85 91 93 94 94 94 97
10 10.1 10.2 10.3	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.11 10.4.12 10.4.13 10.4.14	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Displaying the I/O configuration Configuring the status input Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output Configuring the local display Configuring the local display Configuring the low flow cut off Configuring the HART input Configuring the relay output Configuring the double pulse output	75 75 75 75 77 77 79 80 80 82 85 91 93 94 93 94 93 94 93
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.11 10.4.12 10.4.13 10.4.14	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Setting the system units Displaying the I/O configuration Configuring the status input Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output Configuring the local display Configuring the local display Configuring the low flow cut off Configuring the HART input Configuring the relay output Configuring the double pulse output	75 75 75 75 77 77 77 80 80 80 82 85 91 93 94 94 94 97 98 99
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.13 10.4.14 Advanc	n check	75 75 75 75 77 77 77 80 80 80 82 85 91 93 94 94 94 97 98 99
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.13 10.4.14 Advanc	nissioning	75 75 75 75 77 77 79 80 80 80 82 85 91 93 94 94 97 98 99 102
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.13 10.4.14 Advanc 10.5.1 10.5.2	nissioning n check ng on the measuring device the operating language uring the measuring device Defining the tag name Defining the tag name Defining the system units Displaying the I/O configuration Configuring the status input Configuring the status input Configuring the current input Configuring the current output Configuring the pulse/frequency/ switch output Configuring the local display Configuring the low flow cut off Configuring the low flow cut off Configuring the HART input Configuring the double pulse output Configuring flow damping Using the parameter to enter the access code Carrying out a sensor adjustment	75 75 75 75 77 77 79 80 80 82 85 91 93 94 94 94 97 98 99 102 103 103
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.12 10.4.13 10.4.14 Advance 10.5.1 10.5.2 10.5.3	nissioning	75 75 75 75 77 77 79 80 80 80 82 85 91 93 94 94 94 97 98 99 102 103
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.13 10.4.14 Advanc 10.5.1 10.5.2	nissioning	75 75 75 75 77 77 79 80 80 82 85 91 93 94 93 94 97 98 94 97 98 91 102 103 103
10 10.1 10.2 10.3 10.4	Comm Functio Switchin Setting Configu 10.4.1 10.4.2 10.4.3 10.4.3 10.4.4 10.4.5 10.4.6 10.4.7 10.4.8 10.4.9 10.4.10 10.4.12 10.4.12 10.4.13 10.4.14 Advance 10.5.1 10.5.2 10.5.3	hissioning	75 75 75 75 77 77 79 80 80 82 85 91 93 94 94 94 97 98 99 102 103 103

	10.5.6 WLAN configuration	110
	10.5.7 Configuration management	111
	10.5.8 Using parameters for device	
	administration	113
10.6	Simulation	114
10.7	Protecting settings from unauthorized access	117
	10.7.1 Write protection via access code	117
	10.7.2 Write protection via write protection	110
	switch	119
11	Operation	120
11.1	Reading off the device locking status	120
11.2	Adjusting the operating language	120
11.3	Configuring the display	120
11.4	Reading measured values	120
	11.4.1 "Process variables" submenu	120
	11.4.2 "Totalizer" submenu	122
	11.4.3 "Input values" submenu	122
	11.4.4 Output values	123
11.5	Adapting the measuring device to the process	
	conditions	126
11.6	Performing a totalizer reset	126
	11.6.1 Function scope of "Control Totalizer"	107
	parameter 11.6.2 Function scope of the "Reset all	127
	11.6.2 Function scope of the "Reset all totalizers" parameter	127
11.7	Show data logging	127
11.7		127
12	5	131
12.1	General troubleshooting	131
12.2	Diagnostic information via light emitting	100
	diodes	133
12.3	12.2.1 Transmitter	133 135
12.5	Diagnostic information on local display 12.3.1 Diagnostic message	135
	12.3.1 Diagnostic message 12.3.2 Calling up remedial measures	137
12.4	Diagnostic information in the Web browser .	137
12.1	12.4.1 Diagnostic options	137
	12.4.2 Calling up remedy information	138
12.5	Diagnostic information in FieldCare or	
	DeviceCare	139
	12.5.1 Diagnostic options	139
	12.5.2 Calling up remedy information	140
12.6	Adapting the diagnostic information	140
	12.6.1 Adapting the diagnostic behavior	140
10 5	12.6.2 Adapting the status signal	140
12.7	Overview of diagnostic information	141
12.8	Pending diagnostic events	145
12.9 12.10	Diagnostic list Event logbook	146 146
12.10	12.10.1 Reading out the event logbook	140 146
	12.10.2 Filtering the event logbook	147
	12.10.3 Overview of information events	147
12.11	Resetting the measuring device	149
	12.11.1 Function scope of "Device reset"	
	parameter	149
	Device information	149
12.13	Firmware history	151

12.14	Device history and compatibility	152
13	Maintenance	153
13.1	Maintenance tasks	153
	13.1.1 Exterior cleaning	153
	13.1.2 Interior cleaning	153
	13.1.3 Replacing seals	153
13.2	Measuring and test equipment	153
13.3	Endress+Hauser services	153
14	Repair	154
14.1	General information	154
14.1	14.1.1 Repair and conversion concept	154
	14.1.2 Notes for repair and conversion	154
14.2	-	154
14.2 14.3	Spare parts Endress+Hauser services	154
14.5		154
14.4 14.5	Return	154
14.5	Disposal	155
	14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device	155 155
15	Accessories	156
15.1	Device-specific accessories	156
	15.1.1 For the transmitter	156
	15.1.2 For the sensor	157
15.2	Communication-specific accessories	157
15.3	Service-specific accessories	158
15.4	System components	159
16	Technical data	160
16.1	Application	160
16.2	Function and system design	160
16.3	Input	160
16.4	Output	164
16.5	Power supply	170
16.6	Performance characteristics	171
16.7	Installation	173
16.8	Environment	173
16.9	Process	175
	Mechanical construction	176
	Operability	180
	Certificates and approvals	184
	Application packages	187
	Accessories	188
	Supplementary documentation	188
Index	.	191

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
\sim	Alternating current
\sim	Direct current and alternating current
<u>+</u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Potential equalization connection (PE: protective earth) Ground terminals that must be connected to ground prior to establishing any other connections.
	The ground terminals are located on the interior and exterior of the device:Interior ground terminal: potential equalization is connected to the supply network.Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Communication-specific symbols

Symbol	Meaning
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
	LED Light emitting diode is off.

Symbol	Meaning
Ϋ́.	LED Light emitting diode is on.
	LED Light emitting diode is flashing.

1.2.4 Tool symbols

Symbol	Meaning
•	Flat-blade screwdriver
$\bigcirc \not \blacksquare$	Allen key
Ń	Open-ended wrench

1.2.5 Symbols for certain types of information

Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
►	Notice or individual step to be observed
1., 2., 3	Series of steps
L.	Result of a step
?	Help in the event of a problem
	Visual inspection

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
\bowtie	Safe area (non-hazardous area)
≈ →	Flow direction

1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code on the nameplate

1.3.1 Document function

Document type	Purpose and content of the document			
Technical Information (TI)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.			
Brief Operating Instructions (KA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.			
Operating Instructions (BA)	Your reference guide These Operating Instructions contain all the information that is required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.			
Description of Device Parameters (GP)	Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.			
Safety Instructions (XA)	Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. They are an integral part of the Operating Instructions. The nameplate indicates which Safety Instructions (XA) apply to the device in question.			
Supplementary device-dependent documentation	Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.			

1.4 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids with a minimum conductivity of 5 μ S/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are marked accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified pressure and temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ► If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation → <a> 8.
- Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- Verify the compatibility of the process fluid with the sensor material.
- Ensure the resistance of all fluid-wetted materials in the process.
- ► Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

WARNING

If the temperature of the media or electronics unit is high or low, this may cause the surfaces of the device to become hot or cold. This poses a risk of burns or frostbite!

► In the case of hot or cold medium temperatures, install appropriate protection against contact.

2.3 Workplace safety

When working on and with the device:

• Wear the required personal protective equipment as per national regulations.

2.4 Operational safety

Risk of injury!

- Operate the device only if it is in proper technical condition, free from errors and faults.
- ► The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

Furthermore, the device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards.

By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com

2.6 IT security

Our warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section:

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \textcircled{B} 11$	Not enabled	On an individual basis following risk assessment
Access code (also applies for Web server login or FieldCare connection) $\rightarrow {}12$	Not enabled (0000)	Assign a customized access code during commissioning
WLAN (order option in display module)	Enabled	On an individual basis following risk assessment
WLAN security mode	Enabled (WPA2- PSK)	Do not change
WLAN passphrase (password) → 🗎 12	Serial number	Assign a customized WLAN passphrase during commissioning
WLAN mode	Access point	On an individual basis following risk assessment
Web server $\rightarrow \square 12$	Enabled	On an individual basis following risk assessment
CDI-RJ45 service interface $\rightarrow \square 13$	-	On an individual basis following risk assessment

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered $\rightarrow \square$ 119.

2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

User-specific access code

Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.

- WLAN passphrase The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode

When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ($\rightarrow \square$ 117).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface ($\rightarrow \bowtie 65$), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter ($\rightarrow \equiv 111$).

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see the "Write protection via access code" section →
 ⁽¹⁾ 117

2.7.3 Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server ($\rightarrow \cong 56$). The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

F F

For detailed information on device parameters, see: The "Description of Device Parameters" document $\rightarrow \cong 189$.

2.7.4 Access via OPC-UA

The device can communicate with OPC UA clients using the "OPC UA Server" application package.

The OPC UA server integrated in the device can be accessed via the WLAN access point using the WLAN interface - which can be ordered as an optional extra - or the service interface (CDI- RJ45) via Ethernet network. Access rights and authorization as per separate configuration.

The following Security Modes are supported as per the OPC UA Specification (IEC 62541):

- None
- Basic128Rsa15 signed
- Basic128Rsa15 signed and encrypted

2.7.5 Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

Transmitters with an Ex de approval may not be connected via the service interface (CDI-RJ45)!

Order code for "Approval transmitter + sensor", options (Ex de): BA, BB, C1, C2, GA, GB, MA, MB, NA, NB


3 Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design




■ 1 Important components of a measuring device

- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing
- 4 Electronics compartment cover
- 5 Sensor

4 Incoming acceptance and product identification

4.1 Incoming acceptance



4.2 Product identification


The following options are available for identification of the device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations App* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations App*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" and "Supplementary device-dependent documentation"
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.


4.2.1 Transmitter nameplate



Example of a transmitter nameplate

- 1 Place of manufacture
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Date of manufacture: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, RCM tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature (T_a)
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

4.2.2 Sensor nameplate



🛃 3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Place of manufacture
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Flow; nominal diameter of the sensor; pressure rating; nominal pressure; system pressure; medium temperature range; material of liner and electrodes
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Flow direction
- 9 2-D matrix code
- 10 Date of manufacture: year-month
- Document number of safety-related supplementary documentation 11
- CE mark, RCM-Tick mark 12
- 13 Permitted ambient temperature (T_a)



Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

Symbol	Meaning		
\triangle	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. To determine the nature of the potential hazard and the measures required to avoid it, consult the documentation accompanying the measuring device.		
Ĩ	Reference to documentation Refers to the corresponding device documentation.		
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.		

4.2.3 Symbols on measuring device

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring pipe.
- ▶ Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the liner.
- Store in a dry and dust-free place.
- ► Do not store outdoors.

Storage temperature $\rightarrow \square 173$

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- Observe the weight specified on the packaging (stick-on label).



5.2.2 Measuring devices with lifting lugs

ACAUTION

Special transportation instructions for devices with lifting lugs

- Only use the lifting lugs fitted on the device or flanges to transport the device.
- The device must always be secured at two lifting lugs at least.


5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

ACAUTION

Risk of damaging the magnetic coil

- If transporting by forklift, do not lift the sensor by the metal casing.
- This would buckle the casing and damage the internal magnetic coils.



5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:

- Outer packaging of device
 - Polymer stretch wrap, complying with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
- Disposable plastic pallet
- Plastic straps
- Plastic adhesive strips
- Filler material
- Paper pads


6 Mounting

6.1 Mounting requirements


6.1.1 Mounting position

Mounting location

- Do not install the device at the highest point of the pipe.
- Do not install the device upstream from a free pipe outlet in a down pipe.



The device should ideally be installed in an ascending pipe.



Installation upstream from a down pipe


NOTICE

Negative pressure in the measuring pipe can damage the liner!

• If installing upstream of down pipes whose length $h \ge 5 \text{ m}$ (16.4 ft): install a siphon with a vent valve downstream of the device.




This arrangement prevents the flow of liquid stopping in the pipe and air entrainment.



- 1 Vent valve
- Pipe siphon 2
- Length of down pipe h

Installation with partially filled pipes

- Partially filled pipes with a gradient require a drain-type configuration.
- The installation of a cleaning valve is recommended.




Installation near pumps

NOTICE

Negative pressure in the measuring pipe can damage the liner!

- ► In order to maintain the system pressure, install the device in the flow direction downstream from the pump.
- ► Install pulsation dampers if reciprocating, diaphragm or peristaltic pumps are used.



Information on the liner's resistance to partial vacuum

• Information on the measuring system's resistance to vibration and shock \rightarrow 🗎 174


Installation in event of pipe vibrations

A remote version is recommended in the event of strong pipe vibrations.

NOTICE

Pipe vibrations can damage the device!

- Do not expose the device to strong vibrations.
- Support the pipe and fix it in place.
- Support the device and fix it in place.
- Mount the sensor and transmitter separately.



Information on the measuring system's resistance to vibration and shock ightarrow 🖺 174

Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orien	Recommendation	
Vertical orientation		
	A0015591	
Horizontal orientation	- <u>ε</u> [[]]ε]α	1)
	A0041328	
Horizontal orientation, transmitter at bottom		2) 3) (4)
	A0015590	
Horizontal orientation, transmitter at side		×
	A0015592	

- 1) The measuring device should be self-draining for hygiene applications. A vertical orientation is recommended for this. If only a horizontal orientation is possible, an angle of inclination $\alpha \ge 10^{\circ}$ is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- 3) To prevent the electronics from overheating in the event of strong heat formation (e.g. CIP or SIP cleaning process), install the device with the transmitter part pointing downwards.
- 4) When the empty pipe detection function is switched on, empty pipe detection only works if the transmitter housing is pointing upwards.


Vertical

Optimum for self-emptying pipe systems and for use in conjunction with empty pipe detection.



Horizontal

- Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the measuring electrodes by entrained air bubbles.
- Empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.




- 1 EPD electrode for empty pipe detection (available from $DN > 15 \text{ mm} (\frac{1}{2} \text{ in})$)
- 2 Measuring electrodes for signal detection
- Measuring devices with a nominal diameter < DN 15 mm (½ in) do not have an EPD electrode. In this case, empty pipe detection is performed via the measuring electrodes.


Inlet and outlet runs

Installation with inlet and outlet runs

To avoid a vacuum and to maintain the specified level of accuracy, install the device upstream from assemblies that produce turbulence (e.g. valves, T-sections) and downstream from pumps.

Maintain straight, unimpeded inlet and outlet runs.





Dimensions

For the dimensions and installed lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Environment and process requirements

Ambient temperature range

Transmitter	Standard: -40 to +60 °C (-40 to +140 °F)
Local display	-20 to $+60$ °C (-4 to $+140$ °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	-40 to +60 °C (-40 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner .

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

System pressure

Installation near pumps \rightarrow \cong 22

Vibrations

Installation in event of pipe vibrations \rightarrow \cong 22

Adapters


Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



The nomogram only applies to liquids with a viscosity similar to that of water.
If the medium has a high viscosity, a larger measuring tube diameter can be considered in order to reduce pressure loss.


1. Calculate the ratio of the diameters d/D.

2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.



6.1.3 Special mounting instructions

Weather protection cover



E 4 Engineering unit mm (in)

Hygienic compatibility

- When installing in hygienic applications, please refer to the information in the "Certificates and approvals/hygienic compatibility" section $\rightarrow \cong 185$
 - In the case of measuring devices with the order code for "Housing", option B "Stainless, hygienic", to seal the connection compartment cover, screw it closed finger-tight and tighten it by another 45° (corresponds to 15 Nm).

6.2 Mounting the measuring device

6.2.1 Required tools

For sensor


For flanges and other process connections: use a suitable mounting tool

6.2.2 Preparing the measuring device

- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.


6.2.3 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



☑ 5 Non-Ex housing

- **1.** Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Loosen the securing screw.
- 4. Turn the housing to the desired position.
- 5. Tighten the securing screw.
- 6. Screw on the connection compartment cover.
- **7.** Depending on the device version: Attach the securing clamp of the connection compartment cover.




■ 6 Ex housing

- 1. Loosen the fixing screws.
- 2. Turn the housing to the desired position.
- 3. Tighten the securing screws.

6.2.4 Turning the display module

The display module can be turned to optimize display readability and operability.



- **1.** Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Turn the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 4. Screw on the connection compartment cover.
- 5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.3 Post-installation check

Is the device undamaged (visual inspection)?		
 Does the measuring device conform to the measuring point specifications? For example: Process temperature Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) Ambient temperature Measuring range 		
 Has the correct orientation been selected for the sensor → 23 ? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids) 		
Does the arrow on the sensor nameplate match the actual direction of flow of the fluid through the piping $\rightarrow \bigoplus 23$?		
Are the measuring point identification and labeling correct (visual inspection)?		
Have the fixing screws been tightened with the correct tightening torque?		

7 Electrical connection

WARNING

Live parts! Incorrect work performed on the electrical connections can result in an electric shock.

- ► Set up a disconnecting device (switch or power-circuit breaker) to easily disconnect the device from the supply voltage.
- ► In addition to the device fuse, include an overcurrent protection unit with max. 10 A in the plant installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: Crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver \leq 3 mm (0.12 in)

7.2.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Protective grounding cable for the outer ground terminal

Conductor cross-section < 2.1 mm² (14 AWG)

The use of a cable lug enables the connection of larger cross-sections.

The grounding impedance must be less than 2 $\boldsymbol{\Omega}.$

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

Current output 0/4 to 20 mA Standard installation cable is sufficient

Pulse /frequency /switch output Standard installation cable is sufficient Double pulse output

Standard installation cable is sufficient

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient

Status input

Standard installation cable is sufficient

Cable diameter

- Cable glands supplied:
- $M20 \times 1.5$ with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Requirements for connecting cable – remote display and operating module DKX001

Optionally available connecting cable

A cable is supplied depending on the order option

- Order code for measuring device: order code 030 for "Display; operation", option 0 or
- Order code for measuring device: order code 030 for "Display; operation", option M and
- Order code for DKX001: order code **040** for "Cable", option **A**, **B**, **D**, **E**

Standard cable	$2\times2\times0.34~mm^2$ (22 AWG) PVC cable with common shield (2 pairs, pair-stranded)		
Flame resistance	According to DIN EN 60332-1-2		
Oil resistance According to DIN EN 60811-2-1			
Shield	Tin-plated copper braid, optical cover \geq 85 %		
Capacitance: core/shield	≤ 200 pF/m		
L/R	$\leq 24 \ \mu H/\Omega$		
Available cable length	5 m (15 ft)/10 m (35 ft)/20 m (65 ft)/30 m (100 ft)		
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)		

Standard cable - customer-specific cable

With the following order option, no cable is supplied with the device and must be provided by the customer:

Order code for DKX001: Order code **040** for "Cable", option **1** "None, provided by customer, max 300 m"

A standard cable with the following minimum requirements can be used as the connecting cable, even in the hazardous area (Zone 2, Class I, Division 2 and Zone 1, Class I, Division 1):

Standard cable	4 wires (2 pairs); pair-stranded with common shield, minimum wire cross-section 0.34 $\rm mm^2$ (22 AWG)		
Shield	Tin-plated copper braid, optical cover \geq 85 %		
Cable impedance (pair)	Minimum 80 Ω		

Cable length	Maximum 300 m (1000 ft), maximum loop impedance 20 Ω		
Capacitance: core/shield	Maximum 1000 nF for Zone 1, Class I, Division 1		
L/R	Maximum 24 $\mu H/\Omega$ for Zone 1, Class I, Division 1		

7.2.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply voltage		Input/o	output 1	Input/o	output 2	Input/o	output 3
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)
		Device-specific terminal assignment: adhesive label in terminal cover.					

Terminal assignment of the remote display and operating module $\rightarrow \square$ 35.

7.2.4 Preparing the measuring device

NOTICE

Insufficient sealing of the housing!

Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- If the measuring device is supplied with cable glands:
 Observe requirements for connecting cables →
 ⁽²⁾ 29.


7.3 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ► Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.


7.3.1 Connecting the transmitter




- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45); optional: connection for external WLAN antenna or remote display and operating module DKX001
- 4 Protective earth (PE)




- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.



- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.




- 7. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9. Connect the protective ground.



- **10.** Connect the cable according to the terminal assignment.
 - Signal cable terminal assignment: The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 Supply voltage terminal assignment: Adhesive label in the terminal cover or →
 ⇒ 32.
- **11.** Firmly tighten the cable glands.
 - └ This concludes the cable connection process.
- 12. Close the terminal cover.
- 13. Fit the display module holder in the electronics compartment.
- **14.** Screw on the connection compartment cover.
- **15.** Secure the securing clamp of the connection compartment cover.

Removing a cable




Engineering unit mm (in)

- 1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes
- 2. while simultaneously pulling the cable end out of the terminal.

7.3.2 Connecting the remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra $\rightarrow \cong 156$.

- The remote display and operating module DKX001 is only available for the following housing version: order code for "Housing": option A "Aluminum, coated"
- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



- 1 Remote display and operating module DKX001
- 2 Terminal connection for potential equalization (PE)
- 3 Connecting cable
- 4 Measuring device
- 5 Terminal connection for potential equalization (PE)

7.4 Ensuring potential equalization

7.4.1 Requirements

For potential equalization:

- Pay attention to in-house grounding concepts
- Take account of operating conditions like the pipe material and grounding
- Connect the medium, sensor and transmitter to the same electrical potential
- Use a ground cable with a minimum cross-section of 6 mm² (0.0093 in²) and a cable lug for potential equalization connections

For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

7.4.2 Connection example, standard scenario

Metal process connections

Potential equalization is generally via the metal process connections that are in contact with the medium and mounted directly on the sensor. Therefore there is generally no need for additional potential equalization measures.


7.4.3 Connection example in special situations

Plastic process connections

In the case of plastic process connections, additional grounding rings or process connections with an integrated grounding electrode must be used to ensure potential matching between the sensor and the fluid. If there is no potential matching, this can affect the measuring accuracy or cause the destruction of the sensor as a result of the electrochemical decomposition of the electrodes.


Note the following when using grounding rings:

- Depending on the option ordered, plastic disks are used instead of grounding rings on some process connections. These plastic disks only act as "spacers" and do not have any potential matching function. Furthermore, they also perform a significant sealing function at the sensor/connection interface. Therefore, in the case of process connections without metal grounding rings, these plastic disks/seals should never be removed and should always be installed!
- Grounding rings can be ordered separately as an accessory from Endress+Hauser . When ordering make sure that the grounding rings are compatible with the material used for the electrodes, as otherwise there is the danger that the electrodes could be destroyed by electrochemical corrosion!
- Grounding rings, including seals, are mounted inside the process connections. Therefore the installation length is not affected.



Potential equalization via additional grounding ring

- 1 Hexagonal-headed bolts of process connection
- 2 O-ring seals
- 3 Plastic disk (spacer) or grounding ring
- 4 Sensor




Potential equalization via grounding electrodes on process connection

- 1 Hexagonal-headed bolts of process connection
- 2 Integrated grounding electrodes
- 3 O-ring seal
- 4 Sensor

7.5 Special connection instructions


7.5.1 Connection examples

Current output 4 to 20 mA HART




8 Connection example for 4 to 20 mA HART current output (active)

- 1 Automation system with current input (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 3 Connection for HART operating devices $\rightarrow \square 63$
- 4 Resistor for HART communication ($\geq 250 \Omega$): observe maximum load $\rightarrow \square 164$
- 5 Analog display unit: observe maximum load $\rightarrow \square 164$
- 6 Transmitter



- Connection example for 4 to 20 mA HART current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load $\rightarrow \square 164$
- 5 Transmitter


HART input



■ 10 Connection example for HART input with a common negative (passive)


- 1 Automation system with HART output (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load $\rightarrow \square 164$
- 5 Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- 6 Transmitter

Current output 4-20 mA




- 11 Connection example for 4-20 mA current output (active)
- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load $\rightarrow \square 164$

3 Transmitter



- 12 Connection example for 4-20 mA current output (passive)
- *1 Automation system with current input (e.g. PLC)*
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Analog display unit: observe maximum load $\rightarrow \equiv 164$
- 4 Transmitter


Pulse/frequency output



☑ 13 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC with 10 k Ω pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values $\rightarrow \square 166$

Switch output




14 Connection example for switch output (passive)

- Automation system with switch input (e.g. PLC with a 10 k Ω pull-up or pull-down resistor)
- 2 Power supply

1


3 Transmitter: observe input values $\rightarrow \triangleq 166$

Double pulse output



15 Connection example for double pulse output (active)


- 1 Automation system with double pulse input (e.g. PLC)
- 2 Transmitter: observe input values $\rightarrow \implies 167$
- 3 Double pulse output
- 4 Double pulse output (slave), phase-shifted



16 Connection example for double pulse output (passive)

- 1 Automation system with double pulse input (e.g. PLC with a 10 kΩ pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values → 🖺 167
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


Relay output



E 17 Connection example for relay output (passive)


- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values → 🖺 167

Current input



- 18 Connection example for 4 to 20 mA current input
- 1 Power supply
- 2 Terminal box
- 3 External measuring device (to read in pressure or temperature, for instance)
- 4 Transmitter

Status input



- ☑ 19 Connection example for status input
- 1 Automation system with status output (e.g. PLC)
- 2 Power supply
- 3 Transmitter


7.6 Ensuring the degree of protection

The measuring device fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To guarantee the degree of protection IP66/67, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.

 To ensure that moisture does not enter the cable entry: Route the cable so that it loops down before the cable entry ("water trap").




6. Insert dummy plugs (corresponding to the housing degree of protection) into unused cable entries.

7.7 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Is the protective earthing established correctly?	
Do the cables used comply with the requirements ?	
Do the mounted cables have adequate strain relief?	
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" $\rightarrow \cong 41$?	
Is the terminal assignment correct ?	
If supply voltage is present, do values appear on the display module?	
Is the potential equalization established correctly ?	
Are dummy plugs inserted in unused cable entries and have transportation plugs been replaced with dummy plugs?	

8 Operation options

8.1 Overview of operation options




- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device $\rightarrow \square$ 189



 $\blacksquare 20$ Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu	ı/parameter	User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuration of the operational	 Defining the operating language Defining the Web server operating language Resetting and controlling totalizers
Operation		display • Reading measured values	 Configuring the operational display (e.g. display format, display contrast) Resetting and controlling totalizers
Setup		 "Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs Configuration of the communication interface 	 Wizards for fast commissioning: Configuration of the system units Displaying the I/O configuration Configuration of the inputs Configuration of the outputs Configuration of the low flow cut off Configuration of empty pipe detection Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions)
			 Configuration of totalizers Configuration of electrode cleaning (optional) Configuration of WLAN settings Administration (define access code, reset measuring device)
Diagnostics		 "Maintenance" role Troubleshooting: Diagnostics and elimination of process and device errors Measured value simulation 	Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device. Measured values Contains all current measured values. Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values Heartbeat The functionality of the device is checked on demand and the verification results are documented. Simulation Is used to simulate measured values or output values.
Expert	function-oriented	 Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases 	 Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication. Sensor Configuration of the measurement. Input Configuration of the status input. Output Configuration of the analog current outputs as well as the pulse/frequency and switch output. Communication Configuration of the digital communication interface and the Web server. Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display



- 1 Operational display
- 2 Device tag $\rightarrow \square 77$
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements $\rightarrow \square 51$


Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 135
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- Diagnostic behavior → 🗎 136
 - 🐼: Alarm
 - M: Warning
- $\widehat{\square}$: Locking (the device is locked via the hardware)
- • : Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Measured variables

Symbol	Meaning
Ú	Volume flow
G	Conductivity

'n	Mass flow
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.
Ģ	Output Output Image: The measurement channel number indicates which of the outputs is displayed.
Ð	Status input

Measurement channel numbers

Symbol	Meaning
14	Measurement channel 1 to 4


The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols $\rightarrow \cong 136$


The number and display format of the measured values can be configured via the **Format display** parameter ($\rightarrow \cong 92$).

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



Ca. // Display

For more information about the icons in the menu, refer to the "Display area" section $\rightarrow \cong 48$

Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal

- For information on the diagnostic behavior and status signal ightarrow [ightarrow 135
 - For information on the function and entry of the direct access code $\rightarrow \square 53$

Display area

Menus

Symbol	Meaning
R	 Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu
۶	 Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu
୍ୟ	 Diagnostics Appears: In the menu next to the "Diagnostics" selection At the left in the navigation path in the Diagnostics menu
÷ *	 Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
<u>h.</u>	Wizard
Ø	Parameters within a wizard Image: No display symbol exists for parameters in submenus.

Locking


Symbol	Meaning
ô	Parameter lockedWhen displayed in front of a parameter name, indicates that the parameter is locked.By a user-specific access codeBy the hardware write protection switch

Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 Editing view


Numeric editor



☑ 21 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 Operating elements

Text editor



■ 22 For entering text in parameters (e.g. tag name)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 Operating elements
- 5 Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

Using the operating elements in the editing view

Key	Meaning
Θ	Minus key Move the entry position to the left.
+	Plus key Move the entry position to the right.
E	Enter keyPressing the key briefly confirms the selection.Pressing the key for 2 s confirms your entry.
-++	Escape key combination (press keys simultaneously) Close the editing view without accepting a change.

Input screens

Symbol	Meaning
A	Upper case
а	Lower case
1	Numbers
+*	Punctuation marks and special characters: = + - * / ² ³ ¹ / ₄ ¹ / ₂ ³ / ₄ () [] < > { }
@	Punctuation marks and special characters: ' " ` ^. , ; : ? ! % μ ° \in \$ £ ¥ § @ # / \ I ~ & _
ä.,	Umlauts and accents

Controlling data entries

Symbol	Meaning
←→	Move entry position
X	Reject entry
4	Confirm entry
×	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

8.3.4 Operating elements

Image: Second Secon	Кеу	Meaning
Image: Second Secon		Minus key
Confirms the parameter value and goes to the previous parameter. For text and numeric editor Move the entry position to the left. Immenu, submenu Moves the selection bar downwards in a picklist. With a wizard Confirms the parameter value and goes to the next parameter. For text and numeric editor Move the entry position to the right. Enter key For operational display Pressing the key briefly opens the operating menu. In menu, submenu • Pressing the key briefly: • Open the selected menu, submenu or parameter. • Starts the wizard. • If help text is open, closes the help text of the parameter. • Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. • For start and numeric editor • Pressing the key for 2 s on firms your entry. Escape key combination (press key simultaneously) In menu, submenu • Pressing the key briefly: • Pressing the key briefly: • Starts the current menu level and takes you to the next level up. • If help text is open, closes the help text of the parameter. • Pressing the key tor 2 s onfirms you to the operation		,
Image: Second Secon		
 In menu, submenu Moves the selection bar downwards in a picklist. With a wizard Confirms the parameter value and goes to the next parameter. For text and numeric editor Move the entry position to the right. Enter key For operational display Pressing the key briefly opens the operating menu. In menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. Pressing the key briefly confirms the selection. Pressing the key briefly: Opens the editing view of the parameter. For text and numeric editor Pressing the key briefly confirms the selection. Pressing the key briefly: Pressing the key briefly: Excape key combination (press keys simultaneously) In menu, submenu Pressing the key for 2 s confirms your entry. Excape key combination (press keys simultaneously) In menu, submenu Pressing the key for 2 s returns you to the next level up. I help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ('home position''). With a wizard Exits the wizard and takes you to the next level up.		
Image: Selection bar downwards in a picklist. With a wizard Confirms the parameter value and goes to the next parameter. For text and numeric editor Move the entry position to the right. Enter key For operational display Pressing the key briefly opens the operating menu. In menu, submenu • Pressing the key briefly: • Opens the selected menu, submenu or parameter. • Starts the wizard. • I help text is open, closes the help text of the parameter. • Starts the wizard. • I help text is open, closes the help text of the parameter. • Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. With a wizard Opens the editing view of the parameter. For text and numeric editor • Pressing the key briefly confirms the selection. • Pressing the key briefly: • Escape key combination (press keys simultaneously) In menu, submenu • Pressing the key for 2 s confirms your on the next level up. • I help text is open, closes the help text of the parameter. • Pressing the key for 2 s returns you to the next level up. • I help text is open, closes the he		Plus key
Confirms the parameter value and goes to the next parameter. For text and numeric editor Move the entry position to the right. Enter key For operational display Pressing the key briefly opens the operating menu. In menu, submenu • Pressing the key briefly: • Opens the selected menu, submenu or parameter. • Starts the wizard. • If help text is open, doses the help text of the parameter. • Starts the wizard. • Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. With a wizard Opens the editing view of the parameter. For text and numeric editor • Pressing the key for 2 s confirms your entry. Escape key combination (press keys simultaneously) In menu, submenu • Pressing the key briefly: • Exits the current menu level and takes you to the next level up. • If help text is open, closes the help text of the parameter. • Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard • Exits the wizard and takes you to the next level up. • If help text is open, closes the help text of the parameter. •		,
Move the entry position to the right. Enter key For operational display Pressing the key briefly opens the operating menu. In menu, submenu • Pressing the key briefly: • Opens the selected menu, submenu or parameter. • Starts the wizard. • If help text is open, closes the help text of the parameter. • Starts the wizard. • If help text is open, closes the help text of the parameter. • Pressing the key briefly confirms the selection. • Pressing the key briefly confirms the selection. • Pressing the key briefly: • Escape key combination (press keys simultaneously) In menu, submenu • Pressing the key briefly: • Estis the current menu level and takes you to the next level up. • If help text is open, closes the help text of the parameter. • Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard Exits the wizard and takes you to the next level up. For text and numeric editor <td< td=""><th></th><td></td></td<>		
 For operational display Pressing the key briefly opens the operating menu. In menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter:		
 Pressing the key briefly opens the operating menu. In menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter:		Enter key
 Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter:		
With a wizard Opens the editing view of the parameter. For text and numeric editor • Pressing the key briefly confirms the selection. • Pressing the key for 2 s confirms your entry. Escape key combination (press keys simultaneously) In menu, submenu • Pressing the key briefly: • Exits the current menu level and takes you to the next level up. • If help text is open, closes the help text of the parameter. • Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard Exits the wizard and takes you to the next level up. For text and numeric editor Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) • If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. • If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating	E	 Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter:
For text and numeric editor ● Pressing the key briefly confirms the selection. ● Pressing the key for 2 s confirms your entry. Escape key combination (press keys simultaneously) In menu, submenu ● Pressing the key briefly: ● Exits the current menu level and takes you to the next level up. ● If help text is open, closes the help text of the parameter. ● Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard Exits the wizard and takes you to the next level up. For text and numeric editor Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) ● If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. ● If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating		With a wizard
 In menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next level up. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard Exits the wizard and takes you to the next level up. For text and numeric editor Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating 		For text and numeric editorPressing the key briefly confirms the selection.
 Pressing the key briefly: Pressing the key briefly: Exits the current menu level and takes you to the next level up. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). With a wizard Exits the wizard and takes you to the next level up. For text and numeric editor Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating 		Escape key combination (press keys simultaneously)
Exits the wizard and takes you to the next level up. For text and numeric editor Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) • If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. • If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating	() ++	Pressing the key briefly:Exits the current menu level and takes you to the next level up.If help text is open, closes the help text of the parameter.
Closes the editing view without applying changes. Minus/Enter key combination (press and hold down the keys simultaneously) If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating		
 If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating 		
Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating		Minus/Enter key combination (press and hold down the keys simultaneously)
the keynad lock	—+E	Pressing the key for 3 s disables the keypad lock.If the keypad lock is not enabled:

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the \Box and \blacksquare keys for longer than 3 seconds.
 - └ The context menu opens.



2. Press \Box + \pm simultaneously.

└ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press \pm to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - └ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\rightarrow \cong 47$


Example: Setting the number of displayed measured values to "2 values"



8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path Expert \rightarrow Direct access The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



¹ Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
 Example: Enter 00914 → Assign process variable parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter $00914\text{-}2 \rightarrow Assign \ process \ variable \ parameter$

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

8.3.8 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

← The help text for the selected parameter opens.



23 Example: Help text for parameter "Enter access code"

- 2. Press \Box + \pm simultaneously.
 - └ The help text is closed.

8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

For a description of the editing view - consisting of the text editor and numeric editor - with symbols → 🗎 49, for a description of the operating elements → 🗎 51

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access $\rightarrow \cong 117$.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ► Define the access code.
 - └ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ ¹⁾

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	_ 1)

 Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

The user role with which the user is currently logged on is indicated by the Access status parameter. Navigation path: Operation \rightarrow Access status

8.3.11 Disabling write protection via access code

If the @-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\Rightarrow @$ 117.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ($\rightarrow \square$ 103) via the respective access option.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

➡ The B -symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

- Press the \Box and \blacksquare keys for 3 seconds.
- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- The keypad lock is switched on.
 - Press the \Box and \blacksquare keys for 3 seconds.
 - └ The keypad lock is switched off.

8.4 Access to the operating menu via the Web browser

8.4.1 Function scope

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via the service interface (CDI-RJ45) or via the WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed and allows users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device

8.4.2 Requirements

Computer hardware

Hardware	Interface	
	CDI-RJ45	WLAN
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.
Connection	Ethernet cable with RJ45 connector.	Connection via Wireless LAN.
Screen	Recommended size: ≥ 12 " (depends on the screen resolution)	

Computer software

Software	Interface	
	CDI-RJ45	WLAN
Recommended operating systems	 Microsoft Windows 8 or higher. Mobile operating systems: iOS Android Microsoft Windows XP is supported. 	
Web browsers supported	 Microsoft Internet Explorer 8 or higher Microsoft Edge Mozilla Firefox Google Chrome Safari 	

Computer settings

Settings	Interface		
	CDI-RJ45	WLAN	
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).		
Proxy server settings of the Web browser	The Web browser setting <i>Use proxy server for LAN</i> must be disabled .		
JavaScript	JavaScript must be enabled.		
	1	let/basic.html in the address bar of the ut simplified version of the operating browser.	
		version: To enable correct data display, he) of the Web browser under Internet	
Network connections	Only the active network connections to the measuring device should be used.		
	Switch off all other network connections such as WLAN.	Switch off all other network connections.	

In the event of connection problems: $\rightarrow \cong 132$

Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface
Measuring device	The measuring device has an RJ45 interface.
Web server	 Web server must be enabled; factory setting: ON I For information on enabling the Web server → 62

Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna:Transmitter with integrated WLAN antennaTransmitter with external WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ONI For information on enabling the Web server → 62

8.4.3 Establishing a connection

Via service interface (CDI-RJ45)

Preparing the measuring device

- Depending on the housing version: Loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version:

Unscrew or open the housing cover.

 The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 plug via the standard Ethernet connecting cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- **2.** Connect to the computer using a cable $\rightarrow \bigoplus 64$.
- 3. If a 2nd network card is not used, close all the applications on the notebook.
 - → Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- **5.** Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 \rightarrow e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

- If the WLAN connection is lost during the configuration, settings made may be lost.
- ▶ Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal:
 - Select the measuring device using the SSID (e.g. EH_Promag_300_A802000).
- 2. If necessary, select the WPA2 encryption method.
- **3.** Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - LED on display module flashes: it is now possible to operate the measuring device with a web browser, FieldCare or DeviceCare.

The serial number can be found on the nameplate.

To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting


 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

Starting the Web browser

1. Start the Web browser on the computer.

2. Enter the IP address of the web server in the address line of the web browser: 192.168.1.212

└ The login page appears.



- 1 Picture of device
- 2 Device name
- 3 Device tag ($\rightarrow \square 77$)
- 4 Status signal5 Current measured values
- 6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code ($\rightarrow \square 114$)

If a login page does not appear, or if the page is incomplete $\rightarrow \square$ 132

8.4.4 Logging on

1. Select the preferred operating language for the Web browser.

- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (default setting); can be changed by customer

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal \rightarrow 🖺 138
- Current measured values

Function row

Functions	Meaning	
Measured values	Displays the measured values of the device	
Menu	 Access to the operating menu from the measuring device The structure of the operating menu is the same as for the local display For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device 	
Device status	Displays the diagnostic messages currently pending, listed in order of priority	
Data management	 Data exchange between PC and measuring device: Device configuration: Load settings from the device (XML format, save configuration) Save settings to the device (XML format, restore configuration) Logbook - Export Event logbook (.csv file) Documents - Export documents: Export backup data record (.csv file, create documentation of the measuring point configuration) Verification report (PDF file, only available with the "Heartbeat Verification" application package) Firmware update - Flashing a firmware version 	
Network configuration	 Configuration and checking of all the parameters required for establishing the connection to the measuring device: Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version) 	
Logout	End the operation and call up the login page	

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu \rightarrow Communication \rightarrow Web server

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	OffHTML OffOn	On

Function scope of the "Web server functionality" parameter

Option	Description
Off	The Web server is completely disabled.Port 80 is locked.
HTML Off	The HTML version of the Web server is not available.
On	 The complete Web server functionality is available. JavaScript is used. The password is transferred in an encrypted state. Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

- 1. Select the **Logout** entry in the function row.
 - ← The home page with the Login box appears.
- 2. Close the Web browser.
- 3. If no longer needed:

Reset the modified properties of the Internet protocol (TCP/IP) $\rightarrow \square$ 58.


8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool


Via HART protocol

This communication interface is available in device versions with a HART output.



24 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter



25 Options for remote operation via HART protocol (passive)

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT70
- 9 VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

Service interface


Via service interface (CDI-RJ45)

A point-to-point connection can be established via onsite device configuration. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

An adapter for RJ45 to the M12 plug is optionally available:

Order code for "Accessories", option NB: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 plug mounted in the cable entry. The connection to the service interface can be established via an M12 plug without opening the device.




☑ 26 Connection via service interface (CDI-RJ45)

- Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
 Standard Ethernet connecting cable with RJ45 plug
- Standard Enternet connecting cable with 1945 plug
 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



- 1 Transmitter with integrated WLAN antenna
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- 4 LED flashing: WLAN connection established between operating unit and measuring device 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microso
 - 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 Smart phone or tablet (e.g. Field Xpert SMT70)

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)
Configurable WLAN channels	1 to 11
Degree of protection	IP67
Available antennas	 Internal antenna External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Only 1 antenna is active at any one time!
Range	Internal antenna: typically 10 m (32 ft)External antenna: typically 50 m (164 ft)
Materials (external antenna)	 Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel- plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Plug: Nickel-plated brass Angle bracket: Stainless steel

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

• Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:

Select the measuring device using the SSID (e.g. EH_Promag_300_A802000).

- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - LED on display module flashes: it is now possible to operate the measuring device with a web browser, FieldCare or DeviceCare.
- The serial number can be found on the nameplate.
- To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

8.5.2 Field Xpert SFX350, SFX370

Function range

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

Source for device description files

See information $\rightarrow \square 70$

8.5.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- HART protocol
- CDI-RJ45 service interface $\rightarrow \cong 64$
- WLAN interface $\rightarrow \cong 65$

Typical functions:

- Parameterization of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information $\rightarrow \square 70$

Establishing a connection

1. Start FieldCare and launch the project.

2. In the network: Add a device.

└ The **Add device** window opens.


- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.

← The CDI Communication TCP/IP (Configuration) window opens.

- 6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.
- 7. Establish the online connection to the device.

For additional information, see Operating Instructions BA00027S and BA00059S

User interface



1 Header

- 2 Picture of device
- 3 Device name
- 4 Tag name
- 5 Status area with status signal $\rightarrow \square 138$
- 6 Display area for current measured values
- 7 Edit bar with additional functions such as save/load, event list and document creation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.5.4 DeviceCare

Function scope

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.

For details, see Innovation Brochure IN01047S

Source for device description files

See information $\rightarrow \square 70$

8.5.5 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

Source for device description files

See data $\rightarrow \blacksquare 70$

8.5.6 SIMATIC PDM

Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

Source for device description files

See information on \rightarrow \bigcirc 70

8.5.7 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See data $\rightarrow \textcircled{2}$ 70

9 System integration

9.1 **Overview of device description files**

9.1.1 Current version data for the device

Firmware version	01.06.zz	 On the title page of the Operating Instructions On the transmitter nameplate Firmware version Diagnostics → Device information → Firmware version
Release date of firmware version	08.2022	
Manufacturer ID	0x11	Manufacturer ID Diagnostics \rightarrow Device information \rightarrow Manufacturer ID
Device type ID	0x3C	Device type Diagnostics \rightarrow Device information \rightarrow Device type
HART protocol revision	7	HART revision Expert \rightarrow Communication \rightarrow HART output \rightarrow Information \rightarrow HART revision
Device revision	1	 On the transmitter nameplate Device revision Diagnostics → Device information → Device revision

For an overview of the various firmware versions for the device $\rightarrow \square 151$

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via HART protocol	Sources for obtaining device descriptions
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
Field Xpert SMT70Field Xpert SMT77	Use update function of handheld terminal
AMS Device Manager (Emerson Process Management)	www.endress.com \rightarrow Download Area
SIMATIC PDM (Siemens)	www.endress.com \rightarrow Download Area
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Volume flow
Secondary dynamic variable (SV)	Totalizer 1
Tertiary dynamic variable (TV)	Totalizer 2
Quaternary dynamic variable (QV)	Totalizer 3

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign PV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign SV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign TV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign QV

The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity¹⁾
- Corrected conductivity¹⁾
- Temperature ¹⁾
- Electronics temperature

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity²⁾
- Corrected conductivity²⁾
- Temperature²⁾
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3

The range of options increases if the measuring device has one or more application packages.

Device variables

The device variables are permanently assigned. A maximum of 8 device variables can be transmitted:

- 0 = volume flow
- 1 = mass flow
- 2 = corrected volume flow
- 3 = flow velocity
- 4 =conductivity
- 5 = corrected conductivity
- 6 = temperature
- 7 = electronic temperature

¹⁾ Visibility depends on order options or device settings

²⁾ Visibility depends on order options or device settings

- 8 = totalizer 1
- 9 = totalizer 2
- 10 = totalizer 3

9.3 Other settings

Burst mode functionality in accordance with HART 7 Specification:

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART output \rightarrow Burst configuration \rightarrow Burst configuration 1 to n

► Burst configuration 1 to n	
Burst mode 1 to n) → 🗎 73
Burst command 1 to n	→ 🖹 73
Burst variable 0	→ 🗎 73
Burst variable 1] → 🗎 73
Burst variable 2] → 🗎 73
Burst variable 3] → 🗎 73
Burst variable 4	→ 🗎 73
Burst variable 5	→ 🗎 73
Burst variable 6] → 🗎 73
Burst variable 7] → 🗎 73
Burst trigger mode] → 🗎 73
Burst trigger level	→ 🗎 73
Min. update period] → 🗎 74
Max. update period	→ ■ 74

Parameter	Description	Selection / User entry	Factory setting
Burst mode 1 to n	Activate the HART burst mode for burst message X.	• Off • On	Off
Burst command 1 to n	Select the HART command that is sent to the HART master.	 Command 1 Command 2 Command 3 Command 9 Command 33 Command 48 	Command 2
Burst variable 0	For HART command 9 and 33: select the HART device variable or the process variable.	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity Electronics temperature HBSI* Totalizer 1 Totalizer 2 Totalizer 3 Density Temperature* HART input Percent of range Measured current Primary variable (PV) Secondary variable (SV) Tertiary variable (TV) Quaternary variable (QV) Not used 	Volume flow
Burst variable 1	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 2	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 3	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 4	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 5	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 6	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 7	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst trigger mode	Select the event that triggers burst message X.	 Continuous Window* Rising* Falling* On change 	Continuous
Burst trigger level	Enter the burst trigger value. Together with the option selected in the Burst trigger mode parameter the burst trigger value determines the time of burst message X.	Signed floating-point number	-

Parameter	Description	Selection / User entry	Factory setting
Min. update period	Enter the minimum time span between two burst commands of burst message X.	Positive integer	1 000 ms
	Enter the maximum time span between two burst commands of burst message X.	Positive integer	2 000 ms

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- Checklist for "Post-mounting check" \rightarrow \cong 28
- Checklist for "Post-connection check" $\rightarrow \implies 42$


10.2 Switching on the measuring device

- ► After a successful function check, switch on the measuring device.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" $\rightarrow \square$ 131.

10.3 Setting the operating language


Factory setting: English or ordered local language



■ 27 Taking the example of the local display

10.4 Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu



■ 28 Taking the example of the local display

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

🗲 Setup	
Device tag	→ 🗎 77
► System units	→ 🗎 77
► I/O configuration	→ 🗎 79
► Current input 1 to n	→ 🖺 80
► Status input 1 to n	→ 🖺 80
► Current output 1 to n	→ 🖺 82
 Pulse/frequency/switch output 1 to n 	→ 🗎 85
► Relay output 1 to n	→ 🗎 97
► Double pulse output	→ 🖺 98
► Display	→ 🗎 91
► Low flow cut off	→ 🗎 93
► Empty pipe detection	→ 🖺 94

► Configure flow damping	→ 🗎 99
► Advanced setup	→ \u00e9 102

10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

E 29 Header of the operational display with tag name

Tag name 1

Enter the tag name in the "FieldCare" operating tool $\rightarrow \square 68$

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.



The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (\rightarrow "Supplementary documentation" section).

Navigation

"Setup" menu → System units

► System units	
Volume flow unit	→ 🗎 78
Volume unit	→ 🗎 78
Conductivity unit	→ 🗎 78
Temperature unit	→ 🗎 78

Mass flow unit	→ 🗎 78
Mass unit	→ 🖺 78
Density unit	→ 🗎 78
Corrected volume flow unit	→ 🗎 79
Corrected volume unit	→ 🖺 79

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	-	Select volume flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Depends on country: l/h gal/min (us)
Volume unit	-	Select volume unit.	Unit choose list	Country-specific: • m ³ • gal (us)
Conductivity unit	The On option is selected in the Conductivity measurement parameter parameter.	Select conductivity unit. <i>Effect</i> The selected unit applies for: • Current output • Frequency output • Switch output • Simulation process variable	Unit choose list	µS/cm
Temperature unit	-	Select temperature unit. <i>Effect</i> The selected unit applies for: • Temperature parameter • Maximum value parameter • Minimum value parameter • External temperature parameter • Maximum value parameter • Minimum value parameter	Unit choose list	Country-specific: • °C • °F
Mass flow unit	-	Select mass flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: kg/h lb/min
Mass unit	-	Select mass unit.	Unit choose list	Country-specific: • kg • lb
Density unit	-	Select density unit. <i>Effect</i> The selected unit applies for: • Output • Simulation process variable	Unit choose list	Country-specific: kg/l lb/ft ³

Parameter	Prerequisite	Description	Selection	Factory setting
Corrected volume flow unit	-	Select corrected volume flow unit. <i>Result</i> The selected unit applies for: Corrected volume flow parameter (→ 🗎 121)	Unit choose list	Country-specific: • Nl/h • Sft ³ /h
Corrected volume unit	-	Select corrected volume unit.	Unit choose list	Country-specific: • Nm ³ • Sft ³

10.4.3 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu \rightarrow I/O configuration

► I/O configuration	
I/O module 1 to n terminal numbers	→ 🗎 79
I/O module 1 to n information	→ 🗎 79
I/O module 1 to n type	→ 🗎 79
Apply I/O configuration	→ 🖺 80
I/O alteration code	→ 🖺 80

Parameter	Description	User interface / Selection / User entry	Factory setting
I/O module 1 to n terminal numbers	Shows the terminal numbers used by the I/O module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 	-
I/O module 1 to n information	Shows information of the plugged I/O module.	 Not plugged Invalid Not configurable Configurable HART 	-
I/O module 1 to n type	Shows the I/O module type.	 Off Current output * Current input * Status input * Pulse/frequency/switch output * Double pulse output * Relay output * 	Off

Parameter	Description	User interface / Selection / User entry	Factory setting
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	NoYes	No
I/O alteration code	Enter the code in order to change the I/O configuration.	Positive integer	0

10.4.4 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu \rightarrow Status input 1 to n

► Status input 1 to n			
Assign status input) → 🗎 80		
Terminal number) → 🖺 80		
Active level	→ 🖺 80		
Terminal number] → 🗎 80		
Response time status input) → 🗎 80		
Terminal number) → 🗎 80		

Parameter overview with brief description

Parameter	Description	Selection / User interface / User entry	Factory setting
Assign status input	Select function for the status input.	 Off Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override 	Off
Terminal number	Shows the terminal numbers used by the status input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Active level	Define input signal level at which the assigned function is triggered.	HighLow	High
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms	50 ms

10.4.5 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation "Setup" menu \rightarrow Current input

► Current input 1 to n	
Terminal number	→ 🗎 81
Signal mode	→ 🗎 81
0/4 mA value	→ 🖺 81
20 mA value) → 🗎 81
Current span	→ 🗎 81
Failure mode	→ 🗎 81
Failure value) → 🗎 81

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Signal mode	The measuring device is not approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	 Passive Active[*] 	Active
0/4 mA value	-	Enter 4 mA value.	Signed floating-point number	0
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	_	Select current range for process value output and upper/lower level for alarm signal.	 420 mA (4 20.5 mA) 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 020 mA (0 20.5 mA) 	Country-specific: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA)
Failure mode	-	Define input behavior in alarm condition.	AlarmLast valid valueDefined value	Alarm
Failure value	In the Failure mode parameter, the Defined value option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

* Visibility depends on order options or device settings

10.4.6 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation

"Setup" menu → Current output

► Current output 1	ton	
	Terminal number	→ 🗎 82
	Signal mode	→ 🗎 82
	Process variable current output	→ 🖺 83
	Current range output	→ 🗎 83
	Lower range value output	→ 🗎 83
	Upper range value output	→ 🗎 83
	Fixed current	→ 🗎 83
	Damping current output	→ 🖹 84
	Failure behavior current output	→ 🖹 84
	Failure current	→ 🖺 84

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 	-
Signal mode	-	Select the signal mode for the current output.	 Active * Passive * 	Active

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Process variable current output	-	Select the process variable for the current output.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity* Temperature* Electronics temperature Noise* Coil current shot time* Reference electrode potential against PE* HBS1* Build-up index* Test point 1 Test point 2 Test point 3 	Volume flow
Current range output	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 420 mA (4 20.5 mA) 020 mA (0 20.5 mA) Fixed value 	Depends on country: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA)
Lower range value output	One of the following options is selected in the Current span parameter (→ 🗎 83): • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (4 20.5 mA) • 020 mA (0 20.5 mA)	Enter lower range value for the measured value range.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
Upper range value output	One of the following options is selected in the Current span parameter (→ 🗎 83): • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (4 20.5 mA) • 020 mA (0 20.5 mA)	Enter upper range value for the measured value range.	Signed floating-point number	Depends on country and nominal diameter
Fixed current	The Fixed current option is selected in the Current span parameter ($\rightarrow \cong 83$).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Damping current output	 A process variable is selected in the Assign current output parameter (→	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	1.0 s
Failure behavior current output	 A process variable is selected in the Assign current output parameter (→	Define output behavior in alarm condition.	 Min. Max. Last valid value Actual value Fixed value 	Max.
Failure current	The Defined value option is selected in the Failure mode parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA

10.4.7 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 85

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse

Configuring the pulse output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 86
Terminal number	→ 🗎 86
Signal mode	→ 🗎 86
Assign pulse output	→ 🗎 86
Pulse scaling	→ 🗎 86
Pulse width	→ 🗎 86
Failure mode	→ 🗎 86
Invert output signal	→ 🗎 86

Parameter	overview with	brief description
-----------	---------------	-------------------

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive
Assign pulse output 1 to n	The Pulse option is selected in the Operating mode parameter.	Select process variable for pulse output.	 Off Volume flow Mass flow Corrected volume flow 	Off
Pulse scaling	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \bowtie 86$).	Enter quantity for measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \limsup 86$).	Define time width of the output pulse.	0.05 to 2 000 ms	100 ms
Failure mode	The Pulse option is selected in the Operating mode parameter ($\rightarrow \boxdot 85$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \boxdot 86$).	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	-	Invert the output signal.	• No • Yes	No

Configuring the frequency output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output 1 to n	
Operating mode	→ 🗎 87
Terminal number	→ 🗎 87
Signal mode	→ 🗎 87
Assign frequency output	→ 🗎 87

Minimum frequency value	→ 🗎 88
Maximum frequency value	→ 🗎 88
Measuring value at minimum frequency	→ 🖺 88
Measuring value at maximum frequency	→ 🖺 88
Failure mode	→ 🗎 88
Failure frequency	→ 🗎 88
Invert output signal	→ 🗎 88

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active[*] Passive NE 	Passive
Assign frequency output	In the Operating mode parameter (→	Select process variable for frequency output.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Temperature* Electronics temperature Noise* Coil current shot time* Reference electrode potential against PE* HBSI* Build-up index* Test point 1 Test point 2 Test point 3 	Off

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Minimum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \bowtie 87$).	Enter minimum frequency.	0.0 to 10000.0 Hz	0.0 Hz
Maximum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \bowtie 87$).	Enter maximum frequency.	0.0 to 10000.0 Hz	10000.0 Hz
Measuring value at minimum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \bowtie 87$).	Enter measured value for minimum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \bowtie 85$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \bowtie 87$).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The Frequency option is selected in the Operating mode parameter ($\rightarrow \implies 85$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \implies 87$).	Define output behavior in alarm condition.	Actual valueDefined value0 Hz	0 Hz
Failure frequency	In the Operating mode parameter ($\rightarrow \textcircled{B}$ 85), the Frequency option is selected, in the Assign frequency output parameter ($\rightarrow \textcircled{B}$ 87) a process variable is selected, and in the Failure mode parameter, the Defined value option is selected.	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	0.0 Hz
Invert output signal	-	Invert the output signal.	NoYes	No

Configuring the switch output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

 Pulse/frequency/switch output 1 to n 		
Operating mode) → 🗎 89	
Terminal number] → 🖺 89	
Signal mode) → 🗎 89	
Switch output function] → 🗎 90	
Assign diagnostic behavior] → 🗎 90	
Assign limit] → 🗎 90	
Assign flow direction check] → 🗎 90	
Assign status) → 🗎 90	
Switch-on value) → 🗎 90	
Switch-off value) → 🗎 90	
Switch-on delay) → 🗎 90	
Switch-off delay) → 🗎 91	
Failure mode) → 🗎 91	
Invert output signal) → 🗎 91	

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	 Off On Diagnostic behavior Limit Flow direction check Status 	Off
Assign diagnostic behavior	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. 	Select diagnostic behavior for switch output.	 Alarm Alarm or warning Warning	Alarm
Assign limit	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Limit option is selected. 	Select process variable for limit function.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Totalizer 1 Totalizer 1 Totalizer 3 Temperature * Electronics temperature 	Volume flow
Assign flow direction check	 The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. 	Select process variable for flow direction monitoring.	 Off Volume flow Mass flow Corrected volume flow 	Volume flow
Assign status	 The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. 	Select device status for switch output.	 Empty pipe detection Low flow cut off Build-up index[*] HBSI limit exceeded[*] 	Empty pipe detection
Switch-on value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
Switch-off value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
Switch-on delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open
Invert output signal	-	Invert the output signal.	NoYes	No

10.4.8 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu \rightarrow Display

► Display	
Format display) → 🗎 92
Value 1 display) → 🗎 92
0% bargraph value 1) → 🗎 92
100% bargraph value 1] → 🗎 92
Value 2 display) → 🗎 92
Value 3 display) → 🗎 92
0% bargraph value 3) → 🗎 92
100% bargraph value 3) → 🗎 92
Value 4 display] → 🗎 92

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Mass flow Corrected volume flow Flow velocity Corrected conductivity* Totalizer 1 Totalizer 1 Totalizer 3 Current output 1 Current output 4* Temperature* Electronics temperature HBSI* Noise* Coil current shot time* Reference electrode potential against PE* Build-up index* Test point 1 Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 92$)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\Rightarrow \square 92$)	None
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 92$)	None
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\Rightarrow \square 92$)	None
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square 92$)	None

10.4.9 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off

► Low flow cut off	
Assign process variable] → 🗎 93
On value low flow cutoff] → 🗎 93
Off value low flow cutoff) → 🗎 93
Pressure shock suppression] → 🗎 93

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	 Off Volume flow Mass flow Corrected volume flow 	Volume flow
On value low flow cutoff	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong$ 93).	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong$ 93).	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 93).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.4.10 Configuring empty pipe detection

The measuring devices are calibrated with water (approx. 500 μS/cm) at the factory. For liquids with a lower conductivity, it is advisable to perform a new full pipe adjustment onsite.

The **Empty pipe detection** submenu contains parameters that must be configured for the configuration of empty pipe detection.

Navigation

"Setup" menu \rightarrow Empty pipe detection

► Empty pipe detection	
Empty pipe detection) → 🗎 94
New adjustment) → 🗎 94
Progress	→ 🗎 94
Switch point empty pipe detection	→ 🗎 94
Response time empty pipe detection	→ 🗎 94

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	-	Switch empty pipe detection on and off.	OffOn	Off
New adjustment	The On option is selected in the Empty pipe detection parameter.	Select type of adjustment.	CancelEmpty pipe adjustFull pipe adjust	Cancel
Progress	The On option is selected in the Empty pipe detection parameter.	Shows the progress.	 Ok Busy Not ok	-
Switch point empty pipe detection	The On option is selected in the Empty pipe detection parameter.	Enter the switch point in % of the difference between the two adjustment values. The lower the percentage, the earlier the pipe is detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	A process variable is selected in the Assign process variable parameter ($\rightarrow \textcircled{94}$).	Use this function to enter the minimum time (hold time) the signal must be present before diagnostic message S962 "Empty pipe" is triggered in the event of a partially filled or empty measuring pipe.	0 to 100 s	1 s

10.4.11 Configuring the HART input

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input

► HART input				
[► Configuration		\rightarrow	₿ 95
		Capture mode	→	₿ 95
		Device ID	→	₿ 95
		Device type	→	₿ 96
		Manufacturer ID	→	₿ 96
		Burst command	→	₿ 96
		Slot number	→	₿ 96
		Timeout] →	₿ 96
		Failure mode	→	₿ 96
		Failure value	→	₿ 96
[► Input		\rightarrow	96
		Value	→	₿ 96
		Status	→	₿ 96

"Configuration" submenu

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input \rightarrow Configuration

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Capture mode	-	Select capture mode via burst or master communication.	 Off Burst network Master network	Off
Device ID	The Master network option is selected in the Capture mode parameter.	Enter device ID of external device.	 6-digit value: Via local operation: enter as hexadecimal or decimal number Via operating tool: enter as decimal number 	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Device type	In the Capture mode parameter, the Master network option is selected.	Enter device type of external device.	2-digit hexadecimal number	0x00
Manufacturer ID	The Master network option is selected in the Capture mode parameter.	Enter manufacture ID of external device.	 2-digit value: Via local operation: enter as hexadecimal or decimal number Via operating tool: enter as decimal number 	0
Burst command	The Burst network option or the Master network option are selected in the Capture mode parameter.	Select command to read in external process variable.	 Command 1 Command 3 Command 9 Command 33 	Command 1
Slot number	The Burst network option or the Master network option is selected in the Capture mode parameter.	Define position of external process variable in burst command.	1 to 8	1
Timeout	The Burst network option or the Master network option is selected in the Capture mode parameter.	Enter deadline for process variable of external device. If the waiting time is exceeded, the ⊗F410 Data transfer diagnostic message is displayed.	1 to 120 s	5 s
Failure mode	In the Capture mode parameter, the Burst network option or Master network option is selected.	Define behavior if external process variable is missed.	 Alarm Last valid value Defined value	Alarm
Failure value	 The following conditions are met: In the Capture mode parameter, the Burst network option or Master network option is selected. In the Failure mode parameter, the Defined value option is selected. 	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

"Input" submenu

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input \rightarrow Input

Parameter	Description	User interface
Value	Shows the value of the device variable recorded by the HART input.	Signed floating-point number
Status	Shows the status of the device variable recorded by the HART input.	Manual/FixedGoodPoor accuracyBad

10.4.12 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu \rightarrow Relay output 1 to n

► Relay output 1 to n	
Terminal number	→ 🗎 97
Relay output function) → 🗎 97
Assign flow direction check] → 🗎 97
Assign limit) → 🗎 98
Assign diagnostic behavior] → 🗎 98
Assign status) → 🗎 98
Switch-off value) → 🗎 98
Switch-off delay) → 🗎 98
Switch-on value) → 🗎 98
Switch-on delay] → 🗎 98
Failure mode) → 🗎 98

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the relay output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	_
Relay output function	-	Select the function for the relay output.	 Closed Open Diagnostic behavior Limit Flow direction check Digital Output 	Closed
Assign flow direction check	The Flow direction check option is selected in the Relay output function parameter.	Select process variable for flow direction monitoring.	 Off Volume flow Mass flow Corrected volume flow 	Volume flow

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Assign limit	The Limit option is selected in the Relay output function parameter.	Select process variable for limit function.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Totalizer 1 Totalizer 1 Totalizer 2 Totalizer 3 Temperature * Electronics temperature 	Volume flow
Assign diagnostic behavior	In the Relay output function parameter, the Diagnostic behavior option is selected.	Select diagnostic behavior for switch output.	 Alarm Alarm or warning Warning	Alarm
Assign status	In the Relay output function parameter, the Digital Output option is selected.	Select device status for switch output.	 Partially filled pipe detection Low flow cut off HBSI limit exceeded * 	Partially filled pipe detection
Switch-off value	In the Relay output function parameter, the Limit option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal(us)/min
Switch-off delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Switch-on value	The Limit option is selected in the Relay output function parameter.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal(us)/min
Switch-on delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open

10.4.13 Configuring the double pulse output

The **Double pulse output** submenu guides the user systematically through all the parameters that have to be set for configuring the double pulse output.

Navigation

"Setup" menu \rightarrow Double pulse output

► Double pulse output	
Signal mode) → 🗎 99
Master terminal number) → 🗎 99

Assign pulse output] → 🗎 99
Measuring mode) → 🗎 99
Value per pulse) → 🗎 99
Pulse width) → 🗎 99
Failure mode	→ 🗎 99
Invert output signal	} ⇒ 🗎 99

Parameter overview with brief description

Parameter	Description	Selection / User interface / User entry	Factory setting
Signal mode	Select the signal mode for the double pulse output.	 Passive Active[*] Passive NE 	Passive
Master terminal number	Shows the terminal numbers used by the master of the double pulse output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Assign pulse output	Select process variable for pulse output.	OffVolume flowMass flowCorrected volume flow	Off
Measuring mode	Select measuring mode for pulse output.	 Forward flow Forward/Reverse flow Reverse flow Reverse flow compensation 	Forward flow
Value per pulse	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	Define time width of the output pulse.	0.5 to 2 000 ms	0.5 ms
Failure mode	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	Invert the output signal.	NoYes	No

* Visibility depends on order options or device settings

10.4.14 Configuring flow damping

The **Configure flow damping** wizard guides the user systematically through the parameters, depending on the selected scenario:

- Configuration of damping for the application
 To configure flow damping for the specific requirements of
- To configure flow damping for the specific requirements of the process application. • Replace old device
- To adopt the flow damping for the new device in the event of a device replacement. • Restoring factory settings

To restore the factory settings of all the parameters that are relevant for flow damping.

Navigation "Setup" menu \rightarrow Configure flow damping

► Configure flow damping	
Scenario	→ 🗎 100
Old device	〕 → 🗎 100
CIP filter on	→ 🗎 100
Damping level	→ 🗎 100
Flow change rate	→ 🗎 101
Application	→ 🗎 101
Pulsating flow	→ 🗎 101
Flow peaks	→ 🗎 101
Damping level	→ 🗎 100
Filter options	→ 🗎 101
Median filter depth	→ 🗎 101
Flow damping	→ 🗎 101
Support ID	→ 🗎 101
Save settings	→ 🖹 101
Save settings	


Parameter	Description	Selection / User interface	Factory setting
Scenario	Select the applicable scenario. • Replace old device • Configure damping tapplication • Restore factory setti		Configure damping for application
Old device	Select the measuring device to replace.	 Promag 10 (pre-2021) Promag 50/53 Promag 55 H 	Promag 50/53
CIP filter on	Indicate whether the CIP filter was applied for the device to be replaced.	NoYes	No
Damping level	Select the degree of damping to apply.	 Default Weak Strong	Default

Parameter	Description	Selection / User interface	Factory setting
Flow change rate	Select the rate at which the flow changes.	 Once a day or less Once an hour or less Once a minute or less Once a second or more 	Once a minute or less
Application	Select the type of application that applies.	Display flowControl loopTotalizingBatching	Display flow
Pulsating flow	Indicate whether the process is characterized by pulsating flow (e.g. due to a displacement pump).	NoYes	No
Flow peaks	Select the frequency at which flow interference peaks occur.	Never Never Sporadically Regularly Continuously	
Response Time		FastSlowNormal	Normal
Filter options	Shows the type of flow filter recommended for damping.	 Adaptive Adaptive CIP on Dynamic Dynamic CIP on Binomial Binomial CIP on 	Binomial
Median filter depth	Shows median filter depth recommended for damping.	0 to 255	6
Flow damping	Shows the flow filter depth recommended for damping.	0 to 15	7
Support ID	If the recommended settings are not satisfactory: please contact your Endress +Hauser service organization with the support ID displayed.	0 to 65 535	0
Save settings	Indicate whether to save the recommended settings.	 Cancel Save * 	Cancel
Filter Wizard result:		CompletedAborted	Aborted

10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




- The number of submenus and parameters can vary depending on the device version and the available application packages. These submenus and their parameters are explained in the Special Documentation for the device and not in Operating Instructions.
 - For detailed information on the parameter descriptions for application packages: Special Documentation for the device
 - For detailed information on the SIL parameter descriptions, see the Functional Safety Manual $\rightarrow \cong 189$

Navigation

"Setup" menu \rightarrow Advanced setup

► Advanced setup			
	Enter access code]	→ 🗎 103
	► Sensor adjustment]	→ 🗎 103



10.5.1 Using the parameter to enter the access code

Navigation

"Setup" menu \rightarrow Advanced setup

Parameter overview with brief description

Parameter	Description	User entry
Enter access code	1 1	Max. 16-digit character string comprising numbers, letters and special characters

10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment

► Sensor adjustment	
Installation direction	→ 🗎 103

Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Installation direction	Select sign of flow direction.	Forward flowReverse flow	Forward flow

10.5.3 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n



Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	 Off Volume flow Mass flow Corrected volume flow	Volume flow
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie 104$) of the Totalizer 1 to n submenu.	Select the unit for the process variable of the totalizer.	Unit choose list	Depends on country: l gal (us)
Totalizer operation mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong$ 104) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	NetForwardReverse	Net
Failure mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxdot 104$) of the Totalizer 1 to n submenu.	Select totalizer behavior in the event of a device alarm.	 Hold Continue Last valid value + continue 	Hold

10.5.4 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display	
Format display] → 🗎 106
Value 1 display] → 🗎 106
0% bargraph value 1] → 🗎 106
100% bargraph value 1] → 🗎 106
Decimal places 1) → 🗎 106
Value 2 display] → 🗎 106
Decimal places 2) → 🗎 106
Value 3 display] → 🗎 106
0% bargraph value 3] → 🗎 106
100% bargraph value 3] → 🗎 107
Decimal places 3] → 🗎 107
Value 4 display] → 🗎 107
Decimal places 4] → 🗎 107
Display language] → 🗎 108
Display interval] → 🗎 108
Display damping] → 🗎 108
Header] → 🗎 108
Header text] → 🗎 108
Separator] → 🗎 108
Backlight] → 🗎 108

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Mass flow Corrected volume flow Flow velocity Corrected conductivity* Totalizer 1 Totalizer 1 Totalizer 3 Current output 1 Current output 3* Current output 4* Temperature* Electronics temperature HBSI* Noise* Coil current shot time* Reference electrode potential against PE* Build-up index* Test point 1 Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXXX 	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \cong$ 92)	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \cong 92$)	None
0% bargraph value 5	An option was selected in the Value 5 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
100% bargraph value 5	An option was selected in the Value 5 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 5	A measured value is specified in the Value 5 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxx x.xxxxx x.xxxxx x.xxxxx x.xxxxx 	X.XX
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \cong$ 92)	None
Decimal places 6	A measured value is specified in the Value 6 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXXX X.XXXXX X.XXXXX X.XXXXXX 	x.xx
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None
0% bargraph value 7	An option was selected in the Value 7 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
100% bargraph value 7	An option was selected in the Value 7 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 7	A measured value is specified in the Value 7 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxx x.xxxxx x.xxxxx x.xxxxx 	X.XX
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter ($\rightarrow \square$ 92)	None

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Decimal places 8	A measured value is specified in the Value 8 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxxx x.xxxxx x.xxxxx x.xxxxxx 	x.xx
Display language	A local display is provided.	Set display language.	 English Deutsch Français Español Italiano Nederlands Portuguesa Polski русский язык (Russian) Svenska Türkçe 中文 (Chinese) 日本語 (Japanese) 한국 어 (Korean) tiếng Việt (Vietnamese) čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	 Device tag Free text	Device tag
Header text	The Free text option is selected in the Header parameter.	Enter display header text.	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	 . (point) , (comma) 	. (point)
Backlight	 One of the following conditions is met: Order code for "Display; operation", option F "4-line, illum.; touch control" Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN" Order code for "Display; operation", option O "Remote display 4-line illuminated; 10m/30ft cable; touch control" 	Switch the local display backlight on and off.	DisableEnable	Enable

10.5.5 Performing electrode cleaning

The **Electrode cleaning cycle** submenu contains the parameters that must be set for the configuration of electrode cleaning.

The submenu is only available if the device was ordered with electrode cleaning.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Electrode cleaning cycle

► Electrode cleaning cycle	
Electrode cleaning cycle) → 🗎 109
ECC duration) → 🗎 109
ECC recovery time) → 🗎 109
ECC interval) → 🗎 109
ECC polarity) → 🗎 109

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning cycle	Bei folgendem Bestellmerkmal: "Anwendungspaket", Option EC "ECC Elektrodenreinigung"	Switch electrode cleaning on or off.	• Off • On	On
ECC duration	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the duration of the cleaning phase of the cycle. Diag. msg. no. 530 is displayed until the cleaning phase and recovery phase are complete.	0.01 to 30 s	2 s
ECC recovery time	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the maximum timespan after the cleaning phase for recovery before measurement resumes during which the output signal values are frozen.	1 to 600 s	60 s
ECC interval	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the interval between one cleaning cycle and the next.	0.5 to 168 h	0.5 h
ECC polarity	For the following order code: "Application package", option EC "ECC electrode cleaning"	Select the polarity of the electrode cleaning circuit.	PositiveNegative	Depends on the electrode material: • Tantalum: Negative option • Platinum, Alloy C22, stainless steel: Positive option

10.5.6 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow WLAN settings

► WLAN settings			
	WLAN]	→ 🖺 110
	WLAN mode]	→ 🗎 110
	SSID name]	→ 🗎 110
	Network security		→ 🖺 111
	Security identification		→ 🗎 111
	User name]	→ 🗎 111
	WLAN password]	→ 🗎 111
	WLAN IP address		→ 🗎 111
	WLAN MAC address]	→ 🗎 111
	WLAN passphrase		→ 🗎 111
	Assign SSID name		→ 🖺 111
	SSID name		→ 🖺 111
	Connection state		→ 🗎 111
	Received signal strength		→ 🗎 111

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN	-	Switch WLAN on and off.	DisableEnable	Enable
WLAN mode	-	Select WLAN mode.	WLAN access pointWLAN Client	WLAN access point
SSID name	The client is activated.	Enter the user-defined SSID name (max. 32 characters).	-	-

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Network security	-	Select the security type of the WLAN network.	 Unsecured WPA2-PSK EAP-PEAP with MSCHAPv2* EAP-PEAP MSCHAPv2 no server authentic.* EAP-TLS* 	WPA2-PSK
Security identification	-	Select security settings and download these settings via menu Data management > Security > WLAN.	Trusted issuer certificateDevice certificateDevice private key	-
User name	-	Enter user name.	-	-
WLAN password	-	Enter WLAN password.	-	-
WLAN IP address	-	Enter IP address of the WLAN interface of the device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
WLAN MAC address	-	Enter MAC address of the WLAN interface of the device.	Unique 12-digit character string comprising letters and numbers	Each measuring device is given an individual address.
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters). The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user- defined name.	Device tagUser-defined	User-defined
SSID name	 The User-defined option is selected in the Assign SSID name parameter. The WLAN access point option is selected in the WLAN mode parameter. 	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Promag_300_A 802000)
Connection state	-	Displays the connection status.	ConnectedNot connected	Not connected
Received signal strength	-	Shows the received signal strength.	LowMediumHigh	High

* Visibility depends on order options or device settings

10.5.7 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup** submenu.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Configuration backup

► Configuration backup	
Operating time	→ 🗎 112
Last backup	→ 🗎 112
Configuration management	→ 🗎 112
Backup state	→ 🗎 112
Comparison result	→ 🗎 112

Parameter overview with brief description


Parameter	Description	User interface / Selection	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Last backup	Shows when the last data backup was saved to HistoROM backup.	Days (d), hours (h), minutes (m) and seconds (s)	-
Configuration management	Select action for managing the device data in the HistoROM backup.	 Cancel Execute backup Restore* Compare* Clear backup data 	Cancel
Backup state	Shows the current status of data saving or restoring.	 None Backup in progress Restoring in progress Delete in progress Compare in progress Restoring failed Backup failed 	None
Comparison result	Comparison of current device data with HistoROM backup.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible 	Check not done

* Visibility depends on order options or device settings

Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.

Options	Description
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.



A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.5.8 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

► Administration	
► Define access code) → 🗎 113
► Reset access code) → 🗎 114
Device reset) → 🗎 114

Using the parameter to define the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

► Define access code	
Define access code	→ 🗎 113
Confirm access code	→ 🗎 113

Parameter	Description	User entry
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes.	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code		Max. 16-digit character string comprising numbers, letters and special characters

Using the parameter to reset the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Reset access code

► Reset access code	
Operating time) → 🗎 114
Reset access code] → 🗎 114

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Reset access code	Reset access code to factory settings. For a reset code, contact your Endress+Hauser service organization. The reset code can only be entered via: Web browser DeviceCare, FieldCare (via CDI-RJ45 service interface) Fieldbus	Character string comprising numbers, letters and special characters	0x00

Using the parameter to reset the device

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	 Cancel To delivery settings Restart device Restore S-DAT backup * 	Cancel

* Visibility depends on order options or device settings

10.6 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation "Diagnostics" menu → Simulation

► Simulation	
Assign simulation process variable] → 🗎 116
Process variable value] → 🗎 116
Current input 1 to n simulation) → 🗎 117
Value current input 1 to n	→ 🗎 117
Status input simulation 1 to n) → 🗎 117
Input signal level 1 to n) → 🗎 117
Current output 1 to n simulation) → 🗎 116
Current output value) → 🗎 116
Frequency output 1 to n simulation) → 🗎 116
Frequency output 1 to n value] → 🗎 116
Pulse output simulation 1 to n) → 🗎 116
Pulse value 1 to n) → 🗎 116
Switch output simulation 1 to n] → 🗎 116
Switch state 1 to n] → 🗎 116
Relay output 1 to n simulation) → 🗎 116
Switch state 1 to n) → 🗎 116
Pulse output simulation] → 🗎 116
Pulse value) → 🗎 116
Device alarm simulation] → 🗎 117
Diagnostic event category) → 🗎 117
Diagnostic event simulation] → 🗎 117

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	_	Select a process variable for the simulation process that is activated.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected conductivity* Temperature* 	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter $(\rightarrow \cong 116)$.	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	OffOn	Off
Current output value	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA	3.59 mA
Frequency output 1 to n simulation	In the Operating mode parameter, the Frequency option is selected.	Switch the simulation of the frequency output on and off.	OffOn	Off
Frequency output 1 to n value	In the Frequency simulation 1 to n parameter, the On option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz	0.0 Hz
Pulse output simulation 1 to n	In the Operating mode parameter, the Pulse option is selected.	 Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (→	 Off Fixed value Down-counting value 	Off
Pulse value 1 to n	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation 1 to n	In the Operating mode parameter, the Switch option is selected.	Switch the simulation of the switch output on and off.	OffOn	Off
Switch state 1 to n	-	Select the status of the status output for the simulation.	OpenClosed	Open
Relay output 1 to n simulation	-	Switch simulation of the relay output on and off.	OffOn	Off
Switch state 1 to n	The On option is selected in the Switch output simulation 1 to n parameter parameter.	Select status of the relay output for the simulation.	 Open Closed	Open
Pulse output simulation	-	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	 Off Fixed value Down-counting value 	Off
Pulse value	In the Pulse output simulation parameter, the Down-counting value option is selected.	Set and switch off the pulse output simulation.	0 to 65 535	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Device alarm simulation	-	Switch the device alarm on and off.	OffOn	Off
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off
Current input 1 to n simulation	-	Switch simulation of the current input on and off.	OffOn	Off
Value current input 1 to n	In the Current input 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	0 to 22.5 mA	0 mA
Status input simulation 1 to n	-	Switch simulation of the status input on and off.	OffOn	Off
Input signal level 1 to n	In the Status input simulation parameter, the On option is selected.	Select the signal level for the simulation of the status input.	HighLow	High

* Visibility depends on order options or device settings

10.7 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code $\rightarrow \square 117$
- Protect access to local operation via key locking \rightarrow 🖺 56
- Protect access to measuring device via write protection switch $\rightarrow \square 119$

10.7.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via local display

- **1.** Navigate to the **Define access code** parameter ($\rightarrow \implies 113$).
- **2.** Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
- 3. Enter the access code again in the **Confirm access code** parameter (→ 🗎 113) to confirm the code.
 - ← The 🖻-symbol appears in front of all write-protected parameters.


The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected

parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

- If parameter write protection is activated via an access code, it can also only be deactivated via this access code $\rightarrow \cong 55$.
 - The user role with which the user is currently logged on via the local display
 - → 🗎 55 is indicated by the Access status parameter. Navigation path: Operation → Access status

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the Web browser

- **1**. Navigate to the **Define access code** parameter ($\Rightarrow \triangleq 113$).
- 2. Define a max. 16-digit numeric code as an access code.
- 3. Enter the access code again in the **Confirm access code** parameter ($\rightarrow \implies 113$) to confirm the code.
 - └ The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
 - If parameter write protection is activated via an access code, it can also only be deactivated via this access code $\rightarrow \cong 55$.
 - The user role with which the user is currently logged on via Web browser is indicated by the Access status parameter. Navigation path: Operation → Access status

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

You can only obtain a reset code from your local Endress+Hauser service organization. The code must be calculated explicitly for every device.

- 1. Note down the serial number of the device.
- 2. Read off the **Operating time** parameter.
- **3.** Contact the local Endress+Hauser service organization and tell them the serial number and the operating time.
 - └ → Get the calculated reset code.

4. Enter the reset code in the **Reset access code** parameter ($\Rightarrow \square 114$).

→ The access code has been reset to the factory setting **0000**. It can be redefined $\rightarrow \textcircled{}{}$ 117.


For IT security reasons, the calculated reset code is only valid for 96 hours from the specified operating time and for the specific serial number. If you cannot return to the device within 96 hours, you should either increase the operating time you read out by a few days or switch off the device.

10.7.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.


The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via HART protocol



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

In the Locking status parameter, the Hardware locked option is displayed
 → ■ 120. In addition, on the local display the
 symbol appears in front of the parameters in the header of the operational display and in the navigation view.



- 2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - Isomorphic to be based on the locking status parameter → 120. On the local display, the B symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

11 Operation

11.1 Reading off the device locking status

Device active write protection: Locking status parameter

Operation \rightarrow Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access authorization displayed in the Access status parameter applies $\rightarrow \square$ 55. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \square$ 119.
SIL locked	The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).
CT active - all parameters	The DIP switch for custody transfer mode is activated on the PCB board. Locks the parameters that are relevant for custody transfer and also parameters that are predefined by Endress+Hauser and are not relevant for custody transfer (e.g. on local display or operating tool). For detailed information on custody transfer mode, see the Special Documentation for the device
CT active - defined parameters	The DIP switch for the custody transfer mode is activated on the PCB board. Only locks the parameters that are relevant for custody transfer (e.g. on the local display or operating tool).
	Documentation for the device
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Detailed information:

- To configure the operating language $\rightarrow \square 75$
- For information on the operating languages supported by the measuring device $\rightarrow~\textcircled{}180$

11.3 Configuring the display

Detailed information:

- On the basic settings for the local display $\rightarrow \implies 91$
- On the advanced settings for the local display $\rightarrow \implies 105$

11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

11.4.1 "Process variables" submenu

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Process variables	
Volume flow	→ 🗎 121
Mass flow	→ 🗎 121
Corrected volume flow	→ 🗎 121
Flow velocity	→ 🗎 121
Conductivity	→ 🗎 121
Corrected conductivity	→ 🗎 121
Temperature	→ 🗎 122
Density	→ 🗎 122

Parameter	Prerequisite	Description	User interface
Volume flow	-	Displays the volume flow that is currently measured.	Signed floating-point number
		Dependency The unit is taken from: Volume flow unit parameter ($\rightarrow \square 78$)	
Mass flow	-	Displays the mass flow that is currently calculated.	Signed floating-point number
		Dependency The unit is taken from the Mass flow unit parameter ($\rightarrow \square 78$).	
Corrected volume flow	-	Displays the corrected volume flow that is currently calculated.	Signed floating-point number
		Dependency The unit is taken from: Corrected volume flow unit parameter (→	
Flow velocity	-	Displays the flow velocity that is currently calculated.	Signed floating-point number
Conductivity	-	Displays the conductivity that is currently measured.	Signed floating-point number
		Dependency The unit is taken from the Conductivity unit parameter ($\rightarrow \square 78$).	
Corrected conductivity	One of the following conditions is met: • Order code for "Sensor option", option	Displays the conductivity that is currently corrected.	Positive floating-point number
measurement" or • The temperature		Dependency The unit is taken from: Conductivity unit parameter ($\rightarrow \square 78$)	

Parameter	Prerequisite	Description	User interface
Temperature	 One of the following conditions is met: Order code for "Sensor option", option CI "Medium temperature measurement" or The temperature is read into the flowmeter from an external device. 	Displays the temperature that is currently calculated. <i>Dependency</i> The unit is taken from: Temperature unit parameter ($\rightarrow \square$ 78)	Positive floating-point number
Density	-	Displays the current fixed density or density read in from an external device. <i>Dependency</i> The unit is taken from the Density unit parameter.	Signed floating-point number

11.4.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer

► Totalizer		
Totaliz	zer value 1 to n	→ 🗎 122
Totaliz	er overflow 1 to n	→ 🗎 122

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	A process variable is selected in the Assign process variable parameter $(\rightarrow \bigoplus 104)$ of the Totalizer 1 to n submenu.	Displays the current totalizer counter reading.	Signed floating-point number
Totalizer overflow 1 to n	A process variable is selected in the Assign process variable parameter $(\rightarrow \triangleq 104)$ of the Totalizer 1 to n submenu.	Displays the current totalizer overflow.	Integer with sign

11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values

► Input values		
	► Current input 1 to n	→ 🖺 123
	► Status input 1 to n	→ 🖺 123

Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Current input 1 to n

► Current input 1 to n	
Measured values 1 to n] → 🗎 123
Measured current 1 to n] → 🗎 123

Parameter overview with brief description

Parameter	Description	User interface
Measured values 1 to n	Displays the current input value.	Signed floating-point number
Measured current 1 to n	Displays the current value of the current input.	0 to 22.5 mA

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Status input 1 to n

► Status input 1 to n		
Value status input		→ 🗎 123

Parameter overview with brief description

Parameter	Description	User interface
Value status input	Shows the current input signal level.	HighLow


11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values

► Output values		
► Cu	rrent output 1 to n	→ 🗎 124




Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Value current output 1 to n



Parameter overview with brief description

Parameter	Description	User interface
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Pulse/frequency/switch output 1 to n

Pulse/frequency/switch output 1 to n	
Output frequency 1 to n	→ 🗎 125
Pulse output 1 to n	→ 🗎 125
Switch state 1 to n	→ 🗎 125

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Output frequency 1 to n	In the Operating mode parameter, the Frequency option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output 1 to n	The Pulse option is selected in the Operating mode parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch state 1 to n	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	 Open Closed

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Relay output 1 to n

► Relay output 1 to n	
Switch state	→ 🗎 125
Switch cycles) → 🗎 125
Max. switch cycles number) → 🗎 125

Parameter overview with brief description

Parameter	Description	User interface
Switch state	Shows the current relay switch status.	OpenClosed
Switch cycles	Shows number of all performed switch cycles.	Positive integer
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer

Output values for double pulse output

The **Double pulse output** submenu contains all the parameters needed to display the current measured values for every double pulse output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Double pulse output

► Double pulse output		
Pulse output]	→ 🗎 126

Parameter overview with brief description

Parameter	Description	User interface	
Pulse output	Shows the currently output pulse frequency.	Positive floating-point number	

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu ($\rightarrow \square 75$)
- Advanced settings using theAdvanced setup submenu (→
 [™] 102)

11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu \rightarrow Totalizer handling

► Totalizer handling	
Control Totalizer 1 to n) → 🗎 126
Preset value 1 to n) → 🗎 126
Totalizer value 1 to n) → 🗎 127
Reset all totalizers) → 🗎 127

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxdot 104$) of the Totalizer 1 to n submenu.	Control totalizer value.	 Totalize Reset + hold * Preset + hold * Reset + totalize Preset + totalize * Hold * 	Totalize
Preset value 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 104) of the Totalizer 1 to n submenu.	Specify start value for totalizer. Dependency The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 104).	Signed floating-point number	01

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Totalizer value	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie 104$) of the Totalizer 1 to n submenu.	Displays the current totalizer counter reading.	Signed floating-point number	-
Reset all totalizers	-	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

* Visibility depends on order options or device settings

11.6.1 Function scope of "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold ¹⁾	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize ¹⁾	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

1) Visible depending on the order options or device settings

11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

11.7 Show data logging

The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

Pata logging is also available via:

- Plant Asset Management Tool FieldCare $\rightarrow \cong 66$.
- Web browser

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Measured value trend for each logging channel displayed in the form of a chart

ראַגע (ער אין	xxxxxx
175.77	mmm m
40.69 l/h	-100s 0

A0034352

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

► Data logging	
Assign channel 1	→ 🗎 129
Assign channel 2	→ 🗎 129
Assign channel 3	→ 🗎 129
Assign channel 4	→ 🗎 129
Logging interval	→ 🗎 129
Clear logging data	→ 🗎 129
Data logging	→ 🗎 130
Logging delay	→ 🗎 130
Data logging control	→ 🗎 130
Data logging status	→ 🗎 130
Entire logging duration	→ 🗎 130
Entire logging duration	/ 目 150

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Corrected * conductivity* Temperature* Electronics temperature Current output 1 Current output 2* Current output 3* Current output 4* Noise* Coil current shot time* Reference electrode potential against PE* HBSI* Build-up index* Test point 1 Test point 3 	Off
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \square 129)$	Off
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \square 129)$	Off
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \bowtie 129)$	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3600.0 s	1.0 s
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data	Cancel

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Data logging	-	Select the type of data logging.	 Overwriting Not overwriting	Overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	NoneDelete + startStop	None
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	DoneDelay activeActiveStopped	Done
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating- point number	0 s

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $\rightarrow \textcircled{B}$ 32.
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective. Main electronics module is defective.	Order spare part → 🗎 154.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part $\rightarrow \square 154$.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 141$
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press 2 s \equiv + \oplus ("home position"). 2. Press \boxtimes . 3. Set the desired language in the Display language parameter ($\rightarrow \cong$ 108).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part →

For output signals

Error	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🗎 154.
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	Main electronics module is defective. I/O electronics module is defective.	Order spare part → 🗎 154.

Error	Possible causes	Remedial action
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parametrization errors	Check parameterization and correct it.
Device measures incorrectly.	Configuration error or device is operated outside the application.	 Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access


Error	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position $\rightarrow \cong 119$.
No write access to parameters	Current user role has limited access authorization	1. Check user role → \textcircled{B} 55. 2. Enter correct customer-specific access code → \textcircled{B} 55.
No connection via HART protocol	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly. Observe the maximum load $\rightarrow \square$ 164.
No connection via HART protocol	Commubox Connected incorrectly Configured incorrectly Drivers not installed correctly USB interface on computer configured incorrectly	Observe the documentation for the Commubox. FXA195 HART: Document "Technical Information" TI00404F
No connection to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary $\rightarrow \cong 62$.
	Incorrect settings for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) → 🗎 58 → 🗎 58. 2. Check the network settings with the IT manager.
No connection to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 $\rightarrow \cong 58 \rightarrow \cong 58$
No connection to Web server	Incorrect WLAN access data	 Check WLAN network status. Log on to the device again using WLAN access data. Check that WLAN is enabled on the measuring device and operating device →
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	 Check if WLAN reception is present: LED on display module is lit blue Check if WLAN connection is enabled: LED on display module flashes blue Switch on instrument function.
Network connection not present or unstable	WLAN network is weak.	 Operating device is outside of reception range: Check network status on operating device. To improve network performance, use an external WLAN antenna.
	Parallel WLAN and Ethernet communication	 Check network settings. Temporarily enable only the WLAN as an interface.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.

Error	Possible causes	Remedy	
	Connection lost	 Check cable connection and power supply. Refresh the Web browser and restart if necessary. 	
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	 Use the correct Web browser version	
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.	
No or incomplete display of contents in the Web browser	 JavaScript not enabled JavaScript cannot be enabled	 Enable JavaScript. Enter http://XXX.XXX.X.X.X.X/servlet/ basic.html as the IP address. 	
Operation with FieldCare or DeviceCare not possible via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.	
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.	

Diagnostic information via light emitting diodes 12.2

12.2.1 Transmitter

Different LEDs in the transmitter provide information on the device status.



Supply voltage Device status 1

2

3 Not used

-4 5 Communication

Service interface (CDI) active


LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is ok.
2	Device status (normal	Off	Firmware error
	operation)	Green	Device status is ok.
		Flashing green	Device is not configured.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.

LED		Color	Meaning
		Flashing red/green	The device restarts.
2	Device status (during	Flashes red slowly	If $>$ 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	Off	Communication not active.
		White	Communication active.
5	Service interface (CDI)	Off	Not connected or no connection established.
		Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 145$
- Via submenus →
 [™]
 [™]
 146

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).



The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: • Outside its technical specification limits (e.g. outside the process temperature range) • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
М	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior

Symbol	Meaning
8	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.


Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Кеу	Meaning	
+	Plus key In a menu, submenu Opens the message about remedy information.	
E	Enter key <i>In a menu, submenu</i> Opens the operating menu.	




12.3.2 Calling up remedial measures

- 2. Press = + \pm simultaneously.
 - └ The message for the remedial measures closes.

12.4 Diagnostic information in the Web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 145$
- Via submenu →
 [™]
 [™]
 146

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
\otimes	Failure A device error has occurred. The measured value is no longer valid.
V	Function check The device is in the service mode (during a simulation, for example).
	Out of specification The device is being operated: • Outside its technical specification limits (e.g. outside the process temperature range) • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

D 📽 🖬 🍜 🕋 📾 🖸 🎟 🇯 🗽 Xxxxxx///	2 💽 1 🕆 1 🕅	€ ♥ F • ∰ ∰ ∰ ∰ ∰
Device name: XXXXXXX Device tag: XXXXXXX Status signal:	Function check (Mass flow: ₽ 12.34 kg/h Volume flow: ₽ 12.34 m³/h C)
 Xxxxxx Point Diagnostics 1: Poperation Operation Diagnostics Diagnostics Expert 	C485 Simu Deactivate Mainenance	Instrument health status Image: Second state of the status Image: Second state of the st


- 1 Status area with status signal $\rightarrow \square 135$
- 2 Diagnostics information $\rightarrow \square$ 136
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \triangleq 145$
- Via submenu →
 ⁽¹⁾
 ⁽²⁾
 ⁽²⁾

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
- Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - └ A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior



■ 31 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (Event list submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic** event category submenu.

Expert \rightarrow Communication \rightarrow Diagnostic event category

Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning
A0013956	Failure A device error is present. The measured value is no longer valid.
C	Function check The device is in service mode (e.g. during a simulation).
S 40013958	 Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
M	Maintenance required Maintenance is required. The measured value is still valid.
N	Has no effect on the condensed status.
A0023076	

12.7 Overview of diagnostic information

The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information $\rightarrow \square 140$

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of	sensor			
043	Sensor 1 short circuit detected	 Check sensor cable and sensor Execute Heartbeat Verification Replace sensor cable or sensor 	S	Warning ¹⁾
082	Data storage inconsistent	Check module connections	F	Alarm
083	Memory content inconsistent	 Restart device Restore S-DAT data Replace S-DAT 	F	Alarm
143	HBSI limit exceeded	 Check if external magnetic interference is present Check flow value Replace sensor 	М	Warning ¹⁾
168	Build-up limit exceeded	Clean measuring tube	М	Warning
169	Conductivity measurement failed	 Check grounding conditions Deactivate conductivity measurement 	М	Warning
170	Coil resistance faulty	Check ambient and process temperature	F	Alarm
180	Temperature sensor defective	 Check sensor connections Replace sensor cable or sensor Turn off temperature measurement 	F	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
181	Sensor connection faulty	 Check sensor cable and sensor Execute Heartbeat Verification Replace sensor cable or sensor 	F	Alarm
Diagnostic of	electronic			
201	Electronics faulty	 Restart device Replace electronics 	F	Alarm
242	Firmware incompatible	 Check firmware version Flash or replace electronic module 	F	Alarm
252	Module incompatible	 Check electronic modules Check if correct modules are available (e.g. NEx, Ex) Replace electronic modules 	F	Alarm
262	Module connection interrupted	 Check module connections Replace electronic modules 	F	Alarm
270	Main electronics defective	1. Restart device 2. Replace main electronic module	F	Alarm
271	Main electronics faulty	1. Restart device 2. Replace main electronic module	F	Alarm
272	Main electronics faulty	Restart device	F	Alarm
273	Main electronics defective	 Pay attention to display emergency operation Replace main electronics 	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	1. Restart device 2. Change I/O module	F	Alarm
283	Memory content inconsistent	Restart device	F	Alarm
302	Device verification active	Device verification active, please wait.	С	Warning ¹⁾
303	I/O 1 to n configuration changed	 Apply I/O module configuration (parameter 'Apply I/O configuration') Afterwards reload device description and check wiring 	М	Warning
311	Sensor electronics (ISEM) faulty	Maintenance required! Do not reset device	М	Warning
330	Flash file invalid	 Update firmware of device Restart device 	М	Warning
331	Firmware update failed	 Update firmware of device Restart device 	F	Warning
332	Writing in HistoROM backup failed	 Replace user interface board Ex d/XP: replace transmitter 	F	Alarm
361	I/O module 1 to n faulty	 Restart device Check electronic modules Change I/O module or main electronics 	F	Alarm
372	Sensor electronics (ISEM) faulty	 Restart device Check if failure recurs Replace sensor electronic module (ISEM) 	F	Alarm
373	Sensor electronics (ISEM) faulty	Transfer data or reset device	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
375	I/O- 1 to n communication failed	 Restart device Check if failure recurs Replace module rack inclusive electronic modules 	F	Alarm
376	Sensor electronics (ISEM) faulty	 Replace sensor electronic module (ISEM) Turn off diagnostic message 	S	Warning ¹⁾
377	Electrode signal faulty	 Activate empty pipe detection Check partial filled pipe and installation direction Check sensor cabling Deactivate diagnostics 377 	S	Warning ¹⁾
378	Supply voltage ISEM faulty	 If available: Check connection cable between sensor and transmitter Replace main electronic module Replace sensor electronic module (ISEM) 	F	Alarm
382	Data storage	1. Insert T-DAT 2. Replace T-DAT	F	Alarm
383	Memory content	Reset device	F	Alarm
387	HistoROM data faulty	Contact service organization	F	Alarm
Diagnostic of	configuration		•	
410	Data transfer failed	 Retry data transfer Check connection 	F	Alarm
412	Processing download	Download active, please wait	С	Warning
431	Trim 1 to n required	Carry out trim	С	Warning
437	Configuration incompatible	 Update firmware Execute factory reset 	F	Alarm
438	Dataset different	 Check data set file Check device parameterization Download new device parameterization 	M	Warning
441	Current output faulty	 Check process Check current output settings 	S	Warning ¹⁾
442	Frequency output faulty	 Check process Check frequency output settings 	S	Warning ¹⁾
443	Pulse output 1 to n faulty	 Check process Check pulse output settings 	S	Warning ¹⁾
444	Current input 1 to n faulty	 Check process Check current input settings 	S	Warning ¹⁾
453	Flow override active	Deactivate flow override	С	Warning
484	Failure mode simulation active	Deactivate simulation	С	Alarm
485	Process variable simulation active	Deactivate simulation	С	Warning
486	Current input simulation active	Deactivate simulation	С	Warning
491	Current output 1 to n simulation active	Deactivate simulation	С	Warning
492	Frequency output simulation active	Deactivate simulation frequency output	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
493	Pulse output simulation active	Deactivate simulation pulse output	С	Warning
494	Switch output simulation active	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation active	Deactivate simulation	С	Warning
496	Status input simulation active	Deactivate simulation status input	С	Warning
502	CT activation/ deactivation failed	Follow the sequence of the custody transfer activation/deactivation: First authorized user login, then set the DIP switch on the main electonic module	С	Warning
511	Sensor setting error	 Check measuring period and integration time Check sensor properties 	С	Alarm
512	ECC recovery time exceeded	1. Check ECC recovery time 2. Turn off ECC	F	Alarm
520	I/O 1 to n hardware configuration invalid	 Check I/O hardware configuration Replace wrong I/O module Plug the module of double pulse output on correct slot 	F	Alarm
530	Electrode cleaning active	Switch off electrode cleaning	С	Warning
531	Empty pipe adjustment faulty	Execute EPD adjustment	S	Warning ¹⁾
537	Configuration	1. Check IP addresses in network 2. Change IP address	F	Warning
540	Custody transfer mode failed	 Power off device and toggle DIP switch Deactivate custody transfer mode Reactivate custody transfer mode Check electronic components 	F	Alarm
543	Double pulse output	 Check process Check pulse output settings 	S	Warning ¹⁾
593	Double pulse output simulation	Deactivate simulation pulse output	С	Warning
594	Relay output simulation	Deactivate simulation switch output	С	Warning
599	Custody transfer logbook full	 Deactivate custody transfer mode Clear custody transfer logbook (all 30 entries) Activate custody transfer mode 	S	Warning
Diagnostic of	process			
803	Loop current 1 faulty	 Check wiring Change I/O module 	F	Alarm
832	Electronics temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronics temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
842	Process value below limit	Low flow cut off active! Check low flow cut off configuration	S	Warning ¹⁾
882	Input signal faulty	 Check input signal parameterization Check external device Check process conditions 	F	Alarm
937	Sensor symmetry	 Eliminate external magnetic field near sensor Turn off diagnostic message 	S	Warning ¹⁾
938	Coil current not stable	 Check if external magnetic interference is present Perform Heartbeat Verification Check flow value 	F	Alarm ¹⁾
961	Electrode potential out of specification	 Check process conditions Check ambient conditions 	S	Warning ¹⁾
962	Pipe empty	 Perform full pipe adjustment Perform empty pipe adjustment Turn off empty pipe detection 	S	Warning ¹⁾

1) Diagnostic behavior can be changed.

12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \implies 137$
- Via web browser $\rightarrow \square 138$
- Via "FieldCare" operating tool →
 [™] 140
- Via "DeviceCare" operating tool →
 [™]
 [™]
 140

Other pending diagnostic events can be displayed in the Diagnostic list submenu $\rightarrow \cong 146$

Navigation

"Diagnostics" menu

ද Diagnostics			
	Actual diagnostics]	→ 🗎 146
	Previous diagnostics]	→ 🖺 146
	Operating time from restart		→ 🗎 146
	Operating time		→ 🗎 146

Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Actual diagnostics	Actual diagnostics A diagnostic event has occurred. Si event has occurred.		Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.9 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

 $\text{Diagnostics} \rightarrow \text{Diagnostic list}$



■ 32 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \triangleq 137$
- Via web browser $\rightarrow \square 138$
- Via "FieldCare" operating tool $\rightarrow \implies 140$
- Via "DeviceCare" operating tool $\rightarrow \implies 140$


12.10 Event logbook

12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

 $\textbf{Diagnostics} \text{ menu} \rightarrow \textbf{Event logbook} \text{ submenu} \rightarrow \text{Event list}$



33 Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events $\rightarrow \square 141$
- Information events $\rightarrow \triangleq 147$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - \mathfrak{D} : Occurrence of the event
 - G: End of the event
- Information event
- \odot : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \cong 137$
- Via web browser $\rightarrow \square 138$
- Via "FieldCare" operating tool $\rightarrow \square 140$
- Via "DeviceCare" operating tool $\rightarrow \implies 140$

For filtering the displayed event messages → 🖺 147

12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed

Info number	Info name
I1092	HistoROM backup deleted
I1137	Electronics changed
I1151	History reset
I1155	Reset electronics temperature
I1156	Memory error trend
I1157	Memory error event list
I1256	Display: access status changed
I1264	Safety sequence aborted
I1278	I/O module restarted
I1335	Firmware changed
I1351	Empty pipe detection adjustment failure
I1353	Empty pipe detection adjustment ok
I1361	Web server: login failed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1443	Build-up thickness not determined
I1444	Device verification passed
I1445	Device verification failed
I1457	Measurement error verification failed
I1459	I/O module verification failed
I1461	Sensor verification failed
I1462	Sensor electronic module verific. failed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1517	Custody transfer active
I1518	Custody transfer inactive
I1554	Safety sequence started
I1555	Safety sequence confirmed
I1556	Safety mode off
I1618	I/O module 2 replaced
I1619	I/O module 3 replaced
I1621	I/O module 4 replaced
I1622	Calibration changed
I1624	All totalizers reset
I1625	Write protection activated
I1626	Write protection deactivated
I1627	Web server: login successful
I1628	Display: login successful
I1629	CDI: login successful
I1631	Web server access changed
I1632	Display: login failed

Info number	Info name	
I1633	CDI: login failed	
I1634	Reset to factory settings	
I1635	Reset to delivery settings	
I1639	Max. switch cycles number reached	
I1643	Custody transfer logbook cleared	
I1649	Hardware write protection activated	
I1650	Hardware write protection deactivated	
I1651	Custody transfer parameter changed	
I1712	New flash file received	
I1725	Sensor electronic module (ISEM) changed	
I1726	Configuration backup failed	

12.11 Resetting the measuring device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter ($\Rightarrow \triangleq 114$).

12.11.1 Function scope of "Device reset" parameter

Options	Description		
Cancel	No action is executed and the user exits the parameter.		
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to the customer-specific value. All other parameters are reset to the factory setting.		
Restart device	The restart resets every parameter with data stored in volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.		
Restore S-DAT backup	Restores the data that is saved on the S-DAT. Additional information: This function can be used to resolve the memory issue "083 Memory content inconsistent" or to restore the S-DAT data when a new S-DAT has been installed.		
	This option is displayed only in an alarm condition.		

12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information

► Device information					
Device tag) → 🗎 150				
Serial number	→ 🗎 150				
Firmware version	→ 🗎 150				

Device name		→ 🗎 150
Manufacturer		→ 🗎 150
Order code]	→ 🗎 150
Extended order code 1		→ 🗎 150
Extended order code 2		→ 🗎 151
Extended order code 3		→ 🗎 151
ENP version		→ 🗎 151
Device revision		→ 🗎 151
Device ID		→ 🗎 151
Device type		→ 🖺 151
Manufacturer ID		→ 🗎 151

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Promag 300/500	-
Manufacturer	Displays the manufacturer.	Character string comprising numbers, letters and special characters	Endress+Hauser
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-

Parameter	Description	User interface	Factory setting
Extended order code 2	Shows the 2nd part of the extended order code.	Character string	-
	The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.		
Extended order code 3	Shows the 3rd part of the extended order code.	Character string	-
	The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.		
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00
Device revision	Shows the device revision with which the device is registered with the HART Communication Foundation.	2-digit hexadecimal number	7
Device ID	Shows the device ID for identifying the device in a HART network.	6-digit hexadecimal number	-
Device type	Shows the device type with which the measuring device is registered with the HART Communication Foundation.	2-digit hexadecimal number	0x3A (for Promag 300)
Manufacturer ID	Shows the device's manufacturer ID registered with the HART Communication Foundation.	2-digit hexadecimal number	0x11 (for Endress+Hauser)

12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
08.2022	01.06.zz	Option 60	 HBSI (Heartbeat Technology) Build-up index (Heartbeat Technology) Flow damping configuration 	Operating Instructions	BA01392D/06/EN/04.22
09.2019	01.05.zz	Option 64	Various improvements	Operating Instructions	BA01392D/06/EN/02.19

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
10.2017	01.01.zz	Option 68	 OPC-UA with Security new Local display - enhanced performance and data entry via text editor Optimized keypad lock for local display Web server feature update Support for trend data function Heartbeat function enhanced to include detailed results (page 3/4 of the report) Device configuration as PDF (parameter log, similar to FDT print) Network capability of Ethernet (service) interface Comprehensive Heartbeat feature update Local display - support for WLAN infrastructure mode Implementation of reset code 	Operating Instructions	BA01392D/06/EN/02.17
08.2016	01.00.zz	Option 76	Original firmware	Operating Instructions	BA01392D/06/EN/01.16

- It is possible to flash the firmware to the current version or the previous version using the service interface. For the compatibility of the firmware version, see the "Device history and compatibility" section $\rightarrow \cong 152$
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 5H3B
 - The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

12.14 Device history and compatibility

The device model is documented in the order code on the nameplate of the device (e.g. 8F3BXX-XXX....XXXA1-XXXXX).

Device model	Release	Change compared with earlier model	Compatibility with earlier model
A2	09.2019	I/O module with enhanced performance and functionality: see device firmware $01.05.zz \rightarrow 151$	No
A1	10.2017	-	-

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

Cleaning with pigs

It is essential to take the internal diameters of the measuring tube and process connection into account when cleaning with pigs. All the dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document.

13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.

The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory part) \rightarrow 🖺 188

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \square 156 \rightarrow \square 158$

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General information

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ► Document every repair and each conversion and enter them into the *W*@*M* life cycle management database and Netilion Analytics.

14.2 Spare parts

Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

P Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the Serial number parameter (→
 ^(→) 150) in the Device information submenu.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- Refer to the web page for information: http://www.endress.com/support/return-material
 Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal

X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to persons from process conditions!

 Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.

2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

 Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Proline 300 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: • Approvals • Output • Input • Display/operation • Housing • Software ① Order code: 5X3BXX
	Installation Instructions EA01199D
Remote display and operating module DKX001	 If ordered directly with the measuring device: Order code for "Display; operation", option O "Remote display 4-line, illuminated; 10 m (30 ft) cable; touch control" If ordered separately: Measuring device: order code for "Display; operation", option M "W/o, prepared for remote display" DKX001: Via the separate product structure DKX001 If ordered subsequently: DKX001: Via the separate product structure DKX001
	 Mounting bracket for DKX001 If ordered directly: order code for "Accessory enclosed", option RA "Mounting bracket, pipe 1/2" If ordered subsequently: order number: 71340960
	Connecting cable (replacement cable) Via the separate product structure: DKX002
	Further information on display and operating module DKX001 \rightarrow 🗎 181.
	Special Documentation SD01763D
External WLAN antenna	External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area".
	 The external WLAN antenna is not suitable for use in hygienic applications. Additional information regarding the WLAN interface →
	Order number: 71351317
	Installation Instructions EA01238D
Weather protection cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight. Order number: 71343505
	Order number: 71343505

15.1.2 For the sensor

Accessories	Description
Adapter set	Adapter connections for installing a Promag H instead of a Promag 30/33 A or Promag 30/33 H (DN 25).
	Consists of: 2 process connections Screws Seals
Seal set	For the regular replacement of seals for the sensor.
Spacer	If replacing a DN 80/100 sensor in an existing installation, a spacer is needed if the new sensor is shorter.
Welding jig	Welding socket as process connection: welding jig for installation in pipe.
Grounding rings	Are used to ground the medium in lined measuring tubes to ensure proper measurement.
	Grounding rings can be ordered via the device order structure or configured and ordered as an accessory via the DK5HR order structure.
Mounting kit	Consists of: • 2 process connections • Screws • Seals
Wall mounting kit	Wall mounting kit for measuring device (only DN 2 to 25 (1/12 to 1"))

15.2 Communication-specific accessories

Accessories	Description			
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.			
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values.			
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices • Technical Information TI01297S • Operating Instructions BA01778S • Product page: www.endress.com/fxa42			
Field Xpert SMT50	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.			
	 Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt50 			

Field Xpert SMT70	 The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle. Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt70 		
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1.		
	 Technical Information TI01418S Operating Instructions BA01923S Product page: www.endress.com/smt77 		

15.3 Service-specific accessories

Accessory	Description
Applicator	 Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices with industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.
	 Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator As a downloadable DVD for local PC installation.
W@M	W@M Life Cycle ManagementImproved productivity with information at your fingertips. Data relevant to aplant and its components is generated from the first stages of planning andduring the asset's complete life cycle.W@M Life Cycle Management is an open and flexible information platformwith online and on-site tools. Instant access for your staff to current, in-depthdata shortens your plant's engineering time, speeds up procurement processesand increases plant uptime.Combined with the right services, W@M Life Cycle Management boostsproductivity in every phase. For more information, see:www.endress.com/lifecyclemanagement
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.
	Operating Instructions BA00027S and BA00059S
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices.

15.4 System components

Accessories	Description
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	 Technical Information TI00133R Operating Instructions BA00247R
ITEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.
	Fields of Activity" document FA00006T

16 Technical data

16.1 Application

The measuring device is only suitable for the flow measurement of liquids with a minimum conductivity of 5 $\mu S/cm.$

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of Faraday's law of magnetic induction.
Measuring system	The device consists of a transmitter and a sensor.
	The device is available as a compact version: The transmitter and sensor form a mechanical unit.
	Information on the structure of the device $\rightarrow \square 14$

16.3 Input

Measured variable	Direct measured variables						
	 Volume flow (proportional to induced voltage) Temperature ³⁾ Electrical conductivity 						
	Calculated measured variables						
	 Mass flow Corrected volume flow Corrected electrical conductivity ³⁾ 						
Measuring range	Typically $v = 0.01$ to 10 m/s (0.03 to 33 ft/s) with the specified accuracy						
	Flow characteristic values in SI units: DN 2 to 125 ($\frac{1}{12}$ to 5")						
	Nominal	diameter	Recommended flow		Factory settings		
			min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)	
	[mm]	[in]	[dm³/min]	[dm³/min]	[dm ³]	[dm ³ /min]	
	2	1/12	0.06 to 1.8	0.5	0.005	0.01	
	4	5/32	0.25 to 7	2	0.025	0.05	

³⁾ Available only for nominal diameters DN 15 to 150 (½ to 6") and with the order code for "Sensor option", option CI "Medium temperature measurement".

Nominal diameter		Recommended flow	Factory settings			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)	
[mm]	[in]	[dm ³ /min]	[dm ³ /min]	[dm ³]	[dm³/min]	
8	⁵ / ₁₆	1 to 30	8	0.1	0.1	
15	1/2	4 to 100	25	0.2	0.5	
25 ¹⁾	1	9 to 300	75	0.5	1	
40	1 ½	25 to 700	200	1.5	3	
50	2	35 to 1 100	300	2.5	5	
65	-	60 to 2 000	500	5	8	
80	3	90 to 3 000	750	5	12	
100	4	145 to 4700	1200	10	20	
125 5		220 to 7 500	1850	15	30	

1) The values apply for the product version: 5HxB26

Flow characteristic values in SI units: DN 150 (6")

Nominal diameter		Recommended flow			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)Pulse value (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)
[mm] [in]		[m ³ /h]	[m ³ /h]	[m ³]	[m³/h]
150 6		20 to 600	150	0.03	2.5

Flow characteristic values in US units: $\frac{1}{12}$ - 6" (DN 2 - 150)

Nominal	diameter	Recommended flow		Factory settings	
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/ min]
1/12	2	0.015 to 0.5	0.1	0.001	0.002
1/32	4	0.07 to 2	0.5	0.005	0.008
5/16	8	0.25 to 8	2	0.02	0.025
1/2	15	1 to 27	6	0.05	0.1
1 ¹⁾	25	2.5 to 80	18	0.2	0.25
1 1/2	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4

	Nominal	diameter	Recommended flow	Factory settings			
			min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)	
	[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/ min]	
	5	125	60 to 1950	450	5	7	
	6	150	90 to 2 650	600	5	12	
			y for the product versic	on: 5HxB26			
		Recommended measuring range Flow limit $\rightarrow \cong 176$					
		·	_ 1,0				
			ransfer, the applica lse value and the l		rmines the permitted mea	asuring	
Operable flow range	Over 100	0:1					
					00 : 1 to 630 : 1, dependir the applicable approval.	ng on the	
Input signal	External	measur	ed values				
	 To increase the accuracy of certain measured variables or to calculate the mass flow, the automation system can continuously write different measured values to the measuring device: Medium temperature enables temperature-compensated conductivity measurement (e.g. iTEMP) 						
	 Reference density for calculating the mass flow Various pressure and temperature measuring devices can be ordered from Endress +Hauser: see "Accessories" section →						
	It is recommended to read in external measured values to calculate the corrected volume flow.						
	HART protocol						
	The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions: • HART protocol • Burst mode						
	Current input						
	The mea	sured val	ues are written fro → 🗎 162.	m the automation	system to the measuring	device via	
	Current input 0/4 to 20 mA						

Current input	0/4 to 20 mA (active/passive)
Current span	 4 to 20 mA (active) 0/4 to 20 mA (passive)
Resolution	1 μΑ

Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)
Maximum input voltage	< 30 V (passive)
Open-circuit voltage	< 28.8 V (active)
Possible input variables	TemperatureDensity

Status input

Maximum input values	 DC -3 to 30 V If status input is active (ON): R_i >3 kΩ
Response time	Configurable: 5 to 200 ms
Input signal level	 Low signal: DC -3 to +5 V High signal: DC 12 to 30 V
Assignable functions	 Off Reset the individual totalizers separately Reset all totalizers Flow override

16.4 Output

Output signal

Current output 4 to 20 mA HART

Order code	"Output; input 1" (20): Option BA: current output 4 to 20 mA HART
Signal mode	Can be set to: • Active • Passive
Current range	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • 0 to 20 mA (only if the signal mode is active) • Fixed current
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	250 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature

Current output 4 to 20 mA HART Ex i

Order code	 "Output; input 1" (20) choose from: Option CA: current output 4 to 20 mA HART Ex i passive Option CC: current output 4 to 20 mA HART Ex i active
Signal mode	Depends on the selected order version.
Current range	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • 0 to 20 mA (only if the signal mode is active) • Fixed current
Open-circuit voltage	DC 21.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	 250 to 400 Ω (active) 250 to 700 Ω (passive)
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature

Current output 4 to 20 mA

Order code	"Output; input 2" (21), "Output; input 3" (022): Option B: current output 4 to 20 mA
Signal mode	Can be set to: • Active • Passive
Current span	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • 0 to 20 mA (only if the signal mode is active) • Fixed current
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature

Current output 4 to 20 mA Ex i passive

Order code	"Output; input 2" (21), "Output; input 3" (022): Option C: current output 4 to 20 mA Ex i passive
Signal mode	Passive
Current span	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA Fixed current
Maximum output values	22.5 mA
Maximum input voltage	DC 30 V
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature

Pulse/frequency/switch output

Function	Can be configured as pulse, frequency or switch output
Version	Open collector
	Can be set to: • Active • Passive • Passive NAMUR Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Configurable
Assignable measured variables	Volume flowMass flowCorrected volume flow
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Configurable: end value frequency 2 to 10000 Hz(f $_{\rm max}$ = 12500 Hz)
Damping	Configurable: 0 to 999.9 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
_	

Number of switching cycles	Unlimited
Assignable functions	 Off On Diagnostic behavior Limit value: Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Totalizer 1-3 Temperature Electronics temperature Flow direction monitoring Status Empty pipe detection Buildup index HBSI limit value exceeded Low flow cut off

Double pulse output

Function	Double pulse
Version	Open collector Can be set to: • Active • Passive • Passive NAMUR
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Temperature Electronics temperature

Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: • NO (normally open), factory setting • NC (normally closed)

Maximum switching capacity (passive)	 DC 30 V, 0.1 A AC 30 V, 0.5 A
Assignable functions	 Off On Diagnostic behavior Limit value: Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Corrected conductivity Totalizer 1-3 Temperature Electronics temperature Flow direction monitoring Status Empty pipe detection Buildup index HBSI limit value exceeded Low flow cut off

User-configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm Depending on the interface, failure information is displayed as follows:

Current output 0/4 to 20 mA

4	to	20	тA
4	to	20	тA

Failure mode	Choose from: 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Freely definable value between: 3.59 to 22.5 mA Actual value Last valid value
--------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

0 to 20 mA

Failure mode	Choose from:
	 Maximum alarm: 22 mA Freely definable value between: 0 to 20.5 mA

Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from: • Actual value • No pulses

Frequency output		
Failure modeChoose from: 		
Switch output		
Failure mode	Choose from: • Current status • Open • Closed	

Relay output

Failure mode	Choose from:
	 Current status
	 Open
	Closed

Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication:
- HART protocol
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text d	isplay	With information on cause and remedial measures
--------------	--------	-------------------------------------------------

Web browser

Plain text display With inf	ormation on cause and remedial measures
-------------------------------------	-----------------------------------------

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	The following information is displayed depending on the device version:Supply voltage activeData transmission activeDevice alarm/error has occurred
	Diagnostic information via light emitting diodes $\rightarrow \square$ 133

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

- The outputs are galvanically isolated: from the power supply from one another

- from the potential equalization (PE) terminal

Protocol-specific data	Manufacturer ID	0x11
	Device type ID	0x3C
	HART protocol revision	7
	Device description files (DTM, DD)	Information and files under: www.endress.com
	HART load	Min. 250 Ω
	System integration	 Information on system integration → P 70. Measured variables via HART protocol Burst Mode functionality

16.5 Power supply


Terminal assignment	→ 🗎 32						
Supply voltage	Order code for "Power supply"	Terminal volta	je	Frequency range			
	Option D	DC 24 V	±20%	-			
	Option E	AC 100 to 240 \	′ −15 to +10%	50/60 Hz, ±4 Hz			
	Option I	DC 24 V	±20%	-			
		AC 100 to 240 \	7 -15 to +10%	50/60 Hz, ±4 Hz			
Power consumption	Transmitter						
	Max. 10 W (active po	ower)					
	switch-on current	Max. 36 A (<5 ms) as pe	ax. 36 A (<5 ms) as per NAMUR Recommendation NE 21				
Current consumption	Transmitter						
	 Max. 400 mA (24) Max. 200 mA (110) 	V)) V, 50/60 Hz; 230 V, 5	0/60 Hz)				
Power supply failure	 Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memoryor in the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored. 						
Overcurrent protection element	The device must be operated with a dedicated circuit breaker, as it does not have an ON/OFF switch of its own. • The circuit breaker must be easy to reach and labeled accordingly. • Permitted nominal current of the circuit breaker: 2 A up to maximum 10 A.						
Electrical connection	→ 🗎 32						


Potential equalization		
Terminals	Spring-loaded terminals: Suitable for st Conductor cross-section 0.2 to 2.5 mm	
Cable entries	 Cable gland: M20 × 1.5 with cable Ø Thread for cable entry: NPT ¹/₂" G ¹/₂" M20 	6 to 12 mm (0.24 to 0.47 in)
Cable specification	→ 🗎 29	
Overvoltage protection	Mains voltage fluctuations	→ 🗎 170
	Overvoltage category	Overvoltage category II
	Short-term, temporary overvoltage	Up to 1200 V between cable and ground, for max. 5 s
	Long-term, temporary overvoltage	Up to 500 V between cable and ground

16.6 Performance characteristics

Reference operating conditions	 Error limits following DIN EN 29104, in future ISO 20456 Water, typically: +15 to +45 °C (+59 to +113 °F); 0.5 to 7 bar (73 to 101 psi) Data as indicated in the calibration protocol Accuracy based on accredited calibration rigs according to ISO 17025 Reference temperature for conductivity measurement: 25 °C (77 °F)
Maximum measured error	o.r. = of reading
	Error limits under reference operating conditions
	Volume flow
	• $\pm 0.5 \%$ o.r. $\pm 1 \text{ mm/s} (0.04 \text{ in/s})$

Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s)







Temperature


±3 °C (±5.4 °F)

Electrical conductivity


- The values apply for:
- Devices with stainless steel process connections
- Measurements at a reference temperature of 25 °C (77 °F). At different temperatures, attention must be paid to the temperature coefficient of the medium (typically 2.1 %/K)

Conductivity	Nominal diameter		Measured error	
[µS/cm]	[mm]	[in]	[%] of reading	
5 to 20	15 to 150	½ to 6	± 20%	
> 20 to 50	15 to 150	½ to 6	± 10%	
> 50 to 10 000	2 to 8	¹ / ₁₂ to ⁵ / ₁₆	± 10%	
	15 to 150	½ to 6	 Standard: ± 10% Optional ¹): ± 5% 	
> 10 000 to 20 000	2 to 150	¹ / ₁₂ to 6	± 10%	
> 20 000 to 100 000	2 to 150	¹⁄₁₂ to 6	± 20%	

1) Order code for "Calibrated conductivity measurement", option CW



■ 35 Measured error (standard)



36 Measured error (optional: order code for "Calibrated conductivity measurement", option CW)

Accuracy of outputs

The outputs have the following base accuracy specifications.

		1			
	Accuracy	±5 µA			
	Pulse/frequency output				
	o.r. = of reading				
	Accuracy	Max. ±50 ppm o.r. (over the entire ambient temperature range)			
Repeatability	o.r. = of reading				
	Volume flow Max. ±0.1 % o.r. ± 0.5	mm/s (0.02 in/s)			
	Temperature ±0.5 °C (±0.9 °F)				
	Electrical conductivity	,			
	 Max. ±5 % o.r. Max. ±1 % o.r. for DN 15 to 150 in conjunction with process connections made of stainless steel 1.4404 (F316L) 				
Temperature measurement response time	T ₉₀ < 15 s				
Influence of ambient temperature	Current output				
-	Temperature coefficient	Мах. 1 µА/°С			
	Pulse/frequency output				
	Temperature coefficient	No additional effect. Included in accuracy.			
	16.7 Installation				
Installation conditions	→ 🖹 20				
	16.8 Environ	ment			
Ambient temperature range	→ 🗎 25				
	Temperature tables				
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.				
	For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.				
Storage temperature	The storage temperature corresponds to the operating temperature range of the transmitter and the sensor $\rightarrow \triangleq 25$.				

 Cleaning in place (CIP) Sterilization in place (SIP)
Rough handling shocks according to IEC 60068-2-31
6 ms 30 g
Shock half-sine, according to IEC 60068-2-27
 10 to 200 Hz, 0.003 g²/Hz 200 to 2 000 Hz, 0.001 g²/Hz Total: 1.54 g rms
Vibration broad-band random, according to IEC 60068-2-64
 2 to 8.4 Hz, 3.5 mm peak 8.4 to 2 000 Hz, 1 g peak
Sinusoidal vibration according to IEC 60068-2-6
IP67
External WLAN antenna
Optional
 When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2 Display module: IP20, Type 1 enclosure, suitable for pollution degree 2
TransmitterIP66/67, Type 4X enclosure, suitable for pollution degree 4
 > 2 000 m (6 562 ft) with additional overvoltage protection (e.g. Endress+Hauser HAW Series)
According to EN 61010-1 ■ ≤ 2 000 m (6562 ft)
The device is suitable for use in outdoor and indoor areas with a relative humidity of 4 to 95%.
Order code for "Sensor option", option CF "Harsh environment".
Additional protection against condensation and moisture: the sensor housing is potted with a gel.
 Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures. Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner. If protection caps or protective covers are mounted these should never be removed before installing the measuring device.


Electromagnetic compatibility (EMC) As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) The Details are provided in the Declaration of Conformity.

This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.

16.9 Process

Medium temperature range

-20 to +150 °C (-4 to +302 °F)



T_A Ambient temperature range

 T_F Fluid temperature

2 to 150

¹/₁₂ to 6

The permitted fluid temperature in custody transfer is 0 to +50 $^\circ C$ (+32 to +122 $^\circ F).$

Conductivity	≥5 µS/cm	for liquids	in general.				
Pressure-temperature ratings	For an overview of the pressure-temperature ratings for the process connections, see the Technical Information						
Pressure tightness	Liner: PFA						
	Nominal	diameter	Limit values fo	or absolute press	ure in [mbar] ([]	osi]) for medium	temperatures:
	[mm]	[in]	+25 ℃ (+77 ℉)	+80 °C (+176 °F)	+100 °C (+212 °F)	+130 °C (+266 °F)	+150 °C (+302 °F)

0 (0)

0 (0)

0 (0)

0 (0)

0 (0)

Flow limit	The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the medium: • $v < 2 m/s$ (6.56 ft/s): for low conductivity values • $v > 2 m/s$ (6.56 ft/s): for media producing buildup (e.g. milk with a high fat content)					
	A necessary in nominal diame		velocity can be achieved	by reducing the sensor		
	For an overvie range" section	w of the full scale v	alues for the measuring	range, see the "Measuring		
Pressure loss	 No pressure loss occurs as of nominal diameter DN 8 (5/16") if the sensor is installed in a pipe with the same nominal diameter. Pressure losses for configurations incorporating adapters according to DIN EN 545 → ≅ 25 					
System pressure	→ 🖺 25					
Vibrations	→ 🗎 25					
	16.10 Mech	anical const	ruction			
Design, dimensions	For the dimensions and installed lengths of the device, see the "Technical Information document, "Mechanical construction" section					
Weight	All values (weight exclusive of packaging material) refer to devices with flanges of the standard pressure rating. The weight may be lower than indicated depending on the pressure rating and design. Weight specifications including transmitter as per order code for "Housing", option A "Aluminum, coated".					
	 Transmitter versi 	on for the hazardo Iousing", option A " on for hygienic are	us area Aluminum, coated"; Ex d	-		
	Nominal d			/eight		
	[mm]	[in]	[kg]	[lbs]		
	2 4	5/32	4.7	10.4		
	8	5/32	4.7	10.4		
	15	1/2	4.7	10.4		
	25	1	5.5	12.1		
	40	1 1/2	6.8	15.0		
	50	2	7.3	16.1		
	65	_	8.1	17.9		
	80	3	8.7	19.2		

Nominal diameter		Weight		
[mm]	[in]	[kg]	[lbs]	
125	5	15.4	34.0	
150	6	17.8	39.3	

Measuring tube
specification

Nominal diameter		Pressure rating ¹⁾	Process connection internal diameter	
		EN (DIN)	PFA	
[mm]	[in]	[bar]	[mm]	[in]
2	1/12	PN 16/40	2.25	0.09
4	5/32	PN 16/40	4.5	0.18
8	5/16	PN 16/40	9.0	0.35
15	1/2	PN 16/40	16.0	0.63
-	1	PN 16/40	22.6 ²⁾	0.89 ²⁾
25	-	PN 16/40	26.0 ³⁾	1.02 ³⁾

1) Depending on process connection and seals used

2) Order code 5H**22

3) Order code 5H**26

Materials

Transmitter housing

Order code for "Housing":

- Option A "Aluminum, coated": aluminum, AlSi10Mg, coated
- Option B "Stainless, hygienic": stainless steel, 1.4404 (316L)

Window material


Order code for "Housing":

- Option A "Aluminum, coated": glass
- Option B "Stainless, hygienic": polycarbonate

Seals

Order code for "Housing": Option **B** "Stainless, hygienic": EPDM and silicone

Cable entries/cable glands



■ 37 Possible cable entries/cable glands

1 Female thread M20 × 1.5

2 Cable gland M20 × 1.5

3 Adapter for cable entry with female thread G $\frac{1}{2}$ or NPT $\frac{1}{2}$ "

Order code for "Housing", option A "Aluminum, coated"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Compression fitting M20 × 1.5	Non-Ex: plastic
	Z2, D2, Ex d/de: brass with plastic
Adapter for cable entry with female thread G $\frac{1}{2}$	Nickel-plated brass
Adapter for cable entry with female thread NPT ½"	

Order code for "Housing", option B "Stainless, hygienic"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Plastic
Adapter for cable entry with female thread G ½"	Nickel-plated brass
Adapter for cable entry with female thread NPT ½"	

Sensor housing

Stainless steel 1.4301 (304)

Measuring tubes

Stainless steel 1.4301 (304)

Liner

PFA (USP Class VI, FDA 21 CFR 177.2600)

Process connections

- Stainless steel, 1.4404 (F316L)
- PVDF
- PVC adhesive sleeve

Electrodes

Standard: 1.4435 (316L)

Seals

- O-ring seal, DN 2 to 25 (1/12 to 1"): EPDM, FKM ⁴⁾, Kalrez
- Aseptic⁵⁾ gasket seal, DN 2 to 150 (1/12 to 6"): EPDM, FKM⁴⁾, VMQ (silicone)

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

⁴⁾ USP Class VI, FDA 21 CFR 177.2600, 3A

⁵⁾ Aseptic means hygienic design in this context

	 External WLAN antenna Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Plug: Nickel-plated brass Angle bracket: Stainless steel Grounding rings Standard: 1.4435 (316L) Optional: Alloy C22, tantalum Wall mounting kit Stainless steel, 1.4301 (304)⁶
	Spacer
	1.4435 (F316L)
Fitted electrodes	 2 measuring electrodes for signal detection 1 empty pipe detection electrode for empty pipe detection/temperature measurement (only DN 15 to 150 (¹/₂ to 6"))
Process connections	With O-ring seal: • Welding nipple (DIN EN ISO 1127, ODT/SMS, ISO 2037) • Flange (EN (DIN), ASME, JIS) • Flange from PVDF (EN (DIN), ASME, JIS) • External thread • Internal thread • Hose connection • PVC adhesive sleeve
	With aseptic molded seal: Coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145) Flange DIN 11864-2
	For information on the different materials used in the process connections \rightarrow \cong 178
Surface roughness	Electrodes: ■ Stainless steel, 1.4435 (316L) electropolished ≤ 0.5 μm (19.7 μin) ■ Alloy C22, 2.4602 (UNSN06022); tantalum ≤ 0.5 μm (19.7 μin) (All data refer to parts in contact with the medium)
	Liner with PFA: ≤ 0.4 µm (15.7 µin)
	(All data refer to parts in contact with the medium)
	 Stainless steel process connections: With O-ring seal: ≤ 1.6 µm (63 µin) With aseptic seal: Ra_{max} = 0.76 µm (31.5 µin) Optional: Ra_{max} = 0.38 µm (15 µin) electropolished
	(All data refer to parts in contact with the medium)

⁶⁾ Does not meet the hygienic design installation guidelines.

16.11 Operability

Languages	 Can be operated in the following languages: Via local operation English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Vietnamese, Czech, Swedish Via Web browser English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Vietnamese, Czech, Swedish Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese 		
Local operation	Via display module		
	 Equipment: Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control" Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN" 		
	Information about WLAN interface $\rightarrow \cong 65$		

38 Operation with touch control

Display elements

- 4-line, illuminated, graphic display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.


Operating elements

- External operation via touch control (3 optical keys) without opening the housing: $\boxdot, ~\boxdot, ~\boxtimes$
- Operating elements also accessible in the various zones of the hazardous area

Via remote display and operating module DKX001

The remote display and operating module DKX001 is available as an optional extra $\rightarrow \cong 156$.

- The remote display and operating module DKX001 is only available for the following housing version: order code for "Housing": option A "Aluminum, coated"
- The measuring device is always supplied with a dummy cover when the remote display and operating module DKX001 is ordered directly with the measuring device. Display or operation at the transmitter is not possible in this case.
- If ordered subsequently, the remote display and operating module DKX001 may not be connected at the same time as the existing measuring device display module. Only one display or operation unit may be connected to the transmitter at any one time.



☑ 39 Operation via remote display and operating module DKX001

Display and operating elements

The display and operating elements correspond to those of the display module $\rightarrow \square$ 180.

Housing material

The housing material of the display and operating module DKX001 corresponds to the selected material of the transmitter housing.

Transmitter housing		Remote display and operating module
Order code for "Housing"	Material	Material
Option A "Aluminum, coated"	AlSi10Mg, coated	AlSi10Mg, coated

Cable entry

Corresponds to the choice of transmitter housing, order code for "Electrical connection".

Connecting cable

→ 🗎 30

Dimensions

Information about dimensions:

"Mechanical construction" section of the "Technical Information" document.

Remote operation	→ 🗎 63		
Service interface	→ 🖺 64		

Supported operating tools

Different operating tools can be used for local or remote access to the measuring device. Depending on the operating tool used, access is possible with different operating units and via a variety of interfaces.

Supported operating tools	Operating unit	Interface	Additional information
Web browser	Notebook, PC or tablet with Web browser	CDI-RJ45 service interfaceWLAN interface	Special Documentation for the device
DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows system	CDI-RJ45 service interfaceWLAN interfaceFieldbus protocol	→ 🗎 158
FieldCare SFE500	Notebook, PC or tablet with Microsoft Windows system	 CDI-RJ45 service interface WLAN interface Fieldbus protocol 	→ 🗎 158
Field Xpert	SMT70/77/50	 All fieldbus protocols WLAN interface Bluetooth CDI-RJ45 service interface 	Operating Instructions BA01202S Device description files: Use update function of handheld terminal
SmartBlue app	Smart phone or tablet with iOs or Android	WLAN	→ 🗎 158

- Other operating tools based on FDT technology with a device driver such as DTM/ iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
 - FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
 - Process Device Manager (PDM) from Siemens → www.siemens.com
 - Asset Management Solutions (AMS) from Emerson → www.emersonprocess.com
 - FieldCommunicator 375/475 from Emerson → www.emersonprocess.com
 - Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
 - FieldMate from Yokogawa → www.yokogawa.com
 - PACTWare → www.pactware.com

The related device description files are available: www.endress.com \rightarrow Downloads

Web server

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via the service interface (CDI-RJ45) or via the WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed and allows users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration

Web server special documentation $\rightarrow \triangleq 190$

HistoROMThe measuring device features HistoROM data management. HistoROM data managementdata managementcomprises both the storage and import/export of key device and process data, making
operation and servicing far more reliable, secure and efficient.

When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	HistoROM backup	T-DAT	S-DAT
Available data	 Event logbook such as diagnostic events for example Parameter data record backup Device firmware package 	 Measured value logging ("Extended HistoROM" order option) Current parameter data record (used by firmware at run time) Maximum indicators (min/max values) Totalizer values 	 Sensor data: nominal diameter etc. Serial number Calibration data Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

Data backup function

Backup and subsequent restoration of a device configuration in the device memory HistoROM backup

Data comparison function

Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transmission

Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the **Extended HistoROM** application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

If the **Extended HistoROM** application package (order option) is enabled:

- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Current certificates and approvals that are available for the product can be selected via the Product Configurator at www.endress.com:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Configuration**.

CE markThe device meets the legal requirements of the applicable EU Directives. These are listed in
the corresponding EU Declaration of Conformity along with the standards applied.
Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.UKCA markingThe device meets the legal requirements of the applicable UK regulations (Statutory
Instruments). These are listed in the UKCA Declaration of Conformity along with the
designated standards. By selecting the order option for UKCA marking, Endress+Hauser
confirms a successful evaluation and testing of the device by affixing the UKCA mark.

	Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com
RCM mark	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.
Sanitary compatibility	 3-A SSI 28-06 or more recent Confirmation by affixing the 3-A logo for measuring devices with the order code for "Additional approval", option LP "3-A". The 3-A approval refers to the measuring device. When installing the measuring device, ensure that no liquid can accumulate on the outside of the measuring device. Remote transmitters must be installed in accordance with the 3-A Standard. Accessories (e.g. weather protection cover, wall holder unit) must be installed in accordance with the 3-A Standard. Each accessory can be cleaned. Disassembly may be necessary under certain circumstances. EHEDG Type EL Class I Confirmation by affixing the EHEDG symbol for measuring devices with the order code for "Additional approval", option LT "EHEDG". EPDM is not a suitable seal material for fluids with a fat content > 8 %. To meet the requirements for EHEDG certification, the device must be used with process connections in accordance with the EHEDG position paper entitled "Easy Cleanable Pipe Couplings and Process Connections" (www.ehedg.org). FDA 21 CFR 177 Food Contact Materials Regulation (EC) 1935/2004 Food Contact Materials Regulation China GB 4806 Pasteurized Milk Ordinance (PMO)
Pharmaceutical compatibility	 FDA 21 CFR 177 USP <87> USP <88> Class VI 121 °C TSE/BSE Certificate of Suitability cGMP Devices with the order code for "Test, certificate", option JG "Conformity with cGMP-derived requirements, declaration" comply with the requirements of cGMP with regard to the surfaces of parts in contact with the medium, design, FDA 21 CFR material conformity, USP Class VI tests and TSE/BSE conformity. A serial number-specific declaration is generated.
Functional safety	The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL 3 (multi-channel architecture with homogeneous redundancy) and is independently evaluated and certified in accordance with IEC 61508.
	The following types of monitoring in safety equipment are possible: Functional Safety Manual with information on the SIL device → 🗎 189

HART certification	HART interface
	The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications: • Certified according to HART 7
	 The device can also be operated with certified devices of other manufacturers (interoperability)
Radio approval	The measuring device has radio approval.
	For detailed information on the radio approval, see the Special Documentation
Pressure Equipment Directive	 With the marking: a) PED/G1/x (x = category) or b) UK/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or b) Schedule 2 of Statutory Instruments 2016 No. 1105. Devices not bearing this marking (without PED or UKCA) are designed and manufactured according to sound engineering practice. They meet the requirements of a) Art. 4 Para. 3 of the Pressure Equipment Directive 2014/68/EU or b) Part 1, Para. 8 of Statutory Instruments 2016 No. 1105. The scope of application is indicated a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or b) Schedule 3, Para. 2 of Statutory Instruments 2016 No. 1105.
Additional certification	PWIS-free
	PWIS = paint-wetting impairment substances
	Order code for "Service": • Option HC : PWIS-free (version A) • Option HD : PWIS-free (version B) • Option HE : PWIS-free (version C)
	For more information on PWIS-free certification, see "Test specification" document TS01028D
Other standards and guidelines	 EN 60529 Degrees of protection provided by enclosures (IP code) EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements IEC/EN 61326-2-3 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitter with analog output signal. NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics

	 NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices NAMUR NE 107 Self-monitoring and diagnosis of field devices NAMUR NE 131 Requirements for field devices for standard applications ETSI EN 300 328 Guidelines for 2.4 GHz radio components. EN 301489 Electromagnetic compatibility and radio spectrum matters (ERM).
	16.13 Application packages
	Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.
	The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.
Diagnostic functionality	Order code for "Application package", option EA "Extended HistoROM"
	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	 Data logging (line recorder): Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.
	For detailed information, see the Operating Instructions for the device.
Heartbeat Technology	Order code for "Application package", option EB "Heartbeat Verification + Monitoring" Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment".
	 Functional testing in the installed state without interrupting the process. Traceable verification results on request, including a report. Simple testing process via local operation or other operating interfaces. Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications. Extension of calibration intervals according to operator's risk assessment.

	 Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to: Draw conclusions - using these data and other information - about the impact the process influences (e.g. formation of buildup, magnetic field interference etc.) have on measuring performance over time. Schedule servicing in time. Monitor the process or product quality.
Cleaning	Order code for "Application package", option EC "ECC electrode cleaning "
	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe_3O_4) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to avoid build-up of very conductive matter and thin layers (typical of magnetite).
	For detailed information, see the Operating Instructions for the device.
OPC-UA Server	Order code for "Application package", option EL "OPC-UA Server"
	The application package provides an integrated OPC-UA server for comprehensive device services for IoT and SCADA applications.
	For detailed information, see the Special Documentation for the device.
	16.14 Accessories
	Overview of accessories available for order $\rightarrow \cong 156$
	16.15 Supplementary documentation
	 For an overview of the scope of the associated Technical Documentation, refer to the following: Device Viewer (www.endress.com/deviceviewer): Enter serial number from nameplate. Endress+Hauser Operations app: Enter serial number from nameplate or scan matrix code on nameplate.

Standard documentation Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Promag H	KA01289D

Brief Operating Instructions for transmitter

Measuring device	Documentation code
Proline 300	KA01308D

Technical Information

Measuring device	Documentation code
Promag H 300	TI01223D

Description of Device Parameters

Measuring device	Documentation code
Promag 300	GP01051D

Supplementary devicedependent documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex d/Ex de	XA01414D
ATEX/IECEx Ex ec	XA01514D
cCSAus XP	XA01515D
cCSAus Ex d/ Ex de	XA01516D
cCSAus Ex nA	XA01517D
INMETRO Ex d/Ex de	XA01518D
INMETRO Ex ec	XA01519D
NEPSI Ex d/Ex de	XA01520D
NEPSI Ex nA	XA01521D
EAC Ex d/Ex de	XA01656D
EAC Ex nA	XA01657D
JPN Ex d	XA01775D

Remote display and operating module DKX001

Contents	Documentation code
ATEX/IECEx Ex i	XA01494D
ATEX/IECEx Ex ec	XA01498D
cCSAus IS	XA01499D
cCSAus Ex nA	XA01513D
INMETRO Ex i	XA01500D
INMETRO Ex ec	XA01501D
NEPSI Ex i	XA01502D
NEPSI Ex nA	XA01503D

Functional Safety Manual

Contents	Documentation code
Promag 300	SD01740D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Web server	SD01658D
Remote display and operating module DKX001	SD01763D
OPC-UA Server	SD02043D

Contents	Documentation code
Heartbeat Technology	SD01640D
Web server	SD01654D

Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via <i>Device Viewer</i> → ⁽¹⁾ 154 Accessories available for order with Installation Instructions → ⁽²⁾ 156

Index

A

A
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Adapters
Adapting the diagnostic behavior
Adapting the status signal
Additional certification 186
Ambient conditions
Ambient temperature
Mechanical load
Operating height
Relative humidity
Ambient temperature
Influence
Ambient temperature range
AMS Device Manager
Function
Application
Applicator
Approvals
В
Burst mode
C
Cable entries
Technical data
Cable entry
Degree of protection
CE mark
Certificates
cGMP 185
Check
Connection
Checklist
Post-connection check
Post-installation check
Cleaning
Exterior cleaning
Interior cleaning
Cleaning in place (CIP)
Commissioning
Advanced settings
Configuring the measuring device
Communication-specific data
Compatibility
Conductivity 175
Connecting cable
Connecting cable
Connecting the measuring device
Connecting the measuring device
Connecting the measuring device
Connecting the measuring device32Connecting the signal cables32Connecting the supply voltage cables32

Connection preparations
Calling up
Closing
Explanation
Current consumption
D
Date of manufacture
Declaration of Conformity 10
Define access code
Degree of protection
Device components
Device description files
Device history
Device locking, status
Device name
Sensor
Transmitter
Device repair
Device revision
Device type ID
Device Viewer
DeviceCare
Device description file
Diagnostic behavior
Explanation
Symbols
Diagnostic information
Design, description
DeviceCare
FieldCare139Light emitting diodes133
Local display
Overview 141
Remedial measures
Web browser
Diagnostic list
Diagnostic message
Diagnostics
Symbols
Dimensions
DIP switch
see Write protection switch
Direct access
Direct access code
Disabling write protection
Display
see Local display
Display and operating module DKX001 181
Display area
For operational display
In the navigation view

Connection examples, potential equalization 35, 36

Display values
For locking status
Disposal
Document
Function
Symbols
Document function
Document information
Down pipe

Ε

ECC
Editing view
Input screen
Using operating elements
Electrical connection
Commubox FXA195 (USB) 63
Computer with Web browser (e.g. Internet
Explorer)
Degree of protection
Field Communicator 475
Field Xpert SFX350/SFX370 63
Field Xpert SMT70
Measuring device
Operating tool (e.g. FieldCare, AMS Device
Manager, SIMATIC PDM) 63
Operating tools
Via HART protocol
Via service interface (CDI-RJ45) 64
Via WLAN interface 65
VIATOR Bluetooth modem 63
Web server
WLAN interface
Electromagnetic compatibility
Electronics module
Enabling write protection
Enabling/disabling the keypad lock
Endress+Hauser services
Maintenance
Repair
Environment
Storage temperature
Vibration- and shock-resistance
Error messages
see Diagnostic messages
Event list
Event logbook
Ex approval
Extended order code Sensor
Sensor 17 Transmitter 16
Exterior cleaning
F
FDA 185
Field Communicator
Function
Field Communicator 475

Field of application	
Residual risks	10
Field Xpert	
Function	66
Field Xpert SFX350	66
FieldCare	66
Device description file	
Establishing a connection	67
Function	66
User interface	68
5	147
Firmware	
Release date	
Version	
Firmware history	
	179
Flow direction	
Flow limit	
Function check	75
Function range	
Field Xpert	66
Function scope	
AMS Device Manager	
Field Communicator	69
Field Communicator 475	69
SIMATIC PDM	69
Functional safety (SIL)	185
Functions	
see Parameters	
C	
G	170
-	170
Galvanic isolation	170
Galvanic isolation	
Galvanic isolation Image: Constraint of the second secon	119
Galvanic isolation Image: Constraint of the second secon	119
Galvanic isolation Image: Constraint of the second secon	119 186
Galvanic isolation	119
Galvanic isolation	119 186 94
Galvanic isolation	119 186 94 70
Galvanic isolation	119 186 94 70
Galvanic isolation	119 186 94 70 70
Galvanic isolation	119 186 94 70 70 54
Galvanic isolation	119 186 94 70 70 54 54
Galvanic isolation	119 186 94 70 70 54 54 54
Galvanic isolation	119 186 94 70 70 54 54 54
Galvanic isolation	119 186 94 70 70 54 54 54
Galvanic isolation Image: Setting settin	119 186 94 70 70 54 54 111
Galvanic isolation I H Hardware write protection HART certification I HART input I Settings I Identifying the measuring device I	119 186 94 70 70 54 54 111
Galvanic isolation Image: Setting settin	119 186 94 70 70 54 54 111
Galvanic isolation I H Hardware write protection HART certification I HART input I Settings I Identifying the measuring device I	119 186 94 70 70 54 54 111 15 15
Galvanic isolation I H Hardware write protection HART certification I HART input Settings HART protocol Device variables Measured variables Measured variables Help text Calling up Closing Explanation HistoROM I Identifying the measuring device Incoming acceptance Influence Ambient temperature Ambient temperature Inlet runs	119 186 94 70 70 54 54 54 111 15 15 15 123 24
Galvanic isolation I H Hardware write protection HART certification I HART input Settings HART protocol Device variables Measured variables Measured variables Help text Calling up Closing Explanation HistoROM I Identifying the measuring device Incoming acceptance Influence Ambient temperature Ambient temperature Inlet runs	119 186 94 70 70 54 54 111 15 15
Galvanic isolation I H Hardware write protection HART certification I HART input Settings Settings I HART protocol Device variables Measured variables Measured variables Help text Calling up Closing Explanation HistoROM I I Identifying the measuring device Incoming acceptance Influence Ambient temperature Inlet runs Input Inspection	119 186 94 70 70 54 54 111 15 15 15 15 173 24 160
Galvanic isolation I H Hardware write protection HART certification HART certification HART input Settings Settings HART protocol Device variables Measured variables Measured variables Measured variables Help text Calling up Closing Explanation HistoROM I I Identifying the measuring device Incoming acceptance Influence Ambient temperature Inspection Installation Installation	119 186 94 70 70 54 54 54 111 15 15 15 15 173 24 160 28
Galvanic isolation I H Hardware write protection HART certification I HART input Settings Settings I HART protocol Device variables Measured variables Measured variables Help text Calling up Closing Explanation HistoROM I I Identifying the measuring device Incoming acceptance Influence Ambient temperature Inlet runs Input Inspection	119 186 94 70 70 54 54 54 111 15 15 15 173 24 160 28 15

Installation	conditions
motanation	Contaitions

Dimensions	25
Partially filled pipe	21
System pressure	
Vibrations	25
Intended use	. 9
Interior cleaning	.74

L

Languages, operation options	0
Line recorder	7
Local display	0
Navigation view	7
see Diagnostic message	
see In alarm condition	
see Operational display	
Text editor	9
Low flow cut off 16	9

Μ

Main electronics module
Maintenance tasks
Replacing seals
Managing the device configuration
Manufacturer ID
Materials
Maximum measured error
Measured values
Calculated
Measured
see Process variables
Measuring and test equipment
Measuring device
Configuration
Conversion
Disposal
Integrating via communication protocol 70
Mounting the sensor
Cleaning with pigs
Preparing for electrical connection
Preparing for mounting
Removing
Repairs
Structure
Switching on
Measuring principle 160
Measuring range 160
Measuring system
Measuring tube specification
Mechanical load 174
Medium temperature range
Menu
Diagnostics
Setup
Menus
For measuring device configuration
For specific settings
Mounting

Mounting dimensions see Dimensions
Mounting location
Mounting preparations
Mounting requirements
Adapters
Down pipe
Inlet and outlet runs
Mounting location
Orientation
Mounting tool

Ν

Nameplate	
Sensor	17
Transmitter	16
Navigation path (navigation view)	47
Navigation view	
In the submenu	47
In the wizard	47
Numeric editor	49

0

Ρ

F
Packaging disposal
Parameter
Changing
Entering values or text
Parameter settings
Administration (Submenu)
Advanced setup (Submenu) 103
Burst configuration 1 to n (Submenu) 72
Configuration (Submenu)
Configuration backup (Submenu) 111
Configure flow damping (Wizard) 99
Current input
Current input (Wizard)

Current input 1 to n (Submenu)
Current output
Current output (Wizard)
Data logging (Submenu)
Define access code (Wizard)
Device information (Submenu)
Diagnostics (Menu)
Display (Submenu)
Display (Wizard)
Double pulse output
Double pulse output (Submenu)
Double pulse output (Wizard)
Electrode cleaning cycle (Submenu) 109
Empty pipe detection (Wizard)
I/O configuration
I/O configuration (Submenu) 79
Input (Submenu)
Low flow cut off (Wizard)
Process variables (Submenu)
Pulse/frequency/switch output 85
Pulse/frequency/switch output (Wizard) 85, 86, 89
Pulse/frequency/switch output 1 to n (Submenu) 124
Relay output
Relay output 1 to n (Submenu)
Relay output 1 to n (Wizard)
Reset access code (Submenu)
Sensor adjustment (Submenu) 103
Setup (Menu)
Simulation (Submenu)
Status input
Status input 1 to n (Submenu)
Status input 1 to n (Wizard) 80
System units (Submenu)
Totalizer (Submenu)
Totalizer 1 to n (Submenu)
Totalizer handling (Submenu)
Value current output 1 to n (Submenu) 124
Web server (Submenu) 62
WLAN settings (Wizard) 110
Partially filled pipe
Performance characteristics
Pharmaceutical compatibility
Post-connection check (checklist)
Post-installation check (checklist)
Potential equalization
Power consumption
Power supply failure
Pressure Equipment Directive
Pressure loss
Pressure tightness
Pressure-temperature ratings 175 Process conditions
Conductivity
Flow limit
Flow Inflit 176 Fluid temperature 175
Find temperature 175 Pressure loss 176
Pressure tightness
Process connections
Product safety

Protecting parameter settings
R
Radio approval186RCM mark185Read access55Reading measured values120Recalibration153Reference operating conditions171Registered trademarksRemedial measuresCalling up137Closing137Remote operation181RepairNotes154
Repair of a device 154 Repeatability 173
Replacement
Device components154Replacing seals153Requirements for personnel9Return154
S
Safety9Sanitary compatibility185Serial number16, 17Setting the operating language75Settings
Adapting the measuring device to the process
conditions 126 Administration 113 Advanced display configurations 105 Current input 80 Current output 82 Double pulse output 98 Electrode cleaning circuit (ECC) 109 Empty pipe detection (EPD) 94 HART input 94 I/O configuration 79 Local display 91 Low flow cut off 93 Managing the device configuration 111 Operating language 75 Pulse output 85 Pulse/frequency/switch output 85 Pulse/frequency/switch output 97 Resetting the device 149 Resetting the device 149 Resetting the totalizer 126 Sensor adjustment 103 Simulation 114 Status input 89 System units 77 Tag name 77 Totalizer reset 126 WLAN 110

Signal on alarm 16 SIL (functional safety) 18 SIMATIC DDM 6	27
SIMATIC PDM	
Function	
Software release	0
Spare part	64
Spare parts	64
	37
Special mounting instructions	
Hygienic compatibility	6
Standards and guidelines	
Status area	,0
	6
For operational display	
In the navigation view	
Status signals	
Sterilization in place (SIP) 17	
Storage concept	
Storage conditions	
Storage temperature	9
Storage temperature range 17	'3
Structure	
Measuring device	4
Operating menu	
Submenu	
Administration	4
Advanced setup	
Burst configuration 1 to n	
Configuration	
Configuration backup	
	2
Current input 1 to n	3
Data logging	7
Data logging 12 Device information 14	27 19
Data logging12Device information14Display10	17 19 15
Data logging12Device information14Display10Double pulse output12	17 19 15 15
Data logging12Device information14Display10Double pulse output12Electrode cleaning cycle10	17 19 15 15 19
Data logging12Device information14Display10Double pulse output12	17 19 15 15 19
Data logging12Device information14Display10Double pulse output12Electrode cleaning cycle10	17 19 15 15 19 16
Data logging12Device information14Display10Double pulse output12Electrode cleaning cycle10Event list14HART input9	17 19 15 15 19 16
Data logging12Device information14Display10Double pulse output12Electrode cleaning cycle10Event list14HART input9I/O configuration7	17 19 15 15 19 16 14
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9	27 19 15 19 15 19 16 14 19 16 14 19 16
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12	27 19 15 19 15 19 16 14 19 16 12 19 16 12 19 10 12 19 10 12 19 10 10 10 10 10 10 10 10 10 10 10 10 10
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12 Output values 12	279559649623
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12 Output values 12 Overview 4	27 9 5 5 9 6 4 9 6 2 3 5
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12 Output values 12 Overview 4 Process variables 12	27 9 15 19 60 4 79 16 2 3 5 10 10 10 10 10 10 10 10 10 10 10 10 10 10 1
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12 Overview 4 Process variables 12 Pulse/frequency/switch output 1 to n 12	79559649623504
Data logging 12 Device information 14 Display 10 Double pulse output 12 Electrode cleaning cycle 10 Event list 14 HART input 9 I/O configuration 7 Input 9 Input values 12 Overview 4 Process variables 12 Pulse/frequency/switch output 1 to n 12 Relay output 1 to n 12	795596496235045
Data logging	7955964962350454
Data logging	79559649623504543
Data logging	795596496235045434
Data logging	7955964962350454343
Data logging	79559649623504543437
Data logging	795596496235045434372
Data logging	7955964962350454343723
Data logging	79559649623504543437236
Data logging	79559649623504543437236
Data logging	79559649623504543437236
Data logging	7955964962350454343723642
Data logging	79559649623504543437236428

For measurement channel number 46
For menus
For parameters
For status signal
For submenu 48
For wizard
In the status area of the local display
Input screen
Operating elements
System design
Measuring system
see Measuring device design
System integration
System pressure
y
Т
Technical data, overview
Temperature measurement response time 173
Temperature range
Ambient temperature range for display 180
Storage temperature
Terminal assignment
Terminals
Text editor
Tool
For mounting
Transport
Tool tip
see Help text
Tools
Electrical connection
Totalizer
Configuration
Transmitter
Turning the display module
Turning the housing
Transporting the measuring device 19
Troubleshooting
General
TSE/BSE Certificate of Suitability
Turning the display module
Turning the electronics housing
see Turning the transmitter housing
Turning the transmitter housing
U
UKCA marking
Use of the measuring device
Borderline cases
Incorrect use

Controlling data entries 50

Symbols

see Intended use

User interface Current diagnostic event
V Version data for the device
Vibration- and shock-resistance
W
W@M 153, 154
W@M Device Viewer
Weight
Transport (notes)
Wizard
Configure flow damping
Current input
Current output
Define access code
Display
Double pulse output
Empty pipe detection
Low flow cut off
Pulse/frequency/switch output 85, 86, 89
Relay output 1 to n
Status input 1 to n
WLAN settings
WLAN settings 110 Workplace safety 10
Workplace safety10Write access55
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com

