71574906 2022-08-01 Valid as of version 01.06.zz (Device firmware)

BA01399D/06/EN/06.22-00

Operating Instructions **Proline Promag P 500**

Electromagnetic flowmeter HART







- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	About this document
1.1 1.2 1.3 1.4	Document function6Symbols61.2.1Safety symbols61.2.2Electrical symbols61.2.3Communication-specific symbols61.2.4Tool symbols71.2.5Symbols for certain types of information71.2.6Symbols in graphics7Documentation81.3.1Document function8Registered trademarks8
2	Safety instructions
2.1 2.2 2.3 2.4 2.5 2.6 2.7	Requirements for the personnel9Intended use9Workplace safety10Operational safety10Product safety10IT security10IT security11Device-specific IT security112.7.1Protecting access via hardware write protectionprotecting access via a password112.7.2Protecting access via a password112.7.3Access via OPC-UA132.7.4Access via service interface (CDI- RJ45)RJ45)13
3	Product description 14
3.1	Product design 14 3.1.1 Proline 500 – digital 14 3.1.2 Proline 500 15
4	Incoming acceptance and product
	identification 16
4.1 4.2	Incoming acceptance16Product identification164.2.1Transmitter nameplate174.2.2Sensor nameplate194.2.3Symbols on measuring device20
5	Storage and transport 21
5.1 5.2	Storage conditions21Transporting the product215.2.1Measuring devices without lifting lugs21
5.3	5.2.2Measuring devices with lifting lugs

6	Moun	ting	22
6.1	Mounti	ng requirements	22
	6.1.1	Mounting position	22
	6.1.2	Environment and process	
		requirements	28
	6.1.3	Special mounting instructions	30
6.2	Mounti	ng the measuring device	31
	6.2.1	Required tools	31
	6.2.2	Preparing the measuring device	31
	6.2.3	Mounting the sensor	32
	6.2.4	Mounting the transmitter housing:	
		Proline 500 – digital	36
	6.2.5	Mounting the transmitter housing:	
		Proline 500	37
	6.2.6	Turning the transmitter housing:	
		Proline 500	39
	6.2.7	Turning the display module: Proline	
		500	39
6.3	Post-in	stallation check	40
7	Electr	ical connection	41
7.1		al safety	41
7.2		ting requirements	41
7.2	7.2.1	Required tools	41
	7.2.2	Requirements for connecting cable	41
	7.2.3	Terminal assignment	45
	7.2.4	Preparing the measuring device	45
	7.2.5	Preparing the connecting cable:	17
	1.2.9	Proline 500 – digital	47
	7.2.6	Preparing the connecting cable:	17
	7.2.0	Proline 500	47
7.3	Connec	ting the measuring device: Proline	17
1.5		ligital	49
	7.3.1	Connecting the connecting cable	49
	7.3.2	Connecting the signal cable and the	12
	/ 1912	supply voltage cable	52
7.4	Connec	ting the measuring device: Proline	20
	500		54
	7.4.1	Connecting the connecting cable	54
	7.4.2	Connecting the signal cable and the	
		supply voltage cable	57
7.5	Ensurin	g potential equalization	59
	7.5.1	Introduction	59
	7.5.2	Connection examples for standard	
		situations	60
	7.5.3	Connection example with the	
		potential of medium not equal to	
		protective ground without the	
		"Floating measurement" option	61
	7.5.4	Connection examples with the	
		potential of medium not equal to	
		protective ground with the "Floating	
		measurement" option	62
7.6	Special	connection instructions	
	7.6.1	Connection examples	

7.7	Ensuring the degree of protection
7.8	Post-connection check
8	Operation options 69
8.1	Overview of operation options
8.2	Structure and function of the operating
0.2	menu
	8.2.1 Structure of the operating menu 70
	8.2.2 Operating philosophy
8.3	Access to the operating menu via the local
	display
	8.3.1 Operational display
	8.3.2 Navigation view
	8.3.3 Editing view
	8.3.4 Operating elements
	8.3.5 Opening the context menu
	8.3.6 Navigating and selecting from list 79
	8.3.7 Calling the parameter directly 79
	8.3.8 Calling up help text 80
	8.3.9 Changing the parameters
	8.3.10 User roles and related access
	authorization 81
	8.3.11 Disabling write protection via access
	code
	8.3.12 Enabling and disabling the keypad
	lock
8.4	Access to the operating menu via the Web
	browser
	8.4.1 Function scope 82
	8.4.2 Requirements 83
	8.4.3 Establishing a connection 84
	8.4.4 Logging on 86
	8.4.5 User interface 87
	8.4.6 Disabling the Web server
~ -	8.4.7 Logging out 88
8.5	Access to the operating menu via the
	operating tool
	8.5.1 Connecting the operating tool 89
	8.5.2 Field Xpert SFX350, SFX370 93
	8.5.3 FieldCare
	8.5.4 DeviceCare
	8.5.5 AMS Device Manager
	8.5.6 SIMATIC PDM
	8.5.7 Field Communicator 475 95
0	
9	System integration
9.1	Overview of device description files
	9.1.1 Current version data for the device 96
	9.1.2 Operating tools
9.2	Measured variables via HART protocol 96
9.3	Other settings
10	Commissioning 100
10.1	Function check 100
10.2	Switching on the measuring device 100
10.3	Setting the operating language 100

10.4	Configuring the measuring device	100
	10.4.1 Defining the tag name	102
	10.4.2 Setting the system units	102
	10.4.3 Displaying the I/O configuration	104
	10.4.4 Configuring the status input	105
	10.4.5 Configuring the current input	106
	10.4.6 Configuring the current output	107
	10.4.7 Configuring the pulse/frequency/	
	switch output	110
	10.4.8 Configuring the local display	116
	10.4.9 Configuring the low flow cut off	118
	10.4.10 Configuring empty pipe detection	119
	10.4.11 Configuring the HART input	119
	10.4.12 Configuring the relay output	122
	10.4.13 Configuring the double pulse output	123
	10.4.14 Configuring flow damping	124
10.5	Advanced settings	127
	10.5.1 Using the parameter to enter the	
	access code	128
	10.5.2 Carrying out a sensor adjustment	128
	10.5.3 Configuring the totalizer	128
	10.5.4 Carrying out additional display	
	configurations	130
	10.5.5 Performing electrode cleaning	134
	10.5.6 WLAN configuration	135
	10.5.7 Configuration management	136
	10.5.8 Using parameters for device	
	administration	138
10.6	Simulation	139
10.7	Protecting settings from unauthorized access	142
	10.7.1 Write protection via access code	4 / 0
		142
	10.7.2 Write protection via write protection	142
		142 144
	10.7.2 Write protection via write protection switch	144
11	10.7.2 Write protection via write protection switch	
11 11.1	10.7.2 Write protection via write protection switch	144
	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status 	144 146 146
11.1	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language 	144 146 146
11.1 11.2	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display 	144 146 146 146
11.1 11.2 11.3	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language 	144 146 146 146 146
11.1 11.2 11.3	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 	144 146 146 146 146 146
11.1 11.2 11.3	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 	144 146 146 146 146 146 146
11.1 11.2 11.3	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 	144 146 146 146 146 146 146 147
11.1 11.2 11.3	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 	144 146 146 146 146 146 146 147 148
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values 	144 146 146 146 146 146 146 147 148
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process 	144 146 146 146 146 146 146 147 148 149
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions 	144 146 146 146 146 146 146 147 148 149 151
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions Performing a totalizer reset 	144 146 146 146 146 146 146 147 148 149 151
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions Performing a totalizer reset 11.6.1 Function scope of "Control Totalizer" 	144 146 146 146 146 146 147 148 149 151 151
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions Performing a totalizer reset 11.6.1 Function scope of "Control Totalizer" parameter 	144 146 146 146 146 146 147 148 149 151 151
11.1 11.2 11.3 11.4	 10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Configuring the display Reading measured values 11.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions Performing a totalizer reset 11.6.1 Function scope of "Control Totalizer" parameter 11.6.2 Function scope of the "Reset all 	144 146 146 146 146 146 147 148 149 151 151 152
11.1 11.2 11.3 11.4 11.5 11.6 11.7	10.7.2 Write protection via write protection switch Operation Reading off the device locking status Adjusting the operating language Adjusting the operating language Configuring the display Reading measured values I1.4.1 "Process variables" submenu 11.4.2 "Totalizer" submenu 11.4.3 "Input values" submenu 11.4.4 Output values Adapting the measuring device to the process conditions Performing a totalizer reset 11.6.1 Function scope of "Control Totalizer" parameter 11.6.2 Function scope of the "Reset all totalizers" parameter Show data logging Show data logging	144 146 146 146 146 147 148 149 151 151 152 152 153
11.1 11.2 11.3 11.4 11.5 11.6 11.7 12	 10.7.2 Write protection via write protection switch	144 146 146 146 146 146 147 148 149 151 151 151 152 152 153 156
11.1 11.2 11.3 11.4 11.5 11.6 11.7 12 12.1	 10.7.2 Write protection via write protection switch	144 146 146 146 146 147 148 149 151 151 152 152 153
11.1 11.2 11.3 11.4 11.5 11.6 11.7 12	 10.7.2 Write protection via write protection switch	144 146 146 146 146 147 148 149 151 151 152 152 153 156
11.1 11.2 11.3 11.4 11.5 11.6 11.7 12 12.1	 10.7.2 Write protection via write protection switch	144 146 146 146 146 146 147 148 149 151 151 152 152 153 156 158
11.1 11.2 11.3 11.4 11.5 11.6 11.7 12 12.1	 10.7.2 Write protection via write protection switch	144 146 146 146 146 146 147 148 149 151 151 152 152 153 156 158 158 158

12.3	Diagnostic information on local display	162
	12.3.1 Diagnostic message	162
	12.3.2 Calling up remedial measures	164
12.4	Diagnostic information in the Web browser .	164
	12.4.1 Diagnostic options	164
	12.4.2 Calling up remedy information	165
12.5	Diagnostic information in FieldCare or	
	DeviceCare	166
	12.5.1 Diagnostic options	166
17.6	12.5.2 Calling up remedy information	167 167
12.6	Adapting the diagnostic information	167
	12.6.1 Adapting the diagnostic behavior12.6.2 Adapting the status signal	167
12.7	Overview of diagnostic information	168
12.7	Pending diagnostic events	172
12.9	Diagnostic list	173
12.10	Event logbook	173
10110	12.10.1 Reading out the event logbook	173
	12.10.2 Filtering the event logbook	174
	12.10.3 Overview of information events	174
12.11	Resetting the measuring device	176
	12.11.1 Function scope of "Device reset"	
	parameter	176
12.12	Device information	176
	Firmware history	178
12.14	Device history and compatibility	179
13	Maintonanco	100
	Maintenance	180
13.1	Maintonanao tagla	
17.1	Maintenance tasks	180
17.1	13.1.1 Exterior cleaning	180
	13.1.1 Exterior cleaning13.1.2 Interior cleaning	180 180
13.2	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipment	180 180 180
	13.1.1 Exterior cleaning13.1.2 Interior cleaning	180 180
13.2	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser services	180 180 180
13.2 13.3 14	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepair	180 180 180 180 181
13.2 13.3	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information	180 180 180 180 181
13.2 13.3 14	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept	180 180 180 180 181 181 181
13.2 13.3 14 14.1	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversion	180 180 180 180 181 181 181 181
13.2 13.3 14 14.1 14.2	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare parts	180 180 180 180 181 181 181
13.2 13.3 14 14.1	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversion	180 180 180 180 181 181 181 181 181
13.2 13.3 14 14.1 14.2 14.3	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser services	180 180 180 180 181 181 181 181 181 181
13.2 13.3 14 14.1 14.2 14.3 14.4	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturn	180 180 180 180 181 181 181 181 181 181 181
13.2 13.3 14 14.1 14.2 14.3 14.4	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal	180 180 180 180 181 181 181 181 181 181 181 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5	13.1.1Exterior cleaning13.1.2Interior cleaningMeasuring and test equipmentEndress+Hauser servicesEndress+Hauser servicesEndress+Hauser servicesGeneral information14.1.1Repair and conversion concept14.1.2Notes for repair and conversionSpare partsEndress+Hauser servicesEndress+Hauser servicesBipposal14.5.1Removing the measuring device14.5.2Disposing of the measuring device14.5.2	180 180 180 180 181 181 181 181 181 181 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring deviceAccessories	180 180 180 180 181 181 181 181 181 181 181 182 182 182 183
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring deviceAccessoriesDevice-specific accessories	180 180 180 180 181 181 181 181 181 181 181 182 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesEndress+Hauser servicesGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device14.5.1 For the transmitter	180 180 180 181 181 181 181 181 181 181 182 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1	13.1.1Exterior cleaning13.1.2Interior cleaningMeasuring and test equipmentEndress+Hauser servicesEndress+Hauser servicesEndress+Hauser servicesGeneral information14.1.1Repairand conversion concept14.1.1Repair and conversion concept14.1.2Notes for repair and conversionSpare partsEndress+Hauser servicesEndress+Hauser servicesReturnDisposal14.5.114.5.1Removing the measuring device14.5.2Disposing of the measuring device14.5.3Device-specific accessories15.1.1For the transmitter15.1.2For the sensor	180 180 180 180 181 181 181 181 181 181 182 182 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device14.5.3 Device-specific accessories15.1.1 For the transmitter15.1.2 For the sensorCommunication-specific accessories	180 180 180 180 181 181 181 181 181 181 182 182 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1 15.2 15.3	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device14.5.3 For the transmitter15.1.1 For the transmitter15.1.2 For the sensorCommunication-specific accessoriesService-specific accessoriesService-specific accessories	180 180 180 180 181 181 181 181 181 181 182 182 182 182 183 183 183 184 184
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device14.5.3 Device-specific accessories15.1.1 For the transmitter15.1.2 For the sensorCommunication-specific accessories	180 180 180 180 181 181 181 181 181 181 182 182 182 182 182
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1 15.2 15.3	13.1.1 Exterior cleaning13.1.2 Interior cleaningMeasuring and test equipmentEndress+Hauser servicesRepairGeneral information14.1.1 Repair and conversion concept14.1.2 Notes for repair and conversionSpare partsEndress+Hauser servicesReturnDisposal14.5.1 Removing the measuring device14.5.2 Disposing of the measuring device14.5.3 For the transmitter15.1.1 For the transmitter15.1.2 For the sensorCommunication-specific accessoriesService-specific accessoriesService-specific accessories	180 180 180 180 181 181 181 181 181 181 182 182 182 182 183 183 183 184 184
13.2 13.3 14 14.1 14.2 14.3 14.4 14.5 15 15.1 15.2 15.3 15.4	13.1.1 Exterior cleaning 13.1.2 Interior cleaning Measuring and test equipment Endress+Hauser services Endress+Hauser services Endress+Hauser services General information 14.1.1 Repair General information 14.1.1 Repair and conversion concept 14.1.2 Notes for repair and conversion Spare parts Endress+Hauser services Endress+Hauser services Endress+Hauser services Return Disposal 14.5.1 Removing the measuring device 14.5.2 Disposing of the measuring device 14.5.2 Disposing of the measuring device 15.1.1 For the transmitter 15.1.2 For the sensor Communication-specific accessories Service-specific accessories System components System components	180 180 180 180 181 181 181 181 181 181 182 182 182 182 183 183 183 183 184 185 186

16.3	Input	187
16.4	Output	191
16.5	Power supply	197
16.6	Performance characteristics	198
16.7	Installation	201
16.8	Environment	201
16.9	Process	203
16.10	Mechanical construction	206
16.11	Operability	211
16.12	Certificates and approvals	215
	Application packages	217
16.14	Accessories	218
16.15	Supplementary documentation	218
		_

Index 221

1 About this document

1.1 Document function

These Operating Instructions contain all the information required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to installation, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

A DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning
	Direct current
\sim	Alternating current
\sim	Direct current and alternating current
<u>+</u>	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Potential equalization connection (PE: protective earth)Ground terminals that must be connected to ground prior to establishing any other connections.
	The ground terminals are located on the interior and exterior of the device:Interior ground terminal: potential equalization is connected to the supply network.Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Communication-specific symbols

Symbol	Meaning
((:-	Wireless Local Area Network (WLAN) Communication via a wireless, local network.
	LED Light emitting diode is off.

Symbol	Meaning
-X-	LED Light emitting diode is on.
	LED Light emitting diode is flashing.

1.2.4 Tool symbols

Symbol	Meaning
	Torx screwdriver
•	Phillips head screwdriver
Ń	Open-ended wrench

1.2.5 Symbols for certain types of information

Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
Ĩ	Reference to documentation
	Reference to page
	Reference to graphic
►	Notice or individual step to be observed
1., 2., 3	Series of steps
L.	Result of a step
?	Help in the event of a problem
	Visual inspection

1.2.6 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1., 2., 3.,	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
EX	Hazardous area

Symbol	Meaning
×	Safe area (non-hazardous area)
≈⇒	Flow direction

1.3 Documentation

For an overview of the scope of the associated Technical Documentation, refer to the following:

- *W@M Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code on the nameplate

1.3.1 Document function

Document type	Purpose and content of the document
Technical Information (TI)	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions (KA)	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Operating Instructions (BA)	Your reference guide These Operating Instructions contain all the information that is required in the various life cycle phases of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning, through to troubleshooting, maintenance and disposal.
Description of Device Parameters (GP)	Reference for your parameters The document provides a detailed explanation of each individual parameter. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.
Safety Instructions (XA)	Depending on the approval, safety instructions for electrical equipment in hazardous areas are also supplied with the device. They are an integral part of the Operating Instructions. The nameplate indicates which Safety Instructions (XA) apply to the device in question.
Supplementary device-dependent documentation	Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

2 Safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the flow measurement of liquids with a minimum conductivity of 5 μ S/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are marked accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- Keep within the specified pressure and temperature range.
- Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- Use the measuring device only for media to which the process-wetted materials are sufficiently resistant.
- ► If the ambient temperature of the measuring device is outside the atmospheric temperature, it is absolutely essential to comply with the relevant basic conditions as specified in the device documentation → <a> 8.
- Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage due to corrosive or abrasive fluids and ambient conditions!

- Verify the compatibility of the process fluid with the sensor material.
- Ensure the resistance of all fluid-wetted materials in the process.
- Keep within the specified pressure and temperature range.

NOTICE

Verification for borderline cases:

For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

WARNING

If the temperature of the media or electronics unit is high or low, this may cause the surfaces of the device to become hot or cold. This poses a risk of burns or frostbite!

► In the case of hot or cold medium temperatures, install appropriate protection against contact.

2.3 Workplace safety

When working on and with the device:

• Wear the required personal protective equipment as per national regulations.

2.4 Operational safety

Risk of injury!

- Operate the device only if it is in proper technical condition, free from errors and faults.
- ► The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers!

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

Furthermore, the device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards.

By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.

Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com

2.6 IT security

Our warranty is valid only if the product is installed and used as described in the Operating Instructions. The product is equipped with security mechanisms to protect it against any inadvertent changes to the settings.

IT security measures, which provide additional protection for the product and associated data transfer, must be implemented by the operators themselves in line with their security standards.

2.7 Device-specific IT security

The device offers a range of specific functions to support protective measures on the operator's side. These functions can be configured by the user and guarantee greater in-operation safety if used correctly. An overview of the most important functions is provided in the following section:

Function/interface	Factory setting	Recommendation
Write protection via hardware write protection switch $\rightarrow \textcircled{B} 11$	Not enabled	On an individual basis following risk assessment
Access code (also applies for Web server login or FieldCare connection) $\rightarrow {}12$	Not enabled (0000)	Assign a customized access code during commissioning
WLAN (order option in display module)	Enabled	On an individual basis following risk assessment
WLAN security mode	Enabled (WPA2- PSK)	Do not change
WLAN passphrase (password) → 🗎 12	Serial number	Assign a customized WLAN passphrase during commissioning
WLAN mode	Access point	On an individual basis following risk assessment
Web server $\rightarrow \square 12$	Enabled	On an individual basis following risk assessment
CDI-RJ45 service interface $\rightarrow \square$ 13	-	On an individual basis following risk assessment

2.7.1 Protecting access via hardware write protection

Write access to the parameters of the device via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be disabled via a write protection switch (DIP switch on the main electronics module). When hardware write protection is enabled, only read access to the parameters is possible.

Hardware write protection is disabled when the device is delivered $\rightarrow \square$ 144.

2.7.2 Protecting access via a password

Different passwords are available to protect write access to the device parameters or access to the device via the WLAN interface.

User-specific access code

Protect write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare). Access authorization is clearly regulated through the use of a user-specific access code.

- WLAN passphrase The network key protects a connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface which can be ordered as an option.
- Infrastructure mode

When the device is operated in infrastructure mode, the WLAN passphrase corresponds to the WLAN passphrase configured on the operator side.

User-specific access code

Write access to the device parameters via the local display, Web browser or operating tool (e.g. FieldCare, DeviceCare) can be protected by the modifiable, user-specific access code ($\rightarrow \square$ 142).

When the device is delivered, the device does not have an access code and is equivalent to 0000 (open).

WLAN passphrase: Operation as WLAN access point

A connection between an operating unit (e.g. notebook or tablet) and the device via the WLAN interface ($\rightarrow \bowtie$ 91), which can be ordered as an optional extra, is protected by the network key. The WLAN authentication of the network key complies with the IEEE 802.11 standard.

When the device is delivered, the network key is pre-defined depending on the device. It can be changed via the **WLAN settings** submenu in the **WLAN passphrase** parameter ($\rightarrow \square$ 136).

Infrastructure mode

A connection between the device and WLAN access point is protected by means of an SSID and passphrase on the system side. Please contact the relevant system administrator for access.

General notes on the use of passwords

- The access code and network key supplied with the device should be changed during commissioning.
- Follow the general rules for generating a secure password when defining and managing the access code or network key.
- The user is responsible for the management and careful handling of the access code and network key.
- For information on configuring the access code or on what to do if you lose the password, for example, see the "Write protection via access code" section →
 ¹⁴²
 ¹⁴²

2.7.3 Access via Web server

The device can be operated and configured via a Web browser with the integrated Web server ($\rightarrow \cong 82$). The connection is via the service interface (CDI-RJ45) or the WLAN interface.

The Web server is enabled when the device is delivered. The Web server can be disabled if necessary (e.g. after commissioning) via the **Web server functionality** parameter.

The device and status information can be hidden on the login page. This prevents unauthorized access to the information.

F F

For detailed information on device parameters, see: The "Description of Device Parameters" document $\rightarrow \bigoplus 219$.

2.7.4 Access via OPC-UA

The device can communicate with OPC UA clients using the "OPC UA Server" application package.

The OPC UA server integrated in the device can be accessed via the WLAN access point using the WLAN interface - which can be ordered as an optional extra - or the service interface (CDI- RJ45) via Ethernet network. Access rights and authorization as per separate configuration.

The following Security Modes are supported as per the OPC UA Specification (IEC 62541):

- None
- Basic128Rsa15 signed
- Basic128Rsa15 signed and encrypted

2.7.5 Access via service interface (CDI-RJ45)

The device can be connected to a network via the service interface (CDI-RJ45). Device-specific functions guarantee the secure operation of the device in a network.

The use of relevant industrial standards and guidelines that have been defined by national and international safety committees, such as IEC/ISA62443 or the IEEE, is recommended. This includes organizational security measures such as the assignment of access authorization as well as technical measures such as network segmentation.

Transmitters with an Ex de approval may not be connected via the service interface (CDI-RJ45)!

Order code for "Approval transmitter + sensor", options (Ex de): BA, BB, C1, C2, GA, GB, MA, MB, NA, NB

3 Product description

The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.

3.1 Product design

Two versions of the transmitter are available.

3.1.1 Proline 500 – digital


Signal transmission: digital

Order code for "Integrated ISEM electronics", option A "Sensor"

For use in applications not required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the sensor, the device is ideal: For simple transmitter replacement.

- A standard cable can be used as the connecting cable.
- Not sensitive to external EMC interference.



■ 1 Important components of a measuring device

- *1 Electronics compartment cover*
- 2 Display module
- 3 Transmitter housing
- 4 Sensor connection housing with integrated ISEM electronics: connecting cable connection
- 5 Sensor


3.1.2 Proline 500

Signal transmission: analog Order code for "Integrated ISEM electronics", option **B** "Transmitter"

For use in applications required to meet special requirements due to ambient or operating conditions.

As the electronics are located in the transmitter, the device is ideal in the event of: • Sensor operation in underground installations.


Permanent sensor immersion in water.



- Important components of a measuring device
- 1 Connection compartment cover
- 2 Display module
- 3 Transmitter housing with integrated ISEM electronics
- 4 Electronics compartment cover
- 5 Sensor
- 6 Sensor connection housing: connecting cable connection
- 7 Connection compartment cover: connecting cable connection

4 Incoming acceptance and product identification

4.1 Incoming acceptance



4.2 Product identification

The following options are available for identification of the device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial numbers from the nameplates in the *Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial numbers from the nameplates into the *Endress+Hauser Operations App* or scan the DataMatrix code on the nameplate with the *Endress+Hauser Operations App*: all the information about the device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" and "Supplementary device-dependent documentation"
- The *Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the DataMatrix code on the nameplate.

4.2.1 Transmitter nameplate


Proline 500 – digital



Example of a transmitter nameplate

- 1 Name of the transmitter
- 2 Place of manufacture
- *Space for approvals: use in hazardous areas*
- 4 Degree of protection
- 5 Electrical connection data: available inputs and outputs
- 6 Permitted ambient temperature (T_a)
- 7 2-D matrix code
- 8 Space for approvals and certificates: e.g. CE mark, RCM tick
- 9 Permitted temperature range for cable
- 10 Date of manufacture: year-month
- 11 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 12 Document number of safety-related supplementary documentation
- 13 Space for additional information in the case of special products
- 14 Available inputs and outputs, supply voltage
- 15 Electrical connection data: supply voltage
- 16 Extended order code (Ext. ord. cd.)
- 17 Serial number (Ser. no.)
- 18 Order code


Proline 500



Example of a transmitter nameplate

- 1 Place of manufacture
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Degree of protection
- 7 Space for approvals: use in hazardous areas
- 8 Electrical connection data: available inputs and outputs
- 9 2-D matrix code
- 10 Date of manufacture: year-month
- 11 Document number of safety-related supplementary documentation
- 12 Space for approvals and certificates: e.g. CE mark, RCM tick
- 13 Space for degree of protection of connection and electronics compartment when used in hazardous areas
- 14 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 15 Space for additional information in the case of special products
- 16 Permitted temperature range for cable
- 17 Permitted ambient temperature (T_a)
- 18 Information on cable gland
- 19 Available inputs and outputs, supply voltage
- 20 Electrical connection data: supply voltage

4.2.2 Sensor nameplate



- E 5 Example of sensor nameplate
- 1 Name of the sensor
- 2 Place of manufacture
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Flow; nominal diameter of the sensor; pressure rating; nominal pressure; system pressure; medium temperature range; material of liner and electrodes
- 7 Approval information for explosion protection, Pressure Equipment Directive and degree of protection
- 8 Document number of safety-related supplementary documentation
- 9 2-D matrix code
- 10 Date of manufacture: year-month
- 11 Flow direction
- 12 CE mark, RCM-Tick mark
- 13 Permitted ambient temperature (T_a)



The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury. To determine the nature of the potential hazard and the measures required to avoid it, consult the documentation accompanying the measuring device.
Ĩ	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

4.2.3 Symbols on measuring device

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring pipe.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the liner.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature $\rightarrow \cong 201$

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- Observe the weight specified on the packaging (stick-on label).



5.2.2 Measuring devices with lifting lugs

ACAUTION

Special transportation instructions for devices with lifting lugs

- Only use the lifting lugs fitted on the device or flanges to transport the device.
- The device must always be secured at two lifting lugs at least.


5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

ACAUTION

Risk of damaging the magnetic coil

- If transporting by forklift, do not lift the sensor by the metal casing.
- This would buckle the casing and damage the internal magnetic coils.



5.3 Packaging disposal

All packaging materials are environmentally friendly and 100 % recyclable:

- Outer packaging of device
 - Polymer stretch wrap, complying with EU Directive 2002/95/EC (RoHS)
- Packaging
 - Wooden crate treated in accordance with ISPM 15 standard, confirmed by IPPC logo
 - Cardboard box in accordance with European packaging guideline 94/62EC, recyclability confirmed by Resy symbol
- Carrying and securing materials
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Filler material
- Paper pads


6 Mounting

6.1 Mounting requirements


6.1.1 Mounting position

Mounting location

- Do not install the device at the highest point of the pipe.
- Do not install the device upstream from a free pipe outlet in a down pipe.




The device should ideally be installed in an ascending pipe.



Installation near valves

Install the device in the direction of flow upstream from the valve.




Installation upstream from a down pipe


NOTICE

A

Negative pressure in the measuring pipe can damage the liner!

▶ If installing upstream of down pipes whose length $h \ge 5$ m (16.4 ft): install a siphon with a vent valve downstream of the device.






Vent valve

1

- 2 Pipe siphon
- h Length of down pipe

Installation with partially filled pipes

- Partially filled pipes with a gradient require a drain-type configuration.
- The installation of a cleaning valve is recommended.




Installation near pumps

NOTICE

Negative pressure in the measuring pipe can damage the liner!

- In order to maintain the system pressure, install the device in the flow direction downstream from the pump.
- ▶ Install pulsation dampers if reciprocating, diaphragm or peristaltic pumps are used.



Information on the liner's resistance to partial vacuum

- Information on the measuring system's resistance to vibration and shock ightarrow 🗎 202

Installation of very heavy devices


Support required for nominal diameters of $DN \ge 350 \text{ mm} (14 \text{ in})$.

NOTICE

Damage to the device!

If incorrect support is provided, the sensor housing could buckle and the internal magnetic coils could be damaged.

• Only provide supports at the pipe flanges.




Installation in event of pipe vibrations

A remote version is recommended in the event of strong pipe vibrations.

NOTICE

Pipe vibrations can damage the device!

- Do not expose the device to strong vibrations.
- Support the pipe and fix it in place.
- Support the device and fix it in place.
- Mount the sensor and transmitter separately.



Information on the measuring system's resistance to vibration and shock \rightarrow \cong 202

Orientation


The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orien	Recommendation	
Vertical orientation		
	A0015591	
Horizontal orientation, transmitter at top	A0015589	
Horizontal orientation, transmitter at bottom		 ✓ ✓ ^{2) 3)} ✓ ⁴⁾
Horizontal orientation, transmitter at side	A0015592	

- 1) Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- To prevent the electronics from overheating in the event of strong heat formation (e.g. CIP or SIP cleaning process), install the device with the transmitter part pointing downwards.
- 4) When the empty pipe detection function is switched on, empty pipe detection only works if the transmitter housing is pointing upwards.


Vertical

Optimum for self-emptying pipe systems and for use in conjunction with empty pipe detection.



Horizontal

- Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the measuring electrodes by entrained air bubbles.
- Empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.



- 1 EPD electrode for empty pipe detection
- 2 Measuring electrodes for signal detection
- 3 Reference electrode for potential equalization

Measuring devices with tantalum or platinum electrodes can be ordered without an EPD electrode. In this case, empty pipe detection is performed via the measuring electrodes.


Inlet and outlet runs


Installation with inlet and outlet runs

Installation with elbows, pumps or valves

To avoid a vacuum and to maintain the specified level of accuracy, if possible install the device upstream from assemblies that produce turbulence (e.g. valves, T-sections) and downstream from pumps.

Maintain straight, unimpeded inlet and outlet runs.





Installation without inlet and outlet runs

Depending on the device design and installation location, the inlet and outlet runs can be reduced or omitted entirely.

Devices and possible order options on request.




Maximum measured error

When the device is installed with the inlet and outlet runs described, a maximum measured error of ± 0.5 % of the reading ± 1 mm/s (0.04 in/s) can be guaranteed.

Installation before or after bends

Installation without inlet and outlet runs is possible.



Installation downstream of pumps

Installation without inlet and outlet runs is possible.


Installation upstream of valves

Installation without inlet and outlet runs is possible.

Installation downstream of valves

Installation without inlet and outlet runs is possible if the valve is 100% open during operation.

Dimensions



6.1.2 Environment and process requirements

Ambient temperature range

Transmitter	 Standard: -40 to +60 °C (-40 to +140 °F) Optional: -50 to +60 °C (-58 to +140 °F) (Order code for "Test, certificate", option JN "Ambient temperature of transmitter -50 °C (-58 °F)")
Local display	-20 to $+60$ °C (-4 to $+140$ °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	 Process connection material, carbon steel: -10 to +60 °C (+14 to +140 °F) Process connection material, stainless steel: -40 to +60 °C (-40 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner .

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

System pressure

Installation near pumps $\rightarrow \cong 24$

Vibrations

Installation in event of pipe vibrations $\rightarrow \cong 24$

Thermal insulation

If process fluids are very hot, it is necessary to insulate pipes in order to reduce energy loss and to prevent individuals from accidentally coming into contact with hot pipes. Please observe the applicable standards and guidelines for insulating pipes.




A housing support/an extended neck is used for heat dissipation:

- Devices with the order code for "Lining", option **B** "PFA high-temperature" always come with a housing support.
- In the case of all other devices, a housing support can be ordered via the order code for "Sensor option", option CG "Sensor extended neck".

WARNING

Electronics overheating on account of thermal insulation!

• The housing support is used for heat dissipation and must be completely free (i.e. uncovered). At the very maximum, the sensor insulation may extend as far as the upper edge of the two sensor half-shells.



Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.




The nomogram only applies to liquids with a viscosity similar to that of water.



1. Calculate the ratio of the diameters d/D.

2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.




Length of connecting cable

Proline 500 – digital transmitter Lengths of connecting cable $\rightarrow \implies 43$

Proline 500 transmitter Max. 200 m (650 ft)


To obtain correct measurement results, observe the permitted connecting cable length of L_{max} . This length is determined by the conductivity of the medium. If measuring liquids in general: 5 $\mu S/cm$




☑ 6 Permitted length of connecting cable Colored area = permitted range L_{max}=length of connecting cable in [m] ([ft]) [µS/cm] = medium conductivity

6.1.3 Special mounting instructions

Weather protection cover



Weather protection cover for Proline 500 – digital; engineering unit mm (in)



Weather protection cover for Proline 500; engineering unit mm (in)

Immersion in water

 Only the remote version of the device with IP68 protection, Type 6P is suitable for underwater use: order code for "Sensor option", options CB, CC and CQ.

Pay attention to regional installation instructions.

NOTICE

If the maximum water depth and operating duration is exceeded, this can damage the device!


• Observe the maximum water depth and operating duration.

Order code for "Sensor option", options CB, CC

- For the operation of the device under water
- Operating duration at a maximum depth of:
 - 3 m (10 ft): permanent use
 - 10 m (30 ft): maximum 48 hours

Order code for "Sensor option", option CQ "Temporarily water-proof"

- For the temporary operation of the device under non-corrosive water
- Operating duration at a maximum depth of:
 3 m (10 ft): maximum 168 hours



6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

For mounting on a post:

- Proline 500 digital transmitter
 - Open-ended wrench AF 10
 - Torx screwdriver TX 25
- Proline 500 transmitter
 Open-ended wrench AF 13

For wall mounting: Drill with drill bit Ø 6.0 mm

For sensor

For flanges and other process connections: use a suitable mounting tool

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.


- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the sensor

WARNING

Danger due to improper process sealing!

- Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- Ensure that the seals are clean and undamaged.
- Secure the seals correctly.
- **1.** Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
- 2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
- 3. If using ground disks, comply with the Installation Instructions provided.
- 4. Observe the necessary screw tightening torques $\rightarrow \cong 32$.
- 5. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



Mounting the seals

ACAUTION

An electrically conductive layer could form on the inside of the measuring tube! Risk of measuring signal short circuit.

• Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

- 1. For DIN flanges: only use seals according to DIN EN 1514-1.
- 2. For a "PFA" liner: additional seals are generally **not** required.
- 3. For a "PTFE" liner: additional seals are generally not required.

Mounting the ground cable/ground disks

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks .

Screw tightening torques

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing surface or damage the seal.

[] Nominal screw tightening torques → 🗎 35

Maximum screw tightening torques

Maximum screw tightening torques f	for EN 1092-1 (DIN 2501)
------------------------------------	--------------------------

Nominal diameter	Pressure rating	Screws	Flange thickness		htening torque m]
[mm]	[bar]	[mm]	[mm]	PTFE	PFA
15	PN 40	4 × M12	16	11	-
25	PN 40	4 × M12	18	26	20
32	PN 40	4 × M16	18	41	35
40	PN 40	4 × M16	18	52	47
50	PN 40	4 × M16	20	65	59
65 ¹⁾	PN 16	8 × M16	18	43	40
65	PN 40	8×M16	22	43	40
80	PN 16	8 × M16	20	53	48
80	PN 40	8 × M16	24	53	48
100	PN 16	8 × M16	20	57	51
100	PN 40	8 × M20	24	78	70
125	PN 16	8 × M16	22	75	67
125	PN 40	8 × M24	26	111	99
150	PN 16	8 × M20	22	99	85
150	PN 40	8 × M24	28	136	120
200	PN 10	8 × M20	24	141	101
200	PN 16	12 × M20	24	94	67
200	PN 25	12 × M24	30	138	105
250	PN 10	12 × M20	26	110	-
250	PN 16	12 × M24	26	131	-
250	PN 25	12 × M27	32	200	-
300	PN 10	12 × M20	26	125	-
300	PN 16	12 × M24	28	179	_
300	PN 25	16 × M27	34	204	-
350	PN 10	16 × M20	26	188	-
350	PN 16	16 × M24	30	254	-
350	PN 25	16 × M30	38	380	-
400	PN 10	16 × M24	26	260	-
400	PN 16	16 × M27	32	330	-
400	PN 25	16 × M33	40	488	-
450	PN 10	20 × M24	28	235	-
450	PN 16	20 × M27	40	300	-
450	PN 25	20 × M33	46	385	-
500	PN 10	20 × M24	28	265	-
500	PN 16	20 × M30	34	448	-
500	PN 25	20 × M33	48	533	-
600	PN 10	20 × M27	28	345	-

Nominal diameter	Pressure rating	Screws	Flange thickness	Max. screw tig [N	htening torque m]
[mm]	[bar]	[mm]	[mm]	PTFE	PFA
600	PN 16	20 × M33	36	658	-
600	PN 25	20 × M36	58	731	_

1) Sizing as per EN 1092-1 (not DIN 2501)

Screw tightening torques for ASME B16.5, Class 150/300

Nominal diameter Pressure rating Screws		Screws		ening torque [Nm] · ft])	
[mm]	[in]	[psi]	[in]	PTFE	PFA
15	1/2	Class 150	4 × 1/2	6 (4)	- (-)
15	1/2	Class 300	4 × 1/2	6 (4)	- (-)
25	1	Class 150	4 × 1/2	11 (8)	10 (7)
25	1	Class 300	4 × 5/8	14 (10)	12 (9)
40	1 1/2	Class 150	4 × 1/2	24 (18)	21 (15)
40	1 1/2	Class 300	4 × ¾	34 (25)	31 (23)
50	2	Class 150	4 × 5/8	47 (35)	44 (32)
50	2	Class 300	8 × 5/8	23 (17)	22 (16)
80	3	Class 150	4 × 5/8	79 (58)	67 (49)
80	3	Class 300	8 × ¾	47 (35)	42 (31)
100	4	Class 150	8 × 5/8	56 (41)	50 (37)
100	4	Class 300	8 × ¾	67 (49)	59 (44)
150	6	Class 150	8 × ¾	106 (78)	86 (63)
150	6	Class 300	12 × ¾	73 (54)	67 (49)
200	8	Class 150	8 × ¾	143 (105)	109 (80)
250	10	Class 150	12 × 7/8	135 (100)	- (-)
300	12	Class 150	12 × 7/8	178 (131)	- (-)
350	14	Class 150	12 × 1	260 (192)	- (-)
400	16	Class 150	16 × 1	246 (181)	- (-)
450	18	Class 150	16 × 1 1/8	371 (274)	- (-)
500	20	Class 150	20 × 1 1/8	341 (252)	- (-)
600	24	Class 150	20 × 1 ¼	477 (352)	- (-)

Maximum screw tightening torques for JIS B2220

Nominal diameter	Pressure rating	Screws	Max. screw tightening torque [Nm]	
[mm]	[bar]	[mm]	PTFE	PFA
25	10K	4 × M16	32	27
	20K	4 × M16	32	27
32	10K	4 × M16	38	-
	20K	4 × M16	38	_
40	10K	4 × M16	41	37
	20K	4 × M16	41	37
50	10K	4 × M16	54	46

Nominal diameter	Pressure rating	Screws	Max. screw tighte	ening torque [Nm]
[mm]	[bar]	[mm]	PTFE	PFA
	20K	8 × M16	27	23
65	10K	4 × M16	74	63
	20K	8 × M16	37	31
80	10K	8 × M16	38	32
	20K	8 × M20	57	46
100	10K	8 × M16	47	38
	20K	8 × M20	75	58
125	10K	8 × M20	80	66
	20K	8 × M22	121	103
150	10K	8 × M20	99	81
	20K	12 × M22	108	72
200	10K	12 × M20	82	54
	20K	12 × M22	121	88
250	10K	12 × M22	133	-
	20K	12 × M24	212	-
300	10K	16 × M22	99	-
	20K	16 × M24	183	-

Screw tightening torques for AS 2129, Table E

Nominal diameter	Screws	Max. screw tightening torque [Nm]
[mm]	[mm]	PTFE
25	4 × M12	21
50	4 × M16	42

Screw tightening torques for AS 4087, PN 16

Nominal diameter	Screws	Max. screw tightening torque [Nm]	
[mm]	[mm]	PTFE	
50	4 × M16	42	

Nominal screw tightening torques

Nominal screw tightening torques for JIS B2220

Nominal diameter	Pressure rating	Screws	Nom. screw tightening torque [Nm]	
[mm]	[bar]	[mm]	HG	PUR
350	10K	16 × M22	109	109
	20K	16 × M30×3	217	217
400	10K	16 × M24	163	163
	20K	16 × M30×3	258	258
450	10K	16 × M24	155	155
	20K	16 × M30×3	272	272

Nominal diameter	Pressure rating	Screws	Nom. screw tightening torque [Nm]	
[mm]	[bar]	[mm]	HG	PUR
500	10K	16 × M24	183	183
	20K	16 × M30×3	315	315
600	10K	16 × M30	235	235
	20K	16 × M36×3	381	381
700	10K	16 × M30	300	300
750	10K	16 × M30	339	339

6.2.4 Mounting the transmitter housing: Proline 500 – digital

ACAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- ▶ Do not exceed the permitted maximum ambient temperature $\rightarrow \cong 28$.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

ACAUTION

Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting


Post mounting

WARNING

Excessive tightening torque applied to the fixing screws!


Risk of damaging the plastic transmitter.

• Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)



Engineering unit mm (in)

Wall mounting



■ 10 Engineering unit mm (in)

L Depends on order code for "Transmitter housing"

Order code for "Transmitter housing"

- Option **A**, aluminum, coated: L =14 mm (0.55 in)
- Option **D**, polycarbonate: L = 13 mm (0.51 in)

1. Drill the holes.

- 2. Insert wall plugs into the drilled holes.
- 3. Screw in the securing screws slightly.
- 4. Fit the transmitter housing over the securing screws and hook into place.
- 5. Tighten the securing screws.

6.2.5 Mounting the transmitter housing: Proline 500

ACAUTION

Ambient temperature too high!

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature $\rightarrow \cong 28$.
- ► If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.


Excessive force can damage the housing!

• Avoid excessive mechanical stress.

The transmitter can be mounted in the following ways:

- Post mounting
- Wall mounting

Wall mounting



🖻 11 Engineering unit mm (in)

- 1. Drill the holes.
- 2. Insert wall plugs into the drilled holes.
- **3.** Screw in the securing screws slightly.
- 4. Fit the transmitter housing over the securing screws and hook into place.
- 5. Tighten the securing screws.


Post mounting

WARNING

Order code for "Transmitter housing", option L "Cast, stainless": cast transmitters are very heavy.

They are unstable if they are not mounted on a secure, fixed post.


• Only mount the transmitter on a secure, fixed post on a stable surface.



■ 12 Engineering unit mm (in)

6.2.6 Turning the transmitter housing: Proline 500

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.




E 13 Ex housing

1. Loosen the fixing screws.

- 2. Turn the housing to the desired position.
- 3. Tighten the securing screws.

6.2.7 Turning the display module: Proline 500

The display module can be turned to optimize display readability and operability.



- 1. Depending on the device version: Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Turn the display module to the desired position: max. $8 \times 45^{\circ}$ in each direction.
- 4. Screw on the connection compartment cover.
- 5. Depending on the device version: Attach the securing clamp of the connection compartment cover.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring device conform to the measuring point specifications? For example: • Process temperature • Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document) • Ambient temperature • Measuring range	
 Has the correct orientation been selected for the sensor → ⁽¹⁾ 25 ? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids) 	
Does the arrow on the sensor nameplate match the actual direction of flow of the fluid through the piping $\rightarrow \square 25$?	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Have the fixing screws been tightened with the correct tightening torque?	

7 Electrical connection

WARNING

Live parts! Incorrect work performed on the electrical connections can result in an electric shock.

- Set up a disconnecting device (switch or power-circuit breaker) to easily disconnect the device from the supply voltage.
- ► In addition to the device fuse, include an overcurrent protection unit with max. 10 A in the plant installation.

7.1 Electrical safety

In accordance with applicable national regulations.

7.2 Connecting requirements

7.2.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimper for wire end ferrule
- For removing cables from terminal: Flat blade screwdriver \leq 3 mm (0.12 in)

7.2.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Protective grounding cable for the outer ground terminal

Conductor cross-section < 2.1 mm² (14 AWG)

The use of a cable lug enables the connection of larger cross-sections.

The grounding impedance must be less than 2 $\boldsymbol{\Omega}.$

Permitted temperature range

- The installation guidelines that apply in the country of installation must be observed.
- The cables must be suitable for the minimum and maximum temperatures to be expected.

Power supply cable (incl. conductor for the inner ground terminal)

Standard installation cable is sufficient.

Signal cable

Current output 4 to 20 mA HART

A shielded cable is recommended. Observe grounding concept of the plant.

Current output 0/4 to 20 mA Standard installation cable is sufficient

Pulse /frequency /switch output Standard installation cable is sufficient Double pulse output

Standard installation cable is sufficient

Relay output

Standard installation cable is sufficient.

Current input 0/4 to 20 mA

Standard installation cable is sufficient

Status input


Standard installation cable is sufficient

Cable diameter

- Cable glands supplied: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in)
- Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm² (24 to 12 AWG).

Choice of connecting cable between the transmitter and sensor

Depends on the type of transmitter and the installation zones



- 1 Proline 500 digital transmitter
- 2 Proline 500 transmitter
- 3 Promag sensor
- 4 Non-hazardous area
- 5 Hazardous area: Zone 2; Class I, Division 2
- 6 Hazardous area: Zone 1; Class I, Division 1
- Transmitter and sensor installed in the hazardous area: Zone 2; Class I, Division 2 or Zone 1; Class I, Division 1

A: Connecting cable between sensor and transmitter: Proline 500 – digital

Standard cable

A standard cable with the following specifications can be used as the connecting cable.

Design	4 cores (2 pairs); uninsulated stranded CU wires; pair-stranded with common shield
Shielding	Tin-plated copper braid, optical cover \geq 85 %
Cable length	Maximum 300 m (900 ft), see the following table.

	Cable lengths for use in		
Cross-section	Non-hazardous area, Hazardous area: Zone 2; Class I, Division 2	Hazardous area: Zone 1; Class I, Division 1	
0.34 mm ² (AWG 22)	80 m (240 ft)	50 m (150 ft)	
0.50 mm ² (AWG 20)	120 m (360 ft)	60 m (180 ft)	
0.75 mm ² (AWG 18)	180 m (540 ft)	90 m (270 ft)	
1.00 mm ² (AWG 17)	240 m (720 ft)	120 m (360 ft)	

	Cable lengths for use in			
Cross-section	Non-hazardous area, Hazardous area: Zone 2; Class I, Division 2	Hazardous area: Zone 1; Class I, Division 1		
1.50 mm ² (AWG 15)	300 m (900 ft)	180 m (540 ft)		
2.50 mm ² (AWG 13)	300 m (900 ft)	300 m (900 ft)		

Optionally available connecting cable

Design	$2 \times 2 \times 0.34 \text{ mm}^2$ (AWG 22) PVC cable ¹⁾ with common shield (2 pairs, uninsulated stranded CU wires; pair-stranded)	
Flame resistance	According to DIN EN 60332-1-2	
Oil-resistance	According to DIN EN 60811-2-1	
Shielding	Tin-plated copper braid, optical cover \geq 85 %	
Operating temperature	When mounted in a fixed position: –50 to +105 $^\circ$ C (–58 to +221 $^\circ$ F); when cable can move freely: –25 to +105 $^\circ$ C (–13 to +221 $^\circ$ F)	
Available cable length	Fixed: 20 m (60 ft); variable: up to maximum 50 m (150 ft)	


1) UV radiation can impair the cable outer sheath. Protect the cable from direct sunshine where possible.

B: Connecting cable between sensor and transmitter: Proline 500 Signal cable

Design	$3\times0.38~mm^2$ (20 AWG) with common, braided copper shield (Ø \sim 9.5 mm (0.37 in)) and individual shielded cores
Conductor resistance	\leq 50 Ω/km (0.015 Ω/ft)
Capacitance: core/shield	< 420 pF/m (128 pF/ft)
Cable length (max.)	Depends on the medium conductivity, max. 200 m (656 ft)
Cable lengths (available for order)	5 m (15 ft), 10 m (30 ft), 20 m (60 ft) or variable length up to max. 200 m (600 ft)
Cable diameter	9.4 mm (0.37 in) ± 0.5 mm (0.02 in)
Operating temperature	-20 to +80 °C (-4 to +176 °F)

Coil current cable

Design	$3\times0.75~mm^2$ (18 AWG) with common, braided copper shield (Ø \sim 9 mm (0.35 in)) and individual shielded cores
Conductor resistance $\leq 37 \Omega/\text{km} (0.011 \Omega/\text{ft})$	
Capacitance: core/core, shield grounded	≤ 120 pF/m (37 pF/ft)
Cable length (max.)Depends on the medium conductivity, max. 200 m (656 ft)	
Cable lengths (available for order)5 m (15 ft), 10 m (30 ft), 20 m (60 ft) or variable length up to max. 200 m (600 ft)	
Cable diameter	8.8 mm (0.35 in) ± 0.5 mm (0.02 in)
Continuous operating temperature	-20 to +80 °C (-4 to +176 °F)
Test voltage for cable insulation	≤ AC 1433 V rms 50/60 Hz or ≥ DC 2026 V



- 14 Cable cross-section
- a Electrode cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket 5 Core reinforcen
- 5 Core reinforcement6 Cable shield
- 7 Outer jacket

Operation in zones of severe electrical interference

The measuring system meets the general safety requirements $\rightarrow \cong 216$ and EMC specifications $\rightarrow \cong 203$.

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.

7.2.3 Terminal assignment

Transmitter: supply voltage, input/outputs

The terminal assignment of the inputs and outputs depends on the individual order version of the device. The device-specific terminal assignment is documented on an adhesive label in the terminal cover.

Supply	voltage	Input/	output L	Input/output 2		Input/output 3		Input/output 4	
1 (+)	2 (-)	26 (+)	27 (-)	24 (+)	25 (-)	22 (+)	23 (-)	20 (+)	21 (-)
		Device-specific terminal assignment: adhesive label in terminal cover.							

Transmitter and sensor connection housing: connecting cable

The sensor and transmitter, which are mounted in separate locations, are interconnected by a connecting cable. The cable is connected via the sensor connection housing and the transmitter housing.

Terminal assignment and connection of the connecting cable:

- Proline 500 digital →
 ⁽¹⁾ 49
- Proline $500 \rightarrow \textcircled{5}{54}$

7.2.4 Preparing the measuring device

Carry out the steps in the following order:

1. Mount the sensor and transmitter.

- 2. Sensor connection housing: Connect connecting cable.
- 3. Transmitter: Connect connecting cable.

4. Transmitter: Connect signal cable and cable for supply voltage.

NOTICE

Insufficient sealing of the housing!


Operational reliability of the measuring device could be compromised.

- Use suitable cable glands corresponding to the degree of protection.
- 1. Remove dummy plug if present.
- 2. If the measuring device is supplied without cable glands: Provide suitable cable gland for corresponding connecting cable.
- If the measuring device is supplied with cable glands:
 Observe requirements for connecting cables →
 ⁽²⁾
 ⁽²⁾

7.2.5 Preparing the connecting cable: Proline 500 – digital

When terminating the connecting cable, pay attention to the following points:


For cables with fine-wire cores (stranded cables):
 Fit the cores with ferrules.



7.2.6 Preparing the connecting cable: Proline 500

When terminating the connecting cable, pay attention to the following points:

- In the case of the electrode cable: Make sure that the ferrules do not touch the core shields on the sensor side. Minimum distance = 1 mm (exception: green "GND" cable)
- In the case of the coil current cable:
 Insulate one core of the three-core cable at the level of the core reinforcement. You only require two cores for the connection.
- 3. For cables with fine-wire cores (stranded cables): Fit the cores with ferrules.



7.3 Connecting the measuring device: Proline 500 – digital

NOTICE

Limitation of electrical safety due to incorrect connection!

- Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.


7.3.1 Connecting the connecting cable

WARNING

Risk of damaging electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

Connecting cable terminal assignment



- 1 Cable entry for cable on transmitter housing
- 2 Protective earth (PE)
- 3 Connecting cable ISEM communication
- 4 Grounding via ground connection; on device plug versions grounding is through the plug itself
- 5 Cable entry for cable or connection of device plug on sensor connection housing
- 6 Protective earth (PE)

Connecting the connecting cable to the sensor connection housing

Connection via terminals with order code for "Sensor connection housing":

- Option **A** "Aluminum, coated" \rightarrow \bigcirc 50
- Option **L** "Cast, stainless" $\rightarrow \square 50$


Connecting the connecting cable to the transmitter

The cable is connected to the transmitter via terminals $\rightarrow \cong 51$.

Connecting the sensor connection housing via terminals

For the device version with the order code for "Sensor connection housing":

- Option A "Aluminum coated"
- Option L "Cast, stainless"




- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- **3.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
 - └ This concludes the process for connecting the connecting cable.

WARNING


Housing degree of protection voided due to insufficient sealing of the housing.


- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- 9. Tighten the securing clamp of the housing cover.




Connecting the connecting cable to the transmitter

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- **7.** Connect the cable according to the terminal assignment for the connecting cable $\rightarrow \cong 49$.
- 8. Firmly tighten the cable glands.
 - └ This concludes the process for connecting the connecting cable.
- 9. Close the housing cover.
- **10.** Tighten the securing screw of the housing cover.





- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output
- 4 Terminal connection for connecting cable between sensor and transmitter
- 5 Terminal connection for signal transmission, input/output; optional: connection for external WLAN antenna
- 6 Protective earth (PE)



- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. Fold open the terminal cover.
- 4. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 5. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 6. Connect the protective ground.
- 7. Connect the cable in accordance with the terminal assignment .
 - ▶ Signal cable terminal assignment: The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 Supply voltage terminal assignment: Adhesive label in the terminal cover or →
 →
 45.
- 8. Firmly tighten the cable glands.
 - └ This concludes the cable connection process.
- 9. Close the terminal cover.
- **10.** Close the housing cover.

WARNING

Housing degree of protection may be voided due to insufficient sealing of the housing.

► Screw in the screw without using any lubricant.


WARNING

Excessive tightening torque applied to the fixing screws!

Risk of damaging the plastic transmitter.

- ▶ Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)
- **11.** Tighten the 4 fixing screws on the housing cover.

Removing a cable



■ 15 Engineering unit mm (in)

1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes

2. while simultaneously pulling the cable end out of the terminal.

7.4 Connecting the measuring device: Proline 500

NOTICE

Limitation of electrical safety due to incorrect connection!

- ► Have electrical connection work carried out by appropriately trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► Always connect the protective ground cable ⊕ before connecting additional cables.
- ► For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.


7.4.1 Connecting the connecting cable

WARNING

Risk of damaging electronic components!

- Connect the sensor and transmitter to the same potential equalization.
- Only connect the sensor to a transmitter with the same serial number.
- Ground the connection housing of the sensor via the external screw terminal.

Connecting cable terminal assignment



1 Protective earth (PE)

2 Cable entry for coil current cable on transmitter connection housing

- 3 Coil current cable
- 4 Cable entry for signal cable on transmitter connection housing
- 5 Signal cable
- 6 Cable entry for signal cable on sensor connection housing
- 7 Protective earth (PE)
- 8 Cable entry for coil current cable on sensor connection housing


Connecting the connecting cable to the sensor connection housing

Connection via terminals with order code for "Housing": Option A "Aluminum coated" $\rightarrow \cong 55$

Connecting the sensor connection housing via terminals

For the device version with the order code for "Housing":

- Option A "Aluminum coated"
- Option L "Cast, stainless"




- 1. Loosen the securing clamp of the housing cover.
- 2. Unscrew the housing cover.
- **3.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment.
- 7. Firmly tighten the cable glands.
 - → This concludes the process for connecting the connecting cables.

WARNING

Housing degree of protection voided due to insufficient sealing of the housing.

- Screw in the thread on the cover without using any lubricant. The thread on the cover is coated with a dry lubricant.
- 8. Screw on the housing cover.
- 9. Tighten the securing clamp of the housing cover.




Attaching the connecting cable to the transmitter


- **1.** Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- **3.** Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the protective ground.
- 6. Connect the cable in accordance with the connecting cable terminal assignment $\rightarrow \cong 54$.
- 7. Firmly tighten the cable glands.
 - └ This concludes the process for connecting the connecting cables.
- 8. Screw on the connection compartment cover.
- 9. Tighten the securing clamp of the connection compartment cover.
- **10**. After connecting the connecting cables:

Connect the signal cable and the supply voltage cable $\rightarrow \oplus 57$.


7.4.2 Connecting the signal cable and the supply voltage cable




- 1 Terminal connection for supply voltage
- 2 Terminal connection for signal transmission, input/output
- 3 Terminal connection for signal transmission, input/output or terminal connection for network connection via service interface (CDI-RJ45)
- 4 Protective earth (PE)




- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Squeeze the tabs of the display module holder together.
- 4. Remove the display module holder.



- 5. Attach the holder to the edge of the electronics compartment.
- 6. Open the terminal cover.




- 7. Push the cable through the cable entry. To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 8. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 9. Connect the protective ground.



- **10.** Connect the cable according to the terminal assignment.
 - → Signal cable terminal assignment: The device-specific terminal assignment is documented on an adhesive label in the terminal cover.
 Supply voltage terminal assignment: Adhesive label in the terminal cover or →
 △ 45.
- **11.** Firmly tighten the cable glands.
 - \blacktriangleright This concludes the cable connection process.
- 12. Close the terminal cover.
- **13.** Fit the display module holder in the electronics compartment.
- **14.** Screw on the connection compartment cover.
- **15.** Secure the securing clamp of the connection compartment cover.

Removing a cable



🖻 16 Engineering unit mm (in)

1. To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes

2. while simultaneously pulling the cable end out of the terminal.

7.5 Ensuring potential equalization

7.5.1 Introduction

Correct potential equalization (equipotential bonding) is a prerequisite for stable and reliable flow measurement. Inadequate or incorrect potential equalization can result in device failure and present a safety hazard.

The following requirements must be observed to ensure correct, trouble-free measurement:

- The principle that the medium, the sensor and the transmitter must be at the same electrical potential applies.
- Take in-company grounding guidelines, materials and the grounding conditions and potential conditions of the pipe into consideration.
- The necessary potential equalization connections must be established using a ground cable with a minimum cross-section of 6 mm² (0.0093 in²) and a cable lug.
- In the case of remote device versions, the ground terminal in the example always refers to the sensor and not to the transmitter.

You can order accessories such as ground cables and ground disks directly from Endress+Hauser $\rightarrow \ \textcircled{}183$

For devices intended for use in hazardous areas, observe the instructions in the Ex documentation (XA).

Abbreviations used

н

- PE (Protective Earth): potential at the protective earth terminals of the device
- P_P (Potential Pipe): potential of the pipe, measured at the flanges
- P_M (Potential Medium): potential of the medium


7.5.2 Connection examples for standard situations

Unlined and grounded metal pipe

- Potential equalization is via the measuring pipe.
- The medium is set to ground potential.

Starting conditions:

- Pipes are correctly grounded on both sides.
- Pipes are conductive and at the same electrical potential as the medium




 Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.

Metal pipe without liner

- Potential equalization is via the ground terminal and pipe flanges.
- The medium is set to ground potential.

Starting conditions:

- Pipes are not sufficiently grounded.
- Pipes are conductive and at the same electrical potential as the medium




- **1.** Connect both sensor flanges to the pipe flange via a ground cable and ground them.
- 2. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.
- **3.** For $DN \le 300 (12")$: Mount the ground cable directly on the conductive flange coating of the sensor with the flange screws.
- 4. For $DN \ge 350 (14")$: Mount the ground cable directly on the metal transport bracket. Observe the screw tightening torques: see the Brief Operating Instructions for the sensor.

Plastic pipe or pipe with insulating liner

The medium is set to ground potential.

Starting conditions:

- The pipe has an insulating effect.
- Low-impedance medium grounding close to the sensor is not guaranteed.
- Equalizing currents through the medium cannot be ruled out.



- 1. Connect the ground disks to the ground terminal of the transmitter or sensor connection housing via the ground cable.
- 2. Connect the connection to ground potential.

7.5.3 Connection example with the potential of medium not equal to protective ground without the "Floating measurement" option


In these cases, the medium potential can differ from the potential of the device.

Metal, ungrounded pipe

The sensor and transmitter are installed in a way that provides electrical insulation from PE, e.g. applications for electrolytic processes or systems with cathodic protection.

Starting conditions:

- Unlined metal pipe
- Pipes with an electrically conductive liner



1. Connect the pipe flanges and transmitter via the ground cable.

- 2. Route the shielding of the signal lines via a capacitor (recommended value 1.5μ F/ 50V).
- **3.** Device connected to power supply such that it is floating in relation to the protective earth (isolation transformer). This measure is not required in the case of 24V DC supply voltage without PE (= SELV power unit).

7.5.4 Connection examples with the potential of medium not equal to protective ground with the "Floating measurement" option

In these cases, the medium potential can differ from the potential of the device.

Introduction

The "Floating measurement" option enables the galvanic isolation of the measuring system from the device potential. This minimizes harmful equalizing currents caused by differences in potential between the medium and the device. The "Floating measurement" option is optionally available: order code for "Sensor option", option CV

Operating conditions for the use of the "Floating measurement" option

Device version		Compact version and remote version (length of connecting cable \leq 10 m)
Differences in voltage betw and device potential	een medium potential	As small as possible, usually in the mV range
Alternating voltage frequer or at ground potential (PE)		Below typical power line frequency in the country

To achieve the specified conductivity measuring accuracy, a conductivity calibration is recommended when the device is installed.


A full pipe adjustment is recommended when the device is installed.

Plastic pipe

Sensor and transmitter are correctly grounded. A difference in potential can occur between the medium and protective earth. Potential equalization between P_M and PE via the reference electrode is minimized with the "Floating measurement" option.

Starting conditions:

- The pipe has an insulating effect.
- Equalizing currents through the medium cannot be ruled out.




- 1. Use the "Floating measurement" option, while also observing the operating conditions for floating measurement.
- 2. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for this purpose.

Metal, ungrounded pipe with insulating liner

The sensor and transmitter are installed in a way that provides electrical insulation from PE. The medium and pipe have different potentials. The "Floating measurement" option minimizes harmful equalizing currents between P_M and P_P via the reference electrode.

Starting conditions:

- Metal pipe with insulating liner
- Equalizing currents through the medium cannot be ruled out.




- **1.** Connect the pipe flanges and transmitter via the ground cable.
- 2. Route the shielding of the signal cables via a capacitor (recommended value 1.5μ F/ 50V).
- **3.** Device connected to power supply such that it is floating in relation to the protective earth (isolation transformer). This measure is not required in the case of 24V DC supply voltage without PE (= SELV power unit).
- 4. Use the "Floating measurement" option, while also observing the operating conditions for floating measurement.

7.6 Special connection instructions


7.6.1 Connection examples

Current output 4 to 20 mA HART



17 Connection example for 4 to 20 mA HART current output (active)


- 1 Automation system with current input (e.g. PLC)
- 2 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- *3* Connection for HART operating devices $\rightarrow \cong 89$
- 4 Resistor for HART communication ($\geq 250 \Omega$): observe maximum load $\Rightarrow \square 191$
- 5 Analog display unit: observe maximum load $\rightarrow \square 191$
- 6 Transmitter



18 Connection example for 4 to 20 mA HART current output (passive)

- 1 Automation system with current input (e.g. PLC)
- 2 Power supply
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load $\rightarrow \square$ 191
- 5 Transmitter


HART input



■ 19 Connection example for HART input with a common negative (passive)


- 1 Automation system with HART output (e.g. PLC)
- 2 Active barrier for power supply (e.g. RN221N)
- 3 Cable shield provided at one end. The cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications
- 4 Analog display unit: observe maximum load $\rightarrow \square$ 191
- 5 Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- 6 Transmitter

Current output 4-20 mA




- ☑ 20 Connection example for 4-20 mA current output (active)
- 1 Automation system with current input (e.g. PLC)
- 2 Analog display unit: observe maximum load $\rightarrow \square$ 191

3 Transmitter



- 21 Connection example for 4-20 mA current output (passive)
- *1 Automation system with current input (e.g. PLC)*
- 2 Active barrier for power supply (e.g. RN221N)
- *3* Analog display unit: observe maximum load $\rightarrow \square$ 191
- 4 Transmitter


Pulse/frequency output



22 Connection example for pulse/frequency output (passive)

- 1 Automation system with pulse/frequency input (e.g. PLC with 10 k Ω pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values $\rightarrow \square 193$

Switch output




23 Connection example for switch output (passive)

- Automation system with switch input (e.g. PLC with a 10 k Ω pull-up or pull-down resistor)
- 2 Power supply

1


3 Transmitter: observe input values $\rightarrow \cong 193$

Double pulse output



24 Connection example for double pulse output (active)


- 1 Automation system with double pulse input (e.g. PLC)
- 2 Transmitter: observe input values $\rightarrow \implies 194$
- 3 Double pulse output
- 4 Double pulse output (slave), phase-shifted



25 Connection example for double pulse output (passive)

- 1 Automation system with double pulse input (e.g. PLC with a 10 k Ω pull-up or pull-down resistor)
- 2 Power supply
- 3 Transmitter: observe input values $\rightarrow \square 194$
- 4 Double pulse output
- 5 Double pulse output (slave), phase-shifted


Relay output



26 Connection example for relay output (passive)


- 1 Automation system with relay input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values $\rightarrow \square 194$

Current input



- 27 Connection example for 4 to 20 mA current input
- 1 Power supply
- 2 Terminal box
- 3 External measuring device (to read in pressure or temperature, for instance)
- 4 Transmitter

Status input



■ 28 Connection example for status input

1 Automation system with status output (e.g. PLC)

- 2 Power supply
- 3 Transmitter


7.7 Ensuring the degree of protection

The measuring device fulfills all the requirements for the degree of protection IP66/67, Type 4X enclosure.

To guarantee the degree of protection IP66/67, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly.
- 2. Dry, clean or replace the seals if necessary.
- 3. Tighten all housing screws and screw covers.
- 4. Firmly tighten the cable glands.

 To ensure that moisture does not enter the cable entry: Route the cable so that it loops down before the cable entry ("water trap").




6. Insert dummy plugs (corresponding to the housing degree of protection) into unused cable entries.

7.8 Post-connection check

Are cables or the device undamaged (visual inspection)?		
Is the protective earthing established correctly?		
Do the cables used comply with the requirements ?		
Do the mounted cables have adequate strain relief?		
Are all cable glands installed, securely tightened and leak-tight? Cable run with "water trap" $\rightarrow \bigoplus 67$?		
Is the terminal assignment correct ?		
Is the potential equalization established correctly ?		
Are dummy plugs inserted in unused cable entries and have transportation plugs been replaced with dummy plugs?		

8 Operation options

8.1 Overview of operation options




- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Xpert SMT70
- 5 Mobile handheld terminal
- 6 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu for experts: see the "Description of Device Parameters" document supplied with the device $\rightarrow \cong 219$



Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu/parameter		User role and tasks	Content/meaning		
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuration of the operational	 Defining the operating language Defining the Web server operating language Resetting and controlling totalizers 		
Operation		display • Reading measured values	Configuring the operational display (e.g. display format, display contrast)Resetting and controlling totalizers		
Setup		 "Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs Configuration of the communication interface 	 Wizards for fast commissioning: Configuration of the system units Displaying the I/O configuration Configuration of the inputs Configuration of the outputs Configuration of the low flow cut off Configuration of empty pipe detection Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of electrode cleaning (optional) 		
			 Configuration of VLAN settings Administration (define access code, reset measuring device) 		
Diagnostics		 "Maintenance" role Troubleshooting: Diagnostics and elimination of process and device errors Measured value simulation 	 Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains event messages that have occurred. Device information Contains information for identifying the device. Measured values Contains all current measured values. Data logging submenu with the "Extended HistoROM" order option Storage and visualization of measured values Heartbeat The functionality of the device is checked on demand and the verification results are documented. Simulation Is used to simulate measured values or output values. 		
Expert	function-oriented	 Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases 	 Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication. Sensor Configuration of the measurement. Input Configuration of the status input. Output Configuration of the analog current outputs as well as the pulse/frequency and switch output. Communication Configuration of the digital communication interface and the Web server. Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology. 		

8.3 Access to the operating menu via the local display

8.3.1 Operational display



- 1 Operational display
- 2 Device tag $\rightarrow \square 102$
- 3 Status area
- 4 Display area for measured values (4-line)
- 5 Operating elements $\rightarrow \square 77$


Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 162
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- Diagnostic behavior → 🗎 163
 - 🐼: Alarm
 - M: Warning
- $\widehat{\square}$: Locking (the device is locked via the hardware)
- • : Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



Measured variables

Sym	bol	Meaning
	Ú	Volume flow
	G	Conductivity

'n	Mass flow
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.
Ģ	Output Image: Output Image: The measurement channel number indicates which of the outputs is displayed.
Ð	Status input

Measurement channel numbers

Symbol	Meaning
14	Measurement channel 1 to 4


The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols $\rightarrow \cong 163$


The number and display format of the measured values can be configured via the **Format display** parameter ($\rightarrow \cong 117$).

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:



Display

For more information about the icons in the menu, refer to the "Display area" section $\rightarrow \cong 74$

Status area

The following appears in the status area of the navigation view in the top right corner:

- In the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal

- \blacksquare For information on the diagnostic behavior and status signal o \blacksquare 162
 - For information on the function and entry of the direct access code \rightarrow 🗎 79

Display area

Menus

Symbol	Meaning	
R	 Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the Operation menu 	
بر	 Setup Appears: In the menu next to the "Setup" selection At the left in the navigation path in the Setup menu 	
୍ୟ	 Diagnostics Appears: In the menu next to the "Diagnostics" selection At the left in the navigation path in the Diagnostics menu 	
÷	 Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the Expert menu 	

Submenus, wizards, parameters

Symbol	Meaning
•	Submenu
<u>12</u>	Wizard
Ø	Parameters within a wizard Image: No display symbol exists for parameters in submenus.

Locking


Symbol	Meaning
ô	 Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. By a user-specific access code By the hardware write protection switch

Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
	Confirms the parameter value and switches to the next parameter.
E	Opens the editing view of the parameter.

8.3.3 Editing view


Numeric editor



■ 30 For entering values in parameters (e.g. limit values)

- 1 Entry display area
- 2 Input screen
- 3 Confirm, delete or reject entry
- 4 Operating elements

Text editor



■ 31 For entering text in parameters (e.g. tag name)

- 1 Entry display area
- 2 Current input screen
- 3 Change input screen
- 4 Operating elements
- 5 Move entry position
- 6 Delete entry
- 7 Reject or confirm entry

Using the operating elements in the editing view

Key	Neaning	
Θ	Minus key Move the entry position to the left.	
+	Plus key Move the entry position to the right.	
E	Enter keyPressing the key briefly confirms the selection.Pressing the key for 2 s confirms your entry.	
-++	Escape key combination (press keys simultaneously) Close the editing view without accepting a change.	

Input screens

Symbol	Meaning
A	Upper case
а	Lower case
1	Numbers
+*	Punctuation marks and special characters: = + - * / ² ³ ¹ / ₄ ¹ / ₂ ³ / ₄ () [] < > { }
@	Punctuation marks and special characters: ' " ` ^. , ; : ? ! % μ ° \in \$ £ ¥ § @ # / \ I ~ & _
ä	Umlauts and accents

Controlling data entries

Symbol	Meaning
←→	Move entry position
Х	Reject entry
4	Confirm entry
×	Delete character immediately to the left of the entry position
del	Delete character immediately to the right of the entry position
С	Clear all the characters entered

8.3.4 **Operating elements**

Кеу	Meaning		
	Minus key		
\bigcirc	<i>In menu, submenu</i> Moves the selection bar upwards in a picklist.		
	With a wizard Confirms the parameter value and goes to the previous parameter.		
	For text and numeric editor Move the entry position to the left.		
	Plus key		
	<i>In menu, submenu</i> Moves the selection bar downwards in a picklist.		
	With a wizard Confirms the parameter value and goes to the next parameter.		
	For text and numeric editor Move the entry position to the right.		
	Enter key		
	For operational display Pressing the key briefly opens the operating menu.		
E	 In menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter. 		
	With a wizard Opens the editing view of the parameter.		
	For text and numeric editorPressing the key briefly confirms the selection.Pressing the key for 2 s confirms your entry.		
	Escape key combination (press keys simultaneously)		
○ + ()	 In menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next level up. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). 		
	With a wizard Exits the wizard and takes you to the next level up.		
	For text and numeric editor Closes the editing view without applying changes.		
	Minus/Enter key combination (press and hold down the keys simultaneously)		
-+E	 If the keypad lock is enabled: Pressing the key for 3 s disables the keypad lock. If the keypad lock is not enabled: Pressing the key for 3 s opens the context menu including the selection for activating the keypad lock. 		
	In neypuu lock.		

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Data backup
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- **1.** Press the \Box and \blacksquare keys for longer than 3 seconds.
 - └ The context menu opens.



2. Press \Box + \pm simultaneously.

└ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press \pm to navigate to the desired menu.
- 3. Press 🗉 to confirm the selection.
 - └ The selected menu opens.

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\rightarrow \textcircled{B} 73$


Example: Setting the number of displayed measured values to "2 values"



8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path Expert \rightarrow Direct access The direct access code consists of a 5-digit number (at maximum) and the channel number, which identifies the channel of a process variable: e.g. 00914-2. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Enter "914" instead of "00914"
- If no channel number is entered, channel 1 is opened automatically.
 Example: Enter 00914 → Assign process variable parameter
- If a different channel is opened: Enter the direct access code with the corresponding channel number.

Example: Enter $00914-2 \rightarrow Assign \ process \ variable$ parameter

For the direct access codes of the individual parameters, see the "Description of Device Parameters" document for the device

8.3.8 Calling up help text


Help text is available for some parameters and can be called up from the navigation view. The help text provides a brief explanation of the parameter function and thereby supports swift and safe commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

1. Press E for 2 s.

← The help text for the selected parameter opens.



32 Example: Help text for parameter "Enter access code"

- **2.** Press \Box + \pm simultaneously.
 - └ The help text is closed.

8.3.9 Changing the parameters

Parameters can be changed via the numeric editor or text editor.

- Numeric editor: Change values in a parameter, e.g. specifications for limit values.
- Text editor: Enter text in a parameter, e.g. tag name.

A message is displayed if the value entered is outside the permitted value range.

Ent. access code
Invalid or out of range input
value
Min:0
Max:9999

For a description of the editing view - consisting of the text editor and numeric editor - with symbols → 🗎 75, for a description of the operating elements → 🗎 77

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access $\rightarrow \cong 142$.

Defining access authorization for user roles

An access code is not yet defined when the device is delivered from the factory. Access authorization (read and write access) to the device is not restricted and corresponds to the "Maintenance" user role.

- ► Define the access code.
 - └ The "Operator" user role is redefined in addition to the "Maintenance" user role. Access authorization differs for the two user roles.

Access authorization to parameters: "Maintenance" user role

Access code status	Read access	Write access
An access code has not yet been defined (factory setting).	V	V
After an access code has been defined.	V	✓ ¹⁾

1) The user only has write access after entering the access code.

Access authorization to parameters: "Operator" user role

Access code status	Read access	Write access
After an access code has been defined.	V	_ 1)

 Despite the defined access code, certain parameters can always be modified and thus are excluded from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

The user role with which the user is currently logged on is indicated by the **Access status** parameter. Navigation path: Operation → Access status

8.3.11 Disabling write protection via access code

If the @-symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using local operation $\Rightarrow @$ 142.

Parameter write protection via local operation can be disabled by entering the user-specific access code in the **Enter access code** parameter ($\rightarrow \square 128$) via the respective access option.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

➡ The B -symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

- Press the \Box and \blacksquare keys for 3 seconds.
- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the **Keylock on** message appears.

Switching off the keypad lock

- The keypad lock is switched on.
 - Press the \Box and \blacksquare keys for 3 seconds.
 - └ The keypad lock is switched off.

8.4 Access to the operating menu via the Web browser

8.4.1 Function scope

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via the service interface (CDI-RJ45) or via the WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed and allows users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

For additional information on the Web server, refer to the Special Documentation for the device

8.4.2 Requirements

Computer hardware

Hardware	Interface		
	CDI-RJ45 WLAN		
Interface	The computer must have an RJ45 interface.	The operating unit must have a WLAN interface.	
Connection	Ethernet cable with RJ45 connector. Connection via Wireless LAN.		
Screen	Recommended size: \geq 12" (depends on the screen resolution)		

Computer software

Software	Interface	
	CDI-RJ45	WLAN
Recommended operating systems	 Microsoft Windows 8 or higher. Mobile operating systems: iOS Android Microsoft Windows XP is supported. Microsoft Windows 7 is supported.	
Web browsers supported	 Microsoft Internet Explorer 8 or higher Microsoft Edge Mozilla Firefox Google Chrome Safari 	

Computer settings

Settings	Interface	
	CDI-RJ45	WLAN
User rights	Appropriate user rights (e.g. administrator rights) for TCP/IP and proxy server settings are necessary (for adjusting the IP address, subnet mask etc.).	
Proxy server settings of the Web browser	The Web browser setting <i>Use proxy server for LAN</i> must be disabled .	
JavaScript	JavaScript must be enabled.	
	If JavaScript cannot be enabled: Enter http://192.168.1.212/servlet/basic.html in the address bar of the web browser. A fully functional but simplified version of the operating menu structure starts in the Web browser.	
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under Internet options.	
Network connections	Only the active network connections to the measuring device should be used.	
Switch off all other network connections such as WLAN.Switch off all other connections.		Switch off all other network connections.

In the event of connection problems: $\rightarrow \cong 157$

Measuring device: Via CDI-RJ45 service interface

Device	CDI-RJ45 service interface	
Measuring device	The measuring device has an RJ45 interface.	
Web server	 Web server must be enabled; factory setting: ON I For information on enabling the Web server → ■ 88 	

Measuring device: via WLAN interface

Device	WLAN interface
Measuring device	The measuring device has a WLAN antenna:Transmitter with integrated WLAN antennaTransmitter with external WLAN antenna
Web server	Web server and WLAN must be enabled; factory setting: ONI For information on enabling the Web server → 88

8.4.3 Establishing a connection

Via service interface (CDI-RJ45)

Preparing the measuring device

Proline 500 – digital

- 1. Loosen the 4 fixing screws on the housing cover.
- 2. Open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 plug via the standard Ethernet connecting cable .

Proline 500

- Depending on the housing version: Loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version: Unscrew or open the housing cover.
- 3. The location of the connection socket depends on the measuring device and the communication protocol:

Connect the computer to the RJ45 plug via the standard Ethernet connecting cable .

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)

- 1. Switch on the measuring device.
- **2.** Connect to the computer using a cable $\rightarrow \square$ 90.
- 3. If a 2nd network card is not used, close all the applications on the notebook.
 - ← Applications requiring Internet or a network, such as e-mail, SAP applications, Internet or Windows Explorer.
- 4. Close any open Internet browsers.
- 5. Configure the properties of the Internet protocol (TCP/IP) as defined in the table:

IP address	192.168.1.XXX; for XXX all numerical sequences except: 0, 212 and 255 \rightarrow e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

Via WLAN interface

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

• Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

1. In the WLAN settings of the mobile terminal:

Select the measuring device using the SSID (e.g. EH_Promag_500_A802000).

- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - └ LED on display module flashes: it is now possible to operate the measuring device with a web browser, FieldCare or DeviceCare.
 - The serial number can be found on the nameplate.
 - To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting


 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

Starting the Web browser

1. Start the Web browser on the computer.

2. Enter the IP address of the web server in the address line of the web browser: 192.168.1.212

└ The login page appears.



- 1 Picture of device
- 2 Device name
- 3 Device tag ($\rightarrow \square 102$)
- 4 Status signal
- 5 Current measured values6 Operating language
- 7 User role
- 8 Access code
- 9 Login
- 10 Reset access code ($\rightarrow \square 139$)

If a login page does not appear, or if the page is incomplete $\rightarrow \square$ 157

8.4.4 Logging on


1. Select the preferred operating language for the Web browser.

- 2. Enter the user-specific access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (default setting); can be changed by customer
--

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.4.5 User interface



- 1 Function row
- 2 Local display language
- 3 Navigation area

Header

The following information appears in the header:

- Device name
- Device tag
- Device status with status signal $\rightarrow \square 165$
- Current measured values

Function row

Functions	Meaning
Measured values	Displays the measured values of the device
Menu	 Access to the operating menu from the measuring device The structure of the operating menu is the same as for the local display For detailed information on the structure of the operating menu, see the Operating Instructions for the measuring device
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	 Data exchange between PC and measuring device: Device configuration: Load settings from the device (XML format, save configuration) Save settings to the device (XML format, restore configuration) Logbook - Export Event logbook (.csv file) Documents - Export documents: Export backup data record (.csv file, create documentation of the measuring point configuration) Verification report (PDF file, only available with the "Heartbeat Verification" application package)
Network configuration	 Configuration and checking of all the parameters required for establishing the connection to the measuring device: Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.4.6 Disabling the Web server

The Web server of the measuring device can be switched on and off as required using the **Web server functionality** parameter.

Navigation

"Expert" menu \rightarrow Communication \rightarrow Web server

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	OffHTML OffOn	On

Function scope of the "Web server functionality" parameter

Option	Description
Off	The Web server is completely disabled.Port 80 is locked.
HTML Off	The HTML version of the Web server is not available.
On	 The complete Web server functionality is available. JavaScript is used. The password is transferred in an encrypted state. Any change to the password is also transferred in an encrypted state.

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

- Via local display
- Via Bedientool "FieldCare"
- Via "DeviceCare" operating tool

8.4.7 Logging out

Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

- 1. Select the **Logout** entry in the function row.
 - ← The home page with the Login box appears.
- 2. Close the Web browser.
- 3. If no longer needed:

Reset the modified properties of the Internet protocol (TCP/IP) $\rightarrow \cong$ 84.


8.5 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.5.1 Connecting the operating tool


Via HART protocol

This communication interface is available in device versions with a HART output.



33 Options for remote operation via HART protocol (active)

- 1 Control system (e.g. PLC)
- 2 Field Communicator 475
- 3 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 4 Commubox FXA195 (USB)
- 5 Field Xpert SFX350 or SFX370
- 6 Field Xpert SMT70
- 7 VIATOR Bluetooth modem with connecting cable
- 8 Transmitter



34 Options for remote operation via HART protocol (passive)

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or computer with operating tool (e.g. FieldCare, DeviceCare, AMS Device Manager, SIMATIC PDM) with COM DTM "CDI Communication TCP/IP"
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 Field Xpert SMT70
- 9 VIATOR Bluetooth modem with connecting cable
- 10 Transmitter

Service interface

Via service interface (CDI-RJ45)


A point-to-point connection can be established via onsite device configuration. With the housing open, the connection is established directly via the service interface (CDI-RJ45) of the device.

An adapter for RJ45 to the M12 plug is optionally available:

Order code for "Accessories", option NB: "Adapter RJ45 M12 (service interface)"

The adapter connects the service interface (CDI-RJ45) to an M12 plug mounted in the cable entry. The connection to the service interface can be established via an M12 plug without opening the device.


Proline 500 - digital transmitter



■ 35 Connection via service interface (CDI-RJ45)

- Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP"
 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Proline 500 transmitter




🛃 36 Connection via service interface (CDI-RJ45)

- 1 Computer with Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated Web server or with "FieldCare", "DeviceCare" operating tool with COM DTM "CDI Communication TCP/IP" 2
- Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI-RJ45) of the measuring device with access to the integrated Web server

Via WLAN interface

The optional WLAN interface is available on the following device version: Order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN"



- Transmitter with integrated WLAN antenna 1
- 2 Transmitter with external WLAN antenna
- 3 LED lit constantly: WLAN reception is enabled on measuring device
- LED flashing: WLAN connection established between operating unit and measuring device 4
- 5 Computer with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft Edge) for accessing the integrated device Web server or with operating tool (e.g. FieldCare, DeviceCare)
- 6 Mobile handheld terminal with WLAN interface and Web browser (e.g. Microsoft Internet Explorer, Microsoft *Edge*) for accessing the integrated device Web server or operating tool (e.g. FieldCare, DeviceCare)
- 7 *Smart phone or tablet (e.g. Field Xpert SMT70)*

Function	WLAN: IEEE 802.11 b/g (2.4 GHz)	
Encryption	WPA2-PSK AES-128 (in accordance with IEEE 802.11i)	
Configurable WLAN channels	1 to 11	
Degree of protection	IP67	
Available antennas	 Internal antenna External antenna (optional) In the event of poor transmission/reception conditions at the place of installation. Only 1 antenna is active at any one time! 	
Range	 Internal antenna: typically 10 m (32 ft) External antenna: typically 50 m (164 ft) 	
Materials (external antenna)	 Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel- plated brass Adapter: Stainless steel and nickel-plated brass Cable: Polyethylene Plug: Nickel-plated brass Angle bracket: Stainless steel 	

Configuring the Internet protocol of the mobile terminal

NOTICE

If the WLAN connection is lost during the configuration, settings made may be lost.

• Make sure that the WLAN connection is not disconnected while configuring the device.

NOTICE

In principle, avoid simultaneous access to the measuring device via the service interface (CDI-RJ45) and the WLAN interface from the same mobile terminal. This could cause a network conflict.

- Only activate one service interface (CDI-RJ45 service interface or WLAN interface).
- ► If simultaneous communication is necessary: configure different IP address ranges, e.g. 192.168.0.1 (WLAN interface) and 192.168.1.212 (CDI-RJ45 service interface).

Preparing the mobile terminal

• Enable WLAN reception on the mobile terminal.

Establishing a connection from the mobile terminal to the measuring device

- 1. In the WLAN settings of the mobile terminal: Select the measuring device using the SSID (e.g. EH Promag 500 A802000).
- 2. If necessary, select the WPA2 encryption method.
- 3. Enter the password: serial number of the measuring device ex-works (e.g. L100A802000).
 - LED on display module flashes: it is now possible to operate the measuring device with a web browser, FieldCare or DeviceCare.

The serial number can be found on the nameplate.

To ensure the safe and swift assignment of the WLAN network to the measuring point, it is advisable to change the SSID name. It should be possible to clearly assign the new SSID name to the measuring point (e.g. tag name) because it is displayed as the WLAN network.

Disconnecting

 After configuring the device: Terminate the WLAN connection between the operating unit and measuring device.

8.5.2 Field Xpert SFX350, SFX370

Function range

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-hazardous area** (SFX350, SFX370) and **hazardous area** (SFX370).

For details, see Operating Instructions BA01202S

Source for device description files

See information $\rightarrow \square 96$

8.5.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

- HART protocol
- CDI-RJ45 service interface $\rightarrow \cong 90$
- WLAN interface $\rightarrow \cong 91$

Typical functions:

- Parameterization of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information $\rightarrow \square 96$

Establishing a connection

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.

└ The **Add device** window opens.

3. Select the CDI Communication TCP/IP option from the list and press OK to confirm.


- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press OK to confirm.

 The CDI Communication TCP/IP (Configuration) window opens.
- 6. Enter the device address in the **IP address** field: 192.168.1.212 and press **Enter** to confirm.

7. Establish the online connection to the device.

For additional information, see Operating Instructions BA00027S and BA00059S

User interface



1 Header

- 2 Picture of device
- 3 Device name
- 4 Tag name
- 5 Status area with status signal $\rightarrow \square 165$
- 6 Display area for current measured values
- 7 Edit bar with additional functions such as save/load, event list and document creation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.5.4 DeviceCare

Function scope

Tool for connecting and configuring Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.

For details, see Innovation Brochure IN01047S

Source for device description files

See information $\rightarrow \square 96$

8.5.5 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

Source for device description files

See data $\rightarrow \square 96$

8.5.6 SIMATIC PDM

Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

Source for device description files

See information on $\rightarrow \square 96$

8.5.7 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See data $\rightarrow \square 96$

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.06.zz	 On the title page of the Operating Instructions On the transmitter nameplate Firmware version Diagnostics → Device information → Firmware version
Release date of firmware version	08.2022	
Manufacturer ID	0x11	Manufacturer ID Diagnostics \rightarrow Device information \rightarrow Manufacturer ID
Device type ID	0x3C	Device type Diagnostics \rightarrow Device information \rightarrow Device type
HART protocol revision	7	HART revision Expert → Communication → HART output → Information → HART revision
Device revision	1	 On the transmitter nameplate Device revision Diagnostics → Device information → Device revision

For an overview of the various firmware versions for the device $\rightarrow \square 178$

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.

Operating tool via HART protocol	Sources for obtaining device descriptions
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
Field Xpert SMT70Field Xpert SMT77	Use update function of handheld terminal
AMS Device Manager (Emerson Process Management)	www.endress.com \rightarrow Download Area
SIMATIC PDM (Siemens)	www.endress.com \rightarrow Download Area
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Volume flow
Secondary dynamic variable (SV)	Totalizer 1
Tertiary dynamic variable (TV)	Totalizer 2
Quaternary dynamic variable (QV)	Totalizer 3

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign PV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign SV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign TV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Output \rightarrow Assign QV

The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity¹⁾
- Electronics temperature

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity²⁾
- Electronics temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3

The range of options increases if the measuring device has one or more application packages.

Device variables

The device variables are permanently assigned. A maximum of 8 device variables can be transmitted:

- 0 = volume flow
- 1 = mass flow
- 2 = corrected volume flow
- 3 = flow velocity
- 4 = conductivity
- 7 = electronic temperature
- 8 = totalizer 1
- 9 = totalizer 2
- 10 = totalizer 3

¹⁾ Visibility depends on order options or device settings

²⁾ Visibility depends on order options or device settings

9.3 Other settings

Burst mode functionality in accordance with HART 7 Specification:

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART output \rightarrow Burst configuration \rightarrow Burst configuration 1 to n

► Burst configuration 1 to n	
Burst mode 1 to n) → 🗎 98
Burst command 1 to n) → 🗎 98
Burst variable 0) → 🗎 99
Burst variable 1) → 🗎 99
Burst variable 2) → 🗎 99
Burst variable 3) → 🗎 99
Burst variable 4) → 🗎 99
Burst variable 5) → 🗎 99
Burst variable 6) → 🗎 99
Burst variable 7) → 🗎 99
Burst trigger mode) → 🗎 99
Burst trigger level	→ 🗎 99
Min. update period	→ 🗎 99
Max. update period	} → 🗎 99

Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Burst mode 1 to n	Activate the HART burst mode for burst message X.	OffOn	Off
Burst command 1 to n	Select the HART command that is sent to the HART master.	 Command 1 Command 2 Command 3 Command 9 Command 33 Command 48 	Command 2

Parameter	Description	Selection / User entry	Factory setting
Burst variable 0	For HART command 9 and 33: select the HART device variable or the process variable.	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature HBSI* Totalizer 1 Totalizer 2 Totalizer 3 Density HART input Percent of range Measured current Primary variable (PV) Secondary variable (SV) Tertiary variable (TV) Quaternary variable (QV) Not used 	Volume flow
Burst variable 1	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 2	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 3	For HART command 9 and 33: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 4	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 5	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 6	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst variable 7	For HART command 9: select the HART device variable or the process variable.	See the Burst variable 0 parameter.	Not used
Burst trigger mode	Select the event that triggers burst message X.	 Continuous Window* Rising* Falling* On change 	Continuous
Burst trigger level	Enter the burst trigger value.	Signed floating-point number	-
	Together with the option selected in the Burst trigger mode parameter the burst trigger value determines the time of burst message X.		
Min. update period	Enter the minimum time span between two burst commands of burst message X.	Positive integer	1 000 ms
Max. update period	Enter the maximum time span between two burst commands of burst message X.	Positive integer	2 000 ms

* Visibility depends on order options or device settings

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- Checklist for "Post-mounting check" $\rightarrow \square 40$
- Checklist for "Post-connection check" $\rightarrow \cong 68$


10.2 Switching on the measuring device

- After a successful function check, switch on the measuring device.
 - ← After a successful startup, the local display switches automatically from the startup display to the operational display.

If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" $\rightarrow \square$ 156.

10.3 Setting the operating language


Factory setting: English or ordered local language



■ 37 Taking the example of the local display

10.4 Configuring the measuring device

- The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.
- Navigation to the Setup menu



38 Taking the example of the local display

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

🗲 Setup		
	Device tag	→ 🗎 102
	► System units	→ 🗎 102
	► I/O configuration	→ 🗎 104
	► Current input 1 to n	→ 🖺 106
	► Status input 1 to n	→ 🖺 105
	► Current output 1 to n	→ 🗎 107
	 Pulse/frequency/switch output 1 to n 	→ 🗎 110
	► Relay output 1 to n	→ 🗎 122
	► Double pulse output	→ 🗎 123
	► Display	→ 🗎 116
	► Low flow cut off	→ 🗎 118
	► Empty pipe detection	→ 🖺 119

► Configure flow damping] → 🖺 124
► Advanced setup	→ 🗎 127

10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.




Image: Barbon State of the operational display with tag name

1 Tag name

Enter the tag name in the "FieldCare" operating tool $\rightarrow \cong 94$

Navigation

"Setup" menu \rightarrow Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

The number of submenus and parameters can vary depending on the device version. Certain submenus and parameters in these submenus are not described in the Operation Instructions. Instead a description is provided in the Special Documentation for the device (→ "Supplementary documentation" section).

Navigation

"Setup" menu → System units

► System units	
Volume flow unit	→ 🗎 103
Volume unit	→ 🗎 103
Conductivity unit	→ 🗎 103
Temperature unit	→ 🗎 103

Mass flow unit) → 🗎 103
Mass unit) → 🗎 103
Density unit) → 🗎 103
Corrected volume flow unit] → 🗎 104
Corrected volume unit] → 🗎 104
	Mass unit Density unit Corrected volume flow unit

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection	Factory setting
Volume flow unit	-	Select volume flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Depends on country: • l/h • gal/min (us)
Volume unit	-	Select volume unit.	Unit choose list	Country-specific: • m ³ • gal (us)
Conductivity unit	The On option is selected in the Conductivity measurement parameter parameter.	Select conductivity unit. <i>Effect</i> The selected unit applies for: • Current output • Frequency output • Switch output • Simulation process variable	Unit choose list	µS/cm
Temperature unit	-	Select temperature unit. Effect The selected unit applies for: • Temperature parameter • Maximum value parameter • Minimum value parameter • External temperature parameter • Maximum value parameter • Maximum value parameter • Minimum value parameter • Maximum value parameter • Maximum value parameter • Maximum value parameter	Unit choose list	Country-specific: • °C • °F
Mass flow unit	-	Select mass flow unit. <i>Effect</i> The selected unit applies for: • Output • Low flow cut off • Simulation process variable	Unit choose list	Country-specific: • kg/h • lb/min
Mass unit	-	Select mass unit.	Unit choose list	Country-specific: kg lb
Density unit	_	Select density unit. <i>Effect</i> The selected unit applies for: • Output • Simulation process variable	Unit choose list	Country-specific: • kg/l • lb/ft ³


Parameter	Prerequisite	Description	Selection	Factory setting
Corrected volume flow unit	-	Select corrected volume flow unit. Result The selected unit applies for: Corrected volume flow parameter ($\rightarrow \square$ 147)	Unit choose list	Country-specific: • Nl/h • Sft ³ /h
Corrected volume unit	-	Select corrected volume unit.	Unit choose list	Country-specific: • Nm ³ • Sft ³

10.4.3 Displaying the I/O configuration

The **I/O configuration** submenu guides the user systematically through all the parameters in which the configuration of the I/O modules is displayed.

Navigation

"Setup" menu \rightarrow I/O configuration



Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry	Factory setting
I/O module 1 to n terminal numbers	Shows the terminal numbers used by the I/O module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
I/O module 1 to n information	Shows information of the plugged I/O module.	 Not plugged Invalid Not configurable Configurable HART 	-
I/O module 1 to n type	Shows the I/O module type.	 Off Current output * Current input * Status input * Pulse/frequency/switch output * Double pulse output * Relay output * 	Off

Parameter	Description	User interface / Selection / User entry	Factory setting
Apply I/O configuration	Apply parameterization of the freely configurable I/O module.	NoYes	No
I/O alteration code	Enter the code in order to change the I/O configuration.	Positive integer	0

* Visibility depends on order options or device settings

10.4.4 Configuring the status input

The **Status input** submenu guides the user systematically through all the parameters that have to be set for configuring the status input.

Navigation

"Setup" menu \rightarrow Status input 1 to n

► Status input 1 to n	
Assign status input) → 🗎 105
Terminal number] → 🗎 105
Active level	→ 🗎 105
Terminal number) → 🖺 105
Response time status input) → 🗎 105
Terminal number) → 🗎 105

Parameter overview with brief description

Parameter	Description	Selection / User interface / User entry	Factory setting
Assign status input	Select function for the status input.	 Off Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override 	Off
Terminal number	Shows the terminal numbers used by the status input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Active level	Define input signal level at which the assigned function is triggered.	HighLow	High
Response time status input	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	5 to 200 ms	50 ms

* Visibility depends on order options or device settings

10.4.5 Configuring the current input

The **"Current input" wizard** guides the user systematically through all the parameters that have to be set for configuring the current input.

Navigation

"Setup" menu \rightarrow Current input

► Current input 1 to n	
Terminal number] → 🗎 106
Signal mode] → 🗎 106
0/4 mA value	→ 🗎 106
20 mA value	→ 🗎 106
Current span	→ 🗎 106
Failure mode	→ 🗎 107
Failure value] → 🗎 107
) [107

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current input module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Signal mode	The measuring device is not approved for use in the hazardous area with type of protection Ex-i.	Select the signal mode for the current input.	 Passive Active[*] 	Active
0/4 mA value	-	Enter 4 mA value.	Signed floating-point number	0
20 mA value	-	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA (4 20.5 mA) 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 020 mA (0 20.5 mA) 	Country-specific: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA)

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Failure mode	-	Define input behavior in alarm condition.	AlarmLast valid valueDefined value	Alarm
Failure value	In the Failure mode parameter, the Defined value option is selected.	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

* Visibility depends on order options or device settings

10.4.6 Configuring the current output

The **Current output** wizard guides you systematically through all the parameters that have to be set for configuring the current output.

Navigation

"Setup" menu \rightarrow Current output

► Current output 1 to n	
Terminal number	→ 🗎 108
Signal mode	→ 🗎 108
Process variable current output	→ 🗎 108
Current range output	→ 🗎 108
Lower range value output	→ 🗎 108
Upper range value output	→ 🗎 108
Fixed current	→ 🗎 108
Damping current output	→ 🗎 109
Failure behavior current output	→ 🗎 109
Failure current	→ 🗎 109

Parameter overview with brief description

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the current output module.	 Not used 26-27 (I/O 1) 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Signal mode	-	Select the signal mode for the current output.	 Active[*] Passive[*] 	Active
Process variable current output	-	Select the process variable for the current output.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature Noise* Coil current shot time* Reference electrode potential against PE* HBSI* Build-up index* Test point 1 Test point 2 Test point 3 	Volume flow
Current range output	_	Select current range for process value output and upper/lower level for alarm signal.	 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 420 mA (4 20.5 mA) 020 mA (0 20.5 mA) Fixed value 	Depends on country: • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA)
Lower range value output	 One of the following options is selected in the Current span parameter (→ 🗎 108): 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 420 mA (4 20.5 mA) 020 mA (0 20.5 mA) 	Enter lower range value for the measured value range.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
Upper range value output	 One of the following options is selected in the Current span parameter (→ 🗎 108): 420 mA NE (3.820.5 mA) 420 mA US (3.920.8 mA) 420 mA (4 20.5 mA) 020 mA (0 20.5 mA) 	Enter upper range value for the measured value range.	Signed floating-point number	Depends on country and nominal diameter
Fixed current	The Fixed current option is selected in the Current span parameter ($\rightarrow \square$ 108).	Defines the fixed output current.	0 to 22.5 mA	22.5 mA

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Damping current output	A process variable is selected in the Assign current output parameter (→ 🗎 108) and one of the following options is selected in the Current span parameter (→ 🗎 108): • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (4 20.5 mA) • 020 mA (0 20.5 mA)	Set reaction time for output signal to fluctuations in the measured value.	0.0 to 999.9 s	1.0 s
Failure behavior current output	A process variable is selected in the Assign current output parameter ($\rightarrow \supseteq 108$) and one of the following options is selected in the Current span parameter ($\rightarrow \supseteq 108$): • 420 mA NE (3.820.5 mA) • 420 mA US (3.920.8 mA) • 420 mA (4 20.5 mA) • 020 mA (0 20.5 mA)	Define output behavior in alarm condition.	 Min. Max. Last valid value Actual value Fixed value 	Max.
Failure current	The Defined value option is selected in the Failure mode parameter.	Enter current output value in alarm condition.	0 to 22.5 mA	22.5 mA

10.4.7 Configuring the pulse/frequency/switch output

The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Pulse/frequency/switch output

Pulse/frequency 1 to n	/switch output	
	Operating mode	→ 🖺 110

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Operating mode	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse

Configuring the pulse output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

 Pulse/frequency/switch output 1 to n 	
Operating mode] → 🗎 111
Terminal number) → 🗎 111
Signal mode) → 🗎 111
Assign pulse output) → 🗎 111
Pulse scaling	→ 🗎 111
Pulse width) → 🗎 111
Failure mode) → 🗎 111
Invert output signal) → 🗎 111

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive
Assign pulse output 1 to n	The Pulse option is selected in the Operating mode parameter.	Select process variable for pulse output.	 Off Volume flow Mass flow Corrected volume flow 	Off
Pulse scaling	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bowtie 110$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \bowtie 111$).	Enter quantity for measured value at which a pulse is output.	Positive floating point number	Depends on country and nominal diameter
Pulse width	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bowtie 110$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \bowtie 111$).	Define time width of the output pulse.	0.05 to 2 000 ms	100 ms
Failure mode	The Pulse option is selected in the Operating mode parameter ($\rightarrow \bowtie 110$) and a process variable is selected in the Assign pulse output parameter ($\rightarrow \bowtie 111$).	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	-	Invert the output signal.	• No • Yes	No

* Visibility depends on order options or device settings

Configuring the frequency output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Pulse/frequency/switch output 1 to n	
Operating mode) → 🗎 112
Terminal number) → 🗎 112
Signal mode	→ 🗎 112

Assign frequency output	→ 🗎 112
Minimum frequency value	→ 🗎 113
Maximum frequency value	→ 🗎 113
Measuring value at minimum frequency	→ 🗎 113
Measuring value at maximum frequency	→ 🗎 113
Failure mode	→ 🗎 113
Failure frequency	→ 🖺 113
Invert output signal	→ 🗎 113

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive
Assign frequency output	In the Operating mode parameter (→ ■ 110), the Frequency option is selected.	Select process variable for frequency output.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Electronics temperature Noise* Coil current shot time* Reference electrode potential against PE* HBSI* Build-up index* Test point 1 Test point 2 Test point 3 	Off

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Minimum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \implies 110$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \implies 112$).	Enter minimum frequency.	0.0 to 10000.0 Hz	0.0 Hz
Maximum frequency value	The Frequency option is selected in the Operating mode parameter ($\rightarrow \square 110$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \square 112$).	Enter maximum frequency.	0.0 to 10000.0 Hz	10 000.0 Hz
Measuring value at minimum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \implies 110$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \implies 112$).	Enter measured value for minimum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	The Frequency option is selected in the Operating mode parameter ($\rightarrow \boxminus 110$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \trianglerighteq 112$).	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	The Frequency option is selected in the Operating mode parameter ($\rightarrow \implies 110$) and a process variable is selected in the Assign frequency output parameter ($\rightarrow \implies 112$).	Define output behavior in alarm condition.	 Actual value Defined value 0 Hz 	0 Hz
Failure frequency	In the Operating mode parameter ($\rightarrow \square 110$), the Frequency option is selected, in the Assign frequency output parameter ($\rightarrow \square 112$) a process variable is selected, and in the Failure mode parameter, the Defined value option is selected.	Enter frequency output value in alarm condition.	0.0 to 12 500.0 Hz	0.0 Hz
Invert output signal	-	Invert the output signal.	NoYes	No

Configuring the switch output

Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

 Pulse/frequency/switch output 1 to n 	
Operating mode] → 🗎 114
Terminal number) → 🗎 114
Signal mode] → 🗎 114
Switch output function) → 🗎 115
Assign diagnostic behavior] → 🗎 115
Assign limit] → 🗎 115
Assign flow direction check] → 🗎 115
Assign status] → 🗎 115
Switch-on value) → 🗎 115
Switch-off value	→ 🗎 115
Switch-on delay	→ 🗎 115
Switch-off delay	→ 🗎 116
Failure mode] → 🗎 116
Invert output signal] → 🗎 116

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Terminal number	-	Shows the terminal numbers used by the PFS output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4)* 	-
Signal mode	-	Select the signal mode for the PFS output.	 Passive Active * Passive NE 	Passive

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	 Off On Diagnostic behavior Limit Flow direction check Status 	Off
Assign diagnostic behavior	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Diagnostic behavior option is selected. 	Select diagnostic behavior for switch output.	 Alarm Alarm or warning Warning	Alarm
Assign limit	 In the Operating mode parameter, the Switch option is selected. In the Switch output function parameter, the Limit option is selected. 	Select process variable for limit function.	 Off Volume flow Mass flow Corrected volume flow Flow velocity* Conductivity* Totalizer 1 Totalizer 2 Totalizer 3 Electronics temperature 	Volume flow
Assign flow direction check	 The Switch option is selected in the Operating mode parameter. The Flow direction check option is selected in the Switch output function parameter. 	Select process variable for flow direction monitoring.	 Off Volume flow Mass flow Corrected volume flow 	Volume flow
Assign status	 The Switch option is selected in the Operating mode parameter. The Status option is selected in the Switch output function parameter. 	Select device status for switch output.	 Empty pipe detection Low flow cut off Build-up index[*] HBSI limit exceeded[*] 	Empty pipe detection
Switch-on value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
Switch-off value	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
Switch-on delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Switch-off delay	 The Switch option is selected in the Operating mode parameter. The Limit option is selected in the Switch output function parameter. 	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open
Invert output signal	-	Invert the output signal.	NoYes	No

10.4.8 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu \rightarrow Display

► Display	
Format display	→ 🗎 117
Value 1 display	→ 🗎 117
0% bargraph value 1	→ 🗎 117
100% bargraph value 1	→ 🗎 117
Value 2 display	→ 🗎 117
Value 3 display	→ 🗎 117
0% bargraph value 3	→ 🗎 117
100% bargraph value 3	→ 🗎 117
Value 4 display	→ 🗎 117

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Mass flow Corrected volume flow Flow velocity Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 2* Current output 4* Electronics temperature HBSI* Noise* Coil current shot time* Reference electrode potential against PE* Build-up index* Test point 1 Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 1/h • 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \square 117)$	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \square 117)$	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None


Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \square 117)$	None

10.4.9 Configuring the low flow cut off

The **Low flow cut off** wizard systematically guides the user through all the parameters that must be set to configure low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off



Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	OffVolume flowMass flowCorrected volume flow	Volume flow
On value low flow cutoff	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong 118$).	Enter on value for low flow cut off.	Positive floating- point number	Depends on country and nominal diameter
Off value low flow cutoff	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong 118$).	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 118).	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.4.10 Configuring empty pipe detection

 The measuring devices are calibrated with water (approx. 500 µS/cm) at the factory. For liquids with a lower conductivity, it is advisable to perform a new full pipe adjustment onsite.

• It is recommended to perform a new empty pipe adjustment onsite if a cable that is longer than 50 meters is used.

The **Empty pipe detection** submenu contains parameters that must be configured for the configuration of empty pipe detection.

Navigation

"Setup" menu \rightarrow Empty pipe detection

► Empty pipe detection	
Empty pipe detection	→ 🗎 119
New adjustment	→ 🖺 119
Progress	→ 🗎 119
Switch point empty pipe detection	→ 🗎 119
Response time empty pipe detection	→ 🗎 119

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	-	Switch empty pipe detection on and off.	OffOn	Off
New adjustment	The On option is selected in the Empty pipe detection parameter.	Select type of adjustment.	CancelEmpty pipe adjustFull pipe adjust	Cancel
Progress	The On option is selected in the Empty pipe detection parameter.	Shows the progress.	OkBusyNot ok	-
Switch point empty pipe detection	The On option is selected in the Empty pipe detection parameter.	Enter the switch point in % of the difference between the two adjustment values. The lower the percentage, the earlier the pipe is detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 119).	Use this function to enter the minimum time (hold time) the signal must be present before diagnostic message S962 "Empty pipe" is triggered in the event of a partially filled or empty measuring pipe.	0 to 100 s	1 s

10.4.11 Configuring the HART input

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input

► HART input		
► Config	uration	→ 🗎 120
	Capture mode	→ 🗎 120
	Device ID	→ 🗎 120
	Device type	→ 🗎 121
	Manufacturer ID	→ 🗎 121
	Burst command	→ 🗎 121
	Slot number	→ 🗎 121
	Timeout	→ 🗎 121
	Failure mode	→ 🗎 121
	Failure value	→ 🗎 121
► Input		→ 🗎 121
	Value	→ 🗎 121
	Status	→ 🗎 121

"Configuration" submenu

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input \rightarrow Configuration

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Capture mode	-	Select capture mode via burst or master communication.	 Off Burst network Master network	Off
Device ID	The Master network option is selected in the Capture mode parameter.	Enter device ID of external device.	 6-digit value: Via local operation: enter as hexadecimal or decimal number Via operating tool: enter as decimal number 	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Device type	In the Capture mode parameter, the Master network option is selected.	Enter device type of external device.	2-digit hexadecimal number	0x00
Manufacturer ID	The Master network option is selected in the Capture mode parameter.	Enter manufacture ID of external device.	 2-digit value: Via local operation: enter as hexadecimal or decimal number Via operating tool: enter as decimal number 	0
Burst command	The Burst network option or the Master network option are selected in the Capture mode parameter.	Select command to read in external process variable.	 Command 1 Command 3 Command 9 Command 33 	Command 1
Slot number	The Burst network option or the Master network option is selected in the Capture mode parameter.	Define position of external process variable in burst command.	1 to 8	1
Timeout	The Burst network option or the Master network option is selected in the Capture mode parameter.	Enter deadline for process variable of external device. If the waiting time is exceeded, the SF410 Data transfer diagnostic message is displayed.	1 to 120 s	5 s
Failure mode	In the Capture mode parameter, the Burst network option or Master network option is selected.	Define behavior if external process variable is missed.	 Alarm Last valid value Defined value	Alarm
Failure value	 The following conditions are met: In the Capture mode parameter, the Burst network option or Master network option is selected. In the Failure mode parameter, the Defined value option is selected. 	Enter value to be used by the device if input value from external device is missing.	Signed floating-point number	0

"Input" submenu

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART input \rightarrow Input

Parameter	Description	User interface
Value	Shows the value of the device variable recorded by the HART input.	Signed floating-point number
Status	Shows the status of the device variable recorded by the HART input.	Manual/FixedGoodPoor accuracyBad

10.4.12 Configuring the relay output

The **Relay output** wizard guides the user systematically through all the parameters that have to be set for configuring the relay output.

Navigation

"Setup" menu \rightarrow Relay output 1 to n

► Relay output 1 to n	
Terminal number	→ 🗎 122
Relay output function] → 🗎 122
Assign flow direction check) → 🗎 122
Assign limit) → 🗎 123
Assign diagnostic behavior	→ 🗎 123
Assign status) → 🗎 123
Switch-off value) → 🗎 123
Switch-off delay) → 🗎 123
Switch-on value	→ 🗎 123
Switch-on delay	→ 🗎 123
Failure mode	→ 🗎 123

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Terminal number	-	Shows the terminal numbers used by the relay output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 20-21 (I/O 4) 	-
Relay output function	-	Select the function for the relay output.	 Closed Open Diagnostic behavior Limit Flow direction check Digital Output 	Closed
Assign flow direction check	The Flow direction check option is selected in the Relay output function parameter.	Select process variable for flow direction monitoring.	 Off Volume flow Mass flow Corrected volume flow	Volume flow

Parameter	Prerequisite	Description	User interface / Selection / User entry	Factory setting
Assign limit	The Limit option is selected in the Relay output function parameter.	Select process variable for limit function.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Totalizer 1 Totalizer 2 Totalizer 3 Electronics temperature 	Volume flow
Assign diagnostic behavior	In the Relay output function parameter, the Diagnostic behavior option is selected.	Select diagnostic behavior for switch output.	AlarmAlarm or warningWarning	Alarm
Assign status	In the Relay output function parameter, the Digital Output option is selected.	Select device status for switch output.	 Partially filled pipe detection Low flow cut off HBSI limit exceeded* 	Partially filled pipe detection
Switch-off value	In the Relay output function parameter, the Limit option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal(us)/min
Switch-off delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Switch-on value	The Limit option is selected in the Relay output function parameter.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal(us)/min
Switch-on delay	In the Relay output function parameter, the Limit option is selected.	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open

10.4.13 Configuring the double pulse output

The **Double pulse output** submenu guides the user systematically through all the parameters that have to be set for configuring the double pulse output.

Navigation

"Setup" menu \rightarrow Double pulse output

► Double pulse output	
Signal mode	→ 🗎 124
Master terminal number	→ 🗎 124
Assign pulse output	→ 🗎 124

Measuring mode) → 🗎 124
Value per pulse	→ 🗎 124
Pulse width	→ 🗎 124
Failure mode	→ 🗎 124
Invert output signal	→ 🗎 124

Parameter	Description	Selection / User interface / User entry	Factory setting
Signal mode	Select the signal mode for the double pulse output.	 Passive Active* Passive NE 	Passive
Master terminal number	Shows the terminal numbers used by the master of the double pulse output module.	 Not used 24-25 (I/O 2) 22-23 (I/O 3) 	-
Assign pulse output	Select process variable for pulse output.	 Off Volume flow Mass flow Corrected volume flow	Off
Measuring mode	Select measuring mode for pulse output.	Forward flowForward/Reverse flowReverse flowReverse flow compensation	Forward flow
Value per pulse	Enter measured value at which a pulse is output.	Signed floating-point number	Depends on country and nominal diameter
Pulse width	Define time width of the output pulse.	0.5 to 2 000 ms	0.5 ms
Failure mode	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	Invert the output signal.	NoYes	No

* Visibility depends on order options or device settings

10.4.14 Configuring flow damping

The **Configure flow damping** wizard guides the user systematically through the parameters, depending on the selected scenario:

- Configuration of damping for the application
- To configure flow damping for the specific requirements of the process application. • Replace old device
- To adopt the flow damping for the new device in the event of a device replacement. • Restoring factory settings
 - To restore the factory settings of all the parameters that are relevant for flow damping.

Navigation

"Setup" menu \rightarrow Configure flow damping

Configure flow damping

Scenario	→ 🖺 125
Old device	→ 🖺 125
CIP filter on	→ 🗎 125
Damping level	→ 🗎 125
Flow change rate	→ 🖺 125
Application	→ 🗎 125
Pulsating flow	→ 🗎 126
Flow peaks	→ 🗎 126
Damping level	→ 🗎 125
Filter options	→ 🗎 126
Median filter depth	→ 🗎 126
Flow damping	→ 🗎 126
Support ID	→ 🖺 126
Save settings	→ 🗎 126


Parameter	Description	Selection / User interface	Factory setting
Scenario	Select the applicable scenario.	 Replace old device Configure damping for application Restore factory settings 	Configure damping for application
Old device	Select the measuring device to replace.	 Promag 10 (pre-2021) Promag 50/53 Promag 55 H 	Promag 50/53
CIP filter on	Indicate whether the CIP filter was applied for the device to be replaced.	NoYes	No
Damping level	Select the degree of damping to apply.	DefaultWeakStrong	Default
Flow change rate	Select the rate at which the flow changes.	 Once a day or less Once an hour or less Once a minute or less Once a second or more 	Once a minute or less
Application	Select the type of application that applies.	Display flowControl loopTotalizingBatching	Display flow

Parameter	Description	Selection / User interface	Factory setting
Pulsating flow	Indicate whether the process is characterized by pulsating flow (e.g. due to a displacement pump).		No
Flow peaks	Select the frequency at which flow interference peaks occur.	 Never Sporadically Regularly Continuously 	Never
Response Time		FastSlowNormal	Normal
Filter options	Shows the type of flow filter recommended for damping.	 Adaptive Adaptive CIP on Dynamic Dynamic CIP on Binomial Binomial CIP on 	Binomial
Median filter depth	Shows median filter depth recommended for damping.	0 to 255	6
Flow damping	Shows the flow filter depth recommended for damping.	0 to 15	7
Support ID	If the recommended settings are not satisfactory: please contact your Endress +Hauser service organization with the support ID displayed.	0 to 65 535	0
Save settings	Indicate whether to save the recommended settings.	 Cancel Save[*] 	Cancel
Filter Wizard result:		CompletedAborted	Aborted

10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu




The number of submenus and parameters can vary depending on the device version and the available application packages. These submenus and their parameters are explained in the Special Documentation for the device and not in Operating Instructions.

- For detailed information on the parameter descriptions for application packages: Special Documentation for the device
- For detailed information on the SIL parameter descriptions, see the Functional Safety Manual $\rightarrow \cong 219$

Navigation

"Setup" menu → Advanced setup

► Advanced setup		
Enter access	s code	→ 🗎 128
► Sensor a	djustment	→ 🗎 128



10.5.1 Using the parameter to enter the access code

Navigation

"Setup" menu → Advanced setup

Parameter overview with brief description

Parameter	Description	User entry
Enter access code	1 1	Max. 16-digit character string comprising numbers, letters and special characters

10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment

► Sensor adjustment	
Installation direction	→ 🗎 128

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Installation direction	Select sign of flow direction.	Forward flowReverse flow	Forward flow

10.5.3 Configuring the totalizer

In the **"Totalizer 1 to n" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to n

► Totalizer 1 to n	
Assign process variable	→ 🗎 129
Unit totalizer 1 to n	→ 🗎 129
Totalizer operation mode	→ 🗎 129
Failure mode	→ 🗎 129

Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	 Off Volume flow Mass flow Corrected volume flow	Volume flow
Unit totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie$ 129) of the Totalizer 1 to n submenu.	Select the unit for the process variable of the totalizer.	Unit choose list	Depends on country: l gal (us)
Totalizer operation mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \bowtie$ 129) of the Totalizer 1 to n submenu.	Select totalizer calculation mode.	NetForwardReverse	Net
Failure mode	A process variable is selected in the Assign process variable parameter ($\rightarrow \boxdot 129$) of the Totalizer 1 to n submenu.	Select totalizer behavior in the event of a device alarm.	 Hold Continue Last valid value + continue 	Hold

10.5.4 Carrying out additional display configurations

In the **Display** submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display	
Format display	→ 🗎 131
Value 1 display	→ 🗎 131
0% bargraph value 1	→ 🖹 131
100% bargraph value 1	→ 🖹 131
Decimal places 1	→ 🖹 131
Value 2 display	→ 🗎 131
Decimal places 2	→ 🖹 131
Value 3 display	→ 🗎 131
0% bargraph value 3	→ 🗎 131
100% bargraph value 3	→ 🗎 132
Decimal places 3	→ 🗎 132
Value 4 display	→ 🗎 132
Decimal places 4	→ 🗎 132
Display language	→ 🗎 133
Display interval	→ 🗎 133
Display damping	→ 🗎 133
Header	→ 🗎 133
Header text	→ 🗎 133
Separator	→ 🗎 133
Backlight	→ 🗎 133

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 Volume flow Mass flow Corrected volume flow Flow velocity Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 3* Current output 4* Electronics temperature HBSI* Noise* Coil current shot time* Reference electrode potential against PE* Build-up index* Test point 1 Test point 3 	Volume flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXX X.XXXX 	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxx 	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
0% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 l/h • 0 gal/min (us)

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
100% bargraph value 3	A selection was made in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	X.XX
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxx x.xxxx 	x.xx
Value 5 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
0% bargraph value 5	An option was selected in the Value 5 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
100% bargraph value 5	An option was selected in the Value 5 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 5	A measured value is specified in the Value 5 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxx x.xxxxx x.xxxxx x.xxxxx 	X.XX
Value 6 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Decimal places 6	A measured value is specified in the Value 6 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxxx x.xxxxx x.xxxxx x.xxxxx 	x.xx
Value 7 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
0% bargraph value 7	An option was selected in the Value 7 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	Depends on country: • 0 l/h • 0 gal/min (us)
100% bargraph value 7	An option was selected in the Value 7 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 7	A measured value is specified in the Value 7 display parameter.	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXXX X.XXXXX X.XXXXX X.XXXXXX 	x.xx

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Value 8 display	A local display is provided.	Select the measured value that is shown on the local display.	For the picklist, see the Value 1 display parameter $(\rightarrow \cong 117)$	None
Decimal places 8	A measured value is specified in the Value 8 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx x.xxxx x.xxxxx x.xxxxx x.xxxxx 	X.XX
Display language	A local display is provided.	Set display language.	 English Deutsch Français Español Italiano Nederlands Portuguesa Polski pycский язык (Russian) Svenska Türkçe 中文 (Chinese) 日本語 (Japanese) 한국어 (Korean) tiếng Việt (Vietnamese) čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	 Device tag Free text	Device tag
Header text	The Free text option is selected in the Header parameter.	Enter display header text.	Max. 12 characters, such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	 . (point) , (comma) 	. (point)
Backlight	One of the following conditions is met: • Order code for "Display; operation", option F "4-line, illum.; touch control" • Order code for "Display; operation", option G "4-line, illum.; touch control +WLAN"	Switch the local display backlight on and off.	DisableEnable	Enable

10.5.5 Performing electrode cleaning

The **Electrode cleaning cycle** submenu contains the parameters that must be set for the configuration of electrode cleaning.

The submenu is only available if the device was ordered with electrode cleaning.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Electrode cleaning cycle

► Electrode cleaning cycle	
Electrode cleaning cycle] → 🗎 134
ECC duration) → 🗎 134
ECC recovery time] → 🗎 134
ECC interval] → 🗎 134
ECC polarity] → 🗎 134

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning cycle	Bei folgendem Bestellmerkmal: "Anwendungspaket", Option EC "ECC Elektrodenreinigung"	Switch electrode cleaning on or off.	OffOn	On
ECC duration	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the duration of the cleaning phase of the cycle. Diag. msg. no. 530 is displayed until the cleaning phase and recovery phase are complete.	0.01 to 30 s	2 s
ECC recovery time	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the maximum timespan after the cleaning phase for recovery before measurement resumes during which the output signal values are frozen.	1 to 600 s	60 s
ECC interval	For the following order code: "Application package", option EC "ECC electrode cleaning"	Specify the interval between one cleaning cycle and the next.	0.5 to 168 h	0.5 h
ECC polarity	For the following order code: "Application package", option EC "ECC electrode cleaning"	Select the polarity of the electrode cleaning circuit.	PositiveNegative	Depends on the electrode material: • Tantalum: Negative option • Platinum, Alloy C22, stainless steel: Positive option

10.5.6 WLAN configuration

The **WLAN Settings** submenu guides the user systematically through all the parameters that have to be set for the WLAN configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow WLAN settings

► WLAN settings	
WLAN	→ 🗎 135
WLAN mode	→ 🗎 135
SSID name	→ 🗎 135
Network security	→ 🗎 136
Security identification	→ 🗎 136
User name	→ 🗎 136
WLAN password	→ 🗎 136
WLAN IP address	→ 🗎 136
WLAN MAC address	→ 🗎 136
WLAN passphrase	→ 🗎 136
Assign SSID name	→ 🗎 136
SSID name	→ 🗎 136
Connection state	→ 🗎 136
Received signal strength	→ 🗎 136

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
WLAN	-	Switch WLAN on and off.	DisableEnable	Enable
WLAN mode	-	Select WLAN mode.	WLAN access pointWLAN Client	WLAN access point
SSID name	The client is activated.	Enter the user-defined SSID name (max. 32 characters).	-	-

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Network security	-	Select the security type of the WLAN network.	 Unsecured WPA2-PSK EAP-PEAP with MSCHAPv2* EAP-PEAP MSCHAPv2 no server authentic.* EAP-TLS* 	WPA2-PSK
Security identification	_	Select security settings and download these settings via menu Data management > Security > WLAN.	Trusted issuer certificateDevice certificateDevice private key	-
User name	-	Enter user name.	-	-
WLAN password	-	Enter WLAN password.	-	-
WLAN IP address	-	Enter IP address of the WLAN interface of the device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
WLAN MAC address	-	Enter MAC address of the WLAN interface of the device.	Unique 12-digit character string comprising letters and numbers	Each measuring device is given an individual address.
WLAN passphrase	The WPA2-PSK option is selected in the Security type parameter.	Enter the network key (8 to 32 characters). The network key supplied with the device should be changed during commissioning for security reasons.	8 to 32-digit character string comprising numbers, letters and special characters (without spaces)	Serial number of the measuring device (e.g. L100A802000)
Assign SSID name	-	Select which name will be used for SSID: device tag or user- defined name.	Device tagUser-defined	User-defined
SSID name	 The User-defined option is selected in the Assign SSID name parameter. The WLAN access point option is selected in the WLAN mode parameter. 	Enter the user-defined SSID name (max. 32 characters). The user-defined SSID name may only be assigned once. If the SSID name is assigned more than once, the devices can interfere with one another.	Max. 32-digit character string comprising numbers, letters and special characters	EH_device designation_last 7 digits of the serial number (e.g. EH_Promag_500_A 802000)
Connection state	-	Displays the connection status.	ConnectedNot connected	Not connected
Received signal strength	-	Shows the received signal strength.	LowMediumHigh	High

10.5.7 Configuration management

After commissioning, you can save the current device configurationor restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup** submenu.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Configuration backup

► Configuration backup	
Operating time	→ 🗎 137
Last backup	→ 🗎 137
Configuration management	→ 🗎 137
Backup state	→ 🗎 137
Comparison result	→ 🗎 137

Parameter overview with brief description

Parameter	Description	User interface / Selection	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Last backup	Shows when the last data backup was saved to HistoROM backup.	Days (d), hours (h), minutes (m) and seconds (s)	-
Configuration management	Select action for managing the device data in the HistoROM backup.	 Cancel Execute backup Restore[*] Compare[*] Clear backup data 	Cancel
Backup state	Shows the current status of data saving or restoring.	 None Backup in progress Restoring in progress Delete in progress Compare in progress Restoring failed Backup failed 	None
Comparison result	Comparison of current device data with HistoROM backup.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible 	Check not done

* Visibility depends on order options or device settings

Function scope of the "Configuration management" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Execute backup	A backup copy of the current device configuration is saved from the HistoROM backup to the memory of the device. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the device memory to the device's HistoROM backup. The backup copy includes the transmitter data of the device.

Options	Description
Compare	The device configuration saved in the device memory is compared with the current device configuration of the HistoROM backup.
Clear backup data	The backup copy of the device configuration is deleted from the memory of the device.

🚹 HistoROM backup

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.5.8 Using parameters for device administration

The **Administration** submenu systematically guides the user through all the parameters that can be used for device administration purposes.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

► Administration	
► Define access code	→ 🗎 138
► Reset access code	→ 🗎 139
Device reset	→ 🗎 139

Using the parameter to define the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

► Define access code	
Define access code) → 🗎 138
Confirm access code] → 🗎 138

Parameter	Description	User entry
	1 1 5	Max. 16-digit character string comprising numbers, letters and special characters
Confirm access code		Max. 16-digit character string comprising numbers, letters and special characters

Using the parameter to reset the access code

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Reset access code

► Reset access code	
Operating time] → 🗎 139
Reset access code] → 🗎 139

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Operating time	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	-
Reset access code	 Reset access code to factory settings. For a reset code, contact your Endress+Hauser service organization. The reset code can only be entered via: Web browser DeviceCare, FieldCare (via CDI-RJ45 service interface) Fieldbus 	Character string comprising numbers, letters and special characters	0x00

Using the parameter to reset the device

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
	Reset the device configuration - either entirely or in part - to a defined state.	 Cancel To delivery settings Restart device Restore S-DAT backup[*] 	Cancel

* Visibility depends on order options or device settings

10.6 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation "Diagnostics" menu → Simulation

► Simulation			
Assign simulat	ion process variable	}	₿ 141
Process variabl	e value	}	₿ 141
Current input 1	to n simulation	}	🗎 142
Value current i	nput 1 to n	}	🗎 142
Status input sin	nulation 1 to n	} →	₿ 142
Input signal lev	rel 1 to n	}	🗎 142
Current output	1 to n simulation	}	₿ 141
Current output	value	, }	₿ 141
Frequency out	out 1 to n simulation] →	₿ 141
Frequency out	out 1 to n value	〕 │	₿ 141
	mulation 1 to n	〕 │	₿ 141
Pulse value 1 t]	₿ 141
	simulation 1 to n]	₿ 141
Switch state 1			■ 141
]	■ 141
	to n simulation]	□ 141□ 141
Switch state 1]	
Pulse output si	mulation		141
Pulse value]	141
Device alarm si]	₿ 141
Diagnostic ever	nt category) →	₿ 142
Diagnostic even	nt simulation		142

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* 	Off
Process variable value	A process variable is selected in the Assign simulation process variable parameter $(\rightarrow \cong 141)$.	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Current output 1 to n simulation	-	Switch the simulation of the current output on and off.	OffOn	Off
Current output value	In the Current output 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA	3.59 mA
Frequency output 1 to n simulation	In the Operating mode parameter, the Frequency option is selected.	Switch the simulation of the frequency output on and off.	OffOn	Off
Frequency output 1 to n value	In the Frequency simulation 1 to n parameter, the On option is selected.	Enter the frequency value for the simulation.	0.0 to 12 500.0 Hz	0.0 Hz
Pulse output simulation 1 to n	In the Operating mode parameter, the Pulse option is selected.	 Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (→ □ 111) defines the pulse width of the pulses output. 	 Off Fixed value Down-counting value 	Off
Pulse value 1 to n	In the Pulse output simulation 1 to n parameter, the Down-counting value option is selected.	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation 1 to n	In the Operating mode parameter, the Switch option is selected.	Switch the simulation of the switch output on and off.	OffOn	Off
Switch state 1 to n	-	Select the status of the status output for the simulation.	OpenClosed	Open
Relay output 1 to n simulation	-	Switch simulation of the relay output on and off.	OffOn	Off
Switch state 1 to n	The On option is selected in the Switch output simulation 1 to n parameter parameter.	Select status of the relay output for the simulation.	 Open Closed	Open
Pulse output simulation	-	Set and switch off the pulse output simulation.	OffFixed valueDown-counting	Off
		For Fixed value option: Pulse width parameter defines the pulse width of the pulses output.	value	
Pulse value	In the Pulse output simulation parameter, the Down-counting value option is selected.	Set and switch off the pulse output simulation.	0 to 65 535	0
Device alarm simulation	-	Switch the device alarm on and off.	OffOn	Off

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off
Current input 1 to n simulation	-	Switch simulation of the current input on and off.	OffOn	Off
Value current input 1 to n	In the Current input 1 to n simulation parameter, the On option is selected.	Enter the current value for simulation.	0 to 22.5 mA	0 mA
Status input simulation 1 to n	-	Switch simulation of the status input on and off.	OffOn	Off
Input signal level 1 to n	In the Status input simulation parameter, the On option is selected.	Select the signal level for the simulation of the status input.	HighLow	High

10.7 Protecting settings from unauthorized access

The following write protection options exist in order to protect the configuration of the measuring device from unintentional modification:

- Protect access to parameters via access code $\rightarrow \implies 142$
- Protect access to local operation via key locking \rightarrow 🗎 82
- Protect access to measuring device via write protection switch \rightarrow 🗎 144

10.7.1 Write protection via access code

The effects of the user-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are writeprotected and their values can no longer be changed.
- Device access is protected via the Web browser, as are the parameters for the measuring device configuration.
- Device access is protected via FieldCare or DeviceCare (via CDI-RJ45 service interface), as are the parameters for the measuring device configuration.

Defining the access code via local display

- **1**. Navigate to the **Define access code** parameter ($\rightarrow \square$ 138).
- 2. Define a max. 16-digit character string comprising numbers, letters and special characters as the access code.
- **3.** Enter the access code again in the **Confirm access code** parameter ($\rightarrow \triangleq 138$) to confirm the code.
 - └ The ⓓ-symbol appears in front of all write-protected parameters.


The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected

parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.

- If parameter write protection is activated via an access code, it can also only be deactivated via this access code $\rightarrow \cong 81$.
 - The user role with which the user is currently logged on via the local display
 - → 🗎 81 is indicated by the Access status parameter. Navigation path: Operation → Access status

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from parameter write protection via the local display. Despite the user-specific access code, they can always be modified, even if the other parameters are locked.



Defining the access code via the Web browser

- **1**. Navigate to the **Define access code** parameter ($\rightarrow \square$ 138).
- 2. Define a max. 16-digit numeric code as an access code.
- **3.** Enter the access code again in the **Confirm access code** parameter ($\rightarrow \implies 138$) to confirm the code.
 - ← The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
 - - The user role with which the user is currently logged on via Web browser is indicated by the Access status parameter. Navigation path: Operation → Access status

Resetting the access code

If you misplace the user-specific access code, it is possible to reset the code to the factory setting. A reset code must be entered for this purpose. The user-specific access code can then be defined again afterwards.

Via Web browser, FieldCare, DeviceCare (via CDI-RJ45 service interface), fieldbus

You can only obtain a reset code from your local Endress+Hauser service organization. The code must be calculated explicitly for every device.

1. Note down the serial number of the device.

2. Read off the **Operating time** parameter.

- 3. Contact the local Endress+Hauser service organization and tell them the serial number and the operating time.
 - └ Get the calculated reset code.

4. Enter the reset code in the **Reset access code** parameter ($\Rightarrow \square 139$).

- → The access code has been reset to the factory setting **0000**. It can be redefined $\rightarrow \cong 142$.
- For IT security reasons, the calculated reset code is only valid for 96 hours from the specified operating time and for the specific serial number. If you cannot return to the device within 96 hours, you should either increase the operating time you read out by a few days or switch off the device.

10.7.2 Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):

- Via local display
- Via HART protocol


Proline 500 - digital

WARNING

Excessive tightening torque applied to the fixing screws!


Risk of damaging the plastic transmitter.

► Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)




- 1. Open the housing cover.
- 2. Remove the display module.
- 3. Fold open the terminal cover.

- **4.** Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.
 - → In the Locking status parameter, the Hardware locked option is displayed
 → 146. In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.




- **5.** Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - ► No option is displayed in the Locking status parameter → <a>Pmin 146. On the local display, the <a>Pmin symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

Proline 500



Setting the write protection (WP) switch on the main electronics module to the **ON** position enables hardware write protection.

In the **Locking status** parameter, the **Hardware locked** option is displayed $\rightarrow \square$ 146. In addition, on the local display the \square symbol appears in front of the parameters in the header of the operational display and in the navigation view.



- 2. Setting the write protection (WP) switch on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - Isomorphic to be based on the locking status parameter → 146. On the local display, the B symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

11 Operation

11.1 Reading off the device locking status

Device active write protection: Locking status parameter

Operation \rightarrow Locking status

Function scope of the "Locking status" parameter

Options	Description
None	The access authorization displayed in the Access status parameter applies $\rightarrow \square$ 81. Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the PCB board. This locks write access to the parameters (e.g. via local display or operating tool) $\rightarrow \square$ 144.
SIL locked	The SIL mode is enabled. This locks write access to the parameters (e.g. via local display or operating tool).
Temporarily locked	Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset, etc.). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Petailed information:

- To configure the operating language $\rightarrow \implies 100$
- For information on the operating languages supported by the measuring device $\rightarrow \ \textcircled{B}\ 211$

11.3 Configuring the display

Detailed information:

- On the basic settings for the local display $\rightarrow \square 116$
- On the advanced settings for the local display $\rightarrow \implies 130$

11.4 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

11.4.1 "Process variables" submenu

The **Process variables** submenu contains all the parameters needed to display the current measured values for each process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables

► Process variables	
Volume flow	→ 🗎 147
Mass flow	→ 🗎 147

Cor	rected volume flow	÷	🖺 147
Flow	w velocity	÷	147
Con	uductivity	÷	147
Der	asity	→	₿ 147

Parameter	Description	User interface
Volume flow	Displays the volume flow that is currently measured.	Signed floating-point number
	Dependency The unit is taken from: Volume flow unit parameter $(\Rightarrow \square 103)$	
Mass flow	Displays the mass flow that is currently calculated.	Signed floating-point number
	Dependency The unit is taken from the Mass flow unit parameter $(\neq \square 103).$	
Corrected volume flow	Displays the corrected volume flow that is currently calculated.	Signed floating-point number
	Dependency The unit is taken from: Corrected volume flow unit parameter $(\rightarrow \cong 104)$	
Flow velocity	Displays the flow velocity that is currently calculated.	Signed floating-point number
Conductivity	Displays the conductivity that is currently measured.	Signed floating-point number
	Dependency The unit is taken from the Conductivity unit parameter $(\rightarrow \square 103)$.	
Density	Displays the current fixed density or density read in from an external device.	Signed floating-point number
	<i>Dependency</i> The unit is taken from the Density unit parameter.	

11.4.2 "Totalizer" submenu

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer

► Totalizer	
Totalizer value 1 to n	→ 🗎 148
Totalizer overflow 1 to n	→ 🗎 148

Parameter	Prerequisite	Description	User interface
Totalizer value 1 to n	A process variable is selected in the Assign process variable parameter $(\rightarrow \bigoplus 129)$ of the Totalizer 1 to n submenu.	Displays the current totalizer counter reading.	Signed floating-point number
Totalizer overflow 1 to n	A process variable is selected in the Assign process variable parameter $(\rightarrow \cong 129)$ of the Totalizer 1 to n submenu.	Displays the current totalizer overflow.	Integer with sign

11.4.3 "Input values" submenu

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values


► Input values		
	► Current input 1 to n	→ 🖺 148
	► Status input 1 to n	→ 🖺 148

Input values of current input

The **Current input 1 to n** submenu contains all the parameters needed to display the current measured values for every current input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Current input 1 to n



Parameter overview with brief description

Parameter	Description	User interface
Measured values 1 to n	Displays the current input value.	Signed floating-point number
Measured current 1 to n	Displays the current value of the current input.	0 to 22.5 mA

Input values of status input

The **Status input 1 to n** submenu contains all the parameters needed to display the current measured values for every status input.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Input values \rightarrow Status input 1 to n

► Status input 1 to n]	
Value status input	→ 🗎 149	

Parameter overview with brief description

Parameter	Description	User interface
Value status input	Shows the current input signal level.	HighLow

11.4.4 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values

► Output values	
► Current output 1 to n	→ 🗎 149
Pulse/frequency/switch output 1 to n	→ 🗎 150
► Relay output 1 to n	→ 🗎 150
► Double pulse output	→ 🗎 151

Output values of current output

The **Value current output** submenu contains all the parameters needed to display the current measured values for every current output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Value current output 1 to n

► Current output 1 to n		
Output current 1 to n) → 🗎 150	
Measured current 1 to n] → 🗎 150	


Parameter	Description	User interface
Output current 1	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA
Measured current	Displays the current value currently measured for the current output.	0 to 30 mA

Output values for pulse/frequency/switch output

The **Pulse/frequency/switch output 1 to n** submenu contains all the parameters needed to display the current measured values for every pulse/frequency/switch output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Pulse/frequency/switch output 1 to n



Parameter overview with brief description

Parameter	Prerequisite	Description	User interface
Output frequency 1 to n	In the Operating mode parameter, the Frequency option is selected.	Displays the value currently measured for the frequency output.	0.0 to 12 500.0 Hz
Pulse output 1 to n	The Pulse option is selected in the Operating mode parameter parameter.	Displays the pulse frequency currently output.	Positive floating-point number
Switch state 1 to n	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	 Open Closed

Output values for relay output

The **Relay output 1 to n** submenu contains all the parameters needed to display the current measured values for every relay output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values \rightarrow Relay output 1 to n

► Relay output 1 to n				
Switch state) → 🗎 151			
Switch cycles) → 🗎 151			
Max. switch cycles number	→ 🗎 151			

Parameter	Description	User interface
Switch state	Shows the current relay switch status.	 Open Closed
Switch cycles	Shows number of all performed switch cycles.	Positive integer
Max. switch cycles number	Shows the maximal number of guaranteed switch cycles.	Positive integer

Output values for double pulse output

The **Double pulse output** submenu contains all the parameters needed to display the current measured values for every double pulse output.

Navigation

"Diagnostics" menu → Measured values → Output values → Double pulse output

► Double pulse output		
Pulse output		→ 🗎 151

Parameter overview with brief description

Parameter	Description	User interface
Pulse output	Shows the currently output pulse frequency.	Positive floating-point number

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the Setup menu ($\rightarrow \implies 100$)
- Advanced settings using the Advanced setup submenu ($\rightarrow \square 127$)

11.6 Performing a totalizer reset

The totalizers are reset in the **Operation** submenu:

- Control Totalizer
- Reset all totalizers

Navigation

"Operation" menu \rightarrow Totalizer handling

► Totalizer handling			
	Control Totalizer 1 to n	→ 🗎 152	
	Preset value 1 to n	→ 🗎 152	

Totalizer value 1 to n	→ 🗎 152
Reset all totalizers	→ 🗎 152

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Control Totalizer 1 to n	A process variable is selected in the Assign process variable parameter ($\rightarrow \square$ 129) of the Totalizer 1 to n submenu.	Control totalizer value.	 Totalize Reset + hold * Preset + hold * Reset + totalize Preset + totalize * Hold * 	Totalize
Preset value 1 to n	A process variable is selected in the Assign process variable parameter (→ 🗎 129) of the Totalizer 1 to n submenu.	 Specify start value for totalizer. Dependency The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 129). 	Signed floating-point number	01
Totalizer value	A process variable is selected in the Assign process variable parameter ($\rightarrow \cong$ 129) of the Totalizer 1 to n submenu.	Displays the current totalizer counter reading.	Signed floating-point number	-
Reset all totalizers	-	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

* Visibility depends on order options or device settings

11.6.1 Function scope of "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started or continues running.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold ¹⁾	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize ¹⁾	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

1) Visible depending on the order options or device settings

11.6.2 Function scope of the "Reset all totalizers" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

11.7 Show data logging


The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.

P Data logging is also available via:

- Plant Asset Management Tool FieldCare $\rightarrow \square$ 93.
- Web browser

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Measured value trend for each logging channel displayed in the form of a chart



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

► Data logging]	
Assign channel 1		→ 🗎 154
Assign channel 2		→ 🗎 154
Assign channel 3		→ 🖺 154
Assign channel 4		→ 🖺 154
Logging interval		→ 🖺 154
Clear logging data		→ 🖺 155
Data logging		→ 🖺 155
Logging delay		→ 🖺 155
Data logging contro	ıl	→ 🗎 155

Data logging status] → 🗎 155
Entire logging duration] → 🗎 155

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign channel 1	The Extended HistoROM application package is available.	Assign process variable to logging channel.	 Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity* Electronics temperature Current output 1 Current output 2* Current output 3* Current output 4* Noise* Coil current shot time* Reference electrode potential against PE* HBSI* Build-up index* Test point 1 Test point 2 Test point 3 	Off
Assign channel 2	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \square 154)$	Off
Assign channel 3	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \square 154)$	Off
Assign channel 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign a process variable to logging channel.	For the picklist, see the Assign channel 1 parameter $(\rightarrow \square 154)$	Off
Logging interval	The Extended HistoROM application package is available.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	0.1 to 3 600.0 s	1.0 s

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Clear logging data	The Extended HistoROM application package is available.	Clear the entire logging data.	CancelClear data	Cancel
Data logging	-	Select the type of data logging.	OverwritingNot overwriting	Overwriting
Logging delay	In the Data logging parameter, the Not overwriting option is selected.	Enter the time delay for measured value logging.	0 to 999 h	0 h
Data logging control	In the Data logging parameter, the Not overwriting option is selected.	Start and stop measured value logging.	NoneDelete + startStop	None
Data logging status	In the Data logging parameter, the Not overwriting option is selected.	Displays the measured value logging status.	DoneDelay activeActiveStopped	Done
Entire logging duration	In the Data logging parameter, the Not overwriting option is selected.	Displays the total logging duration.	Positive floating- point number	0 s

* Visibility depends on order options or device settings

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Error	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $\rightarrow {}57 \rightarrow {}52.$
Local display dark and no output signals	The polarity of the supply voltage is wrong.	Correct the polarity.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly. Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective. Main electronics module is defective.	Order spare part → 🗎 181.
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	 Check the connection of the electrode cable and correct if necessary. Check the connection of the coil current cable and correct if necessary.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part $\rightarrow \square$ 181.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures $\rightarrow \square 168$
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	 Press 2 s □ + 1 ("home position"). Press E. Set the desired language in the Display language parameter (→ ≅ 133).
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part → [□] 181.

For output signals

Error	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🗎 181.
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	Main electronics module is defective. I/O electronics module is defective.	Order spare part $\rightarrow \square$ 181.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Parametrization errors	Check parameterization and correct it.
Device measures incorrectly.	Configuration error or device is operated outside the application.	 Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access

Error	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position $\rightarrow \cong 144$.
No write access to parameters	Current user role has limited access authorization	 Check user role → ➡ 81. Enter correct customer-specific access code → ➡ 81.
No connection via HART protocol	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly. Observe the maximum load $\rightarrow \square$ 191.
No connection via HART protocol	Commubox Connected incorrectly Configured incorrectly Drivers not installed correctly USB interface on computer configured incorrectly	Observe the documentation for the Commubox. FXA195 HART: Document "Technical Information" TI00404F
No connection to Web server	Web server disabled	Using the "FieldCare" or "DeviceCare" operating tool, check whether the Web server of the measuring device is enabled, and enable it if necessary→ 🗎 88.
	Incorrect settings for the Ethernet interface of the computer	 Check the properties of the Internet protocol (TCP/IP) → ≅ 84→ ≅ 84. Check the network settings with the IT manager.
No connection to Web server	Incorrect IP address	Check the IP address: 192.168.1.212 $\rightarrow \cong 84 \rightarrow \cong 84$
No connection to Web server	Incorrect WLAN access data	 Check WLAN network status. Log on to the device again using WLAN access data. Check that WLAN is enabled on the measuring device and operating device → 84.
	WLAN communication disabled	-
Not connecting to Web server, FieldCare or DeviceCare	No WLAN network available	 Check if WLAN reception is present: LED on display module is lit blue Check if WLAN connection is enabled: LED on display module flashes blue Switch on instrument function.
Network connection not present or unstable	WLAN network is weak.	 Operating device is outside of reception range: Check network status on operating device. To improve network performance, use an external WLAN antenna.


Error	Possible causes	Remedy
	Parallel WLAN and Ethernet communication	Check network settings.Temporarily enable only the WLAN as an interface.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
	Connection lost	 Check cable connection and power supply. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	 Use the correct Web browser version → 83. Clear the Web browser cache and restart the Web browser.
	Unsuitable view settings.	Change the font size/display ratio of the Web browser.
No or incomplete display of contents in the Web browser	JavaScript not enabledJavaScript cannot be enabled	 Enable JavaScript. Enter http://XXX.XXX.X.X.X/servlet/ basic.html as the IP address.
Operation with FieldCare or DeviceCare not possible via CDI-RJ45 service interface (port 8000)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.
Flashing of firmware with FieldCare or DeviceCare via CDI-RJ45 service interface (via port 8000 or TFTP ports)	Firewall of computer or network is preventing communication	Depending on the settings of the firewall used on the computer or in the network, the firewall must be adapted or disabled to allow FieldCare/ DeviceCare access.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter

Proline 500 – digital

Different LEDs in the transmitter provide information on the device status.



- Supply voltage Device status 1 2
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active


1. Open the housing cover.

- 2. Remove the display module.
- 3. Fold open the terminal cover.

LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is ok.
2	Device status (normal	Off	Firmware error
	operation)	Green	Device status is ok.
		Flashing green	Device is not configured.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red/green	The device restarts.
2 Device status (during		Flashes red slowly	If > 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	Off	Communication not active.
		White	Communication active.
5	Service interface (CDI)	Off	Not connected or no connection established.
		Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

Proline 500

Different LEDs in the transmitter provide information on the device status.




- 1 Supply voltage
- 2 Device status
- 3 Not used
- 4 Communication
- 5 Service interface (CDI) active

LED		Color	Meaning
1	Supply voltage	Off	Supply voltage is off or too low.
		Green	Supply voltage is ok.
2	Device status (normal	Off	Firmware error
	operation)	Green	Device status is ok.
		Flashing green	Device is not configured.
		Red	A diagnostic event with "Alarm" diagnostic behavior has occurred.
		Flashing red	A diagnostic event with "Warning" diagnostic behavior has occurred.
		Flashing red/green	The device restarts.
2	Device status (during	Flashes red slowly	If > 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Not used	-	-
4	Communication	Off	Communication not active.
		White	Communication active.
5	Service interface (CDI)	Off	Not connected or no connection established.
		Yellow	Connected and connection established.
		Flashing yellow	Service interface active.

12.2.2 Sensor connection housing

Proline 500 – digital

Various light emitting diodes (LED) on the ISEM electronics unit (intelligent sensor electronics module) in the sensor connection housing provide information about the device status.



1 Communication

Device status


2 3 Supply voltage

LED		Color	Meaning
1	Communication	White	Communication active.
2 Device status (normal operation)		Red	Error
		Flashing red	Warning
2 Device status (during		Flashes red slowly	If $>$ 30 seconds: problem with the boot loader.
	start-up)	Flashes red quickly	If > 30 seconds: compatibility problem when reading the firmware.
3	Supply voltage	Green	Supply voltage is ok.
		Off	Supply voltage is off or too low.

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.


Other diagnostic events that have occurred can be displayed in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 172$
- Via submenus $\rightarrow \square 173$

Status signals

•

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).



= Maintenance Required


Symbol	Meaning
F	Failure A device error has occurred. The measured value is no longer valid.
С	Function check The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: • Outside its technical specification limits (e.g. outside the process temperature range) • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
М	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior

Symbol	Meaning
8	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Δ	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.


Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Кеу	Meaning
(+)	Plus key In a menu, submenu Opens the message about remedy information.
E	Enter key In a menu, submenu Opens the operating menu.



12.3.2 Calling up remedial measures

- Diagnostic behavior with diagnostic code 4
- 5 Operation time when error occurred
- 6 Remedial measures

1. The user is in the diagnostic message.

Press 🛨 (① symbol).

- └ The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \mathbb{E} .
 - └ The message about the remedial measures opens.
- 3. Press \Box + \pm simultaneously.
 - └ The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the Diagnostic list submenu or Previous diagnostics parameter.


1. Press E.

- └ The message for the remedial measures for the selected diagnostic event opens.
- **2.** Press \Box + \pm simultaneously.
 - └ The message for the remedial measures closes.

12.4 Diagnostic information in the Web browser

12.4.1 **Diagnostic options**

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- 1 Status area with status signal
- 2 Diagnostic information
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 172$
- Via submenu $\rightarrow \triangleq 173$

Status signals

-

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
\otimes	Failure A device error has occurred. The measured value is no longer valid.
	Function check The device is in the service mode (during a simulation, for example).
	Out of specification The device is being operated: • Outside its technical specification limits (e.g. outside the process temperature range) • Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare or DeviceCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.

XXXXXX///	Function check	<u>Mass flow:</u> 2 12.34 kg/h <u>Volume flow:</u> 2 12.34 m³/h	
Xxxxxx P Diagnostics 1: P Remedy information: P Access status tooling: Operation Setup Diagnostics Expert	C485 Simu Deactivate Mainenance	Instrument health status Image: Second state of the status Image: Second state of the status Image: Second state of the	— 2 — 3


- 1 Status area with status signal $\rightarrow \square 162$
- 2 Diagnostics information $\rightarrow \square 163$
- 3 Remedial measures with service ID

In addition, diagnostic events which have occurred can be shown in the **Diagnostics** menu:

- Via parameter $\rightarrow \square 172$
- Via submenu →
 [□]
 ¹⁷³

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



A0021799-EN

12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
- Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.


- 2. On the right in the working area, mouse over the parameter.
 - └ A tool tip with remedy information for the diagnostic event appears.

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu.

Expert \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior



41 Taking the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (Event list submenu) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.6.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic** event category submenu.

Expert \rightarrow Communication \rightarrow Diagnostic event category

Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning
A0013956	Failure A device error is present. The measured value is no longer valid.
C	Function check The device is in service mode (e.g. during a simulation).
S	 Out of specification The device is being operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
A0013957	Maintenance required Maintenance is required. The measured value is still valid.
N	Has no effect on the condensed status.
A0023076	

12.7 Overview of diagnostic information

The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information $\rightarrow \square 167$

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of	sensor			
043	Sensor 1 short circuit detected	 Check sensor cable and sensor Execute Heartbeat Verification Replace sensor cable or sensor 	S	Warning ¹⁾
082	Data storage inconsistent	Check module connections	F	Alarm
083	Memory content inconsistent	 Restart device Restore S-DAT data Replace S-DAT 	F	Alarm
143	HBSI limit exceeded	 Check if external magnetic interference is present Check flow value Replace sensor 	М	Warning ¹⁾
168	Build-up limit exceeded	Clean measuring tube	М	Warning
169	Conductivity measurement failed	 Check grounding conditions Deactivate conductivity measurement 	М	Warning
170	Coil resistance faulty	Check ambient and process temperature	F	Alarm
180	Temperature sensor defective	 Check sensor connections Replace sensor cable or sensor Turn off temperature measurement 	F	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
181	Sensor connection faulty	 Check sensor cable and sensor Execute Heartbeat Verification Replace sensor cable or sensor 	F	Alarm
Diagnostic of	electronic			
201	Electronics faulty	 Restart device Replace electronics 	F	Alarm
242	Firmware incompatible	 Check firmware version Flash or replace electronic module 	F	Alarm
252	Module incompatible	 Check electronic modules Check if correct modules are available (e.g. NEx, Ex) Replace electronic modules 	F	Alarm
262	Module connection interrupted	 Check module connections Replace electronic modules 	F	Alarm
270	Main electronics defective	 Restart device Replace main electronic module 	F	Alarm
271	Main electronics faulty	 Restart device Replace main electronic module 	F	Alarm
272	Main electronics faulty	Restart device	F	Alarm
273	Main electronics defective	 Pay attention to display emergency operation Replace main electronics 	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	1. Restart device 2. Change I/O module	F	Alarm
283	Memory content inconsistent	Restart device	F	Alarm
302	Device verification active	Device verification active, please wait.	С	Warning ¹⁾
303	I/O 1 to n configuration changed	 Apply I/O module configuration (parameter 'Apply I/O configuration') Afterwards reload device description and check wiring 	М	Warning
311	Sensor electronics (ISEM) faulty	Maintenance required! Do not reset device	М	Warning
330	Flash file invalid	 Update firmware of device Restart device 	М	Warning
331	Firmware update failed	 Update firmware of device Restart device 	F	Warning
332	Writing in HistoROM backup failed	 Replace user interface board Ex d/XP: replace transmitter 	F	Alarm
361	I/O module 1 to n faulty	 Restart device Check electronic modules Change I/O module or main electronics 	F	Alarm
372	Sensor electronics (ISEM) faulty	 Restart device Check if failure recurs Replace sensor electronic module (ISEM) 	F	Alarm
373	Sensor electronics (ISEM) faulty	Transfer data or reset device	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
375	I/O- 1 to n communication failed	 Restart device Check if failure recurs Replace module rack inclusive electronic modules 	F	Alarm
376	Sensor electronics (ISEM) faulty	 Replace sensor electronic module (ISEM) Turn off diagnostic message 	S	Warning ¹⁾
377	Electrode signal faulty	 Activate empty pipe detection Check partial filled pipe and installation direction Check sensor cabling Deactivate diagnostics 377 	S	Warning ¹⁾
378	Supply voltage ISEM faulty	 If available: Check connection cable between sensor and transmitter Replace main electronic module Replace sensor electronic module (ISEM) 	F	Alarm
382	Data storage	 Insert T-DAT Replace T-DAT 	F	Alarm
383	Memory content	Reset device	F	Alarm
387	HistoROM data faulty	Contact service organization	F	Alarm
Diagnostic of	configuration			1
410	Data transfer failed	 Retry data transfer Check connection 	F	Alarm
412	Processing download	Download active, please wait	С	Warning
431	Trim 1 to n required	Carry out trim	С	Warning
437	Configuration incompatible	 Update firmware Execute factory reset 	F	Alarm
438	Dataset different	 Check data set file Check device parameterization Download new device parameterization 	М	Warning
441	Current output faulty	 Check process Check current output settings 	S	Warning ¹⁾
442	Frequency output faulty	 Check process Check frequency output settings 	S	Warning ¹⁾
443	Pulse output 1 to n faulty	 Check process Check pulse output settings 	S	Warning ¹⁾
444	Current input 1 to n faulty	 Check process Check current input settings 	S	Warning ¹⁾
453	Flow override active	Deactivate flow override	С	Warning
484	Failure mode simulation active	Deactivate simulation	С	Alarm
485	Process variable simulation active	Deactivate simulation	С	Warning
486	Current input simulation active	Deactivate simulation	С	Warning
491	Current output 1 to n simulation active	Deactivate simulation	С	Warning
492	Frequency output simulation active	Deactivate simulation frequency output	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
493	Pulse output simulation active	Deactivate simulation pulse output	С	Warning
494	Switch output simulation active	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation active	Deactivate simulation	С	Warning
496	Status input simulation active	Deactivate simulation status input	С	Warning
502	CT activation/ deactivation failed	Follow the sequence of the custody transfer activation/deactivation: First authorized user login, then set the DIP switch on the main electonic module	С	Warning
511	Sensor setting error	 Check measuring period and integration time Check sensor properties 	С	Alarm
512	ECC recovery time exceeded	1. Check ECC recovery time 2. Turn off ECC	F	Alarm
520	I/O 1 to n hardware configuration invalid	 Check I/O hardware configuration Replace wrong I/O module Plug the module of double pulse output on correct slot 	F	Alarm
530	Electrode cleaning active	Switch off electrode cleaning	С	Warning
531	Empty pipe adjustment faulty	Execute EPD adjustment	S	Warning ¹⁾
537	Configuration	 Check IP addresses in network Change IP address 	F	Warning
540	Custody transfer mode failed	 Power off device and toggle DIP switch Deactivate custody transfer mode Reactivate custody transfer mode Check electronic components 	F	Alarm
543	Double pulse output	 Check process Check pulse output settings 	S	Warning ¹⁾
593	Double pulse output simulation	Deactivate simulation pulse output	С	Warning
594	Relay output simulation	Deactivate simulation switch output	С	Warning
599	Custody transfer logbook full	 Deactivate custody transfer mode Clear custody transfer logbook (all 30 entries) Activate custody transfer mode 	S	Warning
Diagnostic of	process			
803	Loop current 1 faulty	 Check wiring Change I/O module 	F	Alarm
832	Electronics temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronics temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
842	Process value below limit	Low flow cut off active! Check low flow cut off configuration	S	Warning ¹⁾
882	Input signal faulty	 Check input signal parameterization Check external device Check process conditions 	F	Alarm
937	Sensor symmetry	 Eliminate external magnetic field near sensor Turn off diagnostic message 	S	Warning ¹⁾
938	Coil current not stable	 Check if external magnetic interference is present Perform Heartbeat Verification Check flow value 	F	Alarm ¹⁾
961	Electrode potential out of specification	 Check process conditions Check ambient conditions 	S	Warning ¹⁾
962	Pipe empty	 Perform full pipe adjustment Perform empty pipe adjustment Turn off empty pipe detection 	S	Warning ¹⁾

1) Diagnostic behavior can be changed.

12.8 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \triangleq 164$
- Via web browser $\rightarrow \square 165$
- Via "FieldCare" operating tool $\rightarrow \ \ 167$
- Via "DeviceCare" operating tool $\rightarrow \implies 167$

Other pending diagnostic events can be displayed in the **Diagnostic list** submenu $\rightarrow \bigoplus 173$

Navigation

1

"Diagnostics" menu

억, Diagnostics	
Actual diagnostics	→ 🗎 173
Previous diagnostics	→ 🗎 173
Operating time from restart	→ 🗎 173
Operating time	→ 🗎 173


Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.9 Diagnostic list

Up to 5 currently pending diagnostic events can be displayed in the **Diagnostic list** submenu along with the associated diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics \rightarrow Diagnostic list



42 Taking the example of the local display

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \triangleq 164$
- Via web browser $\rightarrow \square 165$
- Via "FieldCare" operating tool $\rightarrow \square 167$
- Via "DeviceCare" operating tool $\rightarrow \cong 167$


12.10 Event logbook

12.10.1 Reading out the event logbook

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

 $\textbf{Diagnostics} \; \texttt{menu} \rightarrow \textbf{Event logbook} \; \texttt{submenu} \rightarrow \texttt{Event list}$



43 Taking the example of the local display

- A maximum of 20 event messages can be displayed in chronological order.
- If the **Extended HistoROM** application package (order option) is enabled in the device, the event list can contain up to 100 entries .

The event history includes entries for:

- Diagnostic events →
 [™]
 [™]
 168
- Information events $\rightarrow \square 174$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - $\overline{\mathfrak{O}}$: Occurrence of the event
 - 🕞: End of the event
- Information event

 \oplus : Occurrence of the event

To call up the measures to rectify a diagnostic event:

- Via local display $\rightarrow \square 164$
- Via web browser $\rightarrow \square 165$
- Via "DeviceCare" operating tool \rightarrow 🗎 167

For filtering the displayed event messages → 🖺 174

12.10.2 Filtering the event logbook

Using the **Filter options** parameter you can define which category of event message is displayed in the **Events list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name		
I1000	(Device ok)		
I1079	ensor changed		
I1089	Power on		
I1090	Configuration reset		
I1091	Configuration changed		

Info number	Info name			
I1092	HistoROM backup deleted			
I1137	Electronics changed			
I1151	History reset			
I1155	Reset electronics temperature			
I1156	Memory error trend			
I1157	lemory error event list			
I1256	Display: access status changed			
I1264	Safety sequence aborted			
I1278	I/O module restarted			
I1335	Firmware changed			
I1351	Empty pipe detection adjustment failure			
I1353	Empty pipe detection adjustment ok			
I1361	Web server: login failed			
I1397	Fieldbus: access status changed			
I1398	CDI: access status changed			
I1443	Build-up thickness not determined			
I1444	Device verification passed			
I1445	Device verification failed			
I1457	Measurement error verification failed			
I1459	'O module verification failed			
I1461	ensor verification failed			
I1462	Sensor electronic module verific. failed			
I1512	Download started			
I1513	Download finished			
I1514	Upload started			
I1515	Upload finished			
I1517	Custody transfer active			
I1518	Custody transfer inactive			
I1554	Safety sequence started			
I1555	Safety sequence confirmed			
I1556	Safety mode off			
I1618	I/O module 2 replaced			
I1619	I/O module 3 replaced			
I1621	I/O module 4 replaced			
I1622	Calibration changed			
I1624	All totalizers reset			
I1625	Write protection activated			
I1626	Write protection deactivated			
I1627	Web server: login successful			
I1628	Display: login successful			
I1629	CDI: login successful			
I1631	Web server access changed			
I1632	Display: login failed			

Info number	Info name
I1633	CDI: login failed
I1634	Reset to factory settings
I1635	Reset to delivery settings
I1639	Max. switch cycles number reached
I1643	Custody transfer logbook cleared
I1649	Hardware write protection activated
I1650	Hardware write protection deactivated
I1651	Custody transfer parameter changed
I1712	New flash file received
I1725	Sensor electronic module (ISEM) changed
I1726	Configuration backup failed

12.11 Resetting the measuring device

The entire device configuration or some of the configuration can be reset to a defined state with the **Device reset** parameter ($\Rightarrow \triangleq 139$).

12.11.1 Function scope of "Device reset" parameter

Description		
on is executed and the user exits the parameter.		
arameter for which a customer-specific default setting was ordered is reset ustomer-specific value. All other parameters are reset to the factory setting.		
tart resets every parameter with data stored in volatile memory (RAM) to ory setting (e.g. measured value data). The device configuration remains ged.		
s the data that is saved on the S-DAT. Additional information: This function used to resolve the memory issue "083 Memory content inconsistent" or to the S-DAT data when a new S-DAT has been installed. his option is displayed only in an alarm condition.		

12.12 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu \rightarrow Device information

► Device information					
Device tag	→ 🗎 177				
Serial number) → 🗎 177				
Firmware version) → 🗎 177				

Device name \rightarrow Manufacturer \rightarrow Order code \rightarrow Extended order code 1 \rightarrow Extended order code 2 \rightarrow	
Order code \rightarrow Extended order code 1 \rightarrow Extended order code 2 \rightarrow	177
Extended order code 1 $\rightarrow \square$ Extended order code 2 $\rightarrow \square$	177
Extended order code 2 $\rightarrow \square$	177
	177
	178
Extended order code 3 \rightarrow	178
ENP version $\rightarrow \square$	178
Device revision $\rightarrow \square$	178
Device ID → 🗎	178
Device type $\rightarrow \square$	178
$\square \qquad \qquad$	178

Parameter Description		User interface	Factory setting
Device tag	Shows name of measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string in the format xx.yy.zz	-
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Promag 300/500	-
Manufacturer	Displays the manufacturer.	Character string comprising numbers, letters and special characters	Endress+Hauser
Order code	c code Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.		-
Extended order code 1 Shows the 1st part of the extended order code. Image: The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.		Character string	-

Parameter Description		User interface	Factory setting	
Extended order code 2	ended order code 2 Shows the 2nd part of the extended order code.		-	
	The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.			
Extended order code 3	Shows the 3rd part of the extended order code.	Character string	-	
	The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.			
ENP version	Shows the version of the electronic nameplate (ENP).	Character string	2.02.00	
Device revision	Shows the device revision with which the device is registered with the HART Communication Foundation.	2-digit hexadecimal number	7	
Device ID	Shows the device ID for identifying the device in a HART network.	6-digit hexadecimal number	-	
Device type	Shows the device type with which the measuring device is registered with the HART Communication Foundation.	2-digit hexadecimal number	0x3A (for Promag 500)	
Manufacturer ID	Shows the device's manufacturer ID registered with the HART Communication Foundation.	2-digit hexadecimal number	0x11 (for Endress+Hauser)	

12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
08.2022	01.06.zz	Option 60	HBSI (Heartbeat Technology)Build-up index (Heartbeat Technology)Flow damping configuration	Operating Instructions	BA01399D/06/EN/06.22
09.2019	01.05.zz	Option 64	Various improvements	Operating Instructions	BA01399D/06/EN/02.19

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
10.2017	01.01.zz	Option 68	 OPC-UA with Security new Local display - enhanced performance and data entry via text editor Optimized keypad lock for local display Web server feature update Support for trend data function Heartbeat function enhanced to include detailed results (page 3/4 of the report) Device configuration as PDF (parameter log, similar to FDT print) Network capability of Ethernet (service) interface Comprehensive Heartbeat feature update Local display - support for WLAN infrastructure mode Implementation of reset code 	Operating Instructions	BA01399D/06/EN/02.17
08.2016	01.00.zz	Option 76	Original firmware	Operating Instructions	BA01399D/06/EN/01.16

- It is possible to flash the firmware to the current version or the previous version using the service interface. For the compatibility of the firmware version, see the "Device history and compatibility" section $\rightarrow \cong 179$
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser web site: www.endress.com → Downloads
 - Specify the following details:
 - Product root: e.g. 5P5B
 - The product root is the first part of the order code: see the nameplate on the device.
 - Text search: Manufacturer's information
 - Media type: Documentation Technical Documentation

12.14 Device history and compatibility

The device model is documented in the order code on the nameplate of the device (e.g. 8F3BXX-XXX....XXXA1-XXXXX).

Dev	rice model	Release	Change compared with earlier model	Compatibility with earlier model
A2		09.2019	I/O module with enhanced performance and functionality: see device firmware $01.05.zz \rightarrow \bigoplus 178$	No
A1		08.2016	-	-

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning

No interior cleaning is planned for the device.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

List of some of the measuring and testing equipment: $\rightarrow \square 183 \rightarrow \square 185$

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General information

14.1.1 Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by appropriately trained customers.
- Certified devices can only be converted to other certified devices by Endress+Hauser Service or at the factory.

14.1.2 Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- ▶ Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- ► Document every repair and each conversion and enter them into the *W*@*M* life cycle management database and Netilion Analytics.

14.2 Spare parts

Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

P Measuring device serial number:

- Is located on the nameplate of the device.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- Refer to the web page for information: http://www.endress.com/support/return-material
 Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

14.5 Disposal

X

If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

14.5.1 Removing the measuring device

1. Switch off the device.

WARNING

Danger to persons from process conditions!

- Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive media.
- 2. Carry out the mounting and connection steps from the "Mounting the measuring device" and "Connecting the measuring device" sections in reverse order. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- ► Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Transmitter • Proline 500 – digital • Proline 500	Transmitter for replacement or storage. Use the order code to define the following specifications: Approvals Output Input Display/operation Housing Software Proline 500 - digital transmitter: Order number: 5X5BXX-******A Proline 500 transmitter: Order number: 5X5BXX-******B Proline 500 transmitter for replacement: It is essential to specify the serial number of the current transmitter when ordering. On the basis of the serial number, the device-specific data (e.g. calibration factors) of the replaced device can be used for the new transmitter.
	 Proline 500 – digital transmitter: Installation Instructions EA01151D Proline 500 transmitter: Installation Instructions EA01152D
External WLAN antenna	 External WLAN antenna with 1.5 m (59.1 in) connecting cable and two angle brackets. Order code for "Accessory enclosed", option P8 "Wireless antenna wide area". Inte external WLAN antenna is not suitable for use in hygienic applications. Additional information regarding the WLAN interface → 91. Order number: 71351317 Installation Instructions EA01238D
Pipe mounting set	Pipe mounting set for transmitter. Image: Proline 500 - digital transmitter Order number: 71346427 Image: Proline Instructions EA01195D Image: Proline 500 transmitter Order number: 71346428
Weather protection cover Transmitter • Proline 500 – digital • Proline 500	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight. Proline 500 - digital transmitter Order number: 71343504 Proline 500 transmitter Order number: 71343505 Installation Instructions EA01191D

Display guard Proline 500 – digital	Is used to protect the display against impact or scoring, for example from sand in desert areas. Order number: 71228792		
	Installation Instructions EA01093D		
Ground cable	Set, consisting of two ground cables for potential equalization.		
Connecting cable Proline 500 – digital	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection) or as an accessory (order number DK5012).		
Sensor – Transmitter	 The following cable lengths are available: order code for "Cable, sensor connection" Option B: 20 m (65 ft) Option E: User-configurable up to max. 50 m Option F: User-configurable up to max. 165 ft 		
	Maximum possible cable length for a Proline 500 – digital connecting cable: 300 m (1000 ft)		
Connecting cable Proline 500 Sensor – Transmitter	The connecting cable can be ordered directly with the measuring device (order code for "Cable, sensor connection") or as an accessory (order number DK5012).		
	 The following cable lengths are available: order code for "Cable, sensor connection" Option 1: 5 m (16 ft) Option 2: 10 m (32 ft) Option 3: 20 m (65 ft) Option 4: User-configurable cable length (m) Option 5: User-configurable cable length (ft) 		
	Possible cable length for a Proline 500 connecting cable: depending on the medium conductivity, max. 200 m (660 ft)		

15.1.2 For the sensor

Accessories	Description
Ground disks	Are used to ground the medium in lined measuring tubes to ensure proper measurement. For details, see Installation Instructions EA00070D

15.2 Communication-specific accessories

Accessories	Description				
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface.				
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values. • Technical Information TI00429F • Operating Instructions BA00371F				
Fieldgate FXA42	Is used to transmit the measured values of connected 4 to 20 mA analog measuring devices, as well as digital measuring devices				
	 Technical Information TI01297S Operating Instructions BA01778S Product page: www.endress.com/fxa42 				

Field Xpert SMT50	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.		
	 Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt50 		
Field Xpert SMT70	The Field Xpert SMT70 tablet PC for device configuration enables mobile plant asset management in hazardous and non-hazardous areas. It is suitable for commissioning and maintenance staff to manage field instruments with a digital communication interface and to record progress. This tablet PC is designed as an all-in-one solution with a preinstalled driver library and is an easy-to-use, touch-sensitive tool which can be used to manage field instruments throughout their entire life cycle.		
	 Technical Information TI01342S Operating Instructions BA01709S Product page: www.endress.com/smt70 		
Field Xpert SMT77	The Field Xpert SMT77 tablet PC for device configuration enables mobile plant asset management in areas categorized as Ex Zone 1. • Technical Information TIO1418S • Operating Instructions BA01923S		
	Product page: www.endress.com/smt77		

15.3 Service-specific accessories

Accessory	Description				
Applicator	 Software for selecting and sizing Endress+Hauser measuring devices: Choice of measuring devices with industrial requirements Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, flow velocity and accuracy. Graphic illustration of the calculation results Determination of the partial order code, administration, documentation and access to all project-related data and parameters over the entire life cycle of a project. 				
	 Applicator is available: Via the Internet: https://portal.endress.com/webapp/applicator As a downloadable DVD for local PC installation. 				
W@M	 W@M Life Cycle Management Improved productivity with information at your fingertips. Data relevant to a plant and its components is generated from the first stages of planning and during the asset's complete life cycle. W@M Life Cycle Management is an open and flexible information platform with online and on-site tools. Instant access for your staff to current, in-depth data shortens your plant's engineering time, speeds up procurement processes and increases plant uptime. Combined with the right services, W@M Life Cycle Management boosts productivity in every phase. For more information, see: www.endress.com/lifecyclemanagement 				
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition. Querating Instructions BA00027S and BA00059S				
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices. Image: A state of the state of				

15.4 System components

Accessories	Description					
Memograph M graphic data manager	The Memograph M graphic data manager provides information on all the relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.					
	 Technical Information TI00133R Operating Instructions BA00247R 					
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the medium temperature.					
	Fields of Activity" document FA00006T					

16 Technical data

16.1 Application

The measuring device is only suitable for the flow measurement of liquids with a minimum conductivity of 5 $\mu S/cm.$

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of Faraday's law of magnetic induction.					
Measuring system	The measuring system consists of a transmitter and a sensor. The transmitter and sensor are mounted in physically separate locations. They are interconnected by connecting cables.					
	Information on the structure of the device $\rightarrow \square 14$ 16.3 Input					
	1					

Measured variable	Direct measured variables			
	Volume flow (proportional to induced voltage)Electrical conductivity			
	Calculated measured variables			
	 Mass flow 			
	 Corrected volume flow 			

Measuring range

Typically v = 0.01 to 10 m/s (0.03 to 33 ft/s) with the specified accuracy

Flow characteristic values in SI units: DN 15 to 125 (1/2 to 4")

Nominal diameter		Recommended flow	Factory settings			
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s) Pulse value (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)	
[mm]	[mm] [in]		[dm³/min]	[dm ³]	[dm ³ /min]	
15	1/2	4 to 100	25	0.2	0.5	
25	1	9 to 300	75	0.5	1	
32	-	15 to 500	125	1	2	
40	1 ½	25 to 700	200	1.5	3	
50	2	35 to 1 100	300	2.5	5	
65 –		60 to 2 000	500	5	8	

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s) Pulse value (~ 2 pulse/s)		Low flow cut off (v ~ 0.04 m/s)
[mm] [in]		[dm³/min]	[dm³/min]	[dm ³]	[dm³/min]
80	3	90 to 3 000	750	5	12
100	4	145 to 4700	1200	10	20
125 –		220 to 7500	1850	15	30

Flow characteristic values in SI units: DN 150 to 600 (6 to 24")


Nominal	diameter	Recommended flow	Factory settings				
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)Pulse value (~ 2 pulse/s)Low flow cut off (v ~ 0.04 m/s)				
[mm]	[in]	[m ³ /h]	[m³/h]	[m ³]	[m³/h]		
150	6	20 to 600	150	0.03	2.5		
200	8	35 to 1 100	300	0.05	5		
250	10	55 to 1700	500	0.05	7.5		
300	12	80 to 2 400	750	0.1	10		
350	14	110 to 3300	1000	0.1	15		
400	16	140 to 4200	1200	0.15	20		
450	18	180 to 5400	1500	0.25	25		
500	20	220 to 6600	2 000	0.25	30		
600	24	310 to 9600	2 500	0.3	40		

Flow characteristic values in US units: ½ - 24" (DN 15 - 600)

Nominal	diameter	Recommended flow		Factory settings	
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
1/2	15	1.0 to 27	6	0.1	0.15
1	25	2.5 to 80	18	0.2	0.25
1 1/2	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4
6	150	90 to 2 650	600	5	12
8	200	155 to 4850	1200	10	15
10	250	250 to 7500	1500	15	30
12	300	350 to 10600	2400	25	45
14	350	500 to 15 000	3600	30	60
16	400	600 to 19000	4800	50	60

Nominal diameter		Recommended flow	Factory settings		
		min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
	1				
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
[in] 18	[mm] 450	[gal/min] 800 to 24000	[gal/min] 6000	[gal] 50	[gal/min] 90

Recommended measuring range



Operable flow range	Over 1000 : 1		
Input signal	External measured values		
	automation system can device: • Medium temperature iTEMP)	cy of certain measured variables or to calculate the mass flow, the a continuously write different measured values to the measuring e enables temperature-compensated conductivity measurement (e.g.	
	Various pressure a	and temperature measuring devices can be ordered from Endress essories" section $\rightarrow \cong 186$	
	It is recommended to read in external measured values to calculate the corrected volume flow.		
	HART protocol		
	The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions: • HART protocol • Burst mode		
	Current input		
	The measured values are written from the automation system to the measuring device via the current input $\rightarrow \cong 189$. Current input 0/4 to 20 mA		
	Current input	0/4 to 20 mA (active/passive)	
	Current span	 4 to 20 mA (active) 0/4 to 20 mA (passive) 	
	Resolution	1 μΑ	
	Voltage drop	Typically: 0.6 to 2 V for 3.6 to 22 mA (passive)	
	Maximum input voltage	< 30 V (passive)	
	Open-circuit voltage	< 28.8 V (active)	
	Possible input variables	Temperature Density	

Status input

Maximum input values	 DC -3 to 30 V If status input is active (ON): R_i >3 kΩ
Response time	Configurable: 5 to 200 ms
Input signal level	 Low signal: DC -3 to +5 V High signal: DC 12 to 30 V
Assignable functions	 Off Reset the individual totalizers separately Reset all totalizers Flow override

16.4 Output

Output signal

Current output 4 to 20 mA HART

Order code	"Output; input 1" (20): Option BA: current output 4 to 20 mA HART
Signal mode	Can be set to: • Active • Passive
Current range	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	250 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature

Current output 4 to 20 mA HART Ex i

Order code	 "Output; input 1" (20) choose from: Option CA: current output 4 to 20 mA HART Ex i passive Option CC: current output 4 to 20 mA HART Ex i active
Signal mode	Depends on the selected order version.
Current range	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Open-circuit voltage	DC 21.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	 250 to 400 Ω (active) 250 to 700 Ω (passive)
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature

Current output 4 to 20 mA

Order code	"Output; input 2" (21), "Output; input 3" (022) or "Output; input 4" (023): Option B: current output 4 to 20 mA
Signal mode	Can be set to: • Active • Passive
Current span	Can be set to: 4 to 20 mA NAMUR 4 to 20 mA US 4 to 20 mA 0 to 20 mA (only if the signal mode is active) Fixed current
Maximum output values	22.5 mA
Open-circuit voltage	DC 28.8 V (active)
Maximum input voltage	DC 30 V (passive)
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999.9 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature

Current output 4 to 20 mA Ex i passive

Order code	"Output; input 2" (21), "Output; input 3" (022): Option C: current output 4 to 20 mA Ex i passive
Signal mode	Passive
Current span	Can be set to: • 4 to 20 mA NAMUR • 4 to 20 mA US • 4 to 20 mA • Fixed current
Maximum output values	22.5 mA
Maximum input voltage	DC 30 V
Load	0 to 700 Ω
Resolution	0.38 μΑ
Damping	Configurable: 0 to 999 s
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature

Pulse/frequency/switch output

Function	Can be configured as pulse, frequency or switch output
Version	Open collector
	Can be set to: • Active • Passive
	Passive NAMUR Ex-i, passive
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: ≤ DC 2 V
Pulse output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Pulse width	Configurable: 0.05 to 2 000 ms
Maximum pulse rate	10 000 Impulse/s
Pulse value	Configurable
Assignable measured variables	Volume flowMass flowCorrected volume flow
Frequency output	
Maximum input values	DC 30 V, 250 mA (passive)
Maximum output current	22.5 mA (active)
Open-circuit voltage	DC 28.8 V (active)
Output frequency	Configurable: end value frequency 2 to 10000 Hz(f _{max} = 12 500 Hz)
Damping	Configurable: 0 to 999.9 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature
Switch output	
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Switching behavior	Binary, conductive or non-conductive
Switching behavior Switching delay	Binary, conductive or non-conductive Configurable: 0 to 100 s

Number of switching cycles	Unlimited
Assignable functions	 Off On Diagnostic behavior Limit value: Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Totalizer 1-3 Electronics temperature Flow direction monitoring Status Empty pipe detection Buildup index HBSI limit value exceeded Low flow cut off

Double pulse output

Function	Double pulse
Version	Open collector
	Can be set to: • Active • Passive • Passive NAMUR
Maximum input values	DC 30 V, 250 mA (passive)
Open-circuit voltage	DC 28.8 V (active)
Voltage drop	For 22.5 mA: \leq DC 2 V
Output frequency	Configurable: 0 to 1000 Hz
Damping	Configurable: 0 to 999 s
Pulse/pause ratio	1:1
Assignable measured variables	 Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Electronics temperature

Relay output

Function	Switch output
Version	Relay output, galvanically isolated
Switching behavior	Can be set to: • NO (normally open), factory setting • NC (normally closed)

Maximum switching capacity (passive)	 DC 30 V, 0.1 A AC 30 V, 0.5 A
Assignable functions	 Off On Diagnostic behavior Limit value: Off Volume flow Mass flow Corrected volume flow Flow velocity Conductivity Totalizer 1-3 Electronics temperature Flow direction monitoring Status Empty pipe detection Buildup index HBSI limit value exceeded Low flow cut off

User-configurable input/output

One specific input or output is assigned to a user-configurable input/output (configurable I/O) during device commissioning.

The following inputs and outputs are available for assignment:

- Choice of current output: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Pulse/frequency/switch output
- Choice of current input: 4 to 20 mA (active), 0/4 to 20 mA (passive)
- Status input

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Current output 0/4 to 20 mA

4 to 20 mA

 4 to 20 mA in accordance with NAMUR recommendation NE 43 4 to 20 mA in accordance with US Min. value: 3.59 mA Max. value: 22.5 mA Freely definable value between: 3.59 to 22.5 mA Actual value Last valid value

0 to 20 mA

|--|

Pulse/frequency/switch output

Pulse output	
Failure mode	Choose from: • Actual value • No pulses
Frequency output	

Failure mode	Choose from: • Actual value • 0 Hz • Defined value (f _{max} 2 to 12 500 Hz)
Switch output	
Failure mode	Choose from: • Current status • Open • Closed

Relay output

Failure mode	Choose from:
	 Current status
	 Open
	Closed

Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Interface/protocol

- Via digital communication: HART protocol
- Via service interface
 - CDI-RJ45 service interface
 - WLAN interface

Plain text display	With information on cause and remedial measures
--------------------	---

Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	 The following information is displayed depending on the device version: Supply voltage active Data transmission active Device alarm/error has occurred Diagnostic information via light emitting diodes → 158

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation	The outputs are galvanically isolated:
	 from the power supply
	 from one another

• from the potential equalization (PE) terminal

Protocol-specific data

Manufacturer ID	0x11
Device type ID	0x3C
HART protocol revision	7
Device description files (DTM, DD)	Information and files under: www.endress.com
HART load	Min. 250 Ω
System integration	Information on system integration $\rightarrow \square 96$.
	Measured variables via HART protocolBurst Mode functionality

Max. 36 A (<5 ms) as per NAMUR Recommendation NE 21

16.5 Power supply

switch-on current

Terminal assignment $\rightarrow \cong 45$

Supply voltage	Order code for "Power supply"	Terminal voltage		Frequency range
	Option D	DC 24 V	±20%	-
	Option E	AC 100 to 240 V	-15 to +10%	50/60 Hz, ±4 Hz
	Option I	DC 24 V	±20%	-
		AC 100 to 240 V	-15 to +10%	50/60 Hz, ±4 Hz

Power consumption	Transmitter	
	Max. 10 W (active power)	

Current consumption	Transmitter
	• Max. 400 mA (24 V)
	 Max. 200 mA (110 V, 50/60 Hz; 230 V, 50/60 Hz)
 Power supply failure Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device the pluggable data memory (HistoROM DAT). Error messages (incl. total operated hours) are stored. 	
Overcurrent protection element	 The device must be operated with a dedicated circuit breaker, as it does not have an ON/OFF switch of its own. The circuit breaker must be easy to reach and labeled accordingly. Permitted nominal current of the circuit breaker: 2 A up to maximum 10 A.


Electrical connection	$\bullet \rightarrow riangleq 49$		
	■ → 🖺 54		
Potential equalization	→ 🗎 59		
Terminals	Spring-loaded terminals: Suitable for strands and strands with ferrules. Conductor cross-section 0.2 to 2.5 mm^2 (24 to 12 AWG).		
Cable entries	 Cable gland: M20 × 1.5 with cable Ø 6 to 12 mm (0.24 to 0.47 in) Thread for cable entry: NPT ¹/₂" G ¹/₂" M20 		
Cable specification	→ 🗎 41		
Overvoltage protection	Mains voltage fluctuations		→ 🗎 197

ollage protection	Mains voltage fluctuations	→ 目 197
	Overvoltage category	Overvoltage category II
	Short-term, temporary overvoltage	Up to 1200 V between cable and ground, for max. 5 s
	Long-term, temporary overvoltage	Up to 500 V between cable and ground

16.6 Performance characteristics

Reference operating conditions	 Error limits following DIN EN 29104, in future ISO 20456 Water, typically: +15 to +45 °C (+59 to +113 °F); 0.5 to 7 bar (73 to 101 psi) Data as indicated in the calibration protocol Accuracy based on accredited calibration rigs according to ISO 17025
Maximum measured error	o.r. = of reading
	Error limits under reference operating conditions
	Volume flow
	 ±0.5 % o.r. ± 1 mm/s (0.04 in/s) Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s)


Fluctuations in the supply voltage do not have any effect within the specified range.



■ 44 Maximum measured error in % o.r.

Flat Spec

In the case of Flat Spec, the measured error is constant in the range from $v_{0.5}$ ($v_{0.2}$) to v_{max} .



^{🗷 45} Flat Spec in % o.r.

Flat Spec flow values 0.5 %

Nominal diameter		v _{0.5}		v _{max}	
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]
25 to 600	1 to 24	0.5	1.64	10	32
50 to 300	2 to 12	0.25	0.82	5	16

Flat Spec flow values 0.2 %

Nominal diameter		v).2	v _{max}	
[mm]	[in]	[m/s]	[ft/s]	[m/s]	[ft/s]
25 to 600	1 to 24	1.5	4.92	10	32
50 to 300	2 to 12	0.6	1.97	4	13


Electrical conductivity

The values apply for:


- Proline 500 digital device version
- Devices installed in a metal pipe or in a non-metal pipe with ground disks
- Devices whose potential equalization was performed according to the instructions in the associated Operating Instructions
- Measurements at a reference temperature of 25 °C (77 °F). At different temperatures, attention must be paid to the temperature coefficient of the medium (typically 2.1 %/K)

Conductivity [µS/cm]	Measured error [%] of reading
5 to 20	± 20%
> 20 to 50	± 10%
> 50 to 10 000	 Standard: ± 10% Optional ¹⁾: ± 5%
> 10 000 to 20 000	± 10%
> 20 000 to 100 000	±20%

1) Order code for "Calibrated conductivity measurement", option CW



46 Measured error (standard)



47 Measured error (optional: order code for "Calibrated conductivity measurement", option CW)

Accuracy of outputs

The outputs have the following base accuracy specifications.


	Ľ				
	Accuracy	±5 µA			
	Pulse/frequency output	•			
	o.r. = of reading				
	Accuracy	Max. ±50 ppm o.r. (over the entire ambient temperature range)			
Repeatability	o.r. = of reading				
	Volume flow Max. ± 0.1 % o.r. ± 0.5	mm/s (0.02 in/s)			
	 Electrical conductivity Max. ±5 % o.r. With order code for "Calibrated conductivity measurement", option CW: ±2 % v.M. 				
Influence of ambient temperature	Current output				
	Temperature coefficient	Мах. 1 µА/℃			
	Pulse/frequency output				
	Temperature coefficient	No additional effect. Included in accuracy.			
	16.7 Installation				
Installation conditions	→ 🗎 22				
	16.8 Environ	ment			
Ambient temperature range	→ 🖹 28				
-	Temperature tables				
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.				
		nation on the temperature tables, see the separate document structions" (XA) for the device.			
Storage temperature	The storage temperature corresponds to the operating temperature range of the transmitter and the sensor $\rightarrow \square 28$.				
	unacceptably high su Select a storage locat fungus or bacteria int	ion where moisture cannot collect in the measuring device as festation can damage the liner. protective covers are mounted these should never be removed			

Relative humidity	The device is suitable for use in outdoor and indoor areas with a relative humidity of 4 to 95%.				
Operating height	According to EN 61010-1 ■ ≤ 2 000 m (6 562 ft) ■ > 2 000 m (6 562 ft) with additional overvoltage protection (e.g. Endress+Hauser HAW Series)				
Degree of protection	Transmitter				
	 IP66/67, Type 4X enclosure, suitable for pollution degree 4 When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2 Display module: IP20, Type 1 enclosure, suitable for pollution degree 2 				
	Sensor				
	 IP66/67, Type 4X enclosure, suitable for pollution degree 4 When the housing is open: IP20, Type 1 enclosure, suitable for pollution degree 2 				
	Optionally available for compact and remote version:				
	Order code for "Sensor option", option C3 IP66/67, type 4X enclosure Fully welded, with protective coating as per EN ISO 12944 C5-M For the operation of the device in corrosive environments				
	Optional				
	 Order code for "Sensor option", option CB, CC IP68, type 6P enclosure Fully welded, with protective coating as per EN ISO 12944 C5-M/Im1 and EN 60529 For the operation of the device under water Operating duration at a maximum depth of: 3 m (10 ft): permanent use 10 m (30 ft): maximum 48 hours 				
	Order code for "Sensor option", option CQ IP68, type 6P, temporarily waterproof Sensor with aluminum half-shell housing For the temporary operation of the device under non-corrosive water Operating duration at a maximum depth of: 3 m (10 ft): maximum 168 hours				
	External WLAN antenna				
	IP67				
Vibration- and shock-	Sinusoidal vibration according to IEC 60068-2-6				
Vibration- and shock- resistance	Order code for "Sensor connection housing", option L "Cast alloy, stainless" and order code for "Sensor option", option CG "Extended neck for insulation" • 2 to 8.4 Hz, 3.5 mm peak • 8.4 to 2 000 Hz, 1 g peak				
	Order code for "Sensor connection housing", option A "Aluminum, coated" • 2 to 8.4 Hz, 7.5 mm peak • 8.4 to 2 000 Hz, 2 g peak				

Vibration broad-band random, according to IEC 60068-2-64


	Order code for "Sensor connection housing", option L "Cast alloy, stainless" and order code for "Sensor option", option CG "Extended neck for insulation" 10 to 200 Hz, 0.003 g²/Hz 200 to 2 000 Hz, 0.001 g²/Hz Total: 1.54 g rms 						
	Order code for "Sensor connection housing", option A "Aluminum, coated" • 10 to 200 Hz, 0.01 g ² /Hz • 200 to 2 000 Hz, 0.003 g ² /Hz • Total: 2.70 g rms						
	Shock half-sine, according to IEC 60068-2-27						
	 Order code for "Sensor connection housing", option L "Cast alloy, stainless" and order code for "Sensor option", option CG "Extended neck for insulation" 6 ms 30 g Order code for "Sensor connection housing", option A "Aluminum, coated" 6 ms 50 g 						
	Rough handling shocks according to IEC 60068-2-31						
Mechanical load	Transmitter housing and sensor connection housing: Protect against mechanical effects, such as shock or impact Do not use as a ladder or climbing aid 						
Electromagnetic	As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)						
compatibility (EMC)	Details are provided in the Declaration of Conformity.						
	This unit is not intended for use in residential environments and cannot guarantee adequate protection of the radio reception in such environments.						
	16.9 Process						

Medium temperature range	■ –20 to +150 °C (–4 to +302 °F) for PFA, DN 25 to 200 (1 to 8")
	■ –20 to +180 °C (–4 to +356 °F) for PFA high-temperature, DN 25 to 200 (1 to 8")
	■ −40 to +130 °C (−40 to +266 °F) for PTFE, DN 15 to 600 (½ to 24")



🖸 48 🛛 PFA

- *T_A Ambient temperature*
- T_F Medium temperature
- 1 Colored area: the ambient temperature range -10 to -20 °C (+14 to -4 °F) applies to stainless flanges only
- 2 Hatched area: harsh environment only for medium temperature range -20 to +130 °C (-4 to +266 °F)
- 3 −20 to +150 °C (−4 to +302 °F) for PFA, DN 25 to 200 (1 to 8")
- 4 −20 to +180 °C (−4 to +356 °F) for PFA high-temperature, DN 25 to 200 (1 to 8")



☑ 49 PTFE

H

- T_A Ambient temperature
- T_F Medium temperature
- 1 Colored area: the ambient temperature range of -10 to -40 °C (+14 to -40 °F) applies to stainless flanges only

Conductivity

 \geq 5 µS/cm for liquids in general.

Proline 500 The necessary minimum conductivity also depends on the length of the connecting cable $\rightarrow \bigoplus 29$. Pressure-temperature ratings



Liner: PFA

For an overview of the pressure-temperature ratings for the process connections, see the Technical Information

Pressure tightness

Nominal diameter Limit values for absolute pressure in [mbar] ([psi]) for medium temperatures: +80 °C (+176 °F) [mm] [in] +25 °C (+77 °F) +100 to +180 °C (+212 to +356 °F) 25 1 0 (0) 0 (0) 0 (0) 32 _ 0 (0) 0 (0) 0 (0) 0 (0) 0 (0) 40 1 1/2 0 (0) 0 (0) 0 (0) 0 (0) 50 2 65 _ 0 (0) 0 (0) 0 (0) 80 3 0 (0) 0 (0) 0 (0) 100 4 0 (0) 0 (0) 0 (0) 125 0 (0) 0 (0) 0 (0) _ 150 0 (0) 0 (0) 0 (0) 6 200 8 0 (0) 0 (0) 0 (0)

Liner: PTFE

Nominal	diameter	Limit values for absolute pressure in [mbar] ([psi]) for medium temperatu					
[mm]	[in]	+25 °C (+77 °F)	+80 °C (+176 °F)	+100 °C (+212 °F)	+130 °C (+266 °F)		
15	1/2	0 (0)	0 (0)	0 (0)	100 (1.45)		
25	1	0 (0)	0 (0)	0 (0)	100 (1.45)		
32	-	0 (0)	0 (0)	0 (0)	100 (1.45)		
40	1 1/2	0 (0)	0 (0)	0 (0)	100 (1.45)		
50	2	0 (0)	0 (0)	0 (0)	100 (1.45)		
65	-	0 (0)	-	40 (0.58)	130 (1.89)		
80	3	0 (0)	-	40 (0.58)	130 (1.89)		
100	4	0 (0)	-	135 (1.96)	170 (2.47)		
125	-	135 (1.96)	-	240 (3.48)	385 (5.58)		
150	6	135 (1.96)	-	240 (3.48)	385 (5.58)		
200	8	200 (2.90)	-	290 (4.21)	410 (5.95)		
250	10	330 (4.79)	-	400 (5.80)	530 (7.69)		
300	12	400 (5.80)	-	500 (7.25)	630 (9.14)		
350	14	470 (6.82)	-	600 (8.70)	730 (10.6)		
400	16	540 (7.83)	-	670 (9.72)	800 (11.6)		
450	18		·	·			
500	20	No negative pressure permitted!					
600	24						

Flow limit	The diameter of the pipe and the flow rate determine the nominal diameter of The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also n velocity of flow (v) to the physical properties of the medium: • v < 2 m/s (6.56 ft/s): for abrasive media (e.g. potter's clay, lime milk, ore slu • v > 2 m/s (6.56 ft/s): for media producing buildup (e.g. wastewater sludge)										
		essary inc al diame	crease in the flow ter.	velocit	y can be achieved	l by rec	lucing the sensor				
		overviev section	v of the full scale	values	for the measuring	g range	e, see the "Measu	ring			
Pressure loss	diameter	 No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter. Pressure losses for configurations incorporating adapters according to DIN EN 545 → ≅ 29 									
System pressure	→ 🖺 28										
Vibrations	→ 🗎 28										
	16.10	Mech	anical const	ructi	on						
Design, dimensions			ions and installed chanical construc			ee the	"Technical Inform	nation			
Weight	All values (weight exclusive of packaging material) refer to devices with flanges of the standard pressure rating. The weight may be lower than indicated depending on the pressure rating and design.										
	Proline 5Proline 5	00 – digi 00 – digi 00 alumi	ital polycarbonate ital aluminum: 2.4 inum: 6.5 kg (14. stainless: 15.6 kg	4 kg (5 3 lbs)	.3 lbs)						
	Sensor ■ Sensor w	ith cast c ith alumi	onnection housin	g versi	on, stainless: +3.	7 kg (+	8.2 lbs)				
	Nominal d		EN (DIN), AS	L)	ASME		JIS				
	[mm]	[in]	Pressure rating	[kg]	Pressure rating	[kg]	Pressure rating	[kg]			
	15	1/2	PN 40	4.5	Class 150	4.5	10K	4.5			
	25	1	PN 40	5.3	Class 150	5.3	10K	5.3			
	32	_	PN 40	6	Class 150	-	10K	5.3			
	40	1 ½	PN 40	7.4	Class 150	7.4	10K	6.3			
	50	2	PN 40	8.6	Class 150	8.6	10K	7.3			
	65	-	PN 16	10	Class 150	-	10K	9.1			
	80	3	PN 16	12	Class 150	12	10K	10.5			
	100 4 PN 16 14 Class 150 14 10K 12.7										

Nominal d	iameter	EN (DIN), AS	EN (DIN), AS ¹⁾		ASME		
[mm]	[in]	Pressure rating	[kg]	Pressure rating	[kg]	Pressure rating	[kg]
125	-	PN 16	19.5	Class 150	-	10K	19
150	6	PN 16	23.5	Class 150	23.5	10K	22.5
200	8	PN 10	43	Class 150	43	10K	39.9
250	10	PN 10	63	Class 150	73	10K	67.4
300	12	PN 10	68	Class 150	108	10K	70.3
350	14	PN 10	103	Class 150	173	10K	79
400	16	PN 10	118	Class 150	203	10K	100
450	18	PN 10	159	Class 150	253	10K	128
500	20	PN 10	154	Class 150	283	10K	142
600	24	PN 10	206	Class 150	403	10K	188

1) For flanges according to AS, only DN 25 and 50 are available.

Weight in US units

Nominal	diameter	ASME				
[mm]	[in]	Pressure rating	[lbs]			
15	1/2	Class 150	9.92			
25	1	Class 150	11.7			
40	1 ½	Class 150	16.3			
50	2	Class 150	19.0			
80	3	Class 150	26.5			
100	4	Class 150	30.9			
150	6	Class 150	51.8			
200	8	Class 150	94.8			
250	10	Class 150	161.0			
300	12	Class 150	238.1			
350	14	Class 150	381.5			
400	16	Class 150	447.6			
450	18	Class 150	557.9			
500	20	Class 150	624.0			
600	24	Class 150	888.6			

Measuring tube specification	j						Process connection internal diameter				
			EN (DIN)	ASME	AS 2129	AS 4087	JIS	PI	Ā	PT	ΈE
	[mm]	[in]	[bar]	[psi]	[bar]	[bar]	[bar]	[mm]	[in]	[mm]	[in]
	15	1/2	PN 40	Class 150	-	-	20K	-	-	15	0.59
	25	1	PN 40	Class 150	Table E	-	20K	23	0.91	26	1.02
	32	-	PN 40	-	-	-	20K	32	1.26	35	1.38
	40	1 1/2	PN 40	Class 150	-	-	20K	36	1.42	41	1.61
	50	2	PN 40	Class 150	Table E	PN 16	10K	48	1.89	52	2.05

	Nominal diameter		Pressure rating					connectior	internal (diameter
		EN (DIN)	ASME	AS 2129	AS 4087	JIS	PF	Ā	PT	FE
[mm]	[in]	[bar]	[psi]	[bar]	[bar]	[bar]	[mm]	[in]	[mm]	[in]
65	-	PN 16	-	-	-	10K	63	2.48	67	2.64
80	3	PN 16	Class 150	-	-	10K	75	2.95	80	3.15
100	4	PN 16	Class 150	-	_	10K	101	3.98	104	4.09
125	-	PN 16	-	-	-	10K	126	4.96	129	5.08
150	6	PN 16	Class 150	-	-	10K	154	6.06	156	6.14
200	8	PN 10	Class 150	-	-	10K	201	7.91	202	7.95
250	10	PN 10	Class 150	-	-	10K	_	-	256	10.1
300	12	PN 10	Class 150	-	-	10K	-	-	306	12.0
350	14	PN 10	Class 150	-	-	10K	-	-	337	13.3
400	16	PN 10	Class 150	-	-	10K	-	-	387	15.2
450	18	PN 10	Class 150	-	_	10K	-	-	432	17.0
500	20	PN 10	Class 150	-	-	10K	-	-	487	19.2
600	24	PN 10	Class 150	-	-	10K	-	-	593	23.3

Materials

Transmitter housing

Housing of Proline 500 - digital transmitter

Order code for "Transmitter housing":

- Option **A** "Aluminum coated": aluminum, AlSi10Mg, coated
- Option D "Polycarbonate": polycarbonate

Housing of Proline 500 transmitter

Order code for "Transmitter housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option L "Cast, stainless": cast, stainless steel, 1.4409 (CF3M) similar to 316L

Window material

Order code for "Transmitter housing":

- Option **A** "Aluminum, coated": glass
- Option **D** "Polycarbonate": plastic
- Option L "Cast, stainless": glass

Fastening components for mounting on a post


- Screws, threaded bolts, washers, nuts: stainless A2 (chrome-nickel steel)
- Metal plates: stainless steel, 1.4301 (304)

Sensor connection housing

Order code for "Sensor connection housing":

- Option A "Aluminum coated": aluminum, AlSi10Mg, coated
- Option D "Polycarbonate": polycarbonate
- Option L "Cast, stainless": 1.4409 (CF3M) similar to 316L

Cable entries/cable glands



- 50 Possible cable entries/cable glands
- 1 Female thread M20 × 1.5
- 2 Cable gland $M20 \times 1.5$
- 3 Adapter for cable entry with female thread G $\frac{1}{2}$ or NPT $\frac{1}{2}$ "

Cable entries and adapters	Material
Cable gland M20 × 1.5	Plastic
 Adapter for cable entry with female thread G ½" Adapter for cable entry with female thread NPT ½" 	Nickel-plated brass
 Only available for certain device versions: Order code for "Transmitter housing": Option A "Aluminum, coated" Option D "Polycarbonate" Order code for "Sensor connection housing": Proline 500 - digital: Option A "Aluminum coated" Option L "Cast, stainless" Proline 500: Option A "Aluminum coated" Option A "Aluminum coated" Option A "Aluminum coated" Option A "Aluminum coated" Option A "Aluminum coated" 	
 Adapter for cable entry with female thread G ¹/₂" Adapter for cable entry with female thread NPT ¹/₂" 	Stainless steel, 1.4404 (316L)
 Only available for certain device versions: Order code for "Transmitter housing": Option L "Cast, stainless" Order code for "Sensor connection housing": Option L "Cast, stainless" 	

Connecting cable

UV rays can impair the cable outer sheath. Protect the cable from exposure to sun as much as possible.

Connecting cable for sensor - Proline 500 - digital transmitter

PVC cable with copper shield

Connecting cable for sensor - Proline 500 transmitter

PVC cable with copper shield

Sensor housing

- DN 15 to 300 (½ to 12") Aluminum half-shell housing, aluminum, AlSi10Mg, coated
- DN 25 to 600 (1 to 24")
 Fully welded carbon steel housing with protective varnish

Measuring tubes

Stainless steel, 1.4301/304/1.4306/304LFor flanges made of carbon with Al/Zn protective coating (DN 15 to 300 ($\frac{1}{2}$ to 12")) or protective varnish (DN 350 to 600 (14 to 24"))

Liner

- PFA
- PTFE

Process connections

EN 1092-1 (DIN 2501) Stainless steel, 1.4571; carbon steel, E250C ³⁾/S235JRG2/P245GH

ASME B16.5 Stainless steel, F316L; carbon steel, A105³⁾

JIS B2220 Stainless steel, F316L; carbon steel, A105/A350 LF2 ³⁾

AS 2129 Table E • DN 25 (1"): carbon steel, A105/S235JRG2

DN 40 (1 ½"): carbon steel, A105/S275JR

AS 4087 PN 16 Carbon steel, A105/S275JR

Electrodes

Stainless steel, 1.4435 (F316L); Alloy C22, 2.4602 (UNS N06022); platinum; tantalum; titanium

Seals

As per DIN EN 1514-1, form IBC

Accessories

Protective cover

Stainless steel, 1.4404 (316L)

External WLAN antenna

- Antenna: ASA plastic (acrylic ester-styrene-acrylonitrile) and nickel-plated brass
- Adapter: Stainless steel and nickel-plated brass
- Cable: Polyethylene
- Plug: Nickel-plated brass
- Angle bracket: Stainless steel

Ground disks

- Stainless steel, 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Titanium
- Tantalum

³⁾ DN 15 to 300 (¹/₂ to 12") with Al/Zn protective varnish; DN 350 to 600 (14 to 24") with protective varnish

Fitted electrodes	Measuring electrode, reference electrode and empty pipe detection electrode: 1.4435 (316L) Alloy C22, 2.4602 (UNS N06022) Tantalum Titanium Platinum Optional: only platinum or tantalum measuring electrode
Process connections	 EN 1092-1 (DIN 2501) ASME B16.5 JIS B2220 AS 2129 Table E AS 4087 PN 16
	For information on the different materials used in the process connections \rightarrow 🗎 210
Surface roughness	Stainless steel electrodes, 1.4435 (F316L); Alloy C22, 2.4602 (UNS N06022); platinum; tantalum; titanium: ≤ 0.3 to 0.5 μm (11.8 to 19.7 μin) (All data refer to parts in contact with the medium)
	Liner with PFA: \leq 0.4 µm (15.7 µin) (All data refer to parts in contact with the medium)
	16.11 Operability
Languages	 Can be operated in the following languages: Via local operation English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Korean, Vietnamese, Czech, Swedish Via Web browser


- Via Web browser
 English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Vietnamese, Czech, Swedish
- Via "FieldCare", "DeviceCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

Local operation

Via display module

Equipment:

- Order code for "Display; operation", option F "4-line, illuminated, graphic display; touch control"
- Order code for "Display; operation", option G "4-line, illuminated, graphic display; touch control + WLAN"



Endress+Hauser

	 51 Operation with t 1 Proline 500 - digita 2 Proline 500 			A002823
	Display elements			
	 Format for display configured Permitted ambien 	d lighting; switches to r ying measured variable at temperature for the c	s and status variabl lisplay: –20 to +60	es can be individually
	e, e	n via touch control (3 o Its also accessible in the		t opening the housing: 王, he hazardous area
Remote operation	→ 🖹 89			
Service interface	→ 🗎 90			
Supported operating tools	1 5	perating tool used, acce		s to the measuring device. different operating units and
	Supported operating tools	Operating unit	Interface	Additional information
	Web browser	Notebook, PC or tablet with Web browser	 CDI-RJ45 service interface WLAN interface 	Special Documentation for the device
	DeviceCare SFE100	Notebook, PC or tablet with Microsoft Windows	CDI-RJ45 service interface MI AN interface	→ 🖺 185

WLAN interfaceFieldbus protocol

CDI-RJ45 service

interface WLAN interfaceFieldbus protocol → 🗎 185

system

system

Notebook, PC or tablet with Microsoft Windows

FieldCare SFE500

Supported operating tools	Operating unit	Interface	Additional information
Field Xpert	SMT70/77/50	 All fieldbus protocols WLAN interface Bluetooth CDI-RJ45 service interface 	Operating Instructions BA01202S Device description files: Use update function of handheld terminal
SmartBlue app	Smart phone or tablet with iOs or Android	WLAN	→ 🗎 185

- Other operating tools based on FDT technology with a device driver such as DTM/ iDTM or DD/EDD can be used for device operation. These operating tools are available from the individual manufacturers. Integration into the following operating tools, among others, is supported:
 - FactoryTalk AssetCentre (FTAC) from Rockwell Automation → www.rockwellautomation.com
 - Process Device Manager (PDM) from Siemens → www.siemens.com
 - Asset Management Solutions (AMS) from Emerson → www.emersonprocess.com
 - FieldCommunicator 375/475 from Emerson → www.emersonprocess.com
 - Field Device Manager (FDM) from Honeywell → www.process.honeywell.com
 - FieldMate from Yokogawa → www.yokogawa.com
 - PACTWare → www.pactware.com

The related device description files are available: www.endress.com \rightarrow Downloads

Web server

Thanks to the integrated Web server the device can be operated and configured via a Web browser and via the service interface (CDI-RJ45) or via the WLAN interface. The structure of the operating menu is the same as for the local display. In addition to the measured values, device status information is also displayed and allows users to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

A device that has a WLAN interface (can be ordered as an option) is required for the WLAN connection: order code for "Display; operation", option G "4-line, illuminated; touch control + WLAN". The device acts as an Access Point and enables communication by computer or a mobile handheld terminal.

Supported functions

Data exchange between the operating unit (such as a notebook for example) and the measuring device:

- Upload the configuration from the measuring device (XML format, configuration backup)
- Save the configuration to the measuring device (XML format, restore configuration)
- Export event list (.csv file)
- Export parameter settings (.csv file or PDF file, document the measuring point configuration)
- Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package)
- Flash firmware version for device firmware upgrade, for instance
- Download driver for system integration

Web server special documentation $\rightarrow \cong 219$

HistoROM data management The measuring device features HistoROM data management. HistoROM data management comprises both the storage and import/export of key device and process data, making operation and servicing far more reliable, secure and efficient.

When the device is delivered, the factory settings of the configuration data are stored as a backup in the device memory. This memory can be overwritten with an updated data record, for example after commissioning.

Additional information on the data storage concept

There are different types of data storage units in which device data are stored and used by the device:

	HistoROM backup	T-DAT	S-DAT
Available data	 Event logbook such as diagnostic events for example Parameter data record backup Device firmware package 	 Measured value logging ("Extended HistoROM" order option) Current parameter data record (used by firmware at run time) Maximum indicators (min/max values) Totalizer values 	 Sensor data: nominal diameter etc. Serial number Calibration data Device configuration (e.g. SW options, fixed I/O or multi I/O)
Storage location	Fixed on the user interface board in the connection compartment	Attachable to the user interface board in the connection compartment	In the sensor plug in the transmitter neck part

Data backup

Automatic

- The most important device data (sensor and transmitter) are automatically saved in the DAT modules
- If the transmitter or measuring device is replaced: once the T-DAT containing the previous device data has been exchanged, the new measuring device is ready for operation again immediately without any errors
- If the sensor is replaced: once the sensor has been replaced, new sensor data are transferred from the S-DAT in the measuring device and the measuring device is ready for operation again immediately without any errors
- If exchanging the electronics module (e.g. I/O electronics module): Once the electronics module has been replaced, the software of the module is compared against the current device firmware. The module software is upgraded or downgraded where necessary. The electronics module is available for use immediately afterwards and no compatibility problems occur.

Manual

Additional parameter data record (complete parameter settings) in the integrated device memory HistoROM backup for:

Data backup function

Backup and subsequent restoration of a device configuration in the device memory HistoROM backup

Data comparison function

Comparison of the current device configuration with the device configuration saved in the device memory HistoROM backup

Data transmission

Manual

Transfer of a device configuration to another device using the export function of the specific operating tool, e.g. with FieldCare, DeviceCare or Web server: to duplicate the configuration or to store in an archive (e.g. for backup purposes)

Event list

Automatic

- Chronological display of up to 20 event messages in the events list
- If the Extended HistoROM application package (order option) is enabled: up to 100 event messages are displayed in the events list along with a time stamp, plain text description and remedial measures
- The events list can be exported and displayed via a variety of interfaces and operating tools e.g. DeviceCare, FieldCare or Web server

Data logging

Manual

- If the **Extended HistoROM** application package (order option) is enabled:
- Record up to 1000 measured values via 1 to 4 channels
- User configurable recording interval
- Record up to 250 measured values via each of the 4 memory channels
- Export the measured value log via a variety of interfaces and operating tools e.g. FieldCare, DeviceCare or web server

16.12 Certificates and approvals

Current certificates and approvals that are available for the product can be selected via the Product Configurator at www.endress.com:

- 1. Select the product using the filters and search field.
- 2. Open the product page.
- 3. Select **Configuration**.

CE mark	The device meets the legal requirements of the applicable EU Directives. These are listed in the corresponding EU Declaration of Conformity along with the standards applied.	
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.	
UKCA marking	The device meets the legal requirements of the applicable UK regulations (Statutory Instruments). These are listed in the UKCA Declaration of Conformity along with the designated standards. By selecting the order option for UKCA marking, Endress+Hauser confirms a successful evaluation and testing of the device by affixing the UKCA mark.	
	Contact address Endress+Hauser UK: Endress+Hauser Ltd. Floats Road Manchester M23 9NF United Kingdom www.uk.endress.com	
RCM mark	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".	
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.	
Functional safety	The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture; order code for "Additional approval", option LA) and SIL	

3 (multi-channel architecture with homogeneous redundancy) and is independently evaluated and certified in accordance with IEC 61508.

The following types of monitoring in safety equipment are possible:

Functional Safety Manual with information on the SIL device \rightarrow 🗎 219

HART certification	HART interface		
	The measuring device is certified and registered by the FieldComm Group. The measuring system meets all the requirements of the following specifications: • Certified according to HART 7 • The device can also be operated with certified devices of other manufacturers		
	(interoperability)		
Radio approval	The measuring device has radio approval.		
	For detailed information on the radio approval, see the Special Documentation		
Pressure Equipment Directive	 With the marking: a) PED/G1/x (x = category) or b) UK/G1/x (x = category) on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" 		
	 a) specified in Annex I of the Pressure Equipment Directive 2014/68/EU or b) Schedule 2 of Statutory Instruments 2016 No. 1105. Devices not bearing this marking (without PED or UKCA) are designed and 		
	manufactured according to sound engineering practice. They meet the requirements of a) Art. 4 Para. 3 of the Pressure Equipment Directive 2014/68/EU or b) Part 1, Para. 8 of Statutory Instruments 2016 No. 1105.		
	The scope of application is indicated a) in diagrams 6 to 9 in Annex II of the Pressure Equipment Directive 2014/68/EU or b) Schedule 3, Para. 2 of Statutory Instruments 2016 No. 1105.		
Additional certification	PWIS-free		
	PWIS = paint-wetting impairment substances		
	Order code for "Service": • Option HC : PWIS-free (version A) • Option HD : PWIS-free (version B) • Option HE : PWIS-free (version C)		
	For more information on PWIS-free certification, see "Test specification" document TS01028D		
Other standards and guidelines	 EN 60529 Degrees of protection provided by enclosures (IP code) EN 61010-1 		
	Safety requirements for electrical equipment for measurement, control and laboratory use - general requirements IEC/EN 61326-2-3		
	Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). • NAMUR NE 21		
	Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment		

	 NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics NAMUR NE 105 Specifications for integrating fieldbus devices in engineering tools for field devices NAMUR NE 107 Self-monitoring and diagnosis of field devices NAMUR NE 131 Requirements for field devices for standard applications
	16.13 Application packages
	Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.
	The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.
Diagnostic functionality	Order code for "Application package", option EA "Extended HistoROM"
	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (standard version) to up to 100 entries.
	 Data logging (line recorder): Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Measured value logs can be accessed via the local display or operating tool e.g. FieldCare, DeviceCare or Web server.
	For detailed information, see the Operating Instructions for the device.
Heartbeat Technology	Order code for "Application package", option EB "Heartbeat Verification + Monitoring"
	 Heartbeat Verification Meets the requirement for traceable verification to DIN ISO 9001:2008 Chapter 7.6 a) "Control of monitoring and measuring equipment". Functional testing in the installed state without interrupting the process. Traceable verification results on request, including a report. Simple testing process via local operation or other operating interfaces. Clear measuring point assessment (pass/fail) with high test coverage within the framework of manufacturer specifications. Extension of calibration intervals according to operator's risk assessment.

	 Heartbeat Monitoring Continuously supplies data, which are characteristic of the measuring principle, to an external condition monitoring system for the purpose of preventive maintenance or process analysis. These data enable the operator to: Draw conclusions - using these data and other information - about the impact the process influences (e.g. formation of buildup, magnetic field interference etc.) have on measuring performance over time. Schedule servicing in time. Monitor the process or product quality.
Cleaning	Order code for "Application package", option EC "ECC electrode cleaning "
	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe_3O_4) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to avoid build-up of very conductive matter and thin layers (typical of magnetite).
	For detailed information, see the Operating Instructions for the device.
OPC-UA Server	Order code for "Application package", option EL "OPC-UA Server"
	The application package provides an integrated OPC-UA server for comprehensive device services for IoT and SCADA applications.
	For detailed information, see the Special Documentation for the device.
	16.14 Accessories
	Overview of accessories available for order $\rightarrow \triangleq 183$
	16.15 Supplementary documentation
	For an overview of the scope of the associated Technical Documentation, refer to the following:
	 Device Viewer (www.endress.com/deviceviewer): Enter serial number from nameplate.
	 Endress+Hauser Operations app: Enter serial number from nameplate or scan

Standard documentation Brief Operating Instructions

Brief Operating Instructions for the sensor

Measuring device	Documentation code
Proline Promag P	KA01290D

matrix code on nameplate.

Brief Operating Instructions for the transmitter

Measuring device	Documentation code
Proline 500 – digital	KA01313D
Proline 500	KA01312D

Technical Information

1	Measuring device	Documentation code
]	Promag P 500	TI01226D

Description of Device Parameters

Measuring device	Documentation code
Promag 500	GP01054D

Supplementary devicedependent documentation

Safety instructions

Safety instructions for electrical equipment for hazardous areas.

Contents	Documentation code
ATEX/IECEx Ex i	XA01522D
ATEX/IECEx Ex ec	XA01523D
cCSAus IS	XA01524D
cCSAus Ex e ia/Ex d ia	XA01525D
cCSAus Ex nA	XA01526D
INMETRO Ex i	XA01527D
INMETRO Ex ec	XA01528D
NEPSI Ex i	XA01529D
NEPSI Ex nA	XA01530D
EAC Ex i	XA01658D
EAC Ex nA	XA01659D
JPN	XA01776D

Functional Safety Manual

Contents	Documentation code
Promag 500	SD01741D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD01614D
Radio approvals for WLAN interface for A309/A310 display module	SD01793D
Web server	SD01658D
OPC-UA server	SD02044D

Contents	Documentation code
Heartbeat Technology	SD01641D
Web server	SD01658D

Installation Instructions

Contents	Comment
Installation instructions for spare part sets and accessories	 Access the overview of all the available spare part sets via <i>Device Viewer</i> → ■ 181 Accessories available for order with Installation Instructions → ■ 183

Index

A

11
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Adapters
Adapting the diagnostic behavior
Adapting the status signal 167
Additional certification
Ambient conditions
Ambient temperature
Mechanical load
Operating height 202
Relative humidity
Ambient temperature
Influence
Ambient temperature range
AMS Device Manager
Function
Application
Applicator
Approvals
Attaching the connecting cable
Proline 500 transmitter
B
B Puret mode
B Burst mode
2
Burst mode
Burst mode 98 C Cable entries Technical data 198 Cable entry Degree of protection Degree of protection 67 CE mark 10, 215
Burst mode
Burst mode
Burst mode 98 C Cable entries Technical data 198 Cable entry Degree of protection Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68 Checklist 68
Burst mode 98 C 6 Cable entries 198 Cable entry 198 Cable entry 10, 215 Certificates 215 Check 68 Checklist 68
Burst mode 98 C Cable entries Technical data 198 Cable entry Degree of protection Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68 Connection 68 Post-connection check 68 Post-installation check 40
Burst mode 98 C Cable entries Technical data 198 Cable entry Degree of protection Degree of protection 67 CE mark 10, 215 Certificates 215 Check 215 Checklist 68 Post-connection check 68 Post-installation check 40 Cleaning 10
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68 Post-connection check 68 Post-installation check 40 Cleaning 180
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68 Connection 68 Checklist 68 Post-connection check 68 Post-installation check 40 Cleaning 180 Interior cleaning 180
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 68 Connection 68 Checklist 68 Post-connection check 68 Post-installation check 40 Cleaning 180 Interior cleaning 180 Commissioning 100
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 215 Check 68 Post-connection check 68 Post-installation check 40 Cleaning 180 Interior cleaning 180 Commissioning 100 Advanced settings 127
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 215 Check 68 Connection 68 Checklist 90st-connection check 68 Post-connection check 40 Cleaning 180 110 Exterior cleaning 180 100 Advanced settings 127 Configuring the measuring device
Burst mode 98 C Cable entries Technical data 198 Cable entry 198 Degree of protection 67 CE mark 10, 215 Certificates 215 Check 215 Check 68 Post-connection check 68 Post-installation check 40 Cleaning 180 Exterior cleaning 180 Interior cleaning 100 Advanced settings 127 Configuring the measuring device 100 Communication-specific data 96
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Post-connection check68Post-installation check40Cleaning180Interior cleaning180Interior cleaning127Configuring the measuring device100Communication-specific data96Compatibility179
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Post-connection check68Post-installation check68Post-installation check40Cleaning180Interior cleaning180Commissioning100Advanced settings127Configuring the measuring device100Compatibility179Conductivity204
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Post-connection check68Post-installation check40Cleaning180Interior cleaning180Commissioning100Advanced settings127Configuring the measuring device100Compatibility179Conductivity204Connecting cable41
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Post-connection check68Post-installation check40Cleaning180Interior cleaning180Interior cleaning100Advanced settings127Configuring the measuring device100Communication-specific data96Compatibility179Conductivity204Connecting cable41Connecting the connecting cable41
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Connection68Checklist90st-installation checkPost-connection check40Cleaning180Interior cleaning180Interior cleaning100Advanced settings127Configuring the measuring device100Communication-specific data96Compatibility179Conductivity204Connecting cable41Connecting the connecting cable51
Burst mode98CCable entriesTechnical data198Cable entryDegree of protection67CE mark10, 215Certificates215Check215Check68Post-connection check68Post-installation check40Cleaning180Interior cleaning180Interior cleaning100Advanced settings127Configuring the measuring device100Communication-specific data96Compatibility179Conductivity204Connecting cable41Connecting the connecting cable41

Proline 500	
Proline 500 – digital	
Connecting the signal cable/supply voltage cable	
Proline 500 – digital transmitter 52	
Proline 500 transmitter	
Connection	
see Electrical connection	
Connection preparations	
Connection tools	
Context menu	
Calling up	
Closing	
Explanation	
Current consumption	
r	
D	
Date of manufacture	
Declaration of Conformity	
Define access code	
Degree of protection	
Design	
Measuring device	
Device components	
Device description files	
Device history	
Device locking, status	
Device name	
Sensor	
Transmitter	
Device repair	
Device revision	
Device type ID	
Device Viewer	
DeviceCare	
Device description file	
Diagnostic behavior	
Explanation	
Symbols	
Diagnostic information	
Design, description	
DeviceCare	
FieldCare	
Light emitting diodes	
Local display	
Overview	
Remedial measures	
Web browser	
Diagnostic list	
Diagnostic message	
Diagnostics	
Symbols	
Dimensions	
DIP switch	
see Write protection switch	

Terminal assignment of Proline 500 - digital 49

Connecting the measuring device

Direct access
For operational display
For locking status146Disposal182
Document Function
Document function6Document information6Down pipe23
E ECC
Input screen 76 Using operating elements 76
Electrical connection Commubox FXA195 (USB)
Explorer)
Field Xpert SFX350/SFX370 89 Field Xpert SMT70 89 Measuring device 41
Operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
Operating tools Via HART protocol
Via WLAN interface
Web server 90 WLAN interface 91
Electromagnetic compatibility203Electronics module14Enabling write protection142Enabling/disabling the keypad lock82Endress+Hauser services
Maintenance
Environment Storage temperature
see Diagnostic messages
Event list 173 Event logbook 173
Ex approval

Exterior cleaning
F
Field Communicator
Function
Field Communicator 475
Field of application
Residual risks
Field Xpert
Function
Field Xpert SFX350
FieldCare
Device description file
Establishing a connection
Function
User interface
Filtering the event logbook
Firmware
Release date
Version
Firmware history
Fitted electrodes
Flow direction
Flow limit
Function check 100
Function range
Field Xpert
Function scope AMS Device Manager 94
AMS Device Manager94Field Communicator95
Field Communicator 475
SIMATIC PDM
Functional safety (SIL)
Functions
see Parameters
G
Galvanic isolation
Н
Hardware write protection
HART certification
HART input
Settings
HART protocol
Device variables
Measured variables
Heavy sensors
Help text
Calling up
Closing
Explanation
HistoROM
I
Identifying the measuring device
Immersion in water

Extended order code

Influence	

Ambient temperature
Inlet runs
Input
Inspection
Installation
Received goods
Installation check 100
Installation conditions
Dimensions
Heavy sensors
Partially filled pipe
System pressure
Thermal insulation
Vibrations
Intended use
Interior cleaning

L

Languages, operation options211Length of connecting cable29Line recorder153Local display211Navigation view73
see Diagnostic message
see In alarm condition
see Operational display
Text editor
Low flow cut off 196

Μ

Main electronics module
Maintenance tasks
Managing the device configuration
Manufacturer ID
Materials
Maximum measured error
Measured values
Calculated
Measured
see Process variables
Measuring and test equipment 180
Measuring device
Configuration
Conversion
Design
Disposal
Integrating via communication protocol 96
Mounting the sensor
Mounting the ground cable/ground disks 32
Mounting the seals
Screw tightening torques
Screw tightening torques, maximum 33
Screw tightening torques, nominal
Preparing for electrical connection 45
Preparing for mounting 31
Removing
Repairs
Switching on

N

Nameplate	
Sensor	19
Transmitter	17
Navigation path (navigation view)	73
Navigation view	
In the submenu	73
In the wizard	73
Numeric editor	75

0

Onsite display
Numeric editor
Operable flow range 189
Operating elements
Operating height
Operating keys
see Operating elements
Operating menu
Menus, submenus
Structure
Submenus and user roles 71
Operating philosophy 71
Operation
Operation options
Operational display
Operational safety
Order code
Orientation (vertical, horizontal)
Outlet runs
Output signal
Output variables

P
Packaging disposal
Parameter
Changing
Entering values or text
Parameter settings
Administration (Submenu)
Advanced setup (Submenu)
Burst configuration 1 to n (Submenu)
Configuration (Submenu)
Configuration body (Cubmony)
Configuration backup (Submenu)
Configure flow damping (Wizard) 124
Current input
Current input (Wizard)
Current input 1 to n (Submenu) 148
Current output
Current output (Wizard)
Data logging (Submenu)
Define access code (Wizard)
Device information (Submenu)
Diagnostics (Menu)
Display (Submenu)
Display (Wizard) 116
Double pulse output
Double pulse output (Submenu)
Double pulse output (Wizard)
Electrode cleaning cycle (Submenu)
Empty pipe detection (Wizard)
I/O configuration
I/O configuration (Submenu)
Input (Submenu) 121
Low flow cut off (Wizard) 118
Process variables (Submenu) 146
Pulse/frequency/switch output
Pulse/frequency/switch output (Wizard)
110, 111, 114
Pulse/frequency/switch output 1 to n (Submenu) 150
Relay output
Relay output 1 to n (Submenu)
Relay output 1 to n (Wizard)
Reset access code (Submenu)
Sensor adjustment (Submenu)
Setup (Menu)
Simulation (Submenu)
Status input
Status input 1 to n (Submenu)
System units (Submenu)
Totalizer (Submenu)
Totalizer 1 to n (Submenu)
Totalizer handling (Submenu)
Value current output 1 to n (Submenu) 149
Web server (Submenu)
WLAN settings (Wizard)
Partially filled pipe 24
Performance characteristics
Post-connection check (checklist) 68
Post-installation check (checklist) 40
Potential equalization

Power consumption
Power supply failure 197
Pressure Equipment Directive
Pressure loss
Pressure tightness
Pressure-temperature ratings 205
Process conditions
Conductivity
Flow limit
Medium temperature
Pressure loss
Pressure tightness
Process connections
Product safety
Proline 500 – digital transmitter
Connecting the signal cable/supply voltage cable 52
Proline 500 connecting cable terminal assignment
Sensor connection housing
Proline 500 transmitter
Connecting the signal cable/supply voltage cable 57
Protecting parameter settings

R

Radio approval 216 RCM mark 215 Read access 81
Reading measured values
Recalibration
Reference operating conditions
Registered trademarks
Remedial measures
Calling up
Closing
Remote operation
- F
Repair
1
Repeatability
•
Device components
Return 181
S
Safety
Screw tightening torques
Maximum
Nominal
Sensor
Mounting
Serial number
Setting the operating language
Settings
Adapting the measuring device to the process
conditions
Administration

Advanced display configurations130Current input106Current output107

Double pulse output	
Electrode cleaning circuit (ECC)	
Empty pipe detection (EPD)	
HART input	
I/O configuration	
Local display	
Low flow cut off	
Managing the device configuration	
Operating language	
Pulse output	
Pulse/frequency/switch output 110	
Relay output	
Resetting the device	
Resetting the totalizer	
Sensor adjustment	
Simulation	
Status input	
Switch output	
System units	
Tag name	
Totalizer	
Totalizer reset	
WLAN	
Show data logging	
Signal on alarm	
SIL (functional safety)	
SIMATIC PDM	
Function	
Software release	
Spare part	
Spare parts	
Special connection instructions	
Standards and guidelines	. 210
For operational display	70
In the navigation view	
Status signals	
Storage concept	
Storage conditions	
Storage temperature	
Storage temperature range	
Structure	201
Operating menu	70
Submenu	
Administration	3. 139
Advanced setup	
Burst configuration 1 to n	
Configuration	
Configuration backup	
Current input 1 to n	
Data logging	
Device information	
Display	. 130
Double pulse output	. 151
Electrode cleaning cycle	. 134
Event list	
HART input	
I/O configuration	
Input	. 121

Process variables 146 Pulse/frequency/switch output 1 to n 150 Relay output 1 to n 150 Reset access code 139 Sensor adjustment 128 Simulation 139 Status input 1 to n 148 System units 102 Totalizer 147 Totalizer 1 to n 128 Totalizer handling 151 Value current output 1 to n 149 Web server 88 Supplementary documentation 218 Supply voltage 197
Surface roughness
Switch output
Symbols
Controlling data entries
For communication
For diagnostic behavior
For locking
For measured variable
For measurement channel number
For menus
For parameters
g · · · · · · · · ·
For wizard74In the status area of the local display72
Input screen
Operating elements
System design
Measuring system
see Measuring device design
System integration
System pressure
T
Technical data, overview
Ambient temperature range for display 211
Storage temperature
Terminal assignment
Terminal assignment of connecting cable for Proline
500- digital
Sensor connection housing
Terminals 198 Text editor 75
Thermal insulation
For mounting
For mounting 31 Transport 21
Tool tip
see Help text
r

225

Tools
Electrical connection
Totalizer
Configuration
Transmitter Turning the display module
Turning the display module39Turning the housing39
Transporting the measuring device
Troubleshooting
General
Turning the display module
Turning the electronics housing
see Turning the transmitter housing
Turning the transmitter housing
U
UKCA marking 215
Use in saline water
Use of the measuring device
Borderline cases
Incorrect use
see Intended use User interface
Current diagnostic event
Previous diagnostic event
User roles
17
V Version data for the device
Version data for the device 96
Vibration- and shock-resistance
Vibration- and shock-resistance
Vibration- and shock-resistance
Vibration- and shock-resistance 202 Vibrations 28 W 180, 181
Vibration- and shock-resistance 202 Vibrations
Vibration- and shock-resistance 202 Vibrations
Vibration- and shock-resistance
Vibration- and shock-resistance
Vibration- and shock-resistance
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight16Transport (notes)21WizardConfigure flow dampingCurrent input106Current output107
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight16Transport (notes)21WizardConfigure flow damping124Current input106Current output107Define access code138
Vibration- and shock-resistance202Vibrations28W180, 181W@M180, 181W@M Device Viewer16Weight121Transport (notes)21Wizard124Configure flow damping124Current input106Current output107Define access code138Display116
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight17Transport (notes)21Wizard124Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight16Transport (notes)21Wizard124Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119
Vibration- and shock-resistance202Vibrations28W180, 181W@M180, 181W@M Device Viewer16Weight16Transport (notes)21Wizard124Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119Low flow cut off118
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight17Transport (notes)21Wizard21Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119Low flow cut off110, 111, 114
Vibration- and shock-resistance 202 Vibrations 28 W 180, 181 W@M 180, 181 W@M Device Viewer 16 Weight 1 Transport (notes) 21 Wizard 20 Configure flow damping 124 Current input 106 Current output 107 Define access code 138 Display 116 Double pulse output 123 Empty pipe detection 119 Low flow cut off 118 Pulse/frequency/switch output 110, 111, 114 Relay output 1 to n 122 Status input 1 to n 105
Vibration- and shock-resistance202Vibrations28WWW@M180, 181W@M Device Viewer16Weight16Transport (notes)21Wizard124Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119Low flow cut off118Pulse/frequency/switch output110, 111, 114Relay output 1 to n122Status input 1 to n105WLAN settings135
Vibration- and shock-resistance 202 Vibrations 28 W 28 W@M 180, 181 W@M Device Viewer 16 Weight 16 Transport (notes) 21 Wizard 124 Configure flow damping 124 Current input 106 Current output 107 Define access code 138 Display 116 Double pulse output 123 Empty pipe detection 119 Low flow cut off 118 Pulse/frequency/switch output 110, 111, 114 Relay output 1 to n 122 Status input 1 to n 105 WLAN settings 135
Vibration- and shock-resistance 202 Vibrations 28 W 28 W@M 180, 181 W@M Device Viewer 16 Weight 180, 181 Transport (notes) 21 Wizard 21 Configure flow damping 124 Current input 106 Current output 107 Define access code 138 Display 116 Double pulse output 123 Empty pipe detection 119 Low flow cut off 118 Pulse/frequency/switch output 110, 111, 114 Relay output 1 to n 105 WLAN settings 135 WLAN settings 135
Vibration- and shock-resistance202Vibrations28W28W@M180, 181W@M Device Viewer16Weight17Transport (notes)21Wizard21Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119Low flow cut off110, 111, 114Relay output 1 to n122Status input 1 to n125WLAN settings135Workplace safety10Write access81
Vibration- and shock-resistance 202 Vibrations 28 W 28 W@M 180, 181 W@M Device Viewer 16 Weight 17 Transport (notes) 21 Wizard 124 Current input 106 Current output 107 Define access code 138 Display 116 Double pulse output 123 Empty pipe detection 119 Low flow cut off 118 Pulse/frequency/switch output 110, 111, 114 Relay output 1 to n 122 Status input 1 to n 105 WLAN settings 135 Workplace safety 10 Write protection 10
Vibration- and shock-resistance202Vibrations28W28W@M180, 181W@M Device Viewer16Weight17Transport (notes)21Wizard21Configure flow damping124Current input106Current output107Define access code138Display116Double pulse output123Empty pipe detection119Low flow cut off110, 111, 114Relay output 1 to n122Status input 1 to n125WLAN settings135Workplace safety10Write access81



www.addresses.endress.com

