Operating Instructions Levelflex FMP53 HART

Guided wave radar










Table of contents

1	Important document information	5
1.1 1.2 1.3	Symbols11.2.1Safety symbols1.2.2Electrical symbols1.2.3Tool symbols1.2.4Symbols for certain types of information and graphics	555567
1.4 1.5	1.3.1Technical Information (TI)1.3.2Brief Operating Instructions (KA)1.3.3Safety Instructions (XA)1.3.4Functional Safety Manual (FY)Terms and abbreviations	7 7 7 7 8
2	Basic safety instructions	9
2.1 2.2 2.3 2.4 2.5	1 1	0 0 0
3	Product description 12	2
3.1	Product design123.1.1Levelflex FMP533.1.2Electronics housing	2
4	Incoming acceptance and product	
	identification 14	ł
4.1 4.2	Incoming acceptance14Product identification144.2.1Nameplate1	4
5	Storage, transport 16	5
5.1 5.2	Storage temperature16Transporting the product to the measuringpoint16	-
	point	0
6	Mounting 17	7
6.1	Mounting requirements176.1.1Suitable mounting position176.1.2Mounting under confined conditions186.1.3Notes on the mechanical load of the	7 9
6.2	probe226.1.4Special installation situations22Mounting the measuring device286.2.1Tool list28	2 8

	6.2.2 Mounting the "Sensor, remote"	
	version	28
	6.2.3 Turning the transmitter housing	29
	6.2.4 Turning the display	30
6.3	Post-installation check	31
7	Electrical connection	32
7.1	Connecting requirements	32
	7.1.1 Terminal assignment	32
	7.1.2 Cable specification	36
	7.1.3 Device plug	36
	7.1.4 Supply voltage	38
7 0	7.1.5 Overvoltage protection	41
7.2	Connecting the device7.2.1Opening cover	41 42
	7.2.2 Connecting	42 42
	7.2.3 Plug-in spring-force terminals	42
	7.2.4 Closing the cover of the connection	10
	compartment	43
7.3	Post-connection check	43
8	Operation methods	44
8.1	Overview	44
0.1	8.1.1 Local operation	44
	8.1.2 Operation with remote display and	
	operating module FHX50	45
	8.1.3 Operation via Bluetooth [®] wireless	
	technology	46
0.0	8.1.4 Remote operation	47
8.2	Structure and function of the operating	48
	menu8.2.1Structure of the operating menu	40 48
	8.2.2 User roles and related access	40
	authorization	50
	8.2.3 Data access - Security	50
8.3	Display and operating module	55
	8.3.1 Display	55
	8.3.2 Operating elements	58
	8.3.3 Entering numbers and text	59
	8.3.4 Opening the context menu	60
	8.3.5 Envelope curve display on the display	67
	and operating module	62
9	Device integration via the HART	
	protocol	63
9.1	Overview of the Device Description files (DD).	63
9.2	HART device variables and measuring values .	63
10	Commissioning via SmartBlue	
	(App)	64
10.1	Prerequisites	64
10.2	SmartBlue App	64

10.3	Envelope curve display in SmartBlue 64
11	Commissioning using the
	Commissioning Wizard 66
12	Commissioning via operating
	menu 67
12.1	Function check
12.2	Setting the operating language 67
12.3	Configuring level measurement
12.4	Recording the reference envelope curve 70
12.5	Configuring the local display
	level measurements
	12.5.2 Adjusting the local display 71
12.6	Configuring the current outputs 72
	12.6.1 Factor setting of current outputs for
	level measurements
12.7	Configuration management
12.8	Protecting settings from unauthorized access . 74
	5
13	Diagnostics and troubleshooting 75
13.1	General troubleshooting
	13.1.1 General errors 75 13.1.2 Error - SmartBlue operation 77
	13.1.2Error - SmartBlue operation 7713.1.3Parametrization errors 78
13.2	Diagnostic information on local display 79
19.0	13.2.1 Diagnostic message
	13.2.2 Calling up remedial measures 81
13.3	Diagnostic event in the operating tool 82
13.4	Diagnostic list
13.5	List of diagnostic events
13.6	Event logbook 86 13.6.1 Event history 86
	13.6.2 Filtering the event logbook
	13.6.3 Overview of information events 86
13.7	Firmware history 88
17	N : /
14	Maintenance 89
14.1	Exterior cleaning
14.2 14.3	General cleaning instructions
14.5	Cleaning the probe
	14.3.2 Cleaning the probe outside the
	vessel
15	Repair
	1
15.1	General information 91 15.1.1 Repair concept 91
	15.1.1 Repair concept9115.1.2 Repair of Ex-certified devices91
	15.1.3 Replacing electronics modules 91
	15.1.4 Replacing a device
15.2	Spare parts
15.3	Return

15.4	Disposal	92
16	Accessories	93
16.1	Device-specific accessories 16.1.1 Weather protection cover 16.1.2 Mounting bracket for electronics	93 93
	housing	94 94 95 95 95 96
	devices	97
16.2	Communication-specific accessories	98
16.3	Service-specific accessories	99
16.4	System components	99
17	Operating menu 1	100
17.1	Overview of the operating menu (SmartBlue)	100
17.2	Overview of the operating menu (display module)	105
17.3	Overview of the operating menu (operating	105
17.5		112
17.4		119
2772		126
		127
17.5		174
		176
	17.5.2 "Event logbook" submenu	177
	5	177 178
	17.5.3 "Device information" submenu 17.5.4 "Measured values" submenu	
	 17.5.3 "Device information" submenu 17.5.4 "Measured values" submenu 17.5.5 "Data logging" submenu 	178 181 183
	 17.5.3 "Device information" submenu 17.5.4 "Measured values" submenu 17.5.5 "Data logging" submenu 17.5.6 "Simulation" submenu 	178 181 183 186
	 17.5.3 "Device information" submenu 17.5.4 "Measured values" submenu 17.5.5 "Data logging" submenu 17.5.6 "Simulation" submenu 17.5.7 "Device check" submenu 	178 181 183 186 191
	 17.5.3 "Device information" submenu 17.5.4 "Measured values" submenu 17.5.5 "Data logging" submenu 17.5.6 "Simulation" submenu 17.5.7 "Device check" submenu 	178 181 183 186

1 Important document information

1.1 Purpose of this document

These Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

\sim

Alternating current

\sim

Direct current and alternating current

_ _ _

Direct current

Ŧ

Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols

● ✓
Phillips head screwdriver

0

Flat blade screwdriver

06

Torx screwdriver

⊖ ∉ Allen key

が Open-ended wrench

1.2.4 Symbols for certain types of information and graphics

Permitted

Procedures, processes or actions that are permitted

✓ ✓ Preferred

Procedures, processes or actions that are preferred

Forbidden Procedures, processes or actions that are forbidden

1 Tip Indicates additional information

Reference to documentation

Reference to graphic

Notice or individual step to be observed

1., 2., 3. Series of steps

L► Result of a step

Visual inspection

Operation via operating tool

A

Write-protected parameter

1, 2, 3, ... Item numbers

A, B, C, ... Views

 $\underline{\wedge} \rightarrow \square$ Safety instructions Observe the safety instructions contained in the associated Operating Instructions

Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

1.3 Documentation

The following types of documentation are available in the Download Area of the Endress +Hauser website (www.endress.com/downloads):

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

1.3.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.3.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

The nameplate indicates the Safety Instructions (XA) that are relevant to the device.

1.3.4 Functional Safety Manual (FY)

Depending on the SIL approval, the Functional Safety Manual (FY) is an integral part of the Operating Instructions and applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions.

The different requirements that apply for the protective function are described in the Functional Safety Manual (FY).

1.4 Terms and abbreviations

BA

Document type "Operating Instructions"

KA

Document type "Brief Operating Instructions"

ΤI

Document type "Technical Information"

SD

Document type "Special Documentation"

XA

Document type "Safety Instructions"

PN

Nominal pressure

MWP

Maximum working pressure The MWP is indicated on the nameplate.

ToF

Time of Flight

FieldCare

Scalable software tool for device configuration and integrated plant asset management solutions

DeviceCare

Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices

DTM

Device Type Manager

DD

Device Description for HART communication protocol

$\epsilon_{\rm r}$ (Dk value)

Relative dielectric constant

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

Operating tool

The term "operating tool" is used in place of the following operating software:

- FieldCare / DeviceCare, for operation via HART communication and PC
- SmartBlue app, for operation using an Android or iOS smartphone or tablet

BD

Blocking Distance; no signals are analyzed within the BD.

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

PFS

Pulse Frequency Status (Switch output)

1.5 Registered trademarks

HART®

Registered trademark of the FieldComm Group, Austin, Texas, USA

Bluetooth®

The *Bluetooth*[®] word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple®

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ[®], VITON[®]

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

TEFLON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the level measurement of liquids. Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

If the limit values specified in the "Technical data" and the conditions listed in the instructions and additional documentation are observed, the measuring device may be used for the following measurements only:

- Measured process variables: level
- Calculable process variables: volume or mass in any shape of vessel (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- Use the measuring device only for media to which the process-wetted materials have an adequate level of resistance.
- Observe the limit values in the "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Clarification of borderline cases:

 For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies contained therein (e.g. display module, main electronics module and I/O electronics module) may rise up to 80 $^{\circ}$ C (176 $^{\circ}$ F). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► In the event of high medium temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

When working on and with the device:

• Wear the required protective equipment according to federal or national regulations.

With separable probe rods, medium may penetrate the joints between the individual parts of the rod. This medium may escape when the joints are loosened. This can cause injuries in the case of dangerous (e.g., aggressive or toxic) media.

When loosening the joints between the individual parts of the probe rod, wear appropriate protective equipment according to the medium.

2.4 Operational safety

Risk of injury!

- Operate the device only if it is in proper technical condition, free from errors and faults.
- The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to the repair of an electrical device.
- Use only original spare parts and accessories from the manufacturer.

Hazardous area

To eliminate danger to persons or the installation when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- Check the nameplate to verify whether the ordered device can be put to its intended use in the hazardous area.
- Observe the specifications in the separate supplementary documentation, which is an integral part of this manual.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets the general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 CE mark

The measuring system meets the legal requirements of the applicable EU directives. These are listed in the corresponding EU Declaration of Conformity together with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity


The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity along with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the EAC mark.

3 **Product description**

3.1 Product design


3.1.1 Levelflex FMP53



I Design of the Levelflex

- 1 Electronics housing
- 2 Process connection
- 3 Rod probe

3.1.2 Electronics housing



- ☑ 2 Design of the electronics housing
- 1 Electronics compartment cover
- 2 Display module
- *3 Main electronics module*
- 4 Cable glands (1 or 2, depending on instrument version)
- 5 Nameplate
- 6 I/O electronics module
- 7 Terminals (pluggable spring terminals)
- 8 Connection compartment cover
- 9 Grounding terminal

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Check the following during incoming acceptance:

- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): are the Safety Instructions (XA) provided?


If one of these conditions is not met, please contact your Endress+Hauser sales office.

4.2 Product identification

The following options are available for the identification of the measuring device: • Nameplate specifications

- Order code with breakdown of the device features on the delivery note
- Enter the serial number from the nameplate in W@M Device Viewer (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial number on the nameplate into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information about the measuring device is displayed.

4.2.1 Nameplate



- ☑ 3 Nameplate of the Levelflex; engineering unit: mm (in)
- 1 Device name
- 2 Manufacturer address
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference length
- 8 Certificate symbol
- 9 Certificate- and approval-related data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication protocol): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Materials in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the cable gland thread
- 24 Probe length
- 25 Signal outputs
- 26 Supply voltage



Up to 33 characters of the extended order code are indicated on the nameplate. If the extended order code contains additional characters, these cannot be displayed. However, the complete extended order code can also be displayed via the device operating menu: **Extended order code 1 to 3** parameter

5 Storage, transport

5.1 Storage temperature

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use original packaging.


5.2 Transporting the product to the measuring point

WARNING

Housing or rod may become damaged or pull off.

Danger of injury!


- Transport the measuring device to the measuring point in its original packaging or by the process connection.
- Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or probe. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.
- ► Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs) (IEC 61010).



6 Mounting

6.1 Mounting requirements

6.1.1 Suitable mounting position



4 Installation conditions for Levelflex

Spacing requirements when mounting

- Distance (A) between the vessel wall and rod probes:
 - For smooth metallic walls: > 50 mm (2 in)
 - For plastic walls: > 300 mm (12 in) to metallic parts outside the vessel
- Distance (B) between rod probes and internal fittings (4): > 300 mm (12 in)
- When using more than one Levelflex:
 - Minimum distance between the sensor axes: 100 mm (3.94 in)
- Distance (C) from the end of the probe to the bottom of the vessel: > 10 mm (0.4 in)


Additional conditions

- When mounting outdoors, a weather protection cover (1) can be used to protect the device against extreme weather conditions.
- Do not mount the probe in the filling curtain (2).
- When the housing is mounted in a recess (e.g. in a concrete ceiling), observe a minimum distance of 100 mm (4 in) between the cover of the connection compartment/electronics compartment and the wall. Otherwise the connection compartment/electronics compartment will not be accessible after installation.

6.1.2 Mounting under confined conditions


Mounting with remote probe

The device version with a remote probe is suitable for applications with restricted mounting space (product structure: probe design). In this case, the electronics housing is mounted at a separate position from the probe.



- The connecting cable is connected to the probe upon delivery.
 - Length: 3 m (9 ft) or 6 m (18 ft)
 - Minimum bending radius: 50 mm (2 inch)
- The mounting bracket for the electronics housing is included in the delivery with this version. Mounting options:
 - Wall mounting
 - Mounting on DN32 to DN50 (1-1/4 to 2 inch) post or pipe
- The probe with the connection cable and the electronics are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

Separable probes



The use of separable rod probes (\emptyset 8 mm) is advisable in confined mounting conditions (limited distance to the ceiling).

- Max. probe length 6 m (19.68 ft)
- Max. lateral loading capacity 10 Nm
- Probes can be separated several times, with the individual parts having the following lengths:
 - 500 mm (20 in)
 - 1000 mm (40 in)
- The connection points are sealed gap-free by an O-ring.

To avoid damage to the surface of the probe: use fitting pliers with a plastic surface to mount the probe rod.

6.1.3 Notes on the mechanical load of the probe

Lateral loading capacity (flexural strength) of rod probes

FMP53

Rod 8mm (0.31") 316L 10 Nm **Rod 8mm (0.31") 316L separable** 10 Nm

Lateral load (bending moment) from flow conditions

The formula for calculating the bending moment M acting on the probe:

 $M = c_{w} \times \rho/2 \times v^{2} \times d \times L \times (L_{N} - 0.5 \times L)$

With:

c_w: coefficient of friction

 ρ [kg/m³]: density of the medium

v [m/s]: flow velocity of the medium, perpendicular to the probe rod


d [m]: diameter of the probe rod


L [m]: level

LN [m]: probe length

Sample calculation


Coefficient of friction c_w 0.9 (assuming turbulent flow - high Reynolds number)Density ρ [kg/m³]1000 (e.g. water)Probe diameter d [m]0.008L = L_N(unfavorable conditions)





A0014131

6.1.4 Special installation situations



Tanks with spray ball for probe cleaning


Mounting close to vessel wall

Mounting the probe close to the vessel wall improves the cleaning effect when a spray ball is used. The cleaning jet is directed onto the probe via the vessel wall. As a result, the probe is also cleaned in places the spray ball jet would normally not reach. You only require one spray ball for this probe arrangement.

Mounting in the center of the vessel

If the probe is mounted in the center of the vessel, the use of a second spray ball may be necessary. These balls should then be mounted to the left and right of the probe.


Mounting at an angle



- For mechanical reasons, the probe should be installed as vertically as possible.
- If the probe is installed at an angle, the length of the probe must be reduced depending on the angle of installation.

 - α 5 °: LN_{max.} 4 m (13.1 ft) α 10 °: LN_{max.} 2 m (6.6 ft) α 30 °: LN_{max.} 1 m (3.3 ft)

Non-metal vessels




- 1 Non-metal vessel
- 2 Metal sheet or metal flange

To ensure good measurement results when mounting on non-metal vessels, at the process connection mount a metal sheet with a diameter of at least 200 mm (8 in) at a right angle to the probe.

Plastic and glass vessels: Mounting the probe on the outside wall

In the case of plastic and glass vessels, the probe can also be mounted on the outside wall under certain conditions.



- 1 Plastic or glass vessel
- 2 Metal plate with screw-in sleeve
- 3 No space between vessel wall and probe!

Requirements

- Dielectric constant of the medium: $\varepsilon_r > 7$.
- Non-conductive vessel wall.
- Maximum wall thickness (a):
 - Plastic: < 15 mm (0.6 in)
 - Glass: < 10 mm (0.4 in)
- No metal reinforcements on the vessel.

Note the following when mounting the device:

- Mount the probe directly on the vessel wall without any space between the wall and probe.
- To prevent any influence on the measurement, fit a plastic half pipe with a diameter of at least 200 mm (8 in), or a similar protective unit, on the probe.
- For vessel diameters less than 300 mm (12 in):
- On the opposite side of the vessel, fit a grounding plate that is conductively connected to the process connection and covers around half of the vessel's circumference.
- For vessel diameters of 300 mm (12 in) and higher: At the process connection, fit a metal plate with a diameter of at least 200 mm (8 in) at a right angle to the probe (see above).

Adjustment when mounting on the vessel exterior

When the probe is mounted on the outside of the vessel wall, the speed of propagation of the signal is reduced. There are two ways to compensate for this.

Compensation via gas phase compensation factor

The effect of the dielectric wall is comparable to the effect of a dielectric gas phase and can therefore be corrected in the same way. The correction factor is calculated as the quotient of the actual probe length LN and the probe length measured when the vessel is empty.



The device determines the position of the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.

1. Parameter Expert \rightarrow Sensor \rightarrow Gas phase compensation \rightarrow GPC mode

└ Select the **Const. GPC factor** option.

2. Parameter Expert → Sensor → Gas phase compensation → Const. GPC factor
 Quotient: Enter "(actual probe length)/(measured probe length)".

Compensation via the calibration parameters


If it is necessary to actually compensate for a gas phase, the gas phase compensation function is not available for the correction of external mounting. The calibration parameters (**Empty calibration** and **Full calibration**) must be adjusted in this case. Furthermore, a value that is greater than the actual probe length must be entered in the **Present probe length** parameter. In all three cases, the correction factor is the quotient of the probe length measured when the vessel is empty and the actual probe LN.

The device searches for the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.

- **1.** Parameter Setup \rightarrow Empty calibration
 - └→ Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- 2. Parameter Setup \rightarrow Full calibration
 - └ Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- Parameter Setup → Advanced setup → Probe settings → Probe length correction
 → Confirm probe length
 - ← Select the **Manual input** option.
- Parameter Setup → Advanced setup → Probe settings → Probe length correction
 → Present probe length
 - └ Enter the measured probe length.

Vessel with thermal insulation

If process temperatures are high, the device must be included in normal vessel insulation (1) in order to prevent the electronics heating up as a result of thermal radiation or convection. The insulation may not go beyond the points labeled "MAX" in the drawings.



- ☑ 5 Hygienic process connections
- 1 Vessel insulation
- 2 Compact device
- *3 Compact device, detachable*
- 4 Sensor, remote

6.2 Mounting the measuring device

6.2.1 Tool list



- To shorten rope probes: use a saw or bolt cutters
- To shorten rod or coax probes: use a saw
- For flanges and other process connections: use an appropriate mounting tool

6.2.2 Mounting the "Sensor, remote" version

This section only applies for devices with the version "Probe design" = "Sensor, remote" (feature 600, version MB or MC).

The following is included in the delivery with the version "Probe design" = "Remote":

- The probe with process connection and connecting cable (3 m (9 ft) or 6 m (18 ft))
- The electronics housing
- The mounting bracket for mounting the electronics housing on a wall or post

The connecting cable is connected to the probe upon delivery.

The probe with the connection cable and the electronics are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.


ACAUTION

Mechanical stress can damage the plug of the connection cable or cause it to become loose.

- Mount the probe and the electronics housing securely before connecting the connecting cable.
- ► Lay the connecting cable in such a way that it is not exposed to mechanical stress. Minimum bending radius: 50 mm (2 in).
- ► Torque of the union nut at the plug on the electronics side: 6 Nm
- ► Torque of the union nut at the plug on the sensor side: 20 Nm

In the event of strong vibrations, a locking compound, e.g. Loctite 243, can also be used on the plug on the electronics side.


Mounting the electronics housing



- 6 Mounting the electronics housing with the mounting bracket. Unit of measurement mm (in)
- A Wall mounting
- B Post mounting


Connecting the connecting cable





6.2.3 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned:



- **1.** Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- **3.** Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).


6.2.4 Turning the display

Opening the cover




- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the electronics compartment cover and check the cover seal; replace it if necessary.

Turning the display module



- **1.** Pull out the display module with a gentle rotational movement.
- 2. Turn the display module to the desired position: Max. $8 \times 45^{\circ}$ in each direction.
- **3.** Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

Closing the cover of the electronics compartment



1. Screw down the cover of the electronics compartment.

2. Turn the securing clamp 90° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the electronics compartment cover with 2.5 Nm.

6.3 Post-installation check

□ Is the device undamaged (visual inspection)?

- □ Does the device comply with the measuring point specifications?
- Process temperature
- Process pressure
- Ambient temperature range
- Measuring range

□ Are the measuring point identification and labeling correct (visual inspection)?

 $\hfill\square$ Is the device adequately protected against precipitation and direct sunlight?

 $\Box Is$ the device adequately protected against impact?

□Are all mounting and safety screws securely tightened?

 \Box Is the device properly secured?

7 Electrical connection

7.1 Connecting requirements

7.1.1 Terminal assignment

Terminal assignment, 2-wire: 4 to 20 mA HART





Image: Terminal assignment, 2-wire: 4 to 20 mA HART

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection 4 to 20 mA, HART passive: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection 4 to 20 mA, HART passive: terminals 1 and 2, with integrated overvoltage protection
- 3 Terminal for cable shield


Block diagram, 2-wire: 4 to 20 mA HART



🗷 8 Block diagram, 2-wire: 4 to 20 mA HART


- 1 Active barrier for power supply (e.g. RN221N); observe terminal voltage
- 2 Resistor for HART communication ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device

Terminal assignment, 2-wire: 4 to 20 mA HART, switch output




- 9 Terminal assignment, 2-wire: 4 to 20 mA HART, switch output
- *A* Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection 4 to 20 mA, HART passive: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection, switch output (open collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection, switch output (open collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection 4 to 20 mA, HART passive: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable shield

Block diagram, 2-wire: 4 to 20 mA HART, switch output



- 🖻 10 Block diagram, 2-wire: 4 to 20 mA HART, switch output
- 1 Active barrier for power supply (e.g. RN221N); observe terminal voltage
- 2 Resistor for HART communication ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Switch output (open collector)


Terminal assignment, 2-wire: 4 to 20 mA HART, 4 to 20 mA




■ 11 Terminal assignment, 2-wire: 4 to 20 mA HART, 4 to 20 mA

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection current output 1, 4 to 20 mA HART passive: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection current output 2, 4 to 20 mA: terminals 3 and 4, without integrated overvoltage protection
- 3 Connection current output 2, 4 to 20 mA: terminals 3 and 4, with integrated overvoltage protection
- 4 Connection current output 1, 4 to 20 mA HART passive: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable shield


Block diagram, 2-wire: 4 to 20 mAHART, 4 to 20 mA





- 1 Active barrier for power supply (e.g. RN221N), current output 1; observe terminal voltage
- 2 Resistor for HART communication ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 *Cable screen; observe cable specification*
- 6 Measuring device
- 7 Analog display unit; observe maximum load
- 8 Active barrier for power supply (e.g. RN221N), current output 2; observe terminal voltage


Terminal assignment, 4-wire: 4 to 20 mA HART (10.4 to 48 V_{DC})



 \blacksquare 13 Terminal assignment, 4-wire: 4 to 20 mA HART (10.4 to 48 V_{DC})

- 1 Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- 3 Terminal for cable shield


Block diagram, 4-wire: 4 to 20 mA HART (10.4 to 48 V_{DC})



■ 14 Block diagram, 4-wire: 4 to 20 mA HART (10.4 to 48 V_{DC})

- 1 Evaluation unit, e.g. PLC
- 2 Resistor for HART communication ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Supply voltage; observe terminal voltage, observe cable specification

Terminal assignment, 4-wire: 4 to 20 mA HART (90 to 253 V_{AC})



■ 15 Terminal assignment, 4-wire: 4 to 20 mAHART (90 to 253 V_{AC})

- 1 Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- 3 Terminal for cable shield


ACAUTION

To ensure electrical safety:

- ► Do not disconnect the protective ground connection.
- Disconnect the device from the supply voltage before disconnecting the protective ground.
 - Connect protective ground to the inner ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the outer ground terminal.
- In order to ensure electromagnetic compatibility (EMC): do **not** ground the device exclusively via the protective ground conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.

An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).


Block diagram, 4-wire: 4 to 20 mA HART (90 to 253 V_{AC})




- 16 Block diagram, 4-wire: 4 to 20 mA HART (90 to 253 V_{AC})
- 1 Evaluation unit, e.g. PLC
- 2 Resistor for HART communication ($\geq 250 \Omega$); observe maximum load
- 3 Connection for Commubox FXA195 or FieldXpert SFX350/SFX370 (via VIATOR Bluetooth modem)
- 4 Analog display unit; observe maximum load
- 5 Cable screen; observe cable specification
- 6 Measuring device
- 7 Supply voltage; observe terminal voltage, observe cable specification

Connection examples for the switch output

For HART devices, the switch output is available as an option.



■ 17 Connection of a relay



E 18 Connection to a digital input

- 1 Pull-up resistor
- 2 Digital input

For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or pull-up resistor) of < 1000Ω .

7.1.2 Cable specification


- Devices without integrated overvoltage protection Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
 Devices with integrated overvoltage protection
- Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_{U} \ge 60 \degree C$ (140 $\degree F$): use cable for temperature $T_{U} + 20 \text{ K}$.

HART

- A normal device cable suffices if only the analog signal is used.
- A shielded cable is recommended if using the HART protocol. Observe grounding concept of the plant.
- For 4-wire devices: Standard device cable is sufficient for the power line.


7.1.3 Device plug

In the case of the device versions with a plug, the housing does not need to be opened to connect the signal cable.



■ 19 Pin assignment of M12 plug

- 1 Signal +
- Not assigned Signal -2
- 3
- 4 Ground



■ 20 Pin assignment of 7/8" plug

- 1 Signal -
- 2 3 4
- Signal + Not assigned Shielding

7.1.4 Supply voltage

2-wire, 4-20mA HART, passive

2-wire; 4-20mA HART 1)

"Approval" ²⁾	Terminal voltage U at device	Maximum load R, depending on the supply voltage ${\rm U}_0$ of the power supply unit
 Non-hazardous Ex nA Ex ic CSA GP 	11.5 to 35 V ^{3) 4)}	R [Ω] 500
Ex ia / IS	11.5 to 30 V ⁴⁾	0 10 20 30 35 U ₀ [V] 11.5 22.5 A0035511
 Ex d / XP Ex ic[ia] Ex tD / DIP 	13.5 to 30 V ^{4) 5)}	$ \begin{array}{c} R \left[\Omega\right] \\ 500 \\ 0 \\ 0 \\ 10 \\ 10 \\ 13.5 \\ 24.5 \\ \end{array} U_{0} \left[V\right] \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0 \\ 0$

1) Feature 020 in the product structure: option A

2) Feature 010 in the product structure

3) At ambient temperatures $T_a \le -30$ °C, a terminal voltage U ≥ 14 V is required to start the device with the minimum failure current (3.6 mA). At ambient temperatures $T_a \ge 60$ °C, a terminal voltage U ≥ 12 V is required to start the device with the minimum failure current (3.6 mA). The start-up current can be configured. If the device is operated with a fixed current I ≥ 4.5 mA (HART Multidrop mode), a voltage U ≥ 11.5 V in the entire ambient temperature range suffices.

4) If the Bluetooth module is used, the minimum supply voltage increases by 2 V.

5) At ambient temperatures $T_a \le -30$ °C, a terminal voltage U ≥ 16 V is required to start the device with the minimum failure current (3.6 mA).

2-wire; 4-20 mA HART, switch output ¹⁾

"Approval" ²⁾	Terminal voltage U at device	Maximum load R, depending on the supply voltage $U_{0}\ of$ the power supply unit		
 Non-hazardous Ex nA Ex nA(ia) Ex ic Ex ic[ia] Ex d[ia] / XP Ex ta / DIP CSA GP 	13.5 to 35 V ^{3) 4)}	R [Ω] 500		
 Ex ia / IS Ex ia + Ex d[ia] / IS + XP 	13.5 to 30 V ^{3) 4)}	0 10 10 13.5 24.5 35 L0 V0 V1 L0 L0 L0 L0 L0 L0 L0 L0 L0 L0		

1) Feature 020 in the product structure: option B

2) Feature 010 in the product structure

3) At ambient temperatures $T_a \le -30$ °C, a terminal voltage U ≥ 16 V is required to start the device with the minimum failure current (3.6 mA).

4) If the Bluetooth module is used, the minimum supply voltage increases by 2 V.

"Approval" ²⁾	Terminal voltage U at device	Maximum load R, depending on the supply voltage \mathbf{U}_0 of the power supply unit
All	Channel 1:	
	13.5 to 30 V ^{3) 4) 5)}	$R [\Omega]$ 500 500 0 10 20 30 U0 [V] 13.5 24.5
	Channel 2:	
	12 to 30 V	R [Ω] 500 0 10 12 20 30 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

2-wire; 4-20mA HART, 4-20mA 1)

1) Feature 020 in the product structure: option C

2) Feature 010 in the product structure

3) At ambient temperatures $T_a \le -30$ °C, a terminal voltage U ≥ 16 V is required to start the device with the minimum failure current (3.6 mA).

4) At ambient temperatures T_a \leq -40 °C, the maximum terminal voltage must be limited to U \leq 28 V.

5) If the Bluetooth module is used, the minimum supply voltage increases by 2 V.

Integrated polarity reversal protection	Yes
Permitted residual ripple with f = 0 to 100 Hz	$U_{SS} < 1 \text{ V}$
Permitted residual ripple with f = 100 to 10000 Hz	U _{SS} < 10 mV

4-wire, 4-20mA HART, active

"Power supply; output" ¹⁾	Terminal voltage U	$Maximum \ load \ R_{max}$
K: 4-wire 90-253VAC; 4-20mA HART	90 to 253 V_{AC} (50 to 60 Hz), overvoltage category II	500 Ω
L: 4-wire 10.4-48VDC; 4-20mA HART	10.4 to 48 V _{DC}	

1) Feature 020 in the product structure

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse $8/20 \mu$ s), an overvoltage protection module has to be installed.

Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data			
Resistance per channel	2 × 0.5 Ω max.		
Threshold DC voltage	400 to 700 V		
Threshold impulse voltage	< 800 V		
Capacitance at 1 MHz	< 1.5 pF		
Nominal arrest impulse voltage (8/20 µs)	10 kA		

External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.

For detailed information please refer to the following documents:

- HAW562: TI01012K
- HAW569: TI01013K

7.2 Connecting the device

WARNING


Explosion Hazard!

- Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ► Use specified cable glands only.
- Check to ensure that the power supply matches the information on the nameplate.
- ► Switch off the power supply before connecting the device.
- Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:


- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.

7.2.1 Opening cover




- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90° counterclockwise.
- 2. Unscrew the connection compartment cover and check the cover seal; replace it if necessary.

7.2.2 Connecting



☑ 21 Engineering unit: mm (in)


- **1.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- **3.** Strip the cable ends 10 mm (0.4 in). In the case of stranded cables, also fit wire end ferrules.
- 4. Firmly tighten the cable glands.
- 5. Connect the cable according to the terminal assignment.



6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

The electrical connection of device versions without an integrated overvoltage protection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.




🖻 22 Engineering unit: mm (in)

To remove the cable from the terminal again:

 Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes

2. Simultaneously pull the cable end out of the terminal.

7.2.4 Closing the cover of the connection compartment



1. Screw down the cover of the connection compartment.

2. Turn the securing clamp 90° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the connection compartment cover with 2.5 Nm.

7.3 Post-connection check

□ Is the device or cable undamaged (visual inspection)?

 \Box Do the cables used comply with the requirements?

□ Do the mounted cables have adequate strain relief?

□Are all the cable glands installed, firmly tightened and leak-tight?

Does the supply voltage match the specifications on the nameplate?

□ Is the terminal assignment correct?

□If necessary, has a protective ground connection been established?

□ If supply voltage is present, is the device ready for operation and do values appear on the display module?

 \Box Are all the housing covers installed and tightened?


□ Is the securing clamp firmly tightened?

8 Operation methods

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control			
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"			
Display	A0036312 4-line display	A0036313 4-line display			
elements		white background lighting; switches to red in event of device error			
	Format for displaying measured variables and status variables can be individually config				
		ed ambient temperature for the display: –20 to +70 °C (–4 to +158 °F) dability of the display may be impaired at temperatures outside the temperature			
Operating elements	local operation with 3 push buttons (⊕, □, E) external operation via touch control; 3 optical keys: ⊕, □, E				
	Operating elements also accessible in various hazardous areas				
Additional functionality	r · · · · · · · · · · · · · · · · · · ·				
	Data comparison function The device configuration saved in the display module can be compared to the cu- configuration.				
Data transfer function The transmitter configuration can be transmitted to another device using the displa					




Operation with remote display and operating module FHX50 8.1.2


■ 23 FHX50 operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover Display and operating module SD02, push buttons; cover must be removed 1
- 2

8.1.3 Operation via Bluetooth[®] wireless technology

Requirements






- *1 Electronics housing of the device*
- 2 Bluetooth module

This operation option is only available for devices with Bluetooth module. There are the following options:

- The device has been ordered with a Bluetooth module: Feature 610 "Accessory Mounted", option NF "Bluetooth"
- The Bluetooth module has been ordered as an accessory (ordering number: 71377355) and has been mounted. See Special Documentation SD02252F.

Operation via SmartBlue (app)




■ 25 Operation via SmartBlue (app)

- 1 Transmitter power supply unit
- 2 Smartphone / tablet with SmartBlue (app)
- 3 Transmitter with Bluetooth module

8.1.4 Remote operation


Via HART protocol



■ 26 Options for remote operation via HART protocol

- 1 PLC (programmable logic controller)
- 2 Transmitter power supply unit, e.g., RN42
- 3 Connection for Commubox FXA195 and AMS TrexTM device communicator
- 4 AMS TrexTM device communicator
- 5 Computer with operating tool (e.g., DeviceCare/FieldCare, AMS Device View, SIMATIC PDM)
- 6 Commubox FXA195 (USB)
- 7 Field Xpert SMT70
- 8 Bluetooth modem with connecting cable (e.g., VIATOR)
- 9 Transmitter

Via service interface (CDI)



- 1 Computer with FieldCare/DeviceCare operating tool
- 2 Commubox FXA291
- 3 Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)

8.2 Structure and function of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the local display
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	Once values have been set for these parameters, the measurement should generally be completely configured.
	Advanced setup	 Contains additional submenus and parameters: For more customized configuration of the measurement (adaptation to special measuring conditions). For converting the measured value (scaling, linearization). For scaling the output signal.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat ⁴⁾	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert ⁵⁾ Contains all the parameters of the device (including those that are already contained in one of the other menus). This menu is	System	Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication.
organized according to the function blocks of the device.	Sensor	Contains all parameters needed to configure the measurement.
The parameters of the Expert menu are described in: GP01000F (HART)	Output	 Contains all parameters needed to configure the analog current output. Contains all parameters needed to configure the switch output (PFS).

Menu	Submenu / parameter	Meaning	
	Communication	Contains all parameters needed to configure the digital communication interface.	
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.	

1) If you are operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup \rightarrow Advanced setup \rightarrow Display"

2)

Only if operating via an FDT/DTM system Only available if operating via the local display 3)

4)

Only available if operating via DeviceCare or FieldCare When you call up the "Expert" menu, you are always asked for an access code. If a customer-specific access 5) code has not been defined, "0000" must be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access (Verweisziel existiert nicht, aber @y.link.required='true').

Access authorization	to	parameters
----------------------	----	------------

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	
Maintenance	V	V	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.

The user role with which the user is currently logged on is indicated by the Access **H** status display parameter (for display operation) or Access status tooling parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the numeric code in the **Confirm access code** parameter to confirm it.

Define access code via operating tool (e.g. FieldCare)

- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - └ Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. If the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after 60 s.

- If write access is activated via an access code, it can only be deactivated again via this access code $\rightarrow \square 51$.
 - In the "Description of Device Parameters" documents, each write-protected parameter is identified with the 🖻-symbol.

Disabling write protection via access code

If the \square symbol appears in front of a parameter on the local display, the parameter is write-protected by a device-specific access code and its value cannot currently be changed via the local display $\rightarrow \square$ 50.

The locking of the write access via local operation can be disabled by entering the devicespecific access code.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

→ The @-symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

Navigate to: Setup → Advanced setup → Administration → Define access code

2. Enter **0000**.

- 3. Repeat **0000** in the **Confirm access code** parameter to confirm.
 - └ The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - └ The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch


Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):


- Via local display
- Via service interface (CDI)
- Via HART protocol



- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.



- **4.** Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - └ If hardware write protection is enabled, the Hardware locked option is displayed in the Locking status parameter. In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter. On the local display, the 🖻 symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.

6. Reverse the removal procedure to reassemble the transmitter.

Enabling and disabling the keypad lock

Access to the entire operating menu via local operation can be locked via the keypad lock. When access is locked, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via a context menu.

Switching on the keypad lock

SD03 display module only

- ¹ The keypad lock is switched on automatically:
- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

- Press E for at least 2 seconds.
- └► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- 2. In the context menu select the **Keylock off** option.
 - └ The keypad lock is switched off.


Bluetooth[®] wireless technology

Signal transmission via Bluetooth[®] wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*[®] wireless technology without the SmartBlue app
- Only one point-to-point connection between **one** sensor and **one** smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display



27 Display format on the display and operating module

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (bar graph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Parameter display (here: parameter with picklist)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Picklist; \blacksquare marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

Display symbols for the submenus

Symbol	Meaning
A0018367	 Display/operat. Is displayed: In the main menu next to the "Display/operat." selection In the header on the left in the "Display/operat." menu
% A0018364	Setup Is displayed: • In the main menu next to the "Setup" selection • In the header on the left in the "Setup" menu
*	Expert Is displayed: In the main menu next to the "Expert" selection In the header on the left in the "Expert" menu
Č	 Diagnostics Is displayed: In the main menu next to the "Diagnostics" selection In the header on the left in the "Diagnostics" menu

Status signals

Symbol	Meaning
F 40032902	"Failure" A device error has occurred. The measured value is no longer valid.
C	"Function check" The device is in the service mode (e.g. during a simulation).
S A0032904	 "Out of specification" The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range)
M 40032905	"Maintenance required" Maintenance is required. The measured value is still valid.

Display symbols for locking status


Symbol	Meaning
A0013148	Read-only parameter The parameter shown is only for display purposes and cannot be edited.
6	Device locked
A0013150	In front of a parameter name: The device is locked via software and/or hardware.In the header of the measured value screen: The device is locked via hardware.

Measured value symbols

Symbol	Meaning
Measured values	
 ~~ 	Level
A0032892	
⊢►	Distance
A0032893	
(+	Current output
A0032908	Measured current
	measureu current
A0032894	
\bigcirc	Terminal voltage
A0032895	
	Electronics or sensor temperature
A0032896	
Measuring channels	
(1)	Measuring channel 1
A0032897	
(2)	Measuring channel 2
A0032898	
Status of the measured	value
A0018361	"Alarm" status The measurement is interrupted. The output assumes the defined alarm condition. A diagnostic message is generated.
A0018360	"Warning" status The device continues to measure. A diagnostic message is generated.

8.3.2 **Operating elements**

Key	Meaning
	Minus key In a menu, submenu
A0018330	Moves the selection bar upwards in a picklist. In the text and numeric editor
	In the input mask, moves the selection bar to the left (backwards).
	Plus key
+	<i>In a menu, submenu</i> Moves the selection bar downwards in a picklist.
AU018329	<i>In the text and numeric editor</i> In the input mask, moves the selection bar to the right (forwards).
	Enter key
	For measured value displayPressing the key briefly opens the operating menu.Pressing the key for 2 s opens the context menu.
E 40018328	 In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter.
	 In the text and numeric editor Pressing the key briefly: Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
	Escape key combination (press keys simultaneously)
-++ A0032909	 In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the measured value display ("home position").
	<i>In the text and numeric editor</i> Closes the text or numeric editor without applying changes.
-+E	Minus/Enter key combination (press and hold down the keys simultaneously) Reduces the contrast (brighter setting).
	Plus/Enter key combination (press and hold down the keys simultaneously)
A0032911	Increases the contrast (darker setting).



8.3.3 Entering numbers and text

Input mask

The following input and operating symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
	Selection of numbers from 0 to 9.
9	
A0013996	Inserts decimal separator at the cursor position.
A0016619	
	Inserts minus sign at the cursor position.
	Confirms selection.
A0013985	
	Moves the input position one position to the left.
A0016621	
	Exits the input without applying the changes.
A0013986	
	Clears all entered characters.
A0014040	

Text editor

Symbol	Meaning
(ABC_) (XYZ) A0013997	Selection of letters from A to Z

(Aa1@)	Toggle • Between upper-case and lower-case letters • For entering numbers • For entering special characters
	Confirms selection.
	Switches to the selection of the correction tools.
X 	Exits the input without applying the changes.
	Clears all entered characters.

Text correction under ₩C+→

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
-	Moves the input position one position to the left.
A0018326	
×	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:


- Setup
- Conf. backup disp.
- Envelope curve
- Keylock on

Calling up and closing the context menu

The user is in the operational display.

1. Press E for 2 s.

└ The context menu opens.



2. Press - + + simultaneously.

└ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press \pm to navigate to the desired menu.

3. Press 🗉 to confirm the selection.

└ The selected menu opens.

8.3.5 Envelope curve display on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be shown on the display and operating module:



9 Device integration via the HART protocol

9.1 Overview of the Device Description files (DD)

HART

Manufacturer ID	0x11
Device type	0x1122
HART specification	7.0
DD files	For information and files see: www.endress.com www.fieldcommgroup.org

9.2 HART device variables and measuring values

On delivery the following measuring values are assigned to the HART device varaibles:

Device variables for level measurements

Device variable	Measuring value
Primary variable (PV)	Level linearized
Secondary variable (SV)	Unfiltered distance
Tertiary variable (TV)	Absolute echo amplitude
Quaternary variable (QV)	Relative echo amplitude

The allocation of the measuring values to the device variables can be changed in the following submenu:

Expert \rightarrow Communication \rightarrow Output

10 Commissioning via SmartBlue (App)

10.1 Prerequisites

System requirements

The SmartBlue app is available for download for use with a smartphone or tablet.

- iOS devices: iPhone 5S or higher from iOS11; iPad 5th generation or higher from iOS11; iPod Touch 6th generation or higher from iOS11
- Devices with Android: from Android 6.0 and Bluetooth® 4.0

Initial password

The serial number of the device serves as the initial password when the connection is established for the first time.

Note the following if the Bluetooth module is removed from one device and installed in another device: the password that is changed by the user is only saved in the Bluetooth module and not in the device itself.

10.2 SmartBlue App

1. Scan the QR code or enter "SmartBlue" in the search field of the App Store.



🖻 28 🛛 Download link

2. Start SmartBlue.

- 3. Select device from livelist displayed.
- 4. Enter the login data:
 - └→ User name: admin Password: serial number of the device
- 5. Tap the icons for more information.

After logging in for the first time, change the password!

10.3 Envelope curve display in SmartBlue

Envelope curves can be displayed and recorded in SmartBlue.

In addition to the envelope curve, the following values are displayed:


- D = Distance
- L = Level
- A = Absolute amplitude
- With screenshots, the displayed section (zoom function) is saved
- With video sequences, the whole area without zoom function is saved all the time

A003918



🖻 29 Envelope curve display (sample) in SmartBlue for Android

- 1 Record video
- 2 Create screenshot
- 3 Display mapping menu
- Start/stop video recording
- 4 5 Move time on time axis



🛃 30 Envelope curve display (sample) in SmartBlue for iOS

- Record video 1
- 2 Create screenshot
- 3 Display mapping menu
- 4 Start/stop video recording
- 5 Move time on time axis

11 Commissioning using the Commissioning Wizard

A Wizard is provided in FieldCare and DeviceCare $^{1)}$ that guides the user through the initial commissioning process.

1. Connect the device with FieldCare or DeviceCare.

2. Open the device in FieldCare or DeviceCare.

└ The dashboard (homepage) of the device is displayed:

Wizard			
Commissioning SIL/WHG confirmation	•		
Instrument health status			
ОК			
Process variables - Device tag: Level	flex		
Process variables - Device tag: Level	flex 2000,000	Level linearized	Thickness upper layer
-	_		
-	2000,000 	Level linearized 50,604 %	Thickness upper layer
Interface linearized	2000,000 1600,000 	50,604 🐝	
-	2000,000 1600,000 		

- 1 "Commissioning" button calls up the wizard
- 3. Click "Commissioning" to launch the Wizard.
- 4. Enter the appropriate value in each parameter or select the appropriate option. These values are written directly to the device.
- 5. Click "Next" to go to the next page.
- 6. Once all the pages have been completed, click "Finish" to close the Wizard.
- If you cancel the Wizard before all the necessary parameters have been entered, the device may be in an undefined state. In such situations, it is advisable to reset the device to the factory default settings.

A0025866

¹⁾ DeviceCare is available for download at www.software-products.endress.com. To download the software, it is necessary to register in the Endress +Hauser software portal.


12 Commissioning via operating menu

12.1 Function check


Before commissioning your measuring point, ensure that the post-installation and postconnection checks have been performed:

12.2 Setting the operating language

Factory setting: English or ordered local language



■ 31 Taking the example of the local display



12.3 **Configuring level measurement**

🛃 32 Configuration parameters for level measurement in liquids

- LN Probe length
- Reference point of measurement R
- D Distance
- L Level
- Empty calibration (= zero point) Ε F
- Full calibration (= span)
- If the ε_r value is lower than 7 in the case of rope probes, measurement is not possible in the area of the tensioning weight. The empty calibration *E* should not exceed *LN* -250 mm (LN - 10 in) in these cases.
- 1. Setup \rightarrow Device tag
 - ← Enter device tag.
- 2. Navigate to: Setup \rightarrow Distance unit
 - └ Select the distance unit.
- 3. Navigate to: Setup \rightarrow Tank type
 - ← Select tank type.
- 4. For **Tank type** parameter = Bypass / pipe:
 - Navigate to: Setup \rightarrow Tube diameter

└ Specify the diameter of the bypass or stilling well.

- 5. Navigate to: Setup \rightarrow Medium group
 - ← Specify the medium group: (Water based (DC >= 4) or Others)
- 6. Navigate to: Setup \rightarrow Empty calibration
 - ← Specify the empty distance E (distance from reference point R to 0% mark).
- 7. Navigate to: Setup \rightarrow Full calibration
 - ← Specify the full distance F (distance from the 0% mark to the 100% mark).
- 8. Navigate to: Setup \rightarrow Level
 - └ Displays the measured level L.
- 9. Navigate to: Setup \rightarrow Distance
 - └ Displays the distance D between the reference point R and the level L.
- 10. Navigate to: Setup \rightarrow Signal quality
 - └ Displays the signal quality of the analyzed level echo.

11. Operation via local display:

Navigate to: Setup \rightarrow Mapping \rightarrow Confirm distance

← Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).

12. Operation via operating tool:

Navigate to: Setup \rightarrow Confirm distance

← Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).

12.4 Recording the reference envelope curve

After the measurement has been configured, it is recommended to record the current envelope curve as a reference envelope curve. This can then be used later for diagnostic purposes. The **Save reference curve** parameter is used to record the envelope curve.

Path in the menu

Expert \rightarrow Diagnostics \rightarrow Envelope diagnostics \rightarrow Save reference curve

Meaning of the options

- No
 - No action
- Yes

The current envelope curve is saved as a reference curve.

This submenu is only visible for the "Service" user role in devices supplied with software version 01.00.zz or 01.01.zz.

The reference envelope curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. The "Load Reference Curve" function in FieldCare is used for this.

• = 👬 • 🕒 💕	
· · · · · · · · · · · · ·	

🕑 33 "Load Reference Curve" function

12.5 Configuring the local display

12.5.1 Factory setting of local display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

12.5.2 Adjusting the local display

The local display can be adjusted in the following submenu: Setup \rightarrow Advanced setup \rightarrow Display

12.6 Configuring the current outputs

12.6.1 Factor setting of current outputs for level measurements

Current output	Assigned measured value	4mA value	20mA value
1	Level linearized	0% or the corresponding linearized value	100% or the corresponding linearized value
2 ¹⁾	Relative echo amplitude	0 mV	2 000 mV

1) For devices with two current outputs

12.6.2 Adjusting the current outputs

The current outputs can be adjusted in the following submenus:

Basic settings

Setup \rightarrow Advanced setup \rightarrow Current output 1 to 2

Advanced settings

Expert \rightarrow Output 1 to 2 \rightarrow Current output 1 to 2 See "Description of Device Parameters" GP01000F

12.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and the options available.

Path in the menu

Setup \rightarrow Advanced setup \rightarrow Configuration backup display \rightarrow Configuration management

Meaning of the options

- Cancel
 - No action is executed and the user exits the parameter.
- Execute backup

A backup copy of the current device configuration is saved from the HistoROM (integrated in the device) to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration of the device is duplicated to another device using the display module. The following parameters, which characterize the individual measuring point are **not** transferred:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type
- Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of the comparison is displayed in the **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

If an existing backup copy is restored on a device other than the original device using the **Restore** option, in some cases individual device functions may not be available. In some cases it is also not possible to restore the original state by resetting to the "as-delivered" state.

The **Duplicate** option should always be used to copy the configuration to another device.

12.8 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in two ways:

- Locking via parameters (software locking)
- Locking via write protection switch (hardware locking)

13 Diagnostics and troubleshooting

13.1 General troubleshooting

13.1.1 General errors

Error	Possible cause	Solution
Device does not respond.	Supply voltage does not match the value indicated on the nameplate.	Connect the correct voltage.
	The polarity of the supply voltage is wrong.	Correct the polarity.
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ± and E simultaneously. Decrease contrast by pressing = and E simultaneously.
	The plug of the display cable is not connected correctly.	Connect the plug correctly.
	Display is defective.	Replace display.
"Communication error" is	Electromagnetic interference	Check grounding of the device.
indicated on the display when starting the device or connecting the display.	Broken display cable or display plug.	Replace display.
Duplication of parameters via display from one device to another not working. Only the "Save" and "Cancel" options are available.	Display with backup is not properly detected if a data backup was not carried out on the new device previously.	Connect display (with backup) and restart device.
Output current <3.6 mA	Signal cable connection incorrect.	Check connection.
	Electronics module is defective.	Replace electronics.
HART communication does not function.	Communication resistor missing or incorrectly installed.	Install the communication resistor (250 Ω) correctly.
	Commubox is connected incorrectly.	Connect Commubox correctly.
	Commubox is not set to "HART".	Set Commubox selector switch to "HART".
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.
Device measures incorrectly.	Parameter configuration error	Check and correct the parameter configuration.
No communication with device via SmartBlue	No Bluetooth connection	Enable Bluetooth function on smartphone or tablet
	The device is already connected with another smartphone/ tablet	Disconnect the device from the other smartphone/tablet
	Bluetooth module not connected	Connect Bluetooth module (see SD02252F).
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of Bluetooth module) and change it

Error	Possible cause	Solution
Device cannot be operated via SmartBlue	Incorrect password entered	Enter the correct password, paying attention to lower/upper case
Device cannot be operated via SmartBlue	Password forgotten	Contact Endress+Hauser Service (www.addresses.endress.com)

Error	Possible cause	Solution
Device is not visible in the	No Bluetooth	Enable Bluetooth® function on smartphone or tablet
live list	connection	Bluetooth [®] function of sensor disabled, perform recovery sequence
Device is not visible in the live list	The device is already connected with another smartphone/ tablet	Only one point-to-point connection is established between a sensor and a smartphone or tablet
Device is visible in the live list but cannot be accessed via	Android end device	Is the location function enabled for the app, was it approved the first time?
SmartBlue		GPS or positioning function must be activated for certain Android versions in conjunction with Bluetooth®
		Activate GPS - close the app fully and restart - enable the positioning function for the app
Device is visible in the live list but cannot be accessed via SmartBlue	Apple end device	Log in as standard Enter user name "admin" Enter initial password (ID of the Bluetooth module) paying attention to lower/upper case
Login via SmartBlue not possible	Device is being put into operation for the first time	Enter initial password (ID of the Bluetooth module) and change; paying attention to lower/upper case
Device cannot be operated via SmartBlue	Incorrect password entered	Enter correct password
Device cannot be operated via SmartBlue	Password forgotten	Contact the Endress+Hauser Service department (www.addresses.endress.com)

13.1.2 Error - SmartBlue operation

13.1.3 Parametrization errors


Problem	Possible cause	Remedy
Measured value is incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	 Check the Empty calibration parameter (→ ¹ 121) and correct if necessary. Check the Full calibration parameter (→ ¹ 121) and correct if necessary. Check the linearization and correct if necessary (Linearization submenu (→ ¹ 135)).
	If measured distance (Setup → Distance) does not match the real distance: An interference echo is present.	Carry out mapping (Confirm distance parameter (→ 🗎 124)).
No change of measured value on filling/emptying	An interference echo is present.	Carry out mapping (Confirm distance parameter ($\rightarrow \cong 124$)).
	Buildup at the probe.	Clean the probe.
	Error in the echo tracking.	Deactivate echo tracking (Expert → Sensor → Echo tracking → Evaluation mode = History off).
Echo lost diagnostic message appears after the supply voltage is switched on.	Echo threshold too high.	Check the Medium group parameter $(\rightarrow \bowtie 120)$. If necessary, select a more detailed setting with the Medium property parameter $(\rightarrow \bowtie 129)$.
	Level echo suppressed.	Delete the map and record it again if necessary (Record map parameter $(\rightarrow \cong 125)$).
Device displays a level when the tank is empty.	Incorrect probe length	Perform probe length correction (Confirm probe length parameter $(\rightarrow \cong 150)$).
	Interference echo	Carry out mapping over the entire probe length when the tank is empty (Confirm distance parameter ($\rightarrow \cong 124$)).
Wrong slope of the level over the entire measuring range	Wrong tank type selected.	Select the correct Tank type parameter $(\rightarrow \cong 119)$.

Parametrization errors for level measurements

13.2 Diagnostic information on local display

13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


F 40032902	"Failure (F)" option A device error has occurred. The measured value is no longer valid.
C	"Function check (C)" option The device is in the service mode (e.g. during a simulation).
S A0032904	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range)
M 40032905	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs adopt the defined alarm condition. A diagnostic message is generated.
	"Warning" status The device continues to measure. A diagnostic message is generated.

Diagnostic event and event text

The fault can be identified by means of the diagnostic event. The event text helps you by providing information about the fault. In addition, the associated status symbol is displayed in front of the diagnostic event.




If two or more diagnostic events occur simultaneously, only the diagnostic message with the highest priority is shown. Additional queued diagnostic messages can be shown in the **Diagnostic list** submenu.

Past diagnostic messages that are no longer pending are shown as follows:

- On the local display:
 - In the **Event logbook** submenu
- In FieldCare:
 - Via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu	
+	Plus key Opens the message about the remedial measures.
Ē	Enter key Opens the operating menu.



13.2.2 Calling up remedial measures

34 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures

The user is in the diagnostic message.

1. Press 🛨 (① symbol).

- ← The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \mathbb{E} .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - └ The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** or in **Previous diagnostics**.

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press + + simultaneously.
 - └ The message about the remedial measures closes.


13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)

A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.



A tool tip with remedial measures for the diagnostic event appears.

1. Menu / Variable Diagnostics PD Actual diagnostics:

Select the "Create documentation" function.


B: Via the "Create documentation" function


2.	Documentation	
	Documentation	Status
	Documentation	Initialized
	🖨 🗹 Title Pages	Initialized
	Cover Page	Initialized
	Signatures Page	Initialized
	Device parameters	Initialized
	Linearization table	Initialized
	Envelope curve	Initialized
	Extended HistoROM	Initialized
	🗹 Diagram data	Initialized
	Data overview	Initialized
	Compare Datasets	Not available

Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function







Select the "Load Eventlist" function.

└ The list of events, including remedy information, is shown in the "Data overview" window.

13.4 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

 $\text{Diagnostics} \rightarrow \text{Diagnostic list}$

Calling up and closing the remedial measures

1. Press E.

└ The message for the remedial measures for the selected diagnostic event opens.

2. Press \Box + \pm simultaneously.

← The message about the remedial measures closes.

13.5 List of diagnostic events

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of s	ensor			
003	Broken probe detected	 Check map Check sensor 	F	Alarm
046	Build-up detected	Clean sensor	F	Alarm
104	HF cable	and check sealing 1. Dry HF cable connection 2. Change HF cable	F	Alarm
105	HF cable	 Tighten HF cable connection Check sensor Change HF cable 	F	Alarm
106	Sensor	 Check sensor Check HF cable Contact service 	F	Alarm
Diagnostic of e	lectronic	1	1	
242	Software incompatible	 Check software Flash or change main electronics module 	F	Alarm
252	Modules incompatible	 Check if correct electronic modul is plugged Replace electronic module 	F	Alarm
261	Electronic modules	 Restart device Check electronic modules Change I/O Modul or main electronics 	F	Alarm
262	Module connection	 Check module connections Change electronic modules 	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	 Restart device Change main electronic module 	F	Alarm
272	Main electronic failure	 Restart device Contact service 	F	Alarm
273	Main electronic failure	 Emergency operation via display Change main electronics 	F	Alarm
275	I/O module defective	Change I/O module	F	Alarm
276	I/O module faulty	1. Restart device	F	Alarm
276	I/O module faulty	2. Change I/O module	F	Alarm
282	Data storage	 Restart device Contact service 	F	Alarm
283	Memory content	1. Transfer data or reset device 2. Contact service	F	Alarm
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	М	Warning
Diagnostic of c	onfiguration			
410	Data transfer	 Check connection Retry data transfer 	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
412	Processing download	Download active, please wait	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
431	Trim 1 to 2	Carry out trim	С	Warning
435	Linearization	Check linearization table	F	Alarm
437	Configuration incompatible	 Restart device Contact service 	F	Alarm
438	Dataset	 Check data set file Check device configuration Up- and download new configuration 	М	Warning
441	Current output 1 to 2	 Check process Check current output settings 	S	Warning
484	Failure mode simulation	Deactivate simulation	С	Alarm
485	Simulation measured value	Deactivate simulation	С	Warning
491	Current output 1 to 2 simulation	Deactivate simulation	С	Warning
494	Switch output simulation	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation	Deactivate simulation	С	Warning
585	Simulation distance	Deactivate simulation	С	Warning
Diagnostic of p	rocess	1	I	1
801	Energy too low	Increase supply voltage	S	Warning
803	Current loop	1. Check wiring 2. Change I/O module	F	Alarm
825	Operating temperature	1. Check ambient temperature	S	Warning
825	Operating temperature	2. Check process temperature	F	Alarm
921	Change of reference	 Check reference configuration Check pressure Check sensor 	S	Warning
936	EMC interference	Check installation on EMC	F	Alarm
941	Echo lost	Check parameter 'DC value'	F	Alarm ¹⁾
942	In safety distance	 Check level Check safety distance Reset self holding 	S	Alarm ¹⁾
943	In blocking distance	Reduced accuracy Check level	S	Warning
944	Level range	Reduced accuracy Level at process connection	S	Warning
950	Advanced diagnostic 1 to 2 occured	Maintain your diagnostic event	М	Warning ¹⁾

1) Diagnostic behavior can be changed.

13.6 Event logbook

13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu $^{2)}$.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ①: Event has occurred
 - 🕒: Event has ended
- Information event

€: Event has occurred

Calling up and closing the remedial measures

- 1. Press E
 - └ The message for the remedial measures for the selected diagnostic event opens.

2. Press \Box + \pm simultaneously.

└ The message about the remedial measures closes.

13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

Navigation path

 $\texttt{Diagnostics} \rightarrow \texttt{Event logbook} \rightarrow \texttt{Filter options}$

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

13.6.3 Overview of information events

Info number	Info name
I1000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed

²⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Info number	Info name
I1092	Embedded HistoROM deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1184	Display connected
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1554	Safety sequence started
I1555	Safety sequence confirmed
I1556	Safety mode off

Date	Firmware	Modifications	Documentation (FMP53, HART)			
	version		Operating Instructions	Description of Device Parameters	Technical Information	
07.2010	01.00.zz	Original software	BA01002F/00/EN/05.10	GP01000F/00/EN/05.10	TI01002F/00/EN/05.10	
01.2011	01.01.zz	 SIL integrated Improvements and bugfixes Additional languages 	 BA01002F/00/EN/10.10 BA01002F/00/EN/13.11 BA01002F/00/EN/14.12 	GP01000F/00/EN/10.10GP01000F/00/EN/13.11	 TI01002F/00/EN/10.10 TI01002F/00/EN/13.11 TI01002F/00/EN/14.12 TI01002F/00/EN/15.12 	
02.2014	01.02.zz	 Support of SD03 Additional languages HistoROM functionality enhanced "Advanced Diagnostics" function block integrated Improvements and bugfixes 	 BA01002F/00/EN/15.13 BA01002F/00/EN/16.14 	GP01000F/00/EN/14.13GP01000F/00/EN/15.14	 TI01002F/00/EN/16.13 TI01002F/00/EN/17.14 	
04.2016	01.03.zz	 Update to HART 7 All 17 languages available in the device Improvements and bugfixes 	 BA01002F/00/EN/17.16 BA01002F/00/EN/ 18.16¹⁾ BA01002F/00/EN/ 20.18²⁾ 	GP01000F/00/EN/16.16	 TI01002F/00/EN/18.16 TI01002F/00/EN/20.16¹⁾ TI01002F/00/EN/22.18²⁾ 	

13.7 Firmware history

1) Contains information on the Heartbeat wizards available in the current DTM version for DeviceCare and FieldCare.

2) Contains information on the Bluetooth interface.

The firmware version can explicitly be ordered via the product structure. In this way it is possible to ensure compatibility of the firmware version with an existing or planned system integration.

14 Maintenance

No special maintenance work is required.

14.1 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not corrode the surface of the housing and the seals.

14.2 General cleaning instructions

Dirt or buildup may form on the probe depending on the application. A thin, even layer has little impact on the measurement. Thick layers can dampen the signal and reduce the measuring range. Very uneven deposit formation or caking (e.g. due to crystallization) can result in incorrect measurements. In such cases, use a non-contact measuring principle, or regularly inspect the probe for contamination.

Cleaning with sodium hydroxide solution (e.g. in CIP procedures): if the coupling is wetted, larger measurement errors can occur than under reference operating conditions. Wetting can cause temporary incorrect measurements.

14.3 Cleaning the probe

14.3.1 Cleaning the probe in the vessel

If a suitable mounting position has been selected, the probe can be cleaned by a spray ball in the vessel $\rightarrow \cong 22$.

14.3.2 Cleaning the probe outside the vessel

The probe can be removed for better cleaning.

The following tool is required for cleaning:

- Vise with fiber jaws (surface protection for the polished rod probe)
- Hook wrench with lug ϕ 54 mm (2.1 in)
- Open-ended wrench AF27/AF32 with torque setting up to 20 Nm

Caution!

- Before starting work, make sure that the power supply for the device is switched off.
- When unscrewing the slotted nut (1), make sure to provide counter-support at the process connection ring (5) with an open-ended wrench. Otherwise the adapter (3) will become detached from the flange.

Disassembling the electronics housing

- Unscrew the slotted nut (1) with the hook wrench.
- Remove the loosened housing (2), together with the housing holder, from the adapter (3) of the process connection towards the top. The housing holder remains connected to the housing. Put the housing to one side. In the case of the "Remote sensor" version, only the cable adapter must be removed.
- Replace the O-ring (7) if necessary.
 Order number: see Device Viewer →
 ⁽²⁾ 92

Disassembling the rod probe

- Unscrew the adapter (3) from the process connection (the flange in the example): at the wrench flats unscrew the adapter with an open-ended wrench (AF27) and remove from the vessel together with the probe rod (max. 4 m).
- Clamp the probe rod (4) at the wrench flats or use fitting pliers.


Caution: Protect the surface of the polished probe rod! It must not be damaged by scratches or denting.

- Unscrew the adapter (3) from the probe rod (approx. 12 turns in the counter-clockwise direction) and remove it (plug-in connection). The probe rod is screwed into the insulating bush with 4.5 Nm.
- The O-ring seals (6) of the probe rod and adapter are now freely accessible and can be exchanged if necessary. The probe rod and adapter can be autoclaved.

Order numbers of O-rings: see Device Viewer $\rightarrow \ \bigsep{3.1}{10} 92$

Probe mounting

- Assembly is the reverse of the disassembly sequence:Screw the adapter (3) onto the probe rod (4) with 4.5 Nm.
- Screw the adapter together with the probe rod into the vessel process connection and tighten with 20 Nm.
- Fit the housing (2) along with the housing holder onto the adapter and screw together with the slotted nut (1); torque 20 Nm.



15 Repair

15.1 General information

15.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs can be carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

15.1.2 Repair of Ex-certified devices

WARNING

Incorrect repair can compromise electrical safety! Explosion Hazard!

- Repairs to Ex-certified devices must be carried out by Endress+Hauser Service or by specialist personnel according to national regulations.
- Relevant standards and national regulations on hazardous areas, safety instructions and certificates must be observed.
- ► Use only original Endress+Hauser spare parts.
- Please note the device designation on the nameplate. Only identical parts may be used as replacements.
- Carry out repairs according to the instructions.
- Only the Endress+Hauser service team is permitted to modify a certified device and convert it to another certified version.

15.1.3 Replacing electronics modules

When electronics modules have been replaced the device does not need to be recalibrated as the parameters are saved in the HistoROM inside the housing. It may be necessary when replacing the main electronics to record a new interference echo suppression.

15.1.4 Replacing a device

Once a complete device has been replaced, the parameters can be transferred back into the device using one of the following methods:


- Using the display module Prerequisite: The configuration of the old device was saved previously to the display module.
- Via FieldCare

Prerequisite: The configuration of the old device was saved previously to the computer using FieldCare.

You can continue measuring without performing a new calibration. Only interference echo suppression may need to be carried out once again.

15.2 Spare parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- In the connection compartment cover of the device there is a spare part nameplate which contains the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL to the W@M Device Viewer (www.endress.com/deviceviewer): All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



35 Example for spare part nameplate in the connection compartment cover

All Measuring device serial number:

- Located on the device and spare part nameplate.
- Can be read out via the "Serial number" parameter in the "Device information" submenu.

15.3 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the web page for information:

http://www.endress.com/support/return-material

- Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

15.4 Disposal

X


If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

16 Accessories


16.1 Device-specific accessories

16.1.1 Weather protection cover

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.




🗟 36 Height. Unit of measurement mm (in)



■ 37 Dimensions. Unit of measurement mm (in)


Material 316L

Order number for accessories: 71162242



16.1.2 Mounting bracket for electronics housing

16.1.3 Weld-in adapter




16.1.4 Protective cover

Accessories	Description	
Protective cover		A0013589
	For closing off the probe when the electronics module is removed Order number: 71041379 For details, see Operating Instructions BA362F.	10015505

16.1.5 Calibration kit

Accessories	Description
Calibration kit	The calibration kit is used for regular testing of the accuracy and reproducibility of the Levelflex FMP53 level measurement device. Order number: 71041382 For details, see Operating Instructions SD01003F.

16.1.6 Remote display FHX50



Technical data

- Material:
 - Plastic PBT
 - 316L/1.4404
 - Aluminum
- \bullet Degree of protection: IP68 / NEMA 6P and IP66 / NEMA 4x
- Suitable for display modules:
 - SD02 (push buttons)
 - SD03 (touch control)

- Connecting cable:
 - Cable supplied with device up to 30 m (98 ft)
 - Standard cable supplied by customer up to 60 m (196 ft)
- Ambient temperature: -40 to 80 °C (-40 to 176 °F)
- Ambient temperature (option): -50 to 80 °C (-58 to 176 °F)³⁾

Ordering information

• If the remote display is to be used, the device version "Prepared for display FHX50" must be ordered.

For the FHX50, the option "Prepared for display FHX50" must be selected under "Measuring device version".

If a measuring device has not been ordered with the version "Prepared for display FHX50" and is to be retrofitted with an FHX50, the version "Not prepared for display FHX50" must be ordered for the FHX50 under "Measuring device version". In this case, a retrofit kit for the device is supplied with the FHX50. The kit can be used to prepare the device so that the FHX50 can be used.

Use of the FHX50 may be restricted for transmitters with an approval. A device may only be retrofitted with the FHX50 if the option "Prepared for FHX50" is listed in the associated Safety Instructions (XA) under Basic specifications, "Display, operation".

Also pay attention to the Safety Instructions (XA) of the FHX50.

Retrofitting is not possible on transmitters with:

- An approval for use in areas with flammable dust (dust ignition-proof approval)
- Type of protection Ex nA


For details, see the "Special Documentation" SD01007F

16.1.7 **Overvoltage** protection

The surge arrester for loop-powered devices can be ordered together with the device via the "Accessory mounted" section of the product order structure.

The surge arrester can be used for loop-powered devices.

- I-channel devices OVP10
- 2-channel devices OVP20



Technical data

- Resistance per channel: $2 \times 0.5 \Omega_{max}$
- Threshold DC voltage: 400 to 700 V
- Threshold surge voltage: < 800 V</p>

³⁾ This range applies if the option JN "Transmitter ambient temperature" -50 °C (-58 °F) was selected in feature 580 "Test, Certificate". If the temperature is permanently below -40 °C (-40 °F), higher failure rates can be expected.

- Capacitance at 1 MHz: < 1.5 pF
- Nominal leakage current (8/20 µs): 10 kA
- Suitable for conductor cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)


If retrofitting:

- Order number for 1-channel devices (OVP10): 71128617
- Order number for 2-channel devices (OVP20): 71128619
- The use of the OVP module may be restricted depending on the transmitter approval. A device may only be retrofitted with the OVP module if the option *NA* (overvoltage protection) is listed under *Optional specifications* in the Safety Instructions (XA) associated with the device.
- In order to keep the necessary safety distances when using the surge arrester module, the housing cover also needs to be replaced when the device is retrofitted.
 Depending on the housing type, the suitable cover can be ordered using the following order number:
 - Housing GT18: 71185516
 - Housing GT19: 71185518
 - Housing GT20: 71185517

For details, see the "Special Documentation" SD01090F

16.1.8 Bluetooth module BT10 for HART devices

The Bluetooth module BT10 can be ordered together with the device via the "Accessory mounted" section of the product order structure.



Technical data

- Quick and easy setup with the SmartBlue app
- No additional tools or adapters needed
- Signal curve via SmartBlue (app)
- Encrypted single point-to-point data transmission (tested by Fraunhofer Institute) and password-protected communication via Bluetooth[®] wireless technology
- Range under reference conditions:
 > 10 m (33 ft)
- When the Bluetooth module is used, the minimum supply voltage of the device increases by up to 3 V.

If retrofitting:

- Order number: 71377355
- The use of the Bluetooth module may be restricted depending on the transmitter approval. A device may only be retrofitted with the Bluetooth module if the option NF (Bluetooth module) is listed under Optional specifications in the Safety Instructions (XA) associated with the device.

For details, see the "Special Documentation" SD02252F

16.2 **Communication-specific accessories**

Commubox FXA195 HART

For intrinsically safe HART communication with FieldCare via the USB interface

For details, see "Technical Information" TI00404F

Commubox FXA291

Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop Order number: 51516983



For details, see "Technical Information" TI00405C

HART Loop Converter HMX50

Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values

Order number: 71063562

For details, see "Technical Information" TI00429F and Operating Instructions BA00371F

WirelessHART adapter SWA70

- Is used for the wireless connection of field devices
- The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks

For details, see Operating Instructions BA00061S

Fieldgate FXA42

Fieldgates enable communication between connected 4 to 20 mA, Modbus RS485 and Modbus TCP devices and SupplyCare Hosting or SupplyCare Enterprise. The signals are transmitted either via Ethernet TCP/IP, WLAN or mobile communications (UMTS). Advanced automation capabilities are available, such as an integrated Web-PLC, OpenVPN and other functions.

For details, see "Technical Information" TI01297S and Operating Instructions **I** BA01778S.

SupplyCare Enterprise SCE30B

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

This Web-based software is installed on a local server and can also be visualized and operated with mobile terminals such as a smartphone or tablet.

For details, see Technical Information TI01228S and Operating Instructions BA00055S

SupplyCare Hosting SCH30

Inventory management software that displays the level, volume, mass, temperature, pressure, density or other parameters of tanks. The parameters are recorded and

transmitted by means of gateways like Fieldgate FXA42, Connect Sensor FXA30B or other gateway types.

SupplyCare Hosting is offered as a hosting service (Software as a Service, SaaS). In the Endress+Hauser portal, the user is provided with the data over the Internet.

For details, see Technical Information TI01229S and Operating Instructions BA00050S

Field Xpert SFX350

Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area**.

For details, see Operating Instructions BA01202S

Field Xpert SFX370

Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area** and the **Ex area**.



For details, see Operating Instructions BA01202S

16.3 Service-specific accessories

DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices

Technical Information TI01134S

FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



Technical Information TI00028S

16.4 System components

Memograph M graphic data manager

The Memograph M graphic data manager provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.

Technical Information TI00133R and Operating Instructions BA00247R

RN221N

Active barrier with power supply for safe separation of 4 to 20 mA standard signal circuits. Offers bidirectional HART transmission.

Technical Information TI00073R and Operating Instructions BA00202R

RN221

Supply unit for powering two 2-wire measuring devices solely in the non-Ex area. Bidirectional communication is possible via the HART communication jacks.

Technical Information TI00081R and Brief Operating Instructions KA00110R

17 Operating menu

17.1 Overview of the operating menu (SmartBlue)


Navigation SmartBlue

✓ Setup	→ 🗎 119
Device tag	→ 🗎 119
Distance unit	→ 🗎 119
Tank type	→ 🗎 119
Tube diameter	→ 🗎 120
Medium group	→ 🗎 120
Empty calibration	→ 🗎 121
Full calibration	→ 🗎 121
Level	→ 🗎 122
Distance	→ 🗎 122
Signal quality	→ 🗎 123
Confirm distance	→ 🗎 124
Present mapping	→ 🗎 125
Mapping end point	→ 🗎 125
Record map	→ 🗎 125
► Advanced setup	→ 🗎 127
Locking status	→ 🗎 127
Access status tooling	→ 🗎 127
Enter access code	→ 🗎 128
► Level	→ 🗎 129
Medium type	→ 🗎 129

	Medium property	→	129
	Process property	$]$ \rightarrow	130
	Advanced process conditions	\rightarrow	131
	Level unit] →	132
	Blocking distance	→	132
	Level correction		133
► Linearization		· •	135
	Linearization type		137
	Unit after linearization]	138
]	
	Free text	→ }	🗎 139
	Level linearized	→	140
	Maximum value	→	₿ 140
	Diameter	}	140
	Intermediate height	→	141
	Table mode	}	141
	Table number] →	142
	Level	\rightarrow	142
	Level	}	143
	Customer value)	143
	Activate table	\rightarrow	143
► Probe settings		\rightarrow	🗎 149
	Probe grounded	→	149
	Present probe length	- 	149
	Confirm probe length		₿ 150
	Commun probe lengui	-	

► Safety settings		→ 🗎 144
	Output echo lost	→ 🗎 144
	Value echo lost	→ 🗎 144
	Ramp at echo lost	→ 🗎 145
	Blocking distance	→ 🗎 132
► Current output 1	L to 2	→ 🗎 152
	Assign current output	→ 🖺 152
	Current span	→ 🗎 153
	Fixed current	→ 🗎 153
	Damping output	→ 🗎 154
	Failure mode	→ 🗎 154
	Failure current	→ 🗎 155
	Output current 1 to 2	→ 🗎 155
► Switch output		→ 🗎 156
	Switch output function	→ 🗎 156
	Assign status	→ 🗎 157
	Assign limit	→ 🗎 157
	Assign diagnostic behavior	→ 🗎 157
	Switch-on value	→ 🗎 158
	Switch-on delay	→ 🗎 159
	Switch-off value	→ 🗎 159
	Switch-off delay	→ 🗎 160
	Failure mode	→ 🗎 160

			Switch status]	→ 🗎 160
			Invert output signal]	→ 🖺 160
얺 Diagnostics]				→ 🖺 174
	Actual diagnostics]			→ 🗎 174
	Timestamp]			→ 🗎 174
	Previous diagnostic	S]			→ 🖺 174
	Timestamp]			→ 🗎 175
	Operating time from	n restart]			→ 🗎 175
	Operating time]			→ 🗎 168
	► Diagnostic list]			→ 🗎 176
		Diagnostics 1 to 5]		→ 🗎 176
		Timestamp 1 to 5]		→ 🖺 176
	► Measured value	S]			→ 🖺 181
		Distance]		→ 🗎 122
		Level linearized]		→ 🗎 140
		Output current 1 to	2]		→ 🗎 155
		Measured current 1]		→ 🗎 182
		Terminal voltage 1]		→ 🗎 182
	► Device informat	ion]			→ 🗎 178
		Device tag]		→ 🗎 178
		Serial number]		→ 🗎 178
		Firmware version]		→ 🗎 178
		Device name]		→ 🗎 178
		Order code]		→ 🗎 179
		Extended order cod	e 1 to 3]		→ 🗎 179



17.2 Overview of the operating menu (display module)

	Navigation	Operating	menu		
Language					
🖌 Setup					→ 🗎 119
Device tag					→ 🗎 119
Distance unit					→ 🖺 119
Tank type		_			→ 🗎 119
Tube diameter		_			→ 🗎 120
Medium group)	_			→ 🗎 120
Empty calibrat	ion	_			→ 🗎 121
Full calibration	1	_			→ 🗎 121
Level		_			→ 🗎 122
Distance		_			→ 🗎 122
Signal quality		_			→ 🗎 123
► Mapping					→ 🗎 126
	Confirm distance]		→ 🗎 126
	Mapping end poin	nt]		→ 🖺 126
	Record map]		→ 🖺 126
	Distance]		→ 🗎 126
► Advanced s	etup				→ 🗎 127
	Locking status	_]		→ 🗎 127
	Access status disp	lay]		→ 🗎 128
	Enter access code]		→ 🗎 128
	► Level]		→ 🗎 129
		Medium type		7	→ 🗎 129

Medium property	→ ● 129
Process property	→ 🗎 130
Advanced process conditions	→ 🗎 131
Level unit	→ 🗎 132
Blocking distance	→ 🗎 132
Level correction	→ 🗎 133
► Linearization	→ 🗎 135
Linearization type	→ 🗎 137
Unit after linearization	→ 🗎 138
Free text	→ 🗎 139
Maximum value	→ 🗎 140
Diameter	→ 🗎 140
Intermediate height	→ 🗎 141
Table mode	→ 🖺 141
► Edit table	
Level	
Customer value	
Activate table	→ 🗎 143
► Safety settings	→ 🗎 144
Output echo lost	→ 🗎 144
Value echo lost	→ 🗎 144
Ramp at echo lost	→ 🗎 145
Blocking distance	→ 🗎 132
► SIL/WHG confirmation	→ 🗎 147

► Deactivate SIL/	WHG			\rightarrow	148
	Reset write protecti	on]	\rightarrow	₿ 148
	Code incorrect]	\rightarrow	₿ 148
► Probe settings]		\rightarrow	149
	Probe grounded]	\rightarrow	🖺 149
	► Probe length con	rrection]	\rightarrow	🗎 151
		Confirm probe lengt	th	\rightarrow	🖺 151
		Present probe lengt	h	\rightarrow	🗎 151
► Current output	1 to 2]		\rightarrow	🗎 152
	Assign current outp	put		\rightarrow	152
	Current span			\rightarrow	🖺 153
	Fixed current			\rightarrow	🖺 153
	Damping output			\rightarrow	154
	Failure mode]	\rightarrow	🖺 154
	Failure current]	\rightarrow	155
	Output current 1 to	2]		155
► Switch output]			₿ 156
- Sunten Sutput			1		
	Switch output funct	10n		÷	🖺 156
	Assign status			\rightarrow	🖺 157
	Assign limit]	\rightarrow	🗎 157
	Assign diagnostic b	ehavior]	\rightarrow	🖺 157
	Switch-on value]	\rightarrow	🗎 158
	Switch-on delay]	\rightarrow	🖺 159
	Switch-off value]	\rightarrow	🗎 159
	Switch-off delay]	\rightarrow	160

	Failure mode	→ 🗎 160
	Switch status	→ 🖺 160
	Invert output signal	→ 🖺 160
► Display		→ 🗎 162
	Language	→ 🖺 162
	Format display	→ 🗎 162
	Value 1 to 4 display	→ 🗎 164
	Decimal places 1 to 4	→ 🗎 164
	Display interval	→ 🖺 164
	Display damping	→ 🖺 165
	Header	→ 🖺 165
	Header text	→ 🗎 165
	Separator	→ 🖺 166
	Number format	→ 🖺 166
	Decimal places menu	→ 🖺 166
	Backlight	→ 🖺 166
	Contrast display	→ 🗎 167
► Configuration ba	ackup display	→ 🗎 168
	Operating time	→ 🗎 168
	Last backup	→ 🗎 168

		Configuration man	agement	→ 🗎 168
		Comparison result		→ 🗎 169
	► Administration]	→ 🗎 171
		► Define access co	de	→ 🗎 173
			Define access code	→ 🗎 173
			Confirm access code	→ 🗎 173
		Device reset		→ 🗎 171
父 Diagnostics				→ 🗎 174
Actual diagnostics]		→ 🗎 174
Previous diagnostic	CS]		→ 🗎 174
Operating time fro	m restart]		→ 🗎 175
Operating time]		→ 🗎 168
► Diagnostic list				→ 🗎 176
	Diagnostics 1 to 5]	→ 🗎 176
► Event logbook				→ 🗎 177
	Filter options]	
	► Event list]	→ 🗎 177
► Device information	tion			→ 🗎 178
	Device tag]	→ 🗎 178
	Serial number]	→ 🗎 178
	Firmware version]	→ 🗎 178
	Device name]	→ 🗎 178
	Order code]	→ 🗎 179
	Extended order cod	le 1 to 3]	→ 🗎 179
	Device revision]	→ 🗎 179

	Device ID		→ 🖺 179
	Device type		→ 🗎 180
	Manufacturer ID		→ 🖺 180
► Measured value	25		→ 🗎 181
	Distance		→ 🗎 122
	Level linearized		→ 🗎 140
	Output current 1 to 2		→ 🗎 155
	Measured current 1		→ 🗎 182
	Terminal voltage 1		→ 🖺 182
► Data logging			→ 🖺 183
	Assign channel 1 to 4		→ 🗎 183
	Logging interval		→ 🗎 184
	Clear logging data		→ 🗎 184
	► Display channel 1 to 4		→ 🗎 185
► Simulation			→ 🗎 187
	Assign measurement variable		→ 🗎 188
	Process variable value		→ 🖺 188
	Current output 1 to 2 simulation]	→ 🖺 188
	Value current output 1 to 2		→ 🖺 189
	Switch output simulation		→ 🖺 189
	Switch status		→ 🗎 189
	Device alarm simulation		→ 🗎 190
► Device check			→ 🗎 191
	Start device check		→ 🗎 191
	Result device check		→ 🗎 191

Level signal	→ 🖺 192
Launch signal	→ 🗎 192

17.3 Overview of the operating menu (operating tool)

Navigation 🐵 Operating menu

🗲 Setup		→ 🖺 119
Device tag		→ 🖺 119
Distance unit		→ 🗎 119
Tank type		→ 🗎 119
Tube diameter		→ 🖺 120
Medium group		→ 🖺 120
Empty calibration		→ 🖺 121
Full calibration		→ 🖺 121
Level		→ 🗎 122
Distance		→ 🗎 122
Signal quality		→ 🖺 123
Confirm distance		→ 🖺 124
Present mapping		→ 🖺 125
Mapping end point		→ 🖺 125
Record map		→ 🗎 125
► Advanced setup		→ 🗎 127
Locking status		→ 🗎 127
Access status tooling	J	→ 🗎 127
Enter access code		→ 🖺 128
► Level		→ 🖺 129
[Medium type	→ 🖺 129
[Medium property	→ 🖺 129
[Process property	→ 🗎 130


	Advanced process conditions) → 🗎 131
	Level unit	→ 🗎 132
	Blocking distance	→ 🗎 132
	Level correction	→ 🗎 133
► Linearization	1	→ 🗎 135
	Linearization type	→ 🗎 137
	Unit after linearization	→ 🗎 138
	Free text	→ 🗎 139
	Level linearized	→ 🗎 140
	Maximum value	→ 🗎 140
	Diameter	→ 🗎 140
	Intermediate height	→ 🗎 141
	Table mode	→ 🗎 141
	Table number	→ 🗎 142
	Level	→ 🗎 142
	Level	→ 🗎 143
	Customer value	→ 🗎 143
	Activate table	→ 🗎 143
► Safety setting		→ 🗎 143
► Salety Settin		1
	Output echo lost	→ 🗎 144
	Value echo lost	→ 🖺 144
	Ramp at echo lost	→ 🗎 145
	Blocking distance	→ 🗎 132
► SIL/WHG cor	nfirmation	→ 🗎 147

Þ	• Deactivate SIL/W	ЛНG		→ 🗎 148
		Reset write protection		→ 🗎 148
		Code incorrect		→ 🗎 148
Þ	Probe settings			→ 🖺 149
		Probe grounded		→ 🖺 149
		Present probe length		→ 🖺 149
		Confirm probe length		→ 🗎 150
►	• Current output 1	to 2		→ 🗎 152
		Assign current output]	→ 🗎 152
		Current span		→ 🗎 153
		Fixed current		→ 🗎 153
		Damping output		→ 🗎 154
		Failure mode		→ 🗎 154
		Failure current		→ 🗎 155
		Output current 1 to 2		→ 🗎 155
Þ	• Switch output			→ 🗎 156
		Switch output function		→ 🗎 156
		Assign status		→ 🗎 157
		Assign limit		→ 🗎 157
		Assign diagnostic behavior		→ 🗎 157
		Switch-on value]	→ 🗎 158
		Switch-on delay		→ 🗎 159
		Switch-off value		→ 🗎 159
		Switch-off delay		→ 🗎 160
		Failure mode		→ 🗎 160


	Switch status	→ 🖺 160
	Invert output signal	→ 🗎 160
► Display		→ 🖺 162
	Language	→ 🗎 162
	Format display	→ 🗎 162
	Value 1 to 4 display	→ 🗎 164
	Decimal places 1 to 4	→ 🗎 164
	Display interval	→ 🗎 164
	Display damping	→ 🗎 165
	Header	→ 🗎 165
	Header text	→ 🖺 165
	Separator	→ 🖺 166
	Number format	→ 🖺 166
	Decimal places menu	→ 🗎 166
	Backlight	→ 🖺 166
	Contrast display	→ 🗎 167
► Configuration b	ackup display	→ 🖺 168
	Operating time	→ 🖺 168
	Last backup	→ 🖺 168
		→ 🗎 168
	Configuration management	× 🚍 100

		Backup state	→ 🗎 169
		Comparison result	→ 🗎 169
	► Administration	1	→ 🗎 171
		Define access code	
		Device reset	→ 🗎 171
Ċ Diagnostics			→ 🗎 174
Actual diagn	ostics		→ 🗎 174
Timestamp			→ 🗎 174
Previous diag	gnostics		→ 🗎 174
Timestamp			→ 🗎 175
Operating tir	ne from restart		→ 🗎 175
Operating tir	ne		→ 🗎 168
► Diagnosti	c list		→ 🗎 176
	Diagnostics 1 to 5		→ 🗎 176
	Timestamp 1 to 5		→ 🗎 176
► Device inf	ormation		→ 🗎 178
	Device tag		→ ⇒ 178
	Serial number		→ ⇒ 178
	Firmware version		→ ⇒ 178
	Device name		→ ⇒ 178
	Order code		→ 🗎 179
	Extended order co	de 1 to 3	→ 🗎 179
	Device revision		→ 🗎 179
	Device ID		→ ⇒ 179

		Device type	÷	🗎 180
		Manufacturer ID	\rightarrow	🖺 180
	► Measured values	S	\rightarrow	₿ 181
		Distance	\rightarrow	122
		Level linearized	\rightarrow	🖺 140
		Output current 1 to 2	\rightarrow	🖺 155
		Measured current 1	\rightarrow	182
		Terminal voltage 1	\rightarrow	182
	► Data logging		\rightarrow	183
		Assign channel 1 to 4	\rightarrow	183
		Logging interval	\rightarrow	184
		Clear logging data	\rightarrow	184
	► Simulation		\rightarrow	187
		Assign measurement variable	\rightarrow	188
		Process variable value	\rightarrow	188
		Current output 1 to 2 simulation	\rightarrow	188
		Value current output 1 to 2	\rightarrow	189
		Switch output simulation	\rightarrow	189
		Switch status	\rightarrow	189
		Device alarm simulation	\rightarrow	₿ 190
	► Device check		\rightarrow	191
		Start device check	\rightarrow	🗎 191
		Result device check	\rightarrow	191
		Last check time		191



Device tag



Navigation	
Description	Enter a unique name for the measuring point to identify the device quickly within the plant.
User entry	Character string comprising numbers, letters and special characters (32)

Distance unit			Â	
Navigation	Image: Betup → Dist	ance unit		
Description	Used for the basic o	Used for the basic calibration (Empty / Full).		
Selection	SI units • mm • m	US units ■ ft ■ in		

Tank type		Â
Navigation		
Prerequisite	Medium type (→ 🗎 129) = Liquid	
Description	Select tank type.	
Selection	 Metallic Bypass / pipe Non metallic Mounted outside Coaxial 	

Factory settingDepending on the probe

A

Additional information

- Depending on the probe some of the options mentioned above may not be available or there may be additional options.
- For coax probes and probes with metallic center washer **Tank type** parameter corresponds to the type of probe and cannot be changed.

Tube diameter		
Navigation	$□$ $□$ Setup \rightarrow Tube diameter	
Prerequisite	Tank type (→ 🖺 119) = Bypass / pipe	
Description	Specify diameter of bypass or stilling well.	
User entry	0 to 9.999 m	

Medium	aroup
mculum	group

Navigation	Setup → Medium group
Prerequisite	Medium type (→ 🗎 129) = Liquid
Description	Select medium group.
Selection	 Others Water based (DC >= 4)
Additional information	This parameter roughly specifies the dielectric constant (DC) of the medium. For a more

detailed definition of the DC use the **Medium property** parameter ($\rightarrow \equiv 129$).

The **Medium group** parameter presets the **Medium property** parameter ($\rightarrow \implies 129$) as follows:

Medium group	Medium property (→ 🗎 129)
Others	Unknown
Water based (DC >= 4)	DC 4 7

The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.

The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.

A

Empty calibration

Navigation	8 8	Setup \rightarrow Empty calibr.
------------	-----	-----------------------------------


Description Distance between process connection and minimum level (0%).

Depending on the probe

User entry Depending on the probe

Factory setting


Additional information



☑ 39 Empty calibration (E) for level measurements in liquids

Full calibration		ß
Navigation	■ \square Setup \rightarrow Full calibr.	
Description	Distance between minimum level (0%) and maximum level (100%).	
User entry	Depending on the probe	
Factory setting	Depending on the probe	

Additional information




Full calibration (F) for level measurements in liquids 🛃 40

Level Navigation \blacksquare □ Setup → Level Description Displays measured level $L_{\mbox{\scriptsize L}}$ (before linearization). Additional information ų S • L 0% Ħ A0013194 🛃 41 Level in case of liquid measurements The unit is defined in the **Level unit** parameter ($\rightarrow \square$ 132).

Distance	
Distance	
Navigation	
Description	Displays the measured distance $D_{\rm L}$ between the reference point (lower edge of the flange or threaded connection) and the level.

F

Additional information



42 Distance for liquid measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 119$).

Signal quality

Navigation	Image: Setup → Signal quality
Description	Displays the signal quality of the evaluated echo.
Additional information	 Meaning of the display options Strong The evaluated echo exceeds the threshold by at least 10 mV. Medium The evaluated echo exceeds the threshold by at least 5 mV. Weak The evaluated echo exceeds the threshold by less than 5 mV. No signal The device does not find a usable echo.
	The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo ⁴⁾ or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets. In case of a lost echo (Signal quality = No signal) the device generates the following error message:
	■ F941, for Output echo lost (→ 🗎 144) = Alarm

- F941, for **Output echo lost** ($\rightarrow \square$ **144**) = Alarm.
- S941, if another option has been selected in **Output echo lost** ($\rightarrow \square 144$).

⁴⁾ Of these two echos the one with the lower quality is indicated.

Confirm distance	
Navigation	Setup \rightarrow Confirm distance
Description	Specify, whether the measured distance matches the real distance.
	Depending on the selection the device automatically sets the range of mapping.
Selection	 Manual map Distance ok Distance unknown Distance too small * Distance too big * Tank empty Delete map
Additional information	 Meaning of the options Manual map To be selected if the range of mapping is to be defined manually in the Mapping end
	 point parameter (→ ● 125). In this case it is not necessary to confirm the distance. Distance ok To be selected if the measured distance matches the actual distance. The device performs a mapping. Distance unknown
	To be selected if the actual distance is unknown. A mapping can not be performed in t case.
	 Distance too small To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the Confirm distance parameter. The distant is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be start by selecting Distance ok. Distance too big ⁵
	 To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the Confirm distance parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be start by selecting Distance ok. Tank empty
	 Tank empty To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range. To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range minus Map gap to LN. Factory map
	To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the Confirm distance parameter and a new mapping can be recorded.
	When operating via the display module, the measured distance is displayed togethe with this parameter for reference purposes.
	If the teaching procedure with the Distance too small option or the Distance too b option is quit before the distance has been confirmed, a map is not recorded and th teaching procedure is reset after 60 s.

Visibility depends on order options or device settings Only available for "Expert \rightarrow Sensor \rightarrow Echo tracking \rightarrow **Evaluation mode** parameter" = "Short time history" or "Long time history" 5)

Present mapping		
Navigation	□ Setup → Present mapping	
Description	Indicates up to which distance a mapping has already been recorded.	
Mapping end point		
Navigation	□ Setup \rightarrow Map. end point	
Prerequisite	Confirm distance (→ 🗎 124) = Manual map or Distance too small	
Description	Specify new end of the mapping.	
User entry	0 to 200 000.0 m	
Additional information	This parameter defines up to which distance the new mapping is to be recorded. The distance is measured from the reference point, i.e. from the lower edge of the mountin flange or the threaded connection.	g
	For reference purposes the Present mapping parameter (→ □ 125) is displayed together with this parameter. It indicates up to which distance a mapping has alre been recorded.	ady

Record map		
Navigation	□ Setup \rightarrow Record map	
Prerequisite	Confirm distance (> 🗎 124) = Manual map or Distance too small	
Description	Start recording of the map.	
Selection	NoRecord mapDelete map	
Additional information	 Meaning of the options No No The map is not recorded. Record map The map is recorded. After the recording is completed, the new measured distance a the new mapping range appear on the display. When operating via the local display these values must be confirmed by pressing ☑. Delete map The mapping (if one exists) is deleted and the device displays the recalculated meas distance and the mapping range. When operating via the local display, these values be confirmed by pressing ☑. 	, ured

	 17.4.1 "Mapping" wizard In the Mapping wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the Setup menu (→ 119). In the Mapping wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only. 		
	Navigation \blacksquare Setup \rightarrow Mapping		
Confirm distance		A	
Navigation	Setup → Mapping → Confirm distance		
Description	→ 🗎 124		
Mapping end point		2	
Navigation	Setup → Mapping → Map. end point		
Description	→ 🗎 125		
Record map			
Navigation	Setup → Mapping → Record map		
Description	→ 🗎 125		
Distance			
Navigation	ⓐ Setup → Mapping → Distance		
Description	→ 🗎 122		

17.4.2 "Advanced setup" submenu

Navigation 🛛 S

Setup \rightarrow Advanced setup

Locking status	
Navigation	$ \blacksquare \square Setup \rightarrow Advanced setup \rightarrow Locking status $
Description	Indicates the write protection with the highest priority that is currently active.
User interface	 Hardware locked SIL locked CT active - defined parameters WHG locked Temporarily locked
Additional information	 Meaning and priorities of the types of write protection Hardware locked (priority 1) The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters. SIL locked (priority 2) The SIL mode is activated. Writing access to the relevant parameters is denied. WHG locked (priority 3) The WHG mode is activated. Writing access to the relevant parameters is denied. Temporarily locked (priority 4) Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete. On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

Access status tooling		
Navigation	$ \qquad \qquad$	
Description	Shows the access authorization to the parameters via the operating tool.	
Additional information	The access authorization can be changed via the Enter access code parameter $(\rightarrow \cong 128)$.	
	If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter ($\rightarrow \square 127$).	

Access status display Navigation Setup \rightarrow Advanced setup \rightarrow Access stat.disp Prerequisite The device has a local display. Description Indicates access authorization to parameters via local display. Additional information The access authorization can be changed via the Enter access code parameter F (→ 🗎 128). If additional write protection is active, this restricts the current access authorization A even further. The write protection status can be viewed via the Locking status parameter ($\rightarrow \blacksquare 127$).

Enter access code	
Navigation	□ Setup \rightarrow Advanced setup \rightarrow Ent. access code
Description	Enter access code to disable write protection of parameters.
User entry	0 to 9 999
Additional information	 The customer-specific access code that was defined in the Define access code parameter (→ 171) must be entered for local operation. If an incorrect access code is entered, users retain their current access authorization. The write protection affects all parameters marked with the symbol in the document. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected. If no key is pressed for 10 minutes or the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after another 60 s. Please contact your Endress+Hauser Sales Center if you lose your access code.

"Level" submenu

Navigation $\[Begin{array}{c} \end{array} \mathbb{S} \end{array} \mathsf{Setup} \end{array} \mathsf{Advanced} \end{array} \mathsf{setup} \end{array} \mathsf{Level} \end{array}$

Medium type		ß
Navigation	Image: Setup → Advanced setup → Level → Medium type	
Description	Specify type of medium.	
User interface	LiquidSolid	
Factory setting	FMP50, FMP51, FMP52, FMP53, FMP54, FMP55: Liquid	
Additional information	This parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended r to change the factory setting.	ıot

Medium property		
Navigation	Image: Bow Setup → Advanced setup → Level → Medium property	
Prerequisite	EOP level evaluation ≠ Fix DC	
Description	Specify the dielectric constant $\boldsymbol{\epsilon}_r$ of the medium.	
Selection	 Unknown DC 1.4 1.6 DC 1.6 1.9 DC 1.9 2.5 DC 2.5 4 DC 4 7 DC 7 15 DC > 15 	
Factory setting	Depends on the Medium type ($ightarrow extsf{B}$ 129) and Medium group ($ightarrow extsf{B}$ 120) paramete	ers.

Additional information

Dependency of "Medium type" and "Medium group"

Medium type (→ 🗎 129)	Medium group (→ 🗎 120)	Medium property
Solid		Unknown
Liquid	Water based (DC >= 4)	DC 4 7
	Others	Unknown

For the dielectric constants (DC values) of many media commonly used in industry, please refer to:

- Dielectric constant (DC value) Compendium CP01076F
- The Endress+Hauser "DC Values app" (available for Android and iOS)
- If **EOP level evaluation** = **Fix DC**, the exact dielectric constant must be specified in the **DC value** parameter. The **Medium property** parameter therefore does not apply in this case.

< 1

Process property		۵	
Navigation	Image: Setup → Advanced setup → Level → Process property		
Description	Specify typical rate of level change.		
Selection	For "Medium type" = "Liquid" Very fast > 10 m (400 in)/min Fast > 1 m (40 in)/min Standard < 1 m (40in) /min Medium < 10 cm (4in) /min Slow < 1 cm (0.4in) /min No filter / test 		
	For "Medium type" = "Solid" • Very fast > 100 m (333 ft) /h • Fast > 10 m (33 ft) /h • Standard < 10 m (33 ft) /h • Medium < 1 m (3ft) /h • Slow < 0.1 m (0.3ft) /h • No filter / test		
Additional information	The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter: For "Operating mode" = "Level" and "Medium type" = "Liquid"		
	Process property	Step response time / s	
	Very fast > 10 m (400 in)/min	5	
	Fast > 1 m (40 in)/min	5	
	Standard < 1 m (40in) /min	14	
	Medium < 10 cm (4in) /min	39	
	Slow < 1 cm (0.4in) /min	76	

No filter / test

Process property	Step response time / s
Very fast > 100 m (333 ft) /h	37
Fast > 10 m (33 ft) /h	37
Standard < 10 m (33 ft) /h	74
Medium < 1 m (3ft) /h	146
Slow < 0.1 m (0.3ft) /h	290
No filter / test	< 1

For "Operating mode" = "Interface" or "Interface with capacitance"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	23
Medium < 10 cm (4in) /min	47
Slow < 1 cm (0.4in) /min	81
No filter / test	2.2

Advanced process conditions


Navigation	Setup → Advanced setup → Level → Adv. conditions
Description	Specify additional process conditions (if required).
Selection	 None Oil/Water condensate Probe near tank bottom Build up Foam (>5cm/0,16ft)
Additional information	 Meaning of the options Oil/Water condensate (only Medium type = Liquid) Makes sure that in the case of two-phase media only the total level is detected (example: oil/condensate application). Probe near tank bottom (only for Medium type = Liquid) Improves the empty detection, especially if the probe is mounted close to the tank bottom. Build up Increases EOP range upper area in order to ensure a safe empty-detection even if the end-of-probe signal has shifted due to build-up. Enables a safe empty-detection even if the end-of-probe signal has shifted due to build-up. Foam (>5cm/0,16ft) (only for Medium type = Liquid) Optimizes the signal evaluation in applications with foam formation.

A

Level unit		6	8
Navigation	Image: Setup → Advanced setup → Level → Level unit		
Description	Select level unit.		
Selection	SI units ■ % ■ m ■ mm	US units ■ ft ■ in	
Additional information	The level unit may differ from the distance unit defined in the Distance unit parameter $(\rightarrow \cong 119)$:		
	 The unit defined in the Distance unit parameter is used for the basic calibration (Emp calibration (→ 🗎 121) and Full calibration (→ 🖺 121)). The unit defined in the Level unit parameter is used to display the (unlinearized) level 		

Blocking distance	
Navigation	Image: Setup → Advanced setup → Level → Blocking dist.
Description	Specify upper blocking distance UB.
User entry	0 to 200 m
Factory setting	For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)
Additional information	Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.
	 This behavior is only valid if the following two conditions are met: Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history) Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction
	If one of these conditions is not met, signals in the blocking distance will always be ignored.
	A different behavior for signals in the blocking distance can be defined in the Blocking distance evaluation mode parameter.
	If required a different behavior for signals in the blocking distance can be defined by


If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 43 Blocking distance (UB) for liquid measurements

Level correction		Ê
Navigation	Image: Setup → Advanced setup → Level → Level correction	
Description	Specify level correction (if required).	
User entry	-200000.0 to 200000.0 %	
Additional information	The value specified in this parameter is added to the measured level (before linearization	on).

"Linearization" submenu



🛃 44 Linearization: Conversion of the level and, if applicable, interface into a volume or a weight; the conversion depends on the vessel shape

- 1 Selection of linearization type and unit
- Configuration of the linearization 2
- Α
- Linearization type ($\Rightarrow \square 137$) = None Linearization type ($\Rightarrow \square 137$) = Linear В
- Linearization type ($\rightarrow \square 137$) = Table С
- D *Linearization type* ($\rightarrow \square 137$) = *Pyramid bottom*
- Linearization type ($\rightarrow \square 137$) = Conical bottom Ε
- F *Linearization type* ($\rightarrow \square 137$) = *Angled bottom*
- *Linearization type* ($\rightarrow \square 137$) = *Horizontal cylinder* G
- *Linearization type* ($\rightarrow \square 137$) = *Sphere* Η
- For "Operating mode" = "Interface" or "Interface with capacitance": interface before linearization (measured in Ι the level unit)
- ľ For "Operating mode" = "Interface" or "Interface with capacitance": interface after linearization (corresponds to volume or weight)
- Level before linearization (measured in level unit) L
- Ľ Level linearized ($\rightarrow \square 140$) (corresponds to volume or weight)
- Maximum value ($\rightarrow \square 140$) М
- Diameter ($\rightarrow \square 140$) d
- Intermediate height ($\rightarrow \square 141$) h

Structure of the submenu on the local display

Navigation

Setup \rightarrow Advanced setup \rightarrow Linearization

► Linearization	
	Linearization type
	Unit after linearization
	Free text
	Maximum value
	Diameter
	Intermediate height
	Table mode
	► Edit table
	Level
	Customer value
	Activate table

Structuro	of the	suhmonu	in the	onoratina	tool la c	. FieldCare)
Juluit	Uj lile	submenu	in ine	operating	1001 (6.9	. FieldCule)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization


► Linearization		
	Linearization type]
	Unit after linearization	
	Free text	
	Level linearized	
	Maximum value	
	Diameter	
	Intermediate height	
	Table mode	
	Table number	
	Level	
	Level	
	Customer value	
	Activate table	
1		

Description of the parameters

Navigation $\blacksquare \blacksquare \quad \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Linearization}$

Linearization type		ß
Navigation		
Description	Select linearization type.	
Selection	 None Linear Table Pyramid bottom Conical bottom Angled bottom Horizontal cylinder Sphere 	

Additional information



- ☑ 45 Linearization types
- Α None
- В Table
- С Pyramid bottom
- Conical bottom Angled bottom D
- Ε
- Sphere F
- G . Horizontal cylinder

Meaning of the options

- None
- The level is output in the level unit without being converted (linearized) beforehand.
- Linear

The output value (volume/weight) is proportional to the level L. This applies, for example, to vertical cylindrical tanks and silos. The following parameters must also be specified:

- Unit after linearization ($\rightarrow \triangleq 138$)
- Maximum value (→ 🗎 140): maximum volume or weight
- Table

The relationship between the measured level L and the output value (volume/weight) is defined by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight" respectively. The following parameters must also be specified:

- Unit after linearization ($\rightarrow \triangleq 138$)
- Table mode ($\rightarrow \square 141$)
- For every point in the table: Level (→
 ¹
 ¹⁴²
 ¹⁴²
- For every point in the table: Customer value (→
 ¹
 ¹
 ¹⁴³
 ¹⁴³
- Activate table ($\rightarrow \triangleq 143$)
- Pyramid bottom

The output value corresponds to the volume or weight in a silo with a pyramid bottom. The following parameters must also be specified:

- Unit after linearization (→
 [™] 138)
- Maximum value (→ 🗎 140): maximum volume or weight
- Intermediate height ($\rightarrow \cong 141$): the height of the pyramid
- Conical bottom

The output value corresponds to the volume or weight in a tank with a conical bottom. The following parameters must also be specified:

- Unit after linearization ($\rightarrow \square$ 138)
- Maximum value (→ 🗎 140): maximum volume or weight
- Intermediate height (→ 🗎 141): the height of the cone
- Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following parameters must also be specified:

- Unit after linearization ($\rightarrow \square 138$)
- Maximum value (→ 🗎 140): maximum volume or weight
- **Intermediate height (→** 🗎 **141)**: height of the angled bottom
- Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following parameters must also be specified:

- Unit after linearization ($\rightarrow \triangleq 138$)
- Maximum value (→ 🗎 140): maximum volume or weight
- Diameter (→ 🗎 140)
- Sphere

The output value corresponds to the volume or weight in a spherical tank. The following parameters must also be specified:

- Unit after linearization ($\Rightarrow \triangleq 138$)
- Maximum value (→ 🗎 140): maximum volume or weight

Unit after linearization

Ê

Navigation	
Prerequisite	Linearization type (→ 🗎 137) ≠ None

Description

Select the unit for the linearized value.

Selection

Selection/input (uint16)

- 1095 = [short Ton]
- 1094 = [lb]
- 1088 = [kg]
- 1092 = [Ton]
- 1048 = [US Gal.]
- 1049 = [Imp. Gal.]
- $1043 = [ft^3]$
- $1571 = [cm^3]$
- $1035 = [dm^3]$
- $1034 = [m^3]$
- 1038 = [1]
- 1041 = [hl]
- 1342 = [%]
- 1010 = [m]
- 1012 = [mm]
- 1018 = [ft]
- 1019 = [inch]
- 1351 = [l/s]
- 1352 = [l/min]
- 1353 = [l/h]
- $1347 = [m^3/s]$
- 1348 = [m³/min]
- 1349 = [m³/h]
- $1356 = [ft^3/s]$
- 1357 = [ft³/min]
- 1358 = [ft³/h]
- 1362 = [US Gal./s]
- 1363 = [US Gal./min]
- 1364 = [US Gal./h]
- 1367 = [Imp. Gal./s]
- 1358 = [Imp. Gal./min]
- 1359 = [Imp. Gal./h]
- 32815 = [Ml/s]
- 32816 = [Ml/min]
- 32817 = [Ml/h]
- 1355 = [Ml/d]

Additional information The selected unit is only used for display purposes. The measured value is **not** converted

on the basis of the selected unit.

Distance-to-distance linearization is also possible, i.e. a linearization from the level unit to another length unit. Select the **Linear** linearization mode for this purpose. To specify the new level unit, select the **Free text** option in the **Unit after linearization** parameter and enter the unit in the **Free text** parameter ($\rightarrow \cong$ 139).

Free text		
Navigation	$ \blacksquare \Box \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Linearization} \rightarrow \text{Free text} $	
Prerequisite	Unit after linearization ($\rightarrow \cong 138$) = Free text	
Description	Enter unit symbol.	

Description

User entry

User entry	Up to 32 alphanumerical characters (letters, numbers, special characters)	
Level linearized		
Navigation	□ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level linearized	
Description	Displays linearized level.	
Additional information	1 The unit is defined by the Unit after linearization parameter $\rightarrow \square$ 138.	
Maximum value		
Navigation	□ Setup → Advanced setup → Linearization → Maximum value	
Prerequisite	 Linearization type (→ ^B 137) has one of the following values: Linear Pyramid bottom Conical bottom 	

Angled bottomHorizontal cylinder

-50000.0 to 50000.0 %

Sphere

Diameter		
Navigation	□ Setup → Advanced setup → Linearization → Diameter	
Prerequisite	 Linearization type (→ 137) has one of the following values: Horizontal cylinder Sphere 	
Description	Diameter of the cylindrical or spherical tank.	
User entry	0 to 9 999.999 m	
Additional information	The unit is defined in the Distance unit parameter ($\rightarrow \cong 119$).	

Linearized value corresponding to a level of 100%.

Intermediate height		Â
Navigation	□ Setup → Advanced setup → Linearization → Intermed. height	
Prerequisite	 Linearization type (→ 137) has one of the following values: Pyramid bottom Conical bottom Angled bottom 	
Description	Height of the pyramid, conical or angled bottom.	
User entry	0 to 200 m	
Additional information		40013264
	H Intermediate height	A0013264

The unit is defined in the **Distance unit** parameter ($\Rightarrow \square 119$).

Table mode	
Navigation	Image: Setup → Advanced setup → Linearization → Table mode
Prerequisite	Linearization type ($\Rightarrow \triangleq 137$) = Table
Description	Select editing mode of the linearization table.
Selection	 Manual Semiautomatic Clear table Sort table
Additional information	 Meaning of the options Manual The level and the associated linearized value are entered manually for each linearization point. Semiautomatic The level is measured by the device for each linearization point. The associated linearized value is entered manually. Clear table Deletes the existing linearization table. Sort table Rearranges the linerization points into an ascending order.

Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.

Before entering a linearization table, the values for **Empty calibration** ($\rightarrow \cong 121$) and **Full calibration** ($\rightarrow \cong 121$) must be set correctly.

If values of the table need to be changed after the full or empty calibration have been changed, a correct evaluation is only ensured if the existing table is deleted and the complete table is entered again. To do so delete the existing table (**Table mode** $(\rightarrow \square 141) =$ **Clear table**). Then enter a new table.

How to enter the table

Via FieldCare

The table points can be entered via the **Table number** ($\rightarrow \cong 142$), **Level** ($\rightarrow \cong 142$) and **Customer value** ($\rightarrow \cong 143$) parameters. As an alternative, the graphic table editor may be used: Device Operation \rightarrow Device Functions \rightarrow Additional Functions \rightarrow Linearization (Online/Offline)

Via local display

Select the **Edit table** submenu to call up the graphic table editor. The table is displayed and can be edited line by line.

The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter $(\rightarrow \square 132)$ beforehand.

If a decreasing table is entered, the values for 20 mA and 4 mA of the current output are interchanged. That means: 20 mA refers to the lowest level, whereas 4 mA refers to the highest level.

Table numberImage: Table numberNavigationImage: Setup → Advanced setup → Linearization → Table numberPrerequisiteLinearization type (→ Image: 137) = TableDescriptionSelect table point you are going to enter or change.User entry1 to 32

Level (Manual)

Navigation	$ \qquad \qquad$
Prerequisite	 Linearization type (→ ^B 137) = Table Table mode (→ ^B 141) = Manual
Description	Enter level value of the table point (value before linearization).
User entry	Signed floating-point number

A


A

Level (Semiautomatic)	
Navigation	$ \qquad \qquad$
Prerequisite	 Linearization type (→ 137) = Table Table mode (→ 141) = Semiautomatic
Description	Displays measured level (value before linearization). This value is transmitted to the table.

Customer value

Navigation	$ \qquad \qquad$
Prerequisite	Linearization type ($\rightarrow \triangleq 137$) = Table
Description	Enter linearized value for the table point.
User entry	Signed floating-point number

Navigation	Setup → Advanced setup → Linearization → Activate table
Prerequisite	Linearization type ($\rightarrow \triangleq 137$) = Table
Description	Activate (enable) or deactivate (disable) the linearization table.
Selection	DisableEnable
Additional information	 Meaning of the options Disable The measured level is not linearized. If Linearization type (→ 137) = Table at the same time, the device issues error message F435. Enable The measured level is linearized according to the table.



"Safety settings" submenu

Navigation

 $\blacksquare \square \quad \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Safety sett.}$

Output echo lost	
Navigation	
Description	Output signal in case of a lost echo.
Selection	 Last valid value Ramp at echo lost Value echo lost Alarm
Additional information	 Meaning of the options Last valid value The last valid value is kept in the case of a lost echo. Ramp at echo lost ⁶ In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the Ramp at echo lost parameter (→ 🗎 145). Value echo lost ⁶ In the case of a lost echo the output assumes the value defined in the Value echo lost parameter (→ 🗎 144). Alarm In the case of a lost echo the device generates an alarm; see the Failure mode parameter (→ 🖺 154)

æ

Navigation	Image: Setup → Advanced setup → Safety sett. → Value echo lost
Prerequisite	Output echo lost ($\rightarrow \square 144$) = Value echo lost
Description	Output value in case of a lost echo
User entry	0 to 200000.0 %
Additional information	 Use the unit which has been defined for the measured value output: without linearization: Level unit (→ 🖺 132) with linearization: Unit after linearization (→ 🗎 138)


⁶⁾ Only visible if "Linearization type ($\rightarrow \square 137$)" = "None"

A

Ramp at echo lost

Navigation	□ Setup → Advanced setup → Safety sett. → Ramp echo lost
Prerequisite	Output echo lost ($\rightarrow \triangleq 144$) = Ramp at echo lost
Description	Slope of the ramp in the case of a lost echo
User entry	Signed floating-point number

Additional information



A Delay time echo lost

B Ramp at echo lost ($\rightarrow \square 145$) (positive value)

C Ramp at echo lost ($\rightarrow \square 145$) (negative value)

- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/ min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuosly increased until it reaches 100%.

Blocking distance		
Navigation	Image: Setup → Advanced setup → Safety sett. → Blocking dist.	
Description	Specify upper blocking distance UB.	
User entry	0 to 200 m	
Factory setting	For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)	
Additional information	Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance distance when the device was switched on and move into the blocking distance distance distance was switched on and move into the blocking distance distan	

due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.


This behavior is only valid if the following two conditions are met:

- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
 - Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

A different behavior for signals in the blocking distance can be defined in the **Blocking distance evaluation mode** parameter.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



Blocking distance (UB) for liquid measurements

"SIL/WHG confirmation" wizard

The **SIL/WHG confirmation** wizard is only available for devices with SIL or WHG approval (Feature 590: "Additional Approval", option LA: "SIL" or LC: "WHG overfill prevention") which are currently **not** in the SIL- or WHG-locked state.

The **SIL/WHG confirmation** wizard is required to lock the device according to SIL or WHG. For details refer to the "Functional Safety Manual" of the respective device, which describes the locking procedure and the parameters of the sequence.

Navigation B Setup \rightarrow Advanced setup \rightarrow SIL/WHG confirm.

"Deactivate SIL/WHG" wizard

Navigation \square Setup \rightarrow Advanced setup \rightarrow Deactiv. SIL/WHG

Reset write protection		æ
Navigation	Setup → Advanced setup → Deactiv. SIL/WHG → Res. write prot.	
Description	Enter unlocking code.	
User entry	0 to 65 535	
Code incorrect		
Navigation	Image: Setup → Advanced setup → Deactiv. SIL/WHG → Code incorrect	
Description	Indicates that a wrong unlocking code has been entered. Select procedure.	
Selection	Reenter codeAbort sequence	

"Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** ($\rightarrow \cong 150$) = **Manual input** in order to enter the value manually.

- If a mapping (interference echo suppression) has been recorded after shortening the probe, it is no longer possible to perform an automatic probe length correction. In this case there are two options:
 - Delete the map using the **Record map** parameter (→
 ^(⇒) 125) before performing the automatic probe length correction. After the probe length correction, a new map can be recorded using the **Record map** parameter (→
 ^(⇒) 125).
 - Alternative: Select Confirm probe length (→
 ^(→) 150) = Manual input and enter the probe length manually into the Present probe length parameter →
 ^(→) 149.

An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ($\rightarrow \triangleq 149$).

Navigation \square Setup \rightarrow Advanced setup \rightarrow Probe settings

Probe grounded		
Navigation	Setup → Advanced setup → Probe settings → Probe grounded	
Prerequisite	Operating mode = Level	
Description	Specify whether the probe is grounded.	
Selection	NoYes	

Present probe length		A
Navigation	□ Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Pres. length	
Description	 In most cases: Displays the length of the probe according to the currently measured end-of-prob signal. For Confirm probe length (→ 150) = Manual input: Enter actual length of probe. 	9
User entry	0 to 200 m	

Confirm probe length	8
Navigation	$ \qquad \qquad$
Description	Select, whether the value displayed in the Present probe length parameter $\rightarrow \triangleq 149$ matches the actual length of the probe. Based on this input, the device performs a probe length correction.
Selection	 Probe length OK Probe length too small Probe length too big Probe covered Manual input Probe length unknown
Additional information	Meaning of the options• Probe length OKTo be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.• Probe length too smallTo be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the Present probe length parameter → 🗎 149. This procedure has to be repeated until the displayed value matches the actual length of the probe.• Probe length too bigTo be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the Present probe length parameter → 🖺 149. This procedure has to be repeated until the displayed value matches the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the Present probe length parameter → 🗎 149. This procedure has to be repeated until the displayed value matches the actual length of the probe.• Probe coveredTo be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device quits the sequence.• Manual input To be selected if the probe must be entered manually into the Present probe length parameter → 🖺 149 ⁷ .• Probe length unknown To be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device quits the sequence.

⁷⁾ When operated via FieldCare, the **Manual input** option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited.

	"Probe length correction" wizard			
	The Probe length correction wizard is only available when operating via the loca display. When operating via an operating tool, all parameters concerning the prolength correction are located directly in the Probe settings submenu (→ ■ 149).			
	Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Problemgth control	rr		
Confirm probe length				
Navigation	$\begin{tabular}{lllllllllllllllllllllllllllllllllll$			
Description	→ 🗎 150			
Present probe length				
Navigation	B ■ Setup → Advanced setup → Probe settings → Prob.length corr → Pres. length			
Description	→ 🗎 149			

"Current output 1 to 2" submenu

The **Current output 2** submenu ($\rightarrow \triangleq 152$) is only available for devices with two current outputs.

Navigation \square Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2

Assign current output 1 t	o 2				
Navigation	Image: Bearing → Advance	ed setup \rightarrow Curr.output 1 to 2	2 → Assign curr.		
Description	Select process variable	Select process variable for current output.			
Selection	 Level linearized Distance Electronic temperatu Relative echo amplitu Analog output adv. d Analog output adv. d 	ide iagnostics 1			
	 For level measurements Current output 1: Level linearized Current output 2⁸: Level linearized Definition of the current range for the process variables				
Factory setting Additional information	 Current output 1: Lev Current output 2⁸⁾: L 	rel linearized evel linearized	les		
	 Current output 1: Lev Current output 2⁸⁾: L 	rel linearized evel linearized	oles 20 mA value		
	 Current output 1: Lev Current output 2⁸: L Definition of the current 	rel linearized evel linearized t range for the process variab			
	 Current output 1: Lew Current output 2⁸: L Definition of the current Process variable 	rel linearized evel linearized <i>t range for the process variab</i> 4 mA value 0 % ¹⁾ or the associated	20 mA value		
	 Current output 1: Lev Current output 2⁸: L Definition of the current Process variable Level linearized 	rel linearized evel linearized t range for the process variab 4 mA value 0 % ¹⁾ or the associated linearized value 0 (i.e. level is at the reference	20 mA value 100 % ²⁾ or the associated linearized value Empty calibration (→ 🗎 121) (i.e. level is a		
	 Current output 1: Lew Current output 2⁸: L Definition of the current Process variable Level linearized Distance 	rel linearized evel linearized t range for the process variab 4 mA value 0 % ¹⁾ or the associated linearized value 0 (i.e. level is at the reference point)	20 mA value $100 \%^{2}$ or the associated linearized value Empty calibration (>) 121) (i.e. level is a 0 %)		

1) the 0% level is defined by **Empty calibration** parameter ($\Rightarrow \square 121$)

2) The 100% level is defined by Full calibration parameter ($\rightarrow \square$ 121)

It may be necessary to adjust the 4mA and 20mA values to the application (especially in the case of the **Analog output adv. diagnostics 1/2** option).

This can be done by the following parameters:

- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow Turn down
- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow 4 mA value
- Expert \rightarrow Output \rightarrow Current output 1 to 2 \rightarrow 20 mA value

⁸⁾ only for devices with two current outputs

Current span				Â	
Navigation	$ \blacksquare \blacksquare \text{Setup} \to A $	Advanced setup → Curr.output	1 to 2 → Current span		
Description	Determines the	current range used to transmit	t the measured value.		
	'420mA': Measured variat	ole: 420 mA			
	'420mA NAM Measured variat	UR': ble: 3.8 20.5 mA			
	'420mA US': Measured variable: 3.9 20.8 mA				
	'Fixed current': Measured variable transmitted via HART only				
	Note: Currents below 3.6 mA or above 21.95 mA can be used to signal an alarm.				
Selection	 420 mA 420 mA NA 420 mA US Fixed current 	MUR			
Additional information	Meaning of the c	options			
	Option	Current range for process variable	Lower alarm signal level	Upper alarm signal level	
	(<u>20</u>)	(to 20 5)	() (> 31.05 4	

Option	variable	Lower alarm signal level	opper alarm signal level
420 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
420 mA US	3.9 to 20.8 mA	< 3.6 mA	> 21.95 mA
Fixed current	Constant current, defined in the Fixed current parameter ($\rightarrow \square$ 153).		

- In the case of an error, the output current assumes the value defined in the Failure mode parameter (→
 ¹ 154).
 - If the meausred value is out of the measuring range, **Current output** diagnostic message is issued.

In a HART multidrop loop only one device can use the analog current to transmit a signal. For all other devices one must set:

- Current span = Fixed current

Fixed current		
Navigation	Image Setup → Advanced setup → Curr.output 1 to 2 → Fixed current	
Prerequisite	Current span (→ 🗎 153) = Fixed current	
Description	Define constant value of the output current.	
User entry	4 to 22.5 mA	

Damping output		
Navigation	Setup → Advanced setup → Curr.output 1 to 2 → Damping out.	
Description	Reaction time of the output signal on fluctuation in the measured value.	
User entry	0.0 to 999.9 s	
Additional information	Fluctuations of the measured value affect the output current with an exponential delay, the time constant τ of which is defined in this parameter. With a small time constant the output reacts immediately to changes of the measrued value. With a big time constant to reaction of the output is more delayed. For $\tau = 0$ (factory setting) there is no damping.	ie

Failure mode		
Navigation	■ \square Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2 \rightarrow Failure mode	
Prerequisite	Current span (→ 🗎 153) ≠ Fixed current	
Description	Defines which current the output assumes in the case of an error.	
	'Min.': < 3.6mA	
	'Max.': > 21.95mA	
	'Last valid value': Last valid value before occurrence of the error.	
	'Actual value': Output current is equal to the measured value; error is ignored.	
	'Defined value': User defined value.	
Selection	 Min. Max. Last valid value Actual value Defined value 	

Additional information Meaning of the options • Min. The current output adopts the value of the lower alarm level according to the **Current span** parameter ($\rightarrow \square$ 153). Max. The current output adopts the value of the upper alarm level according to the **Current span** parameter ($\rightarrow \square$ 153). Last valid value The current remains constant at the last value it hat before the error occurred. Actual value The output current follows the actual measured value; the error is ignored. Defined value The output current assumes the value defined in the **Failure current** parameter (→ 🗎 155). The error behavior of other output channels is not influenced by these settings but is defined in separate parameters.

■ Setup \rightarrow Advanced setup \rightarrow Curr.output 1 to 2 \rightarrow Failure current	
Failure mode ($\rightarrow \triangleq 154$) = Defined value	
Defines which current the output assumes in case of an error.	
3.59 to 22.5 mA	
	Failure mode ($\rightarrow \cong 154$) = Defined value Defines which current the output assumes in case of an error.

Output	current	1	to	2	
--------	---------	---	----	---	--

Navigation	Setup → Advanced setup → Curr.output 1 to 2 → Output curr. 1 to 2
Description	Shows the actual calculated value of the output current.

"Switch output" submenu



The **Switch output** submenu ($\rightarrow \implies 156$) is only visible for devices with switch output.⁹⁾

Navigation □ □ Setup \rightarrow Advanced setup \rightarrow Switch output

Switch output function	
Navigation	Image: Setup → Advanced setup → Switch output → Switch out funct
Description	Defines the function of the switch output.
	'Off' The switch output is always open (non-conductive)
	'On' The switch output is always closed (conductive).
	'Diagnostic behavior' The switch output is normally closed and is only opened if a diagnostic event is present.
	'Limit' The switch output is normally closed and is only opened if a measured variable exceeds a defined limit.
	'Digital output' The switch output is controlled by one of the digital output blocks of the device.
Selection	 Off On Diagnostic behavior Limit Digital Output
Additional information	Meaning of the options
	 Off The output is always open (non-conductive).
	• On
	The output is always closed (conductive). Diagnostic behavior
	The output is normally closed and is only opened if a diagnostic event is present. The Assign diagnostic behavior parameter ($\rightarrow \triangleq 157$) determines for which type of event the output is opened.
	 Limit The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters: Assign limit (→ 157) Switch-on value (→ 158) Switch-off value (→ 159) Digital Output The switching state of the output tracks the output value of a DI function block. The
	function block is selected in the Assign status parameter ($\rightarrow \triangleq 157$).
	The Off and On options can be used to simulate the switch output.

⁹⁾ Ordering feature 020 "Power supply; Output", option B, E or G

A Assign status Navigation \blacksquare □ Setup → Advanced setup → Switch output → Assign status Prerequisite Switch output function ($\rightarrow \square 156$) = Digital Output Description Assigns a Discrete Output Block or an Advanced Diagnostic Block to the switch output. Selection • Off Digital output AD 1 Digital output AD 2 Additional information The **Digital output AD 1** and **Digital output AD 2** options refer to the Advanced Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the switch output. æ Assign limit Navigation □ Setup → Advanced setup → Switch output → Assign limit Prerequisite Switch output function ($\rightarrow \square 156$) = Limit Description Defines which process variable will be checked for limit violation. Selection • Off Level linearized Distance Interface linearized ⁷ Interface distance Thickness upper layer^{*} Terminal voltage Electronic temperature Measured capacitance ² Relative echo amplitude Relative interface amplitude^{*} Absolute echo amplitude Absolute interface amplitude^{*}

Assign diagnostic behavior		Ê
Navigation		
Prerequisite	Switch output function (> 🗎 156) = Diagnostic behavior	
Description	Defines to which behavior of diagnostic events the switch output reacts.	


^{*} Visibility depends on order options or device settings

Selection

- Alarm
- Alarm or warning
- Warning

Switch-on value		
Navigation	Image: Boundary Setup → Advanced setup → Switch output → Switch-on value	
Prerequisite	Switch output function ($\rightarrow \cong 156$) = Limit	
Description	Defines the switch-on point. The output is closed if the assigned process variable rises above this point.	
User entry	Signed floating-point number	
Additional information	The switching behavior depends on the relative position of the Switch-on value and Switch-off value parameters:	
	Switch-on value > Switch-off value	

- The output is closed if the measured value is larger than Switch-on value.
 The output is opened if the measured value is smaller than Switch-off value.




- Α Switch-on value
- В Switch-off value
- *Output closed (conductive)* С
- D *Output opened (non-conductive)*

Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.

Â

ß



- Α
- В
- С
- Switch-on value Switch-off value Output closed (conductive) Output opened (non-conductive) D

Switch-on delay

Navigation	$ \blacksquare \Box \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Switch output} \rightarrow \text{Switch-on delay} $
Prerequisite	 Switch output function (→ □ 156) = Limit Assign limit (→ □ 157) ≠ Off
Description	Defines the delay applied before the output is switched on.
User entry	0.0 to 100.0 s

Switch-off value

Navigation	$\textcircled{B} \Box \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Switch output} \rightarrow \text{Switch-off value}$
Prerequisite	Switch output function ($\rightarrow \square$ 156) = Limit
Description	Defines the switch-off point. The output is opened if the assigned process variable falls below this point.
User entry	Signed floating-point number
Additional information	The switching behavior depends on the relative position of the Switch-on value and Switch-off value parameters; description: see the Switch-on value parameter $(\rightarrow \cong 158)$.

Switch-off delay		Â
Navigation	Image: Setup → Advanced setup → Switch output → Switch-off delay	
Prerequisite	 Switch output function (→ □ 156) = Limit Assign limit (→ □ 157) ≠ Off 	
Description	Defines the delay applied before the output is switched off.	
User entry	0.0 to 100.0 s	

Failure mode		
Navigation	Image: Setup → Advanced setup → Switch output → Failure mode	
Prerequisite	Switch output function ($\Rightarrow \triangleq 156$) = Limit or Digital Output	
Description	Defines the state of the switch output in case of an error.	
Selection	Actual statusOpenClosed	
Additional information		

Switch status		
Navigation	Image: Boundary Setup → Advanced setup → Switch output → Switch status	
Description	Current status of the switch output.	
Invert output signal		
Navigation		

Description	'No' The switch output behaves as per its parameter setting.
	'Yes' The switching behavior is inverted as compared to its parameter setting.
Selection	NoYes

Additional information

Meaning of the options

No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

"Display" submenu

Display submenu is only visible if a display module is connected to the device.

Navigation $\ \ \square \ \ \square$ Setup \rightarrow Advanced setup \rightarrow Display

Language	
Navigation	Image: Setup → Advanced setup → Display → Language
Navigation	Setup / Auvanceu setup / Display / Language
Description	Set display language.
Selection	 English Deutsch* Français* Español* Italiano* Nederlands* Portuguesa* Polski pycckий язык (Russian)* Svenska* Türkçe* 中文 (Chinese)* 日本語 (Japanese)* 한국어 (Korean)* Bahasa Indonesia* tiếng Việt (Vietnamese)* čeština (Czech)*
Factory setting	The language selected in feature 500 of the product structure. If no language has been selected: English
Additional information	n
Format display	
Navigation	Image: Setup → Advanced setup → Display → Format display
Description	Select how measured values are shown on the display.
Selection	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values


^{*} Visibility depends on order options or device settings

A0019963


Additional information




💽 47 "Format display" = "1 value, max. size"




48 "Format display" = "1 bargraph + 1 value"




☑ 49 "Format display" = "2 values"



☑ 50 "Format display" = "1 value large + 2 values"



☑ 51 "Format display" = "4 values"



A

Value 1 to 4 display Navigation □ Setup → Advanced setup → Display → Value 1 display Description Select the measured value that is shown on the local display. Selection Level linearized Distance Interface linearized * Interface distance ¹ Thickness upper layer * Current output 1 Measured current Current output 2³ Terminal voltage Electronic temperature Measured capacitance^{*} Analog output adv. diagnostics 1 Analog output adv. diagnostics 2 **Factory setting** For level measurements Value 1 display: Level linearized Value 2 display: Distance • Value 3 display: Current output 1

Value 4 display: None

Decimal places 1 to 4		
Navigation		
Description	This selection does not affect the measurement and calculation accuracy of the device.	
Selection	 x x.x x.xx x.xxx x.xxxx 	
Additional information	The setting does not affect the measuring or computational accuracy of the device.	

Display interval	
Navigation	$ \blacksquare \Box Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display interval $
Description	Set time measured values are shown on display if display alternates between values.
User entry	1 to 10 s

Visibility depends on order options or device settings

Additional information This parameter is only relevant if the number of selected measuring values exceeds the number of values the selected display format can display simultaneously.

Display damping		
Navigation		
Description	Set display reaction time to fluctuations in the measured value.	
User entry	0.0 to 999.9 s	
Header		
Navigation	Image: Boundary Advanced setup → Display → Header	
Description	Select header contents on local display.	
Selection	Device tagFree text	
Additional information	1 XXXXXXXX 1 Position of the header text on the display 1 Position of the header text on the display Meaning of the options Section of the options • Device tag Is defined in the Device tag parameter (→ 🗎 119). • Free text Is defined in the Header text parameter (→ 🖺 165).	A0029422

Header text		Ê
Navigation	Image: Setup → Advanced setup → Display → Header text	
Prerequisite	Header ($\rightarrow \cong 165$) = Free text	
Description	Enter display header text.	
User entry	Character string comprising numbers, letters and special characters (12)	
Additional information	The number of characters which can be displayed depends on the characters used.	

A

Separator		
Navigation	$ \blacksquare \square Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Separator $	
Description	Select decimal separator for displaying numerical values.	
Selection	• . • ,	

Number format

Navigation	Image: Setup → Advanced setup → Display → Number format
Description	Choose number format for the display.
Selection	Decimalft-in-1/16"
Additional information	The ft-in-1/16 " option is only valid for distance units.

Decimal places menu	Â
Navigation	Image: Setup → Advanced setup → Display → Dec. places menu
Description	Select number of decimal places for the representation of numbers within the operating menu.
Selection	 X X.X X.XX X.XXX X.XXX
Additional information	 Is only valid for numbers in the operating menu (e.g. Empty calibration, Full calibration), but not for the measured value display. The number of decimal places for the measured value display is defined in the Decimal places 1 to 4 → 164 parameters. The setting does not affect the accuracy of the measurement or the calculations.

Backlight	
Navigation	$ \blacksquare \Box \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Display} \rightarrow \text{Backlight} $
Prerequisite	The device has the SD03 local display (with optical keys).
Description	Switch the local display backlight on and off.

Selection

- DisableEnable
- Additional information

Meaning of the options

- Disable
- Switches the backlight off.
- Enable
- Switches the backlight on.
- Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Contrast display	
Navigation	Image: Boosting → Advanced setup → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).
User entry	20 to 80 %
Factory setting	Dependent on the display.
Additional information	 Setting the contrast via push-buttons: Darker: press the buttons simultaneously. Brighter: press the buttons simultaneously.

"Configuration backup display" submenu



This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

Navigation \square □ Setup → Advanced setup → Conf.backup disp

Operating time

Navigation	Setup → Advanced setup → Conf.backup disp → Operating time
Description	Indicates how long the device has been in operation.
Additional information	<i>Maximum time</i> 9999 d (≈ 27 years)

Last backup	
Navigation	Setup → Advanced setup → Conf.backup disp → Last backup
Description	Indicates when the last data backup was saved to the display module.

Configuration management

Navigation	□ Setup → Advanced setup → Conf.backup disp → Config. managem.
Description	Select action for managing the device data in the display module.
Selection	 Cancel Execute backup Restore Duplicate Compare Clear backup data

Clear backup data

A

Additional information

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

- HART date code
- HART short tag
- HART message
- HART descriptor
- HART address
- Device tag
- Medium type
- Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ($\rightarrow \square 169$).

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state Navigation Image: Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Backup state Description Displays which backup action is currently in progress. Comparison result Image: Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Compar. result Navigation Image: Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Compar. result Description Comparison between present device data and display backup.

Additional information

Meaning of the display options

Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

Dataset incompatible

The data sets are incompatible and can not be compared.

To start the comparison, set **Configuration management** ($\rightarrow \equiv 168$) = **Compare**.

If the transmitter configuration has been duplicated from a different device by **Configuration management** ($\rightarrow \supseteq 168$) = **Duplicate**, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be **Settings not identical**.

"Administration" submenu

Navigation

Define access code		Â
Navigation	□ Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Def. access code	
Description	Define release code for write access to parameters.	
User entry	0 to 9 999	
Additional information	If the factory setting is not changed or if "0" is entered, the parameters are not write protected and the device configuration data can therefore always be modified. The user is logged on in the "Maintenance" role.	
	The write protection affects all parameters marked with the 🗟 symbol in the document. On the local display, the 🗟 symbol in front of a parameter indicates that the parameter is write-protected.	ıt
	Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Enter access code parameter $(\rightarrow \cong 128)$.	
	Please contact your Endress+Hauser Sales Center if you lose the access code.	
	If operating via the local display: the new access code is only valid once it has been confirmed in the Confirm access code parameter ($\Rightarrow \square 173$).	L

Device reset		Â
Navigation		
Description	Reset the device configuration - either entirely or in part - to a defined state.	
Selection	 Cancel To factory defaults To delivery settings Of customer settings To transducer defaults Restart device 	
Additional information	 Meaning of the options Cancel No action To factory defaults All parameters are reset to the order-code specific factory setting. To delivery settings All parameters are reset to the delivery setting. The delivery setting may differ from factory default if customer specific settings have been ordered. This option is only visible if customer specific settings have been ordered.	m the

Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

	"Define	e access code"	' wizara	1	
	W di	Vhen operatin irectly in the	ng via a Admin	de wizard is only available when operating via the local display on operating tool, the Define access code parameter is located istration submenu. The Confirm access code parameter is no on via operating tool.	
	Navigo	ation	8	Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Def. access code	ē
Define access code					ß
Navigation		Setup \rightarrow Adv	vanced	setup \rightarrow Administration \rightarrow Def. access code \rightarrow Def. access code	
Description	\rightarrow	171			
Confirm access code					ß
Navigation		Setup \rightarrow Adv	vanced	setup \rightarrow Administration \rightarrow Def. access code \rightarrow Confirm code	
Description	Confir	m the entere	d acces	s code.	
User entry	0 to 9	999			

17.5 "Diagnostics" menu

Navigation

Diagnostics

Actual diagnostics	
5	
Navigation	
Description	Displays current diagnostic message.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
	If several messages are active at the same time, the messages with the highest priority is displayed.
	Information on what is causing the message, and remedy measures, can be viewed via the () symbol on the display.

Timestamp			
Navigation	□ Diagnostics \rightarrow Timestamp		
Description	Displays the timestamp for the currently active diagnostic message.		

Previous diagnostics

Navigation	□ □ Diagnostics → Prev.diagnostics
Description	Displays the last diagnostic message which has been active before the current message.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
	The condition displayed may still apply. Information on what is causing the message, and remedy measures, can be viewed via the ④ symbol on the display.

Timestamp	
Navigation	□ Diagnostics → Timestamp
Description	Shows the timestamp of the previous diagnostic message.
Operating time from resta	art
Navigation	□ Diagnostics → Time fr. restart
Description	Displays the time the device has been in operation since the last device restart.
Operating time	
Navigation	Image Diagnostics → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time
	9999 d (≈ 27 years)

"Diagnostic list" submenu 17.5.1

Navigation □ □ Diagnostics \rightarrow Diagnostic list

Diagnostics 1 to 5	
Navigation	■ Diagnostics \rightarrow Diagnostic list \rightarrow Diagnostics 1
Description	Display the current diagnostics messages with the highest to fifth-highest priority.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
Timestamp 1 to 5	

Navigation

Description

```
Timestamp of the diagnostic message.
```

17.5.2 "Event logbook" submenu

The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Navigation \square Diagnostics \rightarrow Event logbook

Filter options		
Navigation	Diagnostics \rightarrow Event logbook \rightarrow Filter options	
Description	Define which category of event messages is shown in the Events list submenu.	
Selection	 All Failure (F) Function check (C) Out of specification (S) Maintenance required (M) Information (I) 	
Additional information	 This parameter is only used for operation via the local display. The status signals are categorized according to NAMUR NE 107. 	

"Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ($\rightarrow \implies 177$). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- \bigcirc : Event has ended

Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation \square Diagnostics \rightarrow Event logbook \rightarrow Event list

17.5.3 "Device information" submenu

Navigation

Device tag	
Navigation	
Description	Enter the name for the measuring point.
User interface	Character string comprising numbers, letters and special characters
Serial number	
Navigation	Image Diagnostics → Device info → Serial number
Description	Shows the serial number of the measuring device.
Additional information	 Uses of the serial number To identify the device quickly, e.g. when contacting Endress+Hauser. To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer The serial number is also indicated on the nameplate.

Firmware version	
Navigation	
Description	Shows the device firmware version installed.
User interface	xx.yy.zz
Additional information	For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.

Device name	
Navigation	Image Diagnostics → Device info → Device name \square
Description	Shows the name of the transmitter.

Order code		
Navigation	□ □ Diagnostics \rightarrow Device info \rightarrow Order code	
Description	Shows the device order code.	
User interface	Character string comprising numbers, letters and special characters	
Additional information	The order code is generated from the extended roder code, which defines all device features of the product structure. In contrast, the device features can not be read direct from the order code.	ly

Extended order code 1 to 3		Ê
Navigation		
Description	Display the three parts of the extended order code.	
User interface	Character string comprising numbers, letters and special characters	
Additional information	The extended order code indicates the version of all the features of the product structuand thus uniquely identifies the device.	ıre

Device revision	
Navigation	□ Diagnostics → Device info → Device revision
Description	Shows the device revision with which the device is registered with the HART Communication Foundation.
Additional information	The device revision is used to allocate the correct Device Description file (DD) to the device.


Device ID	
Navigation	
Description	Shows the device ID for identifying the device in a HART network.
Additional information	In addition to the Device type and Manufacturer ID, the Device ID is part of the unique device identification (Unique ID) which characterizes each HART device unambiguously.

Device type	
Navigation	
Description	Shows the device type with which the measuring device is registered with the HART Communication Foundation.
Additional information	

Manufacturer ID	
Navigation	
Description	Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x11 (for Endress+Hauser)

17.5.4 "Measured values" submenu

Navigation \square \square Diagnostics \rightarrow Measured val.



Measured current 1	
Navigation	
Prerequisite	Only available for current output 1
Description	Shows the current value of the current output which is currently measured.
Terminal voltage 1	

Navigation	Image Bar
Description	Shows the current terminal voltage that is applied at the output.

17.5.5 "Data logging" submenu

Navigation □ □ Diagnostics → Data logging

Assign channel 1 to 4]
Navigation	■ Diagnostics \rightarrow Data logging \rightarrow Assign chan. 1 to 4	
Description	Assign a process variable to logging channel.	
Selection	 Off Level linearized Distance Unfiltered distance Interface linearized* Interface distance* Unfiltered interface distance Thickness upper layer* Current output 1 Measured current Current output 2* Terminal voltage Electronic temperature Measured capacitance* Absolute echo amplitude Relative echo amplitude Absolute EOP amplitude EOP shift Noise of signal Calculated DC value* Analog output adv. diagnostics 1 Analog output adv. diagnostics 2 	
Additional information	A total of 1000 measured values can be logged. This means: 1000 data points if 1 logging channel is used 500 data points if 2 logging channels are used 333 data points if 3 logging channels are used 250 data points if 4 logging channels are used If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).	



The logged data are deleted if a new option is selected in this parameter.

^{*} Visibility depends on order options or device settings

A

Logging interval

Navigation	Diagnostics \rightarrow Data logging \rightarrow Logging interval	
	Diagnostics \rightarrow Data logging \rightarrow Logging interval	
Description	efine the logging interval tlog for data logging. This value defines the time interval etween the individual data points in the memory.	
User entry	0 to 3 600.0 s	
Additional information	nis parameter defines the interval between the individual data points in the data log, an us the maximum loggable process time T $_{ m log}$:	d
	If 1 logging channel is used: T $_{log} = 1000 \cdot t_{log}$ If 2 logging channels are used: T $_{log} = 500 \cdot t_{log}$ If 3 logging channels are used: T $_{log} = 333 \cdot t_{log}$ If 4 logging channels are used: T $_{log} = 250 \cdot t_{log}$	
	nce this time elapses, the oldest data points in the data log are cyclically overwritten suc at a time of T _{log} always remains in the memory (ring memory principle).	:h
	The logged data are deleted if this parameter is changed.	
	ample	
	Then using 1 logging channel	

- $T_{log} = 1000 \cdot 1 \text{ s} = 1000 \text{ s} \approx 16.5 \text{ min}$ $T_{log} = 1000 \cdot 10 \text{ s} = 1000 \text{ s} \approx 2.75 \text{ h}$ $T_{log} = 1000 \cdot 80 \text{ s} = 80000 \text{ s} \approx 22 \text{ h}$ $T_{log} = 1000 \cdot 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data A Navigation $\mathsf{Diagnostics} \rightarrow \mathsf{Data} \ \mathsf{logging} \rightarrow \mathsf{Clear} \ \mathsf{logging}$ Diagnostics \rightarrow Data logging \rightarrow Clear logging Description Clear the entire logging data.


Selection

 Cancel Clear data


"Display channel 1 to 4" submenu

The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.



Navigation

 \square Diagnostics \rightarrow Data logging \rightarrow Displ.channel 1 to 4

17.5.6 "Simulation" submenu

The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.

Conditions which can be simulated

Condition to be simulated	Associated parameters
Specific value of a process variable	 Assign measurement variable (→ 🗎 188) Process variable value (→ 🖺 188)
Specific value of the output current	 Current output simulation (→ 188) Value current output (→ 189)
Specific state of the switch output	 Switch output simulation (→ ^B 189) Switch status (→ ^B 189)
Existence of an alarm	Device alarm simulation ($\rightarrow \square$ 190)
Existence of a specific diagnostic message	Diagnostic event simulation (→ 🗎 190)

Structure of the submenu

Navigation

Expert \rightarrow Diagnostics \rightarrow Simulation

► Simulation			
	Assign measurement variable]	→ 🗎 188
	Process variable value]	→ 🗎 188
	Current output 1 to 2 simulation]	→ 🗎 188
	Value current output 1 to 2]	→ 🗎 189
	Switch output simulation]	→ 🗎 189
	Switch status		→ 🗎 189
	Device alarm simulation]	→ 🗎 190
	Diagnostic event simulation]	→ 🗎 190

Description of parameters

Navigation

□ □ Expert → Diagnostics → Simulation

Assign measurement variable		
Navigation	Image: Barbon Simulation → Assign meas.var.	
Description	Defines the process variable to be simulated.	
Selection	 Off Level Interface * Thickness upper layer * Level linearized Interface linearized Thickness linearized 	
Additional information	 The value of the variable to be simulated is defined in the Process variable value parameter (→	ì

Process variable value		
Navigation	Image: Barbon Simulation → Proc. var. value Image: Simulation → Proc. var. value	
Prerequisite	Assign measurement variable (→ 🗎 188) ≠ Off	
Description	Defines the value of the selected variable. The outputs assume values or states according to this value.	
User entry	Signed floating-point number	
Additional information	Downstream measured value processing and the signal output use this simulation valu this way, users can verify whether the measuring device has been configured correctly.	

Current output 1 to 2 simulation

Navigation	Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Curr.out. 1 to 2 sim.

Description Switch the simulation of the current output on and off.

Â

^{*} Visibility depends on order options or device settings

Selection • Off • On Additional information Additional information An active simulation is indicated by a diagnostic message of the Function check (C) category.

Value current output 1 to 2		Ê
Navigation	Image: Simulation → Value curr.out 1 to 2	
Prerequisite	Current output simulation ($\rightarrow \square 188$) = On	
Description	Defines the value of the simulated output current.	
User entry	3.59 to 22.5 mA	
Additional information	The current output assumes the value specified in this parameter. In this way, users can verify the correct adjustment of the current output and the correct function of connected control units.	

Switch output simulation		ß
Navigation	$ \blacksquare \blacksquare \text{Expert} \rightarrow \text{Diagnostics} \rightarrow \text{Simulation} \rightarrow \text{Switch sim.} $	
Description	Switch the simulation of the switch output on and off.	
Selection	OffOn	

Switch status		Â
Navigation	Image: Boundary System Simulation → Switch status $A = A + A + A + A + A + A + A + A + A + $	
Prerequisite	Switch output simulation ($\rightarrow \cong 189$) = On	
Description	Current status of the switch output.	
Selection	OpenClosed	
Additional information	The switch status assumes the value defined in this parameter. This helps to check corr operation of connected control units.	ect

£

Device alarm simulation

Navigation	$ \blacksquare \blacksquare \text{Expert} \rightarrow \text{Diagnostics} \rightarrow \text{Simulation} \rightarrow \text{Dev. alarm sim.} $
Description	Switch the device alarm on and off.
Selection	OffOn
Additional information	When selecting the On option, the device generates an alarm. This helps to check the correct output behavior of the device in the case of an alarm. An active simulation is indicated by the C484 Failure mode simulation diagnostic message.

Navigation	■ Expert → Diagnostics → Simulation → Diag. event sim.
Description	Select the diagnostic event to be simulated. Note:
	To terminate the simulation, select 'Off'.
Additional information	When operated via the local display, the selection list can be filtered according to the event categories (Diagnostic event category parameter).

17.5.7 "Device check" submenu

Navigation \square Diagnostics \rightarrow Device check

Start device check	6
Navigation	□ □ Diagnostics \rightarrow Device check \rightarrow Start dev. check
Description	Start a device check.
Selection	NoYes
Additional information	In the case of a lost echo a device check can not be performed.
Result device check	
Navigation	■ \square Diagnostics \rightarrow Device check \rightarrow Result dev.check
Description	Displays the result of the device check.
Additional information	 Meaning of the display options Installation ok Measurement possible without restrictions. Accuracy reduced A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes. Measurement capability reduced A measurement is currently possible. Howerver, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium. Check not done No device check has been performed.
Last check time	

Navigation	
Description	Displays the operating time at which the last device check has been performed.
User interface	Character string comprising numbers, letters and special characters

Level signal

Navigation	
Prerequisite	Device check has been performed.
Description	Displays result of the device check for the level signal.
User interface	 Check not done Check not OK Check OK
Additional information	For Level signal = Check not OK : Check the mounting position of the device and the dielectric constant of the medium.

Launch signal	
Navigation	□ Diagnostics → Device check → Launch signal
Prerequisite	Device check has been performed.
Description	Displays result of the display check for the launch signal.
User interface	 Check not done Check not OK Check OK
Additional information	For Launch signal = Check not OK : Check the mounting position of the device. In non- metallic vessels use a metal plate or a metal flange.

17.5.8 "Heartbeat" submenu

The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

Detailed description SD01872F

Navigation \square Diagnostics \rightarrow Heartbeat

Device information (Submenu) 178 Device reset (Parameter) 171 Device type (Parameter) 180 Diagnostic event simulation (Parameter) 190 Diagnostic list (Submenu) 176

Diagnostics 1 (Parameter) 176

Display damping (Parameter) 165

Diagnostics

DIP switch

Document

see Write protection switch

Index

Α

Access authorization to parameters

Read access	50
Write access	
Access code	50
Incorrect input	50
Access status display (Parameter)	128
Access status tooling (Parameter)	127
Accessories	
Communication-specific	98
Device-specific	
Service-specific	
System components	99
Activate table (Parameter)	
Actual diagnostics (Parameter)	174
Administration (Submenu)	
Advanced process conditions (Parameter)	131
Advanced setup (Submenu)	
Application	9
Assign channel 1 to 4 (Parameter)	183
Assign current output (Parameter)	152
Assign diagnostic behavior (Parameter)	157
Assign limit (Parameter)	157
Assign measurement variable (Parameter)	188
Assign status (Parameter)	157

Β

Backlight (Parameter)	166
Backup state (Parameter)	169
Blocking distance (Parameter)	145
Bluetooth [®] wireless technology	. 46

С

-
Cleaning
Clear logging data (Parameter)
Code incorrect (Parameter) 148
Comparison result (Parameter) 169
Configuration backup display (Submenu) 168
Configuration management (Parameter) 168
Configuration of a level measurement 68
Configuring level measurement
Confirm access code (Parameter)
Confirm distance (Parameter)
Confirm probe length (Parameter) 150, 151
Context menu
Contrast display (Parameter) 167
Current output 1 to 2 (Submenu) 152
Current output 1 to 2 simulation (Parameter) 188
Current span (Parameter) 153
Customer value (Parameter) 143

D

Damping output (Parameter)
Data logging (Submenu)
DD
Deactivate SIL/WHG (Wizard) 148

Purpose	. 5
E	
Electronics housing	
Design	13
Empty calibration (Parameter)	121
Enter access code (Parameter)	128
Envelope curve display	62
Event history	86
Event level	
Explanation	79
Symbols	
Event list (Submenu)	177
Event logbook (Submenu)	
Event text	

F

1
Failure current (Parameter)
Failure mode (Parameter)
FHX50
Field of application
Residual risks
Filter options (Parameter)
Filtering the event logbook
Firmware version (Parameter)
Fixed current (Parameter)
Format display (Parameter) 162
Free text (Parameter)
Full calibration (Parameter)
Functional Safety Manual (FY) 7
FV (HART device variable) 63

Η

Hardware write protection51HART device variables63HART protocol47HART-Integration63Header (Parameter)165Header text (Parameter)165Heartbeat (Submenu)193
Housing
Design

I

Input mask
Intended use
Intermediate height (Parameter)
Invert output signal (Parameter)

Ke

54
54

L

Language (Parameter)	162
Last backup (Parameter)	
Last check time (Parameter)	
Launch signal (Parameter)	192
Level (Parameter)	
Level (Submenu)	
Level correction (Parameter)	. 133
Level linearized (Parameter) 14	ŧ0, 181
Level signal (Parameter)	
Level unit (Parameter)	
Linearization (Submenu)	6, 137
Linearization type (Parameter)	. 137
Local display	
see Diagnostic message	
see In alarm condition	
Locking status	56

Locking status (Parameter)		 	 	 	 	127
Logging interval	l (Paramete	er)	 	 		 	184

Μ

1V1
Maintenance
Managing the device configuration
Manufacturer ID (Parameter) 180
Mapping (Wizard) 126
Mapping end point (Parameter)
Maximum value (Parameter)
Measured current 1 (Parameter)
Measured value symbols
Measured values (Submenu) 181
Media
Medium group (Parameter) 120
Medium property (Parameter)
Medium type (Parameter) 129
Menu
Diagnostics
Setup
Mounting outside the vessel
Mounting position for level measurements 17

Ν

Non-metal vessels	24
Number format (Parameter)	66

0

Operating elements
Diagnostic message
Operating module
Operating time (Parameter)
Operating time from restart (Parameter) 175
Operational safety
Order code (Parameter) 179
Output current 1 to 2 (Parameter)
Output echo lost (Parameter)
Overvoltage protection
General information

P

-	
Present mapping (Parameter) 12	25
Present probe length (Parameter) 149, 15	51
Previous diagnostics (Parameter)	74
Probe grounded (Parameter)	
Probe length correction (Wizard) 15	
Probe settings (Submenu) 14	
Process property (Parameter)	30
Process variable value (Parameter)	38
Product safety	10
Purpose of this document	5
PV (HART device variable) 6	53

R

Ramp at echo lost (Parameter)
Read access
Record map (Parameter)
Registered trademarks
Remedial measures
Calling up

Closing
Remote operation
Repair concept
Replacing a device
Requirements for personnel
Reset write protection (Parameter) 148
Result device check (Parameter)
Return
Rod probe
Design
Rod probes
Lateral loading capacity

S

Safety instructions			
Basic			9
Safety Instructions (XA)			7
Safety settings (Submenu)			144
Separator (Parameter)			
Serial number (Parameter)			178
Service interface (CDI)			
Setting the operating language			
Settings			
Managing the device configuration			. 73
Operating language			
Setup (Menu)			
Signal quality (Parameter)			123
SIL/WHG confirmation (Wizard)			
Simulation (Submenu)			
Spare parts			
Nameplate			
Start device check (Parameter)			
Status signals			
Submenu			
Administration			171
Advanced setup			
Configuration backup display			168
Current output 1 to 2			152
Data logging			183
Device check			191
Device information			178
Diagnostic list			176
Display			
Display channel 1 to 4			185
Event list			177
Event logbook			177
Events list			. 86
Heartbeat			193
Level			129
Linearization	135,	136,	137
Measured values			181
Probe settings			149
Safety settings			144
Simulation			188
Switch output			
SV (HART device variable)			. 63
Switch output (Submenu)			156
Switch output function (Parameter)			156
Switch output simulation (Parameter) $$			189

Switch status (Parameter)160, 189Switch-off delay (Parameter)160Switch-off value (Parameter)159Switch-on delay (Parameter)159Switch-on value (Parameter)158Symbols59In the text and numeric editor59System components99
Т
Table mode (Parameter) 141 Table number (Parameter) 142 Tank type (Parameter) 119 Terminal voltage 1 (Parameter) 182 Thermal insulation 27 Timestamp (Parameter) 174, 175 Timestamp 1 to 5 (Parameter) 28
Transmitter Turning the display Turning the display module 30
Transmitter housing29Turning75Troubleshooting120Turning the display30Turning the display module30TV (HART device variable)63
U Unit after linearization (Parameter)
Use of the measuring device see Intended use Use of the measuring devices Borderline cases
V
Value 1 display (Parameter)164Value current output 1 to 2 (Parameter)189Value echo lost (Parameter)144
W
WizardDeactivate SIL/WHGDefine access code173Mapping126Probe length correction151SIL/WHG confirmation147Workplace safety10Write access50Write protection



www.addresses.endress.com

