Operating Instructions Levelflex FMP53 FOUNDATION Fieldbus

Guided wave radar










Table of contents

1	Important document information					
1.1 1.2	Purpose of this document	6 6				
	1.2.1 Safety symbols1.2.2 Electrical symbols1.2.3 Tool symbols1.2.4 Symbols for certain types of	6 6 6				
1.3	information and graphics Documentation	7 8 8				
	 Brief Operating Instructions (KA) Safety Instructions (XA) Functional Safety Manual (FY) 	8 8 8				
1.4 1.5	Terms and abbreviations	8 9				
2	Basic safety instructions 11					
2.1 2.2 2.3	Intended use	11 11 12				
2.4	Operational safety	12				
2.5	5	12 12				
		13				
3	Product description 1	4				
3.1	J	14 14				
		15				
4	Incoming acceptance and product					
	identification 1	.6				
4.1 4.2	5 1	16 16				
1.2		17				
5	Storage, transport 1	8				
5.1 5.2	Transporting the product to the measuring	18				
	point 1	18				
6	Mounting 1	9				
6.1	5 1	19				
	51	19 21				
	1	23 24				
6.2	Mounting the measuring device	30 30				
		-				

	6.2.2 Mounting the "Sensor, remote"				
		30			
	5 5	31			
()	5 1 5	32			
6.3	Post-installation check	33			
7	Electrical connection 34				
7.1	Connecting requirements				
	7.1.1 Terminal assignment	34			
	7.1.2 Cable specification	36			
	7.1.3 Device plug	36			
	7.1.4 Supply voltage	37			
7.2	7.1.5Overvoltage protectionConnecting the device	37 38			
1.2	7.2.1 Opening cover	38			
	7.2.2 Connecting	38			
	7.2.3 Plug-in spring-force terminals	39			
	7.2.4 Closing the cover of the connection				
	compartment	39			
7.3	Post-connection check	39			
0	Operation methods	41			
8	1	41			
8.1		41			
	1	41			
	8.1.2 Operation with remote display and operating module FHX50	42			
	8.1.3 Remote operation	42 42			
8.2	Structure and function of the operating	12			
0.1	menu	44			
	8.2.1 Structure of the operating menu	44			
	8.2.2 User roles and related access				
	authorization	46			
0.0	5	46			
8.3	Display and operating module	51			
	8.3.1 Display8.3.2 Operating elements	51 54			
		55			
	8.3.4 Opening the context menu	56			
	8.3.5 Envelope curve display on the display				
	and operating module	58			
9	Integration into a FOUNDATION				
-	5	59			
9.1		59			
9.2	Integration into the FOUNDATION Fieldbus network	59			
9.3		59 59			
9.4	5	60			
		60			
	9.4.2 Block configuration when device is	-			
	delivered	61			
9.5	Assignment of the measured values				
	(CHANNEL) in an AI Block	61			

9.6	Index tables of Endress+Hauser parameters 62	
2.0	9.6.1 Setup Transducer Block	
	9.6.2 Advanced Setup Transducer Block 63	
	9.6.3 Display Transducer Block	
	9.6.4 Diagnostic Transducer Block	
	9.6.5 Expert Configuration Transducer	
	Block659.6.6Expert Information Transducer	
	Block	
	9.6.7 Service Sensor Transducer Block 68	
	9.6.8 Service Information Transducer Block	
	9.6.9 Data Transfer Transducer Block 69	
9.7	Methods 70	
10	Commissioning using the	
	Commissioning Wizard 71	
	3	
11	Commissioning via operating	
	menu	
11.1	Function check	
11.2	Setting the operating language	
11.3	Configuring level measurement	
11.4	Recording the reference envelope curve 75	
11.5	Configuring the local display 76	
	11.5.1 Factory setting of local display for	
	level measurements	
	11.5.2 Adjusting the local display 76	
11.6	Configuration management	
11.6 11.7		
	Configuration management	
11.7	Configuration management	
11.7	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79	
11.7 12	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79	
11.71212.1	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79	
11.71212.1	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration79	
11.71212.1	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks79	
11.71212.1	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks80	
11.71212.112.2	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8012.2.5Additional configuration80	
 11.7 12 12.1 12.2 12.3 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8012.2.5Additional configuration80Scaling the measured value in the AI Block80	
 11.7 12 12.1 12.2 12.3 12.4 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8012.2.5Additional configuration80Scaling the measured value in the AI Block80Selecting the language81	
 11.7 12 12.1 12.2 12.3 12.4 12.5 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8022.5Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring level measurement82	
 11.7 12 12.1 12.2 12.3 12.4 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks80Scaling the measured value in the AI Block80Selecting the language81Configuring the local display83	
 11.7 12 12.1 12.2 12.3 12.4 12.5 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks80Scaling the measured value in the AI Block80Selecting the language81Configuring the local display8312.6.1Factory setting of local display for	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.5 Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring the local display8312.6.1 Factory setting of local display for level measurements83	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks8012.2.5 Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring the local display8312.6.1 Factory setting of local display for level measurement83Configuration management83	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks8012.2.5 Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring the local display8312.6.1 Factory setting of local display for level measurements83Configuration management83Configuring event behavior according to83	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks80Scaling the measured value in the AI Block80Scaling the language81Configuring the local display8312.6.1 Factory setting of local display for level measurement83Configuration management83Configuring event behavior according to FOUNDATION Fieldbus specification FF91285	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-oriented operation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks80Scaling the measured value in the AI Block80Scaling the language81Configuring the local display8312.6.1 Factory setting of local display for level measurement83Configuration management83Configuring event behavior according to83FOUNDATION Fieldbus specification FF9128512.8.1 Event groups86	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks8012.2.5 Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring level measurement82Configuring the local display8312.6.1 Factory setting of local display for level measurements83Configuration management83Configuring event behavior according to83FOUNDATION Fieldbus specification FF9128512.8.1 Event groups8612.8.2 Assignment parameters88	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8012.2.5Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring level measurement82Configuring the local display8312.6.1Factory setting of local display for level measurements83Configuring event behavior according to83FOUNDATION Fieldbus specification FF9128512.8.1Event groups8612.8.2Assignment parameters8812.8.3Configurable area91	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1Preparatory steps7912.2.2Configuring the Resource Block7912.2.3Configuring the Transducer Blocks7912.2.4Configuring the Analog Input Blocks8012.2.5Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring level measurement82Configuring the local display8312.6.1Factory setting of local display for level measurements83Configuring event behavior according to83FOUNDATION Fieldbus specification FF9128512.8.1Event groups8612.8.2Assignment parameters8812.8.3Configurable area91	
 11.7 12 12.1 12.2 12.3 12.4 12.5 12.6 12.7 	Configuration management77Protecting settings from unauthorized access78Commissioning (block-orientedoperation)79Function check79Block configuration7912.2.1 Preparatory steps7912.2.2 Configuring the Resource Block7912.2.3 Configuring the Transducer Blocks7912.2.4 Configuring the Analog Input Blocks8012.2.5 Additional configuration80Scaling the measured value in the AI Block80Selecting the language81Configuring level measurement82Configuring the local display8312.6.1 Factory setting of local display for level measurements83Configuring event behavior according to83FOUNDATION Fieldbus specification FF9128512.8.1 Event groups8612.8.2 Assignment parameters8812.8.4 Transmission of event messages over91	

13	Diagnostics and troubleshooting 93			
13.1	General troubleshooting			
	13.1.1 General errors			
	13.1.2 Parametrization errors			
13.2	Diagnostic information on local display 95			
	13.2.1 Diagnostic message 95			
	13.2.2 Calling up remedial measures 97			
13.3	Diagnostic event in the operating tool 98			
13.4	Diagnostic messages in the DIAGNOSTIC			
	Transducer Block (TRDDIAG) 99			
13.5	Diagnostic list			
13.6	Event logbook 100			
	13.6.1 Event history			
	13.6.2 Filtering the event logbook 100			
107	13.6.3 Overview of information events 100			
13.7	Firmware history 102			
14	Maintenance 103			
14.1	Exterior cleaning 103			
14.2	General cleaning instructions			
14.3	Cleaning the probe			
2 112	14.3.1 Cleaning the probe in the vessel 103			
	14.3.2 Cleaning the probe outside the			
	vessel 104			
	D 1			
15	Repair 105			
15.1	General information 105			
	15.1.1 Repair concept 105			
	15.1.2 Repair of Ex-certified devices 105			
	15.1.3 Replacing electronics modules 105			
	15.1.4 Replacing a device 105			
15.2	Spare parts 106			
15.3	Return			
15.4	Disposal 106			
16	Accessories 107			
16.1	Device-specific accessories			
	16.1.1 Weather protection cover 107			
	16.1.2 Mounting bracket for electronics housing 108			
	housing 108 16.1.3 Weld-in adapter 108			
	16.1.4 Protective cover			
	16.1.5 Calibration kit			
	16.1.6 Remote display FHX50 109			
	16.1.7 Overvoltage protection 110			
	16.1.8 Bluetooth module BT10 for HART			
	devices			
16.2	Communication-specific accessories 112			
16.3	Service-specific accessories 112			
16.4	System components 112			
17	Operating many 112			
17	Operating menu 113			
17.1	Overview of the operating menu (display			
4	module) 113			
17.2	Overview of the operating menu (operating			
	tool) 120			

Endress+Hauser

17.3	"Setup"	menu	126
	17.3.1	"Mapping" wizard	133
		"Analog input 1 to 5" submenu	134
	17.3.3	"Advanced setup" submenu	136
17.4	"Diagno	stics" menu	177
	17.4.1	"Diagnostic list" submenu	179
	17.4.2	"Event logbook" submenu	180
	17.4.3	"Device information" submenu	181
	17.4.4	"Measured values" submenu	183
	17.4.5	"Analog input 1 to 5" submenu	184
	17.4.6	"Data logging" submenu	186
	17.4.7	"Simulation" submenu	189
	17.4.8	"Device check" submenu	194
	17.4.9	"Heartbeat" submenu	196
Inde	x		197

1 Important document information

1.1 Purpose of this document

These Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

A WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

ACAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

\sim

Alternating current

\sim

Direct current and alternating current

Direct current

Ŧ

Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

• Interior ground terminal: protective earth is connected to the mains supply.

• Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols

● // Flat blade screwdriver

O ↓ Torx screwdriver

🛈 🕼 Allen key

ダ Open-ended wrench

1.2.4 Symbols for certain types of information and graphics

Permitted Procedures, processes or actions that are permitted Preferred

Procedures, processes or actions that are preferred

Forbidden Procedures, processes or actions that are forbidden

Tip Indicates additional information

Reference to documentation

Reference to graphic

►

Notice or individual step to be observed

1., 2., 3.

Series of steps

Result of a step

۲

Visual inspection

Operation via operating tool

Write-protected parameter

1, 2, 3, ... Item numbers

A, B, C, ... Views

$\mathbf{\Lambda} \rightarrow \mathbf{I}$ Safety instructions

Observe the safety instructions contained in the associated Operating Instructions

Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

1.3 Documentation

The following types of documentation are available in the Download Area of the Endress +Hauser website (www.endress.com/downloads):

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

1.3.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.3.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

The nameplate indicates the Safety Instructions (XA) that are relevant to the device.

1.3.4 Functional Safety Manual (FY)

Depending on the SIL approval, the Functional Safety Manual (FY) is an integral part of the Operating Instructions and applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions.

The different requirements that apply for the protective function are described in the Functional Safety Manual (FY).

1.4 Terms and abbreviations

BA

Document type "Operating Instructions"

KA

Document type "Brief Operating Instructions"

ΤI

Document type "Technical Information"

SD

Document type "Special Documentation"

XA Doo

Document type "Safety Instructions"

PN

Nominal pressure

MWP

Maximum working pressure The MWP is indicated on the nameplate.

ToF

Time of Flight

FieldCare

Scalable software tool for device configuration and integrated plant asset management solutions

DeviceCare

Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices

DTM

Device Type Manager

$\epsilon_{\rm r}$ (Dk value)

Relative dielectric constant

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

Operating tool

The term "operating tool" is used in place of the following operating software: SmartBlue (app), for operation using an Android or iOS smartphone or tablet

BD

Blocking Distance; no signals are analyzed within the BD.

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

PFS

Pulse Frequency Status (Switch output)

MBP

Manchester Bus Powered

PDU

Protocol Data Unit

1.5 Registered trademarks

FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

Bluetooth®

The *Bluetooth*[®] word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple®

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android®

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ®, VITON®

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

TEFLON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- Trained, qualified specialists must have a relevant qualification for this specific function and task.
- Are authorized by the plant owner/operator.
- Are familiar with federal/national regulations.
- Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ► Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the level measurement of liquids. Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

If the limit values specified in the "Technical data" and the conditions listed in the instructions and additional documentation are observed, the measuring device may be used for the following measurements only:

- Measured process variables: level
- Calculable process variables: volume or mass in any shape of vessel (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- Use the measuring device only for media to which the process-wetted materials have an adequate level of resistance.
- Observe the limit values in the "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Clarification of borderline cases:

 For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies contained therein (e.g. display module, main electronics module and I/O electronics module) may rise up to 80 $^{\circ}$ C (176 $^{\circ}$ F). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► In the event of high medium temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

When working on and with the device:

• Wear the required protective equipment according to federal or national regulations.

With separable probe rods, medium may penetrate the joints between the individual parts of the rod. This medium may escape when the joints are loosened. This can cause injuries in the case of dangerous (e.g., aggressive or toxic) media.

When loosening the joints between the individual parts of the probe rod, wear appropriate protective equipment according to the medium.

2.4 Operational safety

Risk of injury!

- Operate the device only if it is in proper technical condition, free from errors and faults.
- The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- Carry out repairs on the device only if they are expressly permitted.
- Observe federal/national regulations pertaining to the repair of an electrical device.
- Use only original spare parts and accessories from the manufacturer.

Hazardous area

To eliminate danger to persons or the installation when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- Check the nameplate to verify whether the ordered device can be put to its intended use in the hazardous area.
- Observe the specifications in the separate supplementary documentation, which is an integral part of this manual.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets the general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 CE mark

The measuring system meets the legal requirements of the applicable EU directives. These are listed in the corresponding EU Declaration of Conformity together with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity


The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity along with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the EAC mark.

3 **Product description**

3.1 Product design


3.1.1 Levelflex FMP53



I Design of the Levelflex

- 1 Electronics housing
- 2 Process connection
- 3 Rod probe

3.1.2 Electronics housing



- ☑ 2 Design of the electronics housing
- 1 Electronics compartment cover
- 2 Display module
- *3 Main electronics module*
- 4 Cable glands (1 or 2, depending on instrument version)
- 5 Nameplate
- 6 I/O electronics module
- 7 Terminals (pluggable spring terminals)
- 8 Connection compartment cover
- 9 Grounding terminal

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Check the following during incoming acceptance:

- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): are the Safety Instructions (XA) provided?


If one of these conditions is not met, please contact your Endress+Hauser sales office.

4.2 Product identification

The following options are available for the identification of the measuring device: • Nameplate specifications

- Order code with breakdown of the device features on the delivery note
- Enter the serial number from the nameplate in W@M Device Viewer (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial number on the nameplate into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information about the measuring device is displayed.

4.2.1 Nameplate



- Nameplate of the Levelflex; engineering unit: mm (in)
- 1 Device name
- 2 Manufacturer address
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference length
- 8 Certificate symbol
- 9 Certificate- and approval-related data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication protocol): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Materials in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the cable gland thread
- 24 Probe length
- 25 Signal outputs
- 26 Supply voltage



Up to 33 characters of the extended order code are indicated on the nameplate. If the extended order code contains additional characters, these cannot be displayed. However, the complete extended order code can also be displayed via the device operating menu: **Extended order code 1 to 3** parameter

5 Storage, transport

5.1 Storage temperature

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use original packaging.


5.2 Transporting the product to the measuring point

WARNING

Housing or rod may become damaged or pull off.

Danger of injury!


- Transport the measuring device to the measuring point in its original packaging or by the process connection.
- Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or probe. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.
- ► Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs) (IEC 61010).



6 Mounting

6.1 Mounting requirements

6.1.1 Suitable mounting position



4 Installation conditions for Levelflex

Spacing requirements when mounting

- Distance (A) between the vessel wall and rod probes:
 - For smooth metallic walls: > 50 mm (2 in)
 - For plastic walls: > 300 mm (12 in) to metallic parts outside the vessel
- Distance (B) between rod probes and internal fittings (4): > 300 mm (12 in)
- When using more than one Levelflex:
 - Minimum distance between the sensor axes: 100 mm (3.94 in)
- Distance (C) from the end of the probe to the bottom of the vessel: > 10 mm (0.4 in)


Additional conditions

- When mounting outdoors, a weather protection cover (1) can be used to protect the device against extreme weather conditions.
- Do not mount the probe in the filling curtain (2).
- When the housing is mounted in a recess (e.g. in a concrete ceiling), observe a minimum distance of 100 mm (4 in) between the cover of the connection compartment/electronics compartment and the wall. Otherwise the connection compartment/electronics compartment will not be accessible after installation.

6.1.2 Mounting under confined conditions


Mounting with remote probe

The device version with a remote probe is suitable for applications with restricted mounting space (product structure: probe design). In this case, the electronics housing is mounted at a separate position from the probe.



- The connecting cable is connected to the probe upon delivery.
 - Length: 3 m (9 ft) or 6 m (18 ft)
 - Minimum bending radius: 50 mm (2 inch)
- The mounting bracket for the electronics housing is included in the delivery with this version. Mounting options:
 - Wall mounting
 - Mounting on DN32 to DN50 (1-1/4 to 2 inch) post or pipe
- The probe with the connection cable and the electronics are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

Separable probes



The use of separable rod probes (\emptyset 8 mm) is advisable in confined mounting conditions (limited distance to the ceiling).

- Max. probe length 6 m (19.68 ft)
- Max. lateral loading capacity 10 Nm
- Probes can be separated several times, with the individual parts having the following lengths:
 - 500 mm (20 in)
 - 1000 mm (40 in)
- The connection points are sealed gap-free by an O-ring.

To avoid damage to the surface of the probe: use fitting pliers with a plastic surface to mount the probe rod.

6.1.3 Notes on the mechanical load of the probe

Lateral loading capacity (flexural strength) of rod probes

FMP53

Rod 8mm (0.31") 316L 10 Nm **Rod 8mm (0.31") 316L separable** 10 Nm

Lateral load (bending moment) from flow conditions

The formula for calculating the bending moment M acting on the probe:

 $M = c_{w} \times \rho/2 \times v^{2} \times d \times L \times (L_{N} - 0.5 \times L)$

With:

c_w: coefficient of friction

 ρ [kg/m³]: density of the medium

v [m/s]: flow velocity of the medium, perpendicular to the probe rod


d [m]: diameter of the probe rod


L [m]: level

LN [m]: probe length


Sample calculation

Coefficient of friction c_w 0.9 (assuming turbulent flow - high Reynolds number)Density ρ [kg/m³]1000 (e.g. water)Probe diameter d [m]0.008L = L_N(unfavorable conditions)





6.1.4 Special installation situations



Tanks with spray ball for probe cleaning


Mounting close to vessel wall

Mounting the probe close to the vessel wall improves the cleaning effect when a spray ball is used. The cleaning jet is directed onto the probe via the vessel wall. As a result, the probe is also cleaned in places the spray ball jet would normally not reach. You only require one spray ball for this probe arrangement.

Mounting in the center of the vessel

If the probe is mounted in the center of the vessel, the use of a second spray ball may be necessary. These balls should then be mounted to the left and right of the probe.


Mounting at an angle



- For mechanical reasons, the probe should be installed as vertically as possible.
- If the probe is installed at an angle, the length of the probe must be reduced depending on the angle of installation.

 - α 5 °: LN_{max.} 4 m (13.1 ft) α 10 °: LN_{max.} 2 m (6.6 ft) α 30 °: LN_{max.} 1 m (3.3 ft)

Non-metal vessels




- 1 Non-metal vessel
- 2 Metal sheet or metal flange

To ensure good measurement results when mounting on non-metal vessels, at the process connection mount a metal sheet with a diameter of at least 200 mm (8 in) at a right angle to the probe.

Plastic and glass vessels: Mounting the probe on the outside wall

In the case of plastic and glass vessels, the probe can also be mounted on the outside wall under certain conditions.



- 1 Plastic or glass vessel
- 2 Metal plate with screw-in sleeve
- 3 No space between vessel wall and probe!

Requirements

- Dielectric constant of the medium: $\epsilon_r > 7$.
- Non-conductive vessel wall.
- Maximum wall thickness (a):
 - Plastic: < 15 mm (0.6 in)
 - Glass: < 10 mm (0.4 in)
- No metal reinforcements on the vessel.

Note the following when mounting the device:

- Mount the probe directly on the vessel wall without any space between the wall and probe.
- To prevent any influence on the measurement, fit a plastic half pipe with a diameter of at least 200 mm (8 in), or a similar protective unit, on the probe.
- For vessel diameters less than 300 mm (12 in):
- On the opposite side of the vessel, fit a grounding plate that is conductively connected to the process connection and covers around half of the vessel's circumference.
- For vessel diameters of 300 mm (12 in) and higher: At the process connection, fit a metal plate with a diameter of at least 200 mm (8 in) at a right angle to the probe (see above).

Adjustment when mounting on the vessel exterior

When the probe is mounted on the outside of the vessel wall, the speed of propagation of the signal is reduced. There are two ways to compensate for this.

Compensation via gas phase compensation factor

The effect of the dielectric wall is comparable to the effect of a dielectric gas phase and can therefore be corrected in the same way. The correction factor is calculated as the quotient of the actual probe length LN and the probe length measured when the vessel is empty.



The device determines the position of the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.

1. Parameter Expert \rightarrow Sensor \rightarrow Gas phase compensation \rightarrow GPC mode

└ Select the **Const. GPC factor** option.

2. Parameter Expert → Sensor → Gas phase compensation → Const. GPC factor
 Quotient: Enter "(actual probe length)/(measured probe length)".

Compensation via the calibration parameters


If it is necessary to actually compensate for a gas phase, the gas phase compensation function is not available for the correction of external mounting. The calibration parameters (**Empty calibration** and **Full calibration**) must be adjusted in this case. Furthermore, a value that is greater than the actual probe length must be entered in the **Present probe length** parameter. In all three cases, the correction factor is the quotient of the probe length measured when the vessel is empty and the actual probe LN.

The device searches for the probe end echo in the differential curve. Therefore, the value of the measured probe length depends on the mapping curve. In order to obtain a more accurate value, it is advisable to determine the measured probe length manually using the envelope curve display in FieldCare.

- **1.** Parameter Setup \rightarrow Empty calibration
 - └→ Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- 2. Parameter Setup \rightarrow Full calibration
 - └ Increase the parameter value by the factor "(measured probe length)/(actual probe length)".
- Parameter Setup → Advanced setup → Probe settings → Probe length correction
 → Confirm probe length
 - ← Select the **Manual input** option.
- Parameter Setup → Advanced setup → Probe settings → Probe length correction
 → Present probe length
 - └ Enter the measured probe length.

Vessel with thermal insulation

If process temperatures are high, the device must be included in normal vessel insulation (1) in order to prevent the electronics heating up as a result of thermal radiation or convection. The insulation may not go beyond the points labeled "MAX" in the drawings.



- ☑ 5 Hygienic process connections
- 1 Vessel insulation
- 2 Compact device
- *3 Compact device, detachable*
- 4 Sensor, remote

6.2 Mounting the measuring device

6.2.1 Tool list



- To shorten rope probes: use a saw or bolt cutters
- To shorten rod or coax probes: use a saw
- For flanges and other process connections: use an appropriate mounting tool

6.2.2 Mounting the "Sensor, remote" version

This section only applies for devices with the version "Probe design" = "Sensor, remote" (feature 600, version MB or MC).

The following is included in the delivery with the version "Probe design" = "Remote":

- The probe with process connection and connecting cable (3 m (9 ft) or 6 m (18 ft))
- The electronics housing
- The mounting bracket for mounting the electronics housing on a wall or post

The connecting cable is connected to the probe upon delivery.


The probe with the connection cable and the electronics are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

Mechanical stress can damage the plug of the connection cable or cause it to become loose.

- Mount the probe and the electronics housing securely before connecting the connecting cable.
- ► Lay the connecting cable in such a way that it is not exposed to mechanical stress. Minimum bending radius: 50 mm (2 in).
- ► Torque of the union nut at the plug on the electronics side: 6 Nm
- ► Torque of the union nut at the plug on the sensor side: 20 Nm

In the event of strong vibrations, a locking compound, e.g. Loctite 243, can also be used on the plug on the electronics side.


Mounting the electronics housing



- 6 Mounting the electronics housing with the mounting bracket. Unit of measurement mm (in)
- A Wall mounting
- B Post mounting


Connecting the connecting cable





6.2.3 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned:



- **1.** Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- **3.** Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).


6.2.4 Turning the display

Opening the cover




- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the electronics compartment cover and check the cover seal; replace it if necessary.

Turning the display module



- **1.** Pull out the display module with a gentle rotational movement.
- 2. Turn the display module to the desired position: Max. $8 \times 45^{\circ}$ in each direction.
- **3.** Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

Closing the cover of the electronics compartment



1. Screw down the cover of the electronics compartment.

2. Turn the securing clamp 90° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the electronics compartment cover with 2.5 Nm.

6.3 Post-installation check

□ Is the device undamaged (visual inspection)?

- □ Does the device comply with the measuring point specifications?
- Process temperature
- Process pressure
- Ambient temperature range
- Measuring range

□ Are the measuring point identification and labeling correct (visual inspection)?

 $\hfill\square$ Is the device adequately protected against precipitation and direct sunlight?

 $\Box Is$ the device adequately protected against impact?

□Are all mounting and safety screws securely tightened?


 \Box Is the device properly secured?

7 Electrical connection

7.1 Connecting requirements

7.1.1 Terminal assignment

Terminal assignment, 4-wire: 4 to 20 mA HART (90 to 253 V_{AC})



 \blacksquare 7 Terminal assignment, 4-wire: 4 to 20 mAHART (90 to 253 V_{AC})


- 1 Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- 3 Terminal for cable shield

ACAUTION

To ensure electrical safety:


- ► Do not disconnect the protective ground connection.
- Disconnect the device from the supply voltage before disconnecting the protective ground.
- Connect protective ground to the inner ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the outer ground terminal.
- In order to ensure electromagnetic compatibility (EMC): do **not** ground the device exclusively via the protective ground conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus



- 8 Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus
- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection, PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, without integrated overvoltage protection
- 2 Connection, switch output (open collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection, switch output (open collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection, PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable shield


Block diagram PROFIBUS PA / FOUNDATION Fieldbus




🖲 9 Block diagram PROFIBUS PA / FOUNDATION Fieldbus

- 1 Cable screen; observe cable specification
- 2 Connection PROFIBUS PA / FOUNDATION Fieldbus
- 3 Measuring device
- 4 Switch output (open collector)

Connection examples for the switch output



☑ 10 Connection of a relay



🖻 11 Connection to a digital input

- 1 Pull-up resistor
- 2 Digital input

For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or pull-up resistor) of $< 1000 \Omega$.

7.1.2 Cable specification

- Devices without integrated overvoltage protection
 Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection
 Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_U \ge 60 \degree C$ (140 $\degree F$): use cable for temperature $T_U + 20 \text{ K}$.


FOUNDATION Fieldbus

Endress+Hauser recommends using twisted, shielded two-wire cables.

For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).

7.1.3 Device plug

In the case of the device versions with a plug, the housing does not need to be opened to connect the signal cable.



🖻 12 Pin assignment of 7/8" plug

1 Signal -

-

- 2 Signal +
- 3 Not assigned
- 4 Shielding

7.1.4 Supply voltage

PROFIBUS PA, FOUNDATION Fieldbus

"Power supply; output" ¹⁾	"Approval" ²⁾	Terminal voltage
E: 2-wire; FOUNDATION Fieldbus, switch output G: 2-wire; PROFIBUS PA, switch output	 Non-hazardous Ex nA Ex nA[ia] Ex ic Ex ic[ia] Ex d[ia] / XP Ex ta / DIP CSA GP 	9 to 32 V ³⁾
	 Ex ia / IS Ex ia + Ex d[ia] / IS + XP 	9 to 30 V ³⁾

1) Feature 020 in the product structure

2) Feature 010 in the product structure

3) Input voltages up to 35 V do not destroy the device.

Polarity-dependent	No
FISCO/FNICO compliant according to IEC 60079-27	Yes

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse $8/20 \ \mu$ s), an overvoltage protection module has to be installed.

Integrated overvoltage protection module


An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	2 × 0.5 Ω max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 µs)	10 kA	

External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.



- HAW562: TI01012K
- HAW569: TI01013K

7.2 Connecting the device

WARNING


Explosion Hazard!

- Observe applicable national standards.
- Comply with the specifications in the Safety Instructions (XA).
- Use specified cable glands only.
- Check to ensure that the power supply matches the information on the nameplate.
- ► Switch off the power supply before connecting the device.
- Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:


- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.

7.2.1 Opening cover



- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the connection compartment cover and check the cover seal; replace it if necessary.


7.2.2 Connecting



🕑 13 Engineering unit: mm (in)

- **1.** Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- **3.** Strip the cable ends 10 mm (0.4 in). In the case of stranded cables, also fit wire end ferrules.
- 4. Firmly tighten the cable glands.


5. Connect the cable according to the terminal assignment.



6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

The electrical connection of device versions without an integrated overvoltage protection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.





^{■ 14} Engineering unit: mm (in)

To remove the cable from the terminal again:

- Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. Simultaneously pull the cable end out of the terminal.

7.2.4 Closing the cover of the connection compartment





2. Turn the securing clamp 90° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the connection compartment cover with 2.5 Nm.

7.3 Post-connection check

 \Box Is the device or cable undamaged (visual inspection)?

 $\hfill\square$ Do the cables used comply with the requirements?

□ Do the mounted cables have adequate strain relief?

□Are all the cable glands installed, firmly tightened and leak-tight?

Does the supply voltage match the specifications on the nameplate?

 \Box Is the terminal assignment correct?

□If necessary, has a protective ground connection been established?

 \Box If supply voltage is present, is the device ready for operation and do values appear on the display module?

 $\hfill\square$ Are all the housing covers installed and tightened?


 \Box Is the securing clamp firmly tightened?

8 Operation methods

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"
	A0036312	A0036313
Display elements	4-line display	4-line display white background lighting; switches to red in event of device error
	Format for displaying measured variables and st	atus variables can be individually configured
	Permitted ambient temperature for the display: The readability of the display may be impaired a range.	
Operating elements	local operation with 3 push buttons ($\textcircled{\pm}$, \boxdot , \textcircled{E})	external operation via touch control; 3 optical keys: $\textcircled{\bullet}$, \boxdot , \textcircled{E}
	Operating elements also accessible in various ha	azardous areas
Additional functionality	Data backup function The device configuration can be saved in the display module.	
	Data comparison function The device configuration saved in the display module can be compared to the current device configuration.	
	Data transfer function The transmitter configuration can be transmitte	d to another device using the display module.




8.1.2 Operation with remote display and operating module FHX50

■ 15 FHX50 operating options

- 1 Display and operating module SD03, optical keys; can be operated through the glass of the cover
- 2 Display and operating module SD02, push buttons; cover must be removed

8.1.3 Remote operation

Via FOUNDATION Fieldbus




16 FOUNDATION Fieldbus system architecture with associated components

- 1 FFblue Bluetooth modem
- 2 Field Xpert SFX350/SFX370
- 3 DeviceCare/FieldCare
- 4 NI-FF interface card

IN	Industrial network
FF-HSE	High Speed Ethernet
FF-H1	FOUNDATION Fieldbus-H1
LD	Linking Device FF-HSE/FF-H1
PS	Bus Power Supply
SB	Safety Barrier
BT	Bus Terminator

Via service interface (CDI)



- Computer with FieldCare/DeviceCare operating tool 1
- 2 3 Commubox FXA291
- Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)

8.2 Structure and function of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the local display
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	Once values have been set for these parameters, the measurement should
	Advanced setup	 generally be completely configured. Contains additional submenus and parameters: For more customized configuration of the measurement (adaptation to special measuring conditions). For converting the measured value (scaling, linearization). For scaling the output signal.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat ⁴⁾	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert ⁵⁾ Contains all the parameters of the device (including those that are already contained in one of the other menus). This menu is	System	Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication.
organized according to the function blocks of the device.	Sensor	Contains all parameters needed to configure the measurement.
The parameters of the Expert menu are described in: GP01015F (FOUNDATION Fieldbus)	Output	Contains all parameters needed to configure the switch output (PFS).

8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

1) If you are operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup \rightarrow Advanced setup \rightarrow Display"

2)

Only if operating via an FDT/DTM system Only available if operating via the local display 3)

4)

Only available if operating via DeviceCare or FieldCare When you call up the "Expert" menu, you are always asked for an access code. If a customer-specific access 5) code has not been defined, "0000" must be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access (Verweisziel existiert nicht, aber @y.link.required='true').

Access authorization	to	parameters
----------------------	----	------------

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	
Maintenance	V	V	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.

The user role with which the user is currently logged on is indicated by the Access **H** status display parameter (for display operation) or Access status tooling parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the numeric code in the **Confirm access code** parameter to confirm it.

Define access code via operating tool (e.g. FieldCare)

- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - └ Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. If the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after 60 s.

- If write access is activated via an access code, it can only be deactivated again via this access code $\rightarrow \cong 47$.
 - In the "Description of Device Parameters" documents, each write-protected parameter is identified with the 🖻-symbol.

Disabling write protection via access code

If the \square symbol appears in front of a parameter on the local display, the parameter is write-protected by a device-specific access code and its value cannot currently be changed via the local display $\rightarrow \square 46$.

The locking of the write access via local operation can be disabled by entering the devicespecific access code.

1. After you press E, the input prompt for the access code appears.

2. Enter the access code.

→ The @-symbol in front of the parameters disappears; all previously writeprotected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code

2. Enter **0000**.

- 3. Repeat **0000** in the **Confirm access code** parameter to confirm.
 - └ The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- **1.** Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - └ The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch


Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display" parameter**.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):


- Via local display
- Via FOUNDATION Fieldbus



- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- **3.** Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.



- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - └ If hardware write protection is enabled, the Hardware locked option is displayed in the Locking status parameter. In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter. On the local display, the 🖻 symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.

6. Reverse the removal procedure to reassemble the transmitter.

Enabling and disabling the keypad lock

Access to the entire operating menu via local operation can be locked via the keypad lock. When access is locked, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via a context menu.

Switching on the keypad lock

SD03 display module only

- The keypad lock is switched on automatically:
- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

- Press E for at least 2 seconds.
- └ A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - └ The keypad lock is switched on.

If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press E for at least 2 seconds.

- 2. In the context menu select the **Keylock off** option.
 - └ The keypad lock is switched off.


Bluetooth[®] wireless technology

Signal transmission via Bluetooth[®] wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*[®] wireless technology without the SmartBlue app
- Only one point-to-point connection between **one** sensor and **one** smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display



■ 17 Display format on the display and operating module

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (bar graph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Parameter display (here: parameter with picklist)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Picklist; \blacksquare marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

Display symbols for the submenus

Symbol	Meaning
A001836	 Display/operat. Is displayed: In the main menu next to the "Display/operat." selection In the header on the left in the "Display/operat." menu
A 001836	SetupIs displayed:In the main menu next to the "Setup" selectionIn the header on the left in the "Setup" menu
A001836	Expert Is displayed: In the main menu next to the "Expert" selection In the header on the left in the "Expert" menu
Č	 Diagnostics Is displayed: In the main menu next to the "Diagnostics" selection In the header on the left in the "Diagnostics" menu

Status signals

Symbol	Meaning
F 40032902	"Failure" A device error has occurred. The measured value is no longer valid.
C	"Function check" The device is in the service mode (e.g. during a simulation).
S A0032904	 "Out of specification" The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range)
M 40032905	"Maintenance required" Maintenance is required. The measured value is still valid.

Display symbols for locking status


Symbol	Meaning
A0013148	Read-only parameter The parameter shown is only for display purposes and cannot be edited.
6	Device locked
A0013150	In front of a parameter name: The device is locked via software and/or hardware.In the header of the measured value screen: The device is locked via hardware.

Measured value symbols


Symbol	Meaning
Measured values	
 ~~ 	Level
A0032892	
⊢►	Distance
A0032893	
G	Current output
A0032908	
	Measured current
A0032894	
\bigcirc	Terminal voltage
A0032895	
	Electronics or sensor temperature
A0032896	
Measuring channels	
$\bigcirc \textcircled{1}$	Measuring channel 1
A0032897	
0	Measuring channel 2
A0032898	
Status of the measured	value
	"Alarm" status
A0018361	The measurement is interrupted. The output assumes the defined alarm condition. A diagnostic message is generated.
\wedge	"Warning" status
A0018360	The device continues to measure. A diagnostic message is generated.

Кеу	Meaning
	Minus key
—	<i>In a menu, submenu</i> Moves the selection bar upwards in a picklist.
A0018330	In the text and numeric editor In the input mask, moves the selection bar to the left (backwards).
	Plus key
+	<i>In a menu, submenu</i> Moves the selection bar downwards in a picklist.
A0018329	<i>In the text and numeric editor</i> In the input mask, moves the selection bar to the right (forwards).
	Enter key
	For measured value displayPressing the key briefly opens the operating menu.Pressing the key for 2 s opens the context menu.
E A0018328	 In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter.
	 In the text and numeric editor Pressing the key briefly: Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
	Escape key combination (press keys simultaneously)
-+++ A0032909	 In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the measured value display ("home position").
	<i>In the text and numeric editor</i> Closes the text or numeric editor without applying changes.
– + E	Minus/Enter key combination (press and hold down the keys simultaneously)
A0032910	Reduces the contrast (brighter setting).
++E 	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).

8.3.2 Operating elements



8.3.3 Entering numbers and text



Input mask

The following input and operating symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
0	Selection of numbers from 0 to 9.
9	
A0016619	Inserts decimal separator at the cursor position.
	Inserts minus sign at the cursor position.
	Confirms selection.
A0016621	Moves the input position one position to the left.
A0013986	Exits the input without applying the changes.
	Clears all entered characters.

Text editor

Symbol	Meaning
(ABC_) (XYZ) A0013997	Selection of letters from A to Z

(Aa1@)	Toggle • Between upper-case and lower-case letters • For entering numbers • For entering special characters
	Confirms selection.
	Switches to the selection of the correction tools.
X 	Exits the input without applying the changes.
	Clears all entered characters.

Text correction under ₩C+→

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
-	Moves the input position one position to the left.
A0018326	
×	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu

Using the context menu, the user can call up the following menus quickly and directly from the operational display:


- Setup
- Conf. backup disp.
- Envelope curve
- Keylock on

Calling up and closing the context menu

The user is in the operational display.

1. Press E for 2 s.

└ The context menu opens.



2. Press - + + simultaneously.

└ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press \pm to navigate to the desired menu.

3. Press 🗉 to confirm the selection.

└ The selected menu opens.

8.3.5 Envelope curve display on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be shown on the display and operating module:



9 Integration into a FOUNDATION Fieldbus network

9.1 Device Description (DD)

You require the following to configure a device and integrate it into an FF network:

- An FF configuration program
- The Cff file (Common File Format: *.cff)
- The device description (DD) in one of the following formats
 - Device Description format 4 : *sym, *ffo
 - Device Description format 5 : *sy5, *ff5

Information on the device-specific DD

Manufacturer ID	452B48hex
Device Type	100Fhex
Device Revision	05hex
DD Revision	Information and files at:
CFF Revision	www.endress.comwww.fieldcommgroup.org

9.2 Integration into the FOUNDATION Fieldbus network

- For more in-depth information on integrating the device into the FF system, see the description for the configuration software used.
 - When integrating the field devices into the FF system, make sure you are using the right files. You can read out the required version by means of the Device Revision/ DEV_REV and DD Revision/ DD_REV parameters in the Resource Block.


The device is integrated into the FF network as follows:


- 1. Start the FF configuration program.
- 2. Download the Cff and device description files (*.ffo, *.sym (for format 4) *ff5, *sy5 (for format 5) to the system.
- 3. Configure the interface.
- 4. Configure the device for the measuring task and for the FF system.

9.3 Device identification and addressing

FOUNDATION Fieldbus identifies the device using its ID code (Device ID) and automatically assigns it a suitable field address. The identity code cannot be changed. The device appears in the network display once you have started the FF configuration program and integrated the device into the network. The blocks available are displayed under the device name.

If the device description has not yet been loaded, the blocks report "Unknown" or "(UNK)".





- 1 Device name
- 2 Serial number

9.4 Block model

9.4.1 Blocks of the device software

The device has the following blocks:

- Resource Block (device block)
- Transducer Blocks
 - Setup Transducer Block (TRDSUP)
 - Advanced Setup Transducer Block (TRDASUP)
 - Display Transducer Block (TRDDISP)
 - Diagnostic Transducer Block (TRDDIAG)
 - Expert Configuration Transducer Block (TRDEXP)
 - Expert Information Transducer Block (TRDEXPIN)
 - Service Sensor Transducer Block (TRDSRVSB)
 - Service Information Transducer Block (TRDSRVIF)
 - Data Transfer Transducer Block (TRDHROM)
- Function Blocks
 - 2 Analog Input Blocks (AI)
 - 1 Discrete Input Block (DI)
 - 1 PID Block (PID)
 - 1 Arithmetic Block (AR)
 - 1 Signal Characterizer Block (SC)
 - 1 Input Selector Block (IS)
 - 1 Integrator Block (IT)
 - 1 Analog Alarm Block (AAL)

In addition to the pre-instantiated blocks already mentioned, the following blocks can also be instantiated:

- 5 Analog Input Blocks (AI)
- 2 Discrete Input Blocks (DI)
- 3 PID Blocks (PID)
- 3 Arithemetic Blocks (AR)
- 2 Signal Characterizer Blocks (SC)
- 5 Input Selector Blocks (IS)
- 3 Integrator Blocks (IT)
- 2 Analog Alarm Blocks (AAL)


Up to 20 blocks can be instantiated in the device altogether, including the blocks already instantiated. For instantiating blocks, see the appropriate Operating Instructions of the configuration program used.

-

Endress+Hauser Guideline BA00062S.

The quideline provides an overview of the standard function blocks that are described in FOUNDATION Fieldbus Specifications FF 890 - 894. It is designed to help operators use the blocks implemented in the Endress+Hauser field devices.

9.4.2 Block configuration when device is delivered



🛃 19 Block configuration when device is delivered

S Sensor

- PV Primary value: Level linearized
- SV Secondary value: Distance

9.5 Assignment of the measured values (CHANNEL) in an AI Block

The input value of an Analog Input Block is defined by the **CHANNEL** parameter.

Channel	Measured value
0	Uninitialized
89	Measured capacitance
144	EOP shift

Channel	Measured value
145	Interface distance
172	Calculated DC value
211	Terminal voltage
212	Sensor debug
32785	Absolute EOP amplitude
32786	Absolute echo amplitude
32787	Absolute interface amplitude
32856	Distance
32885	Elektronic temperature
32938	Interface linearized
32949	Level linearized
33044	Relative echo amplitude
33045	Relative interface amplitude
33070	Noise of signal
33107	Upper interface thickness

9.6 Index tables of Endress+Hauser parameters

The following tables list the manufacturer-specific device parameters for the Resource Blocks. For the FOUNDATION Fieldbus parameters, see the document BA062S "Guidline -FOUNDATION Fieldbus Function Blocks", which can be downloaded from www.endress.com.

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
confirm_distance	Confirm distance	82	ENUM16	2	Static	х	OOS	→ 🖺 130
filtered_dist_val	Distance	76	FLOAT	4	Dynamic			→ 🖺 129
map_end_x	Present mapping	84	FLOAT	4	Dynamic			→ 🖺 131
mapping_end_point	Mapping end point	83	FLOAT	4	Static	х	AUTO	→ 🖺 131
record_map	Record map	86	ENUM16	2	Static	х	OOS	→ 🖺 132
signal_quality	Signal quality	81	ENUM16	2	Dynamic			→ 🖺 130
medium_group	Medium group	55	ENUM16	2	Static	х	OOS	→ 🖺 127
tank_type	Tank type	52	ENUM16	2	Static	х	OOS	→ 🖺 126
tube_diameter	Tube diameter	53	FLOAT	4	Static	х	OOS	→ 🖺 126
empty_calibration	Empty calibration	56	FLOAT	4	Static	х	OOS	→ 🖺 127
full_calibration	Full calibration	57	FLOAT	4	Static	х	OOS	→ 🖺 128
distance_unit	Distance unit	51	ENUM16	2	Static	х	OOS	→ 🖺 126
level_unit	Level unit	58	ENUM16	2	Static	х	OOS	→ 🖺 141
output_unit_after_lineariza tion	Unit after linearization	62	ENUM16	2	Static			→ 🖺 147
level_linearized	Level linearized	64	FLOAT	4	Dynamic			→ 🖺 149
present_probe_length	Present probe length	87	FLOAT	4	Dynamic	х	AUTO	→ 🖺 156
level	Level	60	FLOAT	4	Dynamic			→ 🖺 128

9.6.1 Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
decimal_places_menu_ro	Decimal places	93	ENUM16	2	Static	х	AUTO	→ 🗎 167
locking_status	Locking status	96	BIT_ENU M16	2	Dynamic			→ 🖺 136
medium_type_ro	Medium type	92	ENUM16	2	Static	х	OOS	→ 🖺 138

9.6.2 Advanced Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
blocking_distance	Blocking distance	55	FLOAT	4	Static	x	OOS	→ 🖺 141
medium_type	Medium type	50	ENUM16	2	Static	x	OOS	→ 🖺 138
present_probe_length_ro	Present probe length	80	FLOAT	4	Dynamic	x	AUTO	→ 🖺 156
confirm_probe_length	Confirm probe length	79	ENUM16	2	Static	x	OOS	→ 🖺 157
process_property	Process property	52	ENUM16	2	Static	x	OOS	→ 🖺 139
advanced_process_conditio ns	Advanced process conditions	53	ENUM16	2	Static	x	OOS	→ 🖺 140
medium_property	Medium property	51	ENUM16	2	Static	x	OOS	→ 🖺 138
linearization_type	Linearization type	71	ENUM16	2	Static	x	OOS	→ 🖺 146
activate_table	Activate table	70	ENUM16	2	Static	x	OOS	→ 🖺 152
table_mode	Table mode	69	ENUM16	2	Static	x	OOS	→ 🖺 150
custom_table_sel_level	Level	73	FLOAT	4	Static	x	OOS	→ 🖺 128
custom_table_sel_value	Customer value	74	FLOAT	4	Static	x	OOS	→ 🖺 152
unit_after_linearization	Unit after linearization	63	ENUM16	2	Static	x	OOS	→ 🖺 147
free_text	Free text	64	STRING		Static	x	AUTO	→ 🖺 148
diameter	Diameter	66	FLOAT	4	Static	x	OOS	→ 🖺 149
output_echo_lost	Output echo lost	76	ENUM16	2	Static	x	OOS	→ 🖺 153
intermediate_height	Intermediate height	67	FLOAT	4	Static	x	AUTO	→ 🖺 150
level_correction	Level correction	56	FLOAT	4	Static	x	OOS	→ 🖺 142
level_unit_ro	Level unit	54	ENUM16	2	Static	x	OOS	→ 🖺 141
assign_limit	Assign limit	82	ENUM16	2	Static	x	AUTO	→ 🖺 160
maximum_value	Maximum value	65	FLOAT	4	Static	x	OOS	→ 🖺 149
assign_diag_behavior	Assign diagnostic behavior	83	ENUM16	2	Static	x	AUTO	→ 🖺 160
value_echo_lost	Value echo lost	77	FLOAT	4	Static	x	OOS	→ 🖺 153
ramp_at_echo_lost	Ramp at echo lost	78	FLOAT	4	Static	x	OOS	→ 🖺 154
switch_output_failure_mod e	Failure mode	88	ENUM16	2	Static	x	AUTO	→ 🖺 163
switch_output_function	Switch output function	81	ENUM16	2	Static	x	AUTO	→ 🖺 159
switch_status	Switch status	89	ENUM16	2	Dynamic			→ 🖺 163
switch_off_delay	Switch-off delay	87	FLOAT	4	Static	x	AUTO	→ 🖺 163
switch_off_value	Switch-off value	86	FLOAT	4	Static	x	AUTO	→ 🖺 162
switch_on_delay	Switch-on delay	85	FLOAT	4	Static	x	AUTO	→ 🖺 162
switch_on_value	Switch-on value	84	FLOAT	4	Static	x	AUTO	→ 🖺 161
table_number	Table number	68	UINT8	1	Static	x	OOS	→ 🖺 151
level_semiautomatic	Level	75	FLOAT	4	Dynamic			→ 🖺 152
								·

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
assign_status	Assign status	91	ENUM16	2	Static	х	AUTO	→ 🖺 159
locking_status	Locking status	99	BIT_ENUM16	2	Dynamic			→ 🖺 136
decimal_places_menu	Decimal places menu	93	ENUM16	2	Static	х	AUTO	→ 🖺 169
distance_unit_ro	Distance unit	92	ENUM16	2	Static	х	OOS	→ 🗎 126

9.6.3 Display Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
access_status_display	Access status display	51	ENUM16	2	Static			→ 🖺 136
display_damping	Display damping	65	FLOAT	4	Static	x	AUTO	→ 🖺 168
display_interval	Display interval	64	FLOAT	4	Static	x	AUTO	→ 🖺 168
header	Header	66	ENUM16	2	Static	х	AUTO	→ 🖺 168
format_display	Format display	55	ENUM16	2	Static	x	AUTO	→ 🖺 165
number_format	Number format	69	ENUM16	2	Static	x	AUTO	→ 🖺 169
display_separator	Separator	68	ENUM16	2	Static	x	AUTO	→ 🖺 169
language	Language	54	ENUM16	2	Static	х	AUTO	→ 🖺 165
contrast_display	Contrast display	71	FLOAT	4	Static	x	AUTO	→ 🖺 170
header_text	Header text	67	STRING		Static	x	AUTO	→ 🖺 169
access_code_for_display	Enter access code	52	UINT16	2	Static	x	AUTO	→ 🖺 137
configuration_management	Configuration management	75	ENUM16	2	Static	x	AUTO	→ 🖺 171
decimal_places_1	Decimal places 1	57	ENUM16	2	Static	x	AUTO	→ 🖺 167
decimal_places_2	Decimal places 2	59	ENUM16	2	Static	x	AUTO	→ 🖺 167
decimal_places_3	Decimal places 3	61	ENUM16	2	Static	х	AUTO	→ 🖺 167
decimal_places_4	Decimal places 4	63	ENUM16	2	Static	x	AUTO	→ 🖺 167
last_backup	Last backup	74	STRING		Static	х	AUTO	→ 🖺 171
value_1_display	Value 1 display	56	ENUM16	2	Static	x	AUTO	→ 🖺 167
value_2_display	Value 2 display	58	ENUM16	2	Static	x	AUTO	→ 🖺 167
value_3_display	Value 3 display	60	ENUM16	2	Static	x	AUTO	→ 🖺 167
value_4_display	Value 4 display	62	ENUM16	2	Static	x	AUTO	→ 🖺 167
locking_status_display	Locking status	50	ENUM16	2	Static			→ 🖺 136
define_access_code	Define access code	53	UINT16	2	Static	x	AUTO	→ 🖺 174
comparison_result	Comparison result	76	ENUM16	2	Static	x	AUTO	→ 🖺 172
decimal_places_menu	Decimal places menu	70	ENUM16	2	Static	x	AUTO	→ 🖺 169
operating_time	Operating time	73	STRING		Dynamic			→ 🖺 171
locking_status	Locking status	85	BIT_ENUM16	2	Dynamic			→ 🖺 136

9.6.4 Diagnostic Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
operating_time	Operating time	55	STRING		Dynamic			→ 🗎 171
diagnostics_1	Diagnostics	56	UINT32	4	Static			→ 🗎 179

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
diagnostics_2	Diagnostics 2	58	UINT32	4	Static			→ 🖺 179
diagnostics_3	Diagnostics 3	60	UINT32	4	Static			→ 🖺 179
diagnostics_4	Diagnostics 4	62	UINT32	4	Static			→ 🗎 179
diagnostics_5	Diagnostics 5	64	UINT32	4	Static			→ 🖺 179
operating_time_from_resta rt	Operating time from restart	54	STRING		Dynamic			→ 🖺 178
launch_signal	Launch signal	81	ENUM16	2	Dynamic			→ 🖺 195
start_device_check	Start device check	77	ENUM16	2	Static	x	AUTO	→ 🖺 194
level_signal	Level signal	80	ENUM16	2	Dynamic			→ 🖺 195
simulation_device_alarm	Simulation device alarm	75	ENUM16	2	Static	x	OOS	→ 🖺 193
filter_options	Filter options	66	ENUM8	1	Static	x	AUTO	→ 🖺 180
previous_diagnostics	Previous diagnostics	52	UINT32	4	Static			→ 🖺 177
actual_diagnostics	Actual diagnostics	50	UINT32	4	Static			→ 🖺 177
assign_sim_meas	Assign measurement variable	71	ENUM16	2	Static	х	OOS	→ 🖺 192
sim_value_process_variabl e	Process variable value	72	FLOAT	4	Static	х	OOS	→ 🖺 192
switch_output_simulation	Switch output simulation	73	ENUM16	2	Static	x	OOS	→ 🖺 192
sim_switch_status	Switch status	74	ENUM16	2	Static	x	OOS	→ 🖺 193
result_device_check	Result device check	78	ENUM16	2	Dynamic			→ 🖺 194
last_check_time	Last check time	79	STRING		Dynamic			→ 🖺 194
linearization_type	Linearization type	84	ENUM16	2	Static	x	OOS	→ 🖺 146
unit_after_linearization_ro	Unit after linearization	85	STRING		Static	x	AUTO	→ 🖺 147
decimal_places_menu	Decimal places menu	88	ENUM16	2	Static	x	AUTO	→ 🖺 169
level_unit_ro	Level unit	90	ENUM16	2	Static	x	OOS	→ 🖺 141
assign_channel_1	Assign channel 1	92	ENUM16	2	Static	x	AUTO	→ 🖺 186
assign_channel_2	Assign channel 2	93	ENUM16	2	Static	x	AUTO	→ 🖺 186
assign_channel_3	Assign channel 3	94	ENUM16	2	Static	x	AUTO	→ 🖺 186
assign_channel_4	Assign channel 4	95	ENUM16	2	Static	x	AUTO	→ 🖺 186
clear_logging_data	Clear logging data	97	ENUM16	2	Static	x	AUTO	→ 🖺 187
logging_interval	Logging interval	96	FLOAT	4	Static	x	AUTO	→ 🖺 187
display_filter_options	Filter options	99	ENUM8	1	Static	x	AUTO	→ 🖺 180
locking_status	Locking status	108	BIT_ENUM16	2	Dynamic			→ 🖺 136
distance_unit_ro	Distance unit	89	ENUM16	2	Static	x	OOS	→ 🖺 126

9.6.5 Expert Configuration Transducer Block

The parameters of the **Expert Configuration Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
acknowledge_alarm	Acknowledge alarm	81	ENUM16	2	Static	х	AUTO
integration_time	Integration time	67	FLOAT	4	Static	х	OOS
result_self_check	Result self check	77	ENUM16	2	Dynamic		

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
start_self_check	Start self check	76	ENUM16	2	Static	x	AUTO
broken_probe_detection	Broken probe detection	75	ENUM16	2	Static	x	AUTO
gpc_mode	GPC mode	68	ENUM16	2	Static	х	OOS
reference_echo_threshold	Reference echo threshold	73	FLOAT	4	Static	x	OOS
const_gpc_factor	Const. GPC factor	74	FLOAT	4	Static	x	OOS
build_up_ratio	Build-up ratio	90	FLOAT	4	Dynamic		
build_up_threshold	Build-up thres.	91	FLOAT	4	Static	х	AUTO
delay_time_echo_lost	Delay time echo lost	78	FLOAT	4	Static	х	AUTO
empty_capacity	Empty capacity	92	FLOAT	4	Static	х	AUTO
external_pressure_selector	External pressure selector	69	ENUM16	2	Static	х	OOS
measured_capacity	Measured capacitance	89	FLOAT	4	Dynamic		
gas_phase_compens_factor	Gas phase compensation factor	70	FLOT	4	Static	х	OOS
in_safety_distance	In safety distance	80	ENUM16	2	Static	х	OOS
ratio_amplitude_interface_level	Ratio amplitude interface/level	86	FLOAT	4	Static	x	OOS
interface_criterion	Interface criterion	87	FLOAT	4	Dynamic		
control_measurement	Measurement	106	ENUM16	2	Static	х	AUTO
control_measurement	Control measurement	105	ENUM16	2	Static	х	AUTO
filter_dead_time	Dead time	66	FLOAT	4	Static	x	OOS
present_reference_distance	Present reference distance	72	FLOAT	4	Dynamic		
history_reset	History reset	83	ENUM16	2	Static	x	OOS
safety_distance	Safety distance	79	FLOAT	4	Static	х	OOS
history_learning_control	History learning	85	ENUM16	2	Static	x	AUTO
history_learning_control	History learning control	84	ENUM16	2	Static	x	AUTO
sensor_module	Sensor module	107	ENUM16	2	Static		
evaluation_mode	Evaluation mode	82	ENUM16	2	Static	х	OOS
thin_interface	Thin interface	88	ENUM16	2	Static	х	OOS
calculated_dc_value	Calculated DC value	59	FLOAT	4	Dynamic	х	AUTO
dc_value_expert	DC value	55	FLOAT	4	Static	х	OOS
distance_offset	Distance offset	60	FLOAT	4	Static	х	OOS
level_limit_mode	Level limit mode	62	ENUM16	2	Static	х	OOS
level_high_limit	High limit	63	FLOAT	4	Static	х	OOS
level_low_limit	Low limit	64	FLOAT	4	Static	x	OOS
output_mode	Output mode	65	ENUM16	2	Static	x	OOS
level_external_input_1	Level external input 1	93	ENUM16	2	Static	x	AUTO
level_external_input_2	Level external input 2	96	ENUM16	2	Static	x	AUTO
function_input_1_level	Function Input 1 Level	94	ENUM16	2	Static	x	AUTO
function_input_2_level	Function Input 2 Level	97	ENUM16	2	Static	x	AUTO
fixed_value_inp_1	Fixed value inp.1	95	FLOAT	4	Static	x	AUTO
fixed_value_inp_2	Fixed value inp.2	98	FLOAT	4	Static	x	AUTO
interface_external_input_1	Interface external input 1	99	ENUM16	2	Static	x	OOS
interface_external_input_2	Interface external input 2	102	ENUM16	2	Static	x	OOS
function_input_1_interface	Function input 1 interface	100	ENUM16	2	Static	x	OOS
function_input_2_interface	Function input 2 interface	103	ENUM16	2	Static	x	OOS

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
fixed_value_input_1_interface	Fixed value input 1 interface	101	FLOAT	4	Static	х	OOS
fixed_value_input_2_interface	Fixed value input 2 interface	104	FLOAT	4	Static	х	OOS
distance_unit_ro	Distance unit	53	ENUM16	2	Static	х	OOS
level_unit_ro	Level unit	61	ENUM16	2	Static	х	OOS
operating_mode_ro	Operating mode	54	ENUM16	2	Static	х	OOS
enter_access_code	Enter access code	52	UINT16	2	Static	х	AUTO
locking_status	Locking status	50	BIT_ENUM16	2	Dynamic		
access_status_tooling	Access status tooling	51	ENUM16	2	Static		
reference_distance	Reference distance	71	FLOAT	4	Static	х	OOS
sw_option_active_overview	SW option active overview	110	BIT_ENUM32	4	Static		
decimal_places_menu	Decimal places menu	109	ENUM16	2	Static	х	AUTO
fieldbus_type	Fieldbus Type	111	ENUM8	1	Static		
interface_property_ro	Interface property	108	ENUM16	2	Static	х	OOS
medium_type_ro	Medium type	112	ENUM16	2	Static	х	OOS
eop_level_evaluation_ro	EOP level evaluation	113	ENUM16	2	Static	х	OOS
sensor_type_ro	Sensor type	114	ENUM16	2	Static	х	OOS
calculated_dc_status_en	Status	58	ENUM8	1	Dynamic		

9.6.6 Expert Information Transducer Block

The parameters of the **Expert Information Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
abs_echo_amp_val	Absolute echo amplitude	51	FLOAT	4	Dynamic		
abs_eop_amp_val	Absolute EOP amplitude	55	FLOAT	4	Dynamic		
absolute_interface_amplitude	Absolute interface amplitude	58	FLOAT	4	Dynamic		
application_parameter	Application parameter	74	ENUM16	2	Dynamic		
electronic_temp_value	Electronic temperature	66	FLOAT	4	Dynamic		
eop_shift_value	EOP shift	69	FLOAT	4	Dynamic		
found_echoes	Found echoes	71	ENUM16	2	Dynamic		
max_electr_temp	Max. electronics temperature	73	FLOAT	4	Dynamic	х	AUTO
time_max_electr_temp	Time max. electronics temperature	75	STRING		Dynamic		
measurement_frequency	Measurement frequency	76	FLOAT	4	Dynamic		
min_electr_temp	Min. electronics temperature	77	FLOAT	4	Dynamic	х	AUTO
time_min_electr_temp	Time min. electronics temperature	78	STRING		Dynamic		
rel_echo_amp_val	Relative echo amplitude	53	FLOAT	4	Dynamic		
relative_interface_amplitude	Relative interface amplitude	60	FLOAT	4	Dynamic		
reset_min_max_temp	Reset min./max. temp.	79	ENUM16	2	Static	х	AUTO
noise_signal_val	Noise of signal	63	FLOAT	4	Dynamic		
used_calculation	Used calculation	80	ENUM16	2	Dynamic		
tank_trace_state	Tank trace state	81	ENUM16	2	Dynamic		
max_draining_speed	Max. draining speed	82	FLOAT	4	Dynamic	х	AUTO

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
max_filling_speed	L max. fill speed	83	FLOAT	4	Dynamic	x	AUTO
time_max_level	Time max. level	84	STRING		Dynamic		
max_level_value	Max. level value	85	FLOAT	4	Dynamic	x	AUTO
time_min_level	Time min. level	86	STRING		Dynamic		
min_level_value	Min. level value	87	FLOAT	4	Dynamic	х	AUTO
reset_min_max	Reset min./max.	94	ENUM16	2	Static	x	AUTO
interf_max_drain_speed	I max. drain speed	88	FLOAT	4	Dynamic	x	AUTO
interf_max_fill_speed	I max. fill speed	89	FLOAT	4	Dynamic	x	AUTO
time_max_interface	Time max. interface	90	STRING		Dynamic		
max_interface_value	Max. interface value	91	FLOAT	4	Dynamic	х	AUTO
time_min_interface	Time min. interface	92	STRING		Dynamic		
min_interface_value	Min. interface value	93	FLOAT	4	Dynamic	x	AUTO
application_parameter	Application parameter	95	ENUM16	2	Dynamic		
operating_mode_ro	Operating mode	108	ENUM16	2	Static	x	OOS
temperature_unit	Temperature unit	72	ENUM16	2	Static	x	AUTO
activate_sw_option	Activate SW option	110	UINT32	4	Static	x	AUTO
target_echo_status	Status	56	ENUM8	1	Dynamic		
iface_target_echo_status	Status	61	ENUM8	1	Dynamic		
signal_noise_status	Status	64	ENUM8	1	Dynamic		
sens_temp_status	Status	67	ENUM8	1	Dynamic		
eop_shift_status	Status	70	ENUM8	1	Dynamic		
terminal_voltage_1	Terminal voltage 1	97	FLOAT	4	Dynamic		
calculated_dc_value	Calculated DC value	100	FLOAT	4	Dynamic	x	AUTO
upper_interface_thickness	Upper interface thickness	103	FLOAT	4	Dynamic		
debug_value	Debug value	106	FLOAT	4	Dynamic	x	AUTO
sw_option_active_overview	SW option active overview	111	BIT_ENUM32	4	Static		
locking_status	Locking status	113	BIT_ENUM16	2	Dynamic		
decimal_places_menu_ro	Decimal places menu	109	ENUM16	2	Static	x	AUTO
linearization_type	Linearization type	104	ENUM16	2	Static	x	OOS
eop_level_evaluation	EOP level evaluation	112	ENUM16	2	Static	х	OOS
access_status_tooling	Access status tooling	114	ENUM16	2	Static		
calculated_dc_status	Status	99	UINT8	1	Dynamic		
status_up_iface_thickness	Customized upper phase thickness status	102	UINT8	1	Dynamic		
debug_status		107	UINT8	1	Dynamic	x	AUTO

9.6.7 Service Sensor Transducer Block

The parameters of the **Service Sensor** Transducer Block can only be operated by authorized Endress+Hauser service personnel.

9.6.8 Service Information Transducer Block

The parameters of the **Service Information** Transducer Block can only be operated by authorized Endress+Hauser service personnel.



.9 Data Transfer Transducer Block

The parameters of the **Data Transfer Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
used_calculation	Used calculation	87	ENUM16	2	Dynamic		
bdt_cfg_rdwr_ctrl		101	UINT16	2	Static	х	AUTO
bdt_transferred_ctrl		102	BYTEARRAY		Static	х	AUTO
bdt_data_trans		103	BYTEARRAY		Static	х	AUTO
bdt_prepare		99	BYTEARRAY		Static	х	AUTO
bdt_status		100	BYTEARRAY		Static		
sw_option_active_overview	SW option active overview	98	BIT_ENUM32	4	Static		
digits_at_0_mVdB		90	FLOAT	4	Dynamic	х	AUTO
digits_per_mVdB		91	FLOAT	4	Dynamic	х	AUTO
actual_diagnostics	Actual diagnostics	97	UINT32	4	Static		
electric_probe_length	Electric probe length	92	FLOAT	4	Dynamic		
empty_calibration_ro	Empty calibration	93	FLOAT	4	Static	х	OOS
full_calibration_ro	Full calibration	94	FLOAT	4	Static	x	OOS
distance_unit_ro	Distance unit	95	ENUM16	2	Static	x	OOS
operating_mode_ro	Operating mode	88	ENUM16	2	Static	x	OOS
present_probe_length_ro	Present probe length	89	FLOAT	4	Dynamic	x	AUTO
trend_operation_hours		104	UINT32	4	Static		
trend_package_size		105	UINT8	1	Static	x	AUTO
trend_storage_time	Trend storage time	106	UINT32	4	Static		
trend_sup_pack_size		107	UINT8	1	Static		
gpc_mode_ro	GPC mode	109	ENUM16	2	Static	x	OOS
eop_level_evaluation_ro	EOP level evaluation	110	ENUM16	2	Static	x	OOS
temperature_unit_ro	Temperature unit	111	ENUM16	2	Static	x	OOS
max_trend_entries		108	UINT16	2	Static		
line_mapping_point_number	Line mapping point number	126	UINT16	2	Static	x	AUTO
line_mapping_array_x	Line mapping array X	127	FLOAT	4	Static	x	AUTO
line_mapping_array_y	Line mapping array Y	128	FLOAT	4	Static	x	AUTO
mapping_end_point_ro	Mapping end point	125	FLOAT	4	Static	x	AUTO
mapping_start_point	Mapping start point	124	FLOAT	4	Static	x	AUTO
function_block_table		143	UINT32	4	Static		
custom_empty_value		112	FLOAT	4	Static		
custom_full_value		113	FLOAT	4	Static		
customized	Customized	121	UINT8	1	Static		
reset_ordered_configuration	Reset ordered configuration	122	ENUM16	2	Static	x	AUTO
empty_scale		114	FLOAT	4	Static	x	AUTO
eop_map_point_number		116	UINT16	2	Static	x	AUTO
factory_data_valid		123	UINT8	1	Static		
fieldbus_type	Fieldbus Type	144	ENUM8	1	Static		
full_scale		115	FLOAT	4	Static	x	AUTO

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
init_map_point_number		117	UINT16	2	Static	х	AUTO
max_not_assoc_track		118	UINT16	2	Static	х	AUTO
ref_max_dist	Ref max. dist.	119	FLOAT	4	Static	х	AUTO
ref_min_dist	Ref min. dist.	120	FLOAT	4	Static	х	AUTO
line_mapping_accuracy	Line mapping accuracy	130	FLOAT	4	Static	х	AUTO
mapping_curve_left_margin	Mapping curve left margin	131	FLOAT	4	Static	х	AUTO
device_calib_changed		133	ENUM16	2	Static	х	AUTO
echo_thresh_attenuat_const_ee	Threshold attenuation constant	134	FLOAT	4	Dynamic	х	AUTO
echo_threshold_far_ee		135	FLOAT	4	Static	х	AUTO
echo_thresh_inactive_len		137	FLOAT	4	Static	х	AUTO
echo_threshold_near_ee		136	FLOAT	4	Static	х	AUTO
present_probe_length_ee		138	FLOAT	4	Static	х	AUTO
reset_appl_para_chg_flags		139	ENUM16	2	Static	х	AUTO
reset_dyn_persistent		140	ENUM16	2	Static	х	AUTO
locking_status	Locking status	142	BIT_ENUM16	2	Dynamic		
decimal_places_menu	Decimal places menu	96	ENUM16	2	Static	х	AUTO
access_status_tooling	Access status tooling	141	ENUM16	2	Static		
level_linearized	Level linearized	147	FLOAT	4	Dynamic		
bdt_transferred_ctrl		197	UINT8	1	Static	х	AUTO
bdt_cfg_rdwr_ctrl		196	UINT16	2	Static	х	AUTO

9.7 Methods

The FOUNDATION Fieldbus Specification includes the use of methods to make device operation easier. A method is a sequence of interactive steps to be carried out in the specified order so as to configure certain device functions.

The following methods are available for the device:

Restart

This method is located in the Resource Block and directly prompts the setting of the **Device reset** parameter. This resets the device configuration to a defined state.

ENP Restart

This method is located in the Resource Block and directly prompts the setting of the parameters of the Electronic Name Plate (ENP).

Setup

This method is located in the SETUP Transducer Block and allows to set the most important parameters in this block for device configuration (measuring units, type of tank or vessel, type of medium, empty and full calibration).

Linearization

This method is located in the ADV_SETUP Transducer Block and allows to manage the linearization table by which the measured value is converted into volume, mass or flow.

Self Check

This method is located in the EXPERT_CONFIG Transducer Block and prompts the device self check parameters.

10 Commissioning using the Commissioning Wizard

A Wizard is provided in FieldCare and DeviceCare ¹⁾ that guides the user through the initial commissioning process.

1. Connect the device with FieldCare or DeviceCare.

2. Open the device in FieldCare or DeviceCare.

← The dashboard (homepage) of the device is displayed:

1			
Wizard			
Commissioning SIL/WHG confirmation)		
Instrument health status			
ОК			
Process variables - Device tag: Levelfinite for the second	2000,000	Level linearized	Thickness upper layer
	1600,000 1200,000	50,604 %	22,138 %
20 166	800,000	Absolute interface amplitude	
28,466	400,000 • 0,000	127,067 mv	

1 "Commissioning" button calls up the wizard

- 3. Click "Commissioning" to launch the Wizard.
- 4. Enter the appropriate value in each parameter or select the appropriate option. These values are written directly to the device.
- 5. Click "Next" to go to the next page.
- 6. Once all the pages have been completed, click "Finish" to close the Wizard.

If you cancel the Wizard before all the necessary parameters have been entered, the device may be in an undefined state. In such situations, it is advisable to reset the device to the factory default settings.

¹⁾ DeviceCare is available for download at www.software-products.endress.com. To download the software, it is necessary to register in the Endress +Hauser software portal.


11 Commissioning via operating menu

11.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:

11.2 Setting the operating language

Factory setting: English or ordered local language




■ 20 Taking the example of the local display

100%

4 mA 0%

A0011360



11.3 Configuring level measurement

D

I

LN



- LN Probe length
- R Reference point of measurement
- D Distance
- L Level
- E Empty calibration (= zero point)
- F Full calibration (= span)

If the ε_r value is lower than 7 in the case of rope probes, measurement is not possible in the area of the tensioning weight. The empty calibration *E* should not exceed *LN* - 250 mm (*LN* - 10 in) in these cases.

Е

뜌

F

- 1. Setup \rightarrow Device tag
 - └ Enter device tag.
- **2.** Navigate to: Setup \rightarrow Distance unit
 - └ Select the distance unit.
- 3. Navigate to: Setup \rightarrow Tank type
 - └ Select tank type.
- 4. For **Tank type** parameter = Bypass / pipe:
 - Navigate to: Setup \rightarrow Tube diameter

└ Specify the diameter of the bypass or stilling well.

- 5. Navigate to: Setup \rightarrow Medium group
 - ← Specify the medium group: (Water based (DC >= 4) or Others)
- 6. Navigate to: Setup \rightarrow Empty calibration
 - ← Specify the empty distance E (distance from reference point R to 0% mark).
- 7. Navigate to: Setup \rightarrow Full calibration
 - └ Specify the full distance F (distance from the 0% mark to the 100% mark).
- 8. Navigate to: Setup \rightarrow Level
 - └ Displays the measured level L.
- 9. Navigate to: Setup \rightarrow Distance
 - → Displays the distance D between the reference point R and the level L.
- **10.** Navigate to: Setup \rightarrow Signal quality
 - └ Displays the signal quality of the analyzed level echo.

11. Operation via local display:

Navigate to: Setup \rightarrow Mapping \rightarrow Confirm distance

← Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).

12. Operation via operating tool:

Navigate to: Setup \rightarrow Confirm distance

← Compare the distance displayed with the actual value to start recording an interference echo map (where applicable).

Recording the reference envelope curve 11.4

After the measurement has been configured, it is recommended to record the current envelope curve as a reference envelope curve. This can then be used later for diagnostic purposes. The **Save reference curve** parameter is used to record the envelope curve.

Path in the menu

Expert \rightarrow Diagnostics \rightarrow Envelope diagnostics \rightarrow Save reference curve

Meaning of the options

No

No action

Yes

The current envelope curve is saved as a reference curve.



This submenu is only visible for the "Service" user role in devices supplied with software version 01.00.zz.

The reference envelope curve can only be displayed in the envelope curve diagram of -FieldCare after it has been loaded from the device into FieldCare. The "Load Reference Curve" function in FieldCare is used for this.

🔸 = 👬 🗳 🚱 🥌 崎

🖻 22 "Load Reference Curve" function

11.5 Configuring the local display

11.5.1 Factory setting of local display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

11.5.2 Adjusting the local display

The local display can be adjusted in the following submenu: Setup \rightarrow Advanced setup \rightarrow Display

11.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and the options available.

Path in the menu

Setup \rightarrow Advanced setup \rightarrow Configuration backup display \rightarrow Configuration management

Meaning of the options

- Cancel
 - No action is executed and the user exits the parameter.
- Execute backup

A backup copy of the current device configuration is saved from the HistoROM (integrated in the device) to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration of the device is duplicated to another device using the display module. The following parameters, which characterize the individual measuring point are **not** transferred: Medium type


Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of the comparison is displayed in the **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.



The **Duplicate** option should always be used to copy the configuration to another device.

11.7 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in two ways:

- Locking via parameters (software locking)
- Locking via write protection switch (hardware locking)

12 Commissioning (block-oriented operation)

12.1 Function check

Before commissioning your measuring point, ensure that the post-installation and postconnection checks have been performed:

- "Post-installation check" checklist \rightarrow 🖺 33
- "Post-connection check" checklist \rightarrow B 39

12.2 Block configuration

12.2.1 Preparatory steps

- 1. Switch on the measuring device.
- 2. Make a note of the **DEVICE_ID**.
- 3. Open the configuration program.
- 4. Load Cff and device description files into the host system or the configuration program. Make sure you are using the right system files.
- 5. Identify the device using the **DEVICE_ID** (see Point 2). Assign the desired tag name to the device via the **Pd-tag/FF_PD_TAG** parameter.


12.2.2 Configuring the Resource Block

- 1. Open the Resource Block.
- 2. If necessary, disable the lock for device operation.
- 3. If necessary, change the block name. Factory setting: RS-xxxxxxxxx (RB2)
- 4. If necessary, assign a description to the block via the **Description of the** identification tag/TAG_DESC parameter.
- 5. If necessary, change other parameters as required.

12.2.3 Configuring the Transducer Blocks

The measurement and the display module are configured via the Transducer Blocks. The basic procedure is the same for all Transducer Blocks:

- 1. If necessary, change the block name.
- 2. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- 3. Configure the device in accordance with the measuring task.
- 4. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element.



12.2.4 Configuring the Analog Input Blocks

The device has 2 Analog Input Blocks that can be assigned as required to the various process variables.

Factory setting		
Analog Input Block CHANNEL		
AI 1	32949: Level linearized	
AI 2 32856: Distance		


- 1. If necessary, change the block name.
- 2. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- **3.** Via the **Channel/CHANNEL** parameter, select the process variable which should be used as the input value for the Analog Input Block .
- 4. Via the Transducer scale/XD_SCALE parameter, select the desired unit and the block input range for the process variable → <a>B 80. Make sure that the selected unit suits the process variable that is selected. If the process variable and the unit do not suit one another, the Block error/ BLOCK_ERR parameter reports the Block Configuration Error and the block mode cannot be set to Auto.
- 5. Via the Linearization type/L_TYPE parameter, select the type of linearization for the input variable (factory setting: Direct). Make sure that the settings for the Transducer scale/XD_SCALE and Output scale/OUT_SCALE parameters are the same for the Direct linearization type. If the values and units do not match, the Block error/ BLOCK_ERR parameter reports the Block Configuration Error and the block mode cannot be set to Auto.
- 6. Enter the alarms and critical alarm messages via the High alarm limit/ HI_HI_LIM, High early warning limit/HI_LIM, Low alarm limit/ LO_LO_LIM and Low early warning limit/LO_LIM parameters. The limit values entered must be within the value range specified for the Output scale/OUT_SCALE parameter → ≅ 80.
- 7. Specify the alarm priorities via the Priority for high limit value alarm/HI_HI_PRI, Priority for high early warning/HI_PRI, Priority for low limit value alarm/LO_LO_PRI and Priority for low limit value early warning/LO_PRI parameters. Reporting to the field host system only takes place with alarms with a priority greater than 2.
- 8. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element. For this purpose, the Resource Block must also be set to the **Auto** block mode.

12.2.5 Additional configuration

- 1. Link the function blocks and output blocks.
- 2. After specifying the active LAS, download all the data and parameters to the field device.

12.3 Scaling the measured value in the AI Block

The measured value can be scaled if the $L_TYPE = Indirect$ linearization type has been selected in the AI Block. **XD_SCALE** defines the input range with the **EU_0** and **EU_100** elements. This is mapped linearly to the output range, defined by **OUT_SCALE** also with the elements **EU_0** and **EU_100**.



Scaling the measured value in the AI Block

- If you have selected the Direct mode in the L_TYPE parameter, you cannot change the values and units for XD_SCALE and OUT_SCALE.
 - The **L_TYPE**, **XD_SCALE** and **OUT_SCALE** parameters can only be changed in the OOS block mode.


12.4 Selecting the language

Step	Block	Parameter	Action
1	DISPLAY (TRDDISP)	Language (language)	Select the language ¹⁾ .
			Options: 32805: Arabic 32824: Chinese 32842: Czech 32881: Dutch 32888: English 32917: French 32920: German 32945: Italian 32946: Japanese 32948: Korean 33026: Polish 33027: Portuguese 33062: Russian 33083: Spanish 33103: Thai 33120: Vietnamese 33155: Indonesian 33166: Turkish

1) The languages the device supports are specified when the device is ordered. See feature 500 "Additional operating language" in the product structure for this purpose

12.5 Configuring level measurement

The **Setup** method can also be used to configure the measurement. This method can be called via the SETUP Transducer Block (TRDSUP).



24 Configuration parameters for level measurement in liquids

LN = Probe length	R = Reference point of measurement
D = Distance	E = Empty calibration (= zero point)
L = Level	F = Full calibration (= span)

If the DC value is less than 7 in the case of rope probes, measurement in the area of the tensioning weight is not possible. The empty calibration E may not exceed LN - 250 mm (LN - 10 in) in these cases.

Step	Block	Parameter	Action
1	SETUP (TRDSUP)	Distance unit (distance_unit)	Select the distance unit. Options: • 1010: m • 1013: mm • 1018: in • 1019: ft
2	SETUP (TRDSUP)	Tank type (tank_type)	Select tank type. Options: • 32816: Bypass/stilling well • 33288: Metal • 33302: Coax • 33432: Double cable • 33433: Double rod • 33437: Rope, metal centering disk • 33438: Rod, metal centering disk • 33441: Non-metal • 33444: Installation outside
3	SETUP (TRDSUP)	Tube diameter (tube_diameter) ¹⁾	Specify the diameter of the bypass or stilling well.
4	SETUP (TRDSUP)	Medium group (medium_group)	Specify the medium group. Options: • 316: Water-based (DC > 4) • 256: Other (DC > 1.9) ²⁾

Step	Block	Parameter	Action
5	SETUP (TRDSUP)	Empty calibration (empty_calibration)	Specify the empty distance E (distance from reference point R to 0% mark).
6	SETUP (TRDSUP)	Full calibrationSpecify the full distance F (distance from the mark to the 100% mark).	
7	SETUP (TRDSUP)	Level (level)	Displays the measured level L.
8	SETUP (TRDSUP)	Distance (filtered_dist_val)	Displays the distance D between the reference point R and the level L.
9	SETUP (TRDSUP)	Signal quality (signal_quality)	Displays the signal quality of the analyzed level echo.
10	SETUP (TRDSUP)	Confirm distance (confirm_distance)	Compare the distance displayed with the actual value to start recording an interference echo map.
			Options: 179: Record map manually 32847: Delete mapping curve 32859: Distance Ok 32860: Distance too large 32861: Distance too small 32862: Distance unknown 33100: Tank empty

1) Only available for coated probes and "Tank type" = "Bypass/stilling well"

2) Lower DCs can also be entered in the "DC Value (dc_value)" parameter if necessary. However, the measuring range can be limited if DC<1.6. In this case, contact Endress+Hauser.

12.6 Configuring the local display

12.6.1 Factory setting of local display for level measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, large format	1 value, large format
Value 1 display	Level linearized	Level linearized
Value 2 display	Distance	Distance
Value 3 display	Current output 1	Current output 1
Value 4 display	None	Current output 2

The local display can be customized in the Transducer Block **DISPLAY (TRDDISP)**.

12.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and its options.

Path in the menu

Setup \rightarrow Extended setup \rightarrow Data backup \rightarrow Configuration management

Block operation Block: DISPLAY (TRDDISP)


Parameter: Configuration management (configuration_management)

Functions of the	parameter	options
------------------	-----------	---------

Options	Description
33097: Backup	A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.
33057: Restore	The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy includes the transmitter data of the device.
33838: Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
265: Compare	The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
32848: Delete data backup	The backup copy of the device configuration is deleted from the display module of the device.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.



In devices with FOUNDATION Fieldbus communication, the "PD-Tag" parameter is also accepted when duplicating the parameters. If necessary, set this parameter to the desired value after duplication.

12.8 Configuring event behavior according to FOUNDATION Fieldbus specification FF912

The device complies with FOUNDATION Fieldbus specification FF912. Among other things this means that:

- The diagnostic category as per NAMUR Recommendation NE107 is transmitted over the fieldbus in a format that is independent of the manufacturer:
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- The diagnostic category of the predefined event groups can be adapted by the user according to the requirements of the individual application.
- Certain events can be separated from their group and be treated individually:
 - 941: Lost echo
 - 942: In safety distance
- Additional information and troubleshooting measures are transmitted over the fieldbus with the event message.

Diagnostic messages according to FF912 are only available in the host if the **Multi-bit Alarm Support** option is activated in the **FEATURE_SEL** parameter of the Resource Block. For reasons of compatibility, this option is **not** enabled when the device is delivered:

B © GRANT_DENY - GRANT 0x00 mm	xtensions Help
ocess Tuning Options Alarms Diagnostics Others Methods Parameter Value Type & E GRANT_DENY GRANT_0X00 mm	xtensions Help
rocess Tuning Options Alarms Diagnostics Others Methods Parameter Value Type & E GRANT_DENY GRANT 0x00	xtensions Help
Parameter Value Type & E GRANT_DENY GRANT 0x00 mm	xtensions Help
GRANT_DENY GRANT 0x00 mm	xtensions Help
L DENY 0x00 mm	
RESTART 🚮 Run 🚥	
FEATURES Reports Faultstate Soft W Lock Head	
FEATURE_SEL	
FAULT_STATE Soft W Lock	
Hard W Lock	
SET_FSTATE Change Bypass in Auto	
CLR_FSTATE MUVC Report Distribution supported Multi-bit Alarm (Bit-Alarm) Support	
Defer Inter-Parameter Write Checks	
WRITE_LOCK Not Locked and	
- Contraction -	

12.8.1 Event groups

The diagnostic events are divided into 16 groups according to the **source** and the **weighting**. A **default event category** is assigned to each group at the factory. Here, one bit of the assignment parameters belongs to every event group.

Event weighting	Default event category	Event source	Bit	Events in this group
Highest weighting	ghest weighting Failure (F)	Sensor	31	 F003: Broken probe detected F046: Buildup detected F083: Memory content F104: HF cable F105: HF cable F106: Sensor
		Electronics	30	 F242: Software incompatible F252: Modules incompatible F261: Electronic modules F262: Module connection F270: Main electronic failure F271: Main electronic failure F272: Main electronic failure F273: Main electronic failure F275: I/O module failure F276: I/O module failure F282: Data storage F283: Memory content F311: Memory content
		Configuration	29	 F410: Data transfer F411: Upload/download F435: Linearization F437: Configuration incompatible
		Process	28	 F803: Loop current 1 F825: Operating temperature F936: EMC interference F941: Echo lost ¹⁾ F970: Linearization

1) This event can be removed from the group and treated separately; see the "Configurable area" section.

Event weighting	Default event category	Event source	Bit	Events in this group
High weighting	Function check (C)	Sensor	27	Not used in Levelflex
		Electronics	26	Not used in Levelflex
		Configuration	25	 C411: Upload/download C431: Trim C484: Failure mode simulation C485: Simulation measured value C491: Simulation current output C585: Simulation distance
		Process	24	Not used in Levelflex

Event weighting	Default event category	Event source	Bit	Events in this group
Low weighting	Out of specification (S)	Sensor	23	Not used in Levelflex
		Electronics	22	Not used in Levelflex

Event weighting	Default event category	Event source	Bit	Events in this group
		Configuration	21	S441: Current output 1
		Process	20	 S801: Energy too low S825: Operating temperature S921: Change of reference S942: In safety distance ¹⁾ S943: In blocking distance S944: Level range S968: Level limited

1) This event can be removed from the group and treated separately; see the "Configurable area" section.

Event weighting	Default event category	Event source	Bit	Events in this group
Lowest weighting	Maintenance required (M)	Sensor	19	Not used in Levelflex
		Electronics	18	 M270: Main electronics error M272: Main electronics error M311: Memory content
		Configuration	17	M438: Dataset
		Process	16	M801: Loop current 1

12.8.2 Assignment parameters

Event categories are assigned to the event groups via four assignment parameters. These are located in the **RESOURCE (RB2)** Block:

- FD_FAIL_MAP: For the Failure (F) event category
- FD_CHECK_MAP: For the Function check (C) event category
- FD_OFFSPEC_MAP: For the Out of specification (S) event category
- FD_MAINT_MAP: For the Maintenance required (M) event category

Each of these parameters consists of 32 bits with the following meaning:

- Bit 0: Reserved by the Fieldbus Foundation
- Bits 1 to 15: Configurable area; certain diagnostic events can be assigned here independently of the event group they belong to. They are then removed from the event group and their behavior can be configured individually.

In the Levelflex the following parameters can be assigned to the configurable area: • 941: Lost echo

- 942: In safety distance
- **Bits 16-31:** Standard range; these bits are permanently assigned to the event groups. If the bit is set to **1**, this event group is assigned to the individual event category.

The following table indicates the default setting of the assignment parameters. In the default setting, there is a clear assignment between the event weighting and the event category (i.e. the assignment parameter).

		Standard range										Configurable area					
Event weighting		Highest weighting		High weighting L				Lo	Low weighting		Lowest weighting			I			
Event source ¹⁾	S	E	С	Р	S	E	С	Р	S	E	С	Р	S	E	С	Р	
Bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15 1
FD_FAIL_MAP	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FD_CHECK_MAP	0	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	0
FD_OFFSPEC_MAP	0	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0
FD_MAINT_MAP	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	0

Default setting of assignment parameters

1) S: Sensor; E: Electronics; C: Configuration; P: Process


Proceed as follows to change the diagnostic behavior of an event group:

- 1. Open the assignment parameter in which the group is currently assigned.
- 2. Change the event group bit from **1** to **0**. When operating via FieldCare, this is done by unchecking the corresponding check box (see the next example).
- 3. Open the assignment parameter to which the group should be assigned.
- 4. Change the event group bit from **0** to **1**. When operating via FieldCare, this is done by checking the corresponding check box (see the next example).


Example

The **Highest weighting / configuration error** group contains the events **410: Data transfer**, **411: Upload/download**, **435: Linearization** and **437: Configuration**

incompatible. These should be categorized as **Function check (C)** and no longer as **Failure (F)**.



In the FieldCare navigation window, navigate to **Expert** \rightarrow **Communication** \rightarrow **Field diagnostics** \rightarrow **Alarm detection enable**.



■ 25 The "Fail Map" and "Check Map" columns in the as-delivered state

In the **Fail Map** column, look for the **Configuration Highest Severity** group and uncheck the corresponding check box (A). Check the relevant check box in the **Check Map** (B) column. Note that you must press the Enter key to confirm every entry.

Process Highest severity	Process Highest severity
Configuration Highest severity	🔽 Configuration Highest severity
🔽 Electronic Highest severity	Electronic Highest severity
Sensor Highest severity	Sensor Highest severity

🖻 26 The "Fail Map" and "Check Map" columns after the change

- Please ensure that the corresponding bit is set in at least one of the assignment parameters for each event group. Otherwise no category will be transmitted with the event over the bus, and the control system will therefore generally ignore the presence of the event.
- The detection of diagnostic events is parameterized on the **Alarm detection enable** FieldCare page but the transmission of messages over the bus is not. The latter is performed on the **Alarm broadcast enable** page. The operation of this page is identical to the operation of the **Alarm detection enable** page. The Resource Block must be in the **Auto** mode for the status information to be transmitted over the bus.

12.8.3 Configurable area


The event category can be individually defined for the following events - irrespective of the event group they are assigned to in the default setting:

- F941: Lost echo
- **S942:** In safety distance

To change the event category, the event first has to be assigned to one of the bits 1 to 15. The **FF912 ConfigArea_1** to **FF912ConfigArea_15** parameters in the **DIAGNOSTIC (TRDDIAG)** Block are used for this purpose. Then the corresponding bit can be set from 0 to **1** in the desired assignment parameter.

Example

Error **942** "In safety distance" should no longer be categorized as **Out of specification (S)** and should be categorized as **Function check (C)** instead.



In the FieldCare navigation window, navigate to **Expert** \rightarrow **Communication** \rightarrow **Field diagnostics** \rightarrow **Alarm detection enable**.

Configurable Area Bit 1:	Not used 🛛 🖌
Configurable Area Bit 2:	Not used 🛛 🖂
Configurable Area Bit 3:	Not used 🛛 🖌
Configurable Area Bit 4:	Not used 🛛 🖂
Configurable Area Bit 5:	Not used 🛛 🖌
Configurable Area Bit 6:	Not used 🖌
	Configurable Area Bit 2: Configurable Area Bit 3: Configurable Area Bit 4: Configurable Area Bit 5:

In the default setting, all bits in the **Configurable Area Bits** column have the value **not used**.

3. Configurable Area Bit 1:	In safety distance
Configurable Area Bit 2:	Not used
Configurable Area Bit 3:	Not used 🔽
Configurable Area Bit 4:	Not used 🔽
Configurable Area Bit 5:	Not used 🔽
Configurable Area Bit 6:	Not used 🔽

Select one of these bits (here for example: **Configurable Area Bit 1**) and select the **In safety distance** option from the corresponding selection list. Press Enter to confirm the option selected.

4.	Offspec Map:	Configurable Area Bit 1
		Configurable Area Bit 2
		🔲 Configurable Area Bit 3
		Configurable Area Bit 4
		Configurable Area Bit 5
		🗌 Configurable Area Bit 6

Go to the **Offspec Map** column and check the check box for the corresponding bit (here: **Configurable Area Bit 1**). Press ENTER to confirm your entries.

A change to the **In safety distance** error category does not affect an error that already exists. The new category is only assigned if this error occurs again after the change has been made.

12.8.4 Transmission of event messages over the bus

Event priority

Event messages are only transmitted over the bus if their priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Priority 0-events are ignored. In the factory setting, the priority of all events is 0. The priority can be individually changed for the four assignment parameters. The following four parameters of the Resource Block are used for this purpose:

pply Values Device information		
ESOURCE_AAFFFFAAFFF (🛛 🕅	2 2 2 2 2	1 🛅 😧
Periodic Updates 2 (sec)	<u>.</u>	
00S Auto		
Process Tuning Options Alarm	ns Diagnostics Others Methods	
Process Tuning Uptions Alarm Parameter	ns Diagnostics Uthers Methods Value	Type & Extensions Help
1 -1 - 1		Type & Extensions Help
Parameter	Value	
Parameter FD_FAIL_PRI	Value 10	vs Range=0 - 15

Suppression of certain events

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare under **Expert** \rightarrow **Communication** \rightarrow **Field diagnostics** \rightarrow **Alarm broadcast enable**. The mask is a negative selection mask, i.e. if a field is selected the associated events are **not** transmitted over the bus.

12.9 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in the following ways:

- Locking via write protection switch (hardware locking)
- Locking via the operating menu (software locking)
- Locking via block operation:
 - Block: DISPLAY (TRDDISP); parameter: Define access code
 - Block: EXPERT_CONFIG (TRDEXP); parameter: Enter access code

13 Diagnostics and troubleshooting

13.1 General troubleshooting

13.1.1 General errors

Error	Possible cause	Solution
Device does not respond.	Supply voltage not connected.	Connect the correct voltage.
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ± and E simultaneously. Decrease contrast by pressing Ξ and E simultaneously.
	The plug of the display cable is not connected correctly.	Connect the plug correctly.
	Display is defective.	Replace display.
"Communication error" is indicated	Electromagnetic interference	Check grounding of the device.
on the display when starting the device or connecting the display.	Broken display cable or display plug.	Replace display.
Duplication of parameters via display from one device to another not working. Only the "Save" and "Cancel" options are available.	Display with backup is not properly detected if a data backup was not carried out on the new device previously.	Connect display (with backup) and restart device.
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.
Device measures incorrectly.	Parameter configuration error	Check and correct the parameter configuration.

13.1.2 Parametrization errors


Problem	Possible cause	Remedy		
Measured value is incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	 Check the Empty calibration parameter (→ ≅ 127) and correct if necessary. Check the Full calibration parameter (→ ≅ 128) and correct if necessary. Check the linearization and correct if necessary (Linearization submenu (→ ≅ 144)). 		
	If measured distance (Setup → Distance) does not match the real distance: An interference echo is present.	Carry out mapping (Confirm distance parameter ($\rightarrow \textcircled{B}$ 130)).		
No change of measured value on filling/emptying	An interference echo is present.	Carry out mapping (Confirm distance parameter ($\rightarrow \cong$ 130)).		
	Buildup at the probe.	Clean the probe.		
	Error in the echo tracking.	Deactivate echo tracking (Expert → Sensor → Echo tracking → Evaluation mode = History off).		
Echo lost diagnostic message appears after the supply voltage is switched on.	Echo threshold too high.	Check the Medium group parameter $(\rightarrow \bowtie 127)$. If necessary, select a more detailed setting with the Medium property parameter $(\rightarrow \bowtie 138)$.		
	Level echo suppressed.	Delete the map and record it again if necessary (Record map parameter $(\rightarrow \cong 132)$).		
Device displays a level when the tank is empty.	Incorrect probe length	Perform probe length correction (Confirm probe length parameter $(\rightarrow \cong 157)$).		
	Interference echo	Carry out mapping over the entire probe length when the tank is empty (Confirm distance parameter ($\rightarrow \cong 130$)).		
Wrong slope of the level over the entire measuring range	Wrong tank type selected.	Select the correct Tank type parameter $(\rightarrow \cong 126)$.		

Parametrization errors for level measurements

13.2 Diagnostic information on local display

13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


F 40032902	"Failure (F)" option A device error has occurred. The measured value is no longer valid.
C	"Function check (C)" option The device is in the service mode (e.g. during a simulation).
S A0032904	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range)
M 40032905	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs adopt the defined alarm condition. A diagnostic message is generated.		
	"Warning" status The device continues to measure. A diagnostic message is generated.		

Diagnostic event and event text

The fault can be identified by means of the diagnostic event. The event text helps you by providing information about the fault. In addition, the associated status symbol is displayed in front of the diagnostic event.




If two or more diagnostic events occur simultaneously, only the diagnostic message with the highest priority is shown. Additional queued diagnostic messages can be shown in the **Diagnostic list** submenu.

Past diagnostic messages that are no longer pending are shown as follows:

- On the local display:
 - In the **Event logbook** submenu
- In FieldCare:
 - Via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu		
Plus key Opens the message about the remedial measures. E Enter key Opens the operating menu.		



13.2.2 Calling up remedial measures

■ 27 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures

The user is in the diagnostic message.

1. Press 🛨 (① symbol).

- ← The **Diagnostic list** submenu opens.
- **2.** Select the desired diagnostic event with \pm or \Box and press \mathbb{E} .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- **3.** Press \Box + \pm simultaneously.
 - \blacktriangleright The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** or in **Previous diagnostics**.

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press + + simultaneously.
 - └ The message about the remedial measures closes.


13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)

A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
 - └ In the Actual diagnostics parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.



A tool tip with remedial measures for the diagnostic event appears.

1. Menu / Variable Diagnostics PD Actual diagnostics:

Select the "Create documentation" function.


B: Via the "Create documentation" function

2.	Documentation		
	Documentation	Status	
	⊡· ✓ Documentation	Initialized	
	🖨 🔽 Title Pages	Initialized	
	Cover Page	Initialized	
	Signatures Page	Initialized	
		Initialized	
	Linearization table	Initialized	
	Envelope curve	Initialized	
	Extended HistoROM	Initialized	
	🗹 Diagram data	Initialized	
	Data overview	Initialized	
	Compare Datasets	Not available	

Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.

2.	Online-Parametrierung 🗙	Eventliste / Erweitertes HistoROM	X
	한 🚔 🗄 🗹 🕑 🔍	a s. 🛪 🗹 🚖 × 🐼	🛃 🎯
		~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	

Select the "Load Eventlist" function.

└ The list of events, including remedy information, is shown in the "Data overview" window.

## 13.4 Diagnostic messages in the DIAGNOSTIC Transducer Block (TRDDIAG)

- The Actual diagnostics parameter displays the message with the highest priority. Every
  message is also output as per the FOUNDATION Fieldbus Specification by means of the
  XD_ERROR and BLOCK_ERROR parameters.
- A list of diagnostic messages is displayed in the **Diagnostics 1** to **Diagnostics 5** parameters. If more than 5 messages are currently active, only those with the highest priority are displayed.
- You can view a list of alarms which are no longer active (event log) via the **Previous** diagnostics parameter.

# 13.5 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

### Navigation path

 $\text{Diagnostics} \rightarrow \text{Diagnostic list}$ 

### Calling up and closing the remedial measures

1. Press E.

└ The message for the remedial measures for the selected diagnostic event opens.

- 2. Press  $\Box$  +  $\pm$  simultaneously.
  - └ The message about the remedial measures closes.

# 13.6 Event logbook

## 13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu  $^{2)}$ .

### Navigation path

 $\texttt{Diagnostics} \rightarrow \texttt{Event logbook} \rightarrow \texttt{Event list}$ 

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
  - ①: Event has occurred
  - 🕒: Event has ended
- Information event

€: Event has occurred

### Calling up and closing the remedial measures

- 1. Press E
  - └ The message for the remedial measures for the selected diagnostic event opens.

2. Press  $\Box$  +  $\pm$  simultaneously.

└ The message about the remedial measures closes.

### 13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

### Navigation path

 $\texttt{Diagnostics} \rightarrow \texttt{Event logbook} \rightarrow \texttt{Filter options}$ 

### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

## 13.6.3 Overview of information events

Info number	Info name		
I1000	(Device ok)		
I1089	Power on		
I1090	Configuration reset		
I1091	Configuration changed		

²⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Info number	Info name			
I1092	Trend data deleted			
I1110	Write protection switch changed			
I1137	Electronic changed			
I1151	History reset			
I1154	Reset terminal voltage min/max			
I1155	Reset electronic temperature			
I1156	Memory error trend			
I1157	Memory error event list			
I1185	Display backup done			
I1186	Restore via display done			
I1187	Settings downloaded with display			
I1188	Display data cleared			
I1189	Backup compared			
I1256	Display: access status changed			
I1264	Safety sequence aborted			
I1335	Firmware changed			
I1397	Fieldbus: access status changed			
I1398	CDI: access status changed			
I1512	Download started			
I1513	Download finished			
I1514	Upload started			
I1515	Upload finished			

Date	Firmware version	Modifications	Documentation (FMP53, FOUNDATION Fieldbus)		
			Operating Instructions	Description of Device Parameters	Technical Information
04.2012	01.00.zz	Original software	BA01053F/00/EN/01.12	GP01015F/00/EN/01.12	TI01002F/00/EN/14.12
05.2015	01.01.zz	<ul> <li>Support of SD03</li> <li>Additional languages</li> <li>HistoROM functionality enhanced</li> <li>"Advanced Diagnostics" function block integrated</li> <li>Improvements and bugfixes</li> </ul>	BA01053F/00/EN/03.15 BA01053F/00/EN/04.16 ¹⁾	GP01015F/00/EN/02.15	TI01002F/00/EN/17.15 TI01002F/00/EN/20.16 ¹⁾

# 13.7 Firmware history

1) Contains information on the Heartbeat wizards available in the current DTM version for DeviceCare and FieldCare.

The firmware version can explicitly be ordered via the product structure. In this way it is possible to ensure compatibility of the firmware version with an existing or planned system integration.

# 14 Maintenance

No special maintenance work is required.

## 14.1 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not corrode the surface of the housing and the seals.

# 14.2 General cleaning instructions

Dirt or buildup may form on the probe depending on the application. A thin, even layer has little impact on the measurement. Thick layers can dampen the signal and reduce the measuring range. Very uneven deposit formation or caking (e.g. due to crystallization) can result in incorrect measurements. In such cases, use a non-contact measuring principle, or regularly inspect the probe for contamination.

Cleaning with sodium hydroxide solution (e.g. in CIP procedures): if the coupling is wetted, larger measurement errors can occur than under reference operating conditions. Wetting can cause temporary incorrect measurements.

# 14.3 Cleaning the probe

## 14.3.1 Cleaning the probe in the vessel

If a suitable mounting position has been selected, the probe can be cleaned by a spray ball in the vessel  $\rightarrow \cong 24$ .

### 14.3.2 Cleaning the probe outside the vessel

#### The probe can be removed for better cleaning.

The following tool is required for cleaning:

- Vise with fiber jaws (surface protection for the polished rod probe)
- Hook wrench with lug  $\phi$  54 mm (2.1 in)
- Open-ended wrench AF27/AF32 with torque setting up to 20 Nm

#### Caution!

- Before starting work, make sure that the power supply for the device is switched off.
- When unscrewing the slotted nut (1), make sure to provide counter-support at the process connection ring (5) with an open-ended wrench. Otherwise the adapter (3) will become detached from the flange.

#### Disassembling the electronics housing

- Unscrew the slotted nut (1) with the hook wrench.
- Remove the loosened housing (2), together with the housing holder, from the adapter (3) of the process connection towards the top. The housing holder remains connected to the housing. Put the housing to one side. In the case of the "Remote sensor" version, only the cable adapter must be removed.
- Replace the O-ring (7) if necessary.
   Order number: see Device Viewer → 
   ¹ 106

#### Disassembling the rod probe

- Unscrew the adapter (3) from the process connection (the flange in the example): at the wrench flats unscrew the adapter with an openended wrench (AF27) and remove from the vessel together with the probe rod (max. 4 m).
- Clamp the probe rod (4) at the wrench flats or use fitting pliers.


**Caution**: Protect the surface of the polished probe rod! It must not be damaged by scratches or denting.

- Unscrew the adapter (3) from the probe rod (approx. 12 turns in the counter-clockwise direction) and remove it (plug-in connection). The probe rod is screwed into the insulating bush with 4.5 Nm.
- The O-ring seals (6) of the probe rod and adapter are now freely accessible and can be exchanged if necessary. The probe rod and adapter can be autoclaved.

Order numbers of O-rings: see Device Viewer  $\rightarrow \triangleq 106$ 

#### Probe mounting

- Assembly is the reverse of the disassembly sequence:Screw the adapter (3) onto the probe rod (4) with 4.5 Nm.
- Screw the adapter together with the probe rod into the vessel process connection and tighten with 20 Nm.
- Fit the housing (2) along with the housing holder onto the adapter and screw together with the slotted nut (1); torque 20 Nm.



# 15 Repair

# 15.1 General information

## 15.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs can be carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

## 15.1.2 Repair of Ex-certified devices

### **WARNING**

**Incorrect repair can compromise electrical safety!** Explosion Hazard!

- Repairs to Ex-certified devices must be carried out by Endress+Hauser Service or by specialist personnel according to national regulations.
- Relevant standards and national regulations on hazardous areas, safety instructions and certificates must be observed.
- ► Use only original Endress+Hauser spare parts.
- Please note the device designation on the nameplate. Only identical parts may be used as replacements.
- Carry out repairs according to the instructions.
- Only the Endress+Hauser service team is permitted to modify a certified device and convert it to another certified version.

## 15.1.3 Replacing electronics modules

When electronics modules have been replaced the device does not need to be recalibrated as the parameters are saved in the HistoROM inside the housing. It may be necessary when replacing the main electronics to record a new interference echo suppression.

## 15.1.4 Replacing a device

Once a complete device has been replaced, the parameters can be transferred back into the device using one of the following methods:


- Using the display module Prerequisite: The configuration of the old device was saved previously to the display module.
- Via FieldCare

Prerequisite: The configuration of the old device was saved previously to the computer using FieldCare.

You can continue measuring without performing a new calibration. Only interference echo suppression may need to be carried out once again.

# 15.2 Spare parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- In the connection compartment cover of the device there is a spare part nameplate which contains the following information:
  - A list of the most important spare parts for the measuring device, including their ordering information.
  - The URL to the *W@M Device Viewer* (www.endress.com/deviceviewer): All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



28 Example for spare part nameplate in the connection compartment cover

All Measuring device serial number:

- Located on the device and spare part nameplate.
- Can be read out via the "Serial number" parameter in the "Device information" submenu.

# 15.3 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the web page for information:

http://www.endress.com/support/return-material

- └ Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

# 15.4 Disposal

# X


If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

# 16 Accessories


# 16.1 Device-specific accessories

## 16.1.1 Weather protection cover

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.




🖻 29 Height. Unit of measurement mm (in)



☑ 30 Dimensions. Unit of measurement mm (in)


Material 316L

**Order number for accessories:** 71162242



## 16.1.2 Mounting bracket for electronics housing

## 16.1.3 Weld-in adapter




# 16.1.4 Protective cover

Accessories	Description	
Protective cover		A0013589
	For closing off the probe when the electronics module is removed Order number: 71041379 For details, see Operating Instructions BA362F.	A0015385

# 16.1.5 Calibration kit

Accessories	Description
	The calibration kit is used for regular testing of the accuracy and reproducibility of the Levelflex FMP53 level measurement device. Order number: 71041382 For details, see Operating Instructions SD01003F.

# 16.1.6 Remote display FHX50



# Technical data

- Material:
  - Plastic PBT
  - 316L/1.4404
  - Aluminum
- $\bullet$  Degree of protection: IP68 / NEMA 6P and IP66 / NEMA 4x
- Suitable for display modules:
  - SD02 (push buttons)
  - SD03 (touch control)

- Connecting cable:
  - Cable supplied with device up to 30 m (98 ft)
  - Standard cable supplied by customer up to 60 m (196 ft)
- Ambient temperature:-40 to 80 °C (-40 to 176 °F)
- Ambient temperature (option): -50 to 80 °C (-58 to 176 °F)³⁾

# Ordering information

• If the remote display is to be used, the device version "Prepared for display FHX50" must be ordered.

For the FHX50, the option "Prepared for display FHX50" must be selected under "Measuring device version".

- If a measuring device has not been ordered with the version "Prepared for display FHX50" and is to be retrofitted with an FHX50, the version "Not prepared for display FHX50" must be ordered for the FHX50 under "Measuring device version". In this case, a retrofit kit for the device is supplied with the FHX50. The kit can be used to prepare the device so that the FHX50 can be used.
  - Use of the FHX50 may be restricted for transmitters with an approval. A device may only be retrofitted with the FHX50 if the option "Prepared for FHX50" is listed in the associated Safety Instructions (XA) under *Basic specifications*, "Display, operation".

Also pay attention to the Safety Instructions (XA) of the FHX50.

Retrofitting is not possible on transmitters with:

- An approval for use in areas with flammable dust (dust ignition-proof approval)
- Type of protection Ex nA


For details, see the "Special Documentation" SD01007F

# 16.1.7 Overvoltage protection

The surge arrester for loop-powered devices can be ordered together with the device via the "Accessory mounted" section of the product order structure.

The surge arrester can be used for loop-powered devices.

- 1-channel devices OVP10
- 2-channel devices OVP20



# Technical data

- Resistance per channel:  $2 \times 0.5 \Omega_{max}$
- Threshold DC voltage: 400 to 700 V
- Threshold surge voltage: < 800 V</li>

³⁾ This range applies if the option JN "Transmitter ambient temperature" –50 °C (–58 °F) was selected in feature 580 "Test, Certificate". If the temperature is permanently below –40 °C (–40 °F), higher failure rates can be expected.

- Capacitance at 1 MHz: < 1.5 pF
- Nominal leakage current (8/20 µs): 10 kA
- Suitable for conductor cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)


# If retrofitting:

- Order number for 1-channel devices (OVP10): 71128617
- Order number for 2-channel devices (OVP20): 71128619
- The use of the OVP module may be restricted depending on the transmitter approval. A device may only be retrofitted with the OVP module if the option *NA* (overvoltage protection) is listed under *Optional specifications* in the Safety Instructions (XA) associated with the device.
- In order to keep the necessary safety distances when using the surge arrester module, the housing cover also needs to be replaced when the device is retrofitted.
   Depending on the housing type, the suitable cover can be ordered using the following order number:
  - Housing GT18: 71185516
  - Housing GT19: 71185518
  - Housing GT20: 71185517

For details, see the "Special Documentation" SD01090F

# 16.1.8 Bluetooth module BT10 for HART devices

The Bluetooth module BT10 can be ordered together with the device via the "Accessory mounted" section of the product order structure.



## Technical data

- Quick and easy setup with the SmartBlue app
- No additional tools or adapters needed
- Signal curve via SmartBlue (app)
- Encrypted single point-to-point data transmission (tested by Fraunhofer Institute) and password-protected communication via Bluetooth[®] wireless technology
- Range under reference conditions:
   > 10 m (33 ft)
- When the Bluetooth module is used, the minimum supply voltage of the device increases by up to 3 V.

# If retrofitting:

- Order number: 71377355
- The use of the Bluetooth module may be restricted depending on the transmitter approval. A device may only be retrofitted with the Bluetooth module if the option NF (Bluetooth module) is listed under Optional specifications in the Safety Instructions (XA) associated with the device.

For details, see the "Special Documentation" SD02252F

#### 16.2 **Communication-specific accessories**

## Commubox FXA291

Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop Order number: 51516983



For details, see "Technical Information" TI00405C

# Field Xpert SFX350

Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area.



For details, see Operating Instructions BA01202S

# Field Xpert SFX370

Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area** and the **Ex area**.

For details, see Operating Instructions BA01202S 

#### 16.3 Service-specific accessories

## DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices

Technical Information TI01134S

# FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



Technical Information TI00028S

#### 16.4 System components

## Memograph M graphic data manager

The Memograph M graphic data manager provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.

Technical Information TI00133R and Operating Instructions BA00247R

# 17 Operating menu

# 17.1 Overview of the operating menu (display module)

	Nav	vigation		Operating menu	
Language		]			
🗲 Setup					→ 🖺 134
	Distance unit				
	Tank type				
	Tube diameter				
	Medium group				
	Empty calibration				
	Full calibration				
	Level				
	Distance				
	Signal quality				
	► Mapping				→ 🗎 133
		Confirm distance			→ 🗎 133
		Mapping end point	t		→ 🖺 133
		Record map			→ 🗎 133
		Distance			→ 🗎 133
	► Analog inputs				
		► Analog input 1	to 5		→ 🗎 134
			Block	< tag	→ 🗎 134

	Channel	→ 🗎 134
	Process Value Filter Time	→ 🗎 135
► Advanced setup		→ 🗎 136
Locking status	S	→ 🗎 136
Access status	display	→ 🗎 136
Enter access o	rode	→ ➡ 137
► Level		→ 🗎 138
	Medium type	→ ➡ 138
	Medium property	→ 🗎 138
	Process property	→ 🗎 139
	Advanced process conditions	→ 🗎 140
	Level unit	→ 🗎 141
	Blocking distance	→ 🗎 141
	Level correction	→ 🗎 142
► Linearizati	ion	→ 🗎 144
	Linearization type	→ 🗎 146
	Unit after linearization	→ ➡ 147
	Free text	→ 🗎 148
	Maximum value	→ 🗎 149
	Diameter	→ 🗎 149
	Intermediate height	→ 🗎 150
	Table mode	→ 🗎 150

	► Edit table		
			7
		Level	
		Customer value	]
	Activate table		→ 🗎 152
► Safety settings			→ 🗎 153
	Output echo lost		→ 🗎 153
	Value echo lost		→ 🖺 153
	Ramp at echo lost		→ 🖺 154
	Blocking distance		→ 🗎 141
► Probe settings		]	→ 🗎 156
	Probe grounded		→ 🖺 156
	► Probe length cor	rrection	→ 🗎 158
		Confirm probe length	] → 🗎 158
		Present probe length	→ 🗎 158
► Switch output		]	→ 🗎 159
	Switch output funct	ion	→ 🖺 159
	Assign status		→ 🗎 159
	Assign limit		→ 🗎 160
	Assign diagnostic b	ehavior	→ 🗎 160
	Switch-on value		→ 🗎 161
	Switch-on delay		→ 🗎 162
	Switch-off value		→ 🗎 162
	Switch-off delay		→ 🗎 163
	Failure mode		→ 🗎 163

	Switch status	→ 🗎 163
	Invert output signal	→ 🗎 163
► Dis	splay	→ 🗎 165
	Language	→ 🗎 165
	Format display	→ 🗎 165
	Value 1 to 4 display	→ 🗎 167
	Decimal places 1 to 4	→ 🗎 167
	Display interval	→ 🗎 168
	Display damping	→ 🗎 168
	Header	→ 🗎 168
	Header text	→ ¹ 169
	Separator	→ 🗎 169
	Number format	→ 🗎 169
	Decimal places menu	→ 🗎 169
	Backlight	→ 🗎 170
	Contrast display	→ 🗎 170
► Co	nfiguration backup display	→ 🗎 171
	Operating time	→ 🖹 171
	Last backup	→ 🗎 171

			Configuration mana	agement	→ 🗎 171
			Comparison result		→ 🗎 172
		► Administration		]	→ 🗎 174
			► Define access co	de	→ 🗎 176
				Define access code	→ 🗎 176
				Confirm access code	→ 🗎 176
			Device reset		→ 🗎 174
엇. Diagnostics		]			→ 🗎 177
	Actual diagnostics		]		→ 🗎 177
	Previous diagnostic	S	]		→ 🗎 177
	Operating time from	n restart	]		→ 🗎 178
	Operating time		]		→ 🗎 171
	► Diagnostic list				→ 🗎 179
		Diagnostics 1 to 5		]	→ 🗎 179
	► Event logbook		]		→ 🗎 180
		Filter options		]	
		► Event list		]	→ 🗎 180
	► Device informat	ion	]		→ 🗎 181
		Device tag		]	→ 🗎 181
		Serial number		]	→ 🗎 181
		Firmware version		]	→ 🗎 181
		Device name		]	→ 🗎 182
		Order code		-	→ 🗎 182
		Extended order cod	e 1 to 3	-	→ 🗎 182

► Measured value	S		→ 🗎 183
	Distance		→ 🖺 129
	Level linearized		→ 🗎 149
	Terminal voltage 1		→ 🗎 184
► Analog inputs			
	► Analog input 1 t	o 5	→ 🗎 184
		Block tag	→ 🗎 134
		Channel	→ 🗎 134
		Status	→ 🗎 185
		Value	→ 🗎 185
		Units index	→ 🗎 185
► Data logging			→ 🗎 186
	Assign channel 1 to	4	→ 🗎 186
	Logging interval		→ 🗎 187
	Clear logging data		→ 🗎 187
	► Display channel	1 to 4	→ 🗎 188
► Simulation			→ 🗎 191
	Assign measuremen	t variable	→ 🗎 192
	Process variable val	le	→ 🗎 192
	Switch output simul	ation	→ 🗎 192
	Switch status		→ 🗎 193
	Simulation device al	arm	→ 🗎 193
► Device check			→ 🗎 194
	Start device check		→ 🗎 194
	Result device check		→ 🗎 194

Last check time	] → 🗎 194
Level signal	] → 🗎 195
Launch signal	] → 🗎 195

# 17.2 Overview of the operating menu (operating tool)

Navigation 🗐 Opera

Operating menu

🗲 Setup					→ 🗎 134
	Distance unit				
	Tank type				
	Tube diameter				
	Medium group				
	Empty calibration				
	Full calibration				
	Level				
	Distance				
	Signal quality				
	Confirm distance				
	Present mapping				
	Mapping end point				
	Record map				
	► Analog inputs				
		► Analog input 1 to	o 5		→ 🖺 134
			Block tag		→ 🖺 134
			Channel		→ 🖺 134
			Process Value Filter	Time	→ 🖺 135
	► Advanced setup				→ 🖺 136
		Locking status			→ 🖺 136
		Access status tooling	g		→ 🖺 136
		Enter access code			→ 🗎 137

► Level			→ 🗎 138
	Medium type	]	→ 🗎 138
	Medium property		→ 🗎 138
	Process property	]	→ 🖺 139
	Advanced process conditions	]	→ 🗎 140
	Level unit	]	→ 🗎 141
	Blocking distance	]	→ 🗎 141
	Level correction	]	→ 🗎 142
► Linearization			→ 🗎 144
	Linearization type	]	→ 🖺 146
	Unit after linearization		→ 🗎 147
	Free text		→ 🖺 148
	Level linearized		→ 🖺 149
	Maximum value		→ 🖺 149
	Diameter		→ 🗎 149
	Intermediate height	]	→ 🗎 150
	Table mode	]	→ 🗎 150
	Table number	]	→ 🗎 151
	Level	]	→ 🗎 151
	Level	]	→ 🗎 152
	Customer value	]	→ 🗎 152
	Activate table	]	→ 🗎 152
► Safety settings			→ 🗎 153
	Output echo lost		→ 🖺 153
	Value echo lost	]	→ 🗎 153

	Ramp at echo lost	-	→ 🖺 154
	Blocking distance	-	→ 🖺 141
► Probe settings			→ 🖺 156
	Probe grounded		→ 🖺 156
	Present probe length		→ 🖺 156
	Confirm probe length		→ 🖺 157
► Switch output			→ 🖺 159
> Switch output			, 81))
	Switch output function		→ 🖺 159
	Assign status		→ 🖺 159
	Assign limit	-	→ 🖺 160
	Assign diagnostic behavior		→ 🖺 160
	Switch-on value		→ 🖺 161
	Switch-on delay		→ 🖺 162
	Switch-off value		→ 🖺 162
	Switch-off delay		→ 🖺 163
	Failure mode	-	→ 🖺 163
	Switch status	-	→ 🗎 163
	Invert output signal		→ 🗎 163
► Display		-	→ 🗎 165
	Language		→ 🖺 165
	Format display		→ 🖺 165
	Value 1 to 4 display	-	→ 🗎 167
	Decimal places 1 to 4	-	→ 🖺 167
	Display interval	-	→ 🖺 168
	Display damping		→ 🗎 168

	Header	→ 🗎 168
	Header text	→ 🗎 169
	Separator	→ 🗎 169
	Number format	→ 🗎 169
	Decimal places menu	→ ➡ 169
	Backlight	→ ➡ 170
	Contrast display	→ 🗎 170
► Configuration ba	ackup display	→ 🗎 171
	Operating time	→ 🗎 171
	Last backup	→ 🗎 171
	Configuration management	→ 🗎 171
	Backup state	→ 🗎 172
	Comparison result	→ 🗎 172
► Administration		→ 🗎 174
	Define access code	
	Device reset	→ 🗎 174
얺. Diagnostics		→ 🗎 177
Actual diagnostics	]	→ 🗎 177
Timestamp	-	→ 🗎 177
Previous diagnostics	-	→ 🗎 177
Timestamp	]	→ 🗎 178
Operating time from restart	]	→ 🗎 178
Operating time	]	→ 🗎 171

► Diagnostic list				→ @	179
	Diagnostics 1 to 5			$\rightarrow$	179
	Timestamp 1 to 5			$\rightarrow$	179
► Device informat	ion			→ 🖺	181
	Device tag			→ 🖺	181
	Serial number			→ @	181
	Firmware version			→ 🖺	181
	Device name			→ 🖺	182
	Order code			→ 🖺	182
	Extended order code	1 to 3		→ 🖺	182
► Measured value	25			→ 🖺	183
	Distance			→ 🖺	129
	Level linearized			→ 🖺	149
	Terminal voltage 1			$\rightarrow$	184
► Analog inputs					
	► Analog input 1 to	5		$\rightarrow$	184
	[	Block tag		→ 🖺	134
	[	Channel		→ 🖺	134
		Status		$\rightarrow$	185
	[	Value		$\rightarrow$	185
	[	Units index		→	185
► Data logging				$\rightarrow$	186
	Assign channel 1 to	4		$\rightarrow$	186
	Logging interval			$\rightarrow$	187
	Clear logging data			→ 🖺	187

► Simulation			→ 🗎 191
	Assign measurement variable	]	→ 🗎 192
	Process variable value	]	→ 🗎 192
	Switch output simulation	]	→ 🗎 192
	Switch status	]	→ 🗎 193
	Simulation device alarm	]	→ 🗎 193
► Device check			→ 🗎 194
	Start device check	]	→ 🗎 194
	Result device check	]	→ 🗎 194
	Last check time	]	→ 🗎 194
	Level signal	]	→ 🗎 195
	Launch signal	]	→ 🗎 195
► Heartbeat			→ 🖺 196

Distance unit			Â
Navigation	■ Setup → Dis	tance unit	
Description	Length unit for dis	Length unit for distance calculation.	
Selection	<i>SI units</i> ■ mm ■ m	US units • ft • in	

#### "Setup" menu 17.3

- 🗐 : Indicates how to navigate to the parameter using the display and operating module
  - 🖃 : Indicates how to navigate to the parameter using operating tools (e.g. FieldCare)
  - 🗊 : Indicates parameters that can be locked via the access code.

Navigation

Distance unit			
Navigation	Image: Barbon Barbo	ance unit	
Description	Length unit for distance calculation.		
Selection	<i>SI units</i> ■ mm ■ m	US units • ft • in	

🛛 🖃 Setup

# Tank type _ _

Navigation	
Prerequisite	Medium type (→ 🗎 138) = Liquid
Description	Select tank type.
Selection	<ul> <li>Metallic</li> <li>Bypass / pipe</li> <li>Non metallic</li> <li>Mounted outside</li> <li>Coaxial</li> </ul>
Factory setting	Depending on the probe
Additional information	<ul> <li>Depending on the probe some of the options mentioned above may not be available or there may be additional options.</li> <li>For coax probes and probes with metallic center washer <b>Tank type</b> parameter corresponds to the type of probe and cannot be changed.</li> </ul>

Tube diameter		
Navigation		
Prerequisite	Tank type (→ 🗎 126) = Bypass / pipe	

A


Description Specify diameter of bypass or stilling well.

User entry 0 to 9.999 m

Medium group		ß
Navigation		р
Prerequisite	Medium type (Ə 🗎 138) =	Liquid
Description	Select medium group.	
Selection	<ul><li>Others</li><li>Water based (DC &gt;= 4)</li></ul>	
Additional information		ifies the dielectric constant (DC) of the medium. For a more use the <b>Medium property</b> parameter ( $\rightarrow \square$ 138).
	The <b>Medium group</b> paramet follows:	ter presets the <b>Medium property</b> parameter ( $ ightarrow  extsf{B}$ 138) as
	Medium group	Medium property ( $\Rightarrow \square 138$ )
	Others	Unknown
	Water based (DC $\geq$ = 4)	DC 4 7



The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.




# **Empty calibration**

Navigation	Setup → Empty calibr.
Description	Distance process connection to min. level.
User entry	Depending on the probe
Factory setting	Depending on the probe

æ

# Additional information






# Full calibration

Navigation	
Description	Span: max. level - min level.
User entry	Depending on the probe
Factory setting	Depending on the probe

# Additional information





# Level

# Navigation


Image: Barbon Barbo

Description

Displays measured level  $L_L$  (before linearization).

Â

# Additional information



34 Level in case of liquid measurements

The unit is defined in the **Level unit** parameter ( $\Rightarrow \square 141$ ).

# Distance

Navigation

□ □ Setup → Distance

Description

Displays the measured distance  $D_{\rm L}$  between the reference point (lower edge of the flange or threaded connection) and the level.

 $\mathsf{D}_\mathsf{L}$ 

ŧ

## Additional information

35 Distance for liquid measurements



The unit is defined in the **Distance unit** parameter ( $\rightarrow \square$  126).

Signal quality	
Navigation	
Description	Displays the signal quality of the evaluated echo.
Additional information	<ul> <li>Meaning of the display options</li> <li>Strong <ul> <li>The evaluated echo exceeds the threshold by at least 10 mV.</li> </ul> </li> <li>Medium <ul> <li>The evaluated echo exceeds the threshold by at least 5 mV.</li> </ul> </li> <li>Weak <ul> <li>The evaluated echo exceeds the threshold by less than 5 mV.</li> </ul> </li> <li>No signal <ul> <li>The device does not find a usable echo.</li> </ul> </li> </ul>
	<ul> <li>The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo⁴⁾ or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets.</li> <li>In case of a lost echo (Signal quality = No signal) the device generates the following error message:</li> <li>F941, for Output echo lost (→  153) = Alarm.</li> <li>S941, if another option has been selected in Output echo lost (→  153).</li> </ul>

Confirm distance		æ
Navigation	□ Setup $\rightarrow$ Confirm distance	
Description	Specify, whether the measured distance matches the real distance.	
	Depending on the selection the device automatically sets the range of mapping.	
Selection	<ul> <li>Manual map</li> <li>Distance ok</li> <li>Distance unknown</li> <li>Distance too small *</li> <li>Distance too big *</li> <li>Tank empty</li> <li>Delete map</li> </ul>	
Additional information	<ul> <li>Meaning of the options</li> <li>Manual map To be selected if the range of mapping is to be defined manually in the Mapping energy point parameter (→  131). In this case it is not necessary to confirm the distance. </li> <li>Distance ok To be selected if the measured distance matches the actual distance. The device performs a mapping. </li> <li>Distance unknown To be selected if the actual distance is unknown. A mapping can not be performed in case.</li></ul>	

Of these two echos the one with the lower quality is indicated. Visibility depends on order options or device settings 4)

# Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Distance too big⁵

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range.

# Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.

If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.

Present mapping		
Navigation	□ Setup $\rightarrow$ Present mapping	
Description	Indicates up to which distance a mapping has already been recorded.	
Mapping end point	l	£
Navigation	Setup $\rightarrow$ Map. end point	
Prerequisite	Confirm distance (→ 🗎 130) = Manual map or Distance too small	
Description	Specify new end of the mapping.	
User entry	0 to 200 000.0 m	
Additional information	This parameter defines up to which distance the new mapping is to be recorded. The distance is measured from the reference point, i.e. from the lower edge of the mounting flange or the threaded connection.	
	For reference purposes the <b>Present mapping</b> parameter (→  131) is displayed together with this parameter. It indicates up to which distance a mapping has alread been recorded.	ly

⁵⁾ Only available for "Expert  $\rightarrow$  Sensor  $\rightarrow$  Echo tracking  $\rightarrow$  **Evaluation mode** parameter" = "Short time history" or "Long time history"

Record map	۵
Navigation	□ Setup $\rightarrow$ Record map
Prerequisite	Confirm distance ( > 🗎 130) = Manual map or Distance too small
Description	Start recording of the map.
Selection	<ul><li>No</li><li>Record map</li><li>Delete map</li></ul>
Additional information	<ul> <li>Meaning of the options</li> <li>No <ul> <li>No</li> <li>The map is not recorded.</li> </ul> </li> <li>Record map <ul> <li>The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing ☑.</li> </ul> </li> <li>Delete map <ul> <li>The mapping (if one exists) is deleted and the device displays the recalculated measured distance and the mapping range. When operating via the local display, these values must be confirmed by pressing ☑.</li> </ul> </li> </ul>

	17.3.1 "Mapping" wizard	
	<ul> <li>The Mapping wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the Setup menu (→</li></ul>	
	Navigation Setup $\rightarrow$ Mapping	
Confirm distance		
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🗎 130	
Mapping end point	۵	
Navigation	Setup → Mapping → Map. end point	
Description	→ 🗎 131	
Record map	<u> </u>	
Navigation	Setup → Mapping → Record map	
Description	→ 🗎 132	
Distance		
Navigation		
Description	→ 🗎 129	

	There is an <b>Analog inputs</b> submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.		
	Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the <b>Expert</b> menu.		
	<i>Navigation</i> $\square$ Setup $\rightarrow$ Analog inputs $\rightarrow$ Analog input 1 to 5		
Block tag			
Navigation	Setup → Analog inputs → Analog input 1 to 7 → Block tag		
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.		
User entry	Character string comprising numbers, letters and special characters (32)		
Channel			
Navigation	■ Setup $\rightarrow$ Analog inputs $\rightarrow$ Analog input 1 to 7 $\rightarrow$ Channel		
Description	Use this function to select the input value that should be processed in the Analog Input function block.		
Selection	<ul> <li>Uninitialized</li> <li>Level linearized</li> <li>Absolute echo amplitude</li> <li>Absolute EOP amplitude *</li> <li>Absolute interface amplitude *</li> <li>Distance</li> <li>Electronic temperature</li> <li>EOP shift</li> <li>Interface linearized *</li> <li>Interface distance *</li> <li>Measured capacitance *</li> <li>Relative echo amplitude *</li> <li>Noise of signal</li> <li>Terminal voltage</li> <li>Thickness upper layer *</li> <li>Calculated DC value *</li> <li>Analog output adv. diagnostics 2</li> <li>Analog output adv. diagnostics 1</li> </ul>		

"Analog input 1 to 5" submenu

17.3.2

^{*} Visibility depends on order options or device settings

Process Value Filter Time	
Navigation	
Description	Use this function to enter the filter time specification for the filtering of the unconverted input value (PV).
User entry	Positive floating-point number
Additional information	<i>Factory setting</i> If the value 0 s is entered, filtering will not be performed.

# 17.3.3 "Advanced setup" submenu

```
Navigation \square Setup \rightarrow Advanced setup
```

Locking status	
Navigation	Image: Boosting Setup → Advanced setup → Locking status
Description	Indicates the write protection with the highest priority that is currently active.
User interface	<ul><li>Hardware locked</li><li>Temporarily locked</li></ul>
Additional information	<ul> <li>Meaning and priorities of the types of write protection</li> <li>Hardware locked (priority 1) <ul> <li>The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.</li> </ul> </li> <li>SIL locked (priority 2) <ul> <li>The SIL mode is activated. Writing access to the relevant parameters is denied.</li> </ul> </li> <li>WHG locked (priority 3) <ul> <li>The WHG mode is activated. Writing access to the relevant parameters is denied.</li> </ul> </li> <li>Temporarily locked (priority 4) <ul> <li>Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.</li> </ul> </li> <li>On the display module, the symbol appears in front of parameters that cannot be modified since they are write-protected.</li> </ul>

# Access status toolingNavigation $\Box$ Setup $\rightarrow$ Advanced setup $\rightarrow$ Access stat.toolDescriptionShows the access authorization to the parameters via the operating tool.Additional information $\boxdot$ The access authorization can be changed via the Enter access code parameter<br/>( $\rightarrow \blacksquare 137$ ).If additional write protection is active, this restricts the current access authorization<br/>even further. The write protection status can be viewed via the Locking status<br/>parameter ( $\rightarrow \blacksquare 136$ ).

Access status display		
Navigation	9	Setup $\rightarrow$ Advanced setup $\rightarrow$ Access stat.disp
Prerequisite	The	device has a local display.

Description	Indicates access authorization to parameters via local display.	
Additional information	The access authorization can be changed via the <b>Enter access code</b> parameter $(\rightarrow \cong 137)$ .	
	If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the <b>Locking status</b> parameter ( $\rightarrow \cong 136$ ).	
Enter access code		
Navigation	$ \qquad \qquad$	
Description	Enter access code to disable write protection of parameters.	
User entry	0 to 9 999	
Additional information	<ul> <li>The customer-specific access code that was defined in the Define access code parameter (→ ) 174) must be entered for local operation.</li> <li>If an incorrect access code is entered, users retain their current access authorization.</li> <li>The write protection affects all parameters marked with the ) symbol in the document. On the local display, the ) symbol in front of a parameter indicates that the parameter is write-protected.</li> <li>If no key is pressed for 10 minutes or the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after another 60 s.</li> </ul>	

Please contact your Endress+Hauser Sales Center if you lose your access code.

# "Level" submenu

Navigation

 $\blacksquare \square \quad \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Level}$ 

Medium type		
Navigation	Image: Beauty → Advanced setup → Level → Medium type	
Description	Specify type of medium.	
User interface	<ul><li>Liquid</li><li>Solid</li></ul>	
Factory setting	FMP50, FMP51, FMP52, FMP53, FMP54, FMP55: Liquid	
Additional information	This parameter determines the value of several other parameters and strongly influences the complete signal evaluation. Therefore, it is strongly recommended to change the factory setting.	not

Medium property		
Navigation		
Prerequisite	EOP level evaluation $\neq$ Fix DC	
Description	Specify the dielectric constant $\epsilon_r$ of the medium.	
Selection	<ul> <li>Unknown</li> <li>DC 1.4 1.6</li> <li>DC 1.6 1.9</li> <li>DC 1.9 2.5</li> <li>DC 2.5 4</li> <li>DC 4 7</li> <li>DC 7 15</li> <li>DC &gt; 15</li> </ul>	
Factory setting	Depends on the Medium type ( $ ightarrow  extsf{B}$ 138) and Medium group ( $ ightarrow  extsf{B}$ 127) paramet	ters.

# Additional information

Dependency of "Medium type" and "Medium group"

Medium type (→ 🗎 138)	Medium group (→ 🗎 127)	Medium property
Solid		Unknown
Liquid	Water based (DC $\geq$ = 4)	DC 4 7
	Others	Unknown

For the dielectric constants (DC values) of many media commonly used in industry, please refer to:

- Dielectric constant (DC value) Compendium CP01076F
- The Endress+Hauser "DC Values app" (available for Android and iOS)

If **EOP level evaluation** = **Fix DC**, the exact dielectric constant must be specified in the **DC value** parameter. The **Medium property** parameter therefore does not apply in this case.

76

< 1

Process property		۵	
Navigation	□ Setup → Advanced setup → Level → Process property		
Description	Specify typical rate of level change.		
Selection	For "Medium type" = "Liquid" Very fast > 10 m (400 in)/min Fast > 1 m (40 in)/min Standard < 1 m (40in) /min Medium < 10 cm (4in) /min Slow < 1 cm (0.4in) /min No filter / test		
	For "Medium type" = "Solid" • Very fast > 100 m (333 ft) /h • Fast > 10 m (33 ft) /h • Standard < 10 m (33 ft) /h • Medium < 1 m (3ft) /h • Slow < 0.1 m (0.3ft) /h • No filter / test		
Additional information       The device adjusts the signal evaluation filters and the damping of the outputypical rate of level change defined in this parameter:         For "Operating mode" = "Level" and "Medium type" = "Liquid"		ameter:	
	Process property	Step response time / s	
	Very fast > 10 m (400 in)/min	5	
	Fast > 1 m (40 in)/min	5	
	Standard < 1 m (40in) /min	14	
	Medium < 10 cm (4in) /min	39	

Slow < 1 cm (0.4in) /min

No filter / test

Process property	Step response time / s
Very fast > 100 m (333 ft) /h	37
Fast > 10 m (33 ft) /h	37
Standard < 10 m (33 ft) /h	74
Medium < 1 m (3ft) /h	146
Slow < 0.1 m (0.3ft) /h	290
No filter / test	< 1

# For "Operating mode" = "Level" and "Medium type" = "Solid"

For "Operating mode" = "Interface" or "Interface with capacitance"

Process property	Step response time / s
Very fast > 10 m (400 in)/min	5
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	23
Medium < 10 cm (4in) /min	47
Slow < 1 cm (0.4in) /min	81
No filter / test	2.2


# Advanced process conditions

Navigation	Setup → Advanced setup → Level → Adv. conditions
Description	Specify additional process conditions (if required).
Selection	<ul> <li>None</li> <li>Oil/Water condensate</li> <li>Probe near tank bottom</li> <li>Build up</li> <li>Foam (&gt;5cm/0,16ft)</li> </ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Oil/Water condensate (only Medium type = Liquid) Makes sure that in the case of two-phase media only the total level is detected (example: oil/condensate application).</li> <li>Probe near tank bottom (only for Medium type = Liquid) Improves the empty detection, especially if the probe is mounted close to the tank bottom.</li> <li>Build up Enables a safe empty-detection even if the end-of-probe signal has shifted due to build-up.</li> <li>Foam (&gt;5cm/0,16ft) (only for Medium type = Liquid) Optimizes the signal evaluation in applications with foam formation.</li> </ul>

A

Level unit		R
Navigation	Image: Betup → Advanced set	$tup \rightarrow Level \rightarrow Level unit$
Description	Select level unit.	
Selection	SI units ■ % ■ m ■ mm	US units • ft • in
Additional information	The level unit may differ fro $(\rightarrow \cong 126)$ :	m the distance unit defined in the <b>Distance unit</b> parameter
	calibration ( $\rightarrow \cong 127$ ) as	stance unit parameter is used for the basic calibration (Empty nd Full calibration (→ 🗎 128)). vel unit parameter is used to display the (unlinearized) level.


Blocking distance	
Navigation	Image: Setup → Advanced setup → Level → Blocking dist.
Description	Specify upper blocking distance UB.
User entry	0 to 200 m
Factory setting	For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)
Additional information	Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.
	<ul> <li>This behavior is only valid if the following two conditions are met:</li> <li>Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)</li> <li>Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction</li> </ul>
	If one of these conditions is not met, signals in the blocking distance will always be ignored.
	If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 36 Blocking distance (UB) for liquid measurements

Level correction	٦
Navigation	$ \blacksquare \Box  \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Level} \rightarrow \text{Level correction} $
Description	Specify level correction (if required).
User entry	-200000.0 to 200000.0 %
Additional information	The value specified in this parameter is added to the measured level (before linearization).

# "Linearization" submenu



- 37 Linearization: Conversion of the level and, if applicable, interface into a volume or a weight; the conversion depends on the vessel shape
- 1 Selection of linearization type and unit
- 2 Configuration of the linearization
- A Linearization type ( $\rightarrow \square 146$ ) = None
- *B* Linearization type ( $\Rightarrow \square 146$ ) = Linear
- *C* Linearization type ( $\rightarrow \square 146$ ) = Table
- *D* Linearization type ( $\rightarrow \square 146$ ) = Pyramid bottom
- *E* Linearization type ( $\rightarrow \square 146$ ) = Conical bottom
- *F* Linearization type ( $\rightarrow \square 146$ ) = Angled bottom
- *G* Linearization type ( $\rightarrow \square 146$ ) = Horizontal cylinder
- *H* Linearization type ( $\rightarrow \square 146$ ) = Sphere
- *I* For "Operating mode" = "Interface" or "Interface with capacitance": interface before linearization (measured in the level unit)
- *I'* For "Operating mode" = "Interface" or "Interface with capacitance": interface after linearization (corresponds to volume or weight)
- L Level before linearization (measured in level unit)
- L' Level linearized ( $\rightarrow \cong 149$ ) (corresponds to volume or weight)
- M Maximum value ( $\rightarrow \square 149$ )
- d Diameter ( $\rightarrow \square 149$ )
- h Intermediate height ( $\rightarrow \square 150$ )

Linearization
Linearization type
Unit after linearization
Free text
Maximum value
Diameter
Intermediate height
Table mode
► Edit table
Level
Customer value
Activate table

Structure of the submenu on the local display

*Navigation*  $\blacksquare$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization

Structure o	of the	submenu	in the	e operatina	a tool (e	e.g. FieldCare)	
0 0.0000 0 0	J 0.00	00001100100		operation	,	Jig. 1 10101000.07	

Navigation

 $\mathsf{Setup} \to \mathsf{Advanced} \ \mathsf{setup} \to \mathsf{Linearization}$ 

Linearization	
	Linearization type
	Unit after linearization
	Free text
	Level linearized
	Maximum value
	Diameter
	Intermediate height
	Table mode
	Table number
	Level
	Level
	Customer value
	Activate table


Description of the parameters

*Navigation*  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Linearization

## Linearization type Image: Setup → Advanced setup → Linearization → Lineariz. type Navigation Image: Setup → Advanced setup → Linearization → Lineariz. type Description Select linearization type. Selection Image: None Image: Linearization + Table Pyramid bottom Operation + Description Image: Considered + Description

- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

#### Additional information



8 B 38 Linearization types

- A None
- B Table
- C Pyramid bottom
- D Conical bottom
- *E* Angled bottom
- F Sphere
- G Horizontal cylinder

#### Meaning of the options

None

The level is output in the level unit without being converted (linearized) beforehand.

Linear

The output value (volume/weight) is proportional to the level L. This applies, for example, to vertical cylindrical tanks and silos. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \triangleq 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- Table

The relationship between the measured level L and the output value (volume/weight) is defined by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight" respectively. The following parameters must also be specified:

- Unit after linearization ( $\Rightarrow \square 147$ )
- Table mode (→ 
   [™]
   [™]
   150)
- For every point in the table: Level ( $\rightarrow \square 151$ )
- For every point in the table: **Customer value (→** 🗎 152)
- Activate table ( $\rightarrow \triangleq 152$ )
- Pyramid bottom

The output value corresponds to the volume or weight in a silo with a pyramid bottom. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \square 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- Intermediate height (→ 
  □ 150): the height of the pyramid
- Conical bottom

The output value corresponds to the volume or weight in a tank with a conical bottom. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \square 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- Intermediate height (→ 
   ^(⇒) 150): the height of the cone
- Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \square 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- **Intermediate height (→** 🗎 **150)**: height of the angled bottom
- Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \square 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- Diameter (→ 🗎 149)
- Sphere

The output value corresponds to the volume or weight in a spherical tank. The following parameters must also be specified:

- Unit after linearization ( $\rightarrow \cong 147$ )
- Maximum value (→ 🗎 149): maximum volume or weight
- Diameter (→ 🗎 149)

Unit after linearization

£

Navigation	Setup → Advanced setup → Linearization → Unit lineariz.
Prerequisite	Linearization type (→ 🗎 146) ≠ None

Description	Select the unit for the linearized value.
Selection	Selection/input (uint16) 1095 = [short Ton] 1094 = [lb] 1088 = [kg] 1092 = [Ton] 1044 = [US Gal.] 1049 = [Imp. Gal.] $1043 = [tt^3]$ $1035 = [dm^3]$ $1035 = [dm^3]$ $1034 = [m^3]$ $1034 = [m^3]$ $1034 = [m^3]$ 1034 = [m] 1010 = [m] 1010 = [m] 1010 = [m] 1012 = [mm] 1012 = [mm] 1013 = [tt] 1019 = [inch] 1351 = [l/s] 1352 = [l/min] 1353 = [l/h] $1349 = [m^3/n]$ $1354 = [tt^3/s]$ $1357 = [tt^3/min]$ $1358 = [tt^3/n]$ 1354 = [US Gal./s] 1354 = [US Gal./h] 1355 = [Imp. Gal./s] 1355 = [Imp. Gal./h] 13251 = [Mi/d]
Additional information	<ul> <li>The selected unit is only used for display purposes. The measured value is not converted on the basis of the selected unit.</li> <li>Distance-to-distance linearization is also possible, i.e. a linearization from the level unit to another length unit. Select the Linear linearization mode for this purpose. To specify the new level unit, select the Free text option in the Unit after linearization parameter and enter the unit in the Free text parameter (→ ) 148)</li> </ul>

Free text		
Navigation	Image: Setup → Advanced setup → Linearization → Free text	
Prerequisite	Unit after linearization ( $\rightarrow \equiv 147$ ) = Free text	
1	· · · · · · · · · · · · · · · · · · ·	
Description	Enter unit symbol.	

parameter and enter the unit in the **Free text** parameter ( $\rightarrow \square 148$ ).

#### **User entry** Up to 32 alphanumerical characters (letters, numbers, special characters)

Level linearized		
Navigation		Setup $\rightarrow$ Advanced setup $\rightarrow$ Linearization $\rightarrow$ Level linearized
Description	Displ	ays linearized level.
Additional information	i	The unit is defined by the <b>Unit after linearization</b> parameter $\rightarrow \equiv 147$ .

Maximum value		
Navigation		
Prerequisite	<ul> <li>Linearization type (→ ) 146) has one of the following values:</li> <li>Linear</li> <li>Pyramid bottom</li> <li>Conical bottom</li> <li>Angled bottom</li> <li>Horizontal cylinder</li> <li>Sphere</li> </ul>	
User entry	-50 000.0 to 50 000.0 %	

Diameter		
Navigation		
Prerequisite	<ul> <li>Linearization type (→  ^B 146) has one of the following values:</li> <li>Horizontal cylinder</li> <li>Sphere</li> </ul>	
User entry	0 to 9 999.999 m	
Additional information	The unit is defined in the <b>Distance unit</b> parameter ( $\rightarrow \implies 126$ ).	

#### Intermediate height

A

Navigation	Image: Setup → Advanced setup → Linearization → Intermed. height
Prerequisite	<ul> <li>Linearization type (→  ^B 146) has one of the following values:</li> <li>Pyramid bottom</li> <li>Conical bottom</li> <li>Angled bottom</li> </ul>
User entry	0 to 200 m
Additional information	Intermediate height

H Intermediate height

The unit is defined in the **Distance unit** parameter ( $\rightarrow \square$  126).

Table mode	Â
Navigation	
Prerequisite	Linearization type ( $\rightarrow \cong 146$ ) = Table
Description	Select editing mode of the linearization table.
Selection	<ul> <li>Manual</li> <li>Semiautomatic[*]</li> <li>Clear table</li> <li>Sort table</li> </ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Manual The level and the associated linearized value are entered manually for each linearization point. </li> <li>Semiautomatic The level is measured by the device for each linearization point. The associated linearized value is entered manually. </li> <li>Clear table Deletes the existing linearization table. </li> <li>Sort table Rearranges the linerization points into an ascending order.</li></ul>

^{*} Visibility depends on order options or device settings




Table number		
Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Linearization $\rightarrow$ Table number	
Prerequisite	Linearization type (→ 🗎 146) = Table	
Description	Select table point you are going to enter or change.	
User entry	1 to 32	
Level (Manual)		
Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Linearization $\rightarrow$ Level	
Prerequisite	<ul> <li>Linearization type (→ ≅ 146) = Table</li> <li>Table mode (→ ≅ 150) = Manual</li> </ul>	
Description	Enter level value of the table point (value before linearization).	

User entry Signed floating-point number

A

# Level (Semiautomatic) Navigation □ Setup → Advanced setup → Linearization → Level Prerequisite • Linearization type (→ □ 146) = Table<br/>• Table mode (→ □ 150) = Semiautomatic Description Displays measured level (value before linearization). This value is transmitted to the table.

#### **Customer value**

Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Linearization $\rightarrow$ Customer value	
Prerequisite	Linearization type ( > 🗎 146) = Table	
Description	Enter linearized value for the table point.	
User entry	Signed floating-point number	

### Activate table

Navigation	$\square$ Setup → Advanced setup → Linearization → Activate table
Prerequisite	Linearization type ( $\rightarrow \triangleq 146$ ) = Table
Description	Activate (enable) or deactivate (disable) the linearization table.
Selection	<ul><li>Disable</li><li>Enable</li></ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Disable The measured level is not linearized. If Linearization type (→  [□] 146) = Table at the same time, the device issues error message F435. </li> <li>Enable The measured level is linearized according to the table.</li></ul>

When editing the table, the **Activate table** parameter is automatically reset to **Disable** and must be reset to **Enable** after the table has been entered.

#### "Safety settings" submenu

*Navigation*  $\square \square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Safety sett.

Output echo lost	
Navigation	
Description	Output signal in case of a lost echo.
Selection	<ul> <li>Last valid value</li> <li>Ramp at echo lost</li> <li>Value echo lost</li> <li>Alarm</li> </ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Last valid value The last valid value is kept in the case of a lost echo.</li> <li>Ramp at echo lost ⁶⁾ In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the Ramp at echo lost parameter (→ 🗎 154).</li> <li>Value echo lost ⁶⁾ In the case of a lost echo the output assumes the value defined in the Value echo lost parameter (→ 🗎 153).</li> <li>Alarm In the case of a lost echo the device generates an alarm; see the Failure mode parameter</li> </ul>

Value echo lost		
Navigation	Image: Setup → Advanced setup → Safety sett. → Value echo lost	
Prerequisite	Output echo lost (→ 🗎 153) = Value echo lost	
Description	Output value in case of a lost echo	
User entry	0 to 200000.0 %	
Additional information	Use the unit which has been defined for the measured value output: • without linearization: Level unit ( $\rightarrow \cong 141$ ) • with linearization: Unit after linearization ( $\rightarrow \cong 147$ )	

⁶⁾ Only visible if "Linearization type ( $\Rightarrow \square 146$ )" = "None"

A

#### Ramp at echo lost

Navigation	Setup $\rightarrow$ Advanced setu	$p \rightarrow Safe$	ty sett. $\rightarrow$	Ramp echo lost


Prerequisite Output echo lost (→ 🗎 153) = Ramp at echo lost

**Description** Slope of the ramp in the case of a lost echo

Signed floating-point number

#### Additional information

User entry



- A Delay time echo lost
- *B* Ramp at echo lost ( $\rightarrow \square 154$ ) (positive value)
- C Ramp at echo lost ( $\rightarrow \square 154$ ) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/ min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuosly increased until it reaches 100%.

Blocking distance		A
Navigation	Image: Setup → Advanced setup → Safety sett. → Blocking dist.	
Description	Specify upper blocking distance UB.	
User entry	0 to 200 m	
Factory setting	For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)	
Additional information	Signals in the upper blocking distance are only evaluated if they have been outside th blocking distance when the device was switched on and move into the blocking distar	


due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

This behavior is only valid if the following two conditions are met:

- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
- Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



Blocking distance (UB) for liquid measurements

#### "Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** ( $\rightarrow \blacksquare 157$ ) = **Manual input** in order to enter the value manually.

- Alternative: Select Confirm probe length (→ 
   ^(→)) = Manual input and enter the probe length manually into the Present probe length parameter → 
   ^(→)) 156.

An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ( $\rightarrow \triangleq 156$ ).

Navigation

Setup → Advanced setup → Probe settings

Probe grounded	

Navigation	Setup → Advanced setup → Probe settings → Probe grounded
Prerequisite	Operating mode = Level
Description	Specify whether the probe is grounded.
Selection	<ul><li>No</li><li>Yes</li></ul>

Present probe length		
Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Probe settings $\rightarrow$ Pres. length	
Description	<ul> <li>In most cases: Displays the length of the probe according to the currently measured end-of-probe signal.</li> <li>For Confirm probe length (→  157) = Manual input: Enter actual length of probe.</li> </ul>	
User entry	0 to 200 m	

If a mapping (interference echo suppression) has been recorded after shortening the probe, it is no longer possible to perform an automatic probe length correction. In this case there are two options:

Confirm probe length	8
Navigation	$ \qquad \qquad$
Description	Select, whether the value displayed in the <b>Present probe length</b> parameter $\rightarrow \triangleq 156$ matches the actual length of the probe. Based on this input, the device performs a probe length correction.
Selection	<ul> <li>Probe length OK</li> <li>Probe length too small</li> <li>Probe length too big</li> <li>Probe covered</li> <li>Manual input</li> <li>Probe length unknown</li> </ul>
Additional information	Meaning of the options• Probe length OKTo be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.• Probe length too smallTo be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the Present probe length parameter → 🗎 156. This procedure has to be repeated until the displayed value matches the actual length of the probe.• Probe length too bigTo be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the Present probe length parameter → 🖺 156. This procedure has to be repeated until the displayed value matches the actual length of the probe.• Probe length too bigTo be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the Present probe length parameter → 🖺 156. This procedure has to be repeated until the displayed value matches the actual length of the probe.• Probe coveredTo be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device quits the sequence.• Manual inputTo be selected if the probe must be entered manually into the Present probe length parameter → 🖺 156^{-7}.• Probe length unknownTo be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device quits the sequence.

⁷⁾ When operated via FieldCare, the **Manual input** option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited.

	"Probe length correction" wizard	
	The Probe length correction wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the probe length correction are located directly in the Probe settings submenu (→  156).	
	<i>Navigation</i> $\ \ \textcircled{B} \ \blacksquare$ Setup $\rightarrow$ Advanced setup $\rightarrow$ Probe settings $\rightarrow$ Problength cor	'n
Confirm probe length		
Navigation		
Description	→ 🗎 157	
Present probe length		
Navigation	$\textcircled{B} \Box  \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Probe settings} \rightarrow \text{Prob.length corr} \rightarrow \text{Pres. length}$	
Description	→ 🖺 156	

#### "Switch output" submenu



The **Switch output** submenu ( $\rightarrow \implies 159$ ) is only visible for devices with switch

Navigation □ Setup → Advanced setup → Switch output

Switch output function	බ
Navigation	Image: Setup → Advanced setup → Switch output → Switch out funct
Description	Select function for switch output.
Selection	<ul> <li>Off</li> <li>On</li> <li>Diagnostic behavior</li> <li>Limit</li> <li>Digital Output</li> </ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Off <ul> <li>The output is always open (non-conductive).</li> </ul> </li> <li>On <ul> <li>The output is always closed (conductive).</li> </ul> </li> <li>Diagnostic behavior <ul> <li>The output is normally closed and is only opened if a diagnostic event is present. The Assign diagnostic behavior parameter (→ <ul> <li>160) determines for which type of event the output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters: <ul> <li>Assign limit (→ <ul> <li>160)</li> <li>Switch-on value (→ <ul> <li>161)</li> <li>Switch-off value (→ <ul> <li>162)</li> </ul> </li> <li>Digital Output <ul> <li>The switching state of the output tracks the output value of a DI function block. The function block is selected in the Assign status parameter (→ <ul> <li>159).</li> </ul> </li> <li>The Off and On options can be used to simulate the switch output.</li> </ul></li></ul></li></ul></li></ul></li></ul></li></ul></li></ul>

Assign status		Ê
Navigation	$ \blacksquare \square Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign status $	
Prerequisite	Switch output function ( $\Rightarrow \cong 159$ ) = Digital Output	
Selection	<ul> <li>Off</li> <li>Digital output AD 1</li> <li>Digital output AD 2</li> </ul>	

Ordering feature 020 "Power supply; Output", option B, E or G 8)

	<ul> <li>Digital output 1</li> <li>Digital output 2</li> <li>Digital output 3</li> <li>Digital output 4</li> <li>Digital output 5</li> <li>Digital output 6</li> <li>Digital output 7</li> <li>Digital output 8</li> </ul>	
Additional information	The <b>Digital output AD 1</b> and <b>Digital output AD 2</b> options refer to the Advanced Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the switch output.	۱.
Assign limit		ß
Navigation	Image: Setup → Advanced setup → Switch output → Assign limit	
Prerequisite	Switch output function ( $\rightarrow \cong 159$ ) = Limit	
Selection	<ul> <li>Off</li> <li>Level linearized</li> <li>Distance</li> <li>Interface linearized *</li> <li>Interface distance *</li> <li>Thickness upper layer *</li> <li>Terminal voltage</li> <li>Electronic temperature</li> <li>Measured capacitance *</li> <li>Relative echo amplitude</li> <li>Relative interface amplitude *</li> <li>Absolute echo amplitude *</li> </ul>	

Assign diagnostic behavior		Ê
Navigation	Setup → Advanced setup → Switch output → Assign diag. beh	
Prerequisite	Switch output function ( $\Rightarrow \square 159$ ) = Diagnostic behavior	

**Description** Select diagnostic behavior for switch output.

- Selection
- Alarm
- Alarm or warning
- Warning

^{*} Visibility depends on order options or device settings


#### A

#### Switch-on value

Navigation	
Prerequisite	Switch output function ( $\rightarrow \square$ 159) = Limit
Description	Enter measured value for the switch-on point.
User entry	Signed floating-point number
Additional information	The switching behavior depends on the relative position of the <b>Switch-on value</b> and <b>Switch-off value</b> parameters:

#### Switch-on value > Switch-off value


- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

#### Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.



- Α
- В
- С
- Switch-on value Switch-off value Output closed (conductive) Output opened (non-conductive) D

#### Switch-on delay

Navigation	Image: Setup → Advanced setup → Switch output → Switch-on delay
Prerequisite	<ul> <li>Switch output function (→  ^B 159) = Limit</li> <li>Assign limit (→  ^B 160) ≠ Off</li> </ul>
Description	Define delay for the switch-on of status output.
User entry	0.0 to 100.0 s

#### Switch-off value

Navigation	$ \blacksquare \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off value $
Prerequisite	Switch output function ( $\rightarrow \square 159$ ) = Limit
Description	Enter measured value for the switch-off point.
User entry	Signed floating-point number
Additional information	The switching behavior depends on the relative position of the <b>Switch-on value</b> and <b>Switch-off value</b> parameters; description: see the <b>Switch-on value</b> parameter $( \rightarrow \square 161 )$ .

£

ß

Switch-off delay		
Navigation	Image: Setup → Advanced setup → Switch output → Switch-off delay	
Prerequisite	<ul> <li>Switch output function (→ ≧ 159) = Limit</li> <li>Assign limit (→ ≧ 160) ≠ Off</li> </ul>	
Description	Define delay for the switch-off of status output.	
User entry	0.0 to 100.0 s	
Failure mode		Â
Navigation	Image: Setup → Advanced setup → Switch output → Failure mode	
Prerequisite	Switch output function ( $\rightarrow \square$ 159) = Limit or Digital Output	
Description	Define output behavior in alarm condition.	
Selection	<ul><li>Actual status</li><li>Open</li><li>Closed</li></ul>	
Additional information		
Switch status		
Navigation	$ \blacksquare \Box  \text{Setup} \rightarrow \text{Advanced setup} \rightarrow \text{Switch output} \rightarrow \text{Switch status} $	
Description	Shows the current switch output status.	
Invert output signal		
Navigation	Image: Setup → Advanced setup → Switch output → Invert outp.sig.	
Description	Invert the output signal.	
Selection	<ul><li>No</li><li>Yes</li></ul>	

#### Additional information

#### Meaning of the options

- No
  - The behavior of the switch output is as described above.
  - Yes
    - The states **Open** and **Closed** are inverted as compared to the description above.

#### "Display" submenu

**Display** submenu is only visible if a display module is connected to the device.

Navigation 🛛 🗐 🖾 Setu

8 2	Setup $\rightarrow I$	Advanced	l setup →	Display	
-----	-----------------------	----------	-----------	---------	--


Language	
Navigation	Image Setup → Advanced setup → Display → Language
Description	Set display language.
Selection	<ul> <li>English</li> <li>Deutsch*</li> <li>Français*</li> <li>Español*</li> <li>Italiano*</li> <li>Nederlands*</li> <li>Portuguesa*</li> <li>Polski*</li> <li>pycский язык (Russian)*</li> <li>Svenska*</li> <li>Türkçe*</li> <li>中文 (Chinese)*</li> <li>日本語 (Japanese)*</li> <li>한국어 (Korean)*</li> <li>Bahasa Indonesia*</li> <li>tiếng Việt (Vietnamese)*</li> <li>čeština (Czech)*</li> </ul>
Factory setting	The language selected in feature 500 of the product structure. If no language has been selected: <b>English</b>
Additional information	
Format display	
Navigation	Image: Setup → Advanced setup → Display → Format display
Description	Select how measured values are shown on the display.
Selection	<ul> <li>1 value, max. size</li> <li>1 bargraph + 1 value</li> <li>2 values</li> <li>1 value large + 2 values</li> <li>4 values</li> </ul>

^{*} Visibility depends on order options or device settings


#### Additional information




🕑 40 "Format display" = "1 value, max. size"




#### 41 "Format display" = "1 bargraph + 1 value"



#### # 42 "Format display" = "2 values"



#### If a "Format display" = "1 value large + 2 values"



If a "Format display" = "4 values"

- The Value 1 to 4 display → 
  □ 167 parameters specify which measured values are shown on the display and in which order.

A

Value 1 to 4 display		
Navigation	$ \blacksquare \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Value 1 display $	
Description	Select the measured value that is shown on the local display.	
Selection	<ul> <li>Level linearized</li> <li>Distance</li> <li>Interface linearized *</li> <li>Interface distance *</li> <li>Thickness upper layer *</li> <li>Terminal voltage</li> <li>Electronic temperature</li> <li>Measured capacitance *</li> <li>Analog output adv. diagnostics 1</li> <li>Analog output adv. diagnostics 2</li> <li>Analog output 1</li> <li>Analog output 2</li> <li>Analog output 3</li> <li>Analog output 4</li> <li>Analog output 5</li> <li>Analog output 6</li> <li>Analog output 7</li> <li>Analog output 8</li> </ul>	
Factory setting	<ul> <li>For level measurements</li> <li>Value 1 display: Level linearized</li> <li>Value 2 display: Distance</li> <li>Value 3 display: Current output 1</li> <li>Value 4 display: None</li> </ul>	

Image: Setup → Advanced setup → Display → Decimal places 1	
Select the number of decimal places for the display value.	
<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> <li>x.xxx</li> <li>x.xxxx</li> </ul>	
	Select the number of decimal places for the display value.  X X X X X X X X X X X X X X X X X X

Additional information

The setting does not affect the measuring or computational accuracy of the device.


^{*} Visibility depends on order options or device settings

Display interval	
Navigation	
Description	Set time measured values are shown on display if display alternates between values.
User entry	1 to 10 s
Additional information	This parameter is only relevant if the number of selected measuring values exceeds the number of values the selected display format can display simultaneously.

Display damping		
Navigation		
Description	Set display reaction time to fluctuations in the measured value.	
User entry	0.0 to 999.9 s	

Header	<b></b>

Navigation	
Description	Select header contents on local display.
Selection	<ul><li>Device tag</li><li>Free text</li></ul>
Additional information	1 XXXXXXXX



1 Position of the header text on the display

#### Meaning of the options

Device tag Is defined in the Device tag parameter.
Free text

Header text		
Navigation	Image: Setup → Advanced setup → Display → Header text	
Prerequisite	Header (→ 🗎 168) = Free text	
Description	Enter display header text.	
User entry	Character string comprising numbers, letters and special characters (12)	
Additional information	The number of characters which can be displayed depends on the characters used.	

Separator		Â
Navigation	$ \blacksquare \Box Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Separator $	
Description	Select decimal separator for displaying numerical values.	
Selection	■ . ■ ,	

Number format		
Navigation	Image: Boundary Setup → Advanced setup → Display → Number format	
Description	Choose number format for the display.	
Selection	<ul><li>Decimal</li><li>ft-in-1/16"</li></ul>	
Additional information	The <b>ft-in-1/16</b> " option is only valid for distance units.	

8
Image: Setup → Advanced setup → Display → Dec. places menu
Select number of decimal places for the representation of numbers within the operating menu.
<ul> <li>x</li> <li>x.x</li> <li>x.xx</li> <li>x.xxx</li> </ul>

**Contrast display** 

#### Additional information

- Is only valid for numbers in the operating menu (e.g. Empty calibration, Full calibration), but not for the measured value display. The number of decimal places for the measured value display is defined in the Decimal places 1 to 4 → 167 parameters.
- The setting does not affect the accuracy of the measurement or the calculations.

Backlight	
Navigation	Image: Backlight Image: Backlight Image: Backlight
Prerequisite	The device has the SD03 local display (with optical keys).
Description	Switch the local display backlight on and off.
Selection	<ul><li>Disable</li><li>Enable</li></ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Disable Switches the backlight off.</li> <li>Enable Switches the backlight on.</li> </ul>
	Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Navigation	Image: Setup → Advanced setup → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).
User entry	20 to 80 %
Factory setting	Dependent on the display.
Additional information	Setting the contrast via push-buttons: • Darker: press the © © buttons simultaneously.

■ Brighter: press the 🕑 🖲 buttons simultaneously.

#### "Configuration backup display" submenu



This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.

*Navigation*  $\square$  Setup  $\rightarrow$  Advanced setup  $\rightarrow$  Conf.backup disp

Operating time	
Navigation	□ □ Setup → Advanced setup → Conf.backup disp → Operating time
Description	Indicates how long the device has been in operation.
Additional information	Maximum time 9999 d ( ≈ 27 years)

Last backup	
Navigation	■ Setup $\rightarrow$ Advanced setup $\rightarrow$ Conf.backup disp $\rightarrow$ Last backup
Description	Indicates when the last data backup was saved to the display module.

Configuration mana	Configuration management	
Navigation		
Description	Select action for managing the device data in the display module.	
Selection	<ul> <li>Cancel</li> <li>Execute backup</li> <li>Restore</li> <li>Duplicate</li> <li>Compare</li> <li>Clear backup data</li> </ul>	

Display incompatible

#### Additional information Meaning of the options

#### Cancel

No action is executed and the user exits the parameter.

#### Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

#### Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

#### Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration: Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ( $\rightarrow \implies 172$ ).

#### Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state	
Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Conf.backup disp $\rightarrow$ Backup state
Description	Displays which backup action is currently in progress.
Comparison result	
Navigation	Image: Setup → Advanced setup → Conf.backup disp → Compar. result
Description	Comparison between present device data and display backup.

#### Additional information

#### Meaning of the display options

#### Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

- No backup available There is no backup copy of the device configuration of the HistoROM in the display module.
- Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

- Check not done The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.
- Dataset incompatible

The data sets are incompatible and can not be compared.

To start the comparison, set **Configuration management** ( $\rightarrow \equiv 171$ ) = **Compare**.

If the transmitter configuration has been duplicated from a different device by **Configuration management** ( $\rightarrow \implies 171$ ) = **Duplicate**, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be **Settings not identical**.

#### "Administration" submenu

Navigation

Define access code		£
Navigation	□ Setup → Advanced setup → Administration → Def. access code	
Description	Define release code for write access to parameters.	
User entry	0 to 9999	
Additional information	If the factory setting is not changed or if "0" is entered, the parameters are not write- protected and the device configuration data can therefore always be modified. The user is logged on in the "Maintenance" role.	
	The write protection affects all parameters marked with the 🝙 symbol in the document. On the local display, the 🔒 symbol in front of a parameter indicates that the parameter is write-protected.	
	Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the <b>Enter access code</b> parameter $(\rightarrow \cong 137)$ .	
	Please contact your Endress+Hauser Sales Center if you lose the access code.	
	If operating via the local display: the new access code is only valid once it has been confirmed in the <b>Confirm access code</b> parameter ( $\Rightarrow \equiv 176$ ).	

Device reset	
Navigation	□ Setup $\rightarrow$ Advanced setup $\rightarrow$ Administration $\rightarrow$ Device reset
Selection	<ul> <li>Cancel</li> <li>To fieldbus defaults</li> <li>To factory defaults</li> <li>To delivery settings</li> <li>Of customer settings</li> <li>To transducer defaults</li> <li>Restart device</li> </ul>
Additional information	<ul> <li>Meaning of the options</li> <li>Cancel No action</li> <li>To factory defaults All parameters are reset to the order-code specific factory setting.</li> <li>To delivery settings All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered. This option is only visible if customer specific settings have been ordered.</li> </ul>

#### Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

	The <b>Define access code</b> wizard is only available when operating via the local display. When operating via an operating tool, the <b>Define access code</b> parameter is located directly in the <b>Administration</b> submenu. The <b>Confirm access code</b> parameter is no available for operation via operating tool.	
	Navigation $\ensuremath{\boxtimes}$ Setup $\rightarrow$ Advanced setup $\rightarrow$ Administration $\rightarrow$ Def. access code	
Define access code		
Navigation	$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	
Description	→ 🗎 174	
Confirm access code		2
Navigation	$\begin{tabular}{lllllllllllllllllllllllllllllllllll$	
Description	Confirm the entered access code.	
User entry	0 to 9 999	

"Define access code" wizard

#### 17.4 "Diagnostics" menu

Navigation

■ ■ Diagnostics

Actual diagnostics	
Navigation	Image: Barbon Barbo
Description	Displays current diagnostic message.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
	If several messages are active at the same time, the messages with the highest priority is displayed.
	Information on what is causing the message, and remedy measures, can be viewed via the (i) symbol on the display.

Timestamp	
Navigation	□ Diagnostics → Timestamp
Previous diagnostics	
Navigation	
Description	Displays the last diagnostic message which has been active before the current message.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
	The condition displayed may still apply. Information on what is causing the message, and remedy measures, can be viewed via the (i) symbol on the display.

Timestamp	
Navigation	□ Diagnostics $\rightarrow$ Timestamp
Operating time from resta	art
Navigation	
Description	Displays the time the device has been in operation since the last device restart.
Operating time	
Navigation	
Description	Indicates how long the device has been in operation.
Additional information	Maximum time 9999 d ( ≈ 27 years)

#### 17.4.1 "Diagnostic list" submenu

*Navigation*  $\square$  Diagnostics  $\rightarrow$  Diagnostic list

Diagnostics 1 to 5	
Navigation	□ □ Diagnostics $\rightarrow$ Diagnostic list $\rightarrow$ Diagnostics 1
Description	Display the current diagnostics messages with the highest to fifth-highest priority.
Additional information	The display consists of: • Symbol for event behavior • Code for diagnostic behavior • Operating time of occurrence • Event text
Timestamp 1 to 5	
Navigation	■ □ Diagnostics → Diagnostic list → Timestamp 1 to 5

	The <b>Event logbook</b> submenu is only available when operating via the local display When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".	
	Navigation $\square$ Diagnostics $\rightarrow$ Event logbook	
Filter options		
Navigation	Diagnostics $\rightarrow$ Event logbook $\rightarrow$ Filter options	
Selection	<ul> <li>All</li> <li>Failure (F)</li> <li>Function check (C)</li> <li>Out of specification (S)</li> <li>Maintenance required (M)</li> <li>Information (I)</li> </ul>	
Additional information	<ul> <li>This parameter is only used for operation via the local display.</li> <li>The status signals are categorized according to NAMUR NE 107.</li> </ul>	

"Event logbook" submenu

#### "Event list" submenu

17.4.2

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ( $\rightarrow \implies 180$ ). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ∋: Event has occurred
- 🕒: Event has ended

Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

#### **Display format**

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation

Diagnostics  $\rightarrow$  Event logbook  $\rightarrow$  Event list

#### 17.4.3 "Device information" submenu

*Navigation*  $\square$  Diagnostics  $\rightarrow$  Device info


Device tag			
Navigation	8	Diagnostics $\rightarrow$ Device info $\rightarrow$ Device tag Diagnostics $\rightarrow$ Device info $\rightarrow$ Device tag	
Description	Ente	r tag for measuring point.	
User interface	Char	acter string comprising numbers, letters and special characters	
Serial number			Â
Navigation	8	Diagnostics $\rightarrow$ Device info $\rightarrow$ Serial number Diagnostics $\rightarrow$ Device info $\rightarrow$ Serial number	
Additional information		<ul> <li>Uses of the serial number</li> <li>To identify the device quickly, e.g. when contacting Endress+Hauser.</li> <li>To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer</li> <li>The serial number is also indicated on the nameplate.</li> </ul>	
Firmware version			

Navigation	▣	Diagnostics → Device info → Firmware version Diagnostics → Device info → Firmware version
User interface	xx.yy	.ZZ
Additional information		For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.

 Device name			
Navigation		Diagnostics $\rightarrow$ Device info $\rightarrow$ Device name	
		Diagnostics $\rightarrow$ Device info $\rightarrow$ Device name	
Order code			
Navigation		Diagnostics $\rightarrow$ Device info $\rightarrow$ Order code	
		Diagnostics $\rightarrow$ Device info $\rightarrow$ Order code	
User interface	Character string comprising numbers, letters and special characters		
Additional information	The order code is generated from the extended roder code, which defines all device features of the product structure. In contrast, the device features can not be read directly from the order code.		
Extended order code 1 to 3			<b>a</b>
Navigation		Diagnostics $\rightarrow$ Device info $\rightarrow$ Ext. order cd. 1	
	0	Diagnostics $\rightarrow$ Device info $\rightarrow$ Ext. order cd. 1	
Description	Display the three parts of the extended order code.		
User interface	Character string comprising numbers, letters and special characters		
Additional information	The extended order code indicates the version of all the features of the product structure and thus uniquely identifies the device.		

#### 17.4.4 "Measured values" submenu

*Navigation*  $\square$   $\square$  Diagnostics  $\rightarrow$  Measured val.



Terminal voltage 1	
Navigation	■ □ Diagnostics $\rightarrow$ Measured val. $\rightarrow$ Terminal volt. 1
	17.4.5 "Analog input 1 to 5" submenu
	There is an <b>Analog inputs</b> submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.
	Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the <b>Expert</b> menu.

*Navigation*  $\square$  Diagnostics  $\rightarrow$  Analog inputs  $\rightarrow$  Analog input 1 to 5

Block tag	
Navigation	□ □ Diagnostics $\rightarrow$ Analog inputs $\rightarrow$ Analog input 1 to 7 $\rightarrow$ Block tag
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.
User entry	Character string comprising numbers, letters and special characters (32)
Channel	
Navigation	■ Diagnostics $\rightarrow$ Analog inputs $\rightarrow$ Analog input 1 to 7 $\rightarrow$ Channel
Description	Use this function to select the input value that should be processed in the Analog Input function block.
Selection	<ul> <li>Uninitialized</li> <li>Level linearized</li> <li>Absolute echo amplitude</li> <li>Absolute EOP amplitude</li> <li>Absolute interface amplitude *</li> <li>Distance</li> <li>Electronic temperature</li> <li>EOP shift</li> <li>Interface linearized *</li> <li>Interface distance *</li> <li>Measured capacitance *</li> <li>Relative echo amplitude</li> <li>Relative interface amplitude *</li> <li>Noise of signal</li> </ul>

^{*} Visibility depends on order options or device settings

- Terminal voltage
- Thickness upper layer *
- Calculated DC value
- Analog output adv. diagnostics 2
- Analog output adv. diagnostics 1

Status	
Navigation	$\blacksquare$ □ Diagnostics → Analog inputs → Analog input 1 to 7 → Status
Description	Indicates the status of the output of the AI block according to the FOUNDATION Fieldbus specification.
Value	
Navigation	Bell Diagnostics → Analog inputs → Analog input 1 to 7 → Value
Description	Indicates the output value of the AI block.
Units index	
Navigation	□ Diagnostics $\rightarrow$ Analog inputs $\rightarrow$ Analog input 1 to 7 $\rightarrow$ Units index
Description	Indicates the unit of the output value.

^{*} Visibility depends on order options or device settings

### 17.4.6 "Data logging" submenu

Navigation	Diagnostics → Data logging
------------	----------------------------

Assign channel 1 to 4		Ê
Navigation	□ Diagnostics → Data logging → Assign chan. 1 to 4	
Selection	<ul> <li>Off</li> <li>Level linearized</li> <li>Distance</li> <li>Unfiltered distance</li> <li>Interface linearized *</li> <li>Interface distance *</li> <li>Unfiltered interface distance</li> <li>Thickness upper layer *</li> <li>Terminal voltage</li> <li>Electronic temperature</li> <li>Measured capacitance *</li> <li>Absolute echo amplitude</li> <li>Relative echo amplitude *</li> <li>Relative interface amplitude *</li> <li>Relative EOP amplitude</li> <li>EOP shift</li> <li>Noise of signal</li> <li>Calculated DC value *</li> <li>Analog output adv. diagnostics 1</li> <li>Analog output 1</li> <li>Analog output 3</li> <li>Analog output 4</li> </ul>	
Additional information	A total of 1000 measured values can be logged. This means: <ul> <li>1000 data points if 1 logging channel is used</li> <li>500 data points if 2 logging channels are used</li> <li>333 data points if 3 logging channels are used</li> <li>250 data points if 4 logging channels are used</li> </ul> If the maximum number of data points is reached, the oldest data points in the data logging that are used	0
	are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle). The logged data are deleted if a new option is selected in this parameter.	L

^{*} Visibility depends on order options or device settings

Logging interval		6
Navigation	Diagnost	ics $\rightarrow$ Data logging $\rightarrow$ Logging interval
	■ Diagnost	ics $\rightarrow$ Data logging $\rightarrow$ Logging interval
User entry	1.0 to 3 600.0 s	
Additional information	-	defines the interval between the individual data points in the data log, and um loggable process time T $_{\rm log}$ :
	<ul><li> If 2 logging cl</li><li> If 3 logging cl</li></ul>	nannel is used: T _{log} = $1000 \cdot t_{log}$ nannels are used: T _{log} = $500 \cdot t_{log}$ nannels are used: T _{log} = $333 \cdot t_{log}$ nannels are used: T _{log} = $250 \cdot t_{log}$
		elapses, the oldest data points in the data log are cyclically overwritten such log always remains in the memory (ring memory principle).
	1 The logged	data are deleted if this parameter is changed.
	Example	
	• $T_{log} = 1000 \cdot$ • $T_{log} = 1000 \cdot$ • $T_{log} = 1000 \cdot 8$	logging channel 1 s = 1000 s ≈ 16.5 min 10 s = 1000 s ≈ 2.75 h 30 s = 80000 s ≈ 22 h 3600 s = 3600000 s ≈ 41 d

Clear logging data			ß
Navigation	9	Diagnostics → Data logging → Clear logging Diagnostics → Data logging → Clear logging	
Selection	■ Cai ■ Cle	ncel Par data	

#### "Display channel 1 to 4" submenu

The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.

אַיי	xxx	
175.77	mull	
40.69 kg/h		Ľ,
	-100 <i>s</i>	Ó

- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.

To return to the operating menu, press  $\oplus$  and  $\Box$  simultaneaously.

Navigation

□ Diagnostics → Data logging → Displ.channel 1 to 4

#### 17.4.7 "Simulation" submenu


The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.

Condition to be simulated	Associated parameters
Specific value of a process variable	<ul> <li>Assign measurement variable (→  ☐ 192)</li> <li>Process variable value (→  ☐ 192)</li> </ul>
Specific state of the switch output	<ul> <li>Switch output simulation (→  ☐ 192)</li> <li>Switch status (→  ☐ 193)</li> </ul>
Existence of an alarm	Simulation device alarm ( $\rightarrow \square$ 193)

#### Enable/disable simulation


The simulation of measured values can be enabled or disabled via a hardware switch (SIM switch) at the electronics. Simulating a measured value is only possible if the SIM switch is in the ON position.

The switch output can always be simulated, irrespective of the position of the SIM switch.



- 1. Loosen the securing clamp.
- 2. Unscrew the housing cover.

- **3.** Pull out the display module with a gentle rotation movement. To make it easier to access the SIM switch, attach the display module to the edge of the electronics compartment.
  - └ Display module is attached to the edge of the electronics compartment.



- 4. SIM switch in the **ON** position: measured values can be simulated. SIM switch in the **OFF** position (factory setting): Simulation of measured values is disabled.
- 5. Feed the spiral cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Screw the electronics compartment cover closed and tighten the securing clamp.

#### Structure of the submenu

Navigation

Expert  $\rightarrow$  Diagnostics  $\rightarrow$  Simulation

► Simulation	
Assign measurement variable	→ 🗎 192
Process variable value	→ 🗎 192
Switch output simulation	) → 🗎 192
Switch status	→ 🗎 193
Simulation device alarm	→ 🗎 193

#### **Description of parameters**

Navigation 🛛 🗐 🖾 Exper

 $\blacksquare \blacksquare \quad \text{Expert} \rightarrow \text{Diagnostics} \rightarrow \text{Simulation}$ 

Assign measurement variable		â
Navigation	□ Expert → Diagnostics → Simulation → Assign meas.var.	
Selection	<ul> <li>Off</li> <li>Level</li> <li>Interface *</li> <li>Level linearized</li> <li>Interface linearized</li> <li>Thickness linearized</li> </ul>	
Additional information	<ul> <li>The value of the variable to be simulated is defined in the Process variable value parameter (→  192).</li> <li>If Assign measurement variable ≠ Off, a simulation is active. This is indicated by a diagnotic message of the <i>Function check (C)</i> category.</li> </ul>	

Process variable value		
Navigation	Image: Boostics → Simulation → Proc. var. value $Mathbf{Mathematical}$	
Prerequisite	Assign measurement variable (→ 🖺 192) ≠ Off	
User entry	Signed floating-point number	
Additional information	Downstream measured value processing and the signal output use this simulation value this way, users can verify whether the measuring device has been configured correctly.	

Switch output simulation		
Navigation	$ \blacksquare \blacksquare  \text{Expert} \rightarrow \text{Diagnostics} \rightarrow \text{Simulation} \rightarrow \text{Switch sim.} $	
Description	Switch the simulation of the switch output on and off.	
Selection	<ul><li>Off</li><li>On</li></ul>	

^{*} Visibility depends on order options or device settings

Â

Navigation	■ Expert → Diagnostics → Simulation → Switch status
Prerequisite	Switch output simulation ( $\Rightarrow \triangleq 192$ ) = On
Description	Select the status of the status output for the simulation.
Selection	<ul><li>Open</li><li>Closed</li></ul>
Additional information	The switch status assumes the value defined in this parameter. This helps to check correct operation of connected control units.

Simulation device alarm		Â
Navigation	Image: Barbon Simulation → Sim. alarm	
Description	Switch the device alarm on and off.	
Selection	<ul><li>Off</li><li>On</li></ul>	
Additional information	When selecting the <b>On</b> option, the device generates an alarm. This helps to check the correct output behavior of the device in the case of an alarm.	
	An active simulation is indicated by the <b>C484 Simulation failure mode</b> diagnostic message.	

Diagnostic event simulation		
Navigation	■ Expert → Diagnostics → Simulation → Diag. event sim.	
Description	Select a diagnostic event to simulate this event.	
Additional information	When operated via the local display, the selection list can be filtered according to the event categories ( <b>Diagnostic event category</b> parameter).	

## 17.4.8 "Device check" submenu

*Navigation*  $\square \square$  Diagnostics  $\rightarrow$  Device check

Start device check		æ
Navigation		
Description	Start a device check.	
Selection	<ul><li>No</li><li>Yes</li></ul>	
Additional information	In the case of a lost echo a device check can not be performed.	
Result device check		
Navigation		
Description	Displays the result of the device check.	
Additional information	<ul> <li>Meaning of the display options</li> <li>Installation ok Measurement possible without restrictions.</li> <li>Accuracy reduced A measurement is possible. However, the measuring accuracy may be reduced due to signal amplitudes.</li> <li>Measurement capability reduced A measurement is currently possible. Howerver, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.</li> <li>Check not done No device check has been performed.</li> </ul>	

Last check time	
Navigation	
Description	Displays the operating time at which the last device check has been performed.
User interface	Character string comprising numbers, letters and special characters

#### Level signal

Navigation	□ □ Diagnostics → Device check → Level signal
Prerequisite	Device check has been performed.
Description	Displays result of the device check for the level signal.
User interface	<ul> <li>Check not done</li> <li>Check not OK</li> <li>Check OK</li> </ul>
Additional information	For <b>Level signal = Check not OK</b> : Check the mounting position of the device and the dielectric constant of the medium.

Launch signal	
Navigation	□ Diagnostics → Device check → Launch signal
Prerequisite	Device check has been performed.
Description	Displays result of the display check for the launch signal.
User interface	<ul> <li>Check not done</li> <li>Check not OK</li> <li>Check OK</li> </ul>
Additional information	For <b>Launch signal</b> = <b>Check not OK</b> : Check the mounting position of the device. In non- metallic vessels use a metal plate or a metal flange.



#### "Heartbeat" submenu

The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

**Detailed description** SD01872F

Navigation

□ □ Diagnostics → Heartbeat

# Index

## A

A
Access authorization to parameters
Read access
Write access
Access code
Incorrect input
Access status display (Parameter) 136
Access status tooling (Parameter)
Accessories
Communication-specific
Device-specific
Service-specific
System components
Activate table (Parameter)
Actual diagnostics (Parameter) 177
Administration (Submenu)
Advanced process conditions (Parameter) 140
Advanced setup (Submenu)
Analog input 1 to 5 (Submenu) 134, 184
Application
Assign channel 1 to 4 (Parameter)
Assign diagnostic behavior (Parameter) 160
Assign limit (Parameter)
Assign measurement variable (Parameter) 192
Assign status (Parameter)

## В

Backlight (Parameter)	)
Backup state (Parameter) 172	
Block tag (Parameter)	ŧ
Blocking distance (Parameter)	ŧ

## С

Channel (Parameter)
Cleaning
Clear logging data (Parameter)
Comparison result (Parameter)
Configuration backup display (Submenu) 171
Configuration management (Parameter) 171
Configuration of a level measurement 73, 82
Configuring level measurement 73, 82
Configuring the language 81
Confirm access code (Parameter)
Confirm distance (Parameter) 130, 133
Confirm probe length (Parameter) 157, 158
Context menu
Contrast display (Parameter)
Customer value (Parameter) 152

## D

Data logging (Submenu)	186
Decimal places 1 (Parameter)	167
Decimal places menu (Parameter)	169
Define access code (Parameter)	176
Define access code (Wizard)	176
Define the access code	. 46

Device check (Submenu)	194
	181
	182
	105
Device reset (Parameter)	174
	181
Diagnostic event	96
In the operating tool	
- U	193
Diagnostic events	95
Diagnostic list	99
Diagnostic list (Submenu)	
Diagnostic message	. 95
Diagnostics	
Symbols	. 95
Diagnostics (Menu)	177
Diagnostics 1 (Parameter)	179
Diameter (Parameter)	149
DIP switch	
see Write protection switch	
Disable simulation	189
1 5 ( )	165
Display and operating module FHX50	42
Display channel 1 to 4 (Submenu)	188
Display damping (Parameter)	168
······································	168
Display module	
Display symbols	. 52
Disposal	106
Distance (Parameter)	183
Distance unit (Parameter)	126
Document	
Purpose	. 6
_	

#### Ε

Electronics housing

Design
Empty calibration (Parameter)
Enable simulation
Enter access code (Parameter)
Envelope curve display
Event history
Event level
Explanation
Symbols
Event list (Submenu) 180
Event logbook (Submenu)
Event text
Events list
Extended order code 1 (Parameter)
Exterior cleaning
_
F

#### F

Failure mode (Parameter)	163
FHX50	. 42

FF	
Residual risks	. 11
Filter options (Parameter)	180
Filtering the event logbook	100
Firmware version (Parameter)	181
Format display (Parameter)	165
Free text (Parameter)	148
Full calibration (Parameter)	128
Functional Safety Manual (FY)	8

#### Η

11
Hardware write protection
Header (Parameter) 168
Header text (Parameter)
Heartbeat (Submenu) 196
HistoROM (description) 83
Housing
Design
Turning

### I

#### К

Keypad lock	
Disabling	50
Enabling	50

## L

Language (Parameter)
Last backup (Parameter)
Last check time (Parameter)
Launch signal (Parameter)
Level (Parameter)
Level (Submenu)
Level correction (Parameter)
Level linearized (Parameter) 149, 183
Level signal (Parameter) 195
Level unit (Parameter) 141
Linearization (Submenu) 144, 145, 146
Linearization type (Parameter) 146
Local display
see Diagnostic message
see In alarm condition
Locking status
Locking status (Parameter)
Logging interval (Parameter)

### Μ

Maintenance
Managing the device configuration
Mapping (Wizard) 133
Mapping end point (Parameter)
Maximum value (Parameter)
Measured value symbols
Measured values (Submenu)
Media

Medium group (Parameter)	27
Medium property (Parameter)	
Medium type (Parameter) 13	38
Menu	
Diagnostics	77
Setup	26
Mounting outside the vessel	27
Mounting position for level measurements 1	19

#### Ν

Non-metal vessels	. 26
Number format (Parameter)	169

### 0

Operating elements
Diagnostic message
Operating module
Operating time (Parameter)
Operating time from restart (Parameter) 178
Operational safety
Order code (Parameter)
Output echo lost (Parameter)
Overvoltage protection
General information

#### Ρ

Present mapping (Parameter)	131
Present probe length (Parameter) 156,	158
Previous diagnostics (Parameter)	177
Probe grounded (Parameter)	156
Probe length correction (Wizard)	158
Probe settings (Submenu)	156
Process property (Parameter)	139
Process Value Filter Time (Parameter)	135
Process variable value (Parameter)	192
Product safety	. 12
Purpose of this document	. 6

#### R

Ramp at echo lost (Parameter)
Read access
Record map (Parameter)
Registered trademarks
Remedial measures
Calling up
Closing
Remote operation
Repair concept
Replacing a device
Requirements for personnel
Result device check (Parameter)
Return
Rod probe
Design
Rod probes
Lateral loading capacity
S
Safety instructions
Basic

Safety Instructions (XA) Safety settings (Submenu)	153
Separator (Parameter)	
Serial number (Parameter)	
Service interface (CDI)	
Setting the operating language	
Managing the device configuration	
Operating language	
Setup (Menu)	
Signal quality (Parameter)	
SIM switch	189
Simulation (Submenu)	
Simulation device alarm (Parameter)	193
Spare parts	
Nameplate	
Start device check (Parameter)	194
Status (Parameter)	185
Status signals	2, 95
Submenu	
Administration	174
Advanced setup	136
Analog input 1 to 5	184
Configuration backup display	171
Data logging	186
Device check	194
Device information	181
Diagnostic list	179
Display	165
Display channel 1 to 4	188
Event list	180
Event logbook	180
Events list	100
Heartbeat	196
Level	138
Linearization	
Measured values	183
Probe settings	156
Safety settings	
Simulation	
Switch output	
Switch output (Submenu)	159
Switch output function (Parameter)	159
Switch output simulation (Parameter)	192
Switch status (Parameter)	
Switch-off delay (Parameter)	163
Switch-off value (Parameter)	
Switch-on delay (Parameter)	
Switch-on value (Parameter)	
Symbols	TOT
For correction	55
In the text and numeric editor	
System components	
oystem components	114
Т	

Thermal insulation    2'      Timestamp (Parameter)    177, 175	
Timestamp 1 to 5 (Parameter)	9
Tool	
Transmitter	
Turning the display	2
Turning the display module	2
Transmitter housing	
Turning	1
Troubleshooting	3
Tube diameter (Parameter)	6
Turning the display	2
Turning the display module	

### U

Unit after linearization (Parameter)
Units index (Parameter) 185
Use of the measuring device
see Intended use
Use of the measuring devices
Borderline cases
Incorrect use

#### V

Value (Parameter)	185
Value 1 display (Parameter)	167
Value echo lost (Parameter)	153

### W

Wizard
Define access code
Mapping
Probe length correction
Workplace safety 12
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



www.addresses.endress.com

