01.01.zz (Device software)

Products Solutions

S Services

Operating Instructions Levelflex FMP55 FOUNDATION Fieldbus

Guided wave radar










Table of contents

1	Important document information 6		6.1.6 Securing the probe	
1.1	Purpose of this document 6	6.2	6.1.7 Special installation situations Mounting the measuring device	
1.2	Symbols 6	0.2	6.2.1 Tool list	
	1.2.1 Safety symbols 6		6.2.2 Mounting the device	
	1.2.2 Electrical symbols 6		6.2.3 Mounting the "Sensor, remote"	
	1.2.3 Tool symbols 6 1.2.4 Symbols for certain types of		version	
	information and graphics		6.2.4 Turning the transmitter housing	
1.3	Documentation		6.2.5 Turning the display	
2.0	1.3.1 Technical Information (TI) 8	6.3	Post-installation check	31
	1.3.2 Brief Operating Instructions (KA) 8	_	- 1	
	1.3.3 Safety Instructions (XA) 8	7	Electrical connection	
	1.3.4 Functional Safety Manual (FY) 8	7.1	Connecting requirements	
1.4	Terms and abbreviations		7.1.1 Terminal assignment	
1.5	Registered trademarks 9		7.1.2 Cable specification	35
2	Desir of the instanctions		7.1.3 Device plug	
2	Basic safety instructions 11		7.1.4 Supply Voltage	36
2.1	Requirements for the personnel	7.2	Connecting the device	37
2.2	Intended use		7.2.1 Opening cover	
2.3	Workplace safety		7.2.2 Connecting	
2.4 2.5	Operational safety12Product safety12		7.2.3 Plug-in spring-force terminals	38
۵.۶	2.5.1 CE mark		7.2.4 Closing the cover of the connection	0.0
	2.5.2 EAC conformity	7.2	compartment	
	, and the second	7.3	Post-connection check	20
3	Product description	8	Operation methods	40
3.1	Product design	8.1	Overview	40
	3.1.1 Levelflex FMP51/FMP52/FMP54/		8.1.1 Local operation	
	FMP55		8.1.2 Operation with remote display and	
	5.1.2 Electronics floating		operating module FHX50	
4	Incoming acceptance and product	8.2	8.1.3 Remote operation Structure and function of the operating	41
•		0.2	menu	43
	identification		8.2.1 Structure of the operating menu	43
4.1	Incoming acceptance		8.2.2 User roles and related access	
4.2	Product identification		authorization	45
	4.2.1 Nameplate		8.2.3 Data access - Security	45
_	Store so transport	8.3	Display and operating module	50
5	Storage, transport		8.3.1 Display	50 53
5.1	Storage temperature		8.3.3 Entering numbers and text	54
5.2	Transporting the product to the measuring		8.3.4 Opening the context menu	55
	point		8.3.5 Envelope curve display on the display	
6	Mounting		and operating module	57
6.1	Mounting requirements	9	Integration into a FOUNDATION	
	6.1.1 Suitable mounting position		Fieldbus network	58
	6.1.3 Notes on the mechanical load of the	9.1	Device Description (DD)	58
	probe 21	9.2	Integration into the FOUNDATION Fieldbus)(
	6.1.4 Lateral loading capacity (flexural	•	network	58
	strength) of coax probes 21	9.3	Device identification and addressing	58
	6.1.5 Mounting cladded flanges 22			

9.4	Block model			12.8.2 Assignment parameters	
	9.4.2 Block configuration when device is			12.8.4 Transmission of event messages over	
9.5	delivered		12.9	the bus	
9.6	· · · · · · · · · · · · · · · · · · ·	60 61	10	Diagnostics and troublash acting	വാ
7.0	<u> -</u>	61	13	Diagnostics and troubleshooting	92
	9.6.2 Advanced Setup Transducer Block	62 63	13.1	General troubleshooting	. 92
	9.6.4 Diagnostic Transducer Block	64	12.2	13.1.2 Parametrization errors	
	9.6.5 Expert Configuration Transducer		13.2	Diagnostic information on local display 13.2.1 Diagnostic message	
		64		13.2.2 Calling up remedial measures	
	9.6.6 Expert Information Transducer Block	66	13.3	Diagnostic event in the operating tool	
		67	13.4	Diagnostic messages in the DIAGNOSTIC	
	9.6.8 Service Information Transducer	0,		Transducer Block (TRDDIAG)	
		68	13.5	Diagnostic list	
		68	13.6	Event logbook	
9.7	Methods	69		13.6.1 Event history	
				13.6.2 Filtering the event logbook	
10	Commissioning using the		13.7	Firmware history	
	Commissioning Wizard	70			
	3		14	Maintenance	102
11	Commissioning via operating		14.1	Exterior cleaning	102
	menu	71	14.2	General cleaning instructions	102
11.1 11.2		71	14.3	Cleaning coax probes	102
11.3		72	15	Repair	103
11.4		74	15.1	General information	103
11.5		75		15.1.1 Repair concept	103
	11.5.1 Factory setting of local display for			15.1.2 Repair of Ex-certified devices	
		75		15.1.3 Replacing electronics modules	
11 (11.5.2 Adjusting the local display		1	15.1.4 Replacing a device	
11.6 11.7	Configuration management Protecting settings from unauthorized access .		15.2 15.3	Spare parts	
11./	r rotecting settings from unauthorized access.	′′	15.4	Disposal	104
12	Commissioning (block-oriented		22.1	2.50	101
	_ ·	78	16	Accessories	105
10 1	-		16.1	Device-specific accessories	105
12.1 12.2		78 78		16.1.1 Weather protection cover	105
	5	78		16.1.2 Mounting bracket for electronics	100
		78		housing	106
	5 5	78		16.1.3 Centering star	107 108
	3 3 3 1	79		16.1.5 Overvoltage protection	100
12.2	3	79		16.1.6 Bluetooth module BT10 for HART	10)
12.3 12.4	5	79 80		devices	110
12.5		80	16.2	Communication-specific accessories	111
12.6		82	16.3	Service-specific accessories	
. =	12.6.1 Factory setting of local display for		16.4	System components	111
	interface measurements	82			110
12.7	5	82	17	Operating menu	112
12.8	Configuring event behavior according to FOUNDATION Fieldbus specification FF912	0 /:	17.1	Overview of the operating menu (display	
	FULLINDA LION FIEIGDUS SDECITICATION FEY L	O4		1 1 \	110
	12.8.1 Event groups			module)	112

17.2	Overview of the operating menu (operating		
			119
17.3	"Setup" ı	menu	126
	17.3.1	"Mapping" wizard	136
		"Analog input 1 to 5" submenu	137
	17.3.3	"Advanced setup" submenu	139
17.4	"Diagno	stics" menu	183
	17.4.1	"Diagnostic list" submenu	185
	17.4.2	"Event logbook" submenu	186
	17.4.3	"Device information" submenu	187
	17.4.4	"Measured values" submenu	189
	17.4.5	"Analog input 1 to 5" submenu	191
	17.4.6	"Data logging" submenu	194
	17.4.7	"Simulation" submenu	197
	17.4.8	"Device check" submenu	202
	17.4.9	"Heartbeat" submenu	204
Inde	x		205

1 Important document information

1.1 Purpose of this document

These Operating Instructions contain all the information that is required in the various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols

1.2.1 Safety symbols

▲ DANGER

This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

WARNING

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

A CAUTION

This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.

NOTICE

This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols



Alternating current



Direct current and alternating current

Direct current



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols



Phillips head screwdriver

7



Flat blade screwdriver



Torx screwdriver



Allen key



Open-ended wrench

1.2.4 Symbols for certain types of information and graphics

✓ Permitted

Procedures, processes or actions that are permitted

✓ ✓ Preferred

Procedures, processes or actions that are preferred

X Forbidden

Procedures, processes or actions that are forbidden



Indicates additional information



Reference to documentation



Reference to graphic



Notice or individual step to be observed

1., 2., 3.

Series of steps



Result of a step



Visual inspection



Operation via operating tool



Write-protected parameter

1, 2, 3, ...

Item numbers

A, B, C, ...

Views

$\triangle \rightarrow \square$ Safety instructions

Observe the safety instructions contained in the associated Operating Instructions

Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

1.3 Documentation

The following types of documentation are available in the Download Area of the Endress +Hauser website (www.endress.com/downloads):



For an overview of the scope of the associated Technical Documentation, refer to the following:

- Device Viewer (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

1.3.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.3.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.3 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.

The nameplate indicates the Safety Instructions (XA) that are relevant to the device.



1.3.4 Functional Safety Manual (FY)

Depending on the SIL approval, the Functional Safety Manual (FY) is an integral part of the Operating Instructions and applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions.

The different requirements that apply for the protective function are described in the Functional Safety Manual (FY).

1.4 Terms and abbreviations

BA

Document type "Operating Instructions"

KA

Document type "Brief Operating Instructions"

TI

Document type "Technical Information"

SD

Document type "Special Documentation"

XA

Document type "Safety Instructions"

PN

Nominal pressure

MWP

Maximum working pressure

The MWP is indicated on the nameplate.

ToF

Time of Flight

FieldCare

Scalable software tool for device configuration and integrated plant asset management solutions

DeviceCare

Universal configuration software for Endress+Hauser HART, PROFIBUS, FOUNDATION Fieldbus and Ethernet field devices

DTM

Device Type Manager

ε_r (Dk value)

Relative dielectric constant

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

Operating tool

The term "operating tool" is used in place of the following operating software: SmartBlue (app), for operation using an Android or iOS smartphone or tablet

BI

Blocking Distance; no signals are analyzed within the BD.

PLC

Programmable logic controller (PLC)

CDI

Common Data Interface

PFS

Pulse Frequency Status (Switch output)

MBP

Manchester Bus Powered

PDU

Protocol Data Unit

1.5 Registered trademarks

FOUNDATION™ Fieldbus

Registration-pending trademark of the FieldComm Group, Austin, Texas, USA

Bluetooth®

The *Bluetooth*® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Endress+Hauser is under license. Other trademarks and trade names are those of their respective owners.

Apple[®]

Apple, the Apple logo, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Android[®]

Android, Google Play and the Google Play logo are trademarks of Google Inc.

KALREZ®, VITON®

Registered trademarks of DuPont Performance Elastomers L.L.C., Wilmington, DE USA

TEFLON®

Registered trademark of E.I. DuPont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ► Are authorized by the plant owner/operator.
- ► Are familiar with federal/national regulations.
- ▶ Before starting work, read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ► Are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Intended use

Application and media

The measuring device described in this manual is intended only for the level and interface measurement of liquids. Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

If the limit values specified in the "Technical data" and the conditions listed in the instructions and additional documentation are observed, the measuring device may be used for the following measurements only:

- ▶ Measured process variables: level and/or interface height
- ► Calculable process variables: volume or mass in any shape of vessel (calculated from the level by the linearization functionality)

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Use the measuring device only for media to which the process-wetted materials have an adequate level of resistance.
- ▶ Observe the limit values in the "Technical data".

Incorrect use

The manufacturer is not liable for damage caused by improper or non-intended use.

Clarification of borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability.

Residual risks

Due to heat transfer from the process as well as power loss in the electronics, the temperature of the electronics housing and the assemblies contained therein (e.g. display module, main electronics module and I/O electronics module) may rise up to 80 $^{\circ}\text{C}$ (176 $^{\circ}\text{F}$). When in operation, the sensor may reach a temperature close to the medium temperature.

Danger of burns from contact with surfaces!

► In the event of high medium temperatures, ensure protection against contact to prevent burns.

2.3 Workplace safety

When working on and with the device:

▶ Wear the required protective equipment according to federal or national regulations.

2.4 Operational safety

Risk of injury!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ► The operator is responsible for the interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

▶ If modifications are nevertheless required, consult with the manufacturer.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to the repair of an electrical device.
- ▶ Use only original spare parts and accessories from the manufacturer.

Hazardous area

To eliminate danger to persons or the installation when the device is used in the hazardous area (e.g. explosion protection, pressure vessel safety):

- ► Check the nameplate to verify whether the ordered device can be put to its intended use in the hazardous area.
- ► Observe the specifications in the separate supplementary documentation, which is an integral part of this manual.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets the general safety standards and legal requirements.

NOTICE

Loss of degree of protection by opening of the device in humid environments

▶ If the device is opened in a humid environment, the degree of protection indicated on the nameplate is no longer valid. This may also impair the safe operation of the device.

2.5.1 **CE mark**

The measuring system meets the legal requirements of the applicable EU directives. These are listed in the corresponding EU Declaration of Conformity together with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the CE mark.

2.5.2 EAC conformity


The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity along with the standards applied.

The manufacturer confirms successful testing of the device by affixing to it the EAC mark.

3 Product description

3.1 Product design


3.1.1 Levelflex FMP51/FMP52/FMP54/FMP55



■ 1 Design of the Levelflex

- 1 Electronics housing
- 2 Process connection (here as an example: flange)
- 3 Rope probe
- 4 End-of-probe weight
- 5 Rod probe
- 6 Coax probe

3.1.2 **Electronics housing**



₽ 2 Design of the electronics housing

- ${\it Electronics\ compartment\ cover}$
- Display module 2
- Main electronics module 3
- Cable glands (1 or 2, depending on instrument version)
- Nameplate
 I/O electronics module
- Terminals (pluggable spring terminals)
 Connection compartment cover
- Grounding terminal

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Check the following during incoming acceptance:


- Are the order codes on the delivery note and the product sticker identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): are the Safety Instructions (XA) provided?
- If one of these conditions is not met, please contact your Endress+Hauser sales office.

4.2 Product identification

The following options are available for the identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter the serial number from the nameplate in *W@M Device Viewer* (www.endress.com/deviceviewer): all the information about the device is displayed.
- Enter the serial number on the nameplate into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information about the measuring device is displayed.

4.2.1 Nameplate



■ 3 Nameplate of the Levelflex; engineering unit: mm (in)

- 1 Device name
- 2 Manufacturer address
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Process pressure
- 7 Gas phase compensation: reference length
- 8 Certificate symbol
- 9 Certificate- and approval-related data
- 10 Degree of protection: e.g. IP, NEMA
- 11 Document number of the Safety Instructions: e.g. XA, ZD, ZE
- 12 2-D matrix code (QR code)
- 13 Modification mark
- 14 Manufacturing date: year-month
- 15 Permitted temperature range for cable
- 16 Device revision (Dev.Rev.)
- 17 Additional information about the device version (certificates, approvals, communication protocol): e.g. SIL, PROFIBUS
- 18 Firmware version (FW)
- 19 CE mark, C-Tick
- 20 DeviceID
- 21 Materials in contact with process
- 22 Permitted ambient temperature (T_a)
- 23 Size of the cable gland thread
- 24 Probe length
- 25 Signal outputs
- 26 Supply voltage

Up to 33 characters of the extended order code are indicated on the nameplate. If the extended order code contains additional characters, these cannot be displayed. However, the complete extended order code can also be displayed via the device operating menu: **Extended order code 1 to 3** parameter

5 Storage, transport

5.1 Storage temperature

- Permitted storage temperature: -40 to +80 °C (-40 to +176 °F)
- Use original packaging.


5.2 Transporting the product to the measuring point

WARNING

Housing or rod may become damaged or pull off.

Danger of injury!

- ► Transport the measuring device to the measuring point in its original packaging or by the process connection.
- Always secure lifting equipment (slings, eyes, etc.) at the process connection and never lift the device by the electronic housing or probe. Pay attention to the center of gravity of the device so that it does not tilt or slip unintentionally.
- ► Follow the safety instructions and transport conditions for devices weighing more than 18 kg (39.6 lbs) (IEC 61010).




A001392

NOTICE

Transport lock in the FMP55 with coax probe

► The coax tube is not firmly connected to the electronics housing in the FMP55 with coax probe. It is fixed onto the mounting flange with two cable ties during transportation. These cable ties must not be released during transportation or installation of the device to prevent the spacer from sliding at the probe rod. They may only be removed immediately before screwing the process connection flange into place.




A001547

6 Mounting

6.1 Mounting requirements

6.1.1 Suitable mounting position




■ 4 Mounting position of Levelflex FMP55

- Rod probes/rope probes: mount in the bypass/stilling well.
- Coax probes can be mounted at any distance from the wall.
- When mounting outdoors, a weather protection cover can be used to protect the device against extreme weather conditions.
- Minimum distance from the end of the probe to the bottom of the vessel: 10 mm (0.4 in)

6.1.2 Mounting under confined conditions

Mounting with remote probe

The device version with a remote probe is suitable for applications with restricted mounting space. In this case, the electronics housing is mounted at a separate position from the probe.



A001479

- A Angled plug at the probe
- B Angled plug at the electronics housing
- C Length of the remote cable as ordered
- Product structure, feature 600 "Probe design":
 Version MB "Sensor remote, 3m cable"
- The connecting cable is included in the delivery with these versions. Minimum bending radius: 100 mm (4 inch)
- The mounting bracket for the electronics housing is included in the delivery with these versions. Mounting options:
 - Wall mounting
 - Mounting on DN32 to DN50 (1-1/4 to 2 inch) post or pipe
- The connection cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

6.1.3 Notes on the mechanical load of the probe

Tensile loading capacity of rope probes

FMP55

Rope 4mm (1/6") PFA>316

2 kN

Lateral loading capacity (flexural strength) of rod probes

FMP55

Rod 16mm (0.63") PFA>316L

30 Nm

6.1.4 Lateral loading capacity (flexural strength) of coax probes

FMP55

Probe Ø 42.4 mm 316L

300 Nm

6.1.5 Mounting cladded flanges

Note the following for cladded flanges:

- Use the same number of flange screws as the number of flange bores provided.
- Tighten the screws with the necessary torque (see Table).
- Retighten after 24 hours or after the first temperature cycle.
- Depending on the process pressure and temperature, check and retighten the screws, where necessary, at regular intervals.


The PTFE flange cladding normally acts simultaneously as a seal between the nozzle and the device flange.

Flange size	Number of screws	Tightening torque
EN		
DN40/PN40	4	35 to 55 Nm
DN50/PN16	4	45 to 65 Nm
DN50/PN40	4	45 to 65 Nm
DN80/PN16	8	40 to 55 Nm
DN80/PN40	8	40 to 55 Nm
DN100/PN16	8	40 to 60 Nm
DN100/PN40	8	55 to 80 Nm
DN150/PN16	8	75 to 115 Nm
DN150/PN40	8	95 to 145 Nm
ASME		
1½"/150lbs	4	20 to 30 Nm
1½"/300lbs	4	30 to 40 Nm
2"/150lbs	4	40 to 55 Nm
2"/300lbs	8	20 to 30 Nm
3"/150lbs	4	65 to 95 Nm
3"/300lbs	8	40 to 55 Nm
4"/150lbs	8	45 to 70 Nm
4"/300lbs	8	55 to 80 Nm
6"/150lbs	8	85 to 125 Nm
6"/300lbs	12	60 to 90 Nm
JIS		1
10K 40A	4	30 to 45 Nm
10K 50A	4	40 to 60 Nm
10K 80A	8	25 to 35 Nm
10K 100A	8	35 to 55 Nm
10K 100A	8	75 to 115 Nm

6.1.6 Securing the probe

Securing coax probes

For WHG approval: A support is required for probe lengths \geq 3 m (10 ft).




Coax probes can be secured (fixed) at any point in the ground tube.

6.1.7 Special installation situations

Bypasses and stilling wells

- The use of centering disks/stars/weights (available as accessories) is recommended in bypass and stilling well applications.
- As the measuring signal penetrates many plastics, installation in plastic bypasses or stilling wells can produce incorrect results. For this reason use a metal bypass or stilling well.



A001412


- 1 Mounting in stilling well
- 2 Mounting in bypass
- 3 Minimum distance between probe end and lower edge of bypass 10 mm (0.4 in)
- Pipe diameter: > 40 mm (1.6 in) (for rod probes).
- A rod probe can be installed in pipes with a diameter of up to 150 mm (6 in). The use of a coax probe is recommended for larger pipe diameters.
- Side outlets, holes, slots and welds with a maximum inward projection of 5 mm (0.2 in) do not affect the measurement.
- There should not be any changes in the diameter of the pipe.
- The probe must be 100 mm (4 in) longer than the lower outlet.
- The probes must not touch the pipe wall within the measuring range. Support or brace the probe if necessary. All rope probes are prepared for bracing in vessels (tensioning weight with anchor hole).
- The probes must not touch the pipe wall within the measuring range. If necessary, use a PFA centering star.
- Coax probes can be used within any restrictions provided that the pipe diameter permits their installation.
- For bypasses with condensate formation (water) and a medium with a low dielectric constant (e.g. hydrocarbons):

Over time, the bypass fills with condensate up to the lower outlet. When levels are low, the level echo is masked by the echo of the condensate as a result. In this range, the level of the condensate is output and the correct value is only output when levels are higher. For this reason, ensure that the lower outlet is 100 mm (4 in) below the lowest level to be measured and fit a metal centering disk at the level of the lower edge of the lower outlet.

In thermally insulated vessels, the bypass should also be insulated in order to prevent condensate formation.

Assignment of centering disk/centering star/centering weight to the pipe diameter

Underground tanks



A001414

In the case of nozzles with large diameters, use a coax probe to avoid reflections at the nozzle wall.


Non-metal vessels

Use a coax probe if mounting in non-metal vessels.

26

Vessel with thermal insulation


If process temperatures are high, the device must be included in normal vessel insulation (1) in order to prevent the electronics heating up as a result of thermal radiation or convection. The insulation may not go beyond the points labeled "MAX" in the drawings.



- \blacksquare 5 Process connection with flange
- 1 Vessel insulation
- 2 Compact device
- 3 Sensor, remote

6.2 Mounting the measuring device

6.2.1 Tool list



For flanges and other process connections: use an appropriate mounting tool

6.2.2 Mounting the device

Mounting devices with a flange


If a seal is used to mount the device, use uncoated metal screws to ensure good electrical contact between the process flange and the probe flange.

Mounting rope probes

NOTICE

Electrostatic discharge can damage the electronics.

• Ground the housing before lowering the rope probe into the vessel.



A0012852

Pay attention to the following when introducing the rope probe into the vessel:

- Uncoil the rope slowly and lower it carefully into the vessel.
- Make sure the rope does not bend or buckle.
- Avoid uncontrolled swinging of the weight, as this could damage internal fittings in the vessel.

6.2.3 Mounting the "Sensor, remote" version

This section only applies for devices with the version "Probe design" = "Sensor, remote" (feature 600, version MB/MC/MD).

The following is included in the delivery with the version "Probe design" = "Remote":

- The probe with process connection
- The electronics housing
- The mounting bracket for mounting the electronics housing on a wall or post
- The connection cable (length as ordered). The cable has one straight plug and one plug angled at 90°. Depending on the local conditions the angled plug can be connected at the probe or at the electronics housing.


A CAUTION

Mechanical stress can damage the plugs of the connection cable or cause them to become loose.

- ► Mount the probe and the electronics housing securely before connecting the connecting cable.
- ► Lay the connecting cable in such a way that it is not exposed to mechanical stress. Minimum bending radius: 100 mm (4 in).
- ▶ When connecting the cable, connect the straight plug before you connect the angled plug. Torque for the union nuts of both plugs: 6 Nm.
- The probe, electronics and connection cable are mutually compatible and bear a common serial number. Only components with the same serial number may be connected to one another.

In the event of strong vibrations, a locking compound, e.g. Loctite 243, can also be used on the plug-in connectors.

Mounting the electronics housing




■ 6 Mounting the electronics housing with the mounting bracket. Unit of measurement mm (in)

A Wall mounting

B Post mounting

Connecting the connecting cable






- Connecting the connecting cable. The cable can be connected in the following ways:. Unit of
- Angled plug at the probe Α
- Angled plug at the electronics housing В

measurement mm (in)

Length of the remote cable as ordered

6.2.4 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned:



- 1. Unscrew the securing screw using an open-ended wrench.
- 2. Rotate the housing in the desired direction.
- 3. Tighten the securing screw (1.5 Nm for plastic housing; 2.5 Nm for aluminum or stainless steel housing).

6.2.5 Turning the display


Opening the cover



A0021430

- 1. Loosen the screw of the securing clamp of the electronics compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the electronics compartment cover and check the cover seal; replace it if necessary.


Turning the display module



A0036401

- 1. Pull out the display module with a gentle rotational movement.
- 2. Turn the display module to the desired position: Max. $8 \times 45^{\circ}$ in each direction.
- 3. Feed the coiled cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.

Closing the cover of the electronics compartment



A0021451

- 1. Screw down the cover of the electronics compartment.
- 2. Turn the securing clamp 90 ° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the electronics compartment cover with 2.5 Nm.

6.3 Post-installation check

☐ Is the device undamaged (visual inspection)?

☐ Does the device comply with the measuring point specifications?
Process temperature
Process pressure
 Ambient temperature range
Measuring range
$\hfill \square$ Are the measuring point identification and labeling correct (visual inspection)?
\square Is the device adequately protected against precipitation and direct sunlight?
\square Is the device adequately protected against impact?
☐Are all mounting and safety screws securely tightened?

 $\ \square$ Is the device properly secured?


32

7 Electrical connection

7.1 Connecting requirements

7.1.1 Terminal assignment

Terminal assignment, 4-wire: 4 to 20 mA HART (90 to 253 V_{AC})



A003651


- \blacksquare 8 Terminal assignment, 4-wire: 4 to 20 mAHART (90 to 253 V_{AC})
- 1 Connection 4 to 20 mA HART (active): terminals 3 and 4
- 2 Connection, supply voltage: terminals 1 and 2
- 3 Terminal for cable shield

A CAUTION

To ensure electrical safety:

- ▶ Do not disconnect the protective ground connection.
- ▶ Disconnect the device from the supply voltage before disconnecting the protective ground.
- Connect protective ground to the inner ground terminal (3) before connecting the supply voltage. If necessary, connect the potential matching line to the outer ground terminal
- In order to ensure electromagnetic compatibility (EMC): do **not** ground the device exclusively via the protective ground conductor of the supply cable. Instead, the functional grounding must also be connected to the process connection (flange or threaded connection) or to the external ground terminal.
- An easily accessible power switch must be installed in the proximity of the device. The power switch must be marked as a disconnector for the device (IEC/EN61010).

Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus




■ 9 Terminal assignment PROFIBUS PA / FOUNDATION Fieldbus

A0036500

- A Without integrated overvoltage protection
- *B* With integrated overvoltage protection
- 1 Connection, PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, without integrated overvoltage protection
- $\stackrel{\cdot}{\text{Connection}}$, switch output (open collector): terminals 3 and 4, without integrated overvoltage protection
- 3 Connection, switch output (open collector): terminals 3 and 4, with integrated overvoltage protection
- 4 Connection, PROFIBUS PA / FOUNDATION Fieldbus: terminals 1 and 2, with integrated overvoltage protection
- 5 Terminal for cable shield

Block diagram PROFIBUS PA / FOUNDATION Fieldbus




A003653

$\blacksquare 10$ Block diagram PROFIBUS PA / FOUNDATION Fieldbus


- 1 Cable screen; observe cable specification
- 2 Connection PROFIBUS PA / FOUNDATION Fieldbus
- 3 Measuring device
- 4 Switch output (open collector)

34

Connection examples for the switch output



Connection of a relay



■ 12 Connection to a digital input

- Pull-up resistor
- Digital input
- For optimum interference immunity we recommend to connect an external resistor (internal resistance of the relay or pull-up resistor) of $< 1000 \Omega$.

7.1.2 Cable specification

- Devices without integrated overvoltage protection Pluggable spring-force terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Devices with integrated overvoltage protection Screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)
- For ambient temperature $T_U \ge 60$ °C (140 °F): use cable for temperature $T_U + 20$ K.


FOUNDATION Fieldbus

Endress+Hauser recommends using twisted, shielded two-wire cables.

For further information on the cable specifications, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview", FOUNDATION Fieldbus Guideline and IEC 61158-2 (MBP).

7.1.3 Device plug

In the case of the device versions with a plug, the housing does not need to be opened to connect the signal cable.



■ 13 Pin assignment of 7/8" plug

- Signal -
- Signal +
- Not assigned
- Shielding

7.1.4 Supply voltage

PROFIBUS PA, FOUNDATION Fieldbus

"Power supply; output" 1)	"Approval" ²⁾	Terminal voltage
E: 2-wire; FOUNDATION Fieldbus, switch output G: 2-wire; PROFIBUS PA, switch output	 Non-hazardous Ex nA Ex nA[ia] Ex ic Ex ic[ia] Ex d[ia] / XP Ex ta / DIP CSA GP 	9 to 32 V ³⁾
	Ex ia / ISEx ia + Ex d[ia] / IS + XP	9 to 30 V ³⁾

- 1) Feature 020 in the product structure
- 2) Feature 010 in the product structure
- 3) Input voltages up to 35 V do not destroy the device.

Polarity-dependent	No
FISCO/FNICO compliant according to IEC 60079-27	Yes

7.1.5 Overvoltage protection

If the measuring device is used for level measurement in flammable liquids which requires the use of overvoltage protection according to DIN EN 60079-14, standard for test procedures 60060-1 (10 kA, pulse 8/20 μs), an overvoltage protection module has to be installed.

Integrated overvoltage protection module

An integrated overvoltage protection module is available for 2-wire HART as well as PROFIBUS PA and FOUNDATION Fieldbus devices.

Product structure: Feature 610 "Accessory mounted", option NA "Overvoltage protection".

Technical data		
Resistance per channel	$2 \times 0.5 \Omega$ max.	
Threshold DC voltage	400 to 700 V	
Threshold impulse voltage	< 800 V	
Capacitance at 1 MHz	< 1.5 pF	
Nominal arrest impulse voltage (8/20 μs)	10 kA	

External overvoltage protection module

HAW562 or HAW569 from Endress+Hauser are suited as external overvoltage protection.

For detailed information • HAW562: TI01012K

For detailed information please refer to the following documents:

■ HAW569: TI01013K

7.2 Connecting the device

WARNING


Explosion Hazard!

- ► Observe applicable national standards.
- ► Comply with the specifications in the Safety Instructions (XA).
- ► Use specified cable glands only.
- ▶ Check to ensure that the power supply matches the information on the nameplate.
- ► Switch off the power supply before connecting the device.
- ► Connect the potential matching line to the outer ground terminal before applying the power supply.

Required tools/accessories:

- For devices with a cover lock: Allen key AF3
- Wire stripper
- When using stranded cables: One ferrule for every wire to be connected.


7.2.1 Opening cover



Δ0021490

- 1. Loosen the screw of the securing clamp of the connection compartment cover using an Allen key (3 mm) and turn the clamp 90 ° counterclockwise.
- 2. Unscrew the connection compartment cover and check the cover seal; replace it if necessary.

7.2.2 Connecting




A003641

■ 14 Engineering unit: mm (in)

- 1. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 2. Remove the cable sheath.
- 3. Strip the cable ends 10 mm (0.4 in). In the case of stranded cables, also fit wire end ferrules.
- 4. Firmly tighten the cable glands.


5. Connect the cable according to the terminal assignment.



6. If using shielded cables: Connect the cable shield to the ground terminal.

7.2.3 Plug-in spring-force terminals

The electrical connection of device versions without an integrated overvoltage protection is via plug-in spring-force terminals. Rigid conductors or flexible conductors with ferrules can be inserted directly into the terminal without using the lever, and create a contact automatically.




🖪 15 Engineering unit: mm (in)

To remove the cable from the terminal again:

- 1. Using a flat-blade screwdriver ≤ 3 mm, press down on the slot between the two terminal holes
- 2. Simultaneously pull the cable end out of the terminal.

7.2.4 Closing the cover of the connection compartment



A0021491

- 1. Screw down the cover of the connection compartment.
- 2. Turn the securing clamp 90 ° in the clockwise direction and, using an Allen key (3 mm), tighten the screw of the securing clamp on the connection compartment cover with 2.5 Nm.

7.3 Post-connection check

- ☐ Is the device or cable undamaged (visual inspection)?
- ☐ Do the cables used comply with the requirements?

☐ Do the mounted cables have adequate strain relief?
□Are all the cable glands installed, firmly tightened and leak-tight?
\square Does the supply voltage match the specifications on the nameplate?
☐ Is the terminal assignment correct?
□If necessary, has a protective ground connection been established?
\Box If supply voltage is present, is the device ready for operation and do values appear on the display module?
☐ Are all the housing covers installed and tightened?
☐ Is the securing clamp firmly tightened?


8 Operation methods

8.1 Overview

8.1.1 Local operation

Operation with	Pushbuttons	Touch Control
Order code for "Display; Operation"	Option C "SD02"	Option E "SD03"
Display elements	A0036312 4-line display	4-line display white background lighting; switches to red in
Cicincints		event of device error
	Format for displaying measured variables and status variables can be individually configured	
	Permitted ambient temperature for the display: $-20 \text{ to } +70 \text{ °C } (-4 \text{ to } +158 \text{ °F})$ The readability of the display may be impaired at temperatures outside the temperature range.	
Operating elements	local operation with 3 push buttons $(\boxdot, \boxdot, \sqsubseteq)$	external operation via touch control; 3 optical keys: ⊕, ⊡, 區
	Operating elements also accessible in various hazardous areas	
Additional functionality	Data backup function The device configuration can be saved in the display module.	
	Data comparison function The device configuration saved in the display module can be compared to the current configuration.	
	Data transfer function The transmitter configuration can be transmitte	ed to another device using the display module.

8.1.2 Operation with remote display and operating module FHX50




■ 16 FHX50 operating options

- Display and operating module SD03, optical keys; can be operated through the glass of the cover
- 2 Display and operating module SD02, push buttons; cover must be removed

8.1.3 Remote operation

Via FOUNDATION Fieldbus




 \blacksquare 17 FOUNDATION Fieldbus system architecture with associated components

- 1 FFblue Bluetooth modem
- 2 Field Xpert SFX350/SFX370
- 3 DeviceCare/FieldCare
- 4 NI-FF interface card

IN	Industrial network
FF-HSE	High Speed Ethernet
FF-H1	FOUNDATION Fieldbus-H1
LD	Linking Device FF-HSE/FF-H1
PS	Bus Power Supply
SB	Safety Barrier
BT	Bus Terminator

Via service interface (CDI)



- Computer with FieldCare/DeviceCare operating tool
- Commubox FXA291
- 2 3 Service interface (CDI) of the measuring device (= Endress+Hauser Common Data Interface)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

Menu	Submenu / parameter	Meaning
	Language ¹⁾	Defines the operating language of the local display
Commissioning ²⁾		Launches the interactive wizard for guided commissioning. Additional settings generally do not need to be made in the other menus when the wizard is finished.
Setup	Parameter 1 Parameter N	Once values have been set for these parameters, the measurement should generally be completely configured.
	Advanced setup	Contains additional submenus and parameters: For more customized configuration of the measurement (adaptation to special measuring conditions). For converting the measured value (scaling, linearization). For scaling the output signal.
Diagnostics	Diagnostic list	Contains up to 5 currently active error messages.
	Event logbook 3)	Contains the last 20 messages (which are no longer active).
	Device information	Contains information for identifying the device.
	Measured values	Contains all current measured values.
	Data logging	Contains the history of the individual measuring values.
	Simulation	Is used to simulate measured values or output values.
	Device check	Contains all parameters needed to check the measurement capability of the device.
	Heartbeat 4)	Contains all the wizards for the Heartbeat Verification and Heartbeat Monitoring application packages.
Expert ⁵⁾ Contains all the parameters of the device (including those that are already contained in one of the other menus). This menu is organized according to the function blocks of the device.	System	Contains all higher-level device parameters that do not pertain either to the measurement or to measured value communication.
	Sensor	Contains all parameters needed to configure the measurement.
The parameters of the Expert menu are described in: GP01015F (FOUNDATION Fieldbus)	Output	Contains all parameters needed to configure the switch output (PFS).

Menu	Submenu / parameter	Meaning
	Communication	Contains all parameters needed to configure the digital communication interface.
	Diagnostics	Contains all parameters needed to detect and analyze operational errors.

- 1) If you are operating via operating tools (e.g. FieldCare), the "Language" parameter is located under "Setup ri you are operating via operating tools (e.g. FieldCare), the Language parameter is located under Setup

 → Advanced setup → Display"

 Only if operating via an FDT/DTM system

 Only available if operating via the local display

 Only available if operating via DeviceCare or FieldCare

 When you call up the "Expert" menu, you are always asked for an access code. If a customer-specific access
- 2)
- 3)
- 4) 5) code has not been defined, "0000" must be entered.

8.2.2 User roles and related access authorization

The two user roles **Operator** and **Maintenance** have different write access to the parameters if a device-specific access code has been defined. This protects the device configuration via the local display from unauthorized access (Verweisziel existiert nicht, aber @y.link.required='true').

Access authorization to parameters

User role Read access		Read access		access
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	
Maintenance	V	~	V	V

If an incorrect access code is entered, the user obtains the access rights of the **Operator** role.



The user role with which the user is currently logged on is indicated by the **Access status display** parameter (for display operation) or **Access status tooling** parameter (for tool operation).

8.2.3 Data access - Security

Write protection via access code

Using the device-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Define access code via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Repeat the numeric code in the **Confirm access code** parameter to confirm it.
 - ► The 🖻-symbol appears in front of all write-protected parameters.

Define access code via operating tool (e.g. FieldCare)

- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Define a max. 4-digit numeric code as an access code.
 - ▶ Write protection is active.

Parameters that can always be changed

The write protection does not include certain parameters that do not affect the measurement. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. If the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the write-protected parameters after 60 s.



- In the "Description of Device Parameters" documents, each write-protected parameter is identified with the 🛍-symbol.

Disabling write protection via access code

The locking of the write access via local operation can be disabled by entering the device-specific access code.

- 1. After you press E, the input prompt for the access code appears.
- 2. Enter the access code.
 - The \(\mathbb{O}\)-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

Deactivation of the write protection via access code

Via local display

- Navigate to: Setup → Advanced setup → Administration → Define access code
 Define access code
- 2. Enter **0000**.
- 3. Repeat **0000** in the **Confirm access code** parameter to confirm.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Via an operating tool (e.g. FieldCare)


- 1. Navigate to: Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code
- 2. Enter **0000**.
 - The write protection is deactivated. Parameters can be changed without entering an access code.

Write protection via write protection switch

Unlike parameter write protection via a user-specific access code, this allows the user to lock write access to the entire operating menu - apart from the **"Contrast display"** parameter.


The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):

- Via local display
- Via FOUNDATION Fieldbus




A0021474

- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the write protection switch, attach the display module to the edge of the electronics compartment.



A0036086

- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter. In addition, on the local display the symbol appears in front of the parameters in the header of the operational display and in the navigation view.



- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

Enabling and disabling the keypad lock

Access to the entire operating menu via local operation can be locked via the keypad lock. When access is locked, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

The keypad lock is switched on and off via a context menu.

Switching on the keypad lock

SD03 display module only

The keypad lock is switched on automatically:

- If the device has not been operated via the display for > 1 minute.
- Each time the device is restarted.

To activate the keylock manually:

1. The device is in the measured value display.

Press E for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

1. The keypad lock is switched on.

Press

for at least 2 seconds.

- ► A context menu appears.
- 2. In the context menu select the **Keylock off** option.
 - ► The keypad lock is switched off.


Bluetooth® wireless technology

Signal transmission via Bluetooth® wireless technology uses a cryptographic technique tested by the Fraunhofer Institute

- The device is not visible via *Bluetooth*® wireless technology without the SmartBlue app
- Only one point-to-point connection between one sensor and one smartphone or tablet is established

8.3 Display and operating module

8.3.1 Display



■ 18 Display format on the display and operating module

- 1 Measured value display (1 value max. size)
- 1.1 Header containing tag and error symbol (if an error is active)
- 1.2 Measured value symbols
- 1.3 Measured value
- 1.4 Unit
- 2 Measured value display (bar graph + 1 value)
- 2.1 Bargraph for measured value 1
- 2.2 Measured value 1 (including unit)
- 2.3 Measured value symbols for measured value 1
- 2.4 Measured value 2
- 2.5 Unit for measured value 2
- 2.6 Measured value symbols for measured value 2
- 3 Parameter display (here: parameter with picklist)
- 3.1 Header containing parameter name and error symbol (if an error is active)
- 3.2 Picklist; \square marks the current parameter value.
- 4 Input matrix for numbers
- 5 Input matrix for alphanumeric and special characters

50

Display symbols for the submenus

Symbol	Meaning
A0018367	Display/operat. Is displayed: In the main menu next to the "Display/operat." selection In the header on the left in the "Display/operat." menu
A0018364	Setup Is displayed: In the main menu next to the "Setup" selection In the header on the left in the "Setup" menu
A0018365	Expert Is displayed: In the main menu next to the "Expert" selection In the header on the left in the "Expert" menu
A0018366	Diagnostics Is displayed: ■ In the main menu next to the "Diagnostics" selection ■ In the header on the left in the "Diagnostics" menu

Status signals

Symbol	Meaning	
A0032902	"Failure" A device error has occurred. The measured value is no longer valid.	
C	"Function check" The device is in the service mode (e.g. during a simulation).	
S	 "Out of specification" The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range) 	
M	"Maintenance required" Maintenance is required. The measured value is still valid.	

Display symbols for locking status

Symbol	Meaning
A001314	Read-only parameter The parameter shown is only for display purposes and cannot be edited.
	Device locked
A001315	 In front of a parameter name: The device is locked via software and/or hardware. In the header of the measured value screen: The device is locked via hardware.


Measured value symbols

Symbol	Meaning
Measured values	
[~~]	Level
A0032892	
A0032893	Distance
(Current output
A0032908	Measured current
(A)	measured current
A0032894	
W	Terminal voltage
A0032895	
	Electronics or sensor temperature
A0032896	
Measuring channels	
1	Measuring channel 1
A0032897	
(2)	Measuring channel 2
A0032898	
Status of the measure	d value
A0018361	"Alarm" status The measurement is interrupted. The output assumes the defined alarm condition. A diagnostic message is generated.
A0018360	"Warning" status The device continues to measure. A diagnostic message is generated.

8.3.2 Operating elements

Key	Meaning
	Minus key
	In a menu, submenu Moves the selection bar upwards in a picklist.
A0018330	In the text and numeric editor In the input mask, moves the selection bar to the left (backwards).
	Plus key
+	In a menu, submenu Moves the selection bar downwards in a picklist.
A0018329	In the text and numeric editor In the input mask, moves the selection bar to the right (forwards).
	Enter key
	For measured value display ■ Pressing the key briefly opens the operating menu. ■ Pressing the key for 2 s opens the context menu.
E) A0018328	 In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Pressing the key for 2 s in a parameter: If present, opens the help text for the function of the parameter.
	 In the text and numeric editor Pressing the key briefly: Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value.
	Escape key combination (press keys simultaneously)
—++ A0032909	 In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the measured value display ("home position").
	In the text and numeric editor Closes the text or numeric editor without applying changes.
-+E	Minus/Enter key combination (press and hold down the keys simultaneously)
A0032910	Reduces the contrast (brighter setting).
++E A0032911	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).

8.3.3 Entering numbers and text



Input mask


The following input and operating symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
0	Selection of numbers from 0 to 9.
9 A0013998	
A0016619	Inserts decimal separator at the cursor position.
— A0016620	Inserts minus sign at the cursor position.
A0013985	Confirms selection.
A0016621	Moves the input position one position to the left.
X A0013986	Exits the input without applying the changes.
C	Clears all entered characters.

Text editor

Symbol	Meaning
ABC	Selection of letters from A to Z



Text correction under ₹C←∃

Symbol	Meaning
C	Clears all entered characters.
A0032907	
-	Moves the input position one position to the right.
A0018324	
4	Moves the input position one position to the left.
A0018326	
₹ X	Deletes one character immediately to the left of the input position.
A0032906	

8.3.4 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:

- Setup
- Conf. backup disp.
- Envelope curve
- Keylock on

Calling up and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
 - ► The context menu opens.



A003787

- 2. Press \Box + \pm simultaneously.
 - └ The context menu is closed and the operational display appears.

Calling up the menu via the context menu


- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.

3. Press **E** to confirm the selection.

► The selected menu opens.

8.3.5 Envelope curve display on the display and operating module

In order to assess the measuring signal, the envelope curve and - if a mapping has been recorded - the mapping curve can be shown on the display and operating module:



9 Integration into a FOUNDATION Fieldbus network

9.1 Device Description (DD)

You require the following to configure a device and integrate it into an FF network:

- An FF configuration program
- The Cff file (Common File Format: *.cff)
- The device description (DD) in one of the following formats
 - Device Description format 4: *sym, *ffo
 - Device Description format 5: *sy5, *ff5

Information on the device-specific DD

Manufacturer ID	452B48hex
Device Type	100Fhex
Device Revision	05hex
DD Revision	Information and files at:
CFF Revision	www.endress.comwww.fieldcommgroup.org

9.2 Integration into the FOUNDATION Fieldbus network

- For more in-depth information on integrating the device into the FF system, see the description for the configuration software used.
 - When integrating the field devices into the FF system, make sure you are using the right files. You can read out the required version by means of the Device Revision/ DEV REV and DD Revision/ DD REV parameters in the Resource Block.


The device is integrated into the FF network as follows:

- 1. Start the FF configuration program.
- 2. Download the Cff and device description files (*.ffo, *.sym (for format 4) *ff5, *sy5 (for format 5) to the system.
- 3. Configure the interface.
- 4. Configure the device for the measuring task and for the FF system.

9.3 Device identification and addressing

FOUNDATION Fieldbus identifies the device using its ID code (Device ID) and automatically assigns it a suitable field address. The identity code cannot be changed. The device appears in the network display once you have started the FF configuration program and integrated the device into the network. The blocks available are displayed under the device name.

If the device description has not yet been loaded, the blocks report "Unknown" or "(UNK)".



 $\blacksquare~19~$ Typical display in a configuration program after the connection has been established

- 1 Device name
- 2 Serial number

9.4 Block model

9.4.1 Blocks of the device software

The device has the following blocks:

- Resource Block (device block)
- Transducer Blocks
 - Setup Transducer Block (TRDSUP)
 - Advanced Setup Transducer Block (TRDASUP)
 - Display Transducer Block (TRDDISP)
 - Diagnostic Transducer Block (TRDDIAG)
 - Expert Configuration Transducer Block (TRDEXP)
 - Expert Information Transducer Block (TRDEXPIN)
 - Service Sensor Transducer Block (TRDSRVSB)
 - Service Information Transducer Block (TRDSRVIF)
 - Data Transfer Transducer Block (TRDHROM)
- Function Blocks
 - 2 Analog Input Blocks (AI)
 - 1 Discrete Input Block (DI)
 - 1 PID Block (PID)
 - 1 Arithmetic Block (AR)
 - 1 Signal Characterizer Block (SC)
 - 1 Input Selector Block (IS)
 - 1 Integrator Block (IT)
 - 1 Analog Alarm Block (AAL)

In addition to the pre-instantiated blocks already mentioned, the following blocks can also be instantiated:


- 5 Analog Input Blocks (AI)
- 2 Discrete Input Blocks (DI)
- 3 PID Blocks (PID)
- 3 Arithemetic Blocks (AR)
- 2 Signal Characterizer Blocks (SC)
- 5 Input Selector Blocks (IS)
- 3 Integrator Blocks (IT)
- 2 Analog Alarm Blocks (AAL)

Up to 20 blocks can be instantiated in the device altogether, including the blocks already instantiated. For instantiating blocks, see the appropriate Operating Instructions of the configuration program used.

Endress+Hauser Guideline BA00062S.

The guideline provides an overview of the standard function blocks that are described in FOUNDATION Fieldbus Specifications FF 890 - 894. It is designed to help operators use the blocks implemented in the Endress+Hauser field devices.

9.4.2 Block configuration when device is delivered



■ 20 Block configuration when device is delivered

S Sensor

PV Primary value: Level linearized

SV Secondary value: Distance

9.5 Assignment of the measured values (CHANNEL) in an AI Block

The input value of an Analog Input Block is defined by the **CHANNEL** parameter.

Channel	Measured value
0	Uninitialized
89	Measured capacitance
144	EOP shift

Channel	Measured value
145	Interface distance
172	Calculated DC value
211	Terminal voltage
212	Sensor debug
32785	Absolute EOP amplitude
32786	Absolute echo amplitude
32787	Absolute interface amplitude
32856	Distance
32885	Elektronic temperature
32938	Interface linearized
32949	Level linearized
33044	Relative echo amplitude
33045	Relative interface amplitude
33070	Noise of signal
33107	Upper interface thickness

9.6 Index tables of Endress+Hauser parameters

The following tables list the manufacturer-specific device parameters for the Resource Blocks. For the FOUNDATION Fieldbus parameters, see the document BA062S "Guidline - FOUNDATION Fieldbus Function Blocks", which can be downloaded from www.endress.com.

9.6.1 Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
confirm_distance	Confirm distance	82	ENUM16	2	Static	х	OOS	→ 🖺 133
filtered_dist_val	Distance	76	FLOAT	4	Dynamic			→ 🖺 130
interface_distance	Interface distance	79	FLOAT	4	Dynamic			→ 🖺 132
map_end_x	Present mapping	84	FLOAT	4	Dynamic			→ 🖺 134
mapping_end_point	Mapping end point	83	FLOAT	4	Static	х	AUTO	→ 🖺 134
record_map	Record map	86	ENUM16	2	Static	х	OOS	→ 🖺 135
operating_mode	Operating mode	50	ENUM16	2	Static	х	OOS	→ 🖺 126
signal_quality	Signal quality	81	ENUM16	2	Dynamic			→ 🖺 130
medium_group	Medium group	55	ENUM16	2	Static	х	OOS	→ 🖺 127
tank_type	Tank type	52	ENUM16	2	Static	х	OOS	→ 🖺 126
tube_diameter	Tube diameter	53	FLOAT	4	Static	х	OOS	→ 🖺 127
dc_value	DC value	68	ENUM16	2	Static	х	OOS	→ 🖺 131
empty_calibration	Empty calibration	56	FLOAT	4	Static	х	OOS	→ 🖺 128
full_calibration	Full calibration	57	FLOAT	4	Static	х	OOS	→ 🖺 128
distance_unit	Distance unit	51	ENUM16	2	Static	х	OOS	→ 🖺 126
interface	Interface	70	FLOAT	4	Dynamic			→ 🖺 131
output_unit_after_lineariza tion	Unit after linearization	62	ENUM16	2	Static			→ 🖺 152

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BL K	Description
level_linearized	Level linearized	64	FLOAT	4	Dynamic			→ 🖺 154
present_probe_length	Present probe length	87	FLOAT	4	Dynamic	х	AUTO	→ 🖺 162
level	Level	60	FLOAT	4	Dynamic			→ 🖺 129
interface_linearized	Interface linearized	73	FLOAT	4	Dynamic			→ 🖺 154
decimal_places_menu_ro	Decimal places	93	ENUM16	2	Static	х	AUTO	→ 🖺 173
locking_status	Locking status	96	BIT_ENU M16	2	Dynamic			→ 🖺 139

9.6.2 Advanced Setup Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
calculated_dc_value	Calculated DC value	61	FLOAT	4	Dynamic			→ 🖺 145
blocking_distance	Blocking distance	55	FLOAT	4	Static	х	OOS	→ 🖺 160
interface_property	Interface property	57	ENUM16	2	Static	х	OOS	→ 🖺 141
dc_value_lower_medium	DC value lower medium	58	FLOAT	4	Static	х	OOS	→ 🖺 142
present_probe_length_ro	Present probe length	80	FLOAT	4	Dynamic	х	AUTO	→ 🖺 162
confirm_probe_length	Confirm probe length	79	ENUM16	2	Static	х	OOS	→ 🖺 163
meas_upper_iface_thickne	Measured thickness upper layer	60	FLOAT	4	Dynamic			→ 🖺 145
manual_interface_thicknes	Manual thickness upper layer	59	FLOAT	4	Static	х	OOS	→ 🖺 144
use_calculated_dc_value	Use calculated DC value	62	ENUM16	2	Static	х	OOS	→ 🖺 146
linearization_type	Linearization type	71	ENUM16	2	Static	х	OOS	→ 🖺 151
activate_table	Activate table	70	ENUM16	2	Static	х	OOS	→ 🖺 157
table_mode	Table mode	69	ENUM16	2	Static	х	OOS	→ 🖺 155
custom_table_sel_level	Level	73	FLOAT	4	Static	х	OOS	→ 🖺 129
custom_table_sel_value	Customer value	74	FLOAT	4	Static	х	OOS	→ 🖺 157
unit_after_linearization	Unit after linearization	63	ENUM16	2	Static	х	OOS	→ 🖺 152
free_text	Free text	64	STRING		Static	х	AUTO	→ 🖺 153
diameter	Diameter	66	FLOAT	4	Static	х	OOS	→ 🖺 154
output_echo_lost	Output echo lost	76	ENUM16	2	Static	х	OOS	→ 🖺 159
intermediate_height	Intermediate height	67	FLOAT	4	Static	х	AUTO	→ 🖺 155
assign_limit	Assign limit	82	ENUM16	2	Static	х	AUTO	→ 🖺 166
maximum_value	Maximum value	65	FLOAT	4	Static	х	OOS	→ 🖺 154
assign_diag_behavior	Assign diagnostic behavior	83	ENUM16	2	Static	х	AUTO	→ 🖺 166
value_echo_lost	Value echo lost	77	FLOAT	4	Static	х	OOS	→ 🖺 159
ramp_at_echo_lost	Ramp at echo lost	78	FLOAT	4	Static	х	OOS	→ 🖺 160
switch_output_failure_mod e	Failure mode	88	ENUM16	2	Static	х	AUTO	→ 🖺 169
switch_output_function	Switch output function	81	ENUM16	2	Static	х	AUTO	→ 🖺 165
switch_status	Switch status	89	ENUM16	2	Dynamic			→ 🖺 169
switch_off_delay	Switch-off delay	87	FLOAT	4	Static	х	AUTO	→ 🖺 169
switch_off_value	Switch-off value	86	FLOAT	4	Static	х	AUTO	→ 🖺 168

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
switch_on_delay	Switch-on delay	85	FLOAT	4	Static	х	AUTO	→ 🖺 168
switch_on_value	Switch-on value	84	FLOAT	4	Static	х	AUTO	→ 🖺 167
operating_mode_ro	Operating mode	95	ENUM16	2	Static	х	OOS	→ 🖺 126
table_number	Table number	68	UINT8	1	Static	х	OOS	→ 🖺 156
level_semiautomatic	Level	75	FLOAT	4	Dynamic			→ 🖺 157
assign_status	Assign status	91	ENUM16	2	Static	х	AUTO	→ 🖺 165
locking_status	Locking status	99	BIT_ENUM16	2	Dynamic			→ 🖺 139
decimal_places_menu	Decimal places menu	93	ENUM16	2	Static	х	AUTO	→ 🖺 175
distance_unit_ro	Distance unit	92	ENUM16	2	Static	х	oos	→ 🖺 126

9.6.3 Display Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write	MODE_BLK	Description
access_status_display	Access status display	51	ENUM16	2	Static			→ 🖺 139
display_damping	Display damping	65	FLOAT	4	Static	х	AUTO	→ 🖺 174
display_interval	Display interval	64	FLOAT	4	Static	х	AUTO	→ 🖺 174
header	Header	66	ENUM16	2	Static	х	AUTO	→ 🖺 174
format_display	Format display	55	ENUM16	2	Static	х	AUTO	→ 🖺 171
number_format	Number format	69	ENUM16	2	Static	х	AUTO	→ 🖺 175
display_separator	Separator	68	ENUM16	2	Static	х	AUTO	→ 🖺 175
language	Language	54	ENUM16	2	Static	х	AUTO	→ 🖺 171
contrast_display	Contrast display	71	FLOAT	4	Static	х	AUTO	→ 🖺 176
header_text	Header text	67	STRING		Static	х	AUTO	→ 🖺 175
access_code_for_display	Enter access code	52	UINT16	2	Static	х	AUTO	→ 🖺 140
configuration_management	Configuration management	75	ENUM16	2	Static	х	AUTO	→ 🖺 177
decimal_places_1	Decimal places 1	57	ENUM16	2	Static	х	AUTO	→ 🖺 173
decimal_places_2	Decimal places 2	59	ENUM16	2	Static	х	AUTO	→ 🖺 173
decimal_places_3	Decimal places 3	61	ENUM16	2	Static	х	AUTO	→ 🖺 173
decimal_places_4	Decimal places 4	63	ENUM16	2	Static	х	AUTO	→ 🖺 173
last_backup	Last backup	74	STRING		Static	х	AUTO	→ 🖺 177
value_1_display	Value 1 display	56	ENUM16	2	Static	х	AUTO	→ 🖺 173
value_2_display	Value 2 display	58	ENUM16	2	Static	x	AUTO	→ 🖺 173
value_3_display	Value 3 display	60	ENUM16	2	Static	х	AUTO	→ 🖺 173
value_4_display	Value 4 display	62	ENUM16	2	Static	х	AUTO	→ 🖺 173
locking_status_display	Locking status	50	ENUM16	2	Static			→ 🖺 139
define_access_code	Define access code	53	UINT16	2	Static	х	AUTO	→ 🖺 180
comparison_result	Comparison result	76	ENUM16	2	Static	x	AUTO	→ 🖺 178
decimal_places_menu	Decimal places menu	70	ENUM16	2	Static	х	AUTO	→ 🖺 175
operating_time	Operating time	73	STRING		Dynamic			→ 🖺 177
operating_mode_ro	Operating mode	83	ENUM16	2	Static	х	OOS	→ 🖺 126
locking_status	Locking status	85	BIT_ENUM16	2	Dynamic			→ 🖺 139

9.6.4 Diagnostic Transducer Block

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK	Description
operating_time	Operating time	55	STRING		Dynamic			→ 🖺 177
diagnostics_1	Diagnostics	56	UINT32	4	Static			→ 🖺 185
diagnostics_2	Diagnostics 2	58	UINT32	4	Static			→ 🖺 185
diagnostics_3	Diagnostics 3	60	UINT32	4	Static			→ 🖺 185
diagnostics_4	Diagnostics 4	62	UINT32	4	Static			→ 🖺 185
diagnostics_5	Diagnostics 5	64	UINT32	4	Static			→ 🖺 185
operating_time_from_resta rt	Operating time from restart	54	STRING		Dynamic			→ 🖺 184
launch_signal	Launch signal	81	ENUM16	2	Dynamic			→ 🖺 203
start_device_check	Start device check	77	ENUM16	2	Static	х	AUTO	→ 🖺 202
interface_signal	Interface signal	82	ENUM16	2	Dynamic			→ 🖺 203
level_signal	Level signal	80	ENUM16	2	Dynamic			→ 🖺 203
simulation_device_alarm	Simulation device alarm	75	ENUM16	2	Static	х	OOS	→ 🖺 201
filter_options	Filter options	66	ENUM8	1	Static	х	AUTO	→ 🖺 186
previous_diagnostics	Previous diagnostics	52	UINT32	4	Static			→ 🖺 183
actual_diagnostics	Actual diagnostics	50	UINT32	4	Static			→ 🖺 183
assign_sim_meas	Assign measurement variable	71	ENUM16	2	Static	х	OOS	→ 🖺 200
sim_value_process_variabl	Process variable value	72	FLOAT	4	Static	х	OOS	→ 🖺 200
switch_output_simulation	Switch output simulation	73	ENUM16	2	Static	х	OOS	→ 🖺 200
sim_switch_status	Switch status	74	ENUM16	2	Static	х	OOS	→ 🖺 201
result_device_check	Result device check	78	ENUM16	2	Dynamic			→ 🖺 202
last_check_time	Last check time	79	STRING		Dynamic			→ 🖺 202
linearization_type	Linearization type	84	ENUM16	2	Static	х	OOS	→ 🖺 151
unit_after_linearization_ro	Unit after linearization	85	STRING		Static	х	AUTO	→ 🖺 152
decimal_places_menu	Decimal places menu	88	ENUM16	2	Static	х	AUTO	→ 🖺 175
operating_mode_ro	Operating mode	91	ENUM16	2	Static	х	OOS	→ 🖺 126
assign_channel_1	Assign channel 1	92	ENUM16	2	Static	х	AUTO	→ 🖺 194
assign_channel_2	Assign channel 2	93	ENUM16	2	Static	х	AUTO	→ 🖺 194
assign_channel_3	Assign channel 3	94	ENUM16	2	Static	х	AUTO	→ 🖺 194
assign_channel_4	Assign channel 4	95	ENUM16	2	Static	х	AUTO	→ 🖺 194
clear_logging_data	Clear logging data	97	ENUM16	2	Static	х	AUTO	→ 🖺 195
logging_interval	Logging interval	96	FLOAT	4	Static	х	AUTO	→ 🖺 195
display_filter_options	Filter options	99	ENUM8	1	Static	х	AUTO	→ 🖺 186
locking_status	Locking status	108	BIT_ENUM16	2	Dynamic			→ 🖺 139
distance_unit_ro	Distance unit	89	ENUM16	2	Static	х	OOS	→ 🖺 126

9.6.5 Expert Configuration Transducer Block

The parameters of the **Expert Configuration Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
acknowledge_alarm	Acknowledge alarm	81	ENUM16	2	Static	х	AUTO
integration_time	Integration time	67	FLOAT	4	Static	х	OOS
result_self_check	Result self check	77	ENUM16	2	Dynamic		
start_self_check	Start self check	76	ENUM16	2	Static	х	AUTO
broken_probe_detection	Broken probe detection	75	ENUM16	2	Static	х	AUTO
gpc_mode	GPC mode	68	ENUM16	2	Static	х	OOS
reference_echo_threshold	Reference echo threshold	73	FLOAT	4	Static	х	OOS
const_gpc_factor	Const. GPC factor	74	FLOAT	4	Static	х	OOS
build_up_ratio	Build-up ratio	90	FLOAT	4	Dynamic		
build_up_threshold	Build-up thres.	91	FLOAT	4	Static	х	AUTO
delay_time_echo_lost	Delay time echo lost	78	FLOAT	4	Static	х	AUTO
empty_capacity	Empty capacity	92	FLOAT	4	Static	х	AUTO
external_pressure_selector	External pressure selector	69	ENUM16	2	Static	х	OOS
measured_capacity	Measured capacitance	89	FLOAT	4	Dynamic		
gas_phase_compens_factor	Gas phase compensation factor	70	FLOT	4	Static	х	OOS
in_safety_distance	In safety distance	80	ENUM16	2	Static	х	OOS
ratio_amplitude_interface_level	Ratio amplitude interface/level	86	FLOAT	4	Static	х	OOS
interface_criterion	Interface criterion	87	FLOAT	4	Dynamic		
control_measurement	Measurement	106	ENUM16	2	Static	х	AUTO
control_measurement	Control measurement	105	ENUM16	2	Static	х	AUTO
filter_dead_time	Dead time	66	FLOAT	4	Static	х	OOS
present_reference_distance	Present reference distance	72	FLOAT	4	Dynamic		
history_reset	History reset	83	ENUM16	2	Static	х	OOS
safety_distance	Safety distance	79	FLOAT	4	Static	х	OOS
history_learning_control	History learning	85	ENUM16	2	Static	х	AUTO
history_learning_control	History learning control	84	ENUM16	2	Static	х	AUTO
sensor_module	Sensor module	107	ENUM16	2	Static		
evaluation_mode	Evaluation mode	82	ENUM16	2	Static	х	OOS
thin_interface	Thin interface	88	ENUM16	2	Static	х	OOS
calculated_dc_value	Calculated DC value	59	FLOAT	4	Dynamic	х	AUTO
dc_value_expert	DC value	55	FLOAT	4	Static	х	OOS
distance_offset	Distance offset	60	FLOAT	4	Static	х	OOS
level_limit_mode	Level limit mode	62	ENUM16	2	Static	х	OOS
level_high_limit	High limit	63	FLOAT	4	Static	х	OOS
level_low_limit	Low limit	64	FLOAT	4	Static	х	OOS
output_mode	Output mode	65	ENUM16	2	Static	х	OOS
level_external_input_1	Level external input 1	93	ENUM16	2	Static	х	AUTO
level_external_input_2	Level external input 2	96	ENUM16	2	Static	х	AUTO
function_input_1_level	Function Input 1 Level	94	ENUM16	2	Static	х	AUTO
function_input_2_level	Function Input 2 Level	97	ENUM16	2	Static	х	AUTO
fixed_value_inp_1	Fixed value inp.1	95	FLOAT	4	Static	х	AUTO
fixed_value_inp_2	Fixed value inp.2	98	FLOAT	4	Static	х	AUTO
interface_external_input_1	Interface external input 1	99	ENUM16	2	Static	х	OOS

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
interface_external_input_2	Interface external input 2	102	ENUM16	2	Static	х	oos
function_input_1_interface	Function input 1 interface	100	ENUM16	2	Static	х	OOS
function_input_2_interface	Function input 2 interface	103	ENUM16	2	Static	х	OOS
fixed_value_input_1_interface	Fixed value input 1 interface	101	FLOAT	4	Static	х	oos
fixed_value_input_2_interface	Fixed value input 2 interface	104	FLOAT	4	Static	х	oos
distance_unit_ro	Distance unit	53	ENUM16	2	Static	х	OOS
level_unit_ro	Level unit	61	ENUM16	2	Static	х	OOS
operating_mode_ro	Operating mode	54	ENUM16	2	Static	х	OOS
enter_access_code	Enter access code	52	UINT16	2	Static	х	AUTO
locking_status	Locking status	50	BIT_ENUM16	2	Dynamic		
access_status_tooling	Access status tooling	51	ENUM16	2	Static		
reference_distance	Reference distance	71	FLOAT	4	Static	х	oos
sw_option_active_overview	SW option active overview	110	BIT_ENUM32	4	Static		
decimal_places_menu	Decimal places menu	109	ENUM16	2	Static	х	AUTO
fieldbus_type	Fieldbus Type	111	ENUM8	1	Static		
interface_property_ro	Interface property	108	ENUM16	2	Static	х	oos
medium_type_ro	Medium type	112	ENUM16	2	Static	х	oos
eop_level_evaluation_ro	EOP level evaluation	113	ENUM16	2	Static	х	oos
sensor_type_ro	Sensor type	114	ENUM16	2	Static	х	OOS
calculated_dc_status_en	Status	58	ENUM8	1	Dynamic		

Expert Information Transducer Block 9.6.6



The parameters of the **Expert Information Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
abs_echo_amp_val	Absolute echo amplitude	51	FLOAT	4	Dynamic		
abs_eop_amp_val	Absolute EOP amplitude	55	FLOAT	4	Dynamic		
absolute_interface_amplitude	Absolute interface amplitude	58	FLOAT	4	Dynamic		
application_parameter	Application parameter	74	ENUM16	2	Dynamic		
electronic_temp_value	Electronic temperature	66	FLOAT	4	Dynamic		
eop_shift_value	EOP shift	69	FLOAT	4	Dynamic		
found_echoes	Found echoes	71	ENUM16	2	Dynamic		
max_electr_temp	Max. electronics temperature	73	FLOAT	4	Dynamic	х	AUTO
time_max_electr_temp	Time max. electronics temperature	75	STRING		Dynamic		
measurement_frequency	Measurement frequency	76	FLOAT	4	Dynamic		
min_electr_temp	Min. electronics temperature	77	FLOAT	4	Dynamic	х	AUTO
time_min_electr_temp	Time min. electronics temperature	78	STRING		Dynamic		
rel_echo_amp_val	Relative echo amplitude	53	FLOAT	4	Dynamic		
relative_interface_amplitude	Relative interface amplitude	60	FLOAT	4	Dynamic		
reset_min_max_temp	Reset min./max. temp.	79	ENUM16	2	Static	х	AUTO
noise_signal_val	Noise of signal	63	FLOAT	4	Dynamic		

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
used_calculation	Used calculation	80	ENUM16	2	Dynamic		
tank_trace_state	Tank trace state	81	ENUM16	2	Dynamic		
max_draining_speed	Max. draining speed	82	FLOAT	4	Dynamic	х	AUTO
max_filling_speed	L max. fill speed	83	FLOAT	4	Dynamic	х	AUTO
time_max_level	Time max. level	84	STRING		Dynamic		
max_level_value	Max. level value	85	FLOAT	4	Dynamic	х	AUTO
time_min_level	Time min. level	86	STRING		Dynamic		
min_level_value	Min. level value	87	FLOAT	4	Dynamic	х	AUTO
reset_min_max	Reset min./max.	94	ENUM16	2	Static	х	AUTO
interf_max_drain_speed	I max. drain speed	88	FLOAT	4	Dynamic	х	AUTO
interf_max_fill_speed	I max. fill speed	89	FLOAT	4	Dynamic	х	AUTO
time_max_interface	Time max. interface	90	STRING		Dynamic		
max_interface_value	Max. interface value	91	FLOAT	4	Dynamic	х	AUTO
time_min_interface	Time min. interface	92	STRING		Dynamic		
min_interface_value	Min. interface value	93	FLOAT	4	Dynamic	х	AUTO
application_parameter	Application parameter	95	ENUM16	2	Dynamic		
operating_mode_ro	Operating mode	108	ENUM16	2	Static	х	OOS
temperature_unit	Temperature unit	72	ENUM16	2	Static	х	AUTO
activate_sw_option	Activate SW option	110	UINT32	4	Static	х	AUTO
target_echo_status	Status	56	ENUM8	1	Dynamic		
iface_target_echo_status	Status	61	ENUM8	1	Dynamic		
signal_noise_status	Status	64	ENUM8	1	Dynamic		
sens_temp_status	Status	67	ENUM8	1	Dynamic		
eop_shift_status	Status	70	ENUM8	1	Dynamic		
terminal_voltage_1	Terminal voltage 1	97	FLOAT	4	Dynamic		
calculated_dc_value	Calculated DC value	100	FLOAT	4	Dynamic	х	AUTO
upper_interface_thickness	Upper interface thickness	103	FLOAT	4	Dynamic		
debug_value	Debug value	106	FLOAT	4	Dynamic	х	AUTO
sw_option_active_overview	SW option active overview	111	BIT_ENUM32	4	Static		
locking_status	Locking status	113	BIT_ENUM16	2	Dynamic		
decimal_places_menu_ro	Decimal places menu	109	ENUM16	2	Static	Х	AUTO
linearization_type	Linearization type	104	ENUM16	2	Static	х	OOS
eop_level_evaluation	EOP level evaluation	112	ENUM16	2	Static	Х	OOS
access_status_tooling	Access status tooling	114	ENUM16	2	Static		
calculated_dc_status	Status	99	UINT8	1	Dynamic		
status_up_iface_thickness	Customized upper phase thickness status	102	UINT8	1	Dynamic		
debug_status		107	UINT8	1	Dynamic	Х	AUTO

9.6.7 Service Sensor Transducer Block

The parameters of the **Service Sensor** Transducer Block can only be operated by authorized Endress+Hauser service personnel.

9.6.8 Service Information Transducer Block

The parameters of the **Service Information** Transducer Block can only be operated by authorized Endress+Hauser service personnel.

9.6.9 Data Transfer Transducer Block

The parameters of the **Data Transfer Transducer Block** are described in GP01015F: "Levelflex FMP5x - Description of Device Parameters - FOUNDATION Fieldbus"

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
used_calculation	Used calculation	87	ENUM16	2	Dynamic		
bdt_cfg_rdwr_ctrl		101	UINT16	2	Static	х	AUTO
bdt_transferred_ctrl		102	BYTEARRAY		Static	х	AUTO
bdt_data_trans		103	BYTEARRAY		Static	х	AUTO
bdt_prepare		99	BYTEARRAY		Static	х	AUTO
bdt_status		100	BYTEARRAY		Static		
sw_option_active_overview	SW option active overview	98	BIT_ENUM32	4	Static		
digits_at_0_mVdB		90	FLOAT	4	Dynamic	х	AUTO
digits_per_mVdB		91	FLOAT	4	Dynamic	х	AUTO
actual_diagnostics	Actual diagnostics	97	UINT32	4	Static		
electric_probe_length	Electric probe length	92	FLOAT	4	Dynamic		
empty_calibration_ro	Empty calibration	93	FLOAT	4	Static	х	OOS
full_calibration_ro	Full calibration	94	FLOAT	4	Static	х	OOS
distance_unit_ro	Distance unit	95	ENUM16	2	Static	х	OOS
operating_mode_ro	Operating mode	88	ENUM16	2	Static	х	OOS
present_probe_length_ro	Present probe length	89	FLOAT	4	Dynamic	х	AUTO
trend_operation_hours		104	UINT32	4	Static		
trend_package_size		105	UINT8	1	Static	х	AUTO
trend_storage_time	Trend storage time	106	UINT32	4	Static		
trend_sup_pack_size		107	UINT8	1	Static		
gpc_mode_ro	GPC mode	109	ENUM16	2	Static	х	OOS
eop_level_evaluation_ro	EOP level evaluation	110	ENUM16	2	Static	х	OOS
temperature_unit_ro	Temperature unit	111	ENUM16	2	Static	х	OOS
max_trend_entries		108	UINT16	2	Static		
line_mapping_point_number	Line mapping point number	126	UINT16	2	Static	х	AUTO
line_mapping_array_x	Line mapping array X	127	FLOAT	4	Static	х	AUTO
line_mapping_array_y	Line mapping array Y	128	FLOAT	4	Static	х	AUTO
mapping_end_point_ro	Mapping end point	125	FLOAT	4	Static	х	AUTO
mapping_start_point	Mapping start point	124	FLOAT	4	Static	х	AUTO
function_block_table		143	UINT32	4	Static		
custom_empty_value		112	FLOAT	4	Static		
custom_full_value		113	FLOAT	4	Static		
customized	Customized	121	UINT8	1	Static		
reset_ordered_configuration	Reset ordered configuration	122	ENUM16	2	Static	х	AUTO
empty_scale		114	FLOAT	4	Static	х	AUTO

Name	Label	Index	Data type	Size (Bytes)	Storage Class	Write access	MODE_BLK
eop_map_point_number		116	UINT16	2	Static	х	AUTO
factory_data_valid		123	UINT8	1	Static		
fieldbus_type	Fieldbus Type	144	ENUM8	1	Static		
full_scale		115	FLOAT	4	Static	х	AUTO
init_map_point_number		117	UINT16	2	Static	х	AUTO
max_not_assoc_track		118	UINT16	2	Static	х	AUTO
ref_max_dist	Ref max. dist.	119	FLOAT	4	Static	х	AUTO
ref_min_dist	Ref min. dist.	120	FLOAT	4	Static	х	AUTO
line_mapping_accuracy	Line mapping accuracy	130	FLOAT	4	Static	х	AUTO
mapping_curve_left_margin	Mapping curve left margin	131	FLOAT	4	Static	х	AUTO
device_calib_changed		133	ENUM16	2	Static	х	AUTO
echo_thresh_attenuat_const_ee	Threshold attenuation constant	134	FLOAT	4	Dynamic	х	AUTO
echo_threshold_far_ee		135	FLOAT	4	Static	х	AUTO
echo_thresh_inactive_len		137	FLOAT	4	Static	х	AUTO
echo_threshold_near_ee		136	FLOAT	4	Static	х	AUTO
present_probe_length_ee		138	FLOAT	4	Static	х	AUTO
reset_appl_para_chg_flags		139	ENUM16	2	Static	х	AUTO
reset_dyn_persistent		140	ENUM16	2	Static	х	AUTO
locking_status	Locking status	142	BIT_ENUM16	2	Dynamic		
decimal_places_menu	Decimal places menu	96	ENUM16	2	Static	х	AUTO
access_status_tooling	Access status tooling	141	ENUM16	2	Static		
level_linearized	Level linearized	147	FLOAT	4	Dynamic		
bdt_transferred_ctrl		197	UINT8	1	Static	х	AUTO
bdt_cfg_rdwr_ctrl		196	UINT16	2	Static	х	AUTO

9.7 Methods

The FOUNDATION Fieldbus Specification includes the use of methods to make device operation easier. A method is a sequence of interactive steps to be carried out in the specified order so as to configure certain device functions.

The following methods are available for the device:

Restart

This method is located in the Resource Block and directly prompts the setting of the **Device reset** parameter. This resets the device configuration to a defined state.

■ ENP Restart

This method is located in the Resource Block and directly prompts the setting of the parameters of the Electronic Name Plate (ENP).

Setup

This method is located in the SETUP Transducer Block and allows to set the most important parameters in this block for device configuration (measuring units, type of tank or vessel, type of medium, empty and full calibration).

Linearization

This method is located in the ADV_SETUP Transducer Block and allows to manage the linearization table by which the measured value is converted into volume, mass or flow.


Self Check

This method is located in the EXPERT_CONFIG Transducer Block and prompts the device self check parameters.

10 Commissioning using the Commissioning Wizard

A Wizard is provided in FieldCare and DeviceCare ¹⁾ that guides the user through the initial commissioning process.

- 1. Connect the device with FieldCare or DeviceCare.
- 2. Open the device in FieldCare or DeviceCare.
 - ► The dashboard (homepage) of the device is displayed:



- "Commissioning" button calls up the wizard
- 3. Click "Commissioning" to launch the Wizard.
- 4. Enter the appropriate value in each parameter or select the appropriate option. These values are written directly to the device.
- 5. Click "Next" to go to the next page.
- 6. Once all the pages have been completed, click "Finish" to close the Wizard.
- If you cancel the Wizard before all the necessary parameters have been entered, the device may be in an undefined state. In such situations, it is advisable to reset the device to the factory default settings.

¹⁾ DeviceCare is available for download at www.software-products.endress.com. To download the software, it is necessary to register in the Endress +Hauser software portal.


11 Commissioning via operating menu

11.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:


11.2 Setting the operating language

Factory setting: English or ordered local language



21 Taking the example of the local display

11.3 Configuring interface measurement



■ 22 Configuration parameters for interface measurement

- LN Probe length
- *R* Reference point of measurement
- DI Interface distance (distance from flange to lower medium)
- LI Interface
- DL Distance
- LL Level
- UP Thickness upper layer
- E Empty calibration (= zero point)
- F Full calibration (= span)
- 1. Navigate to: Setup → Device tag
 - ► Enter device tag.
- 2. Navigate to: Setup → Operating mode
 - Select the **Interface with capacitance** option.
- 3. Navigate to: Setup → Distance unit
 - ► Select the distance unit.
- 4. Navigate to: Setup → Tank type
 - Select tank type.
- 5. For **Tank type** parameter = Bypass / pipe:

Navigate to: Setup \rightarrow Tube diameter

- ► Specify the diameter of the bypass or stilling well.
- 6. Navigate to: Setup \rightarrow DC value
 - Specify the relative dielectric constant (ε_r) of the upper medium.
- 7. Navigate to: Setup \rightarrow Empty calibration
 - ► Specify the empty distance E (distance from reference point R to 0% mark).
- 8. Navigate to: Setup → Full calibration
 - ► Specify the full distance F (distance from the 0% mark to the 100% mark).
- 9. Navigate to: Setup → Level
 - ightharpoonup Displays the measured level L_L.
- 10. Navigate to: Setup \rightarrow Interface
 - ightharpoonup Displays the interface height L_I.

72

- 11. Navigate to: Setup → Distance
 - ightharpoonup Displays the distance D_L between the reference point R and the level L_L .
- 12. Navigate to: Setup \rightarrow Interface distance
 - ightharpoonup Displays the distance D_I between the reference point R and the interface L_I .
- 13. Navigate to: Setup \rightarrow Signal quality
 - ► Displays the signal quality of the analyzed level echo.
- 14. Operation via local display:

Navigate to: Setup \rightarrow Mapping \rightarrow Confirm distance

- └ Ensure that the tank is fully drained. Then select the Tank empty option.
- 15. Via an operating tool (e.g. FieldCare):

Navigate to: Setup → Confirm distance

► Ensure that the tank is fully drained. Then select the Tank empty option.

NOTICE

Wrong measurement due to incorrect dielectric constant of the lower medium

► The dielectric constant (DC value) of the lower medium must be specified if the lower medium is not water when **Operating mode** = **Interface with capacitance**. Navigation: Setup → Advanced setup → Interface → DC value lower medium

NOTICE

Wrong measurement due to incorrect empty capacitance

- ▶ In the case of rod and rope probes in the bypass, a correct measurement is only possible for **Operating mode** = **Interface with capacitance** after the empty capacitance has been determined. For this purpose, select **Confirm distance** = **Tank empty** after installing the probe when the tank is completely empty. A calculated empty capacitance can be entered for rod probes in the following parameters in exceptional cases only (if the tank cannot be emptied during commissioning): Expert → Sensor → Interface → Empty capacitance.
- The empty capacitance is always calibrated ex works in the case of coax probes.

11.4 Recording the reference envelope curve

After the measurement has been configured, it is recommended to record the current envelope curve as a reference envelope curve. This can then be used later for diagnostic purposes. The **Save reference curve** parameter is used to record the envelope curve.

Path in the menu

Expert \rightarrow Diagnostics \rightarrow Envelope diagnostics \rightarrow Save reference curve

Meaning of the options

- No
- No action
- Yes

The current envelope curve is saved as a reference curve.

- This submenu is only visible for the "Service" user role in devices supplied with software version 01.00.zz.
- The reference envelope curve can only be displayed in the envelope curve diagram of FieldCare after it has been loaded from the device into FieldCare. The "Load Reference Curve" function in FieldCare is used for this.



■ 23 "Load Reference Curve" function

11.5 Configuring the local display

11.5.1 Factory setting of local display for interface measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, max. size	1 value, max. size
Value 1 display	Interface linearized	Interface linearized
Value 2 display	Level linearized	Level linearized
Value 3 display	Thickness upper layer	Current output 1
Value 4 display	Current output 1	Current output 2

11.5.2 Adjusting the local display

The local display can be adjusted in the following submenu: Setup \to Advanced setup \to Display

11.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and the options available.

Path in the menu

Setup → Advanced setup → Configuration backup display → Configuration management

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration is saved from the HistoROM (integrated in the device) to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration of the device is duplicated to another device using the display module. The following parameters, which characterize the individual measuring point are **not** transferred:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of the comparison is displayed in the **Comparison result** parameter.

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup copy is restored on a device other than the original device using the **Restore** option, in some cases individual device functions may not be available. In some cases it is also not possible to restore the original state by resetting to the "asdelivered" state.

The **Duplicate** option should always be used to copy the configuration to another device.

11.7 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in two ways:

- Locking via parameters (software locking)
- Locking via write protection switch (hardware locking)

12 Commissioning (block-oriented operation)

12.1 Function check

Before commissioning your measuring point, ensure that the post-installation and post-connection checks have been performed:

- "Post-installation check" checklist → 🖺 31
- "Post-connection check" checklist → 🖺 38

12.2 Block configuration

12.2.1 Preparatory steps

- 1. Switch on the measuring device.
- 2. Make a note of the **DEVICE_ID**.
- 3. Open the configuration program.
- 4. Load Cff and device description files into the host system or the configuration program. Make sure you are using the right system files.
- 5. Identify the device using the **DEVICE_ID** (see Point 2). Assign the desired tag name to the device via the **Pd-tag/FF_PD_TAG** parameter.

12.2.2 Configuring the Resource Block

- 1. Open the Resource Block.
- 2. If necessary, disable the lock for device operation.
- 3. If necessary, change the block name. Factory setting: RS-xxxxxxxxx (RB2)
- 4. If necessary, assign a description to the block via the **Description of the identification tag/TAG_DESC** parameter.
- 5. If necessary, change other parameters as required.

12.2.3 Configuring the Transducer Blocks

The measurement and the display module are configured via the Transducer Blocks. The basic procedure is the same for all Transducer Blocks:

- 1. If necessary, change the block name.
- 2. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- 3. Configure the device in accordance with the measuring task.
- 4. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- The block mode must be set to **Auto** to ensure the smooth operation of the device.

12.2.4 Configuring the Analog Input Blocks

The device has 2 Analog Input Blocks that can be assigned as required to the various process variables.

Factory setting			
Analog Input Block CHANNEL			
AI 1	32949: Level linearized		
AI 2	32856: Distance		


- 1. If necessary, change the block name.
- 2. Set the block mode to **OOS** via the **Block mode/MODE_BLK** parameter, **TARGET** element.
- 3. Via the **Channel/CHANNEL** parameter, select the process variable which should be used as the input value for the Analog Input Block .
- 4. Via the **Transducer scale/XD_SCALE** parameter, select the desired unit and the block input range for the process variable → 🖺 79. Make sure that the selected unit suits the process variable that is selected. If the process variable and the unit do not suit one another, the **Block error/BLOCK_ERR** parameter reports the **Block Configuration Error** and the block mode cannot be set to **Auto**.
- 5. Via the Linearization type/L_TYPE parameter, select the type of linearization for the input variable (factory setting: Direct). Make sure that the settings for the Transducer scale/XD_SCALE and Output scale/OUT_SCALE parameters are the same for the Direct linearization type. If the values and units do not match, the Block error/ BLOCK_ERR parameter reports the Block Configuration Error and the block mode cannot be set to Auto.
- 6. Enter the alarms and critical alarm messages via the **High alarm limit/HI_LIM**, **High early warning limit/HI_LIM**, **Low alarm limit/LO_LIM** and **Low early warning limit/LO_LIM** parameters. The limit values entered must be within the value range specified for the **Output scale/OUT SCALE** parameter → 79.
- 7. Specify the alarm priorities via the **Priority for high limit value alarm/HI_HI_PRI**, **Priority for high early warning/HI_PRI**, **Priority for low limit value alarm/ LO_LO_PRI** and **Priority for low limit value early warning/LO_PRI** parameters. Reporting to the field host system only takes place with alarms with a priority greater than 2.
- 8. Set the block mode to **Auto** via the **Block mode/MODE_BLK** parameter, **TARGET** element. For this purpose, the Resource Block must also be set to the **Auto** block mode.

12.2.5 Additional configuration

- 1. Link the function blocks and output blocks.
- After specifying the active LAS, download all the data and parameters to the field device.

12.3 Scaling the measured value in the AI Block

The measured value can be scaled if the $L_TYPE = Indirect$ linearization type has been selected in the AI Block. XD_SCALE defines the input range with the EU_0 and EU_100 elements. This is mapped linearly to the output range, defined by OUT_SCALE also with the elements EU_0 and EU_100 .



■ 24 Scaling the measured value in the AI Block

- If you have selected the Direct mode in the L_TYPE parameter, you cannot change the values and units for XD_SCALE and OUT_SCALE.
 - The **L_TYPE**, **XD_SCALE** and **OUT_SCALE** parameters can only be changed in the OOS block mode.


12.4 Selecting the language

Step	Block	Parameter	Action
1	DISPLAY (TRDDISP)	Language (language)	Select the language ¹⁾ .
			Options: 32805: Arabic 32824: Chinese 32842: Czech 32881: Dutch 32888: English 32917: French 32920: German 32945: Italian 32946: Japanese 32948: Korean 33026: Polish 33027: Portuguese 33062: Russian 33083: Spanish 33103: Thai 33120: Vietnamese 33155: Indonesian 33166: Turkish

¹⁾ The languages the device supports are specified when the device is ordered. See feature 500 "Additional operating language" in the product structure for this purpose

12.5 Configuring interface measurement

The **Setup** method can also be used to configure the measurement. This method can be called via the SETUP Transducer Block (TRDSUP).



25 Configuration parameters for interface measurement

R = Reference point of measurement

 $E = Empty \ calibration \ (= zero \ point)$

 $F = Full\ calibration\ (= span)$

 $LN = Probe\ length$

 $\mathit{UP} = \mathit{Thickness}\ \mathit{of}\ \mathit{upper}\ \mathit{medium}$

 D_I = Distance to interface (distance from flange to DC_2)

 L_I = Interface level

 D_L = Total level distance

 $L_L = Total\ level$

Step	Block	Parameter	Action
1	SETUP (TRDSUP)	Operating mode (operating_mode)	Select 32940: Interface+capacitance .
2	SETUP (TRDSUP)	Distance unit (distance_unit)	Select the distance unit. Options: 1010: m 1013: mm 1018: in 1019: ft
3	SETUP (TRDSUP)	Tank type (tank_type)	Select tank type. Options: 32816: Bypass/stilling well 33288: Metal 33302: Coax 33432: Double cable 33433: Double rod 33437: Rope, metal centering disk 33438: Rod, metal centering disk 33441: Non-metal 33444: Installation outside
4	SETUP (TRDSUP)	Tube diameter (tube_diameter) 1)	Specify the diameter of the bypass or stilling well.
5	SETUP (TRDSUP)	DC value (dc_value)	Specify the dielectric constant of the upper medium.
6	SETUP (TRDSUP)	Empty calibration (empty_calibration)	Specify the empty distance E (distance from reference point R to 0% mark).
7	SETUP (TRDSUP)	Full calibration (full_calibration)	Specify the full distance F (distance from the 0% mark to the 100% mark).
8	SETUP (TRDSUP)	Level (level)	Displays the measured level L.
9	SETUP (TRDSUP)	Interface (interface)	Displays the interface height L _I .

Step	Block	Parameter	Action
10	SETUP (TRDSUP)	Distance (filtered_dist_val)	Displays the distance D between the reference point R and the level L.
11	SETUP (TRDSUP)	Interface distance (interface_distance)	Displays the distance D_I between the reference point R and the interface L_I .
12	SETUP (TRDSUP)	Signal quality (signal_quality)	Displays the signal quality of the analyzed level echo.
13	SETUP (TRDSUP)	Confirm distance (confirm_distance)	Make sure the vessel is completely empty. Then select the 33100: Empty tank option.

1) Only available for coated probes and "Tank type" = "Bypass/stilling well"

NOTICE

Wrong measurement due to incorrect dielectric constant of the lower medium

► The dielectric constant (DC value) of the lower medium must be specified if the lower medium is not water in the operating mode 32940: Interface+capacitance. Block: ADV_SETUP (TRDASUP); parameter: DC value lower medium (dc_value_lower_medium).

NOTICE

Wrong measurement due to incorrect empty capacitance

- ▶ In the case of rod and rope probes in the bypass, a correct measurement is only possible in the operating mode **32940**: Interface+capacitance once the empty capacitance has been determined. For this purpose, select the "Empty tank" option in the "Confirm distance" parameter after installing the probe when the tank is completely empty (Step 13 in the table above). A calculated empty capacitance can be entered for rod probes in exceptional cases only (if the tank cannot be emptied during commissioning). Block: EXPERT_CONFIG (TRDEXP); parameter: Empty capacity (empty_capacity).
- The empty capacitance is always calibrated ex works in the case of coax probes.

12.6 Configuring the local display

12.6.1 Factory setting of local display for interface measurements

Parameter	Factory setting for devices with 1 current output	Factory setting for devices with 2 current outputs
Format display	1 value, large format	1 value, large format
Value 1 display	Interface	Interface
Value 2 display	Level linearized	Level linearized
Value 3 display	Upper interface thickness	Current output 1
Value 4 display	Current output 1	Current output 2

lacktriangle The local display can be customized in the Transducer Block **DISPLAY (TRDDISP)**.

12.7 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration. You can do so using the **Configuration management** parameter and its options.

Path in the menu

Setup → Extended setup → Data backup → Configuration management

Block operation

Block: **DISPLAY (TRDDISP)**

Parameter: Configuration management (configuration_management)

Functions of the parameter options

Options	Description
33097: Backup	A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.
33057: Restore	The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy includes the transmitter data of the device.
33838: Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
265: Compare	The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
32848: Delete data backup	The backup copy of the device configuration is deleted from the display module of the device.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.


- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- In devices with FOUNDATION Fieldbus communication, the "PD-Tag" parameter is also accepted when duplicating the parameters. If necessary, set this parameter to the desired value after duplication.

12.8 Configuring event behavior according to FOUNDATION Fieldbus specification FF912

The device complies with FOUNDATION Fieldbus specification FF912. Among other things this means that:

- The diagnostic category as per NAMUR Recommendation NE107 is transmitted over the fieldbus in a format that is independent of the manufacturer:
 - F: Failure
 - C: Function check
 - S: Out of specification
 - M: Maintenance required
- The diagnostic category of the predefined event groups can be adapted by the user according to the requirements of the individual application.
- Certain events can be separated from their group and be treated individually:
 - 941: Lost echo
 - 942: In safety distance
- Additional information and troubleshooting measures are transmitted over the fieldbus with the event message.
- Diagnostic messages according to FF912 are only available in the host if the **Multi-bit Alarm Support** option is activated in the **FEATURE_SEL** parameter of the Resource

 Block. For reasons of compatibility, this option is **not** enabled when the device is delivered:



12.8.1 Event groups

The diagnostic events are divided into 16 groups according to the **source** and the **weighting**. A **default event category** is assigned to each group at the factory. Here, one bit of the assignment parameters belongs to every event group.

Event weighting	Default event category	Event source	Bit	Events in this group
Highest weighting	Failure (F)	Sensor	31	 F003: Broken probe detected F046: Buildup detected F083: Memory content F104: HF cable F105: HF cable F106: Sensor
		Electronics	30	 F242: Software incompatible F252: Modules incompatible F261: Electronic modules F262: Module connection F270: Main electronic failure F271: Main electronic failure F272: Main electronic failure F273: Main electronic failure F275: I/O module failure F276: I/O module failure F282: Data storage F283: Memory content F311: Memory content
		Configuration	29	 F410: Data transfer F411: Upload/download F435: Linearization F437: Configuration incompatible
		Process	28	 F803: Loop current 1 F825: Operating temperature F936: EMC interference F941: Echo lost ¹⁾ F970: Linearization

1) This event can be removed from the group and treated separately; see the "Configurable area" section.

Event weighting	Default event category	Event source	Bit	Events in this group
High weighting	Function check (C)	Sensor	27	Not used in Levelflex
		Electronics	26	Not used in Levelflex
		Configuration	25	 C411: Upload/download C431: Trim C484: Failure mode simulation C485: Simulation measured value C491: Simulation current output C585: Simulation distance
		Process	24	Not used in Levelflex

Event weighting	Default event category	Event source	Bit	Events in this group
Low weighting	Out of specification (S)	Sensor	23	Not used in Levelflex
		Electronics	22	Not used in Levelflex

Event weighting	Default event category	Event source	Bit	Events in this group
		Configuration	21	S441: Current output 1
		Process	20	 S801: Energy too low S825: Operating temperature S921: Change of reference S942: In safety distance ¹⁾ S943: In blocking distance S944: Level range S968: Level limited

1) This event can be removed from the group and treated separately; see the "Configurable area" section.

Event weighting	Default event category	Event source	Bit	Events in this group
Lowest weighting	Maintenance required (M)	Sensor	19	Not used in Levelflex
		Electronics	18	 M270: Main electronics error M272: Main electronics error M311: Memory content
		Configuration	17	M438: Dataset
		Process	16	M801: Loop current 1

12.8.2 Assignment parameters

Event categories are assigned to the event groups via four assignment parameters. These are located in the **RESOURCE (RB2)** Block:

- FD FAIL MAP: For the Failure (F) event category
- FD_CHECK_MAP: For the Function check (C) event category
- FD OFFSPEC MAP: For the Out of specification (S) event category
- FD_MAINT_MAP: For the Maintenance required (M) event category

Each of these parameters consists of 32 bits with the following meaning:

- Bit 0: Reserved by the Fieldbus Foundation
- **Bits 1 to 15:** Configurable area; certain diagnostic events can be assigned here independently of the event group they belong to. They are then removed from the event group and their behavior can be configured individually.

In the Levelflex the following parameters can be assigned to the configurable area:

- 941: Lost echo
- 942: In safety distance
- **Bits 16-31:** Standard range; these bits are permanently assigned to the event groups. If the bit is set to **1**, this event group is assigned to the individual event category.

The following table indicates the default setting of the assignment parameters. In the default setting, there is a clear assignment between the event weighting and the event category (i.e. the assignment parameter).

Default setting of assignment parameters

		Standard range								Configurable area							
Event weighting	Highest weighting		High weighting			Low weighting			Lowest weighting			J					
Event source 1)	S	Е	С	P	S	Е	С	P	S	Е	С	P	S	Е	С	P	
Bit	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15 1
FD_FAIL_MAP	1	1	1	1	0	0	0	0	0	0	0	0	0	0	0	0	0
FD_CHECK_MAP	0	0	0	0	1	1	1	1	0	0	0	0	0	0	0	0	0
FD_OFFSPEC_MAP	0	0	0	0	0	0	0	0	1	1	1	1	0	0	0	0	0
FD_MAINT_MAP	0	0	0	0	0	0	0	0	0	0	0	0	1	1	1	1	0

1) S: Sensor; E: Electronics; C: Configuration; P: Process


Proceed as follows to change the diagnostic behavior of an event group:

- 1. Open the assignment parameter in which the group is currently assigned.
- 2. Change the event group bit from **1** to **0**. When operating via FieldCare, this is done by unchecking the corresponding check box (see the next example).
- 3. Open the assignment parameter to which the group should be assigned.
- 4. Change the event group bit from **0** to **1**. When operating via FieldCare, this is done by checking the corresponding check box (see the next example).


Example

The **Highest weighting / configuration error** group contains the events **410**: **Data transfer**, **411**: **Upload/download**, **435**: **Linearization** and **437**: **Configuration**

incompatible. These should be categorized as **Function check (C)** and no longer as **Failure (F)**.



In the FieldCare navigation window, navigate to **Expert** \rightarrow **Communication** \rightarrow **Field** diagnostics \rightarrow Alarm detection enable.



 \blacksquare 26 The "Fail Map" and "Check Map" columns in the as-delivered state

In the **Fail Map** column, look for the **Configuration Highest Severity** group and uncheck the corresponding check box (A). Check the relevant check box in the **Check Map** (B) column. Note that you must press the Enter key to confirm every entry.



■ 27 The "Fail Map" and "Check Map" columns after the change

- Please ensure that the corresponding bit is set in at least one of the assignment parameters for each event group. Otherwise no category will be transmitted with the event over the bus, and the control system will therefore generally ignore the presence of the event.
- The detection of diagnostic events is parameterized on the **Alarm detection enable** FieldCare page but the transmission of messages over the bus is not. The latter is performed on the **Alarm broadcast enable** page. The operation of this page is identical to the operation of the **Alarm detection enable** page. The Resource Block must be in the **Auto** mode for the status information to be transmitted over the bus.

12.8.3 Configurable area


The event category can be individually defined for the following events - irrespective of the event group they are assigned to in the default setting:

- **F941**: Lost echo
- **S942:** In safety distance

To change the event category, the event first has to be assigned to one of the bits 1 to 15. The FF912 ConfigArea_1 to FF912ConfigArea_15 parameters in the DIAGNOSTIC (TRDDIAG) Block are used for this purpose. Then the corresponding bit can be set from 0 to 1 in the desired assignment parameter.

Example

Error **942** "In safety distance" should no longer be categorized as **Out of specification (S)** and should be categorized as **Function check (C)** instead.



In the FieldCare navigation window, navigate to **Expert** \rightarrow **Communication** \rightarrow **Field** diagnostics \rightarrow Alarm detection enable.




In the default setting, all bits in the **Configurable Area Bits** column have the value **not used**.



Select one of these bits (here for example: **Configurable Area Bit 1**) and select the **In safety distance** option from the corresponding selection list. Press Enter to confirm the option selected.

90




Go to the **Offspec Map** column and check the check box for the corresponding bit (here: **Configurable Area Bit 1**). Press ENTER to confirm your entries.

A change to the **In safety distance** error category does not affect an error that already exists. The new category is only assigned if this error occurs again after the change has been made.

12.8.4 Transmission of event messages over the bus

Event priority

Event messages are only transmitted over the bus if their priority is between 2 and 15. Priority 1-events are displayed but are not transmitted over the bus. Priority 0-events are ignored. In the factory setting, the priority of all events is 0. The priority can be individually changed for the four assignment parameters. The following four parameters of the Resource Block are used for this purpose:



Suppression of certain events

It is possible to suppress certain events during transmission over the bus using a mask. While these events are displayed they are not transmitted over the bus. This mask is in FieldCare under $\mathbf{Expert} \to \mathbf{Communication} \to \mathbf{Field}$ diagnostics $\to \mathbf{Alarm}$ broadcast enable. The mask is a negative selection mask, i.e. if a field is selected the associated events are **not** transmitted over the bus.

12.9 Protecting settings from unauthorized access

The settings can be protected from unauthorized access in the following ways:

- Locking via write protection switch (hardware locking)
- Locking via the operating menu (software locking)
- Locking via block operation:
 - Block: **DISPLAY (TRDDISP)**; parameter: **Define access code**
 - Block: EXPERT_CONFIG (TRDEXP); parameter: Enter access code

13 Diagnostics and troubleshooting

13.1 General troubleshooting

13.1.1 General errors

Error	Possible cause	Solution	
Device does not respond.	Supply voltage not connected.	Connect the correct voltage.	
	The cables do not contact the terminals properly.	Ensure electrical contact between the cable and the terminal.	
Values on the display invisible	Contrast setting is too weak or too strong.	 Increase contrast by pressing ⊕ and E simultaneously. Decrease contrast by pressing ⊡ and E simultaneously. 	
	The plug of the display cable is not connected correctly.	Connect the plug correctly.	
	Display is defective.	Replace display.	
"Communication error" is indicated	Electromagnetic interference	Check grounding of the device.	
on the display when starting the device or connecting the display.	Broken display cable or display plug.	Replace display.	
Duplication of parameters via display from one device to another not working. Only the "Save" and "Cancel" options are available.	Display with backup is not properly detected if a data backup was not carried out on the new device previously.	Connect display (with backup) and restart device.	
CDI communication does not work.	Wrong setting of the COM port on the computer.	Check the setting of the COM port on the computer and change it if necessary.	
Device measures incorrectly.	Parameter configuration error	Check and correct the parameter configuration.	

13.1.2 Parametrization errors

Parametrization errors for level measurements

Problem	Possible cause	Remedy		
Measured value is incorrect	If measured distance (Setup → Distance) matches the real distance: Calibration error	 Check the Empty calibration parameter (→		
	If measured distance (Setup → Distance) does not match the real distance: An interference echo is present.	Carry out mapping (Confirm distance parameter ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$		
No change of measured value on filling/emptying	An interference echo is present.	Carry out mapping (Confirm distance parameter ($\rightarrow \triangleq 133$)).		
	Buildup at the probe.	Clean the probe.		
	Error in the echo tracking.	Deactivate echo tracking (Expert → Sensor → Echo tracking → Evaluation mode = History off).		
Echo lost diagnostic message appears after the supply voltage is switched on.	Echo threshold too high.	Check the Medium group parameter (→ 🖺 127). If necessary, select a more detailed setting with the Medium property parameter.		
	Level echo suppressed.	Delete the map and record it again if necessary (Record map parameter (→ 🖺 135)).		
Device displays a level when the tank is empty.	Incorrect probe length	Perform probe length correction (Confirm probe length parameter (→ 🖺 163)).		
	Interference echo	Carry out mapping over the entire probe length when the tank is empty (Confirm distance parameter (→ 🖺 133)).		
Wrong slope of the level over the entire measuring range	Wrong tank type selected.	Select the correct Tank type parameter $(\rightarrow \ \ \)$ 126).		


Parametrization errors for interface measurements

Problem	Possible cause	Remedy
Incorrect slope of the interface measured value	The dielectric constant (DC value) of the upper medium is incorrectly set.	Enter the correct dielectric constant (DC value) of the upper medium (DC value parameter ($\rightarrow \blacksquare 131$)).
The measured value for the interface and the total level are identical.	The echo threshold for the total level is too high due to an incorrect dielectric constant.	Enter the correct dielectric constant (DC value) of the upper medium (DC value parameter (→ 🖺 131)).
The total level jumps to the interface level in the case of thin interfaces.	The thickness of the upper medium is lower than 60 mm.	Measurement of the interface is only possible for interface heights greater than 60 mm.

13.2 Diagnostic information on local display

13.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the measured value display.



Status signals


A0032902	"Failure (F)" option A device error has occurred. The measured value is no longer valid.
C	"Function check (C)" option The device is in the service mode (e.g. during a simulation).
S	 "Out of specification (S)" option The device is operated: Outside of its technical specifications (e.g. during startup or a cleaning) Outside of the configuration performed by the user (e.g. level outside the configured range)
M	"Maintenance required (M)" option Maintenance is required. The measured value is still valid.

Status symbol (symbol for event level)

8	"Alarm" status The measurement is interrupted. The signal outputs adopt the defined alarm condition. A diagnostic message is generated.
Δ	"Warning" status The device continues to measure. A diagnostic message is generated.

Diagnostic event and event text

The fault can be identified by means of the diagnostic event. The event text helps you by providing information about the fault. In addition, the associated status symbol is displayed in front of the diagnostic event.



If two or more diagnostic events occur simultaneously, only the diagnostic message with the highest priority is shown. Additional queued diagnostic messages can be shown in the **Diagnostic list** submenu.



Past diagnostic messages that are no longer pending are shown as follows:


- On the local display:
- In the **Event logbook** submenu
- In FieldCare:

Via the "Event List /HistoROM" function.

Operating elements

Operating functions in menu, submenu				
+	Plus key Opens the message about the remedial measures.			
E	Enter key Opens the operating menu.			

13.2.2 Calling up remedial measures



A0029431-EN

- 28 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time when error occurred
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (① symbol).
 - ► The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \Box .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** or in **Previous diagnostics**.

- 1. Press E.
 - └─ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

96


13.3 Diagnostic event in the operating tool

If a diagnostic event is present in the device, the status signal appears in the top left status in the operating tool along with the corresponding symbol for event level in accordance with NAMUR NE 107:

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)


A: Via the operating menu

- 1. Navigate to the **Diagnostics** menu.
 - In the **Actual diagnostics** parameter, the diagnostic event is shown with event text.
- 2. On the right in the display range, hover the cursor over the **Actual diagnostics** parameter.




A tool tip with remedial measures for the diagnostic event appears.

B: Via the "Create documentation" function




Select the "Create documentation" function.



Make sure "Data overview" is marked.

- 3. Click "Save as ..." and save a PDF of the protocol.
 - └ The protocol contains the diagnostic messages and remedy information.

C: Via the "Eventlist / Extended HistoROM" function



Select the "Eventlist / Extended HistoROM" function.



Select the "Load Eventlist" function.

The list of events, including remedy information, is shown in the "Data overview" window.

13.4 Diagnostic messages in the DIAGNOSTIC Transducer Block (TRDDIAG)

- The Actual diagnostics parameter displays the message with the highest priority. Every
 message is also output as per the FOUNDATION Fieldbus Specification by means of the
 XD_ERROR and BLOCK_ERROR parameters.
- A list of diagnostic messages is displayed in the Diagnostics 1 to Diagnostics 5
 parameters. If more than 5 messages are currently active, only those with the highest
 priority are displayed.
- You can view a list of alarms which are no longer active (event log) via the Previous diagnostics parameter.

13.5 Diagnostic list

In the **Diagnostic list** submenu submenu, up to 5 currently pending diagnostic messages can be displayed. If more than 5 messages are pending, the messages with the highest priority are shown on the display.

Navigation path

 $Diagnostics \rightarrow Diagnostic\ list$

Calling up and closing the remedial measures

- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press □ + ± simultaneously.
 - ► The message about the remedial measures closes.

13.6 Event logbook

13.6.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Event list** submenu ²⁾.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Event list

A maximum of 100 event messages can be displayed in chronological order.

Die Ereignishistorie umfasst Einträge zu:

- Diagnostic events
- Information events

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ①: Event has occurred
 - 🕒: Event has ended
- Information event
 - €: Event has occurred

Calling up and closing the remedial measures

- 1. Press E
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message about the remedial measures closes.

13.6.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Event list** submenu.

Navigation path

Diagnostics \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information

13.6.3 Overview of information events

Info number	Info name
I1000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed


²⁾ This submenu is only available for operation via local display. In the case of operation via FieldCare, the event list can be displayed with the "Event List / HistoROM" functionality of FieldCare.

Info number	Info name
I1092	Trend data deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished

13.7 Firmware history

Date	Firmware	Modifications	Documentation (FMP55, FOUNDATION Fieldbus)						
	version		Operating Instructions	Description of Device Parameters	Technical Information				
04.2012	01.00.zz	Original software	BA01054F/00/EN/01.12	GP01015F/00/EN/01.12	TI01003F/00/EN/14.12				
05.2015	01.01.zz	 Support of SD03 Additional languages HistoROM functionality enhanced "Advanced Diagnostics" function block integrated Improvements and bugfixes 	BA01054F/00/EN/03.15 BA01054F/00/EN/04.16 ¹⁾	GP01015F/00/EN/02.15	TI01003F/00/EN/17.15 TI01003F/00/EN/20.16 1)				

1) Contains information on the Heartbeat wizards available in the current DTM version for DeviceCare and FieldCare.



14 Maintenance

No special maintenance work is required.

14.1 Exterior cleaning

When cleaning the exterior, always use cleaning agents that do not corrode the surface of the housing and the seals.

14.2 General cleaning instructions

Dirt or buildup may form on the probe depending on the application. A thin, even layer has little impact on the measurement. Thick layers can dampen the signal and reduce the measuring range. Very uneven deposit formation or caking (e.g. due to crystallization) can result in incorrect measurements. In such cases, use a non-contact measuring principle, or regularly inspect the probe for contamination.

Cleaning with sodium hydroxide solution (e.g. in CIP procedures): if the coupling is wetted, larger measurement errors can occur than under reference operating conditions. Wetting can cause temporary incorrect measurements.

14.3 Cleaning coax probes

The ground tube can be removed towards the bottom for cleaning purposes. When disassembling and reassembling, make sure that the spacers between the probe rod and ground tube are not displaced. A spacer is located approx. 10 cm (4 in) from the end of the probe. Depending of the length of the probe there may be additional spacers evenly distributed along the probe.

102

15 Repair

15.1 General information

15.1.1 Repair concept

Under the Endress+Hauser repair concept, devices have a modular design and repairs can be carried out by Endress+Hauser Service or by properly trained customers.

Spare parts are grouped into logical kits with the associated replacement instructions.

For more information on service and spare parts, please contact Endress+Hauser Service.

15.1.2 Repair of Ex-certified devices

A WARNING

Incorrect repair can compromise electrical safety!

Explosion Hazard!

- ► Repairs to Ex-certified devices must be carried out by Endress+Hauser Service or by specialist personnel according to national regulations.
- Relevant standards and national regulations on hazardous areas, safety instructions and certificates must be observed.
- ▶ Use only original Endress+Hauser spare parts.
- ► Please note the device designation on the nameplate. Only identical parts may be used as replacements.
- ► Carry out repairs according to the instructions.
- ▶ Only the Endress+Hauser service team is permitted to modify a certified device and convert it to another certified version.

15.1.3 Replacing electronics modules

When electronics modules have been replaced the device does not need to be recalibrated as the parameters are saved in the HistoROM inside the housing. It may be necessary when replacing the main electronics to record a new interference echo suppression.

15.1.4 Replacing a device

Once a complete device has been replaced, the parameters can be transferred back into the device using one of the following methods:


- Using the display module
 Prerequisite: The configuration of the old device was saved previously to the display module.
- Via FieldCare
 Prerequisite: The configuration of the old device was saved previously to the computer using FieldCare.

You can continue measuring without performing a new calibration. Only interference echo suppression may need to be carried out once again.

15.2 Spare parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- In the connection compartment cover of the device there is a spare part nameplate which contains the following information:
 - A list of the most important spare parts for the measuring device, including their ordering information.
 - The URL to the W@M Device Viewer (www.endress.com/deviceviewer):

 All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



A001497

■ 29 Example for spare part nameplate in the connection compartment cover

- Measuring device serial number:
 - Located on the device and spare part nameplate.
 - Can be read out via the "Serial number" parameter in the "Device information" submenu.

15.3 Return

The requirements for safe device return can vary depending on the device type and national legislation.

- 1. Refer to the web page for information: http://www.endress.com/support/return-material
 - ► Select the region.
- 2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

15.4 Disposal




If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

16 Accessories


16.1 Device-specific accessories

16.1.1 Weather protection cover

The weather protection cover can be ordered together with the device via the "Accessory enclosed" product structure.



🖪 30 Height. Unit of measurement mm (in)



 \blacksquare 31 Dimensions. Unit of measurement mm (in)


Material

316L


Order number for accessories:


71162242

16.1.2 Mounting bracket for electronics housing




16.1.3 Centering star





16.1.4 Remote display FHX50



Technical data

- Material:
 - Plastic PBT
 - 316L/1.4404
 - Aluminum
- Degree of protection: IP68 / NEMA 6P and IP66 / NEMA 4x
- Suitable for display modules:
 - SD02 (push buttons)
 - SD03 (touch control)

- Connecting cable:
 - Cable supplied with device up to 30 m (98 ft)
 - Standard cable supplied by customer up to 60 m (196 ft)
- Ambient temperature:-40 to 80 °C (-40 to 176 °F)
- Ambient temperature (option): -50 to 80 °C (-58 to 176 °F) $^{3)}$

Ordering information

• If the remote display is to be used, the device version "Prepared for display FHX50" must be ordered.

For the FHX50, the option "Prepared for display FHX50" must be selected under "Measuring device version".

- If a measuring device has not been ordered with the version "Prepared for display FHX50" and is to be retrofitted with an FHX50, the version "Not prepared for display FHX50" must be ordered for the FHX50 under "Measuring device version". In this case, a retrofit kit for the device is supplied with the FHX50. The kit can be used to prepare the device so that the FHX50 can be used.
- Use of the FHX50 may be restricted for transmitters with an approval. A device may only be retrofitted with the FHX50 if the option "Prepared for FHX50" is listed in the associated Safety Instructions (XA) under *Basic specifications*, "Display, operation".

Also pay attention to the Safety Instructions (XA) of the FHX50.

Retrofitting is not possible on transmitters with:


- An approval for use in areas with flammable dust (dust ignition-proof approval)
- Type of protection Ex nA
- For details, see the "Special Documentation" SD01007F

16.1.5 Overvoltage protection

The surge arrester for loop-powered devices can be ordered together with the device via the "Accessory mounted" section of the product order structure.

The surge arrester can be used for loop-powered devices.

- 1-channel devices OVP10
- 2-channel devices OVP20



A002172

Technical data

Resistance per channel: 2 × 0.5 Ω_{max}
 Threshold DC voltage: 400 to 700 V
 Threshold surge voltage: < 800 V

³⁾ This range applies if the option JN "Transmitter ambient temperature" -50 °C (-58 °F) was selected in feature 580 "Test, Certificate". If the temperature is permanently below -40 °C (-40 °F), higher failure rates can be expected.

- Capacitance at 1 MHz: < 1.5 pF
- Nominal leakage current (8/20 µs): 10 kA
- Suitable for conductor cross-sections: 0.2 to 2.5 mm² (24 to 14 AWG)

If retrofitting:


- Order number for 1-channel devices (OVP10): 71128617
- Order number for 2-channel devices (OVP20): 71128619
- The use of the OVP module may be restricted depending on the transmitter approval. A device may only be retrofitted with the OVP module if the option *NA* (overvoltage protection) is listed under *Optional specifications* in the Safety Instructions (XA) associated with the device.
- In order to keep the necessary safety distances when using the surge arrester module, the housing cover also needs to be replaced when the device is retrofitted.Depending on the housing type, the suitable cover can be ordered using the following order number:
 - Housing GT18: 71185516
 Housing GT19: 71185518
- Housing GT20: 71185517



For details, see the "Special Documentation" SD01090F

16.1.6 Bluetooth module BT10 for HART devices

The Bluetooth module BT10 can be ordered together with the device via the "Accessory mounted" section of the product order structure.



A003649

Technical data

- Quick and easy setup with the SmartBlue app
- No additional tools or adapters needed
- Signal curve via SmartBlue (app)
- Encrypted single point-to-point data transmission (tested by Fraunhofer Institute) and password-protected communication via Bluetooth® wireless technology
- Range under reference conditions:> 10 m (33 ft)
- When the Bluetooth module is used, the minimum supply voltage of the device increases by up to 3 V.

If retrofitting:

Order number: 71377355

■ The use of the Bluetooth module may be restricted depending on the transmitter approval. A device may only be retrofitted with the Bluetooth module if the option NF (Bluetooth module) is listed under Optional specifications in the Safety Instructions (XA) associated with the device.



For details, see the "Special Documentation" SD02252F

16.2 Communication-specific accessories

Commubox FXA291

Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop Order number: 51516983



For details, see "Technical Information" TI00405C

Field Xpert SFX350

Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area.



For details, see Operating Instructions BA01202S

Field Xpert SFX370

Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the **non-Ex area** and the **Ex area**.



For details, see Operating Instructions BA01202S

16.3 Service-specific accessories

DeviceCare SFE100

Configuration tool for HART, PROFIBUS and FOUNDATION Fieldbus field devices



Technical Information TI01134S

FieldCare SFE500

FDT-based plant asset management tool

It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.



Technical Information TI00028S

16.4 System components

Memograph M graphic data manager


The Memograph M graphic data manager provides information on all the relevant process variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.



Technical Information TI00133R and Operating Instructions BA00247R

17 Operating menu

17.1 Overview of the operating menu (display module)



► Analog inputs				
	► Analog input 1	L to 5		
		Block tag		
		Channel		
		Process Value Filte	r Time	
► Advanced setu	p			
	Locking status		7	
	Access status disp	lav		
]	
	Enter access code			
	► Interface			
		Process property		
		Interface property		
		DC value lower med	dium	
		Level unit		
		Blocking distance		
		Level correction		
		► Automatic DC co	alculation	
			Manual thickness upper layer	
			DC value	
			Use calculated DC value	
	► Linearization]	
	7 2	Linearization type		
		Unit after lineariza	tion	
		Free text		
		Maximum value		

	Diameter	→ 🗎 154
	Intermediate height	→ 🖺 155
	Table mode	→ 🖺 155
	► Edit table	
	Level]
	Customer value	
	Activate table	→ 🗎 157
► Sa	afety settings	→ 🖺 159
	Output echo lost	→ 🖺 159
	Value echo lost	→ 🖺 159
	Ramp at echo lost	→ 🖺 160
	Blocking distance	→ 🖺 160
▶ Pı	robe settings	→ 🖺 162
	Probe grounded	→ 🖺 162
	► Probe length correction	→ 🖺 164
	Confirm probe length	→ 🖺 164
	Present probe length	→ 🖺 164
► St	witch output	→ 🖺 165
	Switch output function	→ 🖺 165
	Assign status	→ 🖺 165
	Assign limit	→ 🖺 166
	Assign diagnostic behavior	→ 🖺 166
	Switch-on value	→ 🖺 167
	Switch-on delay	→ 🖺 168
	Switch-off value	→ 🖺 168

114

	Switch-off delay	→ 🖺 169
	Failure mode	→ 🗎 169
	Switch status	→ 🖺 169
	Invert output signal	→ 🖺 169
► Display		→ 🖺 171
	Language	→ 🖺 171
	Format display	→ 🖺 171
	Value 1 to 4 display	→ 🖺 173
	Decimal places 1 to 4	→ 🖺 173
	Display interval	→ 🖺 174
	Display damping	→ 🖺 174
	Header	→ 🖺 174
	Header text	→ 🖺 175
	Separator	→ 🖺 175
	Number format	→ 🖺 175
	Decimal places menu	→ 🖺 175
	Backlight	→ 🖺 176
	Contrast display	→ 🖺 176
► Configuration b	ackup display	→ 🖺 177
	Operating time	→ 🖺 177
	Last backup	→ 🖺 177

			Configuration mana	ngement	→ 🖺 177
			Comparison result		→ 🖺 178
		► Administration			→ 🖺 180
			▶ Define access co	de	→ 🗎 182
				Define access code	→ 🗎 182
				Confirm access code	→ 🗎 182
			Device reset		→ 🖺 180
억 Diagnostics					→ 🖺 183
	Actual diagnostics				→ 🖺 183
	Previous diagnostic	s			→ 🖺 183
	Operating time from	n restart			→ 🖺 184
	Operating time				→ 🖺 177
	▶ Diagnostic list				→ 🖺 185
		Diagnostics 1 to 5			→ 🖺 185
	► Event logbook				→ 🖺 186
		Filter options	_		
		► Event list			→ 🖺 186
	► Device informat	ion		-	→ 🖺 187
		Device tag	-		→ 🖺 187
		Serial number		_	→ 🖺 187
		Firmware version			→ 🖺 187
		Device name			→ 🖺 188
		Order code			→ 🖺 188
		Extended order code	e 1 to 3		→ 🖺 188
				1	


116

► Measured valu	es	→ 🖺 189
	Distance	→ 🖺 130
	Level linearized	→ 🖺 154
	Interface distance	→ 🖺 132
	Interface linearized	→ 🖺 154
	Thickness upper layer	→ 🖺 190
	Terminal voltage 1	→ 🖺 191
► Analog inputs		
	► Analog input 1 to 5	→ 🖺 191
	Block tag	→ 🖺 137
	Channel	→ 🖺 137
		→ 1 97
	Status	
	Value	→ 🖺 192
	Units index	→ 🖺 193
► Data logging		→ 🖺 194
	Assign channel 1 to 4	→ 🖺 194
	Logging interval	→ 🖺 195
	Clear logging data	→ 🖺 195
	▶ Display channel 1 to 4	→ 🖺 196
► Simulation		→ 🖺 199
	Assign measurement variable	→ 🖺 200
	Process variable value	→ 🖺 200
	Switch output simulation	→ 🖺 200

	Switch status	→ 🖺 201
	Simulation device alarm	→ 🖺 201
▶ Device check		→ 🖺 202
	Start device check	→ 🖺 202
	Result device check	→ 🖺 202
	Last check time	→ 🖺 202
	Level signal	→ 🖺 203
	Launch signal	→ 🖺 203
	Interface signal	→ 🖺 203

118

17.2 Overview of the operating menu (operating tool)



		Channel	→ 🖺 137
		Process Value Filter Time	→ 🖺 138
► Advanced setup			→ 🖺 139
	Locking status		→ 🖺 139
	Access status tooli	ng	→ 🖺 139
	Enter access code		→ 🖺 140
	► Interface		→ 🖺 141
		Process property	→ 🖺 141
		Interface property	→ 🖺 141
		DC value lower medium	→ 🖺 142
		Level unit	→ 🖺 143
		Blocking distance	→ 🖺 143
		Level correction	→ 🖺 144
		Manual thickness upper layer	→ 🖺 144
		Measured thickness upper layer	→ 🖺 145
		DC value	→ 🖺 145
		Calculated DC value	→ 🗎 145
		Use calculated DC value	→ 🗎 146
	► Linearization		→ 🖺 149
		Linearization type	→ 🖺 151
		Unit after linearization	→ 🖺 152
		Free text	→ 🖺 153
		Level linearized	→ 🖺 154
		Interface linearized	→ 🖺 154
		Maximum value	→ 🗎 154

	Diameter	→ @	154
	Intermediate height	→ €	155
	Table mode	→ @	155
	Table number	→ @	156
	Level	<i>,</i> } €	157
	Level	→ @	157
	Customer value	}	157
	Activate table		157
		I	
➤ Safety settings		→ (159
	Output echo lost	→ 🖺	159
	Value echo lost	→ [159
	Ramp at echo lost	→ @	160
	Blocking distance	→ 🖺	160
► Probe settings		→ [162
	Probe grounded	→ @	162
	Present probe length	→ €	162
	Confirm probe length	→ @	163
► Switch output		→ €	165
	Switch output function	→ @	165
	Assign status	→ @	165
	Assign limit	→ [166
	Assign diagnostic behavior		166
	Switch-on value		167
	Switch-on delay	} → €	168
	Switch-off value	→ 🖺	168

	Switch-off delay	→ 🖺 169
	Failure mode	→ 🖺 169
	Switch status	→ 🖺 169
	Invert output signal	→ 🖺 169
► Display		→ 🖺 171
	Language	→ 🗎 171
	Format display	→ 🖺 171
	Value 1 to 4 display	→ 🖺 173
	Decimal places 1 to 4	→ 🗎 173
	Display interval	→ 🖺 174
	Display damping	→ 🖺 174
	Header	→ 🖺 174
	Header text	→ 🗎 175
	Separator	→ 🖺 175
	Number format	→ 🖺 175
	Decimal places menu	→ 🖺 175
	Backlight	→ 🖺 176
	Contrast display	→ 🖺 176
		/ = 1/0
► Configuration b	ackup display	→ 🗎 177
	Operating time	→ 🖺 177
	Last backup	→ 🖺 177
	Configuration management	→ 🖺 177

Backup state	→ 🖺 178
Comparison result	→ 🖺 178
► Administration	→ 🖺 180
Define access code	
Device reset	→ 🖺 180
♥ Diagnostics	→ 🖺 183
Actual diagnostics	→ 🖺 183
Timestamp	→ 🖺 183
Previous diagnostics	→ 🖺 183
Timestamp	→ 🖺 184
Operating time from restart	→ 🖺 184
Operating time	→ 🗎 177
▶ Diagnostic list	→ 🖺 185
Diagnostics 1 to 5	→ 🖺 185
Timestamp 1 to 5	→ 🖺 185
► Device information	→ 🖺 187
Device tag	→ 🖺 187
Serial number	→ 🖺 187
Firmware version	→ 🖺 187
Device name	→ 🖺 188
Order code	→ 🖺 188
Extended order code 1 to 3	→ 🖺 188
► Measured values	→ 🖺 189
Distance	→ 🖺 130
Level linearized	→ 🖺 154

	Interface distance	→ 🖺 132
	Interface linearized	→ 🖺 154
	Thickness upper layer	→ 🖺 190
	Terminal voltage 1	→ 🖺 191
► Analog inputs		
	► Analog input 1 to 5	→ 🖺 191
	Block tag	→ 🖺 137
	Channel	→ 🖺 137
	Status	→ 🖺 192
	Value	→ 🖺 192
	Units index	→ 🖺 193
► Data logging		→ 🖺 194
	Assign channel 1 to 4	→ 🖺 194
	Logging interval	→ 🖺 195
	Clear logging data	→ 🖺 195
► Simulation		→ 🖺 199
	Assign measurement variable	→ 🖺 200
	Process variable value	→ 🖺 200
	Switch output simulation	→ 🖺 200
	Switch status	→ 🖺 201
	Simulation device alarm	→ 🖺 201
► Device check		→ 🖺 202
	Start device check	→ 🖺 202
	Result device check	→ 🖺 202
	Last check time	→ 🖺 202

124

Level signal	→ 🗎 203
Launch signal	→ 🗎 203
Interface signal	→ 🗎 203
► Heartbeat	→ 🖺 204

17.3 "Setup" menu



- 📔 🗟 : Indicates how to navigate to the parameter using the display and operating module
 - ☐ : Indicates how to navigate to the parameter using operating tools (e.g. FieldCare)
 - 🗈 : Indicates parameters that can be locked via the access code.

Navigation ■ ■ Setup

Operating		
Operating mode		1
Navigation	Setup → Operating mode	
Prerequisite	The device has the "interface measurement" application package $^{4)}$. FMP55 always contains this package.	
Description	Select operating mode.	
Selection	 Level Interface with capacitance * Interface * 	
Factory setting	FMP55: Interface with capacitance	
Additional information	The Interface with capacitance option is only available for FMP55.	
Distance unit		
Navigation		

Navigation	Setup → Distance	ance unit
Description	Length unit for dist	ance calculation.
Selection	SI units ■ mm ■ m	<i>US units</i> ■ ft ■ in

Tank type	
J I	

Navigation Setup → Tank type

Prerequisite Medium type = Liquid

Description Select tank type.

126

Product structure: Feature 540 "Application Package", Option EB "Interface measurement" 4)

Visibility depends on order options or device settings

Selection • Metallic

Bypass / pipeNon metallicMounted outside

Coaxial

Factory setting Depending on the probe

Additional information

User entry

- Depending on the probe some of the options mentioned above may not be available or there may be additional options.
- For coax probes and probes with metallic center washer **Tank type** parameter corresponds to the type of probe and cannot be changed.

Tube diameter		
Navigation		
Prerequisite	 Tank type (→ 🗎 126) = Bypass / pipe The probe is coated. 	
Description	Specify diameter of bypass or stilling well.	

Medium group	

0 to 9.999 m

Prerequisite ■ For FMP51/FMP52/FMP54/FMP55: Operating mode (→ 🖺 126) = Level

■ Medium type = Liquid

Description Select medium group.

Selection • Others

■ Water based (DC >= 4)

Additional information This parameter roughly specifies the dielectric constant (DC) of the medium. For a more

detailed definition of the DC use the **Medium property** parameter.

The **Medium group** parameter presets the **Medium property** parameter as follows:

Medium group	Medium property
Others	Unknown
Water based (DC >= 4)	DC 4 7

- The **Medium property** parameter can be changed at a later point of time. However, when doing so, the **Medium group** parameter retains its value. Only the **Medium property** parameter is relevant for the signal evaluation.
- The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.


Navigation $\blacksquare \Box$ Setup \rightarrow Empty calibr.

Description Distance process connection to min. level.

User entry Depending on the probe

Factory setting Depending on the probe

Additional information



■ 33 Empty calibration (E) for interface measurements

In the case of interface measurements the **Empty calibration** parameter is valid for both, the total and the interface level.

Full calibration

Navigation $\blacksquare \Box$ Setup \rightarrow Full calibr.

Description Span: max. level - min level.

128


User entry

Depending on the probe

Factory setting

Depending on the probe

Additional information



■ 34 Full calibration (F) for interface measurements

In the case of interface measurements the **Full calibration** parameter is valid for both, the total and the interface level.

Level


Navigation

Setup → Level

Description

Displays measured level L_L (before linearization).

Additional information



■ 35 Level in case of interface measurements

Endress+Hauser 129

A001319


Distance

Navigation

Description

Displays the measured distance D_L between the reference point (lower edge of the flange or threaded connection) and the level.

Additional information



■ 36 Distance for interface measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Signal quality

Navigation

Description

Displays the signal quality of the evaluated echo.

Additional information

Meaning of the display options

Strong

The evaluated echo exceeds the threshold by at least 10 mV.

Medium

The evaluated echo exceeds the threshold by at least 5 mV.


Weak

The evaluated echo exceeds the threshold by less than 5 mV.

No signal

The device does not find a usable echo.

The signal quality indicated in this parameter always refers to the currently evaluated echo: either the level/interface echo 5 or the end-of-probe echo. To differentiate between these two, the quality of the end-of-probe echo is always displayed in brackets.



- F941, for Output echo lost (\rightarrow 🗎 159) = Alarm.
- S941, if another option has been selected in **Output echo lost** ($\rightarrow \square$ **159**).

⁵⁾ Of these two echos the one with the lower quality is indicated.

DC value


Navigation $\blacksquare \Box$ Setup \rightarrow DC value

Prerequisite The device has the "Interface measurement" application package ⁶⁾.

Description Specify the relative dielectric constant ε_r of the upper medium (DC₁).

User entry 1.0 to 100

Additional information



DC1 Relative dielectric constant of the upper medium.

For the dielectric constants (DC values) of many media commonly used in industry, please refer to:

- Dielectric constant (DC value) Compendium CP01076F
- The Endress+Hauser "DC Values app" (available for Android and iOS)

Interface


Navigation \blacksquare Setup \rightarrow Interface

Prerequisite Operating mode (→ 🖺 126) = Interface or Interface with capacitance

Description Displays the measured interface level L_I (before linearization).

⁶⁾ Product structure: feature 540 "Application packages", option EB "Interface measurement"

Additional information



A0013197

The unit is defined in the **Level unit** parameter ($\rightarrow \triangleq 143$).

Interface distance

Navigation


Prerequisite

Operating mode (→ 🗎 126) = Interface or Interface with capacitance

Description

Displays the measured distance D_{I} between the reference point (lower edge of flange or threaded connection) and the interface.

Additional information



A001320

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Confirm distance Navigation □ Setup → Confirm distance

Description Specify, whether the measured distance matches the real distance.

Depending on the selection the device automatically sets the range of mapping.

Selection • Manual map

■ Distance ok

Distance unknown

■ Distance too small

Distance too big

■ Tank empty

■ Delete map

Additional information

Meaning of the options

Manual map

To be selected if the range of mapping is to be defined manually in the **Mapping end point** parameter ($\Rightarrow \implies 134$). In this case it is not necessary to confirm the distance.

■ Distance ok

To be selected if the measured distance matches the actual distance. The device performs a mapping.

■ Distance unknown

To be selected if the actual distance is unknown. A mapping can not be performed in this case.

■ Distance too small

To be selected if the measured distance is smaller than the actual distance. The device searches for the next echo and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

^{*} Visibility depends on order options or device settings

■ Distance too big ⁷⁾

To be selected if the measured distance exceeds the actual distance. The device adjusts the signal evaluation and returns to the **Confirm distance** parameter. The distance is recalculated and displayed. The comparison must be repeated until the displayed distance matches the actual distance. After this, the recording of the map can be started by selecting **Distance ok**.

Tank empty

To be selected if the tank is completely empty. The device records a mapping covering the complete measuring range.

Factory map

To be selected if the present mapping curve (if one exists) is to be deleted. The device returns to the **Confirm distance** parameter and a new mapping can be recorded.

- When operating via the display module, the measured distance is displayed together with this parameter for reference purposes.
- For interface measurements the distance always refers to the toatal level (not the interface level).
- For FMP55 with rope probes and **Operating mode** (→ 🖺 **126**) = **Interface with capacitance** the mapping must be recorded with the tank being empty, and the **Tank empty** option must be selected. Otherwise the device can not register the correct empty capacitance.

For FMP55 with coax probes a mapping must be recorded at least in the upper part of the probe, as tightening the flange has an influence on the envelope curve. However, even with coax probes it is recommended to record the mapping with the tank being completely empty (and selecting the **Tank empty** option).

If the teaching procedure with the **Distance too small** option or the **Distance too big** option is quit before the distance has been confirmed, a map is **not** recorded and the teaching procedure is reset after 60 s.

Present mapping		
Navigation	Setup → Present mapping	
Description	Indicates up to which distance a mapping has already been recorded.	
Mapping end point		
Navigation		
Prerequisite	Confirm distance (→ 🗎 133) = Manual map or Distance too small	
Description	Specify new end of the mapping.	
User entry	0 to 200 000.0 m	

⁾ Only available for "Expert → Sensor → Echo tracking → **Evaluation mode** parameter" = "Short time history" or "Long time history"

Additional information

This parameter defines up to which distance the new mapping is to be recorded. The distance is measured from the reference point, i.e. from the lower edge of the mounting flange or the threaded connection.



For reference purposes the **Present mapping** parameter ($\rightarrow \boxminus 134$) is displayed together with this parameter. It indicates up to which distance a mapping has already been recorded.

Record map		
Navigation	Setup → Record map	
Prerequisite	Confirm distance (→ 🖺 133) = Manual map or Distance too small	
Description	Start recording of the map.	

Selection • No.

Record mapDelete map

Additional information

Meaning of the options

No

The map is not recorded.

Record map

The map is recorded. After the recording is completed, the new measured distance and the new mapping range appear on the display. When operating via the local display, these values must be confirmed by pressing \square .

Delete map

The mapping (if one exists) is deleted and the device displays the recalculated measured distance and the mapping range. When operating via the local display, these values must be confirmed by pressing \square .

17.3.1 "Mapping" wizard

- The **Mapping** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the mapping are located directly in the **Setup** menu (→ ≅ 126).
- In the **Mapping** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Confirm distance		A
Navigation	Setup → Mapping → Confirm distance	
Description	→ 🗎 133	
Monning and paint		
Mapping end point		
Navigation	Setup → Mapping → Map. end point	
Description	→ 🗎 134	
Record map		a
Navigation	Setup → Mapping → Record map	
Description	→ 🖺 135	
Distance		
Navigation	Setup → Mapping → Distance	

136

Description

→ 🖺 130

17.3.2 "Analog input 1 to 5" submenu

There is an **Analog inputs** submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.

Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the **Expert** menu.

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Analog inputs \rightarrow Analog input 1 to 5

Block tag	
Navigation	
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.
User entry	Character string comprising numbers, letters and special characters (32)
Channel	
Navigation	Setup → Analog inputs → Analog input 1 to 7 → Channel
Description	Use this function to select the input value that should be processed in the Analog Input function block.
Selection	 Uninitialized Level linearized Absolute echo amplitude Absolute EOP amplitude Absolute interface amplitude* Distance Electronic temperature EOP shift Interface linearized* Interface distance* Measured capacitance* Relative echo amplitude Relative interface amplitude* Noise of signal Terminal voltage Thickness upper layer* Calculated DC value* Analog output adv. diagnostics 2 Analog output adv. diagnostics 1

^{*} Visibility depends on order options or device settings

Process Value Filter Time

Navigation Setup \rightarrow Analog input 1 to 7 \rightarrow PV Filter Time

Description Use this function to enter the filter time specification for the filtering of the unconverted

input value (PV).

User entry Positive floating-point number

Additional information Factory setting

If the value 0 s is entered, filtering will not be performed.

17.3.3 "Advanced setup" submenu

Navigation \square Setup \rightarrow Advanced setup

Locking status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Locking status

Description Indicates the write protection with the highest priority that is currently active.

User interface • Hardware locked

Temporarily locked

Additional information

Meaning and priorities of the types of write protection

Hardware locked (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters.

SIL locked (priority 2)

The SIL mode is activated. Writing access to the relevant parameters is denied.

■ WHG locked (priority 3)

The WHG mode is activated. Writing access to the relevant parameters is denied.

Temporarily locked (priority 4)

Write access to the parameters is temporarily locked on account of internal processes in progress in the device (e.g. data upload/download, reset etc.). The parameters can be modified as soon as the processes are complete.

On the display module, the a-symbol appears in front of parameters that cannot be modified since they are write-protected.

Access status tooling

Navigation \square Setup \rightarrow Advanced setup \rightarrow Access stat.tool

Description Shows the access authorization to the parameters via the operating tool.

Additional information

The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \boxminus 140)$.

If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 139$).

Access status display

Navigation Setup \rightarrow Advanced setup \rightarrow Access stat.disp

Prerequisite The device has a local display.

Description

Indicates access authorization to parameters via local display.

Additional information

- The access authorization can be changed via the **Enter access code** parameter $(\rightarrow \stackrel{\triangle}{=} 140)$.
- If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter ($\rightarrow \implies 139$).

Enter access code

Navigation

Description

Enter access code to disable write protection of parameters.

User entry

0 to 9999

Additional information

- The customer-specific access code that was defined in the **Define access code** parameter
 (→ ≅ 180) must be entered for local operation.
- If an incorrect access code is entered, users retain their current access authorization.
- The write protection affects all parameters marked with the 🗈 symbol in the document. On the local display, the 🗈 symbol in front of a parameter indicates that the parameter is write-protected.
- If no key is pressed for 10 minutes or the user goes from the navigation and editing mode back to the measured value display mode, the device automatically locks the writeprotected parameters after another 60 s.
- Please contact your Endress+Hauser Sales Center if you lose your access code.

"Interface" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Interface

Process property

Navigation Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Process property

Description Specify typical rate of change for the interface position.

Selection ■ Fast > 1 m (40 in)/min

Standard < 1 m (40in) /min
 Medium < 10 cm (4in) /min
 Slow < 1 cm (0.4in) /min

■ No filter / test

Additional information

The device adjusts the signal evaluation filters and the damping of the output signal to the typical rate of level change defined in this parameter:

Process property	Step response time / s
Fast > 1 m (40 in)/min	5
Standard < 1 m (40in) /min	15
Medium < 10 cm (4in) /min	40
Slow < 1 cm (0.4in) /min	74
No filter / test	2.2

Interface property

Navigation Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Interface prop.

Prerequisite Operating mode ($\rightarrow \equiv 126$) = Interface with capacitance

Description Select interface property.

The interface property determines how the Guided Radar and the Capacitance

Measurement interact.

Selection ■ Special: automatic DC

■ Build up

■ Standard

■ Emulsion layer

Additional information

Meaning of the options

■ Special: automatic DC

Condition:

The specific capacitance (pF/m) is known. 8)

■ Signal evaluation:

As long as a clear interface is detected, both the total and the interface level are determined via the Guided Radar. The dielectric constant of the upper medium is continuously adjusted. If an emulsion layer is present, the total level is determined via the Guided Radar whereas the interface level is determined via the Capacitance Measurement.

Build up

Condition:

The dielectric constant of the upper medium and the specific capacitance (pF/m) are known. $^{8)}$

Signal evaluation:

As long as a clear interface is detected, the interface level is determined via the Guided Radar as well as via the Capacitance Measurement. If these two values start to diverge from each other due to build-up formation, an error message is generated. If an emulsion layer is present, the total level is determined via the Guided Radar whereas the interface level is determined via the Capacitance Measurement.

Standard

Condition:

The dielectric constant of the upper medium is known.

Signal evaluation:

As long as a clear interface is detected, the specific capacitance (pF/m) is continuously adjusted. Therefore build-up has only little influence on the measurement. If an emulsion layer is present, the total level is determined via the Guided Radar whereas the interface level is determined via the Capacitance Measurement.

Oil/Water condensate

Condition:

The dielectric constant of the upper medium and the specific capacitance (pF/m) are known. $^{8)}$

■ Signal evaluation:

The total level is always determined via the Guided Radar. The interface level is always determined via the Capacitance Measurement.

DC value lower medium	

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow DC lower medium

Prerequisite Operating mode ($\Rightarrow \equiv 126$) = Interface or Interface with capacitance

Description Specify the dielectric constant ε_r of the lower medium.

User entry 1 to 100

⁸⁾ The specific capacitance of the media depends on the DC value and the geometry of the probe, which may differ noticeably. For rod probes < 2 m, the probe geometry is measured after production and the resulting specific capacitance for conductive media is preset on delivery.

Additional information

- For the dielectric constants (DC values) of many media commonly used in industry, please refer to:
 - Dielectric constant (DC value) Compendium CP01076F
 - The Endress+Hauser "DC Values app" (available for Android and iOS)
- The factory setting, ε_r = 80, applies for water at 20 °C (68 °F).

Level unit			
Navigation			
Description	Select level unit.		
Selection	SI units	US units ■ ft	
	■ m ■ mm	■ in	
Additional information	The level unit may differ from the distance unit defined in the Distance unit parameter $(\rightarrow \stackrel{\triangle}{=} 126)$:		
		the Distance unit parameter is used for the basic calibration (Empty 128) and Full calibration (\Rightarrow 128).	

Blocking distance	<u> </u>

and interface position.

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting ■ For coax probes: 100 mm (3.9 in)

• For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)


• For rod and rope probes above 8 m (26 ft): 0.025 * length of probe

Additional information

Echoes from within the blocking distance are not taken into account in the signal evaluation. The upper blocking distance is used

• The unit defined in the **Level unit** parameter is used to display the (unlinearized) level

- to suppress interference echoes at the top end of the probe.
- $\mbox{\ \, \blacksquare}$ to suppress the echo of the total level in the case of flooded by passes.



A001322

- 1 Suppression of interference echoes at the top end of the probe.
- 2 Suppression of the level signal in case of a flooded bypass.
- UB Upper blocking distance

Level correction	
------------------	--

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Level correction

Description Specify level correction (if required).

User entry -200 000.0 to 200 000.0 %

Additional information The value specified in this parameter is added to the measured total and interface levels

(before linearization).


Manual thickness upper layer

Navigation \square Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Man.thick.up.lay

Description Specify the manually determined interface thickness UP (i.e. the thickness of the upper

medium).

User entry 0 to 200 m



UP Interface thickness (= thickness of upper medium)

On the local display, the measured interface thickness is indicated together with the manual interface thickness. By comparing these two values the device can automatically adjust the dielectric constant of the upper medium.

Measured thickness up	per layer	
Navigation	$egin{array}{ll} & & & \\ & &$	
Description	Displays the measured interface thickness. (Thickness UP of the upper medium).	
DC value		
Navigation		
Description	Displays relatvie dielectric constant $\epsilon_{\rm r}$ of the upper medium (DC1) before correction.	
Calculated DC value		
Navigation		
Description	Displays calculated (i.e. corrected) relative dielectric constant $\epsilon_{\rm r}$ (DC1) of the upper medium.	

Selection ■ Save and exit ■ Cancel and exit

Additional information Meaning of the options

Save and exit
 The calculated constant is assumed to be the correct one.

Cancel and exit
 The calculated dielectric constant is rejected; the previous dielectric constant remains active.

On the local display, the **Calculated DC value** parameter ($\Rightarrow \implies 145$) is displayed together with this parameter.

"Automatic DC calculation" wizard


The **Automatic DC calculation** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the automatic DC calculation are located directly in the **Interface** submenu (→ 🖺 141)

In the **Automatic DC calculation** wizard two parameters are displayed simultaneously on the display module at any one time. The upper parameter can be edited, whereas the lower parameter is displayed for reference purposes only.

Navigation Setup \rightarrow Advanced setup \rightarrow Interface \rightarrow Autom. DC calc.

Manual thickness upper l	ayer	
Navigation		
Description	→ 🖺 144	
DC value		
Navigation	Setup → Advanced setup → Interface → Autom. DC calc. → DC value	
Description	→ 🗎 145	
Use calculated DC value		(a)
Navigation		
Description	→ 🗎 146	

"Linearization" submenu



■ 37 Linearization: Conversion of the level and, if applicable, interface into a volume or a weight; the conversion depends on the vessel shape

- 1 Selection of linearization type and unit
- Configuration of the linearization 2
- Α
- Linearization type ($\rightarrow \triangleq 151$) = None Linearization type ($\rightarrow \triangleq 151$) = Linear В
- Linearization type ($\rightarrow \blacksquare 151$) = Table С
- D *Linearization type* ($\rightarrow \square 151$) = *Pyramid bottom*
- Linearization type ($\rightarrow = 151$) = Conical bottom Ε
- F Linearization type ($\rightarrow \equiv 151$) = Angled bottom
- Linearization type ($\rightarrow \triangleq 151$) = Horizontal cylinder G
- *Linearization type* ($\rightarrow \equiv 151$) = *Sphere* Н
- For "Operating mode (→ 🖺 126)" = "Interface" or "Interface with capacitance": interface before linearization Ι (measured in the level unit)
- For "Operating mode ($\rightarrow \cong 126$)" = "Interface" or "Interface with capacitance": interface after linearization (corresponds to volume or weight)
- Level before linearization (measured in level unit) L
- L'
- Maximum value (→ 🖺 154) Μ
- d *Diameter (→ 🖺 154)*
- Intermediate height ($\rightarrow \equiv 155$) h

Structure of the submenu on the local display

► Linearization	
	Linearization type
	Unit after linearization
	Free text
	Maximum value
	Diameter
	Intermediate height
	Table mode
	▶ Edit table
	Level
	Customer value
	Activate table

Structure of the submenu in the operating tool (e.g. FieldCare)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization

► Linearization	
Linearization type	
Unit after linearizat	tion
Free text	
Level linearized	
Interface linearized	
Maximum value	
Diameter	
Intermediate heigh	t
Table mode	
Table number	
Level	
Level	
Customer value	
Activate table	

Description of the parameters

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Linearization

Linearization type


Navigation Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Lineariz. type

Description Select linearization type.

Selection ■ None

- Linear
- Table
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

Additional information



- 38 Linearization types
- A None
- B Table
- C Pyramid bottom
- D Conical bottom
- E Angled bottom
- F Sphere
- G Horizontal cylinder

Meaning of the options

None

The level is output in the level unit without being converted (linearized) beforehand.

Linear

The output value (volume/weight) is proportional to the level L. This applies, for example, to vertical cylindrical tanks and silos. The following parameters must also be specified:

- Maximum value (→ 🖺 154): maximum volume or weight

Table

The relationship between the measured level L and the output value (volume/weight) is defined by a linearization table consisting of up to 32 pairs of values "level - volume" or "level - weight" respectively. The following parameters must also be specified:

- **■** Table mode (→ 🗎 155)
- For every point in the table: **Level** (\rightarrow 🖺 **157**)
- For every point in the table: **Customer value** (→ 🗎 **157**)

Pyramid bottom

The output value corresponds to the volume or weight in a silo with a pyramid bottom. The following parameters must also be specified:

- **Maximum value** (→ 🗎 **154**): maximum volume or weight
- **Intermediate height (→ 🗎 155)**: the height of the pyramid

Conical bottom

The output value corresponds to the volume or weight in a tank with a conical bottom. The following parameters must also be specified:

- Maximum value (→ 🗎 154): maximum volume or weight
- **Intermediate height (→** 🖺 **155)**: the height of the cone

Angled bottom

The output value corresponds to the volume or weight in a silo with an angled bottom. The following parameters must also be specified:

- Maximum value (→ 🖺 154): maximum volume or weight
- **Intermediate height (→** 🗎 **155)**: height of the angled bottom

Horizontal cylinder

The output value corresponds to the volume or weight in a horizontal cylinder. The following parameters must also be specified:

- Maximum value (→ 🖺 154): maximum volume or weight
- **■** Diameter (→ 🗎 154)

Sphere

The output value corresponds to the volume or weight in a spherical tank. The following parameters must also be specified:

- Maximum value (→ 🖺 154): maximum volume or weight
- **■** Diameter (→ 🗎 154)

Unit after linearization

Navigation

Prerequisite

Linearization type (\rightarrow $\stackrel{\triangle}{=}$ **151**) ≠ None

Description

Select the unit for the linearized value.

Selection

Selection/input (uint16)

- 1095 = [short Ton]
- 1094 = [lb]
- 1088 = [kg]
- 1092 = [Ton]
- 1048 = [US Gal.]
- 1049 = [Imp. Gal.]
- \bullet 1043 = [ft³]
- $1571 = [cm^3]$
- \bullet 1035 = [dm³]
- $-1034 = [m^3]$
- 1038 = [l]
- 1041 = [hl]
- **1**342 = [%]
- 1010 = [m]
- 1012 = [mm]
- 1018 = [ft]
- 1019 = [inch]
- 1351 = [l/s]
- 1352 = [l/min]
- 1353 = [l/h]
- $-1347 = [m^3/s]$
- $1348 = [m^3/min]$
- $1349 = [m^3/h]$
- $1356 = [ft^3/s]$
- $1357 = [ft^3/min]$
- $1358 = [ft^3/h]$
- 1362 = [US Gal./s]
- 1363 = [US Gal./min]
- 1364 = [US Gal./h]
- 1367 = [Imp. Gal./s]
- 1358 = [Imp. Gal./min]
- 1359 = [Imp. Gal./h]
- \blacksquare 32815 = [Ml/s]
- \blacksquare 32816 = [Ml/min]
- 32817 = [Ml/h]
- 1355 = [Ml/d]

Additional information

The selected unit is only used for display purposes. The measured value is **not** converted on the basis of the selected unit.



Distance-to-distance linearization is also possible, i.e. a linearization from the level unit to another length unit. Select the **Linear** linearization mode for this purpose. To specify the new level unit, select the **Free text** option in the **Unit after linearization** parameter and enter the unit in the **Free text** parameter ($\rightarrow \implies 153$).

Free text

Navigation

Prerequisite

Unit after linearization (→ 🖺 152) = Free text

Description

Enter unit symbol.

User entry

Up to 32 alphanumerical characters (letters, numbers, special characters)

Level linearized

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level linearized

Description Displays linearized level.

Additional information

- The unit is defined by the **Unit after linearization** parameter $\rightarrow \blacksquare 152$.
- For interface measurements, this parameter always refers to the total level.

Interface linearized

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Interf. lineariz

Prerequisite Operating mode (→ 🖺 126) = Interface or Interface with capacitance

Description Displays the linearized interface height.

Additional information

The unit is defined in the **Unit after linearization** parameter $\rightarrow \implies 152$.

Maximum value	
---------------	--

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Maximum value

Prerequisite Linearization type ($\rightarrow \triangleq 151$) has one of the following values:

- Linear
- Pyramid bottom
- Conical bottom
- Angled bottom
- Horizontal cylinder
- Sphere

User entry -50 000.0 to 50 000.0 %

Diameter

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Diameter

Prerequisite Linearization type (→ 🗎 151) has one of the following values:

- Horizontal cylinder
- Sphere

User entry 0 to 9 999.999 m

Additional information The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Intermediate height


Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Intermed. height

Prerequisite Linearization type $(\rightarrow \ \ \ \ \ \ \ \ \ \ \)$ has one of the following values:

Pyramid bottomConical bottomAngled bottom

User entry 0 to 200 m

Additional information



H Intermediate height

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Table mode 🗈

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Table mode

Prerequisite Linearization type $(\Rightarrow \triangle 151) = Table$

Description Select editing mode of the linearization table.

Selection • Manual

- Semiautomatic *Clear table
- Sort table

^{*} Visibility depends on order options or device settings

Meaning of the options

Manual

The level and the associated linearized value are entered manually for each linearization point.

Semiautomatic

The level is measured by the device for each linearization point. The associated linearized value is entered manually.

Clear table

Deletes the existing linearization table.

Sort table

Rearranges the linerization points into an ascending order.

Conditions the linearization table must meet:

- The table may consist of up to 32 pairs of values "Level Linearized Value".
- The table must be monotonic (monotonically increasing or decreasing).
- The first linearization point must refer to the minimum level.
- The last linearization point must refer to the maximum level.
- Before entering a linearization table, the values for **Empty calibration** ($\rightarrow \triangleq 128$) and **Full calibration** ($\rightarrow \triangleq 128$) must be set correctly.

If values of the table need to be changed after the full or empty calibration have been changed, a correct evaluation is only ensured if the existing table is deleted and the complete table is entered again. To do so delete the existing table (**Table mode** $(\rightarrow \ \ \)$ **155)** = **Clear table**). Then enter a new table.

How to enter the table

■ Via FieldCare

The table points can be entered via the **Table number** (\rightarrow 🖺 **156**), **Level** (\rightarrow **🖺 157**) and **Customer value** (\rightarrow **🖺 157**) parameters. As an alternative, the graphic table editor may be used: Device Operation \rightarrow Device Functions \rightarrow Additional Functions \rightarrow Linearization (Online/Offline)

Via local display

Select the **Edit table** submenu to call up the graphic table editor. The table is displayed and can be edited line by line.

The factory setting for the level unit is "%". If you want to enter the linearization table in physical units, you must select the appropriate unit in the **Level unit** parameter (→ 🖺 143) beforehand.

Table number		
Navigation		
Prerequisite	Linearization type (→ 🗎 151) = Table	
Description	Select table point you are going to enter or change.	
User entry	1 to 32	

Level (Manual)

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level

Prerequisite ■ Linearization type (→ 🗎 151) = Table

■ Table mode (→ 🖺 155) = Manual

Description Enter level value of the table point (value before linearization).

User entry Signed floating-point number

Level (Semiautomatic)

Customer value

Navigation

Navigation \square Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Level

Prerequisite ■ Linearization type (→ 🖺 151) = Table

■ Table mode (→ 🖺 155) = Semiautomatic

Description Displays measured level (value before linearization). This value is transmitted to the table.

Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Customer value

Prerequisite Linearization type (→ 🖺 151) = Table

Description Enter linearized value for the table point.

User entry Signed floating-point number

Activate table

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Linearization \rightarrow Activate table

Prerequisite Linearization type ($\rightarrow \triangleq 151$) = Table

Description Activate (enable) or deactivate (disable) the linearization table.

Selection ■ Disable

Enable

Meaning of the options

Disable

The measured level is not linearized.

If **Linearization type** (\rightarrow **\stackrel{\triangle}{=} 151)** = **Table** at the same time, the device issues error message F435.

■ Enable

The measured level is linearized according to the table.

When editing the table, the **Activate table** parameter is automatically reset to **Disable** and must be reset to **Enable** after the table has been entered.

"Safety settings" submenu

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Safety sett.

Output echo lost

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Output echo lost

Description Output signal in case of a lost echo.

Selection • Last valid value

Ramp at echo lostValue echo lost

Alarm

Additional information Meaning of the options

Last valid value

The last valid value is kept in the case of a lost echo.

■ Ramp at echo lost 9)

In the case of a lost echo the output value is continously shifted towards 0% or 100%. The slope of the ramp is defined in the **Ramp at echo lost** parameter ($\rightarrow \triangleq 160$).

■ Value echo lost 9)

In the case of a lost echo the output assumes the value defined in the **Value echo lost** parameter ($\rightarrow \triangleq 159$).

Alarm

In the case of a lost echo the device generates an alarm; see the Failure mode parameter

Value echo lost

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Value echo lost

Prerequisite Output echo lost $(\rightarrow \triangle 159) =$ Value echo lost

Description Output value in case of a lost echo

User entry 0 to 200 000.0 %

Additional information Use the unit which has been defined for the measured value output:

• with linearization: Unit after linearization (\rightarrow $\stackrel{ riangle}{=}$ 152)

Ramp at echo lost


Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Ramp echo lost

Prerequisite Output echo lost (→ 🖺 159) = Ramp at echo lost

Description Slope of the ramp in the case of a lost echo

User entry Signed floating-point number

Additional information



A001326

- A Delay time echo lost
- *B* Ramp at echo lost ($\rightarrow \blacksquare$ 160) (positive value)
- *C* Ramp at echo lost ($\Rightarrow \triangleq 160$) (negative value)
- The unit for the slope of the ramp is "percentage of the measuring range per minute" (%/min).
- For a negative slope of the ramp: The measured value is continuously decreased until it reaches 0%.
- For a positive slope of the ramp: The measured value is continuously increased until it reaches 100%.

Blocking distance

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Safety sett. \rightarrow Blocking dist.

Description Specify upper blocking distance UB.

User entry 0 to 200 m

Factory setting ■ For coax probes: 0 mm (0 in)

• For rod and rope probes up to 8 m (26 ft): 200 mm (8 in)

■ For rod and rope probes above 8 m (26 ft): 0.025 * Sondenlänge

For FMP51/FMP52/FMP54 with the **Interface measurement** application package ¹⁰⁾ and for FMP55:

100 mm (3.9 in) for all antenna types


Additional information

Signals in the upper blocking distance are only evaluated if they have been outside the blocking distance when the device was switched on and move into the blocking distance due to a level change during operation. Signals which are already in the blocking distance when the device is switched on, are ignored.

- This behavior is only valid if the following two conditions are met:
- Expert → Sensor → Echo tracking → Evaluation mode = Short time history or Long time history)
- Expert → Sensor → Gas phase compensation → GPC mode= On, Without correction or External correction

If one of these conditions is not met, signals in the blocking distance will always be ignored.

If required, a different behavior for signals in the blocking distance can be defined by the Endress+Hauser service.



■ 39 Blocking distance (UB) for liquid measurements

¹⁰⁾ Ordering feature 540 "Application Package", option EB "Interface measurement"

"Probe settings" submenu

The **Probe settings** submenu helps to ensure that the end of probe signal within the envelope curve is correctly assigned by the evaluation algorithm. The assignment is correct if the length of probe indicated by the device matches the acutal length of the probe. The automatic probe length correction can only be performed if the probe is installed in the vessel and is completely uncovered (no medium). For partially filled vessels and if the probe length is known, select **Confirm probe length** (\rightarrow 163) = **Manual input** in order to enter the value manually.

- If a mapping (interference echo suppression) has been recorded after shortening the probe, it is no longer possible to perform an automatic probe length correction. In this case there are two options:
 - Delete the map using the **Record map** parameter ($\rightarrow \boxminus 135$) before performing the automatic probe length correction. After the probe length correction, a new map can be recorded using the **Record map** parameter ($\rightarrow \boxminus 135$).
 - Alternative: Select Confirm probe length (→ 163) = Manual input and enter the probe length manually into the Present probe length parameter → 162.
- An automatic probe length correction is only possible after the correct option has been selected in the **Probe grounded** parameter ($\rightarrow \implies 162$).

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Probe settings

Probe grounded		a
Navigation		
Prerequisite	Operating mode (→ 🖺 126) = Level	
Description	Specify whether the probe is grounded.	
Selection	■ No ■ Yes	
Present probe length		
Navigation		
Description	 In most cases: Displays the length of the probe according to the currently measured end-of-probe signal. For Confirm probe length (→ 🗎 163) = Manual input: Enter actual length of probe. 	
User entry	0 to 200 m	

Confirm probe length

Setup \rightarrow Advanced setup \rightarrow Probe settings \rightarrow Confirm length

Description

Navigation

Select, whether the value displayed in the **Present probe length** parameter $\rightarrow \triangleq 162$ matches the actual length of the probe. Based on this input, the device performs a probe length correction.

Selection

■ Probe length OK

- Probe length too small
- Probe length too big
- Probe covered
- Manual input
- Probe length unknown

Additional information

Meaning of the options

■ Probe length OK

To be selected if the indicated length is correct. An adjustment is not required. The device quits the sequence.

■ Probe length too small

To be selected if the displayed length is smaller than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is displayed in the **Present probe length** parameter $\rightarrow \triangleq 162$. This procedure has to be repeated until the displayed value matches the actual length of the probe.

Probe length too big

To be selected if the displayed length is bigger than the actual length of the probe. A different end of probe signal is allocated and the newly calculated length is indicated in the **Present probe length** parameter $\rightarrow \implies 162$. This procedure has to be repeated until the displayed value matches the actual length of the probe.

■ Probe covered

To be selected if the probe is (partially or completely) covered. A probe length correction is impossible in this case. The device quits the sequence.

Manual input

To be selected if no automatic probe length correction is to be performed. Instead, the actual length of the probe must be entered manually into the **Present probe length** parameter $\rightarrow \implies 162^{11}$.

Probe length unknown

To be selected if the acutal length of the probe is unknown. A probe length correction is impossible in this case and the device quits the sequence.

¹¹⁾ When operated via FieldCare, the **Manual input** option needs not to be selected explicitly. In FieldCare the length of the probe can always be edited.

"Probe length correction" wizard

The **Probe length correction** wizard is only available when operating via the local display. When operating via an operating tool, all parameters concerning the probe length correction are located directly in the **Probe settings** submenu ($\rightarrow \implies 162$).

Navigation

Confirm probe length		A
Navigation		
Description	→ 🖺 163	
Present probe length		
Navigation		
Description	→ 🖺 162	

"Switch output" submenu

The **Switch output** submenu ($\rightarrow \triangleq 165$) is only visible for devices with switch output. ¹²⁾

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output

Switch output function

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch out funct

Description Select function for switch output.

Selection ■ Off

- On
- Diagnostic behavior
- Limit
- Digital Output

Additional information

Meaning of the options

Off

The output is always open (non-conductive).

On

The output is always closed (conductive).

■ Diagnostic behavior

The output is normally closed and is only opened if a diagnostic event is present. The **Assign diagnostic behavior** parameter ($\rightarrow \implies 166$) determines for which type of event the output is opened.

Limit

The output is normally closed and is only opened if a measured variable exceeds or falls below a defined limit. The limit values are defined by the following parameters:

- Switch-on value ($\rightarrow \triangle 167$)
- Digital Output

The switching state of the output tracks the output value of a DI function block. The function block is selected in the **Assign status** parameter ($\rightarrow \stackrel{\triangle}{=} 165$).

The **Off** and **On** options can be used to simulate the switch output.

Assign status

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign status

Prerequisite Switch output function (→ 🗎 165) = Digital Output

Selection ■ Off

- Digital output AD 1
- Digital output AD 2

¹²⁾ Ordering feature 020 "Power supply; Output", option B, E or G

- Digital output 1
- Digital output 2
- Digital output 3
- Digital output 4
- Digital output 5
- Digital output 6
- Digital output 7
- Digital output 8

The **Digital output AD 1** and **Digital output AD 2** options refer to the Advanced Diagnostic Blocks. A switch signal generated in these blocks can be transmitted via the switch output.

Assign limit

Navigation $\blacksquare \square$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign limit

Prerequisite Switch output function ($\rightarrow \triangleq 165$) = Limit

Selection ■ Off

- Level linearized
- Distance
- Interface linearized ^{*}
- Interface distance *
- Thickness upper layer *
- Terminal voltage
- Electronic temperature
- Measured capacitance
- Relative echo amplitude
- Relative interface amplitude ^{*}
- Absolute echo amplitude
- Absolute interface amplitude *

Assign diagnostic behavior

Navigation Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Assign diag. beh

Prerequisite Switch output function (→ 🗎 165) = Diagnostic behavior

Description Select diagnostic behavior for switch output.

Selection • Alarm

- Alarm or warning
- Warning

^{*} Visibility depends on order options or device settings

Switch-on value

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-on value

Prerequisite Switch output function (→ 🖺 165) = Limit

Description Enter measured value for the switch-on point.


User entry Signed floating-point number

Additional information

The switching behavior depends on the relative position of the **Switch-on value** and **Switch-off value** parameters:

Switch-on value > Switch-off value


- The output is closed if the measured value is larger than **Switch-on value**.
- The output is opened if the measured value is smaller than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on value < Switch-off value

- The output is closed if the measured value is smaller than **Switch-on value**.
- The output is opened if the measured value is larger than **Switch-off value**.



- A Switch-on value
- B Switch-off value
- C Output closed (conductive)
- D Output opened (non-conductive)

Switch-on delay	<u> </u>

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-on delay

Prerequisite • Switch output function (\rightarrow 🖺 165) = Limit

■ Assign limit (→ 🗎 166) ≠ Off

Description Define delay for the switch-on of status output.

User entry 0.0 to 100.0 s

Switch-off value	

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off value

Prerequisite Switch output function (→ 🖺 165) = Limit

Description Enter measured value for the switch-off point.

User entry Signed floating-point number

Additional information The switching behavior depends on the relative position of the Switch-on value and Switch-off value parameters; description: see the Switch-on value parameter

(→ 🖺 167).

Switch-off delay

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch-off delay

Prerequisite • Switch output function ($\rightarrow \stackrel{\triangle}{=} 165$) = Limit

■ Assign limit (→ 🖺 166) ≠ Off

Description Define delay for the switch-off of status output.

User entry 0.0 to 100.0 s

Failure mode

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Failure mode

Prerequisite Switch output function (→ 🗎 165) = Limit or Digital Output

Description Define output behavior in alarm condition.

Selection • Actual status

OpenClosed

Additional information

Switch status

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Switch status

Description Shows the current switch output status.

Invert output signal

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Switch output \rightarrow Invert outp.sig.

Description Invert the output signal.

Selection ■ No

Yes

Meaning of the options

No

The behavior of the switch output is as described above.

Yes

The states **Open** and **Closed** are inverted as compared to the description above.

"Display" submenu

Display submenu is only visible if a display module is connected to the device.

Navigation

Language

Navigation

Description Set display language.

Selection ■ English

Deutsch

Français ■ Español

■ Italiano

Nederlands '

Portuguesa

■ Polski

■ русский язык (Russian) *

Svenska

Türkçe

■ 中文 (Chinese) *

■ 日本語 (Japanese) *

■ 한국어 (Korean) *
■ Bahasa Indonesia *

tiếng Việt (Vietnamese) *

čeština (Czech)

Factory setting The language selected in feature 500 of the product structure.

If no language has been selected: English

Additional information

Format display

Navigation

Description Select how measured values are shown on the display.

Selection ■ 1 value, max. size

■ 1 bargraph + 1 value

■ 2 values


■ 1 value large + 2 values

4 values


Visibility depends on order options or device settings




■ 40 "Format display" = "1 value, max. size"




■ 41 "Format display" = "1 bargraph + 1 value"



■ 42 "Format display" = "2 values"



■ 43 "Format display" = "1 value large + 2 values"



■ 44 "Format display" = "4 values"

- The **Value 1 to 4 display** \rightarrow $\stackrel{\triangle}{=}$ 173 parameters specify which measured values are shown on the display and in which order.
 - If more measured values are specified than the current display mode permits, the values alternate on the device display. The display time until the next change is configured in the **Display interval** parameter ($\Rightarrow \implies 174$).

Value 1 to 4 display		Î
Navigation	Setup → Advanced setup → Display → Value 1 display	
Description	Select the measured value that is shown on the local display.	
Selection	 Level linearized Distance Interface linearized * Interface distance * 	

Thickness upper layer *
 Terminal voltage
 Electronic temperature
 Measured capacitance *
 Analog output adv. diagnostics 1
 Analog output adv. diagnostics 2
 Analog output 1

Analog output 1
Analog output 2
Analog output 3
Analog output 4
Analog output 5
Analog output 6
Analog output 7
Analog output 8

Factory setting

For interface measurements and one current output

Value 1 display: Interface linearized
Value 2 display: Level linearized
Value 3 display: Thickness upper layer
Value 4 display: Current output 1

For interface measurements and two current outputs

Value 1 display: Interface linearized
 Value 2 display: Level linearized
 Value 3 display: Current output 1
 Value 4 display: Current output 2

Decimal places 1 to 4	(i)
Decimal places I to I	

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Decimal places 1

Description Select the number of decimal places for the display value.

Selection • x

X.XX.XXX.XXXX.XXXX

Additional information

The setting does not affect the measuring or computational accuracy of the device.

Visibility depends on order options or device settings

Display interval

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display interval

Description Set time measured values are shown on display if display alternates between values.

User entry 1 to 10 s

Additional information This parameter is only relevant if the number of selected measuring values exceeds the

number of values the selected display format can display simultaneously.

Display damping

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Display damping

Description Set display reaction time to fluctuations in the measured value.

User entry 0.0 to 999.9 s

Header 🗈


Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header

Description Select header contents on local display.

Selection ■ Device tag

■ Free text

Additional information



A0029422

1 Position of the header text on the display

Meaning of the options

Device tag

Is defined in the **Device tag** parameter.

Free text

Is defined in the **Header text** parameter ($\Rightarrow \implies 175$).

Header text

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Header text

Prerequisite Header (→ 🗎 174) = Free text

Description Enter display header text.

User entry Character string comprising numbers, letters and special characters (12)

Additional information The number of characters which can be displayed depends on the characters used.

Separator

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Separator

Description Select decimal separator for displaying numerical values.

Selection • .

■ ,

Number format

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Number format

Description Choose number format for the display.

Selection • Decimal

■ ft-in-1/16"

Additional information The **ft-in-1/16"** option is only valid for distance units.

Decimal places menu

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Dec. places menu

Description Select number of decimal places for the representation of numbers within the operating

menu.

Selection ■ x

x.xx.xxx.xxxx.xxx

- Is only valid for numbers in the operating menu (e.g. **Empty calibration**, **Full calibration**), but not for the measured value display. The number of decimal places for the measured value display is defined in the **Decimal places 1 to 4** \Rightarrow \cong 173 parameters.
- The setting does not affect the accuracy of the measurement or the calculations.

Backlight

Navigation $\blacksquare \blacksquare$ Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Backlight

Prerequisite The device has the SD03 local display (with optical keys).

Description Switch the local display backlight on and off.

Selection • Disable

■ Enable

Additional information

Meaning of the options

Disable

Switches the backlight off.

■ Enable

Switches the backlight on.

Regardless of the setting in this parameter the backlight may be automatically switched off by the device if the supply voltage is too low.

Contrast display

Navigation \blacksquare Setup \rightarrow Advanced setup \rightarrow Display \rightarrow Contrast display

Description Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle).

User entry 20 to 80 %

Factory setting Dependent on the display.

Additional information

Setting the contrast via push-buttons:

■ Darker: press the 🗇 📵 buttons simultaneously.

■ Brighter: press the 🕒 📵 buttons simultaneously.

"Configuration backup display" submenu

i

This submenu is only visible if a display module is connected to the device.

The configuration of the device can be saved to the display module at a certain point of time (backup). The saved configurateion can be restored to the device if required, e.g. in order to bring the device back into a defined state. The configuration can also be transferred to a different device of the same type using the display module.



Configurations can only be exchanged between devices which are in the same operating mode (see the **Operating mode** parameter ($\Rightarrow \implies 126$)).

Navigation

 \blacksquare Setup \rightarrow Advanced setup \rightarrow Conf.backup disp

		ime

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

Last backup

Navigation Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Last backup

Description Indicates when the last data backup was saved to the display module.

Configuration management

Navigation $\blacksquare \Box$ Setup \rightarrow Advanced setup \rightarrow Conf.backup disp \rightarrow Config. managem.

Description Select action for managing the device data in the display module.

Selection • Cancel

- Execute backup
- Restore
- Duplicate
- Compare
- Clear backup data
- Display incompatible

Meaning of the options

Cancel

No action is executed and the user exits the parameter.

Execute backup

A backup copy of the current device configuration in the HistoROM (built-in in the device) is saved to the display module of the device.

Restore

The last backup copy of the device configuration is copied from the display module to the HistoROM of the device.

Duplicate

The transmitter configuration is duplicated to another device using the transmitter display module. The following parameters, which characterize the individual measuring point are **not** included in the transmitted configuration:

Medium type

Compare

The device configuration saved in the display module is compared to the current device configuration of the HistoROM. The result of this comparison is displayed in the **Comparison result** parameter ($\rightarrow \implies 178$).

Clear backup data

The backup copy of the device configuration is deleted from the display module of the device.

- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.
- If an existing backup is restored to a different device using the **Restore** option, it may occur that some device functionalities are no longer available. In some cases even a device reset will not restore the original status.

In order to transmit a configuration to a different device, the **Duplicate** option should always be used.

Backup state		
Navigation		
Description	Displays which backup action is currently in progress.	
Comparison result		
Navigation		
Description	Comparison between present device data and display backup.	

Meaning of the display options

Settings identical

The current device configuration of the HistoROM is identical to the backup copy in the display module.

Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.

■ No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.

Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.

Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.

■ Dataset incompatible

The data sets are incompatible and can not be compared.

- To start the comparison, set **Configuration management** ($\rightarrow \triangleq 177$) = **Compare**.
- If the transmitter configuration has been duplicated from a different device by Configuration management (→ 🗎 177) = Duplicate, the new device configuration in the HistoROM is only partially identical to the configuration stored in the display module: Sensor specific properties (e.g. the mapping curve) are not duplicated. Thus, the result of the comparison will be Settings not identical.

"Administration" submenu

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration

Navigation Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Def. access code

Description Define release code for write access to parameters.

User entry 0 to 9 999

Additional information

- If the factory setting is not changed or if "O" is entered, the parameters are not write-protected and the device configuration data can therefore always be modified. The user is logged on in the "Maintenance" role.
- The write protection affects all parameters marked with the symbol in the document. On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.
- Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter $(\rightarrow \implies 140)$.
- Please contact your Endress+Hauser Sales Center if you lose the access code.
- If operating via the local display: the new access code is only valid once it has been confirmed in the **Confirm access code** parameter ($\rightarrow \implies 182$).

Device reset	

Navigation \square Setup \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset

Selection • Cancel

- To fieldbus defaults
- To factory defaults
- To delivery settings
- Of customer settings
- To transducer defaults
- Restart device

Additional information

Meaning of the options

Cancel

No action

To factory defaults

All parameters are reset to the order-code specific factory setting.

To delivery settings

All parameters are reset to the delivery setting. The delivery setting may differ from the factory default if customer specific settings have been ordered.

This option is only visible if customer specific settings have been ordered.

Of customer settings

All customer parameters are reset to their factory setting. Service parameters, however, remain unchanged.

■ To transducer defaults

Every measurment-related parameter is reset to its factory setting. Service parameters and communication-related parameters, however, remain unchanged.

■ Restart device

The restart resets every parameter which is stored in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

"Define access code" wizard

The **Define access code** wizard is only available when operating via the local display. When operating via an operating tool, the **Define access code** parameter is located directly in the **Administration** submenu. The **Confirm access code** parameter is not available for operation via operating tool.

Define access code		
Navigation	Setup → Advanced setup → Administration → Def. access code → Def. access code	ode
Description	→ 🖺 180	
Confirm access code		
No. i action		
Navigation		!
Description	Confirm the entered access code.	
User entry	0 to 9 999	

17.4 "Diagnostics" menu

Actual diagnostics Navigation Diagnostics \rightarrow Actual diagnos. Description Displays current diagnostic message. Additional information The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence Event text If several messages are active at the same time, the messages with the highest priority is displayed. Information on what is causing the message, and remedy measures, can be viewed via the (i) symbol on the display. **Timestamp Navigation** Diagnostics → Timestamp **Previous diagnostics Navigation** Diagnostics → Prev.diagnostics Description Displays the last diagnostic message which has been active before the current message. Additional information The display consists of: Symbol for event behavior Code for diagnostic behavior Operating time of occurrence ■ Event text The condition displayed may still apply. Information on what is causing the message,

Endress+Hauser 183

and remedy measures, can be viewed via the (i) symbol on the display.

Timestamı	1
1 IIIIeStaiiii	J

Navigation

□ Diagnostics → Timestamp

Operating time from restart

Navigation \Box Diagnostics \rightarrow Time fr. restart

Description Displays the time the device has been in operation since the last device restart.

Operating time

Navigation \Box Diagnostics \rightarrow Operating time

Description Indicates how long the device has been in operation.

Additional information *Maximum time*

9999 d (≈ 27 years)

17.4.1 "Diagnostic list" submenu

Navigation \Box Diagnostics \rightarrow Diagnostic list

Diagnostics 1 to 5

Navigation \blacksquare Diagnostics \rightarrow Diagnostic list \rightarrow Diagnostics 1

Description Display the current diagnostics messages with the highest to fifth-highest priority.

Additional information The display consists of:

Symbol for event behaviorCode for diagnostic behaviorOperating time of occurrence

Event text

Timestamp 1 to 5

Navigation Diagnostics \rightarrow Diagnostic list \rightarrow Timestamp 1 to 5

17.4.2 "Event logbook" submenu



The **Event logbook** submenu is only available when operating via the local display. When operating via FieldCare, the event list can be displayed in the FieldCare function "Event List / HistoROM".

Navigation

Diagnostics → Event logbook

Filter options

Navigation

Diagnostics → Event logbook → Filter options

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Additional information



- This parameter is only used for operation via the local display.
- The status signals are categorized according to NAMUR NE 107.

"Event list" submenu

The **Event list** submenu displays the history of past events of the category selected in the **Filter options** parameter ($\rightarrow \implies$ 186). A maximum of 100 events are displayed in chronological order.

The following symbols indicate whether an event has occurred or has ended:

- ①: Event has occurred
- (→: Event has ended
- Information on what is causing the message, and remedy instructions, can be viewed via the ①-button.

Display format

- For event messages in category I: information event, event text, "recording event" symbol and time the event occurred
- For event messages in category F, M, C, S (status signal): diagnostics event, event text, "recording event" symbol and time the event occurred

Navigation

extstyle ext

17.4.3 "Device information" submenu

Navigation \Box Diagnostics \rightarrow Device info

Device tag		
Navigation	 □ Diagnostics → Device info → Device tag □ Diagnostics → Device info → Device tag 	
Description	Enter tag for measuring point.	
User interface	Character string comprising numbers, letters and special characters	
Serial number		
Navigation	☐ Diagnostics → Device info → Serial number	
	■ Diagnostics \rightarrow Device info \rightarrow Serial number	
Additional information	 Uses of the serial number To identify the device quickly, e.g. when contacting Endress+Hauser. To obtain specific information on the device using the Device Viewer: www.endress.com/deviceviewer 	
	The serial number is also indicated on the nameplate.	

Firmware version		
Navigation	 □ Diagnostics → Device info → Firmware version □ Diagnostics → Device info → Firmware version 	
User interface	xx.yy.zz	
Additional information	For firmware versions differing only in the last two digits ("zz") there is no difference concerning functionality or operation.	

Device name			
Navigation		Diagnostics \rightarrow Device info \rightarrow Device name	
Š		Diagnostics → Device info → Device name	
Order code			<u></u>
Order code			
Navigation		Diagnostics \rightarrow Device info \rightarrow Order code	
		Diagnostics \rightarrow Device info \rightarrow Order code	
User interface	Character string comprising numbers, letters and special characters		
Additional information	The order code is generated from the extended roder code, which defines all device features of the product structure. In contrast, the device features can not be read directly from the order code.		ly
Extended order code 1 to 3			
Navigation		Diagnostics \rightarrow Device info \rightarrow Ext. order cd. 1	
		Diagnostics \rightarrow Device info \rightarrow Ext. order cd. 1	
Description	Display the three parts of the extended order code.		
User interface	Character string comprising numbers, letters and special characters		
Additional information	The extended order code indicates the version of all the features of the product structure and thus uniquely identifies the device.		

17.4.4 "Measured values" submenu


Navigation \Box Diagnostics \rightarrow Measured val.

Distance

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Measured val. \rightarrow Distance

or threaded connection) and the level.

Additional information



■ 45 Distance for interface measurements

The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Level linearized

Navigation \blacksquare Diagnostics \rightarrow Measured val. \rightarrow Level linearized

Description Displays linearized level.

Additional information

- \blacksquare The unit is defined by the **Unit after linearization** parameter \rightarrow \blacksquare 152.
 - For interface measurements, this parameter always refers to the total level.

Interface distance


Navigation $\blacksquare \square$ Diagnostics \rightarrow Measured val. \rightarrow Interface dist.

Prerequisite Operating mode (→ 🖺 126) = Interface or Interface with capacitance

Description

Displays the measured distance D_I between the reference point (lower edge of flange or threaded connection) and the interface.

Additional information



The unit is defined in the **Distance unit** parameter ($\rightarrow \triangleq 126$).

Interface 1	

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Measured val. \rightarrow Interf. lineariz

Prerequisite Operating mode (→ 🖺 126) = Interface or Interface with capacitance

Description Displays the linearized interface height.

Additional information


Thickness upper layer

Navigation \blacksquare Diagnostics \rightarrow Measured val. \rightarrow Thickn.upp.layer

Prerequisite Operating mode (→ 🖺 126) = Interface or Interface with capacitance

Description Displays the upper interface thickness (UP).

Additional information



UP Thickness upper layer

The unit is defined by the **Unit after linearization** parameter $\rightarrow \triangleq 152$.

Terminal voltage 1

Navigation

17.4.5 "Analog input 1 to 5" submenu

There is an **Analog inputs** submenu for every AI block of the device. The AI block is used to configure the measured value transmission to the bus.

Only the most basic properties of the AI block can be configured in this submenu. For a detailed configuration of the AI blocks refer to the **Expert** menu.

Block tag	
Navigation	
Description	Defined to be unique throughout the control system at one plant site. The tag may be changed using the FB_Tag service.
User entry	Character string comprising numbers, letters and special characters (32)

Channel **Navigation** Diagnostics \rightarrow Analog inputs \rightarrow Analog input 1 to 7 \rightarrow Channel Description Use this function to select the input value that should be processed in the Analog Input function block. Selection Uninitialized Level linearized Absolute echo amplitude Absolute EOP amplitude Absolute interface amplitude * Distance ■ Electronic temperature ■ EOP shift ■ Interface linearized * ■ Interface distance Measured capacitance * ■ Relative echo amplitude Relative interface amplitude * Noise of signal Terminal voltage Thickness upper layer * Calculated DC value Analog output adv. diagnostics 2 Analog output adv. diagnostics 1 Status **Navigation** Description Indicates the status of the output of the AI block according to the FOUNDATION Fieldbus specification. Value **Navigation** Diagnostics \rightarrow Analog inputs \rightarrow Analog input 1 to 7 \rightarrow Value

Indicates the output value of the AI block.

192

Description

^{*} Visibility depends on order options or device settings

Navigation \blacksquare Diagnostics \rightarrow Analog input 1 to 7 \rightarrow Units index

Description Indicates the unit of the output value.

17.4.6 "Data logging" submenu

Assign channel 1 to 4

Navigation

Selection

- Off
- Level linearized
- Distance
- Unfiltered distance
- Interface linearized ⁷
- Interface distance
- Unfiltered interface distance
- Thickness upper layer ²
- Terminal voltage
- Electronic temperature
- Measured capacitance *
- Absolute echo amplitude
- Relative echo amplitude
- Absolute interface amplitude *
- Relative interface amplitude
- Absolute EOP amplitude
- EOP shift
- Noise of signal
- Calculated DC value *
- Analog output adv. diagnostics 1
- Analog output adv. diagnostics 2
- Analog output 1
- Analog output 2
- Analog output 3
- Analog output 4

Additional information

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

If the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The logged data are deleted if a new option is selected in this parameter.

Visibility depends on order options or device settings

Logging interval

Navigation

- \square Diagnostics \rightarrow Data logging \rightarrow Logging interval
- Diagnostics → Data logging → Logging interval

User entry

1.0 to 3600.0 s

Additional information

This parameter defines the interval between the individual data points in the data log, and thus the maximum loggable process time T $_{\rm log}$:

- If 1 logging channel is used: T $_{log}$ = 1000 · t $_{log}$
- If 2 logging channels are used: $T_{log} = 500 \cdot t_{log}$
- If 3 logging channels are used: $T_{log} = 333 \cdot t_{log}$
- If 4 logging channels are used: $T_{log} = 250 \cdot t_{log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T $_{log}$ always remains in the memory (ring memory principle).



The logged data are deleted if this parameter is changed.

Example

When using 1 logging channel

- $T_{log} = 1000 \cdot 1 \text{ s} = 1000 \text{ s} \approx 16.5 \text{ min}$
- $T_{log} = 1000 \cdot 10 \text{ s} = 1000 \text{ s} \approx 2.75 \text{ h}$
- $T_{log} = 1000 \cdot 80 \text{ s} = 80000 \text{ s} \approx 22 \text{ h}$
- $T_{log} = 1000 \cdot 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data

Navigation

- □ Diagnostics → Data logging → Clear logging
- Diagnostics → Data logging → Clear logging

Selection


- Cancel
- Clear data

"Display channel 1 to 4" submenu



The **Display channel 1 to 4** submenus are only available for operation via the local display. When operating via FieldCare, the logging diagram can be displayed in the FieldCare function "Event List / HistoROM".

The **Display channel 1 to 4** submenus invoke a diagram of the logging history of the respective channel.



- x-axis: depending on the number of selected channels, 250 to 1000 measured values of a process variable are displayed.
- y-axis: covers the approximate measured value span and constantly adapts this to the measurement.
- To return to the operating menu, press \pm and \Box simultaneaously.

Navigation

□ Diagnostics → Data logging → Displ.channel 1 to 4

"Simulation" submenu 17.4.7

The **Simulation** submenu is used to simulate specific measuring values or other conditions. This helps to check the correct configuration of the device and connected control units.


Conditions which can be simulated

Condition to be simulated	Associated parameters
Specific value of a process variable	 Assign measurement variable (→ 🖺 200) Process variable value (→ 🖺 200)
Specific state of the switch output	■ Switch output simulation (→ 🖺 200) ■ Switch status (→ 🖺 201)
Existence of an alarm	Simulation device alarm ($\rightarrow riangleq 201$)

Enable/disable simulation


The simulation of measured values can be enabled or disabled via a hardware switch (SIM switch) at the electronics. Simulating a measured value is only possible if the SIM switch is in the ON position.

The switch output can always be simulated, irrespective of the position of the SIM switch.



- 1. Loosen the securing clamp.
- 2. Unscrew the housing cover.

- 3. Pull out the display module with a gentle rotation movement. To make it easier to access the SIM switch, attach the display module to the edge of the electronics compartment.
 - ► Display module is attached to the edge of the electronics compartment.




A0013909

- 4. SIM switch in the **ON** position: measured values can be simulated. SIM switch in the **OFF** position (factory setting): Simulation of measured values is disabled.
- 5. Feed the spiral cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Screw the electronics compartment cover closed and tighten the securing clamp.

Structure of the submenu

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation



Description of parameters

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Diagnostics \rightarrow Simulation

Assign measurement variable

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Assign meas.var.

Selection ■ Off

- Level
- Interface *
- Level linearized
- Interface linearized
- Thickness linearized

Additional information

- The value of the variable to be simulated is defined in the **Process variable value** parameter ($\rightarrow \cong 200$).
- If **Assign measurement variable** ≠ **Off**, a simulation is active. This is indicated by a diagnotic message of the *Function check (C)* category.

Process variable value

æ

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Proc. var. value

Prerequisite Assign measurement variable ($\rightarrow \stackrel{\triangle}{=} 200$) \neq Off

User entry Signed floating-point number

Additional information

Downstream measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

Switch output simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch sim.

Description Switch the simulation of the switch output on and off.

Selection ■ Off

On

Visibility depends on order options or device settings

Switch status

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Switch status

Prerequisite Switch output simulation (→ 🖺 200) = On

Description Select the status of the status output for the simulation.

Selection • Open

Closed

Additional information The switch status assumes the value defined in this parameter. This helps to check correct

operation of connected control units.

Simulation device alarm

Navigation $\blacksquare \Box$ Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Sim. alarm

Description Switch the device alarm on and off.

Selection ■ Off

■ On

Additional information When selecting the **On** option, the device generates an alarm. This helps to check the

correct output behavior of the device in the case of an alarm.

An active simulation is indicated by the **♦C484 Simulation failure mode** diagnostic

message.

Diagnostic event simulation

Navigation \blacksquare Expert \rightarrow Diagnostics \rightarrow Simulation \rightarrow Diag. event sim.

Description Select a diagnostic event to simulate this event.

Additional information When operated via the local display, the selection list can be filtered according to the event

categories (Diagnostic event category parameter).

17.4.8 "Device check" submenu

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device check

Start device check

Navigation \blacksquare Diagnostics \rightarrow Device check \rightarrow Start dev. check

Description Start a device check.

Selection ■ No ■ Yes

Additional information In the case of a lost echo a device check can not be performed.

Result device check

Navigation $\blacksquare \blacksquare$ Diagnostics \rightarrow Device check \rightarrow Result dev.check

Description Displays the result of the device check.

Additional information Meaning of the display options

■ Installation ok

Measurement possible without restrictions.

Accuracy reduced

A measurement is possible. However, the measuring accuracy may be reduced due to the signal amplitudes.

■ Measurement capability reduced

A measurement is currently possible. However, there is the risk of an echo loss. Check the mounting position of the device and the dielectric constant of the medium.

Check not done

No device check has been performed.

Last check time

Navigation \blacksquare Diagnostics \rightarrow Device check \rightarrow Last check time

Description Displays the operating time at which the last device check has been performed.

User interface Character string comprising numbers, letters and special characters

Level signal

Navigation \Box Diagnostics \rightarrow Device check \rightarrow Level signal

Prerequisite Device check has been performed.

Description Displays result of the device check for the level signal.

User interface ■ Check not done

Check not OKCheck OK

Additional information

For Level signal = Check not OK: Check the mounting position of the device and the

dielectric constant of the medium.

Launch signal

Navigation $\blacksquare \square$ Diagnostics \rightarrow Device check \rightarrow Launch signal

Prerequisite Device check has been performed.

Description Displays result of the display check for the launch signal.

User interface ■ Check not done

Check not OKCheck OK

Additional information

For **Launch signal** = **Check not OK**: Check the mounting position of the device. In non-

metallic vessels use a metal plate or a metal flange.

Interface signal

Navigation $\blacksquare \Box$ Diagnostics \rightarrow Device check \rightarrow Interface signal

Prerequisite ■ Operating mode (→ 🖺 126) = Interface or Interface with capacitance

• Device check has been performed.

Description Displays result of the device check for the interface signal.

User interface ■ Check not done

■ Check not OK

■ Check OK

17.4.9 "Heartbeat" submenu



The **Heartbeat** submenu is only available via **FieldCare** or **DeviceCare**. It contains the wizards which are part of the **Heartbeat Verification** and **Heartbeat Monitoring** application packages.

Detailed description

SD01872F

Navigation

Index

A	D
Access authorization to parameters	Data logging (Submenu)
Read access	DC value (Parameter) 131, 145, 147
Write access	DC value lower medium (Parameter) 142
Access code	Decimal places 1 (Parameter)
Incorrect input	Decimal places menu (Parameter) 175
Access status display (Parameter) 139	Define access code (Parameter) 180, 182
Access status tooling (Parameter)	Define access code (Wizard) 182
Accessories	Define the access code 45
Communication-specific	Device check (Submenu) 202
Device-specific	Device information (Submenu)
Service-specific	Device name (Parameter)
System components	Device replacement
Activate table (Parameter)	Device reset (Parameter)
Actual diagnostics (Parameter)	Device tag (Parameter)
Administration (Submenu)	Diagnostic event
Advanced setup (Submenu)	In the operating tool
Analog input 1 to 5 (Submenu) 137, 191	Diagnostic event simulation (Parameter) 201
Application	Diagnostic events
Assign channel 1 to 4 (Parameter) 194	Diagnostic list
Assign diagnostic behavior (Parameter) 166	Diagnostic list (Submenu)
Assign limit (Parameter)	Diagnostic message
Assign measurement variable (Parameter) 200	Diagnostics
Assign status (Parameter)	Symbols
Automatic DC calculation (Wizard) 147	Diagnostics (Menu)
	Diagnostics 1 (Parameter)
В	Diameter (Parameter)
Backlight (Parameter)	DIP switch
Backup state (Parameter)	see Write protection switch
Block tag (Parameter)	Disable simulation
Blocking distance (Parameter) 143, 160	Display (Submenu)
Bypass	Display and operating module FHX50 41
	Display channel 1 to 4 (Submenu) 196
C	Display damping (Parameter) 174
Calculated DC value (Parameter)	Display interval (Parameter)
Channel (Parameter)	Display module 50
Cleaning	Display symbols
Clear logging data (Parameter)	Disposal
Coax probe	Distance (Parameter) 130, 136, 189
Design	Distance unit (Parameter)
Coax probes	Document
Lateral loading capacity	Purpose 6
Comparison result (Parameter)	_
Configuration backup display (Submenu) 177	E
Configuration management (Parameter)	Electronics housing
Configuration of an interface measurement 72, 80	Design
Configuring interface measurement	Empty calibration (Parameter)
Configuring the language	Enable simulation
Confirm access code (Parameter)	Enter access code (Parameter)
Confirm proba longth (Parameter)	Envelope curve display
Confirm probe length (Parameter) 163, 164	Event history
Context menu	Event level
Contrast display (Parameter)	Explanation
Customer value (Parameter)	Symbols
	Event list (Submenu)
	Event logbook (Submenu)

Event text	see In alarm condition Locking status
Extended order code 1 (Parameter)	Locking status (Parameter)
F	M
Failure mode (Parameter)	Maintenance
Field of application Residual risks	Manual thickness upper layer (Parameter) 144, 147 Mapping (Wizard)
Filter options (Parameter)	Mapping end point (Parameter) 134, 136 Maximum value (Parameter)
Firmware version (Parameter)	Measured thickness upper layer (Parameter) 145 Measured value symbols
Format display (Parameter)	Measured values (Submenu)
Full calibration (Parameter)	Medium group (Parameter)
Н	Diagnostics 183 Setup 126
Hardware write protection	Mounting position for interface measurements 19
Header text (Parameter)175Heartbeat (Submenu)204	N Number format (Parameter)
HistoROM (description)	0
Housing Design14	Operating elements
Turning	Diagnostic message 95
ī	Operating mode (Parameter)
Input mask	Operating frieddie
Intended use	Operating time from restart (Parameter)
Interface (Parameter)	Operational safety
Interface (Submenu)	Order code (Parameter)
Interface distance (Parameter) 132, 189	Output echo lost (Parameter) 159
Interface linearized (Parameter) 154, 190	Overvoltage protection
Interface property (Parameter)	General information
Interface signal (Parameter) 203	n
Intermediate height (Parameter)	P
Invert output signal (Parameter)	Present mapping (Parameter)
K	Previous diagnostics (Parameter)
Keypad lock Disabling	Probe grounded (Parameter)
Enabling	Probe settings (Submenu)
Enabling	Process property (Parameter)
L	Process Value Filter Time (Parameter)
Language (Parameter)	Process variable value (Parameter)
Last backup (Parameter)	Product safety
Last check time (Parameter) 202	Purpose of this document 6
Launch signal (Parameter) 203	•
Level (Parameter)	R
Level correction (Parameter)	Ramp at echo lost (Parameter) 160
Level linearized (Parameter)	Read access
Level signal (Parameter)	Record map (Parameter) 135, 136
Level unit (Parameter)	Registered trademarks
Linearization (Submenu) 149, 150, 151	Remedial measures
Linearization type (Parameter)	Closing 96
Local display	Closing
see Diagnostic incosage	1. Temote operation

Repair concept 103 Replacing a device 103 Requirements for personnel 11 Result device check (Parameter) 202 Return 104 Rod probe 13 Design 13 Rod probes 21 Lateral loading capacity 21 Rope probe 13 Rope probes 28 Mounting 28 Tensile loading capacity 21	Simulation199, 200Switch output165Switch output (Submenu)165Switch output function (Parameter)165Switch output simulation (Parameter)200Switch status (Parameter)169, 201Switch-off delay (Parameter)169Switch-off value (Parameter)168Switch-on delay (Parameter)168Switch-on value (Parameter)167SymbolsFor correction54In the text and numeric editor54System components111
S	T
Safety instructions Basic	Table mode (Parameter)155Table number (Parameter)156Tank type (Parameter)126Terminal voltage 1 (Parameter)191Thermal insulation27Thickness upper layer (Parameter)190Timestamp (Parameter)183, 184Timestamp 1 to 5 (Parameter)185Tool28
Settings Managing the device configuration	Transmitter Turning the display
Signal quality (Parameter)130SIM switch197Simulation (Submenu)199, 200Simulation device alarm (Parameter)201Spare parts104Nameplate104	Turning
Start device check (Parameter) 202 Status (Parameter) 192 Status signals 51, 94 Stilling well 24 Submenu 180 Advanced setup 139	Underground tanks
Analog input 1 to 5	Use of the measuring devices Borderline cases
Device information 187 Diagnostic list 185 Display 171 Display channel 1 to 4 196 Event list 186 Event logbook 186	Value (Parameter)
Events list 99 Heartbeat 204 Interface 141 Linearization 149, 150, 151 Measured values 189 Probe settings 162 Safety settings 159	Wizard147Automatic DC calculation147Define access code182Mapping136Probe length correction164Workplace safety12Write access45

Write	protection
VVIICC	protection

Write protection	
Via access code	45
Via write protection switch	46
Write protection switch	46



www.addresses.endress.com