

Functional Safety Manual

Diaphragm seal for pressure and differential pressure transmitters

PMP55, PMP75, PMP51B, PMP71B, FMD77, FMD78,
PMD78B





A0023555

Table of contents

1	Declaration of conformity	4	8	Appendix	13
1.1	Safety-related characteristic values	5	8.1	Use of the characteristic values of the diaphragm seal when specifying the safety function	13
2	About this document	6	8.1.1	λ_{DU}	13
2.1	Document function	6	8.1.2	PTC values	13
2.2	Symbols used	6	8.2	Version history	14
2.2.1	Safety symbols	6			
2.2.2	Symbols for certain types of information and graphics	6			
2.3	Supplementary device documentation	6			
2.3.1	Further applicable documents	7			
2.3.2	Functional Safety Manual (FY)	7			
3	Design	7			
3.1	Permitted device types	7			
3.1.1	Order codes	7			
3.2	Identification marking	7			
3.3	Safety function	8			
3.4	Basic conditions for use in safety-related applications	8			
3.4.1	Safety-related failures according to IEC / EN 61508	8			
3.4.2	Additional restrictions for safety-related use	8			
3.5	Dangerous undetected failures in this scenario	9			
3.6	Safety measured error	9			
3.7	Useful lifetime of electrical components	9			
4	Commissioning (installation and configuration)	9			
4.1	Requirements for personnel	9			
4.2	Installation	9			
4.3	Commissioning	9			
4.4	Operation	10			
4.5	Parameter configuration for safety-related applications	10			
5	Operation	10			
6	Proof testing	10			
6.1	Verification criterion	11			
7	Repair and error handling	12			
7.1	Maintenance	12			
7.2	Repair	12			
7.3	Modification	12			
7.4	Decommissioning	12			
7.5	Disposal	12			

1 Declaration of conformity

SIL_00429_02.23

Endress+Hauser 
People for Process Automation

Declaration of Conformity

Functional Safety according to IEC 61508
Based on NE 130 Form B.1

Endress+Hauser SE+Co. KG, Hauptstraße 1, 79689 Maulburg

being the manufacturer, declares that the product

**Diaphragm seals for pressure and differential pressure transmitters
PMP55, PMP75, PMP51B, PMP71B, FMD77, FMD78 and PMD78B**

is suitable for the use in safety-instrumented systems according to IEC 61508. The instructions of the corresponding functional safety manual must be followed.

This declaration of conformity is exclusively valid for the listed products and accessories in delivery status.

Maulburg, March 15, 2023
Endress+Hauser SE+Co. KG

i. V.

E-SIGNED by Gerd Bechtel
on 17 March 2023 14:51:22 GMT

Gerd Bechtel
Dept. Man. R&D Devices Pressure
Research & Development

i. V.

E-SIGNED by Manfred Hammer
on 16 March 2023 15:04:32 GMT

Manfred Hammer
Dept. Man. R&D Quality Management/FSM
Research & Development

A0045625

1.1 Safety-related characteristic values

SIL_00429_02.23



People for Process Automation

General			
Device designation and permissible types ¹⁾	Diaphragm seals for PMP55, PMP75, PMP51B, PMP71B, FMD77, FMD78 and PMD78B		
	Valid order codes and order code exclusions are maintained in the E+H ordering system		
Safety-related output signal	See safety manual of the corresponding device		
Fault signal	Gauge / Absolute Pressure:		
Process variable/function	PMP55	SD00347P	
	PMP75	SD00190P	
	PMP51B	FY01027P	
	PMP71B	FY01028P	
	Differential pressure, Gauge pressure:		
	FMD77	SD00189P	
	FMD78	SD00189P	
Safety function(s)	PMD78B	FY01031P	
Device type acc. to IEC 61508-2	<input checked="" type="checkbox"/> Type A	<input type="checkbox"/> Type B	
Operating mode	Refer to corresponding device safety manual mentioned above		
Valid hardware version	Refer to corresponding device safety manual mentioned above		
Valid software version	Refer to corresponding device safety manual mentioned above		
Safety manual	FY01038P		
Type of evaluation (check only <u>one</u> box)	<input checked="" type="checkbox"/>	Complete HW/SW evaluation parallel to development incl. FMEDA and change request acc. to IEC 61508-2, 3	
	<input type="checkbox"/>	Evaluation of "proven in use" performance for HW/SW incl. FMEDA and change request acc. to IEC 61508-2, 3	
	<input type="checkbox"/>	Evaluation of HW/SW field data to verify „prior use“ acc. to IEC 61511	
	<input type="checkbox"/>	Evaluation by FMEDA acc. to IEC 61508-2 for devices w/o software	
Evaluation through – report/certificate no.	TÜV Rheinland 968/INS 471		
Test documents	Development documents	Test reports	Data sheets
SIL – Integrity			
Systematic safety integrity		<input type="checkbox"/> SC 2	<input checked="" type="checkbox"/> SC 3
Hardware safety integrity	Single channel use (HFT = 0)	<input checked="" type="checkbox"/> SIL 2 capable	<input type="checkbox"/> SIL 3 capable
	Multi channel use (HFT ≥ 1)	<input type="checkbox"/> SIL 2 capable	<input checked="" type="checkbox"/> SIL 3 capable
FMEDA			
Safety function	Refer to corresponding device safety manual mentioned above		
$\lambda_{DU}^{2),3)}$	41 FIT		
$\lambda_{DD}^{2),3)}$	0 FIT		
$\lambda_S^{2),3)}$	0 FIT		
SFF	0%		
PFD _{avg} (T ₁ = 1 year) ³⁾ (single channel architecture)	1.83 · 10 ⁻⁶		
PFH	4.10 · 10 ⁻⁸ 1/h		
PTC ⁴⁾ A / B	99% / 0%		
Diagnostic test interval ⁵⁾	No diagnostics available		
Fault reaction time ⁶⁾	---		
Comments			
–			
Declaration			
<input checked="" type="checkbox"/>	Our internal company quality management system ensures information on safety-related systematic faults which become evident in the future		

¹⁾ Valid order codes and order code exclusions are maintained in the E+H ordering system
²⁾ FIT = Failure In Time, number of failures per 10⁹ h
³⁾ Valid for average ambient temperature up to +40 °C (+104 °F)
 For continuous operation at ambient temperature close to +60 °C (+140 °F), a factor of 2.1 should be applied
⁴⁾ PTC = Proof Test Coverage
⁵⁾ All diagnostic functions are performed at least once within the diagnostic test interval
⁶⁾ Maximum time between error recognition and error response

2 About this document

2.1 Document function

This supplementary Safety Manual applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions. The supplementary device documentation must be observed during installation, commissioning and operation. The requirements specific to the protection function are described in this safety manual.



General information on functional safety (SIL) is available at:
www.endress.com/SIL

2.2 Symbols used

2.2.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.



This symbol contains information on procedures and other facts which do not result in personal injury.

2.2.2 Symbols for certain types of information and graphics



Tip
Indicates additional information



Reference to documentation



Reference to graphic

2.3 Supplementary device documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
- *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The following document types are available in the download area of the Endress+Hauser website (www.endress.com/downloads):

2.3.1 Further applicable documents

All Technical Information documents, Brief Operating Instructions, Operating Instructions and Descriptions of Device Parameters for the basic units also describe the use of devices with mounted diaphragm seals.

Particular attention must be given to the Functional Safety Manuals of the following basic units:

Gauge, absolute pressure (piezoresistive):

- PMP55: SD00347P
- PMP75: SD00190P
- PMP51B: FY01027P
- PMP71B: FY01028P

Differential pressure, gauge pressure (piezoresistive):

- FMD77: SD00189P
- FMD78: SD00189P
- PMD78B: FY01031P

2.3.2 Functional Safety Manual (FY)

Depending on the SIL approval, the Functional Safety Manual (FY) is an integral part of the Operating Instructions and applies in addition to the Operating Instructions, Technical Information and ATEX Safety Instructions.



The different requirements that apply for the protective function are described in the Functional Safety Manual (FY).

3 Design

3.1 Permitted device types

This document is a supplement to the Functional Safety Manuals for pressure and differential pressure transmitters if these transmitters are fitted with diaphragm seals. It provides an overview of the safety-related characteristic values of the diaphragm seals and explains how they must be combined with the values of the basic units.

The document also contains instructions and conditions that apply for the devices fitted with diaphragm seals.

The details pertaining to functional safety in this manual relate to the device versions listed in the Functional Safety Manual of the basic unit and are valid as of the specified firmware and hardware versions.

A modification process according to IEC 61508 is applied for any device modifications.

3.1.1 Order codes

Please refer to the Functional Safety Manual of the basic unit for the permitted order codes.

3.2 Identification marking


SIL-certified devices are marked with the SIL logo  on the nameplate.

3.3 Safety function

Safety function →  Functional Safety Manual for the basic unit

3.4 Basic conditions for use in safety-related applications

The measuring system must be used correctly for the specific application, taking into account the medium properties and ambient conditions. Carefully follow instructions pertaining to critical process situations and installation conditions from the Operating Instructions. The application-specific limits must be observed. The specifications in the Operating Instructions and the Technical Information must not be exceeded.

 A pressure measuring device that is fitted with two diaphragm seals is not a redundant system. **The hardware failure tolerance (HFT) is 0!**

3.4.1 Safety-related failures according to IEC / EN 61508

The safety-related characteristic values of a diaphragm seal and their application in connection with a pressure or differential pressure measuring device are listed in the following sections.

Characteristic values of a diaphragm seal

Failure rates λ : (these values apply per diaphragm seal)

- $\lambda_{DU} = 41 \text{ FIT}$
- λ_{DD} and $\lambda_{SD} = 0 \text{ FIT}$
(as a purely mechanical component, a diaphragm seal does not offer any diagnostics)
- $\lambda_{SU} = 0$
(value is negligibly small)


Safety-related failures →  Functional Safety Manual for the basic unit

3.4.2 Additional restrictions for safety-related use

The technical data of the basic unit change if a diaphragm seal is fitted. Detailed measured errors, such as for other temperature ranges, can be calculated with the Applicator "Sizing Pressure Performance".




A0038927

 1 QR code for the Applicator "Sizing Pressure Performance"


NOTICE

Damage to the diaphragm seal from corrosive or abrasive media/environments.


A dangerous undetected failure can occur.

- ▶ Take suitable measures to ensure that no damage occurs that affects the measuring ability of the device.
- ▶ Other potential restrictions →  Functional Safety Manual for the basic units

3.5 Dangerous undetected failures in this scenario

Dangerous undetected failures →  Functional Safety Manual for the basic unit

3.6 Safety measured error

Safety measured error →  Functional Safety Manual for the basic unit

3.7 Useful lifetime of electrical components

Diaphragm seals do not contain any electrical components or any parts subject to wear. The useful lifetime of the electrical components of the basic unit applies.

4 Commissioning (installation and configuration)

4.1 Requirements for personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:


- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task.
- ▶ Personnel must be authorized by the plant owner/operator.
- ▶ Be familiar with federal/national regulations.
- ▶ Before starting work: personnel must read and understand the instructions in the manual and supplementary documentation as well as the certificates (depending on the application).
- ▶ Personnel must follow instructions and comply with general policies.

The operating personnel must fulfill the following requirements:

- ▶ Personnel are instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Personnel follow the instructions in this manual.

4.2 Installation

The mounting and wiring of the device and the permitted orientations are described in the Operating Instructions pertaining to the device.

 Correct installation is a prerequisite for safe operation of the device.

4.3 Commissioning

The commissioning of the device is described in the Operating Instructions pertaining to the device.

Prior to operating the device in a safety instrumented system, verification must be performed by carrying out a test sequence as described in **Section 6 Proof testing** of the Functional Safety Manual for the basic unit.


4.4 Operation

Operation →  Corresponding Operating Instructions for the basic unit

4.5 Parameter configuration for safety-related applications

All aspects of the configuration, such as:

- Calibration of the measuring point
- Device protection
- Configuration methods
- Parameters and default settings
- Locking and unlocking

→  Corresponding Operating Instructions and Functional Safety Manual for the basic unit


5 Operation

All aspects of operation, such as:

- Device behavior when switched on
- Safety function requirements
- Safe states
- Device behavior in event of alarms and warnings
- Alarm and warning messages

→  Corresponding Functional Safety Manual for the basic unit

6 Proof testing

 The safety-related functionality of the device in the SIL mode must be verified during commissioning, when changes are made to safety-related parameters, and also at appropriate time intervals. This enables this functionality to be verified within the entire safety instrumented system. The time intervals must be specified by the operator.

CAUTION

The safety function is not guaranteed during a proof test

Suitable measures must be taken to guarantee process safety during the test.

- ▶ The safety-related output signal 4 to 20 mA must not be used for the safety instrumented system during testing.
 - ▶ A completed test must be documented; the reports provided in the Appendix can be used for this purpose (see Section 8.2).
 - ▶ The operator specifies the test interval and this must be taken into account when determining the probability of failure PFD_{avg} of the sensor system.
- During the test, the safety-related output signal 4 to 20 mA must not be used for the safety instrumented system.
 - The performance of a test must be documented. The template in the Appendix can be used for this purpose
 - The operator specifies the testing interval and this must be taken into account when determining the probability of failure PFD_{avg} of the sensor system

If no operator requirements for the proof test are specified, the procedures described in the Functional Safety Manual of the associated basic unit can be applied.

As the basic unit and diaphragm seal are tested together but have different PTC values, these values must be combined to calculate an overall value for the device with a mounted diaphragm seal.

Proof test coverage PTC

The proof test for the diaphragm seal is performed together with the basic unit, e.g. according to one of the procedures described in the Functional Safety Manual of the basic unit. However, different PTC values apply for the diaphragm seal and the basic unit. These values must be combined.

The following applies for the diaphragm seal component:

- Full test sequence: PTC = 99 %
- Simplified test sequence: PTC = 0 %



The names of the test sequences vary between the different instrument families.

The following applies:

- **FMD77, FMD78, PMP75**
 - Full test sequence → "Test sequence 2"
 - Simplified test sequence → "Test sequence 1"
- **PMP55**
 - Full test sequence → "Test sequence B"
 - Simplified test sequence → "Test sequence A"
- **PMD78B, PMP51B, PMP71B**
 - Full test sequence → "Test sequence A"
 - Simplified test sequence → "Test sequence B"

The safety-related characteristic values of the diaphragm seal must be appropriately combined with the characteristic values of the basic unit.

Calculation example → Section 8.1

6.1 Verification criterion

The test criteria listed in the Functional Safety Manual of the basic unit apply.

The technical data of the basic unit change if a diaphragm seal is fitted. Detailed measured errors, such as for other temperature ranges, can be calculated with the Applicator "Sizing Pressure Performance".



2 QR code for the Applicator "Sizing Pressure Performance"


A0038927

If one of the test criteria from the test sequences described above is not satisfied, the device may no longer be used as part of a safety instrumented system.

7 Repair and error handling

7.1 Maintenance

Maintenance instructions and instructions regarding recalibration may be found in the Operating Instructions pertaining to the device.

 Alternative monitoring measures must be taken to ensure process safety during configuration, proof-testing and maintenance work on the device.

7.2 Repair

Repair means restoring functional integrity by replacing defective components.

No repairs by the user or E+H Service staff are envisaged for diaphragm seals. A defective diaphragm seal may only be repaired by Endress+Hauser. For this purpose, you must return the basic device together with the diaphragm seal.

When returning the defective device, always enclose the "Declaration of Hazardous Material and Decontamination" with the note "Used as SIL device in a safety instrumented system".

Information on returns: <http://www.endress.com/support/return-material>

7.3 Modification

Modifications are changes to SIL devices that are already delivered or installed:

- **Modifications to SIL devices by the user are not permitted as they can impair the functional safety of the device**
- Modifications to SIL devices may be performed onsite at the user's plant following approval by the Endress+Hauser manufacturing center
- Modifications to SIL devices must be performed by staff who have been authorized to perform this work by Endress+Hauser
- Only **original spare parts** from Endress+Hauser must be used for modifications
- All modifications must be documented in the W@M Device Viewer (www.endress.com/deviceviewer)
- All modifications require a modification nameplate or the replacement of the original nameplate.

7.4 Decommissioning

When decommissioning, the requirements according to IEC 61508-1:2010 section 7.17 must be observed.

7.5 Disposal



If required by the Directive 2012/19/EU on waste electrical and electronic equipment (WEEE), the product is marked with the depicted symbol in order to minimize the disposal of WEEE as unsorted municipal waste. Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

8 Appendix

8.1 Use of the characteristic values of the diaphragm seal when specifying the safety function

8.1.1 λ_{DU}

If several components C1 to Cn are interconnected in a channel of a safety function, the failure rates are added together. In the case of diaphragm seals, this only concerns λ_{DU} , as zero is to be applied for the other failure rates.

$$\lambda_{DU} = \lambda_{DU}^{C1} + \lambda_{DU}^{C2} + \dots + \lambda_{DU}^{Cn}$$

The failure rates for the pressure or differential pressure device being used are provided in the associated Functional Safety Manual (see the "Further applicable documents" section).

Examples of failure rates

FMD77 (parameter profile B):

$$\lambda_{DU}^{CP} = 76 \text{ FIT}$$

Diaphragm seal:

$$\lambda_{DU}^{CD} = 47 \text{ FIT}$$

FMD77 (parameter profile B) with a diaphragm seal:

$$\lambda_{DU} = \lambda_{DU}^{CP} + \lambda_{DU}^{CD} \rightarrow \lambda_{DU} = 76 \text{ FIT} + 47 \text{ FIT} = 123 \text{ FIT}$$

FMD77 with two diaphragm seals:

$$\lambda_{DU} = \lambda_{DU}^{CP} + \lambda_{DU}^{CD1} + \lambda_{DU}^{CD2} \rightarrow \lambda_{DU} = 76 \text{ FIT} + 47 \text{ FIT} + 47 \text{ FIT} = 170 \text{ FIT}$$

This corresponds to a PFH value of 1.70×10^{-7} 1/h.

8.1.2 PTC values

If several components C1 to Cn with different proof test coverages are interconnected, the PTC is calculated as follows:

$$PTC = \frac{(\lambda_{DU}^{C1} \times PTC^{C1}) + (\lambda_{DU}^{C2} \times PTC^{C2}) + \dots + (\lambda_{DU}^{Cn} \times PTC^{Cn})}{\lambda_{DU}^{C1} + \lambda_{DU}^{C2} + \dots + \lambda_{DU}^{Cn}}$$

A0045741

The proof test coverages for the pressure or differential pressure device being used are provided in the associated Functional Safety Manual (see the "Further applicable documents" section), depending on the test sequence applied.

Examples of PTC values

FMD77

$$\lambda_{DU}^{CP} = 76 \text{ FIT}$$

Full test sequence (2): PTC^{CP} = 99 %

Simplified test sequence (1): PTC^{CP} = 50 %

Diaphragm seal

$$\lambda_{DU}^{CD} = 47 \text{ FIT}$$

Full test sequence (A): $PTC^{CD} = 99 \%$

Simplified test sequence (B): $PTC^{CD} = 0 \%$

$$PTC = \frac{(\lambda_{DU}^{CP} \times PTC^{CP}) + (\lambda_{DU}^{CD} \times PTC^{CD})}{\lambda_{DU}^{CP} + \lambda_{DU}^{CD}}$$

$$PTC = \frac{(76 \text{ FIT} \times 50\%) + (47 \text{ FIT} \times 0\%)}{76 \text{ FIT} + 47 \text{ FIT}} = 31\%$$

A0045742

3 Sample calculation for FMD77 with one diaphragm seal and a simplified test sequence

$$PTC = \frac{(\lambda_{DU}^{CP} \times PTC^{CP}) + (\lambda_{DU}^{CD1} \times PTC^{CD1}) + (\lambda_{DU}^{CD2} \times PTC^{CD2})}{\lambda_{DU}^{CP} + \lambda_{DU}^{CD1} + \lambda_{DU}^{CD2}}$$

$$PTC = \frac{(76 \text{ FIT} \times 99\%) + (47 \text{ FIT} \times 99\%) + (47 \text{ FIT} \times 99\%)}{76 \text{ FIT} + 47 \text{ FIT} + 47 \text{ FIT}} = 99\%$$

A0045743

4 Sample calculation for FMD77 with two diaphragm seals and a full test sequence

8.2 Version history

FY01038P; Version 02.23

- Firmware version: diaphragm seals do not have firmware
- Hardware version: indicated in the Functional Safety Manual for the basic unit
- Changes:
 - FIT value adjustment
 - New declaration of conformity

FY01038P; Version 01.21

- Firmware version: diaphragm seals do not have firmware
- Hardware version: indicated in the Functional Safety Manual for the basic unit
- Changes:
 - First version



71611015

www.addresses.endress.com
