


Operating Instructions

NAR300 system for high temperature

Oil leak detector float sensor





A0023555

Table of contents

1	Document information	4	9	Repair	42
1.1	Document function	4	9.1	General information on repairs	42
1.2	Symbols used	4	9.2	Spare parts	42
1.3	Documentation	6	9.3	Endress+Hauser services	42
2	Basic safety instructions	7	9.4	Return	43
2.1	Requirements for personnel	7	9.5	Disposal	43
2.2	Designated use	7	10	Accessories	44
2.3	Workplace safety	7	10.1	Float guide	44
2.4	Operational safety	8	10.2	U-bolt / cable gland (waterproof connection for JPNEx)	45
2.5	Product safety	8	Index		46
3	Product description	9			
3.1	Product design	9			
3.2	Technical data	9			
3.3	Process conditions	11			
3.4	Delivery example by order code	12			
3.5	Detection sensitivity	14			
3.6	Pit water	14			
4	Incoming acceptance and product identification	15			
4.1	Incoming acceptance	15			
4.2	Product identification	15			
4.3	Manufacturer address	19			
4.4	Storage and transport	19			
5	Installation	20			
5.1	NAR300 system dimensions	20			
5.2	Installation conditions	24			
5.3	Mounting NAR300 system	26			
5.4	Adjustment	30			
6	Electrical connection	31			
6.1	NRR262-4/A/B/C wiring	31			
6.2	NRR261-5 wiring	33			
6.3	Wiring diagram	35			
6.4	Operating principles of alarm activation	36			
7	Troubleshooting	37			
7.1	Fail-safe (alarm is output when there is no oil leak)	37			
7.2	Delayed alarm (alarm is not output when there is an oil leak)	37			
7.3	Operation check	38			
7.4	Firmware history	40			
8	Maintenance	41			
8.1	Maintenance work	41			
8.2	Endress+Hauser services	41			

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.



This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.



This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols



Alternating current



Direct current and alternating current



Direct current



Ground connection

A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.

Protective earth (PE)

Ground terminals that must be connected to ground prior to establishing any other connections.

The ground terminals are located on the interior and exterior of the device:

- Interior ground terminal: protective earth is connected to the mains supply.
- Exterior ground terminal: device is connected to the plant grounding system.

1.2.3 Tool symbols



Phillips head screwdriver



Flat blade screwdriver



Torx screwdriver



Allen key



Open-ended wrench

1.2.4 Symbols for certain types of information and graphics



Permitted

Procedures, processes or actions that are permitted



Preferred

Procedures, processes or actions that are preferred



Forbidden

Procedures, processes or actions that are forbidden



Tip

Indicates additional information




Reference to documentation



Reference to graphic



Notice or individual step to be observed



1., 2., 3.

Series of steps



Result of a step



Visual inspection



Operation via operating tool



Write-protected parameter

1, 2, 3, ...

Item numbers

A, B, C, ...

Views



Safety instructions

Observe the safety instructions contained in the associated Operating Instructions



Temperature resistance of the connection cables

Specifies the minimum value of the temperature resistance of the connection cables

1.3 Documentation

The following documents can be found in the Download area of our website (www.endress.com/downloads).



For an overview of the scope of the associated Technical Documentation, refer to the following:

W@M Device Viewer (www.endress.com/deviceviewer): Enter the serial number from nameplate

1.3.1 Technical Information (TI)

Planning aid

The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.

1.3.2 Brief Operating Instructions (KA)

Guide that takes you quickly to the 1st measured value

The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.3 Operating Instructions (BA)

The Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.3.4 Safety Instructions (XA)

Depending on the approval, the following Safety Instructions (XA) are supplied with the device. They are an integral part of the Operating Instructions.



The nameplate indicates the Safety Instructions (XA) that are relevant to the device.

2 Basic safety instructions

2.1 Requirements for personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Be specialists who are trained and have a relevant qualification for this specific function and task.
- ▶ Be authorized by the plant owner-operator.
- ▶ Be familiar with local/national regulations.
- ▶ Before starting work, read and understand the instructions in the Operating Instructions and supplementary documentation as well as the certificates (depending on the application).
- ▶ Follow instructions and comply with basic conditions.

The operating personnel must fulfill the following requirements:

- ▶ Be instructed and authorized according to the requirements of the task by the facility's owner-operator.
- ▶ Follow the instructions in this manual.

2.2 Designated use

Application and measured materials

Depending on the version ordered, the device can also be used with potentially explosive, flammable, poisonous or oxidizing materials.

Devices that are used in hazardous areas have corresponding labels on their nameplates.

To ensure that the device remains in proper condition for the operation time:

- ▶ Only use the device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Check the nameplate to verify if the device can be put to its intended use in hazardous areas.
- ▶ If the device is not operated at an atmospheric temperature, compliance with the relevant basic conditions specified in the relevant device documentation is absolutely essential.
- ▶ Protect the device permanently against corrosion from environmental influences.
- ▶ Observe the limit values in the "Technical Information".

The manufacturer is not liable for damage caused by improper or non-designated use.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to local/national regulations.

2.4 Operational safety

Risk of injury!

- ▶ Operate the device in proper technical conditions and fail-safe conditions only.
- ▶ The plant owner-operator is responsible for interference-free operation of the device.

Modifications to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers:

- ▶ If modifications are nevertheless required, contact your Endress+Hauser Sales Center.

Repair

To ensure continued operational safety and reliability:

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe local/national regulations pertaining to repair of an electrical device.
- ▶ Use only original spare parts and accessories from Endress+Hauser.

Ex-area

Observe the following notes to eliminate the risk of danger to persons or the facility when the device is used in Ex-areas (e.g. explosion protection, pressure equipment safety):

- ▶ Check the model nameplate to ensure that the ordered device is explosion proof.
- ▶ Observe the specifications in the separate supplementary documentation attached to these Instructions.

2.5 Product safety

This device was designed in accordance with GEP (Good Engineering Practice) to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. It meets the general safety standards and legal requirements.

3 Product description

The NAR300 system is installed in an oil-retaining wall in a tank or in a sump pit near a plant or a pump yard, and it provides the ultimate leak detection function for oils, such as petrochemicals and vegetable oils. A sensor with a conductive detection function is used to monitor the detection conditions. A two-stage alarm logic allows for an extremely low false-positive alert, ensuring the safety of the tank yard with a precise and simple device configuration.

NOTICE


TIIS specifications

These operating instructions are not intended for products with TIIS specifications.

- If you are using a product with TIIS specifications, download and refer to BA00403G/JA/23.22-00 or an earlier version from our website (www.endress.com/downloads).

3.1 Product design

The NAR300 system is configured mainly in combination with the following products.



1 NAR300 product design

- 1 Float sensor NAR300
- 2 Ex d [ia] Converter NRR261
- 3 Ex [ia] Converter NRR262
- 4 Ex [ia] sensor I/F Ex box

3.2 Technical data

3.2.1 Float sensor NAR300

Item	Description
Protection class	IP67 (outdoor installation)
Power supply	Supplied by a sensor I/F Ex box or NRR261 (NAR300 sensor I/F Ex box, integrated type)
Wetted material	Float: SUS316L, conductivity sensor: SUS316 and PTFE
Detection sensitivity ¹⁾	Water-filled pit: 10 ± 1 mm (0.04 in) with kerosene at the time of shipment from the factory
I/O cable	Dedicated shielded cable (PVC) as well as with cable float (Standard 6 m (19.69 ft))
Weight	Approx. 2.5 kg (5.5 lb) (including the dedicated shielded cable (PVC) 6 m (19.69 ft))

1) Adjusted with oil (kerosene: approx. density: 0.8), lower-layer water (water: approx. density: 1.0), static level condition and/or without surface tension.

3.2.2 Ex [ia] sensor I/F Ex box

Item	Description
Protection class	IP67 (outdoor installation)
Power supply	Supplied by NRR261 or NRR262
Cable entry	<ul style="list-style-type: none"> ■ NAR300 (float sensor) side: G1/2, with cable gland ■ NRR261 or NRR262 (converter) side: G1/2, NPT1/2, M20
Weight	3.2 kg (7.1 lb)
Materials	Housing/cover: Aluminum casting

3.2.3 Ex d [ia] Converter NRR261

Item	Description
Protection class	IP67 (outdoor installation)
Permissible power-supply voltage range	<ul style="list-style-type: none"> ■ AC power supply: 90 to 250 V_{AC}, 50/60 Hz ■ DC power supply: 22 to 26 V_{DC} (built-in power supply arrester)
Maximum power consumption	<ul style="list-style-type: none"> ■ AC power supply: 20 VA ■ DC power supply: 2 W
Output	<ul style="list-style-type: none"> ■ Contact output: 1SPDT ■ Maximum contact rating: 250 V_{AC}, 1 A, 100 VA or 100 V_{DC}: 1 A, 25 W ■ Fail-safe function: Activated when the power is turned off and under frozen conditions (refer to "Alarm output table")
Cable entry	<ul style="list-style-type: none"> ■ G3/4 x2 (Ex d), G1/2 x1 (Ex ia) ■ G1/2 x2 (Ex d), G1/2 x1 (Ex ia) ■ NPT3/4 x2 (Ex d), NPT1/2 x1 (Ex ia) ■ NPT1/2 x2 (Ex d), NPT1/2 x1 (Ex ia) ■ M25 x2 (Ex d), M20 x1 (Ex ia) ■ M20 (Ex d), M20 x1 (Ex ia) ■ JPNEx explosion-proof specifications are equipped with cable gland model SFLU
Lightning arrester	Built-in (power supply arrester)
Weight	Approx. 10 kg (22 lb)
Materials	Housing/cover: Aluminum casting

3.2.4 Ex [ia] Converter NRR262

Item	Description
Protection class	IP20 (indoor installation), installed in non-hazardous locations
Permissible power-supply voltage range	<ul style="list-style-type: none"> ■ AC power supply: 90 to 250 V_{AC}, 50/60 Hz ■ DC power supply: 22 to 26 V_{DC} (built-in power supply arrester)
Maximum power consumption	<ul style="list-style-type: none"> ■ AC power supply: 20 VA ■ DC power supply: 2 W
Output	<ul style="list-style-type: none"> ■ Contact output: 1SPDT ■ Maximum contact rating: 250 V_{AC}, 1 A, 100 VA or 100 V_{DC}: 1 A, 25 W ■ Fail-safe function: Activated when the power is turned off and under frozen conditions (refer to "Alarm output table")
Lightning arrester	Built-in (power supply arrester)
Weight	Approx. 0.6 kg (1.3 lb)
Materials	Housing: Plastic

3.3 Process conditions

3.3.1 Float sensor NAR300 / sensor I/F Ex box

Item	Description
Requirements for substance detection	<ul style="list-style-type: none"> ▪ Density is at least 0.7 g/cm³ but less than 1.0 g/cm³ ▪ Floats in water (if the density is 0.9 g/cm³ or higher, the viscosity must be at least 1 mPa·s. Water ≈ 1 mPa·s) ▪ Water-insoluble ▪ Non-conductive ▪ Liquid ▪ Low affinity with water (a layer of the substance must be formed on the water)
Operating temperature	<ul style="list-style-type: none"> ▪ Ambient temperature: -20 to 100 °C (-4 to 212 °F) ▪ Measured liquid temperature: 0 to 100 °C (32 to 212 °F)
Requirements for pit water	<ul style="list-style-type: none"> ▪ Density is at least 1.0 g/cm³ but less than 1.13 g/cm³ (only if the kinematic viscosity is 1 mm²/sec) ¹⁾ ▪ Not frozen ▪ Conductivity is at least 10 µS/cm (not more than 100 kΩ·cm) ▪ Cannot be used at sea level or in locations that may be penetrated by seawater
Other	<ul style="list-style-type: none"> ▪ Promptly remove any debris that adheres to the sensor unit. ▪ Ensure that there is no caked-on mud (dried solids), etc. ▪ Avoid installation conditions that cause the float sensor to tilt off-balance or change the draft line. ▪ Install measures, such as a breakwater, to avoid cross-currents and waves.



- 1) Sensitivity will vary with the specific gravity of lower-layer water that differs from the factory-setting environment, such as when an antifreeze is used.


3.3.2 Connecting cable (connection to Converter NRR261/262 from sensor I/F Ex box)

Item	Description
Connecting cables	<p>Maximum inductance: 2.3 mH, maximum capacitance: 83 nF Example: Use of KPEV-S (instrumentation cable) $C = 65 \text{ nF/Km}$, $L = 0.65 \text{ mH/km}$ $CW/C = 0.083 \text{ µF} / 65 \text{ nF} = 1.276 \text{ km} \dots 1$ $LW/L = 2.3 \text{ mH} / 0.65 \text{ mH} = 3.538 \text{ km} \dots 2$ Maximum extended cable length: 1.27 km The smaller of 1 or 2 is the maximum cable length (round down instead of rounding off)</p>
Operating temperature	-20 to 60 °C (-4 to 140 °F)



3.4 Delivery example by order code


Delivery example 1

Float sensor order code	Converter order code
NAR300- * 6 * * 2 / 3 *	NRR262
<div></div> <div><div>1 <i>Float sensor</i></div><div>2 <i>Float guide (bar) packaged separately</i></div><div>3 <i>Weight (packed at the bottom of the box with the converter)</i></div><div>4 <i>U-bolt</i></div><div>5 <i>Sensor I/F Ex box</i></div><div>6 <i>Check tool (accessory)</i></div></div>	<div></div>

- 
- The sensor I/F Ex box is included in the order code NAR300-x6xxxx. The intrinsically safe system is used in combination with NRR262.
 - A cable gland (water-proof connection) is only included with the sensor I/F Ex box or NRR261 with JPNEx specifications.

Delivery example 2

Float sensor order code	Converter order code
NAR300- * 6* * 2 / 3*	NRR261- 5**
<div></div> <div><p>1 Float sensor</p><p>2 Float guide (bar) packaged separately</p><p>3 Weight (packed at the bottom of the box with the converter)</p><p>4 U-bolt</p><p>5 Sensor I/F Ex box</p><p>6 Check tool (accessory)</p></div>	<div></div> <div><p>1 NRR261</p><p>2 U-bolt</p></div>

- 
- The sensor I/F Ex box is included in the order code NAR300-x6xxxx. The pressure-resistant, intrinsically safe system is used in combination with NRR261- 5**.
 - A cable gland (water-proof connection) is only included with the sensor I/F Ex box or NRR261 with JPNEx specifications.

3.5 Detection sensitivity

If the electrode tip is pulled out of the lower-layer water due to increased thickness of the oil layer, water may cling onto the electrode tip like an icicle even if the electrode tip is in oil. In this case, detection sensitivity may increase by 1 to 2 mm (0.04 to 0.08 in). When an accurate detection check is required, apply a small amount of neutral detergent to the electrode tip to keep water from clinging to the electrode.

3.6 Pit water

The high-temperature specification is exclusively for applications in which there is always water in the pit.

3.6.1 Do not use in sea water

The oil leak detector is not designed for use in sea water. The following problems may occur if it is used in sea water:

- Failed or delayed alarm when overturned by waves
- Delayed alarm caused by generation of a bypass circuit between the conductivity sensor and the float itself due to salt coating
- Corrosion of the float sensor caused by sea water

3.6.2 Special pit water

- If the float sensor is used in certain special pit water, such as pit water containing solvents, it may become corroded or damaged.
- It cannot measure highly hydrophilic liquids, such as alcohol.

3.6.3 Pit water with high electrical resistance

Use in pit water with high electrical resistance, such as in a steam drain and pure water, may activate the alarm. Ensure that the conductivity of pit water is at least 10 $\mu\text{S}/\text{cm}$ (not more than 100 $\text{k}\Omega \cdot \text{cm}$).

Example, pure water: 1 to 0.1 $\mu\text{S}/\text{cm}$ (1 to 10 $\text{M}\Omega \cdot \text{cm}$)

3.6.4 Frozen pit water


If ice forms in the pit, the alarm may be triggered (fail-safe function). Implement anti-freeze measures to prevent freezing.

4 Incoming acceptance and product identification

4.1 Incoming acceptance

Upon receipt of the goods, check the following:

- Are the order codes on the delivery note and the product label identical?
- Are the goods undamaged?
- Do the nameplate data match the ordering information on the delivery note?
- If required (see nameplate): Are the Safety Instructions (XA) enclosed?

 If one or more of these conditions are not satisfied, contact your Endress+Hauser Sales Center or distributor.


4.2 Product identification

The following options are available for identification of the device:

- Nameplate specifications
- Extended order code on the delivery note (including details of the device specification codes)
- Entering the serial number from the nameplate in *W@M Device Viewer* (www.endress.com/deviceviewer) will display all the information about the device.

 Note that the information on a nameplate may be changed without warning when credentials and certificates are updated.


4.2.1 Nameplate specifications



 2 NAR300 model nameplate


- 1 Order code
- 2 Serial number
- 3 Cable length (order code 040)
- 4 Explosion-proof performance (except TIIS specification)

A0038619



3 Nameplate for NAR300


- A NAR300 for FM
- B NAR300 nameplate for ATEX / IECEx
- 1 Order code
- 2 Serial number



A0039864


 4 Nameplate for NRR262

- A NRR262 nameplate for FM
B NRR262 nameplate for ATEX / IECEx
1 Order code
2 Serial number
3 Power supply voltage
4 Manufacturing date



5 Nameplate for JPN Ex

- A NAR300 nameplate for JPN Ex
- B NRR261 nameplate for JPN Ex (NAR300 separate type)
- 1 Order code
- 2 Serial number
- 3 Power supply voltage
- 4 Manufacturing date



6 NRR262 nameplate for JPN Ex

- 1 Order code
- 2 Serial number
- 3 Power supply voltage
- 4 Manufacturing date

4.3 Manufacturer address

Endress+Hauser Yamanashi Co., Ltd.
406-0846
862-1 Mitsukunugi, Sakaigawa-cho, Fuefuki-shi, Yamanashi

4.4 Storage and transport

4.4.1 Storage conditions

- Storage temperature: -20 to +60 °C (-4 to 140 °F)
- Store the device in its original packaging.

4.4.2 Transport

NOTICE

The housing may become damaged or dislodged.


Risk of injury

- ▶ When transporting the device to the measuring point, either use the device's original packaging or hold by the process connector.
- ▶ Secure a hoisting device (such as a hoisting ring or a lifting eye bolt) to the process connector, not to the housing. Pay attention to the device's center of gravity to prevent unexpected tilting.
- ▶ Comply with the safety precautions and transportation conditions for devices that weigh 18 kg (39.6 lbs) or more (IEC61010).

5 Installation

5.1 NAR300 system dimensions

5.1.1 Dimensions of NAR300 float sensor



A0039905

7 Float sensor NAR300 dimensions


1 Float sensor cover

5.1.2 Dimensions of Ex d [ia] converter NRR261

Only NRR261 with JPN Ex explosion-proof specifications are delivered with a cable gland (external diameter of compatible cables: $\phi 12$ to 16 mm (0.47 to 1.02 in)).

Use the order code of Ex d [ia] converter NRR261 to specify the conduit connection port.

Ex d [ia] converter NRR261 is usually mounted onto a pipe in a tank yard with a U bolt (JIS F 3022 B 50 type). It can also be mounted directly onto walls (requires 4 $\phi 12$ mm (0.47 in) holes, M10 securing bolts and nuts (sold separately)).




A0039880

8 NRR261 dimensions. Unit of measurement mm (in)

- 1 Ex d side terminal
- 2 Ex [ia] side terminal
- 3 U bolt (JIS F3022 B50 material: iron (chromate), 2 nut and 2 flat washer included)
- 4 4 $\phi 12$ hole
- L G1/2: 85 mm (3.35 in), NPT1/2: 97 mm (3.82 in), M20: 107 mm (4.21 in)

5.1.3 Dimensions of Ex [ia] converter NRR262

NRR262 is designed for indoor installation, such as in an instrument room, and it can be mounted easily with two M4 screws. It can also be snapped into place with just one touch using DIN rail EN50022 (sold separately). This rail mounting method is convenient for mounting multiple converters in a row or when additional converters are scheduled to be installed in the future.




A0039884

9 NRR262 dimensions. Unit of measurement mm (in)

- 1 Screw (M4) for protective grounding
- 2 Delay trimmer
- 3 Screw (M3)
- 4 Screw (M4)
- 5 DIN rail: complies with EN50022

5.1.4 Dimensions of Ex [ia] sensor I/F Ex box

Ex [ia] sensor I/F Ex box is used in combination with Ex [d] ia converter NRR261 or Ex [ia] converter NRR262 to convert signals from the float sensor into current signals. Ex [ia] sensor I/F Ex box is usually mounted onto a pipe in a tank yard with a U bolt (JIS F 3022 B 50 type). It can also be mounted directly onto walls (requires 4 $\phi 12$ mm (0.47 in) holes, M10 securing bolts and nuts (sold separately)).



10 Ex [ia] sensor I/F Ex box dimensions. Unit of measurement mm (in)


L1 G1/2 / NPT1/2: 85 mm (3.35 in), M25: 107 mm (4.21 in)

1 U bolt (JIS F3022 B50 material: iron (chromate), 2 nut and 2 flat washer included)

2 4 $\phi 12$ mm (0.47 in) hole

i Use the order code of float sensor NAR300 to specify the conduit connection port.

5.2 Installation conditions



A0039906

11 NAR300 + NRR26x

- a Alarm output*
- 1 Tank*
- 2 Junction box*
- 3 Divider*
- 4 U-shaped groove*
- 5 Screen*
- 6 Pit*
- 7 Pit cover*
- 8 Float guide*
- 9 Chain*
- 10 Weight*
- 11 Float sensor NAR300*
- 12 Discharge nozzle (100 mm (3.94 in) or longer)*
- 13 Dedicated cable (included with NAR300)*
- 14 Valve*
- 15 Drainage groove*
- 16 Ex [ia] sensor I/F Ex box*
- 17 U bolt (JIS F3022 B50)*
- 18 NRR261 (Ex d [ia] converter)*
- 19 NRR262 (Ex [ia] converter)*

i To ground the barrier, either connect it to the tank or use the shielded wire for the remote cable. Refer to "Electrical connection" for more information on using the shielded wire for the remote cable.


5.2.1 Installation and mounting precautions

1. To prevent snow and debris from entering the pit, installing a waste guard, roof or other covering is recommended. When snow accumulates on the float sensor, for each 50 g of snow accumulation, the draft line will rise 1 mm (0.04 in), which reduces the float sensor's sensitivity. The cover should be installed above the pit water inlet to prevent the float sensor's housing from becoming submerged under water when pit water overflows due to heavy rain, etc. If water enters the float sensor, it may cause a malfunction or failure.
2. If the float sensor becomes off-balance (tilted by approx. 3 ° or more), it may cause faulty operation or a delayed alarm. Use a float guide as much as possible, and also pay attention to the way cables and chains are laid out.
3. Install a screen at the pit's inlet to remove any debris. If debris or foreign matter clogs the sensor unit or inside the pit, it may cause a malfunction. Inspect and clean the screen regularly.
4. Attach a chain to the ring on the side of the float sensor head in advance for added convenience. However, each 50 g of increased load on the float will raise the draft line by 1 mm (0.04 in), resulting in reduced sensitivity. If using a chain to anchor the float, do not forcibly pull on the chain during inspection.
5. If the pit is completely filled with water, an oil layer will not form even when oil is flowing. Drain the water as needed so that an oil layer can form.
6. Do not forcibly pull or grab and carry the cable as it may cause a malfunction or compromised waterproofing.
7. Bend the tip of the discharge nozzle downward by 100 mm (3.94 in) or more when the drain valve is kept open so that an oil layer can form. Failure to do so may cause oil to discharge from the pit before it can form a detectable layer on the water surface, resulting in a delayed alarm or detection failure. For pits without a discharge nozzle, such as the one shown in the above diagram, install an oil-water separation divider so that an oil layer can form.
8. Depending on the liquid flowing into the pit, install a divider to prevent waves, crosscurrents or liquid from splashing on top of the float.
9. If the pit is too large, divide the pit using an oil separator. Oil leakage cannot be detected unless the volume of oil outflow increases in proportion to the surface area.
10. NAR300, NRR261 and sensor I/F Ex box must be installed at least 50 cm (1.64 ft) apart from each other.

5.3 Mounting NAR300 system

5.3.1 Handling precautions

When transporting NAR300, be sure to hold the float with both hands. Avoid holding the parts shown in the diagram below, and do not lift NAR300 by the top of the float sensor. In addition, do not rotate the housing. Doing so may cause device failure.




A0048026

12 Handling NAR300

5.3.2 Mounting the float guide

NAR300 can be mounted onto a float guide that has been installed for existing products (CFD10, CFD30, UFD10, NAR291, NAR292).

If the float guide is shorter than 2 000 mm (78.74 in), either cut and use it or follow the protocol for when it is 2 000 mm (78.74 in) or longer and contact your nearest Endress+Hauser Sales Center or distributor.



13 NAR300, float guide

- 1 Nut (M10)
- 2 Float guide
- 3 Weight


i The 20 mm (0.73 in) and 40 mm (1.57 in) of the float guide in the diagram indicate the lengths of thread grooves.

5.3.3 NAR300-x6xxxx and sensor I/F Ex box cable mounting

Mounting process

1. Remove the intrinsically safe terminal box cover [5] and the circuit board guard [4].
2. Pass the float sensor cable [2] through the cable gland [1] and the cable entry of the intrinsically safe terminal box.
3. Connect the cable to the terminal block (refer to Electrical connection).
4. Tighten the main unit of the cable gland [1] and the seal nut.
↳ Tightening torque (main unit, seal nut): approx. 1.96 N·m (20 kgf·cm)
5. Pass the connecting cable for NRR262/NRR261 through the cable entry of the terminal box, and connect it to the terminal block.
6. Secure the cable in place with the cable holder [3].
7. Attach the circuit board guard, and close the cover of the intrinsically safe terminal box.

This completes the mounting process.



14 NAR300-x6xxxx and sensor I/F Ex box cable mounting

- a Cable gland (must be procured separately)
- b Shielded cable for NRR261/262 (must be procured separately)
- 1 Cable gland mounting example
- 2 Float sensor cable
- 3 Cable holder
- 4 Circuit board guard
- 5 Intrinsically safe terminal box cover
- 6 Shielded cable screw (M3)
- 7 Screw (M5)
- 8 Shielded cable gland


i Since the cable gland a shown in the diagram is not supplied with products that do not have JPN Ex specifications, a water-proof cable gland that is IP67 or higher must be procured separately.

5.3.4 NRR261-5xx cable mounting

Mounting process

1. Remove the intrinsically safe terminal box cover [4] and the terminal block cover [3].
2. Pass the float sensor cable [2] through the cable gland [1] and the cable entry of the intrinsically safe terminal box.
3. Connect the cable to the terminal block (refer to Electrical connection).
4. Mount the cable gland [1] according to the operating instructions.
5. Secure the cable in place with the cable holder.
6. Attach the terminal block cover, and close the cover of the intrinsically safe terminal box.

This completes the mounting process.



A00399883

15 NRR261-5xx cable mounting

- 1 Cable gland mounting example
- 2 Float sensor cable
- 3 Terminal block cover
- 4 Intrinsically safe terminal box cover
- 5 Cable gland (Ex d) (supplied with JPN Ex specifications only)



Since the cable gland [1] shown in the diagram is not supplied with products that do not have JPN Ex specifications, a water-proof cable gland that is IP67 or higher must be procured separately.

5.4 Adjustment

5.4.1 Verification of detection sensitivity with actual liquid

Verification of detection sensitivity with water in the bottom layer and oil in the top layer


When the tip of an electrode is pulled out from the water in the bottom layer, water may cling to the electrode tip like an icicle even when it is in the oil layer due to increased thickness of the oil layer, and this will increase the detection sensitivity by 1 to 2 mm. If accurate sensitivity verification is required, apply a small amount of neutral detergent to the electrode tip to improve water release.


Verification of oil layer thickness with a transparent container

Be cautious, as liquid surface tension and the adhesion of liquid onto the container wall may cause reading errors.


5.4.2 Alarm output adjustment

Only the delay operation time (ON delay) setting of the alarm output relay can be adjusted on the converter. Time can be set using the delay trimmer. In NRR261, the delay trimmer can be found by turning off the power supply and opening the main unit's cover. In NRR262, the delay trimmer is found on the case surface. Match the setting to the necessary delay time in units of seconds. Delay operation is used to prevent false alarms by activating the alarm when an alarm state persists continuously over a certain period of time and not activating the alarm for operation that occurs within the set delay time. This can be set up to a maximum of 15 seconds for SIL specifications.

-  A response delay time of approximately 6 seconds on the detection circuit is always added to the delay time of the delay trimmer.
- When opening the main unit cover of NRR261, ensure that at least 10 minutes have passed after the power supply was cut.




A0039891

 16 Alarm output relay

- 1 Delay trimmer
- 2 Cover
- 3 LED power (green), alarm (red)

6 Electrical connection

6.1 NRR262-4/A/B/C wiring



A0039908

17 Wiring of Ex [ia] Converter NRR262-4/A/B/C

- A Float sensor NAR300-x6xxxx (sensor I/F Ex box is also included in the code)
- B Sensor I/F Ex box
- C Ex [ia] Converter NRR262
- a Green, screw (M3) (see 1 below)
- b Output to NRR262, screw (M3)
- c Yellow, screw (M3)
- d Black, screw (M3)
- e White, screw (M3)
- f Input from sensor I/F Ex box, screw (M3)
- g 90 to 250 V_{AC} 50/60 Hz, screw (M3)
- h Alarm output, screw (M3)
- i Check monitor output, screw (M3)


- 1 *Ex [ia]-dedicated connection cable used (6 to 30 m (19.69 to 98.43 ft): Supplied with the product depending on the option code)*
- 2 *Sensor I/F Ex box and NRR262 cable (must be procured by the customer)*
- 3 *For protective grounding, screw (M4)*



Below, the numbers correspond to the description in the diagram.

1. Normally, only the FG of a sensor I/F Ex box is shielded; however, depending on the installation environment, either the GND of NRR262 alone or both the FG of the sensor I/F Ex box and the GND of NRR262 are connected.
2. When the power supply is 22 to 26 V_{DC}, terminal number L is + (plus) and N is - (minus).
3. In order to maintain the Ex [ia] performance, ensure that the power supply voltage does not exceed 250 V_{AC} 50/60 Hz and 250 V_{DC} during normal time and abnormal time, respectively.
4. Although cable (1) that connects NAR300 and a sensor I/F Ex box is included with the device, a cable (2) that connects a sensor I/F Ex box and NRR262 is not included, and it must be procured by the customer. For detailed information on the connection cables, refer to the "Process conditions" section.

6.2 NRR261-5 wiring



A0039909

18 Wiring of Ex d [ia] Converter NRR261-5

A Float sensor NAR300-x6xxxx (sensor I/F Ex box is also included in the code)

B Sensor I/F Ex box

C Ex d [ia] Converter NRR261 (separate type)

a Green, screw (M3) (see 1 below)

b Output to NRR261-3xx, screw (M3)

c Yellow, screw (M3)

d Black, screw (M3)

e White, screw (M3)

f Blue 2, screw (M4) (connected at the time of shipping)

g Blue 3, screw (M4) (connected at the time of shipping)

h Input from sensor I/F Ex box, screw (M4)

1 Ex [ia]-dedicated connection cable used (6 to 30 m (19.69 to 98.43 ft)): Supplied with the product depending on the option code)

2 Sensor I/F Ex box and NRR261 cable (must be procured by the customer)

3 Power supply: AC/DC

4 Alarm output: Alarm/PLC/DCS, etc.


- 5 *Ex d terminal*
- 6 *Intrinsically safe terminal*
- 7 *Power supply arrester (installed), screw (M3)*



Below, the numbers correspond to the description in the diagram.

1. Normally, only the FG of a sensor I/F Ex box is shielded; however, depending on the installation environment, either the GND of NRR262 alone or both the FG of the sensor I/F Ex box and the GND of NRR262 are connected.
2. It is connected when an FG-equipped AC cable is used.
3. When the power supply is 22 to 26 V_{DC}, terminal number L is + (plus) and N is - (minus).
4. In order to maintain the Ex [ia] performance, ensure that the power supply voltage does not exceed 250 V_{AC} 50/60 Hz and 250 V_{DC} during normal time and abnormal time, respectively.
5. The cable for connecting NAR300 and the sensor I/F Ex box (1) is included with NAR300. The cable (5) connecting the sensor I/F Ex box to the NRR261, the alarm output cable (2) from the NRR261, as well as the power cable (3) to the NRR261 are not included and must be procured by the customer. For detailed information on the connection cables, refer to the "Process conditions" section.

6.3 Wiring diagram



A0039910

19 Wiring diagram

- A Ex d-type converter system (integrated type)
- B Intrinsically safe-type converter system (separate type)
- PE Protection earth (protective grounding)
- 1 Conductivity detection electrode (sensor)
- 2 Conductivity detection electrode (float)
- 3 Dedicated cable
- 4 Conductivity detection circuit
- 5 Current output circuit
- 6 Sensor I/F Ex box
- 7 Current signal
- 8 Safety barrier
- 9 Power supply circuit
- 10 Current detection
- 11 Relay
- 12 Delay circuit
- 13 Converter NRR262
- 14 Delay trimmer
- 15 Alarm
- 16 Converter NRR261 (separate type)

6.4 Operating principles of alarm activation

The oil leak detection signal detected by the NAR300 float sensor is converted to a current signal in the converter or the sensor I/F Ex box. After this, it is connected to the current detection circuit via the Ex [ia] safety barrier in the converter. In the current detection circuit, the presence or absence of an oil leak alarm signal is determined by the magnitude of electrical current values, and the alarm output relay is turned on or off by the operation delay circuit. The delay time can be set, and there is a trimmer for setting the delay time in the alarm delay circuit. A fail-safe function is available in the relay contact output (refer to the "Alarm output table" below).

Alarm output table

NRR261/NRR262 terminals		Between NC and COM	Between NO and COM
Condition	Non-alarm	Contact point is open	Contact point is closed
	Oil leak alarm	Contact point is closed	Contact point is open
	Power OFF		
	Frozen liquid		



The high-temperature sensor is exclusively for use in the presence of water; an alarm will be activated in an empty pit.

NAR300 current value	
Non-alarm	12 mA
Oil leak alarm	16 mA
Other trouble	< 10 mA or 14 mA <

7 Troubleshooting

7.1 Fail-safe (alarm is output when there is no oil leak)

There is a risk of an alarm being output due to the following causes even if there is no actual oil leak.

Item	Description
Frozen pit water	An alarm is activated when the pit water freezes and the conductivity sensor recognizes it as an insulator.
Tilted float sensor	When the conductivity sensor is tilted so much that it is no longer submerged in water while it is floating on pit water, an alarm is activated because it recognizes insulating air.
Empty pit	An alarm will always be activated in an empty pit.
Sensor buried in mud	When the float sensor becomes buried in mud and the mud dries out and hardens, an alarm is activated.
Essentially pure water in pit	In pit water with a large electrical resistance value, such as drain water, the conductivity sensor detects it as an insulator, thereby activating an alarm.


7.2 Delayed alarm (alarm is not output when there is an oil leak)

There is a risk of an alarm not being output due to the following causes even if there is an oil leak.

Item	Description
Waves and cross-currents on the liquid surface	If the oil layer and the pit water are not stable due to strong waves on the surface of leaked oil caused by wind, etc., the conductivity sensor will detect the pit water and therefore will not activate the alarm.
Tilted float sensor	When the float sensor tilts most of the way to one side due to snow, an animal on the float sensor, or a cable/chain becoming tangled, the conductivity sensor detects the pit water under the oil layer and therefore will not activate the alarm.
Sunk float sensor	If snow, garbage or an animal lands on the float, the float will sink and the conductivity sensor will detect the pit water under the oil layer, and no alarm will be activated.
Moist garbage, etc.	If moist garbage or algae comes in contact between the conductivity sensor and the earth (such as the float body or the ground) and generates conductivity, an alarm will not be activated.
Oil leak during snowfall	If there is snow floating on the oil layer surface, the water from melted snow will be recognized as water by the conductivity sensor, and an alarm will not be activated.
Oil leak during snowfall	If there is snow floating on the oil layer surface, the water from melted snow will be recognized as water by the conductivity sensor, and an alarm will not be activated.


7.3 Operation check

7.3.1 Operation check flowchart



A0048099

Prior to performing an alarm operation check, take preemptive measures to ensure that the alarm system will not be impacted even if an oil leak alarm is activated. See the previous section "Operation check flowchart" for how to perform an operation check. The following diagram shows the voltage check point that was described in the flowchart.



A0039874

20 Intrinsically safe terminal box

A Sensor I/F Ex box
H- Blue
H+ Blue

7.3.2 Converter / alarm system problems

Item	Description
LED is lit red: Normal alarm activation	An alarm is activated even if the sensor voltage has not been detected. Replace the converter if there is no problem with the wiring between the converter and the sensor I/F Ex box.
LED is lit green: There is no alarm signal from the sensor	If an alarm has been activated under this condition, investigate the resistance values of the converter's alarm output terminal in the following order: <ol style="list-style-type: none">1. Turn off the power supply to the alarm activation system.2. Disconnect the alarm output wire from the converter.3. Check to ensure that the LED is continuously lit green.4. Measure the resistance between 1: COM and NO and 2: COM and NC. The converter is normal if 1: 0Ω (short) and 2: several MΩ or higher (open). Otherwise, replace the converter.
LED is not lit: The converter is not turned on	If there is rated voltage between terminal L and N on the converter, replace the converter. If the voltage cannot be measured between the L and N terminals, check the power supply or the power cable.

7.3.3 **Cleaning the conductivity sensor unit**

NAR300 is usually checked for conductivity between the electrode and the float body. Conductivity indicates that there is water; non-conductivity indicates that there is oil or air in the pit. Since the electrode holder is connected to the float body, if the holder becomes conductive with the tip of the electrode, it determines that "water" is present, thereby preventing the alarm from being activated and causing erroneous operation. Clean the space between the tip of the electrode and the holder periodically to maintain non-conductivity.


Items to prepare

- Rag
- Neutral detergent

Cleaning procedure

1. Remove the NAR300 sensor from the pit.
2. Clean conductivity sensor components from electrode tip to electrode holder with a rag to remove any moss, algae or dust.
3. Clean the entire electrode using a neutral detergent that has been diluted to a suitable concentration.

This completes the cleaning procedure.



A0039904

21 *Sensor cleaning*

- 1 *Electrode holder*
- 2 *Electrode tip*

7.4 **Firmware history**

Date	Software version	Changes	Documentation		
			Specifications	Operating instructions	Technical information
11.2003	V1.40	Initial software	Standard	BA027N/08/ja/02.04	TI045N/08/ja/01.05
04.2015	V1.50	SIL2 obtained	High temperature	BA00403G08JA06.16	TI00457G08JA04.16

8 Maintenance

8.1 Maintenance work

No special maintenance work is required.

8.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

8.1.2 Periodic maintenance

While the NAR300 float sensor is not easily affected by deposits or adhered material, conduct overall periodic inspections of the cable and wiring, etc., semi-annually along with an operation check as follows.

- Inspect and clean the sensor and the pit periodically as clogging caused by debris, foreign matter and algae may result in a malfunction. To clean the float sensor, wipe it with a soft cloth that has been soaked in water.
- Remove any accumulated debris, sand or snow on the float sensor periodically as they can lower the draft position and cause changes in sensitivity.
- Check operation after ensuring that the cables are not damaged and that there are no wiring issues (loose terminal screw, etc.).

8.2 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

9 Repair

9.1 General information on repairs

9.1.1 Repair concept

The Endress+Hauser repair concept assumes that the devices have a modular design and that repairs can be done by the Endress+Hauser Service Department or specially trained customers.

Spare parts are contained in suitable kits. They also come with relevant replacement instructions.

For more information on service and spare parts, contact the Service Department at Endress+Hauser.

9.1.2 Repairs to Ex-approved devices

When carrying out repairs to Ex-approved devices, note the following:

- Repairs to Ex-approved devices may only be carried out by trained personnel or by the Endress+Hauser Service.
- Comply with the prevailing standards, national Ex-area regulations, Safety Instructions (XA) and certificates.
- Only use original spare parts from Endress+Hauser.
- When ordering a spare part, note the device designation on the nameplate. Only replace parts with identical parts.
- Carry out repairs according to the instructions. On completion of repairs, carry out the specified routine test on the device.
- Only Endress+Hauser Service may convert a certified device into a different certified variant.
- Document all repair work and conversions.

9.2 Spare parts

Some interchangeable device components are listed on an overview sign in the connection compartment cover.

The spare part overview sign contains the following information:

- A list of the most important spare parts for the device, including their ordering information
- The URL for the *W@M Device Viewer* (www.endress.com/deviceviewer):
All the spare parts for the device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

9.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

9.4 Return

The requirements for safe device return can vary depending on the device type and national legislation.

1. Refer to the website for more information:
<http://www.endress.com/support/return-material>
2. Return the device if repairs or a factory calibration are required, or if the wrong device was ordered or delivered.

9.5 Disposal


Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

10 Accessories

10.1 Float guide

If you ordered a device that is equipped with a float guide, install the float horizontally. Remove any debris or stones so that the float sensor can land horizontally. The standard length of a float guide is 2 m (6.57 in); however, if you need a different length, contact your nearest Endress+Hauser Sales Center or distributor.



22 Float guide

- 1 Nut (M10)
- 2 Float guide
- 3 Weight


Name	Delivered quantity	Materials
Float guide	2	SUS304
Weight	1	Selectable as options from SS400 or SUS304
Nut (M10)	6	SUS304

i The 20 mm (0.73 in) and 40 mm (1.57 in) of the float guide in the diagram represent the lengths of thread grooves.

10.2 U-bolt / cable gland (waterproof connection for JPNEx)

The U-bolt (JIS F3022 B50) is used when mounting a converter. Have a spare 50A (2B $\phi 60.5$ mm (198.5 in)) pipe ready. Tighten and secure the cable gland after inserting the cable from NAR300.

i The pressure-resistant packing cable gland is supplied for the JPN Ex specification only. Always use this cable gland.



A0039892

- 23** U-bolt / cable gland
- 1 U-bolts (JIS F 3022 B50)
 - 2 Cable gland (waterproof connection)

Name		Delivered quantity	Materials
U-bolt		2	Iron (chromate)
U-bolt accessory	Nut	4	
	Flat washer	4	
Cable gland (waterproof connection)		1	Nylon

Index

Symbols

Application	7
Safety Instructions	
Basic	7
Operational safety	8
Measured materials	7
Declaration of Conformity	8
Maintenance	41
Requirements for personnel	7

C

CE mark	8
Cleaning	
Exterior cleaning	41

D

Designated use	7
Disposal	43
Document	
Function	4
Document function	4

E

Endress+Hauser services	
Maintenance	41
Repair	42
Exterior cleaning	41

P

Product description	9
Product design	9
Product safety	8

R

Recalibration	41
Repair concept	42
Return	43

S

Safety Instructions (XA)	6
------------------------------------	---

W

Workplace safety	7
----------------------------	---



www.addresses.endress.com
