BA02237C/07/EN/02.24-00 71673948 2024-03-31 Valid as of version 03.00.00

Operating Instructions Liquiline Control CDC90

Data transmission via analog communication 0/4 to 20 mA





Table of contents

1	About this document 4
1.1 1.2 1.3 1.4 1.5	Warnings4Symbols4Symbols on the device4Documentation4List of abbreviations5
2	Basic safety instructions
2.1 2.2 2.3 2.4 2.5 2.6	Requirements for the personnel6Intended use6Workplace safety6Operational safety6Product safety8IT security8
3	Electrical connection
3.1	Connecting the communication interfaces 9
4	System integration 10
4.1	Integrating analog communication into the system

1 About this document

1.1 Warnings

Structure of information	Meaning		
A DANGER Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) • Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation will result in a fatal or serious injury.		
WARNING Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid the dangerous situation can result in a fatal or serious injury.		
CAUTION Causes (/consequences) If necessary, Consequences of non-compliance (if applicable) Corrective action	This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or more serious injuries.		
NOTICE Cause/situation If necessary, Consequences of non-compliance (if applicable) Action/note	This symbol alerts you to situations which may result in damage to property.		

1.2 Symbols

- ✓ Permitted
- Recommended
- Not permitted or not recommended
- Reference to device documentation
- Reference to page
- Reference to graphic
- Le Result of an individual step

1.3 Symbols on the device

- ⚠—∭ Reference to device documentation
- Do not dispose of products bearing this marking as unsorted municipal waste. Instead, return them to the manufacturer for disposal under the applicable conditions.

1.4 Documentation

This supplementary documentation must be used only in conjunction with a Liquiline Control CDC90 with analog communication.

This supplementary documentation is an integral part of the Operating Instructions and provides additional information on the use of the device with analog communication.

More information can be found in the following Operating Instructions:

Operating Instructions CDC90 BA01707C

It is assumed that the reader has basic knowledge in this area.

This document is aimed at individuals who are incorporating the CDC90 into a control system via analog communication. It is assumed that the reader has basic knowledge of the CM44 transmitter.

1.5 List of abbreviations

n/a	Not applicable
NaN	Not a number (IEEE-754, 7Fh A0h 00h 00h)
ENP	Electronic name plate
I&M	Identification & Maintenance
AI	Analog Input (PA Profile function block)
DI	Discrete Input (PA Profile function block)
AO	Analog Output (PA Profile function block)
DO	Discrete Output (PA Profile function block)
DCS	Distributed control system

2 Basic safety instructions

2.1 Requirements for the personnel

- Installation, commissioning, operation and maintenance of the measuring system may be carried out only by specially trained technical personnel.
- The technical personnel must be authorized by the plant operator to carry out the specified activities.
- The electrical connection may be performed only by an electrical technician.
- The technical personnel must have read and understood these Operating Instructions and must follow the instructions contained therein.
- Faults at the measuring point may only be rectified by authorized and specially trained personnel.

Repairs not described in the Operating Instructions provided must be carried out only directly at the manufacturer's site or by the service organization.

2.2 Intended use

Liquiline Control CDC90 is a fully automatic measuring, cleaning and calibration system for Memosens sensors.

2.2.1 Non-intended use

Any use other than that intended puts the safety of people and the measuring system at risk. Therefore, any other use is not permitted.

The manufacturer is not liable for harm caused by improper or unintended use.

2.3 Workplace safety

As the user, you are responsible for complying with the following safety conditions:

- Installation guidelines
- Local standards and regulations
- Regulations for explosion protection

Electromagnetic compatibility

- The product has been tested for electromagnetic compatibility in accordance with the applicable international standards for industrial applications.
- The electromagnetic compatibility indicated applies only to a product that has been connected in accordance with these Operating Instructions.

2.4 Operational safety

Before commissioning the entire measuring point:

- 1. Verify that all connections are correct.
- 2. Ensure that electrical cables and hose connections are undamaged.
- 3. Do not operate damaged products, and protect them against unintentional operation.
- 4. Label damaged products as defective.

During operation:

 If faults cannot be rectified, take products out of service and protect them against unintentional operation.

ACAUTION

Programs not switched off during maintenance activities.

Risk of injury due to medium or cleaning agent!

- Quit any programs that are active.
- Switch to the service mode.
- If testing the cleaning function while cleaning is in progress, wear protective clothing, goggles and gloves or take other suitable measures to protect yourself.

2.5 Product safety

2.5.1 State of the art

The product is designed to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. The relevant regulations and international standards have been observed.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

3 Electrical connection

3.1 Connecting the communication interfaces

Installation and wiring is described in the Operating Instructions of Liquiline Control CDC90.

3.1.1 Notes

The device starts when the supply voltage is applied. This process can take up to two minutes, depending on the device configuration. Communication with the device is not possible during the start-up process.

3.1.2 Connection with the CDC90 control unit



- 1 Analog output in BASE2-E
- 2 Analog input 2AI
- 3 Process control system, PCS

Analog input/analog output	Use	
Current input 4:1	Internal use for softkeys*	
Current input 4:2	Can be used freely for control signals to Liquiline Control CDC90 [mA], according to parameter tables $\rightarrow {}10$	
Current output 1:1	Internal use for status LED*	
Current output 1:2	Feedback from Liquiline Control CDC90 to the control system [mA], according to parameter tables $\rightarrow \cong 10$	

* Internally used connections must not be altered, as this would compromise the functionality.

Connecting analog communication

- 1. Unscrew the housing from the CDC90 control unit. See Operating Instructions BA01707C.
- 2. Connect a 2-wire cable from the analog output AI of the control system (3) to the analog input of the 2AI module (2) in the CDC90 control unit.
- 3. Connect a 2-wire cable from the analog input AI of the control system (3) to the analog input of the BASE2-E module (1) in the CDC90 control unit.

For more details on analog input and output characteristics of the CM44x transmitter, please refer to the Operating Instructions of the CM44x (BA00451C).

4 System integration

To send commands to the Liquiline Control CDC90, the internal analog input of the CDC90 control unit is used. Conversely, the analog output of the CDC control unit is used for receiving analog feedback from the Liquiline Control CDC90.

4.1 Integrating analog communication into the system

4.1.1 Configuration in Liquiline Control CDC90

Time State 09:44:35 Good	Measuring point 1 7.34 рН	Measuring point 2 7.04рн
E Communica	ation	Maintenance 🔨
Communication		
Communication selection None EtherNet/IP Modbus/TCP	PROFIBUS Profinet Analog	DP
		Apply

To start remote control, it must be set to the **Remote access** mode. It is possible to read the parameters in any mode.

- **1.** In the Liquiline Control CDC90 menu, navigate to **Application/Communication**.
- 2. Select Analog.
- 3. Press **Accept** to confirm.

Only fieldbus communication or analog communication is used to send commands to the Liquiline Control CDC90 or to read the values.

4.1.2 Parameter tables

Input and output parameters

The following table provides an overview of the possible commands that CDC90 can receive via the analog input. Once a corresponding current signal has been sent and accepted, the CDC90 responds with the corresponding current level.

Commands [mA]	Description	Response from	CDC90 [mA]
4	No command active Do not select a program	4	No program is active No program is selected
5	Start program	5	Program is started
6	Pause program (currently not supported)	6	Program is paused (currently not supported)
7	Stop program	7	Program is stopped

Commands [mA]	Description	Response from	CDC90 [mA]
8	Not defined	8	Program is canceled
9	Not defined	9	Program is quit successfully
10	Not defined	10	CDC90 has a failure alarm
11	Select program 801	11	Program 801 is selected
12	Select program 802	12	Program 802 is selected
13	Select program 803	13	Program 803 is selected
14	Select program 804	14	Program 804 is selected
15	Select program 805	15	Program 805 is selected
16	Select program 806	16	Program 806 is selected
17	Select program 807	17	Program 807 is selected
18	Select program 808	18	Program 808 is selected
19	Select program 809	19	Program 809 is selected
20	Select program 810	20	Program 810 is selected

i

With analog communication, the programs 801 to 810 can be controlled.

Program control

For an overview of the preconfigured cleaning and calibration programs, see the Liquiline Control CDC90 BA01707C operating instructions.



■ 1 Overview of programs (20 programs are displayed).

The program IDs can be found in the local display under menu: **User Guidance**/**Programs**.

Each program must be selected before starting. An example of controlling program 801:

1. Set AI to 4 mA.

└ Initialization in progress.

2. Wait for confirmation AO equal to 4 mA.

3. Set AI to 11 mA.

- └ Program selection in progress.
- 4. Wait for confirmation AO equal to 11 mA.

5. Set AI to 5 mA.

← Program starts.

After the program starts, the analog output outputs 5 mA as long as the program is running. When the program is finished, the analog output outputs 9 mA.

With short programs (e.g. valve travel), the AO may output 9mA.

After quitting a program successfully, a new program can be selected and started immediately.

If the program is stopped or is aborted due to an error:

1. First initialize the system by sending 4 mA.

2. Select and start a new program.

Diagnostics

Diagnostic via digital inputs 11-16:

DO	Description	Assignment
11	Operating mode	Setting, if DO11 = 0 and DO12 = 0
12		Manual, if $DO11 = 1$ and $DO12 = 0$ Automatic, $DO11 = 0$ and $DO12 = 1$ Remote access, $DO11 = 1$ and $DO12 = 1$
13	Assembly 1	0 = service, 1 = measure
14	Assembly 2	0 = service, 1 = measure
15	Program	0 = no program, 1 = program active
16	Alarm	0 = alarm, 1 = no alarm



www.addresses.endress.com

