


Description of Device Parameters

Micropilot FMR60B - FMR67B

Free-space radar
PROFINET over Ethernet-APL



1 About this document

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters.

Tasks that require detailed knowledge of the function of the device:

- Starting up measurements under difficult conditions
- Optimal adjustment of measurements to difficult conditions
- Detailed configuration of communication interface
- Fault diagnosis in difficult cases

1.2 Target group

This document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Document structure

The document consists of a general part and a specific part.

The structure of the document and its components are explained in the general part (section 1).

The specific part starts with an overview of the device operating menu, which is the focus of this manual.

The description of the device parameters follows the overview of the operating menu. The description is divided into 4 main menus and their submenus.

The 4 main menus:

- Guidance
- Diagnostics
- Application
- System

In the "Description of device parameters" section, the menus, submenus and parameters are displayed in the same way as they are laid out in the menu structure for the **operating tool**.

An operating tool is software, such as FieldCare, which can be used to display and edit the data and parameters stored in the device on a PC or laptop. Compared to operation via the local display, an operating tool offers more options. It provides additional information, such as graphics and help texts, which explain the properties of the parameters.

The submenus visible to a user depend on the **User role** (→  79) they are logged in with. This document lists the submenus and their parameters that are available to the User role **Maintenance**.

The operating menu is dynamic and adapts the choice of parameters to the selected options.



For information on operating options, see the Operating Instructions.

1.4 Elements of parameter descriptions

Parameter descriptions are structured and made up of a number of elements. Depending on the parameter, more or fewer elements may be available. Below are 2 examples of different parameters:

1	Simulation		7
2	Navigation	Diagnostics → Simulation → Simulation	
3	Prerequisite	Options marked with *: The corresponding device function must be available and configured.	
4	Description	Simulates one or more process variables and/or events. Warning: - Output will reflect the simulated value or event.	
5	Selection	<ul style="list-style-type: none"> ■ Off ■ Distance ■ Level ■ Level linearized * ■ Current output ■ Diagnostic event simulation ■ Foam index * ■ Build-up index * 	
6	Factory setting	Off	

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Prerequisite: The marked options can only be selected under the condition specified in each case
- 4 Description: Description of the parameter function
- 5 Selection: List of the individual options for the parameter
- 6 Factory setting: Default setting on leaving the factory
- 7 The lock symbol indicates that the parameter is write-protected

1	Timestamp	
2	Navigation	Diagnostics → Active diagnos. → Timestamp
3	Description	Displays the timestamp for the currently active diagnostic message.
4	User interface	Days (d), hours (h), minutes (m), seconds (s)
5	Factory setting	
6	Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: -

- 1 Name: Parameter designation (Label)
- 2 Navigation: Navigation path to the parameter. The graphics indicate whether the path applies to the onsite display, the operating tool or both.
- 3 Description: Description of the parameter function
- 4 User interface: Display value/data of the parameter
- 5 Factory setting: Default setting on leaving the factory
- 6 Additional information:
Read and write access: Information on access rights that users with certain roles have to the parameter

Additional information at the end of the parameter description can refer to all elements of the parameter description and expand them.

1.5 Symbols

1.5.1 Safety symbols



This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.

⚠ WARNING

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in serious or fatal injury.

⚠ CAUTION

This symbol alerts you to a potentially dangerous situation. Failure to avoid this situation can result in minor or medium injury.

📌 NOTICE

This symbol alerts you to a potentially harmful situation. Failure to avoid this situation can result in damage to the product or something in its vicinity.

1.5.2 Symbols for certain types of Information

-  Indicates additional information
-  Reference to documentation
-  Operation via local display
-  Operation via operating tool
-  Write-protected parameter

1.6 Documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
 - *Device Viewer* (www.endress.com/deviceviewer): Enter the serial number from the nameplate
 - *Endress+Hauser Operations app*: Enter serial number from nameplate or scan matrix code on nameplate.

The documentation is available via the Internet: → www.endress.com Download

2 Overview of the operating menu

Navigation

 Operating tool

Guidance	→  16
▶ Commissioning	→  16
▶ Heartbeat Technology	→  17
▶ Heartbeat Verification	→  18
▶ Foam detection	→  18
▶ Buildup detection	→  18
▶ Import / Export	→  18
▶ Compare	→  19
Diagnostics	→  19
▶ Active diagnostics	→  19
Active diagnostics	→  19
Timestamp	→  19
Previous diagnostics	→  20
Timestamp	→  20
Operating time from restart	→  20
Operating time	→  20
▶ Diagnostic list	→  21
▶ Event logbook	→  21
▶ Minimum/maximum values	→  21
Min. level value	→  21
Time min. level	→  21
Max. level value	→  22
Time max. level	→  22

Max. draining speed	→  22
Max. filling speed	→  22
Counter underfilling	→  22
Counter overfilling	→  23
Minimum sensor temperature	→  23
Time min. sensor temperature	→  23
Maximum sensor temperature	→  23
Time max. sensor temperature	→  23
Minimum electronics temperature	→  23
Maximum electronics temperature	→  24
Reset min./max.	→  24
► Simulation	→  24
Simulation	→  24
Simulation distance	→  25
Buildup index	→  25
Foam index	→  25
Process variable value	→  25
Diagnostic event simulation	→  26
► Heartbeat Technology	→  27
► Heartbeat Verification	→  27
Date/time Heartbeat Verification	→  27
Operating time (Verification)	→  27
Verification result	→  28
Status	→  28

▶ Foam detection	→ 28
952 Foam detected	→ 28
Foam index	→ 29
Foam detec. threshold	→ 29
Foam detec. threshold value	→ 29
Lower level range limit	→ 29
Upper level range limit	→ 30
Distance at foam zero adjustment	→ 30
0% foam value	→ 30
▶ Buildup detection	→ 30
168 Buildup detected	→ 30
Buildup index	→ 31
Buildup detection threshold	→ 31
Buildup detection threshold value	→ 31
Minimum distance for buildup detection	→ 31
Maximum distance for buildup detection	→ 32
0 % buildup value	→ 32
Area of incoupling	→ 32
Limit offset for buildup detection	→ 32
▶ Echo curve	→ 33
Save reference curve	→ 33

Time reference curve	→ 33
Reference curve active	→ 33
▶ Diagnostic settings	→ 34
▶ Properties	→ 34
941 Diagnostic behavior	→ 34
941 Event category	→ 34
Value echo lost	→ 35
Ramp at echo lost	→ 35
Delay time echo lost	→ 36
942 Diagnostic behavior	→ 37
942 Event category	→ 37
Safety distance	→ 38
Acknowledge alarm	→ 38
▶ Configuration	→ 38
▶ Sensor	→ 38
168 Diagnostic behavior	→ 38
168 Event category	→ 39
▶ Configuration	→ 39
436 Diagnostic behavior	→ 39
436 Event category	→ 39
▶ Process	→ 40
941 Diagnostic behavior	→ 40
941 Event category	→ 40
942 Diagnostic behavior	→ 41
942 Event category	→ 41

	952 Diagnostic behavior	→ 41
	952 Event category	→ 42
Application		→ 42
▶ Measuring units		→ 42
Level unit		→ 42
Distance unit		→ 42
Temperature unit		→ 43
▶ Measured values		→ 43
Level linearized		→ 43
Level		→ 43
Distance		→ 44
Unfiltered distance		→ 44
Sensor temperature		→ 44
Electronics temperature		→ 44
▶ Sensor		→ 45
▶ Basic settings		→ 45
Tank type		→ 45
Bin type		→ 45
Empty calibration		→ 46
Full calibration		→ 46
Maximum draining speed solid		→ 46
Maximum filling speed solid		→ 47
Maximum draining speed liquid		→ 47
Maximum filling speed liquid		→ 48
Tank/silo height		→ 48

Damping output	→ 49
Distance	→ 49
Confirm distance	→ 49
Record map	→ 50
Mapping end point	→ 50
Active map	→ 52
► Additional settings	→ 52
Medium type	→ 52
Medium group	→ 53
Medium property	→ 53
Upper blank out	→ 54
Output mode	→ 54
Level limit mode	→ 55
High limit	→ 55
Low limit	→ 55
Level correction	→ 56
► Linearization	→ 63
Linearization type	→ 63
Unit after linearization	→ 63
Free text	→ 64
Level linearized	→ 64
Maximum value	→ 64
Diameter	→ 64
Intermediate height	→ 65
Table mode	→ 65

Table number	→ 65
Level	→ 66
Customer value	→ 66
Activate table	→ 67
► Signal information	→ 67
Signal quality	→ 67
Absolute echo amplitude	→ 67
Relative echo amplitude	→ 68
► PROFINET	→ 69
► Configuration	→ 69
PROFINET device name	→ 69
Parameter change acknowledge mode	→ 69
Acknowledge parameter change	→ 69
Descriptor	→ 70
► Analog input	→ 70
► Analog input 1 to 11	→ 70
Process value	→ 70
Assign process variable	→ 70
Damping	→ 71
► Binary input	→ 72
► Binary input 1 to 2	→ 72
Controller input value	→ 72
► Binary output	→ 74
Set point value	→ 74
BO block output value	→ 74

	Failure behavior	→ 74
	Failure behavior delay	→ 74
	Fixed value	→ 75
	► Information	→ 75
	Device ID	→ 75
	PA profile version	→ 75
	► Application relation	→ 76
	AR state	→ 76
	MAC address IO controller	→ 76
	MAC address backup IO controller	→ 76
	IP address IO controller	→ 76
	IP address backup IO controller	→ 77
System		→ 77
	► Device management	→ 77
	Device tag	→ 77
	Locking status	→ 78
	Configuration counter	→ 78
	Reset device	→ 78
	► User management	→ 79
	User role	→ 79
	Password	→ 79
	Enter access code	→ 79
	Status password entry	→ 79
	New password	→ 80
	Confirm new password	→ 80

Status password entry	→ 79
Old password	→ 80
New password	→ 80
Confirm new password	→ 80
Status password entry	→ 79
Old password	→ 80
Status password entry	→ 79
Reset password	→ 81
Status password entry	→ 79
► Connectivity	→ 81
► Interfaces	→ 81
Display operation	→ 81
Web server functionality	→ 81
Bluetooth activation	→ 82
Service (UART-CDI)	→ 82
► Ethernet	→ 82
MAC address	→ 82
IP address	→ 82
Subnet mask	→ 83
Default gateway	→ 83
Service IP active	→ 83
Interface connection status	→ 83
Interface speed	→ 84
Duplex status	→ 84
Auto negotiation status	→ 84

	Number of received packets	→  84
	Number of sent packets	→  85
	Number of failed received packets	→  85
	Number of failed sent packets	→  85
	Signal to noise ratio	→  86
	Number of failed received packets	→  86
	Active TCP connections	→  86
	Supported TCP connections	→  86
	TCP connection requests	→  86
	TCP connection timeouts	→  87
	Number of TCP connections closed	→  87
	Number of received TCP packets	→  87
	Number of sent TCP packets	→  87
	Number of TCP failed received packets	→  87
	Available UDP ports	→  88
	Number of received UDP packets	→  88
	Number of sent UDP packets	→  88
	Number of UDP failed received packets	→  88
	► Display	→  89
	Language	→  89
	Format display	→  89
	Value 1 ... 4 display	→  90
	Decimal places 1 ... 4	→  91
	Contrast display	→  91

▶ Date/time	→  91
Date/time	→  91
Time zone	→  92
Enable NTP	→  93
NTP server address	→  93
Clock synchronized	→  93
▶ Geolocation	→  93
Location description	→  93
Longitude	→  94
Latitude	→  94
Altitude	→  94
▶ Information	→  95
Device name	→  95
Manufacturer	→  95
Serial number	→  95
Order code	→  95
Firmware version	→  96
Hardware version	→  96
Extended order code 1 ... 3	→  96
Checksum	→  97
▶ Software configuration	→  101
CRC device configuration	→  101
Activate SW option	→  102
Software option overview	→  102

3 Description of device parameters

3.1 Guidance

In the **Guidance** menu, the user can quickly perform basic tasks, such as commissioning. These primarily consist of guided wizards and cross-thematic special functions.

Navigation  Guidance

3.1.1 Overview

The **Guidance** menu contains the following submenus and wizards:

- Commissioning
- Heartbeat Technology
 - Heartbeat Verification
 - Foam detection
 - Buildup detection
- Import / Export
- Compare

3.1.2 Commissioning

Run the **Commissioning** wizard to commission the device. Enter the appropriate value in each parameter or select the appropriate option.

WARNING

If the wizard is canceled before all the necessary parameters have been configured, any settings already made are saved.

The device may be in an undefined state!

- ▶ Reset the device to factory settings.

Navigation

Guidance → Commissioning

Parameters for "Commissioning" wizard**The following parameters are configured in this wizard:**

- **Device identification**
 - Device tag
 - Device name
 - Serial number
 - Extended order code 1 ... 3
 - Locking status
 - Time zone
 - Date/time
 - PROFINET device name
 - IP address
 - Descriptor
 - MAC address
 - Device ID
 - Manufacturer ID
- **Measurement adjustments**
 - Level unit
 - Distance unit
 - Temperature unit
 - Bin type
 - Tank type
 - Medium group
 - Empty calibration
 - Full calibration
 - Level
 - Displayed level/distance correct?
 - Show possible signals in?
 - Distance
 - Level
 - Is a linearization required?
 - Linearization type
 - Unit after linearization
 - Maximum value
 - Diameter
 - Intermediate height
 - Level linearized
 - Table mode
 - Table number
 - Level
 - Customer value
 - Activate table
- **Output settings**
 - Assign process variable

3.1.3 Heartbeat Technology

Heartbeat Technology offers the following functions:

- Diagnostics through continuous self-monitoring
- Additional measured variables output to an external condition monitoring system
- In situ verification of measuring instruments in the application

Special Documentation on Heartbeat Technology is available via the Internet:
www.endress.com → Download

Navigation  Guidance → Heartbeat Techn.

Heartbeat Verification

This wizard is used to start an automatic verification of the device functionality. The results can be documented as a verification report.

Navigation  Guidance → Heartbeat Techn. → Heartbeat Verif.

Foam detection

This wizard configures the automatic foam detection.

Foam detection can be linked to an output variable or status information e.g. to control a sprinkler used to dissolve the foam. It is also possible to monitor the foam increase in a so called foam index. The foam index can also be linked to an output variable and can be shown on the display.

Preparation:

The Foam monitoring initialization should only be done without or less foam.

Navigation  Guidance → Heartbeat Techn. → Foam detection

Buildup detection

This wizard configures the build-up detection.

Basic idea:

The build-up detection can, for example, be linked to a compressed-air system to clean the antenna.

With the build-up monitoring the maintenance cycles can be optimized.

Preparation:

The build-up monitoring initialization should only be done without or less build-up.

Navigation  Guidance → Heartbeat Techn. → Buildup detect.

3.1.4 Import / Export

Save / Restore

- The device settings can be saved in a .deh file.
- The device settings saved in a .deh file can be written to the device.

Create configuration report

Device documentation can be saved in PDF format under Create configuration report. This device documentation contains the following general device information:

- Information on device parameters
- Information on Linearization
- Echo curve
- Event list
- Diagnostic list

Navigation  Guidance → Import / Export

3.1.5 Compare

Compare datasets

This function can be used to compare the following datasets:

- Data records in the .deh file format from the function Import / Export
- Datasets with the configuration currently in the device

Navigation  Guidance → Compare

3.2 Diagnostics

Navigation   Diagnostics

3.2.1 Active diagnostics

Navigation   Diagnostics → Active diagnos.

Active diagnostics

Navigation	  Diagnostics → Active diagnos. → Active diagnos.
Description	Displays the currently active diagnostic message. If there is more than one pending diagnostic event, the message for the diagnostic event with the highest priority is displayed.
User interface	<ul style="list-style-type: none"> ■ Operating time of the device until the event occurs ■ Symbol for diagnostic behavior ■ Code for diagnostic behavior ■ Event text ■ Corrective measure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp for the currently active diagnostic message.
User interface	Date, time

Previous diagnostics

Navigation	  Diagnostics → Active diagnos. → Prev.diagnostics
Description	Displays the diagnostic message for the last diagnostic event that has ended.
User interface	<ul style="list-style-type: none"> ■ Operating time of the device until the event occurs ■ Symbol for diagnostic behavior ■ Code for diagnostic behavior ■ Event text ■ Corrective measure

Timestamp

Navigation	  Diagnostics → Active diagnos. → Timestamp
Description	Displays the timestamp of the diagnostic message generated for the last diagnostic event that has ended.
User interface	Date, time

Operating time from restart

Navigation	  Diagnostics → Active diagnos. → Time fr. restart
Description	Indicates how long the device has been in operation since the last time the device was restarted.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Operating time

Navigation	  Diagnostics → Active diagnos. → Operating time
Description	Indicates how long the device has been in operation.
User interface	Days (d), hours (h), minutes (m), seconds (s)

3.2.2 Diagnostic list

Navigation  Diagnostics → Diagnostic list

3.2.3 Event logbook

Navigation  Diagnostics → Event logbook

Clear event list

Navigation	 Diagnostics → Event logbook → Clear event list
Description	Delete all entries of the event list.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Clear data
Factory setting	Cancel
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

3.2.4 Minimum/maximum values

Navigation  Diagnostics → Min/max val.

Min. level value

Navigation	 Diagnostics → Min/max val. → Min. level value
Description	Minimum or maximum value measured by device.
User interface	Signed floating-point number

Time min. level

Navigation	 Diagnostics → Min/max val. → Time min. level
User interface	Character string comprising numbers, letters and special characters

Max. level value

Navigation   Diagnostics → Min/max val. → Max. level value

Description Minimum or maximum value measured by device.

User interface Signed floating-point number

Time max. level

Navigation   Diagnostics → Min/max val. → Time max. level

User interface Character string comprising numbers, letters and special characters

Max. draining speed

Navigation   Diagnostics → Min/max val. → Max.drain.speed

User interface Positive floating-point number

Factory setting 0.0 %/min

Max. filling speed

Navigation   Diagnostics → Min/max val. → Max. fill. speed

User interface Positive floating-point number

Factory setting 0.0 %/min

Counter underfilling

Navigation   Diagnostics → Min/max val. → Count underfill.

User interface 0 to 65 535

Factory setting 0

Counter overfilling

Navigation	  Diagnostics → Min/max val. → Count overfill.
User interface	0 to 65 535
Factory setting	0

Minimum sensor temperature

Navigation	  Diagnostics → Min/max val. → Min. sensor temp
User interface	-150 to 200 °C

Time min. sensor temperature

Navigation	  Diagnostics → Min/max val. → Time min s. temp
User interface	Character string comprising numbers, letters and special characters

Maximum sensor temperature

Navigation	  Diagnostics → Min/max val. → Max. sensor temp
User interface	-150 to 200 °C

Time max. sensor temperature

Navigation	  Diagnostics → Min/max val. → Time max s. temp
User interface	Character string comprising numbers, letters and special characters

Minimum electronics temperature

Navigation	  Diagnostics → Min/max val. → Min.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Maximum electronics temperature

Navigation	  Diagnostics → Min/max val. → Max.electr.temp.
Description	Minimum or maximum measured main electronics temperature.
User interface	Signed floating-point number

Reset min./max.



Navigation	  Diagnostics → Min/max val. → Reset min/max
Description	Resets the drag indicator of the selected process variable.
Selection	<ul style="list-style-type: none"> ■ None ■ Drain/fill speed ■ Level ■ Reset all
Factory setting	None

3.2.5 Simulation

Navigation   Diagnostics → Simulation

Simulation



Navigation	  Diagnostics → Simulation → Simulation
Prerequisite	<p>Selection options marked with *:</p> <p>The corresponding device function must be available and configured.</p>
Description	<p>Simulates one or more process variables and/or events.</p> <p>Warning: Output will reflect the simulated value or event.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ Distance ■ Level ■ Level linearized *

* Visibility depends on order options or device settings

- Diagnostic event simulation
- Foam index *
- Buildup index *

Factory setting Off

Simulation distance

Navigation   Diagnostics → Simulation → Sim distance

Prerequisite Simulation = Distance (→  44)

User entry -999.9 to 999.9 m

Factory setting 0 m

Buildup index

Navigation   Diagnostics → Simulation → Buildup index

Prerequisite Simulation = Buildup index

User entry 0 to 100.0 %

Factory setting 0 %

Foam index

Navigation   Diagnostics → Simulation → Foam index

Prerequisite Simulation = Foam index (→  29)

User entry 0 to 100.0 %

Factory setting 0 %

Process variable value

Navigation   Diagnostics → Simulation → Proc. var. value

Prerequisite Simulation = Level linearized (→  43)

* Visibility depends on order options or device settings

Description	Defines the value of the selected variable. The outputs assume values or states according to this value.
User entry	Signed floating-point number
Factory setting	0

Diagnostic event simulation

Navigation   Diagnostics → Simulation → Diagnostic event

Prerequisite Simulation = Diagnostic event simulation

Description Select the diagnostic event to be simulated.
Note:
To terminate the simulation, select "Off".

Selection

- Buildup detected
- Foam detected
- Record map
- Dataset different
- Data storage inconsistent
- Data transfer failed
- Date/time incorrect
- Processing download
- Echo lost
- Real time clock defective
- Electronics and HistoROM defective
- Electronics temperature
- Firmware incompatible
- Firmware update failed
- Level limited
- Main electronics defective
- Main electronics faulty
- In safety distance
- Configuration incompatible
- Configuration Sensor Unit invalid
- Linearization faulty
- Module incompatible
- Trim required
- Sensor electronic failure
- Sensor temperature out of range
- Sensor connection faulty

	Diagnostic event simulation active
	Simulation distance
	Failure mode simulation active
	Process variable simulation active
	Memory content inconsistent
	Supply voltage too high
	Supply voltage too low
Factory setting	Off

3.2.6 Heartbeat Technology

Navigation  Diagnostics → Heartbeat Techn.

Heartbeat Verification

Navigation  Diagnostics → Heartbeat Techn. → Heartbeat Verif.

Date/time Heartbeat Verification

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Date/time Heartbeat Verification
Description	Date and time of last Heartbeat Verification. This value is updated with every Heartbeat verification. Note: If time information is not available, e.g. Heartbeat verification is started from display, '-----' is shown.
User interface	Character string comprising numbers, letters and special characters
Factory setting	01.01.1970 00:00:00

Operating time (Verification)

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Operating time
Description	Value of the operating hours counter at the time of verification.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Verification result

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Verific. result
Description	Result of Heartbeat Verification.
User interface	<ul style="list-style-type: none"> ■ Not done ■ Passed ■ Not done ■ Failed
Factory setting	Not done

Status

Navigation	 Diagnostics → Heartbeat Techn. → Heartbeat Verif. → Status
Description	Shows the actual status.
User interface	<ul style="list-style-type: none"> ■ Done ■ Busy ■ Failed ■ Not done
Factory setting	Not done

Foam detection

Navigation  Diagnostics → Heartbeat Techn. → Foam detection

952 Foam detected



Navigation	 Diagnostics → Heartbeat Techn. → Foam detection → 952 Foam detected
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	Off

Foam index

Navigation	  Diagnostics → Heartbeat Techn. → Foam detection → Foam index
Description	Foam index 0% means: no foam. Foam index 100% means: maximum detectable foam.
User interface	0 to 100 %
Factory setting	0 %

Foam detec. threshold



Navigation	  Diagnostics → Heartbeat Techn. → Foam detection → Foam threshold
Description	Enter the threshold for the foam detection. As soon as the foam index has reached the preset switching point, an event is triggered.
Selection	<ul style="list-style-type: none"> ■ Sensitive (20%) ■ Middle (40%) ■ Insensitive (80%) ■ User defined (xx%)
Factory setting	Middle (40%)

Foam detec. threshold value



Navigation	  Diagnostics → Heartbeat Techn. → Foam detection → Foam detect val.
Description	User-defined threshold value for the foam detection.
User entry	0 to 100.0 %
Factory setting	40 %

Lower level range limit



Navigation	  Diagnostics → Heartbeat Techn. → Foam detection → LLR limit
Description	Assign lower limit of foam monitoring area.
Factory setting	0 %

Upper level range limit



Navigation   Diagnostics → Heartbeat Techn. → Foam detection → ULR limit

Description Assign upper limit of foam monitoring area.

Factory setting 100.0 %

Distance at foam zero adjustment



Navigation   Diagnostics → Heartbeat Techn. → Foam detection → Dist. @zero foam

User entry Signed floating-point number

Factory setting 0 m

0% foam value



Navigation   Diagnostics → Heartbeat Techn. → Foam detection → 0% foam value

User entry -999 999.9 to 999 999.9 dB

Factory setting 0 dB

Buildup detection

Navigation   Diagnostics → Heartbeat Techn. → Buildup detect.

168 Buildup detected



Navigation   Diagnostics → Heartbeat Techn. → Buildup detect. → 168 Buildup det.

Description Activate or deactivate build-up detection.

Selection

- Off
- On

Factory setting Off

Buildup index

Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup index
Description	Build-up index 0% means: no build-up. Build-up index 100% means: maximum detectable build-up.
User interface	0 to 100 %
Factory setting	0 %

Buildup detection threshold



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup detec.
Description	Enter the threshold for the build-up detection. As soon as the build-up index has reached the preset switching point, an event is triggered.
Selection	<ul style="list-style-type: none"> ■ Sensitive (20%) ■ Middle (40%) ■ Insensitive (80%) ■ User defined (xx%)
Factory setting	Middle (40%)

Buildup detection threshold value



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Buildup value
Description	User-defined threshold value for the build-up detection.
User entry	0 to 100.0 %
Factory setting	40 %

Minimum distance for buildup detection



Navigation	 Diagnostics → Heartbeat Techn. → Buildup detect. → Min dist buildup
User entry	-999.9 to 999.9 m
Factory setting	0 m

Maximum distance for buildup detection



Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Max dist buildup
User entry	-999.9 to 999.9 m
Factory setting	1 m

0 % buildup value



Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → 0 % buildup val
User entry	Positive floating-point number
Factory setting	0

Area of incoupling

Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Area incoupling
Description	Ring integral within the detection area.
User interface	Positive floating-point number
Factory setting	0.0

Limit offset for buildup detection



Navigation	Diagnostics → Heartbeat Techn. → Buildup detect. → Offset buildup
User entry	-999 999.9 to 999 999.9 dB
Factory setting	10 dB

3.2.7 Echo curve

Navigation  Diagnostics → Echo curve

Save reference curve 	
Navigation	 Diagnostics → Echo curve → Save ref. curve
Selection	<ul style="list-style-type: none"> ■ Customer reference curve ■ Not active
Factory setting	Not active
Additional information	<p>Access:</p> <ul style="list-style-type: none"> ■ Read access: Maintenance ■ Write access: Maintenance
Time reference curve	
Navigation	 Diagnostics → Echo curve → Time ref. curve
User interface	Days (d), hours (h), minutes (m), seconds (s)
Additional information	<p>Timestamp of the recording of the reference curve.</p> <p>Access:</p> <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: -
Reference curve active	
Navigation	 Diagnostics → Echo curve → Ref.curve active
User interface	<ul style="list-style-type: none"> ■ Delivery reference curve available ■ Customer reference curve available
Factory setting	Customer reference curve available
Additional information	<p>The delivery reference curve is recorded at the factory before delivery. A customer reference curve is recorded as standard at the end of the Guidance → Commissioning . These reference curves can be used for diagnosing problems when troubleshooting.</p> <p>Access:</p> <ul style="list-style-type: none"> ■ Read access: Maintenance ■ Write access: -

3.2.8 Diagnostic settings

Navigation  Diagnostics → Diag. settings

Properties

Navigation  Diagnostics → Diag. settings → Properties

941 Diagnostic behavior

Navigation	 Diagnostics → Diag. settings → Properties → 941 Diag. behav.
Description	<p>Defines the behavior of the output in case of an echo loss.</p> <p>"Last valid value" Last valid value is kept.</p> <p>"Ramp at echo lost" Output value is continuously shifted towards 0% or 100%.</p> <p>"Value echo lost" Output assumes a defined value.</p> <p>"Alarm" Device generates an alarm.</p>
Selection	<ul style="list-style-type: none"> ■ Last valid value ■ Ramp at echo lost ■ Value echo lost ■ Alarm
Factory setting	Last valid value

941 Event category

Navigation	 Diagnostics → Diag. settings → Properties → 941Event category
User interface	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized
Factory setting	Out of specification (S)

Value echo lost



Navigation	Diagnostics → Diag. settings → Properties → Value echo lost
Description	Value of the output in case of an echo loss.
User entry	Signed floating-point number
Factory setting	0 m

Ramp at echo lost



Navigation	Diagnostics → Diag. settings → Properties → Ramp echo lost
Description	Slope of the ramp in the case of an echo loss. Note: If the slope is positive (+), the output increases until it reaches 100%. If the slope is negative (-), the output decreases until it reaches 0%.
User entry	Signed floating-point number
Factory setting	0.0 %/min

Delay echo lost



Navigation	Diagnostics → Diag. settings → Properties → Delay echo lost
Description	Activate or deactivate the delay time in case of echo loss. After an echo loss, the device allows the delay time to pass before the reaction defined in parameter "941 Diagnostic behavior" occurs. This way it can be avoided that temporary disturbances interrupt the measurement unnecessarily.
Selection	<ul style="list-style-type: none"> ■ Off ■ On
Factory setting	On
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Delay time echo lost



Navigation	  Diagnostics → Diag. settings → Properties → Delay echo lost
Description	Time between the echo loss and the reaction defined for the output.
User entry	0 to 99 999.9 s
Factory setting	900 s

Echo jump delay



Navigation	  Diagnostics → Diag. settings → Properties → Echo jump delay
User entry	0 to 99 999.9 s
Factory setting	60.0 s
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo lost window right



Navigation	  Diagnostics → Diag. settings → Properties → Echo l.win.right
User entry	0.0 to 99.9 m
Factory setting	4 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo lost window left



Navigation	  Diagnostics → Diag. settings → Properties → Echo l.win.left
User entry	0.0 to 99.0 m
Factory setting	4 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Draining speed



Navigation	Diagnostics → Diag. settings → Properties → Draining speed
User entry	Signed floating-point number
Factory setting	100 cm/min
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Filling speed



Navigation	Diagnostics → Diag. settings → Properties → Filling speed
User entry	Signed floating-point number
Factory setting	100 cm/min
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

942 Diagnostic behavior



Navigation	Diagnostics → Diag. settings → Properties → 942 Diag. behav.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Self holding
Factory setting	Warning

942 Event category

Navigation	Diagnostics → Diag. settings → Properties → 942Event category
User interface	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized
Factory setting	Out of specification (S)

Safety distance 

Navigation	  Diagnostics → Diag. settings → Properties → Safety distance
User entry	-200.0 to 125 m
Factory setting	0.0 m

Acknowledge alarm 

Navigation	  Diagnostics → Diag. settings → Properties → Acknowl. alarm
Selection	<ul style="list-style-type: none"> ▪ No ▪ Yes
Factory setting	No

Configuration

Navigation   Diagnostics → Diag. settings → Configuration

Sensor

Navigation   Diagnostics → Diag. settings → Configuration → Sensor

168 Diagnostic behavior 

Navigation	  Diagnostics → Diag. settings → Configuration → Sensor → 168 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": No forwarding of the message via the fieldbus.</p> <p>"Warning": Warning message is transmitted via the fieldbus (default setting).</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Alarm ▪ Warning ▪ Logbook entry only
Factory setting	Warning

168 Event category

Navigation  Diagnostics → Diag. settings → Configuration → Sensor → 168Event category

Description

- User interface**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - Not categorized

Factory setting Maintenance required (M)

Configuration

Navigation  Diagnostics → Diag. settings → Configuration → Configuration

436 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Configuration → Configuration → 436 Diag. behav.

Description

Select event behavior

"Logbook entry only":
No forwarding of the message via the fieldbus.

"Warning": Warning message is transmitted via the fieldbus (default setting).
Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.

- Selection**
- Warning
 - Logbook entry only

Factory setting Warning

436 Event category

Navigation  Diagnostics → Diag. settings → Configuration → Configuration → 436 Event category

- User interface**
- Failure (F)
 - Function check (C)
 - Out of specification (S)
 - Maintenance required (M)
 - Not categorized

Factory setting Maintenance required (M)

Process

Navigation  Diagnostics → Diag. settings → Configuration → Process

941 Diagnostic behavior

Navigation  Diagnostics → Diag. settings → Configuration → Process → 941 Diag. behav.

Description Defines the behavior of the output in case of an echo loss.

"Last valid value"

Last valid value is kept.

"Ramp at echo lost"

Output value is continuously shifted towards 0% or 100%.

"Value echo lost"

Output assumes a defined value.

"Alarm"

Device generates an alarm.

Selection

- Last valid value
- Ramp at echo lost
- Value echo lost
- Alarm

Factory setting Last valid value

941 Event category

Navigation  Diagnostics → Diag. settings → Configuration → Process → 941Event category

User interface

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Not categorized

Factory setting Out of specification (S)

942 Diagnostic behavior



Navigation	Diagnostics → Diag. settings → Configuration → Process → 942 Diag. behav.
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Self holding
Factory setting	Warning

942 Event category

Navigation	Diagnostics → Diag. settings → Configuration → Process → 942Event category
User interface	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized
Factory setting	Out of specification (S)

952 Diagnostic behavior



Navigation	Diagnostics → Diag. settings → Configuration → Process → 952 Diag. behav.
Description	<p>Select event behavior</p> <p>"Logbook entry only": No forwarding of the message via the fieldbus.</p> <p>"Warning": Warning message is transmitted via the fieldbus (default setting).</p> <p>Regardless of the setting, the message appears on the display. If the permissible conditions are reached again, the warning is no longer available in the instrument.</p>
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning

952 Event category

Navigation	 Diagnostics → Diag. settings → Configuration → Process → 952Event category
Description	Display diagnostic message category.
User interface	<ul style="list-style-type: none"> ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Not categorized
Factory setting	Out of specification (S)

3.3 Application

Navigation  Application

3.3.1 Measuring units

Navigation  Application → Measuring units

Level unit

Navigation	 Application → Measuring units → Level unit						
Description	Used to display the level.						
User interface	<table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"><i>SI units</i></td> <td style="width: 50%;"><i>US units</i></td> </tr> <tr> <td>■ m</td> <td>■ ft</td> </tr> <tr> <td>■ mm</td> <td>■ in</td> </tr> </table>	<i>SI units</i>	<i>US units</i>	■ m	■ ft	■ mm	■ in
<i>SI units</i>	<i>US units</i>						
■ m	■ ft						
■ mm	■ in						
Factory setting	m						

Distance unit



Navigation	 Application → Measuring units → Distance unit						
Description	Used for the basic calibration (Empty / Full).						
Selection	<table style="width: 100%; border: none;"> <tr> <td style="width: 50%;"><i>SI units</i></td> <td style="width: 50%;"><i>US units</i></td> </tr> <tr> <td>■ mm</td> <td>■ ft</td> </tr> <tr> <td>■ m</td> <td>■ in</td> </tr> </table>	<i>SI units</i>	<i>US units</i>	■ mm	■ ft	■ m	■ in
<i>SI units</i>	<i>US units</i>						
■ mm	■ ft						
■ m	■ in						

Factory setting m

Temperature unit

Navigation   Application → Measuring units → Temperature unit

Description Select the temperature unit.

Selection

<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	

Factory setting °C

3.3.2 Measured values

Navigation   Application → Measured values

Level linearized

Navigation   Application → Measured values → Level linearized

Description Displays the linearized level.

User interface Signed floating-point number

Factory setting 0 %

Level

Navigation   Application → Measured values → Level

Description Currently measured level

User interface -99 999.9 to 200 000.0 m

Factory setting 0.0 m

Distance

Navigation	 Application → Measured values → Distance
Description	Distance from lower edge of device flange to product surface.
User interface	Signed floating-point number
Factory setting	0 m

Unfiltered distance

Navigation	 Application → Measured values → Unfiltered dist.
User interface	-999 999.9 to 999 999.9 m
Factory setting	0.0 m

Sensor temperature

Navigation	 Application → Measured values → Sensor temp.
Description	Displays the current temperature of the sensor electronics.
User interface	-150 to 200 °C
Factory setting	-150 °C

Electronics temperature

Navigation	 Application → Measured values → Electronics temp
Description	Displays the current temperature of the main electronics.
User interface	Signed floating-point number
Factory setting	0 °C

3.3.3 Sensor

Navigation  Application → Sensor

Basic settings

Navigation  Application → Sensor → Basic settings

Tank type	
------------------	---

Navigation	 Application → Sensor → Basic settings → Tank type
Description	Optimizes the signal filters for the respective tank type. Note: "Workbench test" deactivates all filters. This option should exclusively be used for tests.
Selection	<ul style="list-style-type: none"> ■ Process vessel standard ■ Process vessel with agitator ■ Storage vessel ■ Sphere ■ Open channel ■ Stilling well ■ Workbench test *
Factory setting	Process vessel standard

Bin type	
-----------------	---

Navigation	 Application → Sensor → Basic settings → Bin type
Description	Optimizes the signal filters for the respective bin type. Note: "Workbench test" deactivates all filters. This option should exclusively be used for tests.
Selection	<ul style="list-style-type: none"> ■ Silo ■ Buffer silo (fast) * ■ Bin/Pile * ■ Crusher/belt ■ Workbench test
Factory setting	Silo

* Visibility depends on order options or device settings

Additional information	<ul style="list-style-type: none"> ■ Silo: Silo for bulk material (tall and narrow) ■ Bunker (wide area): Storage bunker for solids (wide area). Visibility depends on order options or device settings ■ Stockpile/Profile measurement: Open stockpile or profile measurement of the stockpile. Visibility depends on order options or device settings ■ Crusher/belt: Crusher or conveyor belt. Visibility depends on order options or device settings ■ Workbench test: All signal filters are deactivated. This mode should only be used for test purposes.
-------------------------------	--

Empty calibration

Navigation	  Application → Sensor → Basic settings → Empty calibr.
Description	Distance between process connection and minimum level (0 %).
User entry	0.0 to 125.0 m
Factory setting	20 m

Full calibration

Navigation	  Application → Sensor → Basic settings → Full calibr.
Description	Distance between minimum level (0 %) and maximum level (100 %).
User entry	0.001 to 125.0 m
Factory setting	20 m

Maximum draining speed solid

Navigation	  Application → Sensor → Basic settings → Max.drain solid
Description	<p>By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.</p> <p>Note: The filling and draining speeds can be set separately as the filling and draining procedures may be different.</p> <p>Note: With the 'No filter / test' option all signal evaluation filters are deactivated. This option should exclusively be used for tests.</p>
Selection	<ul style="list-style-type: none"> ■ Very slow < 0.5m (1.6ft) /h ■ Slow < 1 m (3.3 ft)/h ■ Standard < 2m (6,5ft) /h

- Medium < 4m (13ft) /h
- Fast < 8m (26ft) /h
- Very fast > 8m (26ft) /h
- No filter / test

Factory setting No filter / test

Maximum filling speed solid

Navigation   Application → Sensor → Basic settings → Max. fill. solid

Description By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the 'No filter / test' option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

- Selection**
- Very slow < 0.5m (1.6ft) /h
 - Slow < 1 m (3.3 ft)/h
 - Standard < 2m (6,5ft) /h
 - Medium < 4m (13ft) /h
 - Fast < 8m (26ft) /h
 - Very fast > 8m (26ft) /h
 - No filter / test

Factory setting No filter / test

Maximum draining speed liquid

Navigation   Application → Sensor → Basic settings → Max drain liquid

Description By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the 'No filter / test' option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

- Selection**
- Slow < 1cm (0.4in) /min
 - Medium < 10cm (4in) /min
 - Standard < 1m (40in) /min
 - Fast < 2m (80in) /min
 - Very fast > 2m (80in) /min
 - No filter / test

Factory setting Standard < 1m (40in) /min

Maximum filling speed liquid



Navigation Application → Sensor → Basic settings → Max. fill liquid

Description By selecting the maximum expected filling and draining speed the signal evaluation is automatically optimized for the process.

Note:

The filling and draining speeds can be set separately as the filling and draining procedures may be different.

Note:

With the 'No filter / test' option all signal evaluation filters are deactivated. This option should exclusively be used for tests.

Selection

- Slow < 1cm (0.4in) /min
- Medium < 10cm (4in) /min
- Standard < 1m (40in) /min
- Fast < 2m (80in) /min
- Very fast > 2m (80in) /min
- No filter / test

Factory setting Standard < 1m (40in) /min

Tank/silo height



Navigation Application → Sensor → Basic settings → Tank/silo height

Description If the parametrized measuring range (Empty calibration) differs significantly from the tank or silo height, it is recommended to enter the tank or silo height in this parameter.

Example:

Continuous level monitoring in the upper third of a tank or silo.

Note:

For tanks with conical outlet, this parameter should not be changed as in this type of applications "Empty calibration" is usually not << the tank or silo height.

User entry 0 to 125 m

Factory setting 20 m

Damping output

**Navigation**

Application → Sensor → Basic settings → Damping out.

Description

The damping is effective before the measured value is further processed, i.e., before the following processes:

- Scaling
- Limit value monitoring
- Forwarding to display
- Forwarding to Analog Input Block

Note:

The Analog Input Block has its own “Damping” parameter. In the measurement chain, only one of the two attenuation parameters shall have a value other than 0. Otherwise, the signal will be attenuated several times.

User entry

0.0 to 1200.0 s

Factory setting

0.0 s

Distance

Navigation

Application → Sensor → Basic settings → Distance

Description

Distance from lower edge of device flange to product surface.

User interface

Signed floating-point number

Factory setting

0 m

Confirm distance

**Navigation**

Application → Sensor → Basic settings → Confirm distance

Selection

- Modify map
- Distance ok
- Distance unknown
- Tank empty

Factory setting

Distance unknown

Record map



Navigation	  Application → Sensor → Basic settings → Record map
Selection	<ul style="list-style-type: none"> ■ No ■ Overlay map ■ Delete cust map
Factory setting	No

Mapping start point



Navigation	  Application → Sensor → Basic settings → Map. start point
User entry	-999.9 to 999.9 m
Factory setting	-0.25 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Mapping end point



Navigation	  Application → Sensor → Basic settings → Map. end point
Description	Defines up to which distance the new mapping has to be recorded. Remark: Make sure the level signal is not covered by the mapping.
User entry	0.0001 to 125 m
Factory setting	0.1 m

Mapping overlay time



Navigation	  Application → Sensor → Basic settings → Map overlay time
User entry	0 to 1200 s
Factory setting	5 s
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Map gap



Navigation	Application → Sensor → Basic settings → Map gap
User entry	0 to 100 m
Factory setting	0.235 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

End of mapping



Navigation	Application → Sensor → Basic settings → End of mapping
Description	Defines the behavior of the mapping curve in the tank bottom area.
Selection	<ul style="list-style-type: none"> ■ Adjustable ■ Last map value
Factory setting	Adjustable
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

End map. ampl.



Navigation	Application → Sensor → Basic settings → End map. ampl.
Description	Amplitude of the mapping curve in the tank bottom area.
User entry	-99 999.0 to 99 999.0 dB
Factory setting	-100 dB
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Active map
**Navigation**

Application → Sensor → Basic settings → Active map

Description

Select the mapping curve that is to be active. Alternatively, the option "No map" can be selected.

Selection

- Factory map
- Customer map
- No map

Factory setting

Factory map

Additional information

- Factory map: The device activates the mapping curve recorded in the factory. This curve cannot be edited or deleted.
- Customer map: If a customer map has been recorded, this can be activated in order to minimize distortions in the application. This curve can be edited.
- No map

Additional settings

Navigation Application → Sensor → Add. settings

Medium type
**Navigation**

Application → Sensor → Add. settings → Medium type

Description

Select whether the measured medium is liquid or solid.

Selection

- Liquid
- Solid

Factory setting

Liquid

Medium group


Navigation Application → Sensor → Add. settings → Medium group

Description Rough specification of the dielectric constant (DC).
This parameter presets the "Medium property" parameter as follows:

"Others'

->'Medium property' = 'Unknown'

"Water based (DC >= 4)'

-> "Medium property" = "DC 4 ... 7'

Note:

If "Medium property" is changed afterwards, "Medium group" retains its value. Only "Medium property" is relevant for the signal evaluation.

Note:

The measuring range may be reduced for small dielectric constants. For details refer to the Technical Information (TI) of the respective device.

Selection

- Others
- Water based (DC >= 4)

Factory setting Others

Medium property


Navigation Application → Sensor → Add. settings → Medium property

Description Specify the dielectric constant (DC) of the medium.

Note:

For multiple-phase systems this value refers to the upper medium.

Selection

- Unknown
- DC 1.2 ... 1.6
- DC 1.6 ... 1.9
- DC 1.9 ... 2.5
- DC 2.5 ... 4
- DC 4 ... 7
- DC 7 ... 15
- DC > 15

Factory setting DC 1.9 ... 2.5

Upper blank out



Navigation	Application → Sensor → Add. settings → Upper blank out
Description	This parameter describes a line segment between reference point and close to maximum level (100%). The value is calculated by the device to blanket potentially disturbing signals coming from this space. The value can be adapted manually.
User entry	0.0 to 125 m
Factory setting	0.05 m

Output mode



Navigation	Application → Sensor → Add. settings → Output mode
Description	Select output mode between: Ullage = The remaining space in the tank or silo is indicated. or Level linearized = The level is indicated (more precisely: the linearized value if a linearization has been activated).
Selection	<ul style="list-style-type: none"> ▪ Ullage ▪ Level linearized
Factory setting	Level linearized

L max. drain speed



Navigation	Application → Sensor → Add. settings → L max draining
User entry	0.0 to 50 000.0 %/min
Factory setting	0.0 %/min
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

L max. fill speed



Navigation	Application → Sensor → Add. settings → L max.fill speed
User entry	0.0 to 50 000.0 %/min
Factory setting	0.0 %/min
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Level limit mode



Navigation	Application → Sensor → Add. settings → Level limit mode
Description	Determines whether the output value is limited by an upper or lower limit (or by both).
Selection	<ul style="list-style-type: none"> ■ Off ■ Low limit ■ High limit ■ Low and High Limit
Factory setting	Low limit

High limit



Navigation	Application → Sensor → Add. settings → High limit
Description	Defines the upper limit of the output value.
User entry	Signed floating-point number
Factory setting	0 m

Low limit



Navigation	Application → Sensor → Add. settings → Low limit
Description	Defines the lower limit of the output value.
User entry	-200 000.0 to 200 000.0 m
Factory setting	0.0 m

Level correction		
Navigation	  Application → Sensor → Add. settings → Level correction	
Description	The measured level is corrected by this value to compensate for a constant level error. Level correction > 0: The level is increased by this value. Level correction < 0: The level is decreased by this value.	
User entry	-200 000.0 to 200 000.0 m	
Factory setting	0.0 m	

Echo evaluation

Navigation   Application → Sensor → Add. settings → Echo evaluation

Echo curve statistic		
Navigation	  Application → Sensor → Add. settings → Echo evaluation → Ec. curve stat.	
Description	Activate or deactivate the weighted echo curve statistics.	
Selection	<ul style="list-style-type: none"> ■ Off ■ On 	
Factory setting	On	
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert 	

Echo curve statistics up		
Navigation	  Application → Sensor → Add. settings → Echo evaluation → EC. stat. up	
Description	Enter the number of measuring cycles to define the weighting of the last echo curve for ascending signals.	
User entry	0 to 30	
Factory setting	3	

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--

Echo curve statistic down

Navigation	  Application → Sensor → Add. settings → Echo evaluation → ECS in down
Description	Enter the number of measuring cycles to define the weighting of the last echo curve for descending signals.
User entry	0 to 30
Factory setting	5
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo curve smoothing mode

Navigation	  Application → Sensor → Add. settings → Echo evaluation → EC. smooth.mode
Selection	<ul style="list-style-type: none"> ■ Off ■ SG smoothing ■ Symmetric smoothing ■ Asymmetric smoothing
Factory setting	Symmetric smoothing
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Echo curve smoothing

Navigation	  Application → Sensor → Add. settings → Echo evaluation → EC. smoothing
User entry	0.0 to 9.9 m
Factory setting	0 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

FAC offset 

Navigation   Application → Sensor → Add. settings → Echo evaluation → FAC offset

Description Enter offset of the weighting curve.

User entry -9 999.0 to 9 999.0 dB

Factory setting 12 dB

Additional information **Access:**
■ Read access: Expert
■ Write access: Expert

FAC window size 

Navigation   Application → Sensor → Add. settings → Echo evaluation → FAC window size

Description Enter width of the weighting curve window.

User entry 0.0 to 9.9 m

Factory setting 1.6 m

Additional information **Access:**
■ Read access: Expert
■ Write access: Expert

Max Value EWC 

Navigation   Application → Sensor → Add. settings → Echo evaluation → Max Value EWC

Description Enter maximum amplitude of the weighting curve.

User entry -9 999.0 to 9 999.0 dB

Factory setting 100 dB

Additional information **Access:**
■ Read access: Expert
■ Write access: Expert

First echo factor



Navigation Application → Sensor → Add. settings → Echo evaluation → First echo fact.

Description Enter width of the first echo band.

User entry 0.0 to 100.0 dB

Factory setting 10 dB

Additional information **Access:**
▪ Read access: Expert
▪ Write access: Expert

Parabolic fit window size



Navigation Application → Sensor → Add. settings → Echo evaluation → Parab fit window

User entry 0.0 to 9.9 m

Factory setting 0.12 m

Additional information **Access:**
▪ Read access: Expert
▪ Write access: Expert

Tank bottom range



Navigation Application → Sensor → Add. settings → Echo evaluation → TB range

Description Defines the range in which the tank bottom echo is searched for.
The Tank bottom range extends downward and starts at level 0% (Empty calibration). It ends at the entered value.

Note: If the level 0% (Empty calibration) is far above the tank or silo bottom, the Tank bottom range starts at the entered Tank/silo height.

User entry 0.0 to 312.5 m

Factory setting 15 m

Min. amplitude TBD



Navigation Application → Sensor → Add. settings → Echo evaluation → Min. ampl. TBD

Description Enter the minimum amplitude for tank bottom detection.

User entry	0 to 9 999.0 dB
Factory setting	3 dB
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

Lower level area

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Lower level area
Description	<p>Enter lower level area.</p> <p>In this defined range, the first echo band is lowered to the weighting curve.</p>
User entry	0 to 125 m
Factory setting	1 m
Additional information	Access: <ul style="list-style-type: none"> ▪ Read access: Expert ▪ Write access: Expert

Evaluation mode

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Evaluation mode
Description	Defines the evaluation mode for the echo tracking.
Selection	<ul style="list-style-type: none"> ▪ FlexTracking ▪ FlexTracking - Weak signals ▪ FixTracking ▪ FixTracking - Weak signals
Factory setting	FlexTracking

Reset evaluation

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Reset evaluation
Description	Restarts level determination.
Selection	<ul style="list-style-type: none"> ▪ Reset done ▪ Yes
Factory setting	Reset done

Window size tracking



Navigation	Application → Sensor → Add. settings → Echo evaluation → Wind.size track.
User entry	0.0 to 20.5 m
Factory setting	0.500 m
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Maximal track counter



Navigation	Application → Sensor → Add. settings → Echo evaluation → Max track count
User entry	0 to 100
Factory setting	2
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Debug parameter index



Navigation	Application → Sensor → Add. settings → Echo evaluation → Debug parm. idx
User entry	0 to 65 535
Factory setting	2
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Debug array index



Navigation	Application → Sensor → Add. settings → Echo evaluation → Debug array indx
User entry	0 to 255
Factory setting	0

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--

Status

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Status
-------------------	---

User entry	0 to 255
-------------------	----------

Factory setting	0
------------------------	---

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert
-------------------------------	--

Debug value

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Debug value
-------------------	--

User interface	Signed floating-point number
-----------------------	------------------------------

Factory setting	4.0
------------------------	-----

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Debug value integer32

Navigation	  Application → Sensor → Add. settings → Echo evaluation → Debug val. int32
-------------------	---

User interface	Positive integer
-----------------------	------------------

Factory setting	0
------------------------	---

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Linearization

Navigation  Application → Sensor → Linearization

Linearization type	
<hr/>	
Navigation	 Application → Sensor → Linearization → Lineariz. type
Description	Select type of linearization.
Selection	<ul style="list-style-type: none"> ■ None ■ Linear ■ Table ■ Pyramid bottom ■ Conical bottom ■ Angled bottom ■ Horizontal cylinder ■ Sphere
Factory setting	Linear

Unit after linearization													
<hr/>													
Navigation	 Application → Sensor → Linearization → Unit lineariz.												
Description	<p>Defines the unit of the linearized value.</p> <p>Note: The selected unit is only used to be indicated on the display. The measured value is not transformed according to the selected unit.</p> <p>Note: If "Free text" is selected, an additional parameter "Free text" appears in which the designation of the unit can be defined.</p>												
Selection	<table border="0" style="width: 100%;"> <tr> <td style="width: 33%;"><i>SI units</i></td> <td style="width: 33%;"><i>US units</i></td> <td style="width: 33%;"><i>Imperial units</i></td> </tr> <tr> <td> <ul style="list-style-type: none"> ■ STon ■ t ■ kg ■ cm³ ■ dm³ ■ m³ ■ hl ■ l ■ m ■ mm ■ % </td> <td> <ul style="list-style-type: none"> ■ lb ■ UsGal ■ ft³ ■ ft ■ in </td> <td> <ul style="list-style-type: none"> ■ impGal </td> </tr> <tr> <td colspan="3"> <i>Custom-specific units</i></td> </tr> <tr> <td colspan="3">Free text</td> </tr> </table>	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>	<ul style="list-style-type: none"> ■ STon ■ t ■ kg ■ cm³ ■ dm³ ■ m³ ■ hl ■ l ■ m ■ mm ■ % 	<ul style="list-style-type: none"> ■ lb ■ UsGal ■ ft³ ■ ft ■ in 	<ul style="list-style-type: none"> ■ impGal 	 <i>Custom-specific units</i>			Free text		
<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>											
<ul style="list-style-type: none"> ■ STon ■ t ■ kg ■ cm³ ■ dm³ ■ m³ ■ hl ■ l ■ m ■ mm ■ % 	<ul style="list-style-type: none"> ■ lb ■ UsGal ■ ft³ ■ ft ■ in 	<ul style="list-style-type: none"> ■ impGal 											
 <i>Custom-specific units</i>													
Free text													
Factory setting	%												

Free text 

Navigation	  Application → Sensor → Linearization → Free text
User entry	Character string comprising numbers, letters and special characters (32)
Factory setting	Free text

Level linearized

Navigation	  Application → Sensor → Linearization → Level linearized
Description	Displays the linearized level.
User interface	Signed floating-point number
Factory setting	0 %

Maximum value 

Navigation	  Application → Sensor → Linearization → Maximum value
Description	Linearized value corresponding to a level of 100 %.
User entry	-200 000 to 200 000.0 %
Factory setting	100.0 %

Diameter 

Navigation	  Application → Sensor → Linearization → Diameter
Description	Diameter of the spherical tank or horizontal cylinder tank.
User entry	0.001 to 125 m
Factory setting	20 m

Intermediate height



Navigation	Application → Sensor → Linearization → Intermed. height
Description	Height of the pyramid, conical or angled bottom
User entry	0.0 to 125 m
Factory setting	0.0 m

Table mode



Navigation	Application → Sensor → Linearization → Table mode
Description	<p>Defines the editing mode of the linearization table.</p> <p>"Manual" The level and the associated linearized value are entered manually for each linearization point.</p> <p>"Semiautomatic" The level is measured by the device for each linearization point. The associated linearized value is entered manually.</p> <p>"Clear table" Deletes the existing linearization table.</p> <p>"Sort table" Rearranges the linerization points into an ascending order.</p> <p>Note: DeviceCare and FieldCare contain a graphical tool for the easy creation of a linearization table. Device Care: "Additional functions" -> "Linearization table" FieldCare: "Device Operation" -> "Device Functions" -> "Additional functions" -> "Linearization table"</p>
Selection	<ul style="list-style-type: none"> ■ Manual ■ Semiautomatic * ■ Clear table ■ Sort table *
Factory setting	Manual

Table number



Navigation	Application → Sensor → Linearization → Table number
Description	Enter or change the table point.

* Visibility depends on order options or device settings

User entry 1 to 32

Factory setting 1

Level

Navigation   Application → Sensor → Linearization → Level

Description Enter level value of the table point (value before linearization).

User entry Signed floating-point number

Factory setting 0 m

Level

Navigation   Application → Sensor → Linearization → Level

Description Displays measured level (value before linearization). This value is transmitted to the table.

User interface Signed floating-point number

Factory setting 0.0 m

Customer value

Navigation   Application → Sensor → Linearization → Customer value

Description Enter linearized value for the table point.

User entry Signed floating-point number

Factory setting 0 %

Activate table



Navigation	Application → Sensor → Linearization → Activate table
Description	<p>Activate or deactivate table. The table can only be activated if the table values:</p> <ul style="list-style-type: none"> - are present in at least 2 value pairs - do not exceed the sensor limits - represent a function which is monotonically ascending or descending
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Disable

Signal information

Navigation Application → Sensor → Signal inform.

Signal quality

Navigation	Application → Sensor → Signal inform. → Signal quality
Description	Shows the quality of the evaluated level signal.
User interface	<ul style="list-style-type: none"> ▪ Strong ▪ Medium ▪ Weak ▪ No signal
Factory setting	Strong

Absolute echo amplitude

Navigation	Application → Sensor → Signal inform. → Abs. echo ampl.
Description	Shows the absolute amplitude of the evaluated level signal.
User interface	-150.0 to 32.0 dB
Factory setting	0.0 dB

Relative echo amplitude

Navigation	 Application → Sensor → Signal inform. → Relat.echo ampl.
Description	Shows the relative amplitude (i.e. the distance to the evaluation curve) of the evaluated level signal.
User interface	0.0 to 150.0 dB
Factory setting	0.0 dB

Sensor cycle time

Navigation	 Application → Sensor → Signal inform. → Sens. cycle time
User interface	0 to 65 535 ms
Factory setting	0 ms
Additional information	Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: -

Actual IF gain

Navigation	 Application → Sensor → Signal inform. → Actual IF gain
User interface	0 to 1 000
Factory setting	0
Additional information	Access: <ul style="list-style-type: none">■ Read access: Expert■ Write access: -

3.3.4 PROFINET

Navigation  Application → PROFINET

Configuration

Navigation  Application → PROFINET → Configuration

PROFINET device name

Navigation  Application → PROFINET → Configuration → PROFINET DevName

Description Up to 240 characters are allowed.
 The following syntax must be used:
 - 1 or more identifiers, separated with [.]
 - Identifier length is 1 to 63 characters
 - Identifier consists of [a-z 0-9] only lowercase letters and numbers allowed.

Parameter change acknowledge mode

Navigation  Application → PROFINET → Configuration → ParaChngAcknMode

Description Select how to acknowledge the displayed flag when changing the device configuration:
 - "Auto acknowledge": the flag disappears automatically after 20 seconds.
 - "Manual acknowledge": the flag must be acknowledged manually.

Selection

- Auto acknowledge
- Manual acknowledge

Factory setting Auto acknowledge

Acknowledge parameter change

Navigation  Application → PROFINET → Configuration → AcknParaChange

Description If the Option "Manual acknowledge" is selected as the acknowledgement type, then a parameter change must be acknowledged with the "Reset update event flag" option.

Selection

- No acknowledge
- Reset update event flag

Factory setting No acknowledge

Descriptor 

Navigation	  Application → PROFINET → Configuration → Descriptor
Description	Enter a description for the measuring point
User entry	Character string comprising numbers, letters and special characters (54)

Analog input

Navigation   Application → PROFINET → Analog input

Analog input 1 to 11

Navigation   Application → PROFINET → Analog input → Analog input 1 to 11

Process value

Navigation	  Application → PROFINET → Analog input → Analog input 1 to 11 → Process value
Description	Shows the process value reported to the controller for further processing
User interface	Signed floating-point number
Factory setting	0 m

Assign process variable

Navigation	  Application → PROFINET → Analog input → Analog input 1 to 11 → Assign variable
Description	
User interface	<ul style="list-style-type: none"> ■ Sensor temperature * ■ Electronics temperature * ■ Level * ■ Distance * ■ Volume * ■ Relative echo amplitude * ■ Percent of range * ■ Area of incoupling *

* Visibility depends on order options or device settings

- Absolute echo amplitude *
- Buildup index *
- Foam index *

Factory setting Level

Damping

Navigation   Application → PROFINET → Analog input → Analog input 1 to 11 → Damping

Description Enter time constant for input damping (PT1 element). Damping reduces the effect of fluctuations in the measured value on the output signal.

User entry Positive floating-point number

Factory setting 0 s

Simulation value

Navigation   Application → PROFINET → Analog input → Analog input 1 to 11 → Simulation value

Description Enter the simulation value for the selected process variable.

User entry Signed floating-point number

Factory setting 0 m

Additional information **Access:**

- Read access: Expert
- Write access: Maintenance

Simulated status

Navigation   Application → PROFINET → Analog input → Analog input 1 to 11 → Simulated status

Description To simulate a process status for this block. Possible input values can be taken from the PA profile used, see there under the chapter "Process variable status and diagnosis".

Examples for status values are:

0x80 (decimal 128) for status "GOOD"

0x24 (decimal 36) for status "BAD"

* Visibility depends on order options or device settings

User entry	0 to 255
Factory setting	60
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Maintenance

Simulation


Navigation	Application → PROFINET → Analog input → Analog input 1 to 11 → Simulation
Description	Switch simulation of the analog input on or off (Off = 0, On <> 0)
User entry	0 to 255
Factory setting	0
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Binary input

Navigation Application → PROFINET → Binary input

Binary input 1 to 2

Navigation Application → PROFINET → Binary input → Binary input 1 to 2

Controller input value

Navigation	Application → PROFINET → Binary input → Binary input 1 to 2 → ControllInputVal
Description	Shows for each device function the state reported to the controller for further processing
User interface	0 to 255
Factory setting	0

Simulation value



Navigation	Application → PROFINET → Binary input → Binary input 1 to 2 → Simulation value
Description	Enter the simulated state for each device function
User entry	0 to 255
Factory setting	0
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Maintenance

Simulated status



Navigation	Application → PROFINET → Binary input → Binary input 1 to 2 → Simulated status
Description	Specify the status of the simulated state for each device function (Hex)
User entry	0 to 255
Factory setting	60
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Maintenance

Simulation



Navigation	Application → PROFINET → Binary input → Binary input 1 to 2 → Simulation
Description	Switch simulation of the binary input on or off (Off = 0; On <> 0)
User entry	0 to 255
Factory setting	0
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Maintenance

Binary output

Navigation  Application → PROFINET → Binary output

Set point value 

Navigation  Application → PROFINET → Binary output → Set point value

User entry 0 to 255

Factory setting 0

BO block output value 

Navigation  Application → PROFINET → Binary output → BOBlockOutValue

Description Shows for each device function the state reported to the measuring device for further processing

User entry 0 to 255

Factory setting 0

Failure behavior 

Navigation  Application → PROFINET → Binary output → Failure behavior

Description Select failure behavior in the event of a failure (value with status 'Bad')

Selection

- Fixed value
- Last valid value
- Actual value

Factory setting Fixed value

Failure behavior delay 

Navigation  Application → PROFINET → Binary output → FailBehavDelay

Description Enter a delay until in the event of a failure (value with status 'Bad') the failure behavior specified applies

User entry Positive floating-point number

Factory setting 0 s

Fixed value 

Navigation   Application → PROFINET → Binary output → Fixed value

Description Enter value to report in the event of a failure (value with status 'Bad')

User entry 0 to 255

Factory setting 0

Information

Navigation   Application → PROFINET → Information

Device ID

Navigation   Application → PROFINET → Information → Device ID

User interface 0 to 65 535

Factory setting 41 409

PA profile version

Navigation   Application → PROFINET → Information → PA profile vers.

User interface 0 to 65 535

Factory setting 1026

Application relation

Navigation  Application → PROFINET → Applicat. relat.

AR state

Navigation	 Application → PROFINET → Applicat. relat. → AR state
Description	Shows whether an AR connection and a system redundancy have been established
User interface	<ul style="list-style-type: none"> ■ Active ■ Not active ■ Redundancy 1AR active ■ Redundancy 2AR active
Factory setting	Not active

MAC address IO controller

Navigation	 Application → PROFINET → Applicat. relat. → MAC IO contr.
Description	Shows the MAC address of the only or of the primary IO controller
User interface	Character string comprising numbers, letters and special characters
Factory setting	0x00

MAC address backup IO controller

Navigation	 Application → PROFINET → Applicat. relat. → MAC backup IO c.
Description	Shows the MAC adress of the backup IO controller
User interface	Character string comprising numbers, letters and special characters
Factory setting	0x00

IP address IO controller

Navigation	 Application → PROFINET → Applicat. relat. → IP IO controller
Description	Shows the IP address of the only or of the primary IO controller

User interface	Character string comprising numbers, letters and special characters
Factory setting	0x00

IP address backup IO controller

Navigation	 Application → PROFINET → Applicat. relat. → IP backup IO c.
Description	Shows the IP adress of the backup IO controller
User interface	Character string comprising numbers, letters and special characters
Factory setting	0x00

3.4 System

Navigation  System

3.4.1 Device management

Navigation  System → Device manag.

Device tag



Navigation	 System → Device manag. → Device tag
Description	Enter a name for the measuring point to identify the measuring device in the plant
User entry	Character string comprising numbers, letters and special characters (32)

Locking status

Navigation	 System → Device manag. → Locking status
Description	<p>Indicates the type of locking.</p> <p>"Hardware locked" (HW) The device is locked by the "WP" switch on the main electronics module. To unlock, set the switch into the OFF position.</p> <p>"Temporarily locked" (SW) The device is temporarily locked by processes in the device (e.g. data upload/download, reset). The device will automatically be unlocked after completion of these processes.</p>
User interface	<ul style="list-style-type: none"> ■ Hardware locked ■ Temporarily locked

Configuration counter

Navigation	 System → Device manag. → Config. counter
Description	Shows the number of changes made to static parameters (e.g. configuration parameters)
User interface	0 to 65 535
Factory setting	0

Reset device



Navigation	 System → Device manag. → Reset device
Description	Reset the device configuration - either entirely or in part - to a defined state
Selection	<ul style="list-style-type: none"> ■ Cancel ■ To factory defaults * ■ To delivery settings * ■ Restart device
Factory setting	Cancel

* Visibility depends on order options or device settings

3.4.2 User management

Navigation  System → User manag.

User role	
Navigation	  System → User manag. → User role
Description	Shows the access authorization to the parameters via the operating tool
User interface	<ul style="list-style-type: none"> ■ Operator ■ Maintenance ■ Expert ■ Production ■ Development
Factory setting	Maintenance
Password	
Navigation	 System → User manag. → Password
Description	Enter the password for the "Maintenance" user role to get access to the functionality of this role.
User entry	Character string comprising numbers, letters and special characters (16)
Enter access code 	
Navigation	 System → User manag. → Ent. access code
Description	For authorized service personnel only.
User entry	0 to 9999
Factory setting	0
Status password entry	
Navigation	  System → User manag. → Status pw entry
Description	Use this function to display the status of the password verification.

User interface	<ul style="list-style-type: none"> ■ ----- ■ Wrong password ■ Password rule violated ■ Password accepted ■ Permission denied ■ Confirm PW mismatch ■ Reset password accepted ■ Invalid user role ■ Wrong sequence of entry
-----------------------	---

Factory setting	-----
------------------------	-------

New password

Navigation	  System → User manag. → New password
-------------------	---

Description	<p>Define the new "Maintenance" password. A new password is valid after it has been confirmed within the "Confirm new password" parameter. Any valid password consists of 4 to 16 characters and can contain letters and numbers.</p>
--------------------	---

User entry	Character string comprising numbers, letters and special characters (16)
-------------------	--

Confirm new password

Navigation	  System → User manag. → Confirm password
-------------------	---

Description	Enter the new password again to confirm.
--------------------	--

User entry	Character string comprising numbers, letters and special characters (16)
-------------------	--

Old password

Navigation	  System → User manag. → Old password
-------------------	---

Description	Enter the current password, to subsequently change the existing password.
--------------------	---

User entry	Character string comprising numbers, letters and special characters (16)
-------------------	--

Reset password

Navigation	 System → User manag. → Reset password
Description	Enter a code to reset the current "Maintenance" password. The code is delivered by your local support.
User entry	Character string comprising numbers, letters and special characters (16)

3.4.3 Connectivity

Navigation   System → Connectivity

Interfaces

Navigation   System → Connectivity → Interfaces

Display operation



Navigation	  System → Connectivity → Interfaces → DisplayOperation
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable
Factory setting	Enable

Web server functionality



Navigation	  System → Connectivity → Interfaces → Webserver funct.
Description	Switch web server on and off, switch off HTML.
Selection	<ul style="list-style-type: none"> ■ Disable ■ Enable
Factory setting	Enable

Bluetooth activation

Navigation	  System → Connectivity → Interfaces → Bluetooth active
Description	If Bluetooth is deactivated, it can only be reactivated via the display or the operating tool. Reactivating via the SmartBlue app is not possible.
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Enable

Service (UART-CDI)



Navigation	  System → Connectivity → Interfaces → Service (CDI)
Selection	<ul style="list-style-type: none"> ▪ Disable ▪ Enable
Factory setting	Enable

Ethernet

Navigation   System → Connectivity → Ethernet

MAC address

Navigation	  System → Connectivity → Ethernet → MAC Address
Description	Shows the MAC address of the measuring device
User interface	Character string comprising numbers, letters and special characters

IP address



Navigation	 System → Connectivity → Ethernet → IP address
Description	Enter the IP address of the device. Then accept the change with "Apply".
User entry	Character string comprising numbers, letters and special characters (15)
Factory setting	192.168.1.212

Subnet mask



Navigation	System → Connectivity → Ethernet → Subnet mask
Description	Enter subnet mask of the device. Then accept the change with "Apply".
User entry	Character string comprising numbers, letters and special characters (15)
Factory setting	255.255.255.0

Default gateway



Navigation	System → Connectivity → Ethernet → Default gateway
Description	Enter IP address for the default gateway of the device.. Then accept the change with "Apply".
User entry	Character string comprising numbers, letters and special characters (15)
Factory setting	0.0.0.0

Service IP active

Navigation	System → Connectivity → Ethernet → Service IP act.
User interface	<ul style="list-style-type: none"> ■ No ■ Yes
Factory setting	No

Interface connection status

Navigation	System → Connectivity → Ethernet → Interface status
User interface	<ul style="list-style-type: none"> ■ Connected ■ Not connected
Factory setting	Not connected

Interface speed

Navigation	 System → Connectivity → Ethernet → Interface speed
User interface	Positive integer
Factory setting	0 MBaud

Duplex status

Navigation	 System → Connectivity → Ethernet → Duplex status
User interface	<ul style="list-style-type: none"> ▪ Full duplex ▪ Half duplex ▪ Unknown
Factory setting	Unknown

Auto negotiation status

Navigation	 System → Connectivity → Ethernet → Auto negot.stat.
User interface	<ul style="list-style-type: none"> ▪ Idle ▪ In progress ▪ Completed ▪ Failed ▪ Speed detection failed
Factory setting	Idle

Number of received packets

Navigation	 System → Connectivity → Ethernet → RX packet no.
User interface	Positive integer
Factory setting	0

Number of sent packets

Navigation	 System → Connectivity → Ethernet → TX packet number
User interface	Positive integer
Factory setting	0

Number of failed received packets

Navigation	 System → Connectivity → Ethernet → FailRcvdPackets
User interface	Positive integer
Factory setting	0

Number of failed sent packets

Navigation	 System → Connectivity → Ethernet → No.FailTXPackets
User interface	Positive integer
Factory setting	0

Reset Ethernet diagnostics



Navigation	 System → Connectivity → Ethernet → ResetEthernDiag.
Selection	<ul style="list-style-type: none"> ■ Cancel ■ Reset
Factory setting	Cancel
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: Expert

Signal to noise ratio

Navigation	 System → Connectivity → Ethernet → SNR
Description	Shows the signal to noise ratio of the Ethernet-APL connection. A value >21dB is good and >23dB is excellent.
User interface	Signed floating-point number
Factory setting	0 dB

Number of failed received packets

Navigation	 System → Connectivity → Ethernet → FailRXPackagesNo.
Description	Shows the number of failed received packets.
User interface	0 to 65 535
Factory setting	0

Active TCP connections

Navigation	 System → Connectivity → Ethernet → Act. TCP connec.
User interface	0 to 65 535
Factory setting	0

Supported TCP connections

Navigation	 System → Connectivity → Ethernet → Supported TCP
User interface	0 to 65 535
Factory setting	0

TCP connection requests

Navigation	 System → Connectivity → Ethernet → TCPConnecRequest
User interface	0 to 65 535

Factory setting 0

TCP connection timeouts

Navigation  System → Connectivity → Ethernet → TCPConnectTimeout

User interface 0 to 255

Factory setting 0

Number of TCP connections closed

Navigation  System → Connectivity → Ethernet → TCPConnect.close

User interface 0 to 255

Factory setting 0

Number of received TCP packets

Navigation  System → Connectivity → Ethernet → No.RX TCP Packet

User interface Positive integer

Factory setting 0

Number of sent TCP packets

Navigation  System → Connectivity → Ethernet → No.TX TCP packet

User interface Positive integer

Factory setting 0

Number of TCP failed received packets

Navigation  System → Connectivity → Ethernet → TCPFailRXPackets

User interface Positive integer

Factory setting 0

Available UDP ports

Navigation  System → Connectivity → Ethernet → Avail. UDP ports

User interface Positive integer

Factory setting 0

Number of received UDP packets

Navigation  System → Connectivity → Ethernet → No.RX UDP Packet

User interface Positive integer

Factory setting 0

Number of sent UDP packets

Navigation  System → Connectivity → Ethernet → No.TX UDP packet

User interface Positive integer

Factory setting 0

Number of UDP failed received packets

Navigation  System → Connectivity → Ethernet → UDPFailRXpackets

User interface Positive integer

Factory setting 0

3.4.4 Display

Navigation  System → Display

Language

Navigation  System → Display → Language

Description Set display language

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting English

Format display

Navigation  System → Display → Format display

Description Select how measured values are shown on the display

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values

Factory setting 1 value, max. size

* Visibility depends on order options or device settings

Value 1 display

**Navigation**

System → Display → Value 1 display

Description

Select the measured value that is shown on the local display

Selection

- Distance
- Level
- Level linearized
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Buildup index^{*}
- Foam index^{*}
- Alignment quality
- Electronics temperature
- Sensor temperature
- Unfiltered distance

Factory setting

Level

Value 2 ... 4 display

**Navigation**

System → Display → Value 2 display

Description

Select the measured value that is shown on the local display

Selection

- None
- Level
- Level linearized
- Distance
- Absolute echo amplitude
- Relative echo amplitude
- Area of incoupling
- Buildup index^{*}
- Foam index^{*}
- Alignment quality
- Electronics temperature
- Sensor temperature
- Unfiltered distance

Factory setting

None

* Visibility depends on order options or device settings

Decimal places 1 ... 4



Navigation	System → Display → Decimal places 1
Description	This selection does not affect the measurement and calculation accuracy of the device.
Selection	<ul style="list-style-type: none"> ■ x ■ x.X ■ x.XX ■ x.XXX ■ x.XXXX
Factory setting	x.xx

Contrast display

Navigation	System → Display → Contrast display
Description	Adjust local display contrast setting to ambient conditions (e.g. lighting or reading angle)
User entry	20 to 80 %
Factory setting	30 %

3.4.5 Date/time

Navigation System → Date/time

Date/time

Navigation	System → Date/time → Date/time
Description	Displays the date and time entered.
User interface	Character string comprising numbers, letters and special characters
Factory setting	01.01.1970 00:00:00

Time zone	
Navigation	  System → Date/time → Time zone
Description	Select the time zone. Every time the time zone is changed, a logbook entry is created.
Selection	<p><i>Other units</i></p> <ul style="list-style-type: none">■ UTC-12:00■ UTC-11:00■ UTC-10:00■ UTC-09:30■ UTC-09:00■ UTC-08:00■ UTC-07:00■ UTC-06:00■ UTC-05:00■ UTC-04:00■ UTC-03:30■ UTC-03:00■ UTC-02:30■ UTC-02:00■ UTC-01:00■ UTC 00:00■ UTC+01:00■ UTC+02:00■ UTC+03:00■ UTC+03:30■ UTC+04:00■ UTC+04:30■ UTC+05:00■ UTC+05:30■ UTC+05:45■ UTC+06:00■ UTC+06:30■ UTC+07:00■ UTC+08:00■ UTC+08:45■ UTC+09:00■ UTC+09:30■ UTC+10:00■ UTC+10:30■ UTC+11:00■ UTC+12:00■ UTC+12:45■ UTC+13:00■ UTC+13:45■ UTC+14:00
Factory setting	UTC 00:00

Enable NTP



Navigation  System → Date/time → Enable NTP

Selection
▪ No
▪ Yes

Factory setting No

NTP server address



Navigation  System → Date/time → NTP server add.

Description IP address of the NTP server.

User entry Character string comprising numbers, letters and special characters (64)

Factory setting 192.168.1.1

Clock synchronized

Navigation   System → Date/time → Clock synch.

Description Timestamp of last synchronization with an NTP server.

User interface Character string comprising numbers, letters and special characters

Factory setting -----

3.4.6 Geolocation

Navigation  System → Geolocation

Location description



Navigation   System → Geolocation → Location descr.

Description Enter a description for the location

User entry Character string comprising numbers, letters and special characters (32)

Factory setting somewhere

Longitude 

Navigation   System → Geolocation → Longitude

Description Enter the longitude.

User entry -180 to 180 °

Factory setting 0 °

Latitude 

Navigation   System → Geolocation → Latitude

Description Enter latitude

User entry -90 to 90 °

Factory setting 0 °

Altitude 

Navigation   System → Geolocation → Altitude

Description Enter altitude

User entry Signed floating-point number

Factory setting 0 m

3.4.7 Information

Navigation   System → Information

Device name

Navigation	  System → Information → Device name
Description	Use this function to display the device name. It can also be found on the nameplate.
User interface	Character string comprising numbers, letters and special characters
Factory setting	Micropilot

Manufacturer

Navigation	  System → Information → Manufacturer
User interface	Character string comprising numbers, letters and special characters
Factory setting	Endress+Hauser

Serial number

Navigation	  System → Information → Serial number
Description	The serial number is a unique alphanumeric code identifying the device. It is printed on the nameplate. In combination with the Operations app it allows to access all device related documentation.
User interface	Character string comprising numbers, letters and special characters

Order code

Navigation	  System → Information → Order code
Description	Shows the device order code.
User interface	Character string comprising numbers, letters and special characters

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: Expert
-------------------------------	--

Firmware version

Navigation	  System → Information → Firmware version
Description	Displays the device firmware version installed.
User interface	Character string comprising numbers, letters and special characters

Hardware version

Navigation	  System → Information → Hardware version
User interface	Character string comprising numbers, letters and special characters
Factory setting	01.00.00

Extended order code 1 ... 3

Navigation	 System → Information → Ext. order cd. 1
Description	The extended order code is an alphanumeric code containing all information to identify the device and its options.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Operator ■ Write access: Expert

XML build number

Navigation	  System → Information → XML build no.
User interface	Positive integer
Factory setting	480

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Checksum

Navigation	 System → Information → Checksum
Description	Checksum for Firmware version.
User interface	Positive integer
Factory setting	0

3.4.8 Additional information

Navigation  System → Additional info

Sensor

Navigation  System → Additional info → Sensor

Serial number

Navigation	 System → Additional info → Sensor → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Firmware version

Navigation	 System → Additional info → Sensor → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Build no. software

Navigation	 System → Additional info → Sensor → Build no. softw.
-------------------	--

Description	Shows the build number of the module firmware
--------------------	---

User interface	0 to 65 535
-----------------------	-------------

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Hardware version

Navigation	 System → Additional info → Sensor → Hardware version
-------------------	--

Description	Displays the hardware version of the module.
--------------------	--

User interface	Character string comprising numbers, letters and special characters
-----------------------	---

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Checksum

Navigation	 System → Additional info → Sensor → Checksum
-------------------	--

Description	Checksum for Firmware version.
--------------------	--------------------------------

User interface	Positive integer
-----------------------	------------------

Factory setting	0
------------------------	---

Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -
-------------------------------	---

Electronics

Navigation  System → Additional info → Electronics

Serial number

Navigation	 System → Additional info → Electronics → Serial number
Description	Shows the serial number of the module
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Firmware version

Navigation	 System → Additional info → Electronics → Firmware version
Description	Displays the firmware version of the module.
User interface	Positive integer
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Build no. software

Navigation	 System → Additional info → Electronics → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Hardware version

Navigation  System → Additional info → Electronics → Hardware version

Description Displays the hardware version of the module.

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**

- Read access: Expert
- Write access: -

Display/Bluetooth

Navigation  System → Additional info → Displ./Bluetooth

Serial number

Navigation  System → Additional info → Displ./Bluetooth → Serial number

Description Shows the serial number of the module

User interface Character string comprising numbers, letters and special characters

Additional information **Access:**

- Read access: Expert
- Write access: -

Firmware version

Navigation  System → Additional info → Displ./Bluetooth → Firmware version

Description Displays the firmware version of the module.

User interface Positive integer

Additional information **Access:**

- Read access: Expert
- Write access: -

Build no. software

Navigation	 System → Additional info → Displ./Bluetooth → Build no. softw.
Description	Shows the build number of the module firmware
User interface	0 to 65 535
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

Hardware version

Navigation	 System → Additional info → Displ./Bluetooth → Hardware version
Description	Displays the hardware version of the module.
User interface	Character string comprising numbers, letters and special characters
Additional information	Access: <ul style="list-style-type: none"> ■ Read access: Expert ■ Write access: -

3.4.9 Software configuration

Navigation  System → Softw. config.

CRC device configuration

Navigation	 System → Softw. config. → CRC device conf.
Description	CRC device configuration based on current settings of safety relevant parameters. The CRC device configuration is unique and can be used to detect changes in safety relevant parameter settings.
User interface	0 to 65 535

Activate SW option

**Navigation** System → Softw. config. → Activate SW opt.**Description**

Enter the application package code or code of another re-ordered functionality to enable it

User entryPositive integer

Software option overview

Navigation System → Softw. config. → SW option overv.**Description**

Shows all enabled software options

User interface

- Heartbeat Verification
- Heartbeat Monitoring



71679501

www.addresses.endress.com
