

Description of Device Parameters

Proline Prosonic Flow 200

HART

Ultrasonic time-of-flight flowmeter




Table of contents

1	Document information	4		
1.1	Document function	4		
1.2	Target group	4		
1.3	Using this document	4		
1.3.1	Information on the document structure	4		
1.3.2	Structure of a parameter description	6		
1.4	Symbols used	6		
1.4.1	Symbols for certain types of information	6		
1.4.2	Symbols in graphics	7		
2	Overview of the Expert operating menu	8		
3	Description of device parameters	11		
3.1	"System" submenu	14		
3.1.1	"Display" submenu	14		
3.1.2	"Configuration backup display" submenu	27		
3.1.3	"Diagnostic handling" submenu	31		
3.1.4	"Administration" submenu	39		
3.2	"Sensor" submenu	44		
3.2.1	"Measured values" submenu	45		
3.2.2	"System units" submenu	58		
3.2.3	"Process parameters" submenu	74		
3.2.4	"Measurement mode" submenu	78		
3.2.5	"External compensation" submenu	82		
3.2.6	"Calculated values" submenu	84		
3.2.7	"Sensor adjustment" submenu	86		
3.2.8	"Calibration" submenu	91		
3.2.9	"Properties" submenu	92		
3.3	"Input" submenu	94		
3.3.1	"Current input" submenu	94		
3.4	"Output" submenu	96		
3.4.1	"Current output 1 to 2" submenu	96		
3.4.2	"Pulse/frequency/switch output" submenu	111		
3.5	"Communication" submenu	127		
3.5.1	"HART input" submenu	127		
3.5.2	"HART output" submenu	133		
3.5.3	"Diagnostic configuration" submenu	149		
3.6	"Application" submenu	157		
3.6.1	"Totalizer 1 to 3" submenu	157		
3.7	"Diagnostics" submenu	162		
3.7.1	"Diagnostic list" submenu	165		
3.7.2	"Event logbook" submenu	169		
3.7.3	"Device information" submenu	171		
3.7.4	"Mainboard module" submenu	175		
3.7.5	"I/O module" submenu	175		
3.7.6	"Display module" submenu	176		
3.7.7	"Data logging" submenu	176		
3.7.8	"Min/max values" submenu	182		
3.7.9	"Heartbeat" submenu	188		
3.7.10	"Simulation" submenu	189		
4	Country-specific factory settings	197		
4.1	SI units	197		
4.1.1	System units	197		
4.1.2	Full scale values	197		
4.1.3	Output current span	197		
4.1.4	On value low flow cut off	197		
4.2	US units	198		
4.2.1	System units	198		
4.2.2	Full scale values	198		
4.2.3	Output current span	198		
4.2.4	On value low flow cut off	199		
5	Explanation of abbreviated units	200		
5.1	SI units	200		
5.2	US units	200		
5.3	Imperial units	201		
	Index	202		

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document

1.3.1 Information on the document structure


The document lists the submenus and their parameters according to the structure from the **Expert** menu (→ 8).



A0022576-EN

1 Sample graphic

For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→ 162), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

1.3.2 **Structure of a parameter description**

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code)  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Options	List of the individual options for the parameter ■ Option 1 ■ Option 2
User entry	Input range for the parameter
User interface	User interface value/data for parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): ■ On individual options ■ On display values/data ■ On the input range ■ On the factory setting ■ On the parameter function

1.4 **Symbols used**

1.4.1 **Symbols for certain types of information**

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

 Expert		
Direct access (0106)	→ 	11
Locking status (0004)	→ 	12
Access status display (0091)	→ 	12
Enter access code (0092)	→ 	14
▶ System	→ 	14
▶ Display	→ 	14
▶ Configuration backup display	→ 	27
▶ Diagnostic handling	→ 	31
▶ Administration	→ 	39
▶ Sensor	→ 	44
▶ Measured values	→ 	45
▶ System units	→ 	58
▶ Process parameters	→ 	74
▶ Measurement mode	→ 	78
▶ External compensation	→ 	82
▶ Calculated values	→ 	84
▶ Sensor adjustment	→ 	86
▶ Calibration	→ 	91
▶ Properties	→ 	92
▶ Input	→ 	94
▶ Current input	→ 	94

► Output	→ 96
► Current output 1	→ 96
► Current output 2	→ 96
► Pulse/frequency/switch output	→ 111
► Communication	→ 127
► HART input	→ 127
► HART output	→ 133
► Diagnostic configuration	→ 149
► Application	→ 157
Reset all totalizers (2806)	→ 157
► Totalizer 1 to 3	→ 157
► Diagnostics	→ 162
Actual diagnostics (0691)	→ 163
Previous diagnostics (0690)	→ 164
Operating time from restart (0653)	→ 165
Operating time (0652)	→ 165
► Diagnostic list	→ 165
► Event logbook	→ 169
► Device information	→ 171
► Mainboard module	→ 175
► I/O module	→ 175
► Display module	→ 176
► Data logging	→ 176
► Min/max values	→ 182

▶ Heartbeat	→  188
▶ Simulation	→  189

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert		
Direct access (0106)	→	11
Locking status (0004)	→	12
Access status display (0091)	→	12
Enter access code (0092)	→	14
► System	→	14
► Sensor	→	44
► Input	→	94
► Output	→	96
► Communication	→	127
► Application	→	157
► Diagnostics	→	162

Direct access

Navigation	Expert → Direct access (0106)
Description	Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears on the right in the header of the selected parameter in the navigation view.
User entry	0 to 65 535

Additional information	<i>User entry</i> The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1  The leading zeros in the direct access code do not have to be entered. Example: Input of "914" instead of "0914" ■ If no channel number is entered, channel 1 is jumped to automatically. Example: Input of 0914 → Assign process variable parameter ■ If a different channel is jumped to: Enter the direct access code with the corresponding channel number. Example: Input of 0914-3 → Assign process variable parameter
Locking status	
Navigation	 Expert → Locking status (0004)
Description	Use this function to view the active write protection.
User interface	■ Hardware locked ■ Temporarily locked
Additional information	<i>User interface</i> If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are selected.  The -symbol appears in front of parameters that cannot be modified due to write protection. <i>"Hardware locked" option (priority 1)</i> The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).  Information on disabling hardware write protection is provided in the "Write protection via the locking DIP switch" section of the Operations Instructions for the device. <i>"Temporarily locked" option (priority 3)</i> Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Access status display

Navigation	 Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Use this function to view the access authorization to the parameters via the local display.

User interface	■ Operator ■ Maintenance
Factory setting	Operator
Additional information	<i>Description</i> If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.  The access authorization can be modified via the Enter access code parameter (→  14).  For information on the Enter access code parameter (→  14), see the "Disabling write protection via access code" section of the Operating Instructions for the device  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12). <i>User interface</i>  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Access status tooling

Navigation	 Expert → Access stat.tool (0005)
Description	Use this function to view the access authorization to the parameters via the operating tool.
User interface	■ Operator ■ Maintenance
Factory setting	Maintenance
Additional information	<i>Description</i>  The access authorization can be modified via the Enter access code parameter (→  14).  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12). <i>User interface</i>  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Enter access code

Navigation	 Expert → Ent. access code (0092)
Description	Use this function to enter the user-specific release code to remove parameter write protection on the local display.
User entry	0 to 9 999

Enter access code

Navigation	 Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.
User entry	0 to 9 999

3.1 "System" submenu

Navigation   Expert → System

► System	
► Display	→  14
► Configuration backup display	→  27
► Diagnostic handling	→  31
► Administration	→  39

3.1.1 "Display" submenu

Navigation   Expert → System → Display

► Display	
Language (0104)	→  15
Format display (0098)	→  16
Value 1 display (0107)	→  18

0% bargraph value 1 (0123)	→  18
100% bargraph value 1 (0125)	→  19
Decimal places 1 (0095)	→  19
Value 2 display (0108)	→  20
Decimal places 2 (0117)	→  20
Value 3 display (0110)	→  21
0% bargraph value 3 (0124)	→  21
100% bargraph value 3 (0126)	→  22
Decimal places 3 (0118)	→  22
Value 4 display (0109)	→  23
Decimal places 4 (0119)	→  23
Display interval (0096)	→  24
Display damping (0094)	→  24
Header (0097)	→  24
Header text (0112)	→  25
Separator (0101)	→  26
Contrast display (0105)	→  26
Backlight (0111)	→  26
Access status display (0091)	→  27

Language

Navigation

  Expert → System → Display → Language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English *
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting

English (alternatively, the ordered language is preset in the device)

Format display

Navigation

 Expert → System → Display → Format display (0098)

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.




- The **Value 1 display** parameter (→  18)...**Value 4 display** parameter (→  23) parameters are used to specify which measured values are shown on the display and in which order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (→  24) parameter.


Possible measured values shown on the local display:

* Visibility depends on order options or device settings


"1 value, max. size" option



"1 bargraph + 1 value" option




"2 values" option




3

"1 value large + 2 values" option



"4 values" option



Value 1 display	
Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Temperature * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Current output 1 ■ Current output 2 * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *
Factory setting	Volume flow
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how. <i>Options</i> The unit of the displayed measured value is taken from the System units submenu (→ 58).
0% bargraph value 1	

Navigation Expert → System → Display → 0% bargraph 1 (0123)

Prerequisite A local display is provided.

* Visibility depends on order options or device settings

Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m³/h ■ 0 ft³/h
Additional information	<i>Description</i>  The Format display parameter (→  16) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

100% bargraph value 1



Navigation	  Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter →  197
Additional information	<i>Description</i>  The Format display parameter (→  16) is used to specify that the measured value is to be displayed as a bar graph. <i>Options</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Decimal places 1



Navigation	  Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is specified in the Value 1 display parameter (→  18).
Description	Use this function to select the number of decimal places for measured value 1.

Selection	■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX
Factory setting	X.XX
Additional information	<i>Description</i>  This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display



Navigation	 Expert → System → Display → Value 2 display (0108)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist see Value 1 display parameter (→  18)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.  The Format display parameter (→  16) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Decimal places 2



Navigation	 Expert → System → Display → Decimal places 2 (0117)
Prerequisite	A measured value is specified in the Value 2 display parameter (→  20).
Description	Use this function to select the number of decimal places for measured value 2.
Selection	■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX

Factory setting x.xx

Additional information *Description*



This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation  Expert → System → Display → Value 3 display (0110)

Prerequisite A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection Picklist see **Value 1 display** parameter (→  18)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→  16) is used to specify how many measured values are displayed simultaneously and how.

Selection



The unit of the displayed measured value is taken from the **System units** submenu (→  58).

0% bargraph value 3

Navigation  Expert → System → Display → 0% bargraph 3 (0124)

Prerequisite A selection has been made in the **Value 3 display** parameter (→  21).

Description Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

User entry Signed floating-point number

Factory setting Country-specific:
 ■ 0 m³/h
 ■ 0 ft³/h

Additional information *Description*



The **Format display** parameter (→  16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→  58).

100% bargraph value 3

Navigation	  Expert → System → Display → 100% bargraph 3 (0126)
Prerequisite	An option was selected in the Value 3 display parameter (→  21).
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter →  197
Additional information	<i>Description</i>  The Format display parameter (→  16) is used to specify that the measured value is to be displayed as a bar graph. <i>Options</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Decimal places 3

Navigation	  Expert → System → Display → Decimal places 3 (0118)
Prerequisite	A measured value is specified in the Value 3 display parameter (→  21).
Description	Use this function to select the number of decimal places for measured value 3.
Selection	■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx
Factory setting	x.xx
Additional information	<i>Description</i>  This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display

Navigation	 Expert → System → Display → Value 4 display (0109)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist see Value 1 display parameter (→  18)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.  The Format display parameter (→  16) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Decimal places 4

Navigation	 Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (→  23).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx
Factory setting	x.xx
Additional information	<i>Description</i>  This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation	 Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s
Factory setting	5 s
Additional information	<i>Description</i> This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously. ■ The Value 1 display parameter (→  18)...Value 4 display parameter (→  23) are used to specify which measured values are shown on the display. ■ The display format of the displayed measured values is specified using the Format display parameter (→  16).

Display damping




Navigation	 Expert → System → Display → Display damping (0094)
Prerequisite	A local display is provided.
Description	Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	3.0 s
Additional information	<i>User entry</i> A time constant is entered: ■ If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables. ■ On the other hand, the display reacts more slowly if a high time constant is entered.

Header



Navigation	 Expert → System → Display → Header (0097)
Prerequisite	A local display is provided.
Description	Use this function to select the contents of the header of the local display.

Selection	■ Device tag ■ Free text
Factory setting	Device tag
Additional information	Description The header text only appears during normal operation.




A0013375

1 Position of the header text on the display

- Selection
- Device tag
Is defined in the **Device tag** parameter (→  171).
- Free text
Is defined in the **Header text** parameter (→  25).

Header text

Navigation	 Expert → System → Display → Header text (0112)
Prerequisite	The Free text option is selected in the Header parameter (→  24).
Description	Use this function to enter a customer-specific text for the header of the local display.
User entry	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	-----
Additional information	Description The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator		
Navigation	  Expert → System → Display → Separator (0101)	
Prerequisite	A local display is provided.	
Description	Use this function to select the decimal separator.	
Selection	▪ . (point) ▪ , (comma)	
Factory setting	. (point)	

Contrast display	
Navigation	  Expert → System → Display → Contrast display (0105)
Prerequisite	A local display is provided.
Description	Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).
User entry	20 to 80 %
Factory setting	Depends on the display
Additional information	<i>Set the contrast via the push-buttons:</i> ▪ Brighter: Press and hold down the   keys simultaneously. ▪ Darker: Press and hold down the   keys simultaneously.

Backlight	
Navigation	  Expert → System → Display → Backlight (0111)
Prerequisite	Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"
Description	Option for switching the backlight of the local display on and off.
Selection	▪ Disable ▪ Enable
Factory setting	Disable

Access status display

Navigation	 Expert → System → Display → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Use this function to view the access authorization to the parameters via the local display.
User interface	■ Operator ■ Maintenance
Factory setting	Operator
Additional information	<i>Description</i> If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.  The access authorization can be modified via the Enter access code parameter (→  14).  For information on the Enter access code parameter (→  14), see the "Disabling write protection via access code" section of the Operating Instructions for the device  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12). <i>User interface</i>  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1.2 "Configuration backup display" submenu

Navigation  Expert → System → Conf.backup disp

► Configuration backup display		
Operating time (0652)		→  28
Last backup (0102)		→  28
Configuration management (0100)		→  28
Comparison result (0103)		→  30

Operating time	
Navigation	 Expert → System → Conf.backup disp → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.
Last backup	
Navigation	 Expert → System → Conf.backup disp → Last backup (0102)
Prerequisite	A local display is provided.
Description	Use this function to display the time since a backup copy of the data was last saved to the display module.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Configuration management 	
Navigation	 Expert → System → Conf.backup disp → Config. managem. (0100)
Prerequisite	A local display is provided.
Description	Use this function to select an action to save the data to the display module.
Selection	■ Cancel ■ Execute backup ■ Restore ■ Duplicate ■ Compare ■ Clear backup data
Factory setting	Cancel
Additional information	<i>Description</i> Configuration via the local display is disabled while the action is performed.  For information on the status message in the operating tool, see the Backup state parameter (→  29)

Selection

- **Cancel**
No action is executed and the user exits the parameter.
- **Execute backup**
 - A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.
 - The following message appears on local display: Backup active, please wait!
- **Restore**
 - The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device.
 - The following message appears on local display: Restore active! Do not interrupt power supply!
- **Duplicate**
 - The transmitter configuration from another device is duplicated to the device using the display module.
 - The following message appears on local display: Copy active! Do not interrupt power supply!
- **Compare**
 - The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
 - The following message appears on local display: Comparing files
 - The result can be viewed in the **Comparison result** parameter (→  30).
- **Clear backup data**
 - The backup copy of the device configuration is deleted from the display module of the device.
 - The following message appears on local display: Deleting file

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state

Navigation	 Expert → System → Conf.backup disp → Backup state (0121)
Prerequisite	A local display is provided.
Description	Use this function to view the status of the data backup process.
User interface	■ None ■ Store in progress ■ Restore in progress ■ Import in progress ■ Delete in progress ■ Compare in progress
Factory setting	None

Comparison result	
Navigation	 Expert → System → Conf.backup disp → Compar. result (0103)
Prerequisite	A local display is provided.
Description	Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.
User interface	■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible
Factory setting	Check not done
Additional information	<i>Description</i>  The comparison is started via the Compare option in the Configuration management parameter (→  28). <i>Selection</i> ■ Settings identical – The current device configuration of the HistoROM is identical to the backup copy in the display module. – If the transmitter configuration of another device has been copied to the device via the display module and the Duplicate option in the Configuration management parameter (→  28), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical. ■ Settings not identical The current device configuration of the HistoROM is not identical to the backup copy in the display module. ■ No backup available There is no backup copy of the device configuration of the HistoROM in the display module. ■ Backup settings corrupt The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module. ■ Check not done The device configuration of the HistoROM has not yet been compared to the backup copy in the display module. ■ Dataset incompatible The backup copy in the display module is not compatible with the device. <i>HistoROM</i> A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagnostic handling" submenu

Navigation  Expert → System → Diagn. handling

► Diagnostic handling		
Alarm delay (0651)	→ 	31
► Diagnostic behavior	→ 	32

Alarm delay

Navigation	 Expert → System → Diagn. handling → Alarm delay (0651)
Description	Use this function to enter the time interval until the device generates a diagnostic message.
User entry	0 to 60 s
Factory setting	0 s
Additional information	Description This setting affects the following diagnostic messages: ■ 452 Calculation error ■ 832 Electronic temperature too high ■ 833 Electronic temperature too low ■ 834 Process temperature too high ■ 835 Process temperature too low ■ 836 Process pressure ■ 837 Process pressure ■ 841 Sensor range ■ 930 Process fluid ■ 931 Process fluid

"Diagnostic behavior" submenu

For a list of all the diagnostic events, see the Operating Instructions for the device.



Modifying the diagnostic behavior of a diagnostic event. Each diagnostic event is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostics events.

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

- **Off** option

The diagnostic event is ignored; it is neither entered into the Event logbook, nor is a diagnostic message generated.

- **Alarm** option

The device continues to measure. The signal outputs assume the defined alarm condition. A diagnostic message is generated.

- **Warning** option

The device continues to measure. A diagnostic message is generated.

- **Logbook entry only** option

The device continues to measure. The diagnostic message is entered in the **Event logbook** submenu (→  169) (**Event list** submenu (→  170)) only and is not displayed in alternation with the measured value display.

Navigation



Expert → System → Diagn. handling → Diagn. behavior

► Diagnostic behavior	
Assign behavior of diagnostic no. 123 (0773)	→  33
Assign behavior of diagnostic no. 124 (0774)	→  33
Assign behavior of diagnostic no. 125 (0775)	→  34
Assign behavior of diagnostic no. 160 (0776)	→  34
Assign behavior of diagnostic no. 441 (0657)	→  34
Assign behavior of diagnostic no. 442 (0658)	→  35
Assign behavior of diagnostic no. 443 (0659)	→  35
Assign behavior of diagnostic no. 452 (0713)	→  36
Assign behavior of diagnostic no. 444 (0740)	→  36
Assign behavior of diagnostic no. 801 (0660)	→  36

Assign behavior of diagnostic no. 832 (0675)	→  37
Assign behavior of diagnostic no. 833 (0676)	→  37
Assign behavior of diagnostic no. 834 (0677)	→  37
Assign behavior of diagnostic no. 835 (0678)	→  38
Assign behavior of diagnostic no. 837 (0714)	→  38
Assign behavior of diagnostic no. 841 (0680)	→  38
Assign behavior of diagnostic no. 881 (0724)	→  39

Assign behavior of diagnostic no. 123 (Predicted signal strength)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 123 (0773)
Description	Use this function to change the diagnostic behavior of the diagnostic message 123 Predicted signal strength .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 124 (Relative signal strength)



Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 124 (0774)
Description	Use this function to change the diagnostic behavior of the diagnostic message 124 Relative signal strength .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 125 (Relative sound velocity)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 125 (0775)

Description

Use this function to change the diagnostic behavior of the diagnostic message **125 Relative sound velocity**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 160 (Signal path switched off)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 160 (0776)

Description

Use this function to change the diagnostic behavior of the diagnostic message **160 Signal path switched off**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 441 (Current output 1 to 2)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)

Description

Use this function to change the diagnostic behavior of the diagnostic message **441 Current output 1 to 2**.

Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 442 (Frequency output)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 442 Frequency output .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 443 (Pulse output)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)
Prerequisite	The measuring device has a pulse/frequency/switch output.
Description	Use this function to change the diagnostic behavior of the diagnostic message 443 Pulse output .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 452 (Calculation error)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 452 (0713)
Description	Use this function to change the diagnostic behavior of the diagnostic message 452 Calculation error .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 444 (Current input 1)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 444 (0740)
Prerequisite	The device has one current input (I/O module 218).
Description	Use this function to change the diagnostic behavior of the diagnostic message 444 Current input 1 .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 801 (Supply voltage too low)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 801 (0660)
Description	Use this function to change the diagnostic behavior of the diagnostic message 801 Supply voltage too low .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning

Additional information  For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 832 (Electronic temperature too high)



Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

Description Use this function to change the diagnostic behavior of the diagnostic message **832 Electronic temperature too high.**

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 833 (Electronic temperature too low)



Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)

Description Use this function to change the diagnostic behavior of the diagnostic message **833 Electronic temperature too low.**

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 834 (Process temperature too high)



Navigation   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)

Description Use this function to change the diagnostic behavior of the diagnostic message **834 Process temperature too high.**

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 835 (Process temperature too low)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)

DescriptionUse this function to change the diagnostic behavior of the diagnostic message **835 Process temperature too low**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 837 (Process pressure)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 837 (0714)

DescriptionUse this function to change the diagnostic behavior of the diagnostic message **837 Process pressure**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 841 (Sensor range)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 841 (0680)

DescriptionUse this function to change the diagnostic behavior of the diagnostic message **841 Sensor range**.

Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

Assign behavior of diagnostic no. 881 (Sensor signal path 1 to 2)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 881 (0724)
Description	Use this function to change the diagnostic behavior of the diagnostic message 881 Sensor signal path 1 to 2 .
Selection	■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: →  32

3.1.4 "Administration" submenu

Navigation  Expert → System → Administration

► Administration

► Define access code

Device reset (0000)

Activate SW option (0029)

Software option overview (0015)

Activate sensor emergency mode (5610)

→  40

→  42

→  42

→  43

→  43

"Define access code" wizard

 The **Define access code** wizard is only available if you are operating via the local display. If you are operating via the operating tool, the **Define access code** parameter (→  41) is directly in the **Administration** submenu. The **Confirm access code** parameter is not available if you are operating via the operating tool.

Navigation  Expert → System → Administration → Def. access code

► Define access code

Define access code

→  40

Confirm access code

→  41

Define access code

Navigation	 Expert → System → Administration → Def. access code → Def. access code
Description	Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.
User entry	0 to 9 999
Factory setting	0
Additional information	<i>Description</i> The write protection affects all parameters in the document marked with the  symbol. On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.  Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Enter access code parameter (→  14).  Please contact your Endress+Hauser Sales Center if you lose your access code. <i>User entry</i> A message is displayed if the access code is not in the input range. <i>Factory setting</i> If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "Maintenance" role.

Confirm access code 	
Navigation	 Expert → System → Administration → Def. access code → Confirm code
Description	Enter the defined release code a second time to confirm the release code.
User entry	0 to 9999
Factory setting	0

Additional parameters in the "Administration" submenu

Define access code 	
Navigation	 Expert → System → Administration → Def. access code (0093)
Description	Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.
User entry	0 to 9999
Factory setting	0
Additional information	<i>Description</i> The write protection affects all parameters in the document marked with the  symbol.  Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Enter access code parameter (→  14).  Please contact your Endress+Hauser Sales Center if you lose your access code. <i>User entry</i> A message is displayed if the access code is not in the input range. <i>Factory setting</i> If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "Maintenance" role.

Device reset 	
Navigation	 Expert → System → Administration → Device reset (0000)
Description	Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.
Selection	■ Cancel ■ To factory defaults ■ To delivery settings ■ Restart device
Factory setting	Cancel
Additional information	<i>"Cancel" option</i> No action is executed and the user exits the parameter.
	<i>"To factory defaults" option</i> Every parameter is reset to its factory setting.
	<i>"To delivery settings" option</i> Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
	 This option is not visible if no customer-specific settings have been ordered.
	<i>"Restart device" option</i> The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
Activate SW option 	
Navigation	 Expert → System → Administration → Activate SW opt. (0029)
Description	Use this function to enter an activation code to enable an additional, ordered software option.
User entry	Positive integer
Factory setting	0
Additional information	<i>User entry</i>  Endress+Hauser provides the corresponding activation code for the software option with the order.
	<i>Example</i> Order code for "Application package", option EA "Extended HistoROM"

Software option overview

Navigation	 Expert → System → Administration → SW option overv. (0015)
Description	Use this function to display all the software options that are enabled in the device.
User interface	■ Extended HistoROM ■ Heartbeat Verification ■ Heartbeat Monitoring
Additional information	<i>Description</i> Displays all the options that are available if ordered by the customer. <i>"Extended HistoROM" option</i> Order code for "Application Package", option EA "Extended HistoROM" <i>"Heartbeat Verification" option and "Heartbeat Monitoring" option</i> Order code for "Application Package", option EB "Heartbeat Verification + Monitoring"

Activate sensor emergency mode



Navigation	 Expert → System → Administration → Sens. emerg.mode (5610)
Prerequisite	The device has identified an error during verification of the characteristics in the sensor data storage or electronics module. A diagnostic message of status type ⊗F is output.
Description	Use this function to switch on the emergency mode of the sensor to use the backup of the sensor characteristics or main electronics characteristics stored in the HistoROM.
Selection	■ Cancel ■ Ok
Factory setting	Cancel
Additional information	<i>Description</i> The status signal of the output diagnostic message changes from F (failure) to M (maintenance required), the diagnostic behavior changes from Alarm to Warning: ΔM. The diagnostic message is output until the characteristics in the sensor data storage are again correct.  Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.  Information on status signals and diagnostic behavior: Operating Instructions about the device, "Diagnostic message" chapter

Reset write protection



Navigation	 Expert → System → Administration → Res. write prot. (0019)
Prerequisite	The SIL mode has been enabled.
Description	Use this function to enter the SIL locking code to disable write protection in the SIL mode.
User entry	0 to 65 535
Factory setting	0
Additional information	<i>Prerequisite</i>  For detailed information about enabling and disabling the SIL mode, see the Special Documentation for the device <i>Description</i>  Once the SIL mode has been activated, the process-related parameters are write protected, and thereby locked, for security reasons. It is still possible to read the parameters. When SIL locking is enabled, restrictions apply on all communication options, such as the service interface, the HART protocol and the onsite display.

3.2 "Sensor" submenu

Navigation  Expert → Sensor

► Sensor	
► Measured values	→  45
► System units	→  58
► Process parameters	→  74
► Measurement mode	→  78
► External compensation	→  82
► Calculated values	→  84
► Sensor adjustment	→  86
► Calibration	→  91
► Properties	→  92

3.2.1 "Measured values" submenu

Navigation  Expert → Sensor → Measured val.

► Measured values		
► Process variables	→ 	45
► System values	→ 	50
► Totalizer	→ 	53
► Input values	→ 	54
► Output values	→ 	55

"Process variables" submenu

Navigation  Expert → Sensor → Measured val. → Process variab.

► Process variables		
Volume flow (1838)	→ 	46
Corrected volume flow (1847)	→ 	46
Corrected methane volume flow (1850)	→ 	46
Mass flow (1872)	→ 	47
Energy flow (1851)	→ 	47
Dry methane in % (1852)	→ 	47
Calorific value (1853)	→ 	48
Wobbe index (1854)	→ 	48
Temperature (1857)	→ 	49
Sound velocity (1863)	→ 	49
Flow velocity (1864)	→ 	49

Volume flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)

Description Use this function to view the volume flow currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Volume flow unit** parameter (→  58)

Corrected volume flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1847)

Description Displays the corrected volume flow currently calculated.

User interface Signed floating-point number

Additional information *Description*

The corrected volume flow is derived from the measured volume flow corrected to the selected reference conditions.

Dependency

 The unit is taken from the **Corrected volume flow unit** parameter (→  60)

Corrected methane volume flow

Navigation  Expert → Sensor → Measured val. → Process variab. → Corr CH4 volflow (1850)

Prerequisite For the following order code:
"Sensor version", option 2 "Volume flow + biogas analysis"

Description Displays the methane corrected volume flow currently calculated.

User interface Signed floating-point number

Additional information *Description*

The methane corrected volume flow is calculated from the measured methane volume flow corrected to the selected reference conditions.

Dependency

 The unit is taken from the **Corrected volume flow unit** parameter (→  60)

Mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Mass flow (1872)
Description	Displays the mass flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→  61)

Energy flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Energy flow (1851)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Displays the energy flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Description</i> It is derived from the measured corrected methane volume flow and the quantity of heat that is released when the methane is burned under reference combustion conditions. This value refers to the gross calorific value (sometimes called gross energy or upper heating value or higher calorific value) or net calorific value (sometimes called net energy or lower heating value or lower calorific value). <i>Dependency</i>  The unit is taken from the Energy flow unit parameter (→  62)

Dry methane in %

Navigation	 Expert → Sensor → Measured val. → Process variab. → Dry CH ₄ in % (1852)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Displays the methane fraction of the dry gas currently measured.
User interface	Signed floating-point number

Calorific value

Navigation	 Expert → Sensor → Measured val. → Process variab. → Calorific value (1853)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Displays the calorific value currently calculated.
User interface	Signed floating-point number
Additional information	<i>Description</i> The calorific value is equivalent to the quantity of heat that is released when the methane fraction is burned under predefined reference combustion conditions. This value refers to the gross calorific value (sometimes called gross energy or upper heating value or higher calorific value) or net calorific value (sometimes called net energy or lower heating value or lower calorific value). <i>Dependency</i>  The unit is taken from the Calorific value unit parameter (→  64)

Wobbe index

Navigation	 Expert → Sensor → Measured val. → Process variab. → Wobbe index (1854)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Displays the Wobbe index currently calculated.
User interface	Signed floating-point number
Additional information	<i>Description</i> The Wobbe index compares the combustion energy output of different composition fuel gases in an appliance. If two fuels have identical Wobbe Indices then for given pressure and valve settings the energy output will also be identical. The Wobbe index is the ratio of the calorific value (heating value) and the square root of the gases' relative density (often called specific gravity). The relative density is the ratio of the density of the gas and the density of dry air under the same pressure and temperature conditions. This index refers to the gross calorific value (sometimes called gross energy or upper heating value or higher calorific value) or net calorific value (sometimes called net energy or lower heating value or lower calorific value). <i>Dependency</i>  The unit is taken from the Calorific value unit parameter (→  64)

Temperature

Navigation  Expert → Sensor → Measured val. → Process variab. → Temperature (1857)

Prerequisite For the following order code:
"Sensor version", option 2 "Volume flow + biogas analysis"

Description Displays the temperature currently calculated.

User interface Signed floating-point number

Additional information *Dependency*
 The unit is taken from the **Temperature unit** parameter (→  65).

Sound velocity

Navigation  Expert → Sensor → Measured val. → Process variab. → Sound velocity (1863)

Description Displays the sound velocity currently measured.

User interface Signed floating-point number

Additional information *Limit value*
The value should be between 250 to 500 m/s (820 to 1 640 ft/s). In the two-path version, this value corresponds to the average of the individual sound velocity values measured.

Dependency
 The unit is taken from the **Velocity unit** parameter (→  66)

Flow velocity

Navigation  Expert → Sensor → Measured val. → Process variab. → Flow velocity (1864)

Description Displays the flow velocity currently calculated.

User interface Signed floating-point number

Additional information *Limit value*
The value should be between -1 to +30 m/s (-3.3 to +98 ft/s).

Dependency
 The unit is taken from the **Velocity unit** parameter (→  66)

"System values" submenu

Navigation  Expert → Sensor → Measured val. → System values

► System values		
Signal strength	→ 	50
Signal to noise ratio	→ 	50
Acceptance rate	→ 	51
Asymmetry	→ 	51
Turbulence	→ 	51
Sound velocity	→ 	52
Flow velocity	→ 	52
Methane fraction of wet gas	→ 	52

Signal strength

Navigation	 Expert → Sensor → Measured val. → System values → Signal strength (5650)
Description	Use this function to display the current signal strength.
User interface	Signed floating-point number
Additional information	<i>Description</i> A drop in the signal strength over time can be an indicator of deposit buildup on the converter or high ultrasonic damping in the gas. A very fast drop is an indication of a high concentration of CO₂.

Signal to noise ratio

Navigation	 Expert → Sensor → Measured val. → System values → SNR (5656)
Description	Displays the current signal to noise ratio.
User interface	Signed floating-point number
Additional information	<i>Description</i> A low value or a drop in the signal to noise ratio over time is an indicator of poor signal quality. A rapid drop indicates a high concentration of CO₂.

Acceptance rate

Navigation	  Expert → Sensor → Measured val. → System values → Acceptance rate (5601)
Description	Displays the acceptance rate currently measured.
User interface	0 to 100 %
Additional information	<i>Limit values</i> The acceptance rate under ideal operating conditions is from 80 to 100 %. An acceptance rate from 50 to 80 % is still within the specified range of the measuring device. However, the operating conditions are only close to ideal, or else a fault is present. If the acceptance rate is below 50 %, the operating conditions are significantly below the ideal values. This indicates that faults are present or that the operating conditions are not ideal.

Asymmetry

Navigation	  Expert → Sensor → Measured val. → System values → Asymmetry (5605)
Prerequisite	The Dual path sensor option is selected in the Path configuration parameter (→  93).
Description	Displays the asymmetry of the measured values between signal path 1 and signal path 2.
User interface	Signed floating-point number
Factory setting	0 %
Additional information	<i>Limit values</i> if the value 0 is displayed, both measured values are the same. The higher the displayed value, the greater the difference between the two measured values of the signal paths.

Turbulence

Navigation	  Expert → Sensor → Measured val. → System values → Turbulence (5661)
Description	Displays the current turbulence.
User interface	Signed floating-point number

Sound velocity

Navigation	 Expert → Sensor → Measured val. → System values → Sound velocity (5658)
Description	Use this function to view the sound velocity currently measured.
User interface	Signed floating-point number
Additional information	<i>Limit value</i> The value should be between 250 and 500 m/s (820 to 1640 ft/s). In the two-path version, this value corresponds to the average of the individual sound velocity values measured. <i>Dependency</i>  The unit is taken from the Velocity unit parameter (→  66)

Flow velocity

Navigation	 Expert → Sensor → Measured val. → System values → Flow velocity (5622)
Description	Use this function to view the flow velocity currently calculated.
User interface	Signed floating-point number
Additional information	<i>Limit value</i> The value should be between -1 and +30 m/s (-3.3 to +98 ft/s). <i>Dependency</i>  The unit is taken from the Velocity unit parameter (→  66)

Methane fraction of wet gas

Navigation	 Expert → Sensor → Measured val. → System values → Meth. fract. wet (5633)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Displays the methane fraction of the wet gas currently calculated.
User interface	0 to 100 %

Totalizer

Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3 (0911-1 to 3)

► Totalizer

Totalizer value 1 to 3 (0911-1 to 3)

→  53

Totalizer overflow 1 to 3 (0910-1 to 3)

→  54

Totalizer value 1 to 3

Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3 (0911-1 to 3)

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→  158) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *

Description Displays the current totalizer reading.

User interface Signed floating-point number

Additional information *Description*

As it is only possible to display a maximum of 7 digits, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to 3** parameter if the display range is exceeded.

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→  162).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→  160).

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→  158).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 1 10⁷ (1 overflow) = 10 000 000 [m³]
- Current totalizer reading: 10 196 845.7 m³

* Visibility depends on order options or device settings

Totalizer overflow 1 to 3

Navigation	 Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to 3 (0910–1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Displays the current totalizer overflow.
User interface	Integer with sign
Additional information	<i>Description</i> If the current reading has more than 7 digits, which is the maximum value range that can be displayed, the value above this range is given as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the Totalizer value 1 to 3 parameter <i>User interface</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  158). <i>Example</i> Calculation of the current totalizer reading when the value exceeds the 7-digit display range: ■ Value in the Totalizer value 1 parameter: 196 845.7 m³ ■ Value in the Totalizer overflow 1 parameter: 2 10⁷ (2 overflows) = 20 000 000 [m³] ■ Current totalizer reading: 20 196 845.7 m³

"Input values" submenu

Navigation  Expert → Sensor → Measured val. → Input values

► Input values

Measured current 1 (1604–1)

→  55

Measured values 1 (1603–1)

→  55

* Visibility depends on order options or device settings

Measured current 1

Navigation	 Expert → Sensor → Measured val. → Input values → Measur. curr. 1 (1604-1)
Description	Displays the current value of the current input.
User interface	3.59 to 22.5 mA

Measured values 1

Navigation	 Expert → Sensor → Measured val. → Input values → Measured val. 1 (1603-1)
Description	Displays the current input value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Pressure unit parameter (→  65)

"Output values" submenu

Navigation  Expert → Sensor → Measured val. → Output values

► Output values		
Output current 1 (0361-1)		→  56
Measured current 1 (0366-1)		→  56
Terminal voltage 1 (0662)		→  56
Output current 2 (0361-2)		→  56
Pulse output (0456)		→  56
Output frequency (0471)		→  57
Switch status (0461)		→  57

Output current 1 to 2

Navigation	  Expert → Sensor → Measured val. → Output values → Output curr. 1 to 2 (0361–1 to 2)
Description	Displays the actual calculated value of the output current.
User interface	3.59 to 22.5 mA

Measured current 1


Navigation	  Expert → Sensor → Measured val. → Output values → Measur. curr. 1 (0366–1)
Description	Use this function to display the actual measured value of the output current.
User interface	0 to 30 mA

Terminal voltage 1

Navigation	  Expert → Sensor → Measured val. → Output values → Terminal volt. 1 (0662)
Description	Use this function to view the actual terminal voltage that is present at the current output.
User interface	0.0 to 50.0 V

Pulse output

Navigation	  Expert → Sensor → Measured val. → Output values → Pulse output (0456)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  112).
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<i>Description</i> The pulse output is an open collector output. This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. The value (i.e. the amount of the measured value) that a pulse corresponds to and the duration of the pulse can be defined using the Value per pulse parameter (→  113) and the Pulse width parameter (→  114).



0 Non-conductive
1 Conductive
NC Normally closed
NO Normally opened

The output behavior can be reversed using the **Invert output signal** parameter (→ 127), i.e. the transistor is not conductive for the duration of the pulse.
In addition, the behavior of the output can be configured in the event of an error (**Failure mode** parameter (→ 115)).

Output frequency

Navigation	Expert → Sensor → Measured val. → Output values → Output freq. (0471)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 112).
Description	Use this function to view the actual value of the output frequency which is currently measured.
User interface	0 to 1250 Hz

Switch status

Navigation	Expert → Sensor → Measured val. → Output values → Switch status (0461)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 112).
Description	Use this function to view the current switch status of the status output.
User interface	■ Open ■ Closed

3.2.2 "System units" submenu

Navigation  Expert → Sensor → System units

► System units		
Volume flow unit (0553)	→ 	58
Volume unit (0563)	→ 	59
Corrected volume flow unit (0558)	→ 	60
Corrected volume unit (0575)	→ 	61
Mass flow unit (0554)	→ 	61
Mass unit (0574)	→ 	62
Energy flow unit (0565)	→ 	62
Energy unit (0559)	→ 	63
Calorific value unit (0552)	→ 	64
Temperature unit (0557)	→ 	65
Pressure unit (0564)	→ 	65
Velocity unit (0566)	→ 	66
Date/time format (2812)	→ 	67
► User-specific units	→ 	67

Volume flow unit



Navigation  Expert → Sensor → System units → Volume flow unit (0553)

Description Use this function to select the unit for the volume flow.

Selection	<i>SI units</i> ■ dm³/s ■ dm³/min ■ dm³/h ■ dm³/d ■ m³/s ■ m³/min ■ m³/h ■ m³/d ■ l/s ■ l/min ■ l/h ■ l/d <i>Custom-specific units</i> ■ User vol./s ■ User vol./min ■ User vol./h ■ User vol./d	<i>US units</i> ■ ft³/s ■ ft³/min ■ ft³/h ■ ft³/d	<i>Imperial units</i> ■ bbl/s (imp;beer) ■ bbl/min (imp;beer) ■ bbl/h (imp;beer) ■ bbl/d (imp;beer)
Factory setting	Country-specific: ■ m³/h ■ ft³/min		
Additional information	<i>Result</i> The selected unit applies for: Volume flow parameter (→  46) <i>Options</i>  For an explanation of the abbreviated units: →  200 <i>Customer-specific units</i>  The unit for the customer-specific volume is specified in the User volume text parameter (→  68).		

Volume unit



Navigation   Expert → Sensor → System units → Volume unit (0563)

Description Use this function to select the unit for the volume.

Selection	<i>SI units</i> ■ dm³ ■ m³ ■ l <i>Custom-specific units</i> User vol.	<i>US units</i> ft³	<i>Imperial units</i> bbl (imp;beer)
------------------	--	--	--

Factory setting Country-specific:

- m³
- ft³

Additional information

Selection

 For an explanation of the abbreviated units: →  200

Customer-specific units

 The unit for the customer-specific volume is specified in the **User volume text** parameter (→  68).

Corrected volume flow unit

Navigation

  Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection

SI units

- Nl/s
- Nl/min
- Nl/h
- Nl/d
- Nm^3/s
- Nm^3/min
- Nm^3/h
- Nm^3/d
- Sm^3/s
- Sm^3/min
- Sm^3/h
- Sm^3/d

US units

- Sft^3/s
- Sft^3/min
- Sft^3/h
- Sft^3/d

Custom-specific units

- UserCrVol./s
- UserCrVol./min
- UserCrVol./h
- UserCrVol./d

Factory setting

Country-specific:

- Nm^3/h
- Sft^3/h

Additional information

Result

The selected unit applies for:

- **Corrected volume flow** parameter (→  46)
- **Corrected methane volume flow** parameter (→  46)

Options

 For an explanation of the abbreviated units: →  200

Customer-specific units

 The unit for the customer-specific corrected volume is defined in the **User corrected volume text** parameter (→  70).

Corrected volume unit 	
Navigation	  Expert → Sensor → System units → Corr. vol. unit (0575)
Description	Use this function to select the unit for the corrected volume.
Selection	<i>SI units</i> ■ NI ■ Nm³ ■ Sm³ <i>US units</i> ■ Sft³ <i>Custom-specific units</i> ■ UserCrVol.
Factory setting	Country-specific: ■ Nm³ ■ Sft³
Additional information	<i>Options</i>  For an explanation of the abbreviated units: →  200 <i>Customer-specific units</i>  The unit for the customer-specific corrected volume is defined in the User corrected volume text parameter (→  70).
Mass flow unit 	
Navigation	  Expert → Sensor → System units → Mass flow unit (0554)
Description	Use this function to select the unit for the mass flow.
Selection	<i>SI units</i> ■ g/s ■ g/min ■ kg/s ■ kg/min ■ kg/h ■ kg/d ■ t/h ■ t/d <i>US units</i> ■ oz/s ■ oz/min ■ lb/s ■ lb/min ■ lb/h ■ lb/d ■ STon/h ■ STon/d <i>Custom-specific units</i> ■ User mass/s ■ User mass/min ■ User mass/h ■ User mass/d
Factory setting	Country-specific: ■ kg/h ■ lb/min

Additional information		Result The selected unit applies for: Mass flow parameter (→ ⓘ 47) Options  For an explanation of the abbreviated units: → ⓘ 200 Customer-specific units  The unit for the customer-specific mass is specified in the User mass text parameter (→ ⓘ 70).
Mass unit		
Navigation		  Expert → Sensor → System units → Mass unit (0574)
Description		Use this function to select the unit for the mass.
Selection	SI units	US units
	■ g ■ kg ■ t	■ oz ■ lb ■ STon
		Custom-specific units User mass
Factory setting		Country-specific: ■ kg ■ lb
Additional information		Selection  For an explanation of the abbreviated units: → ⓘ 200 Customer-specific units  The unit for the customer-specific mass is specified in the User mass text parameter (→ ⓘ 70).
Energy flow unit		

Navigation	  Expert → Sensor → System units → Energy flow unit (0565)
Description	Use this function to select the unit for the energy flow.

Selection*SI units*

- kW
- MW
- kJ/s
- kJ/min
- kJ/h
- kJ/d
- MJ/h
- MJ/d
- kcal/s
- kcal/min
- kcal/h
- kcal/d
- Mcal/h
- Mcal/d

Imperial units

- Btu/s
- Btu/min
- Btu/h
- Btu/day
- MBtu/min
- MBtu/h
- MBtu/d
- MMBtu/h
- MMBtu/d

Custom-specific units

- User en./s
- User en./min
- User en./h
- User en./d

Factory setting

Country-specific:

- kW
- Btu/h

Additional information*Options*

For an explanation of the abbreviated units: → 200

Customer-specific units

The unit for the customer-specific energy is specified in the **User energy text** parameter (→ 71).

Energy unit**Navigation**

Expert → Sensor → System units → Energy unit (0559)

Description

Use this function to select the unit for energy.

Selection*SI units*

- kWh
- MWh
- GWh
- kJ
- MJ
- GJ
- kcal
- Mcal

Imperial units

- Btu
- MBtu
- MMBtu

Custom-specific units

User en.

Factory setting	Country-specific: ■ kWh ■ Btu
Additional information	<i>Options</i>  For an explanation of the abbreviated units: →  200 <i>Customer-specific units</i>  The unit for the customer-specific energy is specified in the User energy text parameter (→  71).

Calorific value unit	
----------------------	---

Navigation	  Expert → Sensor → System units → Cal. value unit (0552)				
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"				
Description	Use this function to select the unit for the calorific value.				
Selection	<table><tr><td><i>SI units</i> ■ kJ/Nm³ ■ kWh/Nm³ ■ kWh/Sm³ ■ kJ/Sm³ </td><td><i>Imperial units</i> ■ Btu/Sm³ ■ MBtu/Sm³ ■ Btu/Sft³ ■ MBtu/Sft³ </td></tr><tr><td colspan="2"><i>Custom-specific units</i> User cval.</td></tr></table>	<i>SI units</i> ■ kJ/Nm³ ■ kWh/Nm³ ■ kWh/Sm³ ■ kJ/Sm³	<i>Imperial units</i> ■ Btu/Sm³ ■ MBtu/Sm³ ■ Btu/Sft³ ■ MBtu/Sft³	<i>Custom-specific units</i> User cval.	
<i>SI units</i> ■ kJ/Nm³ ■ kWh/Nm³ ■ kWh/Sm³ ■ kJ/Sm³	<i>Imperial units</i> ■ Btu/Sm³ ■ MBtu/Sm³ ■ Btu/Sft³ ■ MBtu/Sft³				
<i>Custom-specific units</i> User cval.					

Factory setting	Country-specific: ■ kWh/Nm³ ■ Btu/Sft³
Additional information	<i>Result</i> The selected unit applies for: ■ Calorific value parameter (→  48) ■ Wobbe index parameter (→  48) <i>Options</i>  For an explanation of the abbreviated units: →  200 <i>Customer-specific units</i>  The unit for the customer-specific calorific value is specified in the User calorific value text parameter (→  72).

**Temperature unit**

Navigation  Expert → Sensor → System units → Temperature unit (0557)

Description Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	■ °R

Factory setting Country-specific:
 ■ °C
 ■ °F

Additional information *Result*
 The selected unit applies for:
 ■ **Temperature** parameter (→  49)
 ■ **Maximum value** parameter (→  185)
 ■ **Minimum value** parameter (→  184)
 ■ **Average value** parameter (→  185)
 ■ **Maximum value** parameter (→  186)
 ■ **Minimum value** parameter (→  185)
 ■ **Process temperature** parameter (→  83)
 ■ **Maximum value** parameter (→  186)
 ■ **Minimum value** parameter (→  187)

Options

For an explanation of the abbreviated units: →  200

**Pressure unit**

Navigation  Expert → Sensor → System units → Pressure unit (0564)

Description Use this function to select the unit for the pipe pressure.

Selection

<i>SI units</i>	<i>US units</i>
■ Pa a	psi a
■ bar a	
■ mbar a	
■ kPa a	
■ MPa a	

Custom-specific units
 User pres.

Factory setting Country-specific:
 ■ mbar a
 ■ psi a

Additional information	<i>Result</i> The unit is taken from: ■ Failure value parameter (→ ⓘ 132) ■ Measured values parameter (→ ⓘ 55) ■ 4 mA value parameter (→ ⓘ 95) ■ 20 mA value parameter (→ ⓘ 95) ■ Failure value parameter (→ ⓘ 96) ■ Maximum value parameter (→ ⓘ 188) ■ Atmospheric pressure parameter (→ ⓘ 83) ■ Pressure value parameter ■ Process pressure parameter (5640) <i>Options</i> ⓘ For an explanation of the abbreviated units: → ⓘ 200 <i>Customer-specific units</i> ⓘ The unit is taken from the Pressure unit parameter (→ ⓘ 65)
------------------------	--

Velocity unit	ⓘ	
Navigation	ⓘ ⓘ Expert → Sensor → System units → Velocity unit (0566)	
Description	Use this function to select the unit for the flow velocity.	
Selection	<i>SI units</i> m/s	<i>US units</i> ft/s
Factory setting	Country-specific: ■ m/s ■ ft/s	
Additional information	<i>Result</i> The selected unit applies for: ■ Flow velocity (→ ⓘ 49) ■ Sound velocity (→ ⓘ 49) ■ Flow velocity (→ ⓘ 52) ■ Sound velocity (→ ⓘ 52) ■ Maximum value (→ ⓘ 187) ■ Minimum value (→ ⓘ 187) <i>Options</i> ⓘ For an explanation of the abbreviated units: → ⓘ 200	

Date/time format		
Navigation	Expert → Sensor → System units → Date/time format (2812)	
Description	Use this function to select the desired time format for calibration history.	
Selection	■ dd.mm.yy hh:mm ■ dd.mm.yy hh:mm am/pm ■ mm/dd/yy hh:mm ■ mm/dd/yy hh:mm am/pm	
Factory setting	dd.mm.yy hh:mm	
Additional information	<i>Selection</i> For an explanation of the abbreviated units: → 200	

"User-specific units" submenu

Navigation Expert → Sensor → System units → User-spec. units

► User-specific units		
User volume text (0567)	→	68
User volume offset (0569)	→	68
User volume factor (0568)	→	69
User corrected volume factor (0590)	→	69
User corrected volume offset (0602)	→	69
User corrected volume text (0592)	→	70
User mass text (0560)	→	70
User mass offset (0562)	→	71
User mass factor (0561)	→	71
User energy text (0600)	→	71
User energy offset (0599)	→	72
User energy factor (0586)	→	72

User calorific value text (0585)	→  72
User calorific value offset (0584)	→  73
User calorific value factor (0583)	→  73
User pressure text (0581)	→  73
User pressure offset (0580)	→  73
User pressure factor (0579)	→  74

User volume text

Navigation	  Expert → Sensor → System units → User-spec. units → Volume text (0567)
Description	Use this function to enter a text for the user-specific unit of volume and volume flow. The corresponding time units (s, min, h, d) for volume flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User vol.
Additional information	Result  The defined unit is shown as an option in the choose list of the following parameters: ▪ Volume flow unit parameter (→  58) ▪ Volume unit parameter (→  59) Example If the text GLAS is entered, the choose list of the Volume flow unit parameter (→  58) shows the following options: ▪ GLAS/s ▪ GLAS/min ▪ GLAS/h ▪ GLAS/d

User volume offset

Navigation	  Expert → Sensor → System units → User-spec. units → Volume offset (0569)
Description	Use this function to enter the offset for adapting the user-specific volume unit and volume flow unit (without time).
User entry	Signed floating-point number
Factory setting	0

Additional information*Description*

Value in user-specific unit = (factor × value in base unit) + offset

User volume factor**Navigation**

Expert → Sensor → System units → User-spec. units → Volume factor (0568)

Description

Use this function to enter a quantity factor (without time) for the user-specific volume and volume flow unit.

User entry

Signed floating-point number

Factory setting

1.0

User corrected volume factor**Navigation**

Expert → Sensor → System units → User-spec. units → Cor.vol. factor (0590)

Description

Use this function to enter a quantity factor (without time) for the user-specific corrected volume unit and corrected volume flow unit.

User entry

Signed floating-point number

Factory setting

1.0

User corrected volume offset**Navigation**

Expert → Sensor → System units → User-spec. units → Corr vol. offset (0602)

Description

Use this function to enter the offset for adapting the user-specific corrected volume unit and corrected volume flow unit (without time).



Value in user-specific unit = (factor × value in base unit) + offset

User entry

Signed floating-point number

Factory setting

0

User corrected volume text 	
Navigation	 Expert → Sensor → System units → User-spec. units → Corr. vol. text (0592)
Description	Use this function to enter a text for the user-specific unit of the corrected volume and corrected volume flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	UserCrVol.
Additional information	<i>Result</i>  The defined unit is shown as an option in the choose list of the following parameters: ▪ Corrected volume flow unit parameter (→  60) ▪ Corrected volume unit parameter (→  61) <i>Example</i> If the text GLAS is entered, the choose list of the Corrected volume flow unit parameter (→  60) shows the following options: ▪ GLAS/s ▪ GLAS/min ▪ GLAS/h ▪ GLAS/d
User mass text 	
Navigation	 Expert → Sensor → System units → User-spec. units → Mass text (0560)
Description	Use this function to enter a text for the user-specific unit of mass and mass flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User mass
Additional information	<i>Description</i>  The defined unit is shown as an option in the choose list of the following parameters: ▪ Mass flow unit parameter (→  61) ▪ Mass unit parameter (→  62) <i>Example</i> If the text GLAS is entered, the choose list of the Mass flow unit parameter (→  61) shows the following options: ▪ GLAS/s ▪ GLAS/min ▪ GLAS/h ▪ GLAS/d

User mass offset		
Navigation	  Expert → Sensor → System units → User-spec. units → Mass offset (0562)	
Description	Use this function to enter the offset for adapting the user-specific mass unit and mass flow unit (without time).	
User entry	Signed floating-point number	
Factory setting	0	
Additional information	<i>Description</i>  Value in user-specific unit = (factor × value in base unit) + offset	
User mass factor		
Navigation	  Expert → Sensor → System units → User-spec. units → Mass factor (0561)	
Description	Use this function to enter a quantity factor (without time) for the user-specific mass and mass flow unit.	
User entry	Signed floating-point number	
Factory setting	1.0	
User energy text		
Navigation	  Expert → Sensor → System units → User-spec. units → Energy text (0600)	
Description	Use this function to enter a text for the user-specific energy unit.	
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)	
Factory setting	User en.	
Additional information	<i>Result</i>  The defined unit is shown as an option in the choose list of the following parameters: ■ Energy unit parameter (→  63) ■ Energy flow unit parameter (→  62) <i>Example</i> If the text W is entered, the choose list of the Energy flow unit parameter (→  62) shows the following options: ■ W/s ■ W/min ■ W/h ■ W/d	

User energy offset



Navigation	 Expert → Sensor → System units → User-spec. units → Energy offset (0599)
Description	Use this function to enter the offset for adapting the user-specific energy unit (without time).
User entry	Signed floating-point number
Factory setting	0

User energy factor



Navigation	 Expert → Sensor → System units → User-spec. units → Energy factor (0586)
Description	Use this function to enter a quantity factor for the user-specific energy unit.
User entry	Signed floating-point number
Factory setting	1.0

User calorific value text



Navigation	 Expert → Sensor → System units → User-spec. units → Cal. value text (0585)
Description	Use this function to enter a text for the user-specific calorific value unit. The corresponding volume units (Nm ³ , m ³ , ft ³ , Sft ³) for the calorific value are generated automatically.
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)
Factory setting	User cval.
Additional information	<i>Result</i> The defined unit is shown as an option in the choose list of the Calorific value unit parameter (→  64). <i>Example</i> If the text CAL is entered, the choose list of the Calorific value unit parameter (→  64) shows the following options: ■ CAL/Nm³ ■ CAL/m³ ■ CAL/ft³ ■ CAL/Sft³

User calorific value offset		
Navigation	  Expert → Sensor → System units → User-spec. units → Cal. val. offset (0584)	
Description	Use this function to enter the offset for adapting the user-specific calorific value unit (without volume).	
User entry	Signed floating-point number	
Factory setting	0	
User calorific value factor		
Navigation	  Expert → Sensor → System units → User-spec. units → Cal. val. factor (0583)	
Description	Use this function to enter a quantity factor (without volume) for the user-specific calorific value unit.	
User entry	Signed floating-point number	
Factory setting	1.0	
Additional information	<i>Example</i> $1 \text{ W} \times \text{min} = 60 \text{ J} \rightarrow 0.166 \text{ W} \times \text{min} = 1 \text{ J} \rightarrow \text{user entry: } 0.0166$	
User pressure text		
Navigation	  Expert → Sensor → System units → User-spec. units → Pressure text (0581)	
Description	Use this function to enter a text for the user-specific pressure unit.	
User entry	Max. 10 characters such as letters, numbers or special characters (@, %, /)	
Factory setting	User pres.	
Additional information	<i>Result</i>  The defined unit is shown as an option in the choose list of the Pressure unit parameter (→  65).	
User pressure offset		
Navigation	  Expert → Sensor → System units → User-spec. units → Pressure offset (0580)	
Description	Use this function to enter the offset for adapting the user-specific pressure unit.	

User entry	Signed floating-point number
Factory setting	0

User pressure factor

Navigation	  Expert → Sensor → System units → User-spec. units → Pressure factor (0579)
Description	Use this function to enter a quantity factor for the user-specific pressure unit.
User entry	Signed floating-point number
Factory setting	1.0
Additional information	<i>Example</i> 1 Dyn/cm ² = 0.1 Pa → 10 Dyn/cm ² = 1 Pa → user entry: 10

3.2.3 "Process parameters" submenu

Navigation   Expert → Sensor → Process param.

► Process parameters

Flow override (1839)

→  74

Flow damping (1802)

→  75

Dry methane damping (1803)

→  75

Temperature damping (1822)

→  76

► Low flow cut off

→  76

Flow override

Navigation	  Expert → Sensor → Process param. → Flow override (1839)
Description	Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning process of a pipeline, for example.
Selection	■ Off ■ On

Factory setting Off

Additional information *Result*



This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message Δ **C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: Proceeding output
 - Totalizers 1-3: Stop being totalized

Flow damping



Navigation Expert → Sensor → Process param. → Flow damping (1802)

Description Use this function to enter flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 1 s

Additional information *Result*



The damping has an effect on the following variables of the device:

- Outputs → 96
- Low flow cut off → 76
- Totalizer → 157

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Dry methane damping



Navigation Expert → Sensor → Process param. → Dry CH₄ damping (1803)

Prerequisite For the following order code:
"Sensor version", option 2 "Volume flow + biogas analysis"

Description Use this function to enter a damping time for dry methane in seconds.

User entry 0 to 999.9 s

Factory setting 10 s

Additional information	<i>Result</i>  The damping, in addition to the dry methane, affects the following methane-dependent process variables: ▪ Corrected methane volume flow (→  46) ▪ Energy flow (→  47) ▪ Calorific value (→  48) ▪ Wobbe index (→  48)
Temperature damping 	

Navigation	  Expert → Sensor → Process param. → Temp. damping (1822)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter a temperature damping time in seconds.
User entry	0 to 999.9 s
Factory setting	10 s

Additional information	<i>Result</i>  The damping, in addition to the dry methane, affects the following methane-dependent process variables: ▪ Corrected volume flow (→  46) ▪ Corrected methane volume flow (→  46) ▪ Mass flow (→  47) ▪ Energy flow (→  47)
------------------------	--

"Low flow cut off" submenu

Navigation   Expert → Sensor → Process param. → Low flow cut off

 Low flow cut off	
Assign process variable (1837)	→  77
On value low flow cutoff (1805)	→  77
Off value low flow cutoff (1804)	→  78

Assign process variable 	
Navigation	  Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)
Description	Use this function to select a process variable for low flow cut off.
Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Flow velocity
Factory setting	Off
On value low flow cutoff 	
Navigation	  Expert → Sensor → Process param. → Low flow cut off → On value (1805)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  77): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Flow velocity
Description	Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  78.
User entry	Positive floating-point number
Factory setting	Depends on country and nominal diameter →  197
Additional information	<i>Dependency</i>  The unit depends on the process variable selected in the Assign process variable parameter (→  77).

* Visibility depends on order options or device settings

Off value low flow cutoff



Navigation Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ 77):


- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Flow velocity

Description Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 77.

User entry 0 to 100.0 %

Factory setting 50 %

Additional information *Example*



A0012887

- Q Flow
- t Time
- H Hysteresis
- A Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.4 "Measurement mode" submenu

Navigation Expert → Sensor → Measurement mode

► Measurement mode

Select gas type (5662)

→ 79

Methane fraction (5631)

→ 79

* Visibility depends on order options or device settings

Nitrogen fraction (5635)	→ 80
Oxygen fraction (5636)	→ 80
Additional gas component (5604)	→ 80
Gas fraction (5603)	→ 81
Relative humidity (5646)	→ 81
Relative humidity (5645)	→ 81

Select gas type



Navigation Expert → Sensor → Measurement mode → Select gas type (5662)

Description Use this function to select the type of gas for the measuring application.

Selection

- Biogas
- Coal seam gas
- Air
- Nitrogen N2
- Natural gas
- User-specific biogas

Factory setting Biogas

Additional information *"Biogas" option*
The **Biogas** option is made up of 60 % methane and 40 % carbon dioxide.

Methane fraction



Navigation Expert → Sensor → Measurement mode → Methane fraction (5631)

Prerequisite The following conditions are met:

- Order code for "Sensor version", option 1 "Volume flow"
- In the **Select gas type** parameter (→ 79), the **User-specific biogas** option is selected.

Description Use this function to enter the methane fraction of the gas.

User entry Positive floating-point number

Factory setting 55 %

Additional information *Description*
 Only necessary for measuring devices that do not have a methane analysis function.

Nitrogen fraction 	
Navigation	  Expert → Sensor → Measurement mode → Nitrogen fract. (5635)
Prerequisite	In the Select gas type parameter (→  79), the User-specific biogas option is selected.
Description	Use this function to enter the N ₂ fraction of the biogas to reduce the measuring uncertainty of the methane analysis.
User entry	Positive floating-point number
Factory setting	0 %
Oxygen fraction 	
Navigation	  Expert → Sensor → Measurement mode → Oxygen fraction (5636)
Prerequisite	In the Select gas type parameter (→  79), the User-specific biogas option is selected.
Description	Use this function to enter the O ₂ fraction of the biogas to reduce the measuring uncertainty of the methane analysis.
User entry	Positive floating-point number
Factory setting	0 %
Additional gas component 	
Navigation	  Expert → Sensor → Measurement mode → Add. gas compon. (5604)
Prerequisite	In the Select gas type parameter (→  79), the User-specific biogas option is selected.
Description	Use this function to enter an additional gas component of the biogas to reduce the measuring uncertainty of the methane analysis.
Selection	■ None ■ Hydrogen H₂ ■ Ammonia NH₃ ■ Hydrogen sulfide H₂S
Factory setting	None

Gas fraction 	
Navigation	  Expert → Sensor → Measurement mode → Gas fraction (5603)
Prerequisite	In the Additional gas component parameter (→  80), one of the following options is selected: ■ Hydrogen H₂ ■ Ammonia NH₃ ■ Hydrogen sulfide H₂S
Description	Use this function to enter the gas fraction to reduce the measuring uncertainty of the methane analysis.
User entry	Positive floating-point number
Factory setting	0 %
Relative humidity 	
Navigation	  Expert → Sensor → Measurement mode → Rel. humidity (5646)
Prerequisite	In the Select gas type parameter (→  79), the User-specific biogas option is selected.
Description	Use this function to enter the relative humidity of the user-specific biogas.
User entry	0 to 100 %
Factory setting	100 %
Relative humidity 	
Navigation	  Expert → Sensor → Measurement mode → Rel. humidity (5645)
Prerequisite	In the Select gas type parameter (→  79), the Air option is selected.
Description	Use this function to enter the relative humidity of the air.
User entry	0 to 100 %
Factory setting	50 %

3.2.5 "External compensation" submenu

Navigation  Expert → Sensor → External comp.

► External compensation

Pressure compensation (5641)

Absolute pressure value (5620)

Atmospheric pressure (5614)

Process temperature (5621)

→  82

→  82

→  83

→  83

Pressure compensation

Navigation	 Expert → Sensor → External comp. → Pressure compen. (5641)
Description	Select pressure compensation type. Pressure compensation is used to calculate the (corrected) volume flow, methane fraction and the methane measured values (e.g. calorific value).
Selection	■ Fixed value ■ External absolute pressure ■ External gauge pressure
Factory setting	Fixed value
Additional information	Options  At almost atmospheric conditions, better accuracy can be achieved with an absolute pressure transmitter as the atmospheric air variations can account for approx. 50 mbar (50/1000 = 5 % error).

Absolute pressure value

Navigation	 Expert → Sensor → External comp. → Abs. press. val. (5620)
Prerequisite	In the Pressure compensation parameter (→  82), the Fixed value option is selected.
Description	Use this function to enter a fixed pressure value.
User entry	700 to 11 000 mbar
Factory setting	Country-specific: ■ 1 043 mbar a ■ 15.1 psi a

Additional information	<i>Description</i> This value is needed to calculate the (corrected) volume flow, methane fraction and the methane measured values (e.g. calorific value). An incorrect entry directly affects the accuracy of the calculated values. <i>User entry</i>  The unit is taken from the Pressure unit parameter (→  65)
Atmospheric pressure 	
Navigation	  Expert → Sensor → External comp. → Atmosph. press. (5614)
Prerequisite	In the Pressure compensation parameter (→  82), the External gauge pressure option is selected.
Description	Use this function to enter a value for the ambient pressure to be used for pressure correction.
User entry	700 to 1 100 mbar
Factory setting	Country-specific: ■ 1 013.25 mbar a ■ 14.696 psi a
Additional information	<i>Dependency</i>  The unit is taken from the Pressure unit parameter (→  65)
Process temperature 	
Navigation	  Expert → Sensor → External comp. → Process temp. (5621)
Prerequisite	For the following order code: "Sensor version", option 1 "Volume flow"
Description	Use this function to enter a fixed temperature value.
User entry	0 to 80 °C
Factory setting	Country-specific: ■ 50 °C ■ 122 °F
Additional information	<i>Description</i> This value is needed to calculate the (corrected) volume flow, methane fraction and the methane measured values (e.g. calorific value). An incorrect entry directly affects the accuracy of the calculated values.

Dependency

 The unit is taken from the **Temperature unit** parameter (→  65)

3.2.6 "Calculated values" submenu

Navigation   Expert → Sensor → Calculated value

► Calculated values

Calorific value calculation (5611)

→  84

► Reference values

→  85

Calorific value calculation

Navigation	  Expert → Sensor → Calculated value → Cal.value calc. (5611)
Description	Use this function to select the reference variable for calorific value calculation.
Selection	■ Gross calorific value ■ Net calorific value
Factory setting	Gross calorific value
Additional information	Selection  The Gross calorific value option and the Net calorific value option are also known by the following names: ■ Gross calorific value option = gross energy or upper heating value or higher calorific value ■ Net calorific value option = net energy or lower heating value or lower calorific value  This selection is also made when calculating the Wobbe index and the energy flow.

"Reference values" submenu

Navigation

 Expert → Sensor → Calculated value → Reference values

► Reference values

Reference conditions (5644)

→  85

Reference combustion temperature (5643)

→  85

Reference conditions

Navigation	 Expert → Sensor → Calculated value → Reference values → Ref. conditions (5644)
Prerequisite	The Corrected volume flow option is selected in the Assign current output parameter (→  97).
Description	Use this function to select the reference conditions for calculating the corrected volume flow.
Selection	■ 1013.25 hPa, 0 °C ■ 1013.25 hPa, 15 °C ■ 1013.25 hPa, 20 °C ■ 1013.25 hPa, 25 °C ■ 1000.00 hPa, 0 °C ■ 1000.00 hPa, 15 °C ■ 1000.00 hPa, 20 °C ■ 1000.00 hPa, 25 °C ■ 14.696 Psi, 59 °F ■ 14.696 Psi, 60 °F ■ 14.730 Psi, 60 °F
Factory setting	Country-specific: ■ 1013.25 hPa, 0 °C ■ 14.696 Psi, 59 °F

Reference combustion temperature

Navigation	 Expert → Sensor → Calculated value → Reference values → Ref. comb. temp. (5643)
Prerequisite	The Energy flow option is selected in the Assign current output parameter (→  97).
Description	Use this function to select the reference combustion temperature for calculating the energy value of the gas.

- Selection

■ 0 °C

■ 15 °C

■ 20 °C

■ 25 °C

■ 60 °F
- Factory setting

Country-specific:

■ 25 °C

■ 60 °F

3.2.7 "Sensor adjustment" submenu

Navigation  Expert → Sensor → Sensor adjustm.

► Sensor adjustment

► Process variable adjustment

→  86

"Process variable adjustment" submenu

Navigation  Expert → Sensor → Sensor adjustm. → Variable adjust

► Process variable adjustment

Volume flow offset (1831)

→  87

Volume flow factor (1832)

→  87

Corrected volume flow offset (1841)

→  87

Corrected volume flow factor (1846)

→  88

Corrected CH4 volume flow offset (1848)

→  88

Corrected CH4 volume flow factor (1849)

→  88

Mass flow offset (1881)

→  89

Mass flow factor (1882)

→  89

Energy flow offset (1866)

→  89

Energy flow factor (1867)

→  90

Methane fraction offset (5652)

→  90

Methane fraction factor (5653)	→ 90
Temperature offset (1855)	→ 91
Temperature factor (1856)	→ 91

Volume flow offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset (1831)
Description	Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is 1 m ³ /s.
User entry	Signed floating-point number
Factory setting	0 m ³ /s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Volume flow factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor (1832)
Description	Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.
User entry	Positive floating-point number
Factory setting	1

Corrected volume flow offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset (1841)
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s

Additional information *Description*

Corrected value = (factor × value) + offset

Corrected volume flow factor**Navigation** Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor (1846)**Description** Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.**User entry** Positive floating-point number**Factory setting** 1**Corrected CH₄ volume flow offset****Navigation** Expert → Sensor → Sensor adjustm. → Variable adjust → Corr CH₄ VolOffs (1848)**Prerequisite** For the following order code:
"Sensor version", option 2 "Volume flow + biogas analysis"**Description** Use this function to enter the zero point shift for the methane corrected volume flow trim. The corrected methane volume flow unit on which the shift is based is 1 Nm³/s.**User entry** Signed floating-point number**Factory setting** 0 Nm³/s**Additional information** *Description*

Corrected value = (factor × value) + offset

Corrected CH₄ volume flow factor**Navigation** Expert → Sensor → Sensor adjustm. → Variable adjust → Corr CH₄ vol fac (1849)**Prerequisite** For the following order code:
"Sensor version", option 2 "Volume flow + biogas analysis"**Description** Use this function to enter a quantity factor for the methane corrected volume flow. This multiplication factor is applied over the methane corrected volume flow range.**User entry** Positive floating-point number**Factory setting** 1

Mass flow offset

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset (1881)
Description	Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is 1 kg/s.
User entry	Signed floating-point number
Factory setting	0 kg/s
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Mass flow factor

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor (1882)
Description	Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.
User entry	Positive floating-point number
Factory setting	1

Energy flow offset

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → En. flow offset (1866)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter the zero point shift for the energy flow trim. The energy flow unit on which the shift is based is 1 W.
User entry	Signed floating-point number
Factory setting	0 W
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Energy flow factor

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → En. flow factor (1867)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter a quantity factor (without time) for the energy flow. This multiplication factor is applied over the energy flow range.
User entry	Positive floating-point number
Factory setting	1

Methane fraction offset

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Methane offset (5652)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter the zero point shift for the methane fraction trim. The methane fraction unit on which the shift is based is 1 %.
User entry	-100 to 100 %
Factory setting	0 %
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Methane fraction factor

Navigation	 Expert → Sensor → Sensor adjustm. → Variable adjust → Methane factor (5653)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter a quantity factor for the methane fraction. This multiplication factor is applied over the methane fraction range.
User entry	Positive floating-point number
Factory setting	1

Temperature offset

Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset (1855)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.
User entry	Signed floating-point number
Factory setting	0 K
Additional information	<i>Description</i>  Corrected value = (factor × value) + offset

Temperature factor

Navigation	  Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor (1856)
Prerequisite	For the following order code: "Sensor version", option 2 "Volume flow + biogas analysis"
Description	Use this function to enter a quantity factor for the temperature. In each case, this factor refers to the temperature in Kelvin.
User entry	Positive floating-point number
Factory setting	1

3.2.8 "Calibration" submenu

Navigation   Expert → Sensor → Calibration

 Calibration	
Calibration factor (5606)	→  92
Zero point (5666)	→  92
Nominal diameter (2807)	→  92

Calibration factor

Navigation	 Expert → Sensor → Calibration → Cal. factor (5606)
Description	Displays the current calibration factor for the sensor.
User interface	Signed floating-point number
Factory setting	Depends on calibration

Zero point

Navigation	 Expert → Sensor → Calibration → Zero point (5666)
Description	Displays the current zero point correction value for the sensor.
User interface	Signed floating-point number
Factory setting	Depends on calibration

Nominal diameter

Navigation	 Expert → Sensor → Calibration → Nominal diameter (2807)
Description	Use this function to view the nominal diameter of the sensor.
User interface	DNxx / x"
Factory setting	Depends on the size of the sensor
Additional information	Description  The value is also specified on the sensor nameplate.

3.2.9 "Properties" submenu

Navigation

 Expert → Sensor → Properties

► Properties

Sensor version (5637)

→  93

Path configuration (5638)	→ 93
Signal path control (5673)	→ 93

Sensor version

Navigation	 Expert → Sensor → Properties → Sensor version (5637)
Description	Displays the sensor version.
User interface	■ Volume flow ■ Volume flow + biogas analysis
Factory setting	Volume flow + biogas analysis

Path configuration

Navigation	 Expert → Sensor → Properties → Path conf. (5638)
Description	Displays the path version.
User interface	■ Single path sensor ■ Dual path sensor
Factory setting	Dual path sensor

Signal path control

Navigation	 Expert → Sensor → Properties → Sig.path control (5673)
Prerequisite	The Dual path sensor option is selected in the Path configuration parameter (→ 93).
Description	Displays the path control.
User interface	■ All signal paths ■ Only signal path 1 ■ Only signal path 2
Factory setting	All signal paths

3.3 "Input" submenu

Navigation   Expert → Input

► Input

► Current input

→  94

3.3.1 "Current input" submenu

Navigation   Expert → Input → Current input

► Current input

Current span (1605)

4 mA value (1606)

20 mA value (1607)

Failure mode (1601)

Failure value (1602)

→  94

→  95

→  95

→  95

→  96

Current span

Navigation	  Expert → Input → Current input → Current span (1605)
Description	Use this function to select the current range for the process value to be read in.
Selection	■ 4...20 mA ■ 4...20 mA NAMUR ■ 4...20 mA US
Factory setting	Country-specific: ■ 4...20 mA NAMUR ■ 4...20 mA US
Additional information	Examples  Sample values for the current range: Current span parameter (→  98)

4 mA value 	
Navigation	  Expert → Input → Current input → 4 mA value (1606)
Description	Use this function to enter a pressure value for the 4 mA current.
User entry	Positive floating-point number
Factory setting	700 mbar
Additional information	<i>Dependency</i> The unit is taken from the Pressure unit parameter (→  65) <i>Current input behavior</i> The current input behaves differently depending on the settings configured in the following parameters: ■ Current span (→  94) ■ Failure mode (→  95) <i>Configuration examples</i>  Pay attention to the configuration examples for 4 mA value parameter (→  99).
20 mA value 	
Navigation	  Expert → Input → Current input → 20 mA value (1607)
Description	Use this function to enter a pressure value for the 20 mA current.
User entry	Positive floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i> The unit is taken from the Pressure unit parameter (→  65) <i>Configuration examples</i>  Pay attention to the configuration examples for 4 mA value parameter (→  99).
Failure mode 	
Navigation	  Expert → Input → Current input → Failure mode (1601)
Description	Use this function to select the input behavior when measuring a current outside the configured Current span parameter (→  94).

Selection	■ Alarm ■ Last valid value ■ Defined value
Factory setting	Alarm
Additional information	Options ■ Alarm An error message is set. ■ Last valid value The last valid measured value is used. ■ Defined value A user-defined measured value is used (Failure value parameter (→  96)).

Failure value

Navigation	  Expert → Input → Current input → Failure value (1602)
Prerequisite	In the Failure mode parameter (→  95), the Defined value option is selected.
Description	Use this function to enter the value that the device uses if it does not receive an input signal from the external device, or if the input signal is invalid.
User entry	Signed floating-point number
Factory setting	0 mbar

3.4 "Output" submenu

Navigation   Expert → Output

► Output

► Current output 1 to 2

→  96

► Pulse/frequency/switch output

→  111

3.4.1 "Current output 1 to 2" submenu

Navigation   Expert → Output → Curr.output 1 to 2

► Current output 1 to 2

Assign current output (0359-1 to 2)

→  97

Current span (0353-1 to 2)	→  98
Fixed current (0365-1 to 2)	→  99
4 mA value (0367-1 to 2)	→  99
20 mA value (0372-1 to 2)	→  101
Measuring mode (0351-1 to 2)	→  102
Damping output (0363-1 to 2)	→  106
Response time (0378-1 to 2)	→  107
Failure mode (0364-1 to 2)	→  108
Failure current (0352-1 to 2)	→  109
Output current 1 to 2 (0361-1 to 2)	→  109
Start-up mode (0368-1 to 2)	→  110
Start-up current (0369-1 to 2)	→  110
Measured current 1 (0366-1 to 2)	→  111
Terminal voltage 1 (0662-1 to 2)	→  111

Assign current output



- Navigation
-  Expert → Output → Curr.output 1 → Assign curr. (0359-1)
 Expert → Output → Curr.output 2 → Assign curr. (0359-2)

Description

Use this function to select a process variable for the current output.

- Selection
- Off
 - Mass flow
 - Volume flow
 - Corrected volume flow
 - Corrected methane volume flow *
 - Temperature *
 - Energy flow *
 - Methane fraction *
 - Calorific value *
 - Wobbe index *
 - Sound velocity

* Visibility depends on order options or device settings

- Flow velocity
- Acceptance rate
- Signal asymmetry
- Turbulence
- Signal strength
- Signal to noise ratio

Factory setting

Volume flow

Current span

- Navigation
- Expert → Output → Curr.output 1 → Current span (0353-1)
- Expert → Output → Curr.output 2 → Current span (0353-2)

Description

The selection specifies the operational range for the process value and the upper and lower level for signal on alarm.

- Selection
- 4...20 mA NAMUR
 - 4...20 mA US
 - 4...20 mA
 - Fixed current

- Factory setting
- Country-specific:
 - 4...20 mA NAMUR
 - 4...20 mA US

- Additional information
- Description

i


 - If an error occurs, the current output adopts the value defined in the **Failure mode** parameter (→ 108).
 - If the measured value is outside the measuring range, the diagnostic message **△S441 Current output 1 to 2** is displayed.
 - The measuring range is specified by the **4 mA value** parameter (→ 99) and **20 mA value** parameter (→ 101).

"Fixed current" option

The current value is set via the **Fixed current** parameter (→ 99).

Example

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:



- I

 Current
- 1

 Current span for process value
- 2

 Lower level for signal on alarm
- 3

 Upper level for signal on alarm

Options	1	2	3
4 to 20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4 to 20 mA US	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4 to 20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA



If the flow hits the upper or lower Signal on Alarm Level, the diagnostic message **△S441 Current output 1 to 2** is displayed.

Fixed current



Navigation	Expert → Output → Curr.output 1 → Fixed current (0365-1) Expert → Output → Curr.output 2 → Fixed current (0365-2)
Prerequisite	The Fixed current option is selected in the Current span parameter (→ 98).
Description	Use this function to enter a constant current value for the current output.
User entry	3.59 to 22.5 mA
Factory setting	4 mA
Additional information	<i>Example</i> This setting can be used for HART multidrop, for example.

4 mA value



Navigation	Expert → Output → Curr.output 1 → 4 mA value (0367-1) Expert → Output → Curr.output 2 → 4 mA value (0367-2)
Prerequisite	One of the following options is selected in the Current span parameter (→ 98): ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to enter a value for the 4 mA current.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m³/h ■ 0 ft³/min
Additional information	<i>Description</i> Positive and negative values are permitted depending on the process variable assigned in the Assign current output parameter (→ 97). In addition, the value can be greater or smaller than the value assigned for the 20 mA current in the 20 mA value parameter (→ 101).

Dependency

i The unit depends on the process variable selected in the **Assign current output** parameter (→ 97).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 98)
- Measuring mode (→ 102)
- Failure mode (→ 108)


Configuration examples

Some examples of parameter settings and their effect on the current output are given in the following section.

Configuration example A

Measuring mode with **Forward flow** option

- **4 mA value** parameter (→ 99) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 101) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow




A0013757

Q Flow
I Current
1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined with the values entered for the **4 mA value** parameter (→ 99) and **20 mA value** parameter (→ 101). If the effective flow exceeds or falls below this operational range, the diagnostic message **△S441 Current output 1 to 2** is output.

Configuration example B

Measuring mode with **Forward/Reverse flow** option



A0013758

I Current
Q Flow
1 Value assigned to 4 mA current
2 Forward flow
3 Reverse flow

The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **4 mA value** parameter (→  99) and **20 mA value** parameter (→  101) must have the same sign. The value for **20 mA value** parameter (→  101) (e.g. reverse flow) corresponds to the mirrored value for **20 mA value** parameter (→  101) (e.g. forward flow).

Configuration example C


Measuring mode with **Reverse flow compensation** option

If flow is characterized by severe fluctuations (e.g. when using Piston pumps), flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s →  102.

20 mA value	
Navigation	  Expert → Output → Curr.output 1 → 20 mA value (0372-1)   Expert → Output → Curr.output 2 → 20 mA value (0372-2)
Prerequisite	One of the following options is selected in the Current span parameter (→  98): ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Enter a value for the 20 mA current.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter →  197
Additional information	<i>Description</i> Positive and negative values are permitted depending on the process variable assigned in the Assign current output parameter (→  97). In addition, the value can be greater or smaller than the value assigned for the 4 mA current in the 4 mA value parameter (→  99). <i>Dependency</i>  The unit depends on the process variable selected in the Assign current output parameter (→  97). <i>Example</i> ■ Value assigned to 4 mA = -250 m³/h ■ Value assigned to 20 mA = +750 m³/h ■ Calculated current value = 8 mA (at zero flow) If the Forward/Reverse flow option is selected in the Measuring mode parameter (→  102), different signs cannot be entered for the values for the 4 mA value parameter (→  99) and 20 mA value parameter (→  101). The diagnostic message △S441 Current output 1 to 2 is displayed. <i>Configuration examples</i>  Pay attention to the configuration examples for 4 mA value parameter (→  99).

Measuring mode	
Navigation	 Expert → Output → Curr.output 1 → Measuring mode (0351-1)  Expert → Output → Curr.output 2 → Measuring mode (0351-2)
Prerequisite	One of the following options is selected in the Assign current output parameter (→  97): ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Temperature ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio * One of the following options is selected in the Current span parameter (→  98): ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to select the measuring mode for the current output.
Selection	■ Forward flow ■ Forward/Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow
Additional information	<i>Description</i>  The process variable that is assigned to the current output via the Assign current output parameter (→  97) is displayed below the parameter. <i>"Forward flow" option</i> The current output signal is proportional to the process variable assigned. The measuring range is defined by the values that are assigned to the 4 mA and 20 mA current value. The flow components outside the scaled measuring range are taken into account for signal output as follows: ■ Both values are defined such that they are not equal to zero flow (e.g. – 4 mA current value = –5 m³/h – 20 mA current value = 10 m³/h ■ If the effective flow exceeds or falls below the measuring range, the diagnostic message △S441 Current output 1 to 2 is output.

* Visibility depends on order options or device settings

"Forward/Reverse flow" option

A0013758

- I* Current strength
Q Flow
 1 Value assigned to 4 mA current
 2 Forward flow
 3 Reverse flow

- The current output signal is independent of the direction of flow (absolute amount of the measured variable). The values for the **4 mA value** parameter (→ 99) and **20 mA value** parameter (→ 101) must have the same sign.
- The value for **20 mA value** parameter (→ 101) (e.g. reverse flow) corresponds to the mirrored value for **20 mA value** parameter (→ 101) (e.g. forward flow).

"Reverse flow compensation" option


If flow is characterized by severe fluctuations (e.g. when using reciprocating pumps), flow components outside of the measuring range are buffered, balanced and output after a maximum delay of 60 s.

If buffering is not processed within approx. 60 s, the diagnostic message **S441 Current output 1 to 2** is displayed.

Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid reverse flow. However, this buffer is reset in all relevant programming adjustments which affect the current output.

*Examples of how the current output behaves***Example 1**

Defined measuring range: lower range value and upper range value with the **same** sign




A0001248

- 4 Measuring range

- I* Current strength
Q Flow
 1 Lower range value (value assigned to 4 mA current)
 2 Upper range value (value assigned to 20 mA current)

With the following flow response:



A0001265


5 Flow response

Q Flow

t Time

With **Forward flow** option

The current output signal is proportional to the process variable assigned. The flow components outside the scaled measuring range are not taken into account for signal output:.




A0001267

I Current strength

t Time

With **Forward/Reverse flow** option

The current output signal is independent of the direction of flow.




A0001268

I Current strength

t Time

With **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0001269

I Current strength


t Time

S Flow components saved

A Balancing of saved flow components

Example 2

Defined measuring range: lower range value and upper range value with **different** signs



A0001272

6 Measuring range


I Current strength

Q Flow

1 Lower range value (value assigned to 4 mA current)

2 Upper range value (value assigned to 20 mA current)

With flow a (—) outside, b (---) inside the measuring range



A0001273

Q Flow

t Time

1 Lower range value (value assigned to 4 mA current)


2 Upper range value (value assigned to 20 mA current)

With **Forward flow** option

■ a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output.

The diagnostic message **△S441 Current output 1 to 2** is output.

■ b (---): The current output signal is proportional to the process variable assigned.



A0001274

I Current strength


t Time

With **Forward/Reverse flow** option

This option cannot be selected here as the values for the **4 mA value** parameter (→ 99) and **20 mA value** parameter (→ 101) have different signs.

With **Reverse flow compensation** option

Flow components outside the span are buffered, balanced and output after a maximum delay of 60 s.



A0001275

- I* Current strength
- t* Time
- S* Flow components saved
- A* Balancing of saved flow components

Damping output



Navigation

- Expert → Output → Curr.output 1 → Damping out. (0363-1)
- Expert → Output → Curr.output 2 → Damping out. (0363-2)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 97):

- Mass flow
- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Temperature
- Energy flow *
- Methane fraction *
- Calorific value *
- Wobbe index *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

One of the following options is selected in the **Current span** parameter (→ 98):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description

Use this function to enter the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

3.0 s

* Visibility depends on order options or device settings

Additional information*User entry*

Use this function to enter a time constant:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Response time**Navigation**

  Expert → Output → Curr.output 1 → Response time (0378-1)

  Expert → Output → Curr.output 2 → Response time (0378-2)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→  97):

- Mass flow
- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Temperature
- Energy flow *
- Methane fraction *
- Calorific value *
- Wobbe index *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

One of the following options is selected in the **Current span** parameter (→  98):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Prerequisite**Description**

Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

* Visibility depends on order options or device settings

Additional information*Description*

The response time is made up of the time specified for the following dampings:

- Current output damping → 106 and
- Depending on the measured variable assigned to the output.
 - Flow damping or
 - Temperature damping or
 - Dry methane damping

Failure mode**Navigation**

Expert → Output → Curr.output 1 → Failure mode (0364-1)

Expert → Output → Curr.output 2 → Failure mode (0364-2)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 97):

- Mass flow
- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Temperature
- Energy flow *
- Methane fraction *
- Calorific value *
- Wobbe index *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

One of the following options is selected in the **Current span** parameter (→ 98):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description

Use this function to select the value of the current output in the event of an alarm condition.

Selection

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

Factory setting

Max.

* Visibility depends on order options or device settings

Additional information*Description*

This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

"Min." option

The current output adopts the value of the lower level for signal on alarm.



The signal on alarm level is defined via the **Current span** parameter (→ 98).

"Max." option

The current output adopts the value of the upper level for signal on alarm.



The signal on alarm level is defined via the **Current span** parameter (→ 98).

"Last valid value" option

The current output is based on the last measured value that was valid before the error occurred.

"Actual value" option

The current output is based on the actual measured value on the basis of the current flow measurement; the error is ignored.

"Defined value" option

The current output adopts a defined measured value.



The measured value is determined using the **Failure current** parameter (→ 109).

Failure current**Navigation**

Expert → Output → Curr.output 1 → Failure current (0352-1)



Expert → Output → Curr.output 2 → Failure current (0352-2)

Prerequisite

The **Defined value** option is selected in the **Failure mode** parameter (→ 108).

Description

Use this function to enter a fixed value that the current output adopts in an alarm condition.

User entry

3.59 to 22.5 mA

Factory setting

22.5 mA

Output current 1 to 2**Navigation**

Expert → Output → Curr.output 1 to 2 → Output curr. 1 to 2 (0361-1 to 2)

Description

Displays the actual calculated value of the output current.

User interface

3.59 to 22.5 mA

Start-up mode 	
Navigation	  Expert → Output → Curr.output 1 → Start-up mode (0368-1)   Expert → Output → Curr.output 2 → Start-up mode (0368-2)
Prerequisite	In the Current span parameter (→  98), one of the following options is selected: ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to select the current value that the current output adopts during the device start-up phase as long as no measured value is present.
Selection	■ Min. ■ Max. ■ Defined value
Factory setting	Min.
Additional information	<i>"Min." option</i> The current output adopts the value of the lower level for signal on alarm.  The signal on alarm level is defined via the Current span parameter (→  98). <i>"Max." option</i> The current output adopts the value of the upper level for signal on alarm.  The signal on alarm level is defined via the Current span parameter (→  98). <i>"Defined value" option</i> The current output outputs a defined current value.  The current value is defined via the Start-up current parameter (→  110).
Start-up current 	

Navigation	  Expert → Output → Curr.output 1 → Start-up current (0369-1)   Expert → Output → Curr.output 2 → Start-up current (0369-2)
Prerequisite	The Defined value option is selected in the Start-up mode parameter (→  110).
Description	Use this function to enter a fixed current value that the current output adopts during the device start-up phase as long as no measured value is present.
User entry	3.59 to 22.5 mA
Factory setting	3.6 mA

Measured current 1

Navigation	  Expert → Output → Curr.output 1 → Measur. curr. 1 (0366-1)
Description	Use this function to display the actual measured value of the output current.
User interface	0 to 30 mA

Terminal voltage 1

Navigation	  Expert → Output → Curr.output 1 → Terminal volt. 1 (0662-1)
Description	Use this function to view the actual terminal voltage that is present at the current output.
User interface	0.0 to 50.0 V

3.4.2 "Pulse/frequency/switch output" submenu

Navigation   Expert → Output → PFS output

► Pulse/frequency/switch output		
Operating mode (0469)	→	 112
Assign pulse output (0460)	→	 113
Value per pulse (0455)	→	 113
Pulse width (0452)	→	 114
Measuring mode (0457)	→	 114
Failure mode (0480)	→	 115
Pulse output (0456)	→	 115
Assign frequency output (0478)	→	 116
Minimum frequency value (0453)	→	 117
Maximum frequency value (0454)	→	 117
Measuring value at minimum frequency (0476)	→	 118

Measuring value at maximum frequency (0475)	→  118
Measuring mode (0479)	→  119
Damping output (0477)	→  120
Response time (0491)	→  121
Failure mode (0451)	→  121
Failure frequency (0474)	→  122
Output frequency (0471)	→  123
Switch output function (0481)	→  123
Assign diagnostic behavior (0482)	→  123
Assign limit (0483)	→  124
Switch-on value (0466)	→  124
Switch-off value (0464)	→  125
Assign flow direction check (0484)	→  125
Assign status (0485)	→  125
Switch-on delay (0467)	→  126
Switch-off delay (0465)	→  126
Failure mode (0486)	→  126
Switch status (0461)	→  126
Invert output signal (0470)	→  127

Operating mode



Navigation

  Expert → Output → PFS output → Operating mode (0469)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection	■ Pulse ■ Frequency ■ Switch
------------------	--

Factory setting	Pulse
------------------------	-------

Assign pulse output

Navigation	  Expert → Output → PFS output → Assign pulse (0460)
-------------------	--

Prerequisite	In the Operating mode parameter (→  112) the Pulse option is selected.
---------------------	---

Description	Use this function to select the process variable for the pulse output.
--------------------	--

Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
------------------	--

Factory setting	Off
------------------------	-----

Value per pulse

Navigation	  Expert → Output → PFS output → Value per pulse (0455)
-------------------	---

Prerequisite	One of the following options is selected in the Assign pulse output parameter (→  113): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
---------------------	--

Description	Use this function to enter the value for the measured value that a pulse is equivalent to.
--------------------	--

User entry	Signed floating-point number
-------------------	------------------------------

Factory setting	Depends on country and nominal diameter
------------------------	---


* Visibility depends on order options or device settings

Pulse width 	
Navigation	 Expert → Output → PFS output → Pulse width (0452)
Prerequisite	One of the following options is selected in the Assign pulse output parameter (→  113): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to enter the duration of the output pulse.
User entry	5 to 2 000 ms
Factory setting	100 ms
Measuring mode 	
Navigation	 Expert → Output → PFS output → Measuring mode (0457)
Prerequisite	One of the following options is selected in the Assign pulse output parameter (→  113): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to select the measuring mode for the pulse output.
Selection	■ Forward flow ■ Forward/Reverse flow ■ Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow
Additional information	<i>Options</i>  For a detailed description of the options available, see the Measuring mode parameter (→  102) <i>Examples</i>  For a detailed description of the configuration examples, see the Measuring mode parameter (→  102)

* Visibility depends on order options or device settings

Failure mode 	
Navigation	  Expert → Output → PFS output → Failure mode (0480)
Prerequisite	One of the following options is selected in the Assign pulse output parameter (→  113): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to select an output behavior in the event of a device alarm.
Selection	■ Actual value ■ No pulses
Factory setting	No pulses
Pulse output	
Navigation	  Expert → Output → PFS output → Pulse output (0456)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→  112).
Description	Displays the pulse frequency currently output.
User interface	Positive floating-point number
Additional information	<i>Description</i> The pulse output is an open collector output. This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented. The value (i.e. the amount of the measured value) that a pulse corresponds to and the duration of the pulse can be defined using the Value per pulse parameter (→  113) and the Pulse width parameter (→  114).

* Visibility depends on order options or device settings



0 Non-conductive
1 Conductive
NC Normally closed
NO Normally opened

The output behavior can be reversed using the **Invert output signal** parameter (→ 127), i.e. the transistor is not conductive for the duration of the pulse.
In addition, the behavior of the output can be configured in the event of an error (**Failure mode** parameter (→ 115)).

Assign frequency output

Navigation Expert → Output → PFS output → Assign freq. (0478)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 112).

Description Use this function to select the process variable for the frequency output.

- Selection**
- Off
 - Volume flow
 - Corrected volume flow
 - Corrected methane volume flow *
 - Mass flow
 - Energy flow *
 - Methane fraction *
 - Wobbe index *
 - Calorific value *
 - Temperature *
 - Sound velocity
 - Flow velocity
 - Acceptance rate *
 - Signal asymmetry *
 - Turbulence *
 - Signal strength *
 - Signal to noise ratio *

Factory setting Off

* Visibility depends on order options or device settings

Minimum frequency value 	
Navigation	  Expert → Output → PFS output → Min. freq. value (0453)
Prerequisite	One of the following options is selected in the Assign frequency output parameter (→  116): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Wobbe index * ■ Calorific value * ■ Temperature * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *
Description	Use this function to enter the start value frequency.
User entry	0 to 1 000 Hz
Factory setting	0 Hz
Maximum frequency value 	

Navigation	  Expert → Output → PFS output → Max. freq. value (0454)
Prerequisite	One of the following options is selected in the Assign frequency output parameter (→  116): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Wobbe index * ■ Calorific value * ■ Temperature * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *

* Visibility depends on order options or device settings

Description	Use this function to enter the end value frequency.
User entry	0 to 1 000 Hz
Factory setting	1 000 Hz

Measuring value at minimum frequency


Navigation Expert → Output → PFS output → Val. at min.freq (0476)

Prerequisite One of the following options is selected in the **Assign frequency output** parameter (→ 116):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Methane fraction *
- Wobbe index *
- Calorific value *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Dependency*

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 116).

Measuring value at maximum frequency


Navigation Expert → Output → PFS output → Val. at max.freq (0475)

Prerequisite One of the following options is selected in the **Assign frequency output** parameter (→ 116):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *

* Visibility depends on order options or device settings

- Mass flow
- Energy flow *
- Methane fraction *
- Wobbe index *
- Calorific value *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<i>Dependency</i>  The entry depends on the process variable selected in the Assign frequency output parameter (→  116).

Measuring mode

Navigation	  Expert → Output → PFS output → Measuring mode (0479)
Prerequisite	One of the following options is selected in the Assign frequency output parameter (→  116): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Wobbe index * ■ Calorific value * ■ Temperature * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *
Description	Use this function to select the measuring mode for the frequency output.

* Visibility depends on order options or device settings

Selection	■ Forward flow ■ Forward/Reverse flow ■ Reverse flow compensation
Factory setting	Forward flow
Additional information	<i>Options</i>  For a detailed description of the options available, see the Measuring mode parameter (→  102) <i>Examples</i>  For a detailed description of the configuration examples, see the Measuring mode parameter (→  102)

Damping output

Navigation	 Expert → Output → PFS output → Damping out. (0477)
Prerequisite	One of the following options is selected in the Assign frequency output parameter (→  116): ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Wobbe index * ■ Calorific value * ■ Temperature * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *

Description	Use this function to enter the reaction time of the output signal to fluctuations in the measured value.
User entry	0 to 999.9 s
Factory setting	0.0 s

* Visibility depends on order options or device settings

Response time

Navigation
 Expert → Output → PFS output → Response time (0491)
Prerequisite

One of the following options is selected in the **Assign frequency output** parameter (→  116):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Methane fraction *
- Wobbe index *
- Calorific value *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

Description

Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

Additional information

Description



The response time is made up of the time specified for the following dampings:

- Damping of pulse/frequency/switch output →  106
and
- Depending on the measured variable assigned to the output.
 - Flow damping
or
 - Temperature damping
or
 - Dry methane damping

Failure mode

**Navigation**
 Expert → Output → PFS output → Failure mode (0451)
Prerequisite

One of the following options is selected in the **Assign frequency output** parameter (→  116):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Methane fraction *

* Visibility depends on order options or device settings

- Wobbe index *
- Calorific value *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

Description Use this function to select an output behavior in the event of a device alarm.

Selection

- Actual value
- Defined value
- 0 Hz

Factory setting 0 Hz

Failure frequency

Navigation   Expert → Output → PFS output → Failure freq. (0474)

Prerequisite One of the following options is selected in the **Assign frequency output** parameter (→  116):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Methane fraction *
- Wobbe index *
- Calorific value *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

Description Use this function to enter the value for the frequency output in the event of a device alarm.

User entry 0.0 to 1250.0 Hz

Factory setting 0.0 Hz

* Visibility depends on order options or device settings

Output frequency

Navigation	 Expert → Output → PFS output → Output freq. (0471)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→  112).
Description	Use this function to view the actual value of the output frequency which is currently measured.
User interface	0 to 1 250 Hz

Switch output function



Navigation	 Expert → Output → PFS output → Switch out funct (0481)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  112).
Description	Use this function to select a function for the switch output.
Selection	■ Off ■ On ■ Diagnostic behavior ■ Limit ■ Flow direction check ■ Status
Factory setting	Off

Assign diagnostic behavior



Navigation	 Expert → Output → PFS output → Assign diag. beh (0482)
Prerequisite	The Diagnostic behavior option is selected in the Switch output function parameter (→  123).
Description	Use this function to select a diagnostic behavior for the switch output.
Selection	■ Alarm ■ Alarm or warning ■ Warning
Factory setting	Alarm

Assign limit



Navigation	 Expert → Output → PFS output → Assign limit (0483)
Prerequisite	In the Switch output function parameter (→  123) the Limit option is selected.
Description	Use this function to select a process variable for the limit function.
Selection	■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Wobbe index * ■ Calorific value * ■ Temperature * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *
Factory setting	Volume flow

Switch-on value



Navigation	 Expert → Output → PFS output → Switch-on value (0466)
Prerequisite	In the Switch output function parameter (→  123) the Limit option is selected.
Description	Use this function to enter the measured value for the switch-on point.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m³/h ■ 0 ft³/h
Additional information	Dependency  The unit depends on the process variable selected in the Assign limit parameter (→  124).

* Visibility depends on order options or device settings

Switch-off value 	
Navigation	  Expert → Output → PFS output → Switch-off value (0464)
Prerequisite	In the Switch output function parameter (→  123) the Limit option is selected.
Description	Use this function to enter the measured value for the switch-off point.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m³/h ■ 0 ft³/h
Additional information	<i>Dependency</i>  The unit depends on the process variable selected in the Assign limit parameter (→  124).
Assign flow direction check 	
Navigation	  Expert → Output → PFS output → Assign dir.check (0484)
Prerequisite	The Flow direction check option is selected in the Switch output function parameter (→  123).
Description	Use this function to select a process variable for monitoring the flow direction.
Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow ■ Mass flow ■ Energy flow
Factory setting	Volume flow
Assign status 	
Navigation	  Expert → Output → PFS output → Assign status (0485)
Prerequisite	The Status option is selected in the Switch output function parameter (→  123).
Description	Use this function to select a device status for the switch output.
Selection	Low flow cut off
Factory setting	Low flow cut off

Switch-on delay

**Navigation** Expert → Output → PFS output → Switch-on delay (0467)**Prerequisite**The **Limit** option is selected in the **Switch output function** parameter (→  123).**Description**

Use this function to enter a delay time for switching on the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Switch-off delay

**Navigation** Expert → Output → PFS output → Switch-off delay (0465)**Prerequisite**The **Limit** option is selected in the **Switch output function** parameter (→  123).**Description**

Use this function to enter a delay time for switching off the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Failure mode

**Navigation** Expert → Output → PFS output → Failure mode (0486)**Description**

Use this function to select an output behavior in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Switch status

Navigation Expert → Output → PFS output → Switch status (0461)**Prerequisite**The **Switch** option is selected in the **Operating mode** parameter (→  112).**Description**

Use this function to view the current switch status of the status output.

User interface

- Open
- Closed

Invert output signal 

Navigation  Expert → Output → PFS output → Invert outp.sig. (0470)

Description Use this function to select whether to invert the output signal.

Selection

- No
- Yes

Factory setting No

3.5 "Communication" submenu

Navigation  Expert → Communication

► Communication

► HART input

→  127

► HART output

→  133

► Diagnostic configuration

→  149

3.5.1 "HART input" submenu

Navigation  Expert → Communication → HART input

► HART input

► Configuration

→  127

► Input

→  132

"Configuration" submenu

Navigation  Expert → Communication → HART input → Configuration

► Configuration

Capture mode (7001)

→  128

Device ID (7007)	→ ⓘ 128
Device type (7008)	→ ⓘ 129
Manufacturer ID (7009)	→ ⓘ 129
Burst command (7006)	→ ⓘ 130
Slot number (7010)	→ ⓘ 130
Timeout (7005)	→ ⓘ 131
Failure mode (7011)	→ ⓘ 131
Failure value (7012)	→ ⓘ 132

Capture mode ⓘ

Navigation	ⓘ ⓘ Expert → Communication → HART input → Configuration → Capture mode (7001)
Description	Use this function to select the capture mode via burst or master communication.
Selection	■ Off ■ Burst network ■ Master network
Factory setting	Off
Additional information	<i>"Burst network" option</i> The device records data transmitted via burst in the network. ⓘ An external pressure sensor must also be in burst mode. <i>"Master network" option</i> In this case, the device must be located in a HART network in which a HART master (control) queries the measured values of the up to 64 network participants. The device reacts only to the responses of a specific device in the network. Device ID, device type, manufacturer ID and the HART commands used by the master must be defined.

Device ID ⓘ

Navigation	ⓘ ⓘ Expert → Communication → HART input → Configuration → Device ID (7007)
Prerequisite	The Master network option is selected in the Capture mode parameter (→ ⓘ 128).

Description	Use this function to enter the device ID of the HART slave device whose data are to be recorded.
User entry	6-digit value: ■ Via local operation: enter as hexadecimal or decimal number ■ Via operating tool: enter as decimal number
Factory setting	0
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	 Expert → Communication → HART input → Configuration → Device type (7008)
Prerequisite	The Master network option is selected in the Capture mode parameter (→  128).
Description	Use this function to enter the device type of the HART slave device whose data are to be recorded.
User entry	4-digit hexadecimal number
Factory setting	0x1138
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Manufacturer ID

Navigation	 Expert → Communication → HART input → Configuration → Manufacturer ID (7009)
Prerequisite	The Master network option is selected in the Capture mode parameter (→  128).
Description	Use this function to enter the manufacturer ID of the HART slave device whose data are to be recorded.
User entry	2-digit value: ■ Via local operation: enter as hexadecimal or decimal number ■ Via operating tool: enter as decimal number
Factory setting	0
Additional information	 In addition to the device ID and manufacturer ID, the device type is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Burst command

Navigation	 Expert → Communication → HART input → Configuration → Burst command (7006)
Prerequisite	The Burst network option or the Master network option are selected in the Capture mode parameter (→  128).
Description	Use this function to select the burst command to be recorded.
Selection	■ Command 1 ■ Command 3 ■ Command 9 ■ Command 33
Factory setting	Command 1
Additional information	<i>Selection</i> ■ Command 1 Use this function to capture the primary variable. ■ Command 3 Use this function to capture the dynamic HART variables and the current. ■ Command 9 Use this function to capture the dynamic HART variables including the associated status. ■ Command 33 Use this function to capture the dynamic HART variables including the associated unit.

Slot number

Navigation	 Expert → Communication → HART input → Configuration → Slot number (7010)
Prerequisite	In Capture mode parameter (→  , Burst network option or Master network option is selected.
Description	Use this function to enter the position of the process variable to be determined in burst command.
User entry	1 to 8
Factory setting	1
Additional information	<i>User entry</i>

Slot	Command			
	1	3	9	33
1	PV	PV	HART variable (slot 1)	HART variable (slot 1)
2	–	SV	HART variable (slot 2)	HART variable (slot 2)
3	–	TV	HART variable (slot 3)	HART variable (slot 3)
4	–	QV	HART variable (slot 4)	HART variable (slot 4)
5	–	–	HART variable (slot 5)	–
6	–	–	HART variable (slot 6)	–

Slot	Command			
	1	3	9	33
7	–	–	HART variable (slot 7)	–
8	–	–	HART variable (slot 8)	–

Timeout

Navigation	 Expert → Communication → HART input → Configuration → Timeout (7005)
Prerequisite	In the Capture mode parameter (→  128), the Burst network option or Master network option is selected.
Description	Use this function to enter the maximum permitted interval between two HART frames.
User entry	1 to 120 s
Factory setting	5 s
Additional information	<i>Description</i>  If the interval is exceeded, the measuring device displays the diagnostic message ⊗F410 Data transfer .

Failure mode

Navigation	 Expert → Communication → HART input → Configuration → Failure mode (7011)
Prerequisite	In the Capture mode parameter (→  128), the Burst network option or Master network option is selected.
Description	Use this function to select the device behavior if no data are recorded within the maximum permitted interval.
Selection	■ Alarm ■ Last valid value ■ Defined value
Factory setting	Alarm
Additional information	<i>Options</i> ■ Alarm An error message is set. ■ Last valid value The last valid measured value is used. ■ Defined value A user-defined measured value is used: (Failure value parameter (→  132)).

Failure value

Navigation	Expert → Communication → HART input → Configuration → Failure value (7012)
Prerequisite	The following conditions are met: ■ In the Capture mode parameter (→ 128), the Burst network option or Master network option is selected. ■ In the Failure mode parameter (→ 131), the Defined value option is selected.
Description	Use this function to enter the measured value to be used if no data are recorded within the maximum permitted interval.
User entry	Signed floating-point number
Factory setting	1 013.25 mbar
Additional information	<i>Dependency</i> The unit is taken from the Pressure unit parameter (→ 65)

"Input" submenu

Navigation Expert → Communication → HART input → Input

► Input

Value (7003)

→ 132

Status (7004)

→ 133

Value

Navigation	Expert → Communication → HART input → Input → Value (7003)
Description	Displays the value of the device variable recorded by the HART input.
User interface	Signed floating-point number
Additional information	<i>Dependency</i> The unit is taken from the Pressure unit parameter (→ 65)

Status	
Navigation	 Expert → Communication → HART input → Input → Status (7004)
Description	Displays the value of the device variable recorded by the HART input in accordance with the HART specification.
User interface	■ Manual/Fixed ■ Good ■ Poor accuracy ■ Bad
Additional information	<i>Description</i> If the measuring device reads in an invalid pressure measured value, the diagnostic message ✖F882 Input signal is output

3.5.2 "HART output" submenu

Navigation  Expert → Communication → HART output

► HART output	
► Configuration	→  133
► Burst configuration	→  135
► Information	→  141
► Output	→  145

"Configuration" submenu

Navigation  Expert → Communication → HART output → Configuration

► Configuration	
HART short tag (0220)	→  134
Device tag (0215)	→  134
HART address (0219)	→  134
No. of preambles (0217)	→  134

HART short tag

Navigation	 Expert → Communication → HART output → Configuration → HART short tag (0220)
Description	Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 8 characters: A-Z, 0-9 and certain special characters (e.g. punctuation marks, @, %).
Factory setting	PROSONIC

Device tag

Navigation	 Expert → Communication → HART output → Configuration → Device tag (0215)
Description	Use this function to enter the name for the measuring point.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).
Factory setting	Prosonic Flow

HART address

Navigation	 Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0

No. of preambles

Navigation	 Expert → Communication → HART output → Configuration → No. of preambles (0217)
Description	Use this function to enter the number of preambles in the HART protocol.
User entry	2 to 20
Factory setting	5

Additional information

User entry

As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.

"Burst configuration" submenu

Navigation  Expert → Communication → HART output → Burst config.
→ Burst config. 1 to 3

► Burst configuration

► Burst configuration 1 to 3

Burst mode 1 to 3 (2032-1 to 3)

Burst command 1 to 3 (2031-1 to 3)

Burst variable 0 (2033-1 to 3)

Burst variable 1 (2034-1 to 3)

Burst variable 2 (2035-1 to 3)

Burst variable 3 (2036-1 to 3)

Burst variable 4 (2037-1 to 3)

Burst variable 5 (2038-1 to 3)

Burst variable 6 (2039-1 to 3)

Burst variable 7 (2040-1 to 3)

Burst trigger mode (2044-1 to 3)

Burst trigger level (2043-1 to 3)

Min. update period (2042-1 to 3)

Max. update period (2041-1 to 3)

→  136

→  136

→  137

→  138

→  138

→  138

→  139

→  139

→  139

→  139

→  140

→  140

→  141

→  141

Burst mode 1 to 3 	
Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst mode 1 to 3 (2032-1 to 3)
Description	Use this function to select whether to activate the HART burst mode for burst message X.
Selection	■ Off ■ On
Factory setting	Off
Additional information	<i>Options</i> ■ Off The measuring device transmits data only when requested by the HART master. ■ On The measuring device transmits data regularly without being requested.
Burst command 1 to 3 	
Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst command 1 to 3 (2031-1 to 3)
Description	Use this function to select the HART command that is sent to the HART master.
Selection	■ Command 1 ■ Command 2 ■ Command 3 ■ Command 9 ■ Command 33 ■ Command 48
Factory setting	Command 2
Additional information	<i>Options</i> ■ Command 1 Read out the primary variable. ■ Command 2 Read out the current and the main measured value as a percentage. ■ Command 3 Read out the dynamic HART variables and the current. ■ Command 9 Read out the dynamic HART variables including the related status. ■ Command 33 Read out the dynamic HART variables including the related unit. ■ Command 48 Read out the complete device diagnostics. <i>"Command 33" option</i> The HART device variables are defined via Command 107.

The following measured variables (HART device variables) can be read out:

- Volume flow
- Mass flow
- Temperature
- Totalizer 1...3
- Sound velocity
- Flow velocity
- Signal asymmetry *
- Acceptance rate *
- Turbulence *
- Signal strength *
- Signal to noise ratio *
- Percent Of Range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)

Commands



Information about the defined details of the command: HART specifications



The measured variables (HART device variables) are assigned to the dynamic variables in the **Output** submenu (→ 96).

Burst variable 0



Navigation



Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 0 (2033-1 to 3)

Description

For HART command 9 and 33: select the HART device variable or the process variable.

Selection

- Volume flow
- Mass flow
- Energy flow
- Methane fraction
- Calorific value
- Wobbe index
- Corrected volume flow
- Corrected methane volume flow
- Temperature
- Totalizer 1
- Totalizer 2
- Totalizer 3
- Pressure
- Sound velocity
- Flow velocity
- Signal asymmetry *
- Acceptance rate *
- Turbulence *
- Signal strength *
- Signal to noise ratio *

* Visibility depends on order options or device settings

- Percent Of Range
- Measured current
- Primary variable (PV)
- Secondary variable (SV)
- Tertiary variable (TV)
- Quaternary variable (QV)
- Not used

Factory setting Volume flow

Burst variable 1



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to 3
→ Burst variable 1 (2034-1 to 3)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See **Burst variable 0** parameter (→ 137).

Factory setting Not used

Burst variable 2



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to 3
→ Burst variable 2 (2035-1 to 3)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See **Burst variable 0** parameter (→ 137).

Factory setting Not used

Burst variable 3



Navigation Expert → Communication → HART output → Burst config. → Burst config. 1 to 3
→ Burst variable 3 (2036-1 to 3)

Description For HART command 9 and 33: select the HART device variable or the process variable.

Selection See **Burst variable 0** parameter (→ 137).

Factory setting Not used

Burst variable 4

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 4 (2037–1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  137).
Factory setting	Not used

Burst variable 5

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 5 (2038–1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  137).
Factory setting	Not used

Burst variable 6

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 6 (2039–1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  137).
Factory setting	Not used

Burst variable 7

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Burst variable 7 (2040–1 to 3)
Description	For HART command 33: select the HART device variable or the process variable.
Selection	See Burst variable 0 parameter (→  137).
Factory setting	Not used

Burst trigger mode

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger mode (2044-1 to 3)
Description	Use this function to select the event that triggers burst message X.
Selection	■ Continuous ■ Window ■ Rising ■ Falling ■ On change
Factory setting	Continuous
Additional information	<i>Options</i> ■ Continuous The message is sent continuously, at least at intervals corresponding to the time frame specified in the Burst min period parameter (→  141). ■ Window The message is sent if the specified measured value has changed by the value in the Burst trigger level parameter (→  140). ■ Rising The message is sent if the specified measured value exceeds the value in the Burst trigger level parameter (→  140). ■ Falling The message is sent if the specified measured value drops below the value in the Burst trigger level parameter (→  140). ■ On change The message is sent if a measured value changes in the burst message.

Burst trigger level

Navigation	 Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Trigger level (2043-1 to 3)
Description	For entering the burst trigger value.
User entry	Positive floating-point number
Additional information	<i>Description</i> Together with the option selected in the Burst trigger mode parameter (→  140) the burst trigger value determines the time of burst message X.

Min. update period

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Min. upd. per. (2042-1 to 3)
Description	Use this function to enter the minimum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	1 000 ms

Max. update period

Navigation	  Expert → Communication → HART output → Burst config. → Burst config. 1 to 3 → Max. upd. per. (2041-1 to 3)
Description	Use this function to enter the maximum time span between two burst commands of burst message X.
User entry	Positive integer
Factory setting	2 000 ms

"Information" submenu

<i>Navigation</i>	  Expert → Communication → HART output → Information
► Information Device revision (0204) Device ID (0221) Device type (0209) Manufacturer ID (0259) HART revision (0205) HART descriptor (0212) HART message (0216) Hardware revision (0206) →  142 →  142 →  142 →  143 →  143 →  143 →  143 →  144	

Software revision (0224)	→ 144
HART date code (0202)	→ 144

Device revision

Navigation	 Expert → Communication → HART output → Information → Device revision (0204)
Description	Use this function to view the device revision with which the device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x03
Additional information	<i>Description</i>  The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation	 Expert → Communication → HART output → Information → Device ID (0221)
Description	Use this function to view the device ID for identifying the measuring device in a HART network.
User interface	6-digit hexadecimal number
Additional information	<i>Description</i>  In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation	 Expert → Communication → HART output → Information → Device type (0209)
Description	Displays the device type with which the measuring device is registered with the HART Communication Foundation.
User interface	2-digit hexadecimal number
Factory setting	0x5A (for Prosonic Flow B 200)

Additional information*Description*

The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID**Navigation**

Expert → Communication → HART output → Information → Manufacturer ID (0259)

Description

Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Factory setting

0x11 (for Endress+Hauser)

HART revision**Navigation**

Expert → Communication → HART output → Information → HART revision (0205)

Description

Use this function to display the HART protocol revision of the measuring device.

User interface

5 to 7

Factory setting

7

HART descriptor**Navigation**

Expert → Communication → HART output → Information → HART descriptor (0212)

Description

Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Pros. Flow B 200

HART message**Navigation**

Expert → Communication → HART output → Information → HART message (0216)

Description

Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Pros. Flow B 200

Hardware revision

Navigation  Expert → Communication → HART output → Information → Hardware rev. (0206)

Description Displays the hardware revision of the measuring device.

User interface 0 to 255

Factory setting 1

Software revision

Navigation  Expert → Communication → HART output → Information → Software rev. (0224)

Description Displays the software revision of the measuring device.

User interface 0 to 255

Factory setting 3

HART date code



Navigation  Expert → Communication → HART output → Information → HART date code (0202)

Description Use this function to enter the date information for individual use.

User entry Date entry format: yyyy-mm-dd

Factory setting 2009-07-20

Additional information *Example*
Device installation date

"Output" submenu

Navigation  Expert → Communication → HART output → Output

► Output		
Assign PV (0234)	→ 	145
Primary variable (PV) (0201)	→ 	146
Assign SV (0235)	→ 	146
Secondary variable (SV) (0226)	→ 	147
Assign TV (0236)	→ 	147
Tertiary variable (TV) (0228)	→ 	148
Assign QV (0237)	→ 	148
Quaternary variable (QV) (0203)	→ 	149

Assign PV



Navigation  Expert → Communication → HART output → Output → Assign PV (0234)

Description Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

- Selection
- Off
 - Mass flow
 - Volume flow
 - Corrected volume flow
 - Corrected methane volume flow *
 - Temperature *
 - Energy flow *
 - Methane fraction *
 - Calorific value *
 - Wobbe index *
 - Sound velocity
 - Flow velocity
 - Acceptance rate *
 - Signal asymmetry *
 - Turbulence *
 - Signal strength *
 - Signal to noise ratio *

* Visibility depends on order options or device settings

Primary variable (PV)

Navigation	 Expert → Communication → HART output → Output → Primary var (PV) (0201)
Description	Displays the current measured value of the primary dynamic variable (PV).
User interface	Signed floating-point number
Additional information	<i>User interface</i> The measured value displayed depends on the process variable selected in the Assign PV parameter (→  145). <i>Dependency</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Assign SV

Navigation	 Expert → Communication → HART output → Output → Assign SV (0235)
Description	Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).
Selection	■ Volume flow ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Corrected volume flow ■ Corrected methane volume flow * ■ Temperature * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Pressure ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *

* Visibility depends on order options or device settings

Secondary variable (SV)

Navigation	 Expert → Communication → HART output → Output → Second.var(SV) (0226)
Description	Displays the current measured value of the secondary dynamic variable (SV).
User interface	Signed floating-point number
Additional information	<i>User interface</i> The measured value displayed depends on the process variable selected in the Assign SV parameter (→  146). <i>Dependency</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Assign TV

Navigation	 Expert → Communication → HART output → Output → Assign TV (0236)
Description	Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).
Selection	■ Volume flow ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Corrected volume flow ■ Corrected methane volume flow * ■ Temperature * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Pressure ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *

* Visibility depends on order options or device settings

Tertiary variable (TV)

Navigation	 Expert → Communication → HART output → Output → Tertiary var(TV) (0228)
Description	Displays the current measured value of the tertiary dynamic variable (TV).
User interface	Signed floating-point number
Additional information	<i>User interface</i> The measured value displayed depends on the process variable selected in the Assign TV parameter (→  147). <i>Dependency</i>  The unit of the displayed measured value is taken from the System units submenu (→  58).

Assign QV



Navigation	 Expert → Communication → HART output → Output → Assign QV (0237)
Description	Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).
Selection	■ Volume flow ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Corrected volume flow ■ Corrected methane volume flow * ■ Temperature * ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Pressure ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio *

* Visibility depends on order options or device settings

Quaternary variable (QV)	
Navigation	 Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)
Description	Displays the current measured value of the quaternary dynamic variable (QV).
User interface	Signed floating-point number
Additional information	<i>User interface</i>
	The measured value displayed depends on the process variable selected in the Assign QV parameter (→  148).
	<i>Dependency</i>
 The unit of the displayed measured value is taken from the System units submenu (→  58).	

3.5.3 "Diagnostic configuration" submenu

-  For a list of all the diagnostic events, see the Operating Instructions for the device.
-  Assign a category to the particular diagnostic event:
 - **Failure (F)** option
A device error has occurred. The measured value is no longer valid.
 - **Function check (C)** option
The device is in service mode (e.g. during a simulation).
 - **Out of specification (S)** option
The device is being operated:
 - Outside its technical specification limits (e.g. outside the process temperature range)
 - Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
 - **Maintenance required (M)** option
Maintenance is required. The measured value is still valid.
 - **No effect (N)** option
Has no effect on the condensed status.

Navigation  Expert → Communication → Diag. config.

► Diagnostic configuration

Event category 123 (0269)

→  150

Event category 124 (0270)

→  151

Event category 125 (0271)

→  151

Event category 160 (0272)

→  151

Event category 441 (0210)

→  152

Event category 442 (0230)	→  152
Event category 443 (0231)	→  152
Event category 444 (0211)	→  153
Event category 452 (0265)	→  153
Event category 801 (0232)	→  154
Event category 832 (0218)	→  154
Event category 833 (0225)	→  154
Event category 834 (0227)	→  155
Event category 835 (0229)	→  155
Event category 837 (0266)	→  155
Event category 841 (0267)	→  156
Event category 881 (0268)	→  156

Event category 123 (Predicted signal strength)



Navigation	 Expert → Communication → Diag. config. → Event category 123 (0269)
Description	Use this option to select a category for the diagnostic message 123 Predicted signal strength .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 124 (Relative signal strength)



Navigation	Expert → Communication → Diag. config. → Event category 124 (0270)
Description	Use this option to select a category for the diagnostic message 124 Relative signal strength .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 149

Event category 125 (Relative sound velocity)



Navigation	Expert → Communication → Diag. config. → Event category 125 (0271)
Description	Use this option to select a category for the diagnostic message 125 Relative sound velocity .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	For a detailed description of the options available for selection: → 149

Event category 160 (Signal path switched off)



Navigation	Expert → Communication → Diag. config. → Event category 160 (0272)
Description	Use this option to select a category for the diagnostic message 160 Signal path switched off .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Maintenance required (M)

Additional information  For a detailed description of the options available for selection: →  149

Event category 441 (Current output 1 to 2)



Navigation  Expert → Communication → Diag. config. → Event category 441 (0210)

Description Use this function to select a category for the diagnostic message **441 Current output 1 to 2**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  149

Event category 442 (Frequency output)



Navigation  Expert → Communication → Diag. config. → Event category 442 (0230)

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select the category assigned to diagnostic message **442 Frequency output**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  149

Event category 443 (Pulse output)



Navigation  Expert → Communication → Diag. config. → Event category 443 (0231)

Prerequisite The pulse/frequency/switch output is available.

Description Use this function to select the category assigned to diagnostic message **443 Pulse output**.

Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 444 (Current input 1)



Navigation	 Expert → Communication → Diag. config. → Event category 444 (0211)
Prerequisite	The current input is available.
Description	Use this function to select a category for the diagnostic message 444 Current input 1 .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	<i>Options</i>  For a detailed description of the options available for selection: →  149

Event category 452 (Calculation error)



Navigation	 Expert → Communication → Diag. config. → Event category 452 (0265)
Description	Use this option to select a category for the diagnostic message 452 Calculation error .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 801 (Supply voltage too low)



Navigation	 Expert → Communication → Diag. config. → Event category 801 (0232)
Description	Use this function to select the category assigned to diagnostic message 801 Supply voltage too low .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 832 (Electronic temperature too high)



Navigation	 Expert → Communication → Diag. config. → Event category 832 (0218)
Description	Use this function to select the category assigned to diagnostic message 832 Electronic temperature too high .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 833 (Electronic temperature too low)



Navigation	 Expert → Communication → Diag. config. → Event category 833 (0225)
Description	Use this function to select the category assigned to diagnostic message 833 Electronic temperature too low .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  149

Event category 834 (Process temperature too high)



Navigation  Expert → Communication → Diag. config. → Event category 834 (0227)

Description Use this function to select a category for the diagnostic message **834 Process temperature too high**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  149

Event category 835 (Process temperature too low)



Navigation  Expert → Communication → Diag. config. → Event category 835 (0229)

Description Use this function to select a category for the diagnostic message **835 Process temperature too low**.

Selection

- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- No effect (N)

Factory setting Out of specification (S)

Additional information  For a detailed description of the options available for selection: →  149

Event category 837 (Process pressure)



Navigation  Expert → Communication → Diag. config. → Event category 837 (0266)

Description Use this option to select a category for the diagnostic message **837 Process pressure**.

Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 841 (Sensor range)



Navigation	 Expert → Communication → Diag. config. → Event category 841 (0267)
Description	Use this option to select a category for the diagnostic message 841 Sensor range .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Out of specification (S)
Additional information	 For a detailed description of the options available for selection: →  149

Event category 881 (Sensor signal path 1 to 2)



Navigation	 Expert → Communication → Diag. config. → Event category 881 (0268)
Description	Use this option to select a category for the diagnostic message 881 Sensor signal path 1 to 2 .
Selection	■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ No effect (N)
Factory setting	Maintenance required (M)
Additional information	 For a detailed description of the options available for selection: →  149

3.6 "Application" submenu

Navigation  Expert → Application

► Application		
Reset all totalizers (2806)	→ 	157
► Totalizer 1 to 3	→ 	157

Reset all totalizers

Navigation	 Expert → Application → Reset all tot. (2806)
Description	Use this function to reset all totalizers to the value 0 and restart the totaling process. This deletes all the flow values previously totalized.
Selection	■ Cancel ■ Reset + totalize
Factory setting	Cancel
Additional information	Selection ■ Cancel No action is executed and the user exits the parameter. ■ Reset + totalize All totalizers are reset to 0 and the totaling process is restarted.

3.6.1 "Totalizer 1 to 3" submenu

Navigation  Expert → Application → Totalizer 1 to 3

► Totalizer 1 to 3		
Assign process variable (0914-1 to 3)	→ 	158
Unit totalizer (0915-1 to 3)	→ 	158
Totalizer operation mode (0908-1 to 3)	→ 	160
Control Totalizer 1 to 3 (0912-1 to 3)	→ 	160

Preset value 1 to 3 (0913-1 to 3)	→ 161
Failure mode (0901-1 to 3)	→ 162

Assign process variable

Navigation	  Expert → Application → Totalizer 1 to 3 → Assign variable (0914-1 to 3)
Description	Use this function to select a process variable for totalizer 1-3.
Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow ■ Mass flow ■ Energy flow
Factory setting	Volume flow
Additional information	Description  If the option selected is changed, the device resets the totalizer to 0. Options If the Off option is selected, only Assign process variable parameter (→ 158) is displayed in the Totalizer 1 to 3 submenu. All other parameters in the submenu are hidden.

Unit totalizer

Navigation	  Expert → Application → Totalizer 1 to 3 → Unit totalizer (0915-1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *

* Visibility depends on order options or device settings

Description	Use this function to select the unit for the process variable of totalizer 1-3.		
Selection	<i>SI units</i> ■ g ■ kg ■ t <i>US units</i> ■ oz ■ lb ■ STon <i>Custom-specific units</i> User mass or <i>SI units</i> ■ dm³ ■ m³ ■ l <i>US units</i> ft³ <i>Imperial units</i> bbl (imp;beer) <i>Custom-specific units</i> User vol. or <i>SI units</i> ■ NI ■ Nm³ ■ Sm³ <i>US units</i> Sft³ <i>Custom-specific units</i> UserCrVol. or <i>SI units</i> ■ kWh ■ MWh ■ GWh ■ kJ ■ MJ ■ GJ ■ kcal ■ Mcal ■ Gcal <i>Imperial units</i> ■ Btu ■ MBtu ■ MMBtu <i>Custom-specific units</i> User en.		
Factory setting	Country-specific: ■ m³ ■ ft³		
Additional information	<i>Description</i>  The unit is selected separately for each totalizer. It is independent of the option selected in the System units submenu (→  58). <i>Options</i> The selection depends on the process variable selected in the Assign process variable parameter (→  158).		

Totalizer operation mode 	
Navigation	 Expert → Application → Totalizer 1 to 3 → Operation mode (0908-1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to select how the totalizer summates the flow.
Selection	■ Net flow total ■ Forward flow total ■ Reverse flow total
Factory setting	Net flow total
Additional information	<i>Options</i> ■ Net flow total Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction. ■ Forward flow total Only the flow in the forward flow direction is totalized. ■ Reverse flow total Only the flow against the forward flow direction is totalized (= reverse flow total).
Control Totalizer 1 to 3	

Navigation	 Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3 (0912-1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to select the control of totalizer value 1-3.
Selection	■ Totalize ■ Reset + hold ■ Preset + hold ■ Reset + totalize ■ Preset + totalize ■ Hold

* Visibility depends on order options or device settings

Factory setting	Totalize
Additional information	<i>Options</i> ■ Totalize The totalizer is started or continues totalizing with the current counter reading. ■ Reset + hold The totaling process is stopped and the totalizer is reset to 0. ■ Preset + hold The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter (→  161). ■ Reset + totalize The totalizer is reset to 0 and the totaling process is restarted. ■ Preset + totalize The totalizer is set to the defined start value in the Preset value parameter (→  161) and the totaling process is restarted. ■ Hold The totaling process is stopped.

Preset value 1 to 3

Navigation	  Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3 (0913-1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→  158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to enter a start value for totalizer 1-3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m³ ■ 0 ft³
Additional information	<i>User entry</i>  The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→  158). <i>Example</i> This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

* Visibility depends on order options or device settings

Failure mode

Navigation	Expert → Application → Totalizer 1 to 3 → Failure mode (0901–1 to 3)
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 158) of the Totalizer 1 to 3 submenu: ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow *
Description	Use this function to select how a totalizer behaves in an alarm condition.
Selection	■ Stop ■ Actual value ■ Last valid value
Factory setting	Stop
Additional information	<i>Description</i> This setting does not affect the error response mode of other totalizers and the outputs. This is specified in separate parameters. <i>Options</i> ■ Stop Totalizing is stopped in an alarm condition. ■ Actual value The totalizer continues to count based on the actual measured value; the error is ignored. ■ Last valid value The totalizer continues to count based on the last valid measured value before the error occurred.

3.7 "Diagnostics" submenu

Navigation Expert → Diagnostics

► Diagnostics

Actual diagnostics (0691)

→ 163

Previous diagnostics (0690)

→ 164

Operating time from restart (0653)

→ 165

* Visibility depends on order options or device settings

Operating time (0652)	→ ⓘ 165
▶ Diagnostic list	→ ⓘ 165
▶ Event logbook	→ ⓘ 169
▶ Device information	→ ⓘ 171
▶ Mainboard module	→ ⓘ 175
▶ I/O module	→ ⓘ 175
▶ Display module	→ ⓘ 176
▶ Data logging	→ ⓘ 176
▶ Min/max values	→ ⓘ 182
▶ Heartbeat	→ ⓘ 188
▶ Simulation	→ ⓘ 189

Actual diagnostics

Navigation	ⓘ ⓘ Expert → Diagnostics → Actual diagnos. (0691)
Prerequisite	A diagnostic event has occurred.
Description	Use this function to display the current diagnostics message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i> ⓘ Additional pending diagnostic messages can be viewed in the Diagnostic list submenu (→ ⓘ 165). ⓘ Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the ⓘ-button. <i>Example</i> For the display format: △S442 Frequency output

Timestamp	
Navigation	 Expert → Diagnostics → Timestamp (0667)
Description	Displays the operating time at which the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Actual diagnostics parameter (→  163). <i>Example</i> For the display format: 24d12h13m00s
Previous diagnostics	
Navigation	  Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Use this function to display the diagnostic message last displayed before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>User interface</i>  Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button. <i>Example</i> For the display format: △S442 Frequency output
Timestamp	
Navigation	 Expert → Diagnostics → Timestamp (0672)
Description	Displays the operating time of the last diagnostic message that occurred before the current message.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Previous diagnostics parameter (→  164).

Example
For the display format:
24d12h13m00s

Operating time from restart	
Navigation	 Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Operating time	
Navigation	 Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.7.1 "Diagnostic list" submenu

Navigation  Expert → Diagnostics → Diagnostic list

► Diagnostic list	
Diagnostics 1 (0692)	→  166
Diagnostics 2 (0693)	→  166
Diagnostics 3 (0694)	→  167
Diagnostics 4 (0695)	→  168
Diagnostics 5 (0696)	→  168

Diagnostics 1

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)
Description	Use this function to display the current diagnostics message with the highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  S442 Frequency output ■  F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0683)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Diagnostics 1 parameter (→  166). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Use this function to display the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  S442 Frequency output ■  F276 I/O module failure

Timestamp	
Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0684)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Diagnostics 2 parameter (→  166). <i>Example</i> For the display format: 24d12h13m00s
Diagnostics 3	
Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)
Description	Use this function to display the current diagnostics message with the third-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ▪  S442 Frequency output ▪  F276 I/O module failure
Timestamp	
Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0685)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Diagnostics 3 parameter (→  167). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 4

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)
Description	Use this function to display the current diagnostics message with the fourth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  S442 Frequency output ■  F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0686)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Diagnostics 4 parameter (→  168). <i>Example</i> For the display format: 24d12h13m00s

Diagnostics 5

Navigation	 Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)
Description	Use this function to display the current diagnostics message with the fifth-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Examples</i> For the display format: ■  S442 Frequency output ■  F276 I/O module failure

Timestamp	
Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp (0687)
Description	Displays the operating time at which the diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be viewed via the Diagnostics 5 parameter (→  168).
<i>Example</i> For the display format: 24d12h13m00s	

3.7.2 "Event logbook" submenu

Navigation  Expert → Diagnostics → Event logbook

► Event logbook

Filter options (0705) →  169

► Event list →  170

Filter options		
Navigation	 Expert → Diagnostics → Event logbook → Filter options (0705)	
Description	Use this function to select the category whose event messages are displayed in the events list.	
Selection	■ All ■ Failure (F) ■ Function check (C) ■ Out of specification (S) ■ Maintenance required (M) ■ Information (I)	
Factory setting	All	


Additional information

Description

-  The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu

Navigation  Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

 Expert → Diagnostics → Event logbook → Event list

Description

Use this function to display the history of event messages that have occurred in the category selected in the **Filter options** parameter (→  169).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information

Description

A maximum of 20 event messages are displayed in chronological order. If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- ↺: Occurrence of the event
- ↻: End of the event

Examples

For the display format:

- I1091 Configuration modified
↺ 24d12h13m00s
- ΔS442 Frequency output
↺ 01d04h12min30s

 Additional information, such as remedial measures, can be called up via the  key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

 To order the **HistoROM advanced capabilities** application package, see the "Accessories" section of the "Technical Information" document.

3.7.3 "Device information" submenu

Navigation   Expert → Diagnostics → Device info


► Device information		
Device tag (0011)	→ 	171
Serial number (0009)	→ 	172
Firmware version (0010)	→ 	172
Device name (0013)	→ 	173
Order code (0008)	→ 	173
Extended order code 1 (0023)	→ 	173
Extended order code 2 (0021)	→ 	174
Extended order code 3 (0022)	→ 	174
Configuration counter (0233)	→ 	174
ENP version (0012)	→ 	174

Device tag

Navigation	  Expert → Diagnostics → Device info → Device tag (0011)
Description	Use this function to display a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.
User interface	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)
Factory setting	Prosonic Flow

Additional information

User interface



The number of characters displayed depends on the characters used.

Serial number

Navigation	Expert → Diagnostics → Device info → Serial number (0009)
Description	Use this function to view the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.
User interface	Max. 11-digit character string comprising letters and numbers.
Factory setting	–
Additional information	Description Uses of the serial number ▪ To identify the measuring device quickly, e.g. when contacting Endress+Hauser. ▪ To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

Firmware version

Navigation	Expert → Diagnostics → Device info → Firmware version (0010)
Description	Use this function to view the device firmware version installed.
User interface	Character string with the following format: xx.yy.zz
Factory setting	01.02

Device name	
Navigation	 Expert → Diagnostics → Device info → Device name (0013)
Description	Use this function to view the name of the transmitter. It can also be found on the nameplate of the transmitter.
User interface	Pros. Flow B 200
Factory setting	–
Order code	
Navigation	 Expert → Diagnostics → Device info → Order code (0008)
Description	Use this function to display the device order code.
User interface	Character string composed of letters, numbers and certain punctuation marks (e.g. /).
Additional information	<i>Description</i>  The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field. The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly intelligible from the order code.  Uses of the order code ■ To order an identical spare device. ■ To identify the device quickly and easily, e.g. when contacting Endress+Hauser.
Extended order code 1	
Navigation	 Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)
Description	For displaying the first part of the extended order code. On account of length restrictions, the extended order code is split into a maximum of 3 parameters.
User interface	Character string
Additional information	<i>Description</i> The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2

Navigation	 Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)
Description	For displaying the second part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→  173)

Extended order code 3

Navigation	 Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)
Description	For displaying the third part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→  173)

Configuration counter

Navigation	 Expert → Diagnostics → Device info → Config. counter (0233)
Description	Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.
User interface	0 to 65 535

ENP version

Navigation	 Expert → Diagnostics → Device info → ENP version (0012)
Description	Displays the version of the electronic nameplate.
Factory setting	2.02.00
Additional information	<i>Description</i> This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

3.7.4 "Mainboard module" submenu

Navigation  Expert → Diagnostics → Mainboard module

► Mainboard module

Software revision (0072)

→  175

Software revision

Navigation	 Expert → Diagnostics → Mainboard module → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

3.7.5 "I/O module" submenu

Navigation  Expert → Diagnostics → I/O module

► I/O module

Software revision (0072)

→  175

Software revision

Navigation	 Expert → Diagnostics → I/O module → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

3.7.6 "Display module" submenu

Navigation  Expert → Diagnostics → Display module

► Display module

Software revision (0072) →  176

Software revision

Navigation	 Expert → Diagnostics → Display module → Software rev. (0072)
Description	Use this function to display the software revision of the module.
User interface	Positive integer

3.7.7 "Data logging" submenu

Navigation  Expert → Diagnostics → Data logging

► Data logging

Assign channel 1 (0851) →  177

Assign channel 2 (0852) →  178

Assign channel 3 (0853) →  178

Assign channel 4 (0854) →  178

Logging interval (0856) →  179

Clear logging data (0855) →  179

► Display channel 1 →  180

► Display channel 2 →  181

► Display channel 3 →  181

► Display channel 4 →  182

Assign channel 1	
Navigation	Expert → Diagnostics → Data logging → Assign chan. 1 (0851) Expert → Diagnostics → Data logging → Assign chan. 1 (0851)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 43).
Description	Use this function to select a process variable for the data logging channel.
Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Corrected methane volume flow * ■ Mass flow ■ Energy flow * ■ Methane fraction * ■ Calorific value * ■ Wobbe index * ■ Temperature * ■ Sound velocity ■ Flow velocity ■ Acceptance rate * ■ Signal asymmetry * ■ Turbulence * ■ Signal strength * ■ Signal to noise ratio * ■ Current output 1
Factory setting	Off
Additional information	<i>Description</i> A total of 1000 measured values can be logged. This means: ■ 1000 data points if 1 logging channel is used ■ 500 data points if 2 logging channels are used ■ 333 data points if 3 logging channels are used ■ 250 data points if 4 logging channels are used Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle). The log contents are cleared if the option selected is changed.

* Visibility depends on order options or device settings

Assign channel 2		
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)	
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  43).	
Description	Options for the assignment of a process variable to the data logging channel.	
Selection	Picklist, see Assign channel 1 parameter (→  177)	
Factory setting	Off	
Assign channel 3		
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)	
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  43).	
Description	Options for the assignment of a process variable to the data logging channel.	
Selection	Picklist, see Assign channel 1 parameter (→  177)	
Factory setting	Off	
Assign channel 4		
Navigation	  Expert → Diagnostics → Data logging → Assign chan. 4 (0854)	
Prerequisite	The Extended HistoROM application package is available.  The software options currently enabled are displayed in the Software option overview parameter (→  43).	
Description	Options for the assignment of a process variable to the data logging channel.	
Selection	Picklist, see Assign channel 1 parameter (→  177)	
Factory setting	Off	

Logging interval	
Navigation	Expert → Diagnostics → Data logging → Logging interval (0856) Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 43).
Description	Use this function to enter the logging interval $t_{\log}$ for data logging.
User entry	1.0 to 3 600.0 s
Factory setting	10.0 s
Additional information	<i>Description</i> This defines the interval between the individual data points in the data log, and thus the maximum loggable process time $T_{\log}$: ■ If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$ ■ If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$ ■ If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$ ■ If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$ Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of $T_{\log}$ always remains in the memory (ring memory principle). The log contents are cleared if the length of the logging interval is changed. <i>Example</i> If 1 logging channel is used: ■ $T_{\log} = 1000 \times 1 \text{ s} = 1\,000 \text{ s} \approx 15 \text{ min}$ ■ $T_{\log} = 1000 \times 10 \text{ s} = 10\,000 \text{ s} \approx 3 \text{ h}$ ■ $T_{\log} = 1000 \times 80 \text{ s} = 80\,000 \text{ s} \approx 1 \text{ d}$ ■ $T_{\log} = 1000 \times 3\,600 \text{ s} = 3\,600\,000 \text{ s} \approx 41 \text{ d}$
Clear logging data	

Navigation	Expert → Diagnostics → Data logging → Clear logging (0855) Expert → Diagnostics → Data logging → Clear logging (0855)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter (→ 43).
Description	Option to clear the entire logging data.
Selection	■ Cancel ■ Clear data
Factory setting	Cancel

Additional information

- Selection
- Cancel
The data is not cleared. All the data is retained.
 - Clear data
The logging data is cleared. The logging process starts from the beginning.

"Display channel 1" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1

► Display channel 1

Display channel 1 →  180

Display channel 1

Navigation  Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  43).

One of the following options is selected in the **Assign channel 1** parameter (→  177):

- Volume flow
- Corrected volume flow
- Corrected methane volume flow *
- Mass flow
- Energy flow *
- Methane fraction *
- Calorific value *
- Wobbe index *
- Temperature *
- Sound velocity
- Flow velocity
- Acceptance rate *
- Signal asymmetry *
- Turbulence *
- Signal strength *
- Signal to noise ratio *
- Current output 1


Description

Displays the measured value trend for the logging channel in the form of a chart.

* Visibility depends on order options or device settings

Additional information

Description



- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2

► Display channel 2

Display channel 2 →  181

Display channel 2

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 2
Prerequisite	A process variable is defined in the Assign channel 2 parameter.
Description	See the Display channel 1 parameter →  180

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

► Display channel 3

Display channel 3 →  182

Display channel 3

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 3
Prerequisite	A process variable is defined in the Assign channel 3 parameter.
Description	See the Display channel 1 parameter →  180

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4

► Display channel 4

Display channel 4 →  182

Display channel 4

Navigation	 Expert → Diagnostics → Data logging → Displ.channel 4
Prerequisite	A process variable is defined in the Assign channel 4 parameter.
Description	See the Display channel 1 parameter →  180

3.7.8 "Min/max values" submenu

Navigation   Expert → Diagnostics → Min/max val.

► Min/max values

Reset min/max values (5647) →  183

► Terminal voltage →  183

► Main electronic temperature →  185

► IO module temperature →  184

► Medium temperature →  186

► Flow velocity	→ 187
► External pressure	→ 188

Reset min/max values

Navigation	 Expert → Diagnostics → Min/max val. → Reset min/max (5647)
Description	Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.
Selection	■ Cancel ■ Terminal voltage 1 ■ IO module temperature
Factory setting	Cancel

"Terminal voltage" submenu

Navigation  Expert → Diagnostics → Min/max val. → Terminal volt.

► Terminal voltage	
Minimum value (0689)	→ 183
Maximum value (0663)	→ 184
Average value (0698)	→ 184

Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → Terminal volt. → Minimum value (0689)
Description	Use this function to display the smallest previously measured terminal voltage value in Volts.
User interface	0.0 to 50.0 V

Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → Terminal volt. → Maximum value (0663)
Description	Use this function to view the largest previously measured terminal voltage value in Volts.
User interface	0.0 to 50.0 V

Average value

Navigation	 Expert → Diagnostics → Min/max val. → Terminal volt. → Average value (0698)
Description	Use this function to view the average of all previously measured terminal voltage values in Volts.
User interface	Signed floating-point number

"IO module temperature" submenu

Navigation  Expert → Diagnostics → Min/max val. → IO module temp.

► IO module temperature

Minimum value (0688)

Maximum value (0665)

Average value (0697)

→  184

→  185

→  185

Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Minimum value (0688)
Description	Use this function to view the lowest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Maximum value (0665)
Description	Use this function to view the highest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

Average value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Average value (0697)
Description	Use this function to view the average value of all previously measured temperature values of the I/O electronics module.
User interface	−1 273.15 to 726.85 °C
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

"Main electronic temperature" submenu

Navigation  Expert → Diagnostics → Min/max val. → Main elect.temp.

► Main electronic temperature

Minimum value (5617)

→  185

Maximum value (5616)

→  186

Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value (5617)
Description	Displays the lowest previously measured temperature value of the main electronics module.

User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value (5616)
Description	Displays the highest previously measured temperature value of the main electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

"Medium temperature" submenu

Navigation   Expert → Diagnostics → Min/max val. → Medium temp.

► Medium temperature

Minimum value (5629)

→  187

Maximum value (5628)

→  186

Maximum value

Navigation	  Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (5628)
Description	Displays the highest previously measured medium temperature value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (5629)
Description	Displays the lowest previously measured medium temperature value.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  65).

"Flow velocity" submenu

Navigation  Expert → Diagnostics → Min/max val. → Flow velocity

► Flow velocity

Minimum value (5624)

→  187

Maximum value (5623)

→  187

Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → Flow velocity → Maximum value (5623)
Description	Displays the highest previously measured flow velocity.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Velocity unit parameter (→  66)

Minimum value

Navigation	 Expert → Diagnostics → Min/max val. → Flow velocity → Minimum value (5624)
Description	Displays the lowest previously measured flow velocity.
User interface	Signed floating-point number

Additional information	Dependency  The unit is taken from the Velocity unit parameter (→  66)
"External pressure" submenu Navigation Expert → Diagnostics → Min/max val. → External press. ▶ External pressure Maximum value (5619) →  188	

Maximum value	
Navigation	  Expert → Diagnostics → Min/max val. → External press. → Maximum value (5619)
Description	Displays the highest previously measured external pressure.
User interface	Signed floating-point number
Additional information	Dependency  The unit is taken from the Pressure unit parameter (→  65)

3.7.9 "Heartbeat" submenu

 For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device

Navigation	  Expert → Diagnostics → Heartbeat
▶ Heartbeat ▶ Heartbeat base settings ▶ Performing verification ▶ Verification results	

3.7.10 "Simulation" submenu

Navigation  Expert → Diagnostics → Simulation

► Simulation		
Assign simulation process variable (1810)	→ 	189
Process variable value (1811)	→ 	190
Simulation current input 1 (1608-1)	→ 	191
Value current input 1 (1609-1)	→ 	191
Simulation current output 1 to 2 (0354-1 to 2)	→ 	191
Value current output 1 to 2 (0355-1 to 2)	→ 	192
Frequency Output Simulation (0472)	→ 	192
Frequency Value (0473)	→ 	193
Pulse output simulation (0458)	→ 	193
Pulse value (0459)	→ 	194
Switch output simulation (0462)	→ 	194
Switch status (0463)	→ 	194
Simulation device alarm (0654)	→ 	195
Diagnostic event category (0738)	→ 	195
Diagnostic event simulation (0737)	→ 	196

Assign simulation process variable



Navigation  Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection	■ Off ■ Volume flow ■ Corrected volume flow ■ Methane fraction ■ Corrected methane volume flow ■ Mass flow ■ Temperature ■ Energy flow ■ Wobbe index ■ Calorific value ■ Flow velocity ■ Sound velocity
Factory setting	Off
Additional information	<i>Description</i>  The simulation value of the selected process variable is specified in the Process variable value parameter (→  190).

Process variable value


Navigation	  Expert → Diagnostics → Simulation → Proc. var. value (1811)
Prerequisite	One of the following options is selected in the Assign simulation process variable parameter (→  189): ■ Volume flow ■ Corrected volume flow ■ Methane fraction * ■ Corrected methane volume flow * ■ Mass flow ■ Temperature * ■ Energy flow * ■ Wobbe index * ■ Calorific value * ■ Flow velocity ■ Sound velocity

Description Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry Depends on the process variable selected

Factory setting 0

Additional information *User entry*

 The unit of the displayed measured value is taken from the **System units** submenu (→  58).

* Visibility depends on order options or device settings

Simulation current input 1 	
Navigation	  Expert → Diagnostics → Simulation → Sim.curr.inp 1 (1608–1)
Description	Option for switching simulation of the current input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.  The desired simulation value is specified in the Value current input parameter (→  191).
Selection	■ Off ■ On
Factory setting	Off
Additional information	<i>Options</i> ■ Off Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ On Current simulation is active.
Value current input 1 	
Navigation	  Expert → Diagnostics → Simulation → Value curr.inp 1 (1609–1)
Prerequisite	In the Simulation current input parameter (→  191) the On option is selected.
Description	Use this function to enter the current value for the simulation. In this way, users can verify the correct configuration of the current input and the correct function of upstream feed-in units.
User entry	3.59 to 22.5 mA
Simulation current output 1 to 2 	
Navigation	  Expert → Diagnostics → Simulation → Sim.curr.out. 1 to 2 (0354–1 to 2)
Description	Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	■ Off ■ On
Factory setting	Off

Additional information *Description*

The desired simulation value is specified in the **Value current output 1 to 2** parameter.

Options

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value current output 1 to 2**Navigation**

Expert → Diagnostics → Simulation → Value curr.out 1 to 2 (0355-1 to 2)

Prerequisite

In the **Simulation current output 1 to 2** parameter the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

3.59 to 22.5 mA

Factory setting

3.59 mA

Frequency Output Simulation**Navigation**

Expert → Diagnostics → Simulation → FreqOutputSim (0472)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 112).

Description

Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information *Description*

The desired simulation value is defined in the **Frequency Value** parameter (→ 193).

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Frequency Value

Navigation	Expert → Diagnostics → Simulation → Freq Value (0473)
Prerequisite	The On option is selected in the Frequency Output Simulation parameter (→ 192).
Description	Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.
User entry	0.0 to 1 250.0 Hz
Factory setting	0.0 Hz

Pulse output simulation

Navigation	Expert → Diagnostics → Simulation → Puls.outp.sim. (0458)
Prerequisite	The Pulse option is selected in the Operating mode parameter (→ 112).
Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	■ Off ■ Fixed value ■ Down-counting value
Factory setting	Off
Additional information	<i>Description</i> The desired simulation value is defined in the Pulse value parameter (→ 194). <i>Selection</i> ■ Off Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ Fixed value Pulses are continuously output with the pulse width specified in the Pulse width parameter (→ 114). ■ Down-counting value The pulses specified in the Pulse value parameter (→ 194) are output.

Pulse value 	
Navigation	  Expert → Diagnostics → Simulation → Pulse value (0459)
Prerequisite	The Down-counting value option is selected in the Pulse output simulation parameter (→  193).
Description	Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.
User entry	0 to 65 535
Factory setting	0

Switch output simulation 	
Navigation	  Expert → Diagnostics → Simulation → Switch sim. (0462)
Prerequisite	The Switch option is selected in the Operating mode parameter (→  112).
Description	Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	■ Off ■ On
Factory setting	Off
Additional information	<i>Description</i>  The desired simulation value is defined in the Switch status parameter (→  194). <i>Selection</i> ■ Off Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ On Switch simulation is active.

Switch status 	
Navigation	  Expert → Diagnostics → Simulation → Switch status (0463)
Prerequisite	The On option is selected in the Switch output simulation parameter (→  194).

Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	■ Open ■ Closed
Factory setting	Open
Additional information	<i>Options</i> ■ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ■ Closed Switch simulation is active.

Simulation device alarm


Navigation	Expert → Diagnostics → Simulation → Sim. alarm (0654)
Description	Use this function to switch the device alarm on and off. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	■ Off ■ On
Factory setting	Off

Diagnostic event category


Navigation	Expert → Diagnostics → Simulation → Event category (0738)
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Diagnostic event simulation parameter (→ 196).
Selection	■ Sensor ■ Electronics ■ Configuration ■ Process
Factory setting	Process

Diagnostic event simulation



Navigation	Expert → Diagnostics → Simulation → Diag. event sim. (0737)
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	■ Off ■ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<i>Description</i> For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 195).

4 Country-specific factory settings

4.1 SI units



Not valid for USA and Canada.

4.1.1 System units

Mass	kg
Mass flow	kg/h
Volume	m ³
Volume flow	m ³ /h
Corrected volume	Nm ³
Corrected volume flow	Nm ³ /h
Energy	kWh
Energy flow	kW
Calorific value	kWh/Nm ³
Velocity	m/s
Temperature	°C
Pressure	mbar a

4.1.2 Full scale values



The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1
- 100% bar graph value 3

Nominal diameter [mm]	Full scale value [m ³ /h]
50	130
80	310
100	520
150	1 140
200	1 940

4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
Current output 2	4 to 20 mA NAMUR

4.1.4 On value low flow cut off



The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	On value [m ³ /h]
50	0.9
80	2.0
100	3.4
150	7.6
200	12.9

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass	lb
Mass flow	lb/min
Volume	ft ³
Volume flow	ft ³ /min
Corrected volume	Sft ³
Corrected volume flow	Sft ³ /h
Energy	Btu
Energy flow	Btu/h
Calorific value	Btu/Sft ³
Velocity	ft/s
Temperature	°F
Pressure	psi a

4.2.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1
- 100% bar graph value 3

Nominal diameter [in]	Full scale value [ft ³ /min]
2	80
3	180
4	300
6	670
8	1 140

4.2.3 Output current span

Current output 1	4 to 20 mA US
Current output 2	4 to 20 mA US

4.2.4 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	On value [ft³/min]
2	0.5
3	1.2
4	2.0
6	4.5
8	7.6

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Calorific value	kWh/Nm ³ , kJ/Nm ³	Kilowatt hour, kilojoule/standard cubic meter
	kWh/Sm ³ , kJ/Sm ³	Kilowatt hour, kilojoule/standard cubic meter
Pressure	Pa, kPa, MPa	Pascal, kilopascal, megapascal
	mbar, bar	Millibar, bar
Energy	kWh, MWh, GWh	Kilowatt hour, megawatt hour, gigawatt hour
	kJ, MJ, GJ	Kilojoule, megajoule, gigajoule
	kcal, Mcal	Kilocalories, megacalories
Energy flow	kW, MW	Kilowatt, megawatt
	kJ/s, kJ/min, kJ/h, kJ/d	Kilojoule/time unit
	MJ/h, MJ/d	Megajoule/time unit
	kcal/s, kcal/min, kcal/h, kcal/d	Kilocalories/time unit
	Mcal/h, Mcal/d	Megacalories/time unit
Velocity	m/s	Meter/time unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/h, t/d	Metric ton/time unit
Corrected volume	Nl, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Corrected volume flow	Nl/s, Nl/min, Nl/h, Nl/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume	dm ³ , m ³	Cubic decimeter, meter
	l	Liter
Volume flow	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Pressure	psi a	Psi absolute
Velocity	ft/s	Foot/time unit
Mass	oz, lb, STon	Ounce, pound, standard ton

Process variable	Units	Explanation
Mass flow	oz/s, oz/min	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/h, STon/d	Standard ton/time unit
Corrected volume	Sft ³	Standard cubic foot
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	ft ³	Cubic foot
Volume flow	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Calorific value	Btu/Sm ³ , MBtu/Sm ³	British thermal unit, thousand British thermal units/standard cubic meter
	Btu/Sft ³ , MBtu/Sft ³	British thermal unit, thousand British thermal units/standard cubic foot
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Energy	Btu, MBtu, MMBtu	British thermal unit, thousand British thermal units, million British thermal units
Energy flow	Btu/s, Btu/min, Btu/h, Btu/day	British thermal unit/time unit
	MBtu/min, MBtu/h, MBtu/d	Thousand British thermal units/time unit
	MMBtu/h, MMBtu/d	Million British thermal units/time unit
Volume	bbl (imp;beer)	Barrel (beer)
Volume flow	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0% bargraph value 1 (Parameter)	18
0% bargraph value 3 (Parameter)	21
4 mA value (Parameter)	95, 99
20 mA value (Parameter)	95, 101
100% bargraph value 1 (Parameter)	19
100% bargraph value 3 (Parameter)	22

A

Absolute pressure value (Parameter)	82
Acceptance rate (Parameter)	51
Access status display (Parameter)	12, 27
Access status tooling (Parameter)	13
Activate sensor emergency mode (Parameter)	43
Activate SW option (Parameter)	42
Actual diagnostics (Parameter)	163
Additional gas component (Parameter)	80
Administration (Submenu)	39
Alarm delay (Parameter)	31
Application (Submenu)	157
Assign behavior of diagnostic no. 123 (Parameter) ...	33
Assign behavior of diagnostic no. 124 (Parameter) ...	33
Assign behavior of diagnostic no. 125 (Parameter) ...	34
Assign behavior of diagnostic no. 160 (Parameter) ...	34
Assign behavior of diagnostic no. 441 (Parameter) ...	34
Assign behavior of diagnostic no. 442 (Parameter) ...	35
Assign behavior of diagnostic no. 443 (Parameter) ...	35
Assign behavior of diagnostic no. 444 (Parameter) ...	36
Assign behavior of diagnostic no. 452 (Parameter) ...	36
Assign behavior of diagnostic no. 801 (Parameter) ...	36
Assign behavior of diagnostic no. 832 (Parameter) ...	37
Assign behavior of diagnostic no. 833 (Parameter) ...	37
Assign behavior of diagnostic no. 834 (Parameter) ...	37
Assign behavior of diagnostic no. 835 (Parameter) ...	38
Assign behavior of diagnostic no. 837 (Parameter) ...	38
Assign behavior of diagnostic no. 841 (Parameter) ...	38
Assign behavior of diagnostic no. 881 (Parameter) ...	39
Assign channel 1 (Parameter)	177
Assign channel 2 (Parameter)	178
Assign channel 3 (Parameter)	178
Assign channel 4 (Parameter)	178
Assign current output (Parameter)	97
Assign diagnostic behavior (Parameter)	123
Assign flow direction check (Parameter)	125
Assign frequency output (Parameter)	116
Assign limit (Parameter)	124
Assign process variable (Parameter)	77, 158
Assign pulse output (Parameter)	113
Assign PV (Parameter)	145
Assign QV (Parameter)	148
Assign simulation process variable (Parameter) ...	189
Assign status (Parameter)	125
Assign SV (Parameter)	146
Assign TV (Parameter)	147
Asymmetry (Parameter)	51
Atmospheric pressure (Parameter)	83

Average value (Parameter)	184, 185
---------------------------------	----------

B

Backlight (Parameter)	26
Backup state (Parameter)	29
Burst command (Parameter)	130
Burst command 1 to 3 (Parameter)	136
Burst configuration 1 to 3 (Submenu)	135
Burst mode 1 to 3 (Parameter)	136
Burst trigger level (Parameter)	140
Burst trigger mode (Parameter)	140
Burst variable 0 (Parameter)	137
Burst variable 1 (Parameter)	138
Burst variable 2 (Parameter)	138
Burst variable 3 (Parameter)	138
Burst variable 4 (Parameter)	139
Burst variable 5 (Parameter)	139
Burst variable 6 (Parameter)	139
Burst variable 7 (Parameter)	139

C

Calculated values (Submenu)	84
Calibration (Submenu)	91
Calibration factor (Parameter)	92
Calorific value (Parameter)	48
Calorific value calculation (Parameter)	84
Calorific value unit (Parameter)	64
Capture mode (Parameter)	128
Clear logging data (Parameter)	179
Communication (Submenu)	127
Comparison result (Parameter)	30
Configuration (Submenu)	127, 133
Configuration backup display (Submenu)	27
Configuration counter (Parameter)	174
Configuration management (Parameter)	28
Confirm access code (Parameter)	41
Contrast display (Parameter)	26
Control Totalizer 1 to 3 (Parameter)	160
Corrected CH ₄ volume flow factor (Parameter)	88
Corrected CH ₄ volume flow offset (Parameter)	88
Corrected methane volume flow (Parameter)	46
Corrected volume flow (Parameter)	46
Corrected volume flow factor (Parameter)	88
Corrected volume flow offset (Parameter)	87
Corrected volume flow unit (Parameter)	60
Corrected volume unit (Parameter)	61
Current input (Submenu)	94
Current output 1 to 2 (Submenu)	96
Current span (Parameter)	94, 98

D

Damping output (Parameter)	106, 120
Data logging (Submenu)	176
Date/time format (Parameter)	67
Decimal places 1 (Parameter)	19
Decimal places 2 (Parameter)	20
Decimal places 3 (Parameter)	22

- Decimal places 4 (Parameter) 23
- Define access code (Parameter) 40, 41
- Define access code (Wizard) 40
- Device ID (Parameter) 128, 142
- Device information (Submenu) 171
- Device name (Parameter) 173
- Device reset (Parameter) 42
- Device revision (Parameter) 142
- Device tag (Parameter) 134, 171
- Device type (Parameter) 129, 142
- Diagnostic behavior (Submenu) 32
- Diagnostic configuration (Submenu) 149
- Diagnostic event category (Parameter) 195
- Diagnostic event simulation (Parameter) 196
- Diagnostic handling (Submenu) 31
- Diagnostic list (Submenu) 165
- Diagnostics (Submenu) 162
- Diagnostics 1 (Parameter) 166
- Diagnostics 2 (Parameter) 166
- Diagnostics 3 (Parameter) 167
- Diagnostics 4 (Parameter) 168
- Diagnostics 5 (Parameter) 168
- Direct access
 - 0% bargraph value 1 (0123) 18
 - 0% bargraph value 3 (0124) 21
 - 4 mA value
 - Current output 1 (0367-1) 99
 - Current output 2 (0367-2) 99
 - 4 mA value (1606) 95
 - 20 mA value
 - Current output 1 (0372-1) 101
 - Current output 2 (0372-2) 101
 - 20 mA value (1607) 95
 - 100% bargraph value 1 (0125) 19
 - 100% bargraph value 3 (0126) 22
 - Absolute pressure value (5620) 82
 - Acceptance rate (5601) 51
 - Access status display (0091) 12, 27
 - Access status tooling (0005) 13
 - Activate sensor emergency mode (5610) 43
 - Activate SW option (0029) 42
 - Actual diagnostics (0691) 163
 - Additional gas component (5604) 80
 - Alarm delay (0651) 31
 - Assign behavior of diagnostic no. 123 (0773) 33
 - Assign behavior of diagnostic no. 124 (0774) 33
 - Assign behavior of diagnostic no. 125 (0775) 34
 - Assign behavior of diagnostic no. 160 (0776) 34
 - Assign behavior of diagnostic no. 441 (0657) 34
 - Assign behavior of diagnostic no. 442 (0658) 35
 - Assign behavior of diagnostic no. 443 (0659) 35
 - Assign behavior of diagnostic no. 444 (0740) 36
 - Assign behavior of diagnostic no. 452 (0713) 36
 - Assign behavior of diagnostic no. 801 (0660) 36
 - Assign behavior of diagnostic no. 832 (0675) 37
 - Assign behavior of diagnostic no. 833 (0676) 37
 - Assign behavior of diagnostic no. 834 (0677) 37
 - Assign behavior of diagnostic no. 835 (0678) 38
 - Assign behavior of diagnostic no. 837 (0714) 38
 - Assign behavior of diagnostic no. 841 (0680) 38
 - Assign behavior of diagnostic no. 881 (0724) 39
 - Assign channel 1 (0851) 177
 - Assign channel 2 (0852) 178
 - Assign channel 3 (0853) 178
 - Assign channel 4 (0854) 178
 - Assign current output
 - Current output 1 (0359-1) 97
 - Current output 2 (0359-2) 97
 - Assign diagnostic behavior (0482) 123
 - Assign flow direction check (0484) 125
 - Assign frequency output (0478) 116
 - Assign limit (0483) 124
 - Assign process variable
 - Totalizer 1 to 3 (0914-1 to 3) 158
 - Assign process variable (1837) 77
 - Assign pulse output (0460) 113
 - Assign PV (0234) 145
 - Assign QV (0237) 148
 - Assign simulation process variable (1810) 189
 - Assign status (0485) 125
 - Assign SV (0235) 146
 - Assign TV (0236) 147
 - Asymmetry (5605) 51
 - Atmospheric pressure (5614) 83
 - Average value (0697) 185
 - Average value (0698) 184
 - Backlight (0111) 26
 - Backup state (0121) 29
 - Burst command (7006) 130
 - Burst command 1 to 3 (2031-1 to 3) 136
 - Burst mode 1 to 3 (2032-1 to 3) 136
 - Burst trigger level
 - Burst configuration 1 to 3 (2043-1 to 3) 140
 - Burst trigger mode
 - Burst configuration 1 to 3 (2044-1 to 3) 140
 - Burst variable 0
 - Burst configuration 1 to 3 (2033-1 to 3) 137
 - Burst variable 1
 - Burst configuration 1 to 3 (2034-1 to 3) 138
 - Burst variable 2
 - Burst configuration 1 to 3 (2035-1 to 3) 138
 - Burst variable 3
 - Burst configuration 1 to 3 (2036-1 to 3) 138
 - Burst variable 4
 - Burst configuration 1 to 3 (2037-1 to 3) 139
 - Burst variable 5
 - Burst configuration 1 to 3 (2038-1 to 3) 139
 - Burst variable 6
 - Burst configuration 1 to 3 (2039-1 to 3) 139
 - Burst variable 7
 - Burst configuration 1 to 3 (2040-1 to 3) 139
 - Calibration factor (5606) 92
 - Calorific value (1853) 48
 - Calorific value calculation (5611) 84
 - Calorific value unit (0552) 64
 - Capture mode (7001) 128
 - Clear logging data (0855) 179
 - Comparison result (0103) 30

Configuration counter (0233)	174	Event category 441 (0210)	152
Configuration management (0100)	28	Event category 442 (0230)	152
Contrast display (0105)	26	Event category 443 (0231)	152
Control Totalizer 1 to 3 (0912-1 to 3)	160	Event category 444 (0211)	153
Corrected CH4 volume flow factor (1849)	88	Event category 452 (0265)	153
Corrected CH4 volume flow offset (1848)	88	Event category 801 (0232)	154
Corrected methane volume flow (1850)	46	Event category 832 (0218)	154
Corrected volume flow (1847)	46	Event category 833 (0225)	154
Corrected volume flow factor (1846)	88	Event category 834 (0227)	155
Corrected volume flow offset (1841)	87	Event category 835 (0229)	155
Corrected volume flow unit (0558)	60	Event category 837 (0266)	155
Corrected volume unit (0575)	61	Event category 841 (0267)	156
Current span		Event category 881 (0268)	156
Current output 1 (0353-1)	98	Extended order code 1 (0023)	173
Current output 2 (0353-2)	98	Extended order code 2 (0021)	174
Current span (1605)	94	Extended order code 3 (0022)	174
Damping output		Failure current	
Current output 1 (0363-1)	106	Current output 1 (0352-1)	109
Current output 2 (0363-2)	106	Current output 2 (0352-2)	109
Damping output (0477)	120	Failure frequency (0474)	122
Date/time format (2812)	67	Failure mode	
Decimal places 1 (0095)	19	Current output 1 (0364-1)	108
Decimal places 2 (0117)	20	Current output 2 (0364-2)	108
Decimal places 3 (0118)	22	Totalizer 1 to 3 (0901-1 to 3)	162
Decimal places 4 (0119)	23	Failure mode (0451)	121
Define access code (0093)	41	Failure mode (0480)	115
Device ID (0221)	142	Failure mode (0486)	126
Device ID (7007)	128	Failure mode (1601)	95
Device name (0013)	173	Failure mode (7011)	131
Device reset (0000)	42	Failure value (1602)	96
Device revision (0204)	142	Failure value (7012)	132
Device tag (0011)	171	Filter options (0705)	169
Device tag (0215)	134	Firmware version (0010)	172
Device type (0209)	142	Fixed current	
Device type (7008)	129	Current output 1 (0365-1)	99
Diagnostic event category (0738)	195	Current output 2 (0365-2)	99
Diagnostic event simulation (0737)	196	Flow damping (1802)	75
Diagnostics 1 (0692)	166	Flow override (1839)	74
Diagnostics 2 (0693)	166	Flow velocity (1864)	49
Diagnostics 3 (0694)	167	Flow velocity (5622)	52
Diagnostics 4 (0695)	168	Format display (0098)	16
Diagnostics 5 (0696)	168	Frequency Output Simulation (0472)	192
Direct access (0106)	11	Frequency Value (0473)	193
Display damping (0094)	24	Gas fraction (5603)	81
Display interval (0096)	24	Hardware revision (0206)	144
Dry methane damping (1803)	75	HART address (0219)	134
Dry methane in % (1852)	47	HART date code (0202)	144
Energy flow (1851)	47	HART descriptor (0212)	143
Energy flow factor (1867)	90	HART message (0216)	143
Energy flow offset (1866)	89	HART revision (0205)	143
Energy flow unit (0565)	62	HART short tag (0220)	134
Energy unit (0559)	63	Header (0097)	24
ENP version (0012)	174	Header text (0112)	25
Enter access code (0003)	14	Invert output signal (0470)	127
Enter access code (0092)	14	Language (0104)	15
Event category 123 (0269)	150	Last backup (0102)	28
Event category 124 (0270)	151	Locking status (0004)	12
Event category 125 (0271)	151	Logging interval (0856)	179
Event category 160 (0272)	151	Manufacturer ID (0259)	143

- Manufacturer ID (7009) 129
- Mass flow (1872) 47
- Mass flow factor (1882) 89
- Mass flow offset (1881) 89
- Mass flow unit (0554) 61
- Mass unit (0574) 62
- Max. update period
 - Burst configuration 1 to 3 (2041-1 to 3) 141
- Maximum frequency value (0454) 117
- Maximum value (0663) 184
- Maximum value (0665) 185
- Maximum value (5616) 186
- Maximum value (5619) 188
- Maximum value (5623) 187
- Maximum value (5628) 186
- Measured current 1 (0366-1) 56, 111
- Measured current 1 (1604-1) 55
- Measured values 1 (1603-1) 55
- Measuring mode
 - Current output 1 (0351-1) 102
 - Current output 2 (0351-2) 102
- Measuring mode (0457) 114
- Measuring mode (0479) 119
- Measuring value at maximum frequency (0475) 118
- Measuring value at minimum frequency (0476) 118
- Methane fraction (5631) 79
- Methane fraction factor (5653) 90
- Methane fraction of wet gas (5633) 52
- Methane fraction offset (5652) 90
- Min. update period
 - Burst configuration 1 to 3 (2042-1 to 3) 141
- Minimum frequency value (0453) 117
- Minimum value (0688) 184
- Minimum value (0689) 183
- Minimum value (5617) 185
- Minimum value (5624) 187
- Minimum value (5629) 187
- Nitrogen fraction (5635) 80
- No. of preambles (0217) 134
- Nominal diameter (2807) 92
- Off value low flow cutoff (1804) 78
- On value low flow cutoff (1805) 77
- Operating mode (0469) 112
- Operating time (0652) 28, 165
- Operating time from restart (0653) 165
- Order code (0008) 173
- Output current 1 to 2 (0361-1 to 2) 56, 109
- Output frequency (0471) 57, 123
- Oxygen fraction (5636) 80
- Path configuration (5638) 93
- Preset value 1 to 3 (0913-1 to 3) 161
- Pressure compensation (5641) 82
- Pressure unit (0564) 65
- Previous diagnostics (0690) 164
- Primary variable (PV) (0201) 146
- Process temperature (5621) 83
- Process variable value (1811) 190
- Pulse output (0456) 56, 115
- Pulse output simulation (0458) 193
- Pulse value (0459) 194
- Pulse width (0452) 114
- Quaternary variable (QV) (0203) 149
- Reference combustion temperature (5643) 85
- Reference conditions (5644) 85
- Relative humidity (5645) 81
- Relative humidity (5646) 81
- Reset all totalizers (2806) 157
- Reset min/max values (5647) 183
- Reset write protection (0019) 44
- Response time
 - Current output 1 (0378-1) 107
 - Current output 2 (0378-2) 107
- Response time (0491) 121
- Secondary variable (SV) (0226) 147
- Select gas type (5662) 79
- Sensor version (5637) 93
- Separator (0101) 26
- Serial number (0009) 172
- Signal path control (5673) 93
- Signal strength (5650) 50
- Signal to noise ratio (5656) 50
- Simulation current input 1 (1608-1) 191
- Simulation current output 1 to 2 (0354-1 to 2) .. 191
- Simulation device alarm (0654) 195
- Slot number (7010) 130
- Software option overview (0015) 43
- Software revision (0072) 175, 176
- Software revision (0224) 144
- Sound velocity (1863) 49
- Sound velocity (5658) 52
- Start-up current
 - Current output 1 (0369-1) 110
 - Current output 2 (0369-2) 110
- Start-up mode
 - Current output 1 (0368-1) 110
 - Current output 2 (0368-2) 110
- Status (7004) 133
- Switch output function (0481) 123
- Switch output simulation (0462) 194
- Switch status (0461) 57, 126
- Switch status (0463) 194
- Switch-off delay (0465) 126
- Switch-off value (0464) 125
- Switch-on delay (0467) 126
- Switch-on value (0466) 124
- Temperature (1857) 49
- Temperature damping (1822) 76
- Temperature factor (1856) 91
- Temperature offset (1855) 91
- Temperature unit (0557) 65
- Terminal voltage 1
 - Current output 1 (0662-1) 111
- Terminal voltage 1 (0662) 56
- Tertiary variable (TV) (0228) 148
- Timeout (7005) 131
- Timestamp (0667) 164
- Timestamp (0672) 164
- Timestamp (0683) 166

Timestamp (0684)	167
Timestamp (0685)	167
Timestamp (0686)	168
Timestamp (0687)	169
Totalizer operation mode	
Totalizer 1 to 3 (0908–1 to 3)	160
Totalizer overflow 1 to 3 (0910–1 to 3)	54
Totalizer value 1 to 3 (0911–1 to 3)	53
Turbulence (5661)	51
Unit totalizer	
Totalizer 1 to 3 (0915–1 to 3)	158
User calorific value factor (0583)	73
User calorific value offset (0584)	73
User calorific value text (0585)	72
User corrected volume factor (0590)	69
User corrected volume offset (0602)	69
User corrected volume text (0592)	70
User energy factor (0586)	72
User energy offset (0599)	72
User energy text (0600)	71
User mass factor (0561)	71
User mass offset (0562)	71
User mass text (0560)	70
User pressure factor (0579)	74
User pressure offset (0580)	73
User pressure text (0581)	73
User volume factor (0568)	69
User volume offset (0569)	68
User volume text (0567)	68
Value (7003)	132
Value 1 display (0107)	18
Value 2 display (0108)	20
Value 3 display (0110)	21
Value 4 display (0109)	23
Value current input 1 (1609–1)	191
Value current output 1 to 2 (0355–1 to 2)	192
Value per pulse (0455)	113
Velocity unit (0566)	66
Volume flow (1838)	46
Volume flow factor (1832)	87
Volume flow offset (1831)	87
Volume flow unit (0553)	58
Volume unit (0563)	59
Wobbe index (1854)	48
Zero point (5666)	92
Direct access (Parameter)	11
Display (Submenu)	14
Display channel 1 (Submenu)	180
Display channel 2 (Submenu)	181
Display channel 3 (Submenu)	181
Display channel 4 (Submenu)	182
Display damping (Parameter)	24
Display interval (Parameter)	24
Display module (Submenu)	176
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4

Symbols used	6
Target group	4
Using the document	4
Document function	4
Dry methane damping (Parameter)	75
Dry methane in % (Parameter)	47

E

Energy flow (Parameter)	47
Energy flow factor (Parameter)	90
Energy flow offset (Parameter)	89
Energy flow unit (Parameter)	62
Energy unit (Parameter)	63
ENP version (Parameter)	174
Enter access code (Parameter)	14
Event category 123 (Parameter)	150
Event category 124 (Parameter)	151
Event category 125 (Parameter)	151
Event category 160 (Parameter)	151
Event category 441 (Parameter)	152
Event category 442 (Parameter)	152
Event category 443 (Parameter)	152
Event category 444 (Parameter)	153
Event category 452 (Parameter)	153
Event category 801 (Parameter)	154
Event category 832 (Parameter)	154
Event category 833 (Parameter)	154
Event category 834 (Parameter)	155
Event category 835 (Parameter)	155
Event category 837 (Parameter)	155
Event category 841 (Parameter)	156
Event category 881 (Parameter)	156
Event list (Submenu)	170
Event logbook (Submenu)	169
Extended order code 1 (Parameter)	173
Extended order code 2 (Parameter)	174
Extended order code 3 (Parameter)	174
External compensation (Submenu)	82
External pressure (Submenu)	188

F

Factory settings	197
SI units	197
US units	198
Failure current (Parameter)	109
Failure frequency (Parameter)	122
Failure mode (Parameter) 95, 108, 115, 121, 126, 131,	162
Failure value (Parameter)	96, 132
Filter options (Parameter)	169
Firmware version (Parameter)	172
Fixed current (Parameter)	99
Flow damping (Parameter)	75
Flow override (Parameter)	74
Flow velocity (Parameter)	49, 52
Flow velocity (Submenu)	187
Format display (Parameter)	16
Frequency Output Simulation (Parameter)	192
Frequency Value (Parameter)	193

Function
see Parameter

G

Gas fraction (Parameter) 81

H

Hardware revision (Parameter) 144
HART address (Parameter) 134
HART date code (Parameter) 144
HART descriptor (Parameter) 143
HART input (Submenu) 127
HART message (Parameter) 143
HART output (Submenu) 133
HART revision (Parameter) 143
HART short tag (Parameter) 134
Header (Parameter) 24
Header text (Parameter) 25
Heartbeat (Submenu) 188

I

I/O module (Submenu) 175
Information (Submenu) 141
Input (Submenu) 94, 132
Input values (Submenu) 54
Invert output signal (Parameter) 127
IO module temperature (Submenu) 184

L

Language (Parameter) 15
Last backup (Parameter) 28
Locking status (Parameter) 12
Logging interval (Parameter) 179
Low flow cut off (Submenu) 76

M

Main electronic temperature (Submenu) 185
Mainboard module (Submenu) 175
Manufacturer ID (Parameter) 129, 143
Mass flow (Parameter) 47
Mass flow factor (Parameter) 89
Mass flow offset (Parameter) 89
Mass flow unit (Parameter) 61
Mass unit (Parameter) 62
Max. update period (Parameter) 141
Maximum frequency value (Parameter) 117
Maximum value (Parameter) .. 184, 185, 186, 187, 188
Measured current 1 (Parameter) 55, 56, 111
Measured values (Submenu) 45
Measured values 1 (Parameter) 55
Measurement mode (Submenu) 78
Measuring mode (Parameter) 102, 114, 119
Measuring value at maximum frequency (Parameter)
..... 118
Measuring value at minimum frequency (Parameter)
..... 118
Medium temperature (Submenu) 186
Methane fraction (Parameter) 79
Methane fraction factor (Parameter) 90
Methane fraction of wet gas (Parameter) 52

Methane fraction offset (Parameter) 90
Min. update period (Parameter) 141
Min/max values (Submenu) 182
Minimum frequency value (Parameter) 117
Minimum value (Parameter) 183, 184, 185, 187

N

Nitrogen fraction (Parameter) 80
No. of preambles (Parameter) 134
Nominal diameter (Parameter) 92

O

Off value low flow cutoff (Parameter) 78
On value low flow cutoff (Parameter) 77
Operating mode (Parameter) 112
Operating time (Parameter) 28, 165
Operating time from restart (Parameter) 165
Order code (Parameter) 173
Output (Submenu) 96, 145
Output current 1 to 2 (Parameter) 56, 109
Output frequency (Parameter) 57, 123
Output values (Submenu) 55
Oxygen fraction (Parameter) 80

P

Parameter

Structure of a parameter description 6
Path configuration (Parameter) 93
Preset value 1 to 3 (Parameter) 161
Pressure compensation (Parameter) 82
Pressure unit (Parameter) 65
Previous diagnostics (Parameter) 164
Primary variable (PV) (Parameter) 146
Process parameters (Submenu) 74
Process temperature (Parameter) 83
Process variable adjustment (Submenu) 86
Process variable value (Parameter) 190
Process variables (Submenu) 45
Properties (Submenu) 92
Pulse output (Parameter) 56, 115
Pulse output simulation (Parameter) 193
Pulse value (Parameter) 194
Pulse width (Parameter) 114
Pulse/frequency/switch output (Submenu) 111

Q

Quaternary variable (QV) (Parameter) 149

R

Reference combustion temperature (Parameter) 85
Reference conditions (Parameter) 85
Reference values (Submenu) 85
Relative humidity (Parameter) 81
Reset all totalizers (Parameter) 157
Reset min/max values (Parameter) 183
Reset write protection (Parameter) 44
Response time (Parameter) 107, 121

S

Secondary variable (SV) (Parameter) 147

Select gas type (Parameter)	79
Sensor (Submenu)	44
Sensor adjustment (Submenu)	86
Sensor version (Parameter)	93
Separator (Parameter)	26
Serial number (Parameter)	172
Signal path control (Parameter)	93
Signal strength (Parameter)	50
Signal to noise ratio (Parameter)	50
Simulation (Submenu)	189
Simulation current input 1 (Parameter)	191
Simulation current output 1 to 2 (Parameter)	191
Simulation device alarm (Parameter)	195
Slot number (Parameter)	130
Software option overview (Parameter)	43
Software revision (Parameter)	144, 175, 176
Sound velocity (Parameter)	49, 52
Start-up current (Parameter)	110
Start-up mode (Parameter)	110
Status (Parameter)	133
Submenu	
Administration	39
Application	157
Burst configuration 1 to 3	135
Calculated values	84
Calibration	91
Communication	127
Configuration	127, 133
Configuration backup display	27
Current input	94
Current output 1 to 2	96
Data logging	176
Device information	171
Diagnostic behavior	32
Diagnostic configuration	149
Diagnostic handling	31
Diagnostic list	165
Diagnostics	162
Display	14
Display channel 1	180
Display channel 2	181
Display channel 3	181
Display channel 4	182
Display module	176
Event list	170
Event logbook	169
External compensation	82
External pressure	188
Flow velocity	187
HART input	127
HART output	133
Heartbeat	188
I/O module	175
Information	141
Input	94, 132
Input values	54
IO module temperature	184
Low flow cut off	76
Main electronic temperature	185

Mainboard module	175
Measured values	45
Measurement mode	78
Medium temperature	186
Min/max values	182
Output	96, 145
Output values	55
Process parameters	74
Process variable adjustment	86
Process variables	45
Properties	92
Pulse/frequency/switch output	111
Reference values	85
Sensor	44
Sensor adjustment	86
Simulation	189
System	14
System units	58
System values	50
Terminal voltage	183
Totalizer	53
Totalizer 1 to 3	157
User-specific units	67
Switch output function (Parameter)	123
Switch output simulation (Parameter)	194
Switch status (Parameter)	57, 126, 194
Switch-off delay (Parameter)	126
Switch-off value (Parameter)	125
Switch-on delay (Parameter)	126
Switch-on value (Parameter)	124
System (Submenu)	14
System units (Submenu)	58
System values (Submenu)	50

T

Target group	4
Temperature (Parameter)	49
Temperature damping (Parameter)	76
Temperature factor (Parameter)	91
Temperature offset (Parameter)	91
Temperature unit (Parameter)	65
Terminal voltage (Submenu)	183
Terminal voltage 1 (Parameter)	56, 111
Tertiary variable (TV) (Parameter)	148
Timeout (Parameter)	131
Timestamp (Parameter)	164, 166, 167, 168, 169
Totalizer (Submenu)	53
Totalizer 1 to 3 (Submenu)	157
Totalizer operation mode (Parameter)	160
Totalizer overflow 1 to 3 (Parameter)	54
Totalizer value 1 to 3 (Parameter)	53
Turbulence (Parameter)	51

U

Unit totalizer (Parameter)	158
User calorific value factor (Parameter)	73
User calorific value offset (Parameter)	73
User calorific value text (Parameter)	72
User corrected volume factor (Parameter)	69

User corrected volume offset (Parameter)	69
User corrected volume text (Parameter)	70
User energy factor (Parameter)	72
User energy offset (Parameter)	72
User energy text (Parameter)	71
User mass factor (Parameter)	71
User mass offset (Parameter)	71
User mass text (Parameter)	70
User pressure factor (Parameter)	74
User pressure offset (Parameter)	73
User pressure text (Parameter)	73
User volume factor (Parameter)	69
User volume offset (Parameter)	68
User volume text (Parameter)	68
User-specific units (Submenu)	67

V

Value (Parameter)	132
Value 1 display (Parameter)	18
Value 2 display (Parameter)	20
Value 3 display (Parameter)	21
Value 4 display (Parameter)	23
Value current input 1 (Parameter)	191
Value current output 1 to 2 (Parameter)	192
Value per pulse (Parameter)	113
Velocity unit (Parameter)	66
Volume flow (Parameter)	46
Volume flow factor (Parameter)	87
Volume flow offset (Parameter)	87
Volume flow unit (Parameter)	58
Volume unit (Parameter)	59

W

Wizard	
Define access code	40
Wobbe index (Parameter)	48

Z

Zero point (Parameter)	92
----------------------------------	----

www.addresses.endress.com
