

Description of Device Functions

Cubemass DCI

Modbus RS485
Coriolis flowmeter




Table of contents

1	Using this manual	7
1.1	Finding a function description	7
1.1.1	Using the table of contents → 3	7
1.1.2	Using the graphic of the function matrix	7
1.1.3	Using the index of the function matrix → 125	7
2	Function matrix	8
2.1	General layout of the function matrix	8
2.1.1	Blocks (A, B, C etc.)	8
2.1.2	Groups (AAA, AEA, CAA etc.)	8
2.1.3	Function groups (000, 020, 060 etc.)	8
2.1.4	Functions (0000, 0001, 0002 etc.)	8
2.1.5	Codes identifying cells	9
2.2	Illustration of the function descriptions	10
2.3	Display lines on the local display	10
2.4	Function matrix	11
3	Block MEASURED VARIABLES	12
3.1	Group MEASURING VALUES	13
3.1.1	Function group MAIN VALUES	13
3.2	Group SYSTEM UNITS	14
3.2.1	Function group CONFIGURATION	14
3.2.2	Function group ADDITIONAL CONFIGURATION	17
4	Block QUICK SETUP	19
4.1	Quick Setup	21
4.1.1	Quick Setup "Commissioning"	21
4.1.2	Quick Setup "Pulsating Flow"	23
4.1.3	Quick Setup "Gas Measurement"	25
4.1.4	Quick Setup "Communication"	26
4.2	Data back-up/transfer	27
5	Block USER INTERFACE	28
5.1	Group CONTROL	29
5.1.1	Function group BASIC CONFIGURATION	29
5.1.2	Function group UNLOCKING/LOCKING	31
5.1.3	Function group OPERATION	32
5.2	Group MAIN LINE	33
5.2.1	Function group CONFIGURATION	33
5.2.2	Function group MULTIPLEX	35
5.3	Group ADDITIONAL LINE	37
5.3.1	Function group CONFIGURATION	37
5.3.2	Function group MULTIPLEX	39
5.4	Group INFORMATION LINE	41
5.4.1	Function group CONFIGURATION	41
5.4.2	Function group MULTIPLEX	43
6	Block TOTALIZER	45
6.1	Group TOTALIZER (1 to 3)	46
6.1.1	Function group CONFIGURATION	46
6.1.2	Function group OPERATION	48

6.2	Group HANDLING TOTALIZER	49
7	Block OUTPUTS	50
7.1	Group CURRENT OUTPUT	51
7.1.1	Function group CONFIGURATION	51
7.1.2	Function group OPERATION	60
7.1.3	Function group INFORMATION	61
7.2	Group PULSE/FREQUENCY OUTPUT	62
7.2.1	Function group CONFIGURATION	62
7.2.2	Function group OPERATION	79
7.2.3	Function group INFORMATION	82
7.3	Group RELAY OUTPUT (1 to 2)	83
7.3.1	Function group CONFIGURATION	83
7.3.2	Function group OPERATION	87
7.3.3	Function group INFORMATION	88
7.3.4	Information on the response of the relay output	89
7.3.5	Switching behavior of the relay output	90
8	Block INPUTS	92
8.1	Group STATUS INPUT	93
8.1.1	Function group CONFIGURATION	93
8.1.2	Function group OPERATION	94
8.1.3	Function group INFORMATION	95
9	Block BASIC FUNCTION	96
9.1	Group Modbus RS485	97
9.1.1	Function group CONFIGURATION	97
9.2	Group PROCESS PARAMETER	100
9.2.1	Function group CONFIGURATION	100
9.2.2	Function group EPD PARAMETER	102
9.2.3	Function group REFERENCE PARAMETER	104
9.2.4	Function group ADJUSTMENT	106
9.2.5	Function group PRESSURE CORRECTION	108
9.3	Group SYSTEM PARAMETER	109
9.3.1	Function group CONFIGURATION	109
9.4	Group SENSOR DATA	110
9.4.1	Function group CONFIGURATION	110
9.4.2	Function group FLOW COEFFICIENT	111
9.4.3	Function group DENSITY COEFFICIENT	112
9.4.4	Function group ADDITIONAL COEFFICIENT	113
10	Block SUPERVISION	114
10.1	Group SYSTEM	115
10.1.1	Function group CONFIGURATION	115
10.1.2	Function group OPERATION	116
10.2	Group VERSION-INFO	118
10.2.1	Function group DEVICE	118
10.2.2	Function group SENSOR	119
10.2.3	Function group AMPLIFIER	120
10.2.4	Function group I/O MODULE	121
10.2.5	Function groups I/O SUBMODULE 2 to 4	122
11	Factory settings	123
11.1	SI units (not for USA and Canada)	123
11.1.1	Low flow cut off, full scale value, pulse value	123

11.2 US units (only for USA and Canada)	123
11.2.1 Low flow cut off, full scale value, pulse value	123
Index of function matrix	125
Index.....	129

1 Using this manual

This manual must be used in conjunction with the Operating Instructions of the measuring device. A description of all the functions of the measuring device is provided here.

1.1 Finding a function description

There are various ways of locating the description of a function of your choice in the manual:

1.1.1 Using the table of contents → 3

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as USER INTERFACE, INPUTS, OUTPUTS etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question.

1.1.2 Using the graphic of the function matrix


This step-by-step, top-down approach starts with the blocks, the highest level, and factory down through the matrix to the description of the function you need:

1. All blocks available, and their related groups, are illustrated on →  11. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.1.3 Using the index of the function matrix → 125

Each "cell" in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected "cell" appears at the top right on the local display.

The function matrix index lists the codes for all the available "cells" in alphabetic and consecutive order, complete with the page references for the corresponding functions.



A0004821-EN

Fig. 1: Local display

- 1 Name of the function, e.g. mass flow, user interface
2 Function code, e.g. 0000, CAA

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks → Groups → Function groups → Functions




Fig. 2: Layout of the function matrix

2.1.1 Blocks (A, B, C etc.)

The blocks are the highest-level grouping of the operation options for the device. The blocks include, for example: MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZER etc.

2.1.2 Groups (AAA, AEA, CAA etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the "USER INTERFACE" block, for example, include: CONTROL, MAIN LINE, ADDITION LINE etc.

2.1.3 Function groups (000, 020, 060 etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the "CONTROL" group, for example, include: BASIC CONFIG., UNLOCKING/LOCKING, CONTROL etc.

2.1.4 Functions (0000, 0001, 0002 etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the measuring instrument. Numerical values can be entered or parameters selected and saved. Available functions of the function group "BASIC CONFIG." are: LANGUAGE, DISPLAY DAMPING, CONTRAST LCD etc.

The procedure for changing the language of the user interface, for example, is as follows:

1. Select the block "USER INTERFACE".
2. Select the group "CONTROL".
3. Select the function group "BASIC CONFIG.".
4. Select the function "LANGUAGE" (here you can set the language required).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A _ _; the codes of the groups in block B start with a B _ _ etc.). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100 etc.).

Functions:


The code consists of four digits (0000, 0001, 0201 etc.).

The first three digits are the same as the code for the function group.

The last digit counts the functions in the function group, counting up from 0 to 9 (for example, function 0005 is the sixth function in the group 000).



2.2 Illustration of the function descriptions



A0004827-EN

Fig. 3: Example for the description of a function

- 1 Name of the function
- 2 Number of the function (appears on the local display; is **not** identical to the Modbus RS485 register address)
- 3 Description of the function
- 4 Selection or entry options or display
- 5 Factory setting (the measuring device is delivered with this setting/selected option)
- 6 Information on communication via Modbus RS485
 - Modbus RS485 register (information in decimal numerical format)
 - Data type: float (length = 4 bytes), integer (length = 2 bytes), string (length = depends on function)
 - Possible ways of accessing the function:
read = read access via function code 03, 04 or 23
write = write access via function code 06, 16 or 23




Note!

If a nonvolatile device parameter is modified via the Modbus RS485 function codes 06, 16 or 23, this change is saved in the EEPROM of the measuring device. The number of writes to the EEPROM is technically restricted to a maximum of 1 million. Attention must be paid to this limit since, if exceeded, it results in data loss and measuring device failure. For this reason, avoid constantly writing nonvolatile device parameters via the Modbus RS485!

2.3 Display lines on the local display

The local display is split into various display lines.



A0001253

Fig. 4: Local display

- 1 Main line
- 2 Additional line
- 3 Information line

The values are assigned to the individual lines in the block → 29.

2.4 Function matrix

Blocks	Groups	Function groups
MEASURED VARIABLES A → 12)	MEASURING VALUES AAA SYSTEM UNITS ACA	→ → 13 → → 14
QUICK SETUP B → 19)	Commissioning and application setups	→ → 19
USER INTERFACE C → 28)	CONTROL CAA MAIN LINE CCA ADDITIONAL LINE CEA INFORMATION LINE CGA	→ → 29 → → 33 → → 37 → → 41
TOTALIZER D → 45)	TOTALIZER 1 DAA TOTALIZER 2 DAB TOTALIZER 3 DAC HANDLING TOTALIZER DJA	→ → 46 → → 46 → → 46 → → 49
OUTPUTS E → 50)	CURRENT OUTPUT EAA PULSE/FREQ. OUTPUT ECA RELAY OUTPUT 1 EGA RELAY OUTPUT 2 EGB	→ → 51 → → 62 → → 83 → → 83
INPUTS F → 92)	STATUS INPUT FAA	→ → 93
BASIC FUNCTION G → 96)	MODBUS RS485 GDA PROCESS PARAMETER GIA SYSTEM PARAMETER GLA SENSOR DATA GNA	→ → 97 → → 100 → → 109 → → 110
SUPERVISION J → 114)	SYSTEM JAA VERSION-INFO JCA	→ → 115 → → 118

3 Block MEASURED VARIABLES

Block	Groups	Function groups	Functions					
MEASURED VARIABLES (A)	MEASURING VALUES (AAA) ⇒	MAIN VALUES ⇒ (000) → 13	MASS FLOW ⇒ (0000) → 13	VOLUME FLOW ⇒ (0001) → 13	CORRECTED VOLUME FLOW ⇒ (0004) → 13	DENSITY ⇒ (0005) → 13	REFERENCE DENSITY ⇒ (0006) → 13	TEMPERATURE ⇒ (0008) → 13
		SYSTEM UNITS (ACA) ⇒ 14	CONFIGURATION ⇒ (040) ⇒ 14	UNIT MASS FLOW ⇒ (0400) ⇒ 14	UNIT VOL. FLOW ⇒ 15	UNIT VOLUME ⇒ 15	UNIT CORR. FLOW ⇒ (0404) ⇒ 16	UNIT CORR. VOLUME ⇒ (0405) ⇒ 16
			ADDITIONAL CONFIGURATION ⇒ (042) ⇒ 17	UNIT REF. DENSITY ⇒ (0421) ⇒ 17	UNIT TEMPERATURE ⇒ (0422) ⇒ 18	UNIT LENGTH ⇒ (0424) ⇒ 18	UNIT PRESSURE ⇒ (0426) ⇒ 18	

3.1 Group MEASURING VALUES


3.1.1 Function group MAIN VALUES



Function description MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES			
Note! <ul style="list-style-type: none"> ■ The units of all the measured variables shown here can be set in the SYSTEM UNITS group. ■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. 			
MASS FLOW Modbus register: Data type: Access:	0000 2007 247 Float read	The currently measured mass flow appears on the display. Display: 5-digit floating-point number, including unit and sign (e.g. 462.87 kg/h; -731.63 lb/min etc.)	
VOLUME FLOW Modbus register: Data type: Access:	0001 2009 253 Float read	The calculated volume flow appears on the display. The volume flow is derived from the measured mass flow and the measured density of the fluid. Display: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d etc.)	
CORRECTED VOLUME FLOW Modbus register: Data type: Access:	0004 2011 Float read	The calculated corrected volume flow appears on the display. The calculated corrected volume flow is derived from the measured mass flow and the reference density of the fluid (density at reference temperature, measured or fixed entry). Display: 5-digit floating-point number, including unit and sign (e.g. 1.3549 Nm³/h; 7.9846 scm/day etc.)	
DENSITY Modbus register: Data type: Access:	0005 2013 249 Float read	The currently measured density or its specific gravity appears on the display. Display: 5-digit floating point number, incl. unit (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C etc.)	
REFERENCE DENSITY Modbus register: Data type: Access:	0006 2015 Float read	The density of the fluid, at reference temperature, appears on the display. The reference density can be measured or also specified via the function FIXED REFERENCE DENSITY (6461) (→ 104). Display: 5-digit floating point number, incl. unit (e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C etc.)	
TEMPERATURE Modbus register: Data type: Access:	0008 2017 251 Float read	The currently measured temperature appears on the display. Display: Max. 4-digit fixed-point number, including unit and sign (e.g. -23.4 °C; 160.0 °F; 295.4 K etc.)	

3.2 Group SYSTEM UNITS

3.2.1 Function group CONFIGURATION




Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
<p>You can select the units for measured variables in this function group.</p>		
UNIT MASS FLOW 0400 Modbus register: 2101 Data type: Integer Access: read/ write	<p>For selecting the unit for displaying the mass flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ▪ Current output ▪ Frequency output ▪ Relay switch points (limit value for mass flow, flow direction) ▪ Low flow cut off <p>Options:</p> <p>Metric: 0 to 3 = gram → g/s; g/min; g/h; g/day 4 to 7 = kilogram → kg/s; kg/min; kg/h; kg/day 8 to 11 = ton → t/s; t/min; t/h; t/day</p> <p>US: 12 to 15 = ounce → oz/s; oz/min; oz/h; oz/day 16 to 19 = pound → lb/s; lb/min; lb/h; lb/day 20 to 23 = ton → ton/s; ton/min; ton/h; ton/day</p> <p>Factory setting: Country-dependent (kg/h or US-lb/min)</p>	
UNIT MASS 0401 Modbus register: 2102 Data type: Integer Access: read/ write	<p>For selecting the unit for displaying the mass.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ▪ Pulse value (e.g. kg/p) <p>Options:</p> <p>Metric: 0 = g 1 = kg 2 = t</p> <p>US: 3 = oz 4 = lb 5 = ton</p> <p>Factory setting: Country-dependent (kg or US-lb)</p> <p> Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>	

Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
UNIT VOLUME FLOW Modbus register: Data type: Access:	0402 2103 Integer read/ write	<p>For selecting the unit for displaying the volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for volume flow, flow direction) ■ Low flow cut off <p>Options:</p> <p>Metric:</p> <p>0 to 3 = cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day 4 to 7 = cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day 8 to 11 = cubic meter → m³/s; m³/min; m³/h; m³/day 12 to 15 = milliliter → ml/s; ml/min; ml/h; ml/day 16 to 19 = liter → l/s; l/min; l/h; l/day 20 to 23 = hectoliter → hl/s; hl/min; hl/h; hl/day 24 to 27 = megaliter → Ml/s; Ml/min; Ml/h; Ml/day</p> <p>US:</p> <p>28 to 31 = cubic centimeter → cc/s; cc/min; cc/h; cc/day 32 to 35 = acre foot → af/s; af/min; af/h; af/day 36 to 39 = cubic foot → ft³/s; ft³/min; ft³/h; ft³/day 40 to 43 = fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day 44 to 47 = gallon → gal/s; gal/min; gal/h; gal/day 88 to 92 = kilo gallon → Kgal/s; Kgal/min; Kgal/h; Kgal/day 48 to 51 = million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day 52 to 55 = barrel (normal fluids: 31.5 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 56 to 59 = barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 60 to 63 = barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 64 to 67 = barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Imperial:</p> <p>68 to 71 = gallon → gal/s; gal/min; gal/h; gal/day 72 to 75 = mega gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day 76 to 79 = barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day 80 to 83 = barrel (petrochemicals: 34.97 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day</p> <p>Factory setting: Country-dependent (m³/h or US-Mgal/day)</p>
UNIT VOLUME Modbus register: Data type: Access:	0403 2104 Integer read/ write	<p>For selecting the unit for displaying the volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Pulse value (e.g. m³/p) <p>Options:</p> <p>0 to 6 = metric → cm³; dm³; m³; ml; l; hl; Ml Mega 7 to 16 = US → cc; af; ft³; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) 22 = Kgal 17 to 20 = Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals)</p> <p>Factory setting: m³</p> <p> Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>

Function description MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION		
UNIT CORRECTED VOLUME FLOW Modbus register: Data type: Access:	0404 2105 Integer read/ write	<p>For selecting the unit for displaying the corrected volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ▪ Current output ▪ Frequency output ▪ Relay switch points (limit value for corrected volume flow, flow direction) ▪ Low flow cut off <p>Options:</p> <p>Metric:</p> <p>0 = NL/s 1 = NL/min 2 = NL/h 3 = NL/day 4 = Nm³/s 5 = Nm³/min 6 = Nm³/h 7 = Nm³/day</p> <p>US:</p> <p>8 = Sm³/s 9 = Sm³/min 10 = Sm³/h 11 = Sm³/day 12 = Scf/s 13 = Scf/min 14 = Scf/h 15 = Scf/day</p> <p>Factory setting: Nm³/h</p>
UNIT CORRECTED VOLUME Modbus register: Data type: Access:	0405 2106 Integer read/ write	<p>For selecting the unit for displaying the corrected volume.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ▪ Pulse value (e.g. Nm³/p) <p>Options:</p> <p>Metric:</p> <p>0 = Nm³ 1 = NL</p> <p>US:</p> <p>2 = Sm³ 3 = Scf</p> <p>Factory setting: Nm³</p> <p> Note! The unit for the totalizers is independent of the selection made here and is selected separately for each totalizer.</p>

3.2.2 Function group ADDITIONAL CONFIGURATION



Function description MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION		
UNIT DENSITY 0420	<p>For selecting the unit for displaying the density.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for density) ■ Density response value for EPD ■ Density adjustment value <p>Options: 0 to 10 = metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C</p> <p>11 to 16 = US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks)</p> <p>17 to 19 = Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals)</p> <p>Factory setting: kg/l</p> <p>SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C).</p>	
UNIT REFERENCE DENSITY 0421	<p>For selecting the unit for displaying the reference density.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ■ Current output ■ Frequency output ■ Relay switch points (limit value for density) ■ Fixed reference density (for calculation of corrected volume flow) <p>Options: Metric: 1 = kg/Nl 2 = kg/Nm³</p> <p>US: 0 = g/Scc 3 = kg/sm³ 4 = lb/Scf</p> <p>Factory setting: kg/Nl</p>	

Function description		
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION		
UNIT TEMPERATURE Modbus register: Data type: Access:	0422 2109 Integer read/ write	<p>For selecting the unit for displaying the temperature.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> ▪ Current output ▪ Frequency output ▪ Relay switch points (limit value for temperature) ▪ Reference temperature (for corrected vol. measurement with measured reference density) <p>Options:</p> <p>0 = °C (Celsius) 1 = K (Kelvin) 2 = °F (Fahrenheit) 3 = °R (Rankine)</p> <p>Factory setting: °C</p>
UNIT LENGTH Modbus register: Data type: Access:	0424 2125 Integer read/ write	<p>For selecting the unit for displaying the length of the nominal diameter.</p> <p>The unit you select here is valid for:</p> <ul style="list-style-type: none"> ▪ Nominal diameter of sensor (function NOMINAL DIAMETER (6804) on → 110) <p>Options:</p> <p>0 = MILLIMETER 1 = INCH</p> <p>Factory setting: MILLIMETER</p>
UNIT PRESSURE Modbus register: Data type: Access:	0426 2130 Integer read/ write	<p>For selecting the unit for displaying the pressure.</p> <p>The unit you select here is valid for:</p> <ul style="list-style-type: none"> ▪ Specified pressure (function PRESSURE (6501) on → 108) <p>Options:</p> <p>0 = bara 1 = barg 2 = psia 3 = psig</p> <p>Factory setting: barg</p>

4 Block QUICK SETUP

Block	Group / Function groups	Functions			
QUICK SETUP (B)	⇒	QS COMMISSION (1002) → 19	QS - PULS. FLOW (1003) → 19	QS - GAS MEASUREMENT	QS - COMMUNICATION (1006) → 19 T-DAT SAVE/LOAD (1009) → 20

Function description QUICK SETUP						
<p> Note!</p> <ul style="list-style-type: none"> ■ The Quick Setups are only available by means of the local display. ■ The flowcharts of the various Quick Setups are provided on the pages to follow. ■ For additional information on the Setups, refer to the Operating Instructions (BA00141D/06). 						
QUICK SETUP COMMISSIONING	1002	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>				
QUICK SETUP PULSATING FLOW	1003	<p> Note! Function only available for measuring devices with a current or frequency output.</p> <p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>				
QUICK SETUP GAS MEASUREMENT	1004	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>				
QUICK SETUP COMMUNICATION	1006	<p>For starting the Setup menu.</p> <p>Options: NO YES</p> <p>Factory setting: NO</p>				

		Function description QUICK SETUP
T-DAT SAVE/LOAD	1009	<p>Use this function to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual backup function).</p> <p>Application examples:</p> <ul style="list-style-type: none"> ▪ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup. ▪ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). <p>Options: 0 = CANCEL 1 = SAVE (from EEPROM to T-DAT) 2 = LOAD (from the T-DAT into EEPROM)</p> <p>Factory setting: CANCEL</p> <p> Note!<ul style="list-style-type: none"> ▪ If the target device has an older software version, the message "TRANSM. SW-DAT" is displayed during startup. Then only the SAVE function is available. ▪ LOAD This function is only possible if the target device has the same software version as, or a more recent software version than, the source device. ▪ SAVE This function is always available. </p>

4.1 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the configuration program, e.g. FieldCare.

If the measuring device is equipped with a local display, all the important device parameters for standard operation can be configured quickly and easily by means of the "Commissioning" Quick Setup menu.

- Quick Setup "Commissioning", see below
- Quick Setup "Pulsating Flow" → 23
- Quick Setup "Gas Measurement" → 25
- Quick Setup "Communication" → 26

4.1.1 Quick Setup "Commissioning"



Note!


- The display returns to the function SETUP COMMISSIONING (1002) if you press the key combination during parameter interrogation. The stored parameters remain valid.
- The "COMMISSIONING" Quick Setup must be carried out before another Quick Setup is run.

1. The "DELIVERY SETTINGS" option sets every selected unit to the factory setting.
The "ACTUAL SETTING" option accepts the units you previously configured.
2. Only units not yet configured in the current Setup are offered for selection in each cycle.
The unit for mass, volume and corrected volume is derived from the corresponding flow unit.
3. The "YES" option remains visible until all the units have been configured.
"NO" is the only option displayed when no further units are available.
4. The prompt only appears if a current output and/or pulse/frequency output is available.
Only the outputs not yet configured in the current Setup are offered for selection in each cycle.
5. The "YES" option remains visible until all the outputs have been configured.
"NO" is the only option displayed when no further outputs are available.
6. The "automatic parameterization of the display" option contains the following basic settings/factory settings:

YES Main line = mass flow
 Additional line = totalizer 1
 Information line = operating/system condition

NO The existing (selected) settings remain.

7. The execution of other Quick Sets are described in the following chapters.



A0011952-EN

Fig. 5: "QUICK SETUP COMMISSIONING"- menu for straightforward configuration of the major device functions

4.1.2 Quick Setup "Pulsating Flow"




Fig. 6: "QUICK SETUP PULSATING FLOW" menu for operation with severely pulsating flow.
Recommended settings are found on the following page.

A0004431-EN

- Only totalizers not yet configured in the current Setup are offered for selection in each cycle.
- The "YES" option remains visible until all the totalizers have been configured.
"NO" is the only option displayed when no further totalizers are available.
- Only the output not yet configured in the current Setup is offered for selection in the second cycle.
- The "YES" option remains visible until both outputs have been parameterized.
"NO" is the only option displayed when no further outputs are available.

**Note!**

- The display returns to the cell QUICK SETUP PULSATING FLOW (1003) if you press the key combination during parameter interrogation.
- You can call up the Setup menu either directly from the "COMMISSIONING" Quick Setup menu or manually by means of the function QUICK SETUP PULSATING FLOW (1003).

Quick Setup "Pulsating Flow"		
HOME position → → MEASURAND → → QUICK SETUP → → QS PULSATING FLOW (1003)		
Function No.	Function name	Selection with To next function with
1003	QS PULS. FLOW	YES After is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.


▼

Basic configuration		
2002	DISPLAY DAMPING	1 s
3002	TOTALIZER MODE (DAA)	BALANCE (Totalizer 1)
3002	TOTALIZER MODE (DAB)	BALANCE (Totalizer 2)
3002	TOTALIZER MODE (DAC)	BALANCE (Totalizer 3)
Signal type for "CURRENT OUTPUT 1"		
4004	MEASURING MODE	PULS. FLOW
4005	TIME CONSTANT	1 s
Signal type for "FREQ./PULSE OUTPUT 1" (for FREQUENCY operating mode)		
4206	MEASURING MODE	PULS. FLOW
4208	TIME CONSTANT	0 s
Signal type for "FREQ./PULSE OUTPUT 1" (for PULSE operating mode)		
4225	MEASURING MODE	PULS. FLOW
Other settings		
8005	ALARM DELAY	0 s
6400	ASSIGN LOW FLOW CUTOFF	MASS FLOW
6402	ON-VALUE LOW FLOW CUT OFF	Setting depends on diameter [kg/h]: DN 1 = 0.08 DN 2 = 0.4 DN 4 = 1.8 DN 6 = 4
6403	OFF-VALUE LOW FLOW CUTOFF	50%
6404	PRESSURE SHOCK SUPPRESSION	0 s

▼

Back to the HOME position: → Press and hold down Esc key for longer than three seconds or → Repeatedly press and release Esc key → Exit the function matrix step by step
--

4.1.3 Quick Setup "Gas Measurement"



A0002502-EN

Fig. 7: QUICK SETUP GAS MEASUREMENT menu

Quick Setup "Gas measurement"		
HOME position → [] → MEASURED VARIABLE (A) MEASURED VARIABLE → [+] → QUICK SETUP (B) QUICK SETUP → [] → QS-GAS MEASUREMENT (1004)		
Function No.	Function name	Setting to be selected ([+]) (to next function with [])
1004	QS GAS MEASUREMENT	YES After [] is pressed by way of confirmation, the Quick Setup menu calls up all the subsequent functions in succession.
▼		
6400	ASSIGN LOW FLOW CUT-OFF	On account of the low mass flow involved when gas flows are measured, it is advisable not use a low flow cutoff. Setting: OFF
6402	ON-VALUE LOW FLOW CUT OFF	If the ASSIGNMENT LOW FLOW CUTOFF function was not set to "OFF", the following applies: Setting: 0.0000 [unit] User input: Flow rates for gas measurements are low, so the value for the switch-on point (= low flow cutoff) must be correspondingly low.
6403	OFF-VALUE LOW FLOW CUTOFF	If the ASSIGNMENT LOW FLOW CUTOFF function was not set to "OFF", the following applies: Setting: 50% User input: Enter the switch-off point as a positive hysteresis in %, referenced to the switch-on point.
▼		
Back to the HOME position: → Press and hold down Esc key [Esc] for longer than three seconds or → Repeatedly press and release Esc key [Esc] → Exit the function matrix step by step		


Note!

Quick Setup automatically deactivates the function EMPTY PIPE DETECTION (6420) so that the instrument can measure flow at low gas pressures.

4.1.4 Quick Setup "Communication"

To establish serial data transfer, various arrangements between the Modbus master and Modbus slave are required which have to be taken into consideration when configuring various functions.

These functions can be configured quickly and easily by means of the "Communication" Quick Setup. The following table explains the parameter configuration options in more detail.



A0004430-en

Settings for the "Communication" Setup menu:			
Fct. code	Function name	Suggested settings	Description
Call up through the function matrix:			
B	QUICK SETUP	QUICK SETUP COMMUNICATION	→ 19
1006	QUICK SETUP COMMUNICATION	YES	→ 19
Basic configuration:		Factory setting:	
6301	FIELDBUS ADDRESS	247	→ 97
6302	BAUDRATE	19200 BAUD	→ 97
6303	TRANSMISSION MODE	RTU	→ 97
6304	PARITY	EVEN	→ 98
6305	BYTE ORDER	1 - 0 - 3 - 2	→ 98
6306	DELAY TELE. REPLY	10 ms	→ 98

4.2 Data back-up/transfer

You can use the T-DAT SAVE/LOAD function to transfer data (device parameters and settings) between the T-DAT (removable memory) and the EEPROM (device memory).


This is required for the following applications:

- Creating a backup: current data are transmitted from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

Installing and removing the T-DAT → Operating Instructions (BA00141D/06)



A0001221-EN

Data storage/transmission with T-DAT SAVE/LOAD

Information on the LOAD and SAVE options available:

LOAD:

Data are transferred from the T-DAT to the EEPROM.



Note!

- Any settings already saved on the EEPROM are deleted.
- This option is only available if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same as, or more recent than, that of the EEPROM. If this is not the case, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE:

Data are transferred from the EEPROM to the T-DAT.

5 Block USER INTERFACE

Block	Groups	Function groups	Functions
USER INTERFACE (C)			
	CONTROL ⇒ (CAA) → 29	BASIC CONFIG. ⇒ (200) → 29 UNLOCKING/LOCKING (202) → 31 TEST DISPLAY (2040) → 32	LANGUAGE ⇒ (2000) → 29 ACCESS CODE ⇒ (2020) → 31 TEST DISPLAY ⇒ (2040) → 32
			DISPLAY DAMPING ⇒ (2002) → 30 PRIVATE CODE ⇒ (2021) → 31
			STATUS ACCESS ⇒ (2022) → 31 COUNTER (2023) → 31
			DISPLAY BACKLIGHT ⇒ (2004) → 30
	MAIN LINE (CCA) → 33	CONFIGURATION ⇒ (220) → 33 MULTIPLEX (222) → 35	ASSIGN ⇒ (2200) → 33 ASSIGN ⇒ (2220) → 35
			100% VALUE ⇒ (2201) → 33 FORMAT ⇒ (2202) → 34
	ADDITIONAL LINE (CEA) → 37	CONFIGURATION ⇒ (240) → 37 MULTIPLEX (242) → 39	ASSIGN ⇒ (2400) → 37 ASSIGN ⇒ (2420) → 39
			100% VALUE ⇒ (2401) → 37 FORMAT ⇒ (2402) → 38
	INFORMATION LINE (CGA) → 41	CONFIGURATION ⇒ (260) → 41 MULTIPLEX (262) → 43	ASSIGN ⇒ (2421) → 39 ASSIGN ⇒ (2422) → 40
			100% VALUE ⇒ (2423) → 40 DISPLAY MODE ⇒ (2403) → 38
			DISPLAY MODE ⇒ (2422) → 40
			FORMAT ⇒ (2423) → 40
			DISPLAY MODE ⇒ (2603) → 42
			FORMAT ⇒ (2602) → 42
			DISPLAY MODE ⇒ (2623) → 44
			FORMAT ⇒ (2622) → 44

5.1 Group CONTROL


5.1.1 Function group BASIC CONFIGURATION

USER INTERFACE C → CONTROL CAA → BASIC CONFIGURATION 200

		Function description
USER INTERFACE → CONTROL → BASIC CONFIGURATION		
LANGUAGE	2000	<p>For selecting the language for all texts, parameters and messages shown on the local display.</p> <p> Note! The displayed options depend on the language group available. The language group that is supplied with the measuring device is displayed in the LANGUAGE GROUP (8226) function (→ 120).</p> <p>Options: (for language group WEST EU / USA) 0 = ENGLISH 1 = DEUTSCH 2 = FRANCAIS 3 = ESPANOL 4 = ITALIANO 5 = NEDERLANDS 12 = PORTUGUESE</p> <p>Options: (for language group EAST EU / SCAND) 0 = ENGLISH 7 = NORSK 8 = SVENSKA 9 = SUOMI 13 = POLISH 14 = RUSSIAN 15 = CZECH</p> <p>Options: (for language group ASIA) 0 = ENGLISH 10 = BAHASA INDONESIA 11 = JAPANESE (syllabary)</p> <p>Options: (for language group CHINA) 0 = ENGLISH 16 = CHINESE</p> <p>Factory setting: Depends on country → 123</p> <p> Note! <ul style="list-style-type: none"> ▪ If you press the / keys simultaneously at startup, the language defaults to "ENGLISH". ▪ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</p>


Function description USER INTERFACE → CONTROL → BASIC CONFIGURATION		
DISPLAY DAMPING Modbus register: Data type: Access:	2002 2503 Float read/ write	For entering a time constant which defines how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Input: 0 to 100 seconds Factory setting: 1 s  Note! Entering the value "0" (seconds) means that the damping is switched off.
CONTRAST LCD Modbus register: Data type: Access:	2003 2505 Float read/ write	For adjusting the display contrast to suit local operating conditions. Input: 10 to 100% Factory setting: 50%
BACKLIGHT Modbus register: Data type: Access:	2004 2566 Float read/ write	For adjusting the backlight to suit local operating conditions. Input: 0 to 100%  Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark. Factory setting: 50%

5.1.2 Function group UNLOCKING/LOCKING



Function description USER INTERFACE → CONTROL → UNLOCKING/LOCKING		
ACCESS CODE Modbus register: Data type: Access:	2020 2508 Float read/ write	<p> Note! This function is only relevant for local operation and has no effect on access via Modbus RS485 communication.</p> <p>All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the ■ or □ keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).</p> <p>You can enable programming by entering your personal code (factory setting = 84, → function DEFINE PRIVATE CODE (2021)).</p> <p>Input: Max. 4-digit number: 0 to 9999</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ Programming is disabled if you do not press a key within 60 seconds following automatic return to the HOME position. ▪ You can also disable programming in this function by entering any number (other than the defined private code). ▪ The Endress+Hauser service organization can be of assistance if you mislay your personal code.
DEFINE PRIVATE CODE Modbus register: Data type: Access:	2021 2510 Float read/ write	<p> Note! This function is only relevant for local operation and has no effect on access via Modbus RS485 communication.</p> <p>For specifying a personal code for enabling programming in the function ACCESS CODE.</p> <p>Input: 0 to 9999 (max. 4-digit number)</p> <p>Factory setting: 84</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ Programming is always enabled with the code "0". ▪ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS Modbus register: Data type: Access:	2022 2512 Integer read	<p>Indicates whether access to the function matrix is currently possible (ACCESS CUSTOMER) or whether configuration is locked (LOCKED).</p> <p>Display: 0 = LOCKED (parameterization disabled) 1 = ACCESS CUSTOMER (parameterization possible)</p>
ACCESS CODE COUNTER Modbus register: Data type: Access:	2023 2568 Integer read	<p>Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix.</p> <p>Display: Max. 7-digit number: 0 to 9999999</p> <p>Factory setting: 0</p>


5.1.3 Function group OPERATION



Function description USER INTERFACE → CONTROL → OPERATION		
TEST DISPLAY Modbus register: Data type: Access:	2040 2513 Integer read/ write	<p>For testing the operability of the local display and its pixels.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p>Test sequence:</p> <ol style="list-style-type: none"> Start the test by selecting "ON". All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds. Main line, additional line and information line show nothing (blank display) for minimum 0.75 second. <p>When the test is completed, the local display returns to its initial state and the setting changes to "OFF".</p>

5.2 Group MAIN LINE


5.2.1 Function group CONFIGURATION



Function description USER INTERFACE → CONTROL → CONFIGURATION			
ASSIGN Modbus register: Data type: Access:	2200 2514 Integer read/ write	<p>For assigning a value to be displayed to the main line (top line in the local display). This value is displayed during normal operation.</p> <p>Options: (standard) 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 </p> <p>Factory setting: MASS FLOW</p>	
100% VALUE Modbus register: Data type: Access:	2201 2519 Float read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2200): <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % </p> <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → 123</p>	

Function description USER INTERFACE → CONTROL → CONFIGURATION		
FORMAT Modbus register: Data type: Access:	2202 2516 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 →kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.2.2 Function group MULTIPLEX




Function description USER INTERFACE → CONTROL → CONFIGURATION			
ASSIGN Modbus register: Data type: Access:	2220 2522 Integer read/ write	<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2220).</p> <p>Options: (standard) 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3</p> <p>Factory setting: OFF</p>	
100% VALUE Modbus register: Data type: Access:	2221 2524 Float read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2220): <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → 123</p>	

Function description USER INTERFACE → CONTROL → CONFIGURATION		
FORMAT Modbus register: Data type: Access:	2222 2523 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX <p>Factory setting: X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 →kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.3 Group ADDITIONAL LINE


5.3.1 Function group CONFIGURATION



Function description USER INTERFACE → ADDITIONAL LINE → CONFIGURATION			
ASSIGN Modbus register: Data type: Access:	2400 2527 Integer read/ write	<p>For assigning a value to be displayed to the additional line (middle line in the local display). This value is displayed during normal operation.</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 20 = TOTALIZER 2 22 = TOTALIZER 3 23 = TAG NAME <p>Factory setting: TOTALIZER 1</p>	
100% VALUE Modbus register: Data type: Access:	2401 2529 Float read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2400):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → 123</p>	

Function description USER INTERFACE → ADDITIONAL LINE → CONFIGURATION		
FORMAT Modbus register: Data type: Access:	2402 2528 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX </p> <p>Factory setting: X.XXXX</p> <p> Note! <ul style="list-style-type: none"> ▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. </p>
DISPLAY MODE Modbus register: Data type: Access:	2403 2531 Integer read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2400): </p> <ul style="list-style-type: none"> ▪ MASS FLOW BARGRAPH IN % ▪ VOLUME FLOW BARGRAPH IN % ▪ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY </p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p>  <p>A0001258</p> <p><i>Fig. 8: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p>  <p>A0001259</p> <p><i>Fig. 9: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

5.3.2 Function group MULTIPLEX




Function description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX			
ASSIGN Modbus register: Data type: Access:	2420 2532 Integer read/ write	<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2400).</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 23 = TAG NAME <p>Factory setting: OFF</p>	
100% VALUE Modbus register: Data type: Access:	2421 2534 Float read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2420):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → 123</p>	

Function description USER INTERFACE → ADDITIONAL LINE → MULTIPLEX		
FORMAT Modbus register: Data type: Access:	2422 2533 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX </p> <p>Factory setting: X.XXXX</p> <p> Note! <ul style="list-style-type: none"> ▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. </p>
DISPLAY MODE Modbus register: Data type: Access:	2423 2536 Integer read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): </p> <ul style="list-style-type: none"> ▪ MASS FLOW BARGRAPH IN % ▪ VOLUME FLOW BARGRAPH IN % ▪ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY </p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p>  <p>A0001258</p> <p><i>Fig. 10: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p>  <p>A0001259</p> <p><i>Fig. 11: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

5.4 Group INFORMATION LINE


5.4.1 Function group CONFIGURATION



Function description			
USER INTERFACE → INFORMATION LINE → CONFIGURATION			
ASSIGN	2600	For assigning a value to be displayed to the information line (bottom line in the local display). This value is displayed during normal operation.	
Modbus register:	2537		
Data type:	Integer		
Access:	read/ write		
		Options: 0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 23 = TAG NAME 24 = OPERATING/SYSTEM CONDITIONS 26 = DISPLAY FLOW DIRECTION	
		Factory setting: OPERATING/SYSTEM CONDITIONS	
100% VALUE	2601		
Modbus register:	2539		
Data type:	Float		
Access:	read/ write		
		Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN %	
		For specifying the flow value to be shown on the display as the 100% value.	
		User input: 5-digit floating-point number	
		Factory setting: depends on nominal diameter and country → 123	

Function description USER INTERFACE → INFORMATION LINE → CONFIGURATION		
FORMAT Modbus register: Data type: Access:	2602 2538 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX </p> <p>Factory setting: X.XXXX</p> <p> Note! <ul style="list-style-type: none"> ▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. </p>
DISPLAY MODE Modbus register: Data type: Access:	2603 2541 Integer read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2600): </p> <ul style="list-style-type: none"> ▪ MASS FLOW BARGRAPH IN % ▪ VOLUME FLOW BARGRAPH IN % ▪ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY </p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p>  <p>A0001258</p> <p><i>Fig. 12: Bar graph for STANDARD option Simple bar graph with 25 / 50 / 75% gradations and integrated sign.</i></p>  <p>A0001259</p> <p><i>Fig. 13: Bar graph for SYMMETRY option Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.</i></p>

5.4.2 Function group MULTIPLEX



Function description USER INTERFACE → INFORMATION LINE → MULTIPLEX		
<p> Note! If you select the BATCHING OPERATING KEYS in the function ASSIGN (2600), the multiplex display functionality is not available in the information line.</p>		
ASSIGN Modbus register: Data type: Access:	2620 2542 Integer read/ write	<p>For assigning a second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2600).</p> <p>Options:</p> <p>0 = OFF 1 = MASS FLOW 2 = MASS FLOW IN % 3 = VOLUME FLOW 4 = VOLUME FLOW IN % 5 = CORRECTED VOLUME FLOW 6 = CORRECTED VOLUME FLOW IN % 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE 10 = MASS FLOW BARGRAPH IN % 11 = VOLUME FLOW BARGRAPH IN % 12 = CORRECTED VOLUME FLOW BARGRAPH IN % 15 = ACTUAL CURRENT 18 = ACTUAL FREQUENCY 20 = TOTALIZER 1 21 = TOTALIZER 2 22 = TOTALIZER 3 23 = TAG NAME 24 = OPERATING/SYSTEM CONDITIONS 26 = DISPLAY FLOW DIRECTION</p> <p>Factory setting: OFF</p>
100% VALUE Modbus register: Data type: Access:	2621 2544 Float read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2620):</p> <ul style="list-style-type: none"> ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ CORRECTED VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % ■ CORRECTED VOLUME FLOW BARGRAPH IN % <p>For specifying the flow value to be shown on the display as the 100% value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: depends on nominal diameter and country → 123</p>

Function description USER INTERFACE → INFORMATION LINE → MULTIPLEX		
FORMAT Modbus register: Data type: Access:	2622 2543 Integer read/ write	<p>For selecting the maximum number of places after the decimal point to be displayed for the display value.</p> <p>Options: 0 = XXXXX 1 = XXXX.X 2 = XXX.XX 3 = XX.XXX 4 = X.XXXX </p> <p>Factory setting: X.XXXX</p> <p> Note! <ul style="list-style-type: none"> ▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. </p>
DISPLAY MODE Modbus register: Data type: Access:	2623 2546 Integer read/ write	<p> Note! This function is not available unless one of the following was selected in the ASSIGN function (2620): </p> <ul style="list-style-type: none"> ▪ MASS FLOW BARGRAPH IN % ▪ VOLUME FLOW BARGRAPH IN % ▪ CORRECTED VOLUME FLOW BARGRAPH IN % <p>Use this function to define the format of the bar graph.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY </p> <p>Factory setting: STANDARD</p> <p>Illustration of bar graph</p>  <p>A0001258</p>

Fig. 14: Bar graph for STANDARD option
 Simple bar graph with 25 / 50 / 75% gradations and integrated sign.



A0001259


Fig. 15: Bar graph for SYMMETRY option
 Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign.

6 Block TOTALIZER

Block	Groups	Function groups	Functions			
TOTALIZER (D)			CONFIGURATION ⇒ (300) → 46 ↓ ↑	ASSIGN ⇒ (300) → 46 ↓ ↑	UNIT TOTALIZER ⇒ (3001) → 46 ↓ ↑	TOTALIZER MODE (3002) ⇒ 47 RESET TOTALIZER (3003) → 47
			OPERATION ⇒ (304) → 48 ↓ ↑	SUM (3040) ⇒ 48 ↓ ↑	OVERFLOW ⇒ (3041) → 48 ↓ ↑	
			TOTALIZER 2 (DAB) → 46 ↓ ↑	CONFIGURATION ⇒ (300) → 46 ↓ ↑	ASSIGN ⇒ (300) → 46 ↓ ↑	UNIT TOTALIZER ⇒ (3001) → 46 ↓ ↑
			OPERATION ⇒ (304) → 48 ↓ ↑	SUM (3040) ⇒ 48 ↓ ↑	OVERFLOW ⇒ (3041) → 48 ↓ ↑	TOTALIZER MODE (3002) ⇒ 47 RESET TOTALIZER (3003) → 47
			TOTALIZER 3 (DAC) → 46 ↓ ↑	CONFIGURATION ⇒ (300) → 46 ↓ ↑	ASSIGN ⇒ (300) → 46 ↓ ↑	UNIT TOTALIZER ⇒ (3001) → 46 ↓ ↑
			OPERATION ⇒ (304) → 48 ↓ ↑	SUM (3040) ⇒ 48 ↓ ↑	OVERFLOW ⇒ (3041) → 48 ↓ ↑	TOTALIZER MODE (3002) ⇒ 47 RESET TOTALIZER (3003) → 47
			HANDLING TOTALIZER (D/A) → 49 ↓ ↑	⇒ ⇒ ⇒	RESET ALL TOTALIZERS (3800) → 49 ↓ ↑	FAILSAFE MODE (3801) → 49 ↓ ↑

6.1 Group TOTALIZER (1 to 3)


6.1.1 Function group CONFIGURATION



Function description TOTALIZER → TOTALIZER (1 to 3) → CONFIGURATION		
<p> Note! The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.</p>		
ASSIGN 3000 Modbus register: Totalizer 1 2601 Totalizer 2 2801 Totalizer 3 3001 Data type: Integer Access: read/ write	For assigning a measured variable to the totalizer in question. Options: 0 = OFF 1 = MASS FLOW 2 = VOLUME FLOW 3 = CORRECTED VOLUME FLOW Factory setting: MASS FLOW Note! <ul style="list-style-type: none"> ■ The totalizer is reset to "0" as soon as the selection is changed. ■ If you select OFF in the function group CONFIGURATION of the totalizer in question, only the ASSIGN (3000) function remains visible. 	
UNIT TOTALIZER 3001 Modbus register: <ul style="list-style-type: none"> ■ Totalizer 1 <ul style="list-style-type: none"> - Mass flow 2602 - Volume flow 2603 - Corr. vol. flow 2604 ■ Totalizer 2 <ul style="list-style-type: none"> - Mass flow 2802 - Volume flow 2803 - Corr. vol. flow 2804 ■ Totalizer 3 <ul style="list-style-type: none"> - Mass flow 3002 - Volume flow 3003 - Corr. vol. flow 3004 Data type: Integer Access: read/ write	For selecting the unit for the measured variable assigned in the function ASSIGN (3000). Options: for the MASS FLOW assignment 0 to 2 = metric → g; kg; t 3 to 4 = US → oz; lb; ton Factory setting: kg Options: for the VOLUME FLOW assignment 0 to 6 = metric → cm ³ ; dm ³ ; m ³ ; ml; l; hl; Ml Mega 7 to 16 = US → cc; af; ft ³ ; oz f; gal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) 22 = Kgal 17 to 20 = Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Factory setting: m ³ Options: for the CORRECTED VOLUME FLOW assignment 0 to 1 = metric → Nl; Nm ³ 2 to 3 = US → Sm ³ ; Scf Factory setting: Nm ³	


Function description TOTALIZER → TOTALIZER (1 to 3) → CONFIGURATION		
TOTALIZER MODE	3002	<p>For selecting how the totalizer should operate.</p> <p>Options: 0 = BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>1 = FORWARD Only positive flow components</p> <p>2 = REVERSE Only negative flow components</p> <p>Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE</p>
RESET TOTALIZER	3003	<p>Resets the total and the overflow of the totalizer to zero.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p> <p> Note! ■ If the device is equipped with a status input, with the appropriate configuration a reset for each individual totalizer can also be triggered by a pulse (→ the function ASSIGN STATUS INPUT (5000) on → 93).</p>

6.1.2 Function group OPERATION



Function description TOTALIZER → TOTALIZER (1 to 3) → OPERATION		
<p> Note!</p> <p>The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.</p>		
SUM 3040 Modbus register: Totalizer 1 2610 Totalizer 2 2810 Totalizer 3 3010 Data type: Float Access: read		<p>Displays the total for the totalizer's measured variable aggregated since measuring began. The value can be positive or negative, depending on the setting selected in the function "TOTALIZER MODE" (3002), and the direction of flow.</p> <p>Display: max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The effect of the setting in the " function (→ 47) is as follows: <ul style="list-style-type: none"> - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. - If the setting is "FORWARD", the totalizer registers only flow in the positive direction. - If the setting is "REVERSE", the totalizer registers only flow in the negative direction. ■ The totalizer's response to faults is defined in the "FAILSAFE MODE" function (3801) (→ 49).
OVERFLOW 3041 Modbus register: Totalizer 1 2612 Totalizer 2 2812 Totalizer 3 3012 Data type: Float Access: read		<p>Displays the total for the totalizer's overflow aggregated since measuring began.</p> <p>Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (> 9999999) as overflows. The effective quantity is thus the total of plus the value returned by the function.</p> <p>Example: Reading for 2 overflows: 2 E7 kg (= 20000000 kg). The value displayed in the function SUM = 196845.7 kg Effective total quantity = 20196845.7 kg</p> <p>Display: integer with exponent, including sign and unit, e.g. 2 E7 kg</p>

6.2 Group HANDLING TOTALIZER



Function description			
TOTALIZER → HANDLING TOTALIZER → Handling totalizer functions			
RESET ALL TOTALIZERS Modbus register: Data type: Access:	3800 2609 Integer read/ write	<p>Resets the totals and the overflows of all totalizers to zero.</p> <p>Options: 0 = NO 1 = YES</p> <p>Factory setting: NO</p> <p> Note! ■ If the device has a status input and if it is appropriately configured, a reset for the totalizer (1 to 3) can also be triggered by a pulse (→ the ASSIGN STATUS INPUT function (5000) on → 93).</p>	
FAILSAFE MODE Modbus register: Data type: Access:	3801 2607 Integer read/ write	<p>Use this function to define the common response of all totalizers (1 to 3) to error.</p> <p>Options: 0 = STOP The totalizers are paused until the fault is rectified.</p> <p>1 = ACTUAL VALUE The totalizer continues to count based on the current flow measuring value. The fault is ignored.</p> <p>2 = HOLD VALUE The totalizers continue to count the flow based on the last valid flow value (before the error occurred).</p> <p>Factory setting: STOP</p>	

7 Block OUTPUTS

Block	Groups	Function groups	Functions					
			Configuration	Operation	Information	Configuration	Operation	Information
OUTPUTS (E)	CURRENT OUTPUT (EA) → 51	ASSIGN CURRENT OUTPUT (400) → 51	CURRENT SPAN ⇒ (4001) → 52	VALUE 0...4 mA ⇒ (4002) → 53	VALUE 20 mA ⇒ (4003) → 55	MEASURING MODE (4004) ⇒ 55	TIME CONSTANT (4005) ⇒ 58	FAILSAFE MODE (4006) ⇒ 59
	↑ ↓	OPERATION ⇒ ACTUAL CURRENT (4040) → 60	SIMULATION CURRENT (4041) → 60	VALUE SIM. CURRENT (4042) → 60				
	INFORMATION ⇒ TERMINAL NUMBER (4080) → 61							
	↑ ↓	CONFIGURATION ⇒ PULSE/FREQ. OUTPUT (ECA) → 62	OPERATION MODE (4200) → 62	ASSIGN FREQUENCY (4201) → 63	END VALUE FREQUENCY (4202) → 63	MEASURING MODE (4204) → 64	MEASURING MODE (4206) → 66	FAILSAFE MODE (4209) → 69
	↑ ↓			FAILSAFE VALUE (4211) → 70				
			ASSIGN PULSE (4221) → 71	PULSE VALUE (4222) → 71	PULSE WIDTH (4223) → 72	MEASURING MODE (4225) ⇒ 72	OUTPUT SIG. NAL(4.2.26) → 73	FAILSAFE MODE (4227) → 75
			ASSIGN STATUS (4241) → 76	ON-VALUE (4242) → 76	SWITCH-ON DELAY (4243) → 77	OFF-VALUE (4244) → 77	SWITCH-OFF DELAY (4245) → 77	TIME CONSTANT (4247) → 78
	↑ ↓	OPERATION ⇒ (430) → 79	ACTUAL FREQUENCY (4301) → 79	SIMULATION FREQUENCY (4302) → 79	VALUE SIMUL. FREQ. (4303) → 79			
	↑ ↓		SIMULATION PULSE (4322) → 80	VALUE SIM. IMPULS (4323) → 80				
			ACTUAL STATUS (4341) → 81	SIMULATION SWITCH POINT (4342) → 81	VALUE SIM. SWITCH PTN. (4343) → 81			
	↑ ↓	INFORMATION ⇒ TERMINAL NUMBER (4380) → 82						
	RELAY 1 to 2 (EGA, EGB) → 83	CONFIGURATION ⇒ (470) → 83	ASSIGN RELAY ⇒ (4700) → 83	ON-VALUE ⇒ (4701) → 84	SWITCH-ON DELAY (4702) → 84	OFF-VALUE (4703) → 84	SWITCH-OFF DELAY (4704) → 85	TIME CONSTANT (4706) → 86
	↑ ↓	OPERATION ⇒ (474) → 87	ACTUAL STATUS RELAY (4740) → 87	SIMULATION SWITCH POINT (4741) → 87	VALUE SIM. SWITCH PNT. (4742) → 87			
	↑ ↓	INFORMATION ⇒ TERMINAL NUMBER (4780) → 88						

7.1 Group CURRENT OUTPUT

7.1.1 Function group CONFIGURATION

OUTPUTS E → CURRENT OUTPUT EAA → CONFIGURATION 400

		Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION
ASSIGN CURRENT OUTPUT	4000	<p>For assigning a measured variable to the current output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE</p> <p>Factory setting: MASS FLOW</p> <p> Note! <ul style="list-style-type: none"> ▪ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN CURRENT OUTPUT (4000). </p>


Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION																															
CURRENT SPAN Modbus register: Data type: Access:	4001 5802 Integer read/ write	<p>For selecting the current span. The selection specifies the operational range and the lower and upper signal on alarm.</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = 0 to 20 mA (25 mA) 1 = 4 to 20 mA (25 mA) 3 = 0 to 20 mA 4 = 4 to 20 mA 6 = 4 to 20 mA NAMUR 8 = 4 to 20 mA US <p>Factory setting: 4 to 20 mA NAMUR or 4 to 20 mA US</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ When switching the hardware from an active (factory setting) to a passive output signal, select a current span of 4 to 20 mA → Operating Instructions (BA00141D/06).  <table border="1"> <thead> <tr> <th>a</th> <th>1</th> <th>2</th> <th>3</th> </tr> </thead> <tbody> <tr> <td>0-20 mA (25 mA)</td> <td>0 - 24 mA</td> <td>0</td> <td>25</td> </tr> <tr> <td>4-20 mA (25 mA)</td> <td>4 - 24 mA</td> <td>2</td> <td>25</td> </tr> <tr> <td>0-20 mA</td> <td>0 - 20.5 mA</td> <td>0</td> <td>22</td> </tr> <tr> <td>4-20 mA</td> <td>4 - 20.5 mA</td> <td>2</td> <td>22</td> </tr> <tr> <td>4-20 mA NAMUR</td> <td>3.8 - 20.5 mA</td> <td>3.5</td> <td>22.6</td> </tr> <tr> <td>4-20 mA US</td> <td>3.9 - 20.8 mA</td> <td>3.75</td> <td>22.6</td> </tr> </tbody> </table>	a	1	2	3	0-20 mA (25 mA)	0 - 24 mA	0	25	4-20 mA (25 mA)	4 - 24 mA	2	25	0-20 mA	0 - 20.5 mA	0	22	4-20 mA	4 - 20.5 mA	2	22	4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6	4-20 mA US	3.9 - 20.8 mA	3.75	22.6	A0002959
a	1	2	3																												
0-20 mA (25 mA)	0 - 24 mA	0	25																												
4-20 mA (25 mA)	4 - 24 mA	2	25																												
0-20 mA	0 - 20.5 mA	0	22																												
4-20 mA	4 - 20.5 mA	2	22																												
4-20 mA NAMUR	3.8 - 20.5 mA	3.5	22.6																												
4-20 mA US	3.9 - 20.8 mA	3.75	22.6																												






Fig. 16: Overview of current span, operational range and signal on alarm level

- a* Current span
 1 Operational range (measuring information)
 2 Lower signal on alarm level
 3 Upper signal on alarm level





- Note!**
- If the measured value exceeds the measuring range (as defined in the functions VALUE 0_4 mA (4002) and VALUE 20 mA (4003)) a notice message is generated (#351 to 354, current span).
 - In case of a fault the behavior of the current output is according to the selected option in the function FAILSAFE MODE (4006).







Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION		
VALUE 0_4 mA Modbus register: Data type: Access:	4002 5803 Float read/ write	<p>Use this function to assign the 0/4 mA current a value. The value can be higher or lower than the value assigned to 20 (function VALUE 20 mA (4003) → 55). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow).</p> <p>Example: 4 mA assigned value = -250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)</p> <p> Note! ■ Note that values with different signs cannot be entered for 0/4 mA and 20 mA if SYMMETRY is the setting selected for the MEASURING MODE function (4004). In this case, the message "INPUT RANGE EXCEEDED" appears on the display.</p> <p>Example for STANDARD measuring mode:</p> <p>A0001223</p> <p> ① = Lower range-value (0 to 20 mA) ② = Lower signal on alarm level: depends on the setting in the function CURRENT SPAN ③ = Lower range-value (4 to 20 mA): depends on the setting in the function CURRENT SPAN ④ = Full scale value (0/4 to 20 mA): depends on the setting in the function CURRENT SPAN ⑤ = Maximum current value: depends on the setting in the function CURRENT SPAN ⑥ = Failsafe mode (upper signal on alarm level): depends on the setting in the functions CURRENT SPAN (→ 52) and FAILSAFE MODE (→ 59) A = Measuring range </p> <p>User input: 5-digit floating-point number, with sign</p> <p>Factory setting: 0 [kg/h] or 0.5 [kg/l] or -50 [°C]</p> <p> Note! ■ The appropriate unit is taken from the following functions: - UNIT MASS FLOW (0400) - UNIT VOLUME FLOW (0402) - UNIT CORRECTED VOLUME FLOW (0404) - UNIT DENSITY (0420) - UNIT REFERENCE DENSITY (0421) - UNIT TEMPERATURE (0422) (→ 14 to → 18).</p> <p> Caution! The current output responds differently, depending on the parameters set in the various functions. Some examples of parameter settings and their effect on the current output are given in the following section.</p> <p>(continued on next page)</p>




Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION	
VALUE 0_4 mA (continued)	4002
	<p>Parameter setting example A:</p> <ol style="list-style-type: none"> 1. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. -5 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4002) = not equal to zero flow (e.g. -40 kg/h) and MEASURING MODE (4004) = STANDARD <p>When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (→ Fig. ①), a fault/notice message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006)..</p>  
	A0001262
	<p>Parameter setting example B:</p> <ol style="list-style-type: none"> 1. VALUE 0_4 mA (4002) = equal to zero flow (e.g. 0 kg/h) VALUE 20 mA (4003) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE 0_4 mA (4002) = not equal to zero flow (e.g. 100 kg/h) VALUE 20 mA (4003) = equal to zero flow (e.g. 0 kg/h) and MEASURING MODE (4004) = STANDARD <p>When you enter the values for 0/4 mA and 20 mA, the working range of the measuring device is defined. In doing so, one of the two values is parameterized as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value parameterized as the zero flow, no fault/notice message is generated and the current output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE(4006).</p>  
	A0001264
	<p>Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed.</p> <p>Parameter setting example C: MEASURING MODE (4004) = SYMMETRY The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA value ① and the 20 mA value ② must have the same sign (+ or -). The 20 mA VALUE ③ (e.g. backflow) corresponds to the mirrored 20 mA VALUE ② (e.g. flow).</p> 
	A0001249
	<p>ASSIGN STATUS (4241) = FLOW DIRECTION With this setting e.g. the flow direction output via a switching contact can be made.</p> <p>Parameter setting example D: MEASURING MODE (4004) = PULSATING FLOW → 55</p>

Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION		
VALUE 20 mA	4003	<p>Use this function to assign the 20 mA current a value. The value can be higher or lower than the value assigned to 0/4 (function VALUE 0_4 mA (4002) → 53). Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow).</p> <p>Example: 4 mA assigned value = -250 kg/h 20 mA assigned value = +750 kg/h Calculated current value = 8 mA (at zero flow)</p> <p>Note that values with different signs cannot be entered for 0/4 mA and 20 mA if SYMMETRY is the setting selected for the MEASURING MODE function (4004). In this case, the message "INPUT RANGE EXCEEDED" appears on the display.</p> <p>User input: 5-digit floating-point number, with sign</p> <p>Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note! ■ The appropriate unit is taken from the following functions: – UNIT MASS FLOW (0400) – UNIT VOLUME FLOW (0402) – UNIT CORRECTED VOLUME FLOW (0404) – UNIT DENSITY (0420) – UNIT REFERENCE DENSITY (0421) – UNIT TEMPERATURE (0422) (→ 14 to → 18).</p> <p>■ The appropriate unit is taken from the function UNIT MASS FLOW (0400) → 14.</p> <p>■ An example for selecting the STANDARD option in the function MEASURING MODE (4004) can be found on → 56.</p> <p> Caution! It is very important to read and comply with the information in the function VALUE 0_4 mA (under "Caution", examples of parameter settings) on → 53.</p>
MEASURING MODE	4004	<p>For selecting the measuring mode for the current output.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY 2 = PULSATING FLOW</p> <p>Factory setting: STANDARD</p>

(continued on next page)


Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION	
MEASURING MODE 4004 (continued)	<p>Description of the individual options:</p> <p>STANDARD</p> <p>The current output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the 0_4 mA VALUE ① and the 20 mA VALUE ②) are taken into account as follows for signal output.</p> <ul style="list-style-type: none"> ▪ If one of the values is defined as equal to the zero flow (e.g. VALUE 0_4 mA = 0 m³/h), no message is given if this value is exceeded or not achieved and the current output retains its value (in example 4 mA). If the other value is exceeded or not achieved, the message "CURRENT OUTPUT AT FULL SCALE VALUE" appears and the current output responds in accordance with the parameter setting in the function FAILSAFE MODE (4006): ▪ If both values defined are not equal to the zero flow (for example VALUE 0_4 mA = -5 m³/h, VALUE 20 mA = 10m³/h), the message "CURRENT OUTPUT AT FULL SCALE VALUE" appears if the measuring range is exceeded or not achieved and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006).  <p>A0001248</p> <p><i>Fig. 17: Example for STANDARD measuring mode</i></p> <p>SYMMETRY</p> <p>The current output signal is independent of the direction of flow (absolute amount of the measured variable). The 0_4 mA value ① and the 20 mA value ② must have the same sign (+ or -). The "20 mA value" ③ (e.g. backflow) corresponds to the mirrored 20 mA value ② (e.g. flow).</p>  <p>A0001249</p> <p><i>Fig. 18: Example for SYMMETRY measuring mode</i></p> <p> Note!</p> <ul style="list-style-type: none"> ▪ The direction of flow can be output via the configurable relay or status outputs. ▪ SYMMETRY cannot be selected unless the values in the VALUE 0_4 mA (4002) and VALUE 20 mA (4003) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed. <p>PULSATING FLOW</p> <p>If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears.</p> <p>Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the current output.</p>

Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION	
Detailed explanations and information	<p>How the current output responds under the following postulated conditions:</p> <p>1. Defined measuring range (①–②): ① and ② have the same sign</p>  <p>A0001248</p> <p>and the following flow behavior:</p>  <p>A0001265</p> <ul style="list-style-type: none"> ▪ STANDARD The current output signal is proportional to the measured variable. The flow components outside the scaled measuring range are not taken into account for signal output.  <p>A0001267</p> <ul style="list-style-type: none"> ▪ SYMMETRY The current output signal is independent of the direction of flow.  <p>A0001268</p> <ul style="list-style-type: none"> ▪ PULSATING FLOW Flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds.  <p>A0001269</p> <p>2. Defined measuring range (①–②): ① and ② do not have the same sign.</p>  <p>A0001272</p> <p>(continued on next page)</p>

Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION		
<p>Detailed explanations and information (continued)</p>	<p>Flow a (—) outside, b (- -) within the measuring range.</p>  <p style="text-align: right;">A0001273</p> <ul style="list-style-type: none"> ■ STANDARD a (—): The flow components outside the scaled measuring range cannot be taken into account for signal output. A fault message is generated (#351 to 354, current range) and the current output responds in accordance with the parameter settings in the function FAILSAFE MODE (4006). b (- -): The current output signal is proportional to the measured variable assigned. 	
	 <p style="text-align: right;">A0001274</p> <ul style="list-style-type: none"> ■ SYMMETRY This option is not available under these circumstances because the 0_4 mA value and the 20 mA value have different signs. ■ PULSATING FLOW Flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds.  <p style="text-align: right;">A0001275</p>	
TIME CONSTANT Modbus register: Data type: Access:	4005 5808 Float read/ write	<p>Entering a time constant defines how the current output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: fixed-point number 0.01 to 100.00 s</p> <p>Factory setting: 1.00 s</p>


Function description OUTPUTS → CURRENT OUTPUT → CONFIGURATION		
FAILSAFE MODE Modbus register: Data type: Access:	4006 5810 Integer read/ write	<p>For safety reasons it is advisable to ensure that the current output assumes a predefined state in the event of a fault. The setting you select here affects only the current output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options:</p> <p>0 = MIN. CURRENT The current output adopts the value of the lower signal on alarm level (as defined in the function CURRENT SPAN (4001) → 52).</p> <p>1 = MAX. CURRENT The current output adopts the value of the upper signal on alarm level (as defined in the function CURRENT SPAN (4001) → 52).</p> <p>2 = HOLD VALUE (not recommended) Measured value output is based on the last measured value saved before the error occurred.</p> <p>3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>Factory setting: MIN. CURRENT</p>

7.1.2 Function group OPERATION



Function description OUTPUTS → CURRENT OUTPUT → OPERATION		
ACTUAL CURRENT 4040 Modbus register: 5811 Data type: Float Access: read	Use this function to view the computed actual value of the output current. Display: 0.00 to 25.00 mA	
SIMULATION CURRENT 4041 Modbus register: 5813 Data type: Integer Access: read/write	Activates simulation of the current output. Options: 0 = OFF 1 = ON Factory setting: OFF Note! <ul style="list-style-type: none"> ▪ If simulation is active, the "SIMULATION CURRENT OUTPUT" message is displayed. ▪ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. Caution! The setting is not saved in the event of a power failure.	
VALUE SIMULATION CURRENT 4042 Modbus register: 5814 Data type: Float Access: read/write	Use this function to define a freely selectable value (e.g. 12 mA) to be output at the current output. This value is used to test downstream devices and the measuring device itself. User input: 0.00 to 25.00 mA Factory setting: 0.00 mA Note! <ul style="list-style-type: none"> ▪ This function is displayed only if the function SIMULATION CURR. (4041) is active (= ON). Caution! The setting is not saved in the event of a power failure.	


7.1.3 Function group INFORMATION



		Function description OUTPUTS → CURRENT OUTPUT → INFORMATION
TERMINAL NUMBER	4080	
Modbus register: Data type: Access:	5816 Integer read	<p>Displays the:</p> <ul style="list-style-type: none"> ▪ Numbers of the terminals used by the current output (in the connection compartment) ▪ Polarity <p>Display: $3 = 20 (+) / 21 (-)$ </p>


7.2 Group PULSE/FREQUENCY OUTPUT

7.2.1 Function group CONFIGURATION








Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION		
OPERATION MODE 4200 Modbus register: 3201 Data type: Integer Access: read/ write	Configuration of the output as a pulse, frequency or status output. The functions available in this function group vary, depending on which option you select here. Options: 0 = PULSE 1 = FREQUENCY 2 = STATUS Factory setting: PULSE	


Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)		
ASSIGN FREQUENCY Modbus register: Data type: Access:	4201 3202 Integer read/ write	<p>For assigning a measured variable to the frequency output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW 7 = DENSITY 8 = REFERENCE DENSITY 9 = TEMPERATURE</p> <p>Factory setting: MASS FLOW</p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ▪ If you select OFF, the only function shown in the CONFIGURATION function group is ASSIGN FREQUENCY (4201). </p>
START VALUE FREQUENCY Modbus register: Data type: Access:	4202 3203 Float read/ write	<p>For defining an initial frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE f LOW(4204).</p> <p>User input: 5-digit fixed-point number: 0 to 10000 Hz</p> <p>Factory setting: 0 Hz</p> <p>Example: <ul style="list-style-type: none"> ▪ VALUE f LOW = 0 kg/h, start value frequency = 0 Hz This means that at a flow rate of 0 kg/h, a frequency of 0 Hz is output. ▪ VALUE f LOW = 1 kg/h, start value frequency = 10 Hz This means that at a flow rate of 1 kg/h, a frequency of 10 Hz is output. </p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). </p>
END VALUE FREQUENCY Modbus register: Data type: Access:	4203 3205 Float read/ write	<p>For defining a full scale frequency for the frequency output. You define the associated measured value of the measuring range in the function VALUE-f HIGH (4205).</p> <p>User input: 5-digit fixed-point number: 2 to 10000 Hz</p> <p>Factory setting: 10000 Hz</p> <p>Example: <ul style="list-style-type: none"> ▪ VALUE f HIGH = 10000 kg/h, full scale value = 10000 Hz This means that at a flow rate of 10000 kg/h, a frequency of 10000 Hz is output. ▪ VALUE f HIGH = 3600 kg/h, full scale value = 10000 Hz This means that at a flow rate of 3600 kg/h, a frequency of 10000 Hz is output. </p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ▪ In the FREQUENCY operating mode the output signal is symmetrical (on/off ratio = 1:1). At low frequencies the pulse duration is limited to a maximum of 2 seconds, i.e. the on/off ratio is no longer symmetrical. </p>

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)		
VALUE f LOW Modbus register: Data type: Access:	4204 3207 Float read/ write	<p>Use this function to assign a variable to the START VALUE FREQUENCY (4202). The value can be higher or lower than the value assigned to the VALUE f HIGH. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE f LOW and VALUE f HIGH values.</p> <p>Input: 5-digit floating-point number</p> <p>Factory setting: 0 [kg/h] or 0 [kg/l] or -50 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ▪ For a graphic illustration of the VALUE F LOW → the VALUE-f HIGH (4205) function. ▪ Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display. ▪ The appropriate unit is taken from the following functions: <ul style="list-style-type: none"> - (UNIT MASS FLOW (0400) - UNIT VOLUME FLOW (0402) - UNIT CORRECTED VOLUME FLOW (0404) - UNIT DENSITY (0420) - UNIT REFERENCE DENSITY (0421) - UNIT TEMPERATURE (0422) (→ to →).
VALUE-f HIGH Modbus register: Data type: Access:	4205 3209 Float read/ write	<p>Use this function to assign a variable to the END VALUE FREQUENCY (4203). The value can be higher or lower than the value assigned to the VALUE F LOW. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow). You define a measuring range by defining the VALUE f LOW and VALUE f HIGH values.</p> <p>Input: 5-digit floating-point number</p> <p>Factory setting: Depends on nominal diameter [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).. ▪ Note that values with different signs cannot be entered for VALUE F LOW and VALUE F HIGH, if SYMMETRY is the setting selected for the MEASURING MODE function (4206). In this case, the message "INPUT RANGE EXCEEDED" appears on the display.  <p>① = Value f low ② = Value f high</p> <p>(continued on next page)</p>




A0001279

		Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)
VALUE-f HIGH (continued)	4205	<p>Parameter setting example 1:</p> <ol style="list-style-type: none"> 1. VALUE f LOW (4204) = not equal to zero flow (e.g. -5 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE f LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. -40 kg/h) <p>and MEASURING MODE (4206) = STANDARD</p> <p>When you enter the values for VALUE f LOW and VALUE f HIGH the working range of the measuring device is defined. If the effective flow drops below or exceeds this working range (→ Fig. ①), a fault/notice message is generated (#355 to 358, frequency range) and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209)..</p>  <p>A0001276</p> <p>Parameter setting example 2:</p> <ol style="list-style-type: none"> 1. VALUE f LOW (4204) = not equal to zero flow (e.g. 0 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 10 kg/h) or 2. VALUE f LOW (4204) = not equal to zero flow (e.g. 100 kg/h) VALUE-f HIGH (4205) = not equal to zero flow (e.g. 0 kg/h) <p>and MEASURING MODE (4206) = STANDARD</p> <p>When you enter the values for VALUE f LOW and VALUE f HIGH the working range of the measuring device is defined. In doing so, one of the two values is parameterized as zero flow (e.g. 0 kg/h). If the effective flow drops below or exceeds the value parameterized as the zero flow, no fault/notice message is generated and the frequency output retains its value. If the effective flow drops below or exceeds the other value, a fault/notice message is generated (#355 to 358, frequency range) and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209).</p>  <p>A0001277</p> <p>Deliberately only one flow direction is output with this setting and flow values in the other flow direction are suppressed.</p> <p>Parameter setting example 3: MEASURING MODE (4206) = SYMMETRY</p> <p>The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE f LOW ① and VALUE f HIGH ② must have the same sign (+ or -). The VALUE f HIGH ③ (e.g. backflow) corresponds to the mirrored VALUE f HIGH ② (e.g. flow).</p>  <p>A0001278</p> <p>ASSIGN STATUS (4241) = FLOW DIRECTION With this setting e.g. the flow direction output via a switching contact can be made.</p> <p>Parameter setting example 4: MEASURING MODE (4206) = PULSATING FLOW → 66</p>


Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)	
<p>MEASURING MODE 4206</p> <p>Modbus register: 3211 Data type: Integer Access: read/write</p>	<p> Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).</p> <p>Use this function to define the measuring mode for the frequency output.</p> <p>Options: 0 = STANDARD 1 = SYMMETRY 2 = PULSATING FLOW</p> <p>Factory setting: STANDARD</p> <p>Description of the individual options:</p> <p>STANDARD The frequency output signal is proportional to the measured variable. The flow components outside the scaled measuring range (defined by the VALUE f LOW ① and the VALUE f HIGH ②) are not taken into account for signal output.</p> <ul style="list-style-type: none"> ▪ If one of the values is defined as equal to the zero flow (e.g. VALUE f LOW = 0 m³/h), no message is given if this value is exceeded or not achieved and the frequency output retains its value (0 Hz in the example). If the other value is exceeded or not achieved, the message "FREQUENCY OUTPUT AT FULL SCALE VALUE" appears and the frequency output responds in accordance with the parameter setting in the function FAILSAFE MODE (4209). ▪ If both values defined are not equal to the zero flow (for example VALUE f LOW = -5 m³/h; VALUE f HIGH = 10m³/h), the message "FREQUENCY OUTPUT AT FULL SCALE VALUE" appears if the measuring range is exceeded or not achieved and the frequency output responds in accordance with the parameter settings in the function FAILSAFE MODE (4209)..  <p>A0001279</p> <p><i>Fig. 19: STANDARD measuring mode</i></p> <p>SYMMETRY The frequency output signal is independent of the direction of flow (absolute amount of the measured variable). The VALUE f LOW ① and VALUE f HIGH ② must have the same sign (+ or -). The VALUE f HIGH ③ (e.g. backflow) corresponds to the mirrored VALUE f HIGH ② (e.g. flow).</p>  <p>A0001280</p> <p><i>Fig. 20: SYMMETRY measuring mode</i></p> <p>(continued on next page)</p>

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)	
MEASURING MODE 4206 (continued)	<p> Note!</p> <ul style="list-style-type: none"> The direction of flow can be output via the configurable relay or status outputs. SYMMETRY cannot be selected unless the values in the VALUE f LOW (4204) and VALUE-f HIGH (4205) functions have the same sign or one of the values is zero. If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed. <p>PULSATING FLOW</p> <ul style="list-style-type: none"> If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, flow components outside the measuring range are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears. Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the frequency output.
OUTPUT SIGNAL 4207 Modbus register: 3212 Data type: Integer Access: read/ write	<p>For selecting the output configuration of the frequency output.</p> <p>Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE (this selection is not supported) 3 = ACTIVE - NEGATIVE (this selection is not supported)</p> <p>Factory setting: PASSIVE - POSITIVE</p> <p>Explanation PASSIVE = power is supplied to the frequency output by means of an external power supply.</p> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the frequency output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> If POSITIVE is selected, the internal transistor is activated with a positive signal level. If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). <p> Note!</p> <ul style="list-style-type: none"> This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). With the passive output configuration, the output signal levels of the frequency output depend on the external circuit (→ examples). <p>Example for passive output circuit (PASSIVE) If PASSIVE is selected, the frequency output is configured as an open collector.</p>  <p>(continued on next page)</p>


Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)	
OUTPUT SIGNAL 4207 (continued)	<p>① = Open collector ② = External power supply ③ = Line monitoring off ④ = Line monitoring on (default)</p> <p> Note! For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).</p> <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p> <p style="text-align: right;">+ $U_{max} = 30 \text{ V DC}$</p> <p style="text-align: right;">A0004687</p> <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level</p> <p style="text-align: right;">A0001975</p> <p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p> <p style="text-align: right;">+ $U_{max} = 30 \text{ V DC}$</p> <p style="text-align: right;">A0004689</p> <p>① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p>
(continued on next page)	





		Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)
OUTPUT SIGNAL 4207 (continued)	<p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p>A0001981</p> <p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p>  <p>A0004690</p> <p> ① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in NEGATIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow) </p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p>A0001981</p>	
TIME CONSTANT 4208 Modbus register: 3213 Data type: Float Access: read/write	<p>Entering a time constant defines how the frequency output signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p>User input: fixed-point number 0.00 to 100.00 s</p> <p>Factory setting: 0.00 s</p> <p> Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).</p>	



Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (FREQUENCY)		
FAILSAFE MODE	4209	<p>For safety reasons it is advisable to ensure that the frequency output assumes a predefined state in the event of a fault. The setting you select here affects only the frequency output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options:</p> <p>0 = FAILBACK VALUE Output is 0 Hz.</p> <p>1 = FAILSAFE LEVEL Output is the frequency specified in the FAILSAFE LEVEL function (4211).</p> <p>2 = HOLD VALUE Measured value output is based on the last measured value saved before the error occurred.</p> <p>3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored.</p> <p>Factory setting: FAILBACK VALUE</p> <p> Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).</p>
FAILSAFE LEVEL	4211	<p> Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and FAILSAFE LEVEL was selected in the FAILSAFE MODE function (4209).</p> <p>For specifying the frequency that the measuring device outputs in the event of an error.</p> <p>User input: max. 5-digit number: 0 to 12500 Hz</p> <p>Factory setting: 12500 Hz</p> <p> Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and FAILSAFE LEVEL was selected in the FAILSAFE MODE function (4209).</p>

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (PULSE)		
ASSIGN PULSE Modbus register: Data type: Access:	4221 3223 Integer read/ write	<p>Use this function to assign a measured variable to the pulse output.</p> <p>Options: 0 = OFF 2 = MASS FLOW 5 = VOLUME FLOW 6 = CORRECTED VOLUME FLOW</p> <p>Factory setting: MASS FLOW</p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ▪ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN PULSE (4221). </p>
PULSE VALUE Modbus register: Data type: Access:	4222 3224 Float read/ write	<p>Use this function to define the flow at which a pulse is triggered. These pulses can be totaled by an external totalizer, and the total flow quantity since measuring started can be registered in this way.</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: Depends on nominal diameter</p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ▪ The appropriate unit is taken from the UNIT MASS FLOW (0400), UNIT VOLUME FLOW (0402) or UNIT CORRECTED VOLUME FLOW (0404) function (→ Fig. 14 to → Fig. 18). </p>
PULSE WIDTH Modbus register: Data type: Access:	4223 3226 Float read/ write	<p> Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).</p> <p>Use this function to enter the pulse width of the output pulse.</p> <p>User input: 0.05 to 2000 ms</p> <p>Factory setting: 100 ms</p> <p>Pulse output is always with the pulse width (B) entered in this function. The pauses (P) between the individual pulses are automatically configured. However, they must at least correspond to the pulse width ($B = P$).</p>  <p style="text-align: right;">A0001233-EN</p> <p><i>Fig. 21: Pulse width</i></p> <p><i>B = Pulse width entered (the illustration applies to positive pulses)</i> <i>P = Pauses between the individual pulses</i></p> <p>(continued on next page)</p>

		Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (PULSE)
PULSE WIDTH	4223 (continued)	<p> Note!</p> <ul style="list-style-type: none"> ▪ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ▪ When entering the pulse width, select a value that can still be processed by an external totalizer (e.g. mechanical totalizer, PLC etc.). <p> Caution!</p> <p>If the pulse number or frequency resulting from the pulse value entered (→ function PULSE VALUE (4222) on → 71) and from the current flow is too large to maintain the pulse width selected (the time interval is smaller than the pulse width B entered), a system error message is generated (#359 to 362, pulse buffer) after approx. 5 seconds buffer/balance time.</p>
MEASURING MODE	4225 Modbus register: 3228 Data type: Integer Access: read/ write	<p>Use this function to define the measuring mode for the pulse output.</p> <p>Options:</p> <p>0 = STANDARD Only positive flow components are totaled. Negative components are not taken into account.</p> <p>1 = SYMMETRY Positive and negative flow components are taken into account.</p> <p> Note! The direction of flow can be output via the relay output.</p> <p>2 = PULSATING FLOW If flow is characterized by severe fluctuations as is the case, for example, with reciprocating pumps, the positive and negative flow components are totaled, with the signs taken into account (e.g. -10 l and +25 l = 15 l).</p> <p>Flow components outside the maximum pulse number per second (value/width) are buffered, balanced and output after a maximum delay of 60 seconds. If the buffered data cannot be processed within approx. 60 seconds, a fault/notice message appears.</p> <p>Under certain plant conditions, flow values can aggregate in the buffer, for example in the case of prolonged and unwanted fluid backflow. However, this buffer is reset in all relevant programming adjustments which affect the pulse output.</p> <p>3 = STANDARD REVERSE Only negative flow components are totaled. Positive components are not taken into account.</p> <p>Factory setting: STANDARD</p> <p> Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).</p>

Function description	
OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (PULSE)	
OUTPUT SIGNAL 4226 Modbus register: 3229 Data type: Integer Access: read/ write	<p>For selecting the output configuration of the pulse output.</p> <p>Options: 0 = PASSIVE - POSITIVE 1 = PASSIVE - NEGATIVE 2 = ACTIVE - POSITIVE (this selection is not supported) 3 = ACTIVE - NEGATIVE (this selection is not supported)</p> <p>Factory setting: PASSIVE - POSITIVE</p> <p>Explanation PASSIVE = power is supplied to the pulse output by means of an external power supply.</p> <p>Configuring the output signal level (POSITIVE or NEGATIVE) determines the quiescent behavior (at zero flow) of the pulse output. The internal transistor is activated as follows:</p> <ul style="list-style-type: none"> ▪ If POSITIVE is selected, the internal transistor is activated with a positive signal level. ▪ If NEGATIVE is selected, the internal transistor is activated with a negative signal level (0 V). <p> Note!</p> <ul style="list-style-type: none"> ▪ This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200). ▪ With the passive output configuration, the output signal levels of the pulse output depend on the external circuit (→ examples). <p>Example for passive output circuit (PASSIVE) If PASSIVE is selected, the pulse output is configured as an open collector.</p>  <p>A0002147</p> <p> ① = Open collector ② = External power supply ③ = Line monitoring off ④ = Line monitoring on (default) </p> <p> Note! For continuous currents up to 25 mA ($I_{max} = 250 \text{ mA} / 20 \text{ ms}$).</p> <p>(continued on next page)</p>

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (PULSE)	
OUTPUT SIGNAL 4226 (continued)	<p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is 0 V.</p>  <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from 0 V to a positive voltage level.</p>  <p>A0004687</p>
	<p>Example for output configuration PASSIVE-POSITIVE: Output configuration with an external pull-down resistance. In the quiescent state (at zero flow), a positive voltage level is measured via the pull-down resistance.</p>  <p>① = Open collector ② = Pull-Down-Resistance ③ = Transistor activation in POSITIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p>A0004689</p>
	<p>(continued on next page)</p>


		Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → CONFIGURATION (PULSE)
OUTPUT SIGNAL (continued)	4226	<p>Example for output configuration PASSIVE-NEGATIVE: Output configuration with an external pull-up resistance. In the quiescent state (at zero flow), the output signal level at the terminals is at a positive voltage level.</p>  <p>① = Open collector ② = Pull-Up-Resistance ③ = Transistor activation in NEGATIVE quiescent state (at zero flow) ④ = Output signal level in quiescent state (at zero flow)</p> <p>In the operating status (flow present), the output signal level changes from a positive voltage level to 0 V.</p>  <p>A0001981</p>
FAILSAFE MODE	4227	<p>Modbus register: 3230 Data type: Integer Access: read/write</p> <p>For safety reasons it is advisable to ensure that the pulse output assumes a predefined state in the event of a fault. The setting you select here affects only the pulse output. It has no effect on other outputs and the display (e.g. totalizers).</p> <p>Options:</p> <ul style="list-style-type: none"> 0 = FALBACK VALUE Output is 0 pulse. 3 = ACTUAL VALUE Measured value output is based on the current flow measurement. The fault is ignored. 4 = MAX. PULSE RATE Outputs the maximum pulse rate $f = 1/(2xT)$ <p>Factory setting: FALBACK VALUE</p> <p> Note! This function is not available unless the PULSE setting was selected in the OPERATION MODE function (4200).</p>

Function description → PULSE/FREQUENCY OUTPUT → (STATUS)		
ASSIGN STATUS Modbus register: Data type: Access:	4241 3236 Integer read/ write	<p>Use this function to assign a switching function to the status output.</p> <p>Options:</p> <p>0 = OFF 1 = ON (operation) 2 = FAULT MESSAGE 3 = NOTICE MESSAGE 4 = FAULT MESSAGE or NOTICE MESSAGE 5 = EMPTY PIPE DETECTION (only with active function) 6 = FLOW DIRECTION 7 = MASS FLOW LIMIT VALUE 8 = VOLUME FLOW LIMIT VALUE 14 = CORRECTED VOLUME FLOW LIMIT VALUE 15 = DENSITY LIMIT VALUE 16 = REFERENCE DENSITY LIMIT VALUE 17 = TEMPERATURE LIMIT VALUE 19 = TOTALIZER 1 LIMIT VALUE 20 = TOTALIZER 2 LIMIT VALUE 21 = TOTALIZER 3 LIMIT VALUE</p> <p>Factory setting: FAULT MESSAGE</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ This function is available only if the STATUS setting was selected in the OPERATION MODE (4200) function. ▪ The behavior of the status output is a normally closed behavior, in other words the output is closed (transistor conductive) when normal, error-free measuring is in progress. <ul style="list-style-type: none"> – "Normal, error-free" operation: Flow direction = forwards; limit values = not exceeded; no fault or notice message present. – Switching response like relay output, → 90 ▪ If you select OFF, the only function shown in the CONFIGURATION function group is this function, in other words ASSIGN STATUS (4241). ▪ Switching response like relay output → 90.
ON-VALUE Modbus register: Data type: Access:	4242 3237 Float read/ write	<p>Use this function to assign a value to the switch-on point (activation of the status output). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241). ▪ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears. ▪ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis.

Function description → PULSE/FREQUENCY OUTPUT → (STATUS)		
SWITCH-ON DELAY 4243 Modbus register: 3239 Data type: Float Access: read/ write	<p>Use this function to define a delay (0 to 100 seconds) for the switch-on (i.e. signal changes from "not conductive" to "conductive") of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch on condition has been valid over the delay time.</p> <p>User input: fixed-point number: 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p> <p> Note! This function is not available unless STATUS was selected in the function OPERATION MODE function (4200) and LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN STATUS function (4241).</p>	
OFF-VALUE 4244 Modbus register: 3241 Data type: Float Access: read/ write	<p>Use this function to assign a value to the switch-off point (deactivation of the status output). The value can be higher or lower than the switch-on point. Positive and negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note! ■ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and LIMIT VALUE was selected in the ASSIGN STATUS function (4241). ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4246) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears.</p>	
SWITCH-OFF DELAY 4245 Modbus register: 3243 Data type: Float Access: read/ write	<p>Use this function to define a delay (0 to 100 seconds) for the switch-off (i.e. signal changes from "conductive" to "not conductive") of the status output. The delay starts when the limit value is reached. The status output does switch when the delay has timed out and the switch off condition has been valid over the delay time.</p> <p>User input: fixed-point number: 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p> <p> Note! This function is not available unless the STATUS setting was selected in the function OPERATION MODE function (4200).</p>	

Function description → PULSE/FREQUENCY OUTPUT → (STATUS)	
MEASURING MODE 4246 Modbus register: 3245 Data type: Integer Access: read/ write	<p>Use this function to define the measuring mode for the status output.</p> <p>Options: 0 = STANDARD The status output signal switches at the defined switch points.</p> <p>1 = SYMMETRY The status output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the status output signal switches as soon as the value is reached in the negative direction (negative sign), (→ illustration).</p> <p>Factory setting: STANDARD</p> <p>A0001247</p>
TIME CONSTANT 4247 Modbus register: 3246 Data type: Float Access: read/ write	<p>Entering a time constant defines how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the status output changing state continuously in response to fluctuations in flow.</p> <p>User input: fixed-point number 0.00 to 100.00 s</p> <p>Factory setting: 0.00 s</p> <p>Note! This function is not available unless the STATUS setting was selected in the function OPERATION MODE function (4200).</p>

7.2.2 Function group OPERATION




Function description			
OUTPUTS → PULSE/FREQUENCY OUTPUT → OPERATION (FREQUENCY)			
ACTUAL FREQUENCY	4301	Use this function to view the computed actual value of the output frequency.	
Modbus register:	3218	Display:	
Data type:	Float	0 to 12500 Hz	
Access:	read	Note! This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200).	
SIMULATION FREQUENCY	4302	Activates simulation of the frequency output.	
Modbus register:	3220	Options:	
Data type:	Integer	0 = OFF	
Access:	read/write	1 = ON	
		Factory setting:	
		OFF	
		Note! ▪ This function is not available unless the FREQUENCY setting was selected in the OPERATION MODE function (4200). ▪ The "SIMULATION FREQUENCY OUTPUT" message indicates that simulation is active. ▪ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.	
		Caution! The setting is not saved in the event of a power failure.	
VALUE SIMULATION FREQUENCY	4303	Define a selectable frequency value (e.g. 500 Hz) which should be output at the frequency output (with maximum pulse frequency or shortened minimum pulse width). This value is used to test downstream devices and the measuring device itself.	
Modbus register:	3221	User input:	
Data type:	Float	0 to 12500 Hz	
Access:	read/write	Factory setting:	
		0 Hz	
		Note! This function is not available unless FREQUENCY was selected in the OPERATION MODE function (4200) and the SIMULATION FREQUENCY function (4302) is active (= ON).	
		Caution! The setting is not saved in the event of a power failure.	

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → OPERATION (PULSE)		
SIMULATION PULSE Modbus register: Data type: Access:	4322 3233 Integer read/ write	<p>Activates simulation of the pulse output.</p> <p>Options:</p> <p>0 = OFF</p> <p>1 = COUNTDOWN</p> <p>The pulses specified in the VALUE SIMULATION PULSE function are output.</p> <p>2 = CONTINUOUSLY</p> <p>Pulses are continuously output with the pulse width specified in the PULSE WIDTH function. Simulation is started once the CONTINUOUSLY option is confirmed with the key.</p> <p> Note! Simulation is started by confirming the CONTINUOUSLY option with the key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p>Factory setting: OFF</p> <p> Note! <ul style="list-style-type: none">▪ This function is available only if the PULSE setting was selected in the OPERATION MODE (4200) function.▪ The notice message #631 "SIM. PULSE" indicates that simulation is active.▪ The on/off ratio is 1:1 for both types of simulation.▪ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.</p> <p> Caution! The setting is not saved in the event of a power failure.</p>
VALUE SIMULATION PULSE Modbus register: Data type: Access:	4323 3234 Float read/ write	<p>Specify the number of pulses (e.g. 50) to be output during the simulation. This value is used to test downstream devices and the measuring device itself. The pulses are output with the pulse width specified in the PULSE WIDTH function. The on/off ratio is 1:1.</p> <p>Simulation is started once the specified value is confirmed with the key. The display remains at 0 if the specified pulses have been output.</p> <p>User input: 0 to 10 000</p> <p>Factory setting: 0</p> <p> Note! <ul style="list-style-type: none">▪ This function is not available unless the COUNTDOWN setting was selected in the function SIMULATION PULSE.▪ Simulation is started by confirming the simulation value with the key. The simulation can be switched off again via the SIMULATION PULSE function.</p> <p> Caution! The setting is not saved in the event of a power failure.</p>

Function description OUTPUTS → PULSE/FREQUENCY OUTPUT → OPERATION (STATUS)		
ACTUAL STATUS Modbus register: Data type: Access:	4341 3248 Integer read	<p>Use this function to check the current status of the status output.</p> <p>Display: 0 = NOT CONDUCTIVE 1 = CONDUCTIVE</p> <p> Note! This function is not available unless the STATUS setting was selected in the OPERATION MODE function (4200).</p>
SIMULATION SWITCH POINT Modbus register: Data type: Access:	4342 3249 Integer read/ write	<p>Use this function to activate simulation of the status output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note! <ul style="list-style-type: none"> ▪ This function is available only if the STATUS setting was selected in the OPERATION MODE (4200) function. ▪ The "SIMULATION STATUS OUTPUT" message indicates that simulation is active. ▪ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs. </p> <p> Caution! The setting is not saved in the event of a power failure.</p>
VALUE SIMULATION SWITCH POINT Modbus register: Data type: Access:	4343 3250 Integer read/ write	<p>Use this function to define the switching response of the status output during the simulation. This value is used to test downstream devices and the measuring device itself.</p> <p>Options: 0 = NOT CONDUCTIVE 1 = CONDUCTIVE</p> <p>Factory setting: NOT CONDUCTIVE</p> <p> Note! <ul style="list-style-type: none"> ▪ This function is not available unless STATUS was selected in the OPERATION MODE function (4200) and the SIMULATION SWITCH POINT function (4342) is active (= ON). </p> <p> Caution! The setting is not saved in the event of a power failure.</p>


7.2.3 Function group INFORMATION



Function description OUTPUTS → PULSE/FREQUENCY OUTPUT →INFORMATION		
TERMINAL NUMBER Modbus register: 3251 Data type: Integer Access: read	4380	<p>Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the pulse/frequency output.</p> <p>Display: 2 = 22 (+) / 23 (-)</p>

7.3 Group RELAY OUTPUT (1 to 2)

7.3.1 Function group CONFIGURATION



Function description OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION		
ASSIGN RELAY 4700 Modbus register: Relay output 1 3801 Relay output 2 4001 Data type: Access: Integer read/ write	Use this function to assign a switching function to the relay output. Options: (standard) 0 = OFF 1 = ON (operation) 2 = FAULT MESSAGE 3 = NOTICE MESSAGE 4 = FAULT MESSAGE or NOTICE MESSAGE 5 = EPD (empty pipe detection, only if active) 6 = FLOW DIRECTION 7 = MASS FLOW LIMIT VALUE 8 = VOLUME FLOW LIMIT VALUE 14 = CORRECTED VOLUME FLOW LIMIT VALUE 15 = DENSITY LIMIT VALUE 16 = REFERENCE DENSITY LIMIT VALUE 17 = TEMPERATURE LIMIT VALUE 19 = TOTALIZER 1 LIMIT VALUE 20 = TOTALIZER 2 LIMIT VALUE 21 = TOTALIZER 3 LIMIT VALUE	Factory setting: FAULT MESSAGE  Note! <ul style="list-style-type: none"> ▪ It is very important to read and comply with the information on the switching characteristics of the relay output (→ 90). ▪ It is advisable to configure at least one relay output as a fault output and define the outputs' failsafe mode. ▪ The relay output is configured as a normally open (NO or make) contact by default. It can be reconfigured as a normally closed (NC or break) contact by means of a jumper on the relay module → Operating Instructions BA141D/06. ▪ If you select OFF or ON, the only function shown in the CONFIGURATION function group is the function ASSIGN RELAY (4700).

		Function description OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION
ON-VALUE	4701	<p> Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to assign a value to the switch-on point (relay output pulls up). The value can be higher or lower than the switch-off point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note! <ul style="list-style-type: none"> ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ Only the switch-on point is available for flow direction output (no switch-off point). If you enter a value not equal to the zero flow (e.g. 5), the difference between the zero flow and the value entered corresponds to half the switchover hysteresis. </p>
SWITCH-ON DELAY	4702	<p> Note! This function is not available unless LIMIT VALUE or FLOW DIRECTION was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define a delay (0 to 100 seconds) for pull-up (i.e. signal changes from 0 to 1) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch on condition has been valid over the delay time.</p> <p>User input: fixed-point number 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p>
OFF-VALUE	4703	<p> Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to assign a value to the switch-off point (relay drops out). The value can be higher or lower than the switch-on point. Positive or negative values are permissible, depending on the measured variable in question (e.g. mass flow, totalizer reading).</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [kg/h] or 2 [kg/l] or 200 [°C]</p> <p> Note! <ul style="list-style-type: none"> ■ The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400). ■ If SYMMETRY is selected in the function MEASURING MODE (4705) and values with different signs are entered for the switch-on and switch-off points, the notice message "INPUT RANGE EXCEEDED" appears. </p>


		Function description OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION
SWITCH-OFF DELAY	4704	<p>Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define a delay (0 to 100 seconds) for dropout (i.e. signal changes from 1 to 0) of the relay output. The delay starts when the limit value is reached. The relay output does switch when the delay has timed out and the switch off condition has been valid over the delay time.</p> <p>User input: fixed-point number 0.0 to 100.0 s</p> <p>Factory setting: 0.0 s</p>
MEASURING MODE	4705	<p>Note! This function is not available unless LIMIT VALUE was selected in the ASSIGN RELAY function (4700).</p> <p>Use this function to define the measuring mode for the relay output.</p> <p>Options: 0 = STANDARD The relay output signal switches at the defined switch points. 1 = SYMMETRY The relay output signal switches at the defined switch points, irrespective of the sign. If you define a switch point with a positive sign, the relay output switches as soon as the value is reached in the negative direction (negative sign), (→ illustration).</p> <p>Factory setting: STANDARD</p>  <p>A0001247</p>

Fig. 23: Example for the SYMMETRY measuring mode

Switch-on point $Q = 4$ Switch-off point $Q = 10$

① = Relay energized


② = Relay de-energized

Note!

- SYMMETRY cannot be selected unless the values in the ON-VALUE (4701) and OFF-VALUE (4703) functions have the same sign or one of the values is zero.
- If the values have different signs, SYMMETRY cannot be selected and an "ASSIGNMENT NOT POSSIBLE" message is displayed.


Function description OUTPUTS → RELAY OUTPUT (1 to 2) → CONFIGURATION		
TIME CONSTANT Modbus register: Relay output 1 Relay output 2 Data type: Access:	4706 3811 4011 Float read/ write	Entering a time constant defines how the measuring signal reacts to severely fluctuating measured variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). Damping acts on the measuring signal before the switch status changes, and consequently before switch-on or switch-off delay is activated. The purpose of damping, therefore, is to prevent the relay output changing state continuously in response to fluctuations in flow. User input: fixed-point number: 0.00 to 100.00 s Factory setting: 0.00 s

7.3.2 Function group OPERATION



Function description OUTPUTS → RELAY OUTPUT (1 to 2) → OPERATION			
ACTUAL STATUS RELAY Modbus register: Relay output 1 3813 Relay output 2 4013 Data type: Access:	4740 3813 4013 Integer read	<p>Use this function to check the current status of the relay output.</p> <p>A jumper on the contact side defines the relay output as a normally open (NO or maker) or normally closed (NC or breaker) contact → Operating Instructions (BA00141D/06).</p> <p>Display: 0 = BREAK CONTACT OPEN 1 = BREAK CONTACT CLOSED 2 = MAKE CONTACT OPEN 3 = MAKE CONTACT CLOSED</p>	
SIMULATION SWITCH POINT Modbus register: Relay output 1 3814 Relay output 2 4014 Data type: Access:	4741 3814 4014 Integer read/ write	<p>Use this function to activate simulation of the relay output.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note! ■ The "SIMULATION RELAY" message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.</p> <p> Caution! The setting is not saved in the event of a power failure.</p>	
VALUE SIMULATION SWITCH POINT Modbus register: Relay output 1 3815 Relay output 2 4015 Data type: Access:	4742 3815 4015 Integer read/ write	<p> Note! The function is not visible unless the function SIMULATION SWITCH POINT (4741) is active.</p> <p>Use this function to define the status of the relay output during the simulation. This value is used to test downstream devices and the measuring device itself. Depending on the relay configuration (as make or break contact) the following selections are available.</p> <p>Options: Relay output configured as NC (breaker) contact 0 = BREAK CONTACT OPEN 1 = BREAK CONTACT CLOSED</p> <p>Options: Relay output configured as NO (maker) contact 2 = MAKE CONTACT OPEN 3 = MAKE CONTACT CLOSED</p> <p> Caution! The setting is not saved in the event of a power failure.</p>	

7.3.3 Function group INFORMATION



Function description OUTPUTS → RELAY OUTPUT (1 to 2) → INFORMATION		
TERMINAL NUMBER	4780	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the relay output. Display: 2 = 22 (+) / 23 (-) → RELAY OUTPUT 1 3 = 20 (+) / 21 (-) → RELAY OUTPUT 2
Modbus register: Relay output 1 Relay output 2 Data type: Access:	3816 4016 Integer read	

7.3.4 Information on the response of the relay output


General

If you have configured the relay output for "LIMIT VALUE" or "FLOW DIRECTION", you can define the requisite switch points in the ON-VALUE and OFF-VALUE functions. When the measured variable in question reaches one of these predefined values, the relay output switches as shown in the illustrations below.

Relay output configured for "flow direction"

The value you entered in the function ON-VALUE defines the switch point for the positive and negative directions of flow.

If, for example, the switch point you define is = $1 \text{ m}^3/\text{h}$, the relay drops out at $-1 \text{ m}^3/\text{h}$ and pulls up at $+1 \text{ m}^3/\text{h}$. Set the switch point to 0 if your process calls for direct switchover (no switching hysteresis). If low flow cut off is used, it is advisable to set hysteresis to a value higher than or equal to the low flow cut off rate.



A0001236

Fig. 24: Relay output configured for "flow direction"


- a Relay energized
- b Relay de-energized

Relay output configured for "limit value"

The relay output signal switches as soon as the measured variable undershoots or overshoots a defined switch point.

Application: Monitoring flow or process-related boundary conditions.

Measured variable



A0001235

Fig. 25: Relay output configured for "limit value"















- ① = Switch-off point, ② = Switch-on point, ③ = Relay de-energized















A = Maximum safety (SWITCH-OFF POINT > SWITCH-ON POINT)

B = Minimum safety (SWITCH-OFF POINT < SWITCH-ON POINT)

C = Minimum safety (SWITCH-OFF POINT = SWITCH-ON POINT, this configuration is to be avoided)

7.3.5 Switching behavior of the relay output

Function	State	Relay coil	Contact*
			NC NO
ON (operation)	System in measuring mode 	energized	 A0001239
	System not in measuring mode (power supply failed) 		 A0001240
Fault message	System OK 	energized	 A0001239
	(System or process error) Fault → Failsafe mode, outputs/inputs and totalizers 		 A0001240
Notice message	System OK 	energized	 A0001239
	(System or process error) Fault → Continuation of measuring 		 A0001240
Fault message or Notice message	System OK 	energized	 A0001239
	(System or process error) Fault → Response to error or Note → Continuation of measuring 		 A0001240

Function	State	Relay coil	Contact*	
			NC	NO
Empty pipe detection (EPD)	Measuring tube full 	energized	 A0001239	 A0001237
	Measuring tube partially filled /empty measuring tube 	de-energized	 A0001240	 A0001238
Flow direction	Forward  A0001241	energized	 A0001239	 A0001237
	Reverse  A0001242	de-energized	 A0001240	 A0001238
Limit value - Mass flow - Volume flow - Corrected volume flow - Density - Reference density - Temperature - Totalizer	Limit value not overshot or undershot  A0001243	energized	 A0001239	 A0001237
	Limit value overshot or undershot  A0001244	de-energized	 A0001240	 A0001238

* Terminal numbers in accordance with the TERMINAL NUMBER function (4780) → 88.

 Note!
If the measuring device has two relays, the factory setting is:

- Relay 1 → normally open contact (NO)
- Relay 2 → normally closed contact (NC)

8 Block INPUTS

Block	Groups	Function groups	Functions									
INPUTS (F)	STATUS INPUT ⇒ (FAA) → 93	<p>CONFIGURATION ⇒ (500) → 93</p> <p>OPERATION ⇒ (504) → 94</p> <p>INFORMATION ⇒ (508) → 95</p>	<table border="1"> <tr> <td>ASSIGN STATUS INPUT (5000)</td> <td>ACTIVE LEVEL ⇒ (5001) → 93</td> <td>MIN. PULSE WIDTH (5002) → 93</td> </tr> <tr> <td>SIMULATION ⇒ (5041) → 94</td> <td>ACTUAL STATUS INPUT (5040) → 94</td> <td>VALUE SIM. STATUS IN. (5042) → 94</td> </tr> <tr> <td>TERMINAL NUMBER (5080) ⇒ (508) → 95</td> <td></td> <td></td> </tr> </table>	ASSIGN STATUS INPUT (5000)	ACTIVE LEVEL ⇒ (5001) → 93	MIN. PULSE WIDTH (5002) → 93	SIMULATION ⇒ (5041) → 94	ACTUAL STATUS INPUT (5040) → 94	VALUE SIM. STATUS IN. (5042) → 94	TERMINAL NUMBER (5080) ⇒ (508) → 95		
ASSIGN STATUS INPUT (5000)	ACTIVE LEVEL ⇒ (5001) → 93	MIN. PULSE WIDTH (5002) → 93										
SIMULATION ⇒ (5041) → 94	ACTUAL STATUS INPUT (5040) → 94	VALUE SIM. STATUS IN. (5042) → 94										
TERMINAL NUMBER (5080) ⇒ (508) → 95												


8.1 Group STATUS INPUT

8.1.1 Function group CONFIGURATION




Function description INPUTS → STATUS INPUT → CONFIGURATION		
ASSIGN STATUS INPUT Modbus register: Data type: Access:	5000 4301 Integer read/ write	<p>Use this function to assign a switching function to the status input.</p> <p>Options: 0 = OFF 1 = RESET TOTALIZER 1 2 = RESET TOTALIZER 2 3 = RESET TOTALIZER 3 4 = RESET ALL TOTALIZERS 5 = POSITIVE ZERO RETURN 8 = ZEROPPOINT ADJUST</p> <p>Factory setting: OFF</p> <p> Caution! POSITIVE ZERO RETURN is active as long as the level is available at the status input (continuous signal). All other assignments react to a change in level (pulse) at the status input.</p>
ACTIVE LEVEL Modbus register: Data type: Access:	5001 4302 Integer read/ write	<p>Use this function to define whether the assigned function (→ function ASSIGN STATUS INPUT (5000)) is released when the signal level is present (HIGH) or not present (LOW).</p> <p>Options: 1 = HIGH 0 = LOW</p> <p>Factory setting: HIGH</p>
MINIMUM PULSE WIDTH Modbus register: Data type: Access:	5002 4303 Float read/ write	<p>Use this function to define a minimum pulse width which the input pulse must achieve in order to trigger the selected switching function, (→ function ASSIGN STATUS INPUT (5000)).</p> <p>User input: 20 to 100 ms</p> <p>Factory setting: 50 ms</p>

8.1.2 Function group OPERATION



Function description INPUTS → STATUS INPUT → OPERATION		
ACTUAL STATUS INPUT 5040 Modbus register: 4305 Data type: Integer Access: read	<p>Use this function to view the current level of the status input.</p> <p>Display: 0 = LOW 1 = HIGH</p>	
SIMULATION STATUS INPUT 5041 Modbus register: 4306 Data type: Integer Access: read/ write	<p>Use this function to simulate the status input, in other words to trigger the function assigned to the status input (→ function ASSIGN STATUS INPUT (5000) on → 93).</p> <p>Display: 0 = OFF 1 = ON</p> <p>Factory setting: OFF</p> <p> Note! ■ The "SIMULATION STATUS INPUT" notice message indicates that simulation is active. ■ The measuring device continues to measure while simulation is in progress, i.e. the current measured values are output correctly via the other outputs.</p> <p> Caution! The setting is not saved in the event of a power failure.</p>	
VALUE SIMULATION STATUS INPUT 5042 Modbus register: 4307 Data type: Integer Access: read/ write	<p> Note! The function is not visible unless the function SIMULATION STATUS INPUT (5041) is active.</p> <p>Use this function to define the level to be assumed at the status output during the simulation. This value is used to test downstream devices and the measuring device itself.</p> <p>Options: 0 = LOW 1 = HIGH</p> <p>Factory setting: LOW</p> <p> Caution! The setting is not saved in the event of a power failure.</p>	

8.1.3 Function group INFORMATION



Function description INPUTS → STATUS INPUT → INFORMATION		
TERMINAL NUMBER	5080	Use this function to view the numbers of the terminals (in the connection compartment) and the polarity used by the status input. Display: $1 = 24 (+) / 25 (-)$

9 Block BASIC FUNCTION

Block	Groups	Function groups	Functions
BASIC FUNCTION (G)	MODBUS RS485 ⇒ (GDA) → 97	CONFIGURATION ⇒ (630) → 97	FIELDBUS ADDRESS (6301) → 97 BAUDRATE (6302) → 97 TRANSMISSION MODE (6303) → 97 PARITY (6304) → 98 BYTE ORDER (6305) → 98 WRITE PROTECTION (6307) → 98 SCAN LIST REGISTER 1 to 16 (6308) → 99
	PROCESS PARAMETER (GIA) → 100	ASSIGN LF CUT OFF (640) → 100	ON-VALUE LF CUT OFF (6402) → 100 OFF-VALUE LF CUT OFF (6043) → 100 PRESS. SHOCK SUPP. (6404) → 101
		EPD PARAMETER (642) → 102	EPD VALUE LOW (6423) → 102 EPD VALUE HIGH (6424) → 102 EPD RESPONSE TIME (6425) → 102 EPD EXC.CURR (6426) → 103
		REFERENCE PARAMETER (646) → 104	FIXED REFERENCE DENSITY (6462) → 104 EXPANSION COEFF. SQR. (6463) → 104 EXPANSION COEFF. SQR. (6464) → 104 TEMPERATURE (6464) → 105
		COR. VOL. CALC. (6460) → 104	DENSITY SET (6482) → 106 MEASURE FLUID 1 (6483) → 106 DENSITY SET MEASURE FLUID 2 (6486) → 107 DENSITY ADJUSTMENT (6487) → 107 RESTORE ORIGINAL (6488) → 107
		ADJUSTMENT (648) → 106	ZERO POINT ADJUSTMENT (6480) → 106 DENSITY ADJUST MODE (6482) → 106 DENSITY SET VALUE 1 (6483) → 106 DENSITY SET VALUE 2 (6485) → 107
		PRESSURE CORRECTION (650) → 108	PRESSURE (6501) → 108
	SYSTEM PARAMETER (GLA) → 109	CONFIGURATION ⇒ (660) → 109	INST. DIR. SEN-SOR (6600) → 109 DENSITY DAMPING (6602) → 109 FLOW DAMPING → 109 POSITIVE ZERO RETURN (6605) → 109
	SENSOR DATA (GNA) → 110	CONFIGURATION ⇒ (680) → 110	K-FACTOR (6800) → 110 ZERO POINT (6803) → 110 FLOW DAMPING → 110 NOMINAL DIAMETER (6804) → 110
		FLOW COEFF. (684) → 111	COEFF. KM (6840) → 111 COEFF. KT (6841) → 111 COEFF. KD1 (6842) → 111 COEFF. KD2 (6843) → 111 (6844) → 111
		DENSITY COEFFICIENT (685) → 112	COEFF. C 0 (6850) → 112 COEFF. C 1 (6851) → 112 COEFF. C 2 (6852) → 112 COEFF. C 3 (6853) → 112 COEFF. C 4 (6854) → 112 COEFF. C 5 (6855) → 112
	ADDITIONAL COEFFICIENT (686) → 113	MIN TEMP. MEAS. (6860) → 113	MAX TEMP. MEAS. (6861) → 113 MIN TEMP. CARRIER (6862) → 113 MAX TEMP. CARRIER (6863) → 113

9.1 Group Modbus RS485

9.1.1 Function group CONFIGURATION

BASIC FUNCTION G → MODBUS RS485 GDA → CONFIGURATION 630


Function description BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
TAG NAME Modbus register: Data type: Access:	6300 4901 String (16) read/ write	For entering a tag name for the measuring device. You can edit and read this tag name via the local display or the Modbus RS485 protocol. User input: max. 16-character text, permissible: A-Z, 0-9, +, -, punctuation marks Factory setting: "-----" (No text)
FIELDBUS ADDRESS Modbus register: Data type: Access:	6301 4910 Integer read/ write	For entering the device address. User input: 1 to 247 Factory setting: 247
BAUDRATE Modbus register: Data type: Access:	6302 4912 Integer read/ write	For selecting the baudrate. Options: 0 = 1200 BAUD 1 = 2400 BAUD 2 = 4800 BAUD 3 = 9600 BAUD 4 = 19200 BAUD 5 = 38400 BAUD 6 = 57600 BAUD 7 = 115200 BAUD Factory setting: 19200 BAUD
TRANSMISSION MODE Modbus register: Data type: Access:	6303 4913 Integer read/ write	For selecting the data transfer mode. Options: 0 = RTU 1 = ASCII Factory setting: RTU  Note! ■ RTU = transmission of data in binary form. Error protection via CRC16. ■ ASCII = transmission of data in the form of readable ASCII characters. Error protection via LRC.



Function description BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
PARITY Modbus register: Data type: Access:	6304 4914 Integer read/ write	For selecting whether no parity bit or an even or uneven parity bit should be transmitted. The options available depend on the TRANSMISSION MODE function: Options: (for TRANSMISSION MODE = RTU) 0 = EVEN 1 = UNEVEN 2 = NONE Options: (for TRANSMISSION MODE = ASCII) 0 = EVEN 1 = UNEVEN Factory setting: EVEN
BYTE ORDER Modbus register: Data type: Access:	6305 4915 Integer read/ write	For selecting the byte transmission sequence for the Integer, Float and String data types. Options: 0 = 0-1-2-3 1 = 3-2-1-0 2 = 2-3-0-1 3 = 1-0-3-2 Factory setting: 1-0-3-2  Note! <ul style="list-style-type: none">■ The transmission sequence must suit the Modbus master.■ For additional information, refer to the "Byte transmission order" section in the Operating Instructions (BA00141D/06).
DELAY TELE. REPLY Modbus register: Data type: Access:	6306 4916 Float read/ write	For entering a delay time after which the measuring device replies to the request telegram of the Modbus master. This allows communication to be adapted to slow Modbus RS485 masters. User input: 0 to 100 ms Factory setting: 10 ms
WRITE PROTECTION Modbus register: Data type: Access:	6307 4918 Integer read	Indicates whether write access to the measuring device is possible via local operation or Modbus RS485. Display: 0 = OFF (write access via Modbus possible) 1 = ON (write access via Modbus blocked) Factory setting: OFF  Note! Hardware write protection is activated and deactivated by means of a jumper on the I/O board → Operating Instructions (BA00141D/06).


Function description		
BASIC FUNCTION → MODBUS RS485 → CONFIGURATION		
SCAN LIST REGISTER 1 to 16 Modbus register: SCAN LIST REG. 1 SCAN LIST REG. 2 SCAN LIST REG. 3 SCAN LIST REG. 4 SCAN LIST REG. 5 SCAN LIST REG. 6 SCAN LIST REG. 7 SCAN LIST REG. 8 SCAN LIST REG. 9 SCAN LIST REG. 10 SCAN LIST REG. 11 SCAN LIST REG. 12 SCAN LIST REG. 13 SCAN LIST REG. 14 SCAN LIST REG. 15 SCAN LIST REG. 16 Data type: Access:	6308 5001 5002 5003 5004 5005 5006 5007 5008 5009 5010 5011 5012 5013 5014 5015 5016 Integer read/ write	By entering the register address, up to 16 device parameters can be grouped in the auto-scan buffer where they are assigned to the scan list registers 1 to 16. The data of the device parameters assigned here are read out via the register addresses 5051 to 5081. User input: 0 to 9999 Factory setting: 0  Note! For additional information and examples of using the auto-scan buffer, refer to the Operating Instructions (BA00141D/06).

9.2 Group PROCESS PARAMETER

9.2.1 Function group CONFIGURATION



Function description BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION				
ASSIGN LOW FLOW CUTOFF 6400 Modbus register: 5101 Data type: Integer Access: read/ write	Use this function to assign the switch point for low flow cut off rate suppression. Options: 0 = OFF 1 = MASS FLOW 2 = VOLUME FLOW 3 = CORRECTED VOLUME FLOW Factory setting: MASS FLOW			
ON-VALUE LOW FLOW CUT OFF 6402 Modbus register: 5138 Data type: Float Access: read/ write	Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active. User input: 5-digit floating-point number, [unit] Factory setting: Depends on nominal diameter Note! The appropriate unit is taken from the function group (→ 14).			
OFF-VALUE LOW FLOW CUTOFF 6403 Modbus register: 5104 Data type: Float Access: read/ write	Enter the off-value (b) of the low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input: Integer 0 to 100% Factory setting: 50%			
 A0003882				
① = on-value, ② = off-value a Low flow cut off is switched on b Low flow cut off is switched off ($a + a \cdot H$) H Hysteresis: 0 to 100%  Low flow cut off active Q Flow				

		Function description
BASIC FUNCTION → PROCESS PARAMETER → CONFIGURATION		
PRESSURE SHOCK SUPPRESSION	6404	<p>The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".</p> <p> Note! Note that pressure shock suppression cannot be used unless the low flow cut off is active, (→ function on → 100).</p> <p>Use this function to define the time span for active pressure shock suppression.</p> <p>Activation of the pressure shock suppression Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (→ point a in graphic). While pressure shock suppression is active, the following conditions apply:</p> <ul style="list-style-type: none"> ■ Flow reading on display → 0 ■ Totalizer reading → the totalizers are pegged at the last correct value. <p>Deactivation of the pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (→ point b in graphic).</p> <p> Note! The actual flow value is displayed and output, when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (→ point c in graphic).</p> 


- ① = Off-value (low flow cut off), ② = On-value (low flow cut off)
 a Active when value falls below the on-value of the low flow cut off
 b Deactivated after specified time expires
 c Flow values are again used to calculate the pulses
 Suppressed values
 Q Flow

User input:
max. 4-digit number, incl. unit: 0.00 to 100.0 s

Factory setting:
0.00 s

A0001285-EN


9.2.2 Function group EPD PARAMETER



Function description BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER		
EMPTY PIPE DETECTION Modbus register: Data type: Access:	6420 5106 Integer read/ write	<p>Use this function to activate the empty pipe detection (EPD). With empty measuring tubes the density of the fluid falls below the value specified in the function EPD VALUE LOW.</p> <p>Options: 0 = OFF 1 = ON</p> <p>Factory setting: Liquid: ON Gas: OFF</p> <p> Caution!</p> <ul style="list-style-type: none"> Select a correspondingly low EPD response value in the function EPD VALUE LOW, so that the difference to the effective density of the fluid is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. For gas measurement we strongly recommend to switch off empty pipe detection.
EPD VALUE LOW Modbus register: Data type: Access:	6423 5110 Float read/ write	<p> Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function.</p> <p>Use this function to set a lower threshold for the measured density value, in order to detect possible problems in the process indicated by too low density.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 0.2000 g/cc</p>
EPD VALUE HIGH Modbus register: Data type: Access:	6424 5112 Float read/ write	<p> Note! This function is not available unless the ON selection was selected in the EMPTY PIPE DETECTION function.</p> <p>Use this function to set an upper threshold for the measured density value.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 6.0000 g/cc</p>
EPD RESPONSE TIME Modbus register: Data type: Access:	6425 5108 Float read/ write	<p>Use this function to enter the time span for which the criteria for an empty pipe have to be satisfied without interruption before a notice message or fault message is generated.</p> <p>User input: fixed-point number: 1.0 to 60 s</p> <p>Factory setting: 1.0 s</p>

Function description		
BASIC FUNCTION → PROCESS PARAMETER → EPD PARAMETER		
EPD EXC.CURR. Modbus register: Data type: Access:	6426 5233 Float read/ write	<p>Empty pipe detection (EPD) can be switched on in this function. In the event of inhomogeneous fluids or air bubbles, the exciting current of the measuring pipes increases. If the exciting current specified in this function is overshot, error message #700 "EPD ACTIVE" is output similar to the EPD VALUE LOW (6423) function.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 100 mA (deactivated)</p> <p> Note! The function is not activated until a value under 100 mA is input. Entering the value 100 mA deactivates the function.</p>


9.2.3 Function group REFERENCE PARAMETER



Function description BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER		
CORRECTED VOLUME CALCULATION Modbus register: Data type: Access:	6460 5129 Integer read/ write	This function is used to set the reference density for calculating the corrected volume flow. Options: 0 = CALCULATED REFERENCE DENSITY 1 = FIXED REFERENCE DENSITY Factory setting: CALCULATED REFERENCE DENSITY
FIXED REFERENCE DENSITY Modbus register: Data type: Access:	6461 5130 Float read/ write	Note! This function is not available unless the FIXED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460). In this function, a fixed value for the reference density can be entered, with which the corrected volume flow or corrected volume is calculated. User input: 5-digit floating-point number Factory setting: 1 kg/Nl
EXPANSION COEFFICIENT Modbus register: Data type: Access:	6462 5132 Float read/ write	Note! This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CORRECTED VOLUME CALCULATION function (6460). For temperature-compensated calculations of the reference density an expansion coefficient specific to the fluid is required and can be entered in this function (→ REFERENCE TEMPERATURE (6464) function on → 105). User input: 5-digit floating-point number Factory setting: 0.5000 e-3 [1/K]
EXPANSION COEFFICIENT SQUARE Modbus register: Data type: Access:	6463 5134 Float read/ write	Use this function to enter a square expansion coefficient, if the temperature compensation follows a nonlinear behavior (→ REFERENCE TEMPERATURE (6464) function on → 105). User input: 5-digit floating-point number Factory setting: 0 e-6 [1/K ²]

		Function description
BASIC FUNCTION → PROCESS PARAMETER → REFERENCE PARAMETER		
REFERENCE TEMPERATURE	6464	<p> Note!</p> <p>This function is not available unless the CALCULATED REFERENCE DENSITY setting was selected in the CALCULATION function (6460).</p> <p>For entering the reference temperature for calculating the corrected volume flow, the corrected volume and the reference density.</p> <p>User input: 5-digit floating-point number</p> <p>Factory setting: 20.000 °C</p> <p>The reference density is calculated as follows: $\rho_N = \rho \cdot (1 + \alpha \Delta t + \beta \Delta t^2)$; Δ where $t = t - t_N$</p> <p>ρ_N = Reference density ρ = currently measured fluid density (measuring value) t = Actual measured temperature of fluid (measuring value) t_N = Reference temperature for calculating the reference density (e.g. 20 °C) α = Vol. expansion coefficient of the fluid, unit [1/K] (K = Kelvin) β = Square volumetric expansion coefficient of the fluid, unit [1/K²]</p>


9.2.4 Function group ADJUSTMENT



Function description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT			
ZERO POINT ADJUSTMENT	6480	<p>This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the function ZERO POINT.</p> <p>Options: 0 = CANCEL 1 = START</p> <p>Factory setting: CANCEL</p> <p> Caution! Before carrying this out, please refer to the Operating Instructions (BA00141D/06) for a detailed description of the procedure for zero point adjustment.</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ Programming is locked during zero point adjustment. The message "ZERO ADJUST RUNNING" appears on the display. ▪ If the zero point adjustment is not possible (e.g. if v > 0.1 m/s) or has been canceled, the alarm message "ZERO ADJUST NOT POSSIBLE" appears on the display. ▪ If the Cubemass DCI measuring electronics are fitted with a status input, then the zero point adjustment can also be activated by using this input. 	
DENSITY ADJUST MODE	6482	<p>Use this function to select whether a 1-point or a 2-point density adjustment should be carried out.</p> <p>Options: 0 = CANCEL 1 = 1-POINT 2 = 2-POINT</p>	
DENSITY SET VALUE 1	6483	<p>Use this function to enter the density setpoint value for the first fluid for which you want to carry out field density adjustment.</p> <p>User input: 5-digit floating-point number, incl. unit</p> <p> Note!</p> <ul style="list-style-type: none"> ▪ The preset density entered here should not vary from the actual fluid density by more than ±10%. ▪ The appropriate unit is taken from the function group (→ 14). 	
MEASURE FLUID 1	6484	<p>In this function the actual density of the first fluid is measured for density adjustment.</p> <p>Options: 0 = CANCEL 1 = START</p>	

Function description BASIC FUNCTION → PROCESS PARAMETER → ADJUSTMENT		
DENSITY SET VALUE 2 Modbus register: Data type: Access:	6485 5181 Float read/ write	Use this function to enter the density setpoint value for the second fluid for which you want to carry out field density adjustment. User input: 5-digit floating-point number, incl. unit  Note! <ul style="list-style-type: none"> ▪ The preset density entered here should not vary from the actual fluid density by more than ±10%. ▪ The difference between the density setpoint values must be at least 0.2 kg/l. ▪ The appropriate unit is taken from the function group SYSTEM UNITS (→ Fig 14).
MEASURE FLUID 2 Modbus register: Data type: Access:	6486 5183 Integer read/ write	In this function the current density of the second fluid is measured for density adjustment. Options: 0 = CANCEL 1 = START
DENSITY ADJUSTMENT Modbus register: Data type: Access:	6487 5127 Integer read/ write	With this function a density adjustment can be carried out on site. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations (e.g. volume flow) are as accurate as possible.  Note! Before carrying this out, please refer to the Operating Instructions (BA00141D/06) for a detailed description of the procedure for density adjustment. Two types of adjustment are possible: 1-point density adjustment (with one fluid) This type of density adjustment is necessary under the following conditions: <ul style="list-style-type: none"> ▪ The sensor does not measure exactly the density value that the user expects on the basis of laboratory analyses. ▪ The fluid properties are outside the measuring points set at the factory, or the reference operating conditions used to calibrate the measuring device. ▪ The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. 2-point density adjustment (with two fluids) This type of adjustment must always be carried out when the measuring tubes are changed mechanically, e.g. due to deposits, abrasion or corrosion: In such instances, the measuring tube resonance frequency is influenced in such a way that it is no longer compatible with the calibration data determined at the factory. The 2-point density adjustment takes these mechanically-based changes into account and calculates new, adjusted calibration data. Options: 0 = CANCEL 1 = MEASURE FLUID 1 2 = MEASURE FLUID 2 3 = DENSITY ADJUST Factory setting: CANCEL
RESTORE ORIGINAL Modbus register: Data type: Access:	6488 5128 Integer read/ write	With this function the original density coefficient determined at the factory are restored. Options: 0 = NO 1 = YES Factory setting: NO


9.2.5 Function group PRESSURE CORRECTION



Function description		
BASIC FUNCTION → PROCESS PARAMETER → PRESSURE CORRECTION		
PRESSURE MODE 6500 Modbus register: Data type: Access:	5184 Integer read/ write	<p>Use this function to configure an automatic pressure correction. In this way, the effect of a pressure deviation between the calibration and process pressures on the measured error for mass flow can be compensated → also Operating Instructions (BA00141D/06), section "Performance characteristics".</p> <p>Options: 0 = OFF 1 = FIX (a fixed process pressure for pressure correction is specified).</p> <p>Factory setting: OFF</p>
PRESSURE 6501 Modbus register: Data type: Access:	5185 Float read/ write	<p> Note! This function is not available unless the FIXED setting was selected in the PRESSURE MODE function (6500).</p> <p>Use this function to enter the value for the process pressure which should be used during pressure correction.</p> <p>User input: 7-digit floating-point number</p> <p>Factory setting: 0 bar g</p> <p> Note! The appropriate unit is taken from the function group SYSTEM UNITS (→ 14).</p>

9.3 Group SYSTEM PARAMETER


9.3.1 Function group CONFIGURATION



Function description BASIC FUNCTION → SYSTEM PARAMETER → CONFIGURATION			
INSTALLATION DIRECTION SENSOR	6600	Use this function to reverse the sign of the flow direction, if necessary.	
Modbus register: Data type: Access:	5501 Integer read/ write	<p>Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).</p> <p>Options: 0 = NORMAL (flow as indicated by the arrow) 1 = INVERSE (flow opposite to direction indicated by the arrow)</p> <p>Factory setting: NORMAL</p>	
DENSITY DAMPING	6602	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the fluid, e.g. with inhomogeneous liquids. The damping acts on all functions and outputs of the measuring device.	
Modbus register: Data type: Access:	5508 Float read/ write	<p>User input: max. 5-digit number, including unit: 0.00 to 100.00 s</p> <p>Factory setting: Liquid: 0.00 s Gas: 0.25 s</p>	
FLOW DAMPING	6603	Setting the filter depth of the digital filter. The sensitivity of the flow measurement signal can be reduced with respect to interference peaks (e.g. in the event of a high solid content, gas bubbles in the fluid etc.). The reaction time of the measuring device increases with every increase in the filter setting. The damping acts on all functions and outputs of the measuring device.	
Modbus register: Data type: Access:	5510 Float read/ write	<p>User input: 0 to 100 s</p> <p>Factory setting: 0 s</p>	
POSITIVE ZERO RETURN	6605	Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device.	
Modbus register: Data type: Access:	5503 Integer read/ write	<p>Options: 0 = OFF 1 = ON (signal output is set to the "ZERO FLOW" value, temperature and density are still output)</p> <p>Factory setting: OFF</p>	


9.4 Group SENSOR DATA

9.4.1 Function group CONFIGURATION




Function description BASIC FUNCTION → SENSOR DATA → CONFIGURATION		
All sensor data (calibration factor, zero point and nominal diameter) are set at the factory and saved on the S-DAT sensor memory chip.		
<p> Caution! Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code. Contact the Endress+Hauser service organization if you have any questions about these functions.</p> <p> Note! The individual values of the functions are also provided on the sensor nameplate.</p>		
K-FACTOR Modbus register: Data type: Access:	6800 7513 Float read	This function shows the current calibration factor for the sensor. Factory setting: Depends on nominal diameter and calibration
ZERO POINT Modbus register: Data type: Access:	6803 7527 Float read/ write	This function shows the current zero point correction value for the sensor. Display: max. 5-digit number: -99999 to +99999 Factory setting: Depends on calibration
NOMINAL DIAMETER Modbus register: mm inch Data type: Access:	6804 7525 7526 Integer read	Display: Nominal diameter of the sensor 0 = DN 1 or $\frac{1}{24}$ " 1 = DN 2 or $\frac{1}{12}$ " 4 = DN 4 or $\frac{1}{8}$ " 5 = DN 6 or $\frac{1}{4}$ "

9.4.2 Function group FLOW COEFFICIENT




Function description BASIC FUNCTION → SENSOR DATA → FLOW COEFFICIENT		
All flow coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip. Contact the Endress+Hauser service organization if you have any questions about these functions.		
TEMPERATURE COEFFICIENT KM Modbus register: 7519 Data type: Float Access: read	6840	This function shows the temperature coefficient KM.
TEMPERATURE COEFFICIENT KM2 Modbus register: 7521 Data type: Float Access: read	6841	This function shows the temperature coefficient KM2.
TEMPERATURE COEFFICIENT KT Modbus register: 7523 Data type: Float Access: read	6842	This function shows the temperature coefficient KT.
CALIBRATION COEFFICIENT KD 1 Modbus register: 7515 Data type: Float Access: read	6843	This function shows the calibration coefficient KD 1.
CALIBRATION COEFFICIENT KD 2 Modbus register: 7517 Data type: Float Access: read	6844	This function shows the calibration coefficient KD 2.

9.4.3 Function group DENSITY COEFFICIENT



Function description		
BASIC FUNCTION → SENSOR DATA → DENSITY COEFFICIENT		
All density coefficients are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.		
Contact the Endress+Hauser service organization if you have any questions about these functions.		
DENSITY COEFF. C0 6850	This function shows the actual density coefficient C0. Modbus register: 7501 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFF. C1 6851	This function shows the actual density coefficient C1. Modbus register: 7503 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFF. C2 6852	This function shows the actual density coefficient C2. Modbus register: 7505 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFF. C3 6853	This function shows the actual density coefficient C3. Modbus register: 7507 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFF. C4 6854	This function shows the actual density coefficient C4. Modbus register: 7509 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.
DENSITY COEFF. C5 6855	This function shows the actual density coefficient C5. Modbus register: 7511 Data type: Float Access: read	Caution! A density adjustment can alter the calibration value of this coefficient.

9.4.4 Function group ADDITIONAL COEFFICIENT



Function description		
BASIC FUNCTION → SENSOR DATA → ADDITIONAL COEFFICIENT		
All sensor data are set at the factory. All the sensor's parameter settings are saved on the S-DAT memory chip.		
<p> Caution!</p> <p>These functions are used for displaying device parameters only and consequently cannot be accessed.</p> <p>Contact the Endress+Hauser service organization if you have any questions about these functions.</p>		
MINIMAL TEMPERATURE MEASURED Modbus register: 7529 Data type: Float Access: read	6860	The lowest fluid temperature measured appears on the display.
MAXIMAL TEMPERATURE MEASURED Modbus register: 7531 Data type: Float Access: read	6861	The highest fluid temperature measured appears on the display.
MINIMAL TEMPERATURE CARRIER TUBE Modbus register: 7533 Data type: Float Access: read	6862	The lowest carrier tube temperature measured appears on the display.
MAXIMUM TEMPERATURE CARRIER TUBE Modbus register: 7535 Data type: Float Access: read	6863	The highest carrier tube temperature measured appears on the display.

10 Block SUPERVISION

Block	Groups	Function groups	Functions
SUPERVISION (0)	SYSTEM ⇒ (0AA) → 115 ↓ ↑	CONFIGURATION ⇒ (800) → 115 ↓ ↑	STORAGE ⇒ (8007) → 115
	OPERATION ⇒ (804) → 116 ↓ ↑	ACT. SYST. CONDITION ⇒ (8040) → 116	PREV. SYST. CONDITION ⇒ (8041) → 116 SIM. FAILSAFE MODE ⇒ (8042) → 116 MEASURAND ⇒ (8043) → 117 VAL SIM. MEASURAND ⇒ (8044) → 117 SYSTEM RESET ⇒ (8046) → 117 OPERATION HOURS (8048) ⇒ 117
	VERSION-INFO ⇒ (0CA) → 118 ↓ ↑	DEVICE SOFTWARE ⇒ (810) → 118 ↓ ↑	DEVICE SOFTWARE ⇒ (8100) → 118
	SENSOR ⇒ (820) → 119 ↓ ↑	SERIAL NUMBER ⇒ (8200) → 119	SENSOR TYPE ⇒ (8201) → 119 SW REV. NO. S-DAT ⇒ (8205) → 119
	AMPLIFIER ⇒ (822) → 120 ↓ ↑	SW REV. NO. AMPLIFIER ⇒ (8222) → 120	SW REV. NO. T-DAT ⇒ (8225) → 120 LANGUAGE GROUP (8226) ⇒ 120
	I/O MODULE ⇒ (830) → 121 ↓ ↑	I/O MODULE TYPE (8300) ⇒ (8303) → 121	SW REV. I/O-MODULE ⇒ (8303) → 121
	I/O SUBMODULE 2 ⇒ (834) → 122 ↓ ↑	SUB IN-/OUTPUT TYPE 2 ⇒ (8340) → 122	SW REV. SUB I/O ⇒ (8343) → 122
	I/O SUBMODULE 3 ⇒ (836) → 122 ↓ ↑	SUB IN-/OUTPUT TYPE 3 ⇒ (8360) → 122	SW REV. SUB I/O ⇒ (8363) → 122
	I/O SUBMODULE 4 ⇒ (838) → 122 ↓ ↑	SUB IN-/OUTPUT TYPE 4 ⇒ (8380) → 122	SW REV. SUB I/O ⇒ (8383) → 122


10.1 Group SYSTEM

10.1.1 Function group CONFIGURATION

SUPERVISION J → SYSTEM JAA → CONFIGURATION 800

Function description SUPERVISION → SYSTEM → CONFIGURATION		
ALARM DELAY Modbus register: Data type: Access:	8005 6808 Float read/ write	<p>Enter the time span for which the criteria for an error have to be satisfied without interruption before a fault or notice message is generated. This suppression acts on:</p> <ul style="list-style-type: none"> ■ Display ■ Current output ■ Frequency output ■ Relay output ■ Modbus RS485 <p>Input: 0 to 100 s (in steps of one second)</p> <p>Factory setting: 0 s</p> <p> Caution! If this function is activated, fault and notice messages are delayed by the time corresponding to the setting before being transmitted to the higher-order controller (process controller etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages may not be suppressed, a value of 0 seconds must be entered here.</p>
STORAGE Modbus register: Data type: Access:	8007 6907 Integer read	<p>Displays whether the automatic, permanent storage of parameter changes in the EEPROM is switched on or off.</p> <p>Display: 0 = OFF 1 = ON</p> <p>Factory setting: ON</p> <p> Caution! <ul style="list-style-type: none"> ■ The selection in the function can be changed by the Endress+Hauser service organization. ■ If you select OFF, all parameter changes are not stored permanently in the EEPROM. This means that these parameter changes are no longer available after a power failure. In this case, the measuring instrument starts up with the last parameter configurations saved in the EEPROM. </p>

10.1.2 Function group OPERATION




Function description SUPERVISION → SYSTEM → OPERATION		
ACTUAL SYSTEM CONDITION Modbus register: 6859 Data type: Integer Access: read	8040	Displays the present system condition. Display: 1 = "SYSTEM OK" or The fault / notice message with the highest priority. Note! For additional information, refer to the "System or process error messages" section in the Operating Instructions (BA00141D/06).
PREVIOUS SYSTEM CONDITIONS Modbus register: See Note Data type: Integer Access: read	8041	Use this function to view the sixteen most recent fault and notice messages since measuring last started. Display: The 16 most recent fault or notice messages. Note to MODBUS! The various previous system conditions are available via the following MODBUS registers (data Modbus register Integer/String): <ul style="list-style-type: none">■ Fault/notice message 1 = Modbus register 6860■ Fault/notice message 2 = Modbus register 6861■ Fault/notice message 3 = Modbus register 6862■ Fault/notice message 4 = Modbus register 6863■ Fault/notice message 5 = Modbus register 6864■ Fault/notice message 6 = Modbus register 6865■ Fault/notice message 7 = Modbus register 6866■ Fault/notice message 8 = Modbus register 6867■ Fault/notice message 9 = Modbus register 6868■ Fault/notice message 10 = Modbus register 6869■ Fault/notice message 11 = Modbus register 6870■ Fault/notice message 12 = Modbus register 6871■ Fault/notice message 13 = Modbus register 6872■ Fault/notice message 14 = Modbus register 6873■ Fault/notice message 15 = Modbus register 6874■ Fault/notice message 16 = Modbus register 6875 Note! For additional information, refer to the "System or process error messages" section in the Operating Instructions (BA00141D/06).
SIMULATION FAILSAFE MODE Modbus register: 6812 Data type: Integer Access: read/write	8042	Use this function to set all inputs, outputs and totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the message "SIMULATION FAILSAFE MODE" appears on the display. Options: 0 = OFF 1 = ON Factory setting: OFF

Function description SUPERVISION → SYSTEM → OPERATION			
SIMULATION MEASURAND Modbus register: Data type: Access:	8043 6813 Integer read/ write	<p>Use this function to set all inputs, outputs and totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the message "SIMULATION MEASURAND" appears on the display.</p> <p>Options: 0 = OFF 1 = MASS FLOW 2 = VOLUME FLOW 3 = CORRECTED VOLUME FLOW 4 = DENSITY 5 = REFERENCE DENSITY 6 = TEMPERATURE</p> <p>Factory setting: OFF</p> <p> Caution! ■ The measuring device cannot be used for measuring while this simulation is in progress. ■ The setting is not saved in the event of a power failure.</p>	
VALUE SIMULATION MEASURAND Modbus register: Data type: Access:	8044 6814 Float read/ write	<p> Note! The function is not visible unless the function SIMULATION MEASURAND (8043) is active.</p> <p>For entering a freely selectable value (e.g. 12 m³/s) to check the associated functions in the device itself and downstream signal loops.</p> <p>User input: 5-digit floating-point number [unit]</p> <p>Factory setting: 0 [unit]</p> <p> Caution! ■ The setting is not saved in the event of a power failure. ■ The appropriate unit is taken from the function group SYSTEM UNITS (ACA) (→ 14).</p>	
SYSTEM RESET Modbus register: Data type: Access:	8046 6817 Integer read/ write	<p>Use this function to perform a reset of the measuring system.</p> <p>Options: 0 = NO 1 = RESTART SYSTEM (restart without interrupting power supply)</p> <p>Factory setting: NO</p>	
OPERATION HOURS Modbus register: Data type: Access:	8048 6810 Float read	<p>The hours of operation of the device appear on the display.</p> <p>Display: Depends on the number of hours of operation elapsed ■ Hours of operation < 10 hours → display format = 0:00:00 (hr:min:sec) ■ Hours of operation 10 to 10000 hours → display format = 0000:00 (hr:min) ■ Hours of operation > 10000 hours → display format = 000000 (hr)</p>	


10.2 Group VERSION-INFO

10.2.1 Function group DEVICE




Function description SUPERVISION → VERSION-INFO → DEVICE	
DEVICE SOFTWARE 8100 Modbus register: 7277 Data type: String Access: (16) read	Displays the current device software version.

10.2.2 Function group SENSOR




Function description SUPERVISION → VERSION-INFO → SENSOR		
SERIAL NUMBER Modbus register: Data type: Access:	8200 7003 String (16) read	Use this function to view the serial number of the sensor.
SENSOR TYPE Modbus register: Data type: Access:	8201 7012 String (16) read	Use this function to view the sensor type (e.g. Promass F).
SW REV. NO. S-DAT Modbus register: Data type: Access:	8205 7021 String (16) read	Use this function to view the software revision number of the software used to create the content of the S-DAT.

10.2.3 Function group AMPLIFIER




Function description SUPERVISION → VERSION-INFO → AMPLIFIER		
SW REV. NO. AMPLIFIER Modbus register: 7039 Data type: String Access: (16) read	8222	Use this function to view the software revision number of the amplifier.
SW REV. NO. T-DAT Modbus register: 7048 Data type: String Access: (16) read	8225	Use this function to view the software revision number of the software used to create the content of the T-DAT.
LANGUAGE GROUP 8226 Modbus register: 7262 Data type: Integer Access: read	8226	<p>Displays the installed language group.</p> <p>Display: 0 = TYPE UNKNOWN 1 = WEST EU / USA 2 = EAST EU / SCAND 3 = ASIA 4 = CHINA</p> <p> Note! <ul style="list-style-type: none"> ■ The language options of the available language group are displayed in the LANGUAGE (2000) function. ■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions. </p>

10.2.4 Function group I/O MODULE



Function description SUPERVISION → VERSION-INFO → I/O MODULE		
I/O MODULE TYPE 8300 Modbus register: 7086 Data type: Integer Access: read	Displays the configuration of the I/O module. Display: 12 = Modbus RS485	
SW REV. NO. I/O MODULE Modbus register: 7078 Data type: String Access: (18) read	Use this function to view the software revision number of the I/O module.	

10.2.5 Function groups I/O SUBMODULE 2 to 4



Function description		
SUPERVISION → VERSION-INFO → I/O SUBMODULE 2 to 4		
SUB I/O TYPE	8340	Displays the configuration of the I/O submodule 2. Display: 7 = STATUS INPUT
Modbus register:	7106	
Data type:	Integer	
Access:	read	
SW REV. NO. SUB I/O TYPE	8343	Use this function to view the software revision number of the submodule 2.
Modbus register:	7190	
Data type:	String (18)	
Access:	read	
SUB I/O TYPE	8360	Displays the configuration of the I/O submodule 3. Display: 0 = TYPE UNKNOWN 5 = PULS/FREQ. OUT. 6 = STATUS/REL. OUT
Modbus register:	7107	
Data type:	Integer	
Access:	read	
SW REV. NO. SUB I/O TYPE	8363	Use this function to view the software revision number of the submodule 3.
Modbus register:	7199	
Data type:	String (18)	
Access:	read	
SUB I/O TYPE	8380	Displays the configuration of the I/O submodule 4. Display: 0 = TYPE UNKNOWN 4 = CURRENT OUTPUT 6 = STATUS/REL. OUT
Modbus register:	7108	
Data type:	Integer	
Access:	read	
SW REV. NO. SUB I/O TYPE	8383	Use this function to view the software revision number of the submodule 4.
Modbus register:	7199	
Data type:	String (18)	
Access:	read	

11 Factory settings

11.1 SI units (not for USA and Canada)

11.1.1 Low flow cut off, full scale value, pulse value

Nominal diameter [mm]	Low flow cut off [kg/h]	Full scale value Current output [kg/h]	Pulse value [kg/p]
1	0.08	4	0.001
2	0.4	20	0.010
4	1.8	90	0.010
6	4.0	200	0.100

11.2 US units (only for USA and Canada)

11.2.1 Low flow cut off, full scale value, pulse value

Nominal diameter [inch]	Low flow cut off [lb/min]	Full scale value Current output [lb/min]	Pulse value [lb/p]
1/24"	0.003	0.15	0.002
1/12"	0.015	0.75	0.020
1/6"	0.066	3.30	0.020
1/4"	0.15	7.4	0.200

Index of function matrix

Blocks

A = MEASURED VARIABLES	12
B = QUICK SETUP	19
C = USER INTERFACE	28
D = TOTALIZER	45
E = OUTPUT	50
F = INPUT	92
G = BASIC FUNCTION	96
J = SUPERVISION	114

Groups

AAA = MEASURING VALUES	13
ACA = SYSTEM UNITS	14
CAA = CONTROL	29
CCA = MAIN LINE	33
CEA = ADDITIONAL LINE	37
CGA = INFORMATION LINE	41
DAA = TOTALIZER 1	46
DAB = TOTALIZER 2	46
DAC = TOTALIZER 3	46
DJA = HANDLING TOTALIZER	49
EAA = OUTPUTS	51
ECA = PULSE/FREQUENCY OUTPUT	62
EGA = RELAY OUTPUT 1	83
EGB = RELAY OUTPUT 2	83
FAA = STATUS INPUT	93
GDA = MODBUS RS485	97
GIA = PROCESS PARAMETER	100
GLA = SYSTEM PARAMETER	109
GNA = SENSOR DATA	110
JAA = SYSTEM	115
JCA = VERSION INFO	118

Function groups

000 = MAIN VALUES	13
040 = CONFIGURATION	14
042 = ADDITIONAL CONFIGURATION	17
200 = BASIC CONFIGURATION	29
202 = UNLOCKING/LOCKING	31
204 = OPERATION	32
220 = CONFIGURATION	33
222 = MULTIPLEX	35
240 = CONFIGURATION	37
242 = MULTIPLEX	39
260 = CONFIGURATION	41
262 = MULTIPLEX	43
300 = CONFIGURATION	46
304 = OPERATION	48
400 = CONFIGURATION	51
404 = OPERATION	60
408 = INFORMATION	61
420 = CONFIGURATION	62
430 = OPERATION	79
438 = INFORMATION	82
470 = CONFIGURATION	83
474 = OPERATION	87

478 = INFORMATION	88
500 = CONFIGURATION	93
504 = OPERATION	94
508 = INFORMATION	95
630 = CONFIGURATION	97
640 = CONFIGURATION	100
642 = EPD PARAMETER	102
646 = REFERENCE PARAMETER	104
648 = ADJUSTMENT	106
650 = PRESSURE CORRECTION	108
660 = CONFIGURATION	109
680 = CONFIGURATION	110
684 = FLOW COEFFICIENT	111
685 = DENSITY COEFFICIENT	112
686 = ADDITIONAL COEFFICIENT	113
800 = CONFIGURATION	115
804 = OPERATION	116
810 = DEVICE	118
820 = SENSOR	119
822 = AMPLIFIER	120
830 = I/O MODULE	121
834 = I/O SUBMODULE 2	122
836 = I/O SUBMODULE 3	122
838 = I/O SUBMODULE 4	122

Functions 0...

0000 = MASS FLOW	13
0001 = VOLUME FLOW	13
0004 = CORRECTED VOLUME FLOW	13
0005 = DENSITY	13
0006 = REFERENCE DENSITY	13
0008 = TEMPERATURE	13
0400 = UNIT MASS FLOW	14
0401 = UNIT MASS	14
0402 = UNIT VOLUME FLOW	15
0403 = UNIT VOLUME	15
0404 = UNIT CORRECTED VOLUME FLOW	16
0405 = UNIT CORRECTED VOLUME	16
0420 = UNIT DENSITY	17
0421 = UNIT REFERENCE DENSITY	17
0422 = UNIT TEMPERATURE	18
0424 = UNIT LENGTH	18
0426 = UNIT PRESSURE	18

1...

1002 = QS COMMISSION	19
1003 = QS PULSATING FLOW	19
1009 = QS COMMUNICATION	19
1009 = T DAT SAVE/LOAD	20

2...

2000 = LANGUAGE	29
2002 = DISPLAY DAMPING	30
2003 = CONTRAST LCD	30
2004 = BACKLIGHT	30
2020 = ACCESS CODE	31

2021 = DEFINE PRIVATE CODE	31
2022 = STATUS ACCESS	31
2023 = ACCESS CODE	31
2040 = TEST DISPLAY	32
2200 = ASSIGN	33
2201 = 100% VALUE	33
2202 = FORMAT	34
2220 = ASSIGN	35
2221 = 100% VALUE	35
2222 = FORMAT	36
2400 = ASSIGN	37
2401 = 100% VALUE	37
2402 = FORMAT	38
2403 = DISPLAY MODE	38
2420 = ASSIGN	39
2421 = 100% VALUE	39
2422 = FORMAT	40
2423 = DISPLAY MODE	40
2600 = ASSIGN	41
2601 = 100% VALUE	41
2602 = FORMAT	42
2603 = DISPLAY MODE	42
2620 = ASSIGN	43
2621 = 100% VALUE	43
2622 = FORMAT	44
2623 = DISPLAY MODE	44

3...

3000 = ASSIGN	46
3001 = UNIT TOTALIZER	46
3002 = TOTALIZER MODE	47
3003 = RESET TOTALIZER	47
3040 = SUM	48
3041 = OVERFLOW	48
3800 = RESET ALL TOTALIZERS	49
3801 = FAILSAFE MODE	49

4...

4000 = ASSIGN CURRENT OUTPUT	51
4001 = CURRENT SPAN	52
4002 = VALUE 0_4 mA	53
4003 = VALUE 20 mA	55
4004 = MEASURING MODE	55
4005 = TIME CONSTANT	58
4006 = FAILSAFE MODE	59
4040 = ACTUAL CURRENT	60
4041 = SIMULATION CURRENT	60
4042 = VALUE SIMULATION CURRENT	60
4080 = TERMINAL NUMBER	61
4200 = OPERATION MODE	62
4201 = ASSIGN FREQUENCY	63
4202 = START VALUE FREQUENCY	63
4203 = END VALUE FREQUENCY	63
4204 = VALUE f LOW	64
4205 = VALUE f HIGH	64
4206 = MEASURING MODE	66
4208 = TIME CONSTANT	69
4209 = FAILSAFE MODE	70
4301 = ACTUAL FREQUENCY	79

4302 = SIMULATION FREQUENCY	79
4303 = VALUE SIMULATION FREQUENCY	79
4322 = SIMULATION PULSE	80
4323 = VALUE SIMULATION PULSE	80
4341 = ACTUAL STATUS	81
4342 = SIMULATION SWITCH POINT	81
4343 = VALUE SIMULATION SWITCH POINT	81
4380 = TERMINAL NUMBER	82
4700 = ASSIGN RELAY	83
4701 = ON-VALUE	84
4702 = SWITCH-ON DELAY	84
4703 = OFF-VALUE	84
4704 = SWITCH-OFF DELAY	85
4705 = MEASURING MODE	85
4706 = TIME CONSTANT	86
4740 = ACTUAL STATUS RELAY	87
4741 = SIMULATION SWITCH POINT	87
4742 = VALUE SIMULATION SWITCH POINT	87
4780 = TERMINAL NUMBER	88

5...

5000 = ASSIGN STATUS INPUT	93
5001 = ACTIVE LEVEL	93
5002 = MINIMUM PULSE WIDTH	93
5040 = ACTUAL STATUS INPUT	94
5041 = SIMULATION STATUS INPUT	94
5042 = VALUE SIMULATION STATUS INPUT	94
5080 = TERMINAL NUMBER	95

6...

6300 = TAG NAME	97
6301 = FIELDBUS ADDRESS	97
6302 = BAUDRATE	97
6303 = TRANSMISSION MODE	97
6304 = PARITY	98
6305 = BYTE ORDER	98
6306 = DELAY TELEGRAM REPLY	98
6307 = WRITE PROTECTION	98
6308 = SCAN LIST REGISTER 1 to 16	99
6400 = ASSIGN LOW FLOW CUT OFF	100
6402 = ON-VALUE LOW FLOW CUT OFF	100
6403 = OFF-VALUE LOW FLOW CUT OFF	100
6404 = PRESSURE SHOCK SUPPRESSION	101
6420 = EMPTY PIPE DETECTION	102
6423 = EPD VALUE LOW	102
6424 = EPD VALUE HIGH	102
6425 = EPD RESPONSE TIME	102
6426 = EPD EXC.CURR	103
6460 = CORRECTED VOLUME CALCULATION	104
6461 = FIXED REFERENCE DENSITY	104
6462 = EXPANSION COEFFICIENT	104
6463 = EXPANSION COEFFICIENT SQUARE	104
6464 = REFERENCE TEMPERATURE	105
6480 = ZEROPOINT ADJUST	106
6482 = DENSITY ADJUST MODE	106
6483 = DENSITY SETPOINT 1	106
6484 = MEASURE FLUID 1	106
6485 = DENSITY SETPOINT 2	107
6486 = MEASURE FLUID 2	107

6487 = DENSITY ADJUST	107
6488 = RESTORE ORIGINAL.....	107
6500 = PRESSURE MODE	108
6501 = PRESSURE	108
6600 = INSTALLATION DIRECTION SENSOR	109
6602 = DENSITY DAMPING	109
6603 = FLOW DAMPING	109
6605 = POSITIVE ZERO RETURN	109
6800 = K-FACTOR	110
6803 = ZERO POINT	110
6804 = NOMINAL DIAMETER	110
6840 = TEMPERATURE COEFFICIENT KM.....	111
6841 = TEMPERATURE COEFFICIENT KM2.....	111
6842 = TEMPERATURE COEFFICIENT KT	111
6843 = CALIBRATION COEFFICIENT KD 1	111
6844 = CALIBRATION COEFFICIENT KD 2	111
6850 = DENSITY COEFFICIENT C0.....	112
6851 = DENSITY COEFFICIENT C1.....	112
6852 = DENSITY COEFFICIENT C2.....	112
6853 = DENSITY COEFFICIENT C3.....	112
6854 = DENSITY COEFFICIENT C4.....	112
6855 = DENSITY COEFFICIENT C5.....	112
6860 = MIN. TEMPERATURE MEASURED	113
6861 = MAX. TEMPERATURE MEASURED	113
6862 = MIN. TEMPERATURE CARRIER TUBE	113
6863 = MAX. TEMPERATURE CARRIER TUBE	113

8...	
8005 = ALARM DELAY	115
8007 = STORAGE	115
8040 = ACTUAL SYSTEM CONDITION	116
8041 = PREVIOUS SYSTEM CONDITION	116
8042 = SIMULATION FAILSAFE MODE.....	116
8043 = SIMULATION MEASURAND.....	117
8044 = VALUE SIMULATION MEASURAND	117
8046 = SYSTEM RESET.....	117
8048 = OPERATION HOURS	117
8100 = DEVICE SOFTWARE	118
8200 = SERIAL NUMBER.....	119
8201 = SENSOR TYPE.....	119
8205 = SW-REV. NUMBER S-DAT	119
8222 = SW-REV. NUMBER AMPLIFIER.....	120
8225 = SW-REV. NUMBER T-DAT	120
8226 = LANGUAGE GROUP	120
8300 = I/O MODULE TYPE	121
8303 = SW-REV. NO. I/O MODULE	121
8340 = SUB I/O MODULE TYPE 2	122
8343 = SW-REV NO. SUB I/O MODULE TYPE 2	122
8360 = SUB I/O MODULE TYPE 3	122
8363 = SW-REV NO. SUB I/O MODULE TYPE 3	122
8380 = SUB I/O MODULE TYPE 4	122
8383 = SW-REV NO. SUB I/O MODULE TYPE 4	122

Index

A

Access type	10
Active level	93
Actual	
Current	60
Frequency	79
Actual status	
Relay output	87
Status	81
Status input	94
Actual system condition	116
Additional coefficient	113
Additional configuration	17
Additional line	
Assign	37
Configuration	37
Display mode	38
Format	38
Multiplex	39
Assign	39
Display mode	40
Format	40
100% Value	39
100% Value	37
Alarm delay	115
Amplifier (version info)	120
Assign	
Additional line	37
Additional line (Multiplex)	39
Frequency (pulse/freq. output)	63
Information line	41
Information line (Multiplex)	43
Low flow cut off	100
Main line	33
Main line (Multiplex)	35
Pulse (pulse/freq. output)	71
Relay output	83
Status input	93
Status (pulse/freq. output)	76
Totalizer	46
Assign current output	51

B

Backlight	30
Basic configuration (user interface)	29
Basic functions	96
Baudrate	97
Block	
Basic functions	96
Inputs	92
Measured variables	12
Outputs	50
Quick Setup	19
Supervision	114
Totalizer	45
User interface	28

Byte order	98
------------------	----

C

Calibration coefficient	
KD1	111
KD2	111
Code	
Access	31
Access counter	31
Configuration	
Additional line	37
Current output	51
Information line	41
Main line	33
MODBUS	
RS485	97
Process parameter	100
Pulse/frequency output	62
Relay output	83
Sensor data	110
Status input	93
System	115
System parameter	109
System units	14
Totalizer	46
Contrast LCD	30
Control	
Basic configuration	29
Operation	32
Unlocking/locking	31
Corrected Volume calculation	104
Corrected volume flow	13
Current output	
Actual current	60
Assign	51
Configuration	51
Current span	52
Failsafe mode	59
Information	61
Measuring mode	55
Operation	60
Simulation current	60
Terminal number	61
Time constant	58
Value simulation current	60
Value 0 to 4 mA	53
Value 20 mA	55
Current span	52

D

Damping	
Density	109
Display	30
Data type	10
Define private code	31
Delay resp. tele.	98

Density	13
Density adjustment	107
Density coefficient	
C0	112
C1	112
C2	112
C3	112
C4	112
C5	112
Device software	118
Display lines of local operation	10
Display mode	
Additional line	38
Additional line (Multiplex)	40
Information line	42
Information line (Multiplex)	44
E	
EEPROM	10
Empty pipe detection (EPD)	102
End value frequency	63
EPD	
Empty pipe detection	102
Exciting current	103
Parameter	102
Response time	102
Value high	102
Value low	102
Expansion coefficient	104
Square (reference parameter)	104
F	
Factory settings	
Full scale value	123
Low flow cut off	123
Pulse value	123
Failsafe mode	
Current span	59
Frequency (pulse/freq. output)	70
Pulse (pulse/freq. output)	75
Totalizer	49
Fieldbus address	97
Fixed	
Reference density	104
Float	10
Flow damping	109
Format	
Additional line	38
Additional line (Multiplex)	40
Information line	42
Information line (Multiplex)	44
Main line	34
Main line (Multiplex)	36
Function group	
Additional coefficient	113
Additional configuration	17
Adjustment	106
Amplifier	120
Basic configuration (user interface)	29

Configuration	
Additional line	37
Current output	51
Information line	41
Main line	33
MODBUS	
RS485	97
Process parameter	100
Pulse/freq. output	62
Relay output	83
Sensor data	110
Status input	93
System	115
System parameter	109
System units	14
Totalizer	46
Density coefficient	112
Device	118
EPD parameter	102
Flow coefficient	111
Information	
Current output	61
Pulse/Frequency output	82
Relay output	88
Status input	95
Input/Output	122
I/O Module	121
Main values	13
Multiplex	
Additional line	39
Information line	43
Main line	35
Operation	
Current output	60
Pulse/frequency output	79
Relay output	87
Status input	94
System	116
Totalizer	48
Operation (user interface)	32
Pressure correction	108
Reference parameter	104
Sensor	118, 119
Unlocking/locking (display)	31
Function matrix	
Codes identifying	9
General layout	8
Overview	11
G	
Group	
Additional line	37
Control (user interface)	29
Current output	51
Handling Totalizer	49
Information line	41
Main line	33
Measuring values	13
MODBUS	

RS485	97	Multiplex	35
Process parameter	100	Assign	35
Pulse/frequency output	62	Format	36
Relay output	83	100% Value	35
Sensor data	110	100% Value	33
Status input	93	Main values	13
System	115	Mapping reg. 1 to 16	99
System parameter	109	Mass flow	13
System units	14	Maximum	
Version Info	118	Medium temperature	113
H		Temperature carrier tube	113
Handling Totalizer	49	Max. writes	10
I		Measure	
Illustration of function description	10	Fluid 1	106
Information		Fluid 2	107
Current output	61	Measure fluid 1	106
Pulse/frequency output	82	Measure fluid 2	107
Relay output	88	Measured variables	12
Status input	95	Measuring mode	
Information line		Current span	55
Assign	41	Frequency (pulse/freq. output)	66
Configuration	41	Pulse (pulse/freq. output)	72
Display mode	42	Relay output	85
Format	42	Status (pulse/freq. output)	78
Multiplex	43	Measuring values	13
Assign	43	Main values	13
Display mode	44	Minimal	
Format	44	Temperature carrier tube	113
100% Value	43	Minimum	
100% Value	41	Medium temperature	113
Inputs	92	Minimum pulse width (status input)	93
Input/output 2 to 4	122	MODBUS register	10
Installation direction sensor	109	MODBUS	
Integer	10	RS485	97
I/O Module	121	Mode	
I/O module type	121	Data transfer	97
I/O submodule		Density adjustment	106
Type 2	122	Multiplex	
Type 3	122	Additional line	39
Type 4	122	Information line	43
K		Main line	35
K-Factor	110	N	
L		Nominal diameter	110
Language	29	O	
Language group	120	Off value	
Local operation (display lines)	10	Low flow cut off	100
Low flow cut off		Pulse/freq. output	77
Assign	100	Relay output	84
Off value	100	On value	
On value	100	Low flow cut off	100
M		Pulse/freq. output	76
Main line		Relay output	84
Assign	33	Operation	
Configuration	33	Current output	60
Format	34	Pulse/frequency output	79

System	116	Measuring mode	78
Totalizer	48	Off value	77
User interface	32	On value	76
Operation hours	117	Simulation	81
Output signal		Switch-off delay	77
Frequency (pulse/freq. output)	67	Switch-on delay	77
Pulse (pulse/freq. output)	73	Time constant	78
Outputs	50	Value simulation	81
Overflow	48	Terminal number	82
P			
Parity	98		
Positive zero return	109	Quick Setup	19
Pressure	108	Commissioning	19
Correction	108	Communication	19
Mode	108	Gas measurement	19
Pressure shock suppression	101	Pulsating flow	19
Previous system condition	116		
Process parameter		R	
Adjustment	106	Read	10
Configuration	100	Reference density	13
EPD parameter	102	Fixed	104
Pressure correction	108	Reference Temperature	105
Reference parameter	104	Relay output	
Pulse		Actual status	87
Value	71	Assign	83
Width	71, 72	Configuration	83
Pulse/frequency output		Flow direction	89
Configuration	62	General	89
Information	82	Information	88
Operation	79	Limit value	89
Pulse/freq. output		Measuring mode	85
Frequency		Off value	84
Actual	79	On value	84
Assign frequency	63	Operation	87
End value frequency	63	Simulation switch point	87
Failsafe level	70	Switching behavior	90
Failsafe mode	70	Switch-off delay	85
Measuring mode	66	Switch-on delay	84
Output signal	67	Terminal number	88
Simulation	79	Time constant	86
Start value frequency	63	Value simulation switch point	87
Time constant	69		
Value F Low	64	Reset	
Value simulation	79	All totalizers	49
Value-f high	64	System	117
Operation mode	62	Totalizer	47
Pulse		Restore original	107
Assign pulse	71		
Failsafe mode	75	S	
Measuring mode	72	Sensor data	
Output signal	73	Additional coefficient	113
Pulse value	71	Configuration	110
Pulse Width	71, 72	Density coefficient	112
Simulation	80	Flow coefficient	111
Value simulation	80	Sensor type	119
Status		Sensor (Version info)	118
Actual	81	Serial number	119
Assign status	76	Setpoint	
		Density 1	106
		Density 2	107
		Simulation	

Current	60	KM2	111
Failsafe mode	116	KT	111
Frequency	79	Terminal number	
Measured variable	117	Current output	61
Pulse	80	Pulse/freq. output	82
Relay output	87	Relay output	88
Status input	94	Status input	95
Switch point	81	Test display	32
Start value frequency	63	Time constant	
Status access	31	Current span	58
Status input		Frequency (pulse/freq. output)	69
Active level	93	Relay output	86
Actual status	94	Status (pulse/freq. output)	78
Assign	93	Totalizer	45
Configuration	93	Assign	46
Information	95	Configuration	46
Minimum pulse width	93	Failsafe mode	49
Operation	94	Operation	48
Simulation	94	Overflow	48
Terminal number	95	Reset all totalizers	49
Value simulation	94	Reset totalizer	47
Storage	115	Sum	48
String	10	Totalizer Mode	47
Sum	48	Unit	46
Supervision	114	Totalizer Mode	47
SW revision number		U	
Amplifier	120	Unit	
I/O Module	121	Corrected volume	16
I/O submodule		Corrected volume flow	16
Type 2	122	Density	17
Type 3	122	Length	18
Type 4	122	Mass	14
S-DAT	119	Mass flow	14
T-DAT	120	Reference density	17
Switching behavior of the relay output	90	Temperature	18
Switch-off delay		Totalizer	46
Pulse/freq. output	77	Volume	15
Relay output	85	Volume flow	15
Switch-on delay		Unlocking/locking (display)	31
Pulse/freq. output	77	User interface	28
Relay output	84	V	
System		Value	
Configuration	115	EPD value high	102
Operation	116	EPD value low	102
System condition		F low	64
Actual	116	Failsafe level	70
Previous	116	Simulation current	60
System parameter	109	Simulation frequency	79
System reset	117	Simulation measurand	117
System units		Simulation Pulse	80
Additional configuration	17	Simulation relay output	87
Configuration	14	Simulation status input	94
T		Simulation switch point	81
Tag Name	97	0 to 4 mA	53
T-DAT Save/Load	20	20 mA	55
Temperature	13	Value F high	64
Temperature coefficient		Version Info	
KM	111		

Amplifier	120
Input/output 1 to 4	122
I/O Module	121
Sensor	118
Volume flow	13

W

Write	10
Write protection	98
Writes (max.)	10

Z

Zero point	110
Zero point adjustment	106

Numbers

100% Value

Additional line	37
Additional line (Multiplex)	39
Information line	41
Information line (Multiplex)	43
Main line	33
Main line (Multiplex)	35

www.addresses.endress.com
