
Products

01.02.zz (Device firmware)

Operating Instructions Proline Promass A 100 EtherNet/IP

Coriolis flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Document information	6	6.2	Mounting the measuring device	
1.1 1.2	Document function	6		6.2.1 Required tools	26
	1.2.1 Safety symbols			6.2.4 Turning the display module	
	1.2.2 Electrical symbols		6.3	Post-installation check	
	information	7	7	Electrical connection	29
	1.2.5 Symbols in graphics		7.1	Connection conditions	
1.3	Documentation	7		7.1.1 Required tools	
	1.3.1 Standard documentation	8		7.1.2 Requirements for connecting cable	
	documentation	8		7.1.3 Terminal assignment	
1.4	Registered trademarks			7.1.4 Pin assignment, device plug	
			7.2	Connecting the measuring device	
2	Basic safety instructions	9		7.2.1 Connecting the transmitter	
	•			7.2.2 Ensuring potential equalization	
2.1 2.2	Requirements for the personnel	9 9	7.3	Special connection instructions	
2.3	Workplace safety	-		7.3.1 Connection examples	
2.4		10	7.4	Hardware settings	
2.5		10	7.5	7.4.1 Setting the device address Ensuring the degree of protection	
2.6		10	7.5	Post-connection check	
_			7.0	1 ost connection check	22
3	Product description		8	Operation options	36
3.1	Product design	12	8.1	Overview of operation options	36
	communication type	12	8.2	Structure and function of the operating	
	communication type	12		menu	37
4	Incoming acceptance and product			8.2.1 Structure of the operating menu 8.2.2 Operating philosophy	37 38
1			8.3	8.2.2 Operating philosophy Access to the operating menu via the Web	20
		13	0.5		38
4.1	3 1	13		8.3.1 Function range	38
4.2	Product identification			8.3.2 Prerequisites	39
	4.2.1 Transmitter nameplate	14 15		8.3.3 Establishing a connection	40
	4.2.2 Sensor nameplate			8.3.4 Logging on	
	1.2.5 Symbols on measuring device	10		8.3.5 User interface	
5	Storage and transport 1	17		8.3.6 Disabling the Web server	
	_		8.4	Access to the operating menu via the	47
5.1 5.2	Storage conditions	17 17	0.1	operating tool	43
٧.٧	5.2.1 Measuring devices without lifting	1/		8.4.1 Connecting the operating tool	43
	3	17		8.4.2 FieldCare	44
	5	18			
	5.2.3 Transporting with a fork lift	18	9	System integration	46
5.3	Packaging disposal	18	9.1	Overview of device description files	46
				9.1.1 Current version data for the device	46
б	Installation 1	19		9.1.2 Operating tools	
6.1	Installation conditions	19	9.2	Overview of system files	46
	6.1.1 Mounting position	19	9.3	Integrating the measuring device in the	1. 6
	6.1.2 Requirements from environment and		9.4	system	46 47
	<u> </u>	21). 4	9.4.1 Block model	47 47
	6.1.3 Special mounting instructions	23		9.4.2 Input and output groups	47

10	Commissioning	51	12.6	Diagnostic information via communication	0.4
10.1	Function check	51		interface	
10.2	Configuring the device address via software	51	10.7	12.6.1 Reading out diagnostic information	
	10.2.1 Ethernet network and Web server	51	12.7	Adapting the diagnostic information	
10.3	Setting the operating language		12.0	12.7.1 Adapting the diagnostic behavior	
10.4	Configuring the measuring device		12.8	Overview of diagnostic information	
	10.4.1 Defining the tag name			Pending diagnostic events	
	10.4.2 Setting the system units	52		Diagnostic list	
	10.4.3 Selecting and setting the medium	54	12.11	Event logbook	
	10.4.4 Configuring the communication			12.11.1 Event history	
	interface	55		12.11.2 Filtering the event logbook 12.11.3 Overview of information events	
	10.4.5 Configuring the low flow cut off	56	12 12	Resetting the measuring device	
	10.4.6 Configuring the partial filled pipe		12.12	12.12.1 Function scope of "Device reset"	07
	detection	57		parameter	88
10.5	Advanced settings	58	12.13	Device information	
	10.5.1 Calculated values			Firmware history	
	10.5.2 Carrying out a sensor adjustment				, ,
	10.5.3 Configuring the totalizer	60	13	Maintenance	Ω1
	10.5.4 Carrying out additional display				
	configurations		13.1	Maintenance tasks	
10.6	Simulation	65		13.1.1 Exterior cleaning	
10.7	Protecting settings from unauthorized		40.0	13.1.2 Interior cleaning	
	access		13.2	Measuring and test equipment	
	10.7.1 Write protection via access code	00	13.3	Endress+Hauser services	91
	10.7.2 Write protection via write protection switch	67			
	Switch	07	14	Repair	92
11	Operation	60	14.1	General notes	
	-	00	14.2	Spare parts	
11.1	Read out and modify current Ethernet		14.3	Endress+Hauser services	
	settings		14.4	Return	
11.2	Reading device locking status		14.5	Disposal	92
11.3	Adjusting the operating language			14.5.1 Removing the measuring device	
11.4	Configuring the display			14.5.2 Disposing of the measuring device	93
11.5	Reading measured values				
	11.5.1 Process variables		15	Accessories	94
	11.5.2 Totalizer		15.1	Device-specific accessories	94
11.6	Adapting the measuring device to the process	/1		15.1.1 For the sensor	
11.0	conditions	71	15.2	Service-specific accessories	
11.7	Performing a totalizer reset	71	15.3	System components	
11.,	refromming a cottanger resection.	, 1			
12	Diagnostics and troubleshooting	73	16	Technical data	96
12.1	General troubleshooting	73	16.1	Application	96
12.2	Diagnostic information via light emitting	, ,	16.2	Function and system design	96
	diodes	75	16.3	Input	96
	12.2.1 Transmitter		16.4	Output	97
12.3	Diagnostic information on local display	I	16.5	Power supply	100
	12.3.1 Diagnostic message	76	16.6		101
	12.3.2 Calling up remedial measures	78	16.7		104
12.4	Diagnostic information in the Web browser	79			104
	12.4.1 Diagnostic options	79			105
	12.4.2 Calling up remedy information	80			108
12.5	Diagnostic information in FieldCare	80		1 ,	110
	12.5.1 Diagnostic options			11	113
	12.5.2 Calling up remedy information	81			114 115
					l 15 l 15
			10.13	Documentation	LID

17	Apper	ndix	117
17.1		w of the operating menu	
	17.1.1	"Operation" menu	117
	17.1.2	"Setup" menu	118
	17.1.3	"Diagnostics" menu	122
	17.1.4	"Expert" menu	126
Inde	x	• • • • • • • • • • • • • • • • • • • •	143

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning
▲ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
▲ WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
▲ CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	Direct current	~	Alternating current
≂	Direct current and alternating current	Ground connection A grounded terminal which, as the operator is concerned, is grounded via a grounding systematical experiments.	
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.	♦	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Tool symbols

Symbol	Meaning
0 6	Allen key
Ó	Open-ended wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning
\checkmark	Permitted Procedures, processes or actions that are permitted.
✓	Preferred Procedures, processes or actions that are preferred.
×	Forbidden Procedures, processes or actions that are forbidden.
i	Tip Indicates additional information.
	Reference to documentation
A	Reference to page
	Reference to graphic
1. , 2. , 3	Series of steps
L-	Result of a sequence of actions
?	Help in the event of a problem
	Visual inspection

1.2.5 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3,	Item numbers	1. , 2. , 3	Series of steps
A, B, C,	Views	A-A, B-B, C-C,	Sections
EX	Hazardous area	×	Safe area (non-hazardous area)
≋➡	Flow direction		

1.3 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
 - The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
- For a detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

Document type	Purpose and content of the document	
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.	
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.	

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

EtherNet/IPTM

Trademark of ODVA, Inc.

Microsoft®

Registered trademark of the Microsoft Corporation, Redmond, Washington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

SWAGELOK®

Registered trademark of Swagelok & Co., Solon, USA

Applicator®, FieldCare®, Field XpertTM, HistoROM®, Heartbeat TechnologyTM Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task
- ► Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ► Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ► Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section $(\rightarrow \ \)$ 7).

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the measuring tube due to corrosive or abrasive fluids.

Housing breakage due to mechanical overload possible!

- ▶ Verify the compatibility of the process fluid with the measuring tube material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

The external surface temperature of the housing can increase by max. $20 \, \text{K}$ due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

► For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.


3 Product description

The device consists of a transmitter and a sensor.

One device version is available: compact version - transmitter and sensor form a mechanical unit.

3.1 Product design


3.1.1 Device version with EtherNet/IP communication type



- $\blacksquare 1$ Important components of a measuring device
- 1 Sensor
- 2 Transmitter housing
- 3 Main electronics module
- 4 Transmitter housing cover
- 5 Transmitter housing cover (version for optional onsite display)
- 6 Onsite display (optional)
- 7 Main electronics module (with bracket for optional onsite display)

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
 - Depending on the device version, the CD-ROM might not be part of the delivery!
 The Technical Documentation is available via the Internet or via the Endress+Hauser Operations App, see the "Product identification" section (→ ≅ 14).

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" (\rightarrow 🖺 8) and "Supplementary device-dependent documentation" (\rightarrow 🖺 8)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.


4.2.1 Transmitter nameplate



■ 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Permitted ambient temperature (T_a)
- 8 Degree of protection
- 9 2-D matrix code
- 10 Document number of safety-related supplementary documentation
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Firmware version (FW)

4.2.2 Sensor nameplate



■ 3 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- Serial number (ser. no.)
- Extended order code (ext. ord. cd.)
- Flange nominal diameter/nominal pressure
- *Test pressure of the sensor*
- Nominal diameter of sensor
- Sensor-specific data: e.g. pressure range of secondary containment, wide-range density specification (special density calibration)
- Material of measuring tube and manifold
- Medium temperature range 11
- 12 Degree of protection
- Approval information for explosion protection and Pressure Equipment Directive 13
- Permitted ambient temperature (T_a)
- Document number of safety-related supplementary documentation
- CE mark, C-Tick
- 17 Flow direction
- Manufacturing date: year-month 18
- 2-D matrix code

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE

4.2.3 Symbols on measuring device

Symbol	Meaning
Δ	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
(i	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport


5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections.
 They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Storage temperature: -40 to +80 °C (-40 to +176 °F), Order Code "Test, Certificate", Option JM: -50 to +60 °C (-58 to +140 °F), preferably at +20 °C (+68 °F)
- Store in a dry and dust-free place.
- Do not store outdoors.

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0015604

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

A WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0015606

5.2.2 Measuring devices with lifting lugs

A CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ► The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - $\,$ Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.

or

- Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

Installation 6

6.1 Installation conditions


No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

6.1.1 Mounting position

Mounting location


To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:

- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.



Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



- € 4 Installation in a down pipe (e.g. for batching applications)
- Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- Valve
- Batching tank

DN		Ø orifice plate, pipe restriction	
[mm]	[in]	[mm]	[in]
1	1/24	0.8	0.03
2	1/12	1.5	0.06
4	1/8	3.0	0.12

Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Recommendation		
A	Vertical orientation	A0015991	₩ ₩
В	Horizontal orientation, transmitter head up	A0015589	✓ ✓ ¹) Exception:
С	Horizontal orientation, transmitter head down	A0015590	✓ ✓ ²⁾ Exception:
D	Horizontal orientation, transmitter head at side	A0015592	×

- Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

Inlet and outlet runs

No special precautions need to be taken for fittings which create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs ($\Rightarrow \triangleq 21$).



Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process

Ambient temperature range

Measuring device	Non-Ex	-40 to +60 °C (-40 to +140 °F)
	Ex na, NI version	-40 to +60 °C (-40 to +140 °F)
	Ex ia, IS version	 −40 to +60 °C (−40 to +140 °F) −50 to +60 °C (−58 to +140 °F) (Order code for "Test, certificate", option JM)
Local display		-20 to $+60$ °C (-4 to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.

► If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.

System pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- **E**nsure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



A001559


Thermal insulation

In the case of some fluids, it is important that the heat radiated from the sensor to the transmitter is kept to a minimum. A wide range of materials can be used for the required insulation.

NOTICE


Electronics overheating on account of thermal insulation!

► Observe maximum permitted insulation height of the transmitter neck so that the transmitter head is completely free.



- a Minimum distance to insulation
- t maximum Insulation thickness

The minimum distance between the transmitter housing and the insulation is 10 mm (0.39 in) so that the transmitter head remains completely exposed.



 \blacksquare 5 Maximum recommended insulation thickness depending on the temperature of the medium and the ambient temperature

t Insulation thickness $T_{m} \qquad \text{Medium temperature} \\ T_{40(104)} \qquad \text{Maximum recommended insulation thickness at an ambient temperature of T_{a} = 40 °C (104 °F)$} \\ T_{60(140)} \qquad \text{Maximum recommended insulation thickness at an ambient temperature of T_{a} = 60 °C (140 °F)$} \\$

NOTICE

Danger of overheating with insulation

▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 $^{\circ}$ C (176 $^{\circ}$ F)

NOTICE

The insulation can also be thicker than the maximum recommended insulation thickness.

Prerequisite:

- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

22

Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter (\rightarrow 🗎 21).
- ► Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE

Danger of overheating when heating

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 $^{\circ}$ C (176 $^{\circ}$ F)
- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

Using an electrical trace heating system

If heating is regulated via phase angle control or pulse packages, magnetic fields can affect the measured values (= for values that are greater than the values approved by the EN standard (sine 30 A/m)).

For this reason, the sensor must be magnetically shielded: the housing can be shielded with tin plates or electric sheets without a privileged direction (e.g. V330-35A).

The sheet must have the following properties:

- Relative magnetic permeability µr ≥ 300
- Plate thickness $d \ge 0.35$ mm ($d \ge 0.014$ in)

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.


6.1.3 Special mounting instructions

Rupture disk

Make sure that the function and operation of the rupture disk is not impeded through the installation of the device. The position of the rupture disk is indicated on a sticker beside it. For additional information that is relevant to the process ($\rightarrow \implies 106$).

The existing connecting nozzles are not intended for the purpose of rinsing or pressure monitoring, but instead serve as the mounting location for the rupture disk.

However, by means of the connection available on the rupture disk holder, the escaping fluid (in case of a disk rupture) can be collected by connecting a suitable relief system.



A0019676

- 1 Rupture disk label
- 2 Rupture disk with 1/2" NPT internal thread with 1" width across flat
- 3 Transport protection

Dimensions in SI units

DN	A	В	С	D	E	F	G
[mm]	[mm]	[in]	[in]	[mm]	[mm]	[mm]	[mm]
1	Approx. 42	AF 1	½ NPT	77.0	70.0	47.0	178
2	Approx. 42	AF 1	½ NPT	77.0	70.0	47.0	260
4	Approx. 42	AF 1	½ NPT	83.0	83.0	59.5	385

Dimensions in US units

DN	A	В	С	D	E	F	G
[in]	[in]	[in]	[in]	[in]	[in]	[in]	[in]
1/24	Approx. 1.65	AF 1	½ NPT	3.0	2.8	1.85	7.01
1/12	Approx. 1.65	AF 1	½ NPT	3.0	2.8	1.85	10.24
1/8	Approx. 1.65	AF 1	½ NPT	3.3	3.2	2.34	15.16

▲ WARNING

Limited functional reliability of the rupture disk.

Danger to persons from escaping fluids!

- ► Do not remove the rupture disk.
- ▶ When using a rupture disk, do not use a heating jacket.
- Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- ► Take precautions to prevent damage and danger to persons if the rupture disk is actuated.
- ▶ Observe information on the rupture disk sticker.

Wall mounting

A WARNING

Incorrect sensor mounting


Risk of injury if measuring tube breaks

- ▶ The sensor should never be installed in a pipe in a way that it is freely suspended
- ▶ Using the base plate, mount the sensor directly on the floor, wall or ceiling.
- ► Support the sensor on a securely mounted support base (e.g. angle bracket).

The following mounting versions are recommended for the installation.

Vertical

- Mounted directly on a wall using the base plate, or
- Device supported on an angle bracket mounted on the wall



A0019631

Horizontal


Device standing on a solid support base



A0019632

Post retainer

The post retainer mounting kit is used to secure the device to a pipe or post (order code for "Accessories", option PR).



A0019746

- 6 Post retainer mounting kit
- 1 8 x hexagonal nut $M8 \times 0.8$
- 2 4 x threaded bolt $M8 \times 150$
- 3 1 x post retaining plate
- 4 1 x post securing plate
- 5 4 x spring washer M8
- $4 \times hexagon bolt M6 \times 20$
- 7 4 x spring washer M6
- 8 4 x hexagonal nut $M6 \times 0.8$

Zero point adjustment

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

Zero point adjustment is performed via the **Zero point adjustment control** parameter $(\rightarrow \triangleq 60)$.

6.2 Mounting the measuring device

6.2.1 Required tools

For sensor

For flanges and other process connections: Corresponding mounting tools

6.2.2 Preparing the measuring device


- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the measuring device

A WARNING

Danger due to improper process sealing!

- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the gaskets are clean and undamaged.
- ► Install the gaskets correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.
- 2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.




Δ0013964

6.2.4 Turning the display module

The local display is only available with the following device version: Order code for "Display; Operation", option **B**: 4-line; lit, via communication


The display module can be turned to optimize display readability.

Aluminum housing version, AlSi10Mg, coated



A0023192

Compact and ultra-compact housing version, hygienic, stainless



A0023195

6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring device conform to the measuring point specifications? For example: Process temperature (→ 🖺 105) Process pressure (refer to the chapter on "Pressure-temperature ratings" of the "Technical Information" document) Ambient temperature (→ 🖺 21) Measuring range (→ 🖺 96)	
Has the correct orientation for the sensor been selected? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids)	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ($\Rightarrow \stackrel{\text{\tiny le}}{=} 20$)?	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

7 Electrical connection



The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp (on aluminum housing): Allen screw3 mm
- For securing screw (for stainless steel housing): open-ended wrench 8 mm
- Wire stripper
- When using stranded cables: crimping tool for ferrule

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40 °C (-40 °F) to +80 °C (+176 °F)
- Minimum requirement: cable temperature range ≥ ambient temperature +20 K

Power supply cable

Standard installation cable is sufficient.

Signal cable

EtherNet/IP

The standard ANSI/TIA/EIA-568-B.2 Annex specifies CAT 5 as the minimum category for a cable used for EtherNet/IP. CAT 5e and CAT 6 are recommended.

For more information on planning and installing EtherNet/IP networks, please refer to the "Media Planning and Installation Manual. EtherNet/IP" of ODVA Organization.

Cable diameter

- Cable glands supplied:
 M20 × 1.5 with cable Φ6 to 12 mm (0.24 to 0.47 in)
- Spring terminals:
 Wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

7.1.3 Terminal assignment

Transmitter

EtherNet/IP connection version


Order code for "Output", option ${\bf N}$

Depending on the housing version, the transmitters can be ordered with terminals or device plugs.

Ouden and a few	Connection me	thods available	Descible entions for order sade	
Order code for "Housing"	Output	Power supply	Possible options for order code "Electrical connection"	
Options A, B	Device plugs (→ 🖺 31)	Terminals	■ Option L : plug M12x1 + thread NPT ½" ■ Option N : plug M12x1 + coupling M20 ■ Option P : plug M12x1 + thread G ½" ■ Option U : plug M12x1 + thread M20	
Options A, B, C	Device plugs (→ 🖺 31)	Device plugs (→ 🖺 31)	Option Q : 2 x plug M12x1	

Order code for "Housing":

- Option **A**: compact, coated aluminum
- Option **B**: compact, hygienic, stainless
- Option **C** ultra-compact, hygienic, stainless



A001705


- 7 EtherNet/IP terminal assignment
- 1 Power supply: DC 24 V
- 2 EtherNet/IP

	Terminal number				
Order code for "Output"	Power supply		Output		
	2 (L-)	1 (L+)	Device plug M12x1		
Option N	DC 2	24 V	EtherNet/IP		
Order code for "Output": Option N : EtherNet/IP					

7.1.4 Pin assignment, device plug

EtherNet/IP

Device plug for supply voltage (device side)



Device plug for signal transmission (device side)

2	Pin		Assignment
	1	+	Tx
1 3	2	+	Rx
	3	-	Tx
	4	-	Rx
4 A0016812	Cod	ling	Plug/socket
	I)	Socket

7.1.5 Preparing the measuring device

- 1. Remove dummy plug if present.
- 2. **NOTICE!** Insufficient sealing of the housing! Operational reliability of the measuring device could be compromised. Use suitable cable glands corresponding to the degree of protection.

If measuring device is delivered without cable glands:

Provide suitable cable gland for corresponding connecting cable ($\rightarrow \triangleq 29$).

3. If measuring device is delivered with cable glands: Observe cable specification $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \)$.

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- ► For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the transmitter

The connection of the transmitter depends on the following order codes:


- Housing version: compact or ultra-compact
- Connection version: device plug or terminals



Housing versions and connection versions

- A Housing version: compact, aluminum coated
- B Housing version: compact hygienic, stainless
- 1 Cable entry or device plug for signal transmission
- 2 Cable entry or device plug for supply voltage
- C Housing version: ultra-compact, hygienic, stainless:
- 3 Device plug for signal transmission
- 4 Device plug for supply voltage

₽8



■ 9 Device versions with connection examples

- 1 Cable
- 2 Device plug for signal transmission
- 3 Device plug for supply voltage

For device version with device plug: follow step 6 only.

- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary $(\rightarrow \implies 111)$.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the cable in accordance with the terminal assignment or the device plug pin assignment .
- 6. Depending on the device version, tighten the cable glands or plug in the device plug and tighten .
- 7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the removal procedure to reassemble the transmitter.

7.2.2 Ensuring potential equalization

Requirements


No special measures for potential equalization are required.

For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

7.3 Special connection instructions

7.3.1 Connection examples

EtherNet/IP



■ 10 Connection example for EtherNet/IP

- 1 Control system (e.g. PLC)
- 2 Ethernet switch
- 3 Observe cable specifications (→ \(\bigsip 29 \))
- 4 Device plugs
- 5 Transmitter

7.4 Hardware settings

7.4.1 Setting the device address

EtherNet/IP

The IP address of the measuring device can be configured for the network via DIP switches.


Addressing data

IP address and configuration options							
1st octet	2nd octet	3rd octet	4th octet				
192.	168.	1.	XXX				
	\downarrow		\				
Can only be	configured via software	e addressing	Can be configured via software addressing and hardware addressing				

IP address range	1 to 254 (4th octet)
IP address broadcast	255
Addressing mode ex works	Software addressing; all DIP switches for hardware addressing are set to OFF.
IP address ex works	DHCP server active

For device addressing via software ($\rightarrow \equiv 51$)

Setting the address




- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary $(\rightarrow \blacksquare 111)$.
- 3. Set the desired IP address using the corresponding DIP switches on the I/O electronics module.
 - ► Hardware addressing with the configured IP address is enabled after 10 s.
- 4. Reverse the removal procedure to reassemble the transmitter.

7.5 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
- 2. Tighten all housing screws and screw covers.
- 3. Firmly tighten the cable glands.
- 4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A001396


5. Insert dummy plugs into unused cable entries.

7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables comply with the requirements (→ 🖺 29)?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
Depending on the device version: are all the device plugs firmly tightened (→ 🖺 32)?	
Does the supply voltage match the specifications on the transmitter nameplate ?	
Is the terminal assignment or the pin assignment of the device plug correct?	
If supply voltage is present, is the power LED on the electronics module of the transmitter lit green $(\rightarrow \ \ \ \ \ \ \ \ \)$?	
Depending on the device version, is the securing clamp or fixing screw firmly tightened?	

8 Operation options

8.1 Overview of operation options



A00177


- Computer with Web browser (e.g. Internet Explorer) or with "FieldCare" operating tool
- 2 Automation system, e.g. "RSLogix" (Rockwell Automation) and work station for measuring device operation with Add-on Profile Level 3 for "RSLogix 5000" software (Rockwell Automation)

36

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu with menus and parameters



■ 11 Schematic structure of the operating menu

8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Operation	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Reading measured values	 Defining the Web server operating language Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: Configuration of the measurement Configuration of the communication interface	Submenus for fast commissioning: Setting the individual system units Defining the medium Configuration of the digital communication interface Configuring the low flow cut off Configuring partial and empty pipe detection
			 "Advanced setup" submenu: For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers "Device reset" submenu Resets the device configuration to certain settings
Diagnostics		"Maintenance" role Fault elimination: Diagnostics and elimination of process and device errors Measured value simulation	Contains all parameters for error detection and analyzing process and device errors: "Diagnostic list" submenu Contains up to 5 currently pending diagnostic messages. "Event logbook" submenu Contains 20 event messages that have occurred. "Device information" submenu Contains information for identifying the device. "Measured values" submenu Contains all current measured values. "Simulation" submenu Is used to simulate measured values or output values.
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: "System" submenu Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. "Sensor" submenu Configuration of the measurement. "Communication" submenu Configuration of the digital communication interface and the Web server. "Application" submenu Configuration of the functions that go beyond the actual measurement (e.g. totalizer). "Diagnostics" submenu Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the Web browser

8.3.1 Function range

Thanks to the integrated Web server the device can be operated and configured via a Web browser. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

8.3.2 Prerequisites

Computer hardware

Interface	The computer must have an RJ45 interface.	
Connecting cable	Standard Ethernet cable with RJ45 connector.	
Screen	Recommended size: ≥12" (depends on the screen resolution)	
	Web server operation is not optimized for touch screens!	

Computer software


Recommended operating systems	Microsoft Windows 7 or higher. Microsoft Windows XP is supported.	
Web browsers supported	 Microsoft Internet Explorer 8 or higher Mozilla Firefox Google chrome 	

Computer settings

User rights	User rights are required for TCP/IP and proxy server settings (for changes to the IP address, subnet mask etc.).	
Proxy server settings of the Web browser	The Web browser setting <i>Use proxy server for LAN</i> must be disabled .	
JavaScript	JavaScript must be enabled.	
	If JavaScript cannot be enabled: enter http://XXX.XXX.XXXX/basic.html in the address line of the Web browser, e.g. http://192.168.1.212/basic.html. A fully functional but simplified version of the operating menu structure starts in the Web browser.	
	When installing a new firmware version: To enable correct data display, clear the temporary memory (cache) of the Web browser under Internet options .	

Measuring device

Web server	Web server must be enabled; factory setting: ON \fill For information on enabling the Web server $(\rightarrow \ \fill$ 42)	
IP address	If the IP address of the device is not known, communication with the Web server can be established via the standard IP address 192.168.1.212. The DHCP function is enabled in the device at the factory, i.e. the device expects an IP address to be assigned by the network. This function can be disabled and the device can be set to the standard IP address 192.168.1.212: set switch DIP switch No. 10 from OFF \rightarrow ON.	



8.3.3 Establishing a connection

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)


IP address	192.168.1.XXX; for XXX all numerical values except: 0, 212 and 255 \rightarrow e.g. 192.168.1.213		
Subnet mask	255.255.255.0		
Default gateway	192.168.1.212 or leave cells empty		

- 1. Switch on the measuring device and connect to the computer via the cable $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \)$.
- 2. If a 2nd network card is not used: all the applications on the notebook should be closed, or all the applications that require the Internet or network, such as e-mail, SAP applications, Internet or Windows Explorer, i.e. close all open Internet browsers.
- 3. Configure the properties of the Internet protocol (TCP/IP) as defined in the table above.

Starting the Web browser

- 1. Start the Web browser on the computer.

The login page appears.



- 1 Device tag ($\rightarrow \implies 52$)
- 2 Picture of device


8.3.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the access code.
- 3. Press **OK** to confirm your entry.

Access code 0000 (factory setting); can be changed by customer ($\rightarrow \triangleq 66$)

If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.3.5 User interface



Header

The following information appears in the header:

- Device tag (\rightarrow 🖺 52)
- Device status with status signal (→ 🗎 79)
- Current measured values

Function row

Functions	Meaning
Measured values	The measured values of the device are displayed
Menu	Access to the operating menu structure of the device, same as for the operating tool
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	 Data exchange between PC and measuring device: Upload the configuration from the device (XML format, create configuration back-up) Save the configuration to the device (XML format, restore configuration) Export the event list (.csv file) Export parameter settings (.csv file, create documentation of the measuring point configuration) Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package) Upload the device driver for system integration from the device
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the device: Network settings (e.g. IP address, MAC address) Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.3.6 Disabling the Web server

The Web server for the measuring device can enabled and disabled as required via the **Web server functionality** parameter.

Navigation

"Expert" menu \rightarrow Communication \rightarrow Web server

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	Off On	On

Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

Via "FieldCare" operating tool

8.3.7 Logging out

- Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.
- 1. Select the **Logout** entry in the function row.


 The home page with the Login box appears.
- 2. Close the Web browser.
- If communication with the Web server was established via the standard IP address 192.168.1.212, DIP switch No. 10 must be reset (from ON \rightarrow OFF) and the IP address of the device is active again for network communication.

8.4 Access to the operating menu via the operating tool

8.4.1 Connecting the operating tool

Via Ethernet-based fieldbus


This communication interface is available in device versions with EtherNet/IP.



■ 12 Options for remote operation via Ethernet-based fieldbus

- 1 Ethernet network
- 2 Automation system, e.g. "RSLogix" (Rockwell Automation)
- 3 Workstation for measuring device operation: with Add-on Profile Level 3 for "RSLogix 5000" (Rockwell Automation) or with Electronic Data Sheet (EDS)
- 4 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 5 Ethernet switch
- 6 Measuring device

Via service interface (CDI-RJ45)



■ 13 Connection for order code for "Output", option N: EtherNet/IP

- Service interface (CDI -RJ45) and EtherNet/IP interface of the measuring device with access to the integrated Web server
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 3 Standard Ethernet connecting cable with RJ45 plug

8.4.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

Service interface CDI-RJ45 (→ 🖺 44)

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook
- $\widehat{\mbox{\bf \sc 1}}$ For details, see Operating Instructions BA00027S and BA00059S

Source for device description files

See data ($\rightarrow \triangleq 46$)


Establishing a connection

Via service interface (CDI-RJ45)

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
 - ► The **Add device** window opens.
- 3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.
 - ► The **CDI Communication TCP/IP (Configuration)** window opens.

- 6. Enter the device address in the **IP** address field and press **Enter** to confirm: 192.168.1.212 (factory setting); if the IP address is not known ($\Rightarrow \triangleq 68$).
- 7. Establish the online connection to the device.
- $\widehat{\mbox{1}}$ For details, see Operating Instructions BA00027S and BA00059S

User interface



A0021051-EN

- 1 Heade
- 2 Picture of device
- 3 Device name
- 4 Device tag (→ 🖺 52)
- 5 Status area with status signal (→ 🖺 79)
- 6 Display area for current measured values ($\rightarrow \triangleq 69$)
- 7 Event list with additional functions such as save/load, events list and document creation
- 8 Navigation area with operating menu structure
- 9 Operating range
- 10 Range of action
- 11 Status area

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.02.zz	 On the title page of the Operating instructions On transmitter nameplate (→ 🖺 14) Parameter firmware version Diagnostics → Device info → Firmware version 	
Release date of firmware version	10.2014		
Manufacturer ID	0x49E	Manufacturer ID parameter Diagnostics → Device info→ Manufacturer ID	
Device type ID	0x104A	Device type parameter Diagnostics → Device info → Device type	
Device revision	Major revision2Minorrevision 1	 On transmitter nameplate (→	
Device profile	Generic device (product type: 0x2B)		

9.1.2 Operating tools

Operating tool via Service interface (CDI)	Sources for obtaining device descriptions	
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser) 	

9.2 Overview of system files

System files	Version	Description	How to acquire
Electronic Data Sheet (EDS system file)	2.1	Certified in accordance with the following ODVA guidelines: Conformance test Performance test PlugFest Embedded EDS Support (File Object 0x37)	■ www.endress.com → Download Area ■ EDS system file integrated in the device: can be downloaded via the Web browser (→ 🖺 42)
Add-on Profile Level 3	Major revision2Minorrevision 1	System file for "RSLogix 5000" software (Rockwell Automation)	www.endress.com → Download Area

9.3 Integrating the measuring device in the system

A detailed description of how to integrate the device into an automation system (e.g. from Rockwell Automation) is available as a separate document: www.endress.com → Select country → Automation → Digital Communication → Feldbus device integration → EtherNet/IP

For information on the protocol-specific data of EtherNet/IP

9.4 Cyclic data transmission

Cyclic data transmission when using the device master file (GSD).

9.4.1 Block model

The block model shows which input and output data the measuring device makes available for implicit messaging. Cyclical data exchange is performed using an EtherNet/IP scanner, e.g. a distributed control system etc.

Block (Assem102) 64 Byte output group Input Assembly Fix Configurable	Measuring device				Control system	
Block (Assem102) 64 Byte (7 = 49) output group Input Assembly Fix Configurable			(→ 🖺 48)	, ,	→	
Input Assembly Fix Configurable →			(→ 🖺 49)	, ,	+	EtherNet/IP
(Assem101) 88 Byte (→ (⇒ 49) input group		1 1	(→ 🖺 49)	3	>	

9.4.2 Input and output groups

Possible configurations

Configuration 1: Exclusive Owner Multicast

Input Assembly Fix		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 64	398	_
Output Assembly Fix	O → T Configuration	0 x 66	64	5
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 64	44	5

Configuration 2: Input Only Multicast

Input Assembly Fix		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 68	398	-
Output Assembly Fix	O → T Configuration	0 x C7	-	-
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 64	44	5

Configuration 3: Exclusive Owner Multicast

Input Assembly Configurable		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 68	398	_
Output Assembly Fix	O → T Configuration	0 x 66	64	5
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 65	88	5

Configuration 4: Input Only Multicast

Input Assembly Configurable		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 68	398	-
Output Assembly Fix	$O \rightarrow T$ Configuration	0 x C7	-	_
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 64	88	5

Configuration 5: Exclusive Owner Multicast

Input Assembly Fix		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 69	-	_
Output Assembly Fix	O → T Configuration	0 x 66	64	5
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 64	44	5

Configuration 6: Input Only Multicast

Input Assembly Fix		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 69	-	-
Output Assembly Fix	O → T Configuration	0 x C7	-	-
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 65	44	5

Configuration 7: Exclusive Owner Multicast

Input Assembly Configurable		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 69	-	_
Output Assembly Fix	O → T Configuration	0 x 66	64	5
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 64	88	5

Configuration 8: Input Only Multicast

Input Assembly Configurable		Instance	Size [byte]	min. RPI (ms)
Input Assembly Configurable	Configuration	0 x 69	-	_
Output Assembly Fix	O → T Configuration	0 x C7	-	_
Input Assembly Fix	$T \rightarrow O$ Configuration	0 x 65	88	5

Permanently assigned input group

Input Assembly Fix (Assem100) 44 Byte

Name	Description	Byte
Input Assembly Fix	1. File header (not visible)	1 to 4
	2. Current diagnosis ¹⁾	5 to 8
	3. Mass flow	9 to 12
	4. Volume flow	13 to 16
	5. Corrected volume flow	17 to 20
	6. Temperature	21 to 24
	7. Density	25 to 28
	8. Reference density	29 to 32
	9. Totalizer 1	33 to 36
	10. Totalizer 2	37 to 40
	11. Totalizer 3	41 to 44

1) Structure: Code, number, description (e.g.: 16777265 F882 input signal)



Detailed description

- Diagnostic information (→ 🖺 82)
- Information events (→ 🖺 86)

Configurable input group

Input Assembly Configurable (Assem101) 88 byte

Name	Description	Format
Input Assembly Configurable	1 10. Input values 1 to 10	Real
	11 20. Input values 11 to 20	Double integer

Possible input values

Possible input values 1 to 10:		
 Off Mass flow Volume flow Corrected volume flow Target mass flow Carrier mass flow Density Reference density Concentration 	 Temperature Carrier pipe temperature Electronics temperature Oscillation frequency 0 Oscillation frequency 1 Oscillation amplitude 0 Oscillation amplitude 1 Oscillation frequency 0 Oscillation frequency 1 Oscillation damping 0 Oscillation damping 1 Signal shift 	 Tube damping fluctuation 0 Tube damping fluctuation 1 Exciter current 0 Exciter current 1 Monitoring of exciter current 0 Monitoring of exciter current 1 Totalizer 1 Totalizer 2 Totalizer 3 Sensor integrity

Possible input values 11 to 20:		
 Off Current diagnosis Previous diagnosis Mass flow unit Volume flow unit Corrected volume flow unit 	 Temperature unit Density unit Reference density unit Concentration unit Current unit Status verification 	Totalizer 1 unitTotalizer 2 unitTotalizer 3 unitVerification result

Permanently assigned output group

Output Assembly Fix (Assem102) 64 byte

Name	Description (format)	Byte	Bit	Value
Output	1. Totalizer 1	1	1	
Assembly Fix	2. Totalizer 2		2	
	3. Totalizer 3		3	
	4. Pressure compensation		4	0: Enable 1: Disable
	5. Reference density compensation		5	
	6. Temperature compensation		6	
	7. Verification		7	
	8. Not used		8	-
	9. Not used	2 to 4	0 to 8	-
	10. Control totalizer 1 (integer)	5 to 6	0 to 8	 32226: Add 32490: Reset and stop 32228: Default value and stop 198: Reset and add 199: Default value and add

Name	Description (format)	Byte	Bit	Value
	11. Not used	7 to 8	0 to 8	-
	12. Control totalizer 2 (integer)	910	0 to 8	See totalizer 1
	13. Not used	11 to 12	0 to 8	-
	14. Control totalizer 3 (integer)	13 to 14	0 to 8	See totalizer 1
	15. Not used	15 to 16	0 to 8	-
	16. External pressure (real)	17 to 20	0 to 8	Data format: Byte 1 to 4: External pressure Floating-point number (IEEE754)
	17. External pressure unit (integer)	21 to 22	0 to 8	 2165: Pa a 2116: kPa a 2137: MPa a 4871: bar a 2166: Pa g 2117: kPa a 2138: MPa a 2053: bar g 2182: Psi a 2183: Psi g 2244: Customer-specific
	18. Not used	23 to 24	0 to 8	-
	19. External reference density (real)	25 to 28	0 to 8	Data format: Byte 1 to 4: External ref. density Floating-point number (IEEE754)
	External reference density unit (integer)	29 to 30	0 to 8	 2112: kg/Nm³ 2113: kg/Nl 2092: g/Scm³ 2114: kg/Scm³ 2181: lb/Sft³
	21. Not used	31 to 32	0 to 8	-
	22. External temperature (real)	33 to 36	0 to 8	Data format: Byte 1 to 4: External temperature Floating-point number (IEEE754)
	23. External temperature unit (integer)	37 to 38	0 to 8	■ 4608: °C ■ 4609: °F ■ 4610: K ■ 4611: °R
	24. Not used	39 to 40	0 to 8	-
	25. Start verification (integer)	41 to 42	0 to 8	• 32378: Start • 32713: Cancel
	26. Not used	43 to 64	0 to 8	-

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.
- "Post-connection check" checklist (→ 🖺 35)

10.2 Configuring the device address via software

In the **"Communication" submenu** the device address can be set.

Navigation

"Setup" menu \rightarrow Communication \rightarrow Device address

10.2.1 Ethernet network and Web server

When delivered, the measuring device has the following factory settings:

IP address	192.168.1.212
Subnet mask	255.255.255.0
Default gateway	192.168.1.212



- If hardware addressing is active, software addressing is disabled.
- If a switch is made to hardware addressing, the address configured via software addressing is retained for the first 9 places (the first three octets).
- If the IP address of the device is not known, the device address currently configured can be read out ($\rightarrow \stackrel{\triangle}{=} 68$).


10.3 Setting the operating language

Factory setting: English or ordered local language

The operating language of the local display can be set in FieldCare or via the Web server: "Operation" menu \to Display language

10.4 Configuring the measuring device

The **Setup** menu with its submenus contains all the parameters needed for standard operation.



► Low flow cut off	(→ 🖺 56)
► Partially filled pipe detection	(→ 🖺 57)
► Advanced setup	(→ 🖺 58)

10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

- The number of characters displayed depends on the characters used.
- For information on the tag name in the "FieldCare" operating tool ($\Rightarrow \triangleq 45$)

Navigation

"Setup" menu \rightarrow Device tag


Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	31	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promass 100

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.



Temperature unit	
Pressure unit	

Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: • kg/h • lb/min
Mass unit	Select mass unit. Result The selected unit is taken from: Mass flow unit parameter	Unit choose list	Country-specific: kg lb
Volume flow unit	Select volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: l/h gal/min (us)
Volume unit	Select volume unit. Result The selected unit is taken from: Volume flow unit parameter	Unit choose list	Country-specific: 1 gal (us)
Corrected volume flow unit	Select corrected volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: NI/h Sft³/h
Corrected volume unit	Select corrected volume unit. Result The selected unit is taken from:Corrected volume flow unit parameter	Unit choose list	Country-specific: NI Sft ³
Density unit	Select density unit. Result The selected unit applies for: Output Simulation process variable	Unit choose list	Country-specific: • kg/l • lb/ft³
Reference density unit	Select reference density unit.	Unit choose list	kg/Nl
Temperature unit	Select temperature unit. Result The selected unit applies for: Output Reference temperature Simulation process variable	Unit choose list	Country-specific: °C (Celsius) °F (Fahrenheit)
Pressure unit	Select process pressure unit.	Unit choose list	Country-specific: bar psi

10.4.3 Selecting and setting the medium

The **Medium selection** submenu contains parameters that have to be configured for selecting and setting the medium.

Navigation

"Setup" menu \rightarrow Select medium



Parameter overview with brief description


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Select medium	-	Select medium type.	Gas	Liquid
Select gas type	The following option is selected in the Medium selection parameter: Gas	Select measured gas type.	Gas type choose list	Methane CH4
Reference sound velocity	The following option is selected in the Select gas type parameter: Others	Enter sound velocity of gas at 0 °C (32 °F).	1 to 99 999.9999 m/s	0 m/s
Temperature coefficient sound velocity	The following option is selected in the Select gas type parameter: Others	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	0 (m/s)/K
Pressure compensation	The following option is selected in the Medium selection parameter:	Select pressure compensation type.	OffFixed valueExternal value	Off
Pressure value	The following option is selected in the Pressure compensation parameter: Fixed value	Enter process pressure to be used for pressure correction.	Positive floating- point number	0 bar
External pressure	The following option is selected in the Pressure compensation parameter: External value		Positive floating- point number	0 bar

10.4.4 Configuring the communication interface

The **"Communication" submenu** guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu \rightarrow Communication



Parameter overview with brief description

Parameter	Description	User interface / Selection / User entry	Factory setting
MAC address	Displays the MAC address of the measuring device. MAC = Media Access Control	Unique 12-digit character string comprising letters and numbers, e.g.: 00:07:05:10:01:5F	Each measuring device is given an individual address.
Default network settings	Select whether to restore network settings.	Off On	Off
DHCP client	Select to activate/deactivate DHCP client functionality.	Off On	On
	Result If the web server's DHCP client functionality is activated, the IP address, subnet mask and default gateway are automatically set.		
	Identification is via the MAC address of the measuring device.		
IP address	IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	0.0.0.0

10.4.5 Configuring the low flow cut off

The **Low flow cut off** submenu contains parameters that must be configured for the configuration of low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off

► Low flow cut off	
Assign process variable	(→ 🖺 56)
On value low flow cutoff	(→ 🖺 56)
Off value low flow cutoff	(→ 🖺 56)
Pressure shock suppression	(→ 🖺 56)

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	OffMass flowVolume flowCorrected volume flow	Mass flow
On value low flow cutoff	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter on value for low flow cut off.	Positive floating- point number	For liquids: depends on country and nominal diameter
Off value low flow cutoff	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.4.6 Configuring the partial filled pipe detection

The **Partially filled pipe detection** submenu contains parameters that have to be set for configuring empty pipe detection.

Navigation

"Setup" menu \rightarrow Partially filled pipe detection

► Partially filled pipe detection				
Assign process variable	(→ 🖺 57)			
Low value partial filled pipe detection	(→ 🖺 57)			
High value partial filled pipe detection	(→ 🖺 57)			
Response time part. filled pipe detect.	(→ 🖺 57)			

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for partially filled pipe detection.	 Off Density Reference density	Off
Low value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: • 0.2 kg/l • 12.5 lb/ft ³
High value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: • 6 kg/l • 374.6 lb/ft ³
Response time part. filled pipe detect.	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s	1s


10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

The number of submenus can vary depending on the device version, e.g. viscosity is available only with the Promass I.

Navigation

"Setup" menu → Advanced setup




10.5.1 Calculated values

The ${f Calculated\ values}$ submenu contains parameters for calculating the corrected volume flow.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Calculated values



Li	inear expansion coefficient	(→ 🖺 59)
Si	quare expansion coefficient	(→ 🖺 59)

Parameter overview with brief description


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	 Fixed reference density Calculated reference density Reference density by API table 53 External reference density 	Calculated reference density
External reference density	-	Shows external reference density.	Floating point number with sign	0 kg/Nl
Fixed reference density	The following option is selected in the Corrected volume flow calculation parameter: Fixed reference density	Enter fixed value for reference density.	Positive floating- point number	1 kg/Nl
Reference temperature	The following option is selected in the Corrected volume flow calculation parameter: Calculated reference density	Enter reference temperature for calculating the reference density.	-273.15 to 99999 °C	20°C
Linear expansion coefficient	The following option is selected in the Corrected volume flow calculation parameter: Calculated reference density	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Square expansion coefficient	-	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0

10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment



Parameter overview with brief description


Parameter	Description	Selection / User interface	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	Flow in arrow directionFlow against arrow direction	Flow in arrow direction
Zero point adjustment control	Start zero point adjustment.	CancelBusyZero point adjust failureStart	Cancel
Progress	Shows the progress of the process.	0 to 100 %	0 %

10.5.3 Configuring the totalizer

In the **"Totalizer 1 to 3" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to 3



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Assign process variable	Select process variable for totalizer.	 Off Volume flow Mass flow Corrected volume flow Target mass flow Carrier mass flow 	Mass flow
Unit totalizer	Select process variable totalizer unit.	Unit choose list	kg

Parameter	Description	Selection	Factory setting
Totalizer operation mode	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	Net flow total
Failure mode	Define totalizer behavior in alarm condition.	StopActual valueLast valid value	Stop

10.5.4 Carrying out additional display configurations

In the "Display" submenu you can set all the parameters involved in the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display		
	Format display	
	Value 1 display	
	0% bargraph value 1	
	100% bargraph value 1	
	Decimal places 1	
	Value 2 display	
	Decimal places 2	
	Value 3 display	
	0% bargraph value 3	
	100% bargraph value 3	
	Decimal places 3	
	Value 4 display	
	Decimal places 4	
	Display language	
	Display interval	
	Display damping	
	Header	
	Header text	
	Separator	
	Backlight	

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Format display	_	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display		Select the measured value that is shown on the local display. Depending on the device version, not all options are available in this parameter. The selection can vary depending on the sensor, e.g. viscosity is available only with the Promass I.	Mass flow Volume flow Corrected volume flow Target mass flow Density Reference density Concentration Dynamic viscosity Kinematic viscosity Temp. compensated dynamic viscosity Temp. compensated kinematic viscosity Temp. compensated kinematic viscosity Temperature Carrier pipe temperature Carrier pipe temperature Electronic temperature Oscillation frequency 0 Oscillation frequency 1 Oscillation amplitude 0 Oscillation amplitude 1 Frequency fluctuation 0 Frequency fluctuation 1 Oscillation damping 0 Oscillation damping 0 Oscillation condition damping 1 Tube damping fluctuation 0 Tube damping fluctuation 1 Signal asymmetry Exciter current 0 Exciter current 1 Sensor integrity None Totalizer 1 Totalizer 2 Totalizer 3	Mass flow
0% bargraph value 1	-	Enter 0% value for bar graph display.	Signed floating-point number	0 kg/h
100% bargraph value 1	_	Enter 100% value for bar graph display.	Signed floating-point number	2.5 kg/h

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Decimal places 1	-	Select the number of decimal places for the display value.	X X.X X.XX X.XXX X.XXX	x.xx
Value 2 display	-	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 2	-	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXXX	x.xx
Value 3 display	-	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	-	Select the number of decimal places for the display value.	• X • X.X • X.XX • X.XXX • X.XXXX	x.xx
Value 4 display	-	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 4	-	Select the number of decimal places for the display value.	 X X.X X.XX X.XXX X.XXX 	x.xx
Display language		Set display language.	 English Deutsch Français Español Italiano Nederlands Portuguesa Polski pусский язык (Russian) Svenska Türkçe 中文 (Chinese) 日本語 (Japanese) 한국어 (Korean) ಪ್ರಭಾಷಣೆ (Arabic) Bahasa Indonesia ภาษาไทย (Thai) tiếng Việt (Vietnamese) čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	-	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	-	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	-	Select header contents on local display.	Device tagFree text	Device tag
Header text	-	Enter display header text.		


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Separator	_	Select decimal separator for displaying numerical values.	• . • ,	
Backlight	-	Switch the local display backlight on and off. Only for device version with onsite display SD03 (touch control)	DisableEnable	Enable

10.6 Simulation

The **"Simulation" submenu** enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu \rightarrow Simulation



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign simulation process variable		Select a process variable for the simulation process that is activated. Depending on the device version, not all options are available in this parameter. The selection can vary depending on the sensor, e.g. viscosity is available only with the Promass I.	 Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature Dynamic viscosity Kinematic viscosity Temp. compensated dynamic viscosity Temp. compensated kinematic viscosity Temp. compensated kinematic viscosity Concentration Target mass flow Carrier mass flow 	Off
Value process variable	A process variable is selected in the Assign simulation process variable parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0
Simulation device alarm	-	Switch the device alarm on and off.	Off On	Off
Diagnostic event category	-	Select the category of the diagnostic event.	SensorElectronicsConfigurationProcess	Process
Simulation diagnostic event	-	Switch simulation of the diagnostic event on and off. For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter.	 Off Picklist Diagnostic events (depends on the selected category) 	Off

10.7 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

10.7.1 Write protection via access code

With the customer-specific access code, access to the measuring device via the Web browser is protected, as are the parameters for the measuring device configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

Structure of the submenu

Define access code	\rightarrow	Define access code
		Confirm access code

Defining the access code via the Web browser

- 1. Navigate to the **Enter access code** parameter.
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Enter the access code again to confirm the code.
 - ► The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
- The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling


10.7.2 Write protection via write protection switch

The write protection switch makes it possible to block write access to the entire operating menu with the exception of the following parameters:

- External pressure
- External temperature
- Reference density
- All parameters for configuring the totalizer

The parameter values are now read only and cannot be edited any more:

- Via service interface (CDI-RJ45)
- Via Ethernet network




A001791

- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary $(\rightarrow \implies 111)$.
- 3. Setting the write protection switch on the I/O electronics module to the ON position enables the hardware write protection. Setting the write protection switch on the I/O electronics module to the OFF position (factory setting) disables the hardware write protection.
- 4. Reverse the removal procedure to reassemble the transmitter.

11 Operation

11.1 Read out and modify current Ethernet settings

If the Ethernet settings such as the IP address of the measuring device are unknown, they can be read out and modified as explained in the following example for an IP address.



A0017965

Prerequisite

- Software addressing is enabled: All the DIP switches for hardware addressing are set to OFF. $(\rightarrow \boxminus 34)$
- Measuring device is switched on.
- 1. Set the DIP switch for "Default Ethernet network settings, IP 192.168.1.212" from OFF \rightarrow ON.
- 2. Restart the device.
 - The device's Ethernet settings are reset to their factory settings:

 IP address: 192.168.1.212; Subnet mask: 255.255.255.0; Default gateway: 192.168.1.212
- 3. Enter the default setting for the IP address in the address line of the Web browser.
- 4. In the operating menu navigate to the IP address parameter: "Setup" menu → Communication → IP address
 - ► The parameter displays the configured IP address.
- 5. Change the IP address of the device if necessary.
- 6. Set the DIP switch for "Default Ethernet network settings, IP 192.168.1.212" from ON → OFF.
- 7. Restart the device.
 - The modified IP address of the device is now enabled.

11.2 Reading device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

Navigation

"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
Hardware locked	The write protection switch (DIP switch) for hardware locking is activated on the I/O electronic module. This prevents write access to the parameters ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Temporarily locked	Due to internal processing in the device (e.g. up-/downloading of data, reset), write access to the parameters is blocked for a short time. Once the internal processing has been completed, the parameters can be changed once again.

11.3 Adjusting the operating language

Information ($\rightarrow \implies 51$)

For information on the operating languages supported by the measuring device $(\Rightarrow \boxminus 112)$

11.4 Configuring the display

- Basic settings for local display
- Advanced settings for local display (\rightarrow 🗎 62)

11.5 Reading measured values

Using the Measured values submenu, it is possible to read all the measured values.


"Diagnostics" menu → Measured values

11.5.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables



Parameter overview with brief description


Parameter	Description	User interface	
Mass flow	Displays the mass flow currently measured.	Signed floating-point number	
Volume flow	Displays the volume flow currently calculated.	Signed floating-point number	
	Dependency The unit is taken from the Volume flow unit parameter		
Corrected volume flow	Displays the corrected volume flow currently calculated.	Signed floating-point number	
	Dependency The unit is taken from the Corrected volume flow unit parameter		
Density	Displays the density currently measured.	Signed floating-point number	
	Dependency The unit is taken from the Density unit parameter		
Reference density	Displays the reference density currently calculated.	Signed floating-point number	
	Dependency The unit is taken from the Reference density unit parameter		
Temperature	Shows the medium temperature currently measured.	Signed floating-point number	
	Dependency The unit is taken from the Temperature unit parameter		
Pressure value	Displays either a fixed or external pressure value.	Signed floating-point number	

11.5.2 Totalizer

The **"Totalizer" submenu** contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer



Parameter overview with brief description


Parameter	Prerequsite	Description	User interface	Factory setting
Totalizer value 1 to 3	In the Assign process variable parameter in the Totalizer 1 to 3 submenu, one of the following options is selected: Volume flow Mass flow Corrected volume flow	Displays the current totalizer counter value.	Signed floating-point number	0 kg
Totalizer overflow 1 to 3	In the Assign process variable parameter in the Totalizer 1 to 3 submenu, one of the following options is selected: Volume flow Mass flow Corrected volume flow	Displays the current totalizer overflow.	Integer with sign	0

11.5.3 Output values

The **"Output values" submenu** contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values



Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Pulse output	Displays the value currently measured for the pulse output.	Positive floating-point number	0 Hz
Output frequency	Displays the value currently measured for the frequency output.	0.0 to 1250.0 Hz	0.0 Hz
Switch status	Displays the current switch output status.	OpenClosed	Open

11.6 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu(→ 🗎 51)
- Advanced settings using the **Advanced setup** submenu($\rightarrow \triangleq 58$)

11.7 Performing a totalizer reset

Function scope of "Control Totalizer" parameter


Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in Preset value parameterand the totaling process is restarted.

Function scope of "Reset all totalizers" parameter

Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

Navigation

"Operation" menu → Operation



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Control Totalizer 1 to 3	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize 	Totalize
Preset value 1 to 3	Specify start value for totalizer.	Signed floating-point number	0 kg
Reset all totalizers	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Problem	Possible causes	Remedial action
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.	Order spare part (→ 🖺 92).
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part (→ 🖺 92).
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures (→ 🖺 82)
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part (→ ₱ 92).

For output signals

Problem	Possible causes	Remedial action
Green power LED on the main electronics module of the transmitter is dark	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access

Problem	Possible causes	Remedial action
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
No connection via EtherNet/IP	Device plug connected incorrectly	Check the pin assignment of the device plug .

Problem	Possible causes	Remedial action
Not connecting to Web server	 Incorrect IP address IP address is not known 	1. If addressing via hardware: open the transmitter and check the IP address configured (last octet). 2. Check the IP address of the measuring device with the network manager. 3. If the IP address is not known, set DIP switch No. 10 on the I/O electronics module to ON, restart the device and enter the default setting for the IP address 192.168.1.212. EtherNet/IP communication is interrupted by enabling the DIP switch.
Not connecting to Web server	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) (→ 🖺 40). 2. Check the network settings with the IT manager.
Not connecting to Web server	Web server disabled	Via the "FieldCare" operating tool check whether the Web server of the measuring device is enabled and enable it if necessary $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Not connecting to Web server	The use of the proxy server is not disabled in the Web browser settings of the computer.	Disable the use of the proxy server in the Web browser settings of the computer. Using the example of MS Internet Explorer: 1. Under Control Panel open Internet options. 2. Select the Connections tab and then double-click LAN settings. 3. In the LAN settings disable the use of the proxy server and select OK to confirm.
Not connecting to Web server	Other network connections or programs are still active on the computer.	 Make sure that no other network connections are established by the computer (also no WLAN) and close other programs withe network access to the computer. If using a docking station for notebooks make sure that a network connection to another network is not active.
No or incomplete display of contents in the Web browser	 JavaScript not enabled JavaScript cannot be enabled	Enable JavaScript. Enter http://XXX.XXX.XXXX/ basic.html as the IP address.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
Web browser frozen and operation no longer possible	Connection lost	Check cable connection and power supply. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	 Use the correct Web browser version (→
Content of Web browser incomplete or difficult to read	Unsuitable view settings.	Change the font size/display ratio of the Web browser.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter


Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.

LED	Color	Meaning	
Power	Off	Supply voltage is off or too low	
	Green	Supply voltage is ok	
Device status	Green	Device status is ok	
	Flashing red	A device error of diagnostic behavior "Warning" has occurred	
	Red	A device error of diagnostic behavior "Alarm" has occurred	
	Alternately flashing red/ green	Boot loader is active	
Network status	Off	Device has no EtherNet/IP address	
	Green	Device's EtherNet/IP connection is active	
	Flashing green	Device has EtherNet/IP address but no EtherNet/IP connection	
	Red	EtherNet/IP address of the device has been assigned twice	
	Flashing red	Device's EtherNet/IP connection is in timeout mode	
Link/Activity	Orange	Link available but no activity	
	Flashing orange	Activity present	
Communication	Flashing white		

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:

 - Via submenus ($\rightarrow \triangleq 85$)

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning	
A0013956	Failure A device error has occurred. The measured value is no longer valid.	
C	Function check The device is in service mode (e.g. during a simulation).	
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)	
A0013957	Maintenance required Maintenance is required. The measured value remains valid.	

Diagnostic behavior

Symbol	Meaning
A0013961	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
A0013962	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



Operating elements

Key	Meaning
	Plus key
A0013970	In a menu, submenu Opens the message about the remedial measures.
	Enter key
A0013952	In a menu, submenu Opens the operating menu.

12.3.2 Calling up remedial measures



- 14 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (i) symbol).
 - ► The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \Box .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.


- 1. Press E.
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

78

12.4 Diagnostic information in the Web browser

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.



- Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

 - Via submenus (\rightarrow 🖺 85)

Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
A0017271	Failure A device error has occurred. The measured value is no longer valid.
A0017278	Function check The device is in service mode (e.g. during a simulation).
A0017277	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
A0017276	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.




12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.

12.5 Diagnostic information in FieldCare

12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- 1 Status area with status signal (→ 🖺 76)
- 2 Diagnostic information (→ 🖺 77)
- 3 Remedial measures with Service ID

- Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
 Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
- Remedy information can be called up in the working area of the user interface.


The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ► A tool tip with remedy information for the diagnostic event appears.

12.6 Diagnostic information via communication interface

12.6.1 Reading out diagnostic information

The current diagnostic event and associated diagnostic information can be read out via the input assembly (fix assembly):



For content of bytes 8 to 16

12.7 Adapting the diagnostic information

12.7.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the ${\bf Diagnostic\ behavior\ submenu\ }$.

"Expert" menu → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. The totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	Measurement is resumed. The totalizers are not affected. A diagnostics message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.8 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Adapt the diagnostic information $(\rightarrow \boxtimes 82)$

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]	
Diagnostic of se	ensor				
022	Sensor temperature	1.Change main electronic module 2.Change sensor	F	Alarm	
046	Sensor limit exceeded	Inspect sensor Check process condition	S	Alarm	
062	Sensor connection	1.Change main electronic module 2.Change sensor	F	Alarm	
082	Data storage	Check module connections Contact service	F	Alarm	
083	Memory content	1. Restart device 2. Contact service	F	Alarm	
140	Sensor signal	1.Check or change main electronics 2.Change sensor	S	Alarm	
144	Measuring error too high	Check or change sensor Check process conditions	F	Alarm	
190	Special event 1	Contact service	F	Alarm	
191	Special event 5	Contact service	F	Alarm	
192	Special event 9	Contact service	F	Alarm 1)	
Diagnostic of e	Diagnostic of electronic				
201	Device failure	1. Restart device 2. Contact service	F	Alarm	

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
242	Software incompatible	Check software Flash or change main electronics module	F	Alarm
252	Modules incompatible	Check electronic modules 2. Change electronic modules	F	Alarm
262	Module connection	Check module connections Change main electronics	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	Restart device Change main electronic module	F	Alarm
272	Main electronic failure	Restart device Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
274	Main electronic failure	Change electronic	S	Warning
283	Memory content	1. Reset device 2. Contact service	F	Alarm
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
311	Electronic failure	Do not reset device Contact service	M	Warning
382	Data storage	1. Insert DAT module 2. Change DAT module	F	Alarm
383	Memory content	1. Restart device 2. Check or change DAT module 3. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
391	Special event 6	Contact service	F	Alarm
392	Special event 10	Contact service	F	Alarm 1)
Diagnostic of o	configuration			
410	Data transfer	Check connection Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
437	Configuration incompatible	Restart device Contact service	F	Alarm
438	Dataset	Check data set file Check device configuration Up- and download new configuration	М	Warning
453	Flow override	Deactivate flow override	С	Warning
484	Simulation failure mode	Deactivate simulation	С	Alarm
485	Simulation measured variable	Deactivate simulation	С	Warning
495	Simulation diagnostic event	Deactivate simulation	С	Warning
537	Configuration	Check IP addresses in network Change IP address	F	Warning
590	Special event 3	Contact service	F	Alarm
591	Special event 7	Contact service	F	Alarm
592	Special event 11	Contact service	F	Alarm 1)

Diagnostic number	Short text Remedy instructions		Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of pr	rocess			
825	Operating temperature	Check ambient temperature Check process temperature	S	Warning
825	Operating temperature	Check ambient temperature Check process temperature	F	Alarm
830	Sensor temperature too high	Reduce ambient temp. around the sensor housing	S	Warning
831	Sensor temperature too low	Increase ambient temp. around the sensor housing	S	Warning
832	Electronic temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronic temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
843	Process limit	Check process conditions	S	Warning
862	Partly filled pipe	1.Check for gas in process 2. Adjust detection limits	S	Warning
882	Input signal	Check input configuration Check external device or process conditions	F	Alarm
910	Tubes not oscillating	1. Check electronic 2. Inspect sensor	F	Alarm
912	Medium inhomogeneous	Check process cond. Increase system pressure	S	Warning
912	Inhomogeneous	Check process cond. Increase system pressure	S	Warning
913	Medium unsuitable	Check process conditions Check electronic modules or sensor	S	Alarm
944	Monitoring failed	Check process conditions for Heartbeat Monitoring	S	Warning
948	Tube damping too high	Check process conditions	S	Warning
990	Special event 4	Contact service	F	Alarm
991	Special event 8	Contact service	F	Alarm
992	Special event 12	Contact service	F	Alarm 1)

¹⁾ Diagnostic status is changeable.

12.9 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event:
 - Via Web browser (→ 🖺 80)
 - Via "FieldCare" operating tool (→ 81)
- Other pending diagnostic events can be displayed in the Diagnostic list submenu($\rightarrow \triangleq 85$)

Navigation

"Diagnostics" menu

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequsite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	_
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	-

12.10 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → Diagnostic list submenu



To call up the measures to rectify a diagnostic event:

- Via Web browser (→
 80)
- Via "FieldCare" operating tool (→ 🖺 81)

12.11 Event logbook

12.11.1 Event history

A chronological overview of the event messages that have occurred is provided in the Events list submenu.

Navigation path

"Diagnostics" menu \rightarrow Event logbook \rightarrow Events list

A maximum of 20 event messages can be displayed in chronological order.

The event history includes entries for:

- Diagnostic events (→ 🖺 82)
- Information events (\rightarrow 🖺 86)

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - ⊕: Event has occurred
 - ←: Event has ended
- Information event
 - ⊕: Event has occurred
- To call up the measures to rectify a diagnostic event:
 - Via Web browser (→

 80)
 - Via "FieldCare" operating tool (→ 🖺 81)
- For filtering the displayed event messages ($\rightarrow \triangleq 86$)

12.11.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared


Info number	Info name
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1361	Wrong web server login
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed
I1446	Device verification active
I1447	Record application reference data
I1448	Application reference data recorded
I1449	Recording application ref. data failed
I1450	Monitoring off
I1451	Monitoring on
I1457	Failed:Measured error verification
I1459	Failed: I/O module verification
I1460	Failed: Sensor integrity verification
I1461	Failed: Sensor verification
I1462	Failed:Sensor electronic module verific.

12.12 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

Navigation

 $\texttt{"Setup"} \ menu \rightarrow Advanced \ setup \rightarrow Administration \rightarrow Device \ reset$



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Restart or reset device manually.	CancelTo delivery settingsRestart device	Cancel

12.12.1 Function scope of "Device reset" parameter

Options	Description	
Cancel	No action is executed and the user exits the parameter.	
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.	
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.	
History reset	Every parameter is reset to its factory setting.	

12.13 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

Navigation

"Diagnostics" menu \rightarrow Device information

➤ Device information	
Device tag	
Serial number	
Firmware version	
Device name	
Order code	
Extended order code 1	
Extended order code 2	
Extended order code 3	
ENP version	
IP address	

Subnet mask	
Default gateway	

Parameter overview with brief description

Parameter	Description	User interface / User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)	Promass 100
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	79AFFF16000
Firmware version	Displays the device firmware version character string with the installed. Character string with the following format: xx.yy.zz		01.02
Device name	Displays the name of the transmitter.	Character string composed of letters, numbers and certain punctuation marks.	Promass 100
Order code	Displays the device order code.	Character string composed of letters, numbers and certain punctuation marks	-
Extended order code 1	Displays the 1st part of the extended order code.	Character string	-
Extended order code 2	Displays the 2nd part of the extended order code.	Character string	-
Extended order code 3	Displays the 3rd part of the extended order code.	Character string	-
ENP version	Displays the version of the electronic nameplate.	Character string in the format xx.yy.zz	2.02.00
IP address	Displays the IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	0.0.0.0

12.14 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
06.2012	01.00.00	_	Original firmware	Operating Instructions	_
04.2013	01.01.zz	Option 73	 Fieldbus access level was changed from service to maintenance Improved calculation: Target mass flow Carrier mass flow Option to access application packages: Heartbeat Technology Concentration 	Operating Instructions	BA01182D/06/EN/01.13
10.2014	01.02.zz	Option 71	 Integration of optional local display Heartbeat functionality for Rockwell AOP New unit "Beer Barrel (BBL)" Monitoring of measuring tube damping Simulation of diagnostic events 	Operating Instructions	BA01182D/06/EN/02.14

- Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) .
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download
 - Specify the following details:
 - Product root, e.g. 8E1B
 - Text search: Manufacturer's information
 - Search range: documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning


Observe the following points for CIP and SIP cleaning:

- Use only cleaning agents to which the process-wetted materials are adequately resistant.
- Observe the maximum permitted medium temperature for the measuring device $(\rightarrow \boxminus 105)$.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.



13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W*@*M* life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

- Measuring device serial number:
 - Is located on the nameplate of the device.
 - Can be read out via the **Serial number** parameter in the **Device information** submenu ($\rightarrow \boxminus 88$).

14.3 Endress+Hauser services

Contact your Endress+Hauser Sales Center for information on services and spare parts.

14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at http://www.endress.com/support/return-material

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.

2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids. If using oil as a heating medium, please consult with Endress+Hauser. Heating jackets cannot be used with sensors fitted with a rupture disk. For details, see Operating Instructions BA00099D

15.2 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. Graphic illustration of the calculation results
	Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project.
	Applicator is available: Via the Internet: https://wapps.endress.com/applicator On CD-ROM for local PC installation.
W@M	Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress +Hauser also takes care of maintaining and updating the data records. W@M is available: Via the Internet: www.endress.com/lifecyclemanagement On CD-ROM for local PC installation.
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.
	For details, see Operating Instructions BA00027S and BA00059S

15.3 System components

Accessories	Description
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	For details, see "Technical Information" TI00133R and Operating Instructions BA00247R
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the fluid temperature.
	For details, see "Fields of Activity", FA00006T

16 Technical data

16.1 Application

The measuring device is suitable for flow measurement of liquids and gases only.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

Measuring principle

Mass flow measurement based on the Coriolis measuring principle

Measuring system

The device consists of a transmitter and a sensor.

One device version is available: compact version - transmitter and sensor form a mechanical unit.

For information on the structure of the device $(\rightarrow \implies 12)$

16.3 Input

Measured variable

Direct measured variables

- Mass flow
- Density
- Temperature

Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

Measuring range

Measuring ranges for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
1	1/24	0 to 20	0 to 0.735
2	1/12	0 to 100	0 to 3.675
4	1/8	0 to 450	0 to 16.54

Measuring ranges for gases

The full scale values depend on the density of the gas and can be calculated with the formula below:

 $\dot{m}_{\max(G)} = \dot{m}_{\max(F)} \cdot \rho_G : x$

ṁ _{max(G)}	Maximum full scale value for gas [kg/h]	
m _{max(F)}	Maximum full scale value for liquid [kg/h]	
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{ max(G)}$ can never be greater than $\dot{m}_{ max(F)}$	
ρ_{G}	Gas density in [kg/m³] at operating conditions	

D	N	х
[mm]	[in]	[kg/m³]
1	1/24	32
2	1/12	32
4	1/8	32

Calculation example for gas

- Sensor: Promass A, DN 2
- Gas: Air with a density of 11.9 kg/m³ (at 20 °C and 10 bar)
- Measuring range (liquid):100 kg/h
- $x = 32 \text{ kg/m}^3 \text{ (for Promass A DN 2)}$

Maximum possible full scale value:

 $\dot{m}_{\max(G)} = \dot{m}_{\max(F)} \cdot \rho_G : x = 100 \text{ kg/h} \cdot 11.9 \text{ kg/m}^3 : 32 \text{ kg/m}^3 = 37.2 \text{ kg/h}$

Recommended measuring range

"Flow limit" section ($\rightarrow \equiv 106$)

Operable flow range

Over 1000:1.

Flow rates above the preset full scale value are not overridden by the electronics unit, with the result that the totalizer values are registered correctly.

16.4 Output

Output signal

EtherNet/IP

Standards	In accordance with IEEE 802.3

Signal on alarm

Depending on the interface, failure information is displayed as follows:

EtherNet/IP

Device diagnostics	Device condition can be read out in Input Assembly
--------------------	--

Local display

Plain text display With information on cause and remedial measures	
Backlight	Red backlighting indicates a device error.

Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication: EtherNet/IP
- Via service interface

Plain text display	With information on cause and remedial measures
--------------------	---

Web browser

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes	
	The following information is displayed depending on the device version: Supply voltage active Data transmission active Device alarm/error has occurred EtherNet/IP network available EtherNet/IP connection established	

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The following connections are galvanically isolated from each other:

- Outputs
- Power supply

Protocol-specific data

EtherNet/IP

Protocol	 The CIP Networks Library Volume 1: Common Industrial Protocol The CIP Networks Library Volume 2: EtherNet/IP Adaptation of CIP 	
Communication type	■ 10Base-T ■ 100Base-TX	
Device profile	Generic device (product type: 0x2B)	
Manufacturer ID	0x49E	
Device type ID	0x104A	
Baud rates	Automatic 10/100 Mbit with half-duplex and full-duplex detection	
Polarity	Auto-polarity for automatic correction of crossed TxD and RxD pairs	
Supported CIP connections	Max. 3 connections	
Explicit connections	Max. 6 connections	
I/O connections	Max. 6 connections (scanner)	
Configuration options for measuring device	 DIP switches on the electronics module for IP addressing Manufacturer-specific software (FieldCare) Add-on Profile Level 3 for Rockwell Automation control systems Web browser Electronic Data Sheet (EDS) integrated in the measuring device 	
Configuration of the EtherNet interface	 Speed: 10 MBit, 100 MBit, auto (factory setting) Duplex: half-duplex, full-duplex, auto (factory setting) 	

98

Configuration of the device address	 DIP switches on the electronics module for IP addressing (last octet) DHCP Manufacturer-specific software (FieldCare) Add-on Profile Level 3 for Rockwell Automation control systems Web browser EtherNet/IP tools, e.g. RSLinx (Rockwell Automation) No 		
Device Level Ring (DLR)			
Fix Input			
RPI	5 ms to 10 s (factory setting:	20 ms)	
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	$O \rightarrow T$ configuration:	0x66	64
	$T \rightarrow O$ configuration:	0x64	44
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	$O \rightarrow T$ configuration:	0x66	64
	$T \rightarrow O$ configuration:	0x64	44
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	$O \rightarrow T$ configuration:	0xC7	-
	$T \rightarrow O$ configuration:	0x64	44
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	$O \rightarrow T$ configuration:	0xC7	-
	$T \rightarrow O$ configuration:	0x64	44
Input Assembly	 Current device diagnostics Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1 Totalizer 2 Totalizer 3 		
Configurable Input			
RPI	5 ms to 10 s (factory setting:	20 ms)	,
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	$O \rightarrow T$ configuration:	0x66	64
	$T \rightarrow O$ configuration:	0x65	88
Exclusive Owner Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	$O \rightarrow T$ configuration:	0x66	64
	$T \rightarrow O$ configuration:	0x65	88
Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x68	398
	$O \rightarrow T$ configuration:	0xC7	-
	$T \rightarrow O$ configuration:	0x65	88

Input only Multicast		Instance	Size [byte]
	Instance configuration:	0x69	-
	O → T configuration:	0xC7	-
	$T \rightarrow O$ configuration:	0x65	88
Configurable Input Assembly	 Current device diagnostics Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1 Totalizer 2 Totalizer 3 The range of options increases if the measuring device has one or more application packages. 		
Fix Output			
Output Assembly	 Activation of reset totalizers 1-3 Activation of pressure compensation Activation of reference density compensation Activation of temperature compensation Reset totalizers 1-3 External pressure value Pressure unit External reference density Reference density unit External temperature Temperature unit 		
Configuration			
Configuration Assembly	Only the most common configurations are listed below. Software write protection Mass flow unit Volume flow unit Volume flow unit Corrected volume flow unit Corrected volume unit Density unit Reference density unit Temperature unit Pressure unit Length Totalizer 1-3: Assignment Unit Measuring mode Failsafe mode Alarm delay		

16.5 Power supply

(→ 🖺 30)
(→ 🖺 31)

Supply voltage

The power unit must be tested to ensure it meets safety requirements (e.g. PELV, SELV).

Transmitter

DC 20 to 30 V

Power consumption

Transmitter

Order code for "Output"	Maximum Power consumption
Option N: EtherNet/IP	3.5 W

Current consumption

Transmitter

Order code for "Output"	Maximum Current consumption	Maximum switch-on current
Option N : EtherNet/IP	145 mA	18 A (<0.125 ms)

Power supply failure

- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Electrical connection

(→ 🖺 31)

Potential equalization

(→ 🖺 33)

Terminals

Transmitter

Spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

Cable entries

- Cable gland: M20 \times 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
 - NPT ½"
 - G ½"
 - M20

Cable specification

(→ 🖺 29)

16.6 Performance characteristics

Reference operating conditions

- Error limits based on ISO 11631
- Water with +15 to +45 °C (+59 to +113 °F) at2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- Accuracy based on accredited calibration rigs that are traced to ISO 17025.

To obtain measured errors, use the *Applicator* sizing tool ($\Rightarrow \triangleq 94$)($\Rightarrow \triangleq 115$)

Maximum measured error

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base accuracy

Mass flow and volume flow (liquids)

±0.10 %

Mass flow (gases)

±0.50 % o.r.



Properties (→ Properties (→ Properties + Properties +

Density (liquids)

- Reference conditions:±0.0005 g/cm³
- Standard density calibration:±0.02 g/cm³ (valid over the entire temperature range and density range)
- Wide-range density specification (order code for "Application package", option EF "Special density and concentration"): ±0.002 g/cm³ (valid range for special density calibration: 0 to 2 g/cm³, +5 to +80 °C (+41 to +176 °F))

Temperature

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Zero point stability

DN		Zero poin	t stability
[mm]	[in]	[kg/h]	[lb/min]
1	1/24	0.0010	0.000036
2	1/12	0.0050	0.00018
4	1/8	0.0225	0.0008

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
1	20	2	1	0.4	0.2	0.04
2	100	10	5	2	1	0.2
4	450	45	22.5	9	4.5	0.9

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
1/24	0.735	0.074	0.037	0.015	0.007	0.001
1/12	3.675	0.368	0.184	0.074	0.037	0.007
1/8	16.54	1.654	0.827	0.331	0.165	0.033

Repeatability

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability

Mass flow and volume flow (liquids)

±0.05 % o.r.

Mass flow (gases)

±0.25 % o.r.



Design fundamentals ($\rightarrow \triangleq 103$)

Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$

Temperature

 $\pm 0.25 \,^{\circ}\text{C} \pm 0.0025 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.45 \,^{\circ}\text{F} \pm 0.0015 \cdot (\text{T}-32) \,^{\circ}\text{F})$

Response time

The response time depends on the configuration (damping).

Influence of medium temperature

Mass flow and volume flow


When there is a difference between the temperature for zero point adjustment and the process temperature, the typical measured error of the sensor is ±0.0002 % of the full scale value/°C (±0.0001 % of the full scale value/°F).

Density

When there is a difference between the density calibration temperature and the process temperature, the typical measured error of the sensor is ± 0.00005 g/cm³ /°C (± 0.000025 g/cm³ /°F). Field density calibration is possible.

Wide-range density specification (special density calibration)

If the process temperature is outside the valid range ($\rightarrow \triangleq 102$) the measured error is $\pm 0.00005 \text{ g/cm}^3 \text{ /°C } (\pm 0.000025 \text{ g/cm}^3 \text{ /°F})$



103

- Field density calibration, for example at +20 °C (+68 °F)
- Special density calibration

Temperature

 $\pm 0.005 \cdot \text{T} \, ^{\circ}\text{C} \, (\pm 0.005 \cdot (\text{T} - 32) \, ^{\circ}\text{F})$

Influence of medium pressure

A difference between the calibration pressure and process pressure does not affect accuracy.

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	NU021337
< ZeroPoint · 100	± ZeroPoint MeasValue · 100
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot ZeroPoint}{BaseRepeat} \cdot 100$	± BaseRepeat
A0021335	A0021340
$<\frac{\frac{1}{2} \cdot \text{ZeroPoint}}{\text{BaseRepeat}} \cdot 100$	± ½ · ZeroPoint MeasValue · 100
A0021336	A0021337

Example for max. measured error



- E Error: Maximum measured error as % o.r. (example)
- Q Flow rate as %

Page 103) Design fundamentals (→ 103)

16.7 Installation

"Mounting requirements" ($\rightarrow \triangleq 19$)

16.8 Environment

Ambient temperature range

Temperature tables

Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.

For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature	All components apart from the display modules: \blacksquare -40 to +80 °C (-40 to +176 °F), preferably at +20 °C (+68 °F) (standard version) \blacksquare -50 to +80 °C (-58 to +176 °F) (Order code for "Test, certificate", option JM)	
	Display modules	
	-40 to +80 °C (-40 to +176 °F)	
Climate class	DIN EN 60068-2-38 (test Z/AD)	
Degree of protection	Transmitter and sensor ■ As standard: IP66/67, type 4X enclosure ■ With the order code for "Sensor options", option CM: IP69K can also be ordered ■ When housing is open: IP20, type 1 enclosure ■ Display module: IP20, type 1 enclosure	
Shock resistance	As per IEC/EN 60068-2-31	
Vibration resistance	Acceleration up to 1 g, 10 to 150 Hz, based on IEC/EN 60068-2-6	
Interior cleaning	Sterilization in place (SIP)Cleaning in place (CIP)	
Electromagnetic compatibility (EMC)	 As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) Complies with emission limits for industry as per EN 55011 (Class A) 	
	For details refer to the Declaration of Conformity.	
	16.9 Process	
Medium temperature range	Sensor -50 to +200 °C (-58 to +392 °F)	
	Seals	
	• No internal seals	
	 For mounting sets with screwed-on connections: Viton:−15 to +200 °C (−5 to +392 °F) 	
	– EPDM:–40 to +160 °C (−40 to +320 °F)	
	– Silicon:–60 to +200 °C (−76 to +392 °F) – Kalrez:–20 to +275 °C (−4 to +527 °F)	
Density	0 to 5 000 kg/m³ (0 to 312 lb/cf)	
Pressure-temperature ratings	An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document	
Secondary containment pressure rating	The sensor housing is filled with dry nitrogen and protects the electronics and mechanic inside.	

The following secondary containment pressure rating is only valid for a fully welded sensor housing and/or a device equipped with closed purge connections (never opened/as delivered).

DN		Secondary containment pressure rating (designed with a safety factor ≥ 4)		Secondary contains	nent burst pressure
[mm]	[in]	[bar]	[psi]	[bar]	[psi]
1	1/24	25	362	175	2535
2	1/12	25	362	155	2245
4	1/8	25	362	130	1885

If there is a risk of measuring tube failure due to process characteristics, e.g. with corrosive fluids, we recommend the use of sensors whose secondary containment is equipped with special pressure monitoring connections (order code for "Sensor option", option CH "Purge connection").

With the help of these connections, the fluid collected in the secondary containment can be bled off in the event of tube failure. This is especially important in high-pressure gas applications. These connections can also be used for gas purging (gas detection).

Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low gauge pressure to purge. Maximum pressure: 5 bar (72.5 psi).

If a device fitted with purge connections is connected to the purge system, the maximum nominal pressure is determined by the purge system itself or by the device, depending on which component has the lower nominal pressure.

If, on the other hand, the device is fitted with a rupture disk, the rupture disk is decisive for the maximum nominal pressure ($\Rightarrow \triangleq 106$).

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Rupture disk

To increase the level of safety, a device version with a rupture disk with a triggering pressure of 10 to 15 bar (145 to 217.5 psi) can be used (order code for "Sensor option", option CA "rupture disk"). Special mounting instructions: $(\rightarrow \cong 23)$

Rupture disks cannot be combined with the separately available heating jacket ($\Rightarrow \triangleq 94$) ($\Rightarrow \triangleq 94$).

Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.

- For an overview of the measuring range full scale values, see the "Measuring range" section $(\rightarrow \ \ \)$
- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- In most applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
 - The flow velocity in the measuring tubes should not exceed half the sonic velocity (0.5 Mach).
 - The maximum mass flow depends on the density of the gas: formula ($\rightarrow \triangleq 96$)

106

Pressure loss

To calculate the pressure loss, use the *Applicator* sizing tool ($\rightarrow \implies 115$)

16.10 Mechanical construction

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Compact version

Weight in SI units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [kg].

DN [mm]	Weight [kg]
1	8
2	9
4	13

Weight in US units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [lbs].


DN [in]	Weight [lbs]
1/24	18
1/12	20
1/8	29

Materials

Transmitter housing

- Order code for "Housing", option A "Compact, aluminum coated": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option B "Compact, hygienic, stainless": Hygienic version, stainless steel 1.4301 (304)
- Order code for "Housing", option **C** "Ultra-compact, hygienic, stainless": Hygienic version, stainless steel 1.4301 (304)

Cable entries/cable glands



A0020640

■ 15 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G ½" or NPT ½"

Order Code for "Housing", Option A "Compact, coated aluminum"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Nickel-plated brass
Adapter for cable entry with internal thread G ½"	
Adapter for cable entry with internal thread NPT ½"	

Order code for "Housing", option B "Compact, hygienic, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread G ½"	
Adapter for cable entry with internal thread NPT ½"	

Device plug

Electrical connection	Material
Plug M12x1	 Socket: Stainless steel, 1.4404 (316L) Contact housing: Polyamide Contacts: Gold-plated brass

Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tubes

Stainless steel, 1.4539 (904L); Alloy C22, 2.4602 (UNS N06022)

Process connections

VCO coupling

- Stainless steel, 1.4539 (904L)
- Alloy C22, 2.4602 (UNS N06022)

Tri-Clamp

Stainless steel, 1.4539 (904L)

Mounting kit, flanges as per EN 1092-1 (DIN 2501), ASME B16.5, JIS B2220


- Stainless steel, 1.4539 (904L)
- Alloy C22, 2.4602 (UNS N06022)

Mounting kit, lap joint flanges as per EN 1092-1 (DIN 2501), ASME B16.5, JIS B2220 Stainless steel, 1.4404 (316/316L)

Mounting kit, SWAGELOK Stainless steel, 1.4539 (904L)

Mounting kit, NPTF

- Stainless steel, 1.4539 (904L)
- Alloy C22



Surface quality (parts in contact with medium)

- Not polished
- $Ra_{max} = 0.8 \mu m (32 \mu in)$
- $Ra_{max} = 0.4 \mu m (16 \mu in)$

Seals


Welded process connections without internal seals

Seals for mounting kit

- Viton
- EPDM
- Silicone
- Kalrez

Process connections

- Flanges:
 - EN 1092-1 (DIN 2501)
 - EN 1092-1 (DIN 2512N)
 - ASME B16.5
 - JIS B2220
- VCO connections
- Tri-Clamp (OD tubes)
- Mounting kits
 - SWAGELOK
 - NPTF



16.11 Operability


Local display

The local display is only available with the following device order code: Order code for "Display; Operation", option **B**: 4-line; lit, via communication

Display element

- 4-line liquid crystal display with 16 characters per line.
- White background lighting; switches to red in event of device errors.
- Format for displaying measured variables and status variables can be individually configured.
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F). The readability of the display may be impaired at temperatures outside the temperature range.

Disconnecting the local display from the main electronics module



"Compact, aluminum coated" housing version

The local display is plugged onto the main electronics module. The electronic connection between the local display and main electronics module is established via a connecting cable.

For some work performed on the measuring device (e.g. electrical connection), it is advisable to disconnect the local display from the main electronics module:


- 1. Press in the side latches of the local display.
- 2. Remove the local display from the main electronics module. Pay attention to the length of the connecting cable when doing so.

Once the work is completed, plug the local display back on.

Remote operation

Via Ethernet-based fieldbus

This communication interface is available in device versions with EtherNet/IP.




₽ 16 Options for remote operation via Ethernet-based fieldbus

- 1 Ethernet network
- Automation system, e.g. "RSLogix" (Rockwell Automation)
- 3 Workstation for measuring device operation: with Add-on Profile Level 3 for "RSLogix 5000" (Rockwell Automation) or with Electronic Data Sheet (EDS)
- Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 5 Ethernet switch
- Measuring device

Service interface

Via service interface (CDI-RJ45)

EtherNet/IP



■ 17 Connection for order code for "Output", option N: EtherNet/IP

- Service interface (CDI -RJ45) and EtherNet/IP interface of the measuring device with access to the integrated Web server
- Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with 2 "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 3 Standard Ethernet connecting cable with RJ45 plug

Languages

Can be operated in the following languages:

- Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese
- Via Web browser English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech

112

16.12 Certificates and approvals

CE mark	The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.		
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.		
C-Tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".		
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.		
Hygienic compatibility	3A approvalEHEDG-tested		
EtherNet/IP certification	The measuring device is certified and registered by the ODVA (Open Device Vendor Association). The measuring system meets all the requirements of the following specifications: Certified in accordance with the ODVA Conformance Test EtherNet/IP Performance Test EtherNet/IP PlugFest compliance The device can also be operated with certified devices of other manufacturers (interoperability)		
Other standards and guidelines	 EN 60529 Degrees of protection provided by enclosures (IP code) IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal). IEC/EN 60068-2-31 Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices. EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control 		

equipment

 NAMUR NE 32
 Data retention in the event of a power failure in field and control instruments with microprocessors

■ NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices $% \left(1\right) =\left(1\right) \left(1\right) \left$

- NAMUR NE 107
 Self-monitoring and diagnosis of field devices
- NAMUR NE 131
 Requirements for field devices for standard applications
- NAMUR NE 132
 Coriolis mass meter

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Detailed information on the application packages: Special Documentation on the device

Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	Heartbeat Monitoring: Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to: Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time. Schedule servicing in time. Monitor the product quality, e.g. gas pockets.
	 Heartbeat Verification: Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process. Access via onsite operation or other operating interfaces, such as FieldCare for instance. Documentation of device functionality within the framework of manufacturer specifications, for proof testing for instance. End-to-end, traceable documentation of the verification results, including report. Makes it possible to extend calibration intervals in accordance with operator's risk assessment.

Concentration

Package	Description
Concentration measurement and special density	Calculation and outputting of fluid concentrations Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system. The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.
	With the help of the "Concentration Measurement" application package, the measured density is used to calculate other process parameters: Temperature-compensated density (reference density). Percentage mass of the individual substances in a two-phase fluid. (Concentration in %). Fluid concentration is output with special units ("Brix, "Baumé, "API, etc.) for standard applications. The measured values are output via the digital and analog outputs of the device.

16.14 Accessories

 \bigcap i Overview of accessories available for order (\rightarrow \bigcirc 94)

16.15 Documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Promass A 100	KA01144D

Technical Information

Measuring device	Documentation code
Promass A 100	TI01104D

Supplementary devicedependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEx Ex i	XA00159D
ATEX/IECEx Ex nA	XA01029D
cCSAus IS	XA00160D
INMETRO Ex i	XA01219D
INMETRO Ex nA	XA01220D
NEPSI Ex i	XA01249D
NEPSI Ex nA	XA01262D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD00142D
Concentration Measurement	SD01152D
Heartbeat Technology	SD01153D

Installation instructions

Contents	Documentation code	
Installation Instructions for spare part sets	Specified for each individual accessory $(\rightarrow \stackrel{\cong}{=} 94)$	
	Overview of accessories available for order $(\rightarrow \ \ \ \ \ \)$	


17 Appendix

17.1 Overview of the operating menu

The following graphic provides an overview of the entire operating menu structure with its menus, submenus and parameters. The page reference indicates where a description of the parameter can be found in the manual.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

For the Order Code "Application Package", the associated parameters are described in the Special Documentation.



17.1.1 "Operation" menu

Operation

Navigation

Operation (→ 🖺 68) Display language (→ 🖺 64) Access status tooling Locking status **▶** Display (→ 🖺 62) Format display (→ 🖺 63) Contrast display Backlight (→ 🖺 65) Display interval (→ 🖺 64) ► Totalizer handling Control Totalizer 1 to 3 (→ 🖺 72)

Preset value 1 to 3	(→ 🖺 72)
Reset all totalizers	(→ 🖺 72)

17.1.2 "Setup" menu

Navigation 📵 🖺 Setup

⊁ Setup		(→ 🖺 51)
► Sys	stem units	
	Mass flow unit	(→ 🖺 53)
	Mass unit	(→ 🖺 53)
	Volume flow unit	(→ 🖺 53)
	Volume unit	(→ 🖺 53)
	Corrected volume flow unit	(→ 🖺 53)
	Corrected volume unit	(→ 🖺 53)
	Density unit	(→ 🖺 53)
	Reference density unit	(→ 🖺 53)
	Temperature unit	(→ 🖺 53)
	Pressure unit	(→ 🖺 53)
► Me	edium selection	
	Select medium	(→ 🖺 54)
	Select gas type	(→ 🖺 54)
	Reference sound velocity	(→ 🖺 54)
	Temperature coefficient sound velocity	(→ 🖺 54)
	Pressure compensation	(→ 🖺 54)
	Pressure value	(→ 🖺 54)
	External pressure	(→ 🖺 54)

118

Communication	
▶ Communication	
MAC address	
Default network settings	
DHCP client	
IP address	
Subnet mask	
Default gateway	
► Low flow cut off	
Assign process variable	
On value low flow cutoff	
Off value low flow cutoff	
Pressure shock suppression	
▶ Partially filled pipe detection	
Assign process variable	
Low value partial filled pipe detec	ction
High value partial filled pipe dete	ection
Response time part. filled pipe de	etect.
► Advanced setup	
Enter access code	
► Calculated values	
► Corrected	i volume flow calculation
	Corrected volume flow calculation
	External reference density
	Fixed reference density
	Reference temperature
	Reference temperature

	Linear expansion coefficient	(→ 🖺 59)
	Square expansion coefficient	(→ 🖺 59)
► Sensor	adjustment	(→ 🖺 59)
	Installation direction	(→ 🖺 60)
	► Zero point adjustment	
	Zero point adjustment control	(→ 🖺 60)
	Progress	(→ 🖺 60)
► Totalize	er 1 to 3	(→ 🖺 60)
	Assign process variable	(→ 🖺 60)
	Unit totalizer	(→ 🖺 60)
	Totalizer operation mode	(→ 🖺 61)
	Failure mode	(→ 🖺 61)
► Display		(→ 🖺 62)
	Format display	(→ 🖺 63)
	Value 1 display	(→ 🖺 63)
	0% bargraph value 1	(→ 🖺 63)
	100% bargraph value 1	(→ 🖺 63)
	Decimal places 1	(→ 🖺 64)
	Value 2 display	(→ 🖺 64)
	Decimal places 2	(→ 🖺 64)
	Value 3 display	(→ 🖺 64)
	0% bargraph value 3	(→ 🖺 64)
	100% bargraph value 3	(→ 🖺 64)
	Decimal places 3	(→ 🖺 64)
	Value 4 display	(→ 🖺 64)
	Decimal places 2 Value 3 display 0% bargraph value 3 100% bargraph value 3 Decimal places 3	$(\rightarrow \stackrel{\triangle}{=} 64)$ $(\rightarrow \stackrel{\triangle}{=} 64)$ $(\rightarrow \stackrel{\triangle}{=} 64)$ $(\rightarrow \stackrel{\triangle}{=} 64)$

	Decimal places 4	(→ 🖺 64)
	Display language	(→ 🖺 64)
	Display interval	(→ 🖺 64)
	Display damping	(→ 🖺 64)
	Header	(→ 🖺 64)
	Header text	(→ 🖺 64)
	Separator	(→ 🖺 65)
	Backlight	(→ 🖺 65)
► Viscosity		
	► Temperature compensation	
	Calculation model	
	Reference temperature	
	Compensation coefficient X 1	
	Compensation coefficient X 2	
	► Dynamic viscosity	
	Dynamic viscosity unit	
	User dynamic viscosity text	
	User dynamic viscosity factor	
	User dynamic viscosity offset	
	► Kinematic viscosity	
	Kinematic viscosity unit	
	User kinematic viscosity text	
	User kinematic viscosity factor	
	User kinematic viscosity offset	

► Concentration		
	Concentration unit	
	User concentration text	
	User concentration factor	
	User concentration offset	
	A 0	
	A 1	
	A 2	
	A 3	
	A 4	
	B1	
	B 2	
	B 3	
► Heartbeat setup		
	► Heartbeat Monitoring	
	Activate monitoring	
► Administration		(→ 🖺 87)
	Define access code	
	Device reset	(→ 🖺 88)

17.1.3 "Diagnostics" menu

♥ Diagnostics		(→ 🖺 84)
	Actual diagnostics	(→ 🖺 85)
	Timestamp	

Previous diag	nostics	(→ 🖺 85
Timestamp		
Operating tim	ne from restart	
Operating tim	ie e	
► Diagnostic	list	
	Diagnostics 1	
	Timestamp	
	Diagnostics 2	
	Timestamp	
	Diagnostics 3	
	Timestamp	
	Diagnostics 4	
	Timestamp	
	Diagnostics 5	
	Timestamp	
► Event logb	ook	
	Filter options	
► Device info	ormation	(→ 🖺 88
	Device tag	(→ 🖺 89
	Serial number	(→ 🖺 89
	Firmware version	(→ 🖺 89
	Device name	(→ 🖺 89
	Order code	(→ 🖺 89
	Extended order code 1	(→ 🖺 89
	Extended order code 2	(→ 🖺 89

	Extended order cod	le 3	(→ 🖺 89)
	ENP version		(→ 🖺 89)
	IP address		(→ 🖺 89)
	Subnet mask		(→ 🖺 89)
	Default gateway		(→ 🖺 89)
► Measured value	es		
	▶ Process variable	es	(→ 🖺 69)
		Mass flow	(→ 🖺 70)
		Volume flow	(→ 🖺 70)
		Corrected volume flow	(→ 🖺 70)
		Density	(→ 🖺 70)
		Reference density	(→ 🖺 70)
		Temperature	(→ 🖺 70)
		Pressure value	(→ 🖺 70)
		Dynamic viscosity	
		Kinematic viscosity	
		Temp. compensated dynamic viscosity	
		Temp. compensated kinematic viscosity	
		Concentration	
		Target mass flow	
		Carrier mass flow	
	► Totalizer	Carret mass now	(→ 🖺 60)
	r Totanzei	Tetalina value 1 to 2	
		Totalizer value 1 to 3	(→ 🖺 70)
		Totalizer overflow 1 to 3	(→ 🖺 70)


► Heartbeat		1	
► Heartbeat			
	► Performing ver	ification	
		Year	
		M. II	
		Month	
		Day	
		Hour	
		AM/PM	
		Minute	
		Start verification	
		Progress	(→ 🖺 60)
		Status	
		Overall result	
	► Verification res	ults	
		Date/time	
		Verification ID	
		Operating time	
		Overall result	
		Sensor	
		Sensor integrity	
		Sensor electronic module	
		I/O module	
	► Monitoring res	ults	
		Sensor integrity	
▶ Simulation			(→ 🖺 65)
	Assign simulation	process variable	(→ 🖺 66)

Value process variable	(→ 🖺 66)
Simulation device alarm	(→ 🖺 66)
Simulation diagnostic event	(→ 🖺 66)

17.1.4 "Expert" menu

The following tables provide an overview of the **Expert** menu with its submenus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.

"System" submenu




	Value 4 display		(→ 🖺 64)
	Decimal places 4		(→ 🖺 64)
	Display interval		(→ 🖺 64)
	Display damping		(→ 🖺 64)
	Header		(→ 🖺 64)
	Header text		(→ 🖺 64)
	Separator		(→ 🖺 65)
	Contrast display		
	Backlight		(→ 🖺 65)
	Access status displa	ру	
▶ Diagnostic han	dling		
	Alarm delay		
	► Diagnostic behav	vior	
		Assign behavior of diagnostic no. 140	
		Assign behavior of diagnostic no. 046	
		Assign behavior of diagnostic no. 144	
		Assign behavior of diagnostic no. 832	
		Assign behavior of diagnostic no. 833	
		Assign behavior of diagnostic no. 834	
		Assign behavior of diagnostic no. 835	
		Assign behavior of diagnostic no. 912	
		Assign behavior of diagnostic no. 913	
		Assign behavior of diagnostic no. 944	
		Assign behavior of diagnostic no. 948	
		Assign behavior of diagnostic no. 192	

		Assign behavior of diagnostic no. 274	
		Assign behavior of diagnostic no. 392	
		Assign behavior of diagnostic no. 592	
		Assign behavior of diagnostic no. 992	
► Administration			(→ 🖺 87)
	Define access code		
	Device reset		(→ 🖺 88)
	Activate SW option		
	Software option ove	rview	

"Sensor" submenu

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Sensor



128

_				
			Temp. compensated kinematic viscosity	
			Concentration	
			Target mass flow	
			Carrier mass flow	
		► Totalizer		(→ 🖺 60)
			Totalizer value 1 to 3	(→ 🖺 70)
			Totalizer overflow 1 to 3	(→ 🗎 70)
	► System units			
	3			() (3,50)
		Mass flow unit		(→ 🖺 53)
		Mass unit		(→ 🖺 53)
		Volume flow unit		(→ 🖺 53)
		Volume unit		(→ 🖺 53)
		Corrected volume f	low unit	(→ 🖺 53)
		Corrected volume t	ınit	(→ 🖺 53)
		Density unit		(→ 🖺 53)
		Reference density	unit	(→ 🖺 53)
		Temperature unit		(→ 🖺 53)
		Pressure unit		(→ 🖺 53)
		Date/time format		
		► User-specific u	nits	
			User mass text	
			User mass offset	
			User mass factor	
			User volume text	
			User volume offset	
L				

		User volume factor	
		User corrected volume text	
		User corrected volume offset	
		User corrected volume factor	
		User density text	
		User density offset	
		User density factor	
		User pressure text	
		User pressure offset	
		User pressure factor	
► Process parame	eters		
	Flow damping		
	Density damping		
	Temperature damp	ing	
	Flow override		
	▶ Low flow cut off		(→ 🖺 56)
		Assign process variable	(→ 🖺 56)
		On value low flow cutoff	(→ 🖺 56)
		Off value low flow cutoff	(→ 🖺 56)
		Pressure shock suppression	(→ 🖺 56)
	▶ Partially filled p	ipe detection	(→ 🖺 57)
		Assign process variable	(→ 🖺 57)
		Low value partial filled pipe detection	(→ 🖺 57)
		High value partial filled pipe detection	(→ 🖺 57)

	Response time part. filled pipe detect.	(→ 🖺 57)
	Maximum damping partial filled pipe	
	det.	
► Measurement mode		
Wiedstrement mode		
Select medium		(→ 🖺 54)
Select gas type		(→ 🖺 54)
Reference sound	velocity	(→ 🖺 54)
Temperature coef	fficient sound velocity	(→ 🖺 54)
► External compensation		
Pressure compens	sation	(→ 🖺 54)
Pressure value		(→ 🖺 54)
External pressure		(→ 🖺 54)
Temperature mod	de	
External tempera	ture	
► Calculated values		(→ 🖺 58)
► Corrected volu	ume flow calculation	
	Corrected volume flow calculation	(→ 🖺 59)
	External reference density	(→ 🖺 59)
	Fixed reference density	(→ 🖺 59)
	Reference temperature	(→ 🖺 59)
	Linear expansion coefficient	(→ 🖺 59)
	Square expansion coefficient	(→ 🖺 59)
► Sensor adjustment		(→ 🖺 59)
Installation direct	tion	(→ 🖺 60)

	► Zero point adjust	tment	
		Zero point adjustment control	(→ 🖺 60)
		Progress	(→ 🖺 60)
	► Process variable	adjustment	
		Mass flow offset	
		Mass flow factor	
		Volume flow offset	
		Volume flow factor	
		Density offset	
		Density factor	
		Corrected volume flow offset	
		Corrected volume flow factor	
		Reference density offset	
		Reference density factor	
		Temperature offset	
		Temperature factor	
► Calibration			
	Calibration factor		
	Zero point		
	Nominal diameter		
	С		
	С		
	С		
	С		

132

	С
	С
► Testpoints	
	Oscillation frequency
	Oscillation frequency
	Oscillation frequency
	Frequency fluctuation
	Frequency fluctuation
	Oscillation amplitude
	Oscillation amplitude
	Oscillation damping
	Oscillation damping
	Tube damping fluctuation
	Tube damping fluctuation
	Signal asymmetry
	Electronic temperature
	Carrier pipe temperature
	Exciter current
	Exciter current
	RawMassFlow
► Supervision	
	Limit value measuring tube damping

"Current input" submenu

Navigation \blacksquare Expert \rightarrow Input \rightarrow Current input

► Input			
	► Status input		
		Assign status input	
		Value status input	
		Active level	
		Response time status input	

► Output	
► Pulse/fr to 2	requency/switch output 1
	Operating mode
	Channel 2
	Assign pulse output
	Value per pulse
	Pulse width
	Measuring mode
	Failure mode
	Pulse output $(\rightarrow \ \ \ \)$ 71)
	Assign frequency output
	Minimum frequency value
	Maximum frequency value
	Measuring value at maximum frequency
	Measuring mode

Damping output	
Failure mode	
Failure frequency	
Output frequency	(→ 🖺 71)
Switch output function	
Assign diagnostic behavior	
Assign limit	
Switch-on value	
Switch-off value	
Assign flow direction check	
Assign status	
Failure mode	
Switch status	(→ 🖺 71)
Invert output signal	(, =,1)
nivert output signal	

► Communication		(→ 🖺 51)
► Configuration		
	Web server language	
	MAC address	(→ 🖺 55)
	Default network settings	(→ 🖺 55)
	DHCP client	(→ 🖺 55)
	IP address	(→ 🖺 55)
	Subnet mask	(→ 🖺 55)
	Default gateway	(→ 🖺 55)

Web server functionality (→ 🖺 42) ► Configurable input assembly Input assembly position 1 Input assembly position 2 Input assembly position 3 Input assembly position 4 Input assembly position 5 Input assembly position 6 Input assembly position 7 Input assembly position 8 Input assembly position 9 Input assembly position 10 Input assembly position 11Input assembly position 12 Input assembly position 13 Input assembly position 14 Input assembly position 15 Input assembly position 16 Input assembly position 17 Input assembly position 18 Input assembly position 19 Input assembly position 20

Reset all totalizers (→ 🖺 72)

136

► Totali	izer 1 to 3	(→ 🖺 60)
	Assign process variable	(→ 🖺 60)
	Unit totalizer	(→ 🖺 60)
	Totalizer operation mode	(→ 🖺 61)
	Control Totalizer 1 to 3	(→ 🖺 72)
	Preset value 1 to 3	(→ 🖺 72)
	Failure mode	(→ 🖺 61)
► Viscos	sity	
	Viscosity damping	
	► Temperature compensation	
	Calculation model	
	Reference temperature	
	Compensation coefficient X 1	
	Compensation coefficient X 2	
	▶ Dynamic viscosity	
	Dynamic viscosity unit	
	User dynamic viscosity text	
	User dynamic viscosity factor	
	User dynamic viscosity offset	
	► Kinematic viscosity	
	Kinematic viscosity unit	
	User kinematic viscosity text	

	User kinematic viscosity factor
	User kinematic viscosity offset
▶ Concentration	
Concentration da	mping
Concentration un	uit
User concentration	on text
User concentration	on factor
User concentration	on offset
A 0	
A 1	
A 2	
A 3	
A 4	
B 1	
B 2	
В 3	

▶ Diagnostics	(→ 🖺 84)
Actual diagnostics	(→ 🖺 85)
Timestamp	
Previous diagnostics	(→ 🖺 85)
Timestamp	
Operating time from restart	
Operating time	

▶ Diagnostic list			
	Diagnostics 1		
	Timestamp		
	Diagnostics 2		
	Timestamp		
	Diagnostics 3		
	Timestamp		
	Diagnostics 4		
	Timestamp		
	Diagnostics 5		
	Timestamp		
► Event logbook			
	Filter options		
► Device information	ion	_	(→ 🖺 88)
	Device tag		(→ 🖺 89)
	Serial number]	(→ 🖺 89)
	Firmware version]	(→ 🖺 89)
	Device name	-]	(→ 🖺 89)
	Order code	-]	(→ 🖺 89)
	Extended order code 1]	(→ 🖺 89)
	Extended order code 2]	(→ 🖺 89)
	Extended order code 3		(→ 🖺 89)
	Configuration counter]	•
	ENP version]	(→ 🖺 89)
			,

► Min/max values	
Reset min/max valu	lues
► Electronic tempe	perature
	Minimum value
	Maximum value
► Medium tempera	erature
	Minimum value
	Maximum value
► Carrier pipe tem	mperature
	Minimum value
	Maximum value
► Oscillation frequ	quency
	Minimum value
	Maximum value
► Torsion oscillation	tion frequency
	Minimum value
	Maximum value
► Oscillation ampl	plitude
	Minimum value
	Maximum value
► Torsion oscillation	tion amplitude
	Minimum value
	Maximum value

	► Oscillation dam	pping		
		Minimum value		
		Maximum value		
	► Torsion oscillat	ion damping		
		Minimum value		
		Maximum value		
	► Signal asymme	try		
		Minimum value		
		Maximum value		
► Heartbeat			-	
	► Performing ver	ification		
		Year		
		Month		
		Day		
		Hour		
		AM/PM		
		Minute		
		Start verification		
		Progress		(→ 🖺 60)
		Status		
		Overall result		
	► Verification res	ults		
		Date/time		
		Verification ID		
		Operating time		

	Overall result	
	Sensor	
	6	
	Sensor integrity	
	Sensor electronic module	
	I/O module	
► Heartbea	at Monitoring	
	Activate monitoring	
► Monitori	ing results	
	Sensor integrity	
▶ Simulation		(→ 🖺 65)
Assign simu	ulation process variable	(→ 🖺 66)
Value proce	ess variable	(→ 🖺 66)
Simulation	device alarm	(→ 🖺 66)
Simulation	diagnostic event	(→ 🖺 66)

Index

A	Supplementary documentation 8
Accuracy	Device locking, status
Adapting the diagnostic behavior 82	Device name
Ambient temperature range 21	Sensor
Application	Transmitter
Application packages	Device repair
Applicator	Device revision
Approvals	Device type ID
C	Explanation
C-Tick symbol	Symbols
Cable entries	Diagnostic information
Technical data	Communication interface 81
Cable entry	Design, description
Degree of protection	FieldCare
CE mark	Light emitting diodes
Certificates	Local display
Check	Overview
Installation	Remedial measures 82
Checklist	Web browser
Post-connection check	Diagnostic list
Post-installation check	Diagnostic message
Cleaning	Diagnostics
Cleaning in place (CIP)	Symbols
Exterior cleaning	Diagnostics (Menu)
Interior cleaning	DIP switch
Sterilization in place (SIP)	see Write protection switch
Cleaning in place (CIP)	Disabling write protection 66
Climate class	Display
Commissioning	Current diagnostic event
Advanced settings	Previous diagnostic event 84
Configuring the measuring device 51	Display values
Connecting cable	For locking status
Connecting the measuring device	Disposal
Connection	Document
see Electrical connection	Function 6
Connection preparations	Symbols used 6
Connection tools	Document function 6
Current consumption	Down pipe
Current input (Submenu)	.
Cyclic data transmission 47	<u>E</u>
D	Electrical connection
D	Degree of protection
Declaration of Conformity	Measuring device
Define access code	Operating tools
Degree of protection	Via Ethernet network 43, 111
Density	Via service interface (CDI-RJ45) 44, 112
Design	RSLogix 5000
Measuring device	Web server
Design fundamentals	Electromagnetic compatibility
Maximum measured error	Enabling write protection
Repeatability	Endress+Hauser services
Designated use	Maintenance
Device components	Repair
Device description files	Environment
Device documentation	Storage temperature

Error messages see Diagnostic messages	System pressure
EtherNet/IP	Vibrations
Diagnostic information	Installation dimensions
EtherNet/IP certification	Interior cleaning
Event history	L
Events list	Languages, operation options
Ex approval	Languages, operation options
Expert (Menu)	see Diagnostic message
Sensor	see In alarm condition
Transmitter	Low flow cut off
Exterior cleaning	
	M
F	Main electronics module
Field of application	Maintenance tasks
Residual risks	Manufacturer ID
FieldCare	Manufacturing date
Device description file	Maximum measured error
Establishing a connection	Measured variables
User interface	see Process variables
Filtering the event logbook	Measuring and test equipment 91
Firmware	Measuring device
Release date	Configuration
Version	Conversion
Firmware history	Design
Fix assembly	Disposal
Flow direction	Mounting the sensor 27
Flow limit	Preparing for electrical connection 31
Function check	Preparing for mounting 26
Functions	Removing
see Parameters	Repair
G	Measuring principle
	Measuring range
Galvanic isolation	Calculation example for gas
Н	For liquids
Hardware write protection	Measuring range, recommended
Hygienic compatibility	Measuring system
	Media
I	Medium pressure
I/O electronics module	Influence
Identifying the measuring device	Medium temperature
Incoming acceptance	Influence
Influence	Menu
Medium pressure	Diagnostics
Medium temperature	Expert
Information on the document	Operation
Inlet runs 20 Input 96	Setup
Inspection	Menus
Received goods	For measuring device configuration
Inspection check	For specific settings
Connection	Mounting dimensions see Installation dimensions
Installation	Mounting location
Installation conditions	Mounting preparations
Down pipe	Mounting requirements
Mounting location	Inlet and outlet runs
Rupture disk	

Installation dimensions	Power consumption
Sensor heating	Pressure loss
Mounting tools	Pressure-temperature ratings
N	Process connections
Nameplate	Process variables
Sensor	Calculated
Transmitter	Measured
Nominal pressure	Product safety
Secondary containment	Protecting parameter settings 66
Secondary contaminent	R
0	
Operable flow range	Reading measured values
Operating elements	Recalibration
Operating menu	Reference operating conditions
Menus, submenus	
Overview of menus with parameters	Registered trademarks
Structure	
Submenus and user roles	Clasing up
Operating philosophy	Closing
Operation	Remote operation
Operation (Menu)	Repair
Operation options	Notes
Operational safety	Repair of a device
Order code	Repeatability
Orientation (vertical, horizontal)	Replacement
Outlet runs	Device components
	Requirements for personnel
Output	Response time
Output signal	Return
Overview 117	Rupture disk
Operating menu	Safety instructions
P	Triggering pressure
Packaging disposal	S
Parameter settings	Safety
Administration (Submenu)	Seals
Calculated values (Submenu)	Medium temperature range
Communication (Submenu)	Sensor
Device information (Submenu)	Medium temperature range
Diagnostics (Menu)	Mounting
Display (Submenu) 62	Sensor (Submenu)
Low flow cut off (Wizard)	Sensor heating
Operation (Submenu)	Serial number
Output values (Submenu)	Setting the operating language
Partially filled pipe detection (Wizard) 57	Setting the operating language
Process variables (Submenu)	Adapting the measuring device to the process
Select medium (Submenu)	conditions
Sensor adjustment (Submenu)	Advanced display configurations 62
Setup (Menu)	Communication interface
Simulation (Submenu)	Device reset
Totalizer (Submenu)	
Totalizer 1 to 3 (Submenu) 60	Device tag
Web server (Submenu)	Low flow cut off
Performance characteristics	Medium
Post-connection check (checklist)	Operating language
Post-installation check	Partial filled pipe detection
Post-installation check (checklist)	Resetting the totalizer
Potential equalization	Sensor adjustment
1 otendar equalization	Simulation

System units	
Totalizer	
Totalizer reset	
Setup (Menu)	
Shock resistance	
Signal on alarm	
Software release	
Spare part	
Special connection instructions	
Standards and guidelines	
Status signals	
Sterilization in place (SIP)	
Storage conditions	
Storage temperature	
Storage temperature range	
Structure	
Operating menu	37
Submenu	
Administration	
Advanced setup	
Calculated values	
Communication	
Current input	
Define access code	
Device information	
Events list	
Operation	
Output values	–
Overview	
Process variables	
Select medium	
Sensor	
Sensor adjustment	
Simulation	65
System	
Totalizer	
Totalizer 1 to 3	
Web server	
Supply voltage	
System (Submenu)	. 126
System design Magguring system	96
Measuring system	50
System file	
Release date	46
Source	
Version	
System integration	
System pressure	
T	
Technical data, overview	96
Temperature range	40-
Medium temperature	
Storage temperature	
Terminal assignment	
TEITHIIIdly	. 101

Thermal insulation	21
Electrical connection	29 26 17
Transmitter Connecting the signal cables	32 27 17
General	
U	
Use of the measuring device Borderline cases	
User roles	38
V Version data for the device Vibration resistance 1 Vibrations	L05
W W@M	
Weight SI units 1 Transport (notes) US units	17
Wizard Define access code	56 57
	10
Write protection Via access code	66 67



