
Valid as of version 01.03.zz (Device firmware)

Operating Instructions **Proline Promass H 100 Modbus RS485**

Coriolis flowmeter





- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Document information 5		6.1.2 Requirements from environment and	
1.1 1.2	Document function	6.2	process	22 23 23 23 23
1.3	Documentation 6	7	Electrical connection	25
1.4	1.3.1 Standard documentation	7.1	Connection conditions	25 25 27
2	Basic safety instructions 8		7.1.4 Pin assignment, device plug7.1.5 Shielding and grounding	
2.1 2.2 2.3 2.4 2.5 2.6	Requirements for the personnel 8 Designated use 8 Workplace safety 9 Operational safety 9 Product safety 9 IT security 9	7.2 7.3	7.1.6 Preparing the measuring device	31 31 31 33 33 34
3	Product description 11	7.4	7.3.1 Connection examples	
3.1	Product design	7. 4 7.5 7.6	7.4.1 Enabling the terminating resistor Ensuring the degree of protection	34 35
4	Incoming acceptance and product	8	Operation options	37
4.1 4.2	identification12Incoming acceptance12Product identification124.2.1Transmitter nameplate134.2.2Sensor nameplate144.2.3Promass 100 safety barrier154.2.4Symbols on measuring device15	8.1 8.2 8.3	Overview of operation options	38 38 39 39
5	Storage and transport 16	9	System integration	42
5.1 5.2	Storage conditions	9.1	Overview of device description files	42 42 42 42
5.3 6	Packaging disposal		9.2.2Register information9.2.3Response time9.2.4Modbus data map	43
6 6.1	Installation18Installation conditions18	10	Commissioning	46
O. I	6.1.1 Mounting position	10.1	Function check	46

L0.3 L0.4	Setting the operating language Configuring the measuring device		12.11	Resetting the measuring device	76
10.4	10.4.1 Defining the tag name			parameter	76
	10.4.2 Setting the system units	47	12 12	Device information	
	10.4.3 Selecting and setting the medium	49		Firmware history	
	10.4.4 Configuring the communication		12,17		
	interface	50 52	13	Maintenance	
	10.4.6 Configuring the partial filled pipe		13.1	Maintenance tasks	
	detection	53		13.1.1 Exterior cleaning	
L0.5	Advanced settings	54	13.2	Measuring and test equipment	
	10.5.1 Calculated values		13.3	Endress+Hauser services	79
	10.5.2 Carrying out a sensor adjustment		1,	n .	00
	10.5.3 Configuring the totalizer		14	Repair	
L0.6	Simulation	5/	14.1	General notes	
LO.7	Protecting settings from unauthorized access	58	14.2	Spare parts	
	10.7.1 Write protection via access code		14.3	Endress+Hauser services	
	10.7.2 Write protection via write protection		14.4	Return	
	switch	59	14.5	Disposal	
				14.5.1 Removing the measuring device	
11	Operation	60		14.5.2 Disposing of the measuring device	01
11.1	Reading device locking status	60	15	Accessories	82
L1.2	Adjusting the operating language		15.1	Device-specific accessories	82
L1.3	Configuring the display	60		15.1.1 For the sensor	
L1.4	Reading measured values		15.2	Service-specific accessories	82
	11.4.1 Process variables		15.3	System components	83
	11.4.2 Totalizer	62			
l 1.5	11.4.3 Output values	OZ	16	Technical data	84
	conditions		16.1	Application	
l1.6	Performing a totalizer reset	63	16.2	Function and system design	
			16.3	Input	
12	Diagnostics and troubleshooting	64	16.4	Output	
L2.1	General troubleshooting	64	16.5 16.6	Power supply	
12.2	Diagnostic information via light emitting			Performance characteristics	
	diodes			Environment	
	12.2.1 Transmitter			Process	
	12.2.2 Safety Barrier Promass 100			Mechanical construction	94
L2.3	Diagnostic information on local display			Operability	96
	12.3.1 Diagnostic message	66		Certificates and approvals	97
12 /	12.3.2 Calling up remedial measures	68		Application packages	98
L2.4	Diagnostic information in FieldCare	68 68		Accessories	99
	12.4.2 Calling up remedy information		16.15	Documentation	99
12.5	Diagnostic information via communication	, 0			_
	interface	70	17	Appendix	.01
	12.5.1 Reading out diagnostic information	70	17.1	Overview of the operating menu	101
	12.5.2 Configuring error response mode	70		17.1.1 "Operation" menu	
12.6	Adapting the diagnostic information	71		17.1.2 "Setup" menu	
	12.6.1 Adapting the diagnostic behavior			17.1.3 "Diagnostics" menu	
12.7	Overview of diagnostic information	71		17.1.4 "Expert" menu	109
12.8	Pending diagnostic events	73			
L2.9	Diagnostic list	74 74	Index		25
LZ.IU					
	12.10.1 Event history				

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning
⚠ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
▲ WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
▲ CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	Direct current	~	Alternating current
≂	Direct current and alternating current	 	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.	♦	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Tool symbols

Symbol	Meaning
06	Allen key
Ø.	Open-ended wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning	
\checkmark	Permitted Procedures, processes or actions that are permitted.	
	Preferred Procedures, processes or actions that are preferred.	
X	Forbidden Procedures, processes or actions that are forbidden.	
i	Tip Indicates additional information.	
[i]	Reference to documentation	
	Reference to page	
	Reference to graphic	
1. , 2. , 3	Series of steps	
L	Result of a sequence of actions	
?	Help in the event of a problem	
	Visual inspection	

1.2.5 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3,	Item numbers	1. , 2. , 3	Series of steps
A, B, C,	Views	A-A, B-B, C-C,	Sections
EX	Hazardous area	×	Safe area (non-hazardous area)
≋➡	Flow direction		

1.3 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
 - The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
- For a detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Modbus RS485 register information	Reference for Modbus RS485 register information The document provides Modbus-specific information for each individual parameter in the operating menu.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

Microsoft®

Registered trademark of the Microsoft Corporation, Redmond, Washington, USA

Applicator®, FieldCare®, Field XpertTM, HistoROM®, TMB®, Heartbeat TechnologyTM Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task
- ► Are authorized by the plant owner/operator
- ► Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ► Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ► Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section $(\rightarrow \boxdot 6)$.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the measuring tube due to corrosive or abrasive fluids.

Housing breakage due to mechanical overload possible!

- ▶ Verify the compatibility of the process fluid with the measuring tube material.
- ► Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

The external surface temperature of the housing can increase by max. 20 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

► For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.


3 Product description

The device consists of a transmitter and a sensor. If a device is ordered with Modbus RS485 intrinsically safe, the Safety Barrier Promass 100 is part of the scope of supply and must be implemented to operate the device.

One device version is available: compact version - transmitter and sensor form a mechanical unit.

3.1 Product design

3.1.1 Device version with Modbus RS485 communication type




 \blacksquare 1 Important components of a measuring device

- 1 Sensor
- 2 Transmitter housing
- 3 Main electronics module
- 4 Transmitter housing cover
- In the case of the device version with Modbus RS485 intrinsically safe, the Safety Barrier Promass 100 forms part of the scope of supply.

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
 - Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the Endress+Hauser Operations App, see the "Product identification" section (→ 🗎 13).

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" (\rightarrow 🗎 7) and "Supplementary device-dependent documentation" (\rightarrow 🖺 7)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.


4.2.1 Transmitter nameplate



■ 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Permitted ambient temperature (T_a)
- 8 Degree of protection
- 9 2-D matrix code
- 10 Document number of safety-related supplementary documentation
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Firmware version (FW)

4.2.2 Sensor nameplate



■ 3 Example of a sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Flange nominal diameter/nominal pressure
- 7 Test pressure of the sensor
- 8 Nominal diameter of sensor
- 9 Sensor-specific data: e.g. pressure range of secondary containment, wide-range density specification (special density calibration)
- 10 Material of measuring tube and manifold
- 11 Medium temperature range
- 12 Degree of protection
- 13 Approval information for explosion protection and Pressure Equipment Directive
- 14 Permitted ambient temperature (T_a)
- 15 Document number of safety-related supplementary documentation
- 16 CE mark, C-Tick
- 17 Flow direction
- 18 Manufacturing date: year-month
- 19 2-D matrix code


Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Promass 100 safety barrier - nameplate



A0017854

- 4 Example of a Safety Barrier Promass 100 nameplate
- 1 Non-hazardous area or zone 2/div. 2
- 2 Serial number, material number and 2-D matrix code of the Safety Barrier Promass 100
- 3 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 4 Approval information for explosion protection
- 5 Safety warning
- 6 Communication-specific information
- 7 Intrinsically safe area
- 8 Manufacturing location
- 9 Document number of safety-related supplementary documentation
- 10 Permitted ambient temperature (T_a)
- 11 CE mark, C-Tick

4.2.4 Symbols on measuring device

Symbol	Meaning
Δ	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
(i	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport


5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections.
 They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Storage temperature: -40 to +80 °C (-40 to +176 °F), Order Code "Test, Certificate", Option JM: -50 to +60 °C (-58 to +140 °F), preferably at +20 °C (+68 °F)
- Store in a dry and dust-free place.
- Do not store outdoors.

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0015604

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

▲ WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0015606

5.2.2 Measuring devices with lifting lugs

A CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.

or

- Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation

6.1 Installation conditions


No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

6.1.1 Mounting position

Mounting location

To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:


- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.



A002334

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A0015596

■ 5 Installation in a down pipe (e.g. for batching applications)

- 1 Supply tank
- 2 Sensor
- *3 Orifice plate, pipe restriction*
- 4 Valve
- 5 Batching tank

18

DN		Ø orifice plate, pipe restriction	
[mm]	[in]	[mm]	[in]
8	3/8	6	0.24
15	1/2	10	0.40
25	1	14	0.55
40	1½	22	0.87
50	2	28	1.10


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Orientation				
A	Vertical orientation	A0015591	✓		
В	Horizontal orientation, transmitter head up	A0015589	$(\rightarrow \bigcirc \bigcirc$		
С	Horizontal orientation, transmitter head down	A0015590	$ \begin{array}{c c} & $		
D	Horizontal orientation, transmitter head at side	A0015592	\checkmark		

- Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.

If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.



 \blacksquare 6 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.
- 2 Avoid this orientation for outgassing fluids: Risk of gas accumulating.

Inlet and outlet runs

No special precautions need to be taken for fittings which create turbulence, such as valves, elbows or T-pieces, as long as no cavitation occurs ($\Rightarrow \triangleq 20$).



Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process

Ambient temperature range

Measuring device	Non-Ex	-40 to +60 °C (-40 to +140 °F)
	Ex na, NI version	-40 to +60 °C (-40 to +140 °F)
	Ex ia, IS version	 -40 to +60 °C (-40 to +140 °F) -50 to +60 °C (-58 to +140 °F) (Order code for "Test, certificate", option JM)
Local display		-20 to $+60$ °C (-4 to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.
Safety Barrier Promass 100		-40 to +60 °C (-40 to +140 °F)

If operating outdoors:

Avoid direct sunlight, particularly in warm climatic regions.

System pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- Ensure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



A0015594

20


Thermal insulation

In the case of some fluids, it is important that the heat radiated from the sensor to the transmitter is kept to a minimum. A wide range of materials can be used for the required insulation.

NOTICE


Electronics overheating on account of thermal insulation!

► Observe maximum permitted insulation height of the transmitter neck so that the transmitter head is completely free.



- Minimum distance to insulation
- t maximum Insulation thickness

The minimum distance between the transmitter housing and the insulation is 10 mm (0.39 in) so that the transmitter head remains completely exposed.



Maximum recommended insulation thickness depending on the temperature of the medium and the ambient temperature

t Insulation thickness

T_m Medium temperature

 $T_{40(104)}$ Maximum recommended insulation thickness at an ambient temperature of T_a = 40 °C (104 °F)

 $T_{60(140)}$ Maximum recommended insulation thickness at an ambient temperature of $T_a = 60 \,^{\circ}\text{C}$ (140 $^{\circ}\text{F}$)

NOTICE

Danger of overheating with insulation

▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 $^{\circ}$ C (176 $^{\circ}$ F)

NOTICE

The insulation can also be thicker than the maximum recommended insulation thickness.

Prerequisite:

- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Observe maximum permitted ambient temperature for the transmitter ($\rightarrow \triangleq 20$).
- ▶ Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE

Danger of overheating when heating

- ▶ Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 $^{\circ}$ C (176 $^{\circ}$ F)
- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

Using an electrical trace heating system

If heating is regulated via phase angle control or pulse packages, magnetic fields can affect the measured values (= for values that are greater than the values approved by the EN standard (sine 30 A/m)).

For this reason, the sensor must be magnetically shielded: the housing can be shielded with tin plates or electric sheets without a privileged direction (e.g. V330-35A).

The sheet must have the following properties:

- Relative magnetic permeability $\mu r \ge 300$
- Plate thickness $d \ge 0.35$ mm ($d \ge 0.014$ in)

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

6.1.3 Special mounting instructions

Zero point adjustment

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).
- Zero point adjustment is performed via the **Zero point adjustment control** parameter $(\rightarrow \ \ \)$ 56).

6.2 Mounting the measuring device

6.2.1 Required tools

For sensor

For flanges and other process connections: Corresponding mounting tools

6.2.2 Preparing the measuring device


- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the measuring device

A WARNING

Danger due to improper process sealing!

- ► Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ► Ensure that the gaskets are clean and undamaged.
- ► Install the gaskets correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.
- 2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



A0013964

6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring device conform to the measuring point specifications?	
For example: ■ Process temperature (→ 🖺 92) ■ Process pressure (refer to the chapter on "Pressure-temperature ratings" of the "Technical Information" document) ■ Ambient temperature (→ 🖺 20) ■ Measuring range (→ 🖺 84)	

Has the correct orientation for the sensor been selected ?	
 According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids) 	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ($\Rightarrow \implies 19$)?	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

7 Electrical connection



The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp (on aluminum housing): Allen screw3 mm
- For securing screw (for stainless steel housing): open-ended wrench 8 mm
- Wire stripper
- When using stranded cables: crimping tool for ferrule

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- $-40 \,^{\circ}\text{C} \, (-40 \,^{\circ}\text{F}) \text{ to } +80 \,^{\circ}\text{C} \, (+176 \,^{\circ}\text{F})$
- Minimum requirement: cable temperature range ≥ ambient temperature +20 K

Power supply cable

Standard installation cable is sufficient.

Signal cable

Modbus RS485

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A
Characteristic impedance	135 to 165 Ω at a measuring frequency of 3 to 20 MHz
Cable capacitance	<30 pF/m
Wire cross-section	>0.34 mm ² (22 AWG)
Cable type	Twisted pairs
Loop resistance	≤110 Ω/km
Signal damping	Max. 9 dB over the entire length of the cable cross-section
Shielding	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.

Connecting cable between Safety Barrier Promass 100 and measuring device

Cable type	Shielded twisted-pair cable with $2x2$ wires. When grounding the cable shield, observe the grounding concept of the plant.
Maximum cable resistance	2.5Ω , one side

Comply with the maximum cable resistance specifications to ensure the operational reliability of the measuring device.

The maximum cable length for individual wire cross-sections is specified in the table below. Observe the maximum capacitance and inductance per unit length of the cable and the connection values in the Ex documentation .

Wire cros	ss-section	Maximum o	able length
[mm ²]	[AWG]	[m]	[ft]
0.5	20	70	230
0.75	18	100	328
1.0	17	100	328
1.5	16	200	656
2.5	14	300	984

Cable diameter

- Cable glands supplied: M20 \times 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Spring terminals:
 Wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- With Safety Barrier Promass 100: Plug-in screw terminals for wire cross-sections 0.5 to 2.5 mm2 (20 to 14 AWG)

26

7.1.3 Terminal assignment

Transmitter

Modbus RS485 connection version

i

For use in the non-hazardous area and Zone 2/Div. 2.


Order code for "Output", option M

Depending on the housing version, the transmitters can be ordered with terminals or device plugs.

Order code for	Connection me	thods available	Possible options for order code
"Housing"	D		"Electrical connection"
Options A, B	Terminals	Terminals	 Option A: coupling M20x1 Option B: thread M20x1 Option C: thread G ½" Option D: thread NPT ½"
Options A, B	Device plugs (→ 🖺 30)	Terminals	■ Option L: plug M12x1 + thread NPT ½" ■ Option N: plug M12x1 + coupling M20 ■ Option P: plug M12x1 + thread G ½" ■ Option U: plug M12x1 + thread M20
Options A, B, C	Device plugs (→ 🖺 30)	Device plugs (→ 🖺 30)	Option Q : 2 x plug M12x1

Order code for "Housing":

- Option A: compact, coated aluminum
- Option **B**: compact, stainless
- Option C: ultra-compact, stainless



A0019528

- Modbus RS485 terminal assignment, connection version for use in non-hazardous areas and Zone 2/Div.
 2
- 1 Power supply: DC 24 V
- 2 Modbus RS485

	Terminal number			
Order code for "Output"	Power supply		Output	
	2 (L-)	1 (L+)	27 (B)	26 (A)
Option M	DC 2	24 V	Modbus	RS485

Order code for "Output":

Option \boldsymbol{M} Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2

Modbus RS485 connection version

For use in the intrinsically safe area. Connection via Safety Barrier Promass 100.


Order code for "Output", option M

Depending on the housing version, the transmitters can be ordered with terminals or device plugs.

Order code for	Connection me	thods available	Descible entions for order and	
"Housing"	Output	Power supply	Possible options for order code "Electrical connection"	
Options A, B	Terminals	Terminals	 Option A: coupling M20x1 Option B: thread M20x1 Option C: thread G ½" Option D: thread NPT ½" 	
A, B, C	Device plugs (→ 🖺 30)		Option I: plug M12x1	

Order code for "Housing":

- Option A: compact, coated aluminum
- Option **B**: compact, stainless
- \bullet Option C : ultra-compact, stainless



A001705


- \blacksquare 9 Modbus RS485 terminal assignment, connection version for use in intrinsically safe areas (connection via Safety Barrier Promass 100)
- 1 Intrinsically safe power supply
- 2 Modbus RS485

Order code for "Output"	20 (L-)	10 (L+)	72 (B)	62 (A)
Option M	Intrinsically safe	e supply voltage	Modbus RS485	intrinsically safe

Order code for "Output":

Option \mathbf{M} : Modbus RS485, for use in intrinsically safe areas (connection via Safety Barrier Promass 100)

Safety Barrier Promass 100



■ 10 Safety Barrier Promass 100 with terminals

- 1 Non-hazardous area and Zone 2/Div. 2
- 2 Intrinsically safe area

7.1.4 Pin assignment, device plug

MODBUS RS485

Device plug for signal transmission with supply voltage (device side), MODBUS RS485 (intrinsically safe)

2	Pin	Assignment		
	1	L+	Supply voltage, intrinsically safe	
3 0 0 1	2	A	Modbus RS485 intrinsically safe	
	3	B Woodbus 15465 Intrinsically safe	Mounds K5407 Intrinsically safe	
5	4	L-	Supply voltage, intrinsically safe	
4 A0016809	4 4 5		Grounding/shielding	
	Cod	ling	Plug/socket	
	I	A	Plug	

Device plug for supply voltage (device side), MODBUS RS485 (not intrinsically safe)

For use in the non-hazardous area and Zone 2/Div. 2.

2	Pin	Assignment		
	1	L+	DC 24 V	
3 0 0 0 1	2			
	3			
5	4	L-	DC 24 V	
4 A0016809	5		Grounding/shielding	
	Cod	ling	Plug/socket	
	A	A	Plug	

Device plug for signal transmission (device side), MODBUS RS485 (not intrinsically safe)

For use in the non-hazardous area and Zone 2/Div. 2.

2	Pin	Assignment		
	1			
$1 \longrightarrow 0 \longrightarrow 3$	2	Α	Modbus RS485	
	3			
5	4	В	Modbus RS485	
4 A0016811	5		Grounding/shielding	
	Cod	ling	Plug/socket	
	I	3	Socket	

7.1.5 Shielding and grounding

Modbus

The shielding and grounding concept requires compliance with the following:

- Electromagnetic compatibility (EMC)
- Explosion protection
- Personal protection equipment
- National installation regulations and guidelines
- Observe cable specification (\rightarrow 🖺 25).
- Keep the stripped and twisted lengths of cable shield to the ground terminal as short as possible.
- Seamless cable shielding.

Grounding of the cable shield

To comply with EMC requirements:

- Ensure the cable shield is grounded to the potential matching line at multiple points.
- Connect every local ground terminal to the potential matching line.

NOTICE

In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!

Damage to the bus cable shield.

▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.

7.1.6 Preparing the measuring device

- 1. Remove dummy plug if present.
- 2. **NOTICE!** Insufficient sealing of the housing! Operational reliability of the measuring device could be compromised. Use suitable cable glands corresponding to the degree of protection.

If measuring device is delivered without cable glands:

Provide suitable cable gland for corresponding connecting cable ($\rightarrow \triangleq 25$).

3. If measuring device is delivered with cable glands: Observe cable specification ($\rightarrow \cong 25$).

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ► Comply with local workplace safety regulations.
- For use in potentially explosive atmospheres, observe the information in the devicespecific Ex documentation.

7.2.1 Connecting the transmitter


The connection of the transmitter depends on the following order codes:

- Housing version: compact or ultra-compact
- Connection version: device plug or terminals



 $\blacksquare 11$ Housing versions and connection versions

- A Housing version: compact, aluminum coated
- B Housing version: compact, stainless
- 1 Cable entry or device plug for signal transmission
- 2 Cable entry or device plug for supply voltage
- C Housing version: ultra-compact, stainless
- 3 Device plug for signal transmission
- 4 Device plug for supply voltage



 \blacksquare 12 Device versions with connection examples

- 1 Cable
- 2 Device plug for signal transmission
- 3 Device plug for supply voltage

For device version with device plug: follow step 6 only.

- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover.

32 Endress+Hauser

A00178


- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the cable in accordance with the terminal assignment or the device plug pin assignment.
- 6. Depending on the device version, tighten the cable glands or plug in the device plug and tighten .
- 7. Enable the terminating resistor if applicable ($\rightarrow \triangleq 34$).
- 8. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the removal procedure to reassemble the transmitter.

7.2.2 Connecting the Safety Barrier Promass 100

In the case of the device version with Modbus RS485 intrinsically safe, the transmitter must be connected to the Safety Barrier Promass 100.

- 1. Strip the cable ends. In the case of stranded cables, also fit ferrules.
- 2. Connect the cable in accordance with the terminal assignment .
- 3. Where applicable, enable the terminating resistor in the Safety Barrier Promass 100 $(\Rightarrow \triangleq 34)$.



A0016804

■ 13 Electrical connection between the transmitter and Safety Barrier Promass 100

- 1 Control system (e.g. PLC)
- 2 Observe cable specification
- 3 Safety Barrier Promass 100: terminal assignment
- 4 *Observe cable specification* ($\rightarrow \triangleq 25$)
- 5 Non-hazardous area
- 6 Non-hazardous area and Zone 2/Div. 2
- 7 Intrinsically safe area
- 8 Transmitter: terminal assignment

7.2.3 Ensuring potential equalization

Requirements


No special measures for potential equalization are required.

For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

7.3 Special connection instructions


7.3.1 Connection examples

Modbus RS485



ightharpoonup 14 Connection example for Modbus RS485, non-hazardous area and Zone 2/Div. 2

- 1 Control system (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications $(\rightarrow \stackrel{\triangle}{=} 25)$
- 3 Distribution box
- 4 Transmitter



A001680

15 Connection example for Modbus RS485 intrinsically safe

- 1 Control system (e.g. PLC)
- 2 Cable shield, observe cable specifications
- 3 Safety Barrier Promass 100
- 4 *Observe cable specifications* ($\rightarrow \stackrel{\triangle}{=} 25$)
- 5 Non-hazardous area
- 6 Non-hazardous area and Zone 2/Div. 2
- 7 Intrinsically safe area
- 8 Transmitter


7.4 Hardware settings

7.4.1 Enabling the terminating resistor

Modbus RS485


To avoid incorrect communication transmission caused by impedance mismatch, terminate the Modbus RS485 cable correctly at the start and end of the bus segment.

If the transmitter is used in the non-hazardous area or Zone 2/Div. 2 $\,$



ightharpoons 16 Terminating resistor can be enabled via DIP switch on the main electronics module

If the transmitter is used in the intrinsically safe area



■ 17 Terminating resistor can be enabled via DIP switch in the Safety Barrier Promass 100


7.5 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
- 2. Tighten all housing screws and screw covers.
- 3. Firmly tighten the cable glands.

4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A001396


5. Insert dummy plugs into unused cable entries.

7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables comply with the requirements (→ 🖺 25)?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" ($\rightarrow \stackrel{\cong}{=} 35$)?	
Depending on the device version: are all the device plugs firmly tightened (→ 🖺 31)?	
 Does the supply voltage match the specifications on the transmitter nameplate? For device version with Modbus RS485 intrinsically safe: does the supply voltage match the specifications on the nameplate of the Safety Barrier Promass 100? 	
Is the terminal assignment or the pin assignment of the device plug correct?	
 If supply voltage is present, is the power LED on the electronics module of the transmitter lit green (→ \$\bigsim 11\)? For device version with Modbus RS485 intrinsically safe, if supply voltage is present, is the power LED on the Safety Barrier Promass 100 lit (→ \$\bigsim 11\)? 	
Depending on the device version, is the securing clamp or fixing screw firmly tightened?	

8 Operation options

8.1 Overview of operation options




- Computer with Web browser (e.g. Internet Explorer) or with "FieldCare" operating tool via Commubox FXA291 and service interface
- 2 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu with menus and parameters



■ 18 Schematic structure of the operating menu

8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.


N	lenu	User role and tasks	Content/meaning	
Operation	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Reading measured values	Resetting and controlling totalizers	
Setup		"Maintenance" role Commissioning: Configuration of the measurement Configuration of the communication interface	Submenus for fast commissioning: Setting the individual system units Defining the medium Configuration of the digital communication interface Configuring the low flow cut off Configuring partial and empty pipe detection	
			 "Advanced setup" submenu: For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers "Device reset" submenu Resets the device configuration to certain settings 	
Diagnostics		"Maintenance" role Fault elimination: Diagnostics and elimination of process and device errors Measured value simulation	Contains all parameters for error detection and analyzing process and device errors: "Diagnostic list" submenu Contains up to 5 currently pending diagnostic messages. "Event logbook" submenu Contains 20 event messages that have occurred. "Device information" submenu Contains information for identifying the device. "Measured values" submenu Contains all current measured values. "Simulation" submenu Is used to simulate measured values or output values.	
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: "System" submenu Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. "Sensor" submenu Configuration of the measurement. "Communication" submenu Configuration of the digital communication interface. "Application" submenu Configuration of the functions that go beyond the actual measurement (e.g. totalizer). "Diagnostics" submenu Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.	

8.3 Access to the operating menu via the operating tool

8.3.1 Connecting the operating tool

Via service interface (CDI)

Modbus RS485



A001692

- 1 Service interface (CDI) of the measuring device
- 2 Commubox FXA291
- 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

8.3.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

Service interface CDI

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook
- For details, see Operating Instructions BA00027S and BA00059S

Source for device description files


See data ($\rightarrow \triangle 42$)

Establishing a connection

Via service interface (CDI)

- 1. Start FieldCare and launch the project.
- 2. In the network: Add a device.
 - ► The **Add device** window opens.
- 3. Select the **CDI Communication FXA291** option from the list and press **OK** to confirm.
- 4. Right-click **CDI Communication FXA291** and select the **Add device** option in the context menu that opens.
- 5. Select the desired device from the list and press **OK** to confirm.
- 6. Establish the online connection to the device.
- $\hfill \hfill \hfill$

User interface



A00210E1

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag (→ 🖺 46)
- 5 Status area with status signal (→ 🖺 69)
- 6 Display area for current measured values (→ 🖺 60)
- 7 Event list with additional functions such as save/load, events list and document creation
- 8 Navigation area with operating menu structure
- 9 Operating range
- 10 Range of action
- 11 Status area

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.03.zz	 On the title page of the Operating instructions On transmitter nameplate (→ 🖺 13) Parameter firmware version Diagnostics → Device info → Firmware version
Release date of firmware version	10.2014	

9.1.2 Operating tools

Operating tool via Service interface (CDI)	Sources for obtaining device descriptions	
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser) 	

9.2 Modbus RS485 information

9.2.1 Function codes

Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:

Code	Name	Description	Application
03	Read holding register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes	Read device parameters with read and write access Example: Read mass flow
		The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	
04	Read input register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes	Read device parameters with read access Example: Read totalizer value
		The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	
06	Write single registers	Master writes a new value to one Modbus register of the measuring device.	Write only 1 device parameter Example: reset totalizer
		Use function code 16 to write multiple registers with just 1 telegram.	

Code	Name	Description	Application
08	Diagnostics	Master checks the communication connection to the measuring device. The following "Diagnostics codes" are supported: ■ Sub-function 00 = Return query data (loopback test) ■ Sub-function 02 = Return diagnostics register	
16	Write multiple registers	Master writes a new value to multiple Modbus registers of the device. A maximum of 120 consecutive registers can be written with 1 telegram. If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map (→ ■ 43)	Write multiple device parameters Example: • Mass flow unit • Mass unit
23	Read/Write multiple registers	Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram. Write access is executed before read access.	Write and read multiple device parameters Example: Read mass flow Reset totalizer

Broadcast messages are only allowed with function codes 06, 16 and 23.

9.2.2 Register information

For an overview on Modbus-specific information of the individual device parameters, please refer to the additional document on Modbus RS485 register information

9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to $5~\mathrm{ms}$

9.2.4 Modbus data map

Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.

Structure of the Modbus data map

The Modbus data map consists of two data sets:

- Scan list: Configuration area
 The device parameters to be grouped are defined in a list in that their Modbus RS485 register addresses are entered in the list.
- Data area

The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.

For an overview of device parameters with their individual Modbus register address, please refer to the additional document on Modbus RS485 register information

Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

Max. entries	16 device parameters
Supported device parameters	Only parameters with the following characteristics are supported: Access type: read or write access Data type: float or integer

Configuring the scan list via FieldCare

Carried out using the operating menu of the measuring device: Expert \rightarrow Communication \rightarrow Modbus data map \rightarrow Scan list register 0 -15

Scan list		
No.	Configuration register	
0	Scan list register 0	
15	Scan list register 15	

Configuring the scan list via Modbus RS485

Carried out using register addresses 5001 - 5016

Scan list	Scan list				
No.	Modbus RS485 register	Data type	Configuration register		
0	5001	Integer	Scan list register 0		
		Integer			
15	5016	Integer	Scan list register 15		

Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.

Master access to data area	Via register addresses 5051-5081
----------------------------	----------------------------------

Data area				
Device parameter value	Modbus RS485 register	Data type*	Access**	
Value of scan list register 0	5051	Integer/float	Read/write	
Value of scan list register 1	5053	Integer/float	Read/write	
Value of scan list register				
Value of scan list register 15	5081	Integer/float	Read/write	

^{*} Data type depends on the device parameters entered in the scan list.

** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area.

10 Commissioning

10.1 Function check

Before commissioning the measuring device:

- Make sure that the post-installation and post-connection checks have been performed.

10.2 Establishing a connection via FieldCare

- For FieldCare user interface (→ 🖺 41)


10.3 Setting the operating language

Factory setting: English or ordered local language

The operating language can be set in FieldCare: "Operation" menu \rightarrow Display language

10.4 Configuring the measuring device

The **Setup** menu with its submenus contains all the parameters needed for standard operation.



10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

The number of characters displayed depends on the characters used.

For information on the tag name in the "FieldCare" operating tool ($\rightarrow \implies 41$)

Navigation


"Setup" menu \rightarrow Device tag


Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promass

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.





Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: kg/h lb/min
Mass unit	Select mass unit. Result The selected unit is taken from: Mass flow unit parameter	Unit choose list	Country-specific: • kg • lb
Volume flow unit	Select volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: l/h gal/min (us)
Volume unit	Select volume unit. Result The selected unit is taken from: Volume flow unit parameter	Unit choose list	Country-specific: l gal (us)
Corrected volume flow unit	Select corrected volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: NI/h Sft³/h
Corrected volume unit	Select corrected volume unit. Result The selected unit is taken from:Corrected volume flow unit parameter	Unit choose list	Country-specific: NI Sft³
Density unit	Select density unit. Result The selected unit applies for: Output Simulation process variable	Unit choose list	Country-specific: kg/l lb/ft³
Reference density unit	Select reference density unit.	Unit choose list	kg/Nl
Temperature unit	Select temperature unit. Result The selected unit applies for: Output Reference temperature Simulation process variable	Unit choose list	Country-specific: °C (Celsius) °F (Fahrenheit)
Pressure unit	Select process pressure unit.	Unit choose list	Country-specific: bar psi

10.4.3 Selecting and setting the medium

The **Medium selection** submenu contains parameters that have to be configured for selecting and setting the medium.

Navigation

"Setup" menu \rightarrow Select medium



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Select medium	-	Select medium type.	Gas	Liquid
Select gas type	The following option is selected in the Medium selection parameter: Gas	Select measured gas type.	Gas type choose list	Methane CH4
Reference sound velocity	The following option is selected in the Select gas type parameter: Others	Enter sound velocity of gas at 0 °C (32 °F).	1 to 99 999.9999 m/s	0 m/s
Temperature coefficient sound velocity	The following option is selected in the Select gas type parameter: Others	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	0 (m/s)/K
Pressure compensation	The following option is selected in the Medium selection parameter: Gas	Select pressure compensation type.	 Off Fixed value External value	Off
Pressure value	The following option is selected in the Pressure compensation parameter: Fixed value	Enter process pressure to be used for pressure correction.	Positive floating- point number	0 bar
External pressure	The following option is selected in the Pressure compensation parameter: External value		Positive floating- point number	0 bar

10.4.4 Configuring the communication interface

The **"Communication" submenu** guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu \rightarrow Communication

► Communication	
Bus address	
Baudrate	
Data transfer mode	
Parity	
Byte order	
Failure mode	

Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Bus address	Enter device address.	1 to 247	247
Baudrate	Define data transfer speed.	 1200 BAUD 2400 BAUD 4800 BAUD 9600 BAUD 19200 BAUD 38400 BAUD 57600 BAUD 115200 BAUD 	19200 BAUD
Data transfer mode	Select data transfer mode.	 ASCII Transmission of data in the form of readable ASCII characters. Error protection via LRC. RTU Transmission of data in binary form. Error protection via CRC16. 	RTU
Parity	Select parity bits.	ASCII picklist • 0 = even • 1 = odd RTU picklist • 0 = even • 1 = odd • 2 = no parity bit/1 stop bit • 3 = no parity bit/2 stop bits	Even

Parameter	Description	User entry / Selection	Factory setting
Byte order	Select byte transmission sequence.	 0-1-2-3 3-2-1-0 1-0-3-2 2-3-0-1 	1-0-3-2
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication.	NaN valueLast valid value	NaN value
	This parameter operates in accordance with the option selected in the Assign diagnostic behavior parameter. NaN: not a number		

10.4.5 Configuring the low flow cut off

The **Low flow cut off** submenu contains parameters that must be configured for the configuration of low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off

► Low flow cut off	
Assign process variable	(→ 🖺 52)
On value low flow cutoff	(→ 🖺 52)
Off value low flow cutoff	(→ 🖺 52)
Pressure shock suppression	(→ 🖺 52)

Parameter overview with brief description


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for low flow cut off.	OffMass flowVolume flowCorrected volume flow	Mass flow
On value low flow cutoff	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter on value for low flow cut off.	Positive floating- point number	For liquids: depends on country and nominal diameter
Off value low flow cutoff	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	In the Assign process variable parameter, one of the following options is selected: Mass flow Volume flow Corrected volume flow	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.4.6 Configuring the partial filled pipe detection

The **Partially filled pipe detection** submenu contains parameters that have to be set for configuring empty pipe detection.

Navigation

"Setup" menu \rightarrow Partially filled pipe detection



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	_	Select process variable for partially filled pipe detection.	 Off Density Reference density	Off
Low value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: • 0.2 kg/l • 12.5 lb/ft ³
High value partial filled pipe detection	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: • 6 kg/l • 374.6 lb/ft ³
Response time part. filled pipe detect.	One of the following options is selected in the Assign process variable parameter: Density Reference density	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s	1s


10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

The number of submenus can vary depending on the device version, e.g. viscosity is available only with the Promass I.

Navigation

"Setup" menu → Advanced setup




10.5.1 Calculated values

The **Calculated values** submenu contains parameters for calculating the corrected volume flow.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Calculated values



Reference temperature	(→ 🖺 55)
Linear expansion coefficient	(→ 🖺 55)
Square expansion coefficient	(→ 🖺 55)

Parameter overview with brief description


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	 Fixed reference density Calculated reference density Reference density by API table 53 External reference density 	Calculated reference density
External reference density	-	Shows external reference density.	Floating point number with sign	0 kg/Nl
Fixed reference density	The following option is selected in the Corrected volume flow calculation parameter: Fixed reference density	Enter fixed value for reference density.	Positive floating- point number	1 kg/Nl
Reference temperature	The following option is selected in the Corrected volume flow calculation parameter: Calculated reference density	Enter reference temperature for calculating the reference density.	-273.15 to 99 999 °C	20 °C
Linear expansion coefficient	The following option is selected in the Corrected volume flow calculation parameter: Calculated reference density	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Square expansion coefficient	-	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0

10.5.2 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment



Parameter overview with brief description


Parameter	Description	Selection / User interface	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	Flow in arrow directionFlow against arrow direction	Flow in arrow direction
Zero point adjustment control	Start zero point adjustment.	CancelBusyZero point adjust failureStart	Cancel
Progress	Shows the progress of the process.	0 to 100 %	0 %

10.5.3 Configuring the totalizer

In the **"Totalizer 1 to 3" submenu** the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to 3



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Assign process variable	Select process variable for totalizer.	 Off Mass flow Volume flow Corrected volume flow Target mass flow Carrier mass flow 	Mass flow
Mass unit	Select mass unit.	Unit choose list	kg
Volume unit	Select volume unit.	Unit choose list	m³


Parameter	Description	Selection	Factory setting
Corrected volume unit	Select corrected volume unit.	Unit choose list	Nm³
Failure mode	Define totalizer behavior in alarm condition.	StopActual valueLast valid value	Stop

10.6 Simulation

The **"Simulation" submenu** enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu \rightarrow Simulation



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign simulation process variable	_	Select a process variable for the simulation process that is activated. Depending on the device version, not all options are available in this parameter. The selection can vary depending on the sensor, e.g. viscosity is available only with the Promass I.	■ Off ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Dynamic viscosity ■ Kinematic viscosity ■ Temp. ■ compensated ■ dynamic viscosity ■ Temp. ■ compensated ■ kinematic viscosity ■ Concentration ■ Target mass flow ■ Carrier mass flow	Off
Value process variable	A process variable is selected in the Assign simulation process variable parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0
Simulation device alarm	-	Switch the device alarm on and off.	Off On	Off
Diagnostic event category	-	Select the category of the diagnostic event.	SensorElectronicsConfigurationProcess	Sensor
Simulation diagnostic event	-	Switch simulation of the diagnostic event on and off. For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter.	 Off Picklist Diagnostic events (depends on the selected category) 	Off

10.7 Protecting settings from unauthorized access

The following option exists for protecting the configuration of the measuring device from unintentional modification after commissioning: Write protection via write protection switch

10.7.1 Write protection via access code

With the customer-specific access code, access to the measuring device via the Web browser is protected, as are the parameters for the measuring device configuration.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code

Structure of the submenu

Define access code	\rightarrow	Define access code
		Confirm access code

Defining the access code via the Web browser

- 1. Navigate to the **Enter access code** parameter.
- 2. Define a max. 4-digit numeric code as an access code.
- 3. Enter the access code again to confirm the code.
 - ► The Web browser switches to the login page.
- If no action is performed for 10 minutes, the Web browser automatically returns to the login page.
- The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling


10.7.2 Write protection via write protection switch

The write protection switch makes it possible to block write access to the entire operating menu with the exception of the following parameters:

- External pressure
- External temperature
- Reference density
- All parameters for configuring the totalizer

The parameter values are now read only and cannot be edited any more:

- Via service interface (CDI)
- Via Modbus RS485



A001795

- 1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
- 2. Depending on the housing version, unscrew or open the housing cover.
- 3. Setting the write protection switch on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch on the main electronics module to the OFF position (factory setting) disables the hardware write protection.
 - If hardware write protection is enabled: the **Locking status** parameter displays the **Hardware locked** option($\rightarrow \triangleq 60$); if disabled, the **Locking status** parameter does not display any option ($\rightarrow \triangleq 60$)
- 4. Reverse the removal procedure to reassemble the transmitter.

11 Operation

11.1 Reading device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

Navigation


"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
Hardware locked	The locking switch (DIPswitch) for locking the hardware is activated on the main electronic module. This prevents write access to the parameters ($\rightarrow \triangleq 59$).
Temporarily locked	Due to internal processing in the device (e.g. up-/downloading of data, reset), write access to the parameters is blocked for a short time. Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Information ($\rightarrow \triangle 46$)



11.3 Configuring the display

- Basic settings for local display
- Advanced settings for local display

11.4 Reading measured values

Using the Measured values submenu, it is possible to read all the measured values.


"Diagnostics" menu \rightarrow Measured values

11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables



Temperature	
Pressure value	

Parameter overview with brief description

Parameter	Description	User interface
Mass flow	Displays the mass flow currently measured.	Signed floating-point number
Volume flow	Displays the volume flow currently calculated.	Signed floating-point number
	Dependency The unit is taken from the Volume flow unit parameter	
Corrected volume flow	Displays the corrected volume flow currently calculated.	Signed floating-point number
	Dependency The unit is taken from the Corrected volume flow unit parameter	
Density	Displays the density currently measured.	Signed floating-point number
	Dependency The unit is taken from the Density unit parameter	
Reference density	Displays the reference density currently calculated.	Signed floating-point number
	Dependency The unit is taken from the Reference density unit parameter	
Temperature	Shows the medium temperature currently measured.	Signed floating-point number
	Dependency The unit is taken from the Temperature unit parameter	
Pressure value	Displays either a fixed or external pressure value.	Signed floating-point number

11.4.2 Totalizer


The **"Totalizer" submenu** contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Totalizer

Navigation

"Expert" menu \rightarrow Sensor \rightarrow Measured values \rightarrow Totalizer



Parameter overview with brief description


Parameter	Prerequsite	Description	User interface	Factory setting
Totalizer value 1 to 3	In the Assign process variable parameter in the Totalizer 1 to 3 submenu, one of the following options is selected: Volume flow Mass flow Corrected volume flow	Displays the current totalizer counter value.	Signed floating-point number	0 kg
Totalizer overflow 1 to 3	In the Assign process variable parameter in the Totalizer 1 to 3 submenu, one of the following options is selected: Volume flow Mass flow Corrected volume flow	Displays the current totalizer overflow.	Integer with sign	0

11.4.3 Output values

The **"Output values" submenu** contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu → Measured values → Output values



Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Pulse output	Displays the value currently measured for the pulse output.	Positive floating-point number	0 Hz
Output frequency	Displays the value currently measured for the frequency output.	0.0 to 1250.0 Hz	0.0 Hz
Switch status	Displays the current switch output status.	OpenClosed	Open

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu(\rightarrow 🖺 46)
- Advanced settings using the **Advanced setup** submenu(→ 🗎 54)

11.6 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:

- Control Totalizer
- Reset all totalizers

Function scope of "Control Totalizer" parameter


Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in Preset value parameterand the totaling process is restarted.

Function scope of "Reset all totalizers" parameter

Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

Navigation

"Operation" menu \rightarrow Operation



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Control Totalizer 1 to 3	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize 	Totalize
Preset value 1 to 3	Specify start value for totalizer.	Signed floating-point number	0 kg
Reset all totalizers	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Problem	Possible causes	Remedial action
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.	Order spare part (→ 🖺 80).
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part (→ 🖺 80).
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures (→ 🖺 71)
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part (→ 180).

For output signals

Problem	Possible causes	Remedial action
Green power LED on the main electronics module of the transmitter is dark	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Green power LED on the main electronics module of the transmitter is dark	Power supply cable connected incorrectly	Check the terminal assignment .
Green power LED on Safety Barrier Promass 100 is dark	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$
Green power LED on Safety Barrier Promass 100 is dark	Power supply cable connected incorrectly	Check the terminal assignment .
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".

For access

Problem	Possible causes	Remedial action	
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position ($\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
No connection via Modbus RS485	Modbus RS485 bus cable connected incorrectly	Check the terminal assignment .	
No connection via Modbus RS485	Device plug connected incorrectly	Check the pin assignment of the device plug .	
No connection via Modbus RS485	Modbus RS485 cable incorrectly terminated	Check terminating resistor $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$	
No connection via Modbus RS485	Incorrect settings for the communication interface	Check the Modbus RS485 configuration (→ 🗎 50).	
No connection via service interface	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox. FXA291: Document "Technical Information" TI00405C	

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter

Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.

LED	Color	Meaning
Power	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Alarm	Off	Device status is ok
	Flashing red	A device error of diagnostic behavior "Warning" has occurred
	Red	 A device error of diagnostic behavior "Alarm" has occurred Boot loader is active
Communication	Flashing white	Modbus RS485 communication is active

12.2.2 Safety Barrier Promass 100


Various light emitting diodes (LEDs) on the Safety Barrier Promass $100\ provide$ status information.

LED	Color	Color	
Power	Off	Supply voltage is off or too low.	
	Green	Supply voltage is ok.	
Communication	Flashing white	Modbus RS485 communication is active.	

12.3 Diagnostic information on local display

12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
 - Via parameters (→

 73)

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning	
A0013956	Failure A device error has occurred. The measured value is no longer valid.	
C	Function check The device is in service mode (e.g. during a simulation).	
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)	
A0013957	Maintenance required Maintenance is required. The measured value remains valid.	

Diagnostic behavior

Symbol	Meaning
A0013961	Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
A0013962	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



Operating elements

Key	Meaning
	Plus key
A0013970	In a menu, submenu Opens the message about the remedial measures.
	Enter key
A0013952	In a menu, submenu Opens the operating menu.

12.3.2 Calling up remedial measures



A0013940-EN

- 19 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (i) symbol).
 - The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \blacksquare .
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

- 1. Press E.
 - └─ The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

12.4 Diagnostic information in FieldCare

12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



- 1 Status area with status signal (→ \(\bigcip \) 66)
- 2 Diagnostic information ($\rightarrow \triangleq 67$)
- 3 Remedial measures with Service ID
- Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
 - Via parameters (\rightarrow 🗎 73)

Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
A0017271	Failure A device error has occurred. The measured value is no longer valid.
A0017278	Function check The device is in service mode (e.g. during a simulation).
A0017277	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
A0017276	Maintenance required Maintenance is required. The measured value is still valid.

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



Example

12.4.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
- Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ► A tool tip with remedy information for the diagnostic event appears.

12.5 Diagnostic information via communication interface

12.5.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270
- For an overview of diagnostic events with diagnosis number and diagnosis code $(\rightarrow \ \ \)$

12.5.2 Configuring error response mode

Error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

Navigation path

"Setup" menu → Communication

Parameter	overview	with	brief	description

Parameter	Description	Options	Factory setting	
Assign diagnostic behavior	Select diagnostic behavior for MODBUS communication.	OffAlarm or warningWarningAlarm	Alarm	
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication. This parameter	 NaN value Last valid value NaN = not a number 	NaN value	
	operates in accordance with the option selected in the Assign diagnostic behavior parameter.			

12.6 Adapting the diagnostic information

12.6.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the ${\bf Diagnostic\ behavior\ submenu\ }$.

"Expert" menu \rightarrow System \rightarrow Diagnostic handling \rightarrow Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description	
Alarm	Measurement is interrupted. Measured value output via Modbus RS485 and totalizers assume the defined alarm condition. A diagnostic message is generated.	
Warning	Measurement is resumed. Measured value output via Modbus RS485 and totalizers are not affected. A diagnostics message is generated.	
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.	
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.	

12.7 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Adapt the diagnostic information $(\rightarrow \bigcirc 71)$

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of se	nsor			
022	Sensor temperature	1.Change main electronic module 2.Change sensor	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
046	Sensor limit exceeded	I. Inspect sensor Check process condition	S	Alarm 1)
062	Sensor connection	1.Change main electronic module 2.Change sensor	F	Alarm
082	Data storage	Check module connections Contact service	F	Alarm
083	Memory content	Restart device Contact service	F	Alarm
140	Sensor signal	1.Check or change main electronics 2.Change sensor	S	Alarm 1)
144	Measuring error too high	Check or change sensor Check process conditions	F	Alarm 1)
190	Special event 1	Contact service	F	Alarm
191	Special event 5	Contact service	F	Alarm
192	Special event 9	Contact service	F	Alarm 1)
Diagnostic of e	lectronic		'	'
242	Software incompatible	Check software Flash or change main electronics module	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	Restart device Change main electronic module	F	Alarm
272	Main electronic failure	Restart device Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
274	Main electronic failure	Change electronic	S	Warning 1)
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
391	Special event 6	Contact service	F	Alarm
392	Special event 10	Contact service	F	Alarm 1)
Diagnostic of c	onfiguration		1	
410	Data transfer	Check connection Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
438	Dataset	Check data set file Check device configuration Up- and download new configuration	М	Warning
453	Flow override	Deactivate flow override	С	Warning
484	Simulation failure mode	Deactivate simulation	С	Alarm
485	Simulation measured variable	Deactivate simulation	С	Warning
590	Special event 3	Contact service	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
591	Special event 7	Contact service	F	Alarm
592	Special event 11	Contact service	F	Alarm 1)
Diagnostic of pr	rocess			
830	Sensor temperature too high	Reduce ambient temp. around the sensor housing	S	Warning
831	Sensor temperature too low	Increase ambient temp. around the sensor housing	S	Warning
832	Electronic temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronic temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning 1)
835	Process temperature too low	Increase process temperature	S	Warning 1)
843	Process limit	Check process conditions	S	Warning
862	Partly filled pipe	1.Check for gas in process 2. Adjust detection limits	S	Warning
910	Tubes not oscillating	Check electronic Inspect sensor	F	Alarm
912	Medium inhomogeneous	Check process cond. Increase system pressure	S	Warning ¹⁾
912	Inhomogeneous	Check process cond. Increase system pressure	S	Warning 1)
913	Medium unsuitable	Check process conditions Check electronic modules or sensor	S	Alarm 1)
944	Monitoring failed	Check process conditions for Heartbeat Monitoring	S	Warning ¹⁾
948	Tube damping too high	Check process conditions	S	Warning
990	Special event 4	Contact service	F	Alarm
991	Special event 8	Contact service	F	Alarm
992	Special event 12	Contact service	F	Alarm 1)

¹⁾ Diagnostic status is changeable.

12.8 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event: Via "FieldCare" operating tool $(\rightarrow \boxminus 70)$
- Other pending diagnostic events can be displayed in the **Diagnostic list** submenu($\Rightarrow \triangleq 74$)

Navigation

"Diagnostics" menu

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequsite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	-
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	-

12.9 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → Diagnostic list submenu



To call up the measures to rectify a diagnostic event: Via "FieldCare" operating tool ($\rightarrow \square$ 70)

12.10 Event logbook

12.10.1 Event history

A chronological overview of the event messages that have occurred is provided in the events list which contains a maximum of 20 message entries. This list can be displayed via FieldCare if necessary.

Navigation path

Event list: $\mathbf{F} \rightarrow \text{Tool box} \rightarrow \text{Additional functions}$

For information on the event list, see the FieldCare user interface

This event history includes entries for:

- Diagnostic events (→ 🗎 71)
- Information events (\rightarrow 🖺 75)

In addition to the operation time of its occurrence and possible troubleshooting measures, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - Đ: Event has occurred
 - ←: Event has ended
- Information event
 - ⊕: Event has occurred
- To call up the measures to rectify a diagnostic event: Via "FieldCare" operating tool $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \)$
- For filtering the displayed event messages ($\rightarrow = 75$)

12.10.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.10.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1089	Power on
11090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1111	Density adjust failure
I1151	History reset
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1444	Device verification passed
I1445	Device verification failed
I1446	Device verification active
I1447	Record application reference data
I1448	Application reference data recorded
I1449	Recording application ref. data failed
I1450	Monitoring off
I1451	Monitoring on


Info number	Info name	
I1457	Failed:Measured error verification	
I1459	Failed: I/O module verification	
I1460	Failed: Sensor integrity verification	
I1461	Failed: Sensor verification	
I1462	Failed:Sensor electronic module verific.	

12.11 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Restart or reset device manually.	 Cancel To fieldbus defaults ¹⁾ To delivery settings Restart device 	Cancel

1) Visibility depends on communication

12.11.1 Function scope of "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

12.12 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

Navigation

"Diagnostics" menu \rightarrow Device information

► Device informat	on
	Device tag
	Serial number
	Firmware version
	Order code
	Extended order code 1
	Extended order code 2
	Device Revision
	Device Type

12.13 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
06.2012	01.01.00	_	Original firmware	Operating Instructions	_
04.2013	01.02.zz	Option 74	Update	Operating Instructions	BA01177D/06/EN/01.13
10.2014	01.03.zz	Option 72	 New unit "Beer Barrel (BBL)" Use of an external pressure value for "liquid" medium type New parameter and diagnostic information for "oscillation damping" upper limit value 	Operating Instructions	BA01177D/06/EN/02.14

Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI).

For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

The manufacturer's information is available:

- ullet In the Download Area of the Endress+Hauser Internet site: www.endress.com oDownload
- Specify the following details:
 - Product root, e.g. 8E1B
 - Text search: Manufacturer's information
 - Search range: documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the W@M life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.

- Measuring device serial number:
 - Is located on the nameplate of the device.
 - Can be read out via the **Serial number** parameter in the **Device information** submenu ($\rightarrow \boxminus 77$).

14.3 Endress+Hauser services

Contact your Endress+Hauser Sales Center for information on services and spare parts.

14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at http://www.endress.com/support/return-material

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.

2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids. If using oil as a heating medium, please consult with Endress+Hauser. For details, see Operating Instructions BA00099D

15.2 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. Graphic illustration of the calculation results
	Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project.
	Applicator is available: Via the Internet: https://wapps.endress.com/applicator On CD-ROM for local PC installation.
W@M	Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress +Hauser also takes care of maintaining and updating the data records.
	W@M is available: ■ Via the Internet: www.endress.com/lifecyclemanagement ■ On CD-ROM for local PC installation.
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.
	For details, see Operating Instructions BA00027S and BA00059S
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.
	For details, see "Technical Information" TI00405C

15.3 System components

Accessories	Description
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick. For details, see "Technical Information" TI00133R and Operating Instructions BA00247R
	BAUU247R
iTEMP	The temperature transmitters can be used in all applications and are suitable for the measurement of gases, steam and liquids. They can be used to read in the fluid temperature.
	For details, see "Fields of Activity", FA00006T

16 Technical data

16.1 Application

The measuring device is suitable for flow measurement of liquids and gases only.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

Measuring principle

Mass flow measurement based on the Coriolis measuring principle

Measuring system

The device consists of a transmitter and a sensor. If a device is ordered with Modbus RS485 intrinsically safe, the Safety Barrier Promass 100 is part of the scope of supply and must be implemented to operate the device.

One device version is available: compact version - transmitter and sensor form a mechanical unit.

For information on the structure of the device $(\rightarrow \implies 11)$

16.3 Input

Measured variable

Direct measured variables

- Mass flow
- Density
- Temperature

Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

Measuring range

Measuring ranges for liquids

D	N	Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$		
[mm]	[in]	[kg/h]	[lb/min]	
8	3/8	0 to 2 000	0 to 73.50	
15	1/2	0 to 6 500	0 to 238.9	
25	1	0 to 18 000	0 to 661.5	
40	1½	0 to 45 000	0 to 1654	
50	2	0 to 70 000	0 to 2 573	

Measuring ranges for gases

Measuring ranges only valid for Promass H with tantalum 2.5W.

The full scale values depend on the density of the gas and can be calculated with the formula below:

 $\dot{m}_{\max(G)} = \dot{m}_{\max(F)} \cdot \rho_G : x$

m _{max(G)}	Maximum full scale value for gas [kg/h]
m _{max(F)}	Maximum full scale value for liquid [kg/h]
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{ max(G)}$ can never be greater than $\dot{m}_{ max(F)}$
ρ_{G}	Gas density in [kg/m³] at operating conditions

D	N	х
[mm]	[in]	[kg/m³]
8	3/8	60
15	1/2	80
25	1	90
40	1½	90
50	2	90

Recommended measuring range

"Flow limit" section ($\rightarrow \implies 93$)

Operable flow range

Over 1000:1.

Flow rates above the preset full scale value are not overridden by the electronics unit, with the result that the totalizer values are registered correctly.

16.4 Output

Output signal

Modbus RS485

Physical interface	In accordance with EIA/TIA-485-A standard
Terminating resistor	 For device version used in non-hazardous areas or Zone 2/Div. 2: integrated and can be activated via DIP switches on the transmitter electronics module For device version used in intrinsically safe areas: integrated and can be activated via DIP switches on the Safety Barrier Promass 100

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Modbus RS485

Failure mode	Choose from:
	NaN value instead of current value
	■ Last valid value

Local display

Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication: Modbus RS485
- Via service interface

Plain text display	With information on cause and remedial measures
--------------------	---

Light emitting diodes (LED)

Status information	Status indicated by various light emitting diodes
	The following information is displayed depending on the device version:
	Supply voltage active
	Data transmission active
	Device alarm/error has occurred

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

The following connections are galvanically isolated from each other:

- Outputs
- Power supply

Protocol-specific data

Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1
Device type	Slave
Slave address range	1 to 247
Broadcast address range	0
Function codes	 03: Read holding register 04: Read input register 06: Write single registers 08: Diagnostics 16: Write multiple registers 23: Read/write multiple registers
Broadcast messages	Supported by the following function codes: O6: Write single registers 16: Write multiple registers 23: Read/write multiple registers
Supported baud rate	 1200 BAUD 2400 BAUD 4800 BAUD 9600 BAUD 19200 BAUD 38400 BAUD 57600 BAUD 115200 BAUD
Data transfer mode	ASCII RTU
Data access	Each device parameter can be accessed via Modbus RS485. For Modbus register information

16.5 Power supply

Terminal assignment

(→ 🖺 27)

Pin assignment, device plug

(→ 🖺 30)

Supply voltage

The power unit must be tested to ensure it meets safety requirements (e.g. PELV, SELV).

Transmitter

- Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2: DC 20 to 30 V
- Modbus RS485, for use in intrinsically safe areas:
 Power supply via Safety Barrier Promass 100

Safety Barrier Promass 100

DC 20 to 30 V

Power consumption

Transmitter

Order code for "Output"	Maximum Power consumption
Option M Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2	3.5 W
Option M : Modbus RS485, for use in intrinsically safe areas	2.45 W

Safety Barrier Promass 100

Order code for "Output"	Maximum Power consumption
Option M : Modbus RS485, for use in intrinsically safe areas	4.8 W

Current consumption

Transmitter

Order code for "Output"	Maximum Current consumption	Maximum switch-on current
Option M Modbus RS485, for use in non-hazardous areas and Zone 2/Div. 2	90 mA	10 A (<0.8 ms)
Option \mathbf{M} : Modbus RS485, for use in intrinsically safe areas	145 mA	16 A (<0.4 ms)

Safety Barrier Promass 100


Order code for "Output"	Maximum Current consumption	Maximum switch-on current
Option M : Modbus RS485, for use in intrinsically safe areas	230 mA	10 A (<0.8 ms)

Power supply failure	 Totalizers stop at the last value measured. Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT). Error messages (incl. total operated hours) are stored.
Electrical connection	(→ 🖺 31)
Potential equalization	(→ 🖺 33)
Terminals	Transmitter Spring terminals for wire cross-sections 0.5 to 2.5 mm ² (20 to 14 AWG)
	Safety Barrier Promass 100 Plug-in screw terminals for wire cross-sections 0.5 to 2.5 mm^2 (20 to 14 AWG)
Cable entries	 Cable gland: M20 × 1.5 with cable \$\phi 6\$ to 12 mm (0.24 to 0.47 in) Thread for cable entry: NPT ½" G ½" M20
Cable specification	(→ 🖺 25)

16.6 Performance characteristics

Reference operating conditions

- Error limits based on ISO 11631
- Water with +15 to +45 °C (+59 to +113 °F) at 2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- \blacksquare Accuracy based on accredited calibration rigs that are traced to ISO 17025.



Maximum measured error

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base accuracy

Mass flow and volume flow (liquids)

±0.10 %

Mass flow (gases)

±0.50 % o.r. (tantalum 2.5W)

nul>
 Design fundamentals (→ 🗎 91)

Density (liquids)

- Reference conditions:±0.0005 q/cm³
- Standard density calibration:±0.02 g/cm³
 (valid over the entire temperature range and density range)
- Wide-range density specification (order code for "Application package", option EF "Special density and concentration" or EH " Special density and viscosity"): ± 0.002 g/cm³ (valid range for special density calibration: 0 to 2 g/cm³, ± 10 to ± 80 °C (± 50 to ± 176 °F))

Temperature

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Zero point stability

DN		Zero point stability		
[mm]	[in]	[kg/h]	[lb/min]	
8	3/8	0.40	0.015	
15	1/2	0.65	0.024	
25	1	1.80	0.066	
40	1½	9.00	0.331	
50	2	14.00	0.514	

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6 500	650	325	130	65	13
25	18 000	1800	900	360	180	36
40	45 000	4500	2 2 5 0	900	450	90
50	70 000	7 000	3 500	1400	700	140

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3/8	73.50	7.350	3.675	1.470	0.735	0.147
1/2	238.9	23.89	11.95	4.778	2.389	0.478
1	661.5	66.15	33.08	13.23	6.615	1.323
11/2	1654	165.4	82.70	33.08	16.54	3.308
2	2573	257.3	128.7	51.46	25.73	5.146

Repeatability

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability

Mass flow and volume flow (liquids)

±0.05 % o.r.

Mass flow (gases)

±0.25 % o.r. (tantalum 2.5W)

i

Design fundamentals (→ 🖺 91)

Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$

Temperature

 ± 0.25 °C ± 0.0025 · T °C (± 0.45 °F ± 0.0015 · (T-32) °F)

Response time

The response time depends on the configuration (damping).

Influence of medium temperature

Mass flow and volume flow


When there is a difference between the temperature for zero point adjustment and the process temperature, the typical measured error of the sensor is ± 0.0002 % of the full scale value/°C (± 0.0001 % of the full scale value/°F).

Density

When there is a difference between the density calibration temperature and the process temperature, the typical measured error of the sensor is $\pm 0.0001 \text{ g/cm}^3$ /°C ($\pm 0.00005 \text{ g/cm}^3$ /°F). Field density calibration is possible.

Wide-range density specification (special density calibration)

If the process temperature is outside the valid range ($\rightarrow \triangleq 88$) the measured error is $\pm 0.0001 \text{ g/cm}^3$ /°C ($\pm 0.00005 \text{ g/cm}^3$ /°F)



- 1 Field density calibration, for example at $+20 \,^{\circ}\text{C}$ ($+68 \,^{\circ}\text{F}$)
- 2 Special density calibration

Temperature

 $\pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.005 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Influence of medium pressure

The table below shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure.

o.r. = of reading

D	N	Promass H zirconium 702/R 60702		Promass H tai	ntalum 2.5W
[mm]	[in]	[% o.r./bar]	[% o.r./psi]	[% o.r./bar]	[% o.r./psi]
8	3/8	-0.017	-0.0012	-0.007	-0.0005
15	1/2	-0.021	-0.0014	-0.005	-0.0003
25	1	-0.013	-0.0009	-0.015	-0.0010
40	11/2	-0.018	-0.0012	-0.012	-0.0008
50	2	-0.015	-0.0010	-0.011	-0.0008

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	RODELSSS
< ZeroPoint · 100	± ZeroPoint MeasValue · 100
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate		Maximum repeatability in % o.r.
$\geq \frac{\frac{1}{2} \cdot ZeroPoint}{BaseRepeat} \cdot 100$		± BaseRepeat
	A0021335	A0021340
< ½ · ZeroPoint BaseRepeat · 100		$\pm \frac{1}{2} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
	A0021336	A0021337

Example for max. measured error



- E Error: Maximum measured error as % o.r. (example)
- Q Flow rate as %

P Design fundamentals (→ 🖺 91)

16.7 Installation

"Mounting requirements" (→ 🗎 18)

16.8 Environment

Ambient temperature range

(→ 🗎 20)

	Temperature tables
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.
	For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.
Storage temperature	All components apart from the display modules: ■ -40 to +80 °C (-40 to +176 °F), preferably at +20 °C (+68 °F) (standard version) ■ -50 to +80 °C (-58 to +176 °F) (Order code for "Test, certificate", option JM)
	Display modules
	-40 to +80 °C (-40 to +176 °F)
Climate class	DIN EN 60068-2-38 (test Z/AD)
Degree of protection	Transmitter and sensor ■ As standard: IP66/67, type 4X enclosure ■ With the order code for "Sensor options", option CM: IP69K can also be ordered ■ When housing is open: IP20, type 1 enclosure ■ Display module: IP20, type 1 enclosure
	Safety Barrier Promass 100 IP20
Shock resistance	As per IEC/EN 60068-2-31
Vibration resistance	Acceleration up to 1 g, 10 to 150 Hz, based on IEC/EN 60068-2-6
Interior cleaning	Sterilization in place (SIP)Cleaning in place (CIP)
Electromagnetic compatibility (EMC)	 As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) Complies with emission limits for industry as per EN 55011 (Class A)
1	For details refer to the Declaration of Conformity.
	16.9 Process
Medium temperature range	Sensor ■ Zirconium 702/R 60702:-50 to +200 °C (-58 to +392 °F) ■ Tantalum 2.5W:-50 to +150 °C (-58 to +302 °F)
	Seals No internal seals
Density	0 to 5 000 kg/m ³ (0 to 312 lb/cf)

92

ratings

Pressure-temperature

Secondary containment pressure rating

The sensor housing is filled with dry nitrogen and protects the electronics and mechanics inside.

The following secondary containment pressure rating is only valid for a fully welded sensor housing and/or a device equipped with closed purge connections (never opened/as delivered).

D	N	Secondary containment pressure rating (designed with a safety factor ≥ 4)		Secondary containment burst pressur	
[mm]	[in]	[bar]	[psi]	[bar]	[psi]
8	3/8	25	362	170	2465
15	1/2	25	362	160	2320
25	1	25	362	130	1885
40	1½	16	232	85	1200
50	2	16	232	85	1200

If there is a risk of measuring tube failure due to process characteristics, e.g. with corrosive fluids, we recommend the use of sensors whose secondary containment is equipped with special pressure monitoring connections (order code for "Sensor option", option CH "Purge connection").

With the help of these connections, the fluid collected in the secondary containment can be bled off in the event of tube failure. This is especially important in high-pressure gas applications. These connections can also be used for gas purging (gas detection).

Do not open the purge connections unless the containment can be filled immediately with a dry, inert gas. Use only low gauge pressure to purge. Maximum pressure: 5 bar (72.5 psi).

If a device fitted with purge connections is connected to the purge system, the maximum nominal pressure is determined by the purge system itself or by the device, depending on which component has the lower nominal pressure.

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Flow limit

Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.

- For an overview of the measuring range full scale values, see the "Measuring range" section $(\rightarrow \triangleq 84)$
- The minimum recommended full scale value is approx. 1/20 of the maximum full scale value
- In most applications, 20 to 50 % of the maximum full scale value can be considered ideal
- A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
- For gas measurement the following rules apply:
 - The flow velocity in the measuring tubes should not exceed half the sonic velocity (0.5 Mach).
 - The maximum mass flow depends on the density of the gas: formula ($\rightarrow \blacksquare$ 85)

Pressure loss

16.10 Mechanical construction

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Compact version

Weight in SI units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [kg].

DN [mm]	Weight [kg]
8	10
15	11
25	17
40	34
50	67

Weight in US units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [lbs].

DN [in]	Weight [lbs]
3/8	22
1/2	24
1	37
1½	75
2	148

Safety Barrier Promass 100


49 g (1.73 ounce)

Materials

Transmitter housing

- Order code for "Housing", option A "Compact, aluminum coated": Aluminum, AlSi10Mg, coated
- Order code for "Housing", option B "Compact, stainless": Stainless steel 1.4301 (304)
- Order code for "Housing", option **C** "Ultra-compact, stainless": Stainless steel 1.4301 (304)

Cable entries/cable glands



A0020640

■ 20 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G ½" or NPT ½"

Order Code for "Housing", Option A "Compact, coated aluminum"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Nickel-plated brass
Adapter for cable entry with internal thread G ½"	
Adapter for cable entry with internal thread NPT ½"	

Order code for "Housing", option B "Compact, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread G ½"	
Adapter for cable entry with internal thread NPT ½"	

Device plug

Electrical connection	Material
Plug M12x1	 Socket: Stainless steel, 1.4404 (316L) Contact housing: Polyamide Contacts: Gold-plated brass

Sensor housing


- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tubes

- Zirconium 702/R 60702
- Tantalum 2.5W

Process connections

- Stainless steel, 1.4301 (304); wetted parts: zirconium 702, tantalum
- Flanges according to EN 1092-1 (DIN 2501) / according to ASME B16.5 / according to JIS B2220



Surface quality (parts in contact with medium)

Seals

Welded process connections without internal seals

Safety Barrier Promass 100

Housing: Polyamide

Process connections

Flanges:

- EN 1092-1 (DIN 2501)
- EN 1092-1 (DIN 2512N)
- ASME B16.5
- JIS B2220


For information on the materials of the process connections ($\Rightarrow \triangleq 94$)

Operability 16.11

Service interface

Via service interface (CDI)

Modbus RS485



- Service interface (CDI) of the measuring device
- Commubox FXA291
- Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

Languages

Can be operated in the following languages:

Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese

16.12 Certificates and approvals

CE mark	The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along				
	with the standards applied.				
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.				
C-Tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".				
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.				
Modbus RS485 certification	The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out and is certified by the "MODBUS/TCP Conformance Test Laboratory" of the University of Michigan.				
Pressure Equipment Directive	 With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC. Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive. 				
Other standards and guidelines	 EN 60529 Degrees of protection provided by enclosures (IP code) IEC/EN 60068-2-6 Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal). IEC/EN 60068-2-31 Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices. EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment NAMUR NE 32 				
	Data retention in the event of a power failure in field and control instruments with				

The application of the pressure equipment directive to process control devices

Software of field devices and signal-processing devices with digital electronics

Standardization of the signal level for the breakdown information of digital transmitters

Endress+Hauser 97

microprocessors
• NAMUR NE 43

■ NAMUR NE 53

with analog output signal.

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

■ NAMUR NE 107

Self-monitoring and diagnosis of field devices

■ NAMUR NE 131

Requirements for field devices for standard applications

■ NAMUR NE 132

Coriolis mass meter

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.



Detailed information on the application packages: Special Documentation on the device

Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	Heartbeat Monitoring: Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to: Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time. Schedule servicing in time. Monitor the product quality, e.g. gas pockets.
	 Heartbeat Verification: Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process. Access via onsite operation or other operating interfaces, such as FieldCare for instance. Documentation of device functionality within the framework of manufacturer specifications, for proof testing for instance. End-to-end, traceable documentation of the verification results, including report. Makes it possible to extend calibration intervals in accordance with operator's risk assessment.

Concentration

Package	Description
Concentration measurement and special density	Calculation and outputting of fluid concentrations Many applications use density as a key measured value for monitoring quality or controlling processes. The device measures the density of the fluid as standard and makes this value available to the control system. The "Special Density" application package offers high-precision density measurement over a wide density and temperature range particularly for applications subject to varying process conditions.
	With the help of the "Concentration Measurement" application package, the measured density is used to calculate other process parameters: Temperature-compensated density (reference density). Percentage mass of the individual substances in a two-phase fluid. (Concentration in %). Fluid concentration is output with special units ("Brix, "Baumé, "API, etc.) for standard applications. The measured values are output via the digital and analog outputs of the device.

16.14 Accessories

16.15 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
 - The W@M Device Viewer: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Promass H 100	KA01146D

Technical Information

Measuring device	Documentation code
Promass H 100	TI01106D

Supplementary devicedependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEx Ex i	XA00159D
ATEX/IECEx Ex nA	XA01029D
cCSAus IS	XA00160D
INMETRO Ex i	XA01219D
INMETRO Ex nA	XA01220D
NEPSI Ex i	XA01249D
NEPSI Ex nA	XA01262D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD00142D
Modbus RS485 Register Information	SD00154D
Concentration Measurement	SD01152D
Heartbeat Technology	SD01153D

Installation instructions

Contents	Documentation code
Installation Instructions for spare part sets	Specified for each individual accessory $(\rightarrow \stackrel{\square}{=} 82)$
	Overview of accessories available for order $(\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$


17 Appendix

17.1 Overview of the operating menu


The following graphic provides an overview of the entire operating menu structure with its menus, submenus and parameters. The page reference indicates where a description of the parameter can be found in the manual.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

For the Order Code "Application Package", the associated parameters are described in the Special Documentation.



17.1.1 "Operation" menu



17.1.2 "Setup" menu

Navigation

■ Setup

➤ System units		
	Mass flow unit	(→ 🖺 48)
	Mass unit	(→ 🖺 48)
	Volume flow unit	(→ 🖺 48)
	Volume unit	(→ 🗎 48)
	Corrected volume flow unit	(→ 🖺 48)
	Corrected volume unit	(→ 🖺 48)
	Density unit	(→ 🖺 48)
	Reference density unit	(→ 🖺 48)
	Temperature unit	(→ 🖺 48)
	Pressure unit	(→ 🖺 48)
► Medium selecti	on	
	Select medium	(→ 🗎 49)
	Select gas type	(→ 🖺 49)
	Reference sound velocity	(→ 🗎 49)
	Temperature coefficient sound velocity	(→ 🖺 49)
	Pressure compensation	(→ 🖺 49)
	Pressure value	(→ 🗎 49)
	External pressure	(→ 🖺 49)
► Communication		(→ 🖺 50)
	Bus address	(→ 🖺 50)
	Baudrate	(→ 🖺 50)
	Data transfer mode	(→ 🗎 50)
	Parity	(→ 🖺 50)
	Byte order	(→ 🖺 51)

	Assign diagnostic behav	ior			
	Failure mode				(→ 🖺
► Low flow cut o	ff				(→ 🖺
	Assign process variable				(→ 🖺
	On value low flow cutoff	:			(→ 🖺
	Off value low flow cutoff	F			(→ 🖺
	Pressure shock suppress	ion			(→ 🖺
► Partially filled	pipe detection				(→ 🖺
	Assign process variable				(→ 🖺
	Low value partial filled p	oipe detection			(→ 🖺
	High value partial filled	pipe detection			(→ 🖺
	Response time part. fille	d pipe detect.			(→ 🖺
► Advanced setu	p				(→ 🖺
	Enter access code				
	► Calculated values				(→ 🖺
	▶ (Corrected volum	e flow calculation		
			Corrected volume flo	ow calculation	(→ 🖺
			External reference d	ensity	(→ 🖺
			Fixed reference dens	sity	(→ 🖺
			Reference temperati	ure	(→ 🖺
			Linear expansion co	efficient	(→ 🖺
			Square expansion co	officient	(→ 🖺

► Sensor	adjustment		(→ 🖺 55)
	Installation direction	n	(→ 🖺 56)
	► Zero point adjus	tment	
		Zero point adjustment control	(→ 🖺 56)
		Progress	(→ 🖺 56)
► Totaliz	er 1 to 3		(→ 🖺 56)
	Assign process vari	able	(→ 🖺 56)
	Mass unit		(→ 🖺 56)
	Volume unit		(→ 🖺 56)
	Corrected volume u	nit	(→ 🖺 57)
	Totalizer operation	mode	
	Failure mode		(→ 🖺 57)
▶ Viscosi	ity]	
	► Temperature co	mpensation	
	1		
		Calculation model	
		Reference temperature	
		Compensation coefficient X 1	
		Compensation coefficient X 2	
	► Dynamic viscosi	ty	
		Dynamic viscosity unit	
		User dynamic viscosity text	
		User dynamic viscosity factor	_
		User dynamic viscosity offset	
	► Kinematic visco	sity	
		Kinematic viscosity unit	

	User kinematic viscosity text
	User kinematic viscosity factor
	User kinematic viscosity offset
▶ Concentration	
Concentration u	nit
User concentration	on text
User concentration	on factor
User concentration	on offset
A 0	
A 1	
A 2	
A 3	
A 4	
B 1	
B 2	
B 3	
► Heartbeat setup	
► Heartbeat Mo	onitoring
	Activate monitoring
► Administration	(→ 🖺 76)
Device reset	(→ 🖺 76)

17.1.3 "Diagnostics" menu

억 Diagnostics				(→ 🖺 73)
	Actual diagnostics			(→ 🖺 74)
	Timestamp			
	Previous diagnostics	S		(→ 🖺 74)
	Timestamp			
	Operating time from	n restart		
	Operating time			
	► Diagnostic list			
		Diagnostics 1		
		Timestamp		
		Diagnostics 2		
		Timestamp		
		Diagnostics 3		
		Timestamp		
		Diagnostics 4		
		Timestamp		
		Diagnostics 5		
		Timestamp		
	► Event logbook			
		Filter options		
► Device information			(→ 🖺 77)	
		Device tag		
		Serial number		


		Firmware version		
	Device name			
		Order code		
		Extended order code	e 1	
	Extended order code 2		e 2	
Extended order code 3			e 3	
		ENP version		
	► Measured value			
	► Measured value			
		▶ Process variable	S	(→ 🖺 60)
			Mass flow	(→ 🖺 61)
			Volume flow	(→ 🖺 61)
			Corrected volume flow	(→ 🖺 61)
			Density	(→ 🖺 61)
			Reference density	(→ 🖺 61)
			Temperature	(→ 🖺 61)
			Pressure value	(→ 🖺 61)
			Dynamic viscosity	
			Kinematic viscosity	
			Temp. compensated dynamic viscosity	
			Temp. compensated kinematic viscosity	
			Concentration	

		Target mass flow		
		Carrier mass flow		
► Totalizer				(→ 🖺 56)
		Totalizer value 1 to 3		(→ 🖺 62)
		Totalizer overflow 1 to 3		(→ 🖺 62)
- W - W - W]		(/ 🕳 02)
► Heartbeat				
	► Performing verif	fication		
		Year		
		Month		
		Day		
		Hour		
		AM/PM		
		Minute		
		Start verification		
		Progress		(→ 🖺 56)
		Status		
		Overall result		
► Verification results				
		D-4- /4:	l	
		Date/time		
		Verification ID		
		Operating time		
		Overall result		
		Sensor		


		Sensor integrity	
		Sensor electronic module	
	► Monitoring resu	ults	
		Sensor integrity	
▶ Simulation			(→ 🖺 57)
	Assign simulation p	process variable	(→ 🖺 58)
	Value process varia	ble	(→ 🖺 58)
	Simulation device a	alarm	(→ 🖺 58)

17.1.4 "Expert" menu

The following tables provide an overview of the **Expert** menu with its submenus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.




"System" submenu



Assign behavior of diagnostic no. 834 Assign behavior of diagnostic no. 835 Assign behavior of diagnostic no. 912 Assign behavior of diagnostic no. 913 Assign behavior of diagnostic no. 944 Assign behavior of diagnostic no. 192 Assign behavior of diagnostic no. 274 Assign behavior of diagnostic no. 392 Assign behavior of diagnostic no. 592 Assign behavior of diagnostic no. 992 ► Administration (→ 🖺 76) (→ 🖺 76) Device reset Activate SW option Software option overview Permanent storage Device tag (→ 🖺 47)

"Sensor" submenu



		Density	(→ 🖺 61)
		Reference density	(→ 🖺 61)
		Temperature	(→ 🖺 61)
		Pressure value	(→ 🖺 61)
		Dynamic viscosity	
		Kinematic viscosity	
		Temp. compensated dynamic viscosity	
		Temp. compensated kinematic viscosity	
		Concentration	
		Target mass flow	
		Carrier mass flow	
	► Totalizer		(→ 🖺 56)
		Totalizer value 1 to 3	(→ 🖺 62)
		Totalizer overflow 1 to 3	(→ 🖺 62)
► System units			
	Mass flow unit		(→ 🖺 48)
	Mass unit		(→ 🖺 48)
	Volume flow unit		(→ 🖺 48)
	Volume unit		(→ 🖺 48)
	Corrected volume f	low unit	(→ 🖺 48)
	Corrected volume u	ınit	(→ 🖺 48)
	Density unit		(→ 🖺 48)
	Reference density t	mit	(→ 🖺 48)
	Temperature unit		(→ 🖺 48)
	Pressure unit		(→ 🖺 48)

Date/time format		
▶ User-specific un	nits	
	User mass text	
	User mass factor	
	User volume text	
	User volume factor	
	User corrected volume text	
	User corrected volume factor	
	User density text	
	User density offset	
	User density factor	
	User pressure text	
	User pressure offset	
	User pressure factor	
► Process parameters]	
Flow damping		
Density damping		
Temperature damp	ing	
Flow override		
► Low flow cut off		(→ 🖺 52)
	Assign process variable	(→ 🖺 52)
	On value low flow cutoff	(→ 🖺 52)
	on value low flow cutoff	(/ 🖃)2)

		Off value low flow cutoff	(→ 🖺 52)
		Pressure shock suppression	(→ 🖺 52)
	► Partially filled	pipe detection	(→ 🖺 53)
		Assign process variable	(→ 🖺 53)
		Low value partial filled pipe detection	(→ 🖺 53)
		High value partial filled pipe detection	(→ 🖺 53)
		Response time part. filled pipe detect.	(→ 🖺 53)
		Maximum damping partial filled pipe det.	
► Measurement n	10de		
	Select medium		(→ 🖺 49)
	Select gas type		(→ 🖺 49)
	Reference sound v	elocity	(→ 🖺 49)
	Temperature coeff	icient sound velocity	(→ 🖺 49)
► External compe	nsation		
	Pressure compensa	ation	(→ 🖺 49)
	Pressure value		(→ 🖺 49)
	External pressure		(→ 🖺 49)
	Temperature mode	e	
	External temperat	ure	
► Calculated value	2S		(→ 🖺 54)
	► Corrected volum	ne flow calculation	
		Corrected volume flow calculation	(→ 🖺 55)
		External reference density	(→ 🖺 55)
		Fixed reference density	(→ 🖺 55)


		Reference temperature	(→ 🖺 55)
		Linear expansion coefficient	(→ 🖺 55)
		Square expansion coefficient	(→ 🖺 55)
► Sensor adjustm	ent		(→ 🖺 55)
	Installation direction	n	(→ 🖺 56)
	► Zero point adjus	tment	
		Zero point adjustment control	(→ 🖺 56)
		Progress	(→ 🖺 56)
	► Process variable	adjustment	
		Mass flow offset	
		Mass flow factor	
		Volume flow offset	
		Volume flow factor	
		Density offset	
		Density factor	
		Corrected volume flow offset	
		Corrected volume flow factor	
		Reference density offset	
		Reference density factor	
		Temperature offset	
		Temperature factor	
► Calibration			
	Calibration factor		
	Zero point		
	Nominal diameter		

	С	
	С	
	С	
	С	
	С	
	С	
► Testpoints		
	Oscillation frequency	
	Oscillation frequency	
	Frequency fluctuation	
	Frequency fluctuation	
	Oscillation amplitude	
	Oscillation amplitude	
	Oscillation damping	
	Oscillation damping	
	Tube damping fluctuation	
	Tube damping fluctuation	
]
	Signal asymmetry	
	Electronic temperature	
	Carrier pipe temperature	
	Exciter current	
	Exciter current	
	RawMassFlow	
► Supervision		I
> Supervision		1
	Limit value measuring tube damping	


"Current input" submenu

Navigation $\blacksquare \blacksquare$ Expert \rightarrow Input \rightarrow Current input

► Input	Status immut		
	► Status input		
		Assign status input	
		Value status input	
		Active level	
		Response time status input	



Damping output	
Failure mode	
Failure frequency	
Output frequency	(→ 🖺 62)
Switch output function	
Assign diagnostic behavior	
Assign limit	
Switch-on value	
Switch-off value	
Assign flow direction check	
Assign status	
Failure mode	
Switch status	(→ 🖺 62)
Invert output signal	



	Failure mode	(→ 🖺 51)
	Interpreter mode	
▶ Modbus informa	ation	
	Device ID	
	Device revision	
► Modbus data m	ар	
	Scan list register	

Reset all totalizers (→ 🖺 63)

► Totalizer 1 to 3		(→ 🖺 56)
Assign p	rocess variable	(→ 🖺 56)
Mass uni	it	(→ 🖺 56)
Volume	unit	(→ 🖺 56)
Corrected	d volume unit	(→ 🖺 57)
Totalizer	r operation mode	
Control 7	Totalizer 1 to 3	(→ 🖺 63)
Preset va	alue 1 to 3	(→ 🖺 63)
Failure n	node	(→ 🖺 57)
► Viscosity		
Viscosity	damping	
► Temp	erature compensation	
	Calculation model	
	Reference temperature	
	Compensation coefficient X 1	
	Compensation coefficient X 2	
► Dynar	mic viscosity	
	Dynamic viscosity unit	
	User dynamic viscosity text	
	User dynamic viscosity factor	
	User dynamic viscosity offset	
► Kinen	natic viscosity	
	Kinematic viscosity unit	
	User kinematic viscosity text	

		User kinematic viscosity f	factor	
		User kinematic viscosity of	offset	
► Concentration				
	Concentration damp	ing		
	Concentration unit			
	User concentration t	rext		
	User concentration f	actor		
	User concentration of	offset		
	A 0			
	A 1			
[A 2			
[A 3			
[A 4			
[B 1			
	B 2			
	В 3			

► Diagnostics	(→ 🖺 73)
Actual diagnostics	(→ 🖺 74)
Timestamp	
Previous diagnostics	(→ 🖺 74)
Timestamp	
Operating time from restart	
Operating time	

► Diagnostic list			
	Diagnostics 1		
	Timestamp		
	Diagnostics 2		
	Timestamp		
	Diagnostics 3		
	Timestamp		
	Diagnostics 4		
	Timestamp	_	
	Diagnostics 5	7	
	Timestamp	_ _	
► Event logbook		_	
	Filter options		
► Device information	ion	_	(→ 🖺 77)
	Device tag		
	Serial number	_ _	
	Firmware version		
	Device name	_	
	Order code	_	
	Extended order code 1		
	Extended order code 2		
	Extended order code 3		
	ENP version	_	
	Configuration counter		

► Min/max	values			
	Reset min/max va	alues		
	► Electronic tem	nperature		
		Minimum value		
		Maximum value		
	N - 1			
	► Medium temp	perature		
		Minimum value		
		Maximum value		
	► Carrier pipe te	emperature		
		Minimum value		
		Maximum value		
	► Oscillation free	equency		
		Minimum value		
		Maximum value		
► Torsion oscillation frequency				
		Minimum value		
		Maximum value		
	► Oscillation am	nplitude		
		Minimum value		
		Maximum value		
	► Torsion oscillation amplitude			
		Minimum value		
		Maximum value		

	► Oscillation dam	nping	
		Minimum value	
		Maximum value	
	► Torsion oscillat	tion damping	
		Minimum value	
		Maximum value	
	► Signal asymme	etry	
		Minimum value	
		Maximum value	
► Heartbeat			
	► Performing ver	rification	
		Year	
		Month	
		Day	
		Hour	
		AM/PM	
		Minute	
		Start verification	
		Progress	(→ 🖺 56)
		Status	
		Overall result	
	► Verification res	sults	
		Date/time	
		Verification ID	
		Operating time	

	Overall result	
	Sensor	
	Sensor integrity	
	Sensor electronic module	
	I/O module	
► Heartbeat Monit	toring	
	Activate monitoring	
► Monitoring resu	ılts	
	Sensor integrity	
▶ Simulation		(→ 🖺 57)
Assign simulation p	process variable	(→ 🖺 58)
Value process varial	ble	(→ 🖺 58)
Simulation device a	larm	(→ 🖺 58)

Index

A	Device l
Accuracy	Device r
Adapting the diagnostic behavior	Sens
Ambient temperature range 20	Tran Device r
Application	Device i
Application packages	Device i
Applicator	Diagnos
Approvals	Expl
Auto scan buffer	Sym
see Modbus RS485 Modbus data map	Diagnos
С	Com
C-Tick symbol	Desi
Cable entries	Field
Technical data	Ligh
Cable entry	Loca
Degree of protection	Over
CE mark	Rem
Certificates	Diagnos
Check	Diagnos
Installation	Diagnos
Checklist	Sym
Post-connection check	Diagnos
Post-installation check 23	DIP swi
Cleaning	see ¹
Exterior cleaning	Disablin
Cleaning in place (CIP)	Display
Climate class	Curr
Commissioning	Prev
Advanced settings 54	Display
Configuring the measuring device 46	For l
Configuring error response mode, Modbus RS485 70	Disposa
Connecting cable	Docume
Connecting the measuring device	Fund
Connection	Sym
see Electrical connection	Docume
Connection preparations	Down p
Connection tools	E
Current consumption	Electrica
Current input (Submenu)	Com
D	Degr
Declaration of Conformity	Mea
Define access code	Oper
Degree of protection	V
Density	Electror
Design	Enablin
Measuring device	Endress
Design fundamentals	Maii
Maximum measured error 91	Repa
Repeatability	Environ
Designated use 8	Stor
Device components	Error m
Device description files 42	see I
Device documentation	Event h
Supplementary documentation 7	Events l
	1

Device locking, status	60
Device name	
Sensor	
Transmitter	13
Device repair	80
Device revision	42
Device type ID	42
Diagnostic behavior	
Explanation	67
Symbols	
Diagnostic information	
Communication interface	70
Design, description 67,	
FieldCare	
Light emitting diodes	
Local display	
Overview	
Diagnostic list	74
Diagnostic message	
Diagnostics Diagnostics	00
Symbols	66
Diagnostics (Menu)	
Diagnostics (Menu)	.00
see Write protection switch	E 0
Disabling write protection	20
Display Current diagnostic event	72
Current diagnostic event	
Previous diagnostic event	/3
Display values	<i>(</i> 0
For locking status	
Disposal	80
Document	_
Function	5
Symbols used	. 5
Document function	
Down pipe	18
F	
Electrical connection	
Commubox FXA291	96
Degree of protection	
Measuring device	
	40
Operating tools	06
Via service interface (CDI) 39,	
Electromagnetic compatibility	
Enabling write protection	20
Endress+Hauser services	70
Maintenance	
Repair	80
Environment	0.0
Storage temperature	92
Error messages	
see Diagnostic messages	.,
Event history	
Events list	/4

Ex approval	see In alarm condition
Extended order code	Low flow cut off
Sensor	1 7 #
Transmitter	,
Exterior cleaning	Maintenance tasks
F	Manufacturer ID
Field of application	Manufacturing date
Residual risks	
FieldCare	
Device description file	
Establishing a connection	
Function	
User interface	
Filtering the event logbook	
Firmware	Conversion
Release date	
Version	
Firmware history	
Flow direction	
Flow limit	
Function check	
Function codes	Repair
Functions	Measuring principle
see Parameters	Measuring range
	For gases
G	For liquids
Galvanic isolation	gg-,
Н	Measuring system
	Media
Hardware write protection	Wediam pressure
Ţ	Influence
I/O electronics module	Medium temperature
Identifying the measuring device	minuelice
Incoming acceptance	, Menu
Influence	Diagnostics
Medium pressure	Expert
Medium temperature	operation
Information on the document	Setup
Inlet runs	Niemus
Input	Por measuring device configuration 40
Inspection	For specific settings
Received goods	Configuring error response mode 70
Inspection check	Diagnostic information
Connection	Function codes
Installation	Modbus data map
Installation conditions	Read access
Down pipe	Reading out data 44
Mounting location	Register addresses
System pressure	Register information 43
Thermal insulation	Response time
Vibrations	Scan list
Installation dimensions	Write access
Interior cleaning	Modbus RS485 certification
L	Mounting dimensions
	see Installation dimensions
Languages, operation options	Mounting location
-coa atopia,	1

Mounting preparations	Potential equalization
Inlet and outlet runs 20	Power supply failure
Installation dimensions 20	Pressure Equipment Directive
Orientation	Pressure loss
Sensor heating	Pressure-temperature ratings
Mounting tools	Process connections
N.Y.	Process variables
N	Calculated
Nameplate	Measured
Safety Barrier Promass 100	Product safety
Sensor	Protecting parameter settings
Transmitter	R
Nominal pressure	
Secondary containment	Reading measured values
0	Reading out diagnostic information, Modbus RS485 70
Operable flow range	Recalibration
Operating elements	Reference operating conditions
Operating menu	Remedial measures
Menus, submenus	Calling up
Overview of menus with parameters 101	Closing
Structure	Repair
Submenus and user roles	Notes
Operating philosophy	Repair of a device
Operation	Repeatability
Operation (Menu)	Replacement
Operation options	Device components
Operational safety	Requirements for personnel
Order code	Response time
Orientation (vertical, horizontal)	Return
Outlet runs	
Output	S
Output signal	Safety
Overview 101	Safety Barrier Promass 100
Operating menu	Seals Medium temperature range
P	Sensor
Packaging disposal	Medium temperature range
Parameter settings	Mounting
Administration (Submenu)	Sensor (Submenu)
Calculated values (Submenu) 54	Sensor heating
Communication (Submenu) 50	Serial number
Diagnostics (Menu)	Setting the operating language
Low flow cut off (Wizard)	Settings
Operation (Submenu) 63	Adapting the measuring device to the process
Output values (Submenu) 62	conditions
Partially filled pipe detection (Wizard) 53	Communication interface 50
Process variables (Submenu) 60	Device reset
Select medium (Submenu)	Device tag
Sensor adjustment (Submenu)	Low flow cut off
Setup (Menu)	Medium
Totalizer (Submenu)	Operating language
Totalizer 1 to 3 (Submenu)	Partial filled pipe detection
Performance characteristics	Sensor adjustment
Post-connection check (checklist)	Simulation
Post-installation check	System units
Post-installation check (checklist) 23	Totalizer

Totalizer reset	63
Setup (Menu)	
Shock resistance	
Signal on alarm	
Software release	
Spare part	80
Spare parts	
Special connection instructions	
Standards and guidelines	
Status signals	
Sterilization in place (SIP)	
Storage conditions	
Storage temperature	16
Storage temperature range	
Structure	
Operating menu	38
Submenu	
Administration	76
Advanced setup	54
Calculated values	54
Communication	50
Current input	
Define access code	58
Device information	77
Events list	74
Operation	
Output values	62
Overview	
Process variables 54	, 60
Select medium	
Sensor	110
Sensor adjustment	
Simulation	
System	
Totalizer	
Totalizer 1 to 3	56
Supply voltage	87
System (Submenu)	109
System design	
Measuring system	84
see Measuring device design	
System integration	
System pressure	
T	
Technical data, overview	84
Temperature range	
Medium temperature	
Storage temperature	
Terminal assignment	
Terminals	
Thermal insulation	21
Tools	
Electrical connection	25
Installation	
Transport	16
Transmitter	
Connecting the signal cables	
Transporting the measuring device	16

Troubleshooting General	64
U	
Use of the measuring device Borderline cases	8
V	
Version data for the device	92
W	
W@M 79, W@M Device Viewer 12, Weight	
SI units	16
Wizard Define access code	52
Workplace safety	
Write protection Via access code	59
Write protection switch	59



