Brief Operating Instructions EngyCal RS33

Steam calculator



These Instructions are Brief Operating Instructions; they are not a substitute for the Operating Instructions pertaining to the device.

For detailed information, refer to the Operating Instructions and other documentation.

Available for all device versions via:

- Internet: www.endress.com/deviceviewer
- Smart phone/Tablet: Endress+Hauser Operations App





Table of contents

1 1.1	Document information	4
2 2.1 2.2 2.3 2.4 2.5 2.6	Safety instructions Requirements for the personnel . Designated use . Workplace safety . Operational safety . Product safety . IT security .	7 7 7 7 7 7 8
3 3.1 3.2 3.3	Identification Device tag Scope of delivery Certificates and approvals	8 . 8 10 10
4 4.1 4.2 4.3 4.4 4.5 4.6	Installation Incoming acceptance, transport, storage Dimensions Installation conditions Installation Installation instructions for temperature sensor(s) Pressure sensor installation instructions	10 11 13 13 18 19
5 5.1 5.2 5.3 5.4 5.5 5.6	Wiring Connection instructions Quick wiring guide Connecting the sensors Outputs Communication Post-connection check	20 20 23 29 29 31
6 6.1 6.2 6.3	Operation General notes for operation . Display and operating elements . Operating matrix .	32 32 32 35
7 7.1	Commissioning Quick commissioning/make it run	36 36

1 Document information

1.1 Document conventions

1.1.1 Safety symbols

Symbol	Meaning
A DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
A WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
A CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.1.2 Electrical symbols

Symbol	Meaning		
A0011197	Direct current A terminal to which DC voltage is applied or through which direct current flows.		
A0011198	Alternating current A terminal to which alternating voltage is applied or through which alternating current flows.		
A0017381	 Direct current and alternating current A terminal to which alternating voltage or DC voltage is applied. A terminal through which alternating current or direct current flows. 		
 	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.		
A0011199	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.		
A0011201	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.		
A0012751	ESD - electrostatic discharge Protect the terminals from electrostatic discharge. Failure to observe this may result in destruction of parts of the electronics.		

1.1.3 Symbols for certain types of information

Symbol	Meaning	Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.		Preferred Procedures, processes or actions that are preferred.
X	Forbidden Procedures, processes or actions that are forbidden.	i	Tip Indicates additional information.
	Reference to documentation		Reference to page
	Reference to graphic	1. , 2. , 3	Series of steps
4	Result of a sequence of actions		Visual inspection

1.1.4 Symbols in graphics

Symbol	Meaning
1, 2, 3,	Item numbers
1. , 2. , 3	Series of steps
A, B, C,	Views
A-A, B-B, C-C,	Sections
≈ →	Flow direction
A0013441	
EX A0011187	Hazardous area Indicates a hazardous area.
A0011188	Safe area (non-hazardous area) Indicates a non-hazardous area.

1.1.5 Tool symbols

Symbol	Meaning
	Flat-blade screwdriver
A0011220	
•	Phillips screwdriver
A0011219	
$\bigcirc \blacksquare$	Allen key
A0011221	

Symbol	Meaning
Ŕ	Open-ended wrench
A0011222	
0	Torx screwdriver
A0013442	

2 Safety instructions

Safe operation of the device is only guaranteed if the Operating Instructions have been read and the safety instructions they contain have been observed.

2.1 Requirements for the personnel

The personnel must fulfill the following requirements for its tasks:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task
- Are authorized by the plant owner/operator
- Are familiar with federal/national regulations
- Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ► Following instructions and basic conditions

2.2 Designated use

The steam calculator is a flow computer for calculating the mass and energy flow of steam. The mains powered device is designed for use in industrial environments.

- The manufacturer accepts no liability for damages resulting from incorrect use or use other than that designated. It is not permitted to convert or modify the device in any way.
- The device may only be operated when installed.

2.3 Workplace safety

For work on and with the device:

 Wear the required personal protective equipment according to federal/national regulations.

2.4 Operational safety

Risk of injury.

- Operate the device in proper technical condition and fail-safe condition only.
- ► The operator is responsible for interference-free operation of the device.

Environmental requirements

If a plastic transmitter housing is permanently exposed to certain steam and air mixtures, this can damage the housing.

- ▶ If you are unsure, please contact your Endress+Hauser Sales Center for clarification.
- ► If used in an approval-related area, observe the information on the nameplate.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet stateof-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

3 Identification

3.1 Device tag

3.1.1 Nameplate

Compare the nameplate on the device with the following diagram:



- 1 Device nameplate (example)
- 1 Device tag
- 2 Order code and serial number
- 3 Supply voltage
- 4 Power consumption
- 5 Firmware version
- 6 Approvals, if available
- 7 Ambient temperature range
- 8 Device revision
- 9 Device protected by double or reinforced seal
- 10 Place and year of manufacture

3.1.2 Serial number on the front of the device



Serial number on front of device

3.2 Scope of delivery

The scope of delivery of the steam calculator comprises:

- Steam calculator (field housing)
- Brief Operating Instructions in paper form
- Optional 3 pcs. connection clamps (5 positions apiece)
- Optional interface cable and DVD set with FieldCare Device Setup parameter configuration software
- Optional Field Data Manager software MS20
- Optional mounting hardware for DIN rail, panel mounting, pipe mounting
- Optional overvoltage protection

Please note the device accessories in Section Accessories in the Operating Instructions.

3.3 Certificates and approvals

The steam calculator meets the general requirements for steam calculators in accordance with OIML R75 and EN-1434.

According to European law, steam calculators are not subject to mandatory verification. However, approval as part of individual measuring point verification is possible. Furthermore, national type approvals are currently pending for the device.

CE mark, Declaration of Conformity

The device is designed to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations in accordance with EN 61010-1 "Safety requirements for electrical equipment for measurement, control and laboratory use".

The device described in these Operating Instructions therefore complies with the statutory requirements of the EU Directives. The manufacturer confirms that the device has been successfully tested by applying the CE mark.

4 Installation

4.1 Incoming acceptance, transport, storage

Compliance with the permitted environmental and storage conditions is mandatory. Precise specifications are provided in the "Technical Information" section of the Operating Instructions.

4.1.1 Incoming acceptance

On receipt of the goods, check the following points:

- Is the packaging or the content damaged?
- Is the delivery complete? Compare the scope of delivery against the information on your order form.

4.1.2 Transport and storage

Please note the following:

- Pack the device in such a way as to protect it reliably against impact for storage (and transportation). The original packaging provides optimum protection.
- The permitted storage temperature is -40 to +85 °C (-40 to +185 °F); it is possible to store the device at borderline temperatures for a limited period (48 hours maximum).

4.2 Dimensions



☑ 3 Dimensions of the device in mm (in)



Dimensions of the mounting plate for wall, pipe and panel mounting in mm (in)



■ 5 Dimensions of the panel cutout in mm (in)



Image: Dimensions of DIN rail adapter in mm (in)

4.3 Installation conditions

With the appropriate accessories the device with field housing is suitable for wall mounting, pipe mounting, panel mounting and DIN rail installation. ¹⁾.

The orientation is only determined by the legibility of the display. Connections and outputs are fed out of the bottom of the device. The cables are connected via coded terminals.

Operating temperature range:-20 to 60 °C (-4 to 140 °F)

You can find more information in the "Technical data" section.

NOTICE

Overheating of the device due to insufficient cooling

To avoid heat buildup, please always ensure that the device is sufficiently cooled. Operating the device in the upper temperature limit range decreases the operating life of the display.

4.4 Installation

4.4.1 Wall mounting

- 1. Use the mounting plate as the template for drilled holes, dimensions ($\rightarrow \square 4$, $\square 12$)
- 2. Attach the device to the mounting plate and fasten it in place from the rear using 4 screws.
- 3. Fasten the mounting plate to the wall using 4 screws.

¹⁾ According to UL approval panel or surface mountable only.





4.4.2 Panel mounting

1. Make the panel cutout in the required size, dimensions ($\rightarrow \square 5$, $\square 12$)



8 Panel mounting

Attach the seal (item 1) to the housing.



Preparing the mounting plate for panel mounting

Screw the threaded rods (item 2) into the mounting plate (dimensions ($\rightarrow \square 4, \square 12$)).



■ 10 Panel mounting

Push the device into the panel cutout from the front and attach the mounting plate to the device from the rear using the 4 screws provided (item 3).

5. Fasten the device in place by tightening the threaded rods.

4.4.3 Support rail/DIN rail (to EN 50 022)



🖻 11 Preparing for DIN rail mounting

Fasten the DIN rail adapter (item 1) to the device using the screws provided (item 2) and open the DIN rail clips.



I2 DIN rail mounting

Attach the device to the DIN rail from the front and close the DIN rail clips.

4.4.4 Pipe mounting



13 Preparing for pipe mounting

Pull the steel belts through the mounting plate (dimensions ($\rightarrow \blacksquare 4$, $\boxdot 12$)) and fasten them to the pipe.



■ 14 Pipe mounting

Attach device to mounting plate and fasten it in place using the 4 screws provided.

4.5 Installation instructions for temperature sensor(s)



- Installation types for temperature sensors
- A BFor cables with a small cross-section, the sensor tip must reach to the piping axis or a little farther (=L).
- C D Slanted orientation.

The immersion length of the thermometer influences the accuracy. If the immersion length is too small, errors in the measurement are caused by heat conduction via the process connection and the container wall. For installation in a pipe, therefore, the recommended installation depth ideally corresponds to half of the pipe diameter.

- Installation possibilities: Pipes, tanks or other plant components
- Minimum immersion depth = 80 to 100 mm (3.15 to 3.94 in) The immersion depth should be at least 8 times the diameter of the thermowell. Example: Thermowell diameter 12 mm (0.47 in) x 8 = 96 mm (3.8 in). We recommend a standard immersion depth of 120 mm (4.72 in).

For pipes with small nominal diameters, ensure that the tip of the thermowell extends far enough into the process so that it also protrudes past the axis of the pipe ((→ 🖻 15, 🗎 18), item A and B). Another solution may be diagonal installation ((→ 🖻 15, 🖺 18), item C and D). To determine the immersion length or installation depth, all parameters of the thermometer and the process to be measured must be taken into account (e.g. flow velocity, process pressure).

Refer also to the installation recommendations EN1434-2 (D), Figure 8.

4.6 Pressure sensor installation instructions



16 Measuring arrangement for pressure measurement in steams

- 1 Pressure sensor
- 2 Shutoff device
- 3 U-shaped water pocket
- 4 O-shaped water pocket
- Mount the pressure sensor with the water pocket pipe above the tapping point. The water pocket pipe reduces the temperature to almost ambient temperature.
- Fill the water pocket pipe with liquid before commissioning.

5 Wiring

5.1 Connection instructions

WARNING

Danger! Electric voltage!

► The entire connection of the device must take place while the device is de-energized.

Pay attention to additional information provided

- ► Before commissioning, ensure that the supply voltage corresponds to the specification on the nameplate.
- Provide a suitable switch or power-circuit breaker in the building installation. This switch must be provided close to the device (within easy reach) and marked as a circuit breaker.
- ► An overload protection element (rated current ≤ 10 A) is required for the power cable.

For installing the steam calculator and the associated components, observe the general instructions according to EN 1434 Part 6.

5.2 Quick wiring guide



🖻 17 Connection diagram of the device

Terminal assignment

- In the case of heat differential /T, the temperature sensor for T condensate must be connected to the T Warm terminals and the temperature sensor for T steam to the T Cold terminals.
 - In the case of heat differential /p, the temperature sensor for T condensate must be connected to the T Warm terminals.

Terminal	Terminal assignment	Inputs	
1	+ RTD power supply	Temperature	
2	- RTD power supply	(Optionally RTD or current input)	
5	+ RTD sensor		
6	- RTD sensor		
52	+ 0/4 to 20 mA input		
53	Ground for 0/4 to 20 mA input		
3	+ RTD power supply	Pressure	
4	- RTD power supply		
7	+ RTD sensor	-	
8	- RTD sensor	-	
54	+ 0/4 to 20 mA input	-	
55	Ground for 0/4 to 20 mA input	-	
10	+ pulse input (voltage)	Flow	
11	- pulse input (voltage)	(Optionally pulse or current input)	
50	+ 0/4 to 20 mA or current pulse (PFM)		
51	Ground for 0/4 to 20 mA input flow		
80	+ digital input 1 (switch input)	Start tariff counter 1Time synchronizationLock device	
81	- digital input (terminal 1)		
82	+ digital input 2 (switch input)	Start tariff counter 2	
81	- digital input (terminal 2)	 Time synchronization Lock device 	
		Outputs	
60	+ pulse output 1 (open collector)	Energy, volume or tariff counter. Alternative: limits/alarms	
61	- pulse output 1 (open collector)		
62	+ pulse output 2 (open collector)		
63	- pulse output 2 (open collector)		
70	+ 0/4 to 20 mA/pulse output	Current values (e.g. power) or	
71	- 0/4 to 20 mA/pulse output	counter values (e.g. energy)	
13	Relay normally open (NO)	Limits, alarms	

14	Relay normally open (NO)		
23	Relay normally open (NO)		
24	Relay normally open (NO)		
90	24V sensor power supply (LPS)	24 V power supply (e.g. for sensor power supply)	
91	Power supply ground		
		Power supply	
L/+	L for AC + for DC		
N/-	N for AC - for DC		

5.2.1 Open the housing



18 Opening the housing of the device

- 1 Terminal assignment labeling
- 2 Terminals

5.3 Connecting the sensors

5.3.1 Flow

Flow sensors with external power supply



- ☑ 19 Connecting a flow sensor
- A Voltage pulses or contact sensors including EN 1434 Type IB, IC, ID, IE
- B Current pulses
- C 0/4 to 20 mA signal

Flow sensors with power supply via the steam calculator



Connecting active flow sensors

A 4-wire sensor

🖻 20

B 2-wire sensor

Settings for flow sensors with pulse output

The input for voltage pulses and contact sensors is divided into different types according to EN1434 and provides a supply for switching contacts.

Pulse output of the flow sensor	Setting at the Rx33	Electrical connection	Notes
Mechanical contact	Pulse ID/IE up to 25 Hz	$A \qquad 10 \qquad B \\ 11 \qquad 11 \qquad A \\ A \qquad A \\ Sensor \\ B Rx33$	As an alternative, it is possible to choose "Pulse IB/IC+U" up to 25 Hz. The current flow via the contact is then lower (approx. 0.05 mA instead of approx. 9 mA). Advantage: lower power consumption, disadvantage: less immunity to interference.
Open collector (NPN)	Pulse ID/IE up to 25 Hz or up to 12.5 kHz	$A \qquad 10 \qquad B \\ 11 \qquad A \\ A \qquad A \qquad$	As an alternative, it is possible to choose "Pulse IB/IC+U". The current flow via the transistor is then lower (approx. 0.05 mA instead of approx. 9 mA). Advantage: lower power consumption, disadvantage: less immunity to interference.
Active voltage	Pulse IB/IC+U	A + b + b + b + b + b + b + b + b + b +	The switching threshold is between 1 V and 2 V

Pulse output of the flow sensor	Setting at the Rx33	Electrical connection	Notes
Active current	Pulse I	$A \qquad \qquad$	The switching threshold is between 8 mA and 13 mA
Namur sensor (as per EN60947-5-6)	Pulse ID/IE up to 25 Hz or up to 12.5 kHz	$A \qquad + \qquad $	No monitoring for short circuit or line break takes place.

Voltage pulses and transmitters according to Class IB and IC (low switching thresholds, small currents)	≤ 1 V corresponds to Low level ≥ 2 V corresponds to High level U max 30 V, U no-load: 3 to 6 V	Floating contacts, reed transmitters
Transmitters to Class ID and IE for higher currents and power supplies	≤ 1.2 mA corresponds to Low level ≥ 2.1 mA corresponds to High level U no-load: 7 to 9 V	

Endress+Hauser flowmeters







DP sensors: Deltabar M PMD55, Deltabar S PMD 70/75	+ 90
	A0014184

5.3.2 Temperature

Connecting the RTD sensors	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$
	A = 2-wire connection B = 3-wire connection C = 4-wire connection * only use in event of energy calculation with heat differential /T, temperature sensor in steam Terminals 1, 2, 5, 6: temperature Terminals 3, 4, 7, 8: temperature



To ensure the highest level of accuracy, we recommend using the RTD 4-wire connection, as this compensates for measurement inaccuracies caused by the mounting location of the sensors or the line length of the connecting cables.

Endress+Hauser temperature sensors and transmitters



Connection of TMT181, TMT121 temperature transmitter	1 / + 90 2 / 52 53	
	A0014	531
	Terminals 90, 91: transmitter power supply Terminals 52, 53: temperature	

5.3.3 Pressure

Pressure sensor connection	+ <u>A</u> 90	В
		+ 54 55
		A0015152
A = 2-wire sensor with power supply via the steam calculator B = 4-wire sensor with external power supply Terminals 90, 91: transmitter power supply Terminals 54, 55: pressure		e steam calculator oly 7

Endress+Hauser pressure transmitter Cerabar M, Cerabar S

Cerabar M, Cerabar S	+ 90
	A0014532
	Terminals 90, 91: transmitter power supply Terminals 54, 55: pressure

5.4 Outputs

5.4.1 Analog output

This output can be used either as a 0/4 to 20 mA current output or as a voltage pulse output. The output is galvanically isolated. Terminal assignment, ($\Rightarrow \square 20$).

5.4.2 Relay

The two relays can be switched in case of fault messages or a limit violation.

Relay 1 or 2 can be selected under **Setup→Advanced setup→System→Fault switching**.

Limit values are assigned under **Setup** \rightarrow **Advanced setup** \rightarrow **Application** \rightarrow **Limits**. Possible settings for limit values are described in the "Limits" section of the Operating Instructions.

5.4.3 Pulse output

Voltage level:

- 0 to 2 V corresponds to Low level
- 15 to 20 V corresponds to High level

Maximum output current:22 mA

5.4.4 Open collector output

The two digital outputs can be used as status or pulse outputs. Make the selection in the following menus **Setup** \rightarrow **Advanced setup** or **Expert** \rightarrow **Outputs** \rightarrow **Open collector**

5.5 Communication

The USB interface is always active and can be used independently of other interfaces. Parallel operation of multiple optional interfaces, e.g. fieldbus and Ethernet, is not possible.

5.5.1 Ethernet TCP/IP (optional)

The Ethernet interface is galvanically isolated (testing voltage: 500 V). A standard patch cable (e.g. CAT5E) can be used to connect the Ethernet interface. A special cable gland is available for this purpose which allows users to guide pre-terminated cables through the housing. Via the Ethernet interface, the device can be connected using a hub or a switch or directly to office equipment.

- Standard: 10/100 Base T/TX (IEEE 802.3)
- Socket: RJ-45
- Max. cable length: 100 m



21 Connection of Ethernet TCP/IP, Modbus TCP

- 1 Ethernet, RJ45
- 2 Cable entry for Ethernet cable

5.5.2 Modbus TCP (optional)

The Modbus TCP interface is used to connect the device to higher-order systems to transmit all measured values and process values. The Modbus TCP interface is physically identical to the Ethernet interface ($\rightarrow \blacksquare 21$, $\boxplus 30$).

5.5.3 Modbus RTU (optional)

The Modbus RTU (RS-485) interface is galvanically isolated (testing voltage: 500 V) and used to connect the device to higher-order systems to transmit all measured values and process values. It is connected via a 3-pin plug-in terminal in the housing cover.



■ 22 Connection of Modbus RTU

5.5.4 M-Bus (optional)

The M-Bus (Meter Bus) interface is galvanically isolated (testing voltage: 500 V) and used to connect the device to higher-order systems to transmit all measured values and process values. It is connected via a 3-pin plug-in terminal in the housing cover.



■ 23 Connection of M-Bus

5.6 Post-connection check

After completing the device's electrical installation, carry out the following checks:

Device condition and specifications	Notes
Is the device or cable damaged (visual inspection)?	-
Electrical connection	Notes
Does the supply voltage match the specifications on the nameplate?	100 to 230 V AC/DC (±10 %) (50/60 Hz) 24 V DC (-50 % / +75 %) 24 V AC (±50 %) 50/60 Hz
Do the cables have adequate strain relief?	-
Are the power supply and signal cables correctly connected?	See wiring diagram on the housing

6 Operation

6.1 General notes for operation

The steam calculator can be configured using keys or using the "FieldCare" operating software.

Die Bediensoftware inklusive Schnittstellenkabel ist als Bestelloption erhältlich, d.h. nicht Grundbestandteil des Lieferumfangs.

The configuration is locked if the device is locked by the hardware lock ($\rightarrow \implies$ 33), user code or digital input.

Details, see section "Access protection" in the Operating Instructions.



6.2 Display and operating elements

24 Display and operating elements of the device

- 1 LED green, "Operation"
- 2 LED red, "Fault indicator"
- 3 USB connection for configuration
- 4 Operating keys: -, +, E
- 5 160x80 DOT matrix display
- H

Green LED for voltage, red LED for alarm/error. Green LED is always illuminated as soon as power is supplied to the device.

Slow flashing of the red LED (approx. 0.5 Hz): the device has been put into bootloader mode.

Fast flashing of the red LED (approx. 2 Hz): in normal operation: maintenance required. During firmware update: data transmission active.

Red LED illuminated constantly: device error.

6.2.1 Operating elements

3 operating keys, "-", "+", "E"

Esc/back function: press "-" and "+" simultaneously.

Enter/confirm entry: press "E"

Hardware lock



25 Hardware lock

1 Hardware lock on the back of the housing cover

6.2.2 Display



26 Display of the steam calculator (example)

- 1 Display Group 1
- 2 Display Group 2

6.2.3 "FieldCare Device Setup" operating software

For configuring the device using the FieldCare Device Setup software, connect the device to your computer's USB interface.

Establishing a connection

- 1. Start FieldCare.
- 2. Connect the device to the computer via USB.
- 3. Generate project via File/New.
- 4. Select communication DTM (CDI Communication USB).
- 5. Add device EngyCal[®] RS33.
- 6. Click "Establish connection".
- 7. Start configuration.

Carry out the rest of the configuration of the device according to these Operating Instructions for the device. The entire Setup menu, i.e. all parameters listed in these Operating Instructions, is also included in the FieldCare Device Setup.

NOTICE

Undefined switching of outputs and relays

► The device can enter undefined states during configuration with FieldCare! This can result in undefined switching of outputs and relays.

6.3 Operating matrix

For a complete overview of the operating matrix including all configurable parameters, see appendix of the operating instructions.

Sprache/Language	Pick list with all available operating languages. Select the language of the device.

Display/operation menu	 Select the group for display (automatic change or fixed display group) Setting for the display brightness and contrast Display the stored analyses (Day, Month, Year, Billing date, Totalizer)
------------------------	--

tup menu In this Setup, you can configure the parameters for quie commissioning of the device. Advanced setup includes important parameters for configuring the instrument f	parameters for quick nced setup includes all ng the instrument function.	
	 Units Pulse value, Value Date and time Pressure 	Parameters for quick commissioning
	Advanced setup (settings that are r of the device) Special settings can be configured v	iot essential for basic operation ria "Expert".

Diagnostics menu	Device information and service functions for a swift device check.
	 Diagnostic messages and list Event logbook Device information Simulation Measured values, outputs

Expert menu	The Expert menu offers access to all operating options of the device, including fine tuning and service functions.
	 Jump directly to parameters via Direct Access (only on the device) Service code for displaying service parameters (via PC operating software only) System (settings) Inputs Outputs Application Diagnostics

7 Commissioning

Make sure that all post-connection checks have been carried out before putting your device into operation:

Checklist, 'Post-connection check' section, ($\Rightarrow \square 31$).

After the operating voltage is applied, the display and the green LED are illuminated. The device is now ready to operate and can be configured via the keys or the "FieldCare" parameter configuration software ($\rightarrow \square$ 34).



Remove the protective film from the display as this would otherwise affect the readability of the display.

7.1 Quick commissioning/make it run

The standard application for steam mass/energy is commissioned in just a few moments by simply configuring 5 operating parameters in the **Setup** menu.

Prerequisites for quick commissioning:

- Flow transmitter with pulse output
- RTD temperature sensor, 4-wire direct connection
- Absolute pressure sensor with current output 4 to 20 mA

Menu/setup

- Units: Select unit type (SI/US)
- Pulse value: Select the unit of the pulse value of the flow transmitter
- Value: Enter the pulse value of the flow sensor
- Date/time: Set the date and time
- **Pressure**: Set the measuring range for the pressure sensor

The device is now operational and ready for measuring the steam mass and heat energy.

You can configure device functions, such as data logging, tariff function, bus connection and the scaling of current inputs for flow or temperature, in the **Advanced setup** menu or in the **Expert** menu. A description of these menus can be found in the Operating Instructions.

Here, you can also find the settings for the inputs (e.g. when connecting a relative pressure sensor, flow transmitter with a current output etc.).

Inputs/flow:

Select the signal type and enter the start and end of the measuring range (for current signal) or the pulse value of the flow transmitter.

Inputs/temperature:

Select the signal type and enter the type of connection or the start and end of the measuring range (for current signals).

Inputs/pressure:

Select the signal type and the pressure unit (absolute or relative) and enter the start and end of the measuring range.

www.addresses.endress.com

