
Products

Operating Instructions **Proline Promass E 200 HART**

Coriolis flowmeter





- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Document information 6		6.2.2 Preparing the measuring device 6.2.3 Mounting the measuring device	
1.1 1.2	Document function 6 Symbols used		6.2.4 Turning the transmitter housing	24
1.2	1.2.1 Safety symbols 6	()	6.2.5 Turning the display module	
	1.2.2 Electrical symbols 6	6.3	Post-installation check	25
	1.2.3 Tool symbols 6 1.2.4 Symbols for certain types of	7	Electrical connection	26
	information 7	7.1	Connection conditions	
1.3	1.2.5 Symbols in graphics		7.1.1 Required tools	
1.5	1.3.1 Standard documentation 8		7.1.2 Connecting cable requirements7.1.3 Terminal assignment	
	1.3.2 Supplementary device-dependent		7.1.4 Requirements for the supply unit	
	documentation 8		7.1.5 Preparing the measuring device	28
1.4	Registered trademarks 8	7.2	Connecting the measuring device	
_	D : ()		7.2.1 Connecting the transmitter 7.2.2 Ensuring potential equalization	
2	Basic safety instructions 9	7.3	Special connection instructions	
2.1	Requirements for the personnel 9		7.3.1 Connection examples	
2.2 2.3	Designated use	7.4	Ensuring the degree of protection	
2.4	Operational safety	7.5	Post-connection check	32
2.5	Product safety	0	0 1:	2.2
2.6	IT security	8	Operation options	
_		8.1 8.2	Overview of operation options	33
3	Product description 12	0.2	Structure and function of the operating menu	34
3.1	Product design		8.2.1 Structure of the operating menu	34
,			8.2.2 Operating philosophy	35
4	Incoming acceptance and product	8.3	Access to the operating menu via the local	36
	identification		display	
4.1	Incoming acceptance		8.3.2 Navigation view	
4.2	Product identification		8.3.3 Editing view	
	4.2.1 Transmitter nameplate		8.3.4 Operating elements	
	4.2.3 Symbols on measuring device 16		8.3.5 Opening the context menu8.3.6 Navigating and selecting from list	
	, s		8.3.7 Calling the parameter directly	
5	Storage and transport 17		8.3.8 Calling up help text	
5.1	Storage conditions		8.3.9 Changing the parameters	45
5.2	Transporting the product		8.3.10 User roles and related access	1. 0
	5.2.1 Measuring devices without lifting		authorization	46
	lugs		code	46
	5.2.2 Measuring devices with fitting rugs		8.3.12 Enabling and disabling the keypad	
5.3	Packaging disposal	0.1	lock	46
		8.4	Access to the operating menu via the operating tool	47
6	Installation		8.4.1 Connecting the operating tool	48
6.1	Installation conditions		8.4.2 Field Xpert SFX350, SFX370	49
	6.1.1 Mounting position 19		8.4.3 FieldCare	49
	6.1.2 Requirements from environment and		8.4.4 AMS Device Manager	
	process		8.4.5 SIMATIC PDM	
6.2	6.1.3 Special mounting instructions 23 Mounting the measuring device 23		8.4.6 Field Communicator 475	1 (ز
٥.۵	6.2.1 Required tools			
	•			

9	System integration	52	12	Diagnostics and troubleshooting	104
9.1	Overview of device description files	52	12.1	General troubleshooting	. 104
	9.1.1 Current version data for the device		12.2	Diagnostic information on local display	. 106
	9.1.2 Operating tools	52		12.2.1 Diagnostic message	
9.2	Measured variables via HART protocol			12.2.2 Calling up remedial measures	108
9.3	Other settings		12.3	Diagnostic information in FieldCare	108
	9.3.1 Burst mode functionality in			12.3.1 Diagnostic options	
	accordance with HART 7			12.3.2 Calling up remedy information	109
	Specification	54	12.4	Adapting the diagnostic information	110
	Specification	7 1	12.1	12.4.1 Adapting the diagnostic behavior	
10	C	F 7		12.4.2 Adapting the status signal	
10	Commissioning	5/	12.5	Overview of diagnostic information	
10.1	Function check	57		Pending diagnostic events	114
10.2	Switching on the measuring device	57		Diagnostic list	115
10.3	Setting the operating language	57		Event logbook	
10.4	Configuring the measuring device		12.0	12.8.1 Event history	
	10.4.1 Defining the tag name			12.8.2 Filtering the event logbook	116
	10.4.2 Selecting and setting the medium	60		12.8.3 Overview of information events	
	10.4.3 Setting the system units	61	12.9	Resetting the measuring device	117
	10.4.4 Configuring the current output	64	14.7	12.9.1 Function scope of the "Device reset"	11/
	10.4.5 Configuring the pulse/frequency/			parameter	11Ω
	switch output	67	12 10	Device information	118
	10.4.6 Configuring the local display	75		Firmware history	
	10.4.7 Configuring the output		12.11	Tilliwate history	120
	conditioning		13	Maintanana	122
	10.4.8 Configuring the low flow cut off	81		Maintenance	
	10.4.9 Configuring the partial filled pipe		13.1	Maintenance tasks	
	detection	83		13.1.1 Exterior cleaning	
10.5	Advanced settings			13.1.2 Interior cleaning	
	10.5.1 Carrying out a sensor adjustment			Measuring and test equipment	
	10.5.2 Configuring the totalizer	85	13.3	Endress+Hauser services	122
	10.5.3 Carrying out additional display	0.1			
	configurations		14	Repair	123
10 (10.5.4 Administration configuration	89	14.1	General notes	123
10.6	Configuration management	90		Spare parts	123
	10.6.1 Function scope of the "Configuration	0.1		Endress+Hauser services	124
107	management" parameter	91		Return	124
	Simulation	91		Disposal	
10.8	Protecting settings from unauthorized	0.0	2 21,5	14.5.1 Removing the measuring device	
	access	93		14.5.2 Disposing of the measuring device	
	10.8.1 Write protection via access code	93			
	10.8.2 Write protection via write protection switch	Q/ı	15	Accessories	126
	Switch	74			
11	Onevetien	07	15.1	Device-specific accessories	
11	Operation			15.1.1 For the transmitter	
11.1	Reading the device locking status	97	1 Г つ	15.1.2 For the sensor	
11.2	Adjusting the operating language	97		Communication-specific accessories	
11.3	Configuring the display	97		Service-specific accessories	
11.4	Reading measured values		17.4	System components	120
	11.4.1 Process variables		4.6	m 1 1 1 1 .	100
	11.4.2 Totalizer	98	16	Technical data	129
44 5	11.4.3 Output values	99	16.1	Application	129
11.5	Adapting the measuring device to the process	100	16.2	Function and system design	
11 /		100	16.3	Input	129
11.6	3	100		Output	131
11.7	Showing data logging	101		Power supply	
				Performance characteristics	
			16.7	Installation	138

16.8	Environment	130
16.9	Process	139
16.10	Mechanical construction	141
16.11	Operability	144
16.12	Certificates and approvals	146
16.13	Application packages	148
16.14	Accessories	148
16.15	Documentation	149
Index	ζ	150

1 Document information

1.1 Document function

These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used

1.2.1 Safety symbols

Symbol	Meaning
▲ DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
▲ WARNING	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
▲ CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols

Symbol	Meaning	Symbol	Meaning
	Direct current	~	Alternating current
≂	Direct current and alternating current	- 11	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.	♦	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Tool symbols

Symbol	Meaning
0	Flat blade screwdriver
0 6	Allen key
Ó	Open-ended wrench

1.2.4 Symbols for certain types of information

Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
Preferred Procedures, processes or actions that are preferred.	
X	Forbidden Procedures, processes or actions that are forbidden.
Tip Indicates additional information.	
Ţį.	Reference to documentation
	Reference to page
Reference to graphic	
1. , 2. , 3	Series of steps
L	Result of a sequence of actions
?	Help in the event of a problem
	Visual inspection

1.2.5 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3,	Item numbers	1. , 2. , 3	Series of steps
A, B, C,	Views	A-A, B-B, C-C,	Sections
EX	Hazardous area	×	Safe area (non-hazardous area)
≋➡	Flow direction		

1.3 Documentation

- For an overview of the scope of the associated Technical Documentation, refer to the following:
 - The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
 - The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
- For a detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

HART®

Registered trademark of the HART Communication Foundation, Austin, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

Applicator[®], FieldCare[®], Field XpertTM, HistoROM[®], Heartbeat TechnologyTM Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ► Trained, qualified specialists must have a relevant qualification for this specific function and task
- ► Are authorized by the plant owner/operator
- ► Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ► Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ► Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids and gases.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ► Check the nameplate to verify if the device ordered can be put to its intended use in the approval-related area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section $\rightarrow \boxdot$ 7.
- ► Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

A WARNING

Danger of breakage of the measuring tube due to corrosive or abrasive fluids or from environmental conditions.

Housing breakage due to mechanical overload possible!

- ▶ Verify the compatibility of the process fluid with the measuring tube material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

Verification for borderline cases:

► For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

A WARNING

Danger of housing breaking due to measuring tube breakage!

▶ In the event of a measuring tube breakage for a device version without rupture disk it is possible for the pressure loading capacity of the sensor housing to be exceeded. This can lead to rupture or failure of the sensor housing.

The external surface temperature of the housing can increase by max. 20 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

► Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ► Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.


3 Product description

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design




A001405

- \blacksquare 1 Important components of a measuring device
- 1 Electronics compartment cover
- 2 Display module
- 3 Main electronics module
- 4 Cable glands
- 5 Transmitter housing (incl. integrated HistoROM)
- 6 I/O electronics module
- 7 Terminals (spring loaded terminals, pluggable)
- 8 Connection compartment cover
- 9 Sensor (incl. HistoROM S-DAT)

4 Incoming acceptance and product identification

4.1 Incoming acceptance



- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
 - Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the Endress+Hauser Operations App, see the "Product identification" section → 14.

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" \rightarrow \blacksquare 8 and "Supplementary device-dependent documentation" \rightarrow \blacksquare 8
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.


4.2.1 Transmitter nameplate



■ 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Type of cable glands
- 8 Permitted ambient temperature (T_a)
- 9 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 10 CE mark, C-Tick
- 11 Additional information on version: certificates, approvals
- 12 Permitted temperature range for cable
- 13 Manufacturing date: year-month
- 14 Degree of protection
- 15 Approval information for explosion protection
- 16 Document number of safety-related supplementary documentation
- 17 2-D matrix code

4.2.2 Sensor nameplate



■ 3 Example of a sensor nameplate

- 1 Manufacturing location
- 2 Name of the sensor
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Nominal diameter of sensor
- 7 Test pressure of the sensor
- 8 Flange nominal diameter/nominal pressure
- 9 Material of measuring tube and manifold
- 10 Medium temperature range
- 11 CE mark, C-Tick
- 12 Additional information on version: certificates, approvals
- 13 Manufacturing date: year-month
- 14 Flow direction
- 15 2-D matrix code
- 16 Degree of protection
- 17 Approval information for explosion protection and Pressure Equipment Directive
- 18 Permitted ambient temperature (T_a)
- 19 Document number of safety-related supplementary documentation

Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approvalrelated specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).

4.2.3 Symbols on measuring device

Symbol	Meaning
Δ	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
(i	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions


Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections.
 They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature: -40 to +80 °C (-40 to +176 °F), Order code for "Test, Certificate", option JM: -50 to +60 °C (-58 to +140 °F), preferably at +20 °C (+68 °F)

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0015604

Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


5.2.1 Measuring devices without lifting lugs

A WARNING

Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ► Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0015606

5.2.2 Measuring devices with lifting lugs

A CAUTION

Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ► The device must always be secured at two lifting lugs at least.

5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - $\,$ Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.

or

- Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation

6.1 Installation conditions


No special measures such as supports are necessary. External forces are absorbed by the construction of the device.

6.1.1 Mounting position

Mounting location

To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:


- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.



A0023344

Installation in down pipes

However, the following installation suggestion allows for installation in an open vertical pipeline. Pipe restrictions or the use of an orifice with a smaller cross-section than the nominal diameter prevent the sensor running empty while measurement is in progress.



A001559

- \blacksquare 4 Installation in a down pipe (e.g. for batching applications)
- 1 Supply tank
- 2 Sensor
- 3 Orifice plate, pipe restriction
- 4 Valve
- 5 Batching tank

D	N	Ø orifice plate, pipe restriction		
[mm]	[in]	[mm]	[in]	
8	3/8	6	0.24	
15	1/2	10	0.40	
25	1	14	0.55	
40	1½	22	0.87	
50	2	28	1.10	


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

	Recommendation		
A	Vertical orientation	A0015591	☑ ☑
В	Horizontal orientation, transmitter head up	A0015589	✓ ✓ 1) Exception:→ 💀 5, 🖺 20
С	Horizontal orientation, transmitter head down	A0015590	✓ ✓ ²⁾ Exception: → 🖫 5, 🖺 20
D	Horizontal orientation, transmitter head at side	A0015592	×

- 1) Applications with low process temperatures may reduce the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.


If a sensor is installed horizontally with a curved measuring tube, match the position of the sensor to the fluid properties.



■ 5 Orientation of sensor with curved measuring tube

- 1 Avoid this orientation for fluids with entrained solids: Risk of solids accumulating.
- 2 Avoid this orientation for outgassing fluids: Risk of gas accumulating.

Inlet and outlet runs



Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process

Ambient temperature range

Measuring device	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to $+60$ °C (-4 to $+140$ °F) The readability of the display may be impaired at temperatures outside the temperature range.

If operating outdoors:
 Avoid direct sunlight, particularly in warm climatic regions.

System pressure


It is important that cavitation does not occur, or that gases entrained in the liquids do not outgas.

Cavitation is caused if the pressure drops below the vapor pressure:

- In liquids that have a low boiling point (e.g. hydrocarbons, solvents, liquefied gases)
- In suction lines
- ► Ensure the system pressure is sufficiently high to prevent cavitation and outgassing.

For this reason, the following mounting locations are recommended:

- At the lowest point in a vertical pipe
- Downstream from pumps (no danger of vacuum)



A0015594


Thermal insulation

In the case of some fluids, it is important that the heat radiated from the sensor to the transmitter is kept to a minimum. A wide range of materials can be used for the required insulation.

NOTICE

Electronics overheating on account of thermal insulation!

► Observe maximum permitted insulation height of the transmitter neck so that the transmitter head is completely free.



Heating

NOTICE

Electronics can overheat due to elevated ambient temperature!

- ▶ Depending on the fluid temperature, take the device orientation requirements into account .

NOTICE

Danger of overheating when heating

- ► Ensure that the temperature at the lower end of the transmitter housing does not exceed 80 °C (176 °F)
- ► Ensure that convection takes place on a sufficiently large scale at the transmitter neck.
- ► Ensure that a sufficiently large area of the housing support remains exposed. The uncovered part serves as a radiator and protects the electronics from overheating and excessive cooling.

Heating options

If a fluid requires that no heat loss should occur at the sensor, users can avail of the following heating options:

- Electrical heating, e.g. with electric band heaters
- Via pipes carrying hot water or steam
- Via heating jackets

Using an electrical trace heating system

If heating is regulated via phase angle control or pulse packages, magnetic fields can affect the measured values (= for values that are greater than the values approved by the EN standard (sine 30 A/m)).

For this reason, the sensor must be magnetically shielded: the housing can be shielded with tin plates or electric sheets without a privileged direction (e.g. V330-35A).

The sheet must have the following properties:


- \blacksquare Relative magnetic permeability $\mu r \geq 300$
- Plate thickness $d \ge 0.35$ mm ($d \ge 0.014$ in)

Vibrations

The high oscillation frequency of the measuring tubes ensures that the correct operation of the measuring system is not influenced by plant vibrations.

6.1.3 Special mounting instructions

Rupture disk



■ 6 Rupture disk label

After the rupture disk is actuated, do not operate the measuring device any more.

A WARNING

Limited functional reliability of the rupture disk.

Danger to persons from escaping fluids!

- ▶ Do not remove the rupture disk.
- ▶ When using a rupture disk, do not use a heating jacket.
- ► Make sure that the function and operation of the rupture disk is not impeded through the installation of the device.
- ► Take precautions to prevent damage and danger to persons if the rupture disk is actuated.
- ▶ Observe information on the rupture disk sticker.

Zero point adjustment

Experience shows that zero point adjustment is advisable only in special cases:

- To achieve maximum measuring accuracy even with low flow rates
- Under extreme process or operating conditions (e.g. very high process temperatures or very high-viscosity fluids).

Zero point adjustment is performed via the **Zero point adjustment control** parameter $(\rightarrow \implies 85)$.

6.2 Mounting the measuring device

6.2.1 Required tools

For transmitter

- For turning the transmitter housing: Open-ended wrench8 mm
- For opening the securing clamps: Allen key3 mm

For sensor

For flanges and other process connections: Corresponding mounting tools

6.2.2 Preparing the measuring device


- 1. Remove all remaining transport packaging.
- 2. Remove any protective covers or protective caps present from the sensor.
- 3. If present, remove transport protection of the rupture disk.
- 4. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the measuring device

A WARNING


Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- Ensure that the gaskets are clean and undamaged.
- Install the gaskets correctly.
- 1. Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.
- 2. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



6.2.4 Turning the transmitter housing


To provide easier access to the connection compartment or display module, the transmitter housing can be turned.



- 1. Release the fixing screw.
- 2. Turn the housing to the desired position.
- 3. Firmly tighten the securing screw.

6.2.5 Turning the display module

The display module can be turned to optimize display readability and operability.



A0013905

- 1. Loosen the securing clamp of the electronics compartment cover using an Allen key.
- 2. Unscrew cover of the electronics compartment from the transmitter housing.
- 3. Optional: pull out the display module with a gentle rotational movement.
- 4. Rotate the display module into the desired position: Max. $8 \times 45^{\circ}$ in each direction.
- 5. Without display module pulled out:
 Allow display module to engage at desired position.
- 6. With display module pulled out:

 Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment until it engages.
- 7. Reverse the removal procedure to reassemble the transmitter.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	
Does the measuring device conform to the measuring point specifications? For example: Process temperature → 🖺 139 Process pressure (refer to the chapter on "Pressure-temperature ratings" of the "Technical Information" document) Ambient temperature → 🖺 21 Measuring range	
Has the correct orientation for the sensor been selected? According to sensor type According to medium temperature According to medium properties (outgassing, with entrained solids)	
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	
Are the measuring point identification and labeling correct (visual inspection)?	
Is the device adequately protected from precipitation and direct sunlight?	
Are the securing screw and securing clamp tightened securely?	

7 Electrical connection

i

The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp: Allen key 3 mm
- Wire stripper
- When using stranded cables: crimping tool for ferrule
- For removing cables from terminal: flat blade screwdriver ≤3 mm (0.12 in)

7.1.2 Connecting cable requirements

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40 °C (-40 °F) to +80 °C (+176 °F)
- Minimum requirement: cable temperature range ≥ ambient temperature +20 K

Signal cable

Current output

- For 4-20 mA: standard installation cable is sufficient.
- For 4-20 mA HART: Shielded cable recommended. Observe grounding concept of the plant.

Pulse/frequency/switch output

Standard installation cable is sufficient.


Cable diameter

- Cable glands supplied: M20 \times 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Plug-in spring terminals for device version without integrated overvoltage protection: wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Screw terminals for device version with integrated overvoltage protection: wire crosssections 0.2 to 2.5 mm² (24 to 14 AWG)

7.1.3 Terminal assignment

Transmitter

4-20 mA HART connection version with additional outputs



Order code for "Output"	Terminal numbers			
	Output 1		Outp	out 2
	1 (+)	2 (-)	3 (+)	4 (-)
Option A	4-20 mA HART (passive)			-
Option B ¹⁾	4-20 mA HART (passive)			y/switch output sive)
Option C ¹⁾	4-20 mA HART (passive)		4-20 mA ana	alog (passive)

1) Output 1 must always be used; output 2 is optional.

7.1.4 Requirements for the supply unit

Supply voltage

Transmitter

An external power supply is required for each output.

The following supply voltage values apply for the outputs available:

Order code for "Output"	Minimum terminal voltage	Maximum terminal voltage
Option A ^{1) 2)} : 4-20 mA HART	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 35 V
Option ${\bf B}^{(1)}$: 4-20 mA HART, pulse/frequency/switch output	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 35 V
Option C ¹⁾ ²⁾ : 4-20 mA HART + 4-20 mA analog	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 30 V

 $1) \qquad \text{External supply voltage of the power supply unit with load.} \\$

2) For device versions with SD03 local display: The terminal voltage must be increased by DC $2\ V$ if backlighting is used.


Load

Load for current output: 0 to 500 Ω , depending on the external supply voltage of the power supply unit

Calculation of the maximum load

Depending on the supply voltage of the power supply unit (U_S) , the maximum load (R_B) including line resistance must be observed to ensure adequate terminal voltage at the device. In doing so, observe the minimum terminal voltage

- For $U_S = 17.9$ to 18.9 V: $R_B \le (U_S 17.9$ V): 0.0036 A
- For $U_S = 18.9$ to 24 V: $R_B \le (U_S 13 \text{ V})$: 0.022 A
- For $U_S = 224 \text{ V}$: $R_B \le 500 \Omega$



- Operating range
- 1.1 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" with Ex i and option C "4-20 mA HART + 4-20 mA analog"
- 1.2 For order code for "Output", option A "4-20 mA HART"/option B "4-20 mA HART, pulse/frequency/switch output" with non-Ex and Ex d

Sample calculation

Supply voltage of the power supply unit: $U_S = 19 \text{ V}$ Maximum load: $R_B \le (19 \text{ V} - 13 \text{ V}) : 0.022 \text{ A} = 273 \Omega$

7.1.5 Preparing the measuring device

- 1. Remove dummy plug if present.
- 2. **NOTICE!** Insufficient sealing of the housing! Operational reliability of the measuring device could be compromised. Use suitable cable glands corresponding to the degree of protection.

If measuring device is delivered without cable glands:

Provide suitable cable gland for corresponding connecting cable.

3. If measuring device is delivered with cable glands: Observe cable specification .

7.2 Connecting the measuring device


NOTICE

Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- ► For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the transmitter


Connection via terminals



- 1. Loosen the securing clamp of the connection compartment cover.
- 2. Unscrew the connection compartment cover.
- 3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
- 4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
- 5. Connect the cable in accordance with the terminal assignment . For HART communication: when connecting the cable shielding to the ground terminal, observe the grounding concept of the facility.
- 6. Firmly tighten the cable glands.
- 7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

Reverse the removal procedure to reassemble the transmitter.

Removing a cable



A0013835

► To remove a cable from the terminal, use a flat-blade screwdriver to push the slot between the two terminal holes while simultaneously pulling the cable end out of the terminal.

7.2.2 Ensuring potential equalization

Requirements


No special measures for potential equalization are required.

For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).

7.3 Special connection instructions

7.3.1 Connection examples


Current output 4-20 mA HART



A001551

- 7 Connection example for 4-20 mA HART current output (passive)
- 1 Automation system with current input (e.g. PLC)
- 2 Active barrier for power supply with integrated resistor for HART communication ($\geq 250~\Omega$)(e.g. RN221N) Connection for HART operating devices $\rightarrow \stackrel{\triangle}{=} 145$ Observe the maximum load $\rightarrow \stackrel{\triangle}{=} 28$
- 3 Cable shield, observe cable specifications
- 4 Analog display unit: observe maximum load → 🖺 28
- 5 Transmitter

Pulse/frequency output




A001680

- \blacksquare 8 Connection example for pulse/frequency output (passive)
- 1 Automation system with pulse/frequency input (e.g. PLC)
- 2 Power supply
- 3 Transmitter: observe input values

30


Switch output



₽ 9 Connection example for switch output (passive)

- Automation system with switch input (e.g. PLC)
- Power supply 2
- Transmitter: observe input values

HART input



Connection example for HART input with a common negative

- 1 Automation system with HART output (e.g. PLC)
- Resistor for HART communication ($\geq 250 \Omega$): observe maximum load $\rightarrow \triangleq 28$
- 3 Active barrier for power supply (e.g. RN221N)
- Cable shield, observe cable specifications
- Pressure transmitter (e.g. Cerabar M, Cerabar S): see requirements
- Transmitter


7.4 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

- 1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
- 2. Tighten all housing screws and screw covers.
- 3. Firmly tighten the cable glands.

4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0013960

5. Insert dummy plugs into unused cable entries.


7.5 Post-connection check

Are cables or the device undamaged (visual inspection)?	
Do the cables comply with the requirements ?	
Do the cables have adequate strain relief?	
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	
Depending on the device version: are all the device plugs firmly tightened ?	
Does the supply voltage match the specifications on the transmitter nameplate ?	
Is the terminal assignment correct ?	
If supply voltage is present, do values appear on the display module?	
Are all housing covers installed and firmly tightened?	
Is the securing clamp tightened correctly?	

32

8 Operation options

8.1 Overview of operation options



A001560


33

- 1 Local operation via display module
- 2 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 3 Field Xpert SFX350 or SFX370
- 4 Field Communicator 475
- 5 Control system (e.g. PLC)

8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

For an overview of the operating menu with menus and parameters



 $\blacksquare 11$ Schematic structure of the operating menu


8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu/parameter		User role and tasks	Content/meaning
Language Operation	task-oriented	Role "Operator", "Maintenance" Tasks during operation: Configuring the operational display Reading measured values	Defining the operating language ■ Configuring the operational display (e.g. display format, display contrast) ■ Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: Configuration of the measurement Configuration of the inputs and outputs	Wizards for fast commissioning: Defining the medium Configuring the outputs Configuring the operational display Defining the output conditioning Configuring the low flow cut off Configuring partial and empty pipe detection
			Advanced setup For more customized configuration of the measurement (adaptation to special measuring conditions) Configuration of totalizers Administration (define access code, reset measuring device)
Diagnostics		"Maintenance" role Fault elimination: Diagnostics and elimination of process and device errors Measured value simulation	Contains all parameters for error detection and analyzing process and device errors: Diagnostic list Contains up to 5 currently pending diagnostic messages. Event logbook Contains up to 20 or 100 (order option "Extended HistoROM") event messages that have occurred. Device information Contains information for identifying the device. Measured values Contains all current measured values. Data logging (Order option "Extended HistoROM") Storage and visualization of up to 1000 measured values Heartbeat The functionality of the device is checked on demand and the verification results are documented. Simulation Is used to simulate measured values or output values.
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: Commissioning measurements under difficult conditions Optimal adaptation of the measurement to difficult conditions Detailed configuration of the communication interface Error diagnostics in difficult cases	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: System Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. Sensor Configuration of the measurement. Input Configuration of the input. Output Configuration of the outputs. Communication Configuration of the digital communication interface. Application Configuration of the functions that go beyond the actual measurement (e.g. totalizer). Diagnostics Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.

8.3 Access to the operating menu via the local display

8.3.1 Operational display




Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals → 🗎 106
 - **F**: Failure
 - C: Function check
 - **S**: Out of specification
 - \mathbf{M} : Maintenance required
- Diagnostic behavior → 🖺 107
 - 🐼: Alarm
 - $\underline{\Lambda}$: Warning
- 🖆: Locking (the device is locked via the hardware)
- ←: Communication (communication via remote operation is active)

Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



event is present for this measured variable.

Measured variables

Symbol	Meaning
ṁ	Mass flow
Ü	Volume flowCorrected volume flow

ρ	DensityReference density			
4	Temperature			
Σ	Totalizer The measurement channel number indicates which of the three totalizers is displayed.			
(Output The measurement channel number indicates which of the two current outputs is displayed.			

Measurement channel numbers

	Symbol	Meaning
	14	Measurement channel 1 to 4
-	٠٠	


The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. totalizer 1-3).

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols $\rightarrow \stackrel{\text{\tiny le}}{=} 107$


The number and display format of the measured values can be configured via the "Format display" parameter → 🗎 75. "Operation" menu → Display → Format display

8.3.2 Navigation view



Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:





For more information about the menu icons, refer to the "Display area" section $\rightarrow \ \cong \ 38$

Status area

The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
 - The direct access code for the parameter you are navigating to (e.g. 0022-1)
 - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard

If a diagnostic event is present, the diagnostic behavior and status signal

- For information on the diagnostic behavior and status signal → 🖺 106
 - For information on the function and entry of the direct access code \rightarrow $\stackrel{\triangle}{=}$ 43

Display area

Menus

Symbol	Meaning			
P	Operation Appears: In the menu next to the "Operation" selection At the left in the navigation path in the "Operation" menu			
۶	Setup Appears: ■ In the menu next to the "Setup" selection ■ At the left in the navigation path in the "Setup" menu			
્યું.	Diagnostics Appears: ■ In the menu next to the "Diagnostics" selection ■ At the left in the navigation path in the "Diagnostics" menu			
₹**	Expert Appears: In the menu next to the "Expert" selection At the left in the navigation path in the "Expert" menu			

Submenus, wizards, parameters

Symbol	Meaning			
•	Submenu			
75.	Wizard			
Parameters within a wizard No display symbol exists for parameters in submenus.				


Locking

Symbol	Meaning		
û	Parameter locked When displayed in front of a parameter name, indicates that the parameter is locked. By a user-specific access code By the hardware write protection switch		

Wizard operation

Symbol	Meaning			
—	Switches to the previous parameter.			
Confirms the parameter value and switches to the next parameter.				
E	Opens the editing view of the parameter.			

8.3.3 Editing view



4 Operating elements $\rightarrow \triangleq 41$

Input mask

The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning			
0	Selection of numbers from 0 to 9.			
9				
·	Inserts decimal separator at the input position.			
_	Inserts minus sign at the input position.			
4	Confirms selection.			
+	Moves the input position one position to the left.			

Exits the input without applying the changes.			
C	Clears all entered characters.		

Text editor

Symbol	Meaning		
(Aa1@)	Toggle Between upper-case and lower-case letters For entering numbers For entering special characters		
ABC_ XYZ	Selection of letters from A to Z.		
abc _ xyz	Selection of letters from a to z.		
····^ ~&	Selection of special characters.		
4	Confirms selection.		
€×C←→	Switches to the selection of the correction tools.		
X	Exits the input without applying the changes.		
C	Clears all entered characters.		

Correction symbols under \checkmark

Symbol	Meaning		
C	Clears all entered characters.		
\rightarrow	Moves the input position one position to the right.		
€	Moves the input position one position to the left.		
**	Deletes one character immediately to the left of the input position.		

8.3.4 Operating elements

Key	Meaning			
	Minus key			
	In a menu, submenu Moves the selection bar upwards in a choose list.			
	With a Wizard Confirms the parameter value and goes to the previous parameter.			
	With a text and numeric editor In the input mask, moves the selection bar to the left (backwards).			
	Plus key			
	In a menu, submenu Moves the selection bar downwards in a choose list.			
(+)	With a Wizard Confirms the parameter value and goes to the next parameter.			
	With a text and numeric editor Moves the selection bar to the right (forwards) in an input screen.			
	Enter key			
	For operational display ■ Pressing the key briefly opens the operating menu. ■ Pressing the key for 2 s opens the context menu.			
E	 In a menu, submenu Pressing the key briefly: Opens the selected menu, submenu or parameter. Starts the wizard. If help text is open, closes the help text of the parameter. Pressing the key for 2 s for parameter: If present, opens the help text for the function of the parameter. 			
	With a Wizard Opens the editing view of the parameter.			
	 With a text and numeric editor Pressing the key briefly: Opens the selected group. Carries out the selected action. Pressing the key for 2 s confirms the edited parameter value. 			
	Escape key combination (press keys simultaneously)			
++	 In a menu, submenu Pressing the key briefly: Exits the current menu level and takes you to the next higher level. If help text is open, closes the help text of the parameter. Pressing the key for 2 s returns you to the operational display ("home position"). With a Wizard Exits the wizard and takes you to the next higher level. 			
	With a text and numeric editor Closes the text or numeric editor without applying changes.			
	Minus/Enter key combination (press the keys simultaneously)			
(-)+(E)	Reduces the contrast (brighter setting).			
++E	Plus/Enter key combination (press and hold down the keys simultaneously) Increases the contrast (darker setting).			
	Minus/Plus/Enter key combination (press the keys simultaneously)			
-+++E	For operational display Enables or disables the keypad lock (only SD02 display module).			

8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display: $\frac{1}{2} \left(\frac{1}{2} \right) = \frac{1}{2} \left(\frac{1}{2} \right) \left(\frac{$

- Setup
- Conf. backup disp.
- Simulation

Calling up and closing the context menu

The user is in the operational display.

- 1. Press E for 2 s.
 - └ The context menu opens.



A0014003-I

- 2. Press \Box + \pm simultaneously.
 - $\begin{tabular}{ll} \end{tabular}$ The context menu is closed and the operational display appears.

Calling up the menu via the context menu

- 1. Open the context menu.
- 2. Press 🛨 to navigate to the desired menu.
- 3. Press **E** to confirm the selection.
 - ► The selected menu opens.


42

8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

For an explanation of the navigation view with symbols and operating elements $\Rightarrow \implies 37$

Example: Setting the number of displayed measured values to "2 values"




8.3.7 Calling the parameter directly

A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.

Navigation path

"Expert" menu → Direct access

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered. Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
 Example: Input of "0914" → Parameter Totalizer 1
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.

Example: Input of "0914-2" → Parameter **Totalizer 2**

For the direct access codes of the individual parameters


8.3.8 Calling up help text

For some parameters, help texts exist, which the user can call up from the navigation view. These briefly describe the function of the parameter and thus support fast and reliable commissioning.

Calling up and closing the help text

The user is in the navigation view and the selection bar is on a parameter.

- 1. Press E for 2 s.
 - ► The help text for the selected parameter opens.




A0014002-EN

■ 12 Example: Help text for parameter "Enter access code"

- 2. Press \Box + \pm simultaneously.
 - ► The help text is closed.

8.3.9 Changing the parameters

Example: Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0014020-E

8.3.10 User roles and related access authorization

The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access .

Access authorization to parameters

User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	V	V	V	1)
Maintenance	V	V	V	V

 Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section

If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

The user role with which the user is currently logged on is indicated by the **Access** status display parameter. Navigation path: Operation \rightarrow Access status display

8.3.11 Disabling write protection via access code

If the $\widehat{\mathbb{H}}$ -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display .

The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

- 1. After you press \square , the input prompt for the access code appears.
- 2. Enter the access code.
 - The a-symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

Local operation with mechanical push buttons (display module SD02)

Display module SD02: order characteristic "Display; Operation", option C

The keypad lock is switched on and off in the same way:

Switching on the keypad lock

- ► The device is in the measured value display. Press the □ + ± + E keys simultaneously.
 - The message **Keylock on** appears on the display: The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

- ► The keypad lock is switched on.

 Press the □ + ± + □ keys simultaneously.
 - └─ The message **Keylock off** appears on the display: The keypad lock is switched off.

Local operation with touch control (display module SD03)

Display module SD03: Order characteristic "Display; Operation", option E

The keypad lock is switched on and off via the context menu.

Switching on the keypad lock

The keypad lock is switched on automatically:

- Each time the device is restarted.
- If the device has not been operated for longer than one minute in the measured value display.
- 1. The device is in the measured value display.

Press the E key for longer than 2 seconds.

- ► A context menu appears.
- 2. In the context menu, select the **Keylock on** option.
 - ► The keypad lock is switched on.
- If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

Switching off the keypad lock

- 1. The keypad lock is switched on.


 Press the E key for longer than 2 seconds.
 - ► A context menu appears.
- 2. In the context menu, select the **Keylock off** option.
 - ► The keypad lock is switched off.

8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

8.4.1 Connecting the operating tool


Via HART protocol



■ 13 Options for remote operation via HART protocol

- 1 Control system (e.g. PLC)
- 2 Transmitter power supply unit, e.g. RN221N (with communication resistor)
- 3 Connection for Commubox FXA195 and Field Communicator 475
- 4 Field Communicator 475
- 5 Computer with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 6 Commubox FXA 195 (USB)
- 7 Field Xpert SFX350 or SFX370
- 8 VIATOR Bluetooth modem with connecting cable
- 9 Transmitter

Via service interface (CDI)



- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring device
- 2 Commubox FXA291
- 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"


48 Endress+Hauser

A001376

8.4.2 Field Xpert SFX350, SFX370

Function scope

Field Xpert SFX350 and Field Xpert SFX370 are mobile computers for commissioning and maintenance. They enable efficient device configuration and diagnostics for HART and FOUNDATION fieldbus devices in the **non-Ex area** (SFX350, SFX370) and the **Ex area** (SFX370).



Source for device description files

See data $\rightarrow \implies 52$

8.4.3 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

- HART protocol → 🖺 48
- Service interface CDI → 🖺 48


Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook
- For details, see Operating Instructions BA00027S and BA00059S

Source for device description files

See data → 🖺 52

User interface



A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag
- 5 Status area with status signal
- 6 Display area for current measured values
- 7 Event list with additional functions such as save/load, events list and document creation
- 8 Navigation area with operating menu structure
- 9 Operating range
- 10 Range of action
- 11 Status area

8.4.4 AMS Device Manager

Function scope

Program from Emerson Process Management for operating and configuring measuring devices via HART protocol.

Source for device description files

See data $\rightarrow \implies 52$

8.4.5 SIMATIC PDM

Function scope

SIMATIC PDM is a standardized, manufacturer-independent program from Siemens for the operation, configuration, maintenance and diagnosis of intelligent field devices via HART protocol.

Source for device description files

See data $\rightarrow \implies 52$

8.4.6 Field Communicator 475

Function scope

Industrial handheld terminal from Emerson Process Management for remote configuration and measured value display via HART protocol.

Source for device description files

See data \rightarrow \blacksquare 52

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.04.zz	 On the title page of the Operating instructions On the transmitter nameplate → ≅ 14 Firmware version "Diagnostics" menu → Device information → Firmware version
Release date of firmware version	06.2015	
Manufacturer ID	0x11	Manufacturer ID "Diagnostics" menu → Device information → Manufacturer ID
Device type ID	0x54	Device type "Diagnostics" menu → Device information → Device type
HART protocol revision	7	
Device revision	5	 On the transmitter nameplate → □ 14 Device revision "Diagnostics" menu → Device information → Device revision

For an overview of the different firmware versions for the device $\rightarrow \stackrel{ riangle}{=} 120$

9.1.2 Operating tools

Operating tool via HART protocol	Sources for obtaining device descriptions
Field Xpert SFX350Field Xpert SFX370	Use update function of handheld terminal
FieldCare	 www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
AMS Device Manager (Emerson Process Management)	www.endress.com → Download Area
SIMATIC PDM (Siemens)	www.endress.com → Download Area
Field Communicator 475 (Emerson Process Management)	Use update function of handheld terminal

9.2 Measured variables via HART protocol

The following measured variables (HART device variables) are assigned to the dynamic variables at the factory:

Dynamic variables	Measured variables (HART device variables)
Primary dynamic variable (PV)	Mass flow
Secondary dynamic variable (SV)	Totalizer 1

Dynamic variables	Measured variables (HART device variables)
Tertiary dynamic variable (TV)	Density
Quaternary dynamic variable (QV)	Temperature

The assignment of the measured variables to the dynamic variables can be modified and assigned as desired via local operation and the operating tool using the following parameters:

- Expert → Communication → HART output → Assign PV
- Expert → Communication → HART output → Assign SV
- Expert \rightarrow Communication \rightarrow HART output \rightarrow Assign TV
- Expert → Communication → HART output → Assign QV

The following measured variables can be assigned to the dynamic variables:

Measured variables for PV (primary dynamic variable)

- Mass flow
- Volume flow
- Corrected volume flow
- Density
- Reference density
- Temperature
- Electronic temperature
- Oscillation frequency
- Oscillation amplitude
- Oscillation damping
- Signal asymmetry

Measured variables for SV, TV, QV (secondary, tertiary and quaternary dynamic variable)


- Mass flow
- Volume flow
- Corrected volume flow
- Density
- Reference density
- Temperature
- Electronic temperature
- Oscillation frequency
- Oscillation amplitude
- Oscillation damping
- Signal asymmetry
- External pressure
- Totalizer 1
- Totalizer 2
- Totalizer 3

9.3 Other settings

9.3.1 Burst mode functionality in accordance with HART 7 Specification

Navigation

"Expert" menu \rightarrow Communication \rightarrow HART output \rightarrow Burst configuration \rightarrow Burst configuration 1 to 3



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Burst mode 1 to 3	Activate the HART burst mode for burst message X.	Off On	Off
Burst command 1 to 3	Select the HART command that is sent to the HART master.	 Command 1 Command 2 Command 3 Command 9 Command 33 Command 48 	Command 2
Burst variable 0	For HART command 9 and 33, assign a HART device variable or process variable to burst variable.	Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation damping Oscillation frequency Oscillation amplitude 0 Signal asymmetry Totalizer 1 Totalizer 2 Totalizer 3 External pressure Percent Of Range Measured current Primary variable (PV) Secondary variable (SV) Tertiary variable (TV) Quaternary variable (QV) Not used	Mass flow
Burst variable 1	For HART command 9 and 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 2	For HART command 9 and 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 3	For HART command 9 and 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 4	For HART command 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 5	For HART command 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 6	For HART command 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst variable 7	For HART command 33, assign a HART device variable or process variable to burst variable.	See Burst variable 0 parameter.	Not used
Burst trigger mode	Select the event that triggers burst message X.	ContinuousWindowRisingFallingOn change	Continuous

Parameter	Description	Selection / User entry	Factory setting
Burst trigger level	Enter the burst trigger value. Together with the option selected in the Burst trigger mode parameter the burst trigger value determines the time of burst message X.	Positive floating-point number	_
Min. update period	Enter the minimum time span between two burst responses of one burst message.	Positive integer	1 000 ms
Max. update period	Enter the maximum time span between two burst responses of one burst message.	Positive integer	2 000 ms

10 Commissioning

10.1 **Function check**

Before commissioning the measuring device:


- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist → 🖺 25
- "Post-connection check" checklist \rightarrow 🗎 32

10.2 Switching on the measuring device

- ► After a successful function check, switch on the measuring device.
 - After a successful startup, the local display switches automatically from the startup display to the operational display.
- If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" $\rightarrow \blacksquare 104$.

10.3 Setting the operating language

Factory setting: English or ordered local language




■ 14 Taking the example of the local display

10.4 Configuring the measuring device


The Setup menuwith its quided wizards contains all the parameters needed for standard operation.

Navigation to the **Setup** menu




Illustrated using the example of the local display

Overview of the wizards in the "Setup" menu



10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.



A0013375

- \blacksquare 16 Header of the operational display with tag name
- 1 Device tag
- The number of characters displayed depends on the characters used. Entry of the tag name in the "FieldCare" operating tool $\Rightarrow \implies 50$

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).	Promass


10.4.2 Selecting and setting the medium

The **Medium selection** wizard guides you systematically through all the parameters that have to be configured for selecting and setting the medium.

Navigation

"Setup" menu \rightarrow Select medium

Structure of the wizard



■ 17 "Select medium" wizard in the "Setup" menu

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Select medium	_	Select medium type.	LiquidGas	Liquid
Select gas type	In the Select medium parameter the Gas option is selected.	Select measured gas type.	Gas type choose list	Air

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Reference sound velocity	In the Select gas type parameter the Others option is selected.	Enter sound velocity of gas at 0 °C (32 °F).	1 to 99 999.9999 m/s	331.5 m/s
Temperature coefficient sound velocity	In the Select gas type parameter the Others option is selected.	Enter temperature coefficient for the gas sound velocity.	Positive floating- point number	0.61 (m/s)/K
Pressure compensation	-	Select pressure compensation type.	OffFixed valueExternal value	Off
Pressure value	In the Pressure compensation parameter the Fixed value option is selected.	Enter process pressure to be used for pressure correction.	Positive floating- point number	Country-specific: 1.01 bar a 14.7 psi a


10.4.3 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Depending on the device version, not all submenus and parameters are available in every device. The selection can vary depending on the order code.

Navigation

"Setup" menu \rightarrow System units



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Mass flow unit	Select mass flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: • kg/h • lb/min
Mass unit	Select mass unit.	Unit choose list	Country-specific: kg lb
Volume flow unit	Select volume flow unit. Result The selected unit applies for: Output Low flow cut off Simulation process variable	Unit choose list	Country-specific: l/h gal/min (us)
Volume unit	Select volume unit.	Unit choose list	Country-specific: l gal (us)
Corrected volume flow unit	Select corrected volume flow unit. Result The selected unit applies for: Corrected volume flow	Unit choose list	Country-specific: NI/h Sft³/min
Corrected volume unit	Select corrected volume unit.	Unit choose list	Country-specific: NI Sft³
Density unit	Select density unit. Result The selected unit applies for: Output Simulation process variable Density adjustment (Expert menu)	Unit choose list	Country-specific: • kg/l • lb/ft³
Reference density unit	Select reference density unit.	Unit choose list	Country-dependent • kg/Nl • lb/Sft ³
Temperature unit	Select temperature unit. Result The selected unit applies for: Minimum value Maximum value Minimum value Minimum value Minimum value Minimum value Minimum value Maximum value Maximum value Maximum value Maximum value Maximum value Reference temperature	Unit choose list	Country-specific: Country-specific: F

Parameter	Description	Selection	Factory setting
Length unit	Select length unit for nominal diameter.	Unit choose list	Country-specific: mm in
Pressure unit	Select process pressure unit. Result The unit is taken from: Pressure value External pressure Failure value 4 mA value 20 mA value	Unit choose list	Country-specific: • bar a • psi a


Configuring the current output 10.4.4

The **"Current output 1 to 2" wizard** guides you systematically through all the parameters that have to be set for configuring the specific current output.


Navigation

"Setup" menu \rightarrow Current output 1 to 2

Structure of the wizard



"Current output 1 to 2" wizard in the "Setup" menu (part 1) *Off** = *Option only for current output 2*



 \blacksquare 19 "Current output 1 to 2" wizard in the "Setup" menu (part 2)

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign current output		Select process variable for current output.	Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Mass flow
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	 Fixed reference density Calculated reference density 	Calculated reference density
Fixed reference density	In the Corrected volume flow calculation parameter the Fixed reference density option is selected.	Enter fixed value for reference density.	Positive floating- point number	1 kg/Nl
Linear expansion coefficient	In the Corrected volume flow calculation parameter the Calculated reference density option is selected.	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Square expansion coefficient	-	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Reference temperature	In the Corrected volume flow calculation parameter the Calculated reference density option is selected.	Enter reference temperature for calculating the reference density.	-273.15 to 99 999 °C	Country-specific: +20 °C +68 °F
Current span	-	Select current range for process value output and upper/lower level for alarm signal.	 420 mA NAMUR 420 mA US 420 mA Fixed current 	Country-specific: 420 mA NAMUR 420 mA US
4 mA value	One of the following options is selected in the Current span parameter (→ 🖺 66): 420 mA NAMUR 420 mA US 420 mA	Enter 4 mA value.	Signed floating-point number	Country-specific: Okg/h Olb/min
20 mA value	One of the following options is selected in the Current span parameter (→ 🖺 66): • 420 mA NAMUR • 420 mA US • 420 mA	Enter 20 mA value.	Signed floating-point number	Depends on country and nominal diameter

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Failure mode	One of the following options is selected in the Assign current output parameter (→ 66): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Define output behavior in alarm condition.	 Min. Max. Last valid value Actual value Defined value 	Max.
	One of the following options is selected in the Current span parameter (→ 🖺 66): 420 mA NAMUR 420 mA US 420 mA			
Failure current	The Defined value option is selected in the Failure mode parameter.	Enter current output value in alarm condition.	3.59 to 22.5 mA	22.5 mA

10.4.5 Configuring the pulse/frequency/switch output


The **Pulse/frequency/switch output** wizard guides you systematically through all the parameters that can be set for configuring the selected output type.

Configuring the pulse output

Navigation

"Setup" menu → Pulse/frequency/switch output

Structure of the wizard for the pulse output



■ 20 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter"Pulse" option

Parameter overview with brief description


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Assign pulse output	In the Operating mode parameter the Pulse option is selected.	Select process variable for pulse output.	OffMass flowVolume flowCorrected volume flow	Off
Corrected volume flow calculation	-	Select reference density for calculating the corrected volume flow.	Fixed reference densityCalculated reference density	Calculated reference density
Fixed reference density	In the Corrected volume flow calculation parameter the Fixed reference density option is selected.	Enter fixed value for reference density.	Positive floating- point number	1 kg/Nl
Linear expansion coefficient	In the Corrected volume flow calculation parameter the Calculated reference density option is selected.	Enter linear, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Square expansion coefficient	-	For media with a non-linear expansion pattern: enter the quadratic, medium-specific expansion coefficient for calculating the reference density.	Signed floating-point number	0.0
Reference temperature	In the Corrected volume flow calculation parameter the Calculated reference density option is selected.	Enter reference temperature for calculating the reference density.	−273.15 to 99 999 °C	Country-specific: +20 °C +68 °F
Value per pulse	One of the following options is selected in the Assign pulse output parameter (→ 🖺 69): • Mass flow • Volume flow • Corrected volume flow	Enter measured value at which a pulse is output.	Signed floating-point number	0
Pulse width	One of the following options is selected in the Assign pulse output parameter (→ 🖺 69): Mass flow Volume flow Corrected volume flow	Define time width of the output pulse.	5 to 2 000 ms	100 ms
Failure mode	One of the following options is selected in the Assign pulse output parameter (→ 🖺 69): Mass flow Volume flow Corrected volume flow	Define output behavior in alarm condition.	Actual valueNo pulses	No pulses
Invert output signal	-	Invert the output signal.	■ No ■ Yes	No

Configuring the frequency output

Navigation

"Setup" menu → Pulse/frequency/switch output

Structure of the wizard for the frequency output



 $\blacksquare~21~$ "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter"Frequency" option

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Assign frequency output	In the Operating mode parameter (→ 🖺 69) the Frequency option is selected.	Select process variable for frequency output.	Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Off
Minimum frequency value	One of the following options is selected in the Assign frequency output parameter (→ ≧ 71): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Enter minimum frequency.	0 to 1000 Hz	0 Hz
Maximum frequency value	One of the following options is selected in the Assign frequency output parameter (→ 월 71): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Enter maximum frequency.	0 to 1000 Hz	1000 Hz

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Measuring value at minimum frequency	One of the following options is selected in the Assign frequency output parameter (→ 🖺 71): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Enter measured value for minmum frequency.	Signed floating-point number	Depends on country and nominal diameter
Measuring value at maximum frequency	One of the following options is selected in the Assign frequency output parameter (→ ≧ 71): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Enter measured value for maximum frequency.	Signed floating-point number	Depends on country and nominal diameter
Failure mode	One of the following options is selected in the Assign frequency output parameter (→ ≧ 71): ■ Mass flow ■ Volume flow ■ Corrected volume flow ■ Density ■ Reference density ■ Temperature ■ Carrier pipe temperature ■ Electronic temperature ■ Descillation frequency ■ Oscillation amplitude ■ Oscillation damping ■ Signal asymmetry	Define output behavior in alarm condition.	 Actual value Defined value 0 Hz 	0 Hz


Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Failure frequency	One of the following options is selected in the Assign frequency output parameter (→ ≧ 71): Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry	Enter frequency output value in alarm condition.	0.0 to 1250.0 Hz	0.0 Hz
Invert output signal	_	Invert the output signal.	NoYes	No

Configuring the switch output


Navigation

"Setup" menu \rightarrow Pulse/frequency/switch output

Structure of the wizard for the switch output



 \blacksquare 22 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Switch" option (part 1)



23 "Pulse/frequency/switch output" wizard in the "Setup" menu: "Operating mode" parameter "Switch" option (part 2)

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Operating mode	-	Define the output as a pulse, frequency or switch output.	PulseFrequencySwitch	Pulse
Switch output function	The Switch option is selected in the Operating mode parameter.	Select function for switch output.	 Off On Diagnostic behavior Limit Flow direction check Status 	Off
Assign diagnostic behavior	The Diagnostic behavior option is selected in the Switch output function parameter.	Select diagnostic behavior for switch output.	AlarmAlarm or warningWarning	Alarm

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign limit	In the Switch output function parameter the Limit option is selected.	Select process variable for limit function.	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1 Totalizer 2 Totalizer 3 	Mass flow
Assign flow direction check	The Flow direction check option is selected in the Switch output function parameter.	Select process variable for flow direction monitoring.	 Mass flow Volume flow Corrected volume flow	Mass flow
Assign status	The Status option is selected in the Switch output function parameter.	Select device status for switch output.	Partially filled pipe detectionLow flow cut off	Partially filled pipe detection
Switch-on value	In the Switch output function parameter the Limit option is selected.	Enter measured value for the switch-on point.	Signed floating-point number	Country-specific: • 0 m³/h • 0 ft³/h
Switch-off value	In the Switch output function parameter the Limit option is selected.	Enter measured value for the switch-off point.	Signed floating-point number	Country-specific: • 0 m³/h • 0 ft³/h
Switch-on delay	The Limit option is selected in the Switch output function parameter.	Define delay for the switch-on of status output.	0.0 to 100.0 s	0.0 s
Switch-off delay	The Limit option is selected in the Switch output function parameter.	Define delay for the switch-off of status output.	0.0 to 100.0 s	0.0 s
Failure mode	-	Define output behavior in alarm condition.	Actual statusOpenClosed	Open
Invert output signal	-	Invert the output signal.	■ No ■ Yes	No


10.4.6 Configuring the local display

The $\bf Display$ wizard guides you systematically through all the parameters that can configured for configuring the local display.

Navigation

"Setup" menu → Display

Structure of the wizard



■ 24 "Display" wizard in the "Setup" menu

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 None Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 2 * 	Mass flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m³/h • 0 ft³/h
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None
0% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None

^{*} Visibility depends on order options or device settings


10.4.7 Configuring the output conditioning

The ${\bf Output\ conditioning}$ wizard guides you systematically through all the parameters that have to be set for configuring the output conditioning.

Navigation

"Setup" menu → Output conditioning

Structure of the "Output conditioning" wizard



■ 25 "Output conditioning" wizard in the "Setup" menu

1 In the "Measuring mode output 1" parameter the "Reverse flow compensation" option was selected.

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Level of flow fluctuation	-	Select fluctuation level of measured value.	SlightModerateStrong	Moderate
Display damping	-	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Damping output 1	-	Set the reaction time of the output signal of the current output to fluctuations in the measured value.	0 to 999.9 s	1 s
Damping output 2	The measuring device has a second current output.	Set the reaction time of the output signal of the second current output to fluctuations in the measured value.	0 to 999.9 s	1 s
Damping output 2	The measuring device has a pulse/frequency/switch output.	Set the reaction time of the output signal of the frequency output to fluctuations in the measured value.	0 to 999.9 s	1 s
Measuring mode output 1	-	Select measuring mode for output.	 Forward flow Forward/Reverse flow Reverse flow compensation 	Forward flow
Measuring mode output 2	-	Select measuring mode for output.	 Forward flow Forward/Reverse flow Reverse flow compensation 	Forward flow
Measuring mode output 2	-	Select measuring mode for output.	 Forward flow Forward/Reverse flow Reverse flow Reverse flow compensation 	Forward flow
Measuring mode output 2	-	Select measuring mode for output.	 Forward flow Forward/Reverse flow Reverse flow Reverse flow compensation 	Forward flow
Operating mode totalizer 1	-	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	Net flow total
Operating mode totalizer 2	-	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	Net flow total
Operating mode totalizer 3	-	Select totalizer calculation mode.	Net flow totalForward flow totalReverse flow total	Net flow total
Assign process variable	-	Select process variable for low flow cut off.	Off Mass flow Volume flow Corrected volume flow	Mass flow

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
On value low flow cutoff	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): • Mass flow • Volume flow • Corrected volume flow	Enter on value for low flow cut off.	Positive floating- point number	For liquids: depends on country and nominal diameter
Off value low flow cutoff	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): • Mass flow • Volume flow • Corrected volume flow	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): • Mass flow • Volume flow • Corrected volume flow	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s


10.4.8 Configuring the low flow cut off

The **Low flow cut off** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

Navigation

"Setup" menu \rightarrow Low flow cut off

Structure of the wizard



 \blacksquare 26 "Low flow cut off" wizard in the "Setup" menu

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	_	Select process variable for low flow cut off.	 Off Mass flow Volume flow Corrected volume flow	Mass flow
On value low flow cutoff	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): Mass flow Volume flow Corrected volume flow	Enter on value for low flow cut off.	Positive floating- point number	For liquids: depends on country and nominal diameter

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Off value low flow cutoff	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): Mass flow Volume flow Corrected volume flow	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	One of the following options is selected in the Assign process variable parameter (→ 🖺 79): Mass flow Volume flow Corrected volume flow	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s


10.4.9 Configuring the partial filled pipe detection

The **Partial filled pipe detection** wizard guides you systematically through all parameters that have to be set for configuring the monitoring of the pipe filling.

Navigation

"Setup" menu \rightarrow Partially filled pipe detection

Structure of the wizard



■ 27 "Partially filled pipe detection" wizard in the "Setup" menu


Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign process variable	-	Select process variable for partially filled pipe detection.	 Off Density Reference density	Off
Low value partial filled pipe detection	-	Enter lower limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: • 0.2 kg/l • 12.5 lb/ft ³
High value partial filled pipe detection	-	Enter upper limit value for deactivating partialy filled pipe detection.	Signed floating-point number	Country-dependent: 6 kg/l 374.6 lb/ft ³
Response time part. filled pipe detect.	In the Assign process variable parameter, one of the following options is selected: Density Reference density	Enter time before diagnostic message is displayed for partially filled pipe detection.	0 to 100 s	1s

10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.


Navigation to the "Advanced setup" submenu




 \blacksquare 28 Taking the example of the local display

Navigation

"Setup" menu → Advanced setup






10.5.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Sensor adjustment



Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	Flow in arrow directionFlow against arrow direction	Flow in arrow direction
Zero point adjustment control	Start zero point adjustment.	CancelBusyZero point adjust failureStart	Cancel

10.5.2 Configuring the totalizer

In the "Totalizer 1 to 3" submenu the individual totalizer can be configured.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Totalizer 1 to 3



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection	Factory setting
Assign process variable	-	Select process variable for totalizer.	 Off Volume flow Mass flow Corrected volume flow	Mass flow
Unit totalizer	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Select process variable totalizer unit.	Unit choose list	Country-specific: l gal (us)
Totalizer operation mode	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Select totalizer calculation mode.	 Net flow total Forward flow total Reverse flow total 	Net flow total
Failure mode	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Define totalizer behavior in alarm condition.	StopActual valueLast valid value	Stop

10.5.3 Carrying out additional display configurations

In the ${\bf Display}$ submenu you can set all the parameters associated with the configuration of the local display.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Display

► Display	
	Format display
	Value 1 display
	Value 1 display
	0% bargraph value 1
	100% bargraph value 1
	Decimal places 1
	Value 2 display
	Decimal places 2
	Value 3 display
	0% bargraph value 3
	100% bargraph value 3
	Decimal places 3
	Value 4 display
	Decimal places 4
	Language
	Display interval
	Display damping
	Header
	Header text
	Separator
	Backlight

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Format display	A local display is provided.	Select how measured values are shown on the display.	 1 value, max. size 1 bargraph + 1 value 2 values 1 value large + 2 values 4 values 	1 value, max. size
Value 1 display	A local display is provided.	Select the measured value that is shown on the local display.	 None Mass flow Volume flow Corrected volume flow Density Reference density Temperature Totalizer 1 Totalizer 2 Totalizer 3 Current output 1 Current output 2* 	Mass flow
0% bargraph value 1	A local display is provided.	Enter 0% value for bar graph display.	Signed floating-point number	Country-specific: • 0 m³/h • 0 ft³/h
100% bargraph value 1	A local display is provided.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 1	A measured value is specified in the Value 1 display parameter.	Select the number of decimal places for the display value.	XX.XX.XXX.XXXX.XXX	x.xx
Value 2 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None
Decimal places 2	A measured value is specified in the Value 2 display parameter.	Select the number of decimal places for the display value.	XX.XX.XXX.XXXX.XXXX.XXXX	x.xx
Value 3 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None
0% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	An option was selected in the Value 3 display parameter.	Enter 100% value for bar graph display.	Signed floating-point number	Depends on country and nominal diameter
Decimal places 3	A measured value is specified in the Value 3 display parameter.	Select the number of decimal places for the display value.	X X.X X.XX X.XXX X.XXX	x.xx
Value 4 display	A local display is provided.	Select the measured value that is shown on the local display.	Picklist see Value 1 display parameter	None
Decimal places 4	A measured value is specified in the Value 4 display parameter.	Select the number of decimal places for the display value.	 x x.x x.xx x.xxx x.xxxx	x.xx

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Language	A local display is provided.	Set display language.	 English Deutsch* Français* Español* Italiano* Nederlands* Portuguesa* Polski* pyсский язык (Russian)* Svenska* Türkçe* 中文 (Chinese)* 日本語 (Japanese)* 한국어 (Korean)* Bahasa Indonesia* tiếng Việt (Vietnamese)* čeština (Czech)* 	English (alternatively, the ordered language is preset in the device)
Display interval	A local display is provided.	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	A local display is provided.	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	A local display is provided.	Select header contents on local display.	Device tagFree text	Device tag
Header text	The Free text option is selected in the Header parameter.	Enter display header text.	Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)	
Separator	A local display is provided.	Select decimal separator for displaying numerical values.	• . (point) • , (comma)	. (point)
Backlight	-	Switch the local display backlight on and off. Only for device version with local display SD03 (touch control)	DisableEnable	Disable


^{*} Visibility depends on order options or device settings

10.5.4 Administration configuration

The ${\bf Administration}$ submenu contains administrative parameters.

Navigation

 $\texttt{"Setup"} \ menu \rightarrow Advanced \ setup \rightarrow Administration$



Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Define access code	Restrict write-access to parameters to protect the configuration of the device against unintentional changes via the local display.	0 to 9 999	0
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	CancelTo factory defaultsTo delivery settingsRestart device	Cancel


10.6 Configuration management

After commissioning, you can save the current device configuration, copy it to another measuring point or restore the previous device configuration.

You can do so using the **Configuration management** parameter and the related options found in the **Configuration backup display** submenu.

Navigation

"Setup" menu → Advanced setup → Configuration backup display



Parameter overview with brief description

Parameter	Prerequsite	Description	User interface / Selection	Factory setting
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)	_
Last backup	A local display is provided.	Indicates when the last data backup was saved to the display module.	Days (d), hours (h), minutes (m) and seconds (s)	_

Parameter	Prerequsite	Description	User interface/ Selection	Factory setting
Configuration management	A local display is provided.	Select action for managing the device data in the display module.	 Cancel Execute backup Restore Duplicate Compare Clear backup data 	Cancel
Comparison result	A local display is provided.	Comparison between present device data and display backup.	 Settings identical Settings not identical No backup available Backup settings corrupt Check not done Dataset incompatible 	Check not done

10.6.1 Function scope of the "Configuration management" parameter

Options	Description
Execute backup	The current device configuration is backed up from the integrated HistoROM to the device's display module. The backup copy includes the transmitter data of the device.
Restore	The last backup copy of the device configuration is restored from the display module to the device's integrated HistoROM. The backup copy includes the transmitter data of the device.
Duplicate	The transmitter configuration from another device is duplicated to the device using the display module.
Compare	The device configuration saved in the display module is compared with the current device configuration of the integrated HistoROM.
Clear backup data	The backup copy of the device configuration is deleted from the display module of the device.


- Integrated HistoROM
 - A HistoROM is a "non-volatile" device memory in the form of an EEPROM.
- While this action is in progress, the configuration cannot be edited via the local display and a message on the processing status appears on the display.

10.7 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu \rightarrow Simulation



Simulation current output 1 to 2

Value current output 1 to 2

Frequency output simulation

Frequency value

Pulse output simulation

Pulse value

Switch output simulation

Switch status

Simulation device alarm

Parameter overview with brief description

Diagnostic event category

Diagnostic event simulation

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign simulation process variable	-	Select a process variable for the simulation process that is activated.	 Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature 	Off
Process variable value	One of the following options is selected in the Assign simulation process variable parameter (→ 🗎 92): Volume flow Mass flow Corrected volume flow Density Reference density Temperature	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Simulation current output 1 to 2	-	Switch the simulation of the current output on and off.	Off On	Off
Value current output 1 to 2	In the Simulation current output 1 to 2 parameter the On option is selected.	Enter the current value for simulation.	3.59 to 22.5 mA	3.59 mA
Frequency output simulation	The Frequency option is selected in the Operating mode parameter.	Switch the simulation of the frequency output on and off.	• Off • On	Off
Frequency value	The On option is selected in the Frequency output simulation parameter.	Enter the frequency value for the simulation.	0.0 to 1250.0 Hz	0.0 Hz

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Pulse output simulation	The Pulse option is selected in the Operating mode parameter.	Set and switch off the pulse output simulation. For Fixed value option: Pulse width parameter (> 69) defines the pulse width of the pulses output.	OffFixed valueDown-counting value	Off
Pulse value	The Down-counting value option is selected in the Pulse output simulation parameter (→ 🖺 93).	Enter the number of pulses for simulation.	0 to 65 535	0
Switch output simulation	The Switch option is selected in the Operating mode parameter.	Switch the simulation of the switch output on and off.	Off On	Off
Switch status	The On option is selected in the Switch output simulation parameter (→ 🖺 93).	Select the status of the status output for the simulation.	OpenClosed	Open
Simulation device alarm	-	Switch the device alarm on and off.	Off On	Off
Diagnostic event category	-	Select a diagnostic event category.	SensorElectronicsConfigurationProcess	Process
Diagnostic event simulation	-	Select a diagnostic event to simulate this event.	 Off Diagnostic event picklist (depends on the category selected) 	Off

10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:


- Write protection via access code
- Write protection via write protection switch

10.8.1 Write protection via access code

With the customer-specific access code, the parameters for the measuring device configuration are write-protected and their values can no longer be changed via local operation.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Define access code



Defining the access code via local display

- 1. Navigate to the **Enter access code** parameter.
- 2. Max. Define a max. 4-digit numeric code as an access code.
- 3. Enter the access code again to confirm the code.
 - ► The 🗈-symbol appears in front of all write-protected parameters.


The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.



- The user role with which the user is currently logged on via the local display
 → \(\begin{align*} \ext{46} \) is indicated by the **Access status display** parameter. Navigation path:
 "Operation" menu → Access status display

Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from write protection via the local display. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.




10.8.2 Write protection via write protection switch


Unlike write protection via a user-specific access code, this allows write access to the entire operating menu - other than the **"Contrast display" parameter** - to be locked.

The parameter values are now read only and cannot be edited any more (exception "Contrast display" parameter):


- Via local display
- Via service interface (CDI)
- Via HART protocol



- 1. Loosen the securing clamp.
- 2. Unscrew the electronics compartment cover.
- 3. Pull out the display module with a gentle rotational movement. To make it easier to access the lock switch, attach the display module to the edge of the electronics compartment.
 - └ Display module is attached to the edge of the electronics compartment.



- 4. Setting the write protection switch (WP) on the main electronics module to the **ON** position enables hardware write protection. Setting the write protection switch (WP) on the main electronics module to the **OFF** position (factory setting) disables hardware write protection.
 - If hardware write protection is enabled, the **Locking status** parameter displays the **Hardware locked** option . In addition, on the local display the ®-symbol appears in front of the parameters in the header of the operational display and in the navigation view.



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter. On the local display, the $\[\[\] \]$ -symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

- 5. Feed the cable into the gap between the housing and main electronics module and plug the display module into the electronics compartment in the desired direction until it engages.
- 6. Reverse the removal procedure to reassemble the transmitter.

Proline Promass E 200 HART Operation

11 Operation

11.1 Reading the device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

Navigation


"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
None	The access status displayed in "Access status display" parameter applies $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters .
Temporarily locked	Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

11.2 Adjusting the operating language

Information $\rightarrow \implies 57$



11.3 Configuring the display

- Basic settings for local display $\rightarrow \triangle 75$

11.4 Reading measured values


With the **Measured values** submenu, it is possible to read all the measured values.


11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Process variables





Parameter overview with brief description


Parameter	Description	User interface
Mass flow	Displays the mass flow currently measured.	Signed floating-point number
	Dependency The unit is taken from the Mass flow unit parameter	
	A .	
Volume flow	Displays the volume flow currently measured.	Signed floating-point number
	Dependency The unit is taken from the Volume flow unit parameter	
Corrected volume flow	Displays the corrected volume flow currently calculated.	Signed floating-point number
	Dependency The unit is taken from the Corrected volume flow unit parameter	
Density	Displays the density or specific density currently measured.	Positive floating-point number
	Dependency The unit is taken from the Density unit parameter	
Reference density	Displays the density at the reference temperature.	Positive floating-point number
	Dependency The unit is taken from the Reference density unit parameter	
Temperature	Displays the temperature currently measured.	Positive floating-point number
	Dependency The unit is taken from the Temperature unit parameter	

11.4.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer



98

Proline Promass E 200 HART Operation

Parameter overview with brief description


Parameter	Prerequsite	Description	User interface	Factory setting
Totalizer value 1 to 3	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Displays the current totalizer counter value.	Signed floating-point number	0 kg
Totalizer overflow 1 to 3	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Displays the current totalizer overflow.	Integer with sign	0

11.4.3 Output values

The **Output values** submenu contains all the parameters needed to display the current measured values for every output.

Navigation

"Diagnostics" menu \rightarrow Measured values \rightarrow Output values



Parameter overview with brief description

Parameter	Prerequsite	Description	User interface	Factory setting
Output current 1	_	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA	3.59 mA
Measured current 1	-	Displays the current value currently measured for the current output.	0 to 30 mA	-

Parameter	Prerequsite	Description	User interface	Factory setting
Terminal voltage 1	-	Displays the current terminal voltage that is applied at the current output.	0.0 to 50.0 V	_
Output current 2	-	Displays the current value currently calculated for the current output.	3.59 to 22.5 mA	3.59 mA
Pulse output	In the Operating mode parameter the Pulse option is selected.	Displays the pulse frequency currently output.	Positive floating- point number	0 Hz
Output frequency	The Frequency option is selected in the Operating mode parameter.	Displays the value currently measured for the frequency output.	0 to 1250 Hz	-
Switch status	The Switch option is selected in the Operating mode parameter.	Displays the current switch output status.	OpenClosed	-

11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu
- Advanced settings using the **Advanced setup** submenu

11.6 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:

- Control Totalizer
- Reset all totalizers

Function scope of the "Control Totalizer" parameter


Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in the Preset value parameterand the totaling process is restarted.
Hold	The totaling process is stopped.

Function scope of the "Reset all totalizers" parameter

Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

Navigation

"Operation" menu → Operation



Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Control Totalizer	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Control totalizer value.	 Totalize Reset + hold Preset + hold Reset + totalize Preset + totalize Hold 	Totalize
Preset value	One of the following options is selected in the Assign process variable parameter (→ 🖺 86) of the Totalizer 1 to 3 submenu: Volume flow Mass flow Corrected volume flow	Specify start value for totalizer. Dependency The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 🖺 86).	Signed floating-point number	Country-specific: • 0 l • 0 gal (us)
Reset all totalizers	-	Reset all totalizers to 0 and start.	CancelReset + totalize	Cancel

11.7 Showing data logging


The **Extended HistoROM** application package must be enabled in the device (order option) for the **Data logging** submenu to appear. This contains all the parameters for the measured value history.



The measured value history is also accessible via the FieldCare plant asset management tool $\rightarrow \triangle 49$.

Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart




₹ 29 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.
- If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

Navigation

"Diagnostics" menu → Data logging

"Data logging" submenu



102

Parameter overview with brief description

Parameter	Prerequsite	Description	Selection / User entry	Factory setting
Assign channel 1 to 4	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Assign process variable to logging channel.	Off Mass flow Volume flow Corrected volume flow Density Reference density Temperature Carrier pipe temperature Electronic temperature Oscillation frequency Oscillation amplitude Oscillation damping Signal asymmetry Current output 1	Off
Logging interval	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	10.0 s
Clear logging data	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.	Clear the entire logging data.	CancelClear data	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For local display

Problem	Possible causes	Remedial action
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage .
Local display dark and no output signals	Supply voltage has incorrect polarity.	Reverse polarity of supply voltage.
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the I/O electronics module correctly.	Check terminals.
Local display dark and no output signals	I/O electronics module is defective.	Order spare part → 🖺 123.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	 Set the display brighter by simultaneously pressing ± + E. Set the display darker by simultaneously pressing □ + E.
Local display is dark, but signal output is within the valid range	The cable of the display module is not plugged in correctly.	Insert the plug correctly into the main electronics module and display module.
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part → 🖺 123.
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures → 🖺 111
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	1. Press □ + ₺ for 2 s ("home position"). 2. Press 匤. 3. Set the desired language in the Language parameter.
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	 Check the cable and the connector between the main electronics module and display module. Order spare part → 123.

$For \ output \ signals$

Problem	Possible causes	Remedial action
Signal output outside the valid range	Main electronics module is defective.	Order spare part → 🖺 123.
Signal output outside the valid current range (< 3.6 mA or > 22 mA)	I/O electronics module is defective.	Order spare part → 🖺 123.
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	Check and correct parameter configuration. Observe limit values specified in the "Technical Data".


For access

Problem	Possible causes	Remedial action	
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position .	
No write access to parameters	Current user role has limited access authorization	1. Check user role → 🖺 46. 2. Enter correct customer-specific access code → 🖺 46.	
No connection via HART protocol	Missing or incorrectly installed communication resistor.	Install the communication resistor (250 Ω) correctly. Observe the maximum load $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $	
No connection via HART protocol	Commubox	Observe the documentation for the Commubox. FXA195 HART: Document "Technical Information" TI00404F	
No connection via service interface	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox. FXA291: Document "Technical Information" T100405C	

12.2 Diagnostic information on local display

12.2.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
 - Via parameters → 🖺 114

Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required


Symbol	Meaning
A0013956	Failure A device error has occurred. The measured value is no longer valid.
C	Function check The device is in service mode (e.g. during a simulation).
S	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range) Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
A0013957	Maintenance required Maintenance is required. The measured value remains valid.

Diagnostic behavior

Symbol	Meaning
A0013961	 Alarm Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
A0013962	Warning Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.

Diagnostic information


The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



Operating elements

Key	Meaning
	Plus key
A00	In a menu, submenu Opens the message about the remedial measures.
	Enter key
(E)	In a menu, submenu Opens the operating menu.

12.2.2 Calling up remedial measures



A0013940-EN

- 30 Message for remedial measures
- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

- 1. Press ± (i) symbol).
 - ► The **Diagnostic list** submenu opens.
- 2. Select the desired diagnostic event with \pm or \Box and press \Box .
 - └ The message for the remedial measures for the selected diagnostic event opens.
- 3. Press \Box + \pm simultaneously.
 - └ The message for the remedial measures closes.


The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

- 1. Press E.
 - ► The message for the remedial measures for the selected diagnostic event opens.
- 2. Press \Box + \pm simultaneously.
 - ► The message for the remedial measures closes.

12.3 Diagnostic information in FieldCare

12.3.1 Diagnostic options


Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



- 1 Status area with status signal → 🖺 106
- 2 Diagnostic information \rightarrow $\stackrel{\triangle}{=}$ 107
- 3 Remedial measures with Service ID
- Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
 - Via parameters \rightarrow 🖺 114

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.



12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
 Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


- 1. Call up the desired parameter.
- 2. On the right in the working area, mouse over the parameter.
 - ► A tool tip with remedy information for the diagnostic event appears.

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic behavior** submenu.

"Expert" menu → System → Diagnostic handling → Diagnostic behavior



A0014048-E

■ 31 Using the example of the local display

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. Signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated. For local display with touch control: the background lighting changes to red.
Warning	Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostics message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.4.2 Adapting the status signal

Each item of diagnostic information is assigned a specific status signal at the factory. The user can change this assignment for certain diagnostic information in the $\bf Diagnostic$ $\bf event$ $\bf category$ $\bf submenu$.

"Expert" menu \rightarrow Communication \rightarrow Diagnostic event category

Available status signals

Configuration as per HART 7 Specification (Condensed Status), in accordance with NAMUR NE107.

Symbol	Meaning
A0013956	Failure A device error has occurred. The measured value is no longer valid.
C	Function check The device is in service mode (e.g. during a simulation).

Symbol	Meaning
S	Out of specification The device is operated: ■ Outside its technical specification limits (e.g. outside the process temperature range) ■ Outside of the configuration carried out by the user (e.g. maximum flow in parameter 20 mA value)
A0013957	Maintenance required Maintenance is required. The measured value remains valid.
N	Has no effect on the condensed status.
A0023076	

12.5 Overview of diagnostic information

- The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.
- In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information $\rightarrow \triangleq 110$

Diagnostics for the sensor

- △S046 Sensor limit exceeded
- △S140 Sensor signal

Diagnostics for the electronics

△S274 Main electronic failure

Diagnostics for the configuration

- △S441 Current output 1 to 2
- △S442 Frequency output
- △S443 Pulse output

Diagnostics for the process

- △S801 Supply voltage too low
- △S830 Sensor temperature too high
- △S831 Sensor temperature too low
- △S832 Ambient temperature too high
- \triangle S833 Ambient temperature too low
- \triangle S834 Process temperature too high
- △S835 Process temperature too low
- △S862 Partly filled pipe
- △S912 Medium inhomogeneous
- △S913 Medium unsuitable

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of se	ensor			
022	Sensor temperature	Change main electronic module Change sensor	F	Alarm
046	Sensor limit exceeded	Inspect sensor Check process condition	S	Warning 1)
062	Sensor connection	Change main electronic module Change sensor	F	Alarm
082	Data storage	Change main electronic module Change sensor	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
083	Memory content	 Restart device Restore S-Dat data Change sensor 	F	Alarm
140	Sensor signal	Check or change main electronics Change sensor	S	Warning ¹⁾
Diagnostic of e	electronic		1	1
242	Software incompatible	Check software Flash or change main electronics module	F	Alarm
252	Modules incompatible	Check electronic modules Change I/O or main electronic module	F	Alarm 1)
261	Electronic modules	Restart device Check electronic modules Change I/O Modul or main electronics	F	Alarm
262	Module connection	Check module connections Change electronic modules	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	Restart device Change main electronic module	F	Alarm
272	Main electronic failure	Restart device Contact service	F	Alarm
273	Main electronic failure	Emergency operation via display Change main electronics	F	Alarm
274	Main electronic failure	Unstable measurement 1. Change main electronics	S	Warning 1)
275	I/O module failure	Change I/O module	F	Alarm
276	I/O module failure	Restart device Change I/O module	F	Alarm
282	Data storage	Restart device Contact service	F	Alarm
283	Memory content	Transfer data or reset device Contact service	F	Alarm
302	Device verification active	Device verification active, please wait.	С	Warning
311	Electronic failure	Transfer data or reset device Contact service	F	Alarm
311	Electronic failure	Maintenance required! 1. Do not perform reset 2. Contact service	М	Warning
362	Main electronic failure	Change main electronic module Change sensor	F	Alarm
Diagnostic of o	configuration	·	'	
410	Data transfer	Check connection Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	С	Warning
412	Processing Download	Download active, please wait	С	Warning
431	Trim 1 to 2	Carry out trim	С	Warning

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
437	Configuration incompatible	Restart device Contact service	F	Alarm
438	Dataset	Check data set file Check device configuration Up- and download new configuration	M	Warning
441	Current output 1 to 2	Check process Check current output settings	S	Warning 1)
442	Frequency output	Check process Check frequency output settings	S	Warning 1)
443	Pulse output	Check process Check pulse output settings	S	Warning ¹⁾
444	Current input 1	Check process Check current input settings	S	Warning ¹⁾
453	Flow override	Deactivate flow override	С	Warning
484	Simulation failure mode	Deactivate simulation	С	Alarm
485	Simulation measured variable	Deactivate simulation	С	Warning
486	Simulation current input 1	Deactivate simulation	С	Warning
491	Simulation current output 1 to 2	Deactivate simulation	С	Warning
492	Simulation frequency output	Deactivate simulation frequency output	С	Warning
493	Simulation pulse output	Deactivate simulation pulse output	С	Warning
494	Switch output simulation	Deactivate simulation switch output	С	Warning
495	Diagnostic event simulation	Deactivate simulation	С	Warning
Diagnostic of p	rocess			
801	Supply voltage too low	Increase supply voltage	S	Warning ¹⁾
803	Current loop	Check wiring Change I/O module	F	Alarm
830	Sensor temperature too high	Reduce ambient temp. around the sensor housing	S	Warning ¹⁾
831	Sensor temperature too low	Increase ambient temp. around the sensor housing	S	Warning 1)
832	Electronic temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronic temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning 1)
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
862	Partly filled pipe	Check for gas in process Adjust detection limits	S	Warning 1)

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
882	Input signal	Check input configuration Check external device or process conditions	F	Alarm
910	Tubes not oscillating	Check process conditions Increase supply Check main electronic or sensor	F	Alarm
912	Medium inhomogeneous	Check process cond. Increase system pressure	S	Warning 1)
913	Medium unsuitable	Check process conditions Increase supply Check main electronic or sensor	S	Warning 1)

¹⁾ Diagnostic status is changeable.

12.6 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

- To call up the measures to rectify a diagnostic event:
 - Via local display → 🖺 108
 - Via "FieldCare" operating tool → 🖺 109

Navigation

"Diagnostics" menu

Structure of the submenu

Diagnostics	\rightarrow	Actual diagnostics
		Previous diagnostics
		Operating time from restart
		Operating time

Parameter overview with brief description

Parameter	Prerequsite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occured diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.
		If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.


Parameter	Prerequsite	Description	User interface
Operating time from restart	-	Shows the time the device has been in operation since the last device restart.	Days (d), hours (h), minutes (m) and seconds (s)
Operating time	-	Indicates how long the device has been in operation.	Days (d), hours (h), minutes (m) and seconds (s)

12.7 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → **Diagnostic list** submenu



A0014006-EN

32 Illustrated using the example of the local display

- To call up the measures to rectify a diagnostic event:
 - Via local display → 🗎 108
 - Via "FieldCare" operating tool →

 109


12.8 Event logbook

12.8.1 Event history

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

"Diagnostics" menu \rightarrow Event logbook \rightarrow Events list



A0014008-EN

■ 33 Illustrated using the example of the local display

A maximum of 20 event messages can be displayed in chronological order. If the advanced HistoROM function is enabled in the device (order option), up to 100 entries can be displayed.

The event history includes entries for:

- Diagnostic events → 🗎 111
- Information events $\rightarrow \implies 116$

In addition to the operation time of its occurrence, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - →: Event has occurred
 - ←: Event has ended
- Information event
 - →: Event has occurred
- To call up the measures to rectify a diagnostic event:
 - Via local display → 🗎 108
 - Via "FieldCare" operating tool → 🖺 109
- For filtering the displayed event messages $\rightarrow \stackrel{\triangle}{=} 116$

12.8.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu \rightarrow Event logbook \rightarrow Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	(Device ok)
I1079	Sensor changed
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Trend data deleted
I1110	Write protection switch changed
I1111	Density adjust failure
I1137	Electronic changed
I1151	History reset
I1154	Reset terminal voltage min/max
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared


Info number	Info name
I1189	Backup compared
I1209	Density adjustment ok
I1221	Zero point adjust failure
I1222	Zero point adjustment ok
I1227	Sensor emergency mode activated
I1228	Sensor emergency mode failed
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1440	Main electronic module changed
I1442	I/O module changed
I1444	Device verification passed
I1445	Device verification failed
I1450	Monitoring off
I1451	Monitoring on
I1459	Failed: I/O module verification
I1461	Failed: Sensor verification
I1512	Download started
I1513	Download finished
I1514	Upload started
I1515	Upload finished
I1552	Failed: Main electronic verification
I1554	Safety sequence started
I1555	Safety sequence confirmed
I1556	Safety mode off

12.9 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

Navigation

"Setup" menu \rightarrow Advanced setup \rightarrow Administration \rightarrow Device reset



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	CancelTo factory defaultsTo delivery settingsRestart device	Cancel

12.9.1 Function scope of the "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

12.10 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

Navigation

"Diagnostics" menu \rightarrow Device information

▶ Device information			
Device tag			
Serial number			
Firmware version			

Device name
Order code
Extended order code 1
Extended order code 2
Extended order code 3
ENP version
Device revision
Device ID
Device type
Manufacturer ID

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)	Promass
Serial number	Shows the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	-
Firmware version	Shows the device firmware version installed.	Character string with the following format: xx.yy.zz	01.04
Device name	Shows the name of the transmitter. The name can be found on the nameplate of the transmitter.	Promass 200	-
Order code	Shows the device order code. The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	-
Extended order code 1	Shows the 1st part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
Extended order code 2	Shows the 2nd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	_

Parameter	Description	User interface	Factory setting
Extended order code 3	Shows the 3rd part of the extended order code. The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	-
ENP version	Shows the version of the electronic nameplate (ENP).		2.02.00
Device revision	Shows the device revision with which the device is registered with the HART Communication Foundation.	2-digit hexadecimal number	0x05
Device ID	Enter device ID of external device.	6-digit hexadecimal number	-
Device type	Displays the device type with which the measuring device is registered with the HART Communication Foundation.	0 to 255	0x54
Manufacturer ID	Displays the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.	0 to 255	0x11

12.11 Firmware history

Release date	Firmwar e version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
06.2015	01.04.zz	Option 72	Device download possible if communication established.	Operating Instructions	BA01027D/06/EN/ 16.15
02.2014	01.03.zz	Option 73	 In accordance with HART 7 Specification Integrated HART input SD03 keypad lock Modification of SIL functionality HistoROM data logging in FieldCare "HistoROM" module Simulation of diagnostic events Ability to access Heartbeat Technology application package 	Operating Instructions	BA01027D/06/EN/ 15.14
07.2012	01.02.zz	Option 75	 Integrated additional operating languages: Chinese New numeric editor SD03 local display with backlighting New menu: Pulse/frequency/switch output wizard Define access code submenu with prompt to confirm code 	Operating Instructions Manual Functional Safety	BA01027D/06/EN/ 14.12 SD00147D/06/EN/02.12
07.2011	01.01.zz	Option 76	SIL integrated (optional)	Operating Instructions	BA01027D/06/EN/ 13.11

Release date	Firmwar e version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
			 Integrated additional operating languages: Portuguese, Polish, Russian, Turkish, Bahasa (Indonesian), Vietnamese, Czech Data logging submenu: Assign channel 1 to 4 extended Min/max values submenu extended For diagnostic event S441: diagnostic behavior can be changed 	Description Device Parameters Manual Functional Safety	GP01010D/06/EN/01.11 SD00147D/06/EN/01.11
06.2010	01.00.zz	Option 78	Original firmware	Operating Instructions Description Device Parameters	BA01027D/06/EN/ 06.10 GP01009D/06/EN/06.10
				Functional Safety Manual	SD00147D/06/EN/01.11

- Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) .
- For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
- The manufacturer's information is available:
 - In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download
 - Specify the following details:
 - Product root, e.g. 8E2B
 - Text search: Manufacturer's information
 - Search range: documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.


13.1.2 Interior cleaning


Observe the following points for CIP and SIP cleaning:

- Use only cleaning agents to which the process-wetted materials are adequately resistant.

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.





13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:


- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the W@M life cycle management database.

14.2 Spare parts

Some interchangeable measuring device components are listed on an overview sign in the connection compartment cover.

The spare part overview sign contains the following information:

- A list of the most important spare parts for the measuring device, including their ordering information.
- The URL for the W@M Device Viewer (www.endress.com/deviceviewer):
 All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



■ 34 Example for "Spare part overview sign" in connection compartment cover

- Measuring device name
- 2 Measuring device serial number
- Measuring device serial number:
 - Is located on the device nameplate and the spare part overview sign.
 - Can be read out via the Serial number parameter in the Device information submenu →

 118.

14.3 Endress+Hauser services

Contact your Endress+Hauser Sales Center for information on services and spare parts.

14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at http://www.endress.com/support/return-material

14.5 Disposal

14.5.1 Removing the measuring device

- 1. Switch off the device.
- 2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

A WARNING

Danger to personnel and environment from fluids that are hazardous to health.

► Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress +Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Promass 200 transmitter	Transmitter for replacement or storage. Use the order code to define the following specifications: Approvals Output Display / operation Housing Software For details, see Installation Instructions EA00104D
Remote display FHX50	FHX50 housing to accommodate a display module → 🖺 145.
FINO	 FHX50 housing suitable for: SD02 display module (push buttons) SD03 display module (touch control) Housing material: Plastic PBT Stainless steel CF-3M (316L, 1.4404) Length of connecting cable: up to max. 60 m (196 ft) (cable lengths available for order: 5 m (16 ft), 10 m (32 ft), 20 m (65 ft), 30 m (98 ft))
	The measuring device can be ordered with the FHX50 housing and a display module. The following options must be selected in the separate order codes: Order code for measuring device, feature 030: Option L or M "Prepared for FHX50 display" Order code for FHX50 housing, feature 050 (device version): Option A "Prepared for FHX50 display" Order code for FHX50 housing, depends on the desired display module in feature 020 (display, operation): Option C: for an SD02 display module (push buttons) Option E: for an SD03 display module (touch control)
	The FHX50 housing can also be ordered as a retrofit kit. The measuring device display module is used in the FHX50 housing. The following options must be selected in the order code for the FHX50 housing: Feature 050 (measuring device version): option B "Not prepared for FHX50 display" Feature 020 (display, operation): option A "None, existing displayed used"
	For details, see Special Documentation SD01007F
Overvoltage protection for 2-wire devices	Ideally, the overvoltage protection module should be ordered directly with the device. See product structure, characteristic 610 "Accessory mounted", option NA "Overvoltage protection". Separate order necessary only if retrofitting.
	 OVP10: For 1-channel devices (characteristic 020, option A): OVP20: For 2-channel devices (characteristic 020, options B, C, E or G)
	For details, see Special Documentation SD01090F.
Weather protection cover	Is used to protect the measuring device from the effects of the weather: e.g. rainwater, excess heating from direct sunlight or extreme cold in winter.
	For details, see Special Documentation SD00333F

15.1.2 For the sensor

Accessories	Description
Heating jacket	Is used to stabilize the temperature of the fluids in the sensor. Water, water vapor and other non-corrosive liquids are permitted for use as fluids. If using oil as a heating medium, please consult with Endress+Hauser. Heating jackets cannot be used with sensors fitted with a rupture disk. For details, see Operating Instructions BA00099D

15.2 Communication-specific accessories

Accessories	Description
Commubox FXA195 HART	For intrinsically safe HART communication with FieldCare via the USB interface. For details, see "Technical Information" TI00404F
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop. For details, see the "Technical Information" document TI405C/07
HART Loop Converter HMX50	Is used to evaluate and convert dynamic HART process variables to analog current signals or limit values. For details, see "Technical Information" TI00429F and Operating Instructions BA00371F
Wireless HART adapter SWA70	Is used for the wireless connection of field devices. The WirelessHART adapter can be easily integrated into field devices and existing infrastructures, offers data protection and transmission safety and can be operated in parallel with other wireless networks with minimum cabling complexity.
	For details, see Operating Instructions BA00061S
Fieldgate FXA320	Gateway for the remote monitoring of connected 4-20 mA measuring devices via a Web browser. For details, see "Technical Information" TI00025S and Operating Instructions BA00053S
Fieldgate FXA520	Gateway for the remote diagnostics and remote configuration of connected HART measuring devices via a Web browser.
	For details, see "Technical Information" TI00025S and Operating Instructions BA00051S
Field Xpert SFX350	Field Xpert SFX350 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area .
	For details, see Operating Instructions BA01202S
Field Xpert SFX370	Field Xpert SFX370 is a mobile computer for commissioning and maintenance. It enables efficient device configuration and diagnostics for HART and FOUNDATION Fieldbus devices in the non-Ex area and the Ex area .
	For details, see Operating Instructions BA01202S

15.3 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. Graphic illustration of the calculation results
	Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project.
	Applicator is available: Via the Internet: https://wapps.endress.com/applicator On CD-ROM for local PC installation.
W@M	Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress +Hauser also takes care of maintaining and updating the data records. W@M is available: Via the Internet: www.endress.com/lifecyclemanagement On CD-ROM for local PC installation.
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.
	For details, see Operating Instructions BA00027S and BA00059S

15.4 System components

Accessories	Description
Memograph M graphic display recorder	The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.
	For details, see "Technical Information" TI00133R and Operating Instructions BA00247R
RN221N	Active barrier with power supply for safe separation of 4-20 mA standard signal circuits. Offers bidirectional HART transmission.
	For details, see "Technical Information" TI00073R and Operating Instructions BA00202R
RNS221	Supply unit for powering two 2-wire measuring devices solely in the non-Ex area. Bidirectional communication is possible via the HART communication jacks.
	For details, see "Technical Information" TI00081R and Brief Operating Instructions KA00110R
Cerabar M	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
	For details, see "Technical Information" TI00426P, TI00436P and Operating Instructions BA00200P, BA00382P
Cerabar S	The pressure transmitter for measuring the absolute and gauge pressure of gases, steam and liquids. It can be used to read in the operating pressure value.
	For details, see "Technical Information" TI00383P and Operating Instructions BA00271P

16 Technical data

16.1 Application

The measuring device is suitable for flow measurement of liquids and gases only.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

Measuring principle

Mass flow measurement based on the Coriolis measuring principle

Measuring system

The device consists of a transmitter and a sensor.

The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

For information on the structure of the device $\rightarrow \implies 12$

16.3 Input

Measured variable

Direct measured variables

- Mass flow
- Density
- Temperature

Calculated measured variables

- Volume flow
- Corrected volume flow
- Reference density

Measuring range

Measuring ranges for liquids

DN		Measuring range full scale values $\dot{m}_{min(F)}$ to $\dot{m}_{max(F)}$	
[mm]	[in]	[kg/h]	[lb/min]
8	3/8	0 to 2 000	0 to 73.50
15	1/2	0 to 6 500	0 to 238.9
25	1	0 to 18 000	0 to 661.5
40	1½	0 to 45 000	0 to 1654
50	2	0 to 70 000	0 to 2 573

Measuring ranges for gases

The full scale values depend on the density of the gas and can be calculated with the formula below:

 $\dot{m}_{max(G)} = \dot{m}_{max(F)} \cdot \rho_G : x$

m _{max(G)}	Maximum full scale value for gas [kg/h]
m _{max(F)}	Maximum full scale value for liquid [kg/h]
$\dot{m}_{\max(G)} < \dot{m}_{\max(F)}$	$\dot{m}_{max(G)}$ can never be greater than $\dot{m}_{max(F)}$
$ ho_{G}$	Gas density in [kg/m³] at operating conditions

DN		х
[mm]	[in]	[kg/m³]
8	3/8	85
15	1/2	110
25	1	125
40	1½	125
50	2	125

Calculation example for gas

- Sensor: Promass E, DN 50
- Gas: Air with a density of 60.3 kg/m³ (at 20 °C and 50 bar)
- Measuring range (liquid): 70 000 kg/h
- $x = 125 \text{ kg/m}^3 \text{ (for Promass E, DN 50)}$

Maximum possible full scale value:

 $\dot{m}_{\max(G)} = \dot{m}_{\max(F)} \cdot \rho_G : x = 70\,000 \text{ kg/h} \cdot 60.3 \text{ kg/m}^3 : 125 \text{ kg/m}^3 = 33\,800 \text{ kg/h}$

Recommended measuring range

Operable flow range

Over 1000: 1.

Flow rates above the preset full scale value are not overridden by the electronics unit, with the result that the totalizer values are registered correctly.

Input signal

External measured values

To increase the accuracy of certain measured variables or to calculate the corrected volume flow for gases, the automation system can continuously write the operating pressure to the measuring device. Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S.



It is recommended to read in external measured values to calculate the following measured variables:

- Mass flow
- Corrected volume flow

HART protocol

The measured values are written from the automation system to the measuring device via the HART protocol. The pressure transmitter must support the following protocol-specific functions:

- HART protocol
- Burst mode

16.4 Output

Output signal

Current output

Current output 1	4-20 mA HART (passive)
Current output 2	4-20 mA (passive)
Resolution	< 1 μA
Damping	Adjustable: 0.0 to 999.9 s
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature

Pulse/frequency/switch output

Function	Can be set to pulse, frequency or switch output	
Version	Passive, open collector	
Maximum input values	■ DC 35 V ■ 50 mA	
Voltage drop	For ≤ 2 mA: 2 VFor 10 mA: 8 V	
Residual current	≤ 0.05 mA	
Pulse output		
Pulse width	Adjustable: 5 to 2 000 ms	
Maximum pulse rate	100 Impulse/s	
Pulse value	Adjustable	
Assignable measured variables	Mass flowVolume flowCorrected volume flow	
Frequency output		
Output frequency	Adjustable: 0 to 1 000 Hz	
Damping	Adjustable: 0 to 999 s	
Pulse/pause ratio	1:1	
Assignable measured variables	 Mass flow Volume flow Corrected volume flow Density Reference density Temperature 	
Switch output	Switch output	
Switching behavior	Binary, conductive or non-conductive	

Switching delay	Adjustable: 0 to 100 s
Number of switching cycles	Unlimited
Assignable functions	■ Off ■ On ■ Diagnostic behavior ■ Limit value - Mass flow - Volume flow - Corrected volume flow - Density - Reference density - Temperature - Totalizer 1-3 ■ Flow direction monitoring ■ Status - Partially filled pipe detection - Low flow cut off

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Current output

4-20 mA

Failure mode	Selectable (as per NAMUR recommendation NE 43): Minimum value: 3.6 mA Maximum value: 22 mA Defined value: 3.59 to 22.5 mA Actual value
	Last valid value

HART

Device diagnostics	Device condition can be read out via HART Command 48
--------------------	--

Pulse/frequency/switch output

Pulse output

Failure mode	Choose from: Actual value No pulses
	• No pulses

Frequency output

Failure mode	Choose from:
	Actual value
	■ 0 Hz
	■ Defined value: 0 to 1250 Hz

Switch output

Failure mode	Choose from:
	Current status
	■ Open
	■ Closed

Proline Promass E 200 HART

Local display

Plain text display	With information on cause and remedial measures
Backlight	Additionally for device version with SD03 local display: red lighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication: HART protocol
- Via service interface

Plain text display With information on cause and re	emedial measures
---	------------------

Load

→ 🗎 28

Low flow cut off

The switch points for low flow cut off are user-selectable.

Galvanic isolation

All outputs are galvanically isolated from one another.

Protocol-specific data

HART

- For information on the device description files $\rightarrow \implies 52$
- For information on the dynamic variables and measured variables (HART device variables) $\rightarrow \triangleq 52$

16.5 Power supply

Terminal assignment

→ 🖺 27

Supply voltage

Transmitter

An external power supply is required for each output.

The following supply voltage values apply for the outputs available:

Order code for "Output"	Minimum terminal voltage	Maximum terminal voltage
Option A ^{1) 2)} : 4-20 mA HART	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 35 V
Option B ^{1) 2)} : 4-20 mA HART, pulse/frequency/switch output	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 35 V
Option C ^{1) 2)} : 4-20 mA HART + 4-20 mA analog	 For 4 mA: ≥ DC 17.9 V For 20 mA: ≥ DC 13.5 V 	DC 30 V

- External supply voltage of the power supply unit with load.
- For device versions with SD03 local display: The terminal voltage must be increased by DC 2 V if backlighting is used.

Power consumption

Transmitter

Order code for "Output"	Maximum power consumption
Option A : 4-20 mA HART	770 mW
Option B : 4-20 mA HART, pulse/ frequency/switch output	 Operation with output 1: 770 mW Operation with output 1 and 2: 2770 mW
Option C : 4-20 mA HART + 4-20 mA analog	 Operation with output 1: 660 mW Operation with output 1 and 2: 1320 mW

Current consumption

Current output

For every 4-20 mA or 4-20 mA HART current output: 3.6 to 22.5 mA



If the option Defined value is selected in the Failure mode parameter : 3.59 to 22.5 mA

Power supply failure

- Totalizers stop at the last value measured.
- Configuration is retained in the device memory (HistoROM).
- Error messages (incl. total operated hours) are stored.

Electrical connection

→ 🖺 28

Terminals

- For device version without integrated overvoltage protection: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- For device version with integrated overvoltage protection: screw terminals for wire cross-sections 0.2 to 2.5 mm² (24 to 14 AWG)

Cable entries

- Cable gland: M20 × 1.5 with cable ϕ 6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
 - NPT ½"
 - G ½"

Cable specification

→ 🖺 26

Overvoltage protection

The device can be ordered with integrated overvoltage protection for diverse approvals: *Order code for "Accessory mounted", option NA "Overvoltage protection"*

Input voltage range Values correspond to supply voltage specifications 1)	
Resistance per channel	2 · 0.5 Ω max
DC sparkover voltage	400 to 700 V
Trip surge voltage	< 800 V
Capacitance at 1 MHz	< 1.5 pF

Nominal discharge current (8/20 μs)	10 kA
Temperature range	−40 to +85 °C (−40 to +185 °F)

1) The voltage is reduced by the amount of the internal resistance I_{min} · R_i

- Depending on the temperature class, restrictions apply to the ambient temperature for device versions with overvoltage protection .
- For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

16.6 Performance characteristics

Reference operating conditions

- Error limits based on ISO 11631
- Water with +15 to +45 °C (+59 to +113 °F) at 2 to 6 bar (29 to 87 psi)
- Specifications as per calibration protocol
- Accuracy based on accredited calibration rigs that are traced to ISO 17025.
- To obtain measured errors, use the *Applicator* sizing tool $\rightarrow \stackrel{\triangle}{=} 128 \rightarrow \stackrel{\triangle}{=} 148$

Maximum measured error

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base accuracy

Mass flow and volume flow (liquids)

±0.25 % o.r.

Mass flow (gases)

±0.75 % o.r.

Design fundamentals

Density (liquids)

- Reference conditions: ±0.0005 q/cm³
- Standard density calibration: ±0.02 g/cm³
 (valid over the entire temperature range and density range)

Temperature

 $\pm 0.5 \,^{\circ}\text{C} \pm 0.005 \cdot \text{T} \,^{\circ}\text{C} \, (\pm 0.9 \,^{\circ}\text{F} \pm 0.003 \cdot (\text{T} - 32) \,^{\circ}\text{F})$

Zero point stability

DN		Zero point stability		
[mm]	[in]	[kg/h]	[lb/min]	
8	3/8	0.24	0.0088	
15	1/2	0.78	0.0287	
25	1	2.16	0.0794	
40	1½	5.40	0.1985	
50	2	8.40	0.3087	

Flow values

Flow values as turndown parameter depending on nominal diameter.

SI units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[mm]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]	[kg/h]
8	2 000	200	100	40	20	4
15	6500	650	325	130	65	13
25	18000	1800	900	360	180	36
40	45 000	4500	2 250	900	450	90
50	70 000	7 000	3 500	1400	700	140

US units

DN	1:1	1:10	1:20	1:50	1:100	1:500
[inch]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]	[lb/min]
3/8	73.50	7.350	3.675	1.470	0.735	0.147
1/2	238.9	23.89	11.95	4.778	2.389	0.478
1	661.5	66.15	33.08	13.23	6.615	1.323
11/2	1654	165.4	82.70	33.08	16.54	3.308
2	2 5 7 3	257.3	128.7	51.46	25.73	5.146

Accuracy of outputs

o.r. = of reading

The outputs have the following base accuracy specifications.

Current output

Accuracy	±10 μA	
----------	--------	--

Pulse/frequency output

Accuracy	Max. ±100 ppm o.r.
----------	--------------------

Repeatability

o.r. = of reading; $1 \text{ g/cm}^3 = 1 \text{ kg/l}$; T = medium temperature

Base repeatability

Mass flow and volume flow (liquids)

±0.125 % o.r.

Mass flow (gases)

±0.35 % o.r.

Pesign fundamentals

Density (liquids)

 $\pm 0.00025 \text{ g/cm}^3$

Temperature

 ± 0.25 °C $\pm 0.0025 \cdot$ T °C (± 0.45 °F $\pm 0.0015 \cdot$ (T-32) °F)

136

Resi	ponse	time
1100	DOLLOC	umi

- The response time depends on the configuration (damping).
- \blacksquare Response time in the event of erratic changes in the measured variable: after 500 ms \rightarrow 95 % of the full scale value

Influence of ambient temperature

o.r. = of reading

Current output

Additional error, in relation to the span of 16 mA:

Temperature coefficient at zero point (4 mA)	0.02 %/10 K
Temperature coefficient with span (20 mA)	0.05 %/10 K


Pulse/frequency output

Temperature coefficient Max. ±100 ppm o.r.

Influence of medium temperature

Mass flow and volume flow

When there is a difference between the temperature for zero point adjustment and the process temperature, the typical measured error of the sensor is ± 0.0002 % of the full scale value/°C (± 0.0001 % of the full scale value/°F).



■ 35 Field density calibration, for example at +20 °C (+68 °F)

Temperature

 $\pm 0.005 \cdot \text{T °C } (\pm 0.005 \cdot (\text{T} - 32) \text{ °F})$

Influence of medium pressure

The table below shows the effect on accuracy of mass flow due to a difference between calibration pressure and process pressure.

o.r. = of reading

Endress+Hauser 137

A001660

DN		[% o.r./bar]	[% o.r./psi]
[mm]	[in]		
8	3/8	no influence	
15	1/2	no influence	
25	1	no influence	
40	11/2	no influence	
50	2	-0.009	-0.0006

Design fundamentals

o.r. = of reading, o.f.s. = of full scale value

BaseAccu = base accuracy in % o.r., BaseRepeat = base repeatability in % o.r.

MeasValue = measured value; ZeroPoint = zero point stability


Calculation of the maximum measured error as a function of the flow rate

Flow rate	Maximum measured error in % o.r.
$\geq \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± BaseAccu
A0021332	
$< \frac{\text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	± ZeroPoint MeasValue · 100
A0021333	A0021334

Calculation of the maximum repeatability as a function of the flow rate

Flow rate	Maximum repeatability in % o.r.
$\geq \frac{\frac{4}{3} \cdot ZeroPoint}{BaseAccu} \cdot 100$	± 1/2 · BaseAccu
A0021341	
$<\frac{4/3 \cdot \text{ZeroPoint}}{\text{BaseAccu}} \cdot 100$	$\pm \frac{2}{3} \cdot \frac{\text{ZeroPoint}}{\text{MeasValue}} \cdot 100$
A0021342	A0021344

Example for max. measured error



■ 36 Maximum measured error in % o.r. (example: DN 25)

P Design fundamentals

16.7 Installation

"Mounting requirements" → 🖺 19

16.8 Environment

Ambient temperature range	→ 🗎 21		
	Temperature tables		
	Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.		
	For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.		
Storage temperature	All components apart from the display modules: -40 to $+80$ °C (-40 to $+176$ °F), preferably at $+20$ °C ($+68$ °F)		
	Display modules		
	-40 to +80 °C (-40 to +176 °F)		
Climate class	DIN EN 60068-2-38 (test Z/AD)		
Degree of protection	Transmitter ■ As standard: IP66/67, type 4X enclosure ■ When housing is open: IP20, type 1 enclosure ■ Display module: IP20, type 1 enclosure		
	Sensor IP66/67, type 4X enclosure		
Shock resistance	As per IEC/EN 60068-2-31		
Vibration resistance	Acceleration up to 1 g, 10 to 150 Hz, based on IEC/EN 60068-2-6		
Interior cleaning	 Sterilization in place (SIP) Cleaning in place (CIP) 		
Electromagnetic	As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)		
compatibility (EMC)	For details, refer to the Declaration of Conformity.		
	16.9 Process		
Medium temperature range	Sensor		
carain temperature range	-40 to +140 °C (-40 to +284 °F)		
	Seals No internal seals		
Density	0 to 2 000 kg/m³ (0 to 125 lb/cf)		

System pressure

→ 🖺 21

Pressure-temperature ratings	An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document
Secondary containment pressure rating	The sensor housing is filled with dry nitrogen and protects the electronics and mechanics inside.
	The housing does not have pressure vessel classification.
	Reference value for the pressure loading capacity of the sensor housing: 16 bar (232 psi)
	For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section
Rupture disk	To increase the level of safety, a device version with a rupture disk with a triggering pressure of 10 to 15 bar (145 to 217.5 psi) can be used (order code for "Sensor option", option CA "rupture disk"). Special mounting instructions: $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
	Rupture disks cannot be combined with the separately available heating jacket $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $
Flow limit	Select the nominal diameter by optimizing between the required flow range and permissible pressure loss.
	For an overview of the measuring range full scale values, see the "Measuring range" section
	 The minimum recommended full scale value is approx. 1/20 of the maximum full scale value In the most common applications, 20 to 50 % of the maximum full scale value can be considered ideal
	 A low full scale value must be selected for abrasive media (such as liquids with entrained solids): flow velocity < 1 m/s (< 3 ft/s).
	 For gas measurement the following rules apply: The flow velocity in the measuring tubes should not exceed half the sound velocity (0.5 Mach).
	– The maximum mass flow depends on the density of the gas: formula
Pressure loss	To calculate the pressure loss, use the <i>Applicator</i> sizing tool $\rightarrow \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ $

16.10 Mechanical construction

Design, dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight

Compact version

Weight in SI units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [kg].

DN	Weight [kg]	
[mm]	Order code for "Housing", option C Aluminum coated	Order code for "Housing", option B 1.4404 (316L)
8	6	8.5
15	6.5	9
25	8	10.5
40	13	15.5
50	22	24.5

Weight in US units

All values (weight) refer to devices with EN/DIN PN 40 flanges. Weight information in [lbs].


DN	Weight [lbs]	
[in]	Order code for "Housing", option C Aluminum coated	Order code for "Housing", option B 1.4404 (316L)
3/8	13.2	18.7
1/2	14.3	19.8
1	17.6	23.2
1 ½	28.7	34.2
2	48.5	54.0

Materials

Transmitter housing

- Order code for "Housing", option **B**: stainless steel CF-3M (316L, 1.4404)
- Order code for "Housing", option **C** "Compact, aluminum coated": Aluminum, AlSi10Mg, coated
- Window material: glass

Cable entries/cable glands



 \blacksquare 37 Possible cable entries/cable glands

- Cable entry in transmitter housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G $\frac{1}{2}$ " or NPT $\frac{1}{2}$ "

Order code for "Housing", option B "GT18 two-chamber, 316L"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	 Non-Ex Ex ia Ex ic Ex nA Ex tb 	Stainless steel ,1.4404
Adapter for cable entry with internal thread G ½"	For non-Ex and Ex (except for CSA Ex d/XP)	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread NPT ½"	For non-Ex and Ex	

Order code for "Housing", option C "GT20 two-chamber, aluminum coated"

Cable entry/cable gland	Type of protection	Material
Cable gland M20 × 1.5	Non-ExEx iaEx ic	Plastic
	Adapter for cable entry with internal thread G ½"	Nickel-plated brass
Adapter for cable entry with internal thread NPT ½"	For non-Ex and Ex (except for CSA Ex d/XP)	Nickel-plated brass
Thread NPT ½" via adapter	For non-Ex and Ex	

Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tubes


Stainless steel, 1.4539 (904L); manifold: stainless steel, 1.4404 (316L)

Process connections

■ Flanges according to EN 1092-1 (DIN2501) / according to ASME B 16.5 / as per JIS B2220:

Stainless steel, 1.4404 (F316/F316L)

 All other process connections: Stainless steel, 1.4404 (316/316L)



Seals

Welded process connections without internal seals

Accessories

Weather protection cover

Stainless steel 1.4404 (316L)

Process connections

- Fixed flange connections:
 - EN 1092-1 (DIN 2501) flange
 - EN 1092-1 (DIN 2512N) flange
 - Namur lengths in accordance with NE 132
 - ASME B16.5 flange
 - JIS B2220 flange
 - DIN 11864-2 Form A flange, DIN11866 line A, flange with notch
- Clamp connections

Tri-Clamp (OD tubes), DIN 11866 line C

- Threaded connection:
 - DIN 11851 thread, DIN11866 line A
 - SMS 1145 thread
 - ISO 2853 thread, ISO2037
 - DIN 11864-1 Form A thread, DIN11866 line A
- VCO connections
 - 8-VCO-4
 - 12-VCO-4

Surface roughness


All data relate to parts in contact with fluid.

- Not polished
- $Ra_{max} = 0.8 \mu m$ (32 μ in) mechanically polished
- $Ra_{max} = 0.4 \mu m$ (16 μ in) mechanically polished

16.11 Operability

Local operation

Via display module



Display elements

- 4-line display
- With order code for "Display; operation", option E:
 White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F) The readability of the display may be impaired at temperatures outside the temperature range.


Operating elements

- With order code for "Display; operation", option **C**: Local operation with 3 push buttons: ①, ②, ⑥
- With order code for "Display; operation", option **E**: External operation via touch control; 3 optical keys: ④, ⑤,⑤
- Operating elements also accessible in various hazardous areas

Additional functionality

- Data backup function
 - The device configuration can be saved in the display module.
- Data comparison function
 - The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function
 - The transmitter configuration can be transmitted to another device using the display module.

Via remote display and operating module FHX50




₹ 38 Operating options via FHX50

- Housing of remote display and operating module FHX50 $\,$
- SD02 display and operating module, push buttons: cover must be opened for operation
- SD03 display and operating module, optical buttons: operation possible through cover glass

Remote operation

Via HART protocol

This communication interface is available in device versions with a HART output.




₹ 39 Options for remote operation via HART protocol

- Control system (e.g. PLC)
- Transmitter power supply unit, e.g. RN221N (with communication resistor) 2
- 3 Connection for Commubox FXA195 and Field Communicator 475
- Field Communicator 475
- $Computer\ with\ operating\ tool\ (e.g.\ Field Care,\ AMS\ Device\ Manager,\ SIMATIC\ PDM)$
- Commubox FXA195 (USB)
- Field Xpert SFX350 or SFX370
- VIATOR Bluetooth modem with connecting cable
- Transmitter

Service interface

Via service interface (CDI)



- A001401
- 1 Service interface (CDI = Endress+Hauser Common Data Interface) of the measuring device
- 2 Commubox FXA291
- 3 Computer with "FieldCare" operating tool with COM DTM "CDI Communication FXA291"

Languages

Can be operated in the following languages:

- Via local display:
 English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Swedish,
 Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech
- Via "FieldCare" operating tool:
 English, German, French, Spanish, Italian, Chinese, Japanese

16.12 Certificates and approvals

CE mark	The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.
	Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.
C-Tick symbol	The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".
Ex approval	The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.
Hygienic compatibility	3A approval
Functional safety	The measuring device can be used for flow monitoring systems (min., max., range) up to SIL 2 (single-channel architecture) and SIL 3 (multichannel architecture with homogeneous redundancy) and is independently evaluated and certified by the TÜV in accordance with IEC 61508.

The following types of monitoring in safety equipment are possible:

- Mass flow
- Volume flow
- Density



HART certification

HART interface

The measuring device is certified and registered by the HCF (HART Communication Foundation). The measuring system meets all the requirements of the following specifications:

- Certified according to HART 7
- The device can also be operated with certified devices of other manufacturers (interoperability)

Pressure Equipment Directive

- With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC.
- Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.

Other standards and quidelines

■ EN 60529

Degrees of protection provided by enclosures (IP code)

■ IEC/EN 60068-2-6

Environmental influences: Test procedure - Test Fc: vibrate (sinusoidal).

■ IEC/EN 60068-2-31

Environmental influences: Test procedure - Test Ec: shocks due to rough handling, primarily for devices.

■ EN 61010-1

Safety requirements for electrical equipment for measurement, control and laboratory use

■ IEC/EN 61326

Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).

■ IEC 61508

Functional safety of electrical/electronic/programmable electronic safety-related systems

■ NAMUR NE 21

Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment

■ NAMUR NE 32

Data retention in the event of a power failure in field and control instruments with microprocessors

NAMUR NE 43

Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.

■ NAMUR NE 53

Software of field devices and signal-processing devices with digital electronics

■ NAMUR NE 80

The application of the pressure equipment directive to process control devices

■ NAMUR NE 105

Specifications for integrating fieldbus devices in engineering tools for field devices

- NAMUR NE 107
 Self-monitoring and diagnosis of field devices
- NAMUR NE 131
 Requirements for field devices for standard applications
- NAMUR NE 132
 Coriolis mass meter

16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered with the device or subsequently from Endress+Hauser. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Diagnostics functions

Package	Description
HistoROM extended function	Comprises extended functions concerning the event log and the activation of the measured value memory.
	Event log: Memory volume is extended from 20 message entries (basic version) to up to 100 entries.
	 Data logging (line recorder): Memory capacity for up to 1000 measured values is activated. 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user. Data logging is visualized via the local display or FieldCare.

Heartbeat Technology

Package	Description
Heartbeat Verification	 Heartbeat Verification: Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process. Access via local operation or other operating interfaces, such as FieldCare for instance. Documentation of device functionality within the framework of manufacturer specifications, for proof testing for instance. End-to-end, traceable documentation of the verification results, including report. Makes it possible to extend calibration intervals in accordance with operator's risk assessment.

16.14 Accessories

16.15 Documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Promass E 200	KA00050D

Technical Information

Measuring device	Documentation code
Promass E 200	TI01009D

Supplementary devicedependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEx Ex i	XA00144D
ATEX/IECEx Ex d	XA00143D
ATEX/IECEx Ex nA	XA00145D
cCSAus IS	XA00151D
cCSAus XP	XA00152D
INMETRO Ex i	XA01300D
INMETRO Ex d	XA01305D
INMETRO Ex nA	XA01306D
NEPSI Ex i	XA00156D
NEPSI Ex d	XA00155D
NEPSI Ex nA	XA00157D

Special Documentation

Contents	Documentation code
Information on the Pressure Equipment Directive	SD00142D
Functional Safety Manual	SD00147D
Heartbeat Technology	SD01300D

Installation Instructions

Contents	Documentation code
Installation Instructions for spare part sets	Overview of accessories available for order → 🖺 126

Index

A	Current consumption
Access authorization to parameters	D
Read access	
Write access	Declaration of Conformity
Access code	Define access code
Incorrect input	
Accuracy	Density
Adapting the diagnostic behavior	Measuring device
Adapting the status signal	Design fundamentals
Ambient temperature	Maximum measured error
Influence	Repeatability
Ambient temperature range	Designated use
AMS Device Manager	Device components
Function	Device description files
Application	Device documentation
Application packages	Supplementary documentation 8
Approvals 146	Device locking, status
Approvals	Device name
В	Sensor
Burst mode	Transmitter
Zarot mode	Device repair
C	Device revision
C-Tick symbol	Device type ID
Cable entries	Diagnostic behavior
Technical data	Explanation
Cable entry	Symbols
Degree of protection	Diagnostic information
CE mark	Design, description
Certificates	FieldCare
Check	Local display
Installation	Overview
Checklist	Remedial measures
Post-connection check	Diagnostic list
Post-installation check	Diagnostic message
Cleaning	Diagnostics
Cleaning in place (CIP)	Symbols
Exterior cleaning	
Interior cleaning	see Write protection switch Direct access
Sterilization in place (SIP)	Direct access code
Climate class	Disabling write protection
Commissioning	Display
Advanced settings	Current diagnostic event
Configuring the measuring device 57	Previous diagnostic event
Communication-specific data	see Local display
Connecting cable	Display area
Connecting the measuring device	For operational display
Connection	In the navigation view
see Electrical connection	Display values
Connection preparations	For locking status
Connection tools	Disposal
Context menu	Document
Closing	Function 6
Explanation	Symbols used 6
Opening	Document function 6
	1

Down pipe	AMS Device Manager 50 Field Communicator 51
E	Field Communicator 475
Electrical connection	Field Xpert
Commubox FXA195	SIMATIC PDM
Commubox FXA195 (USB)	Functional safety (SIL)
Commubox FXA291	Functions
Degree of protection	see Parameter
Field Communicator	see rarameter
Field Communicator 475	G
Field Xpert SFX350/SFX370	Galvanic isolation
Handheld terminals	233
Measuring device	H
Operating tool (e.g. FieldCare, AMS Device	Hardware write protection
Manager, SIMATIC PDM)	HART certification
Operating tools	HART protocol
Via HART protocol 48, 145	Device variables
Via service interface (CDI) 48, 146	Measured variables 52
Transmitter power supply unit 145	Help text
VIATOR Bluetooth modem 145	Calling up
Electromagnetic compatibility	Close
Enabling write protection 93	Explanation
Endress+Hauser services	HistoROM
Maintenance	Hygienic compatibility
Repair	
Environment	I
Storage temperature	I/O electronics module
Error messages	Identifying the measuring device
see Diagnostic messages	Incoming acceptance
Event history	Influence
Events list	Ambient temperature
Ex approval	Medium pressure
Extended order code	Medium temperature
Sensor	Information on the document
Transmitter	Inlet runs
Exterior cleaning	Input
F	Input mask
F	Inspection
Field Communicator	Received goods
Function	Inspection check Connection
Field Communicator 475	Installation
Field of application	Installation conditions
Residual risks	Down pipe
Field Xpert	Mounting location
Function	Orientation
Field Xpert SFX350	Rupture disk
FieldCare	System pressure
Function	Thermal insulation
User interface	Vibrations
Filtering the event logbook	Installation dimensions
Firmware	Interior cleaning
Release date	
Version	K
Firmware history	Keypad lock
Flow direction	Disabling
Flow limit	Enabling
Function check	, and the second
Function scope	L
- and an ocope	Languages, operation options 146

Line recorder	Mounting tools
Local display	N
Editing view	Nameplate
Navigation view	Sensor
see Diagnostic message	Transmitter
see In alarm condition	Navigation path (navigation view)
see Operational display	Navigation view
Low flow cut off	In the submenu
Low flow cut off	In the wizard
M	Nominal pressure
Main electronics module	Secondary containment
Maintenance tasks	Numeric editor
Managing the device configuration 90	Trumeric cuitor
Manufacturer ID	0
Manufacturing date	Operable flow range
Materials	Operating elements 41, 107
Maximum measured error	Operating keys
Measured variables	see Operating elements
see Process variables	Operating menu
Measuring and test equipment	Menus, submenus
Measuring device	Structure
Configuration	Submenus and user roles
Conversion	Operating philosophy
Design	Operation
Disposal	Operation options
Mounting the sensor	Operational display
Preparing for electrical connection	Operational safety
Preparing for mounting	Order code
Removing	Orientation (vertical, horizontal) 20
-	Outlet runs
Repair 123 Switch-on 57	Output
Measuring principle	Output signal
Measuring range	Output signal
Calculation example for gas 130	P
For gases	Packaging disposal
For liquids	Parameter
Measuring range, recommended	Changing
Measuring system	Enter a value
Media	Parameter settings
Medium pressure	Administration (Submenu) 89, 117
Influence	Burst configuration 1 to 3 (Submenu) 54
Medium temperature	Configuration backup display (Submenu) 90
Influence	Current output 1 to 2 (Wizard) 64
Menu	Data logging (Submenu)
Diagnostics	Device information (Submenu)
Operation	Diagnostics (Menu)
Setup	Display (Submenu)
Menus	Display (Wizard)
For measuring device configuration 57	Low flow cut off (Wizard) 81
For specific settings	Operation (Submenu)
Mounting dimensions	Output conditioning (Wizard)
see Installation dimensions	Output values (Submenu)
Mounting location	Partially filled pipe detection (Wizard) 83
Mounting preparations	Process variables (Submenu)
Mounting preparations	Pulse/frequency/switch output (Wizard) 68, 70, 73
Inlet and outlet runs	Select medium (Submenu) 60
Installation dimensions	Sensor adjustment (Submenu)
Sensor heating	Setup (Menu)
bensor heating	- 3

152

Simulation (Submenu)	Current output
System units (Submenu) 61	Device reset
Totalizer (Submenu)	Device tag
Totalizer 1 to 3 (Submenu)	Local display
Performance characteristics	Low flow cut off
Post-connection check (checklist)	Managing the device configuration 90
Post-installation check	Medium
Post-installation check (checklist)	Operating language57
Potential equalization	Output conditioning
Power consumption	Partial filled pipe detection 83
Power supply failure	Pulse output
Pressure Equipment Directive	Pulse/frequency/switch output 67, 70
Pressure loss	Resetting the totalizer
Pressure-temperature ratings 140	Sensor adjustment
Process connections	Simulation
Process variables	Switch output
Calculated	System units 61
Measured	Totalizer
Product safety	Totalizer reset
Protecting parameter settings 93	Shock resistance
D	Showing data logging
R	Signal on alarm
Read access	SIL (functional safety)
Reading measured values	SIMATIC PDM
Recalibration	Function
Reference operating conditions	Software release
Registered trademarks	Spare part
Remedial measures	Spare parts
Calling up	Special connection instructions
Closing	Standards and guidelines
Remote operation	Status area
Repair	For operational display
Notes	In the navigation view
Repair of a device	Status signals
Repeatability	Sterilization in place (SIP)
Replacement 122	Storage conditions
Device components	Storage temperature
Response time	Storage temperature range
Return	Structure
Rupture disk	Operating menu
Safety instructions	Submenu 90, 117
Triggering pressure	Administration
ringgering pressure	Advanced setup
S	Configuration backup display
Safety	Data logging
Seals	Device information
Medium temperature range 139	Display
Sensor	Events list
Medium temperature range 139	Operation
Mounting	Output values
Sensor heating	Overview
Serial number	Process variables
Setting the operating language 57	Select medium
Settings	Sensor adjustment
Adapting the measuring device to the process	Simulation
conditions	System units 61
Administration	Totalizer
Advanced display configurations 87	Totalizer 1 to 3

Supply unit Requirements	27
Supply voltage	33
Symbols For communication	36
For correction	
	36 36
For measured variable	36
	36 38
For menus	
For status signal	36
	38 38
In the status area of the local display	
In the text and numeric editor	
System design Measuring system	29
see Measuring device design	ر ک
System integration	52
System pressure	21
T	
Technical data, overview	29
Temperature range Ambient temperature range for display 1	44
Medium temperature	
Storage temperature	
Terminal assignment	29 28
Terminals	34
	39 21
Thermal insulation	<u>4</u> 1
see Help text	
Tools Electrical connection	26
	20 23
Transport	17
Transmitter Connecting the signal cables	20
	24
Turning the housing	
Transporting the measuring device	17
General	04
Turning the display module	24
Turning the electronics housing see Turning the transmitter housing	
Turning the transmitter housing	24
U	
Use of the measuring device	
Borderline cases	
Incorrect use	9
User roles	35

V
Version data for the device52Vibration resistance139Vibrations22
W
W@M 122, 123
W@M Device Viewer
Weight
SI units
Transport (notes)
US units
Wizard
Current output 1 to 2 64
Define access code
Display
Low flow cut off
Output conditioning
Partially filled pipe detection
Pulse/frequency/switch output 68, 70, 73
Workplace safety
Write access
Write protection
Via access code
Via write protection switch
Write protection switch



