


Operating Instructions

Dosimag

Modbus RS485

Electromagnetic flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these instructions.

Table of contents

1	Document information	5		
1.1	Document function	5		
1.2	Symbols used	5		
1.2.1	Safety symbols	5		
1.2.2	Electrical symbols	5		
1.2.3	Symbols for certain types of information	5		
1.2.4	Symbols in graphics	6		
1.3	Documentation	6		
1.3.1	Standard documentation	7		
1.3.2	Supplementary device-dependent documentation	7		
1.4	Registered trademarks	7		
2	Basic safety instructions	8		
2.1	Requirements for the personnel	8		
2.2	Designated use	8		
2.3	Workplace safety	9		
2.4	Operational safety	9		
2.5	Product safety	9		
2.6	IT security	9		
3	Product description	11		
3.1	Product design	11		
4	Incoming acceptance and product identification	12		
4.1	Incoming acceptance	12		
4.2	Product identification	12		
4.2.1	Sensor nameplate	13		
4.2.2	Symbols on measuring device	14		
5	Storage and transport	15		
5.1	Storage conditions	15		
5.2	Transporting the product	15		
5.3	Packaging disposal	15		
6	Installation	16		
6.1	Installation conditions	16		
6.1.1	Mounting position	16		
6.1.2	Requirements from environment and process	19		
6.1.3	Special mounting instructions	20		
6.2	Mounting the measuring device	21		
6.2.1	Required tools	21		
6.2.2	Preparing the measuring device	21		
6.2.3	Mounting the measuring device	22		
6.2.4	Welding the sensor into the pipe (welding connections)	22		
6.2.5	Cleaning with pigs	22		
6.2.6	Seals	23		
			6.2.7	Nominal diameter and flow
			23	
			6.3	Post-installation check
			23	
7	Electrical connection	24		
7.1	Connection conditions	24		
7.1.1	Requirements for connecting cable	24		
7.1.2	Terminal assignment	24		
7.1.3	Pin assignment, device plug	25		
7.1.4	Requirements for the supply unit	28		
7.2	Connecting the measuring device	28		
7.2.1	Connecting the transmitter	28		
7.3	Ensuring the degree of protection	28		
7.4	Post-connection check	29		
8	Operation options	30		
8.1	Overview of operation options	30		
8.2	Access to the operating menu via the operating tool	30		
8.2.1	Connecting the operating tool	30		
8.2.2	FieldCare	31		
8.2.3	DeviceCare	32		
9	System integration	33		
9.1	Overview of device description files	33		
9.1.1	Current version data for the device	33		
9.1.2	Operating tools	33		
9.2	Modbus RS485 information	33		
9.2.1	Function codes	33		
9.2.2	Register information	34		
9.2.3	Response time	34		
9.2.4	Modbus data map	34		
10	Commissioning	37		
10.1	Function check	37		
10.2	Switching on the measuring device	37		
10.3	Establishing a connection via FieldCare	37		
10.4	Configuring the measuring device	37		
10.4.1	Defining the tag name	38		
10.4.2	Setting the system units	38		
10.4.3	Configuring the status input	38		
10.4.4	Configuring the switch output (batch)	39		
10.4.5	Configuring the communication interface	41		
10.4.6	Low flow cut off	42		
10.5	Advanced settings	42		
10.5.1	Sensor adjustment	43		
10.5.2	Configuring the totalizer	43		
10.6	Simulation	44		
11	Operation	45		
11.1	Reading device locking status	45		

11.2	Reading access authorization status on operating software	45	16.2	Function and system design	64
11.3	Reading measured values	45	16.3	Input	64
11.3.1	Process variables	45	16.4	Output	65
11.3.2	Totalizer	46	16.5	Power supply	67
11.3.3	Input values	46	16.6	Performance characteristics	67
11.4	Performing a totalizer reset	47	16.7	Installation	68
11.5	Batching control	48	16.8	Environment	68
12	Diagnostics and troubleshooting ...	50	16.9	Process	69
12.1	General troubleshooting	50	16.10	Mechanical construction	70
12.2	Diagnostic information in FieldCare	50	16.11	Operability	72
12.2.1	Diagnostic options	50	16.12	Certificates and approvals	73
12.2.2	Calling up remedy information	51	16.13	Accessories	74
12.3	Diagnostic information via communication interface	52	16.14	Supplementary documentation	74
12.3.1	Reading out diagnostic information ..	52	Index	76	
12.3.2	Configuring error response mode	52			
12.4	Adapting the diagnostic information	52			
12.4.1	Adapting the diagnostic behavior	52			
12.5	Overview of diagnostic information	53			
12.6	Pending diagnostic events	54			
12.7	Diagnostic list	55			
12.8	Event logbook	55			
12.8.1	Event history	55			
12.8.2	Filtering the event logbook	55			
12.8.3	Overview of information events	56			
12.9	Resetting the measuring device	56			
12.10	Device information	56			
12.11	Firmware history	58			
13	Maintenance	59			
13.1	Maintenance tasks	59			
13.1.1	Exterior cleaning	59			
13.1.2	Interior cleaning	59			
13.1.3	Replacing seals	59			
13.2	Measuring and test equipment	59			
13.3	Endress+Hauser services	59			
14	Repair	60			
14.1	General notes	60			
14.2	Spare parts	60			
14.3	Endress+Hauser services	60			
14.4	Return	60			
14.5	Disposal	60			
14.5.1	Removing the measuring device	60			
14.5.2	Disposing of the measuring device ...	61			
15	Accessories	62			
15.1	Device-specific accessories	62			
15.1.1	For the sensor	62			
15.2	Communication-specific accessories	62			
15.3	Service-specific accessories	63			
16	Technical data	64			
16.1	Application	64			





1 Document information

1.1 Document function







These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used



1.2.1 Safety symbols











Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.

1.2.2 Electrical symbols








Symbol	Meaning
	Direct current
	Alternating current
	Direct current and alternating current
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

1.2.3 Symbols for certain types of information


Symbol	Meaning
	Permitted Procedures, processes or actions that are permitted.
	Preferred Procedures, processes or actions that are preferred.

Symbol	Meaning
	Forbidden Procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Notice or individual step to be observed
	Series of steps
	Result of a step
	Help in the event of a problem
	Visual inspection


1.2.4 Symbols in graphics

Symbol	Meaning
	Item numbers
	Series of steps
	Views
	Sections
	Hazardous area
	Safe area (non-hazardous area)
	Flow direction

1.3 Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

 For a detailed list of the individual documents along with the documentation code

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Sensor Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 1 The Sensor Brief Operating Instructions are aimed at specialists with responsibility for installing the measuring device. <ul style="list-style-type: none"> ■ Incoming acceptance and product identification ■ Storage and transport ■ Installation
Transmitter Brief Operating Instructions	Guides you quickly to the 1st measured value - Part 2 The Transmitter Brief Operating Instructions are aimed at specialists with responsibility for commissioning, configuring and parameterizing the measuring device (until the first measured value). <ul style="list-style-type: none"> ■ Product description ■ Installation ■ Electrical connection ■ Operation options ■ System integration ■ Commissioning ■ Diagnostic information
Description of Device Parameters	Reference for your parameters The document provides a detailed explanation of each individual parameter in the Expert operating menu. The description is aimed at those who work with the device over the entire life cycle and perform specific configurations. The document provides Modbus-specific information for each individual parameter in the Expert operating menu.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

Modbus®

Registered trademark of SCHNEIDER AUTOMATION, INC.

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

Applicator®, FieldCare®, DeviceCare®

Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

2.2 Designated use

Application and media

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Check the nameplate to verify if the device ordered can be put to its intended use in the approval-related area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section → 6.
- ▶ Protect the measuring device permanently against corrosion from environmental influences.

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the sensor due to corrosive or abrasive fluids or from environmental conditions!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Keep within the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any

warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.


3 Product description

The device consists of a transmitter and a sensor.


The device is available as a compact version:

The transmitter and sensor form a mechanical unit.

3.1 Product design



A0026624



 1 Important components of the measuring device

1 Transmitter




2 Sensor

4 Incoming acceptance and product identification



4.1 Incoming acceptance



Are the order codes on the delivery note (1) and the product sticker (2) identical?



Are the goods undamaged?



Do the nameplate data match the ordering information on the delivery note?



Is the CD-ROM with the Technical Documentation (depends on device version) and documents present?





- If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section → 13.

4.2 Product identification


The following options are available for identification of the measuring device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.

For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" →  7 and "Supplementary device-dependent documentation" →  7
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Sensor nameplate



 2 Example of sensor nameplate

- 1 Manufacturing location
- 2 Order code: see the specifications on the order confirmation for the meanings of the individual letters and digits
- 3 Serial number
- 4 Supply voltage and power consumption
- 5 Process connection
- 6 Wetted materials
- 7 Maximum process temperature
- 8 Permitted ambient temperature range
- 9 Space reserved for additional information on the device version (approvals, certificates, etc.)
- 10 Degree of protection
- 11 Flow direction
- 12 Cable temperature
- 13 Space reserved for additional information on the device version (approvals, certificates, etc.)






Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

4.2.2 Symbols on measuring device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	Reference to documentation Refers to the corresponding device documentation.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.

Storage temperature →  68

5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
 - or
 - Carton in accordance with European Packaging Directive 94/62/EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Installation

6.1 Installation conditions

6.1.1 Mounting position

Mounting location




A0029343

Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow: $h \geq 2 \times \text{DN}$

Installation in down pipes

Install a siphon with a vent valve downstream of the sensor in down pipes whose length $h \geq 5 \text{ m}$ (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.



A0028981

3 Installation in a down pipe


1 Vent valve

2 Pipe siphon

h Length of down pipe

Installation in partially filled pipes





A partially filled pipe with a gradient necessitates a drain-type configuration.



A0029257


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

Orientation			Recommendation
A	Vertical orientation	 A0015591	✓✓
B	Horizontal orientation, transmitter at top	 A0015589	✓✓ ¹⁾
C	Horizontal orientation, transmitter at bottom	 A0015590	✓✓ ^{2) 3)}
D	Horizontal orientation, transmitter at side	 A0015592	✗

- 1) Applications with low process temperatures may decrease the ambient temperature. To maintain the minimum ambient temperature for the transmitter, this orientation is recommended.
- 2) Applications with high process temperatures may increase the ambient temperature. To maintain the maximum ambient temperature for the transmitter, this orientation is recommended.
- 3) To prevent the electronics module from overheating in the case of a sharp rise in temperature (e.g. CIP- or SIP processes), install the device with the transmitter component pointing downwards.

Horizontal




1 Measuring electrodes for signal detection

i Ideally, the measuring electrode plane should be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.

Valves

Never install the sensor downstream from a filling valve. If the sensor is completely empty this corrupts the measured value.

i Correct measurement is only possible if the pipe is completely full. Perform sample fillings before commencing filling in production.




A0003768

- 1 Measuring device
2 Filling valve
3 Container

Filling systems

The pipe system must be completely full to ensure optimum measurement.




A0003795

- 4 Filling system
1 Measuring device
2 Filling valve
3 Container

Inlet and outlet runs


If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:




A0028997

Installation dimensions


 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section.


6.1.2 Requirements from environment and process

Ambient temperature range


Transmitter	-40 to +60 °C (-40 to +140 °F)
Sensor	-40 to +60 °C (-40 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner →  69.

Temperature tables

 Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.

 For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.





System pressure




A0028777

Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.

 Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

-  ■ For information on the liner's resistance to partial vacuum →  70
- For information on the shock resistance of the measuring system →  69
- For information on the vibration resistance of the measuring system →  69

Vibrations



A0029004

 5 Measures to avoid device vibrations (L > 10 m (33 ft))

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.



- For information on the shock resistance of the measuring system → 69
- For information on the vibration resistance of the measuring system → 69


Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



The nomogram only applies to liquids with a viscosity similar to that of water.


1. Calculate the ratio of the diameters d/D .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.



6.1.3 Special mounting instructions


Information for filling systems

Correct measurement is possible only if the piping is completely filled. We therefore recommend that some test batches be carried out prior to production batching.

Circular filling system

A0003761

- 1 Tank
- 2 Measuring device
- 3 Batching valve
- 4 Vessel

Linear filling system

A0003762

- 1 Tank
- 2 Measuring device
- 3 Batching valve
- 4 Vessel

6.2 Mounting the measuring device**6.2.1 Required tools****For sensor**

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.

2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.

6.2.3 Mounting the measuring device

WARNING

Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Install the gaskets correctly.

Depending on the order option, the measuring device is supplied with or without pre-installed process connections. Pre-installed process connections are secured to the measuring device using 4 hexagonal-headed bolts.

- ▶ Ensure that the direction of the arrow on the nameplate of the sensor matches the flow direction of the fluid.


 Depending on the application and pipe length, the measuring device may need to be supported or additionally secured.


6.2.4 Welding the sensor into the pipe (welding connections)

WARNING

Risk of destroying the electronics!

- ▶ Make sure that the welding system is not grounded via the sensor or transmitter.

1. Tack-weld the sensor to secure it in the pipe. A suitable welding jig can be ordered separately as an accessory →  74.
2. Release the screws on the process connection flange and remove the sensor, along with the seal, from the pipe.
3. Weld the process connection into the pipe.
4. Reinstall the sensor in the pipe, and in doing so make sure that the seal is clean and in the right position.

- 
 - If thin-walled pipes carrying food are welded correctly, the seal is not damaged by the heat even when mounted. However, it is recommended to disassemble the sensor and seal.
 - It must be possible to open the pipe by approx. 8 mm (0.31 in).

6.2.5 Cleaning with pigs

It is essential to take the internal diameters of the measuring tube and process connection into account when cleaning with pigs. All the dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document.

6.2.6 Seals

When mounting the process connections, make sure that the seals in question are dry, clean, undamaged and correctly centered.



- The screws must be firmly tightened. The process connection forms a metal connection with the sensor, which ensures a defined compression of the seal.
- Depending on the application the seals should be replaced periodically, particularly if molded seals are used (aseptic version)!
The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.
Replacement seals can be ordered as an accessory.

6.2.7 Nominal diameter and flow

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum flow velocity is between 1 to 4 m/s (3.28 to 13.12 ft/s). The velocity of flow (v), moreover, has to be matched to the physical properties of the fluid:

- $v < 2$ m/s (6.56 ft/s): For abrasive media such as cleaning agents etc.
- $v > 2$ m/s (6.56 ft/s): For media that produce buildup, such as oil and liquids that contain sugar



A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.




Flow characteristic values → 64

6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> ▪ Process temperature ▪ Process pressure → 70 ▪ Ambient temperature → 68 ▪ Measuring range 	<input type="checkbox"/>
Horizontal position of the measuring electrode plane?	<input type="checkbox"/>
Has the correct orientation for the sensor been selected ? <ul style="list-style-type: none"> ▪ According to sensor type ▪ According to medium temperature ▪ According to medium properties (outgassing, with entrained solids) 	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the measuring device adequately protected against vibration (attachment, support)?	<input type="checkbox"/>
Are the inlet and outlet runs respected? → 18	<input type="checkbox"/>

7 Electrical connection

 The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.



Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40 °C (-40 °F) to $+80\text{ °C}$ ($+176\text{ °F}$)
- Minimum requirement: cable temperature range \geq ambient temperature $+20\text{ K}$


Signal cable

 Cables are not included in the scope of delivery; they can be ordered as an accessory →  62.

Status input and switch output (batch)

Standard installation cable is sufficient.

Modbus RS485

-  The electrical connection of the shield to the device housing must be properly implemented (e.g. using a knurled nut).
- Observe the following with regard to cable loading:
 - Voltage drop due to the cable length and cable type.
 - Valve performance.

Total length of cable in the Modbus network $\leq 50\text{ m}$

Use a shielded cable.

Example:

Terminated device plug with cable: Lumberg RKWTH 8-299/10

Total length of cable in the Modbus network $> 50\text{ m}$

Use shielded twisted pair cable for RS485 applications.




Example:

- Cable: Belden item no. 9842 (for 4-wire version, the same cable can be used for the power supply)
- Terminated device plug: Lumberg RKCS 8/9 (shieldable version)

7.1.2 Terminal assignment

Connection is solely by means of device plug:


There are different device versions available. Order code for "Output, input":

- Option 4: Modbus RS485, 1 status output (batch), 1 status input →  25
- Option 5: Modbus RS485, 2 status outputs (batch), 1 status input →  26
- Option 6: Modbus RS485 (custody transfer mode) →  27

7.1.3 Pin assignment, device plug

Device version: Modbus RS485, status output and status input

Order code for "Output, input", option 4:
Modbus RS485, 1 switch output (batch), 1 status input



6 Connection to device


- A Coupling: Supply voltage, Modbus RS485
- B Connector: Supply voltage, Modbus RS485
- C Coupling: Switch output (batch), status input
- D Connector: Switch output (batch), status input
- E PELV or SELV power supply
- V1 Valve 1 (batch)
- 1 to 8 Pin assignment

Pin assignment

Connection: Coupling (A) – Connector (B)			Connection: Coupling (C) – Connector (D)		
Pin	Assignment		Pin	Assignment	
1	L+	Supply voltage	1	+	Status input
2	+	Service interface RX	2	–	Status input
3	+	Service interface TX	3	–	Switch output (batch)
4	L-	Supply voltage	4	+	Switch output (batch)
5	Not assigned		5	Not assigned	
6	A	Modbus RS485			
7	B	Modbus RS485			
8	–	Service interface GND			

Device version: Modbus RS485 , 2 status outputs and status input

Order code for "Output, input", option 5:
Modbus RS485, 2 switch outputs (batch), 1 status input



A0032571

7 Connection to device


- A Coupling: Supply voltage, Modbus RS485
- B Connector: Supply voltage, Modbus RS485
- C Coupling: Switch outputs (batch), status input
- D Connector: Switch outputs (batch), status input
- E PELV or SELV power supply
- V1 Valve (batch), level 1
- V2 Valve (batch), level 2
- 1 to Pin assignment
- 8

Pin assignment

Connection: Coupling (A) – Connector (B)			Connection: Coupling (C) – Connector (D)		
Pin	Assignment		Pin	Assignment	
1	L+	Supply voltage	1	+	Status input
2	+	Service interface RX	2	+	Switch output (batch) 2
3	+	Service interface TX	3	–	Switch outputs, status input
4	L-	Supply voltage	4	+	Switch output (batch) 1
5	Not assigned		5	Not assigned	
6	A	Modbus RS485			
7	B	Modbus RS485			
8	–	Service interface GND			

Device version: Modbus RS485 (custody transfer mode)

Order code for "Output, input", option 6 (device version for custody transfer mode):
Modbus RS485



A0032572

8 Connection to device

- A Coupling: Supply voltage, Modbus RS485
- B Connector: Supply voltage, Modbus RS485
- C Coupling at device
- D Connector: Dongle (hardware write protection for custody transfer mode)
- E PELV or SELV power supply


Pin assignment

Connection: Coupling (A) – Connector (B)			Connection: Coupling (C) – Connector (D)	
Pin	Assignment		Pin	Assignment
1	L+	Supply voltage	1	NC
2	+	Service interface RX	2	NC
3	+	Service interface TX	3	NC
4	L-	Supply voltage	4	+
5	Not assigned		5	-
6	A	Modbus RS485		
7	B	Modbus RS485		
8	-	Service interface GND		

7.1.4 Requirements for the supply unit

Supply voltage

DC 24 V (nominal voltage: DC 20 to 30 V)

-  The power unit must be tested to ensure that it meets safety requirements (e.g. PELV, SELV).
- The supply voltage must not exceed a maximum short-circuit current of 50 A.

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.

7.2.1 Connecting the transmitter

Connection by means of device plug

Connection is solely by means of device plug.




A0032534

A, C Coupling
B, D Plug

Grounding

Grounding is by means of a cable socket.



A0003838


7.3 Ensuring the degree of protection

The measuring device fulfills all the requirements for IP67 degree of protection, Type 4X enclosure.

To guarantee IP67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:


- Tighten all device plugs.

7.4 Post-connection check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the supply voltage in the system match the specifications on the device's nameplate?	<input type="checkbox"/>
Do the cables used comply with the necessary specifications?	<input type="checkbox"/>
Are the maximum values for voltage and current at the pulse and status output being observed? →  65	<input type="checkbox"/>

8 Operation options

8.1 Overview of operation options



A0017760

- 1 Computer with "FieldCare" or "DeviceCare" operating tool
2 Control system (e.g. PLC)


8.2 Access to the operating menu via the operating tool

8.2.1 Connecting the operating tool

Using the service adapter and Commubox FXA291

Operation and configuration can be performed using the Endress+Hauser FieldCare or DeviceCare service and configuration software.

The device is connected to the USB port of the computer via the service adapter and Commubox FXA291.



A0032567

- 1 Supply voltage 24 V DC
2 Service adapter
3 Dosimag
4 Commubox FXA291
5 Computer with "FieldCare" or "DeviceCare" operating tool



The service adapter, cable and Commubox FXA291 are not included in the delivery. These components can be ordered as accessories → 62.

8.2.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access is via:

Service adapter and Commubox FXA291

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook



For additional information about FieldCare, see Operating Instructions BA00027S and BA00059S

Source for device description files

See information →  33

Establishing a connection


Service adapter, Commubox FXA291 and "FieldCare" operating tool

1. Start FieldCare and launch the project.
2. In the network: Add a device.
 - ↳ The **Add device** window opens.
3. Select the **CDI Communication FXA291** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication FXA291** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
6. Establish the online connection to the device.



For additional information, see Operating Instructions BA00027S and BA00059S

User interface



A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Tag name
- 5 Status area with status signal
- 6 Display area for current measured values
- 7 Edit toolbar with additional functions such as save/restore, event list and create documentation
- 8 Navigation area with operating menu structure
- 9 Working area
- 10 Range of action
- 11 Status area

8.2.3 DeviceCare

Function scope

Tool to connect and configure Endress+Hauser field devices.

The fastest way to configure Endress+Hauser field devices is with the dedicated "DeviceCare" tool. Together with the device type managers (DTMs) it presents a convenient, comprehensive solution.



For details, see Innovation Brochure IN01047S

Source for device description files

See information → 33

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	03.00.zz	<ul style="list-style-type: none"> On the title page of the Operating instructions On transmitter nameplate Firmware version Diagnostics menu → Device information submenu → Firmware version parameter
Release date of firmware version	05.2015	---



For an overview of the different firmware versions for the device → 58

9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.




Operating tool	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)
DeviceCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)


9.2 Modbus RS485 information

9.2.1 Function codes


Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:

Code	Name	Description	Application
03	Read holding register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	Read device parameters with read and write access Example: Read volume flow
04	Read input register	Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.	Read device parameters with read access Example: Read totalizer value

Code	Name	Description	Application
06	Write single registers	Master writes a new value to one Modbus register of the measuring device.  Use function code 16 to write multiple registers with just 1 telegram.	Write only 1 device parameter Example: reset totalizer
08	Diagnostics	Master checks the communication connection to the measuring device. The following "Diagnostics codes" are supported: <ul style="list-style-type: none"> ▪ Sub-function 00 = Return query data (loopback test) ▪ Sub-function 02 = Return diagnostics register 	
16	Write multiple registers	Master writes a new value to multiple Modbus registers of the device. A maximum of 120 consecutive registers can be written with 1 telegram.  If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map →  34	Write multiple device parameters
23	Read/Write multiple registers	Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram. Write access is executed before read access.	Write and read multiple device parameters Example: <ul style="list-style-type: none"> ▪ Read mass flow ▪ Reset totalizer

 Broadcast messages are only allowed with function codes 06, 16 and 23.

9.2.2 Register information

 For an overview of Modbus-specific information relating to the individual device parameters: Description of device parameters.

9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to 5 ms

9.2.4 Modbus data map

Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.

Structure of the Modbus data map

The Modbus data map consists of two data sets:

- **Scan list: Configuration area**

The device parameters to be grouped are defined in a list in that their Modbus RS485 register addresses are entered in the list.

- **Data area**

The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.



For an overview of device parameters with their individual Modbus register address, please refer to the additional document on Modbus RS485 register information

Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

Max. entries	16 device parameters
Supported device parameters	Only parameters with the following characteristics are supported: <ul style="list-style-type: none"> ■ Access type: read or write access ■ Data type: float or integer

Configuring the scan list via FieldCare

Carried out using the operating menu of the measuring device:

Expert → Communication → Modbus data map → Scan list register 0 -15

Scan list	
No.	Configuration register
0	Scan list register 0
...	...
15	Scan list register 15

Configuring the scan list via Modbus RS485

Carried out using register addresses 5001 - 5016

Scan list			
No.	Modbus RS485 register	Data type	Configuration register
0	5001	Integer	Scan list register 0
...	...	Integer	...
15	5016	Integer	Scan list register 15

Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.



Master access to data area	Via register addresses 5051-5081
-----------------------------------	----------------------------------

Data area			
Device parameter value	Modbus RS485 register	Data type*	Access**
Value of scan list register 0	5051	Integer/float	Read/write
Value of scan list register 1	5053	Integer/float	Read/write
Value of scan list register
Value of scan list register 15	5081	Integer/float	Read/write
* Data type depends on the device parameters entered in the scan list.			
** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area.			

10 Commissioning

10.1 Function check


Before commissioning the measuring device:

- ▶ Make sure that the post-installation and post-connection checks have been performed.
- "Post-installation check" checklist →  23
- "Post-connection check" checklist →  29



10.2 Switching on the measuring device

- ▶ The function check has been completed successfully.
Switch on the supply voltage.
 - ↳ The measuring device runs through internal test functions.

The device is operational and operation commences.

 If the device does not start up successfully, depending on the cause, a diagnostic message is displayed in the system asset management tool "FieldCare".


10.3 Establishing a connection via FieldCare

- For FieldCare connection
- For establishing a connection via FieldCare →  31
- For FieldCare user interface →  32

10.4 Configuring the measuring device

The **Setup** menu with its submenus contains all the parameters needed for standard operation.

Navigation
"Setup" menu



10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

- 
- The number of characters displayed depends on the characters used.
 - Enter the tag name in the "FieldCare" operating tool →  32

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).	Dosimag

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation

"Setup" menu → System units

► System units

Volume flow unit

Volume unit

Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none">▪ Low flow cut off▪ Simulation process variable	Unit choose list	Country-specific: <ul style="list-style-type: none">▪ ml/s▪ fl oz/s (us)
Volume unit	Select volume unit.	Unit choose list	Country-specific: <ul style="list-style-type: none">▪ ml▪ fl oz (us)

10.4.3 Configuring the status input

The **Status input** submenu guides you systematically through all the parameters that have to be set for configuring the input.

Navigation

"Setup" menu → Status input

Structure of the submenu**Parameter overview with brief description**

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign status input	Start condition for a batching process: <ul style="list-style-type: none"> There is no diagnostic message from the Alarm category. The batch quantity must be > 0. The Batching option is selected in the Switch output function parameter. 	Select function for the status input.	<ul style="list-style-type: none"> Off Start batch Start & stop batch Reset totalizer 1 Reset totalizer 2 Reset totalizer 3 Reset all totalizers Flow override 	Off
Active level	–	Define input signal level at which the assigned function is triggered.	<ul style="list-style-type: none"> High Low 	High
Response time status input	–	Define the minimum amount of time the input signal level must be present before the selected function is triggered.	10 to 200 ms	50 ms


10.4.4 Configuring the switch output (batch)

A batch profile (1 to 6) can be assigned to the switch output (batch) in the **Batch output** submenu.

The individual batch profiles are configured in the **Settings batch profile 1 to n** submenu.

Navigation

"Setup" menu → Batch output



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Batch profile	Select suitable profile for fluid configured by customer.	<ul style="list-style-type: none"> ■ Profile 1 ■ Profile 2 ■ Profile 3 ■ Profile 4 ■ Profile 5 ■ Profile 6 	Profile 1

Batch profile settings

The **Settings batch profile 1 to n** submenu contains all the parameters that must be set for configuration of the batch profiles.

Navigation

"Setup" menu → Batch output → Settings batch profile 1 to n

▶ Settings batch profile 1 to n



Input selector

Batch unit

Batch quantity

Drip correction mode

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Input selector	–	Select a process variable for batch profile.	<ul style="list-style-type: none"> ■ Off ■ Volume flow 	Volume flow
Batch unit	One of the following options is selected in the Input selector parameter: Volume flow	Select unit for process variable of the batch profile. <i>Result</i>  The selected unit applies for: <ul style="list-style-type: none"> ■ Batch quantity ■ Fixed compensation quantity ■ Batch unit 	Unit choose list	Depending on country: <ul style="list-style-type: none"> ■ ml ■ fl oz (us)
Batch quantity	One of the following options is selected in the Input selector parameter: Volume flow	Enter a quantity of selected process variable for batch profile. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Positive floating-point number	Depending on country: <ul style="list-style-type: none"> ■ 0 ml ■ 0 fl oz (us)
Drip correction mode	One of the following options is selected in the Input selector parameter: Volume flow	Select a drip correction.	<ul style="list-style-type: none"> ■ Off ■ Fixed time ■ Fixed time or low flow cut off 	Off

10.4.5 Configuring the communication interface

The **Communication** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication

► Communication

Bus address

Baudrate

Data transfer mode

Parity

Byte order

Assign diagnostic behavior

Failure mode

Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Bus address	Enter device address.	1 to 247	247
Baudrate	Define data transfer speed.	<ul style="list-style-type: none"> ■ 1200 BAUD ■ 2400 BAUD ■ 4800 BAUD ■ 9600 BAUD ■ 19200 BAUD ■ 38400 BAUD ■ 57600 BAUD ■ 115200 BAUD 	19200 BAUD
Data transfer mode	Select data transfer mode.	<ul style="list-style-type: none"> ■ ASCII ■ RTU 	RTU
Parity	Select parity bits.	Picklist ASCII option: <ul style="list-style-type: none"> ■ 0 = Even option ■ 1 = Odd option Picklist RTU option: <ul style="list-style-type: none"> ■ 0 = Even option ■ 1 = Odd option ■ 2 = None / 1 stop bit option ■ 3 = None / 2 stop bits option 	Even
Byte order	Select byte transmission sequence.	<ul style="list-style-type: none"> ■ 0-1-2-3 ■ 3-2-1-0 ■ 1-0-3-2 ■ 2-3-0-1 	1-0-3-2

Parameter	Description	User entry / Selection	Factory setting
Assign diagnostic behavior	Select diagnostic behavior for MODBUS communication.	<ul style="list-style-type: none"> ■ Off ■ Alarm or warning ■ Warning ■ Alarm 	Alarm
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication. NaN ¹⁾	<ul style="list-style-type: none"> ■ NaN value ■ Last valid value 	NaN value

1) Not a Number

10.4.6 Low flow cut off

The **Low flow cut off** submenu contains the parameters that must be set in order to configure the low flow cut off.

Navigation

"Setup" menu → Low flow cut off

▶ Low flow cut off

Assign process variable

On value low flow cutoff

Off value low flow cutoff

Pressure shock suppression

Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	–	Select process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Volume flow 	Volume flow
On value low flow cutoff	In the Assign process variable parameter (→ 42), the Volume flow option is selected.	Enter on value for low flow cut off.	Signed floating-point number	Depends on country and nominal diameter
Off value low flow cutoff	In the Assign process variable parameter (→ 42), the Volume flow option is selected.	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	In the Assign process variable parameter (→ 42), the Volume flow option is selected.	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s

10.5 Advanced settings

The **Advanced setup** submenu together with its submenus contains parameters for specific settings.

Navigation
"Setup" menu → Advanced setup

► Advanced setup

Enter access code

► Sensor adjustment → 43

► Totalizer 1 to n → 43

► Administration → 56

10.5.1 Sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation
"Setup" menu → Advanced setup → Sensor adjustment

► Sensor adjustment

Installation direction

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<div><div>■ Flow in arrow direction</div><div>■ Flow against arrow direction</div></div>	Flow in arrow direction

10.5.2 Configuring the totalizer

The totalizer in question can be configured in the **Totalizer 1 to n** submenu.

Navigation
"Setup" menu → Advanced setup → Totalizer 1 to n

► Totalizer 1 to n

Assign process variable

Volume unit

Totalizer operation mode

Failure mode

Parameter overview with brief description


Parameter	Prerequisite	Description	Selection	Factory setting
Assign process variable	–	Select process variable for totalizer.	<ul style="list-style-type: none"> Off Volume flow 	Volume flow
Volume unit	The Volume flow option is selected in the Assign process variable parameter (→ 44) of the Totalizer 1 to n submenu.	Select volume unit.	Unit choose list	Depending on country: <ul style="list-style-type: none"> ml fl oz (us)
Totalizer operation mode	In the Assign process variable parameter (→ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Select totalizer calculation mode.	<ul style="list-style-type: none"> Net flow total Forward flow total Reverse flow total 	Net flow total
Failure mode	In the Assign process variable parameter (→ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Define totalizer behavior in alarm condition.	<ul style="list-style-type: none"> Stop Actual value Last valid value 	Stop

10.6 Simulation

The **Simulation** submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu → Simulation



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> Off Volume flow 	Off
Value process variable	In the Assign simulation process variable parameter (→ 44), the Volume flow option is selected.	Enter the simulation value for the selected process variable.	Depends on the process variable selected	0
Simulation device alarm	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> Off On 	Off

11 Operation

11.1 Reading device locking status

Device active write protection: **Locking status** parameter

Navigation

"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
Temporarily locked	Write access to the parameters is temporarily lock due to device-internal processing (e.g. data upload/download, reset). Once the internal processing has been completed, the parameters can be changed once again.

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Locking status	Indicates the write protection with the highest priority that is currently active.	Temporarily locked	Temporarily locked

11.2 Reading access authorization status on operating software

Displaying active access authorization: **Access status tooling** parameter

Navigation

"Operation" menu → Access status tooling

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Access status tooling	Shows the access authorization to the parameters via the operating tool.	<ul style="list-style-type: none"> ■ Operator ■ Maintenance 	Maintenance

11.3 Reading measured values

With the **Measured values** submenu, it is possible to read all the measured values.

11.3.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables

► Process variables

Volume flow

Parameter overview with brief description

Parameter	Description	User interface
Volume flow	Displays the volume flow currently measured. <i>Dependency</i> The unit is taken from the Volume flow unit parameter	Signed floating-point number

11.3.2 Totalizer

The **Totalizer** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer

► Totalizer

Totalizer value 1 to n

Totalizer overflow 1 to n

Parameter overview with brief description


Parameter	Prerequisite	Description	User interface
Totalizer value	In the Assign process variable parameter (→ ⓘ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Displays the current totalizer counter value.	Signed floating-point number
Totalizer overflow	In the Assign process variable parameter (→ ⓘ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Displays the current totalizer overflow.	Integer with sign

11.3.3 Input values

The **Input values** submenu guides you systematically to the individual input values.

Navigation

"Diagnostics" menu → Measured values → Input values

Structure of the submenu**Parameter overview with brief description**

Parameter	Description	User interface
Value status input	Shows the current input signal level.	<ul style="list-style-type: none"> ■ High ■ Low

11.4 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:

- Control Totalizer
- Reset all totalizers

Function scope of the "Control Totalizer" parameter


Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in the Preset value parameter and the totaling process is restarted.
Hold	Totalizing is stopped.

Function scope of the "Reset all totalizers" parameter


Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totalized.

Navigation

"Operation" menu → Totalizer handling



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Control Totalizer	In the Assign process variable parameter (→ ⓘ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Control totalizer value.	<ul style="list-style-type: none">■ Totalize■ Reset + hold■ Preset + hold■ Reset + totalize■ Preset + totalize	Totalize
Preset value	In the Assign process variable parameter (→ ⓘ 44) of the Totalizer 1 to n submenu, the Volume flow option is selected.	Specify start value for totalizer. <i>Dependency</i>  The unit of the selected process variable is specified for the totalizer in the Assign process variable parameter. If the following is selected in the Assign process variable parameter: Volume flow option: Volume flow unit parameter	Signed floating-point number	Country-specific: <ul style="list-style-type: none">■ 0 m³■ 0 ft³
Reset all totalizers	–	Reset all totalizers to 0 and start.	<ul style="list-style-type: none">■ Cancel■ Reset + totalize	Cancel

11.5 Batching control

The **Batching** submenu contains all the parameters required for batching control.

Navigation

"Operation" submenu → Batching

► Batching

Batch control

Batch counter

Quantity last batch

Quantity last drip

Current drip correction quantity

Overall batching quantity

Overflow number overall batch.
quantity





Switch output function 1

Switch status 1

Switch output function 2

Switch status 2
Reset overall batching quantity


Parameter overview with brief description

Parameter	Description	Selection / User interface	Factory setting
Batch control	Switch the batch on and off.	<ul style="list-style-type: none"> Start Stop 	Stop
Batch counter	Shows number of passed batch procedures.	Positive integer	–
Quantity last batch	Shows total quantity of last batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Quantity last drip	Shows drip quantity of last batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Current drip correction quantity	Shows the drip correction quantity of current batch. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Overall batching quantity	Shows the total quantity of all passed batch procedures of current profile. <i>Dependency</i>  The unit is taken from: Batch unit parameter	Signed floating-point number	–
Overflow number overall batch. quantity	Shows how often an overflow of the overall batching quantity has occurred.	–32 000.0 to 32 000.0	–
Switch output function 1 to n	Select function for the switch output.	<ul style="list-style-type: none"> Close Open Batching 	<ul style="list-style-type: none"> Batching (Switch output function 1) Open (Switch output function 2)
Switch status 1 to n	Display the current status of the switch output.	<ul style="list-style-type: none"> Closed Open 	–
Reset overall batching quantity	Reset the total quantity of all passed batch procedures to 0.	<ul style="list-style-type: none"> Reset Cancel 	Cancel

12 Diagnostics and troubleshooting

12.1 General troubleshooting


For access

Problem	Possible causes	Remedy
No write access to parameters	Current user role has limited access authorization	Check access authorization status .
No connection via Modbus RS485	Device plug connected incorrectly	Check the pin assignment of the device plug .
No connection via Modbus RS485	Modbus RS485 cable incorrectly terminated	Check the terminating resistor .
No connection via Modbus RS485	Incorrect settings for the communication interface	Check the Modbus RS485 configuration .
No connection via service adapter	Incorrect configuration of USB interface on PC or driver not installed correctly.	Observe the documentation for the Commubox.  FXA291: Document "Technical Information" TI00405C


12.2 Diagnostic information in FieldCare


12.2.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.



A0021799-EN


- 1 Status area with status signal
- 2 Diagnostic information →  51
- 3 Remedy information with Service ID

 Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameter
- Via submenu →  55

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



12.2.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.

1. Call up the desired parameter.



2. On the right in the working area, mouse over the parameter.
 - A tool tip with remedy information for the diagnostic event appears.

12.3 Diagnostic information via communication interface

12.3.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270

 For an overview of diagnostic events with diagnosis number and diagnosis code
→  53



12.3.2 Configuring error response mode

Error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

Navigation path

"Setup" menu → Communication

Parameter overview with brief description

Parameter	Description	Options	Factory setting
Assign diagnostic behavior	Select diagnostic behavior for MODBUS communication.	<ul style="list-style-type: none"> ■ Off ■ Alarm or warning ■ Warning ■ Alarm 	Alarm
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication.  This parameter operates in accordance with the option selected in the Assign diagnostic behavior parameter.	<ul style="list-style-type: none"> ■ NaN value ■ Last valid value  NaN ≡ not a number	NaN value

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior


Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic behavior** submenu.

Expert → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. Measured value output via Modbus RS485 and totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	Measurement is resumed. Measured value output via Modbus RS485 and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

12.5 Overview of diagnostic information

 In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Change the diagnostic information →  52



Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of sensor				
004	Sensor	1. Change sensor 2. Contact service	S	Alarm
062	Sensor connection	1. Check sensor connections 2. Contact service	F	Alarm
082	Data storage	1. Check module connections 2. Contact service	F	Alarm
083	Memory content	1. Restart device 2. Contact service	F	Alarm
Diagnostic of electronic				
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
281	Electronic initialization	Firmware update active, please wait!	F	Alarm
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
322	Electronic drift	1. Perform verification manually 2. Change electronic	S	Warning
Diagnostic of configuration				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning



Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
442	Frequency output 1 to n	1. Check process 2. Check frequency output settings	S	Warning ¹⁾
443	Pulse output 1 to n	1. Check process 2. Check pulse output settings	S	Warning ¹⁾
453	Flow override	Deactivate flow override	C	Warning
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
500	Electrode difference voltage too high	1. Check process cond. 2. Increase system pressure	F	Alarm
Diagnostic of process				
832	Electronic temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Electronic temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾
937	EMC interference	Change main electronic module	S	Warning ¹⁾
938	EMC interference	1. Check ambient conditions regarding EMC influence 2. Change main electronic module	F	Alarm
991	Batch time exceeded	Check process conditions	F	Warning ¹⁾
991	Maximum flow rate exceeded		F	Warning ¹⁾

1) Diagnostic behavior can be changed.

12.6 Pending diagnostic events

The **Diagnostics** menu provides the option of displaying the current and previous diagnostic event separately.

 To call up the measures to rectify a diagnostic event:
Via the DeviceCare and FieldCare operating tool →  51

 Other pending diagnostic events can be displayed in the **Diagnostic list** submenu
→  55

Navigation


"Diagnostics" menu

Structure of the submenu

Diagnostics	→	Actual diagnostics
--------------------	---	--------------------

Previous diagnostics

Parameter overview with brief description



Parameter	Prerequisite	Description	User interface
Actual diagnostics	A diagnostic event has occurred.	Shows the current occurred diagnostic event along with its diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.
Previous diagnostics	Two diagnostic events have already occurred.	Shows the diagnostic event that occurred prior to the current diagnostic event along with its diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.

12.7 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.



Navigation path

Diagnostics menu → **Diagnostic list** submenu

 To call up the measures to rectify a diagnostic event:
Via "FieldCare" operating tool →  51

12.8 Event logbook

12.8.1 Event history

 To call up the measures to rectify a diagnostic event:
Via "FieldCare" operating tool →  51

 For filtering the displayed event messages →  55

12.8.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1151	History reset

12.9 Resetting the measuring device

The device can be reset in the **Administration** submenu.

Navigation

"Expert" menu → System → Administration

► Administration

Device reset

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Reset the device configuration - either entirely or in part - to a defined state.	<ul style="list-style-type: none">■ Cancel■ To delivery settings■ Restart device	Cancel

12.10 Device information

The **Device information** submenu contains all parameters that display different information for device identification.

Navigation

"Diagnostics" menu → Device information

► Device information

Device tag






Serial number

Firmware version

Device name

Order code
Extended order code 1
Extended order code 2
Extended order code 3
ENP version

Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Device tag	Display the name for the measuring point.	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)	Dosimag
Serial number	Shows the serial number of the measuring device.	A maximum of 11-digit character string comprising letters and numbers.	–
Firmware version	Shows the device firmware version installed.	Character string with the following format: xx.yy.zz	03.00
Device name	Shows the name of the transmitter.  The name can be found on the nameplate of the transmitter.	Dosimag	–
Order code	Shows the device order code.  It can be found in the "Order code" field on the nameplate.	Character string composed of letters, numbers and certain punctuation marks (e.g. /).	–
Extended order code 1	Shows the 1st part of the extended order code.  It can be found in the "Ext. ord. cd." field on the nameplate.	Character string	–
Extended order code 2	Shows the 2nd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
Extended order code 3	Shows the 3rd part of the extended order code.  The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.	Character string	–
ENP version	Shows the version of the electronic nameplate (ENP).		2.02.00

12.11 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
09.2015	03.00.zz	Option A	No change in firmware	Operating Instructions	BA01321D/06/EN/02.15
08.2014	03.00.zz	Option A	<ul style="list-style-type: none"> ■ Original firmware ■ Can be operated via FieldCare and DeviceCare 	Operating Instructions	BA01321D/06/EN/01.14



For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.



The manufacturer's information is available:

- In the Downloads area of the Endress+Hauser web site: www.endress.com → Downloads
- Specify the following details:
 - Product root: e.g. 5RH
 - Text search: Manufacturer's information
 - Media type: Documentation – Technical Documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

13.1.2 Interior cleaning


Observe the following points for CIP and SIP cleaning:

- Use only cleaning agents to which the process-wetted materials are adequately resistant.
- Observe the maximum permitted medium temperature for the measuring device .

13.1.3 Replacing seals


The sensor's seals (particularly aseptic molded seals) must be replaced periodically.


The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory part) →  62

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring device cannot be converted.
- If the measuring device is defective, the entire device is replaced.
- It is possible to replace seals.

Information on replacing wear parts (seals)

Please note the following when replacing wear parts:

- Use only original Endress+Hauser spare parts.
- Replace the part according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts

W@M Device Viewer (www.endress.com/deviceviewer):

All the spare parts for the measuring device, along with the order code, are listed here and can be ordered. If available, users can also download the associated Installation Instructions.



Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu → 56.

14.3 Endress+Hauser services

Endress+Hauser offers a wide range of services.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at

<http://www.endress.com/support/return-material>

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.

2. ⚠ WARNING**Danger to persons from process conditions.**

- Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device**⚠ WARNING****Danger to personnel and environment from fluids that are hazardous to health.**

- Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories




Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories




15.1.1 For the sensor

Accessories	Description	Order code
Seal set	For regular replacement of the seals on the process connections.	DK5G**.*
Housing seal	To seal the transmitter	50102857
Mounting set	Consists of: <ul style="list-style-type: none"> 2 process connections Screws Seals 	DKH**.*

15.2 Communication-specific accessories

Accessories	Description
FieldCare	FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.  For details, see Operating Instructions BA00027S and BA00059S
DeviceCare	Tool for connecting and configuring Endress+Hauser field devices.  For details, see Innovation brochure IN01047S
Commubox FXA291	Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.  For details, see the "Technical Information" document TI405C/07
Adapter connection	Adapter connections for installation on other electrical connections: <ul style="list-style-type: none"> Adapter FXA291 (order number: 71035809) Adapter RSE8 (order number: 50107169) RSE8 connection jack, 8-pin adapter (RSE8), 24 V DC, pulse, status Adapter RSE5 (order number: 50107168) RSE8 connection jack, 5-pin adapter (RSE5), 24 V DC, pulse, status Adapter RSE4 (order number: 50107167) RSE8 connection jack, 4-pin adapter (RSE4), 24 V DC, pulse
Connecting cable RSE8	Cable RKWTN8-56/5 P92, length: 5 m (Order number: 50107895)

15.3 Service-specific accessories

Accessories	Description
Applicator	<p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> ■ Calculation of all data required to determine the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. ■ Graphic illustration of the calculation results <p>Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project.</p> <p>Applicator is available:</p> <ul style="list-style-type: none"> ■ Via the Internet: https://wapps.endress.com/applicator ■ On CD-ROM for local PC installation.
W@M	<p>Life cycle management for your plant</p> <p>W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant information is available for every measuring device over time entire life cycle, such as the Device status, spare parts, device-specific documentation.</p> <p>The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records.</p> <p>W@M is available:</p> <ul style="list-style-type: none"> ■ Via the Internet: www.endress.com/lifecyclemanagement ■ On CD-ROM for local PC installation.
FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> For details, see Operating Instructions BA00027S and BA00059S</p>
DeviceCare	<p>Tool for connecting and configuring Endress+Hauser field devices.</p> <p> For details, see Innovation brochure IN01047S</p>
Commubox FXA291	<p>Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.</p> <p> For details, see "Technical Information" TI00405C</p>



16 Technical data

16.1 Application

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are sufficiently resistant.

16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of <i>Faraday's law of magnetic induction</i> .
Measuring system	<p>The device consists of a transmitter and a sensor.</p> <p>The device is available as a compact version: The transmitter and sensor form a mechanical unit.</p> <p>For information on the structure of the device →  11 →  11</p>

16.3 Input

Measured variable	Direct measured variables Volume flow (proportional to induced voltage)
-------------------	---

Measuring range	Typically $v = 0.01$ to 10 m/s (0.03 to 33 ft/s) with specified accuracy
-----------------	--

Flow characteristic values in SI units

Nominal diameter	Recommended flow	Factory settings	
		Pulse value	Low flow cut off ($v \sim 0.04\text{ m/s}$)
[mm]	Max. full scale value [l/s]	[ml]	[ml/s]
4	0.14	0.005	0.5
8	0.5	0.02	2
15K ¹⁾	1.2	0.1	7
15	1.66	0.1	7
25	5	0.2	16

1) Conical version (corresponds to DN 12)

Flow characteristic values in US units

Nominal diameter	Recommended flow	Factory settings	
		Pulse value	Low flow cut off (v ~ 0.13 ft/s)
[in]	[gal/s]	[oz fl]	[oz fl/s]
$\frac{5}{32}$	0.035	0.0002	0.02
$\frac{5}{16}$	0.13	0.001	0.08
$\frac{1}{2}K^{1)}$	0.32	0.004	0.25
$\frac{1}{2}$	0.44	0.004	0.25
1	1.33	0.007	0.53

1) Conical version (corresponds to DN 12)

Recommended measuring range

"Flow limit" section →  70

Operable flow range Over 1000 : 1

Input signal**Status input**

The batching process is controlled by the automation system via the device's status input.

Maximum input values	<ul style="list-style-type: none"> DC 30 V 6 mA
Response time	Adjustable: 10 to 200 ms
Input signal level	<ul style="list-style-type: none"> Low level: 0 to 1.5 V High level: 3 to 30 V
Assignable functions	<ul style="list-style-type: none"> Off Start batching process Start and stop batching process Reset totalizers 1-3 separately Reset all totalizers Flow override

16.4 Output

Output signal**Modbus RS485**

Physical interface	In accordance with EIA/TIA-485-A standard
--------------------	---

Switch output (batch: valve control)

Depending on the device version, the device has one or two switch outputs.

Switch output	
Version	Active, open emitter
Maximum input values	<ul style="list-style-type: none"> DC 30 V 500 mA
Switching behavior	Binary, conductive or non-conductive

Number of switching cycles	Unlimited
Assignable functions	<ul style="list-style-type: none"> ■ Open ■ Closed ■ Batching

Signal on alarm

Depending on the interface, failure information is displayed as follows:

Modbus RS485

Failure mode	Choose from: <ul style="list-style-type: none"> ■ NaN value instead of current value ■ Last valid value
---------------------	---

Low flow cut off



The switch points for low flow cut off are user-selectable.

Galvanic isolation








- Device version: Modbus RS485, 1 switch output (batch), 1 status input (Order code for "Output, input": option 4)
Switch outputs (batch) and status input on supply potential
- Device version: Modbus RS485, 2 switch outputs (batch), 1 status input (Order code for "Output, input", option 5:)
 - Switch outputs (batch) on supply potential.
 - Status input, galvanically isolated.

Protocol-specific data

Modbus RS485

Protocol	Modbus Applications Protocol Specification V1.1
Device type	Slave
Slave address range	1 to 247
Broadcast address range	0
Function codes	<ul style="list-style-type: none"> ■ 03: Read holding register ■ 04: Read input register ■ 06: Write single registers ■ 08: Diagnostics ■ 16: Write multiple registers ■ 23: Read/write multiple registers ■ 43: Read device identification
Broadcast messages	Supported by the following function codes: <ul style="list-style-type: none"> ■ 06: Write single registers ■ 16: Write multiple registers ■ 23: Read/write multiple registers
Supported baud rate	<ul style="list-style-type: none"> ■ 1 200 BAUD ■ 2 400 BAUD ■ 4 800 BAUD ■ 9 600 BAUD ■ 19 200 BAUD ■ 38 400 BAUD ■ 57 600 BAUD ■ 115 200 BAUD
Data transfer mode	<ul style="list-style-type: none"> ■ ASCII ■ RTU
Data access	Each device parameter can be accessed via Modbus RS485.  For Modbus register information →  74

16.5 Power supply

Terminal assignment	→  24								
Pin assignment, device plug	→  25								
Supply voltage	<p>DC 24 V (nominal voltage: DC 20 to 30 V)</p> <div>  <ul style="list-style-type: none"> ▪ The power unit must be tested to ensure that it meets safety requirements (e.g. PELV, SELV). ▪ The supply voltage must not exceed a maximum short-circuit current of 50 A. </div>								
Power consumption	4.5 W								
Current consumption	<table border="1"> <thead> <tr> <th>Order code for "Output, input":</th><th>Maximum Power consumption</th></tr> </thead> <tbody> <tr> <td>Option 4: Modbus RS485, 1 switch output (batch), 1 status input</td><td>225 mA + 500 mA ¹⁾</td></tr> <tr> <td>Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input</td><td>225 mA + 1000 mA ¹⁾</td></tr> <tr> <td>Option 6: Modbus RS485 (custody transfer mode)</td><td>225 mA</td></tr> </tbody> </table> <p>1) Additional 500 mA per switch output (batch) used.</p> <div>  <p>Switch-on current: max. 1 A (< 8 ms)</p> </div>	Order code for "Output, input":	Maximum Power consumption	Option 4: Modbus RS485, 1 switch output (batch), 1 status input	225 mA + 500 mA ¹⁾	Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input	225 mA + 1000 mA ¹⁾	Option 6: Modbus RS485 (custody transfer mode)	225 mA
Order code for "Output, input":	Maximum Power consumption								
Option 4: Modbus RS485, 1 switch output (batch), 1 status input	225 mA + 500 mA ¹⁾								
Option 5: Modbus RS485, 2 switch outputs (batch), 1 status input	225 mA + 1000 mA ¹⁾								
Option 6: Modbus RS485 (custody transfer mode)	225 mA								
Power supply failure	<ul style="list-style-type: none"> ▪ Totalizers stop at the last value measured. ▪ Error messages (incl. total operated hours) are stored. 								
Electrical connection	→  28								
Potential equalization	<p>Requirements</p> <p>No potential matching is needed for grounded steel lines.</p> <div>  <p>For devices intended for use in hazardous locations, please observe the guidelines in the Ex documentation (XA).</p> </div>								
Cable specification	→  24								

16.6 Performance characteristics

Reference operating conditions	<p>In accordance with DIN EN 29104</p> <ul style="list-style-type: none"> ▪ Medium temperature: +28 ± 2 °C (+82 ± 4 °F) ▪ Ambient temperature: +22 ± 2 °C (+72 ± 4 °F) ▪ Warm-up period: 30 min
--------------------------------	---

Installation

- Inlet run > 10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Maximum measured error

Error limits under reference operating conditions

o.r. = of reading

Volume flow

- $\pm 0.25\%$ o.r. ± 1 to 4 m/s (3.3 to 13 ft/s) or
- $\pm 0.5\%$ o.r. ± 1 mm/s (0.04 in/s) or
- $\pm 5\%$ o.r.



Fluctuations in the supply voltage do not have any effect within the specified range.

Repeatability

o.r. = of reading

DN 25 (500 ml/s), DN 15 (200 ml/s), DN 8 (50 ml/s), DN 4 (10 ml/s); 400 µS/cm

Batch time t_a [s]	Relative standard deviation in relation to the batched volume [%]
$1.5\text{ s} < t_a < 3\text{ s}$	0.4
$3\text{ s} < t_a < 5\text{ s}$	0.2
$5\text{ s} < t_a$	0.1

DN 15K (200 ml/s); 400 µS/cm

Batch time t_a [s]	Relative standard deviation in relation to the batched volume [%]
$1.5\text{ s} < t_a < 3\text{ s}$	0.25
$3\text{ s} < t_a < 5\text{ s}$	0.12
$5\text{ s} < t_a$	0.08

16.7 Installation

"Mounting requirements"

16.8 Environment

Ambient temperature range

Temperature tables

Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.



For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature


The storage temperature corresponds to the ambient temperature range of the transmitter and sensor.

- Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.
- If protection caps or protective covers are mounted these should never be removed before installing the measuring device.







Degree of protection	As standard: IP67, type 4X enclosure
Shock resistance	Acceleration up to 2 g based on IEC 60068-2-6
Vibration resistance	Acceleration up to 2 g based on IEC 60068-2-6
Interior cleaning	<div><div><div>■ Cleaning in place (CIP)</div><div>■ Sterilization in place (SIP)</div></div><div><div><div><div>i</div></div></div><div>Observe the maximum medium temperatures → <div><div>69</div></div></div></div></div>
Electromagnetic compatibility (EMC)	<div>According to IEC/EN 61326</div> <div><div><div><div>📄</div></div></div><div>For details, refer to the Declaration of Conformity.</div></div>

16.9 Process

Medium temperature range	<div><div>Sensor</div><div>-20 to +130 °C (-4 to +266 °F)</div><div>Cleaning</div><div>+150 °C (+302 °F) / 60 min for CIP and SIP processes</div><div>Seals</div><div><div>■ EPDM: -20 to +130 °C (-4 to +266 °F) (max. +150 °C (302 °F) for cleaning</div><div>■ Silicon:-20 to +130 °C (-4 to +266 °F)</div><div>■ Viton:0 to +150 °C (+32 to +302 °F)</div></div></div>
--------------------------	---



A0004805

	<div>T_A Ambient temperature</div> <div>T_M Medium temperature</div> <div>Light-gray area: standard fluid temperature range</div> <div>Dark-gray area: fluid temperature range for cleaning</div>												
Conductivity	<div>■ ≥ 5 μS/cm for liquids in general</div> <div>■ ≥ 10 μS/cmfor demineralized water</div>												
Pressure-temperature ratings	<div> An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document</div>												
Pressure tightness	<div>Liner: PFA</div> <table><tr><th colspan="2">Nominal diameter</th><th colspan="2">Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:</th></tr><tr><th>[mm]</th><th>[in]</th><th>+25 °C (+77 °F)</th><th>+150 °C (+302 °F)</th></tr><tr><td>4 to 25</td><td>5/32 to 1</td><td>> 1 mbar (0.402 inH₂O) (0)</td><td>> 1 mbar (0.402 inH₂O) (0)</td></tr></table>	Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:		[mm]	[in]	+25 °C (+77 °F)	+150 °C (+302 °F)	4 to 25	5/32 to 1	> 1 mbar (0.402 inH ₂ O) (0)	> 1 mbar (0.402 inH ₂ O) (0)
Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:											
[mm]	[in]	+25 °C (+77 °F)	+150 °C (+302 °F)										
4 to 25	5/32 to 1	> 1 mbar (0.402 inH ₂ O) (0)	> 1 mbar (0.402 inH ₂ O) (0)										
Flow limit	<div>The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum flow velocity is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:</div> <div>■ v < 2 m/s (6.56 ft/s): For abrasive media (e.g. cleaning agents)</div> <div>■ v > 2 m/s (6.56 ft/s): For media that produce buildup (e.g. liquids containing oil and sugar)</div> <div> A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.</div> <div> For an overview of the full scale values for the measuring range, see the "Measuring range" section →  64</div>												
Pressure loss	<div>■ For DN 8 (5/16"), DN 15 (1/2") and DN 25 (1") no pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.</div> <div>■ Pressure losses for configurations incorporating adapters according to DIN EN 545 →  20</div>												
System pressure	→  19												
Vibrations													

16.10 Mechanical construction

Design, dimensions	<div> For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section</div>
--------------------	---

Weight

Compact version*Weight in SI units*

DN [mm]	Weight [kg]
4	2.8
8	2.8
15	2.8
25	4.3

Weight in US units

DN [in]	Weight [lbs]
$\frac{5}{32}$	6.17
$\frac{5}{16}$	6.17
$\frac{1}{2}$	6.17
1	9.48

Materials

Transmitter housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4308 (304)

Device plugs

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none"> ■ Socket: Stainless steel, 1.4404 (316L) ■ Contact housing: Polyamide ■ Contacts: Gold-plated brass

Sensor housing

- Acid and alkali-resistant outer surface
- Stainless steel 1.4301 (304)

Measuring tube

Stainless steel 1.4301 (304)

Liner

PFA

Electrodes

- 1.4435 (316L)
- Alloy C22, 2.4602 (UNS N06022)
- Platinum
- Tantalum

Process connections



- Weld-in nipple: 1.4404 (316L)
- Weld-in nipple, aseptic: 1.4404 (316L)
- Tri-Clamp: 1.4404 (316L)
- Couplings: 1.4404 (316L)

 List of all available process connections →  72

Seals

Molded seal (EPDM, silicone, Viton)

Fitted electrodes	<ul style="list-style-type: none">■ Standard: stainless steel 1.4435 (316L)■ Optional: Alloy C22, 2.4602 (UNS N06022), platinum, tantalum
-------------------	--


Process connections	<p>With O-ring seal</p> <p>Welded connections</p> <ul style="list-style-type: none">■ DIN EN ISO 1127■ ODT/SMS <p>Coupling</p> <p>ISO 228/DIN 2999</p> <p>With aseptic molded seal:</p> <p>Welded connections</p> <ul style="list-style-type: none">■ EN 10357, DIN 11850■ ODT/SMS <p>Tri-Clamp</p> <p>L14 AM7</p> <p> For information on the different materials used in the process connections →  72</p>
---------------------	---

Surface roughness	<p>Stainless steel electrodes, 1.4435 (304L); Alloy C22, 2.4602 (UNS N06022), platinum, tantalum:</p> <p>0.3 to 0.5 µm (11.8 to 19.7 µin)</p> <p>Liner with PFA:</p> <p>≤ 0.4 µm (15.7 µin)</p> <p>Process connection:</p> <p>≤ 0.8 µm (31 µin)</p> <p>(All data relate to parts in contact with fluid)</p>
-------------------	---

16.11 Operability



Local operation	This device cannot be operated locally using a display or operating elements.
-----------------	---

Remote operation	<p>Using service adapter and Commubox FXA291</p> <p>Operation and configuration can be performed using the Endress+Hauser FieldCare or DeviceCare service and configuration software.</p> <p>The device is connected to the USB port of the computer via the service adapter and Commubox FXA291.</p>
------------------	--



A0032567

- 1 Supply voltage 24 V DC
- 2 Service adapter
- 3 Commubox FXA291
- 4 Measuring device
- 5 Computer with "FieldCare" or "DeviceCare" operating tool

 The service adapter, cable and Commubox FXA291 are not included in the delivery. These components can be ordered as accessories →  62.



16.12 Certificates and approvals

CE mark	<p>The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
C-Tick symbol	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.</p>
Sanitary compatibility	<ul style="list-style-type: none"> ■ 3A approval and EHEDG-certified ■ Seals → FDA-compliant
Pressure Equipment Directive	<ul style="list-style-type: none"> ■ With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC. ■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.
Measuring instrument approval	<p>Dosimag is suitable as an (optional) component for recording volume in legally regulated measuring systems for AdBlue / DEF (Diesel Exhaust Fluid) in accordance with Appendix MI-005 of the European Measuring Instruments Directive 2014/32/EU. Dosimag is certified in accordance with OIML R117-1:2007 / OIML R117-2:2014 and has an MID evaluation certificate confirming conformity with the basic requirements of the Measuring Instruments Directive.</p>


Other standards and guidelines

- EN 60529
Degrees of protection provided by enclosures (IP code)
- EN 61010-1
Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use
- IEC/EN 61326
Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).
- CAN/CSA C22.2 No. 61010-1-12
Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use, Part 1: General Requirements
- ANSI/ISA-61010-1 (82.02.01)
Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use – Part 1: General Requirements

16.13 Accessories

 Overview of accessories available for order →  62

16.14 Supplementary documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Dosimag	KA01175D

Description of device parameters

Measuring device	Documentation code
	Pulse/frequency/status output Option 3
Dosimag	GP01049D

Measuring device	Documentation code
	Modbus RS485 Options 4, 5 and 6
Dosimag	GP01048D

Technical Information

Measuring device	Documentation code
Dosimag	TI00066D

Supplementary device-
dependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEX Ex nA	XA01332D
cCSAus	FES0231
UL Class 1 Division 2	XA01377D

Special Documentation

Contents	Documentation code
Information on Custody Transfer Measurement	SD01514D

Index

A

Adapters	20
Adapting the diagnostic behavior	52
Ambient temperature range	19
Application	8, 64
Approvals	73
Auto scan buffer	
see Modbus RS485 Modbus data map	

C

C-Tick symbol	73
CE mark	9, 73
Certificates	73
Check	
Connection	29
Post-installation	23
Checklist	
Post-connection check	29
Post-installation check	23
Cleaning	
Cleaning in place (CIP)	59
Exterior cleaning	59
Interior cleaning	59
Sterilization in place (SIP)	59
Cleaning in place (CIP)	69
Commissioning	37
Conductivity	70
Configuring error response mode, Modbus RS485	52
Connecting cable	24
Connecting the measuring device	28
Grounding	28
Connecting the transmitter	28
Connection	
see Electrical connection	
Connection conditions	24
Current consumption	67

D

Declaration of Conformity	9
Degree of protection	28, 69
Designated use	8
Device components	11
Device description files	33
Device documentation	
Supplementary documentation	7
Device locking, status	45
Device name	
Sensor	13
DeviceCare	32
Diagnostic information	
Communication interface	52
Design, description	51
FieldCare	50
Overview	53
Remedy information	53
Diagnostic list	55

Display

Current diagnostic event	54
Previous diagnostic event	54
Display values	
For locking status	45
Disposal	60
Document	
Function	5
Symbols used	5
Document function	5
Down pipe	16

E

Electrical connection	
Degree of protection	28
Measuring device	24
Electromagnetic compatibility	69
Endress+Hauser services	
Maintenance	59
Repair	60
Environment	
Ambient temperature	19
Shock resistance	69
Storage temperature	68
Vibration resistance	69
Error messages	
see Diagnostic messages	
Event history	55
Events list	55
Ex approval	73
Extended order code	
Sensor	13
Exterior cleaning	59

F

Field of application	
Residual risks	9
FieldCare	31
Device description file	33
Establishing a connection	31
Function	31
User interface	32
Filtering the event logbook	55
Firmware	
Release date	33
Version	33
Firmware history	58
Fitted electrodes	72
Flow direction	17
Flow limit	70
Function check	37
Function codes	33
Functions	
see Parameters	

G

Galvanic isolation	66
------------------------------	----

I

Identifying the measuring device	12
Incoming acceptance	12
Information on the document	5
Inlet runs	18
Input	64
Inspection	
Received goods	12
Installation	16
Installation	21
Installation conditions	
Adapters	20
Down pipe	16
Inlet and outlet runs	18
Installation dimensions	19
Mounting location	16
Orientation	17
Partially filled pipe	16
System pressure	19
Vibrations	19
Installation dimensions	19
Interior cleaning	59, 69

L

Local operation	72
Low flow cut off	66

M

Maintenance tasks	59
Replacing seals	59
Manufacturing date	13
Materials	71
Maximum measured error	68
Measured variables	
Measured	64
see Process variables	
Measuring and test equipment	59
Measuring device	33
Disposal	61
Mounting the sensor	
Cleaning with pigs	22
Mounting the seals	23
Nominal diameter and flow	23
Welded connections	22
Preparing for mounting	21
Removing	60
structure	11
Switching on	37
Measuring instrument approval	73
Measuring principle	64
Measuring range	64
Measuring system	64
Media	8
Medium temperature range	69
Menu	
Diagnostics	54
Operation	45
Setup	37, 38

Modbus RS485

Configuring error response mode	52
Diagnostic information	52
Function codes	33
Modbus data map	34
Read access	33
Reading out data	35
Register addresses	34
Register information	34
Response time	34
Scan list	35
Write access	33
Mounting dimensions	
see Installation dimensions	
Mounting location	16
Mounting preparations	21
Mounting tools	21

N

Nameplate	
Sensor	13

O

Operable flow range	65
Operation	45
Operation options	30
Operational safety	9
Order code	13
Orientation	
Filling systems	18
Orientation (vertical, horizontal)	17
Outlet runs	18
Output	65
Output signal	65

P

Packaging disposal	15
Parameter settings	
Administration (Submenu)	56
Batch output (Submenu)	39
Batching (Submenu)	48
Communication (Submenu)	41
Device information (Submenu)	56
Diagnostics (Menu)	54
For the status input	38
Input values (Submenu)	46
Low flow cut off (Submenu)	42
Operation (Menu)	45
Process variables (Submenu)	45
Sensor adjustment (Submenu)	43
Settings batch profile 1 to n (Submenu)	40
Setup (Menu)	38
Simulation (Submenu)	44
Status input (Submenu)	38
System units (Submenu)	38
Totalizer (Submenu)	46
Totalizer 1 to n (Submenu)	43
Totalizer handling (Submenu)	47
Partially filled pipe	16

Performance characteristics	67
Pin assignment, device plug	25
Post-connection check (checklist)	29
Post-installation check	37
Post-installation check (checklist)	23
Potential equalization	67
Power consumption	67
Power supply failure	67
Pressure Equipment Directive	73
Pressure loss	70
Pressure tightness	70
Pressure-temperature ratings	70
Process conditions	
Conductivity	70
Flow limit	70
Medium temperature	69
Pressure loss	70
Pressure tightness	70
Process connections	72
Product safety	9

R

Reading measured values	45
Reading out diagnostic information, Modbus RS485	52
Recalibration	59
Reference operating conditions	67
Registered trademarks	7
Remote operation	72
Repair	60
Repeatability	68
Replacement	
Device	60
Wear parts	60
Replacing seals	59
Requirements for personnel	8
Return	60

S

Safety	8
Sanitary compatibility	73
Serial number	13
Settings	
Communication interface	41
Device tag	38
Resetting the totalizer	47
Status input	38
Totalizer reset	47
Shock resistance	69
Signal on alarm	66
Spare parts	60
Standards and guidelines	74
Sterilization in place (SIP)	69
Storage conditions	15
Storage temperature	15
Storage temperature range	68
structure	
Measuring device	11
Submenu	
Administration	56

Advanced setup	42
Batch output	39
Batching	48
Communication	41
Device information	56
Events list	55
Input values	46
Low flow cut off	42
Process variables	45
Sensor adjustment	43
Settings batch profile 1 to n	40
Simulation	44
Status input	38
System units	38
Totalizer	46
Totalizer 1 to n	43
Totalizer handling	47
Supplementary documentation	74
Supply unit	
Requirements	28
Supply voltage	28, 67
Surface roughness	72
Switch output	65
System design	
Measuring system	64
see Measuring device design	
System integration	33
System pressure	19

T

Technical data, overview	64
Temperature range	
Storage temperature	15
Terminal assignment	24
Tools	
For mounting	21
Transport	15
Transporting the measuring device	15
Troubleshooting	
General	50

U

Use of the measuring device	
Borderline cases	8
Incorrect use	8
see Designated use	

V

Vibration resistance	69
Vibrations	19

W

W@M	59
W@M Device Viewer	12, 60
Weight	
SI units	71
Transport (notes)	15
US units	71
Workplace safety	9

www.addresses.endress.com
