


Description of Device Functions


Cerabar S PMC71, PMP71, PMP75

Deltabar S FMD77, FMD78, PMD75

Deltapilot S FMB70

Process pressure / Differential pressure, Flow / Hydrostatic





A0023555

Make sure the document is stored in a safe place such that it is always available when working on or with the device.

To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.

The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Notes on use	4	9	Level measurement (via local operation and FieldCare)	117
1.1	Finding parameter descriptions using ID numbers	4	9.1	Overview of level measurement	117
1.2	Finding function groups using graphic representation	4	9.2	"Level easy pressure" level selection	119
1.3	Finding parameter descriptions using parameter names (index)	4	9.3	"Level easy height" level selection	123
2	Parameter description of local operation and FieldCare	5	9.4	"Level standard" level selection, "Linear" level mode	127
3	Graphic representation of function groups	9	9.5	"Level standard" level selection, "Pressure linearized" level mode	131
3.1	Representation via device display	9	9.6	"Height linearized" level mode	137
3.2	Representation in FieldCare	10	10	Flow measurement (via local operation and FieldCare)	142
4	Pressure measurement (FF configuration program)	11	10.1	Calibration	142
5	Level measurement (FF configuration program)	13	10.2	Totalizer	144
5.1	Overview of level measurement	13	11	Parameter description (local operation and FieldCare)	146
5.2	"Level easy pressure" level selection	14	12	Troubleshooting	224
5.3	"Level easy height" level selection	18	12.1	Messages	224
5.4	"Level standard" level selection, "Linear" level mode	22	12.2	Overview of diagnostic events	229
5.5	"Level standard" level selection, "Pressure linearized" level mode	26	12.3	Response of outputs to errors	237
5.6	"Height linearized" level mode	32	12.4	Confirming messages	238
6	Flow measurement (FF configuration program)	35	13	Appendix	239
6.1	Calibration	35	13.1	Operating menu	239
6.2	Totalizer	37		Index	247
7	Parameter description (FF configuration program)	39			
7.1	Cerabar S/Deltabar S/Deltapilot S block model	39			
7.2	Resource Block	42			
7.3	Transducer Blocks	54			
7.4	Analog Input Block (function block)	104			
8	Pressure measurement (via local operation and FieldCare)	115			
8.1	Selecting the measuring mode	115			

1 Notes on use

Sections 4 to 6 describe how to operate the unit using an FF configuration program. With FOUNDATION Fieldbus, all the device parameters are categorized according to their functional properties and task and are assigned to the Resource Block, the Transducer Blocks and the function blocks. The parameters of the Resource Block, the Transducer Blocks and the Analog Input Block are described in Section 7. For a description of the parameters of the other function blocks, such as the PID or Discret Output Block, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview" or the FOUNDATION Fieldbus Specification. Sections 8 to 10 describe how to operate the unit via the local operation and the Endress+Hauser operating program FieldCare. Section 11 describes all the parameters in the order of how they appear in the menu. Sections 1.1 and 1.2 describe ways of finding a certain parameter description more easily.

1.1 Finding parameter descriptions using ID numbers

Each parameter is indicated on the local operation with a unique identification number (ID). All the parameters are listed in numerical order in Section 2. The page reference/link takes you to the parameter in question. In FieldCare, additional parameters and, to an extent, other parameters are displayed. These parameters are not listed in Section 2. You can find these parameters by means of the index. → See also Section 1.3.

1.2 Finding function groups using graphic representation

All the function groups are shown in table form in Section 3. The page reference/link takes you to the function group in question. In Section 7, all the parameters of a function group are compiled in a table.

1.3 Finding parameter descriptions using parameter names (index)

The index lists all the parameters in alphabetical order. The page reference/link takes you to the parameter in question.

2 Parameter description of local operation and FieldCare

You can find the parameter description as follows:

- Via the ID number for the local operation
- Via the parameter name for FieldCare

ID number	Parameter name	Description, see page
001	DENSITY UNIT	165 or 198
003	HEIGHT UNIT	165
004	FULL CALIB. – QUICK SETUP	153
004	FULL CALIB. – "Level easy pressure" level selection	162
004	FULL CALIB. – "Level easy height" level selection	166
005	FULL PRESSURE	162
006	FULL HEIGHT	167
007	ADJUST DENSITY	165 or 198
008	CALIBRATION MODE – "Level easy pressure" level selection	161
008	CALIBRATION MODE – "Level easy height" level selection	165
009	EMPTY HEIGHT	166
010	EMPTY CALIB. – QUICK SETUP	152
010	EMPTY CALIB. – "Level easy pressure" level selection	161 or 162
010	EMPTY CALIB. – "Level easy height" level selection	166
011	EMPTY PRESSURE	162
014	DOWNLOAD SELECT	219
020	LEVEL SELECTION	148
023	OUTPUT UNIT – "Level easy pressure" level selection	161
023	OUTPUT UNIT – "Level easy height" level selection	165
025	PROCESS DENSITY	198
046	ALARM STATUS	221
047	ENTER RESET CODE	219
048	INSERT PIN NO	219
050	LEVEL BEFORE LIN	216
060	PRESS. ENG. UNIT	157, 160, 164, 168 or 193
075	CUSTOMER UNIT P	158, 160, 164, 168 or 193
079	LANGUAGE	146
247	DAMPING VALUE	150, 153, 154, 158, 162, 167, 178, 182, 191 or 196
250	SENSOR SER. No.	212
264	SOFTWARE VERSION	210
266	HARDWARE REV.	210
301	PRESSURE – "Pressure" measuring mode	215
	PRESSURE – "Level" measuring mode	215
	PRESSURE – "Flow" measuring mode	216
311	MAX. FLOW	154 or 196
313	UNIT VOLUME – "Linear" level mode	172 or 176
	UNIT VOLUME – "Pressure linearized" level mode	180
	UNIT VOLUME – "Height linearized" level mode	185
314	EMPTY CALIB. – QUICK SETUP	152
	EMPTY CALIB. – "Linear" level mode	174
	EMPTY CALIB. – "Height linearized" level mode	188
315	FULL CALIB. – QUICK SETUP	153
	FULL CALIB. – "Pressure linearized" level mode	175
	FULL CALIB. – "Height linearized" level mode	188
316	ADJUST DENSITY – "Linear" level mode	175
	ADJUST DENSITY – "Height linearized" level mode	189
	ADJUST DENSITY – "Level" extended setup	198
317	CUST. UNIT. FACT. P	158, 160, 164, 169 or 194
318	TEMP. ENG. UNIT – "Pressure" measuring mode	197
	TEMP. ENG. UNIT – "Level" measuring mode	197
	TEMP. ENG. UNIT – "Flow" measuring mode	199
319	CALIB. OFFSET	156
323	SET. L. FL. CUT-OFF	199
329	FACT. U.U. TOTAL.1	207
330	FACT. U.U. TOTAL.2	208
331	RESET TOTALIZER 1	207
332	Pmin ALARM WINDOW	223

ID number	Parameter name	Description, see page
333	Pmax ALARM WINDOW	223
334	Tmin ALARM WINDOW	223
335	Tmax ALARM WINDOW	223
336	ALARM DELAY	222
339	DISPLAY CONTRAST	209
350	DEVICE DESIGN.	210
352	CONFIG RECORDER	210
354	DEVICE SERIAL No.	210
357	PCB TEMPERATURE	211
358	Allowed Min. TEMP	211
359	Allowed Max. TEMP	211
360	MAT. PROC. CONN. +	212
361	MAT. PROC. CONN. -	212
362	SEAL TYPE	212
363	DIP STATUS	211
365	MAT. MEMBRANE	213
366	FILLING FLUID	213
367	SENSOR TEMP.	215 or 216
368	Tmin SENSOR	213
369	Tmax SENSOR	213
370	TANK CONTENT	216
375	SUPPRESSED FLOW	216
378	MEAS. VAL. TREND	215 or 216
380	COUNTER: P > Pmax	217
382	RESET PEAKHOLD	218
383	MAX. MEAS. PRESS.	217
386	ELECTR. SERIAL NO.	210
389	MEASURING MODE	147
392	CALIBRATION MODE – "Linear" level mode	174
	CALIBRATION MODE – "Height linearized" level mode	188
397	LIN. EDIT MODE	201
398	TOTALIZER 1 UNIT – "Volume operat. cond." flow type	206
399	TOTALIZER 2 UNIT – "Volume operat. cond." flow type	207
400	NEG. FLOW TOT. 1	207
401	ACK. ALARM MODE	221
404	COUNTER: T > Tmax	217
409	OPERATING HOURS	219
413	SIMULATION MODE	220
414	SIM. PRESSURE	220
416	NEG. FLOW TOT. 2	208
419	MAIN LINE CONT.	208
423	ALTERNATE DATA	209
434	CORRECTED PRESS. – "Pressure" measuring mode	215
	CORRECTED PRESS. – "Level" measuring mode	215
	CORRECTED PRESS. – "Flow" measuring mode	216
442	LOW FLOW CUT-OFF	199
467	COUNTER: P < Pmin	217
469	MIN. MEAS. PRESS.	217
471	MAX. MEAS. TEMP.	217
472	COUNTER: T < Tmin	217
474	MIN. MEAS. TEMP.	217
476	SIM. ERROR NO.	221
480	ALARM DISPL. TIME	222
482	PROC. CONN. TYPE	211
484	PRESS.SENS LOLIM	212
485	PRESS.SENS HILIM	212
487	SENSOR H/WARE REV.	213
488	PCB COUNT: T>Tmax	217
490	PCB MAX. TEMP.	218
492	PCB COUNT: T < Tmin	218
494	PCB MIN. TEMP.	218
500	ACK. ALARM	221
549	MEASURING TABLE (display)	202
549	EDITOR TABLE, LINE-NUMB (enter values)	201
550	EDITOR TABLE, X-VAL. (enter values)	202
551	EDITOR TABLE, Y-VAL. (enter values)	201, 202
563	POS. INPUT VALUE	150, 152 or 156

ID number	Parameter name	Description, see page
564	LAST DIAG. CODE	221
570	Pmax PROC. CONN.	211
571	MASS FLOW UNIT	195
581	SENSOR MEAS. TYPE	213
584	SENSOR PRESSURE – "Pressure" measuring mode	215
	SENSOR PRESSURE – "Level" measuring mode	215
	SENSOR PRESSURE – "Flow" measuring mode	216
591	MINIMUM SPAN	212
595	SELECT ALARMTYPE	222
600	SELECT ALARMTYPE	222
603	RESET ALL ALARMS	221
607	CUST. UNIT FACT. V – "Linear" level mode	173 or 176
	CUST. UNIT FACT. V – "Pressure linearized" level mode	181
	CUST. UNIT FACT. V – "Height linearized" level mode	186
608	CUSTOMER UNIT V – "Linear" level mode	172 or 176
	CUSTOMER UNIT V – "Pressure linearized" level mode	180
	CUSTOMER UNIT V – "Height linearized" level mode	186
609	CUST. UNIT. FACT. F	196
610	CUSTOMER UNIT F	196
627	TOT. 1 USER UNIT	207
628	TOT. 2 UNIT TEXT	208
634	MAX PRESS. FLOW	154 or 196
639	SIM. FLOW VALUE	220
640	FLOW-MEAS. TYPE	194
652	TOTALIZER 1	216
655	TOTAL. 1 OVERFLOW	216
657	TOTALIZER 2	217
658	TOTAL. 2 OVERFLOW	217
660	STD. FLOW UNIT	195
661	NORM FLOW UNIT	195
662	TOTALIZER 1 UNIT – "Mass" flow type	206
663	TOTALIZER 2 UNIT – "Mass" flow type	207
664	TOTALIZER 1 UNIT – "Gas. std. conditions" flow type	206
665	TOTALIZER 2 UNIT – "Gas. std. conditions" flow type	207
666	TOTALIZER 1 UNIT – "Gas. norm conditions" flow type	206
667	TOTALIZER 2 UNIT – "Gas. norm conditions" flow type	207
679	MEASURED VALUE – "Pressure"	214
	MEASURED VALUE – "Level"	215
	MEASURED VALUE – "Flow"	216
685	POS. ZERO ADJUST	150, 152, 154 or 155
688	MAIN DATA FORMAT	209
703	CUST. UNIT FACT. M – "Linear" level mode	174
	CUST. UNIT FACT. M – "Pressure linearized" level mode	182
	CUST. UNIT FACT. M – "Height linearized" level mode	187
704	CUSTOMER UNIT M – "Linear" level mode	173
	CUSTOMER UNIT M – "Pressure linearized" level mode	181
	CUSTOMER UNIT M – "Height linearized" level mode	187
705	CUST. UNIT FACT. H – "Linear" level mode	172 or 177
	CUST. UNIT FACT. H – "Height linearized" level mode	185 or 190
706	CUSTOMER UNIT H – "Linear" level mode	171 or 177
	CUSTOMER UNIT H – "Height linearized" level mode	185 or 190
708	HEIGHT UNIT – "Linear" level mode	171 or 177
	HEIGHT UNIT – "Height linearized" level mode	184 or 189
709	MASS UNIT – "Linear" level mode	173
	MASS UNIT – "Pressure linearized" level mode	181
	MASS UNIT – "Height linearized" level mode	186
710	EMPTY PRESSURE – "Linear" level mode	174
	EMPTY PRESSURE – "Height linearized" level mode	188
711	FULL PRESSURE – "Linear" level mode	175
	FULL PRESSURE – "Height linearized" level mode	188
712	LEVEL MAX.	187
713	TANK CONTENT MAX.	200
714	SIM. LEVEL	220
715	SIM. TANK CONT.	220
717	MEASURING TABLE (selection)	202
718	LEVEL MODE	169
755	LEVEL MIN.	187

ID number	Parameter name	Description, see page
759	TANK CONTENT MIN.	200
761	HYDR. PRESS MAX.	182
770	EDITOR TABLE (continue entries)	202
775	HYDR. PRESS MIN.	182
804	LIN. MEASURAND	171
805	LINd. MEASURAND	180
806	COMB.MEASURAND	184
808	TABLE SELECTION	200
809	EDITOR TABLE (select table)	201
810	ADJUST DENSITY – "Linear" level mode	175
	ADJUST DENSITY – "Height linearized" level mode	188
811	PROCESS DENSITY	198
812	DENSITY UNIT – "Linear" level mode	175
	DENSITY UNIT – "Height linearized" level mode	189
813	100 % POINT – "Linear" level mode	178
	100 % POINT – "Height linearized" level mode	190
814	ZERO POSITION – "Linear" level mode	178
	ZERO POSITION – "Height linearized" level mode	191
815	TANK DESCRIPTION	202
831	HistoROM AVAIL.	219
832	HistoROM CONTROL	219
858	TANK VOLUME	176
859	TANK HEIGHT	177
981	AI 3 OUT Value	217
982	AI 2 OUT Value	217
983	AI 1 OUT Value	217
984	DEVICE ADDRESS	213
985	DD REVISION	213
986	DEVICE REVISION	213
987	DEVICE ID	213

3 Graphic representation of function groups

3.1 Representation via device display

The "Flow" measuring mode is only available for the Deltabar S differential pressure transmitter. The groups marked with "*" are only displayed for Deltabar S.

1. Group selection	2. Selection level	3. Function group	Description, see page
LANGUAGE	LANGUAGE (079)		→ 146
MEASURING MODE	MEASURING MODE (389)		→ 147
Depending on the MEASURING MODE selected (pressure, level or flow), the QUICK SETUP is set to pressure, level or flow.			
QUICK SETUP (pressure)			→ 149
QUICK SETUP (level)			→ 151
QUICK SETUP (flow *)			→ 146
OPERATING MENU	→ SETTINGS (557)	→ POSITION ADJUSTMENT	→ 155
		→ BASIC SETUP (pressure)	→ 157
		→ BASIC SETUP (level), "Level easy pressure"	→ 159
		→ BASIC SETUP (level), "Level easy height"	→ 163
		→ BASIC SETUP (level), "Level standard"	→ 167
		→ BASIC SETUP (flow *)	→ 192
		→ EXTENDED SETUP (pressure)	→ 197
		→ EXTENDED SETUP (level)	→ 197
		→ EXTENDED SETUP (flow *)	→ 198
		→ LINEARIZATION	→ 200
		→ TOTALIZER SETUP *	→ 206
	→ DISPLAY (555)		→ 208
	→ TRANSMITTER INFO (560)	→ FF-DATA	→ 213
		→ TRANSMITTER DATA	→ 210
		→ PROCESS CONNECTION	→ 211
		→ SENSOR DATA	→ 212
	→ PROCESSINFO (561)	→ PROCESS VALUES (pressure)	→ 214
		→ PROCESS VALUES (level)	→ 215
		→ PROCESS VALUES (flow) *	→ 216
		→ FUNCTION BLOCKS	→ 217
		→ PEAK HOLD INDICATOR	→ 217
	→ OPERATION		→ 219
	→ DIAGNOSTICS	→ SIMULATION MODE	→ 220
		→ MESSAGES	→ 221
		→ USER LIMITS	→ 223

3.2 Representation in FieldCare


The "Flow" measuring mode is only available for the Deltabar S differential pressure transmitter. The groups marked with "*" are only displayed for Deltabar S.

1. Identifier	2. Selection level	3. Function group	Description, see page
Depending on the MEASURING MODE selected (pressure, level or flow), the QUICK SETUP is set to pressure, level or flow.			
QUICK SETUP (pressure)			→ 149
QUICK SETUP (level)			→ 151
QUICK SETUP (flow *)			→ 146
OPERATING MENU	→ SETTINGS	→ POSITION ADJUSTMENT	→ 155
		→ BASIC SETUP (pressure)	→ 157
		→ BASIC SETUP (level), "Level easy pressure"	→ 159
		→ BASIC SETUP (level), "Level easy height"	→ 163
		→ BASIC SETUP (level), "Level standard"	→ 167
		→ BASIC SETUP (flow) *	→ 192
		→ EXTENDED SETUP (pressure)	→ 197
		→ EXTENDED SETUP (level)	→ 197
		→ EXTENDED SETUP (flow) *	→ 198
		→ LINEARIZATION	→ 203
		→ TOTALIZER SETUP *	→ 206
	→ DISPLAY		→ 208
	→ TRANSMITTERINFO	→ FF-DATA	→ 213
		→ TRANSMITTER DATA	→ 210
		→ PROCESS CONNECTION	→ 211
		→ SENSOR DATA	→ 212
	→ PROCESSINFO	→ PROCESS VALUES (pressure)	→ 214
		→ PROCESS VALUES (level)	→ 215
		→ PROCESS VALUES (flow) *	→ 216
		→ FUNCTION BLOCKS	→ 217
		→ PEAK HOLD INDICATOR	→ 217
	→ OPERATION		→ 219
	→ DIAGNOSTICS	→ SIMULATION MODE	→ 220
		→ MESSAGES	→ 221
		→ USER LIMITS	→ 223

4 Pressure measurement (FF configuration program)

In this chapter the parameter text as well as the parameter name are indicated.

In FF configuration programs only the parameter text is displayed (exception: in the NI-FBUS configurator you can select if the parameter text or the parameter name is displayed).



P01-xxxxxxx-07-xx-xx-en-001


- The Cerabar S and the Deltabar S are configured for the pressure measuring mode as standard. The Deltapilot S is configured for the level measuring mode as standard. The measuring range and the unit in which the measured value is transmitted, as well as the digital output value of the Analog Input Block OUT, correspond to the data on the nameplate.
- See also Operating Instructions BA00301P Deltabar S, "Pressure measurement" section or Operating Instructions BA00302P Cerabar S, "Pressure measurement" section or BA00372P Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - → 56, Pressure Transducer Block
 - → 104, Analog Input Block.

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!


	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMD75xxx-19-xx-xx-xx-000
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	Carry out position adjustment if necessary. The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	
4	Select the measuring mode if necessary: ■ Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. ■ Select the "Differential pressure", Gauge pressure" or "Absolute pressure" option by means of the Primary Value Typ/PRIMARY_VALUE_TYPE parameter.	
5	Set the Pressure Transducer Block to the "Auto" block mode.	
6	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
7	Result: The device is ready for pressure measurement.	

- You can select another pressure unit by means of the Calibration Units/CAL_UNIT parameter (→ 57). You can also specify a customer-specific unit by means of this parameter.

5 Level measurement (FF configuration program)

In this chapter the parameter text as well as the parameter name are indicated.

In FF configuration programs only the parameter text is displayed (exception: in the NI-FBUS configurator you can select if the parameter text or the parameter name is displayed).



P01-xxxxxxx-07-xx-xx-en-001

5.1 Overview of level measurement

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	LEVEL_TYP/ LEVEL MODE	Description	Measured value display
The measured variable is in direct proportion to the measured pressure.	LEVEL SELECTION: Level easy pressure	– % (level) – Level – Volume – Mass	Linear	Calibration without reference pressure – dry calibration, see → 24, Section 5.4.2	The measured value display and the Primary Value Type/ PRIMARY_VALUE and Level Before Lin./LEVEL_BEFORE_LINEARISATION parameters display the measured value.
The measured variable is not in direct proportion to the measured pressure as is the case with tanks with a conical outlet, for example. A linearization table has to be entered for the calibration.	LEVEL SELECTION: Level standard/ LEVEL MODE: Pressure linearized	– Pressure and % – Pressure and volume – Pressure and mass	Pressure linearized	– Calibration with reference pressure: semiautomatic entry of linearization table, see → 26, Section 5.5.1 – Calibration without reference pressure: manual entry of linearization table, see → 29, Section 5.5.2.	The measured value display and the Primary Value Type/ PRIMARY_VALUE parameter show the measured value.
– Two measured variables are required or – The container shape is given by value pairs, such as height and volume. The 1st measured variable %-height or height must be in direct proportion to the measured pressure. The 2nd measured variable volume, mass or % must not be in direct proportion to the measured pressure. A linearization table has to be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table.	LEVEL SELECTION: Level standard/ LEVEL MODE: Height linearized	– Height and volume – Height and mass – Height and % – %-height and volume – %-height and mass – %-height and %	Height linearized	– Calibration without reference pressure: dry calibration and manual entry of linearization table, see → 32, Section 5.6.1.	The measured value display and the Primary Value Type/ PRIMARY_VALUE parameter show the 2nd measured value (volume, mass or %). The Level Before Lin./LEVEL_BEFORE_LINEARISATION parameter displays the 1st measured value (height or height).

5.2 "Level easy pressure" level selection

5.2.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0-300 mbar (4.5 psi).

Prerequisite:


- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY must be at least 1% apart for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero.
→ For information on how to perform position adjustment, see also → 63, "Pos.Zero Adjust/ZERO_POSITION_ADJUST".


⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMP75xxx-19-xx-xx-xx-008 Fig. 1: Calibration with reference pressure – wet calibration 1 See Table, Step 8. 2 See Table, Step 10.
2	Open the Pressure Transducer Block and set the block mode to OOS.	

	Description	
3	The following options are available for performing position adjustment: - By means of the parameters - Pos.Zero Adjust/ZERO_POSITION_ADJUST (→ 63) or - Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or - Calib. Offset/CALIBRATION_OFFSET (→ 63).	 P01-xxxxxxx-05-xx-xx-xx-011
4	Select the measuring mode if necessary: - Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. - By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter select the "Level" option. Or:	
5	By means of the parameter Level Selection/LEVEL_SELECTION select the "Level Easy Pressure".	
6	By means of the Scale Out/SCALE_OUT "Units Index" parameter, select the "m" option. Or select a level unit, such as "m" in this example, by means of the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter.	
7	By means of the Calibration Mode Level Easy/CALIBRATION_MODE_EASY parameter, select the "Wet" option.	Fig. 2: Calibration with reference pressure – wet calibration 1 See Table, Step 9. 2 See Table, Step 10.
8	Fill the container up to the lower level point. The related pressure value can be viewed via the Pressure/PRESSURE parameter.	
9	By means of the Scale Out/SCALE_OUT "EU at 0%" parameter, enter a level value, here 0 m for example. Or by means of the Empty calib. level easy/EMPTY_CALIBRATION_EASY parameter, enter a level value, here 0 m for example.	
10	Fill the container up to the upper level point. The related pressure value can be viewed via the Pressure/PRESSURE parameter.	
11	By means of the Scale Out/SCALE_OUT "EU at 100%" parameter, enter a level value, here 3 m (9.8 ft) for example. Or by means of the Full calib. level easy/FULL_CALIBRATION_EASY parameter, enter a level value, here 3 m (9.8 ft) for example.	
12	Set the Pressure Transducer Block to the "Auto" block mode.	
13	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	


5.2.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a pressure of 450 mbar (6.75 psi). The minimum volume of 0 liters corresponds to a pressure of 50 mbar (0.75 psi) since the device is mounted below the level lower-range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY must be at least 1 % apart for the "Level easy pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero.
→ For information on how to perform position adjustment, see also → 63, "Pos.Zero Adjust/ZERO_POSITION_ADJUST".

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMC71xxx-19-xx-xx-xx-008
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	
		Fig. 3: Calibration without reference pressure – dry calibration 1 See Table, Step 10. 2 See Table, Step 9.

	Description	
4	Select the measuring mode if necessary: ■ Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Volume" option. Or:	P01-xxxxxxx-05-xx-xx-xx-026
5	By means of the parameter Level Selection/LEVEL_SELECTION select the "Level Easy Pressure".	
6	By means of the Scale Out/SCALE OUT "Units Index" parameter, select the "l" (liter) option. Or select a volume unit, such as "l" in this example, by means of the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter.	
7	By means of the Calibration Mode Level Easy/CALIBRATION_MODE_EASY parameter, select the "Dry" option.	
8	By means of the Full Calib. Level Easy/FULL_CALIBRATION_EASY parameter, enter a pressure, here 450 mbar (7 psi) for example.	Fig. 4: Calibration with reference pressure – wet calibration 1 See Table, Step 7. 2 See Table, Step 8. 3 See Table, Step 9. 4 See Table, Step 10.
9	By means of the Empty calib. level easy/EMPTY_CALIBRATION_EASY parameter, enter a pressure, here 50 mbar (0.75 psi) for example.	
10	By means of the Scale Out/SCALE OUT "EU at 100%" parameter, enter the tank volume, here 1000 l (264 US gal) for example. Or by means of the Full Calib. Level Easy/FULL_CALIBRATION_EASY parameter, enter a volume, here 1000 l (264 US gal) for example.	
11	By means of the Scale Out/SCALE OUT "EU at 0%" parameter, enter the tank volume, here 0 l for example. Or by means of the Empty calib. level easy/EMPTY_CALIBRATION_EASY parameter, enter a volume, here 0 l for example.	
12	Set the Pressure Transducer Block to the "Auto" block mode.	
13	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Scale Out/SCALE OUT (→ 107) parameters by means of the Analog Input Block.	


5.3 "Level easy height" level selection

5.3.1 Calibration with reference pressure – wet calibration

Example:
In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the level lower-range value. The density of the fluid is 1 kg/dm³.

- Prerequisite:**
- The measured variable is in direct proportion to the pressure.
 - The tank can be filled and emptied.
 - See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
 - The values entered for Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY must be at least 1% apart for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
 - Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero.
→ For information on how to perform position adjustment, see also → 63, "Pos.Zero Adjust/ZERO_POSITION_ADJUST".

⚠ WARNING
Changing the measuring mode affects the span (URV)!
This situation can result in product overflow.
► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMC71xxx-19-xx-xx-xx-009 Fig. 5: Calibration with reference pressure – wet calibration 1 See Table, Steps 10 and 11. 2 See Table, Step 12. 3 See Table, Step 13.
2	Open the Pressure Transducer Block and set the block mode to OOS.	

	Description	
3	The following options are available for performing position adjustment: - By means of the parameters - Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or - Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or - Calib. Offset/CALIBRATION_OFFSET (→ 63).	P01-xxxxxxx-05-xx-xx-xx-029
4	Select the measuring mode if necessary: - Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. - By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Volume" option. Or:	
5	By means of the parameter Level Selection/LEVEL_SELECTION select the "Level Easy Height".	
6	By means of the parameter Output Unit Level Easy/OUTPUT_UNIT_EASY select a volume unit, e.g. "l".	
7	By means of the parameter Height Unit/HEIGHT_UNIT_EASY select a height unit, here "m" for example.	
8	By means of the Calibration Mode Level Easy/CALIBRATION_MODE_EASY parameter, select the "Wet" option.	
9	By means of the parameter Density Unit Level Easy/DENSITY_UNIT_EASY select a density unit, e.g. "kg/dm³".	P01-xxxxxxx-05-xx-xx-xx-030
10	By means of the parameter Adjust Density Level Easy/ADJUST_DENSITY_EASY enter a density e.g. "1" kg/dm³.	
11	Fill the container up to the lower level point. The related level value can be viewed via the Meas. level easy/MEASURED_LEVEL_EASY parameter.	
12	By means of the parameter Empty Height Level Easy/EMPTY_HEIGHT_EASY enter a percentage value, e.g. 0 "%".	
13	Fill the container up to the upper level point. The related level value can be viewed via the Meas. level easy/MEASURED_LEVEL_EASY parameter.	
14	By means of the Full Height Level Easy/FULL_HEIGHT_EASY parameter, enter a percentage value, e.g. 1000 "%".	
15	Set the Pressure Transducer Block to the "Auto" block mode.	
16	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	

Fig. 6: Calibration with reference pressure – wet calibration

- 1 See Table, Step 9.
2 See Table, Step 12.
3 See Table, Step 14.


5.3.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the level lower-range value. The density of the fluid is 1 kg/dm³.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the height and volume values for the lower and upper calibration point must be known.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY must be at least 1 % apart for the "Level easy pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero.
→ For information on how to perform position adjustment, see also → 63, "Pos.Zero Adjust/ZERO_POSITION_ADJUST".

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 Fig. 7: Calibration without reference pressure – dry calibration 1 See Table, Step 10. 2 See Table, Steps 12 and 13. 3 See Table, Steps 14 and 15.
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	

	Description	
4	Select the measuring mode if necessary: ■ Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Volume" option. Or:	P01-xxxxxxx-05-xx-xx-xx-029 P01-xxxxxxx-05-xx-xx-xx-032
5	By means of the parameter Level Selection/LEVEL_SELECTION select the "Level Easy Height".	
6	By means of the parameter Output Unit Level Easy/OUTPUT_UNIT_EASY select a volume unit, e.g. "l".	
7	By means of the parameter Height Unit/HEIGHT_UNIT_EASY select a height unit, here "m" for example.	
8	By means of the Calibration Mode Level Easy/CALIBRATION_MODE_EASY parameter, select the "Dry" option.	
9	By means of the parameter Density Unit Level Easy/DENSITY_UNIT_EASY select a density unit, e.g. "kg/dm ³ ".	
10	By means of the parameter Adjust Density Level Easy/ADJUST_DENSITY_EASY enter a density e.g. "1" kg/dm ³ .	
11	By means of the Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY parameter, enter a volume, here 0 l for example.	
12	By means of the Empty Height Level Easy/EMPTY_HEIGHT_EASY parameter, enter a volume, here 0.5 m (1.6 ft) for example.	
13	By means of the Full Calib. Level Easy/FULL_CALIBRATION_EASY parameter, enter a volume, here 1000 l (264 US gal) for example.	
14	By means of the Full Height Level Easy/FULL_HEIGHT_EASY parameter, enter a volume, here 4.5 m (15 ft) for example.	
15	Set the Pressure Transducer Block to the "Auto" block mode.	

Fig. 8: Calibration with reference pressure – wet calibration

- 1 See Table, Step 9.
- 2 See Table, Step 11.
- 3 See Table, Step 12.
- 4 See Table, Step 13.
- 5 See Table, Step 14.

5.4 "Level standard" level selection, "Linear" level mode

5.4.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0-300 mbar (4.5 psi).

Prerequisite:


- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.
- See also Operating Instructions BA00301P for Deltabar S or Operating Instructions BA00302P for Cerabar S or Operating Instructions BA00372P for Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - →  56, Pressure Transducer Block
 - →  104, Analog Input Block.


⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMP75xxx-19-xx-xx-xx-008
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters - Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or - Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or - Calib. Offset/CALIBRATION_OFFSET (→ 63).	
4	Select the measuring mode if necessary: ■ Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter select the "Level" option.	
5	Select the "LEVEL standard" option by means of the Level Selection/LEVEL_SELECTION parameter.	
6	By means of the Level Mode/LEVEL_MODE parameter, select the "Linear" option.	Fig. 9: Calibration without reference pressure – dry calibration 1 See Table, Step 11. 2 See Table, Step 13.
7	Select the "Level" option by means of the Lin. measurand/LINEAR_MEASURAND parameter.	
8	By means of the Scale Out/SCALE OUT "Units Index" parameter, select the "m" option. Or by means of the Unit Height/HEIGHT_UNIT parameter, select a height unit, here "m" for example.	
9	By means of the Calibration mode/CALIBRATION_MODE parameter, select the "Wet" option. See also Point 3 in the following note.	
10	Fill the container up to the lower level point. The related pressure value can be viewed via the Pressure/PRESSURE parameter.	
11	By means of the Scale Out/SCALE OUT "EU at 0%" parameter, enter a level value, here 0m for example.	
12	Fill the container up to the upper level point. The related pressure value can be viewed via the Pressure/PRESSURE parameter.	
13	By means of the Scale Out/SCALE OUT "EU at 100%" parameter, enter a level value, here 3m for example.	
14	Set the Pressure Transducer Block to the "Auto" block mode.	
15	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
		1 See Table, Step 11. 2 See Table, Step 13.




5.4.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in m³. The maximum volume is 5 m³ and the maximum height is 4 m (13 ft). The density of the fluid is 1 kg/dm³. The device is mounted below the level lower-range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration, i.e. the tank volume, tank height and density of the fluid are known.
- See also Operating Instructions BA00301P for Deltabar S or Operating Instructions BA00302P for Cerabar S or Operating Instructions BA00372P for Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - → 56, Pressure Transducer Block
 - → 104, Analog Input Block.

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 Fig. 10: Calibration without reference pressure – dry calibration 1 See Table, Step 11. 2 See Table, Step 12. 3 See Table, Step 13. 4 See Table, Step 14.
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	
4	Select the measuring mode if necessary: ■ Select the "No linearization" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Volume" option.	
5	Select the "LEVEL standard" option by means of the Level Selection/LEVEL_SELECTION parameter.	
6	Select a pressure unit via the Calibration Units/CAL_UNIT parameter, here mbar for example.	
7	By means of the Level Mode/LEVEL_MODE parameter, select the "Linear" option.	
8	By means of the Lin. Measurand/LINEAR_MEASURAND parameter, select the "Volume" option.	
9	Select a volume unit via the Unit Volume/VOLUME_UNIT parameter, here m ³ for example.	
10	By means of the Calibration Mode/CALIBRATION_MODE parameter, select the "Dry" option. See also the following information.	

	Description	
11	By means of the Adjust Density/ADJUST_DENSITY and Density Unit/DENSITY_UNIT parameters, enter a value for the density, here 1 kg/dm ³ for example.	
12	Enter the tank volume via the Tank Volume/TANK_VOLUME parameter, here 5 m ³ for example.	
13	Enter the tank height via the Tank Height/TANK_HEIGHT parameter, here 4 m (13 ft) for example.	
14	By means of the Zero Point/ZERO_POSITION parameter, enter the level offset, here -0.5 m (-1,6 ft) for example.	
15	Set the Pressure Transducer Block to the "Auto" block mode.	
16	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
17	Result: The device is ready for level measurement.	

1. For this level mode, the measured variables %, level, volume and mass are available.
→ 65 ff.
2. You can also specify customer-specific units. See parameter description for Calibration Units/CAL_UNIT (→ 57), Height Unit/HEIGHT_UNIT (→ 66), Unit Volume/VOLUME_UNIT (→ 68) and Unit Mass/MASS_UNIT (→ 69).

5.5 "Level standard" level selection, "Pressure linearized" level mode

5.5.1 Semiautomatic entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.


Prerequisite:

- The tank can be filled. The linearization characteristic must rise continuously.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.
- See also Operating Instructions BA00301P for Deltabar S or Operating Instructions BA00302P for Cerabar S or Operating Instructions BA00372P for Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - →  56, Pressure Transducer Block.
 - →  104, Analog Input Block

** WARNING****Changing the measuring mode affects the span (URV)!**

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMP75xxx-19-xx-xx-xx-002
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters - Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or - Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or - Calib. Offset/CALIBRATION_OFFSET (→ 63).	
Carry out basic setup:		
4	Select the measuring mode if necessary: ■ Select the "Level linearized" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Volume" option. See also Point 3 in the following note.	
5	Select the "LEVEL standard" option by means of the Level Selection/LEVEL_SELECTION parameter.	
6	Select a pressure unit via the Calibration Units/CAL_UNIT parameter, here mbar for example.	
7	By means of the Level Mode/LEVEL_MODE parameter, select the "Pressure linearized" option.	
8	By means of the Lin. Measurand/LINEAR_MEASURAND parameter, select the "Pressure and volume" option.	
9	Select a volume unit via the Unit Volume/VOLUME_UNIT parameter, here m³ for example.	

	Description	
10	Select the Scale In/SCALE_IN parameter, EU_0 element.	P01-xxxxxxxx-05-xx-xx-xx-015
	Enter the minimum hydrostatic pressure to be expected, here 0 mbar for example.	
11	Select the Scale In/SCALE_IN parameter, EU_100 element.	
	Enter the maximum hydrostatic pressure to be expected, here 350 mbar (5.25 psi) for example.	
Carry out linearization:		
12	Select the Scale Out/SCALE_OUT parameter, EU_0 element.	
	Specify the minimum tank contents to be expected, here 0 m³ for example.	
13	Select the Scale Out/SCALE_OUT parameter, EU_100 element.	
	Specify the maximum tank contents to be expected, here 3.5 m³ for example. See also Point 4 in the following note.	
14	By means of the Lin. Edit Mode/LINEARIZATION_EDIT_MODE parameter, select the "Semiautomatic" option.	
15	By means of the Table Selection/LINEARIZATION_TABLE_SELECTION parameter, select the "Edit table" option.	
16	Enter the linearization table (min. 2 points, max. 32 points).	
	Fill the tank to the height of the 1st point.	
	Table Line-Number/LINEARIZATION_TABLE_INDEX: enter the value of the corresponding point.	
	The Sensor Pressure/SENSOR_PRESSURE parameter indicates the hydrostatic pressure present at the device. This hydrostatic pressure displayed is saved by confirming the Y-value. See the following line.	
	Y-Value/LINEARIZATION_TABLE_Y_VALUE, 2nd element (Y-value): Enter the volume value, here 0 m³ for example, and confirm the value.	
17	You can enter further points for the linearization table as explained in Step 15. The previous point first has to be saved in the linearization table before the next point can be entered. This means that complete linearization tables cannot be saved in the device. Once all the points have been entered, the table must be activated by means of the Edit Table/LINEARIZATION_TABLE_POST_EDIT parameter.	
18	Set the Pressure Transducer Block to the "Auto" block mode.	
19	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
20	Result: The linearization table has been entered and the device is ready for level measurement.	

Fig. 11: Semiautomatic entry of the linearization table

- 1 See Table, Step 10.
- 2 See Table, Step 11.
- 3 See Table, Step 12.
- 4 See Table, Step 13.
- 5 See Table, Steps 14 to 17.

1. For this level mode, the measured variables %, volume and mass are available. → 68 ff.
2. You can also specify customer-specific units. See parameter description for Calibration Units/CAL_UNIT (→ 57), Height Unit/HEIGHT_UNIT (→ 66), Unit Volume/VOLUME_UNIT (→ 68) and Unit Mass/MASS_UNIT (→ 69).
3. Once you have selected the "Pressure linearized" level mode (LEVEL_TYPE), the warning message "W710 Set span too small. Not allowed." can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-value of the linearization table, is smaller than the minimum span permitted (→ Calibration Minimum Span/CAL_MIN_SPAN, → 57). The message disappears as soon as the highest X-value is greater than the minimum span and the table entered is active.
4. Once you have entered the maximum tank contents to be expected for Scale Out/SCALE_OUT, EU_100 element, the alarm "A719 Y-Val of lin. table out of edit limits" can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest Y-value of the linearization table, is greater than the value entered for Scale Out/SCALE_OUT, EU_100 element. The message disappears as soon as no Y_value is greater than the value for Scale Out/SCALE_OUT, EU_100 element and the table entered is active.

5.5.2 Manual entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:



- This is a theoretical calibration, i.e. the points for the linearization table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.
- See also Operating Instructions BA00301P for Deltabar S or Operating Instructions BA00302P for Cerabar S or Operating Instructions BA00372P for Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - → 56, Pressure Transducer Block.
 - → 104, Analog Input Block

WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Perform calibration as per Section 5.5.1, Steps 1 to 10.	 P01-PM75xxx-19-xx-xx-xx-002
	Carry out linearization:	
2	Select the Scale Out/SCALE_OUT parameter, EU_0 element. Specify the minimum tank contents to be expected, here 0 m³ for example.	
3	Select the Scale Out/SCALE_OUT parameter, EU_100 element. Specify the maximum tank contents to be expected, here 3.5 m³ for example. See also Point 3 in the following note.	
4	By means of the Lin. Edit Mode/LINEARIZATION_EDIT_MODE parameter, select the "Manual" option.	
5	By means of the Table Selection/LINEARIZATION_TABLE_SELECTION parameter, select the "Edit table" option.	
6	Enter the linearization table (min. 2 points, max. 32 points).	 P01-xxxxxxx-05-xx-xx-xx-015
	Table Line-Number/LINEARIZATION_TABLE_INDEX: enter the value of the corresponding point.	
	X-Value/LINEARIZATION_TABLE_X_VALUE, 1st element (X-value): enter the pressure value.	
	Y-Value/LINEARIZATION_TABLE_Y_VALUE, 2nd element (Y-value): Enter the volume value, here 0 m³ for example, and confirm.	
7	You can enter further points for the linearization table as explained in Step 6. The previous point first has to be saved in the linearization table before the next point can be entered. This means that complete linearization tables cannot be saved in the device. Once all the points have been entered, the table must be activated by means of the Edit Table/LINEARIZATION_TABLE_POST_EDIT parameter.	
8	Set the Pressure Transducer Block to the "Auto" block mode.	Fig. 12: Manual entry of the linearization table 1 See Section 5.5.1, Table, Step 9. 2 See Section 5.5.1, Table, Step 10. 3 See this table, Step 2. 4 See this table, Step 3. 5 See this table, Steps 4 to 7.
9	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
10	Result: The linearization table has been entered and the device is ready for level measurement.	

- For this level mode, the measured variables %, volume and mass are available. → 68 ff.
- You can also specify customer-specific units. See parameter description for Calibration Units/CAL_UNIT (→ 57), Height Unit/HEIGHT_UNIT (→ 66), Unit Volume/VOLUME_UNIT (→ 68) and Unit Mass/MASS_UNIT (→ 69).

3. Once you have entered the maximum tank contents to be expected for Scale Out/SCALE_OUT, EU_100 element, the alarm "A719 Y-Val of lin. table out of edit limits" can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest Y-value of the linearization table, is greater than the value entered for Scale Out/SCALE_OUT, EU_100 element. The message disappears as soon as no Y_value is greater than the value for Scale Out/SCALE_OUT, EU_100 element and the table entered is active.

5.6 "Height linearized" level mode

5.6.1 Dry calibration and manual entry of the linearization table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:


- This is a theoretical calibration, i.e. the points for the linearization table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.
- See also Operating Instructions BA00301P for Deltabar S or Operating Instructions BA00302P for Cerabar S or Operating Instructions BA00372P for Deltapilot S, "Level measurement" section.
- For a description of the parameters mentioned, see
 - → 56, Pressure Transducer Block.
 - → 104, Analog Input Block



⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P, Section 6.6.1	 P01-PMP75xxx-19-xx-xx-xx-006
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	
Perform calibration for the 1st measured variable:		Fig. 13: <i>Calibrating the 1st measured variable</i> 1 See Table, Step 11. 2 See Table, Step 12.
4	Select the measuring mode if necessary: ■ Select the "Level combined" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/ PRIMARY_VALUE_TYPE parameter, select the "Volume" option.	
5	Select the "LEVEL standard" option by means of the Level Selection/LEVEL_SELECTION parameter.	
6	Select a pressure unit via the Calibration Units/ CAL_UNIT parameter, here mbar for example.	
7	By means of the Level Mode/LEVEL_MODE parameter, select the "Height linearized" option.	
8	By means of the Comb. Measurand/ COMBINED_MEASURAND parameter, select the "Height + volume" option.	

	Description	
9	Select the unit for the 1st measured value via the Height Unit/HEIGHT_UNIT parameter, here m for example.	 P01-PMP75xxxx-19-xx-xx-xx-005
10	Select the unit for the 2nd measured variable via the Unit Volume/VOLUME_UNIT parameter, here m³ for example.	
11	Select the Level Min/LEVEL_MIN parameter.	
	Enter the minimum level to be expected, here 0 m for example.	
12	Select the Level Max/LEVEL_MAX parameter.	
	Enter the maximum level to be expected, here 3 m for example. See also Point 3 in the following note.	 P01-xxxxxxx-05-xx-xx-xx-022
13	Select the "Dry" option via the Calibration Mode/CALIBRATION_MODE parameter (calibration mode for the 1st measured variable). See also Point 4 in the following note.	
14	By means of the Adjust Density/ADJUST_DENSITY and Density Unit/DENSITY_UNIT parameters, enter a value for the density, here 1 kg/dm³ for example.	
15	Result: The calibration for the 1st measured variable is carried out.	
Perform linearization (calibration for the 2nd measured variable)		
16	Select the Scale Out/SCALE_OUT parameter, EU_0 element.	Fig. 14: Calibrating the 2nd measured variable 3 See Table, Step 16. 4 See Table, Step 17. 5 See Table, Steps 18 to 21.
	Specify the minimum tank contents to be expected, here 0 m³ for example.	
17	Select the Scale Out/SCALE_OUT parameter, EU_100 element.	
	Specify the maximum tank contents to be expected, here 5 m³ for example.	
18	By means of the Lin. Edit Mode/LINEARIZATION_EDIT_MODE parameter, select the "Manual" option.	
19	By means of the Table Selection/LINEARIZATION_TABLE_SELECTION parameter, select the "Edit table" option.	
20	Enter the linearization table (min. 2 points, max. 32 points).	
	Table Line-Number/ LINEARIZATION_TABLE_INDEX: enter the value of the corresponding point.	
	X-Value/LINEARIZATION_TABLE_X_VALUE, 1st element (X-value): enter the level, here 0 m for example.	
	Y-Value/LINEARIZATION_TABLE_Y_VALUE, 2nd element (Y-value): Enter the volume value, here 0 m³ for example.	
21	You can enter further points for the linearization table as explained in Step 19. The previous point first has to be saved in the linearization table before the next point can be entered. This means that complete linearization tables cannot be saved in the device. Once all the points have been entered, the table must be activated by means of the Edit Table/LINEARIZATION_TABLE_POST_EDIT parameter.	


	Description	
22	Set the Pressure Transducer Block to the "Auto" block mode.	
23	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
24	Result: – The linearization table has been entered. – The measured value display and the Primary Value/PRIMARY_VALUE parameter display the 2nd measured value (here the volume). – The Level Before Lin./LEVEL_BEFORE_LINEARISATION parameter displays the 1st measured value (here the height). See also Point 5 in the following note.	

1. For this level mode, the measured variables "height + %", "height + volume", "height + mass", "%-height + %", "%-height + volume" and "%-height + mass" are available. → 66 ff.
2. You can also specify customer-specific units. See parameter description for Calibration Units/CAL_UNIT (→ 57), Height Unit/HEIGHT_UNIT (→ 66), Unit Volume/VOLUME_UNIT (→ 68) and Unit Mass/MASS_UNIT (→ 69).
3. Once you have entered the maximum level to be expected for Level Max/LEVEL_MAX, the alarm "A707 X-Val of lin. table out of edit limits" can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-value of the linearization table, is greater than the maximum level entered. The message disappears as soon as the highest X-value is greater than the maximum level and the table entered is active.
4. The "Wet" calibration mode is not available by means of the FF operating programs.
5. You can use the Main Line Cont./DISPLAY_MAINLINE_CONTENT parameter (→ 92) to specify which measured value should be displayed on the local operation.

6 Flow measurement (FF configuration program)

In this chapter the parameter text as well as the parameter name are indicated.

In FF configuration programs only the parameter text is displayed (exception: in the NI-FBUS configurator you can select if the parameter text or the parameter name is displayed).



P01-xxxxxxx-07-xx-xx-en-001

6.1 Calibration

Example:

In this example, a volume flow should be measured in m³/h.

- The "Flow measurement" measuring mode is only available for the Deltabar S differential pressure transmitter.
- See also Operating Instructions BA00301P for Deltabar S, Section 6.5 "Flow measurement".
- For a description of the parameters mentioned, see
 - → 56, Pressure Transducer Block.
 - → 104, Analog Input Block.

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	P01-xMD7xxx-05-xx-xx-xx-010
2	Open the Pressure Transducer Block and set the block mode to OOS.	
3	Carry out position adjustment if necessary. The following options are available for performing position adjustment: ■ By means of the parameters – Pos.Zero Adjust/ ZERO_POSITION_ADJUST (→ 63) or – Pos. Input Value/POSITION_INPUT_VALUE (→ 63) or – Calib. Offset/CALIBRATION_OFFSET (→ 63).	
4	Select the measuring mode if necessary: ■ Select the "Flow square root" option by means of the Linearization/LINEARIZATION parameter. ■ By means of the Primary Value Type/PRIMARY_VALUE_TYPE parameter, select the "Flow" option.	
5	Select a pressure unit via the Calibration Units/CAL_UNIT parameter, here mbar for example.	
6	By means of the Flow-Meas. Type/FLOW_TYPE parameter, select the "Volume operat. cond." option.	
7	Select a flow unit via the Unit Flow/FLOW_UNIT parameter, here m ³ /h for example.	

Fig. 15: Flow measurement calibration

- 1 See Table, Step 8.
2 See Table, Step 9.

	Description	
8	Select the Scale Out/SCALE_OUT parameter, EU_100 element.	
	Enter the maximum flow value of the primary device, here 6000 m ³ /h for example. See also the layout sheet of the primary device.	

	Description	
9	Select the Scale In/SCALE_IN parameter, EU_100 element.	
	Enter the maximum pressure, here 400 mbar for example. See also the layout sheet of the primary device.	
10	Set the Pressure Transducer Block to the "Auto" block mode.	
11	Where necessary, configure the Channel/CHANNEL (→ 107), Linearization Type/L_TYPE (→ 108), Transducer Scale/XD_SCALE (→ 106) and Output Scale/OUT_SCALE (→ 107) parameters by means of the Analog Input Block.	
12	Result: The device is configured for flow measurement.	

- By means of the Flow-Meas. Type/FLOW_MEAS_TYPE parameter (→ 86), you can choose between the following flow types:
 - Volume operat. cond. (volume under operating conditions)
 - Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0 °C))
 - Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15 °C/59 °F))
 - Mass p. cond. (mass under operating conditions)
- The unit selected by means of the Unit Flow/STD_FLOW_UNIT parameter (→ 87) has to suit the flow type selected (Flow-Meas. Type/FLOW_MEAS_TYPE, → 86).
- In the lower measuring range, small flow quantities (creepages) can lead to large fluctuations in the measured value. You can activate low flow cut-off via the Low Flow Cut-Off/LOW_FLOW_CUT_OFF parameter (→ 84).

6.2 Totalizer

Example:

In this example, the volume flow should be totalized and displayed in the unit m^3E^3 . Negative flows should be added to the flow rate.

- For a description of the parameters mentioned, see
 - →  86, DP Flow Transducer Block
 - →  104, Analog Input Block.
- Totalizer 1 can be reset. Totalizer 2 cannot be reset.


	Description
1	Calibrate the device in accordance with Section 6.1.
2	Open the DP Flow Transducer Block.
3	By means of the Totalizer 1 Unit/TOTALIZER_1_UNIT parameter, select a flow unit, here m^3E^3 for example.
4	Use the Neg. Flow Tot. 1/TOTALIZER_1_MODE parameter to specify the totalizing mode for negative flows, here the "Positive" option for example.
5	Reset totalizer 1 to zero via the Reset Totalizer/TOTALIZER_1_RESET parameter.
6	Result: The Totalizer 1/TOTALIZER_1_VALUE parameter displays the totalized volume flow.

- You can also specify a customer-specific unit. → See parameter descriptions for Totalizer 1 Unit/TOTALIZER_1_UNIT (→  90).
- You can use the Main Line Cont./DISPLAY_MAINLINE_CONTENT parameter (→  92) to specify which measured value should be displayed on the local operation.
- The parameters for the 2nd totalizer, such as Total 2. Eng. Unit/TOTALIZER_2_UNIT, Neg. Flow Tot. 2/TOTALIZER_2_MODE and Totalizer 2/TOTALIZER_2_FLOAT can be found in the Pressure Transducer Block.

6.2.1 Resetting totalizer 1 automatically

By means of the Analog Alarm Block

With the aid of the Analog Alarm and Discrete Output Block, totalizer 1 in the DP Flow Transducer Block can be reset automatically.




P01-xxxxxxx-02-xc-xc-en-002

The DP Flow Transducer Block is connected to an Analog Input Block by means of the CHANNEL parameter (CHANNEL = 6). In the Analog Alarm Block, the HI_HI_LIM parameter is used to set a limit value at which the totalizer should be reset to zero. As soon as this limit value is overshoot, the Analog Alarm Block transmits an alarm value to the downstream Discrete Output Block. The latter changes its output from 0 to 1 and thus resets the totalizer in the DP Flow Transducer Block to 0. The output of the Analog Alarm Block changes back to 0.

By means of the Analog Input Block

With the aid of Analog Input and Discrete Output Block, totalizer 1 in the DP Flow Transducer Block can be reset automatically.




P01-xxxxxxx-02-xc-xc-en-004

The DP Flow Transducer Block is connected to an Analog Input Block by means of the CHANNEL parameter (CHANNEL = 6). In the Analog Input Block, the HI_HI_LIM parameter is used to set a limit value at which the totalizer should be reset to zero. As soon as this limit value is overshoot, the Analog Input Block transmits an alarm value to the downstream Discrete Output Block. The latter changes its output from 0 to 1 and thus resets the totalizer in the DP Flow Transducer Block to 0. The output of the Analog Input Block changes back to 0.

7 Parameter description (FF configuration program)

In this chapter the parameter text as well as the parameter name are indicated.

In FF configuration programs only the parameter text is displayed (exception: in the NI-FBUS configurator you can select if the parameter text or the parameter name is displayed).



P01-xxxxxxx-07-xx-xx-en-001

- With FOUNDATION Fieldbus, all the device parameters are categorized according to their functional properties and task and are assigned to the Resource Block, the Transducer Blocks and the function blocks. The parameters of the Resource Block, the Transducer Blocks and the Analog Input Block are described in this section. For a description of the parameters of the other function blocks, such as the PID or Discret Output Block, see Operating Instructions BA00013S "FOUNDATION Fieldbus Overview" or the FOUNDATION Fieldbus Specification.
- Some parameters are only relevant if other parameters are appropriately configured. For example, the Customer Unit P/CUSTOMER_UNIT_PRESSURE parameter is only relevant if the "User unit" option was selected beforehand via the Calibration Units/CAL_UNIT parameter. There is a comment in the parameter description here stating: Note: prerequisite: Calibration Units/CAL_UNIT = User unit.
- The menu path is indicated in the header of each table. You can use this path to get to the parameters in question.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. the "LINEARIZATION" function group for the "Level" measuring mode. If certain requirements have to be met for a function group, these are listed in the first row of the table.
- In the "Parameter name" column, the unique identification number (ID) of the parameter is indicated in brackets. This ID only appears on the local operation.

7.1 Cerabar S/Deltabar S/Deltapilot S block model

The Cerabar S/Deltabar S/Deltapilot S has the following blocks:

- Resource Block (device block)
- Transducer Blocks
 - Pressure Transducer Block

This Block supplies the output variables Primary Value/PRIMARY_VALUE and Temperature/MEASURED_TEMPERATURE. It contains all the parameters to configure the measuring device for the measuring task such as measuring mode selection, linearization function and unit selection.
 - Service Transducer Block

This Block supplies the output variables Counter: P > Pmax/COUNTER_PMAX, Max. Meas. Press./MAX_MEASURED_PRESSURE and Pressure/PRESSURE. It also includes all the counters for measuring range overshoot/undershoot for pressure and temperature, minimum and maximum measured values for pressure and temperature and the HistoROM function.
 - DP Flow Transducer Block (only Deltabar S)

This Block supplies the output variable Totalizer 1/TOTALIZER_1_VALUE and Totalizer 2/TOTALIZER_2_VALUE. It contains all the parameters that are needed to configure this totalizer.
 - Diagnostic Transducer Block

This Block does not return any alarm messages. It contains the simulation function for the Pressure Transducer Block, parameters to configure the alarm response and the user limits for pressure and temperature.
 - Display Transducer Block

This Block does not return any output variables. It contains all the parameters for configuring the local operation such as Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST.

■ Function blocks

- Deltabar S: 3 Analog Input Blocks (AI), Cerabar S and Deltapilot S: 2 Analog Input Blocks (AI)
- Discrete Output Block (DO)
- PID Block (PID)
- Arithmetic Block (ARB)
- Signal Characterizer Block (SCB)
- Input Selector Block (ISB)
- Analog Alarm Block (AALB)
- Integrator Block (IT)
- Discrete Input Block (DI)

Endress+Hauser Guideline BA00062S.

The guideline provides an overview of the standard function blocks that are described in FOUNDATION Fieldbus Specifications FF 890 - 894.

It is designed to help operators use the blocks implemented in the Endress+Hauser field devices.

Block configuration when device is delivered

The block model shown below illustrates the block configuration when the device is delivered.




Fig. 16: Block configuration when device is delivered

P01-xdMx7xxxx-02-xc-xc-en-000

Cerabar S/Deltapilot S

The Pressure Transducer Block returns the Primary Value (pressure measured value) and the Secondary Value (sensor temperature). The Primary Value and Secondary Value are each transmitted to an Analog Input Block via the Channel/CHANNEL parameter (→ 107, Channel/CHANNEL parameter description). The Discrete Output, Discrete Input, PID, Arithmetic, Signal Characterizer, Input Selector, Integrator and Analog Alarm Block are not connected in the as-delivered configuration. (IT, DI)

Deltabar S

The Pressure Transducer Block supplies the Primary Value and the sensor temperature. In the DP Flow Transducer Block, the flow is totalized in the "Flow" measuring mode and output by means of the Totalizer 1/TOTALIZER_1_VALUE parameter. The Primary Value, Secondary Value and Totalizer1/TOTALIZER_1_VALUE are each transmitted to one Analog Input Block via the Channel/CHANNEL parameter (→ 107, Channel/CHANNEL parameter description). The Discrete Output, PID, Arithmetic, Signal Characterizer, Input Selector and Analog Alarm Block are not connected in the as-delivered state. (IT, DI)

Please note that the links between the blocks are deleted and the FF parameters are reset to the default values following a reset by means of the Restart/RESTART parameter in the Resource Block, "Default" option.

7.2 Resource Block

Resource Block	
Parameter	Description
Static Revision/ST_REV Display Index: 1 Data type: unsigned16 Access: read only	Displays the counter for static parameters of the Resource Block. The counter is incremented by one with each change of a static parameter of the Resource Block. The counter counts up to 65535 and then starts again at zero.
Tag Description/TAG_DESC Entry Index: 2 Data type: octet string Access: auto, OOS	Enter a description for the related block or the measuring point e.g. TAG number (max. 32 alphanumeric characters).
Strategy/STRATEGY Entry Index: 3 Data type: unsigned16 Access: auto, OOS	Enter user-specific value for grouping and thus faster evaluation of the blocks. Grouping takes place by entering the same numerical value for the Strategy/STRATEGY parameter of the block in question. This value is neither checked nor processed by the Resource Block. Input range: 0...65535 Factory setting: 0
Alert Key/ALERT_KEY Entry Index: 4 Data type: unsigned8 Access: auto, OOS	Enter the identification number for the measuring device or for each individual block. The control level uses this identification number to sort alarm and event messages and initiate other processing steps. Input range: 1...255 Factory setting: 0
Block Mode/MODE_BLK Selection, display Index: 5 Data type: DS-69 Access: auto, OOS	The Block Mode/MODE_BLK parameter is a structured parameter consisting of four elements. The Resource Block supports the "Auto" (automatic) and OOS (out of service) modes. TARGET - Change the block mode. ACTUAL - Displays the current block mode. PERMITTED - Displays the modes supported by the block. NORMAL - Displays the block mode during standard operation.
Block Error/BLOCK_ERR Display Index: 6 Data type: bit string Access: read only	Displays the active block error. Possibilities: - Out of service: the Resource Block is in the OOS block mode. - Simulation active: DIP switch 2 "Simulation" on the electronic insert is set to "on", i.e. simulation is possible.
Resource State/RS_STATE Display Index: 7 Data type: unsigned8 Access: read only	Displays the current status of the Resource Block. Possibilities: - Standby: The Resource Block is in the OOS mode (out-of-service). The remaining blocks cannot be executed. - Online linking: The configured links between the function blocks have not yet been established. - Online: Standard block mode, the Resource Block operates in the auto mode. All the configured links between the function blocks have been established. If a link is missing, this parameter displays the "Online linking" status.

Resource Block	
Parameter	Description
Test Read Write/ TEST_RW Display Index: 8 Data type: DS-85 Access: auto, OOS	This parameter is required only for the FF conformance test and has no meaning in normal operation.
DD Resource/ DD_RESOURCE Index: 9 Data type: visible string Access: read only	String that indicates the tag of the resource that contains the device description for this resource.
Manufacturer ID/ MANUFAC_ID Display Index: 10 Data type: unsigned16 Access: read only	Displays the manufacturer's ID number. Endress+Hauser: 0 x 452B48 (decimal: 4533064)
Device Type/DEV_TYPE Display Index: 11 Data type: unsigned16 Access: read only	Displays the device ID number. Deltabar S: hexadecimal: 1009, decimal: 4105. Cerabar S: hexadecimal: 1007, decimal: 4103. Deltapilot S: hexadecimal: 0 x 100B, decimal: 4107.
Device Revision/ DEV_REV Display Index: 12 Data type: unsigned8 Access: read only	Displays the revision number of the device.
DD Revision/DD_REV Display Index: 13 Data type: unsigned8 Access: read only	Displays the revision number of the device description (DD).
Grant Deny/ GRANT_DENY Selection Index: 14 Data type: DS-70 Access: auto, OOS	Grant or restrict access authorization for a fieldbus host system to the device. This parameter is not evaluated by Deltabar S, Cerabar S and Deltapilot S.
Hard Types/ HARD_TYPES Display Index: 15 Data type: bit string Access: read only	Displays the output signal type for the Output function blocks.

Resource Block	
Parameter	Description
Restart/RESTART Selection Index: 16 Data type: unsigned8 Access: r, w	Select the reset mode. Options: ■ ENP_RESTART: A restart is needed to accept the ENP configuration changes. ■ Run: Standard operating mode ■ Resource: This mode is not supported by Endress+Hauser. ■ Defaults: The device data and the links of the function blocks are reset to the factory settings. The manufacturer-specific parameters of the Transducer Block are not reset to the factory settings. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Factory setting" (reset) section. ■ Processor: Warm start of device, processor restart. ■ Factory: The links of the function blocks, all FF-specific and resettable manufacturer-specific parameters are reset to the factory setting.
Features/FEATURES Display Index: 17 Data type: bit string Access: read only	Displays the additional functions supported by the device. → See also this Table, Feature Selection/FEATURE_SEL parameter description.
Feature Selection/FEATURE_SEL Selection Index: 18 Data type: bit string Access: auto, OOS	Select the additional device functions. The additional functions that the device supports are displayed in the Features/FEATURES parameter (→ 44).
Cycle Type/CYCLE_TYPE Display Index: 19 Data type: bit string Access: read only	Displays the block execution methods supported by the device. → See also this Table, Cycle Selection/CYCLE_SEL parameter description.
Cycle Selection/CYCLE_SEL Display Index: 20 Data type: bit string Access: auto, OOS	Displays the block execution method used by the fieldbus host system. The block execution method is selected by the fieldbus host system. Possibilities: ■ Scheduled: cyclical block execution method ■ Block execution: sequential block execution method
Minimum Cycle Time/MIN_CYCLE_T Display Index: 21 Data type: Unsigned32 Access: read only	Displays the shortest MACROCYCLE supported by the device. Factory setting: 3200 $\frac{1}{32}$ ms ($\approx$ 100 ms)
Memory Size/MEMORY_SIZE Display Index: 22 Data type: DS-69 Access: read only	Displays the available configuration memory in kilobytes. This parameter is not supported by Deltabar S, Cerabar S and Deltapilot S.
Nonvolatile Cycle Time/NV_CYCLE_T Display Index: 23 Data type: Unsigned32 Access: read only	Displays the time interval for which the dynamic device parameters are stored in the nonvolatile memory. Since the Cerabar S, Deltabar S and Deltapilot S units do not store the dynamic device parameters in the nonvolatile memory, the parameter always displays the value 0 $\frac{1}{32}$ ms.

Resource Block	
Parameter	Description
Free Space/ FREE_SPACE Display Index: 24 Data type: float Access: read only	Displays the system memory (in percent) available for the execution of further function blocks. Input range: 0...100 %
Free Time/FREE_TIME Display Index: 25 Data type: float Access: read only	Displays the free system time (in percent) available for the execution of further function blocks. Input range: 0...100 %
Shed Remote Cascade/ SHED_RCAS Entry Index: 26 Data type: Unsigned32 Access: auto, OOS	Enter the monitoring time for checking the connection between the fieldbus host system and the PID function block in the RCAS block mode. On expiry of this monitoring time the PID function block switches from the RCAS block mode to the block mode selected via the Shed Options/SHED_OPT parameter. Factory setting: 640000 $\frac{1}{32}$ ms
Shed Remote Out/ SHED_ROUT Entry Index: 27 Data type: Unsigned32 Access: auto, OOS	Enter the monitoring time for checking the connection between the fieldbus host system and the PID function block in the ROUT block mode. On expiry of this monitoring time the PID function block switches from the ROUT block mode to the block mode selected via the Shed Options/SHED_OPT parameter. Factory setting: 640000 $\frac{1}{32}$ ms
Fault State/ FAULT_STATE Display Index: 28 Data type: unsigned8 Access: read only	Current status display of the fault state of the Discrete Output function block. Possibilities: ■ Uninitialized ■ Clear (fault state not active) ■ Active (fault state active)
Set Fault State/ SET_FSTATE Selection Index: 29 Data type: unsigned8 Access: auto, OOS	Activate the fault state of the Discrete Output function block manually. → See also this Table, Clear Fault State/CLR_FSTATE parameter description. Possibilities: ■ Uninitialized ■ Off ■ Set (the fault state is enabled)
Clear Fault State/ CLR_FSTATE Selection Index: 30 Data type: unsigned8 Access: auto, OOS	Deactivate the fault state of the Discrete Output function block manually. → See also this Table, Set Fault State/SET_FSTATE parameter description. Possibilities: ■ Uninitialized ■ Off ■ Clear (fault state is disabled)
Max Notify/ MAX_NOTIFY Display Index: 31 Data type: unsigned8 Access: read only	Displays the number of event reports supported by the device that can exist unconfirmed at the same time. → See also this Table, Limit Notify/LIM_NOTIFY parameter description.
Limit Notify/ LIM_NOTIFY Entry Index: 32 Data type: unsigned8 Access: auto, OOS	Enter the maximum possible number of event reports that can exist unconfirmed at the same time. This parameter is not evaluated by Deltabar S, Cerabar S and Deltapilot S.

Resource Block	
Parameter	Description
Confirm Time/ CONFIRM_TIME Entry Index: 33 Data type: Unsigned32 Access: auto, OOS	Enter the confirmation time for the event report. If the device does not receive confirmation within this time, the event report is sent to the fieldbus host system again. Factory setting: 640000 $\frac{1}{32}$ ms
Write Lock/ WRITE_LOCK Display Index: 34 Data type: unsigned8 Access: read only	Displays the status of DIP switch 1 on the electronic insert. You can lock or unlock parameters relevant to the measured value with DIP switch 1. If operation is locked by means of the Insert Pin No/SW_LOCK parameter (→ 49), you can only unlock operation again by means of this parameter. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Possibilities: - Locked: Security locking switched on, i.e. the parameters cannot be written to. - Not locked: Security locking switched off. Depending on the block mode in question, it is possible to write to the parameters (→ see Tables, "Parameter" column, access). Factory setting: Locked (locking switched on)
Update Event/ UPDATE_EVT Display Index: 35 Data type: DS-73 Access: read only	The Update Event/UPDATE_EVT parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED - This element is set to "Unacknowledged" as soon as a static parameter changes. UPDATE_STATE - Indicates whether the change was reported. TIME_STAMP - Displays the date and time when a static parameter was changed. STATIC_REVISION - The revision counter is increased each time a static parameter is changed. RELATIVE_INDEX - Displays the altered parameter in the form of the relative index. See also this Table, "Parameter, Index" column.
Block Alarm/ BLOCK_ALM Display, selection Index: 36 Data type: DS-72 Access: auto, OOS	The Block Alarm/BLOCK_ALM parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED - If the "Deactivated" option was selected for the alarm that occurred by means of the Acknowledge Option/ACK_OPTION parameter, this alarm can only be acknowledged by means of this element. ALARM_STATE - Use this function to display the current block condition with information on pending configuration, hardware or system errors. The following block alarm messages are possible with the Resource Block: - Simulate active - Out of service TIME_STAMP - Displays the time when the alarm occurred. SUB_CODE - Displays the reason why the alarm was reported. VALUE - Displays the value of the corresponding parameter at the time the alarm was reported.

Resource Block	
Parameter	Description
Acknowledge Option/ ACK_OPTION Selection Index: 38 Data type: bit string Access: auto, OOS	Use this parameter to specify the process alarm to be acknowledged automatically as soon as it is detected by the fieldbus host system. If the option is activated for a process alarm, this process alarm is acknowledged automatically by the fieldbus host system. Options: ■ DiscAlm: write protection alarm ■ BlockAlm: block alarm The message has to be acknowledged via the Block Alarm/BLOCK_ALM parameter, UNACKNOWLEDGE element for process alarms for which automatic confirmation is not active. Factory setting: The option is not active for any process alarm, i.e. every process alarm message must be acknowledged manually.
Write Priority/ WRITE_PRI Entry Index: 39 Data type: unsigned8 Access: read only	If write protection is disabled, an alarm is issued. Use this parameter to specify the priority which should be assigned to this alarm. Input range: ■ 0...15 ■ 0: The alarm is suppressed. ■ 15: Critical alarm with the highest priority.
Write Alarm/ WRITE_ALM Display Index: 40 Data type: DS-72 Access: read only	The Write Alarm/WRITE_ALM parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED ■ If the "Deactivated" option was selected for the alarm that occurred by means of the Acknowledge Option/ACK_OPTION parameter, this alarm can only be acknowledged by means of this element. ALARM_STATE ■ Displays the status of the write protection alarm. TIME_STATE ■ Displays the time when the alarm occurred. SUB_CODE ■ Displays the reason why the alarm was reported. VALUE ■ Displays the value of the corresponding parameter at the time the alarm was reported.
ITK Version/ITK_VER Display Index: 41 Data type: unsigned16 Access: read only	Displays the revision version of the interoperability test kit (ITK).

Resource Block	
Parameter	Description
Capability Level/ CAPABILITY_LEVEL Index: 42 Data type: unsigned8 Access: read only	This parameter is integrated into a device to indicate what capability level is supported by the device: 1. Mnemonic parameter name: Capability Level/CAPABILITY_LEVEL 2. Object type/structure: Unsigned8 3. Use/model: C/Contained 4. Store: S 5. Size: 1 6. Valid range: 0-255 7. Initial value: 0 8. Direction: 9. Units: not specified 10. Rights: 11. Mode: 12. Other: read only 13. Range check: 14. Block access: not part of View 1, 2, 3, 4 15. Description: capability level supported by the device. A value of zero (0) indicates that the device does not support multiple capability levels.
ENP Version/ENP_VER Index: 44 Data type: visible string Access: read only	This parameter indicates the version of the standard for electronic nameplates supported by the device.
Device Tag/ DEVICE_TAG Index: 45 Data type: visible string Access: read, write, OOS	The Device Tag/DEVICE_TAG currently configured via the device.
Device Serial No./ SERIAL_NUMBER Display Index: 46 Data type: float Access: read, write (service), OOS	Displays the serial number of the main electronics (11 alphanumeric characters).
Order Code/ORDER_ CODE Display Index: 47 Data type: visible string Access: read, write (service), OOS	Displays the device order code.
ENP Version/ ENP_VERSION Display Index: 48 Data type: float Access: read only	Displays the software version e.g.: V04.00.

Resource Block	
Parameter	Description
Insert Pin No./ SW_LOCK Entry Index: 49 Data type: unsigned16 Access: read, write, AUTO, OOS	For entering a code to lock or unlock operation. - The -symbol on the local operation indicates that operation is locked. Parameters which refer to how the display appears, e.g. Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST, can still be altered. - If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation, you can only unlock operation again using remote operation. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Options: - Lock: Enter a number between 0 and 9999 and ≠100. - Unlock: Enter the number 100. Factory setting: 100
Status Locking/ STATUS_LOCKING Index: 50 Data type: unsigned16 Access: read only	Displays the current locking status of the device or conditions that can lock the device (hardware locking, software locking).
FD_VER Index: 51 Data type: unsigned16 Access: read only	A parameter that is equal to the value of the main version of the field diagnostic specification on the basis of which this device was designed.
FD_FAIL_ACTIVE Index: 52 Data type: bit enumerated Access: read only	This parameter displays the fault conditions, which have been recognized as active, as selected for this category. This is a sequence of bits so several conditions can be displayed.
FD_OFFSPEC_ACTIVE Index: 53 Data type: bit enumerated Access: read only	This parameter displays the fault conditions, which have been recognized as active, as selected for this category. This is a sequence of bits so several conditions can be displayed.
FD_MAINT_ACTIVE Index: 54 Data type: bit enumerated Access: read only	This parameter displays the fault conditions, which have been recognized as active, as selected for this category. This is a sequence of bits so several conditions can be displayed.
FD_CHECK_ACTIVE Index: 55 Data type: bit enumerated Access: read only	This parameter displays the fault conditions, which have been recognized as active, as selected for this category. This is a sequence of bits so several conditions can be displayed.
FD_FAIL_MAP Index: 56 Data type: bit enumerated Access: AUTO, OOS	This parameter maps conditions that should be recognized as active for this alarm category. Therefore the same condition can be active in all, some, or none of the 4 alarm categories.

Resource Block	
Parameter	Description
FD_OFFSPEC_MAP Index: 57 Data type: bit enumerated Access: AUTO, OOS	This parameter maps conditions that should be recognized as active for this alarm category. Therefore the same condition can be active in all, some, or none of the 4 alarm categories.
FD_MAINT_MAP Index: 58 Data type: bit enumerated Access: AUTO, OOS	This parameter maps conditions that should be recognized as active for this alarm category. Therefore the same condition can be active in all, some, or none of the 4 alarm categories.
FD_CHECK_MAP Index: 59 Data type: bit enumerated Access: AUTO, OOS	This parameter maps conditions that should be recognized as active for this alarm category. Therefore the same condition can be active in all, some, or none of the 4 alarm categories.
FD_FAIL_MASK Index: 60 Data type: bit enumerated Access: AUTO, OOS	With this parameter the user can prevent some or more conditions, which are active in this category, from being broadcast to the host by the alarm parameter. A bit that is equal to "1" masks (i.e. suppresses) the broadcasting of a condition. A bit that is equal to "0" on the other hand allows the condition to be broadcast.
FD_OFFSPEC_MASK Index: 61 Data type: bit enumerated Access: AUTO, OOS	With this parameter the user can prevent some or more conditions, which are active in this category, from being broadcast to the host by the alarm parameter. A bit that is equal to "1" masks (i.e. suppresses) the broadcasting of a condition. A bit that is equal to "0" on the other hand allows the condition to be broadcast.
FD_MAINT_MASK Index: 62 Data type: bit enumerated Access: AUTO, OOS	With this parameter the user can prevent some or more conditions, which are active in this category, from being broadcast to the host by the alarm parameter. A bit that is equal to "1" masks (i.e. suppresses) the broadcasting of a condition. A bit that is equal to "0" on the other hand allows the condition to be broadcast.
FD_CHECK_MASK Index: 63 Data type: bit enumerated Access: AUTO, OOS	With this parameter the user can prevent some or more conditions, which are active in this category, from being broadcast to the host by the alarm parameter. A bit that is equal to "1" masks (i.e. suppresses) the broadcasting of a condition. A bit that is equal to "0" on the other hand allows the condition to be broadcast.
FD_FAIL_ALM Index: 64 Data type: DS87 Access: AUTO, OOS	This parameter is primarily used to broadcast a change in the associated active - unsuppressed - conditions for this alarm category to a host system.
FD_OFFSPEC_ALM Index: 65 Data type: DS87 Access: AUTO, OOS	This parameter is primarily used to broadcast a change in the associated active - unsuppressed - conditions for this alarm category to a host system.
FD_MAINT_ALM Index: 66 Data type: DS87 Access: AUTO, OOS	This parameter is primarily used to broadcast a change in the associated active - unsuppressed - conditions for this alarm category to a host system.

Resource Block	
Parameter	Description
FD_CHECK_ALM Index: 67 Data type: DS87 Access: AUTO, OOS	This parameter is primarily used to broadcast a change in the associated active - unsuppressed - conditions for this alarm category to a host system.
FD_FAIL_PRI Index: 68 Data type: unsigned8 Access: AUTO, OOS	The user can define a priority for this alarm category via this parameter.
FD_OFFSPEC_PRI Index: 69 Data type: unsigned8 Access: AUTO, OOS	The user can define a priority for this alarm category via this parameter.
FD_MAINT_PRI Index: 70 Data type: unsigned8 Access: AUTO, OOS	The user can define a priority for this alarm category via this parameter.
FD_CHECK_PRI Index: 71 Data type: unsigned8 Access: AUTO, OOS	The user can define a priority for this alarm category via this parameter.
FD_SIMULATE Index: 72 Data type: DS89 Access: AUTO, OOS	If simulation is enabled, the conditions can be effectuated manually via this parameter. If simulation is disabled, the diagnostic simulation value and the diagnostic value track the actual conditions. If simulation is to be enabled, the jumper for simulation is required; while simulation is enabled the recommended action indicates that simulation is enabled.
FD_RECOMMEN_ACT Index: 73 Data type: enumerated Access: read only	This parameter constitutes a summary, numbered by device, of the most difficult conditions, or conditions that have been identified. The DD Help uses numbered measures to describe the action to be taken to rectify the condition or conditions. 0 is defined as "not initialized" and 1 as "no action required"; all the others have been defined by the manufacturer.
Hardware Rev./ HARDWARE_REVISION Display Index: 74 Data type: visible string Access: read only	Displays the revision number of the main electronics e.g. V01.00
FF comm. version/ FF_COMM_VERSION Index: 75 Data type: visible string Access: read only	This parameter comprises the version number of the communication stack software used in the device.
Block Error desc./ BLOCK_ERR_DESC_1 Index: 76 Data type: bit enumerated Access: read only	This parameter is used by the device to provide more specific details on ongoing errors that have been reported via BLOCK_ERR.

Resource Block	
Parameter	Description
Device Dialog/DEVICE DIALOG Display Index: 77 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.
Electr. Serial No./ELECTRONIC_SERIAL_NUMBER Display Index: 78 Data type: visible string Access: read only	Displays the serial number of the main electronics (11 alphanumeric characters).
Proc. Conn. Type/PROCESS_CONNECTION_TYPE Selection Index: 79 Data type: unsigned16 Access: read, write, AUTO, OOS	For selecting and displaying the process connection type. Options: ■ Not used ■ Unknown ■ Special ■ Oval flange ■ Thread female ■ Thread male ■ Flange ■ Remote seal
Mat. Proc. Conn. +/MAT_PROC_CONN_POS Selection Index: 80 Data type: float Access: read, write, AUTO, OOS	For selecting and displaying the material of the process connection (P+). → See also parameter description for Mat. Proc. Conn. -/MAT_PROC_CONN_NEG Options: ■ Not used ■ Unknown ■ Special ■ Steel ■ 304 st. steel ■ 316 st. steel ■ Alloy C ■ Monel ■ Tantalum ■ Titanium ■ PTFE (Teflon) ■ 316L st. steel ■ PVC ■ Inconel ■ PVDF ■ ECTFE Factory setting: As per order specifications
Mat. Proc. Conn. -/MAT_PROC_CONN_NEG Selection Index: 81 Data type: float Access: read, write, AUTO, OOS	For selecting and displaying the material of the process connection (P-). → See also parameter description for Mat. Proc. Conn. +/MAT_PROC_CONN_POS

Resource Block	
Parameter	Description
Seal Type/SEAL_TYPE Selection Index: 82 Data type: visible string Access: read, write, AUTO, OOS	For selecting and displaying the material of the process seal. Options: ■ Not used ■ Unknown ■ Special ■ FKM Viton ■ NBR ■ EPDM ■ Urethane ■ IIR ■ Kalrez ■ FKM Viton oxyg ■ CR ■ MVQ ■ PTFE glass ■ PTFE graphite ■ PTFE oxygen ■ Copper ■ Copper f. oxygen Factory setting: As per order specifications
SCI_OCTET_STR/ SCI_OCTET_STRING Display Index: 83 Data type: visible string Access: read, write, OOS	Internal service parameter.
Resource Directory/ MS_RESOURCE_ DIRECTORY Index: 84 Data type: unsigned16 Access: read only	This parameter is a field of the UINT16 parameter which describes the arrangement of the extended parameters in groups. – Group ID (UINT16) – Number of the parameter in the group (UINT16) – Relative group revision index in the Resource Block of the first parameter in the group (UINT16)

7.3 Transducer Blocks

7.3.1 FOUNDATION Fieldbus Transducer Blocks standard parameters

Transducer Block, FOUNDATION Fieldbus standard parameters (all Transducer Blocks)	
Parameter	Description
Static Revision/ST_REV Display Index: 1 Data type: unsigned16 Access: read only	Displays the counter for static parameters of the Transducer Block. The counter is incremented by one with each change of a static parameter of the corresponding Transducer Block. The counter counts up to 65535 and then starts again at zero.
Tag Description/ TAG_DESC Entry Index: 2 Data type: octet string Access: auto, OOS	Enter a description for the related block or the measuring point e.g. TAG number (max. 32 alphanumeric characters). Factory setting: Empty field
Strategy/STRATEGY Entry Index: 3 Data type: unsigned16 Access: auto, OOS	Enter user-specific value for grouping and thus faster evaluation of the blocks. Grouping takes place by entering the same numerical value for the Strategy/STRATEGY parameter of the block in question. These data are neither checked nor processed by the Transducer Blocks. Input range: 0...65535 Factory setting: 0
Alert Key/ALERT_KEY Entry Index: 4 Data type: unsigned8 Access: auto, OOS	Enter the identification number for the measuring device or for each individual block. The control level uses this identification number to sort alarm and event messages and initiate other processing steps. Input range: 1...255 Factory setting: 0
Block Mode/ MODE_BLK Selection, display Index: 5 Data type: DS-69 Access: auto, OOS	The Block Mode/MODE_BLK parameter is a structured parameter consisting of four elements. The Transducer Blocks support the "Auto" (automatic) and OOS (out of service) modes. TARGET - Change the block mode. ACTUAL - Displays the current block mode. PERMITTED - Displays the modes supported by the block. NORMAL - Displays the block mode during standard operation. Measured values or information can be forwarded to an Analog Input Block via the Pressure, Service and DP Flow Transducer Block. If the Pressure Transducer Block is set to the OOS block mode, the Primary Value and Secondary Value continue to be updated but the status of the downstream Analog Input Block changes to BAD.
Block Error/ BLOCK_ERR Display Index: 6 Data type: bit string Access: read only	Displays the warning messages and error messages of the software and hardware of the Transducer Block in question. In addition, this parameter triggers an alarm. If two or more messages occur simultaneously, the message with the highest priority is shown on the display. For the Pressure, Service and Totalizer Block, see possible messages, these Operating Instructions, Section 12.1 "Messages". The Display and Diagnostic Block do not display any warnings or error messages.

Transducer Block, FOUNDATION Fieldbus standard parameters (all Transducer Blocks)	
Parameter	Description
Update Event/ UPDATE_EVT Display Index: 7 Data type: DS-73 Access: read only	The Update Event/UPDATE_EVT parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED - This element is set to "Unacknowledged" as soon as a static parameter changes. UPDATE_STATE - Indicates whether the change was reported. TIME_STAMP - Displays the date and time when a static parameter was changed. STATIC_REVISION - The revision counter is increased each time a static parameter is changed. RELATIVE_INDEX - Displays the altered parameter in the form of the relative index. See also this Table, "Parameter, Index" column.
Block Alarm/ BLOCK_ALM Display, selection Index: 8 Data type: DS-72 Access: auto, OOS	The Block Alarm/BLOCK_ALM parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED - If the "Deactivated" option was selected for the alarm that occurred by means of the Acknowledge Option/ACK_OPTION parameter, this alarm can only be acknowledged by means of this element. ALARM_STATE - Use this function to display the current block condition with information on pending configuration, hardware or system errors. TIME_STAMP - Displays the date and time when the alarm occurred. SUB_CODE - Displays the reason why the alarm was reported. VALUE - Displays the value of the corresponding parameter at the time the alarm was reported.
Transducer Directory Entry/ TRANSDUCER_DIRECTORY Display Index: 9 Data type: unsigned16 Access: read only	A directory that specifies the number of transducers, and their indexes, mapped in the Pressure Transducer Block. This parameter is only displayed in the Pressure Transducer Block. Display: 0: Only one transducer is mapped in the Pressure Transducer Block.
Transducer Type/ TRANSDUCER_TYPE Display Index: 10 Data type: unsigned16 Access: read only	Displays the Transducer Block type.
Transducer Error/ XD_ERROR Display Index: 11 Data type: unsigned8 Access: read only	Displays the active device state. → See also these Operating Instructions, Section 12.1 "Messages". Prerequisite: - Pressure Transducer Block - Service Transducer Block - DP Flow Transducer Block (only Deltabar S)
Collection Directory/ COLLECTION_DIRECTORY Display Index: 12 Data type: Unsigned32 Access: read only	A directory that specifies the number of parameter groups (data collection), and their indexes and DD item IDS, mapped in the Pressure Transducer Block. This parameter is only displayed in the Pressure Transducer Block. Display: 0: This parameter is not used.

7.3.2 Pressure Transducer Block

Pressure Transducer Block	
Parameter	Description
Primary Value Type/ PRIMARY_VALUE_TYP E Selection Index: 13 Data type: unsigned16 Access: OOS	Select the measuring mode and the measured variable by means of this parameter and the Linearization/LINEARIZATION parameter (→ 61). → See also Operating Instructions for Deltabar S (BA00301P) and Cerabar S (BA00302P) or BA00372P (Deltapilot S), "Selecting the language and measuring mode" section. Options ■ Differential pressure with Deltabar S ■ Deltapilot S with gauge pressure sensors ■ Gauge pressure with Cerabar S with gauge pressure sensors ■ Absolute pressure with Cerabar S with absolute pressure sensors ■ Level ■ Volume ■ Mass ■ Flow (only Deltabar S) ■ Tank content (PV) in % Make sure that the unit selected by means of the Scale Out/SCALE_OUT parameter, "Units Index" element suits the measured variable.
Primary Value/ PRIMARY_VALUE Display Index: 14 Data type: DS-65 Access: read only	The Primary Value/PRIMARY_VALUE parameter is a structured parameter consisting of two elements. VALUE ■ Displays the primary value - a pressure, level or flow value depending on the measuring mode. STATUS ■ Displays the status of the primary value. You can transmit the value and status of the Primary Value/PRIMARY_VALUE parameter via the Channel/CHANNEL parameter (→ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "1" for this purpose.
Primary Value Range/ PRIMARY_VALUE_RAN GE Display Index: 15 Data type: DS-68 Access: read only	The Primary Value Range/PRIMARY_VALUE_RANGE parameter is a structured parameter consisting of four elements. EU_100 ■ Displays the upper limit for the primary value. EU_0 ■ Displays the lower limit for the primary value. UNITS_INDEX ■ Displays the unit. DECIMAL ■ Displays the number of decimal places. The Primary Value Range/PRIMARY_VALUE_RANGE parameter corresponds to the Scale Out/SCALE_OUT parameter (→ 62).
Calibration Highest Point/CAL_POINT_HI Entry Index: 16 Data type: float Access: OOS	Enter the upper point of the sensor characteristic curve in the event of sensor recalibration. By means of this parameter, you can assign a new target pressure value to a reference pressure present at the device. The pressure value present and the target pressure value specified for this parameter correspond to the upper point in the sensor characteristic curve. Position adjustment has to be performed again for the device following sensor recalibration. ■ The sensor recalibration can be reset via the Enter Reset Code / ENTER_RESET_CODE parameter (→ 98) with the "2509" code. ■ The Hi Trim Measured/HIGH_TRIM_MEASURED parameter (→ 64) displays the pressure value that was present at the device during calibration and was used for calibrating the upper point of the sensor characteristic curve. ■ For calibrating the lower point of the sensor characteristic curve, see the parameter description for Calibration Lowest Point/CAL_POINT_LO. Factory setting: High sensor limit (→ Sensor Range/SENSOR_RANGE, EU_100 element)

Pressure Transducer Block	
Parameter	Description
Calibration Lowest Point/CAL_POINT_LO Entry Index: 17 Data type: float Access: OOS	Enter the lower point of the sensor characteristic curve in the event of sensor recalibration. By means of this parameter, you can assign a new target pressure value to a reference pressure present at the device. The pressure value present and the target pressure value specified for this parameter correspond to the lower point in the sensor characteristic curve. Position adjustment has to be performed again for the device following sensor recalibration. ■ The sensor recalibration can be reset via the Enter Reset Code / ENTER_RESET_CODE parameter (→ 98) with the "2509" code. ■ The Lo Trim Measured/LOW_TRIM_MEASURED parameter (→ 64) displays the pressure value that was present at the device during calibration and was used for calibrating the lower point of the sensor characteristic curve. ■ For calibrating the upper point of the sensor characteristic curve, see the parameter description for Calibration Highest Point/CAL_POINT_HI. Factory setting: Low sensor limit (→ Sensor Range/SENSOR_RANGE, EU_0 element)
Calibration Minimum Span/CAL_MIN_SPAN Display Index: 18 Data type: float Access: OOS	Displays the smallest possible span.
Calibration Units/CAL_UNIT Entry Index: 19 Data type: unsigned16 Access: OOS	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → see also parameter descriptions for Customer Unit P/ CUSTOMER_UNIT_PRESSURE (→ 64) and Cust. Unit Fact. P/ CUSTOMER_FACTOR_UNIT_PRESS (→ 64). Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications

Pressure Transducer Block	
Parameter	Description
Sensor Type/ SENSOR_TYPE Selection Index: 20 Data type: unsigned16 Access: OOS	Depending on the sensor type. Factory setting: "Capacitance", "Piezo resistive" or "MANUFACTOR SPEC". ▪ Flow sensor unknown ▪ Coriolis ▪ Electromagnetic ▪ mV ▪ Ohms ▪ Delta Ohms ▪ Nuclear magnetic resonance ▪ Positive displacement ▪ Refraction ▪ Taggin ▪ Ultrasonic (Doppler) ▪ Ultrasonic (time of travel) ▪ Target ▪ Variable Area ▪ Level sensor unknown ▪ Radar ▪ Capacitance ▪ Nuclear ▪ Ultrasonic ▪ Float gauge ▪ Pressure sensor unknown ▪ Resonant wire ▪ Vibrating beam ▪ Strain gauge ▪ Piezo resistive ▪ Silicon resonant ▪ Temperature sensor unknown ▪ PT100_A_385 (IEC 751) ▪ PT100_A_392 (JIS 1604) ▪ PT200_A_385 (IEC 751) ▪ PT500_A_385 (IEC 751) ▪ NI120, Edison #7 ▪ CU10, Edison #15 ▪ T/C Type B (IEC 584-1 und NIST 175) ▪ T/C Type C (NIST 175) ▪ T/C Type E (IEC 584-1 und NIST 175) ▪ T/C Type J (IEC 584-1 und NIST 175) ▪ T/C Type K (IEC 584-1 und NIST 175) ▪ T/C Type N (IEC 584-1 und NIST 175) ▪ T/C Type R (IEC 584-1 und NIST 175) ▪ T/C Type S (IEC 584-1 und NIST 175) ▪ T/C Type T (IEC 584-1 und NIST 175) ▪ T/C Type DIN L (DIN 43710) ▪ T/C Type DIN U (DIN 43710) ▪ MANUFACTOR SPEC. ▪ Non-Std Snsr
Sensor Range/ SENSOR_RANGE Display Index: 21 Data type: DS-68 Access: read only	The Sensor Range/SENSOR_RANGE parameter is a structured parameter consisting of four elements. EU_100 ▪ Displays the upper measuring limit of the sensor. EU_0 ▪ Displays the lower measuring limit of the sensor. UNITS_INDEX ▪ Displays the unit selected. DECIMAL ▪ Displays the number of decimal places.

Pressure Transducer Block	
Parameter	Description
Sensor Serial Number/ SENSOR_SN Display Index: 22 Data type: visible string Access: read only	Displays the serial number of the sensor (11 alphanumeric characters).
Sensor Calibration Method/ SENSOR_CAL_METHO D Selection Index: 23 Data type: unsigned8 Access: OOS	For displaying and selecting the last sensor calibration mode used.
Sensor Calibration Location/ SENSOR_CAL_LOC Entry Index: 24 Data type: visible string Access: OOS	Enter the place the sensor was calibrated (32 alphanumeric characters).
Sensor Calibration Date/ SENSOR_CAL_DATE Entry Index: 25 Data type: date Access: OOS	Enter the date and time the sensor was calibrated.
Sensor Calibration Who/ SENSOR_CAL_WHO Entry Index: 26 Data type: visible string Access: OOS	Enter the name of the person who calibrated the sensor (32 alphanumeric characters).
Sensor Isolator Metal/ SENSOR_ISOLATOR_M TL Display Index: 27 Data type: unsigned16 Access: read only	Displays the material of the process isolating diaphragm.
Sensor Fill Fluid/ SENSOR_FILL_FLUID Display Index: 28 Data type: unsigned16 Access: read only	Displays the filling fluid.

Pressure Transducer Block	
Parameter	Description
Temperature/ MEASURED_TEMPERA TURE Index: 32 Data type: DS-65 Access: read only	Select the unit for the second process value. See also the parameter description for Temp. Eng. Unit/ MEASURED_TEMPERATURE_UNIT. Value - Displays the second process value, here the sensor temperature. Status - Displays the second process value, here the sensor temperature. You can transmit the value and status of the Temperature/ MEASURED_TEMPERATURE parameter via the Channel/CHANNEL parameter (→ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "2" for this purpose.
Temp. Eng. Unit/ MEASURED_TEMPERA TURE_UNIT Index: 33 Data type: unsigned16 Access: read, write, OOS	Select the unit for the second process value. See also the parameter description for Temp. Eng. Unit/ MEASURED_TEMPERATURE_UNIT.
Device Dialog/DEVICE DIALOG Display Index: 34 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.
Insert Pin No./ SW_LOCK Entry Index: 35 Data type: unsigned16 Access: read, write, AUTO, OOS, MAN	For entering a code to lock or unlock operation. - The  symbol on the on-site display indicates that operation is locked. Parameters which refer to how the display appears, e.g. Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST, can still be altered. - If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation, you can only unlock operation again using remote operation. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Options - Lock: Enter a number between 0 and 9999 and ≠100. - Unlock: Enter the number 100. Factory setting: 100
Status Locking/ STATUS_LOCKING Index: 36 Data type: unsigned16 Access: read only	Displays the current locking status of the device or conditions that can lock the device (hardware locking, software locking).

Pressure Transducer Block	
Parameter	Description
Linearization/ LINEARIZATION Selection Index: 37 Data type: unsigned8 Access: read, write, OOS	Select the measuring mode and the measured variable by means of this parameter and the Primary Value Type/PRIMARY_VALUE_TYPE parameter (→ 56). → See also Operating Instructions for Deltabar S (BA00301P) and Cerabar S (BA00302P) or BA00372P (Deltapilot S), "Selecting the language and measuring mode" section. Options: ■ No linearization ("Pressure" or "Level" measuring mode) ■ Level linearized ("Level" measuring mode) ■ Level combined ("Level" measuring mode) ■ % level combined ("Level" measuring mode) ■ Flow square root ("Flow" measuring mode) The option selected for this parameter can also affect the setting of the Level Mode/LEVEL_MODE parameter (→ 65), e.g. if "Level linearized" is selected, the Level Mode/LEVEL_MODE parameter is set to the "Pressure linearized" option. Make sure that the unit selected by means of the Scale Out/SCALE_OUT parameter, "Units Index" element suits the measured variable.
Scale In/SCALE_IN Entry Index: 38 Data type: DS-65 Access: read, write, OOS	The Scale In/SCALE_IN parameter is a structured parameter consisting of four elements. EU_100 ■ "Pressure" measuring mode; "Level easy pressure" measuring mode; "Level easy height" measuring mode; "Level standard" measuring mode, "Linear" or "Height linearized" level mode: enter the upper limit for the pressure value of the Transducer Block. ■ "Level standard" measuring mode, "Pressure linearized" level mode: Enter the maximum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum hydrostatic pressure to be expected, the more accurate the measurement result. ■ "Flow" measuring mode: Enter the maximum pressure of the primary device. → See layout sheet of primary device. This value is assigned to the maximum flow value (→ See the following Scale Out/SCALE_OUT parameter, EU_100 element). ■ Factory setting: Upper range limit of the sensor EU_0 ■ "Pressure" measuring mode; "Level easy pressure" measuring mode; "Level easy height" measuring mode; "Level standard" measuring mode, "Linear" or "Height linearized" level mode, "Flow" measuring mode: enter the lower limit for the pressure value of the Transducer Block. ■ "Level standard" measuring mode, "Pressure linearized" level mode: Enter the minimum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum hydrostatic pressure to be expected, the more accurate the measurement result. ■ Factory setting: 0 UNITS_INDEX ■ Select the unit for input scaling. DECIMAL ■ Displays the number of decimal places.

Pressure Transducer Block	
Parameter	Description
Scale Out/SCALE_OUT Entry Index: 39 Data type: DS-68 Access: read, write, OOS	The Scale Out/SCALE_OUT parameter is a structured parameter consisting of four elements. EU_100 ■ "Pressure" measuring mode; "Level easy pressure" measuring mode; "Level easy height" measuring mode; "Level standard" measuring mode, "Linear" level mode: enter the upper limit for the output value of the Transducer Block. Factory setting: 100 ■ "Level standard" measuring mode, "Pressure linearized" or "Height linearized" level mode: Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result. Factory setting: 100 ■ "Flow" measuring mode: Enter the maximum flow of the primary device. See also the layout sheet of the primary device. The maximum flow is assigned to the maximum pressure you enter via the Scale In/SCALE_IN parameter, EU_100 element. Factory setting: 1.0 EU_0 ■ "Pressure" measuring mode; "Level easy pressure" measuring mode; "Level easy height" measuring mode; "Level standard" measuring mode, "Linear" level mode; "Flow" measuring mode: enter the lower limit for the output value of the Transducer Block. ■ "Level standard" measuring mode, "Pressure linearized" or "Height linearized" level mode: Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result. ■ Factory setting: 0 UNITS_INDEX ■ Select the unit for output scaling. DECIMAL ■ Enter the number of decimal places. Make sure that the unit selected by means of the Scale Out/SCALE_OUT parameter, "Units Index" element suits the measured variable. → See also the parameter descriptions for Primary Value Type/ PRIMARY_VALUE_TYPE (→ 56) and Linearization/LINEARIZATION (→ 73).
Damping Value/ DAMPING_VALUE Entry Index: 40 Data type: float Access: read, write, OOS	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value (Primary Value) and output value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification

Pressure Transducer Block	
Parameter	Description
Pos.Zero Adjust/ ZERO_POSITION_ADJUST Selection Index: 41 Data type: unsigned8 Access: read, write, OOS	Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the Primary Value/PRIMARY_VALUE parameter does not display zero. This parameter provides the possibility of performing position adjustment where the pressure difference between zero (set point) and the measured pressure need not be known. (A reference pressure is present at the device.) Example: – Primary Value/PRIMARY_VALUE = 2.2 mbar (0.033 psi) – Correct the Primary Value/PRIMARY_VALUE via the Pos.Zero Adjust/ZERO_POSITION_ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – Primary Value/PRIMARY_VALUE (after pos. zero adjust) = 0.0 mbar The Calib. Offset/CALIBRATION_OFFSET parameter (→ 63) displays the resulting pressure difference (offset) by which the Primary Value/PRIMARY_VALUE was corrected. Options: ■ Abort ■ Confirm Factory setting: 0.0
Pos. Input Value/ POSITION_INPUT_VALUE Entry Index: 42 Data type: float Access: read, write, OOS	Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the PRIMARY_VALUE parameter does not display zero or the desired value. This parameter provides the possibility of performing position adjustment where the pressure difference between zero (set point) and the measured pressure need not be known. (A reference pressure is present at the device.) Example: – Primary Value/PRIMARY_VALUE = 0.5 mbar (0.0075 psi) – For the Pos. Input Value/POSITION_INPUT_VALUE parameter, specify the desired set point for the Primary Value/PRIMARY_VALUE, for example 2.0 mbar (0.03 psi). – (The following applies: $PRIMARY_VALUE_{new} = PRESSURE_1_ACCEPT_INSTALL_OFFSET$) – Primary Value/PRIMARY_VALUE (after entry for Pos. Input Value/POSITION_INPUT_VALUE) = 2.0 mbar – The Calib. Offset/CALIBRATION_OFFSET parameter (→ 63) displays the resulting pressure difference (offset) by which the PRIMARY_VALUE was corrected. (The following applies: $PRESSURE_1_INSTALL_OFFSET = PRIMARY_VALUE_{old} - PRESSURE_1_ACCEPT_INSTALL_OFFSET$, here: $PRESSURE_1_INSTALL_OFFSET = 0.5 \text{ mbar} - 2.0 \text{ mbar} = -1.5 \text{ mbar}$) Factory setting: 0.0
Calib. Offset/ CALIBRATION_OFFSET Entry Index: 43 Data type: float Access: read, write, OOS	Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the PRIMARY_VALUE parameter does not display zero or the desired value. This parameter provides the possibility of performing position adjustment where the pressure difference between zero (set point) and the measured pressure is known. (A reference pressure is not present at the device.) Example: – Primary Value/PRIMARY_VALUE = 2.2 mbar (0.033 psi) – Via the Calib. Offset/CALIBRATION_OFFSET parameter, enter the value by which the Primary Value/PRIMARY_VALUE should be corrected. To correct the Primary Value/PRIMARY_VALUE to 0.0 mbar, you must enter the value 2.2 here. (The following applies: $PRIMARY_VALUE_{new} = PRIMARY_VALUE_{old} - PRESSURE_1_INSTALL_OFFSET$) – Primary Value/PRIMARY_VALUE (after entry for calib. offset) = 0.0 mbar Factory setting: 0.0

Pressure Transducer Block	
Parameter	Description
Customer Unit P/ CUSTOMER_UNIT_PRESSURE Entry Index: 44 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also Cust. Unit. Fact. P/CUSTOMER_FACTOR_UNIT_PRESS Prerequisite: Calibration Units/CAL_UNIT (→ 57) = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: - - - - -
Cust. Unit. Fact. P/ CUSTOMER_FACTOR_UNIT_PRESS Entry Index: 45 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also Customer Unit P/CUSTOMER_UNIT_PRESSURE. Prerequisite: - Calibration Units/CAL_UNIT (→ 57) = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - Primary Value/PRIMARY_VALUE = 10000 Pa i 1 PU - Enter Customer Unit P/CUSTOMER_UNIT_PRESSURE: PU - Enter Cust. Unit. Fact. P/CUSTOMER_FACTOR_UNIT_PRESS: 0.0001 - Result: Primary Value/PRIMARY_VALUE = 1 PU Factory setting: 1.0
Lo Trim Measured/ LOW_TRIM_MEASURED Display Index: 46 Data type: float Access: read only	Displays the pressure that was present at the device during calibration and was used for the calibration of the lower point of the sensor characteristic curve. → See also the parameter description for Calibration Lowest Point/CAL_POINT_LO (→ 57).
Hi Trim Measured/ HIGH_TRIM_MEASURED Display Index: 47 Data type: float Access: read only	Displays the pressure that was present at the device during calibration and was used for the calibration of the upper point of the sensor characteristic curve. → See also the parameter description for Calibration Highest Point/CAL_POINT_HI (→ 56).

Pressure Transducer Block	
Parameter	Description
Level Mode/ LEVEL_MODE Selection Index: 48 Data type: unsigned8 Access: read, write, OOS	Select the level mode Options: ■ Linear: The measured variable (level, volume, mass or %) is in direct proportion to the measured pressure. → 22 ff, Section 5.4. ■ Pressure linearized: The measured variable (volume, mass or %) is not in direct proportion to the measured pressure such as in the case of containers with a conical outlet. For the calibration, enter a linearization table with at least 2 and not more than 32 points. → 26 ff, Section 5.5. ■ Height linearized: Select this level mode if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume. The following combinations are possible: – Height + volume – Height + mass – Height + % – %-height + volume – %-height + mass – %-height + % Perform two calibrations for this level mode. First for the measured variable height or %-height like for the "Linear" option and then for the measured variable volume, mass or % like for the "Pressure linearized" option. → 32 ff, Section 5.6. This parameter can only be changed if the settings for the Linearization/LINEARIZATION (→ 73) and Primary Value Type/PRIMARY_VALUE_TYPE (→ 56) parameters suit it, e.g. if the "Flow square root" option was selected for the Linearization/LINEARIZATION parameter, this parameter cannot be changed. Factory setting: Linear
Lin. Measurand/ LINEAR_MEASURAND Selection Index: 49 Data type: unsigned8 Access: read, write, OOS	Select the measured variable. Options: ■ Level ■ Volume ■ Mass ■ % (level) This parameter can only be changed if the setting for the Linearization/LINEARIZATION parameter (→ 73) suits it, e.g. if the "Flow square root" option was selected for the Linearization/LINEARIZATION parameter, this parameter cannot be changed. Factory setting: % (level)
Lind. Measurand/ LINEARIZED_MEASURAND Selection Index: 50 Data type: unsigned8 Access: read, write, OOS	Select the measured variable. Options: ■ Pressure and volume ■ Pressure and mass ■ Pressure and % This parameter can only be changed if the setting for the Linearization/LINEARIZATION parameter (→ 73) suits it, e.g. if the "Flow square root" option was selected for the Linearization/LINEARIZATION parameter, this parameter cannot be changed. Factory setting: Pressure and %


Pressure Transducer Block	
Parameter	Description
Comb. Measurand/ COMBINED_MEASURAND Selection Index: 51 Data type: Unsigned8 Access: read, write, OOS	Select the measured variable. Options: ■ Height and volume ■ Height and mass ■ Height and % ■ %-height and volume ■ %-height and mass ■ %-height and % This parameter can only be changed if the setting for the Linearization/ LINEARIZATION parameter (→ 73) suits it, e.g. if the "Flow square root" option was selected for the Linearization/LINEARIZATION parameter, this parameter cannot be changed. Factory setting: %-height and %
Density Unit/ DENSITY_UNIT Selection Index: 52 Data type: unsigned16 Access: read, write, OOS	Select the density unit. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = %-height and %, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height and volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height and mass, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and %, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and mass, Calibration Mode/CALIBRATION_MODE = Dry – Comb. Measurand = COMBINED_MEASURAND – Calibration Mode = CALIBRATION_MODE Options: ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ Factory setting: kg/dm ³
Height Unit/ HEIGHT_UNIT Selection Index: 53 Data type: unsigned16 Access: read, write, OOS	Select the level unit. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = Height and volume, height and mass or height and % Options: ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also Customer Unit H/CUSTOMER_HEIGHT_UNIT (→ 67) and Cust. Unit Fact. H/CUSTOMER_UNIT_FACTOR_HEIGHT (→ 67) Factory setting: m

Pressure Transducer Block	
Parameter	Description
Customer Unit H/ CUSTOMER_HEIGHT_UNIT Selection Index: 54 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also Cust. Unit. Fact. H/CUSTOMER_UNIT_FACTOR_HEIGHT. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = Height and volume, Height Unit/HEIGHT_UNIT = User unit ■ Comb. Measurand/COMBINED_MEASURAND = Height and mass, Height Unit/HEIGHT_UNIT = User unit ■ Comb. Measurand/COMBINED_MEASURAND = Height and %, Height Unit/HEIGHT_UNIT = User unit – Comb. Measurand = COMBINED_MEASURAND – Height Unit = HEIGHT_UNIT Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: _ _ _ _ _
Cust. Unit. Fact. H/ CUSTOMER_UNIT_FACTOR_HEIGHT Entry Index: 55 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also Customer Unit H/CUSTOMER_HEIGHT_UNIT. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = Height and volume, Height Unit/HEIGHT_UNIT = User unit ■ Comb. Measurand/COMBINED_MEASURAND = Height and mass, Height Unit/HEIGHT_UNIT = User unit ■ Comb. Measurand/COMBINED_MEASURAND = Height and %, Height Unit/HEIGHT_UNIT = User unit – Comb. Measurand = COMBINED_MEASURAND – Height Unit = HEIGHT_UNIT Example: – You want the measured value to be displayed in "PU" (PU: packing unit). – Primary Value/PRIMARY_VALUE = 0.5 m i 1 PU – Enter Customer Unit H/CUSTOMER_HEIGHT_UNIT: PU – Enter Cust. Unit. Fact. H/CUSTOMER_UNIT_FACTOR_HEIGHT: 2 – Result: Primary Value/PRIMARY_VALUE = 1 PU Factory setting: 1.0

Pressure Transducer Block	
Parameter	Description
Unit Volume/ VOLUME_UNIT Selection Index: 56 Data type: unsigned16 Access: read, write, OOS	Select the volume unit. Prerequisite: - Comb. Measurand/COMBINED_MEASURAND = Height and volume or %-height and volume Options: - l - hl - cm³ - dm³ - m³ - m³ E³ - ft - ft³ E³ - gal - lgal - bbl - User unit, → see also Customer Unit V/CUSTOMER_UNIT_VOLUME (→ 68) and Cust. Unit. Fact. V/CUSTOMER_UNIT_FACTOR_VOLUME (→ 68) Factory setting: m³
Customer Unit V/ CUSTOMER_UNIT_VOLUME Entry Index: 57 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also Cust. Unit. Fact. V/CUSTOMER_UNIT_FACTOR_VOLUME. Prerequisite: - Comb. Measurand/COMBINED_MEASURAND = Height and volume, Unit Volume/VOLUME_UNIT = User unit - Comb. Measurand/COMBINED_MEASURAND = %-height and volume, Unit Volume/VOLUME_UNIT = User unit - Comb. Measurand = COMBINED_MEASURAND - Unit Volume = VOLUME_UNIT Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: - - - - -
Cust. Unit. Fact. V/ CUSTOMER_UNIT_FACTOR_VOLUME Entry Index: 58 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also Customer Unit V/CUSTOMER_UNIT_VOLUME. Prerequisite: - Comb. Measurand/COMBINED_MEASURAND = Height and volume, Unit Volume/VOLUME_UNIT = User unit - Comb. Measurand/COMBINED_MEASURAND = %-height and volume, Unit Volume/VOLUME_UNIT = User unit - Comb. Measurand = COMBINED_MEASURAND - Unit Volume = VOLUME_UNIT Example: - You want the measured value to be displayed in "buckets". - Primary Value/PRIMARY_VALUE = 0.01 m³ i 1 bucket - Enter Customer Unit V/CUSTOMER_UNIT_VOLUME: bucket - Enter Cust. Unit. Fact. V/CUSTOMER_UNIT_FACTOR_VOLUME : 100 - Result: Primary Value/PRIMARY_VALUE = 1 bucket Factory setting: 1.0

Pressure Transducer Block	
Parameter	Description
Unit Mass/MASS_UNIT Selection Index: 59 Data type: unsigned16 Access: read, write, OOS	Select the mass unit. Prerequisite: ■ Lind. Measurand./LINEARIZED_MEASURAND = Pressure and mass Options: ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter descriptions for Customer Unit M/CUSTOMER_UNIT_MASS (→ 69) and Cust. Unit Fact. M/CUSTOMER_UNIT_FACTOR_MASS (→ 69) Factory setting: kg
Customer Unit M/CUSTOMER_UNIT_MASS Entry Index: 60 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also Cust. Unit Fact. M/CUSTOMER_UNIT_FACTOR_MASS. Prerequisite: ■ Lind. Measurand./LINEARIZED_MEASURAND = Pressure and mass, Unit Mass/MASS_UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: -----
Cust. Unit Fact. M/CUSTOMER_UNIT_FACTOR_MASS Entry Index: 61 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also Customer Unit M/CUSTOMER_UNIT_MASS. Prerequisite: ■ Lind. Measurand./LINEARIZED_MEASURAND = Pressure and mass, Unit Mass/MASS_UNIT = User unit Example: - You want the measured value to be displayed in "buckets". - Primary Value/PRIMARY_VALUE = 10 kg i 1 bucket - Enter Customer Unit M/CUSTOMER_UNIT_MASS: bucket - Enter Cust. Unit Fact. M/CUSTOMER_UNIT_FACTOR_MASS: 0.1 - Result: Primary Value/PRIMARY_VALUE = 1 bucket Factory setting: 1.0


Pressure Transducer Block	
Parameter	Description
Calibration Mode/ CALIBRATION_MODE Selection Index: 62 Data type: unsigned8 Access: read, write, OOS	Select the calibration mode. Options: ■ Wet: option without a function ■ Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. – For the "Level" measured variable, the density of the fluid (→ 70: Adjust Density/ADJUST_DENSITY) must be entered. – For the "Volume" measured variable, the density of the fluid and the tank volume and tank height must be entered (→ 70: Adjust Density/ADJUST_DENSITY, → 72: Tank Volume/TANK_VOLUME and → 72: Tank Height/TANK_HEIGHT). – For the "Mass" measured variable, the tank volume and tank height must be entered (→ 72, Tank Volume/TANK_VOLUME and → 72: Tank Height/TANK_HEIGHT). In the event of a zero point shift (level offset), the density also has to be entered (→ 70, Adjust Density/ADJUST_DENSITY). – For the "%" measured variable, the density of the fluid has to be entered and a level also has to be assigned to the 100 % point (→ 70: Adjust Density/ADJUST_DENSITY and → 72: 100% Point/HUNDRED_PERCENT_VALUE). If the measurement should not start at the mounting location of the device, a level offset must be entered (→ 71: Zero Point/ZERO_POSITION). Factory setting: Wet
Adjust Density/ ADJUST_DENSITY Entry Index: 63 Data type: float Access: read, write, OOS	Enter the density of the fluid. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = %-height and %, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height and volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height and mass, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and %, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = Height and mass, Calibration Mode/CALIBRATION_MODE = Dry – Comb. Measurand = COMBINED_MEASURAND – Calibration Mode = CALIBRATION_MODE Factory setting: 1.0

Pressure Transducer Block	
Parameter	Description
Zero Point/ ZERO_POSITION Entry Index: 64 Data type: float Access: read, write, OOS	Enter the value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset). Prerequisite: - Calibration Mode/CALIBRATION_MODE = Dry Factory setting: 0.0  P01-PMP75xxx-19-xx-xx-xx-001 <i>Fig. 17: Zero point shift</i> - Device is mounted above the level lower-range value: a positive value has to be entered for the LEVEL_ADJUST_MODE/ZERO POINT parameter. - Device is mounted below the level lower-range value: a negative value has to be entered for the LEVEL_ADJUST_MODE/ZERO POINT parameter.
Empty Calib./ EMPTY_CALIBRATION Entry Index: 65 Data type: float Access: read, write, OOS	Enter the level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → see also Empty Pressure Level Easy/EMPTY_PRESSURE_EASY. Prerequisite: Calibration Mode/CALIBRATION_MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 0.0
Full Calib./ FULL_CALIBRATION Entry Index: 66 Data type: float Access: read, write, OOS	Enter the level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also Full Pressure Level Easy/FULL_PRESSURE_EASY. Prerequisite: Calibration Mode/CALIBRATION_MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 100.0

Pressure Transducer Block	
Parameter	Description
Tank Volume/ TANK_VOLUME Entry Index: 67 Data type: float Access: read, write, OOS	Enter the tank volume. Prerequisite: ■ Lin. Measurand/LINEAR_MEASURAND = Volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Lin. Measurand/LINEAR_MEASURAND = Mass, Calibration Mode/CALIBRATION_MODE = Dry – Lin. Measurand = LINEAR_MEASURAND – Calibration Mode = CALIBRATION_MODE Factory setting: 1.0 m ³
Tank Height/TANK HEIGHT Entry Index: 68 Data type: float Access: read, write, OOS	Enter the tank height. Prerequisite: ■ Lin. Measurand/LINEAR_MEASURAND = Volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Lin. Measurand/LINEAR_MEASURAND = Mass, Calibration Mode/CALIBRATION_MODE = Dry – Lin. Measurand = LINEAR_MEASURAND – Calibration Mode = CALIBRATION_MODE Factory setting: 1.0 m
100% Point/ HUNDRED_PERCENT_VALUE Entry Index: 69 Data type: float Access: read, write, OOS	Enter the level value for the 100% point. Prerequisite: ■ Comb. Measurand/COMBINED_MEASURAND = %-height and volume, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height and mass, Calibration Mode/CALIBRATION_MODE = Dry ■ Comb. Measurand/COMBINED_MEASURAND = %-height + %, Calibration Mode/CALIBRATION_MODE = Dry – Comb. Measurand = COMBINED_MEASURAND – Calibration Mode = CALIBRATION_MODE Example: – The 100 %-point should correspond to 4 m. – Select the "m" unit via the Height Unit/HEIGHT_UNIT parameter. – Enter the value "4" for this 100% Point/HUNDRED_PERCENT_VALUE parameter. Factory setting: 1.0
Level Min/LEVEL_MIN Entry Index: 70 Data type: float Access: read, write, OOS	Enter the minimum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum level to be expected, the more accurate the measurement result. Factory setting: 0.0
Level Max/ LEVEL_MAX Entry Index: 71 Data type: float Access: read, write, OOS	Enter the maximum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum level to be expected, the more accurate the measurement result. Factory setting: 100.0
Process Density/ PROCESS_DENSITY Entry Index: 72 Data type: float Access: read, write, OOS	Enter a new density value for density correction. The calibration was carried out with the medium water, for example. Now the container is to be used for another fluid with another density. The calibration is corrected appropriately by entering the new density value in the Process Density/PROCESS_DENSITY parameter. Factory setting: 1.0

Pressure Transducer Block	
Parameter	Description
Table Selection/ LINEARIZATION_ TABLE_SELECTION Index: 73 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values. Options: ■ View meas. table ■ Editor table Factory setting: View meas. table
Lin. Edit Mode/ LINEARIZATION_ EDIT_MODE Entry Index: 74 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select the entry mode for the linearization table. Options: ■ Manual: The container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearization table. ■ Semiautomatic: The container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. Factory setting: Manual
Editor Table/ LINEARIZATION_ TABLE_PRE_EDIT Index: 75 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select table. Prerequisite: ■ Table Selection/LINEARIZATION_TABLE_SELECTION = Editor table Options: ■ New table: Enter a new linearization table. ■ Edit measure table: The measuring table is loaded as an editor table so that changes can be made. → See also TAB. SELECTION ■ Continue edit: Edit an editor table that already exists. → See also EDITOR TABLE (770). Factory setting: New table
Line-Numb/ LINEARIZATION_ TABLE_INDEX Index: 76 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Enter the line number for the linearization table. A linearization table must have at least 2 points and may not have more than 32 points. ■ Table Selection/LINEARIZATION_TABLE_SELECTION = View meas. table Via this parameter you can select the point of the linearization table which should be displayed. ■ Table Selection/LINEARIZATION_TABLE_SELECTION = Editor table Enter a point via the Line-Numb/LINEARIZATION_TABLE_INDEX, X-Val/LINEARIZATION_TABLE_X_VALUE and Y-Val/LINEARIZATION_TABLE_Y_VALUE parameters. See also this table, parameter descriptions for Lin. Edit Mode/LINEARIZATION_EDIT_MODE, X-Val/LINEARIZATION_TABLE_X_VALUE ("Manual" entry mode), X-Val/LINEARIZATION_TABLE_X_VALUE ("Semiautomatic" entry mode) and Y-Val/LINEARIZATION_TABLE_Y_VALUE. In the operating program, you can enter a complete linearization table in one go, and view it, via the "Lin.-Tab." window.
X-Val/ LINEARIZATION_TABL E_X_VALUE (manual) Index: 77 Data type: float Access: read, write, AUTO, OOS, MAN	Enter the pressure value for the linearization table. → See also Lin. Edit Mode/LINEARIZATION_EDIT_MODE, Line-Numb/LINEARIZATION_TABLE_INDEX and Y-Val/LINEARIZATION_TABLE_Y_VALUE. Prerequisite: ■ Table Selection/LINEARIZATION_TABLE_SELECTION = Editor table

Pressure Transducer Block	
Parameter	Description
X-Val/ LINEARIZATION_TABLE_X_VALUE (semiautomatic) Index: 77 Data type: float Access: read, write, AUTO, OOS, MAN	In the "Semiautomatic" entry mode, the container is filled or emptied in stages. The X-Val/LINEARIZATION_TABLE_X_VALUE displays the measured hydrostatic pressure. Prerequisite: Table Selection/LINEARIZATION_TABLE_SELECTION = Editor table Operating program The X-Val/LINEARIZATION_TABLE_X_VALUE is saved by confirming the Y-value. HARD handheld Confirm X-Val/LINEARIZATION_TABLE_X_VALUE displayed. → See also Lin. Edit Mode/LINEARIZATION_EDIT_MODE, Line-Numb/LINEARIZATION_TABLE_INDEX and Y-Val/LINEARIZATION_TABLE_Y_VALUE.
Y-Val/ LINEARIZATION_TABLE_Y_VALUE Index: 78 Data type: float Access: read, write, AUTO, OOS, MAN	Enter the volume, mass or %-value belonging to the X-Val/LINEARIZATION_TABLE_X_VALUE for the linearization table. Prerequisite: Table Selection/LINEARIZATION_TABLE_SELECTION = Editor table Depending on the setting in the Lind. Measurand/LINEARIZED_MEASURAND or Comb. Measurand/COMBINED_MEASURAND parameters, enter a volume, mass or %-value here. → See also table, parameter description for Lin. Edit Mode/LINEARIZATION_EDIT_MODE, Line-Numb/LINEARIZATION_TABLE_INDEX, X-Val/LINEARIZATION_TABLE_X_VALUE ("Manual" entry mode), X-Val/LINEARIZATION_TABLE_X_VALUE ("Semiautomatic" entry mode).
Table Editor/ LINEARIZATION_TABLE_POST_EDIT Index: 79 Data type: unsigned8 Access: read, write, OOS	Select the function for the editor table. Options: - Next point: no function - Last input point: no function - Accept input table: save editor table as measuring table. This overwrites the old measuring table. - Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. - Insert point: see example below. - Delete point: the current point is deleted. See example below. Example: Add point, in this case between the 4th and 5th point for example - Select Point 5 via the Line-Numb/LINEARIZATION_TABLE_INDEX parameter. - Using the Editor Table/LINEARIZATION_TABLE_POST_EDIT parameter, select the "Insert point" option. - Point 5 is displayed for the Line-Numb/LINEARIZATION_TABLE_INDEX parameter. Enter new values for the X-Val/LINEARIZATION_TABLE_X_VALUE and Y-Val/LINEARIZATION_TABLE_Y_VALUE parameters. Example: Delete point, in this case the 5th point for example - Select Point 5 via the Line-Numb/LINEARIZATION_TABLE_INDEX parameter. - Using the Editor Table/LINEARIZATION_TABLE_POST_EDIT parameter, select the "Delete point" option. - The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5. Factory setting: Next point
Measuring Table/ LINEARIZATION_TABLE_POST_VIEW Index: 80 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select the function for the measuring table. Options: - Next point: view next point of the measuring table. - Last input point: view previous point of the measuring table. - Abort: cancel measuring table display. Display next parameter. Factory setting: Next point

Pressure Transducer Block	
Parameter	Description
Tank Description/ LEVEL_TANK_ DESCRIPTION Entry Index: 81 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter tank description. (max. 32 alphanumeric characters) Factory setting: -----
Sensor Pressure/ SENSOR_PRESSURE Display Index: 82 Data type: float Access: read only	Displays the measured pressure before sensor trim, position adjustment and damping. → See also the following graphic, parameter description for Pressure/PRESSURE.
Pressure/PRESSURE Display Index: 83 Data type: float Access: read only	Displays the measured pressure after sensor trim, position adjustment and damping. This value corresponds to the Primary Value/PRIMARY_VALUE parameter in the "Pressure" measuring mode.  P01-xMD7xxxx-05-xx-xx-en-011
Level Before Lin/ LEVEL_BEFORE_ LINEARISATION Display Index: 84 Data type: float Access: read only	Displays the level value prior to linearization. Prerequisite: Level Mode/LEVEL_MODE = Linear or height linearized Depending on the setting for the Lin. Measurand/LINEAR_MEASURAND or Comb. Measurand/COMBINED_MEASURAND parameter, this parameter displays the current level in % or in a unit of level.
Sensor Meas.Type/ SENSOR_MEAS_TYPE Display Index: 85 Data type: unsigned16 Access: read only	Displays the sensor type. - Deltabar S = Differential - Cerabar S with gauge pressure sensors = Relative - Cerabar S with absolute pressure sensors = Absolute - Deltapilot S with gauge pressure sensors = Relative

Pressure Transducer Block	
Parameter	Description
Level Selection/ LEVEL_SELECTION Index: 86 Data type: unsigned8 Access: read, write, OOS	Select the level mode. Prerequisite: - Measuring Mode = Level - With regard to the "Level easy pressure" and "Level easy height" level modes, the values entered are not tested as extensively as in the "Level standard" level mode. In the "Level easy pressure" and "Level easy height" level modes, the values entered for Empty Calib./EMPTY_CALIBRATION, Full Calib./FULL_CALIBRATION, Empty Pressure Level Easy/EMPTY_PRESSURE_EASY, Full Pressure Level Easy/FULL_PRESSURE_EASY, Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY, Full Calib. Level Easy/FULL_CALIBRATION_EASY must be at least 1% apart. The value will be rejected with a message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly. → For an overview of the different level modes and types, see Page 13 Section 5.1 and Page 117 Section 9.1 "Overview of level measurement". - The "Level easy pressure" and "Level easy height" level modes comprise fewer parameters than the "Level standard" mode and are used to quickly and easily configure a level application. - Customer-specific units of level, volume and mass, or a linearization table, can only be entered in the "Level standard" level mode. Prerequisite: - Level easy pressure You specify two pressure-level value pairs for this level mode. The pressure measured value is converted directly to the unit which is selected via the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter (→ Page 77. The two calibration modes, "Wet" and "Dry", are available. - Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. - Dry calibration is a theoretical calibration. For this calibration, you specify two pressure-level value pairs via the Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY, Empty Pressure Level Easy/EMPTY_PRESSURE_EASY, Full Calib. Level Easy/FULL_CALIBRATION_EASY and Full Pressure Level Easy/FULL_PRESSURE_EASY parameters. Parameter description, see Page 72 ff. - Level easy height For this level mode, you specify a height unit, the density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height unit. The two calibration modes, "Wet" and "Dry", are available. - Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. - Dry calibration is a theoretical calibration. For this calibration, you specify two height-level value pairs via the Empty Height Level Easy/EMPTY_HEIGHT_EASY, Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY, Full Height Level Easy/FULL_HEIGHT_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY parameters. → Parameter description, see Page 72 ff. - Level standard Once you have selected this level mode, you can use the Level Mode/LEVEL_MODE parameter (→ → Page 65) to choose between "Linear", "Pressure linearized" and "Height linearized". Factory setting: Level easy pressure

Pressure Transducer Block	
Parameter	Description
Height Unit/ HEIGHT_UNIT_EASY Index: 87 Data type: unsigned16 Access: read, write, OOS	Select the height unit. The measured pressure is converted to the chosen height unit using the Density Unit Level Easy/DENSITY_UNIT_EASY and Adjust Density Level Easy/ADJUST_DENSITY_EASY parameters. Options: ■ mm ■ cm ■ dm ■ m ■ inch ■ ft Factory setting: m
Output Unit Level Easy/ OUTPUT_UNIT_EASY Index: 88 Data type: unsigned16 Access: read, write, OOS	Select the unit for the measured value display and the MEASURED VALUE parameter (→ Page 214). The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted. Example: ■ Current measured value: 0.3 ft ■ New output unit: m ■ New measured value: 0.3 m (9.8 ft) Options: ■ % ■ mm, cm, dm, m ■ ft, inch ■ cm³, dm³, m³, m³E³ ■ l, hl ■ ft³, ft³E³ ■ gal, bbl, lgal ■ g, kg, t ■ lb, ton, oz Factory setting: %
Calibration Mode Level Easy/ CALIBRATION_MODE_EASY Index: 89 Data type: unsigned8 Access: read, write, OOS	Select the calibration mode. Options: ■ Wet Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. (→ See also this table, parameter descriptions for Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY and Full Calib. Level Easy/FULL_CALIBRATION_EASY) ■ Dry Dry calibration is a theoretical calibration. For this calibration, you specify two pressure-level value pairs via the following parameters: Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY, Empty Pressure Level Easy/EMPTY_PRESSURE_EASY, Full Calib. Level Easy/FULL_CALIBRATION_EASY and Full Pressure Level Easy/FULL_PRESSURE_EASY. Factory setting: Wet
Density Unit Level Easy/ DENSITY_UNIT_EASY Index: 90 Data type: unsigned16 Access: read, write, OOS	Select the density unit. The measured pressure is converted to a height unit using the Height Unit/HEIGHT_UNIT_EASY, Density Unit Level Easy/DENSITY_UNIT_EASY and Adjust Density Level Easy/ADJUST_DENSITY_EASY. Options: ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ Factory setting: kg/dm³

Pressure Transducer Block	
Parameter	Description
Adjust Density Level Easy/ ADJUST_DENSITY_EASY Index: 91 Data type: FLOAT Access: read, write, OOS	Enter the density of the fluid. The measured pressure is converted to a height unit using the Height Unit/HEIGHT_UNIT_EASY, Density Unit Level Easy/DENSITY_UNIT_EASY and Adjust Density Level Easy/ADJUST_DENSITY_EASY. Factory setting: 1.0
Empty Height Level Easy/ EMPTY_HEIGHT_EASY Index: 92 Data type: FLOAT Access: read, write, OOS	Enter the level, volume, mass or percentage value for the lower calibration point (empty container). The values entered for the Empty Height Level Easy/EMPTY_HEIGHT_EASY and Empty Pressure Level Easy/EMPTY_PRESSURE_EASY parameters form the pressure-level value pair for the lower calibration point. The unit is selected via the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter (→ Page 77). Prerequisite: Calibration Mode Level Easy/CALIBRATION_MODE_EASY = Dry Factory setting: 0.0
Full Height Level Easy/ FULL_HEIGHT_EASY Index: 93 Data type: FLOAT Access: read, write, OOS	Enter the height, volume, mass or percentage value for the upper calibration point (container full). The values entered for the Full Height Level Easy/FULL_HEIGHT_EASY and Full Pressure Level Easy/FULL_PRESSURE_EASY parameters form the pressure-level value pair for the upper calibration point. The unit is selected via the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter (→ Page 77). Prerequisite: Calibration Mode Level Easy/CALIBRATION_MODE_EASY = Dry Factory setting: 100.0
Process Density Level Easy/ PROCESS_DENSITY_EASY Index: 94 Data type: FLOAT Access: read, write, OOS	Enter a new density value for density correction. The calibration was carried out with the medium water, for example. Now the container is to be used for another fluid with another density. The calibration is corrected appropriately by entering the new density value in the Process Density Level Easy/PROCESS_DENSITY_EASY parameter. If you change to dry calibration after a wet calibration using the Calibration Mode Level Easy/CALIBRATION_MODE_EASY parameter (→ Page 174), the density for the Adjust Density Level Easy/ADJUST_DENSITY_EASY and Process Density Level Easy/PROCESS_DENSITY_EASY parameters must be entered correctly before changing the calibration mode. If the pressure falls with increasing levels, such as in the case of a residual volume measurement, a negative value must be entered for this parameter. Factory setting: 1.0
Meas.Level Easy/ MEASURED_LEVEL_EASY Index: 95 Data type: Access: read only	Displays the measured level.
Full Calib. Level Easy/ FULL_CALIBRATION_EASY Index: 96 Data type: FLOAT Access: read, write, OOS	Enter the value for the upper calibration point (container full). The unit is selected via the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter (→ Page 77). Factory setting: 100 %

Pressure Transducer Block	
Parameter	Description
Empty Calib. Level Easy/ EMPTY_CALIBRATION_EASY Index: 97 Data type: FLOAT Access: read, write, OOS	Enter the height value for the lower calibration point (container empty). The unit is selected via the Output Unit Level Easy/OUTPUT_UNIT_EASY parameter (→ Page 77). Factory setting: 0.0
Full Pressure Level Easy/ FULL_PRESSURE_EASY Index: 98 Data type: FLOAT Access: read, write, OOS	Enter the pressure value for the upper calibration point (container full). → See also Full Calib. Level Easy/FULL_CALIBRATION_EASY. Prerequisite: Calibration Mode Level Easy/CALIBRATION_MODE_EASY = Dry Factory setting: 100.0
Empty Pressure Level Easy/ EMPTY_PRESSURE_EASY Index: 99 Data type: FLOAT Access: read, write, OOS	Enter the pressure value for the lower calibration point (container empty). → See also Empty Calib. Level Easy/EMPTY_CALIBRATION_EASY. Prerequisite: Calibration Mode Level Easy/CALIBRATION_MODE_EASY = Dry Factory setting: 0.0

7.3.3 Service Transducer Block

Service Transducer Block	
Parameter	Description
Device Dialog/DEVICE DIALOG Display Index: 11 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.
Insert Pin No./SW_LOCK Display Index: 12 Data type: unsigned16 Access: read, write, AUTO, OOS, MAN	For entering a code to lock or unlock operation. - The -symbol on the local operation indicates that operation is locked. Parameters which refer to how the display appears, e.g. Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST, can still be altered. - If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation, you can only unlock operation again using remote operation. → See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), Section 5.6 "Locking/unlocking operation". Options: - Lock: Enter a number between 0 and 9999 and ≠100. - Unlock: Enter the number 100. Factory setting: 100
Status Locking/STATUS_LOCKING Display Index: 13 Data type: unsigned16 Access: read only	Displays the current locking status of the device or conditions that can lock the device (hardware locking, software locking).

Service Transducer Block	
Parameter	Description
Config. Recorder/ CONFIGURATION_COUNTER Display Index: 14 Data type: unsigned16 Access: read only	Displays the configuration counter. This counter is incremented by one with each change of a manufacturer-specific parameter. The counter counts up to 65535 and then starts again at zero. Changes to parameters that configure the local operation, such as the Language/DISPLAY_LANGUAGE parameter, do not cause an increase in the counter value.
Pcb Temperature/ ELECTRONICS_TEMPERATURE Display Index: 15 Data type: float Access: read only	Displays the measured temperature of the main electronics.
Allowed Min. Temp/ ELECTRONICS_TEMP_LOW_LIMIT Display Index: 16 Data type: float Access: read only	Displays the lower temperature limit of the main electronics.
Allowed Max. Temp/ ELECTRONICS_TEMP_HIGH_LIMIT Index: 17 Data type: float Access: read only	Displays the upper temperature limit of the main electronics.
Pmax Proc. Conn./ PMAX_PROC_CONN Entry Index: 18 Data type: float Access: read, write, AUTO, OOS, MAN	For entering and displaying the maximum permitted pressure of the process connection. Factory setting: In accordance with nameplate data (→ See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), "Nameplates" section)
Sensor Meas.Type/ SENSOR_MEAS_TYPE Display Index: 19 Data type: unsigned16 Access: read only	Displays the sensor type. ■ Deltabar S = Differential ■ Cerabar S with gauge pressure sensors = Relative ■ Cerabar S with absolute pressure sensors = Absolute ■ Deltapilot S with gauge pressure sensors = Relative
Tmin Sensor/SENSOR_TEMP_LOW_LIMIT Display Index: 22 Data type: float Access: read only	Displays the lower nominal temperature limit of the sensor.
Tmax Sensor/ SENSOR_TEMP_HIGH_LIMIT Display Index: 23 Data type: float Access: read only	Displays the upper nominal temperature limit of the sensor.

Service Transducer Block	
Parameter	Description
Sens H/Ware Rev/ SENSOR_HARDWARE_REV Display Index: 24 Data type: unsigned8 Access: read only	Displays the revision number of the sensor hardware. e.g.: 01.00.00
Counter: P > Pmax/ COUNTER_PMAX Display Index: 25 Data type: DS-65 Access: read only	The Counter: P > Pmax/COUNTER_PMAX parameter is a structured parameter consisting of two elements. VALUE - Displays the overpressure counter of the sensor The limit value is: upper nominal pressure limit of sensor + 10 % of upper nominal pressure limit of sensor. You can reset this counter via the Reset Peakhold/RESET_PEAK_HOLD parameter. STATUS - Displays the status. - You can transmit the value and status of the Counter: P > Pmax/COUNTER_PMAX parameter via the Channel/CHANNEL parameter (→ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "5" for this purpose. - You can transmit the value and status of the Counter: P > Pmax/COUNTER_PMAX parameter via the Channel/CHANNEL parameter in the Discrete Output Block. The Channel/CHANNEL must be set to "1" for this purpose.
Max. Meas. Press./ MAX_MEASURED_PRESSURE Display Index: 26 Data type: DS-65 Access: read only	The Max. Meas. Press./MAX_MEASURED_PRESSURE parameter is a structured parameter consisting of two elements. VALUE - Displays the highest measured pressure value (peak hold indicator). You can reset this maximum indicator via the Reset Peakhold/RESET_PEAK_HOLD parameter. STATUS - Displays the status. You can transmit the value and status of the Max. Meas. Press./MAX_MEASURED_PRESSURE parameter via the Channel/CHANNEL parameter (→ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "4" for this purpose.
Counter: P < Pmin/ COUNTER_PMIN Display Index: 27 Data type: unsigned16 Access: read only	Displays the vacuum pressure counter of the sensor The limit value is: lower nominal pressure limit of sensor – 10 % of upper nominal pressure limit of sensor. You can reset this counter via the Reset Peakhold/RESET_PEAK_HOLD parameter.
Min. Meas. Press./ MIN_MEASURED_PRESSURE Display Index: 28 Data type: float Access: read only	Displays the lowest measured pressure value (peak hold indicator). You can reset this maximum indicator via the Reset Peakhold/RESET_PEAK_HOLD parameter.
Counter: T > Tmax/ COUNTER_TMAX Display Index: 29 Data type: unsigned16 Access: read only	Displays the number of times the specified temperature range of the sensor has been overshoot. You can reset this counter via the Reset Peakhold/RESET_PEAK_HOLD parameter.

Service Transducer Block	
Parameter	Description
Max. Meas. Temp./ MAX_MEASURED_TEMP Display Index: 30 Data type: float Access: read only	Displays the highest measured temperature in the sensor (peak hold indicator). You can reset this maximum indicator via the Reset Peakhold/RESET_PEAK_HOLD parameter.
Counter: T < Tmin/ COUNTER_TMIN Display Index: 31 Data type: unsigned16 Access: read only	Displays the number of times the specified temperature range of the sensor has been undershot. You can reset this counter via the Reset Peakhold/RESET_PEAK_HOLD parameter.
Min. Meas. Temp./ MIN_MEASURED_TEMP Display Index: 32 Data type: float Access: read only	Displays the lowest measured temperature in the sensor (peak hold indicator). You can reset this maximum indicator via the Reset Peakhold/RESET_PEAK_HOLD parameter.
Pcb Count: T > Tmax/ ELECTRONIC_OVER_TEMP_COUNTER Display Index: 33 Data type: unsigned16 Access: read only	Displays the number of times the specified temperature range of the electronics has been overshot.
Pcb Max. Temp./ ELECTRONIC_OVER_TEMPERATURE Display Index: 34 Data type: float Access: read only	Displays the highest electronics temperature measured.
Pcb Count: T < Tmin/ ELECTRONIC_UNDER_TEMP_COUNTER Display Index: 35 Data type: unsigned16 Access: read only	Displays the number of times the specified temperature range of the electronics has been undershot.
Pcb Min. Temp./ ELECTRONIC_UNDER_TEMPERATURE Display Index: 36 Data type: float Access: read only	Displays the lowest electronics temperature measured.

Service Transducer Block	
Parameter	Description
Reset Peakhold/ RESET_PEAK_HOLD Selection Index: 37 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	This parameter lists all the peak hold indicator parameters that can be reset. You can select the peak hold indicators you want to reset. Options: - None - Max. pressure - Min. pressure - Pmax history - Pmin history - Max. temp. - Min. temp. - Tmax history - Tmin history - Reset all Factory setting: None
Pressure/ PRESSURE Display Index: 38 Data type: DS-65 Access: read only	The Pressure/PRESSURE parameter is a structured parameter consisting of two elements. VALUE - Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the Primary Value/PRIMARY_VALUE parameter in the "Pressure" measuring mode. STATUS - Displays the status. P01-xMD7xxxx-05-xx-xx-en-011 You can transmit the value and status of this parameter via the Channel/CHANNEL parameter (→ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "3" for this purpose.
Corrected Press./ CORRECTED_PRESSUR E Display Index: 39 Data type: float Access: read only	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also the graphic for Pressure/PRESSURE.
Meas. Val. Trend/ MEASURED_VALUE_ TREND Display Index: 40 Data type: unsigned8 Access: read only	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant

Service Transducer Block	
Parameter	Description
Max. Turndown/ MAX_TURNDOWN Display Index: 41 Data type: float Access: read, write	Displays the maximum possible turndown of the transmitter.
Sensor Changes/ SENSOR_CHANGES Display Index: 42 Data type: float Access: read, write	Displays the number of sensor changes that have been performed to date.
P Peakhold Step/ PRESSURE_PEAK_ HOLD_STEP Display Index: 43 Data type: float Access: read, write	Displays the step size at which the pressure peakhold values are saved. The value is displayed as a factor of the sensor end value. The pressure peakhold values are saved every 15 minutes regardless of this value.
T. Peakhold Step/ TEMP_PEAK_HOLD_ STEP Display Index: 44 Data type: float Access: read, write	Displays the step size at which the temperature peakhold values are saved. The value is displayed in the Kelvin unit. The temperature peakhold values are saved every 15 minutes regardless of this value.
Acc. Of Gravity/ ACCELERATION_OF_ GRAVITY Display Index: 45 Data type: float Access: read, write, OOS	Displays the gravitational acceleration used by the device to calculate the measured variables in the "Level" measuring mode.
Creep Flow Hyst/ CREEP_FLOW_HYST Display Index: 46 Data type: float Access: read, write, OOS	Displays the hysteresis of the low flow cut off. → 84, Pressure Transducer Block, parameter description for Set. L. Fl. Cut-Off/SET_LOW_FLOW_CUT_OFF. Factory setting: 1 % (of end flow value)
Hist. Saving Cycle/ HISTOROM_SAVING_ CYCLE_TIME Display Index: 47 Data type: unsigned8 Access: read, write	Displays the time interval for saving the measured value.
HistoROM Avail./ HISTOROM_AVAILABL E Display Index: 48 Data type: unsigned8 Access: read only	Indicates whether the optional HistoROM®/M-DAT memory module is connected to the electronic insert. → See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), "HistoROM®/M-DAT (optional)" section. Options: ■ Yes (HistoROM®/M-DAT is attached to the electronic insert) ■ No (HistoROM®/M-DAT is not attached to the electronic insert)



Service Transducer Block	
Parameter	Description
Download Select/ DOWNLOAD_ SELECTION Display Index: 49 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select download function from HistoROM to device. The option selected has no effect on an upload from the device to the HistoROM. Prerequisite: ■ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM AVAIL. = Yes) Options ■ Configuration copy: With this option, all parameters apart from the TRANSMITTER SERIAL No, DEVICE DESIGNATION, CUST. TAG NUMBER, LONG TAG NUMBER, ADDITIONAL INFO., BUS ADDRESS and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ■ Device replacement: With this option, all parameters except for TRANSMITTER SERIAL No, DEVICE DESIGNATION and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ■ Electronics replace: With this option, all parameters except for the parameters of the POSITION ADJUSTMENT group are overwritten. Factory setting: Configuration copy (if HistoROM®/M-DAT is attached to the electronic insert)
HistoROM Control/ HISTOROM_ CONTROL Selection Index: 50 Data type: unsigned8 Access: read, write	For selecting the direction for copying the data. → See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), "HistoROM®/M-DAT (optional)" section. Prerequisite: ■ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM Avail./HISTOROM_AVAILABLE = Yes) Options: ■ Abort ■ HistoROM → Device ■ Device → HistoROM Factory setting: Abort (if HistoROM®/M-DAT is attached to the electronic insert)
Press. Eng. Unit/ PRESSURE_ UNIT Display Index: 51 Data type: unsigned16 Access: read only	Displays the pressure unit selected. The pressure unit is selected via the Calibration Units/CAL_UNIT parameter (→ 57) in the Pressure Transducer Block.
Temp. Eng. Unit/ TEMPERATURE_ UNIT Display Index: 52 Data type: unsigned16 Access: read only	Displays the temperature unit selected. You can select the temperature unit by means of the Temperature/MEASURED_TEMPERATURE parameter (→ 60) in the Pressure Transducer Block.
Inp. Press. Invers/ INPUT_PRESSURE_ INVERSION Index: 53 Data type: unsigned8 Access: read, write, OOS (only with Service Code)	Internal service parameter.







7.3.4 DP Flow Transducer Block (only Deltabar S)

DP Flow Transducer Block	
Parameter	Description
Device Dialog/DEVICE DIALOG Display Index: 11 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.
Insert Pin No./SW_LOCK Entry Index: 12 Data type: unsigned16 Access: read, write, AUTO, OOS, MAN	For entering a code to lock or unlock operation. ▪ The  symbol on the on-site display indicates that operation is locked. Parameters which refer to how the display appears, e.g. Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST, can still be altered. ▪ If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation, you can only unlock operation again using remote operation. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Options ▪ Lock: Enter a number between 0 and 9999 and ≠100. ▪ Unlock: Enter the number 100. Factory setting: 100
Status Locking /STATUS_LOCKING Index: 13 Data type: unsigned16 Access: read only	Displays the current locking status of the device or conditions that can lock the device (hardware locking, software locking).
Flow-Meas. Type/ FLOW_MEAS_TYPE Selection Index: 14 Data type: unsigned8 Access: read, write, OOS	Select the flow type. Prerequisite: ▪ Deltabar S differential pressure transmitter Options ▪ Volume operat. cond. (volume under operating conditions) ▪ Volume norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0 °C)) ▪ Volume std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15 °C/59 °F)) ▪ Mass p. cond. (mass under operating conditions) Factory setting: Volume operat. cond.
Suppressed Flow/ SUPPRESSED_FLOW Display Index: 15 Data type: float Access: read only	Displays the current flow. Depending on the flow mode selected (→ Flow. Meas. Type/ FLOW_MEAS_TYPE), a volume flow, mass flow, standard volume flow or corrected volume flow is displayed.

DP Flow Transducer Block	
Parameter	Description
Unit Flow/ STD_FLOW_UNIT Entry Index: 16 Data type: unsigned16 Access: read, write, OOS	Select flow unit. Prerequisite: ■ Deltabar S differential pressure transmitter Make sure that the unit suits the flow mode selected. → See also Page 86, parameter description for Flow. Meas. Type/FLOW_MEAS_TYPE. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (Flow-Meas. Type/FLOW_MEAS_TYPE). When the flow mode is changed, conversion is not possible. Possible units for Flow-Meas. Type/FLOW_MEAS_TYPE = Volume operat. cond.: ■ m³/s, m³/min, m³/h, m³/day ■ l/s, l/min, l/h ■ hl/s, hl/min, hl/day ■ ft³/s, ft³/min, ft³/h, ft³/day ■ ACFS, ACFM, ACFH, ACFD ■ ozf/s, ozf/min ■ US Gal/S, US Gal/min, US Gal/h, US Gal/day ■ Imp. Gal/s, Imp. Gal/min, Imp. Gal/h ■ bbl/s, bbl/min, bbl/h, bbl/day ■ User unit, see also parameter description for Customer Unit F/CUSTOMER_UNIT_FLOW (Page 88) and Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW (Page 88) Factory setting: m³/s Possible units for Flow-Meas. Type/FLOW_MEAS_TYPE = Volume norm. cond.: ■ NM³/s, Nm³/min, Nm³/h, Nm³/day ■ User unit, Ë see also parameter description for Customer Unit F/CUSTOMER_UNIT_FLOW (Page 88) and Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW (Page 88) Factory setting: Nm³/s Possible units for Flow-Meas. Type/FLOW_MEAS_TYPE = Volume std. cond.: ■ Sm³/s, Sm³/min, Sm³/h, Sm³/day ■ SCFS, SCFM, SCFH, SCFD ■ User unit, Ë see also parameter description for Customer Unit F/CUSTOMER_UNIT_FLOW (Page 88) and Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW (Page 88) Factory setting: Sm³/s Possible units for Flow-Meas. Type/FLOW_MEAS_TYPE = Mass p. cond.: ■ g/s, kg/s, kg/min, kg/h ■ t/s, t/min, t/h, t/day ■ oz/s, oz/min ■ lb/s, lb/min, lb/h ■ ton/s, ton/min, ton/h, ton/day ■ User unit, Ë see also parameter description for Customer Unit F/CUSTOMER_UNIT_FLOW (Page 88) and Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW (Page 88) Factory setting: kg/s

DP Flow Transducer Block	
Parameter	Description
Customer Unit F/ CUSTOMER_UNIT_FLOW Entry Index: 17 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific flow unit. You can enter a maximum of eight alphanumeric characters here. → See also Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW. Prerequisites: ■ Deltabar S differential pressure transmitter ■ Unit Flow/STD_FLOW_UNIT = User unit Only the first five characters are shown on the local operation. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: - - - - -
Cust. Unit Fact. F/ CUSTOMER_UNIT_FACTOR_FLOW Entry Index: 18 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific flow unit. The conversion factor must be entered in relation to an appropriate SI unit, e.g. "m³/s" for the "Volume operat. cond." flow mode. → See also Customer Unit F/CUSTOMER_UNIT_FLOW. Prerequisite: ■ Deltabar S differential pressure transmitter ■ Unit Flow/STD_FLOW_UNIT = User unit Example: - You want the measured value to be displayed in "bucket/h". - Primary Value/PRIMARY_VALUE = 0.01 m³/s i 3600 bucket/h - Enter Customer Unit F/CUSTOMER_UNIT_FLOW: bucket/h - Enter Cust. Unit Fact. F/CUSTOMER_UNIT_FACTOR_FLOW: 360000 - Result: Primary Value/PRIMARY_VALUE = 3600 bucket/h Factory setting: Off
Low Flow Cut-Off/ LOW_FLOW_CUT_OFF Selection Index: 19 Data type: unsigned8 Access: read, write, OOS	Switch the "low flow cut-off" function on and off. In the lower measuring range, small flow quantities (creepages) can lead to large fluctuations in the measured value. Switching on this function stops these flow quantities from being recorded. See also Set.L.Fl.Cut-Off/ SET_LOW_FLOW_CUT_OFF. Prerequisite: ■ Deltabar S differential pressure transmitter Options: ■ Off ■ On Factory setting: Off

DP Flow Transducer Block	
Parameter	Description
Set. L. Fl. Cut-Off/ SET_LOW_FLOW_CUT_OFF Entry Index: 20 Data type: float Access: read, write, OOS	Enter the switch-off point of low flow cut-off. The hysteresis between the switch-on point and the switch-off point is always 1 % of the end flow value. Page 88, Low Flow Cut-Off/LOW_FLOW_CUT_OFF. Prerequisite: ■ Deltabar S differential pressure transmitter ■ Low Flow Cut-Off/LOW_FLOW_CUT_OFF = On Input range: Switch-off point: 0 to 50% of end flow value (→ 62, parameter description for Scale Out/SCALE_OUT, EU_100 element/MAX. FLOW)   P01-PMD7xxxx-05-xx-xx-xx-000 Factory setting: 5% (of end flow value)
Flow Max/MAX_FLOW Entry Index: 21 Data type: float Access: read, write, OOS	Enter the maximum flow of the primary device. → See also the layout sheet of the primary device. The maximum flow is assigned to the maximum pressure which you enter via Max Press. Flow/MAX_PRESS_FLOW. Factory setting 1.0
Pressure/PRESSURE Display Index: 22 Data type: float Access: read only	Displays the measured pressure after sensor trim, position adjustment and damping. This value corresponds to the Primary Value/PRIMARY_VALUE parameter in the "Pressure" measuring mode. P01-xMD7xxxx-05-xx-xx-en-011
Max Press. Flow/ MAX_PRESS_FLOW Entry Index: 23 Data type: float Access: read, write, OOS	Enter maximum pressure of primary device. → See layout sheet of primary device. This value is assigned to the maximum flow value (→ see Flow Max/MAX_FLOW). Factory setting: High sensor limit (→ see PRESS. SENS HILIM (485), Page 212)
Press. Eng. Unit/ PRESSURE_UNIT Display Index: 24 Data type: unsigned16 Access: read, write, OOS	Displays the pressure unit selected. The pressure unit is selected by means of the Calibration Units/CAL_UNIT parameter (→ Page 57) in the Pressure Transducer Block.

DP Flow Transducer Block																	
Parameter	Description																
Totalizer 1/ TOTALIZER_1_VALUE Display Index: 25 Data type: DS-65 Access: read only	The Totalizer 1/TOTALIZER_1_VALUE parameter is a structured parameter consisting of two elements. VALUE ■ Displays the total flow value of totalizer 1. You can reset the value with the Reset Totalizer 1/TOTALIZER_1_RESET parameter. STATUS ■ Displays the status. ■ You can transmit the value and status of this parameter via the Channel/CHANNEL parameter (→ ⓘ 107) in the Analog Input Block. The Channel/CHANNEL must be set to "6" for this purpose. ■ You can transmit the value and status of this parameter via the Channel/CHANNEL parameter in the Discrete Output Block. The Channel/CHANNEL must be set to "2" for this purpose.																
Totalizer 1 Unit/ TOTALIZER_1_UNIT Selection Index: 26 Data type: unsigned16 Access: read, write, OOS	Select the unit for totalizer 1. Depending on the setting in the Flow-Meas. Type/FLOW_MEAS_TYPE parameter (→ ⓘ 86) this parameter offers a list of volume, norm volume, standard volume and mass units. When a new volume or mass unit is selected, totalizer-specific parameters are converted and displayed with the new unit within a unit group. When the flow mode is changed, the totalizer value is not converted. Factory setting: m³																
Neg. Flow Tot. 1/ TOTALIZER_1_MODE Selection Index: 27 Data type: unsigned8 Access: read, write, OOS	Specify the way of counting negative flows for totalizer 1. <table><thead><tr><th></th><th>positive flow</th><th>negative flow</th></tr></thead><tbody><tr><td>Options</td><td></td><td></td></tr><tr><td>Inc. on. neg. flow</td><td>Total increases</td><td>Total increases</td></tr><tr><td>Dec. on neg. flow</td><td>Total increases</td><td>Total decreases</td></tr><tr><td>Stop on neg. flow</td><td>Total increases</td><td>Total remains constant</td></tr></tbody></table> P01-xMD7xxxx-16-xx-xx-en-003 Factory setting: Positive			positive flow	negative flow	Options			Inc. on. neg. flow	Total increases	Total increases	Dec. on neg. flow	Total increases	Total decreases	Stop on neg. flow	Total increases	Total remains constant
	positive flow	negative flow															
Options																	
Inc. on. neg. flow	Total increases	Total increases															
Dec. on neg. flow	Total increases	Total decreases															
Stop on neg. flow	Total increases	Total remains constant															
Fail Safe Mode/ TOTALIZER_1_FAIL_S AFE_MODE Selection Index: 28 Data type: unsigned8 Access: read only	Select the mode for totalizer 1 in the event of an error. Currently, only the "Actual" mode can be selected, i.e. totalizer 1 continues to count in the event of an error.																
Reset Totalizer 1/ TOTALIZER_1_RESET Selection Index: 29 Data type: unsigned8 Access: read, write, OOS	You reset totalizer 1 to zero with this parameter. Options: ■ Abort (do not reset) ■ Reset Factory setting: Abort																

DP Flow Transducer Block	
Parameter	Description
Tot. 1 User Unit/ CUSTOMER_UNIT_TOT_1 Entry Index: 30 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific unit for totalizer 1. You can enter a maximum of eight alphanumeric characters here. → See also Fact. U. U. Total.1/CUSTOMER_UNIT_FACTOR_TOT_1. Prerequisite: ■ Totalizer 1 Unit/TOTALIZER_1_UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. In the FF configuration program, the slash counts as a character, i.e. "crates/m2" would be displayed as "crates/m". Factory setting: - - - - -
Fact. U. U. Total.1/ CUSTOMER_UNIT_FACTOR_TOT_1 Entry Index: 31 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific unit for totalizer 1. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³ for the "Volume operat. cond." Flow-Meas. Type/FLOW_MEAS_TYPE. → See also Tot. 1 User Unit/CUSTOMER_UNIT_TOT_1. Prerequisite: ■ Totalizer 1 Unit/TOTALIZER_1_UNIT = User unit Example: You want the measured value to be displayed in "buckets". - Primary Value/PRIMARY_VALUE = 1 m³ i 100 bucket - Enter Tot. 1 User Unit/CUSTOMER_UNIT_TOT_1: bucket - Enter Fact. U. U. Total.1/CUSTOMER_UNIT_FACTOR_TOT_1: 100 - Result: Primary Value/PRIMARY_VALUE = 100 bucket Factory setting: 1.0
Totalizer 2/ TOTALIZER_2_VALUE Display Index: 32 Data type: float Access: read only	Displays the total flow value of totalizer 2. You cannot reset totalizer 2. Prerequisite: ■ Deltabar S differential pressure transmitter
Total. 2 Eng. Unit/ TOTALIZER_2_UNIT Selection Index: 33 Data type: unsigned16 Access: read, write, OOS	Select the unit for totalizer 2. → 91, Totalizer Transducer Block, parameter description for Tot. 1 User Unit/CUSTOMER_UNIT_TOT_1. Prerequisite: ■ Deltabar S differential pressure transmitter Factory setting: m³
Neg. Flow Tot. 2/ TOTALIZER_2_MODE Entry Index: 34 Data type: unsigned8 Access: read, write, OOS	Specify the way of counting negative flows for totalizer 2. → 90, Totalizer Transducer Block, parameter description for Neg. Flow Tot. 1/TOTALIZER_1_MODE Prerequisite: ■ Deltabar S differential pressure transmitter
Tot. 2 Unit Text/ CUSTOMER_UNIT_TOT_2 Selection Index: 35 Data type: visible string Access: read, write, AUTO, OOS, MAN	Enter text (unit) for customer-specific unit for totalizer 2. → 91, Totalizer Transducer Block, parameter description for Tot. 1 User Unit/CUSTOMER_UNIT_TOT_1. Prerequisite: ■ Deltabar S differential pressure transmitter ■ Total. 2 Eng. Unit/TOTALIZER_2_UNIT = User unit Factory setting: - - - - -

DP Flow Transducer Block	
Parameter	Description
Fact. U. U. Total. 2/ CUSTOMER_UNIT_FACTOR_TOT_2 Entry Index: 36 Data type: float Access: read, write, OOS	Enter the conversion factor for a customer-specific unit for totalizer 2. → 91, Totalizer Transducer Block, parameter description for Fact. U. U. Total.1/ CUSTOMER_UNIT_FACTOR_TOT_1. Prerequisite: ■ Deltabar S differential pressure transmitter ■ Total. 2 Eng. Unit/TOTALIZER_2_UNIT = User unit Factory setting: 1.0

7.3.5 Display Transducer Block

Display Transducer Block	
Parameter	Description
Device Dialog/DEVICE DIALOG Display Index: 10 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.
Main Line Cont./ DISPLAY_MAINLINE_CONTENT Selection Index: 11 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Specify the contents for the main line of the local operation in the measuring mode. Options: ■ Primary value (PV) ■ Main measured value (%) ■ Pressure ■ Flow ■ Level ■ Tank content ■ Temperature ■ Error number ■ Totalizer 1 ■ Totalizer 2 ■ ISEL In1 ■ ISEL In2 ■ ISEL In3 ■ ISEL In4 ■ PID In1 The selection depends on the measuring mode chosen. Factory setting: Primary value (PV)
Main Data Format/ DISPLAY_MAINLINE_FORMAT Selection Index: 12 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Specify the number of places after the decimal point for the value displayed in the main line. Options: ■ Auto ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ x.xxxxx Factory setting: Auto

Display Transducer Block	
Parameter	Description
Alternate Data/ DISPLAY_ALTERNATING_VALUES Selection Index: 13 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Switch on the "Alternating display" mode. In this display mode, the local operation alternates between the following measured values depending on the measuring mode selected. – Pressure: primary value (PV), main measured value (%), pressure and temperature – Level: primary value (PV), main measured value (%), pressure, level, tank contents and temperature – Flow: primary value (PV), main measured value (%), pressure, flow, temperature, totalizer 1 and totalizer 2 Options: ■ Off ■ On Factory setting: Off
Display Contrast/ DISPLAY_CONTRAST Entry Index: 14 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Adjust contrast of local operation. You specify the contrast of the display with a number. Input range: 4 to 13, 4: contrast weaker (brighter), 13: contrast stronger (darker). Factory setting: 8
Language/ DISPLAY_LANGUAGE Selection Index: 15 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Select the menu language for the local operation. Factory setting: English
Digits Set/ SIL_DIGITS_TEST_STRING Display Index: 16 Data type: visible string Access: read only	This parameter is used to check whether characters and digits are displayed correctly on the local operation. "0123456789.-" is shown if the units are displayed correctly.

7.3.6 Diagnostic Transducer Block

Diagnostic Transducer Block	
Parameter	Description
Device Dialog/DEVICE DIALOG Display Index: 10 Data type: unsigned8 Access: read only	If the configuration is unsuitable, this parameter displays a message indicating that a configuration error is present. The message can also refer to the parameter that was configured incorrectly.

Diagnostic Transducer Block	
Parameter	Description
Insert Pin No./ SW_LOCK Index: 11 Data type: unsigned16 Access: read, write, AUTO, OOS, MAN	For entering a code to lock or unlock operation. - The -symbol on the local operation indicates that operation is locked. Parameters which refer to how the display appears, e.g. Language/DISPLAY_LANGUAGE and Display Contrast/DISPLAY_CONTRAST, can still be altered. - If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation, you can only unlock operation again using remote operation. See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), Section 5.6 "Locking/unlocking operation". Options: - Lock: Enter a number between 0 and 9999 and 100 i. - Unlock: Enter the number 100. Factory setting: 100
Status Locking/ STATUS_LOCKING Index: 12 Data type: unsigned16 Access: read only	Displays the current locking status of the device or conditions that can lock the device (hardware locking, software locking).
Simulation Mode/ SIMULATION_MODE Selection Index: 13 Data type: unsigned8 Access: read, write, OOS	Switch on simulation and select simulation type. Any simulation running is switched off if the measuring mode or level mode is changed. Options: - None - Pressure - Flow (only differential pressure transmitter) - Level - Tank content - Alarm/warning P01-xMD7xxxx-05-xx-xx-en-004 Factory setting: None
Units Index/ SCALE_OUT_UNITS_IN DEX Display Index: 14 Data type: unsigned16 Access: read only	Displays the unit selected via the Scale Out/SCALE_OUT parameter (→  62) in the Pressure Transducer Block.

Diagnostic Transducer Block	
Parameter	Description
Simulated Value/ SIMULATED_VALUE Entry Index: 15 Data type: float Access: read, write	Enter the simulation value. Prerequisite: ■ Simulation Mode/SIMULATION_MODE = Pressure, flow, level or tank content.
Sim. Error No./ SIMULATION_ERROR_ NUMBER Entry Index: 16 Data type: unsigned16 Access: read, write	Enter the message number for simulation. → See also these Operating Instructions, Section 12.1 "Messages", "Code" table column. Prerequisite: ■ Simulation Mode/SIMULATION_MODE = Alarm/warning Factory setting: 613 (simulation active)
Alarm Status Info/ ALARM_STATUS Display Index: 17 Data type: unsigned16 Access: read only	Displays the current messages present. If two or more messages are present, the message with the highest priority is shown on the display. → See also these Operating Instructions, Section 12.1 "Messages" and Section 12.4 "Confirming messages".
ALARM_STATUS_WIT H_CATEGORY Index: 18 Data type: unsigned16 Access: read only	Code displays the current messages present with category information. If two or more messages are present, the message with the highest priority is shown on the display.
Last Diag. Code Info/ LAST_DIAGNOSTIC_ CODE Display Index: 19 Data type: unsigned16 Access: read only	Displays the last error that occurred and was eliminated. ■ The message displayed here can be deleted by means of the Reset All Alarms/RESET_ALL_ALARMS parameter.
LAST_DIAGNOSTIC_ CODE_WITH_CATEGO RY Index: 20 Data type: unsigned16 Access: read only	Code displays the last error that occurred and was eliminated along with category information. ■ The message displayed here can be deleted by means of the Reset All Alarms/RESET_ALL_ALARMS parameter.
Ack. Alarm Mode/ ACKNOWLEDGE_ALAR M_MODE Selection Index: 21 Data type: unsigned8 Access: read, write	Switch on the acknowledge alarm mode. → See also Ack. Alarm/ACKNOWLEDGE_ALARM. Options: ■ On ■ Off Factory setting: Off

Diagnostic Transducer Block	
Parameter	Description
Ack. Alarm/ ACKNOWLEDGE_ALARM Selection Index: 22 Data type: unsigned8 Access: read, write	Acknowledge the alarm. Prerequisite: ■ Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = On Options: ■ Abort ■ Confirm The cause of the alarm must be eliminated, the message must be acknowledged via the Ack. Alarm/ACKNOWLEDGE_ALARM parameter and, where applicable, the Alarm Displ. Time/ALARM_DISPLAY_TIME (→ 96) has to have elapsed before the device starts measuring again following an alarm. → See also these Operating Instructions, Section 12.4 "Confirming messages". Factory setting: Abort
Reset All Alarms/ RESET_ALL_ALARMS Selection Index: 23 Data type: unsigned8 Access: read, write	Use this parameter to reset the alarm of the Last Diag. Code/ LAST_DIAGNOSTIC_CODE parameter. Options: ■ Abort ■ Confirm Factory setting: Abort
Error No./ ERROR_NUMBER Entry Index: 24 Data type: unsigned16 Access: read, write	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). Enter the corresponding message number for this parameter. → See also Select Alarmtype/SELECT_ALARM_TYPE. → See also these Operating Instructions, Section 12.1 "Messages" and Section 12.3 "Response of outputs to errors".
Select Alarmtype/ SELECT_ALARM_TYPE Entry Index: 25 Data type: unsigned8 Access: read, write	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). → See also Error No./ERROR_NUMBER. → See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Alarm (A): the process value or measuring channel is transmitted with the status BAD. ■ Warning (W): device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. Operation: 1. Enter the corresponding message number by means of the Error No./ERROR_NUMBER parameter. 2. Select the "Alarm" or "Warning" option by means of the Select Alarmtype/SELECT_ALARM_TYPE parameter. ■ The Alarm (A) or Warning (W) option overwrites the setting for the corresponding parameter FF912_STATUS_SELECT(1-13) and vice versa. ■ The Good option for FF912_STATUS_SELECT (1-13) automatically sets the SELECT_ALARM_TYPE to Warning (W) for the corresponding error number.
Alarm Delay/ ALARM_DELAY Entry Index: 26 Data type: float Access: read, write	Enter the alarm response time. There is no alarm if the cause of the error is eliminated within the alarm delay time. Input range: 0 to 100 s Factory setting: 0.0 s

Diagnostic Transducer Block	
Parameter	Description
Alarm Displ. Time/ ALARM_DISPLAY_TIME Entry Index: 27 Data type: float Access: read, write	Enter the alarm display time. Once the cause of the error is rectified, the alarm display time starts running. The following applies if Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = On: If an alarm appears and the alarm display time elapses before the alarm has been acknowledged, the message is cleared once it has been acknowledged. → See also these Operating Instructions, Section 12.4 "Confirming messages". Input range: 0 to 999.9 s Factory setting: 0.0 s
Press. Eng. Unit/ PRESSURE_UNIT Display Index: 28 Data type: unsigned16 Access: read only	Displays the pressure unit selected. The pressure unit is selected via the Calibration Units/CAL_UNIT parameter (→ 57) in the Pressure Transducer Block.
Pmin Alarm Window/ PMIN_ALARM_WINDOW Entry Index: 29 Data type: float Access: read, write	Customer-specific process monitoring – enter lower pressure limit. You can use the Select Alarmtype/SELECT_ALARM_TYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages", Table, Code E730 and Section 12.3 "Response of outputs to errors". Factory setting: Low sensor limit ■ 1.1 (→ For the low sensor limit, see Sensor Range/SENSOR_RANGE, EU_0 element, → 58.)
Pmax Alarm Window/ PMAX_ALARM_WINDOW Entry Index: 30 Data type: float Access: read, write	Customer-specific process monitoring – enter upper pressure limit. You can use the Select Alarmtype/SELECT_ALARM_TYPE parameter to enter how the device responds if the operating pressure overshoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages", Table, Code E731 and Section 12.3 "Response of outputs to errors". Factory setting: High sensor limit ■ 1.1 (→ For the high sensor limit, see Sensor Range/SENSOR_RANGE, EU_100 element, → 58.)
Temp. Eng. Unit/ TEMPERATURE_UNIT Display Index: 31 Data type: Unsigned16 Access: read only	Displays the temperature unit selected. You can select the temperature unit by means of the Temperature/MEASURED_TEMPERATURE parameter (→ 60) in the Pressure Transducer Block.
Tmin Alarm Window/ TMIN_ALARM_WINDOW Entry Index: 32 Data type: float Access: read, write	Customer-specific process monitoring – enter lower temperature limit. You can use the Select Alarmtype/SELECT_ALARM_TYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages" Table, code E732 and Section 12.3 "Response of outputs to errors". Factory setting: Lower sensor temperature operating limit – 10 K (→ For the lower sensor temperature operating limit, see Tmin Sensor/SENSOR_TEMP_LOW_LIMIT, → 80)
Tmax Alarm Window/ TMAX_ALARM_WINDOW Entry Index: 33 Data type: float Access: read, write	Customer-specific process monitoring – enter upper temperature limit. You can use the Select Alarmtype/SELECT_ALARM_TYPE parameter to enter how the device responds if the operating pressure overshoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages" Table, code E733 and Section 12.3 "Response of outputs to errors". Factory setting: Upper sensor temperature operating limit +10 K (→ For the upper sensor temperature operating limit, see Tmax Sensor/SENSOR_TEMP_HIGH_LIMIT, → 80)

Diagnostic Transducer Block	
Parameter	Description
Enter Reset Code/ ENTER_RESET_CODE Entry Index: 34 Data type: unsigned16 Access: read, write	Reset parameters completely or partially to factory values or delivery status. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Factory setting" (reset) section. Factory setting: 0
Operating Hours/ OPERATING_HOURS Display Index: 35 Data type: Unsigned32 Access: read only	Displays the hours of operation. This parameter cannot be reset.
Alarm History/ STATUS_HISTORY Display Index: 36 Data type: visible string Access: read only	This parameter displays pending alarms and warnings in hexadecimal numerical format (max. 18). Each message is assigned to a bit in the order of the error code in accordance with Section 12.1 "Messages".
HIGHEST_CATEGORY Index: 37 Data type: unsigned8 Access: read only	Displays the current error category present. If two or more messages are present with different error categories, the category with the highest priority is shown on the display. ■ F: Prio 1 ■ C: Prio 2 ■ S: Prio 3 ■ M: Prio 4

Diagnostic Transducer Block	
Parameter	Description
FF912ConfigArea/ FF912_CONFIG_AREA Index: 38 Data type: DS271 Access: read, write	Der FF912ConfigArea/FF912_CONFIG_AREA parameter is a structured parameter consisting of 15 elements. CONFIG_AREA(1-15): These elements make it possible to move the individual, configurable diagnostic events to the lower area of the manufacturer-specific 32 bit diagnostic for Field Diagnostic. This has the advantage that these configurable diagnostic events can be tracked individually (and not as a group) via the Field Diagnostic parameter. Options: ■ Not assigned: the diagnostic event is not moved to the lower area and remains grouped in the upper area (31-15). ■ #115 Sensor overpressure : sets diagnostic event 115 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #120 Sensor low pressure : sets diagnostic event 120 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #715 Sensor over Temperature : sets diagnostic event 715 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #717 Transmitter over temperature : sets diagnostic event 717 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #718 Transmitter under temperature : sets diagnostic event 718 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #720 Sensor under temperature : sets diagnostic event 720 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #726 Sensor temperature error-overrange : sets diagnostic event 726 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #730 LRV user limit exceeded : sets diagnostic event 730 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #731 URV user limit exceeded : sets diagnostic event 731 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #732 LRV-temp user limit exceeded : sets diagnostic event 732 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #733 URV-temp user limit exceeded : sets diagnostic event 733 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15) ■ #740 Calculation Overflow, bad configuration : sets diagnostic event 740 to the bit position (1-15) defined by the corresponding element CONFIG_AREA(1-15)
Status Select Event 115/ FF912_STATUS_SELEC T1 Index: 39 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 115 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 115 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 115 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 115

Diagnostic Transducer Block	
Parameter	Description
Status Select Event 120/ FF912_STATUS_SELEC T2 Index: 40 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 120 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 120 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 120 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 120
Status Select Event 715/ FF912_STATUS_SELEC T3 Index: 41 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 715 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 715 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 715 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 715
Status Select Event 717/ FF912_STATUS_SELEC T4 Index: 42 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 717 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 717 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 717 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 717

Diagnostic Transducer Block	
Parameter	Description
Status Select Event 718/ FF912_STATUS_SELEC T5 Index: 43 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 718 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 718 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 718 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 718
Status Select Event 720/ FF912_STATUS_SELEC T6 Index: 44 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 720 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 720 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 720 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 720
Status Select Event 726/ FF912_STATUS_SELEC T7 Index: 45 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 726 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 726 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 726 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 726

Diagnostic Transducer Block	
Parameter	Description
Status Select Event 727/ FF912_STATUS_SELECT8 Index: 46 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 727 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 727 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 727 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 727
Status Select Event 730/ FF912_STATUS_SELECT9 Index: 47 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 730 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 730 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 730 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 730
Status Select Event 731/ FF912_STATUS_SELECT10 Index: 48 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 731 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 731 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 731 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 731

Diagnostic Transducer Block	
Parameter	Description
Status Select Event 732/ FF912_STATUS_SELEC T11 Index: 49 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 732 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 732 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 732 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 732
Status Select Event 733/ FF912_STATUS_SELEC T12 Index: 50 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 733 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 733 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 733 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 733
Status Select Event 740/ FF912_STATUS_SELEC T13 Index: 51 Data type: enumerated Access: read, write	This parameter determines the status of the process value or of the set measuring channel in the Transducer Block when error event 740 occurs. See also Error No./ERROR_NUMBER. See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: ■ Bad: the process value or measuring channel is transmitted with the status BAD. ■ Uncertain: device continues measuring. The process value or measuring channel is transmitted with the status UNCERTAIN. ■ Good: device continues measuring within its physical limits. The process value or measuring channel is transmitted with the status GOOD. ■ The Good option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 740 ■ The Uncertain option automatically sets the SELECT_ALARM_TYPE to Warning (W) for diagnostic event 740 ■ The Bad option automatically sets the SELECT_ALARM_TYPE to Alarm (A) for diagnostic event 740

7.4 Analog Input Block (function block)

Analog Input Block	
Parameter	Description
Static Revision/ST_REV Display Index: 1 Data type: unsigned16 Access: read only	Displays the counter for static parameters of the Analog Input Block. The counter is incremented by one with each change of a static parameter of the Analog Input Block. The counter counts up to 65535 and then starts again at zero.
Tag Description/TAG_DESC Entry Index: 2 Data type: octet string Access: auto, OOS	Enter a description for the related block or the measuring point e.g. TAG number (max. 32 alphanumeric characters).
Strategy/STRATEGY Entry Index: 3 Data type: unsigned16 Access: auto, man, OOS	Enter user-specific value for grouping and thus faster evaluation of the blocks. Grouping takes place by entering the same numerical value for the Strategy/STRATEGY parameter of the block in question. Input range: 0...65535 Factory setting: 0
Alert Key/ALERT_KEY Entry Index: 4 Data type: unsigned8 Access: auto, man, OOS	Enter the identification number for the measuring device or for each individual block. The control level uses this identification number to sort alarm and event messages and initiate other processing steps. Input range: 1...255 Factory setting: 0
Block Mode/MODE_BLK Selection, display Index: 5 Data type: DS-69 Access: auto, man, OOS	The Block Mode/MODE_BLK parameter is a structured parameter consisting of four elements. The Analog Input Block supports the "Auto" (automatic), "Man" (value and status of the OUT parameter can be specified directly by the operator) and OOS (out of service) modes. TARGET ■ Change the block mode. ACTUAL ■ Displays the current block mode. PERMITTED ■ Displays the modes supported by the block. NORMAL ■ Displays the block mode during standard operation.

Analog Input Block	
Parameter	Description
Block Error/ BLOCK_ERR Display Index: 6 Data type: bit string Access: read only	Displays the active block error. Possibilities: ■ Out of service (OOS): – The Analog Input Block is in the OOS block mode. – The Resource Block is in the OOS block mode. ■ Simulation active: DIP switch 2 "Simulation" on the electronic insert is set to "on", i.e. simulation is possible. – The simulation mode for the Analog Input Block is active. → 106, parameter description for Simulate/SIMULATE. – The simulation function is switched on in the Diagnostic Transducer Block. → 94, parameter description for Simulation Mode/SIMULATION_MODE. ■ Input failure: The input value transmitted by the Pressure or DP Flow Transducer Block is not valid (BAD status). This could be due to the following: – The Pressure or DP Flow Transducer Block is in the OOS block mode. – A device error is present. In the Diagnosis Transducer Block, the Alarm Status/ALARM_STATUS parameter (→ 95) displays an error code. → See also these Operating Instructions, Section 12.1 "Messages". The "Input failure" block error is relayed to downstream function blocks or high-order process control systems by means of the BAD status of the output value of the OUT Analog Input Block. ■ Block configuration error: There is a configuration error in the Analog Input Block. This could be due to the following: – By means of the Transducer Scale/XD_SCALE parameter, a unit was selected that does not suit the input value configured in the Channel/CHANNEL parameter. – No valid input value was selected by means of the Channel/CHANNEL parameter. → 107, parameter description for Channel/CHANNEL. – An unsuitable linearization mode was selected by means of the Linearization Type/L_TYPE parameter. → 108, parameter description for Linearization Type/L_TYPE. – The "Direct" linearization mode was selected by means of the Linearization Type/L_TYPE parameter. The scalings for the Transducer Scale/XD_SCALE and Output Scale/OUT_SCALE parameters do not match. – If you assign the same process variable, such as "Primary value", to two Analog Input Blocks, the same scaling values and units have to be set for both blocks.
Process Value/PV Display Index: 7 Data type: DS-65 Access: read only	The PV parameter is a structured parameter consisting of two elements. VALUE ■ Displays the process variable used for block execution STATUS ■ Displays the status of the process variable. The unit used by the Output Scale/OUT_SCALE parameter is accepted.
Output/OUT Display, entry Index: 8 Data type: DS-65 Access: auto, man, OOS	The Output/OUT parameter is a structured parameter consisting of two elements. VALUE ■ Displays the output value of the Analog Input Block. STATUS ■ Displays the status of the Output/OUT value. ■ The Output/OUT output value is also transmitted if it is outside the scaling range of Output Scale/OUT_SCALE. ■ The unit used by the Output Scale/OUT_SCALE parameter is accepted. ■ If the "MAN" (manual) block mode was selected by means of the Block Mode/MODE_BLK parameter, the output value Output/OUT and its status can be specified manually here.

Analog Input Block	
Parameter	Description
Simulation Mode/ SIMULATION_MODE Entry, display Index: 9 Data type: DS-82 Access: auto, man, OOS	The Simulation Mode/SIMULATION_MODE parameter is a structured parameter consisting of five elements. As the value and status specified here run through the complete algorithm, the behavior of the Analog Input Block can be checked. SIMULATE_STATUS - Enter the status for simulation. SIMULATE_STATUS - Enter the simulation value. TRANSDUCER_STATUS - Displays the current status of the Transducer Block which is linked to the Analog Input Block via the CHANNEL parameter. TRANSDUCER_VALUE - Displays the current process value of the Transducer Block which is linked to the Analog Input Block via the CHANNEL parameter. ENABLE_DISABLE - Switch the simulation mode on and off. The "Simulation" DIP switch on the electronic insert must be set to "On". → See also Operating Instructions BA00301P (Deltabar S) and BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Simulation" section. Factory setting: Simulation disabled (simulation mode not active)
Transducer Scale/ XD_SCALE Entry, selection Index: 10 Data type: DS-68 Access: man, OOS	The Transducer Scale/XD_SCALE parameter is a structured parameter consisting of four elements. EU_100: - Enter the upper limit for the input value of the Analog Input Block. - Factory setting: 100 EU_0: - Enter the lower limit for the input value of the Analog Input Block. - Factory setting: 0 UNITS_INDEX: - Select the unit. - Factory setting: % DECIMAL: - Displays the number of places after the decimal point for the input value. - Factory setting: 2 - The Transducer Scale/XD_SCALE parameter corresponds to the Primary Value Range/PRIMARY_VALUE_RANGE parameter (→ 56) in the Transducer Block. - If you have selected the "Direct" option via the Linearization Type/L_TYPE parameter, the settings for the Transducer Scale/XD_SCALE and Output Scale/OUT_SCALE parameters must be identical. If this is not the case, the block goes to the OOS mode and the "Block config error" message is displayed in the Block Error/BLOCK_ERROR parameter.

Analog Input Block	
Parameter	Description
Output Scale/ OUT_SCALE Entry, display Index: 11 Data type: DS-68 Access: auto, man, OOS	The Output Scale/OUT_SCALE parameter is a structured parameter consisting of four elements. EU_100: - Enter the upper limit for the output value of the AI Block OUT (→ 105). - Factory setting: 100 EU_0: - Enter the lower limit for the output value of the AI Block OUT. - Factory setting: 0 UNITS_INDEX: - Select the unit. - Factory setting: % DECIMAL: - Displays the number of places after the decimal point for the OUT output value. - Factory setting: 2 - The OUT output value is also transmitted if it is outside the scaling range. The status changes to BAD. - If you have selected the "Direct" option via the Linearization Type/L_TYPE parameter, the settings for the Transducer Scale/XD_SCALE and Output Scale/OUT_SCALE parameters must be identical. If this is not the case, the block goes to the OOS mode and the "Block config error" message is displayed in the Block Error/BLOCK_ERROR parameter.
Grant Deny/ GRANT_DENY Selection Index: 12 Data type: DS-70 Access: auto, man, OOS	Grant or restrict access authorization for a fieldbus host system to the device. This parameter is not evaluated by Deltabar S, Cerabar S and Deltapilot S.
I/O options/ IO_OPTS Selection Index: 13 Data type: bit string Access: OOS	Activate options for processing the input and output values of the function block. Factory setting: No option activated
Status Options/ STATUS_OPTS Selection Index: 14 Data type: bit string Access: OOS	Specify status processing and processing of the output parameter Output/OUT. Factory setting: No options active
Channel/CHANNEL Selection Index: 15 Data type: Access: OOS	Assign the output variables (process variables) of the "Pressure" or "Totalizer" Transducer Blocks to an Analog Input Block as the input value. Possibilities 1: Primary value from the Pressure Transducer Block - a pressure, level or flow value depending on the measuring mode selected 2: Secondary value from the Pressure Transducer Block, here the sensor temperature 6: Totalizer 1 from the DP Flow Transducer Block Factory setting: - Analog Input Block 1: Channel/CHANNEL = 1: Primary value (pressure measured value) - Analog Input Block 2: Channel/CHANNEL = 2: Secondary value (sensor temperature) - Analog Input Block 3: Channel/CHANNEL = 6: Totalizer 1

Analog Input Block	
Parameter	Description
Linearization Type/ L_TYPE Selection Index: 16 Data type: unsigned8 Access: OOS	Select the linearization mode for the input value. Options: ■ Direct: In this setting, the input value bypasses the linearization function and is looped unchanged with the same unit through the Analog Input function block. With this option the scaling and unit of the Transducer Scale/XD_SCALE and Output Scale/OUT_SCALE parameters must be identical. If this is not the case, the block goes to the OOS mode and the "Block config error" message is displayed in the Block Error/BLOCK_ERROR parameter. ■ Indirect: The input value is rescaled linearly via the Transducer Scale/XD_SCALE input scaling to the desired Output Scale/OUT_SCALE output range. ■ Indirect square root: The input value is rescaled via the Transducer Scale/XD_SCALE parameter and recalculated using a root function. It is then rescaled again to the desired output range via the Output Scale/OUT_SCALE parameter. Factory setting: Direct
Low Cutoff/LOW_CUT Entry Index: 17 Data type: float Access: auto, man, OOS	Enter the limit value for the low flow cut off. If the converted measured value is below this limit value, the Process Value/PV parameter displays "0". This parameter is only active if the "Low cutoff" option was activated via the I/O Options/IO_OPTS parameter. Input range: Range and unit of Output Scale/OUT_SCALE (→ 107) Factory setting: 0
Process Value Filter Time/PV_FTIME Entry Index: 18 Data type: float Access: auto, man, OOS	Enter the filter time constant for the 1st order digital filter. This time is required in order for 63% of a change in the controlled variable IN to have an effect on the value of Process Value/PV. P01-xxxxxxx-05-xx-xx-xx-021 Factory setting: 0 s
Field Value/ FIELD_VALUE Display Index: 19 Data type: Access: read only	The Field Value/FIELD_VALUE parameter is a structured parameter consisting of two elements. VALUE ■ Displays the process variables after input scaling of the Analog Input Block. The value relates to a percentage of the input range Transducer Scale/XD_SCALE and is replaced by the simulation value when simulation is active. STATUS ■ Displays the current status.

Analog Input Block	
Parameter	Description
Update Event/ UPDATE_EVT Display Index: 20 Data type: DS-73 Access: read only	The Update Event/UPDATE_EVT parameter is a structured parameter consisting of five elements. ACKNOWLEDGED ■ This element is set to "Unacknowledged" as soon as a static parameter changes. REPORTED ■ Displays the date and time when the message was generated. TIME_STAMP ■ Displays the date and time when a static parameter was changed. STATIC_REVISION ■ This revision counter is increased with the alarm. RELATIVE_INDEX ■ Displays the altered parameter in the form of the relative index. See also this Table, "Parameter, Index" column.
Block Alarm/ BLOCK_ALM Display, selection Index: 21 Data type: DS-72 Access: auto, man, OOS	The Block Alarm/BLOCK_ALM parameter is a structured parameter consisting of five elements. UNACKNOWLEDGED ■ If the "Deactivated" option was selected for the alarm that occurred by means of the Acknowledge Option/ACK_OPTION parameter, this alarm can only be acknowledged by means of this element. ALARM_STATE ■ Use this function to display the current block condition with information on pending configuration, hardware or system errors. The following block alarm messages are possible with the Analog Input Block: – Simulate active – Input failure – Block config error – Out of service TIME_STAMP ■ Displays the time when the alarm occurred. SUB_CODE ■ Displays the reason why the alarm was reported. VALUE ■ Displays the value of the corresponding parameter at the time the alarm was reported.
Alarm Summary/ ALARM_SUM Display, selection Index: 22 Data type: DS-74 Access: auto; man, OOS	The Alarm Summary/ALARM_SUM parameter is a structured parameter consisting of four elements. CURRENT ■ Displays the current status of the process alarms in the Analog Input Block. The following alarms are possible: HiHiAlm, HiAlm, LoLoAlm, LoAlm and BlockAlm. UNACKNOWLEDGED ■ Displays the process alarms not confirmed. UNREPORTED ■ Displays the process alarms not reported. DISABLED ■ Possibility of deactivating process alarms.

Analog Input Block	
Parameter	Description
Acknowledge Option/ ACK_OPTION Selection Index: 23 Data type: bit string Access: auto, man, OOS	Use this parameter to specify the process alarm to be acknowledged automatically as soon as it is detected by the fieldbus host system. If the option is activated for a process alarm, this process alarm is acknowledged automatically by the fieldbus host system. Options: ■ HiHiAlm: upper critical limit value alarm ■ HiAlm: upper limit value alarm ■ LoLoAlm: lower critical limit value alarm ■ LoAlm: lower limit value alarm ■ BlockAlm: block alarm The message has to be acknowledged via the Block Alarm/BLOCK_ALM parameter, UNACKNOWLEDGE element for process alarms for which automatic confirmation is not active. Factory setting: The option is not active for any process alarm, i.e. every process alarm message must be acknowledged manually.
Alarm Hysteresis/ ALARM_HYS Entry Index: 24 Data type: float Access: auto, man, OOS	Enter hysteresis value for the upper and lower alarm value or critical alarm value. The hysteresis affects the following alarm or critical alarm limit values: ■ High High Alarm/Hi_HI_ALM: upper critical alarm limit value ■ High Alarm/Hi_ALM: upper alarm limit value ■ Low Alarm/Lo_ALM: lower alarm limit value ■ Low Low Alarm/Lo_LO_ALM: lower critical alarm limit value Fig. 18: Illustration of the output value Output/OUT with limit values and hysteresis as well as the alarms High High Alarm/Hi_HI_ALM, High Alarm/Hi_ALM, Low Alarm/Lo_ALM and Low Low Alarm/Lo_LO_ALM Input range: 0.0 to 50.0 % with regard to the range of the OUT_SCALE group (→ 107) Factory setting: 0.5 %

Analog Input Block	
Parameter	Description
High High Priority/ HI_HI_PRI Entry Index: 25 Data type: unsigned8 Access: auto, man, OOS	Specify how the system should react if the High High Limit/HI_HI_LIM limit value (→ 111) is overshoot. Input range: ■ 0...15 ■ 0: The alarm is suppressed. ■ 1: The alarm is detected by the system. No notification is issued. ■ 2: Reserved for block alarms. ■ 3-7: Informative alarm with increasing priority, 3: Low priority, 7: High priority ■ 8-15: Critical alarm with increasing priority, 8: Low priority, 15: High priority Factory setting: 0
High High Limit/ HI_HI_LIM Entry Index: 26 Data type: float Access: auto, man, OOS	Enter upper critical limit value. Input range: Range and units of Output Scale/OUT_SCALE (→ 107) Factory setting: +INF
High Priority/HI_PRI Entry Index: 27 Data type: unsigned8 Access: auto, man, OOS	Specify how the system should react if the High Limit/HI_LIM limit value (® Page → 111) is overshoot. Input range: ■ 0...15 ■ 0: The alarm is suppressed. ■ 1: The alarm is detected by the system. No notification is issued. ■ 2: Reserved for block alarms. ■ 3-7: Informative alarm with increasing priority, 3: Low priority, 7: High priority ■ 8-15: Critical alarm with increasing priority, 8: Low priority, 15: High priority Factory setting: 0
High Limit/HI_LIM Entry Index: 28 Data type: float Access: auto, man, OOS	Enter upper limit value. Input range: Range and units of Output Scale/OUT_SCALE (→ 107) Factory setting: +INF
Low Priority/LO_PRI Entry Index: 29 Data type: unsigned8 Access: auto, man, OOS	Specify how the system should react if the Low Limit/LO_LIM limit value (→ 111) is undershot. Input range: ■ 0...15 ■ 0: The alarm is suppressed. ■ 1: The alarm is detected by the system. No notification is issued. ■ 2: Reserved for block alarms. ■ 3-7: Informative alarm with increasing priority, 3: Low priority, 7: High priority ■ 8-15: Critical alarm with increasing priority, 8: Low priority, 15: High priority Factory setting: 0
Low Limit/LO_LIM Entry Index: 30 Data type: float Access: auto, man, OOS	Enter lower limit value. Input range: Range and units of Output Scale/OUT_SCALE (→ 107) Factory setting: -INF

Analog Input Block	
Parameter	Description
Low Low Priority/ LO_LO_PRI Entry Index: 31 Data type: unsigned8 Access: auto, man, OOS	Specify how the system should react if the Low Low Limit/LO_LO_LIM limit value (→ 112) is undershot. Input range: ▪ 0...15 ▪ 0: The alarm is suppressed. ▪ 1: The alarm is detected by the system. No notification is issued. ▪ 2: Reserved for block alarms. ▪ 3-7: Informative alarm with increasing priority, 3: Low priority, 7: High priority ▪ 8-15: Critical alarm with increasing priority, 8: Low priority, 15: High priority Factory setting: 0
Low Low Limit/ LO_LO_LIM Entry Index: 32 Data type: float Access: auto, man, OOS	Enter lower critical limit value. Input range: Range and units of Output Scale/OUT_SCALE (→ 107) Factory setting: -INF
Low Low Alarm/ LO_LO_ALM Display, selection Index: 33 Data type: DS-71 Access: auto, man, OOS	Status display for the Low Low Limit/LO_LO_LIM limit value (→ 112).
High High Alarm/ HI_HI_ALM Display, selection Index: 33 Data type: DS-71 Access: auto, man, OOS	Status display for the High High Limit/HI_HI_LIM limit value (→ 111).
High Alarm/HI_ALM Display, selection Index: 34 Data type: DS-71 Access: auto, man, OOS	Status display for the High Limit/HI_LIM limit value (→ 111).
Low Alarm/LO_ALM Display, selection Index: 35 Data type: DS-71 Access: auto, man, OOS	Status display for the Low Limit/LO_LIM limit value (→ 111).

Analog Input Block	
Parameter	Description
Fsafe_Type/ FSAFE_TYPE Selection Index: 37 Data type: unsigned8 Access: read, write, OOS, MAN	If the Analog Input Block receives an input value or simulation value with the status BAD, the Analog Input Block continues working with the failsafe mode defined by means of this parameter. The following options are available by means of the Fsafe_Type/FSAFE_TYPE parameter: ■ Last Good Value The last valid value is used for further processing with the status UNCERTAIN. ■ Fail Safe Value The value specified by means of the Fsafe_Value/FSAFE_VALUE parameter is used for further processing with the status UNCERTAIN. → See this Table, Fsafe_Type/FSAFE_TYPE parameter description. ■ Wrong Value The current value is used for further processing with the status BAD. The failsafe mode is also activated if the "Out of service" option was selected by means of the Block Mode/MODE_BLK parameter, "Target" element. Factory setting: Fail Safe Value
Fsafe_Value/ FSAFE_VALUE Entry Index: 38 Data type: float Access: read, write, AUTO, OOS, MAN	Enter the value for the "Fail Safe Value" option selected by means of the Fsafe_Type/FSAFE_TYPE parameter. → See also this Table, Fsafe_Type/FSAFE_TYPE parameter description. Factory setting: 0
High High Alarm Output Discrete/ HIHI_ALM_OUT_D Index: 39 Data type: DS66 Access: read, write, AUTO, OOS, MAN	Digital outputs (1 or 0) for limit value monitoring. If "Process Value/PV $\geq$ High High Limit/HI_HI_LIM", the output is set to "1".
High Alarm Output Dis- crete/HI_ALM_OUT_D Index: 40 Data type: DS66 Access: read, write, AUTO, OOS, MAN	Digital outputs (1 or 0) for limit value monitoring. If "Process Value/PV $\geq$ High Limit/HI_LIM", the output is set to "1".
Low Alarm Output Dis- crete/LO_ALM_OUT_D Index: 41 Data type: DS66 Access: read, write, AUTO, OOS, MAN	Digital outputs (1 or 0) for limit value monitoring. If "Process Value/PV $\leq$ Low Low Limit/LO_LO_LIM", the output is set to "1".
Low Low Alarm Output Discrete/LOLO_ALM_ OUT_D Index: 42 Data type: DS66 Access: read, write, AUTO, OOS, MAN	Digital outputs (1 or 0) for limit value monitoring. If "Process Value/PV $\leq$ Low Limit/LO_LIM", the output is set to "1".

Analog Input Block	
Parameter	Description
Select Alarm Mode/ ALARM_MODE Index: 43 Data type: unsigned8 Access: read, write, AUTO, OOS, MAN	Facilitates alarm mode settings for the Alarm Output Discrete/ALM_OUT_D parameter Options - Low Cutoff/LOW_CUT - HiHi or LoLo Alarm activates ALARM_OUT_D/HIHI_LOLO - Hi or Lo Alarm activates ALARM_OUT_D/HI_LO
Alarm Output Discrete/ ALM_OUT_D Index: 44 Data type: DS-66 Access: read, write, AUTO, OOS, MAN	The Alarm Output Discrete/ALM_OUT_D parameter comprises the 4 alarms (LO, LOLO, HI, HIHI). The 3 values make it possible to view the current, activated alarm depending on the alarm selected. Options: - LOW_CUT alarm (default): The ALM_OUT_D output returns 1 if the LOW_CUT function restricts the measured value to 0. Otherwise the ALM_OUT_D output is 0. - HIHI/LOLO collective alarm: The ALM_OUT_D output returns 1 if the measured value corresponds to the HIHI limit value or overshoots this value if the measured value corresponds to the LOLO limit value or undershoots this value. The output returns 0 if the measured value is between the limit values HIHI and LOLO. - HI/LO collective alarm: The ALM_OUT_D output returns 1 if the measured value corresponds to the HI limit value or overshoots this value if the measured value corresponds to the LO limit value or undershoots this value. The output returns 0 if the measured value is between the limit values HI and LO.
Block Error Description/ BLOCK_ERR_DESC_1 Index: 45 Data type: Unsigned32 Access: read, AUTO, OOS, MAN	Detailed description of the errors that occur within the block. Error messages: - RS_BLOCK in OOS - Block not scheduled - Channel undefined - L-Type undefined - AI / TRD unit inconsistent

8 Pressure measurement (via local operation and FieldCare)

- The Cerabar S and the Deltabar S are configured for the pressure measuring mode as standard. The Deltapilot S is configured for the level measuring mode as standard. The measuring range and the unit in which the measured value is transmitted, as well as the digital output value of the Analog Input Block OUT, correspond to the data on the nameplate.
- See also Operating Instructions for Deltabar S (BA00301P) "Pressure measurement" section, Cerabar S (BA00302P), "Pressure measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- For a description of the parameters mentioned, see
 - → [147](#), Table 2: GROUP SELECTION → MEASURING MODE
 - → [155](#), Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → [157](#), Table 7: OPERATING MENU → SETTINGS → BASIC SETUP "Pressure".
- For a description of further relevant parameters, see
 - → [197](#), Table 15: OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure"
 - → [214](#), Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure".
- You can also specify a customer-specific unit. See parameter description for PRESS. ENG. UNIT (060) (→ [157](#)).

8.1 Selecting the measuring mode

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

8.1.1 Local operation

The MEASURING MODE parameter is on the 1st selection level.

→ [146](#), Section 11 "Parameter description (local operation and FieldCare)".

The following measuring modes are available:

- Pressure
- Level
- Flow

8.1.2 Selecting the measuring mode by means of the FieldCare operating program

Selecting the measuring mode

The parameters for setting the measuring mode are displayed in the FieldCare "Measuring mode" menu:




Fig. 19: "Measuring mode" menu

The following measuring mode settings are available:

Primary Value Type	Linearization	Level mode
Pressure	None	-
Flow	Root function	-
Level, mass, volume	None	Level Easy Pressure
Level, mass, volume	None	Level Easy Height
Level, mass, volume, tank content in %	None	Level Standard
Level, mass, volume, tank content in %	Level linearized	Level Standard
Level, mass, volume, tank content in %	Level combined	Level Standard

9 Level measurement (via local operation and FieldCare)

9.1 Overview of level measurement

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	Description	Comment	Measured value display
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering two pressure-level value pairs.	LEVEL SELECTION: Level easy pressure	Via OUTPUT UNIT parameter: %, level, volume or mass units.	– Calibration with reference pressure – wet calibration, see → 119, Section 9.2.1 – Calibration without reference pressure – dry calibration, see → 121, Section 9.2.2	– Incorrect entries are possible – Customized units are not possible	The measured value display and the LEVEL BEFORE LIN. parameter show the measured value.
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering the density and two height-level value pairs.	LEVEL SELECTION: Level easy height	Via OUTPUT UNIT parameter: %, level, volume or mass units.	– Calibration with reference pressure – wet calibration, see → 123, Section 9.3.1 – Calibration without reference pressure – dry calibration, see → 125, Section 9.3.2	– Incorrect entries are possible – Customized units are not possible	The measured value display and the LEVEL BEFORE LIN. parameter show the measured value.
The measured variable is in direct proportion to the measured pressure.	LEVEL SELECTION: Level standard/ LEVEL MODE: Linear	Via LIN. MEASURAND parameter: – % (level) – Level – Volume – Mass	– Calibration with reference pressure – wet calibration, see → 127, Section 9.4.1 – Calibration without reference pressure – dry calibration, see → 129, Section 9.4.2	– Incorrect entries are rejected by the device – Customized level, volume and mass units are possible	The measured value display and the LEVEL BEFORE LIN. parameter show the measured value.
The measured variable is not in direct proportion to the measured pressure as is the case with tanks with a conical outlet, for example. A linearization table has to be entered for the calibration.	LEVEL SELECTION: Level standard/ LEVEL MODE: Pressure linearized	Via LIND MEASURAND parameter: – Pressure + % – Pressure + volume – Pressure + mass	– Calibration with reference pressure: semiautomatic entry of linearization table, see → 131, Section 9.5.1 – Calibration without reference pressure: manual entry of linearization table, see → 134, Section 9.5.2.	– Incorrect entries are rejected by the device – Customized level, volume and mass units are possible	The measured value display and the TANK CONTENT parameter show the measured value.

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	Description	Comment	Measured value display
- Two measured variables are required or - The container shape is given by value pairs, such as height and volume. The 1st measured variable %-height or height must be in direct proportion to the measured pressure. The 2nd measured variable volume, mass or % must not be in direct proportion to the measured pressure. A linearization table must be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table.	LEVEL SELECTION: Level standard/ LEVEL MODE: Height linearized	Via COMB. MEASURAND parameter: - Height + volume - Height + mass - Height + % %-height + volume %-height + mass %-height + %	- Calibration with reference pressure: wet calibration and semiautomatic entry of linearization table, see → 137, Section 9.6.1 - Calibration without reference pressure: dry calibration and manual entry of linearization table, see → 140, Section 9.6.2.	- Incorrect entries are rejected by the device - Customized level, volume and mass units are possible	The measured value display and the TANK CONTENT parameter show the 2nd measured value (volume, mass or %). The LEVEL BEFORE LIN parameter displays the 1st measured value (%-height or height).

9.2 "Level easy pressure" level selection

9.2.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m. The pressure range is set to 0-300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for EMPTY CALIB. and FULL CALIB. must be at least 1% apart for the "Level easy pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - → 147, Table 2: GROUP SELECTION → MEASURING MODE
 - → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → 159, Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure".
- For a description of further relevant parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.


- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	② 300 mbar 3 m ① 0 mbar 0 m P01-PMP75xxx-19-xx-xx-xx-008
2	Carry out position adjustment if necessary. See Page → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.	
3	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	
4	If necessary, select the "Level easy pressure" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection	

Fig. 20: Calibration with reference pressure – wet calibration

- 1 See Table, Step 9.
2 See Table, Step 10.

Description	
5	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.
7	Select a level unit via the OUTPUT UNIT parameter, here m for example.
8	Select the "Wet" option by means of the CALIBRATION MODE parameter.
9	The hydrostatic pressure for the lower calibration point is present at the device, here 0 mbar for example. Select the EMPTY CALIB. parameter. Enter the level value, here 0 m for example. The pressure value present is assigned to the lower level value by confirming the value. To accept the value displayed, you must first switch to the edit mode (see "Editing a value" section) and then save the value with the "E" key.
10	The hydrostatic pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example. Select the FULL CALIB. parameter. Enter the level value, here 3 m (9.8 ft) for example. The pressure value present is assigned to the upper level value by confirming the value. To accept the value displayed, you must first switch to the edit mode (see "Editing a value" section) and then save the value with the "E" key.
11	Result: The measuring range is set for 0 to 3 m (9.8 ft).



P01-xxxxxxx-05-xx-xx-xx-011

Fig. 21: Calibration with reference pressure – wet calibration

- 1 See Table, Step 9.
- 2 See Table, Step 10.

1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. → 151 ff, Table 4: QUICK SETUP "Level".
2. For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT, → 161.
3. If operating via the local operation, the EMPTY CALIB. (010) (→ 162) and FULL CALIB. (004) (→ 162) parameters also show the pressure present at the device. For operation using FieldCare, the pressure present at the device is displayed in the PROCESS VALUES group.

9.2.2 Calibration without reference pressure – dry calibration


Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a pressure of 450 mbar (6.75 psi). The minimum volume of 0 liters corresponds to a pressure of 50 mbar (0.75 psi) since the device is mounted below the level lower-range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for EMPTY CALIB. (010) and FULL CALIB. (004) must be at least 1 % apart for the "Level easy pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. → For information on how to perform position adjustment, → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
- For a description of the parameters mentioned, see
 - → 147, Table 2: GROUP SELECTION → MEASURING MODE
 - → 159, Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"
- For a description of further relevant parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type
2	If necessary, select the "Level easy pressure" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection
3	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP



P01-PMC71xxx-19-xx-xx-xx-008

Fig. 22: Calibration without reference pressure – dry calibration

1 See Table, Step 10.

2 See Table, Step 11.

3 See Table, Step 12.

4 See Table, Step 13.

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	Fig. 23: Calibration with reference pressure – wet calibration P01-xxxxxxx-05-xx-xx-xx-026 1 See Table, Step 7. 2 See Table, Step 8. 3 See Table, Step 9. 4 See Table, Step 10.
5	Select a volume unit via the OUTPUT UNIT parameter, here l (liters) for example.	
6	Select the "Dry" option by means of the CALIBRATION MODE parameter.	
7	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example.	
8	Enter the pressure value for the lower calibration point via the EMPTY PRESSURE parameter, here 50 mbar (1 psi) for example.	
9	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 US gal) for example.	
10	Enter the pressure value for the upper calibration point via the FULL PRESSURE parameter, here 450 mbar (7 psi) for example.	
11	Result: The measuring range is set for 0 to 1000 l (264 US gal).	

- For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT (023), → 161.

9.3 "Level easy height" level selection

9.3.1 Calibration with reference pressure – wet calibration

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the level lower-range value. The density of the fluid is 1 kg/dm³.

Prerequisite:


- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE and EMPTY HEIGHT/FULL HEIGHT must be at least 1% apart for the "Level easy height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - 147, Table 2: GROUP SELECTION → MEASURING MODE
 - 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - 163, Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height".
- For a description of further relevant parameters, see
 - 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".



▲ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMC71xxx-19-xx-xx-xx-009 Fig. 24: Calibration with reference pressure – wet calibration 1 See Table, Steps 10 and 11. 2 See Table, Step 12. 3 See Table, Step 13.
2	Carry out position adjustment if necessary. See Page → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.	
3	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	

	Description	
4	If necessary, select the "Level easy height" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection	 P01-xxxxxxx-05-xx-xx-xx-029
5	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select a volume unit via the OUTPUT UNIT parameter, here l (liters) for example.	
8	Select a height unit via the HEIGHT UNIT parameter, here m for example.	 P01-xxxxxxx-05-xx-xx-xx-030
9	Select the "Wet" option by means of the CALIBRATION MODE parameter.	
10	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.	
11	Enter the density of the fluid using the ADJUST DENSITY parameter, here 1 (liter) for example.	
12	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example. (The hydrostatic pressure currently measured is displayed as a height value, here 0.5 m (1.6 ft) for example.) To accept the value displayed, you must first switch to the edit mode (see "Editing a value" section) and then save the value with the "E" key.	Fig. 25: Calibration with reference pressure – wet calibration 1 See Table, Steps 10 and 11. 2 See Table, Step 12. 3 See Table, Step 13.
13	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 US gal) for example. (The hydrostatic pressure currently measured is displayed as a height value, here 4.5 m (15 ft) for example.) To accept the value displayed, you must first switch to the edit mode (see "Editing a value" section) and then save the value with the "E" key.	
14	Result: The measuring range is set for 0 to 1000 l (264 US gal).	

- For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT (023), → 165.

9.3.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in liters. The maximum volume of 1000 liters (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 liters corresponds to a level of 0.5 m (1.6 ft) since the device is mounted below the level lower-range value. The density of the fluid is 1 kg/dm³.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the height and volume values for the lower and upper calibration point must be known.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE and EMPTY HEIGHT/FULL HEIGHT must be at least 1% apart for the "Level easy height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. → For information on how to perform position adjustment, → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
- For a description of the parameters mentioned, see
 - → 147, Table 2: GROUP SELECTION → MEASURING MODE
 - → 163, Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height".
- For a description of further relevant parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.



- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type
2	If necessary, select the "Level easy height" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection
3	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP

P01-PMC71xxx-19-xx-xx-xx-009

Fig. 26: Calibration without reference pressure – dry calibration

1 See Table, Step 11.
2 See Table, Steps 13 and 14.
3 See Table, Steps 15 and 16.

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	 $h = \frac{p}{\rho \cdot g}$ ① $\rho = 1 \frac{\text{g}}{\text{cm}^3}$ P01-xxxxxxx-05-xx-xx-xx-029  ② V ③ ④ ⑤ $h = \frac{p}{\rho \cdot g}$ P01-xxxxxxx-05-xx-xx-xx-032 Fig. 27: Calibration with reference pressure – wet calibration 1 See Table, Steps 8 and 9. 2 See Table, Step 10. 3 See Table, Step 11. 4 See Table, Step 12. 5 See Table, Step 13.
5	Select a volume unit via the OUTPUT UNIT parameter, here l (liters) for example.	
6	Select a height unit via the HEIGHT UNIT parameter, here m for example.	
7	Select the "Dry" option by means of the CALIBRATION MODE parameter.	
8	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.	
9	Enter the density of the fluid using the ADJUST DENSITY parameter, here 1 kg/dm ³ for example.	
10	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l (liters) for example.	
11	Enter the height value for the lower calibration point via the EMPTY HEIGHT parameter, here 0.5 mbar (1.6 ft) for example.	
12	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (liters) (264 US gal) for example.	
13	Enter the height value for the upper calibration point via the FULL HEIGHT parameter, here 4.5 m (15 ft) for example.	
14	Result: The measuring range is set for 0 to 1000 l (liters) (264 US gal).	

1. For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT (023), → 165.

9.4 "Level standard" level selection, "Linear" level mode

9.4.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0-300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled and emptied.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- For a description of the parameters mentioned, see
 - → [147](#), Table 2: GROUP SELECTION → MEASURING MODE
 - → [155](#), Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → [167](#), Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"
 - → [171](#), Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear".
- For a description of further relevant parameters, see
 - → [197](#), Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → [215](#), Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".


▲ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!


Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.
2	Carry out position adjustment if necessary. See Page → 155 , Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
3	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type
4	If necessary, select the "Level standard" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Level Selection



P01-PMP75xxx-19-xx-xx-xx-008

Fig. 28: Calibration with reference pressure – wet calibration

- 1 See Table, Step 11.
- 2 See Table, Step 12.

	Description	
5	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	 P01-xxxxxxx-05-xx-xx-xx-011
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Linear" option by means of the LEVEL MODE parameter.	
8	Select the "Level" option by means of the LIN. MEASURAND parameter.	
9	Select a level unit via the HEIGHT UNIT parameter, here m for example.	
10	Select the "Wet" option by means of the CALIBRATION MODE parameter.	
11	The pressure for the lower calibration point is present at the device, here 0 mbar for example.	
	Select the EMPTY CALIB. parameter.	
	Enter the level value, here 0 m for example. The pressure value present is assigned to the lower level value by confirming the value.	
12	The pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example.	
	Select the FULL CALIB. parameter.	
	Enter the level value, here 3 m (9.8 ft) for example. The pressure value present is assigned to the upper level value by confirming the value.	
14	Result: The corresponding pressure value has been assigned to the lower and upper level value. The device is ready for level measurement.	1 See Table, Step 11. 2 See Table, Step 12.

1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. → 151 ff, Table 4: QUICK SETUP "Level".
2. You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→ 168), HEIGHT UNIT (708) (→ 171), UNIT VOLUME (313) (→ 172) and MASS UNIT (709) (→ 173).
3. For this level mode, the measured variables %, level, volume and mass are available. → 171 ff.
4. The EMPTY PRESSURE (710) (→ 174) and FULL PRESSURE (711) (→ 175) parameters display the pressure values belonging to the EMPTY CALIB. and FULL CALIB. parameters.

9.4.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in m³. The maximum volume is 5 m³ and the maximum height is 4 m (13 ft). The density of the fluid is 1 kg/dm³. The device is mounted below the level lower-range value.

Prerequisite:


- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration, i.e. the tank volume, tank height and density of the fluid are known.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. → For information on how to perform position adjustment, → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
- For a description of the parameters mentioned, see
 - → 147, Table 2: GROUP SELECTION → MEASURING MODE
 - → 167, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"
 - → 171, Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear".
- For a description of further relevant parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	 P01-PMP75xxx-19-xx-xx-xx-003 Fig. 29: Calibration without reference pressure – dry calibration 1 See Table, Step 9. 2 See Table, Step 10. 3 See Table, Step 11. 4 See Table, Step 12.

	Description	
2	If necessary, select the "Level standard" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection	
3	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
5	Select the "Linear" option by means of the LEVEL MODE parameter.	
6	Select the "Volume" option by means of the LIN. MEASURAND parameter.	
7	Select a volume unit via the UNIT VOLUME parameter, here m ³ for example.	
8	Select the "Dry" option by means of the CALIBRATION MODE parameter.	
9	Enter the value for density via the ADJUST DENSITY parameter, here 1 kg/dm ³ for example.	
10	Enter the tank volume via the TANK VOLUME parameter, here 5 m ³ for example.	
11	Enter the tank height via the TANK HEIGHT parameter, here 4 m (13 ft) for example.	
12	Enter the level offset via the ZERO POSITION parameter, here -0.5 m (-1.6 ft) for example.	
13	Result: The device is ready for level measurement	

- For this level mode, the measured variables %, level, volume and mass are available.
→  171 ff.
- You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→  168), HEIGHT UNIT (708) (→  171), UNIT VOLUME (313) (→  172) and MASS UNIT (709) (→  173).

9.5 "Level standard" level selection, "Pressure linearized" level mode

9.5.1 Semiautomatic entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- The tank can be filled. The linearization characteristic must rise continuously.
- See also Operating Instructions for Deltabar S (BA00301P) or Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- For a description of the parameters mentioned, see
 - 147, Table 2: GROUP SELECTION → MEASURING MODE
 - 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - 167, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"
 - 171, Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"
 - 200, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation
 - 203, Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare
- For a description of further relevant parameters, see
 - 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- ▶ If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	P01-PMP75xxx-19-xx-xx-xx-xx-002
2	Carry out position adjustment if necessary. See Page → 151, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.	
Carry out basic setup:		
3	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	
4	If necessary, select the "Level standard" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection	

	Description	
5	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	P01-xxxxxxx-05-xx-xx-xx-015
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Pressure linearized" option by means of the LEVEL MODE parameter. See also Point 3 in the following note.	
8	Select the "Pressure and volume" option by means of the LIND. MEASURAND parameter.	
9	Select a volume unit via the UNIT VOLUME parameter, here m³ for example.	
10	Select the HYDR. PRESS MIN. parameter. Enter the minimum hydrostatic pressure to be expected, here 0 mbar for example.	
11	Select the HYDR. PRESS MAX. parameter. Enter the maximum hydrostatic pressure to be expected, here 350 mbar for example.	
Carry out linearization:		
12	Change the function group. Local operation: Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION FieldCare: Menu path: OPERATING MENU → SETTINGS → LINEARIZATION	
13	Select the TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m³ for example.	
14	Select the TANK CONTENT MAX parameter . Specify the maximum tank contents to be expected, here 3.5 m³ for example. See also Point 4 in the following note.	
15	Local operation: Select the "Editor table" option by means of the TABLE SELECTION parameter.	Fig. 30: Semiautomatic entry of the linearization table 1 See Table, Step 10. 2 See Table, Step 11. 3 See Table, Step 13. 4 See Table, Step 14. 5 See Table, Steps 15 to 19.
16	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.	
17	Select the "New table" option by means of the EDITOR TABLE parameter.	
18	Enter the linearization table (min. 2 points, max. 32 points).	
	Fill the tank to the height of the 1st point.	
	LINE-NUMB: enter the value of the corresponding point.	
	X-VAL.: The hydrostatic pressure present is displayed. The X-VAL. displayed is saved by confirming the Y-value. See following line, Y-VAL.	
	Y-VAL.: Enter the volume value, here 0 m³ for example, and confirm the value.	

Description	
19	Local operation: If you want to enter another point for the linearization table, select the "Next point" option and enter the point as described in Step 18. If you want to finish entering the values and activate the linearization table, select the "Accept input table" option. FieldCare: You can enter further points for the linearization table as explained in Step 18. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.
20	Where necessary scale the OUT value of the Analog Input Block, see Page → 104 parameter descriptions. For this purpose, equate XD SCALE and OUT SCALE or the OUT value with the measured value.
21	Result: The linearization table has been entered and the device is ready for level measurement.

- For this level mode, the measured variables %, volume and mass are available.
→ 179 ff.
- You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→ 168), HEIGHT UNIT (708) (→ 177), UNIT VOLUME (313) (→ 180) and MASS UNIT (709) (→ 181).
- Once you have selected the "Pressure linearized" level mode, the warning message "W710 Set span too small. Not allowed." can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearization table, is smaller than the minimum span permitted (→ MINIMUM SPAN (591), → 212). The message disappears as soon as the highest X-VALUE is greater than the minimum span and the table entered is active.
- Once you have entered the maximum tank contents to be expected for TANK CONTENT MAX., the alarm "A719 Y-Val of lin. table out of edit limits" can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest Y-VALUE of the linearization table, is greater than the value entered for TANK CONTENT MAX. The message disappears as soon as no Y-VALUE is greater than the value for TANK CONTENT MAX. and the table entered is active.

9.5.2 Manual entry of the linearization table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearization table are known.
- See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. → For information on how to perform position adjustment, → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
- For a description of the parameters mentioned, see
 - → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → 159, Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"
 - → 179, Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized"
 - → 200, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation
 - → 203, Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare
- For a description of further relevant parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!






	Description	
1	Perform calibration as per Section 9.5.1, Steps 3 to 11.	
	Carry out linearization:	
2	Change the function group. Local operation: Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION FieldCare: Menu path: OPERATING MENU → SETTINGS → LINEARIZATION	
3	Select the TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m³ for example.	
4	Select the TANK CONTENT MAX parameter . Specify the maximum tank contents to be expected, here 3.5 m³ for example. See also Point 3 in the following note.	
5	Select the "Editor table" option by means of the TABLE SELECTION parameter.	
6	Select the "Manual" option by means of the LIN. EDIT MODE parameter.	
7	Select the "New table" option by means of the EDITOR TABLE parameter.	
8	Enter the linearization table (min. 2 points, max. 32 points). LINE-NUMB: Confirm value displayed. X-VAL.: enter the pressure value and confirm. Y-VAL.: Enter the volume value, here 0 m³ for example, and confirm.	
9	Local operation: If you want to enter another point for the linearization table, select the "Next point" option and enter the point as described in Step 8. If you want to finish entering the values and activate the linearization table, select the "Accept input table" option. FieldCare: You can enter further points for the linearization table as explained in Step 8. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	
10	Where necessary scale the OUT value of the Analog Input Block, see Page → 104 parameter descriptions. For this purpose, equate XD SCALE and OUT SCALE or the OUT value with the measured value.	
11	Result: The linearization table has been entered and the device is ready for level measurement.	

Fig. 31: Manual entry of the linearization table

- 1 See Section 9.5.1, Table, Step 10.
- 2 See Section 9.5.1, Table, Step 11.
- 3 See Table, Step 3.
- 4 See Table, Step 4.
- 5 See Table, Steps 5 to 9.

1. For this level mode, the measured variables %, volume and mass are available.
→ 179 ff.

2. You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→ [168](#)), HEIGHT UNIT (708) (→ [177](#)), UNIT VOLUME (313) (→ [180](#)) and MASS UNIT (709) (→ [181](#)).
3. Once you have selected the "Pressure linearized" level mode, the warning message "W710 Set span too small. Not allowed." can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearization table, is smaller than the minimum span permitted (→ MINIMUM SPAN (591), → [212](#)). The message disappears as soon as the highest X-VALUE is greater than the minimum span and the table entered is active.

9.6 "Height linearized" level mode

9.6.1 Wet calibration and semiautomatic entry of the linearization table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:


- The tank can be filled. The linearization characteristic must rise continuously.
- See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P), "Level measurement" section or Deltapilot S (BA00372P), "Level measurement" section.
- For a description of the parameters mentioned, see
 - → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → 167, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"
 - → 184, Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"
 - → 200, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation
 - → 203, Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare
- For a description of further parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".

▲ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Deltabar S: Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	 P01-PMP75xxx-19-xx-xx-xx-004
2	Carry out position adjustment if necessary. See Page → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.	
	Perform calibration for the 1st measured variable:	
3	Select the "Level" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	
4	If necessary, select the "Level standard" level mode using the LEVEL SELECTION parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION FieldCare: Menu path: MEASURING MODE → Level Selection	

	Description	
5	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	P01-xxxxxxx-05-xx-xx-xx-017
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Height linearized" option by means of the LEVEL MODE parameter.	
8	Select the "Height + volume" option by means of the COMB. MEASURAND parameter.	
9	Select the unit for the 1st measured value via the HEIGHT UNIT parameter, here m for example.	
10	Select the unit for the 2nd measured variable via the UNIT VOLUME parameter, here m ³ for example.	Fig. 32: Calibrating the 1st measured variable 1 See Table, Step 11. 2 See Table, Step 12. 3 See Table, Step 14. 4 See Table, Step 15.
11	Select the LEVEL MIN parameter.	
	Enter the minimum level to be expected, here 0 m for example.	
12	Select the LEVEL MAX parameter.	
	Enter the maximum level to be expected, here 3 m for example. See also Point 3 in the following note.	
13	Select the "Wet" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).	
14	The pressure for the lower calibration point is present at the device, here 0 mbar for example.	
	Select the EMPTY CALIB. parameter.	
	Enter the level value, here 0 m for example. The pressure value present is assigned to the lower level value by confirming the value.	
15	The pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example.	
	Select the FULL CALIB. parameter.	
	Enter the level value, here 3 m (9.8 ft) for example. The pressure value present is assigned to the upper level value by confirming the value.	
16	Result: The calibration for the 1st measured variable is carried out.	
	Perform linearization (calibration for the 2nd measured variable)	
17	Change the function group. Local operation: Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION FieldCare: Menu path: OPERATING MENU → SETTINGS → LINEARIZATION	
18	Select the TANK CONTENT MIN parameter.	
	Specify the minimum tank contents to be expected, here 0 m ³ for example.	
19	Select the TANK CONTENT MAX parameter.	
	Specify the maximum tank contents to be expected, here 5 m ³ for example.	

	Description	
20	Select the "Editor table" option by means of the TABLE SELECTION parameter.	P01-PMP75xxx-19-xx-xx-xx-005
21	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.	
22	Select the "New table" option by means of the EDITOR TABLE parameter.	
23	Enter the linearization table (min. 2 points, max. 32 points).	
	Fill the tank to the height of the 1st point.	
	LINE-NUMB: Confirm value displayed.	P01-xxxxxxx-05-xx-xx-xx-018
	X-VAL.: The hydrostatic pressure present is measured and converted to the corresponding level and displayed. The X-VAL. displayed is saved by confirming the Y-value. See following line, Y-VAL.	
	Y-VAL.: Enter the volume value, here 0 m³ for example, and confirm the value.	
24	Local operation If you want to enter another point for the linearization table, select the "Next point" option and enter the point as described in Step 23. If you want to finish entering the values and activate the linearization table, select the "Accept input table" option. FieldCare: You can enter further points for the linearization table as explained in Step 23. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	
25	Result: – The linearization table has been entered. – The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). – The LEVEL BEFORE LIN parameter displays the 1st measured value (here the height). See also Point 5 in the following note.	

Fig. 33: Calibrating the 2nd measured variable

5 See Table, Step 18.

6 See Table, Step 19.

7 See Table, Steps 20 to 24.

- For this level mode, the measured variables "height + %", "height + volume", "height + mass", "%-height + %", "%-height + volume" and "%-height + mass" are available.
→ 180 ff.
- You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→ 168), HEIGHT UNIT (708) (→ 184), UNIT VOLUME (313) (→ 185) and MASS UNIT (709) (→ 186).
- Once you have entered the maximum level to be expected for LEVEL MAX., the alarm "A707 X-Val of lin. table out of edit limits" can appear. At this stage, the linearization table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VALUE of the linearization table, is greater than the maximum level entered. The message disappears as soon as the highest X-VALUE is greater than the maximum level and the table entered is active.
- You can use the MENU DESCRIPTOR (416) parameter (→ 208) to specify which measured value should be displayed on the local operation.

9.6.2 Dry calibration and manual entry of the linearization table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearization table are known.
- See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P), "Level measurement" section or Deltapilot (BA00372P), "Level measurement" section.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. → For information on how to perform position adjustment, → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.
- For a description of the parameters mentioned, see
 - → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → 167, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"
 - → 184, Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"
 - → 200, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation
 - → 203, Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare
- For a description of further parameters, see
 - → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
 - → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level".


⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

Description	
Perform calibration for the 1st measured variable:	
1	Perform calibration as per Section 9.6.1, Steps 1 to 12.
2	Select the "Dry" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).
3	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.
4	Enter the density of the fluid via the ADJUST DENSITY parameter, here 1.0 for example.
5	If necessary, enter a level offset via the ZERO POSITION parameter, here 0 m for example.
6	Result: The calibration for the 1st measured variable is carried out.
Perform linearization (calibration for the 2nd measured variable)	
7	Change the function group. Local operation: Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION FieldCare: Menu path: OPERATING MENU → SETTINGS → LINEARIZATION



P01-PMP75xxx-19-xx-xx-xx-005

	Description	
8	Select the TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m ³ for example.	
9	Select the TANK CONTENT MAX parameter . Specify the maximum tank contents to be expected, here 5 m ³ for example.	
10	Select the "Editor table" option by means of the TABLE SELECTION parameter.	
11	Select the "Manual" option by means of the LIN. EDIT MODE parameter.	
12	Select the "New table" option by means of the EDITOR TABLE parameter.	
13	Enter the linearization table (min. 2 points, max. 32 points). LINE-NUMB: Confirm value displayed. X-VAL.: enter the height value and confirm. Y-VAL.: Enter the volume value, here 0 m ³ for example, and confirm.	
14	Local operation If you want to enter another point for the linearization table, select the "Next point" option and enter the point as described in Step 13. If you want to finish entering the values and activate the linearization table, select the "Accept input table" option. FieldCare: You can enter further points for the linearization table as explained in Step 13. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	P01-xxxxxxx-05-xx-xx-xx-018 Fig. 34: Calibrating the 2nd measured variable 5 See Table, Step 8. 6 See Table, Step 9. 7 See Table, Steps 10 to 14.
15	Result: – The linearization table has been entered. – The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). – The LEVEL BEFORE LIN. parameter displays the 1st measured value (here the height). See also Point 3 in the following note.	

- For this level mode, the measured variables "height + %", "height + volume", "height + mass", "%-height + %", "%-height + volume" and "%-height + mass" are available.
→ 180 ff.
- You can also specify customer-specific units. See parameter descriptions for PRESS. ENG. UNIT (060) (→ 168), HEIGHT UNIT (708) (→ 184), UNIT VOLUME (313) (→ 185) and MASS UNIT (709) (→ 186).
- You can use the MENU DESCRIPTOR (416) parameter (→ 208) to specify which measured value should be displayed on the local operation.

10 Flow measurement (via local operation and FieldCare)

10.1 Calibration

Example:

In this example, a volume flow should be measured in m³/h.

- The "Flow measurement" measuring mode is only available for the Deltabar S differential pressure transmitter.
- See also Operating Instructions for Deltabar S (BA00301P), "Flow measurement" section.
- For a description of the parameters mentioned, see
 - → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT
 - → 192 ff, Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow".
- For a description of further parameters, see
 - → 198, Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"
 - → 216, Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow".

⚠ WARNING

Changing the measuring mode affects the span (URV)!

This situation can result in product overflow.

- If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured!

	Description	
1	Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00301P.	P01-xMD7xxx-05-xx-xx-xx-010 Fig. 35: Flow measurement calibration 1 See Table, Step 7. 2 See Table, Step 8.
2	Carry out position adjustment if necessary. See Page → 155, Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT.	
3	Select the "Flow" measuring mode via the MEASURING MODE parameter. Local operation: Menu path: GROUP SELECTION → MEASURING MODE FieldCare: Menu path: MEASURING MODE → Primary Value Type	
4	Local operation: Select the BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	

	Description	
5	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
6	Select the "Volume operat. cond." option by means of the FLOW-MEAS. TYPE parameter.	
7	Select a flow unit via the UNIT FLOW parameter, here m ³ /h for example.	
8	Select the MAX. FLOW parameter.	
	Enter the maximum flow value of the primary device, here 6000 m ³ /h for example. See also the layout sheet of the primary device.	
9	Select the MAX PRESS. FLOW parameter.	
	Enter the maximum pressure, here 400 mbar (6 psi) for example. See also the layout sheet of the primary device.	
10	Result: The device is configured for flow measurement.	

1. You can also perform calibration by means of the QUICK SETUP menu. →  153 ff, Table 5: QUICK SETUP "Flow".
2. By means of the FLOW-MEAS. TYPE parameter, you can choose between the following flow types:
 - Volume operat. cond. (volume under operating conditions)
 - Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0 °C))
 - Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288. 15 K (15 °C/59 °F))
 - Mass
3. Depending on the flow type selected, you can choose between various units. You can also specify a customer-specific unit.
See parameter descriptions for PRESS. ENG. UNIT (060) (→  193), UNIT FLOW (391) (→  194), NORM FLOW UNIT (661) (→  195), STD. FLOW UNIT (660) (→  195) and MASS FLOW UNIT (571) (→  195).
4. In the lower measuring range, small flow quantities (creepages) can lead to large fluctuations in the measured value. You can activate low flow cut-off via the LOW FLOW CUT-OFF (442) parameter (→  199).

10.2 Totalizer

Example:

In this example, the volume flow should be totalized and displayed in the unit m^3E^3 .

Negative flows should be added to the flow rate.

- For a description of the parameters mentioned, see
 - → 206 ff, Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP
 - → 216 ff, Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"
- Totalizer 1 can be reset. Totalizer 2 cannot be reset.


	Description
1	Calibrate the device in accordance with Section 10.1.
2	Change the function group. Local operation: Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → TOTALIZER SETUP FieldCare: Menu path: OPERATING MENU → SETTINGS → TOTALIZER SETUP
3	Select a flow unit via the TOTALIZER 1 UNIT parameter, here m^3E^3 for example.
4	Use the NEG. FLOW TOT. 1 parameter to specify the totalizing mode for negative flows, here the "Positive" option for example.
5	Reset totalizer 1 to zero via the RESET TOTALIZER parameter.
6	Result: The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalized volume flow.

- You can also specify a customer-specific unit. → See parameter descriptions for TOTALIZER 1 UNIT (398), (662), (664), (666) (→ 206) and TOTALIZER 2 UNIT (399), (663), (665), (667) (→ 207).
- The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalized flow value of the first totalizer. The TOTALIZER 2 and TOTAL. 2 OVERFLOW parameters display the totalized flow value of the second totalizer.
→ 216 ff, PROCESS VALUES function group.
- You can use the MENU DESCRIPTOR (416) parameter (→ 208) to specify which measured value should be displayed on the local operation.

10.2.1 Resetting totalizer 1 automatically

By means the Analog Alarm Block


With the aid of the Analog Alarm and Discrete Output Block, totalizer 1 in the DP Flow Transducer Block can be reset automatically.



The DP Flow Transducer Block is connected to an Analog Input Block by means of the CHANNEL parameter (CHANNEL = 6). In the Analog Alarm Block, the HI_HI_LIM parameter is used to set a limit value at which the totalizer should be reset to zero. As soon as this limit value is overshoot, the Analog Alarm Block transmits an alarm value to the downstream Discrete Output Block. The latter changes its output from 0 to 1 and thus resets the totalizer in the DP Flow Transducer Block to 0. The output of the Analog Alarm Block changes back to 0.

By means the Analog Input Block

With the aid of Analog Input and Discrete Output Block, totalizer 1 in the DP Flow Transducer Block can be reset automatically.



The DP Flow Transducer Block is connected to an Analog Input Block by means of the CHANNEL parameter (CHANNEL = 6). In the Analog Input Block, the HI_HI_LIM parameter is used to set a limit value at which the totalizer should be reset to zero. As soon as this limit value is overshoot, the Analog Input Block transmits an alarm value to the downstream Discrete Output Block. The latter changes its output from 0 to 1 and thus resets the totalizer in the DP Flow Transducer Block to 0. The output of the Analog Input Block changes back to 0.

11 Parameter description (local operation and FieldCare)

- The following tables list all the parameters as per the menu structure. Each table corresponds to a function group in the menu tree. The overall menu structure is illustrated in Section 13.1.
- The menu structure for local operation and FieldCare are slightly different. The differences mainly affect the MEASURING MODE parameter and the LINEARIZATION function group.
- In FieldCare, additional parameters are displayed. These parameters are marked accordingly.
- The menu path is indicated in the header of each table. You can use this path to get to the parameters in question.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. the "LINEARIZATION" function group for the "Level" measuring mode. If certain requirements have to be met for a function group, these are listed in the first row of the table.
- Some parameters are only displayed if other parameters are appropriately configured. For example, the EMPTY CALIB. parameter is not displayed in the Quick Setup menu ("Level" measuring mode) unless the "Linear" option was selected for the LEVEL MODE parameter and the "Wet" option was selected for the CALIBRATION MODE parameter. There is a comment in the parameter description here stating: Note: prerequisite: LEVEL MODE = Linear and CALIBRATION MODE = Wet.
- Parameter names are written in upper case in the text.
- In the "Parameter name" column, the unique identification number (ID) of the parameter is indicated in brackets. This ID only appears on the local operation.




Fig. 36: 1st selection level in menu, LANGUAGE (→ 146, Table 1: GROUP SELECTION → LANGUAGE – Local operation) and MEASURING MODE (→ 147, Table 2: GROUP SELECTION →MEASURING MODE)

Table 1: GROUP SELECTION → LANGUAGE – Local operation	
Parameter name	Description
LANGUAGE (079) Display	The onsite display is available in English. The assignment of the English parameter names to the German parameter names is provided in → Chap. 2 "Parameter description of local operation and FieldCare". Needless to say, the device can also be operated in 6 languages (de, en, fr, es, jp, ch) via the DTM or EDD. ■ In FieldCare, the LANGUAGE parameter is arranged in the DISPLAY function group. ■ Select the menu language for FieldCare using the "Language button" in the configuration window. Select the menu language for the FieldCare frame via the "Extra" menu → "Options" → "Display" → "Language". Factory setting: English




Fig. 37: "Level" measuring mode, LEVEL SELECTION parameter

Table 2: GROUP SELECTION → MEASURING MODE	
Parameter name	Description
MEASURING MODE (389) Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! ■ When the measuring mode is changed, no conversion takes place. The device has to be recalibrated if the measuring mode is changed. ■ The MEASURING MODE parameter is displayed in FieldCare in the QUICK SETUP menus and in the BASIC SETUP function group (OPERATING MENU → SETTINGS → BASIC SETUP). Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level

Table 2: GROUP SELECTION → MEASURING MODE	
Parameter name	Description
LEVEL SELECTION (020) Selection	Select the level mode. Prerequisite: - MEASURING MODE = Level - In the "Level easy pressure" and "Level easy height" level modes, the values entered are not tested as extensively as in the "Level standard" level mode. The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE and EMPTY HEIGHT/FULL HEIGHT must be at least 1% apart for the "Level easy pressure" and "Level easy height" level modes. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly. → For an overview of the different level modes and types, → 117, Section 9.1 "Overview of level measurement". - The "Level easy pressure" and "Level easy height" level modes comprise fewer parameters than the "Level standard" mode and are used to quickly and easily configure a level application. - Customer-specific units of level, volume and mass or a linearization table may only be entered in the "Level standard" level mode. Options: Level easy pressure Specify two pressure-level value pairs for this level mode. The pressure measured value is converted directly to the unit which is selected via the OUTPUT UNIT (023) parameter (→ 161). The two calibration modes, "Wet" and "Dry", are available. - Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. - Dry calibration is a theoretical calibration. For this calibration, you specify two pressure-level value pairs via the EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE parameters. → Parameter descriptions → 162 ff. Level easy height For this level mode, specify a height unit, the density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height unit. The two calibration modes, "Wet" and "Dry", are available. - Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. - Dry calibration is a theoretical calibration. For this calibration, you specify two height-level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FULL HEIGHT parameters. → Parameter descriptions → 166 ff. Level standard Once you have selected this level mode, you can use the LEVEL MODE (718) parameter (→ 169) to choose between "Linear", "Pressure linearized" and "Height linearized". Factory setting: Level easy pressure → For LEVEL SELECTION = "Level easy pressure" → 159, Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure". → For LEVEL SELECTION = "Level easy height" → 163, Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height". → For LEVEL SELECTION = "Level standard" → 167, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard".




Fig. 38: Quick Setup menu for the "Pressure" measuring mode

Table 3: QUICK SETUP "Pressure"	
Parameter name	Description
This menu displays the most important parameters for the "Pressure" measuring mode. Prerequisite: ■ MEASURING MODE = Pressure Note: See also – → 157 ff, Table 7: OPERATING MENU → SETTINGS → BASIC SETUP "Pressure" – → 197, Table 15: OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure" – → 214 ff, Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure" – → 115 ff, Section 8 "Pressure measurement (via local operation and FieldCare)".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → See also → 115, Section 8 "Pressure measurement (via local operation and FieldCare)". Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level

Table 3: QUICK SETUP "Pressure"	
Parameter name	Description
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty, the MEASURED VALUE parameter does not display zero. Example: – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. Prerequisite: ■ This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensors or Deltapilot S. Options: ■ Abort ■ Confirm Factory setting: 0.0
POS. INPUT VALUE (563) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e.g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty, the MEASURED VALUE parameter does not display zero or the desired value. Example: – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (The following applies: $\text{MEASURED VALUE}_{\text{new}} = \text{POS. INPUT VALUE}$) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. The following applies: $\text{CALIB. OFFSET} = \text{MEASURED VALUE}_{\text{old}} - \text{POS. INPUT VALUE}$, here: $\text{CALIB. OFFSET} = 0.5 \text{ mbar (0.0075 psi)} - 2.0 \text{ mbar (0.03 psi)} = -1.5 \text{ mbar (-0.0225 psi)}$ Prerequisite: ■ This parameter is displayed for Cerabar S with absolute pressure sensors. Factory setting: 0.0
DAMPING VALUE (274) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification





Fig. 39: Quick Setup menu for the "Level" measuring mode

Table 4: QUICK SETUP "Level"	
Parameter name	Description
This menu displays the most important parameters for the "Level" measuring mode. Prerequisite: - MEASURING MODE = Level Note: See also → 167 ff, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard" to Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized" → 197 ff, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level" → 200 ff, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation and Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare → 215 ff, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level" → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → See also → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)". Options: - Pressure - Level - Deltabar S: Flow Factory setting: - Cerabar S and Deltabar S: Pressure - Deltapilot S: Level
LEVEL SELECTION (020) Selection	Select the level mode. →Parameter description, → 148. Factory setting: Level easy pressure

Table 4: QUICK SETUP "Level"	
Parameter name	Description
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. Example: – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. Prerequisite: ■ This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensors and Deltapilot S. Options: ■ Abort ■ Confirm Factory setting: 0.0
POS. INPUT VALUE (563) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e.g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero or the desired value. Example: – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). – (The following applies: $\text{MEASURED VALUE}_{\text{new}} = \text{POS. INPUT VALUE}$) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. – The following applies: $\text{CALIB. OFFSET} = \text{MEASURED VALUE}_{\text{old}} - \text{POS. INPUT VALUE}$, here: $\text{CALIB. OFFSET} = 0.5 \text{ mbar (0.0075 psi)} - 2.0 \text{ mbar (0.03 psi)} = -1.5 \text{ mbar (-0.0225 psi)}$ Prerequisite: ■ This parameter is displayed for Cerabar S with absolute pressure sensors. Factory setting: 0.0
EMPTY CALIB. (314)/ (010) Entry	Enter the level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. Prerequisite: ■ LEVEL SELECTION = Level easy pressure (→ 148), CALIBRATION MODE = Wet (→ 161) ■ LEVEL SELECTION = Level standard (→ 148), LEVEL MODE = Linear (→ 169), CALIBRATION MODE = Wet (→ 174) For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 0.0

Table 4: QUICK SETUP "Level"	
Parameter name	Description
FULL CALIB. (315)/(004) Entry	Enter the level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. Prerequisite: ■ LEVEL SELECTION = Level easy pressure (→ 148), CALIBRATION MODE = Wet (→ 161) ■ LEVEL SELECTION = Level standard (→ 148), LEVEL MODE= Linear (→ 169), CALIBRATION MODE = Wet (→ 174) For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-"-key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 100.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification



P01-xMx7xxxx-19-xx-xx-en-002

Fig. 40: Quick Setup menu, "Flow" measuring mode (differential pressure transmitter Deltabar S only)

Table 5: QUICK SETUP "Flow"	
Parameter name	Description
This menu displays the most important parameters for the "Flow" measuring mode. Prerequisite: ■ Deltabar S differential pressure transmitter ■ MEASURING MODE = Flow Note: See also - → 192 ff, Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow" - → 198 ff, Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow" - → 206 ff, Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP - → 142 ff, Section 10 "Flow measurement (via local operation and FieldCare)".	

Table 5: QUICK SETUP "Flow"	
Parameter name	Description
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → 142, Section 10 "Flow measurement (via local operation and FieldCare)". Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the MEASURED VALUE parameter does not display zero. Example: – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. Options ■ Abort ■ Confirm Factory setting: 0.0
MAX. FLOW (311) Entry	Enter maximum flow of primary device. See also the layout sheet of the primary device. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW. Factory setting: 1.0
MAX PRESS. FLOW (634) Entry	Enter maximum pressure of primary device. → See layout sheet of primary device. This value is assigned to the maximum flow value (→ see MAX. FLOW). Factory setting: High sensor limit (→ see PRESS. SENS HILIM, → 212)
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 41: POSITION ADJUSTMENT function group

Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT	
Parameter name	Description
Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty, the measured value does not display zero. Deltabar S, Cerabar S and Deltapilot S offer three different ways of performing a position adjustment. Recommendation: ■ The pressure difference between zero (set point) and the measured pressure need not be known. – POS. ZERO ADJUST: Deltabar S or Cerabar S with gauge pressure sensors or Deltapilot S. – POS. INPUT VALUE: Cerabar S with absolute pressure sensors. ■ The pressure difference between zero (set point) and the measured pressure is known. – CALIB. OFFSET: Deltabar S, Cerabar S with gauge pressure sensors, Cerabar S with absolute pressure sensors or Deltapilot S.	
POS. ZERO ADJUST (685) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Example: – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. Options ■ Abort ■ Confirm Factory setting: 0.0

Table 6: OPERATING MENU → SETTINGS → POSITION ADJUSTMENT	
Parameter name	Description
POS. INPUT VALUE (563) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e.g. from a reference device). Example: – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (The following applies: $\text{MEASURED VALUE}_{\text{new}} = \text{POS. INPUT VALUE}$) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. The following applies: $\text{CALIB. OFFSET} = \text{MEASURED VALUE}_{\text{old}} - \text{POS. INPUT VALUE}$, here: $\text{CALIB. OFFSET} = 0.5 \text{ mbar (0.0075 psi)} - 2.0 \text{ mbar (0.03 psi)} = -1.5 \text{ mbar (-0.0225 psi)}$ Factory setting: 0.0
CALIB. OFFSET (319) Entry	Position adjustment – the pressure difference between zero (set point) and the measured pressure is known. (A reference pressure is not present at the device.) Example: – MEASURED VALUE = 2.2 mbar (0.033 psi) – Via the CALIB. OFFSET parameter, enter the value by which the MEASURED VALUE should be corrected. To correct the MEASURED VALUE to 0.0 mbar, you must enter the value 2.2 here. (The following applies: $\text{MEASURED VALUE}_{\text{new}} = \text{MEASURED VALUE}_{\text{old}} - \text{CALIB. OFFSET}$) – MEASURED VALUE (after entry for calib. offset) = 0.0 mbar Factory setting: 0.0




Fig. 42: BASIC SETUP function group for the "Pressure" measuring mode

Table 7: OPERATING MENU → SETTINGS → BASIC SETUP "Pressure"	
Parameter name	Description
Prerequisite: - MEASURING MODE = Pressure Note: See also → 149, Table 3: QUICK SETUP "Pressure" → 197, Table 15: OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure" → 214 ff, Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure" → 115 ff, Section 8 "Pressure measurement (via local operation and FieldCare)".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → 115, Section 8 "Pressure measurement (via local operation and FieldCare)". Options: - Pressure - Level - Deltabar S: Flow Factory setting: Pressure
PRESS. ENG. UNIT (060) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options - mbar, bar - mmH₂O, mH₂O, inH₂O, ftH₂O - Pa, hPa, kPa, MPa - psi - mmHg, inHg - Torr - g/cm², kg/cm² - lb/ft² - atm - gf/cm², kgf/cm² - User unit, → see also the following parameter descriptions for CUSTOMER UNIT P and CUST. UNIT. FACT. P. Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications

Table 7: OPERATING MENU → SETTINGS → BASIC SETUP "Pressure"	
Parameter name	Description
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. P Prerequisite: ■ PRESS. ENG. UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. P (317) Entry	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P. Prerequisite: ■ PRESS. ENG. UNIT = User unit Example: – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa i 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU Factory setting: 1.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 43: BASIC SETUP function group for the "Level" measuring mode and "Level easy pressure" level selection

Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"	
Parameter name	Description
The following parameters are displayed if you have selected the "Level easy pressure" option for the LEVEL SELECTION parameter. Specify two pressure-level value pairs for this level mode. The two calibration modes, "Wet" and "Dry", are available.	
Prerequisite:	
■ MEASURING MODE = Level (→ 147).	
■ LEVEL SELECTION = Level easy pressure (→ 148.)	

Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"	
Parameter name	Description
PRESS. ENG. UNIT (060) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT P and CUST. UNIT. FACT. P. Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. P Prerequisite: ■ PRESS. ENG. UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m²" was selected, "crate/m²" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: - - - - -
CUST. UNIT FACT. P (317) Entry	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P. Prerequisite: ■ PRESS. ENG. UNIT = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE = 10000 Pa i 1 PU - Entry CUSTOMER UNIT P: PU - Entry CUST. UNIT FACT. P: 0.0001 - Result: MEASURED VALUE = 1 PU Factory setting: 1.0

Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"	
Parameter name	Description
OUTPUT UNIT (023) Selection	Select the unit for the measured value display and the MEASURED VALUE parameter (→ 215). The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted. Example: - Current measured value: 0.3 ft - New output unit: m - New measured value: 0.3 m (9.8 ft) Options % - mm, cm, dm, m - ft, inch - cm³, dm³, m³, m³ E³ - l, hl - ft³, ft³ E³ - gal, bbl, lgal - g, kg, t - lb, ton, oz Factory setting: %
CALIBRATION MODE (008) Selection	Select the calibration mode. Options: - Wet Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. (→ See also this table, parameter descriptions for EMPTY CALIB. and FULL CALIB.) - Dry Dry calibration is a theoretical calibration. For this calibration, you specify two pressure-level value pairs via the following parameters: EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. Factory setting: Wet
EMPTY CALIB. (010) Entry	Enter the level, volume, mass or percentage value for the lower calibration point (empty container). The container is either empty or part full. By entering a value for this parameter, you assign a level, volume, mass or percentage value to the pressure present at the device. The unit is selected via the OUTPUT UNIT parameter (→ 161). Prerequisite: CALIBRATION MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-"-key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 0.0

Table 8: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy pressure"	
Parameter name	Description
FULL CALIB. (004) Entry	Enter the height, volume or mass value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you assign a height, volume or mass value to the pressure present at the device. The unit is selected via the OUTPUT UNIT parameter (→ 161). Prerequisite: ■ CALIBRATION MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 100.0
EMPTY CALIB. (010) Entry	Enter the level, volume, mass or percentage value for the lower calibration point (empty container). The values entered for the EMPTY CALIB. and EMPTY PRESSURE parameters form the pressure-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (→ 161). Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0
EMPTY PRESSURE (011) Entry	Enter the pressure value for the lower calibration point (container empty). → See also EMPTY CALIB. Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0
FULL CALIB. (004) Entry	Enter the height, volume, mass or percentage value for the upper calibration point (container full). The values entered for the FULL CALIB. and FULL PRESSURE parameters form the pressure-level value pair for the upper calibration point. The unit is selected via the OUTPUT UNIT parameter (→ 161). Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 100.0
FULL PRESSURE (005) Entry	Enter the pressure value for the upper calibration point (container full). → See also FULL CALIB. Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 100.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 44: BASIC SETUP function group for "Level" measuring mode and "Level easy height" level selection

Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height"

Parameter name	Description
The following parameters are displayed if you have selected the "Level easy height" option for the LEVEL SELECTION parameter. For this level mode, specify a height unit, the density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height unit. The two calibration modes, "Wet" and "Dry", are available. Prerequisite: - MEASURING MODE = Level (→ 147). - LEVEL SELECTION = Level easy height (→ 148.)	

Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height"	
Parameter name	Description
PRESS. ENG. UNIT (060) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT P and CUST. UNIT. FACT. P. Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. P Prerequisite: ■ PRESS. ENG. UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m²" was selected, "crate/m²" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: - - - - -
CUST. UNIT FACT. P (317) Entry	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P. Prerequisite: ■ PRESS. ENG. UNIT = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE = 10000 Pa i 1 PU - Entry CUSTOMER UNIT P: PU - Entry CUST. UNIT FACT. P: 0.0001 - Result: MEASURED VALUE = 1 PU Factory setting: 1.0

Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height"	
Parameter name	Description
OUTPUT UNIT (023) Selection	Select the unit for the measured value display and the MEASURED VALUE parameter (→ 215). The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted. Example: - Current measured value: 0.3 ft - New output unit: m - New measured value: 0.3 m (9.8 ft) Options % - mm, cm, dm, m - ft, inch - cm³, dm³, m³, m³ E³ - l, hl - ft³, ft³ E³ - gal, bbl, lgal - g, kg, t - lb, ton, oz Factory setting: %
HEIGHT UNIT (003) Selection	Select the height unit. The measured pressure is converted to the chosen height unit using the DENSITY UNIT and ADJUST DENSITY parameters. Options: - mm - cm - dm - m - inch - ft Factory setting: m
CALIBRATION MODE (008) Selection	Select the calibration mode. Options: - Wet Wet calibration takes place by filling and emptying the container. The measured pressure is converted to the chosen height unit using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. - Dry Dry calibration is a theoretical calibration. For this calibration, you specify two height-level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FULL HEIGHT parameters. Factory setting: Dry
DENSITY UNIT (001) Selection	Select the density unit. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters. Options: - g/cm³ - kg/dm³ - kg/m³ - US lb/in³ - US lb/ft³ Factory setting: kg/dm³
ADJUST DENSITY (007) Entry	Enter the density of the fluid. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters. Factory setting: 1.0

Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height"	
Parameter name	Description
EMPTY CALIB. (010) Entry	Enter the level, volume, mass or percentage value for the lower calibration point (empty container). The container is either empty or part full. The measured pressure is converted to a height value using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters and displayed. By means of the parameter EMPTY CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (→ 165). Prerequisite: ■ CALIBRATION MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 0.0
FULL CALIB. (004) Entry	Enter the level, volume, mass or percentage value for the upper calibration point (full container). The container is either completely or almost full. The measured pressure is converted to a height value using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters and displayed. By means of the parameter FULL CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (→ 165). Prerequisite: ■ CALIBRATION MODE = Wet For this parameter, the local operation shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged. Factory setting: 100.0
EMPTY CALIB. (010) Entry	Enter the level, volume, mass or percentage value for the lower calibration point (empty container). The values entered for the EMPTY CALIB. and EMPTY HEIGHT parameters form the height-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (→ 165). Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0
EMPTY HEIGHT (009) Entry	Enter the height value for the lower calibration point (container empty). The unit is selected via the HEIGHT UNIT parameter (→ 165). → See also EMPTY CALIB. Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0
FULL CALIB. (004) Entry	Enter the level, volume, mass or percentage value for the upper calibration point (full container). The values entered for the FULL CALIB. and FULL HEIGHT parameters form the height-level value pair for the upper calibration point. The unit is selected via the OUTPUT UNIT parameter (→ 165). Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 100.0

Table 9: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level easy height"	
Parameter name	Description
FULL HEIGHT (006) Entry	Enter the value for the upper calibration point (container full). The unit is selected via the HEIGHT UNIT parameter (→ 165). → See also FULL CALIB. Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: Upper range limit (URL) is converted to a unit of height
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 45: BASIC SETUP function group for the "Level" measuring mode, depending on the setting for the LEVEL MODE parameter, → 170, → Fig. 46 BASIC SETUP function group for the "Level" measuring mode and "Linear" level mode → 179, → Fig. 48 BASIC SETUP function group for the "Level" measuring mode and "Pressure linearized" level mode → 183, → Fig. 49 BASIC SETUP function group for the "Level" measuring mode and "Height linearized" level mode.

Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Level Note: See also – → 171 ff, Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear" to Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized" – contd – → 197 ff, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level" – → 200 ff, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation – → 215 ff, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level" – → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	

Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"	
Parameter name	Description
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → 117, Section 9 "Level measurement (via local operation and FieldCare)". Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: Pressure (Deltabar S, Cerabar S) Factory setting: Deltabar S, Cerabar S = Pressure Deltapilot S = Level easy pressure
PRESS. ENG. UNIT (060) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT P and CUST. UNIT. FACT. P. Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. P Prerequisite: ■ PRESS. ENG. UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m²" was selected, "crate/m²" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard"	
Parameter name	Description
CUST. UNIT FACT. P (317) Entry	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P. Prerequisite: ■ PRESS. ENG. UNIT = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE = 10000 Pa i 1 PU - Entry CUSTOMER UNIT P: PU - Entry CUST. UNIT FACT. P: 0.0001 - Result: MEASURED VALUE = 1 PU Factory setting: 1.0
LEVEL MODE (718) Selection	Select level mode. Options: ■ Linear: The measured variable (level, volume, mass or %) is in direct proportion to the measured pressure. → 171 ff, Table 11. ■ Pressure linearized: The measured variable (volume, mass or %) is not in direct proportion to the measured pressure such as in the case of containers with a conical outlet. For the calibration, enter a linearization table with at least 2 and not more than 32 points. → 179 ff, Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized". ■ Height linearized: Select this level mode if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume. The following combinations are possible: - Height + volume - Height + mass - Height + % - %-height + volume - %-height + mass - %-height + % Perform two calibrations for this level mode. First for the measured variable height or %-height like for the "Linear" option and then for the measured variable volume, mass or % like for the "Pressure linearized" option. → 184 ff, Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized". Factory setting: Linear
→ For LEVEL MODE = Linear, → 171 ff, Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear". → For LEVEL MODE = Pressure linearized, → 179 ff, Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized". → For LEVEL MODE = Height linearized, → 184 ff, Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized".	




Fig. 46: BASIC SETUP function group for the "Level" measuring mode and "Linear" level mode

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
The following parameters are displayed if you selected the "Linear" option for the LEVEL MODE parameter. For this level mode, the measured variable (level, volume, mass or %) is in direct proportion to the measured pressure. Prerequisite: ■ MEASURING MODE = Level ■ LEVEL MODE = Linear (→ 169) Note: See also → 167 ff, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard" – general → 197 ff, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level" → 215 ff, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level" → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	
LIN. MEASURAND (804) Selection	Select the measured variable. Options: ■ Level ■ Volume ■ Mass ■ % (level) Factory setting: % (level)
HEIGHT UNIT (708) Selection	Select the level unit. Prerequisite: ■ LIN. MEASURAND = Level Options: ■ mm ■ cm ■ dm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT H and CUST. UNIT. FACT. H. Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. H. Prerequisite: ■ LIN. MEASURAND = Level, HEIGHT UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. H (705) Entry	Enter the conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H. Prerequisite: ■ LIN. MEASURAND = Level, HEIGHT UNIT = User unit Example: – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m i 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU Factory setting: 1.0
UNIT VOLUME (313) Selection	Select the volume unit. Prerequisite: ■ LIN. MEASURAND = Volume Options: ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT V and CUST. UNIT. FACT. V Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m³
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. V Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. V (607) Entry	Enter the conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V. Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit Example: - You want the measured value to be displayed in "buckets". - MEASURED VALUE = 0.01 m³ i 1 bucket - Entry CUSTOMER UNIT V: bucket - Entry CUST. UNIT FACT. V: 100 - Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
MASS UNIT (709) Selection	Select the mass unit. Prerequisite: ■ LIN. MEASURAND = Mass Options: ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT M and CUST. UNIT. FACT. M Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: kg
CUSTOMER UNIT M (704) Entry	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. M. Prerequisite: ■ LIN. MEASURAND = Mass, MASS UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m²" was selected, "crate/m²" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. M (703) Entry	Enter the conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M. Prerequisite: ■ LIN. MEASURAND = Mass, MASS UNIT = User unit Example: – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 10 kg i 1 bucket – Entry CUSTOMER UNIT M: bucket – Entry CUST. UNIT FACT. M: 0.1 – Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
CALIBRATION MODE (392) Selection	Select the calibration mode. Options: ■ Wet Wet calibration takes place by filling and emptying the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. ■ Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. – For the "Level" measured variable, the density of the fluid (→ 175, ADJUST DENSITY) must be entered. – For the "Volume" measured variable, the density of the fluid and the tank volume and tank height must be entered (→ 175, ADJUST DENSITY, TANK VOLUME and TANK HEIGHT). – For the "Mass" measured variable, the tank volume and the tank height must be entered (→ 176, TANK VOLUME and TANK HEIGHT). The density must also be entered in the case of a zero point shift (level offset) (→ 175, ADJUST DENSITY). – For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ 175 and → 178, ADJUST DENSITY and 100% POINT). If the measurement should not start at the mounting location of the device, a level offset must be entered (→ 178, ZERO POSITION). Factory setting: Wet
EMPTY CALIB. (314) Entry	Enter the level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also EMPTY PRESSURE. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: 0.0
EMPTY PRESSURE (710) Display	Displays the pressure value for the lower calibration point (container empty). → See also EMPTY CALIB. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: 0.0

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
FULL CALIB. (315) Entry	Enter the level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also FULL PRESSURE. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: 100.0
FULL PRESSURE (711) Display	Displays the pressure value for the upper calibration point (container full). → See also FULL CALIB. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: High sensor limit (→ see PRESS. SENS HILIM, → 212)
ADJUSTED DENSITY (810) Display	Displays the density calculated from the upper and lower level point. Prerequisite: ■ CALIBRATION MODE = Wet, LIN. MEASURAND = Level
DENSITY UNIT (812) Selection	Select the density unit. Prerequisite: ■ LIN. MEASURAND = Level, CALIBRATION MODE = Dry ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry Options: ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ Factory setting: kg/dm³
ADJUST DENSITY (316) Entry	Enter the density of the fluid. Prerequisite: ■ LIN. MEASURAND = Level, CALIBRATION MODE = Dry ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry Factory setting: 1000.0

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
UNIT VOLUME (313) Selection	Select the volume unit. Prerequisite: ■ LIN. MEASURAND = Volume Options: ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT V and CUST. UNIT. FACT. V Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m³
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. V Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. V (607) Entry	Enter the conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V. Prerequisite: ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit Example: – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ i 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
TANK VOLUME (858) Entry	Enter the tank volume. Prerequisite: ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry Factory setting: 1.0 m³

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
HEIGHT UNIT (708) Selection	Select the level unit. Prerequisite: ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry Options: ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT H and CUST. UNIT. FACT. H. Factory setting: m
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. H. Prerequisite: ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. H (705) Entry	Enter the conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H. Prerequisite: ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE = 0.5 m i 1 PU - Entry CUSTOMER UNIT H: PU - Entry CUST. UNIT FACT. H: 2 - Result: MEASURED VALUE = 1 PU Factory setting: 1.0
TANK HEIGHT (859) Entry	Enter the tank height. Prerequisite: ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry Factory setting: 1.0 m

Table 11: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
100% POINT (813) Entry	Enter the level value for the 100% point. Prerequisite: ■ LIN. MEASURAND = % (level), CALIBRATION MODE = Dry Example: – The 100 %-point should correspond to 4 m. – Select the "m" unit via the HEIGHT UNIT parameter. – Enter the value "4" for this parameter (100% POINT). Factory setting: 1.0
ZERO POSITION (814) Entry	Enter the value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset). Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0 P01-PMP75xxx-19-xx-xx-xx-001 <i>Fig. 47: Zero point shift</i> 1 Device is mounted above the level lower-range value: a positive value has to be entered for ZERO POSITION. 2 Device is mounted below the level lower-range value: a negative value has to be entered for ZERO POSITION.
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 48: BASIC SETUP function group for the "Level" measuring mode and "Pressure linearized" level mode, continue calibration with LINEARIZATION function group → 200 ff.

Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized"

Parameter name	Description
The following parameters are displayed if you selected the "Pressure linearized" option for the LEVEL MODE parameter. For this level mode, the measured variable (volume, mass or %) is not in direct proportion to the measured pressure. For the calibration, enter a linearization table with at least 2 and not more than 32 points. Prerequisite: - MEASURING MODE = Level - LEVEL MODE = Pressure linearized (→ 169). Note: See also → 167 ff, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard" – general → 197 ff, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level" → 200 ff, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation and Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare → 215 ff, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level" → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	

Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized"	
Parameter name	Description
LINd. MEASURAND. (805) Selection	Select the measured variable. Options: ■ Pressure and volume ■ Pressure and mass ■ Pressure and % Factory setting: Pressure and %
UNIT VOLUME (313) Selection	Select the volume unit. Prerequisite: ■ LINd. MEASURAND. = Pressure and volume Options: ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT V and CUST. UNIT. FACT. V Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m³
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. V. Prerequisite: ■ LINd. MEASURAND. = Pressure and volume, UNIT VOLUME = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized"	
Parameter name	Description
CUST. UNIT FACT. V (607) Entry	Enter the conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V. Prerequisite: ■ LInD. MEASURAND. = Pressure and volume, UNIT VOLUME = User unit Example: – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ i 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
MASS UNIT (709) Selection	Select the mass unit. Prerequisite: ■ LInD. MEASURAND. = Pressure and mass Options: ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT M and CUST. UNIT. FACT. M Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: kg
CUSTOMER UNIT M (704) Entry	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. M. Prerequisite: ■ LInD. MEASURAND = Pressure and mass, MASS UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 12: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure linearized"	
Parameter name	Description
CUST. UNIT FACT. M (703) Entry	Enter the conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M. Prerequisite: ■ LIND. MEASURAND = Pressure and mass, MASS UNIT = User unit Example: – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 10 kg i 1 bucket – Entry CUSTOMER UNIT M: bucket – Entry CUST. UNIT FACT. M: 0.1 – Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
HYDR. PRESS MIN. (773) Entry	Enter the minimum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum hydrostatic pressure to be expected, the more accurate the measurement result. Factory setting: 0.0
HYDR. PRESS MAX. (774) Entry	Enter the maximum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum hydrostatic pressure to be expected, the more accurate the measurement result. Factory setting: High sensor limit (→ see PRESS. SENS HILIM, → 212)
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 49: BASIC SETUP function group for the "Level" measuring mode and "Height linearized" level mode, continue calibration with LINEARIZATION function group → 200 ff.

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
	The following parameters are displayed if you selected the "Height linearized" option for the LEVEL MODE parameter. Select this level mode if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume. The following combinations are possible: ■ Height + volume ■ Height + mass ■ Height + % ■ %-height + volume ■ %-height + mass ■ %-height + % The 1st measured variable (%-height or height) must be in direct proportion to the measured pressure. The 2nd measured variable (volume, mass or %) must not be in direct proportion. A linearization table has to be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table. Prerequisite: ■ MEASURING MODE = Level ■ LEVEL MODE = Height linearized (→ 169). Note: See also – → 167 ff, Table 10: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level standard" – general – → 197 ff, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level" – → 200 ff, Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation and Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare – → 215 ff, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level" – → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".
COMB. MEASURAND (806) Selection	Select the measured variable. Options: ■ Height and volume ■ Height and mass ■ Height and % ■ %-height and volume ■ %-height and mass ■ %-height and % Factory setting: %-height and %
HEIGHT UNIT (708) Selection	Select the level unit for the 1st measured variable. Prerequisite: ■ COMB. MEASURAND = Height and volume, height and mass or height and % Options: ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT H and CUST. UNIT. FACT. H. Factory setting: m

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. H. Prerequisite: ■ COMB. MEASURAND = Height and volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and mass, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. H (705) Entry	Enter the conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H. Prerequisite: ■ COMB. MEASURAND = Height and volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and mass, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit Example: - You want the measured value to be displayed in "PU" (PU: packing unit). - MEASURED VALUE = 0.5 m i 1 PU - Entry CUSTOMER UNIT H: PU - Entry CUST. UNIT FACT. H: 2 - Result: MEASURED VALUE = 1 PU Factory setting: 1.0
UNIT VOLUME (313) Selection	Select the volume unit for the 2nd measured value. Prerequisite: ■ COMB. MEASURAND = Height and volume or %-height and volume Options: ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT V and CUST. UNIT. FACT. V Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m³


Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
CUSTOMER UNIT V (608) Entry	Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. V. Prerequisite: ■ COMB. MEASURAND = Height and volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and volume, HEIGHT UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. V (607) Entry	Enter the conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V. Prerequisite: ■ COMB. MEASURAND = Height and volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and volume, HEIGHT UNIT = User unit Example: – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ i 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
MASS UNIT (709) Selection	Select the mass unit for the 2nd measured value. Prerequisite: ■ COMB. MEASURAND = Height and mass or %-height and mass Options: ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT M and CUST. UNIT. FACT. M Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: kg

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
CUSTOMER UNIT M (704) Entry	Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. M. Prerequisite: ■ COMB. MEASURAND = Height and mass, MASS UNIT = User unit ■ COMB. MEASURAND = %-height and mass, MASS UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. M (703) Entry	Enter the conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M. Prerequisite: ■ COMB. MEASURAND = Height and mass, MASS UNIT = User unit ■ COMB. MEASURAND = %-height and mass, MASS UNIT = User unit Example: - You want the measured value to be displayed in "buckets". - MEASURED VALUE = 10 kg i 1 bucket - Entry CUSTOMER UNIT M: bucket - Entry CUST. UNIT FACT. M: 0.1 - Result: MEASURED VALUE = 1 bucket Factory setting: 1.0
LEVEL MIN (755) Entry	Enter the minimum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum level to be expected, the more accurate the measurement result. Factory setting: 0.0
LEVEL MAX (712) Entry	Enter the maximum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum level to be expected, the more accurate the measurement result. Factory setting: 100.0

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
CALIBRATION MODE (392) Selection	Select the calibration mode for the calibration of the 1st measured variable. Options: ■ Wet Wet calibration takes place by filling the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. ■ Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. – For the "Level" measured variable, the density of the fluid (→ 189, ADJUST DENSITY) must be entered. – For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ 189, ADJUST DENSITY and 100% POINT). If the measurement should not start at the mounting location of the device, a level offset must be entered (→ 191, ZERO POSITION). If you change to dry calibration after a wet calibration, the density must be entered correctly via the ADJUST DENSITY and PROCESS DENSITY parameters. → 198. Factory setting: Wet
EMPTY CALIB. (314) Entry	Enter the level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also EMPTY PRESSURE. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: 0.0
EMPTY PRESSURE (710) Display	Displays the pressure value for the lower calibration point (container empty). → See also EMPTY CALIB. Prerequisite: ■ CALIBRATION MODE = Wet
FULL CALIB. (315) Entry	Enter the level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also FULL PRESSURE. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: 100.0
FULL PRESSURE (711) Display	Displays the pressure value for the upper calibration point (container full). → See also FULL CALIB. Prerequisite: ■ CALIBRATION MODE = Wet Factory setting: High sensor limit (→ see PRESS. SENS HILIM, → 212)
ADJUSTED DENSITY (810) Display	Displays the density calculated from the upper and lower level point. Prerequisite: ■ COMB. MEASURAND = Height and volume, CALIBRATION MODE = Wet ■ COMB. MEASURAND = Height and mass, CALIBRATION MODE = Wet ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Wet

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
DENSITY UNIT (812) Selection	Select the density unit. Prerequisite: ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and mass, CALIBRATION MODE = Dry Options: ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ Factory setting: kg/dm³
ADJUST DENSITY (316) Entry	Enter the density of the fluid. Prerequisite: ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and mass, CALIBRATION MODE = Dry Factory setting: 1.0
HEIGHT UNIT (708) Selection	Select the level unit. Prerequisite: ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry Options: ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT H and CUST. UNIT. FACT. H. Factory setting: m

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
CUSTOMER UNIT H (706) Entry	Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. H. Prerequisite: ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----
CUST. UNIT FACT. H (705) Entry	Enter the conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H. Prerequisite: ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit Example: – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m i 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU Factory setting: 1.0
100% POINT (813) Entry	Enter the level value for the 100% point. Prerequisite: ■ COMB. MEASURAND = %-height and volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-height and %, CALIBRATION MODE = Dry Example: – The 100 %-point should correspond to 4 m (13 ft). – Select the "m" unit via the HEIGHT UNIT parameter. – Enter the value "4" for this parameter (100% POINT). Factory setting: 1.0

Table 13: OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height linearized"	
Parameter name	Description
ZERO POSITION (814) Entry	Enter the value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset). Prerequisite: ■ CALIBRATION MODE = Dry  P01-PMP75xxx-19-xx-xx-xx-001 Fig. 50: Zero point shift 1 Device is mounted above the level lower-range value: a positive value has to be entered for ZERO POSITION. 2 Device is mounted below the level lower-range value: a negative value has to be entered for ZERO POSITION. Factory setting: 0.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification




Fig. 51: BASIC SETUP function group for the "Flow" measuring mode

Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
Prerequisite: MEASURING MODE = Flow	
Note: See also → 153, Table 5: QUICK SETUP "Flow" → 198, Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow" → 206, Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP → 216, Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow" → 142 ff, Section 10 "Flow measurement (via local operation and FieldCare)".	

Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. ⚠ WARNING Changing the measuring mode affects the span (URV)! This situation can result in product overflow. ► If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured! When the measuring mode is changed, no conversion takes place. The digital output value of the Analog Input Block OUT no longer displays the same value as the local operation or the MEASURED VALUE. The device has to be recalibrated if the measuring mode is changed. → 142, Section 10 "Flow measurement (via local operation and FieldCare)". Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: Pressure
PRESS. ENG. UNIT (060) Selection	Select the pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: ■ mbar, bar ■ mmH2O, mH2O, inH2O, ftH2O ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT P and CUST. UNIT. FACT. P Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications
CUSTOMER UNIT P (075) Entry	Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. P Prerequisite: ■ PRESS. ENG. UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----

Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
CUST. UNIT FACT. P (317) Entry	Enter the conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P. Prerequisite: ■ PRESS. ENG. UNIT = User unit Example: – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa i 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU Factory setting: 1.0
FLOW-MEAS. TYPE (640) Selection	Select the flow type. Options: ■ Volume operat. cond. (volume under operating conditions) ■ Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0 °C)) ■ Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15 °C/59 °F)) ■ Mass Factory setting: Volume operat. cond.
UNIT FLOW (391) Selection	Select volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible. Prerequisite: ■ FLOW-MEAS. TYPE = Volume operat. cond. Options: ■ m³/s, m³/min, m³/h, m³/day ■ l/s, l/min, l/h ■ hl/s, hl/min, hl/day ■ ft³/s, ft³/min, ft³/h, ft³/day ■ ACFS, ACFM, ACFH, ACFD ■ ozf/s, ozf/min ■ US Gal/s, US Gal/min, US Gal/h, US Gal/day ■ Imp. Gal/s, Imp. Gal/min, Imp. Gal/h ■ bbl/s, bbl/min, bbl/h, bbl/day ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT. FACT. F Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: m³/s

Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
NORM FLOW UNIT (661) Selection	Select the norm volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible. Prerequisite: ■ FLOW-MEAS. TYPE = Gas norm conditions Options: ■ Nm³/s, Nm³/min, Nm³/h, Nm³/day ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT. FACT. F Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Nm³/s
STD. FLOW UNIT (660) Selection	Select the standard volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible. Prerequisite: ■ FLOW-MEAS. TYPE = Gas std. conditions Options: ■ Sm³/s, Sm³/min, Sm³/h, Sm³/day ■ SCFS, SCFM, SCFH, SCFD ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT. FACT. F Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: Sm³/s
MASS FLOW UNIT (571) Selection	Select the mass flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible. Prerequisite: ■ FLOW-MEAS. TYPE = Mass p. cond. Options: ■ g/s, kg/s, kg/min, kg/min, kg/h ■ t/s, t/min, t/h, t/day ■ oz/s, oz/min ■ lb/s, lb/min, lb/h ■ ton/s, ton/min, ton/h, ton/day ■ User unit, → see also the following parameter descriptions for CUSTOMER UNIT F and CUST. UNIT. FACT. F Following a change in the unit, the digital output value of the Analog Input value OUT and the local operation or the MEASURED VALUE no longer display the same value. → See also parameter descriptions for XD SCALE, OUT SCALE and OUT value. Factory setting: kg/s

Table 14: OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
CUSTOMER UNIT F (610) Entry	Enter text (unit) for customer-specific flow unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT. FACT. F. Prerequisite: ■ UNIT FLOW = User unit ■ NORM FLOW UNIT = User unit ■ STD. FLOW UNIT = User unit ■ MASS FLOW UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: - - - - -
CUST. UNIT FACT. F (609) Entry	Enter the conversion factor for a customer-specific flow unit. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³/s for the "Volume operat. cond." flow mode. → See also CUSTOMER UNIT F. Prerequisite: ■ UNIT FLOW = User unit ■ NORM FLOW UNIT = User unit ■ STD. FLOW UNIT = User unit ■ MASS FLOW UNIT = User unit Example: - You want the measured value to be displayed in "bucket/h". - MEASURED VALUE = 0.01 m³/s i 3600 bucket/h - Entry CUSTOMER UNIT F: bucket/h - Entry CUST. UNIT FACT. F: 360000 - Result: MEASURED VALUE = 3600 bucket/h Factory setting: 1.0
MAX. FLOW (311) Entry	Enter maximum flow of primary device. → See also the layout sheet of the primary device. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW. Factory setting: 1.0
MAX PRESS. FLOW (634) Entry	Enter maximum pressure of primary device. → See layout sheet of primary device. This value is assigned to the maximum flow value (→ see MAX. FLOW). Factory setting: High sensor limit (→ see PRESS. SENS HILIM, → 212)
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the local operation, measured value and OUT value of the Analog Input Block react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specification






Fig. 52: EXTENDED SETUP function group
for the "Pressure" measuring mode → 197, Table 15: OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure"
for the "Level" measuring mode → 197, Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"
for the "Flow" measuring mode → 198, Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"

Table 15: OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure"	
Parameter name	Description
Prerequisite: - MEASURING MODE = Pressure Note: - See also → 115 ff, Section 8 "Pressure measurement (via local operation and FieldCare)".	
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured values. → See also PCB TEMPERATURE (→ 211) and SENSOR TEMP. (→ 215). Options: °C °F - K - R Factory setting: °C

Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"	
Parameter name	Description
Prerequisite: - MEASURING MODE = Level Note: - See also → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured values. → See also PCB TEMPERATURE (→ 211) and SENSOR TEMP. (→ 215). Options: °C °F - K - R Factory setting: °C

Table 16: OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"	
Parameter name	Description
DENSITY UNIT (001)/(812) Selection	Select the density unit. Options: ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ Factory setting: kg/dm³
ADJUST DENSITY (007)/(316) Entry	Enter the density of the fluid. LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and COMB. MEASURAND: If you change to dry calibration after a wet calibration using the CALIBRATION MODE parameter (→ 174 or → 188), the density for the ADJUST DENSITY and PROCESS DENSITY parameters must be entered correctly before changing the calibration mode. If the pressure falls with increasing levels (LIN. MEASURED: volume), such as in the case of a residual volume measurement, a negative value must be entered for this parameter. Factory setting: 1.0
PROCESS DENSITY (025)/(811) Entry	Enter a new density value for density correction. The calibration was carried out with the medium water, for example. Now the container is to be used for another fluid with another density. The calibration is corrected appropriately by entering the new density value in the PROCESS DENSITY parameter. LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and COMB. MEASURAND: If you change to dry calibration after a wet calibration using the CALIBRATION MODE parameter (→ 174 or → 188), the density for the ADJUST DENSITY and PROCESS DENSITY parameters must be entered correctly before changing the calibration mode. If the pressure falls with increasing levels (LIN. MEASURED: volume), such as in the case of a residual volume measurement, a negative value must be entered for this parameter. Factory setting: 1.0

Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Flow Note: ► See also → 142 ff, Section 10 "Flow measurement (via local operation and FieldCare)".	

Table 17: OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"	
Parameter name	Description
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured value. → See also PCB TEMPERATURE (→ 211) and SENSOR TEMP. (→ 216). Options: ■ °C ■ °F ■ K ■ R Factory setting: °C
LOW FLOW CUT-OFF (442) Selection	Switch the "low flow cut-off" function on and off. In the lower measuring range, small flow quantities (creepages) can lead to large fluctuations in the measured value. Switching on this function stops these flow quantities from being recorded. → See also SET. L. FL. CUT-OFF. Options: ■ Off ■ On Factory setting: Off
SET. L. FL. CUT-OFF (332) Entry	Enter the switch-off point of low flow cut-off. The hysteresis between the switch-on point and the switch-off point is always 1 % of the end flow value. → See also LOW FLOW CUT-OFF. Prerequisite: ■ LOW FLOW CUT-OFF = On Input range: Switch-off point: 0 to 50 % of end flow value (→ MAX. FLOW). ①  ②  P01-PMD7xxxx-05-xx-xx-xx-000 Factory setting: 5 % (of end flow value)





Fig. 53: LINEARIZATION function group for local operation

Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Level (→ 147). ■ LEVEL MODE = Pressure linearized or height linearized (→ 169). Note: – See also → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	
TANK CONTENT MIN (759) Entry	Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result. Factory setting: 0.0
TANK CONTENT MAX (713) Entry	Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result. Factory setting: 100.0
TABLE SELECTION (808) Selection	Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values. Options: ■ View meas. table ■ Editor table Factory setting: View meas. table

Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation	
Parameter name	Description
LIN. EDIT MODE (397) Selection	Select the entry mode for the linearization table. Prerequisite: - TABLE SELECTION = Editor table Options: - Manual: The container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearization table. - Semiautomatic: The container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. Factory setting: Manual
EDITOR TABLE (809) Selection	Select table. Prerequisite: - TABLE SELECTION = Editor table Options: - New table: Enter a new linearization table. - Edit measure table: The measuring table is loaded as an editor table so that changes can be made. → See also TAB. SELECTION - Continue edit: Edit an editor table that already exists. → See also EDITOR TABLE (770) Factory setting: New table
EDITOR TABLE Entry ("Semiautomatic" edit mode) – LINE-NUMB (549) – Y-VAL. (551)	Enter table in the "Semiautomatic" editing mode. A linearization table must have at least 2 points and may not have more than 32 points. A point consists of LINE-NUMB, X-VAL. and Y-VAL. For this editing mode, the container is filled or emptied in stages. Example: Enter point for LEVEL MODE = Pressure linearized - LINE-NUMB: Confirm value displayed. - Y-VAL.: depending on the setting in the LINd. MEASURAND parameter, enter the volume, mass or % value. - X-VAL.: The hydrostatic pressure present is displayed and saved by confirming the Y-value. Example: Enter point for LEVEL MODE = Height linearized - LINE-NUMB: Confirm value displayed. - Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the volume, mass or % value. - X-VAL.: The hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, the measured pressure is converted to a level unit or a % and displayed. The value is saved by confirming the Y-value. Factory setting: LINE-NUMB = 1, X-VAL. = 0.0, Y-VAL. = 0.0

Table 18: GROUP SELECTION → OPERATING MENU → SETTINGS → LINEARIZATION – Local operation	
Parameter name	Description
EDITOR TABLE Entry ("Manual" edit mode) – LINE-NUMB (549) – Y-VAL. (551) – X-VAL. (550)	Enter the table in the "Manual" editing mode. A linearization table must have at least 2 points and may not have more than 32 points. A point consists of an index, X-value and Y-value. The container neither has to be filled nor emptied for this editing mode. Example: Enter point for LEVEL MODE = Pressure linearized – LINE-NUMB: Confirm value displayed. – X-VAL.: enter pressure value. – Y-VAL.: depending on the setting in the LINd. MEASURAND parameter, enter the related volume, mass or % value. Example: Enter point for LEVEL MODE = Height linearized – LINE-NUMB: Confirm value displayed. – X-VAL.: The hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, enter a level value or % value. – Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the related volume, mass or % value. Factory setting: LINE-NUMB = 1, X-VAL. = 0.0, Y-VAL. = 0.0
EDITOR TABLE (770) Selection	Select the function for the editor table. Options: ■ Next point: enter next point. ■ Last input point: skip back to previous point to correct a mistake for example. ■ Accept input table: save editor table as measuring table. This overwrites the old measuring table. ■ Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. ■ Insert point: see example below. ■ Delete point: the current point is deleted. See example below. Example: Add point, in this case between the 4th and 5th point for example – Select point 5 via the EDITOR TABLE/LINE NUMB parameter. – Confirm current X and Y values with Enter. – Using the EDITOR TABLE (770) parameter, select the option "Insert point". – Point 5 is displayed for the EDITOR TABLE/LINE NUMB parameter. Enter new values for the X-VAL and Y-VAL parameters. Example: Delete point, in this case the 5th point for example – Select point 5 via the EDITOR TABLE/LINE NUMB parameter. – Using the EDITOR TABLE (770) parameter, select the option "Delete point". – The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5. Factory setting: Next point
MEASURING TABLE (549) Display	A point of the linearization table saved (measuring table) appears on the display. The parameter first displays the first point of the linearization table. By entering a line number, you can directly display the corresponding point in the linearization table.
MEASURING TABLE (717) Selection	Select the function for the measuring table. Options: ■ Next point: view next point of the measuring table. ■ Last input point: view previous point of the measuring table. ■ Abort: cancel measuring table display. Display next parameter. Factory setting: Next point
TANK DESCRIPTION (815) Entry	Enter tank description. (max. 32 alphanumeric characters) Factory setting: -----



P01-xxxxxxx-19-xx-xx-en-099

Fig. 54: LINEARIZATION function group for FieldCare

Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare

Parameter name	Description
Prerequisite: - MEASURING MODE = Level (→ 147). - LEVEL MODE = Pressure linearized or height linearized (→ 169). Note: - See also → 117 ff, Section 9 "Level measurement (via local operation and FieldCare)".	
TANK CONTENT MIN Entry	Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result. Factory setting: 0.0
TANK CONTENT MAX Entry	Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result. Factory setting: 100.0
TABLE SELECTION Selection	Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values. Options: - View meas. table - Editor table Factory setting: View meas. table

Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare	
Parameter name	Description
LIN. EDIT MODE Selection	Select the entry mode for the linearization table. Prerequisite: - TABLE SELECTION = Editor table Options: - Manual: The container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearization table. - Semiautomatic: The container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. Factory setting: Manual
EDITOR TABLE Selection	Select table. Prerequisite: - TABLE SELECTION = Editor table Options: - New table: Enter a new linearization table. - View meas. table: View the measuring table saved and change points if necessary. - Continue edit: Edit an editor table that already exists. FieldCare: - If you select the "View meas. table" option, the saved measuring table is loaded in FieldCare. Use the "Lin.-Tab." window to view the entire table, change values if necessary and write the modified table to the device. - If you change a value via the X-VAL. or Y-VAL. parameters, the table in the "Lin-Tab." window is not updated. To view the table saved in the device, this table must first be read out of the device. Factory setting: New table
LINE-NUMB Entry	Enter the line number for the linearization table. A linearization table must have at least 2 points and may not have more than 32 points. - TABLE SELECTION = View meas. table Via this parameter you can select the point of the linearization table which should be displayed. - TABLE SELECTION = Editor table Enter a point via the LINE-NUMB, X-VAL. and Y-VAL. parameters. → See also this table, parameter description for LIN. EDIT MODE, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode) and Y-VAL. In FieldCare, you can enter a complete linearization table in one go, and view it, via the "Lin.-Tab." window.
X-VAL. ("Manual" entry mode) Entry	Enter the pressure value for the linearization table. → See also LIN. EDIT MODE, LINE-NUMB and Y-VAL. Prerequisite: TABLE SELECTION = Editor table
X-VAL. ("Semiautomatic" entry mode) Display	In the "Semiautomatic" entry mode, the container is filled or emptied in stages. The X-VAL. displays the measured hydrostatic pressure. Prerequisite: TABLE SELECTION = Editor table FieldCare: The X-VAL. is saved by confirming the Y-value. → See also LIN. EDIT MODE, LINE-NUMB and Y-VAL.

Table 19: OPERATING MENU → SETTINGS → LINEARIZATION – FieldCare	
Parameter name	Description
Y-VAL. Entry	Enter the volume, mass or %-value belonging to the X-VAL. for the linearization table. Prerequisite: TABLE SELECTION = Editor table Depending on the setting in the LINd. MEASURAND or COMB. MEASURAND parameters, enter a volume, mass or %-value here. → See also this table, parameter description for LIN. EDIT MODE, LINE-NUMB, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode).
EDITOR TABLE Selection	Select the function for the editor table. Options: - Next point: no function - Last input point: no function - Accept input table: save editor table as measuring table. This overwrites the old measuring table. - Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. - Insert point: see example below. - Delete point: the current point is deleted. See example below. Example: Add point, in this case between the 4th and 5th point for example - Select point 5 via the LINE NUMB parameter. - Using the EDITOR TABLE parameter, select the "Insert point" option. - Point 5 is displayed for the LINE NUMB parameter. Enter new values for the X-VAL and Y-VAL parameters. Example: Delete point, in this case the 5th point for example - Select point 5 via the LINE NUMB parameter. - Using the EDITOR TABLE parameter, select the "Delete point" option. - The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5. Factory setting: Next point
ACTIV LIN. TAB. X Display	An X-value of the linearization table already saved appears on the display. You can select a point of the linearization table via the LINE-NUMB parameter. Prerequisite: TABLE SELECTION = View meas. table In FieldCare, you can view the entire saved table in the "Tables" window.
ACTIV LIN. TAB. Y Display	A Y-value of the linearization table already saved appears on the display. You can select a point of the linearization table via the LINE-NUMB parameter. Prerequisite: TABLE SELECTION = View meas. table In FieldCare, you can view the entire saved table in the "Tables" window.
TANK DESCRIPTION Entry	Enter tank description. (max. 32 alphanumeric characters) Factory setting: -----




Fig. 55: TOTALIZER SETUP function group

Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP	
Parameter name	Description
Prerequisite: - MEASURING MODE = Flow Note: - See also → 142 ff, Section 10 "Flow measurement (via local operation and FieldCare)".	
TOTALIZER 1 UNIT (398), (662), (664), (666) Selection	Select the unit for totalizer 1. Depending on the setting in the FLOW-MEAS. TYPE parameter (→ 194) this parameter offers a list of volume, norm volume, standard volume and mass units. When a new volume or mass unit is selected, totalizer-specific parameters are converted and displayed with the new unit within a unit group. When the flow mode is changed, the totalizer value is not converted. The index and the 3-digit ID number depends on the FLOW-MEAS. TYPE selected: - Index 102: TOTALIZER 1 UNIT (general) - Index 156 (398): FLOW-MEAS. TYPE "Volume operat. cond." - Index 168 (662): FLOW-MEAS. TYPE "Mass" - Index 170 (664): FLOW-MEAS. TYPE "Gas. std. cond." - Index 172 (666): FLOW-MEAS. TYPE "Gas. norm cond." Factory setting: m ³

Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP








Parameter name	Description															
TOT. 1 USER UNIT (627) Entry	Enter text (unit) for customer-specific unit for totalizer 1. You can enter a maximum of eight alphanumeric characters here. → See also FACT. U.U.TOTAL.1. Prerequisite: ■ TOTALIZER 1 UNIT = User unit Only the first five characters are shown on the local operation. For example, if the customer-specific unit "crates" was selected, only "crate" would be displayed. If the unit contains a slash, up to eight characters can be shown on the local operation. The maximum number of characters in the counter is again limited to five. For example if the customer-specific unit "crates/m2" was selected, "crate/m2" would be displayed. FieldCare accepts units with eight characters at most. The slash counts as one character. Factory setting: -----															
FACT. U.U. TOTAL. 1 (329) Entry	Enter the conversion factor for a customer-specific unit for totalizer 1. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³ for the "Volume operat. cond." FLOW-MEAS. TYPE. → See also TOT. 1 USER UNIT. Prerequisite: ■ TOTALIZER 1 UNIT = User unit Example: You want the measured value to be displayed in "buckets". - MEASURED VALUE = 1 m³ i 100 buckets - Entry TOT. 1 USER UNIT: bucket - Enter FACT. U.U. TOTAL. 1: 100 - Result: MEASURED VALUE = 100 buckets Factory setting: 1.0															
NEG. FLOW TOT. 1 (400) Selection	Specify the way of counting negative flows for totalizer 1. <table><tr><td></td><td></td><td></td></tr><tr><td>Options</td><td></td><td></td></tr><tr><td>Inc. on neg. flow</td><td>Total increases</td><td>Total increases</td></tr><tr><td>Dec. on neg. flow</td><td>Total increases</td><td>Total decreases</td></tr><tr><td>Stop on neg. flow</td><td>Total increases</td><td>Total remains constant</td></tr></table> P01-xMD7xxxx-16-xx-xx-en-003 Factory setting: Inc. on neg. flow				Options			Inc. on neg. flow	Total increases	Total increases	Dec. on neg. flow	Total increases	Total decreases	Stop on neg. flow	Total increases	Total remains constant
																
Options																
Inc. on neg. flow	Total increases	Total increases														
Dec. on neg. flow	Total increases	Total decreases														
Stop on neg. flow	Total increases	Total remains constant														
RESET TOTALIZER1 (331) Selection	You reset totalizer 1 to zero with this parameter. Options: ■ Abort (do not reset) ■ Reset Factory setting: Abort															
TOTALIZER 2 UNIT (399), (663), (665), (667) Selection	Select the unit for totalizer 2. → See also TOTAL 1. UNIT. The index depends on the FLOW-MEAS. TYPE selected: - Index 103: TOTALIZER 2 UNIT (general) - Index 157 (399): FLOW-MEAS. TYPE "Volume operat. cond." - Index 169 (663): FLOW-MEAS. TYPE "Mass" - Index 171 (665): FLOW-MEAS. TYPE "Gas. std. cond." - Index 173 (667): FLOW-MEAS. TYPE "Gas. norm cond." Factory setting: m³															

Table 20: OPERATING MENU → SETTINGS → TOTALIZER SETUP

Parameter name	Description
TOT. 2 USER UNIT (628) Entry	Enter text (unit) for customer-specific unit for totalizer 2. → See also TOT. 1 USER UNIT. Prerequisite: ■ TOTALIZER 2 UNIT = User unit Factory setting: -----
FACT. U.U. TOTAL 2 (330) Selection	Enter the conversion factor for a customer-specific unit for totalizer 2. → See also FACT. U.U.TOTAL.1. Prerequisite: ■ TOTALIZER 2 UNIT = User unit Factory setting: 1.0
NEG. FLOW TOT. 2 (416) Selection	Specify the way of counting negative flows for totalizer 2. → See NEG. FLOW TOT. 1. Factory setting: Inc. on neg. flow



P01-xMx/xxxx-19-xc-xc-en-014

Fig. 56: DISPLAY group

Table 21: OPERATING MENU → DISPLAY

Parameter name	Description
MENU DESCRIPTOR (416) Selection	Specify the contents for the main line of the local operation in the measuring mode. → See also Operating Instructions BA00301P (Deltabar S) and BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Local operation" section. Options: ■ Primary value (PV) ■ Main measured value (%) ■ Pressure ■ Flow ■ Level ■ Tank content ■ Temperature ■ Error number ■ Totalizer 1 ■ Totalizer 2 The selection depends on the measuring mode chosen. Factory setting: Primary value (PV)

Table 21: OPERATING MENU → DISPLAY	
Parameter name	Description
MAIN DATA FORMAT (688) Selection	Specify the number of places after the decimal point for the value displayed in the main line. → See also Operating Instructions BA00301P (Deltabar S), BA00302P (Cerabar S) or Deltapilot S (BA00372P), "Local operation" section. Options: ■ Auto ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ x.xxxxx Factory setting: Auto
ALTERNATE DATA (423) Selection	Switch on the "Alternating display" mode. In this display mode, the local operation alternates between the following measured values depending on the measuring mode selected. – Pressure: primary value (PV) or main measured value (%) (MEASURED VALUE), pressure (PRESSURE) and temperature (TEMP. SENSOR) – Level: primary value (PV) or main measured value (%) (MEASURED VALUE), pressure (PRESSURE) and temperature (TEMP. SENSOR) – Flow: primary value (PV) or main measured value (%) (MEASURED VALUE), pressure (PRESSURE), temperature (TEMP. SENSOR), totalizer 1 (TOTALIZER 1) and totalizer 2 (TOTALIZER 2) Options: ■ Off ■ On Factory setting: Off
LANGUAGE Display	The onsite display is available in English. The assignment of the English parameter names to the German parameter names is provided in → Chap. 2 "Parameter description of local operation and FieldCare". Needless to say, the device can also be operated in 6 languages (de, en, fr, es, jp, ch) via the DTM or EDD. ■ Select the menu language for FieldCare using the "Language button" in the configuration window. Select the menu language for the FieldCare frame via the "Extra" menu → "Options" → "Display" → "Language". Factory setting: English
DISPLAY CONTRAST (339) Entry	Adjust contrast of local operation. You specify the contrast of the display with a number. Changes are only accepted as single steps, i.e. to change the value from "8" to "4", you need to save four times. You can also adjust the contrast of the display by means of the keys on the electronic insert or at the device. → See also Operating Instructions BA00301P (Deltabar S) and BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Function of the operating keys" section. Input range: 4 to 13, 4: contrast weaker (brighter), 13: contrast stronger (darker). Factory setting: 8




Fig. 57: TRANSMITTER INFO group
 for the TRANSMITTER DATA function group → 210, Table 23: OPERATING MENU → TRANSMITTER INFO → TRANSMITTER DATA
 for the PROCESS CONNECTION function group → 211, Table 24: OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION
 for the SENSOR DATA function group → 212, Table 25: OPERATING MENU → TRANSMITTER INFO → SENSOR DATA
 for the FF DATA function group → 213, Table 26: OPERATING MENU → TRANSMITTER INFO → FF DATA

Table 23: OPERATING MENU → TRANSMITTER INFO → TRANSMITTER DATA	
Parameter name	Description
DEVICE SERIAL No (354) Display	Displays the serial number of the device (11 alphanumeric characters).
ELECTR. SERIAL No (386) Display	Displays the serial number of the main electronics (11 alphanumeric characters).
PD-TAG (57)	Set tag number for the device.
DEVICE DESIGN. (350) Display	Displays the device designation and the order code.
HARDWARE REV. (266) Display	Displays the revision number of the main electronics e.g. V02.00.00
SOFTWARE VERSION (264) Display	Displays the software version e.g.: V 03.00.00
CONFIG RECORDER (352) Display	Displays the configuration counter. This counter is increased by one with each change to a parameter or group. The counter counts up to 65535 and then starts again at zero. Changes in the parameters of the DISPLAY function group do not increase the counter.

Table 23: OPERATING MENU → TRANSMITTER INFO → TRANSMITTER DATA	
Parameter name	Description
PCB TEMPERATURE (357) Display	Displays the measured temperature of the main electronics.
ALLOWED MIN. TEMP (358) Display	Displays the lower temperature limit of the main electronics.
ALLOWED MAX. TEMP (359) Display	Displays the upper temperature limit of the main electronics.
DIP STATUS (363) Display	Displays the status of DIP switch 1 on the electronic insert. You can lock or unlock parameters relevant to the measured value with DIP switch 1. If operation is locked by means of the INSERT PIN No. parameter, you can only unlock operation again by means of this parameter. (→ INSERT PIN NO, see Page → 219.) → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Display: ■ On (locking switched on) ■ Off (locking switched off) Factory setting: Off (locking switched off)

Table 24: OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION	
Parameter name	Description
Pmax PROC. CONN. (570) Entry	For entering and displaying the maximum permitted pressure of the process connection. Factory setting: In accordance with nameplate data (→ See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), "Nameplates" section)
PROC. CONN. TYPE (482) Selection	For selecting and displaying the process connection type. Options: ■ Not used ■ Unknown ■ Special ■ Oval flange ■ Thread female ■ Thread male ■ Flange ■ Remote seal

Table 24: OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION	
Parameter name	Description
MAT. PROC. CONN. + (360) Selection	For selecting and displaying the material of the process connection (P+). → See also parameter description for MAT. PROC. CONN. - Options: ■ Not used ■ Unknown ■ Special ■ Steel ■ 304 st. steel ■ 316 st. steel ■ Alloy C ■ Monel ■ Tantalum ■ Titanium ■ PTFE (Teflon) ■ 316L st. steel ■ PVC ■ Inconel ■ PVDF ■ ECTFE Factory setting: As per order specifications
MAT. PROC. CONN. - (361) Selection	For selecting and displaying the material of the process connection (P-). → See also parameter description for MAT. PROC. CONN. + Prerequisite: ■ Deltabar S differential pressure transmitter
SEAL TYPE (362) Selection	For selecting and displaying the material of the process seal. Options: ■ Not used ■ Unknown ■ Special ■ FKM Viton ■ NBR ■ EPDM ■ Urethane ■ IIR ■ Kalrez ■ FKM Viton oxyg ■ CR ■ MVQ ■ PTFE glass ■ PTFE graphite ■ PTFE oxygen ■ Copper ■ Copper f. oxygen Factory setting: As per order specifications

Table 25: OPERATING MENU → TRANSMITTER INFO → SENSOR DATA	
Parameter name	Description
SENSOR SER. No. (250) Display	Displays the serial number of the sensor (11 alphanumeric characters).
PRESS. SENS LOLIM (484) Display	Displays the lower measuring limit of the sensor.
PRESS. SENS HILIM (485) Display	Displays the upper measuring limit of the sensor.
MINIMUM SPAN (591) Display	Displays the smallest possible span.

Table 25: OPERATING MENU → TRANSMITTER INFO → SENSOR DATA	
Parameter name	Description
SENSOR MEAS.TYPE (581) Display	■ Deltabar S = Differential ■ Cerabar S with gauge pressure sensors = Relative ■ Cerabar S with absolute pressure sensors = Absolute ■ Deltapilot S = Relative Displays the sensor type.
MAT. MEMBRANE (365) Display	Displays the material of the process isolating diaphragm. Factory setting: As per version in the order code → See also Technical Information TI00382P (Deltapilot S), TI00383P (Cerabar S) or TI00416P (Deltapilot S), "Ordering information" section.
FILLING FLUID (366) Display	Displays the filling fluid.
Tmin SENSOR (368) Display	Displays the lower nominal temperature limit of the sensor.
Tmax SENSOR (369) Display	Displays the upper nominal temperature limit of the sensor.
SENS H/WARE REV (487) Display	Displays the revision number of the sensor hardware. e.g.: 1

Table 26: OPERATING MENU → TRANSMITTER INFO → FF DATA	
Parameter name	Description
DEVICE ID (987) Display	The DEVICE ID is the unique device ID in the control system or the FF bus. It consists of the manufacturer ID (452B48), device type number and device serial number. Examples: Deltabar S: 452B481009-6B032A0109D Deltapilot S: 452B48100B-6B032A0109E Cerabar S: 452B481007-6B032A0109F
DEVICE REVISION (986) Display	Displays the revision or version of a complete device (HW+SW) within a device type.
DD REVISION (985) Display	Displays the DD version initially certified.
DEVICE ADDRESS (984) Display	Displays the device address currently configured and valid. The factory setting is 247.




Fig. 58: PROCESS INFO group
for the PROCESS VALUES function group "Pressure" measuring mode → 214, Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure"
for the PROCESS VALUES function group "Level" measuring mode → 215, Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level"
for the PROCESS VALUES function group "Flow" measuring mode → 216, Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"
for the FUNCTION Blocks function group → 216, Table 30: OPERATING MENU → PROCESSINFO → Function Blocks
for the PEAKHOLD function group → 217, Table 31: OPERATING MENU → PROCESSINFO → PEAK HOLD INDICATOR

Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Pressure	
MEASURED VALUE (679) Display	Displays the measured value In the "Pressure" measuring mode, this value corresponds to the PRESSURE parameter.

Table 27: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure"


Parameter name	Description
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.  P01-xMD7xxxx-05-xx-xx-en-000
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the primary value of the Transducer Block. Possibilities: increasing, decreasing, constant

Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level"


Parameter name	Description
Prerequisite: MEASURING MODE = Level	
MEASURED VALUE (679) Display	Displays the measured value In the "Level" measuring mode with "Linear" or "Pressure linearized" level mode, this value corresponds to the LEVEL BEFORE LIN. In the "Level" measuring mode with "Height linearized" level mode, this value corresponds to the TANK CONTENT parameter.
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.  P01-xMD7xxxx-05-xx-xx-en-002
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the primary value of the Transducer Block. Possibilities: increasing, decreasing, constant

Table 28: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level"	
Parameter name	Description
LEVEL BEFORE LIN (050) Display	Displays the level value prior to linearization. Prerequisite: LEVEL MODE = Linear or height linearized Depending on the setting for the LIN. MEASURAND or COMB. MEASURAND parameter, this parameter displays the current level in % or in a unit of level.
TANK CONTENT (370) Display	Displays the level value after linearization. Prerequisite: LEVEL MODE = Pressure linearized or height linearized Depending on the settings for the LINd. MEASURAND or COMB. MEASURAND parameter, the current tank content is displayed in % or in a unit of volume or mass. This value corresponds to the MEASURED VALUE.


Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"	
Parameter name	Description
Prerequisite: MEASURING MODE = Flow	
MEASURED VALUE (679) Display	Displays the measured value In the "Flow" measuring mode, this value corresponds to the SUPPRESSED FLOW parameter.
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.  P01-xMD7/xxxx-05-xx-xx-en-003
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the primary value of the Transducer Block. Possibilities: increasing, decreasing, constant
SUPPRESSED FLOW (375) Display	Displays the current flow. Depending on the flow mode selected (→ FLOW-MEAS. TYPE), a volume flow, mass flow, standard volume flow or corrected volume flow is displayed.
TOTALIZER 1 (652) Display	Displays the total flow value of totalizer 1. You can reset the value with the RESET TOTALIZER 1 parameter. The TOTAL. 1 OVERFLOW parameter displays the overflow. Example: The value 123456789 m ³ is displayed as follows: - TOTALIZER 1: 3456789 m³ - TOTAL. 1 OVERFLOW: 12 E7
TOTAL. 1 OVERFLOW (655) Display	Displays the overflow value of totalizer 1. → See also TOTALIZER 1.

Table 29: OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"

Parameter name	Description
TOTALIZER 2 (657) Display	Displays the total flow value of totalizer 2. You cannot reset totalizer 2. The TOTAL. 2 OVERFLOW parameter displays the overflow. → See also example for TOTALIZER 1.
TOTAL. 2 OVERFLOW (658) Display	Displays the overflow value of totalizer 2. → See also TOTALIZER 2 and example for TOTALIZER 1.

Table 30: OPERATING MENU → PROCESSINFO → Function Blocks

Parameter name	Description															
AI 1 OUT Value (983) Display	The current values are displayed for instantiated analog inputs, with their individual units and status. The first line displays the AI text. The second line displays the current value for the parameter and the unit. The third line displays the status of the value.															
AI 2 OUT Value (982) Display	The following list indicates the status and the related text of the AI OUT value:															
	<table><tr><th>Status</th><th></th><th>Text</th></tr><tr><td>Bad</td><td>=</td><td>BAD</td></tr><tr><td>Uncertain</td><td>=</td><td>UNCERTAIN</td></tr><tr><td>Good non-cascaded</td><td>=</td><td>GOOD</td></tr><tr><td>Good cascaded</td><td>=</td><td>GOOD</td></tr></table>	Status		Text	Bad	=	BAD	Uncertain	=	UNCERTAIN	Good non-cascaded	=	GOOD	Good cascaded	=	GOOD
Status		Text														
Bad	=	BAD														
Uncertain	=	UNCERTAIN														
Good non-cascaded	=	GOOD														
Good cascaded	=	GOOD														
AI 3 OUT Value (981) Display																
Note: ■ When delivered: – Two AI Blocks are preinstantiated for Cerabar S and Deltapilot S – Three AI Blocks are preinstantiated for Deltabar S ■ Up to three additional AI Blocks are instantiated.																

Table 31: OPERATING MENU → PROCESSINFO → PEAK HOLD INDICATOR

Parameter name	Description
COUNTER: P > Pmax (380) Display	Displays the overpressure counter of the sensor The limit value is: upper nominal pressure limit of sensor + 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.
MAX. MEAS. PRESS. (383) Display	Displays the highest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER P < Pmin (467) Display	Displays the vacuum pressure counter of the sensor The limit value is: lower nominal pressure limit of sensor – 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.
MIN. MEAS. PRESS. (469) Display	Displays the lowest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER: T > Tmax (404) Display	Displays the number of times the specified temperature range of the sensor has been overshoot. You can reset this counter by means of the RESET PEAKHOLD parameter.
MAX. MEAS. TEMP. (471) Display	Displays the highest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER: T < Tmin (472) Display	Displays the number of times the specified temperature range of the sensor has been undershot. You can reset this counter by means of the RESET PEAKHOLD parameter.
MIN. MEAS. TEMP. (474) Display	Displays the lowest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
PCB COUNT: T > Tmax (488) Display	Displays the number of times the specified temperature range of the electronics has been overshoot.

Table 31: OPERATING MENU → PROCESSINFO → PEAK HOLD INDICATOR	
Parameter name	Description
PCB MAX. TEMP. (490) Display	Displays the highest electronics temperature measured.
PCB COUNT:T < Tmin (492) Display	Displays the number of times the specified temperature range of the electronics has been undershot.
PCB MIN. TEMP. (494) Display	Displays the lowest electronics temperature measured.
RESET PEAKHOLD (382) Selection	This parameter lists all the peak hold indicator parameters that can be reset. You can select the peak hold indicators you want to reset. Options: ■ None ■ Max. pressure ■ Min. pressure ■ Pmax history ■ Pmin history ■ Max. temp. ■ Min. temp. ■ Tmax history ■ Tmin history ■ Reset all Factory setting: None




Fig. 59: OPERATION and DIAGNOSTICS group
 for the OPERATION group → 219, Table 32: OPERATING MENU → OPERATION
 for the SIMULATION function group → 220, Table 33: OPERATING MENU → DIAGNOSTICS → SIMULATION
 for the MESSAGES function group → 221, Table 34: OPERATING MENU → DIAGNOSTICS → MESSAGES
 for the USER LIMITS function group → 223, Table 35: OPERATING MENU → DIAGNOSTICS → USER LIMITS

Table 32: OPERATING MENU → OPERATION	
Parameter name	Description
ENTER RESET CODE (047) Entry	Reset parameters completely or partially to factory values or delivery status. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Factory setting" (reset) section. Factory setting: 0
OPERATING HOURS (409) Display	Displays the hours of operation. This parameter cannot be reset.
INSERT PIN NO (048) Entry	For entering a code to lock or unlock operation. ▪ The -symbol on the local operation indicates that operation is locked. Parameters which refer to how the display appears, e.g. LANGUAGE and DISPLAY CONTRAST, can still be altered. ▪ If operation is locked by means of the DIP switch, you can only unlock operation again by means of the DIP switch. If operation is locked by means of remote operation e.g. FieldCare, you can only unlock operation again using remote operation. → See also Operating Instructions BA00301P (Deltabar S) or BA00302P (Cerabar S) or BA00372P (Deltapilot S), "Locking/unlocking operation" section. Options: ▪ Lock: Enter the number 0. ▪ Unlock: Enter the number 2457. Factory setting: 2457
HistoROM AVAIL. (831) Display	Indicates whether the optional HistoROM®/M-DAT memory module is connected to the electronic insert. → See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P) "HistoROM®/M-DAT (optional)" section. Options: ▪ Yes (HistoROM®/M-DAT is attached to the electronic insert) ▪ No (HistoROM®/M-DAT is not attached to the electronic insert)
DOWNLOAD SELECT (014) Selection	Select download function from HistoROM to device. The option selected has no effect on an upload from the device to the HistoROM. Prerequisite: ▪ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM AVAIL. = Yes) Options: ▪ Configuration copy: With this option, all parameters apart from the TRANSMITTER SERIAL No, DEVICE DESIGNATION and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ▪ Device replacement: With this option, all parameters except for TRANSMITTER SERIAL No, DEVICE DESIGNATION and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ▪ Electronics replace: With this option, all parameters except for the parameters of the POSITION ADJUSTMENT group are overwritten. Factory setting: Configuration copy (if HistoROM®/M-DAT is attached to the electronic insert)
HistoROM CONTROL (832) Selection	For selecting the direction for copying the data. → See also Operating Instructions for Deltabar S (BA00301P), Cerabar S (BA00302P) or Deltapilot S (BA00372P), "HistoROM®/M-DAT (optional)" section. Prerequisite: ▪ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM AVAIL. = Yes) Options: ▪ Abort ▪ HistoROM → Device ▪ Device → HistoROM Factory setting: Abort (if HistoROM®/M-DAT is attached to the electronic insert)

Table 33: OPERATING MENU → DIAGNOSTICS → SIMULATION


Parameter name	Description
SIMULATION MODE (413) Selection	Switch on simulation and select simulation type. Any simulation running is switched off if the measuring mode or level mode is changed. Options: ■ None ■ Pressure, → see also this table, parameter description for SIM. PRESSURE. ■ Flow (only differential pressure transmitter), → see also this table, parameter description for SIM. FLOW VALUE. ■ Level, → see also this table, parameter description for SIM. LEVEL. ■ Tank content, → see also this table, parameter description for SIM. TANK CONT. ■ Alarm/warning, → see also this table, parameter description for SIM. ERROR NO.  P01-xMD7xxxx-05-xx-xx-en-004 Factory setting: None
SIM. PRESSURE (414) Entry	Enter the simulation value. → See also SIMULATION MODE. Prerequisite: ■ SIMULATION MODE = Pressure Factory setting: Current pressure measured value
SIM. FLOW VALUE (639) Entry	Enter the simulation value. → See also SIMULATION MODE. Prerequisite: ■ MEASURING MODE = Pressure and SIMULATION MODE = Flow ■ MEASURING MODE = Flow and SIMULATION MODE = Flow
SIM. LEVEL (714) Entry	Enter the simulation value. → See also SIMULATION MODE. Prerequisite: ■ MEASURING MODE = Level and SIMULATION MODE = Level
SIM. TANK CONT. (715) Entry	Enter the simulation value. → See also SIMULATION MODE. Prerequisites: ■ MEASURING MODE = Level, LEVEL MODE = Pressure linearized and SIMULATION MODE = Tank content ■ MEASURING MODE = Level, LEVEL MODE = Height linearized and SIMULATION MODE = Tank content

Table 33: OPERATING MENU → DIAGNOSTICS → SIMULATION	
Parameter name	Description
SIM. ERROR NO. (476) Entry	A fault condition that is actually present cannot be simulated. Enter the message number. → See also SIMULATION MODE. → See also these Operating Instructions, Section 12.1 "Messages", "Code" table column. Prerequisite: ■ SIMULATION MODE = Alarm/warning Factory setting: 613 (simulation active)

Table 34: OPERATING MENU → DIAGNOSTICS → MESSAGES	
Parameter name	Description
ALARM STATUS (046) Display	Displays the current message present. → See also these Operating Instructions, Section 12.1 "Messages" and Section 12.4 "Confirming messages". Local operation ■ The measured value display shows the message with the highest priority. ■ The ALARM STATUS parameter shows all the messages in descending order of priority. You can scroll through all the messages present with the O or S key. FieldCare ■ The ALARM STATUS parameter shows the message with the highest priority.
LAST DIAG. CODE (564) Display	Displays the last message that occurred and was eliminated. ■ Local operation: you can scroll through the last 15 messages with the O or S key. ■ FieldCare: the last message appears on the display. ■ Use the RESET ALL ALARMS parameter to delete the messages listed in the LAST DIAG. CODE parameter.
ACK. ALARM MODE (401) Selection	Switch on the acknowledge alarm mode. → See also ACK. ALARM. Options: ■ On ■ Off Factory setting: Off
ACK. ALARM (500) Selection	Acknowledge the alarm. Prerequisite: ■ ACK. ALARM MODE = On Options: ■ Abort ■ Confirm The cause of the alarm must be eliminated, the message must be acknowledged via the ACK. ALARM parameter and, where applicable, the ALARM DISPL. TIME (→ 222) has to have elapsed before the device starts measuring again following an alarm. → See also these Operating Instructions, Section 12.4 "Confirming messages". Factory setting: Abort
RESET ALL ALARMS (603) Selection	Use this parameter to reset all the alarms of the LAST DIAG. CODE parameter. Options: ■ Abort ■ Confirm Factory setting: Abort


Table 34: OPERATING MENU → DIAGNOSTICS → MESSAGES	
Parameter name	Description
ERROR NO. Entry	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). Enter the corresponding message number for this parameter. → See also SELECT ALARMTYPE. → See also these Operating Instructions, Section 12.1 "Messages" and Section 12.3 "Response of outputs to errors".
SELECT ALARMTYPE (595) – Entry (600) – Selection Selection	For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). → See also ERROR No. → See also these Operating Instructions, Section 12.3 "Response of outputs to errors". Options: - Alarm (A): the process variable in question is transmitted with the status BAD. - Warning (W): device continues measuring Local operation: - Enter the corresponding message number for ERROR No. field. - Select "Alarm" or "Warning" option. FieldCare: - Enter the corresponding message number via the ERROR No. parameter. - Use the SELECT ALARMTYPE parameter to select the "Alarm" or "Warning" option.
ALARM DELAY (336) Entry	Enter the alarm response time for all "Error"-type messages. There is no alarm if the cause of the error is eliminated within the alarm delay time. Input range: 0 to 100 s Factory setting: 0.0 s
ALARM DISPL. TIME (480) Entry	Enter the alarm delay time for all "Error"-type messages. Once the cause of the error is rectified, the alarm display time starts running. The following applies if the setting for ACK. ALARM MODE = On: If an alarm appears and the alarm display time elapses before the alarm has been acknowledged, the message is cleared once it has been acknowledged. → See also these Operating Instructions, Section 12.4 "Confirming messages". Input range: 0 to 999.9 s Factory setting: 0.0 s

Table 35: OPERATING MENU → DIAGNOSTICS → USER LIMITS

Parameter name	Description
Pmin ALARM WINDOW (332) Entry	Customer-specific process monitoring – enter lower pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages", Table, code E730 and Section 12.3 "Response of outputs to errors". Factory setting: Low sensor limit ■ 1.1 (→ For the low sensor limit, see PRESS. SENS LOLIM.)
Pmax ALARM WINDOW (333) Entry	Customer-specific process monitoring – enter upper pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages", Table, code E731 and Section 12.3 "Response of outputs to errors". Factory setting: High sensor limit ■ 1.1 (→ For the high sensor limit, see PRESS. SENS HILIM.)
TminALARM WINDOW (334) Entry	Customer-specific process monitoring – enter lower temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages" Table, code E732 and Section 12.3 "Response of outputs to errors". Factory setting: Lower sensor temperature application limit – 10 K (→ For the lower temperature application limit, see Tmin SENSOR)
Tmax ALARM WINDOW (335) Entry	Customer-specific process monitoring – enter upper temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 12.1 "Messages" Table, code E733 and Section 12.3 "Response of outputs to errors". Factory setting: Upper sensor temperature application limit +10 K (→ For the upper temperature application limit, see Tmax SENSOR)

12 Troubleshooting

In this chapter the parameter text as well as the parameter name are indicated.
In FF configuration programs only the parameter text is displayed (expection: in the NI-FBUS configurator you can select if the parameter text or the parameter name is displayed).



12.1 Messages

The following table lists all the messages that can occur. The device makes a distinction between the message types "Alarm", "Warning" and "Error". For "Error"-type messages, you can enter whether the device should react as in the event of an alarm or as in the event of a warning. → See the "Error type" column and Section 12.3 "Response of outputs to errors".

Message display:

- Local operation:
 - The measured value display shows the message with the highest priority.
→ See the "Priority" column.
 - The Alarm Status/ALARM_STATUS parameter shows all the messages present in descending order of priority. You can scroll through all the messages pending using the S or O key.
- FieldCare:
 - The Alarm Status/ALARM_STATUS parameter shows the message with the highest priority.
→ See the "Priority" column.
- Diagnostic Transducer Block (FF configuration program):
 - The Alarm Status/ALARM_STATUS parameter displays the message with the highest priority. This parameter is displayed in the MESSAGES group in the Diagnostic Transducer Block or in FieldCare. See also Section 12.3 "Response of outputs to errors". Every message is also output as per the FOUNDATION Fieldbus Specification by means of the Transducer Error/XD_ERROR and Block Error/BLOCK_ERROR parameters in the Pressure, Service and DP Flow Transducer Block.
 - Numbers are given for these parameters in the following table which are explained
→ 229.
- If the device detects a defect in the local operation during initialization, special error messages are generated. For the error messages, → 228, Section 12.1.1 "Local operation error messages".
- For support and further information, please contact Endress+Hauser Service.

Error type	Diagnostic Code	XD_ERROR Value Bit	XD_ERROR Text	BLOCK_ERROR Value Bit	BLOCK_ERROR Text	PRIMARY_VALUE (Status is set according to Operating Mode)	PRIMARY_VALUE_TYPE (Operating Mode)	TRANSDUCER Status Propagation (Impacted CHANNEL selection)
Alarm	747	17	General Error	0	Other	BAD_SENSOR_FAILURE	Pressure, Level, Flow	All
	707	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	711	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level, Flow	Primary Value(1) Totalizer 1 (6)
	713	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	721	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	722	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	723	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Flow	Primary Value(1) Totalizer 1 (6)
	741	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	719	19	Configuration Error	0	Other	BAD_NON_SPECIFIC	Level	Primary Value(1)
	750	18	Calibration Error	0	Other	BAD_NON_SPECIFIC	Pressure, Level, Flow	Primary Value(1) Pressure(3) Maximum Pressure(4) Counter P > Pmax(5) Totalizer 1 (6)
	122	20	Electronics Failure	7	Sensor Failure	BAD_SENSOR_FAILURE	Pressure, Level, Flow	All
	101	20	Electronics Failure	0	Other	BAD_SENSOR_FAILURE	Pressure, Level, Flow	All
	716	20	Electronics Failure	0	Other	BAD_SENSOR_FAILURE	Pressure, Level, Flow	All
	725	20	Electronics Failure	0	Other	BAD_SENSOR_FAILURE	Pressure, Level, Flow	All
	704	20	Electronics Failure	7	Sensor Failure	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	703	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	705	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	737	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	738	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	739	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	742	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	744	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All

Error type	Diagnostic Code	XD_ERROR Value Bit	XD_ERROR Text	BLOCK_ERROR Value Bit	BLOCK_ERROR Text	PRIMARY_VALUE (Status is set according to Operating Mode)	PRIMARY_VALUE_TYPE (Operating Mode)	TRANSDUCER Status Propagation (Impacted CHANNEL selection)
Alarm	743	20	Electronics Failure	7	Sensor Failure	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	748	20	Electronics Failure	7	Sensor Failure	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	113	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	728	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	729	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	736	20	Electronics Failure	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	110	23	Data Integrity Error	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	130	23	Data Integrity Error	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	131	23	Data Integrity Error	0	Other	GOOD	Pressure, Level, Flow	None
	132	23	Data Integrity Error	0	Other	BAD_DEVICE_FAILURE	Flow	Totalizer 1 (6)
	133	23	Data Integrity Error	0	Other	GOOD	Pressure, Level, Flow	None
	135	23	Data Integrity Error	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All
	121	23	Data Integrity Error	0	Other	BAD_DEVICE_FAILURE	Pressure, Level, Flow	All

Error type	Diagnostic Code	XD_ERROR Value Bit	XD_ERROR Text	BLOCK_ERROR Value Bit	BLOCK_ERROR Text	PRIMARY_VALUE (Status is set according to Operating Mode)	PRIMARY_VALUE_TYPE (Operating Mode)	TRANSDUCER Status Propagation (Impacted CHANNEL selection)
Alarm/ Warning	115	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	Primary Value(1) Pressure(3) Maximum Pressure(4) Counter P > Pmax(5) Totalizer 1 (6)
	120	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	Primary Value(1) Pressure(3) Maximum Pressure(4) Counter P > Pmax(5) Totalizer 1 (6)
	717	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	718	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	720	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	Sensor Temperature(2)
	715	17	General Error	7	Sensor Failure	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	Sensor Temperature(2)
	726	20	Electronics Failure	7	Sensor Failure	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	740	20	Electronics Failure	7	Sensor Failure	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	727	20	Electronics Failure	7	Sensor Failure	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	730	19	Configuration Error	0	Other	GOOD	Pressure, Level, Flow	None
	731	19	Configuration Error	0	Other	GOOD	Pressure, Level, Flow	None
	732	19	Configuration Error	0	Other	GOOD	Pressure, Level, Flow	None
	733	19	Configuration Error	0	Other	GOOD	Pressure, Level, Flow	None

Error type	Diagnostic Code	XD_ERROR Value Bit	XD_ERROR Text	BLOCK_ERROR Value Bit	BLOCK_ERROR Text	PRIMARY_VALUE (Status is set according to Operating Mode)	PRIMARY_VALUE_TYPE (Operating Mode)	TRANSDUCER Status Propagation (Impacted CHANNEL selection)
Warning	106	17	General Error	0	Other	STATUS_UNCERTAIN	Pressure, Level, Flow	All
	134	17	General Error	0	Other	GOOD	Pressure, Level, Flow	None
	116	17	General Error	0	Other	- BAD_NON_SPECIFIC - STATUS_UNCERTAIN - GOOD	Pressure, Level, Flow	All
	701	17	General Error	0	Other	UNCERTAIN_CONFIG_ERROR	Pressure, Level, Flow	All
	745	17	General Error	0	Other	STATUS_UNCERTAIN	Pressure, Level, Flow	All
	613	17	General Error	0	Other	UNCERTAIN_SIM	Pressure, Level, Flow	Primary Value(1) Maximum Pressure(4) Counter P > Pmax(5) Totalizer 1 (6)
	702	17	General Error	0	Other	GOOD	Pressure, Level, Flow	None
	710	18	Calibration Error	0	Other	GOOD	Pressure, Level, Flow	None
	602	19	Configuration Error	0	Other	UNCERTAIN_CONFIG_ERROR	Level	Primary Value(1)
	604	19	Configuration Error	0	Other	UNCERTAIN_CONFIG_ERROR	Level	Primary Value(1)
	746	20	Electronics Failure	0	Other	STATUS_UNCERTAIN	Pressure, Level, Flow	All
	102	23	Data Integrity Error	0	Other	GOOD	Pressure, Level, Flow	Maximum Pressure(4) Counter P > Pmax(5)
	700	23	Data Integrity Error	0	Other	STATUS_UNCERTAIN	Pressure, Level, Flow	All
	706	23	Data Integrity Error	0	Other	GOOD	Pressure, Level, Flow	None

12.1.1 Local operation error messages

If the device detects a defect in the local operation during initialization, the following error messages can be displayed:

Message	Measure
Initialization, VU Electr. Defect A110	Exchange local operation.
Initialization, VU Electr. Defect A114	
Initialization, VU Electr. Defect A281	
Initialization, VU Checksum Err. A110	
Initialization, VU Checksum Err. A112	
Initialization, VU Checksum Err. A171	

12.2 Overview of diagnostic events

12.2.1 Failure (F)

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
101	Alarm	F>Sensor electronic EEPROM error	20	0	- Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. - Sensor defect.	- Wait a few minutes. - Restart the device. Perform reset (Code 62). - Block off electromagnetic effects or eliminate source of disturbance. - Replace sensor.	19
110	Alarm	F>Checksum error in EEPROM: configuration segment	23	0	- The supply voltage is disconnected when writing. - Electromagnetic effects are greater than specifications in the technical data. - Main electronics defect.	- Reestablish supply voltage. Perform reset if necessary (code 7864) and recalibrate the device. - Block off electromagnetic effects or eliminate sources of disturbance. - Replace main electronics.	6
113	Alarm	F>ROM failure in transmitter electronic	20	0	Main electronics defect.	Replace main electronics.	1
121	Alarm	F>Checksum error in factory segment of EEPROM	23	0	Main electronics defect.	Replace main electronics.	5
122	Alarm	F>Sensor not connected	20	7	- Cable connection sensor – main electronics disconnected. - Electromagnetic effects are greater than specifications in the technical data. - Main electronics defect. - Sensor defect.	- Check cable connection and repair if necessary. - Block off electromagnetic effects or eliminate source of disturbance. - Replace main electronics. - Replace sensor.	14
130	Alarm	F>EEPROM is defect.	23	0	Main electronics defect.	Replace main electronics.	11
131	Alarm	F>Checksum error in EEPROM: min/max segment	23	0	Main electronics defect.	Replace main electronics.	9
132	Alarm	F>Checksum error in totalizer EEPROM	23	0	Main electronics defect.	Replace main electronics.	7
133	Alarm	F>Checksum error in History EEPROM	23	0	- An error occurred when writing. - Main electronics defect.	- Perform reset (code 7864) and recalibrate the device. - Replace main electronics.	8
135	Alarm	F>Checksum error in EEPROM FF segment	23	0	Main electronics defect.	Replace main electronics.	10
703	Alarm	F>Measurement error	20	0	- Fault in the main electronics. - Main electronics defect.	- Briefly disconnect device from the power supply. - Replace main electronics.	24
705	Alarm	F>Measurement error	20	0	- Fault in the main electronics. - Main electronics defect.	- Briefly disconnect device from the power supply. - Replace main electronics.	23

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
716	Alarm	F>Process isolating diaphragm broken	20	0	– Sensor defect.	– Replace sensor. – Reduce pressure.	26
725	Alarm	F>Sensor connection error, cycle disturbance	20	0	– Electromagnetic effects are greater than specifications in the technical data. – Setscrew loose. – Sensor or main electronics defect.	– Block off electromagnetic effects or eliminate source of disturbance. – Retighten setscrew with 1 Nm (0.74 lbf ft) (see standard Operating Instructions). – Replace sensor or main electronics.	27
728	Alarm	F>RAM error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	2
729	Alarm	F>RAM error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	3
736	Alarm	F>RAM error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	4
737	Alarm	F>Measurement error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	22
738	Alarm	F>Measurement error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	21
739	Alarm	F>Measurement error	20	0	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	25
742	Alarm	F>Sensor connection error (upload)	20	0	– Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. – Cable connection sensor – main electronics disconnected. – Sensor defect.	– Wait a few minutes. – Perform reset (code 7864) and recalibrate the device. – Check cable connection and repair if necessary. – Replace sensor.	20
743	Alarm	F>Electronic PCB error during initialization	20	7	– Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. – Main electronics defect.	– Wait a few minutes. – Restart the device. Perform reset (Code 62). – Replace main electronics.	15 / 16
744	Alarm	F>Main electronic PCB error	20	0	– Electromagnetic effects are greater than specifications in the technical data. – Main electronics defect.	– Restart the device. Perform reset (Code 62). – Block off electromagnetic effects or eliminate source of disturbance. – Replace main electronics.	12
747	Alarm	F>Sensor software not compatible to electronics	17	0	– Sensor does not suit the device (electronic sensor nameplate).	– Replace sensor with a suitable sensor.	18

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
748	Alarm	F>Memory failure in signal processor	20	7	- Electromagnetic effects are greater than specifications in the technical data. - Main electronics defect.	- Block off electromagnetic effects or eliminate source of disturbance. - Replace main electronics.	17

12.2.2 Check (C)

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
106	Warning	C>Downloading - please wait	17	0	Downloading.	Wait for download to complete.	61
602	Warning	C>Linearization curve not monoton	19	0	The linearization table is not monotonic increasing.	Add to or correct linearization table. Then accept linearization table again.	67
604	Warning	C>linearization table invalid. Min. 2 points.	19	0	There is no min. span for the y-points as of software version "03.00.xx". The linearization table has fewer than 2 points.	- Add to linearization table. Perform the linearization again if necessary. - Correct the linearization table and accept it again.	68
613	Warning	C>Simulation active	17	0	Simulation is switched on, i.e. the device is not measuring at present.	Switch off simulation.	70
701	Warning	C>Adjustment outside sensor nominal range	17	0	The adjustment carried out would cause a breach of the nominal sensor range.	Carry out calibration again.	63
704	Alarm	C>Measurement error	20	7	- Fault in the main electronics. - Main electronics defect.	- Briefly disconnect device from the power supply. - Replace main electronics.	13
707	Alarm	C>X-VAL. (TAB_XY_VALUE) of lin. table out of edit limits.	18	0	At least one X-VALUE (TAB_XY_VALUE) in the linearization table is either below the value for SCALE_IN, EU_0/HYDR. PRESS. MIN. or LINEAR_LEVEL_MIN/LEVEL MIN. or above the value for SCALE_IN, EU_100/HYDR. PRESS. MAX. or LINEAR_LEVEL_MAX/LEVEL MAX.	Carry out calibration again.	45
710	Warning	B>Set span too small. Not allowed.	18	0	- Values for calibration (e.g. lower-range value and upper-range value) are too close together. - The sensor was replaced and the customer-specific configuration does not suit the sensor. - Unsuitable download carried out.	- Adjust calibration to suit sensor, CAL_MIN_SPAN/MINIMUM SPAN parameter. - Adjust calibration to suit sensor. - Replace sensor with a suitable sensor. - Check configuration and perform download again.	60

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
711	Alarm	C>LRV or URV out of edit limits	18	0	- Lower range value and/or upper range value undershoot or overshoot the sensor range limits. - The sensor was replaced and the customer-specific configuration does not suit the sensor. - Unsuitable download carried out.	- Reset the LRV and/or URV to suit the sensor. Pay attention to position adjustment. - Reset the LRV and/or URV to suit the sensor. Pay attention to position adjustment. - Replace sensor with a suitable sensor. - Check configuration and perform download again.	37
713	Alarm	C>100% POINT (LEVEL_100_PERCENT_VALUE) level out of edit limits	18	0	The sensor was replaced.	Carry out calibration again.	46
719	Alarm	C>Y-VAL (TAB_XY_VALUE) of lin. table out of edit limits	19	0	At least one Y-VALUE (TAB_XY_VALUE) in the linearization table is below the SCALE_OUT, EU_0/TANK CONTENT MIN. or above the SCALE_OUT, EU_100/TANK CONTENT MAX.	Carry out calibration again.	47
721	Alarm	C>ZERO POSITION (LEVEL_OFFSET) level out of edit limits	18	0	LEVEL MIN (LINEAR_LEVEL_MIN) or LEVEL MAX (LINEAR_LEVEL_MAX) has been changed.	Perform reset (code 2710) and recalibrate the device.	48
722	Alarm	C>EMPTY CALIB. (SCALE_OUT, EU_0) or FULL CALIB. (SCALE_OUT, EU_100) out of edit limits	18	0	LINEAR_LEVEL_MIN/LEVEL MIN or LINEAR_LEVEL_MAX/LEVEL MAX has been changed.	Perform reset (code 2710) and recalibrate the device.	49/50
723	Alarm	C>MAX. FLOW (SCALE_OUT, EU_100) out of edit limits	18	0	FLOW_TYPE/FLOW-MEAS. TYPE has been changed.	Carry out calibration again.	51
741	Alarm	C>TANK HEIGHT (LEVEL_TANK_HEIGHT) out of edit limits	18	0	LINEAR_LEVEL_MIN/LEVEL MIN or LINEAR_LEVEL_MAX/LEVEL MAX has been changed.	Perform reset (code 2710) and recalibrate the device.	52
746	Warning	C>Sensor connection error - initializing	20	0	- Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. - Overpressure or low pressure present.	- Wait a few minutes. - Restart the device. Perform reset (Code 7864). - Block off electromagnetic effects or eliminate source of disturbance. - Reduce or increase pressure.	28

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
750	Warning	C>Configuration not permitted	18	0	By means of the operation profile, options were selected for the configuration of the device but the options do not suit one another. For example, if the option "1" (linearization table) was selected for LIN_TYPE and the unit "1347 (m³/s)" was selected for PRIMARY_VALUE_UNIT.	- Check configuration. - Perform reset (code 7864) and recalibrate the device.	53

12.2.3 Maintenance required (M)

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
102	Warning	M>Checksum error in EEPROM: peakhold segment	23	0	Main electronics defect. Correct measurement can continue as long as you do not need the peak hold indicator function.	Replace main electronics.	62
116	Warning	M>Download error, repeat download	17	0	- The file is defect. - During the download, the data are not correctly transmitted to the processor, e.g. because of open cable connections, spikes (ripple) on the supply voltage or electromagnetic effects.	- Use another file. - Check cable connection PC – transmitter. - Block off electromagnetic effects or eliminate sources of disturbance. - Perform reset (code 7864) and recalibrate the device. - Repeat download.	38
134	Warning	M>EEPROM lifetime WARNING	17	0	Writing too often to EEPROM.	Reduce write accessing to EEPROM.	65
700	Warning	M>Last configuration not stored	23	0	- An error occurred when writing or reading configuration data or the power supply was disconnected. - Main electronics defect.	- Perform reset (code 7864) and recalibrate the device. - Replace main electronics.	63
702	Warning	M>HistoROM data not consistent	17	0	- Data were not written correctly to the HistoROM, e.g. if the HistoROM was detached during the writing process. - HistoROM does not have any data.	- Repeat upload. - Perform reset (code 7864) and recalibrate the device. - Copy suitable data to the HistoROM. (see standard Operating Instructions)	64

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
706	Warning	M>Configuration in HistoROM and device not identical	23	0	Configuration (parameters) in the HistoROM and in the device not identical.	- Copy data from the device to the HistoROM. (see standard Operating Instructions) - Copy data from the HistoROM to the device. (see standard Operating Instructions) The message remains if the HistoROM and the device have different software versions. The message disappears if you copy the data from the device to the HistoROM. - Device reset codes such as 1 or 40864 do not have any effect on the HistoROM. That means that if you perform a reset, the configurations in the HistoROM and in the device can be different.	69
740	Alarm/warning	M>Calculation overflow, bad configuration	20	7	- Level measuring mode: the measured pressure has undershot the value for SCALE_IN, EU_0/HYDR. PRESS. MIN. or overshoot the value for SCALE_IN, EU_100/HYDR. PRESS MAX. - Level measuring mode: the measured level has undershot the value for LEVEL MIN or overshoot the value for LEVEL MAX - Flow measuring mode: the measured pressure has overshoot the value for SCALE_IN, EU_100/MAX. PRESS FLOW.	- Check configuration and carry out calibration again if necessary. - Select a device with a suitable measuring range. - Check configuration and carry out calibration again if necessary. LEVEL MIN. parameter - Check configuration and carry out calibration again if necessary. - Select a device with a suitable measuring range.	29
745	Warning	M>Sensor data unknown	17	0	Sensor does not suit the device (electronic sensor nameplate). Device continues measuring.	Replace sensor with a suitable sensor.	66

12.2.4 Out of specification (S)

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
115	Alarm/warning	S>Sensor overpressure	17	0	– Overpressure present. – Sensor defect.	– Reduce pressure until message disappears. – Replace sensor.	31
120	Alarm/warning	S>Sensor low pressure	17	0	– Pressure too low. – Sensor defect.	– Increase pressure until message disappears. – Replace sensor.	32
715	Alarm/warning	S>Sensor over temperature	17	7	– The temperature measured in the sensor is greater than the upper nominal temperature of the sensor. TEMPERATURE_1_SENSOR_LIMIT_HIGH/Tmax SENSOR parameter. – Unsuitable download carried out.	– Reduce process temperature/ambient temperature. – Check configuration and perform download again.	34
717	Alarm/warning	S>Transmitter over temperature	17	0	– The temperature measured in the electronics is greater than the upper nominal temperature of the electronics (+88 °C (+190 °F)). – Unsuitable download carried out.	– Reduce ambient temperature. – Check configuration and perform download again.	36
718	Alarm/warning	S>Transmitter under temperature	17	0	– The temperature measured in the electronics is smaller than the lower nominal temperature of the electronics (–43 °C (–45 °F)). – Unsuitable download carried out.	– Increase ambient temperature. Insulate device if necessary. – Check configuration and perform download again.	37
720	Alarm/warning	S>Sensor under temperature	17	0	– The temperature measured in the sensor is lower than the lower nominal temperature of the sensor (TEMPERATURE_1_SENSOR_LIMIT_LOW/Tmin SENSOR parameter). – Unsuitable download carried out. – Loose connection at sensor cable.	– Increase process temperature/ambient temperature. – Check configuration and perform download again. – Wait a short period of time and tighten the connection, or avoid loose connection.	35
726	Alarm/warning	S>Sensor temperature error - overrange	20	7	– Electromagnetic effects are greater than specifications in the technical data. – Process temperature is outside permitted range. – Sensor defect.	– Block off electromagnetic effects or eliminate source of disturbance. – Check temperature present, reduce or increase if necessary. – If the process temperature is within the permitted range, replace sensor.	33

Diagnostic Code	Error type	Message/description	XD_ERROR Value Bit	BLOCK_ERROR Value Bit	Cause	Measure	Priority
727	Alarm/ warning	S>Sensor pressure error - overrange	20	7	– Electromagnetic effects are greater than specifications in the technical data. – Pressure is outside permitted range. – Sensor defect.	– Block off electromagnetic effects or eliminate source of disturbance. – Check pressure present, reduce or increase if necessary. – If the pressure is within the permitted range, replace sensor.	30
730	Alarm/ Warning	S>Pmin ALARM WINDOW (PRESSURE_1_USER_LOW_LIMIT) undershot	19	0	– Pressure measured value has undershot the value specified for the PRESSURE_1_USER_LOW_LIMIT/Pmin ALARM WINDOW parameter. – Loose connection at sensor cable.	– Check system/pressure measured value. – Change value for PRESSURE_1_USER_LOW_LIMIT/Pmin ALARM WINDOW if necessary. – Wait a short period of time and tighten the connection, or avoid loose connection.	55
731	Alarm/ Warning	S>Pmax ALARM WINDOW (PRESSURE_1_USER_HIGH_LIMIT) overshoot	19	0	– Pressure measured value has overshoot the value specified for the PRESSURE_1_USER_HIGH_LIMIT/Pmax ALARM WINDOW parameter.	– Check system/pressure measured value. – Change value for PRESSURE_1_USER_HIGH_LIMIT/Pmax ALARM WINDOW if necessary.	54
732	Alarm/ Warning	S>Tmin ALARM WINDOW (TEMPERATURE_1_USER_LOW_LIMIT) undershot	19	0	– Temperature measured value has undershot the value specified for the TEMPERATURE_1_USER_LOW_LIMIT/Tmin ALARM WINDOW parameter. – Loose connection at sensor cable.	– Check system/temperature measured value. – Change value for TEMPERATURE_1_USER_LOW_LIMIT/Tmin ALARM WINDOW if necessary. – Wait a short period of time and tighten the connection, or avoid loose connection.	57
733	Alarm/ Warning	S>Tmax ALARM WINDOW (TEMPERATURE_1_USER_HIGH_LIMIT) overshoot	19	0	– Temperature measured value has overshoot the value specified for the TEMPERATURE_1_USER_HIGH_LIMIT/Tmax ALARM WINDOW parameter.	– Check system/temperature measured value. – Change value for TEMPERATURE_1_USER_HIGH_LIMIT/Tmax ALARM WINDOW if necessary.	56

12.3 Response of outputs to errors

The device makes a distinction between the message types "Alarm", "Warning" and "Error".
→ See the following table and → 224, Section 12.1 "Messages".

Output	A (Alarm)	W (Warning)	E (Error: Alarm/Warning)
FOUNDATION Fieldbus	The process variable in question is transmitted with the status BAD.	Device continues measuring. The process variable in question is transmitted with the status UNCERTAIN.	For this error, you can enter whether the device should react as in the event of an alarm or as in the event of a warning. See corresponding "Alarm" or "Warning" column. (→ 96 and → 222, parameter description for Select Alarmtype/ SELECT_ALARM_TYPE) The GOOD status can also be assigned to the individual error via the parameters FF912_STATUS_SELECT_1 to FF912_STATUS_SELECT_131.
Local operation	- The measured value and message are displayed alternately - Measured value display:  -symbol is permanently displayed. Message display - A + 3-digit number such as A122 and - Description	- The measured value and message are displayed alternately - Measured value display:  -symbol flashes. Message display: - W + 3-digit number such as W613 and - Description	- The measured value and message are displayed alternately - Measured value display: see corresponding "Alarm" or "Warning" column Message display: - E + 3-digit number such as E731 and - Description
Remote operation (FF configuration program/FieldCare)	In the event of an alarm, the ALARM STATUS/ALARM STATUS parameter ¹⁾ displays a 3-digit number such as 122 for "Sensor connection error, incorrect data."	In the event of a warning, the ALARM STATUS/ALARM STATUS ² parameter displays a 3-digit number such as 613 for "Simulation is active".	In the event of an error, the ALARM STATUS/ALARM STATUS ² parameter displays a 3-digit number such as 731 for "Pmax ALARM WINDOW undershot".

1) FF configuration program: Diagnostic Transducer Block. Menu path FieldCare: OPERATING MENU → MESSAGES

12.3.1 Analog Input Block

If the Analog Input Block receives an input or simulation value with the status BAD, the Analog Input Block uses the failsafe mode defined in the Fsafe_Type/FSAFE_TYPE¹ parameter.

The following options are available by means of the Fsafe_Type/FSAFE_TYPE parameter:

- Last Good Value
The last valid value is used for further processing with the status UNCERTAIN.
- Fail SafeValue
The value specified by means of the Fsafe_Value/FSAFE_VALUE¹ parameter is used for further processing with the status UNCERTAIN.
- Wrong Value
The current value is used for further processing with the status BAD.

Factory setting:

- Fsafe_Type/FSAFE_TYPE: FsafeValue
- Fsafe_Value/FSAFE_VALUE: 0

The failsafe mode is also activated if the "Out of service" option was selected by means of the Block Mode/MODE_BLK parameter, "Target" element.

1 These parameters are not available by means of the FieldCare operating program.

12.4 Confirming messages

Depending on the settings for the Alarm Displ. Time/ALARM_DISPLAY_TIME and Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE parameters, the following measures should be taken to clear a message:


Settings ¹⁾	Measures
- Alarm Displ. Time/ ALARM_DISPLAY_TIME = 0 s - Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = Off	- Rectify the cause of the message (see also Section 12.1).
- Alarm Displ. Time/ ALARM_DISPLAY_TIME > 0 s - Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = Off	- Rectify the cause of the message (see also Section 12.1). - Wait for the alarm display time to elapse.
- Alarm Displ. Time/ ALARM_DISPLAY_TIME = 0 s - Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = On	- Rectify the cause of the message (see also Section 12.1). - Confirm message using ACKNOWLEDGE_ALARM/ACK. ALARM parameter.
- Alarm Displ. Time/ ALARM_DISPLAY_TIME > 0 s - Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE = On	- Rectify the cause of the message (see also Section 12.1). - Confirm message using ACKNOWLEDGE_ALARM/ACK. ALARM parameter. - Wait for the alarm display time to elapse. If a message appears and the alarm display time elapses before the message has been acknowledged, the message is cleared once it has been acknowledged.

1) FF configuration program: The parameters are in the Diagnostic Transducer Blocks.
FieldCare: Menu path for Alarm Displ. Time/ALARM_DISPLAY_TIME and Ack. Alarm Mode/ACKNOWLEDGE_ALARM_MODE: OPERATING MENU → DIAGNOSTICS → MESSAGES

13 Appendix

13.1 Operating menu

- The entire menu is depicted on the following pages.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. the "LINEARIZATION" function group for the "Level" measuring mode.
- In addition, there are also parameters that are only displayed if other parameters are appropriately configured. For example the Customer Unit P/CUSTOMER_UNIT_PRESSURE parameter is only displayed if the "User unit" option was selected for the Press. Eng. Unit/parameter. These parameters are indicated with a "*".
- For a description of the parameters, see Section 11 "Parameter description (local operation and FieldCare)". The exact dependency of individual parameters on one another is explained here.




1) Display via on-site display only

2) Display via FieldCare

3) Cerabar S with gauge pressure sensor, Deltabar S or Deltapilot S

4) Cerabar S with absolute pressure sensor

* There are parameters that are only displayed if other parameters are appropriately configured.
For example the Customer Unit P/CUSTOMER_UNIT_PRESSURE parameter is only displayed if the "User unit" option was selected for the Press. Eng. Unit/PRESSURE UNIT parameter.
These parameters are indicated with a "**".



2) Display via FieldCare

★ There are parameters that are only displayed if other parameters are appropriately configured.
For example the Customer Unit P/CUSTOMER_UNIT_PRESSURE parameter is only displayed if the "User unit" option was selected for the Press. Eng. Unit/PRESSURE_UNIT parameter.
These parameters are indicated with a "★".

Continuation
BASIC SETUP "Level",
see also the previous page

**LEVEL SELECTION =
Level Standard**

PRESS. ENG. UNIT

CUSTOMER UNIT P

CUST. UNIT FACT. P

LEVEL MODE

Linear

LIN. MEASURAND

Ⓒ

Ⓓ

CALIBRATION MODE

Wet

EMPTY CALIB.

EMPTY PRESSURE

FULL CALIB.

FULL PRESSURE

ADJUSTED DENSITY

Dry

DENSITY UNIT

ADJUST DENSITY

VOLUME UNIT *

CUSTOMER UNIT V *

CUST. UNIT FACT. V *

TANK VOLUME *

HEIGHT UNIT *

CUSTOMER UNIT H *

CUST. UNIT FACT. H *

TANK HEIGHT *

100% POINT *

ZERO POSITION *

DAMPING VALUE

Pressure
Linearized

LINd MEASURAND

Ⓔ

Ⓕ

HYDR. PRESS MIN.

HYDR. PRESS MAX.

DAMPING VALUE

Height
Linearized

COMB. MEASURAND

Ⓖ

Ⓗ

Ⓔ

Ⓕ

LEVEL MIN

LEVEL MAX

CALIBRATION MODE

Wet

EMPTY CALIB.

EMPTY PRESSURE

FULL CALIB.

FULL PRESSURE

ADJUSTED DENSITY *

Dry

DENSITY UNIT

ADJUST DENSITY

HEIGHT UNIT *

CUSTOMER UNIT H *

CUST. UNIT FACT. H *

100% POINT *

ZERO POSITION *

DAMPING VALUE

Ⓒ

Height

HEIGHT UNIT

CUSTOMER UNIT H *

CUST. UNIT FACT. H *

Ⓓ

Volume

UNIT VOLUME

CUSTOMER UNIT V *

CUST. UNIT FACT. V *

Ⓓ

Mass

MASS UNIT

CUSTOMER UNIT M *

CUST. UNIT FACT. M *

Ⓓ

%

Ⓓ

Ⓔ

% Volume

UNIT VOLUME

CUSTOMER UNIT V *

CUST. UNIT FACT. V *

Ⓕ

Mass

MASS UNIT

CUSTOMER UNIT M *

CUST. UNIT FACT. M *

Ⓕ

%

Ⓕ

Ⓖ

Height+...

HEIGHT UNIT

CUSTOMER UNIT H *

CUST. UNIT FACT. H *


Ⓗ

%Height+...


Ⓗ

* There are parameters that are only displayed if other parameters are appropriately configured.

For example the Customer Unit H/CUSTOMER_HEIGHT_UNIT parameter is only displayed if the "User unit" option was selected for the Height Unit/HEIGHT_UNIT parameter. These parameters are indicated with a "***".




* There are parameters that are only displayed if other parameters are appropriately configured.
For example the Tot. 1 User Unit/CUSTOMER_UNIT_TOT_1 parameter is only displayed if the "User unit" option was selected for the Totalizer 1 Unit/TOTALIZER_1_UNIT parameter.
These parameters are indicated with a "*".





1) Display via on-site display only

2) Display via FieldCare



★ There are parameters that are only displayed if other parameters are appropriately configured. These parameters are indicated with a "★".



★ There are parameters that are only displayed if other parameters are appropriately configured. These parameters are indicated with a "★".

Index

Numerics

100% Point.....	72
100% POINT (813), "Height linearized" level mode. . .	190
100% POINT (813), "Linear" level mode	178

A

Acc. Of Gravity	84
ACCELERATION_OF_GRAVITY.....	84
ACK_OPTION.....	47, 110
Ack. Alarm	96
ACK. ALARM (500).....	221
Ack. Alarm Mode.....	95
ACK. ALARM MODE (401)	221
ACKNOWLEDGE ALARM.....	96
Acknowledge Option.....	47, 110
ACKNOWLEDGE_ALARM_MODE	95
ACTIV LIN. TAB. X, FieldCare	205
ACTIV LIN. TAB. Y, FieldCare.....	205
Adjust Density	70, 78
ADJUST DENSITY (007), "Level easy height" level selection 165	
ADJUST DENSITY (007)/(316), "Level" extended setup	198
ADJUST DENSITY (316), "Height linearized" level mode. . . 189	
ADJUST DENSITY (316), "Linear" level mode	175
ADJUST_DENSITY	70
ADJUST_DENSITY_EASY	78
ADJUSTED DENSITY (810), "Height linearized" level mode 188	
ADJUSTED DENSITY (810), "Linear" level mode.....	175
AI 1 OUT Value (983).....	217
AI 2 OUT Value (982).....	217
AI 3 OUT Value (981).....	217
Alarm Delay	96
ALARM DELAY (336).....	222
Alarm Displ. Time	97
ALARM DISPL. TIME (480)	222
Alarm History.....	98
Alarm Hysteresis	110
Alarm messages.....	224
Alarm Output Discrete	114
ALARM STATUS (046).....	221
Alarm Status Info.....	95
Alarm Summary.....	109
ALARM_DELAY.....	96
ALARM_DISPLAY_TIME	97
ALARM_HYS	110
ALARM_MODE	114
ALARM_STATUS.....	95
ALARM_STATUS_WITH_CATEGORY	95
ALARM_SUM	109
Alert Key.....	42, 54, 104
ALERT_KEY	42, 54, 104
Allowed Max. Temp	80
ALLOWED MAX. TEMP (359).....	211
Allowed Min. Temp.....	80

ALLOWED MIN. TEMP (358)	211
ALM_OUT_D.....	114
Alternate Data.....	93
ALTERNATE DATA (423)	209

B

Block Alarm	46, 55, 109
Block configuration, delivery status	40
Block Error	42, 54, 105
Block Error Desc.....	51
Block Error Description.....	114
Block Mode	42, 54, 104
BLOCK_ALM	46, 55, 109
BLOCK_ERR.....	42, 54, 105
BLOCK_ERR_DESC_1.....	51, 114

C

CAL_MIN_SPAN.....	57
CAL_POINT_HI	56-57
CAL_POINT_LO.....	57
CAL_UNIT	57
Calib. Offset	63
CALIB. OFFSET (319).....	156
Calibration Highest Point	56-57
Calibration Lowest Point	57
Calibration Minimum Span	57
Calibration Mode.....	70, 77
CALIBRATION MODE (008), "Level easy height" level selec- tion	165
CALIBRATION MODE (008), "Level easy pressure" level se- lection	161
CALIBRATION MODE (392), "Height linearized" level mode 188	
CALIBRATION MODE (392), "Linear" level mode	174
Calibration Units	57
CALIBRATION_MODE	70
CALIBRATION_MODE_EASY	77
CALIBRATION_OFFSET	63
Capability Level	48
CAPABILITY_LEVEL.....	48
CHANNEL.....	107
Channel	107
Clear Fault State	45
CLR_FSTATE	45
Collection Directory.....	55
COLLECTION_DIRECTORY.....	55
Comb. Measurand	66-67
COMB. MEASURAND (806)	184
COMBINED_MEASURAND	66-67
Config Recorder.....	80
CONFIG RECORDER (352)	210
CONFIGURATION_COUNTER	80
Confirm Time.....	46
CONFIRM_TIME	46
Corrected Press.....	83
CORRECTED PRESS. (434), "Flow" measuring mode..	216
CORRECTED PRESS. (434), "Level" measuring mode .	215

CORRECTED PRESS. (434), "Pressure" measuring mode ...	215
CORRECTED_PRESSURE	83
COUNTER	
P > Pmax (380)	217
T > Tmax (404)	217
Counter	
P > Pmax	81
Counter P	81
COUNTER P Pmin (467)	217
Counter T	82
Counter T > Tmax	81
COUNTER T Tmin (472)	217
COUNTER_PMAX	81
COUNTER_PMIN	81
COUNTER_TMAX	81
COUNTER_TMIN	82
Creep Flow Hyst	84
CREEP_FLOW_HYST	84
Cust. Unit Fact. F	88
CUST. UNIT FACT. F (609)	196
CUST. UNIT FACT. H (705), "Height linearized" level mode	
185, 190	
CUST. UNIT FACT. M (703), "Height linearized" level mode	
187	
CUST. UNIT FACT. M (703), "Pressure linearized" level	
mode	182
CUST. UNIT FACT. P (317)	158, 160, 164, 169, 194
CUST. UNIT FACT. V (607), "Height linearized" level mode.	
186	
CUST. UNIT FACT. V (607), "Pressure linearized" level mode	
181	
Cust. Unit. Fact. H	67–68
CUST. UNIT. FACT. H (705), "Linear" level mode	172, 177
Cust. Unit. Fact. M	69
CUST. UNIT. FACT. M (703), "Linear" level mode	174
Cust. Unit. Fact. P	64
Cust. Unit. Fact. V	68
CUST. UNIT. FACT. V (607), "Linear" level mode	173, 176
Customer Unit F	88
CUSTOMER UNIT F (610)	196
Customer Unit H	67
CUSTOMER UNIT H (706), "Height linearized" level mode .	
185, 190	
CUSTOMER UNIT H (706), "Linear" level mode. .	171, 177
Customer Unit M	69
CUSTOMER UNIT M (704), "Height linearized" level mode.	
187	
CUSTOMER UNIT M (704), "Linear" level mode	173
CUSTOMER UNIT M (704), "Pressure linearized" level mode	
181	
Customer Unit P	64
CUSTOMER UNIT P (075)	158, 160, 164, 168, 193
Customer Unit V	68
CUSTOMER UNIT V (608), "Height linearized" level mode .	
186	
CUSTOMER UNIT V (608), "Linear" level mode. .	172, 176
CUSTOMER UNIT V (608), "Pressure linearized" level mode	
180	

CUSTOMER_FACTOR_UNIT_PRESS	64
CUSTOMER_HEIGHT_UNIT	67
CUSTOMER_UNIT_FACTOR_FLOW	88
CUSTOMER_UNIT_FACTOR_HEIGHT	67–68
CUSTOMER_UNIT_FACTOR_MASS	69
CUSTOMER_UNIT_FACTOR_TOT_1	91
CUSTOMER_UNIT_FACTOR_TOT_2	92
CUSTOMER_UNIT_FACTOR_VOLUME	68
CUSTOMER_UNIT_FLOW	88
CUSTOMER_UNIT_MASS	69
CUSTOMER_UNIT_PRESSURE	64
CUSTOMER_UNIT_TOT_1	91
CUSTOMER_UNIT_TOT_2	91
CUSTOMER_UNIT_VOLUME	68
Cycle Selection	44
Cycle Type	44
CYCLE_SEL	44
CYCLE_TYPE	44

D

Damping Value	62
DAMPING VALUE (247) .	153–154, 158, 162, 167, 178, 182, 191, 196
DAMPING VALUE (274)	150
DAMPING_VALUE	62
DD Resource	43
DD Revision	43
DD REVISION (985)	213
DD_RESOURCE	43
DD_REV	43
Density Unit	66, 77
DENSITY UNIT (001), "Level easy height" level selection .	
165	
DENSITY UNIT (001)/(812), "Level" extended setup .	198
DENSITY UNIT (812), "Height linearized" level mode .	189
DENSITY UNIT (812), "Linear" level mode	175
DENSITY_UNIT	66
DENSITY_UNIT_EASY	77
DEV_REV	43
DEV_TYPE	43
DEVICE ADDRESS (984)	213
DEVICE DESIGN. (350)	210
Device Dialog	52, 60, 79, 86, 92–93
DEVICE ID (987)	213
Device Revision	43
DEVICE REVISION (986)	213
DEVICE SERIAL No (354)	210
Device Tag	48
Device Type	43
DEVICE_DIALOG	52, 60, 79, 86, 92–93
DEVICE_TAG	48
Digits Set	93
DIP STATUS (363)	211
Display Contrast	93
DISPLAY CONTRAST (339)	209
DISPLAY_ALTERNATING_VALUES	93
DISPLAY_CONTRAST	93
DISPLAY_LANGUAGE	93
DISPLAY_MAINLINE_CONTENT	92

DISPLAY_MAINLINE_FORMAT	92	FACT. U.U. TOTAL.1	92
Download Select.	85	Fail Safe Mode	90
DOWNLOAD SELECT (014)	219	FAIL SAFE TYPE	113
DOWNLOAD_SELECTION	85	Fault State	45
E		FAULT_STATE	45
Edit Table	73	Feature Selection	44
Editor Table	73	FEATURE_SEL	44
EDITOR TABLE (770), local operation	202	FEATURES	44
EDITOR TABLE (809), local operation	201	Features	44
EDITOR TABLE, FieldCare	204–205	FF Comm. Version	51
ELECTR. SERIAL No (386)	210	FF_COMM_VERSION	51
Electr. Serial No.	52	FF912_CONFIG_AREA	99
ELECTRONIC_OVER_TEMP_COUNTER	82	FF912_STATUS_SELECT1	99
ELECTRONIC_OVER_TEMPERATURE	82	FF912_STATUS_SELECT10	102
ELECTRONIC_SERIAL_NUMBER	52	FF912_STATUS_SELECT11	103
ELECTRONIC_UNDER_TEMP_COUNTER	82	FF912_STATUS_SELECT12	103
ELECTRONIC_UNDER_TEMPERATURE	82	FF912_STATUS_SELECT13	103
ELECTRONICS_TEMP_HIGH_LIMIT	80	FF912_STATUS_SELECT2	100
ELECTRONICS_TEMP_LOW_LIMIT	80	FF912_STATUS_SELECT3	100
ELECTRONICS_TEMPERATURE	80	FF912_STATUS_SELECT4	100
Empty Calib.	71	FF912_STATUS_SELECT5	101
EMPTY CALIB. (010), "Level easy height" level selection ..	166	FF912_STATUS_SELECT6	101
EMPTY CALIB. (010), "Level easy pressure" level selection	161–162	FF912_STATUS_SELECT7	101
EMPTY CALIB. (314), "Height linearized" level mode .	188	FF912_STATUS_SELECT8	102
EMPTY CALIB. (314), "Linear" level mode	174	FF912_STATUS_SELECT9	102
EMPTY CALIB. (314)/(010), QUICK SETUP	152	FF912ConfigArea	99
Empty Calib. Level Easy	79	Field Value	108
Empty Height Level Easy	78	FIELD_VALUE	108
EMPTY HEIGHT. (009), "Level easy height" level selection.	166	FILLING FLUID (366)	213
EMPTY PRESSURE (011), "Level easy pressure" level selec-	162	Firmware Version	48
tion	162	FIRMWARE_VERSION	48
EMPTY PRESSURE (710)	188	Flow Max	89
EMPTY PRESSURE (710), "Height linearized" level mode .	188	FLOW_MAX	89
EMPTY PRESSURE (710), "Linear" level mode	174	FLOW_MEAS_TYPE	86
Empty Pressure Level Easy	79	Flow-Meas. Type	86
EMPTY_CALIBRATION	71	FLOW-MEAS. TYPE (640)	194
EMPTY_CALIBRATION_EASY	79	Free Space	45
EMPTY_HEIGHT_EASY	78	Free Time	45
EMPTY_PRESSURE_EASY	79	FREE_SPACE	45
ENP Version	48	FREE_TIME	45
ENP_VERSION	48	Fsafe Type	113
Enter Reset Code	98	FSAFE_TYPE	113
ENTER RESET CODE (047)	219	FSAFE_VALUE	113
ENTER_RESET_CODE	98	Fsafe_Value	113
Error messages	224	FULL CALIB. (004), "Level easy height" level selection	166
ERROR NO.	222	FULL CALIB. (004), "Level easy pressure" level selection ..	162
Error No.	96	FULL CALIB. (315), "Height linearized" level mode . .	188
ERROR_NUMBER	96	FULL CALIB. (315), "Linear" level mode	175
F		FULL CALIB. (315)/(004), QUICK SETUP	153
Fact. U. U. Total 1	91	Full Calib. Level Easy	71, 78
Fact. U. U. Total. 2	92	FULL HEIGHT (006), "Level easy height" level selection . .	167
FACT. U.U. TOTAL 2 (330)	208	Full Height Level Easy	78
FACT. U.U. TOTAL. 1 (329)	207	FULL PRESSURE (005), "Level easy pressure" level selection	162
		FULL PRESSURE (711), "Height linearized" level mode	188
		FULL PRESSURE (711), "Linear" level mode	175
		Full Pressure Level Easy	79

FULL_CALIBRATION	71
FULL_CALIBRATION_EASY	78
FULL_HEIGHT_EASY	78
FULL_PRESSURE_EASY	79

G

Grant Deny	43, 107
GRANT_DENY	43, 107

H

Hard Types	43
HARD_TYPES	43
Hardware Rev.	51
HARDWARE REV. (266)	210
HARDWARE_REVISION	51
Height Unit	66–67, 77
HEIGHT UNIT (003), "Level easy height" level selection ...	165
HEIGHT UNIT (708), "Height linearized" level mode .	184, 189
HEIGHT UNIT (708), "Linear" level mode	171, 177
HEIGHT_UNIT	66–67
HEIGHT_UNIT_EASY	77
Hi Trim Measured	64
HI_ALM	112
HI_ALM_OUT_D	113
HI_HI_ALM	112
HI_HI_LIM	111
HI_HI_PRI	111
HI_LIM	111
HI_PRI	111
High Alarm	112
High Alarm Output Discrete	113
High High Alarm	112
High High Alarm Output Discrete	113
High High Limit	111
High High Priority	111
High Limit	111
High Priority	111
HIGH_TRIM_MEASURED	64
HIGHEST_CATEGORY	98
HIHI_ALM_OUT_D	113
Hist. Saving Cycle	84
HistoROM Avail.	84
HistoROM AVAIL. (831)	219
Historom Control	85
HistoROM CONTROL (832)	219
HISTOROM_AVAILABLE	84
HISTOROM_CONTROL	85
HISTOROM_SAVING_CYCLE_TIME	84
HUNDRED_PERCENT_VALUE	72
HYDR. PRESS MAX. (774)	182
HYDR. PRESS MIN. (773)	182

I

I/O Options	107
Inp. Press. Ivers	85
INPUT_PRESSURE_INVERSION	85
INSERT PIN NO (048)	219
Insert Pin No.	49, 60, 79, 86, 94

IO_OPTS	107
ITK_VER	47
ITK-Version	47

L

L_TYPE	108
LANGUAGE	209
Language	93
LANGUAGE (079)	146
LAST DIAG. CODE	96
LAST DIAG. CODE (564)	221
Last Diag. Code Info	95
LAST_DIAGNOSTIC_CODE_WITH_CATEGORY	95
LAST_DIAGNOSTIC_CODE	95–96
Level Before Lin.	75
LEVEL BEFORE LIN (050)	216
Level Max.	72
LEVEL MAX (712)	187
LEVEL MIN (755)	187
Level Min.	72
Level Mode	65
LEVEL MODE (718)	169
Level Selection	76
LEVEL SELECTION (020)	148, 151
LEVEL_BEFORE_LINEARISATION	75
LEVEL_MAX	72
LEVEL_MIN	72
LEVEL_MODE	65
LEVEL_SELECTION	76
LEVEL_TANK_DESCRIPTION	75
LIM_NOTIFY	45
Limit Notify	45
LIN. EDIT MODE (397), local operation	201
LIN. EDIT MODE, FieldCare	204
Lin. Measurand	65
LIN. MEASURAND (804)	171
Lind. Measurand	65
LINd. MEASURAND. (805)	180
LINEAR_MEASURAND	65
LINEARIZATION	61–62
Linearization	61–62
Linearization Type	108
LINEARIZATION_EDIT_MODE	73
LINEARIZATION_TABLE_INDEX	73
LINEARIZATION_TABLE_POST_EDIT	74
LINEARIZATION_TABLE_PRE_EDIT	73
LINEARIZATION_TABLE_SELECTION	73
LINEARIZATION_TABLE_X_VALUE	73–74
LINEARIZATION_TABLE_Y_VALUE	74
LINEARIZATION_TABLE_POST_VIEW	74
LINEARIZED_MEASURAND	65
LINE-NUMB (549), local operation	201–202
LINE-NUMB, FieldCare	204
Line-Number	73
Lo Trim Measured	64
LO_ALM	112
LO_ALM_OUT_D	113
LO_LIM	111

LO_LO_ALM	112
LO_LO_LIM	112
LO_LO_PRI	112
LO_PRI	111
LOLO_ALM_OUT_D	113
Low Alarm	112
Low Alarm Output Discrete	113
Low Cutoff	108
Low Flow Cut-Off.	88
LOW FLOW CUT-OFF (442)	199
Low Limit	111
Low Low Alarm	112
Low Low Alarm Output Discrete	113
Low Low Limit	112
Low Low Priority	112
Low Priority	111
LOW_CUT.	108
LOW_FLOW_CUT_OFF	88
LOW_TRIM_MEASURED	64

M

Main Data Format	92
MAIN DATA FORMAT (688)	209
Main Line Cont.	92
MANUFAC_ID	43
Manufacturer ID	43
MASS FLOW UNIT (571)	195
MASS UNIT (709), "Height linearized" level mode ...	186
MASS UNIT (709), "Linear" level mode	173
MASS UNIT (709), "Pressure linearized" level mode ..	181
MASS_UNIT	69
MAT_PROC_CONN_NEG	52
MAT_PROC_CONN_POS	52
MAT. MEMBRANE (365)	213
Mat. Proc. Conn. -	52
MAT. PROC. CONN. - (361)	212
Mat. Proc. Conn. +	52
MAT. PROC. CONN. + (360)	212
Max Notify	45
Max Press. Flow.	89
MAX PRESS. FLOW (634)	154, 196
MAX_MEASURED_PRESSURE	81
MAX_MEASURED_TEMP	82
MAX_PRESS_FLOW	89
MAX. FLOW (311)	154, 196
Max. meas. press.	81
MAX. MEAS. PRESS. (383)	217
Max. meas. temp.	82
MAX. MEAS. TEMP. (471)	217
Max. Turndown	84
Meas. Level Easy	78
Meas. Val. Trend	83
MEAS. VAL. TREND (378)	215–216
MEASURED VALUE (679), "Flow" measuring mode ..	216
MEASURED VALUE (679), "Level" measuring mode ..	215
MEASURED VALUE (679), "Pressure" measuring mode...	214
MEASURED_LEVEL_EASY	78
MEASURED_VALUE_TREND	83

MEASURING MODE	149, 151, 154, 157, 168, 193
MEASURING MODE (389), local operation	147
Measuring Table	74
MEASURING TABLE (549), local operation	202
MEASURING TABLE (717), local operation	202
Memory Size	44
MEMORY_SIZE	44
MENU DESCRIPTOR (416)	208
MIN_CYCLE_T	44
MIN_MEASURED_PRESSURE	81
MIN_MEASURED_TEMP	82
Min. meas. press.	81
MIN. MEAS. PRESS. (469)	217
Min. meas. temp.	82
MIN. MEAS. TEMP. (474)	217
Minimum Cycle Time	44
MINIMUM SPAN (591)	212
MODE_BLK	42, 54
MODE_BLK (AI Block)	104–105
MS_RESOURCE_DIRECTORY	53

N

NEG. FLOW TOT. 1	91
Neg. Flow Tot. 1	90
NEG. FLOW TOT. 1 (400)	207
NEG. FLOW TOT. 2 (416)	208
Neg. Flow. Tot. 2	91
Nonvolatile Cycle Time	44
NORM FLOW UNIT (661)	195
NV_CYCLE_T	44

O

Operating Hours	98
OPERATING HOURS (409)	219
OPERATING_HOURS	98
Order Code	48
ORDER_CODE	48
OUT	105
OUT_SCALE	107
Output	105
Output Scale	107
OUTPUT UNIT (023), "Level easy height" level selection ..	165
OUTPUT UNIT (023), "Level easy pressure" level selection	161
Output Unit Level Easy	77
OUTPUT_UNIT_EASY	77

P

P Peakhold Step	84
PCB COUNT	
T > Tmax (488)	217
PCB COUNT T	218
Pcb Count T	82
Pcb Count T > Tmax	82
Pcb Max. Temp	82
PCB MAX. TEMP. (490)	218
Pcb Min. Temp.	82
PCB MIN. TEMP. (494)	218
PCB TEMPERATURE (357)	211

Pcb. Temperature	80
PD-TAG	210
Pmax ALARM WINDOW (333)	223
Pmax PROC. CONN. (570)	211
PMAX_ALARM_WINDOW	97
PMAX_PROC_CONN	80
Pmax. Proc. Conn.	80
Pmaxalarm Window	97
Pmin ALARM WINDOW (322)	223
PMIN_ALARM_WINDOW	97
Pminalarm Window	97
Pos. Input Value	63
POS. INPUT VALUE (563)	150, 152, 156
POS. ZERO ADJUST	194
Pos. Zero Adjust	63
POS. ZERO ADJUST (685)	150, 152, 154–155
POSITION_INPUT_VALUE	63
Press. Eng. Unit.	85, 89, 97
PRESS. ENG. UNIT (060)	157, 160, 164, 168, 193
PRESS. SENS HILIM (485)	212
PRESS. SENS LOLIM (484)	212
PRESSURE	75, 89
Pressure	75, 83, 89
PRESSURE (301), "Flow" measuring mode	216
PRESSURE (301), "Level" measuring mode	215
PRESSURE (301), "Pressure" measuring mode	215
PRESSURE_PEAK_HOLD_STEP	84
PRESSURE_UNIT	85, 89, 97
Primary Value	56
Primary Value Range	56
Primary Value Type	56, 61
PRIMARY_VALUE	56
PRIMARY_VALUE_RANGE	56
PRIMARY_VALUE_TYPE	56, 61
Proc. Conn. Type	52
PROC. CONN. TYPE (482)	211
Process Density	72, 78
PROCESS DENSITY (025)/(811)	198
Process Value	105
Process Value Filter Time	108
PROCESS_CONNECTION_TYPE	52
PROCESS_DENSITY	72
PROCESS_DENSITY_EASY	78
PV	105
PV_FTIME	108

Q

Quick Setup "Flow" menu	153
Quick Setup "Level" menu	151
Quick Setup "Pressure" menu	149

R

Reset All Alarms	96
RESET ALL ALARMS (603)	221
Reset Peakhold	83
RESET PEAKHOLD (382)	218
Reset Totalizer 1	90
RESET TOTALIZER1 (331)	207
RESET_ALL_ALARMS	96

RESET_PEAK_HOLD	83
Resource Directory	53
Resource State	42
RESTART	44
Restart	44
RS_STATE	42

S

Scale In	61
Scale Out	62
SCALE_OUT	62
SCALE_OUT_UNITS_INDEX	94
SCI_OCTET_STR	53
SCI_OCTET_STRING	53
Seal Type	53
SEAL TYPE (362)	212
SEAL_TYPE	53
SECONDARY_VALUE_UNIT	60
Select Alarm Mode	114
Select Alarm Type	96
SELECT ALARMTYPE (595), (600)	222
SELECT_ALARM_TYPE	96
Selecting the language	115
Selecting the measuring mode	115
Sens H/Ware Rev	81
SENS H/WARE REV (487)	213
Sensor Calibration Date	59
Sensor Calibration Location	59
Sensor Calibration Method	59
Sensor Calibration Who	59
Sensor Changes	84
Sensor Fill Fluid	59
Sensor Isolator Metal	59
Sensor Meas. Type	75, 80
SENSOR MEAS.TYPE (581)	213
Sensor Pressure	75
SENSOR PRESSURE (584), "Flow" measuring mode ..	216
SENSOR PRESSURE (584), "Level" measuring mode ..	215
SENSOR PRESSURE (584), "Pressure" measuring mode ...	215
Sensor Range	58
SENSOR SER. No. (250)	212
Sensor Serial Number	59
SENSOR TEMP. (367)	215–216
Sensor Type	58
SENSOR_CAL_DATE	59
SENSOR_CAL_LOC	59
SENSOR_CAL_METHOD	59
SENSOR_CAL_WHO	59
SENSOR_CHANGES	84
SENSOR_FILL_FLUID	59
SENSOR_HARDWARE_REV	81
SENSOR_ISOLATOR_MTL	59
SENSOR_MEAS_TYPE	75, 80
SENSOR_PRESSURE	75
SENSOR_RANGE	58
SENSOR_SN	59
SENSOR_TEMP_HIGH_LIMIT	80
SENSOR_TEMP_LOW_LIMIT	80

SENSOR_TYPE	58
Serial number	48
SERIAL_NUMBER	48
Set Fault State	45
SET_FSTATE	45
SET_LOW_FLOW_CUT_OFF	89
Set. L. Fl. Cut-Off	89
SET. L. FL. CUT-OFF (332)	199
Shed Remote Cascade	45
Shed Remote Out	45
SHED_RCAS	45
SHED_ROUT	45
SIL_DIGITS_TEST_STRING	93
Sim. Error No.	95
SIM. ERROR NO. (476)	221
SIM. FLOW VALUE (639)	220
SIM. LEVEL (714)	220
SIM. PRESSURE (414)	220
SIM. TANK CONT. (715)	220
SIMULATE	106
Simulated Value	95
SIMULATED_VALUE	95
SIMULATION MODE	95
Simulation Mode	94, 106
SIMULATION MODE (413)	220
SIMULATION_ERROR_NUMBER	95
SIMULATION_MODE	94–95, 106
SOFTWARE VERSION	210
ST_REV	42, 54
ST_REV (AI Block)	104
Static Revision	42, 54, 104
Status Locking	49, 60, 79, 86, 94
Status Options	107
Status Select Event 115	99
Status Select Event 120	100
Status Select Event 715	100
Status Select Event 717	100
Status Select Event 718	101
Status Select Event 720	101
Status Select Event 726	101
Status Select Event 727	102
Status Select Event 730	102
Status Select Event 731	102
Status Select Event 732	103
Status Select Event 733	103
Status Select Event 740	103
STATUS_HISTORY	98
STATUS_LOCKING	60, 79, 94
STATUS_OPTS	107
STD_FLOW_UNIT	87
STD. FLOW UNIT (660)	195
STRATEGY	42
Strategy	42, 54, 104
Suppressed Flow	86
SUPPRESSED FLOW (375)	216
SUPPRESSED_FLOW	86
SW_LOCK	49, 60, 79, 86, 94

T

T. Peakhold Step	84
Table Editor	74
Table Selection	73
TABLE SELECTION (808), local operation	200
TABLE SELECTION, FieldCare	203
Tag Description	42, 54, 104
TAG_DESC	42, 54
TAG_DESC (AI Block)	104
TANK CONTENT (370)	216
TANK CONTENT MAX (713), local operation	200
TANK CONTENT MAX, FieldCare	203
TANK CONTENT MIN (759), local operation	200
TANK CONTENT MIN, FieldCare	203
Tank Description	75
TANK DESCRIPTION (815), local operation	202
TANK DESCRIPTION, FieldCare	205
Tank Height	72
TANK HEIGHT (859)	177
Tank Volume	72
TANK VOLUME (858)	176
TANK_HEIGHT	72
TANK_VOLUME	72
TEMP_PEAK_HOLD_STEP	84
Temp. Eng. Unit	60, 85, 97
TEMP. ENG. UNIT (318), "Flow" measuring mode ...	199
TEMP. ENG. UNIT (318), "Level" measuring mode ...	197
TEMP. ENG. UNIT (318), "Pressure" measuring mode	197
Temperature	39, 60, 85, 97
TEMPERATURE_UNIT	85, 97
Test Read Write	43
TEST_RW	43
Tmax Alarm Window	97
Tmax ALARM WINDOW (335)	223
Tmax Sensor	80
Tmax SENSOR (369)	213
TMAX_ALARM_WINDOW	97
Tmin Alarm Window	97
Tmin ALARM WINDOW (334)	223
Tmin Sensor	80
Tmin SENSOR (368)	213
TMIN_ALARM_WINDOW	97
TOT. 1 USER UNIT	91
Tot. 1 User Unit	91
TOT. 1 USER UNIT (627)	207
Tot. 2 Unit Text	91
TOT. 2 USER UNIT (628)	208
TOTAL. 1 OVERFLOW (655)	216
Total. 2 Eng. Unit	91
TOTAL. 2 OVERFLOW (658)	217
Totalizer 1	90
TOTALIZER 1 (652)	216
Totalizer 1 Unit	90
TOTALIZER 1 UNIT (392), (662), (664), (666)	206
TOTALIZER 2	217
Totalizer 2	91
TOTALIZER 2 (657)	217
TOTALIZER 2 UNIT(399), (663), (665), (667)	207
TOTALIZER_1_FAIL_SAFE_MODE	90

TOTALIZER_1_MODE	90-91
TOTALIZER_1_RESET	90
TOTALIZER_1_UNIT	90
TOTALIZER_1_UNIT_SCALE	92
TOTALIZER_1_UNIT_TEXT	91
TOTALIZER_1_VALUE	90
TOTALIZER_2_MODE	91
TOTALIZER_2_UNIT	91
TOTALIZER_2_VALUE	91
Transducer Directory	55
Transducer Error	55
Transducer Scale	106
Transducer Type	55
TRANSDUCER_DIRECTORY	55
TRANSDUCER_TYPE	55
Troubleshooting	224

U

Unit Flow	87
UNIT_FLOW (391)	194
Unit Mass	69
Unit Volume	68
UNIT_VOLUME (313), "Height linearized" level mode .	185
UNIT_VOLUME (313), "Linear" level mode.	172, 176
UNIT_VOLUME (313), "Pressure linearized" level mode. ...	180
Units Index	94
Update Event	46, 55, 109
UPDATE_EVT	46, 55
UPDATE_EVT (AI Block)	109

V

Volume_UNIT	68
-------------------	----

W

Warnings	224
Write Alarm	47
Write Lock	46
Write Priority	47
WRITE_ALM	47
WRITE_LOCK	46
WRITE_PRI	47

X

XD_ERROR	55
XD_SCALE	106
X-VAL. (550), local operation	202
X-VAL., FieldCare	204
X-Value	73-74

Y

Y-VAL. (551), local operation	201-202
Y-VAL., FieldCare	205
Y-Value	74

Z

Zero Point	71
ZERO_POSITION (814), "Height linearized" level mode.	191
ZERO_POSITION (814), "Linear" level mode	178
ZERO_POSITION	71

ZERO_POSITION_ADJUST	63
----------------------------	----



www.addresses.endress.com
