


# Operating Instructions

## Proline Promag D 400

### Modbus RS485

Electromagnetic flowmeter





- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.



# Table of contents

<b>1</b>	<b>Document information</b>	<b>6</b>		
1.1	Document function	6		
1.2	Symbols used	6		
1.2.1	Safety symbols	6		
1.2.2	Electrical symbols	6		
1.2.3	Tool symbols	6		
1.2.4	Symbols for certain types of information	7		
1.2.5	Symbols in graphics	7		
1.3	Documentation	7		
1.3.1	Standard documentation	8		
1.3.2	Supplementary device-dependent documentation	8		
1.4	Registered trademarks	8		
<b>2</b>	<b>Basic safety instructions</b>	<b>9</b>		
2.1	Requirements for the personnel	9		
2.2	Designated use	9		
2.3	Workplace safety	10		
2.4	Operational safety	10		
2.5	Product safety	10		
2.6	IT security	11		
<b>3</b>	<b>Product description</b>	<b>12</b>		
3.1	Product design	12		
<b>4</b>	<b>Incoming acceptance and product identification</b>	<b>13</b>		
4.1	Incoming acceptance	13		
4.2	Product identification	13		
4.2.1	Transmitter nameplate	14		
4.2.2	Sensor nameplate	15		
4.2.3	Symbols on measuring device	15		
<b>5</b>	<b>Storage and transport</b>	<b>16</b>		
5.1	Storage conditions	16		
5.2	Transporting the product	16		
5.2.1	Measuring devices without lifting lugs	16		
5.2.2	Measuring devices with lifting lugs	17		
5.2.3	Transporting with a fork lift	17		
5.3	Packaging disposal	17		
<b>6</b>	<b>Installation</b>	<b>18</b>		
6.1	Installation conditions	18		
6.1.1	Mounting position	18		
6.1.2	Requirements from environment and process	20		
6.1.3	Special mounting instructions	22		
6.2	Mounting the measuring device	22		
6.2.1	Required tools	22		
6.2.2	Preparing the measuring device	22		
6.2.3	Mounting the sensor	22		
6.2.4	Mounting the transmitter of the remote version	25		
6.2.5	Turning the transmitter housing	27		
6.2.6	Turning the display module	29		
6.3	Post-installation check	30		
<b>7</b>	<b>Electrical connection</b>	<b>31</b>		
7.1	Connection conditions	31		
7.1.1	Required tools	31		
7.1.2	Requirements for connecting cable	31		
7.1.3	Terminal assignment	33		
7.1.4	Shielding and grounding	34		
7.1.5	Preparing the measuring device	34		
7.1.6	Preparing the connecting cable for the remote version	35		
7.2	Connecting the measuring device	36		
7.2.1	Connecting the remote version	36		
7.2.2	Connecting the transmitter	38		
7.2.3	Ensuring potential equalization	38		
7.3	Special connection instructions	40		
7.3.1	Connection examples	40		
7.4	Hardware settings	40		
7.4.1	Enabling the terminating resistor	40		
7.5	Ensuring the degree of protection	41		
7.5.1	Degree of protection IP66/67, Type 4X enclosure	41		
7.6	Post-connection check	41		
<b>8</b>	<b>Operation options</b>	<b>42</b>		
8.1	Overview of operation options	42		
8.2	Structure and function of the operating menu	43		
8.2.1	Structure of the operating menu	43		
8.2.2	Operating philosophy	44		
8.3	Access to the operating menu via the local display	45		
8.3.1	Operational display	45		
8.3.2	Navigation view	46		
8.3.3	Editing view	48		
8.3.4	Operating elements	50		
8.3.5	Opening the context menu	50		
8.3.6	Navigating and selecting from list	52		
8.3.7	Calling the parameter directly	52		
8.3.8	Calling up help text	53		
8.3.9	Changing the parameters	54		
8.3.10	User roles and related access authorization	55		
8.3.11	Disabling write protection via access code	55		
8.3.12	Enabling and disabling the keypad lock	55		



8.4	Access to the operating menu via the operating tool .....	56	12.2	Diagnostic information via light emitting diodes .....	85
8.4.1	Connecting the operating tool .....	56	12.2.1	Transmitter .....	85
8.4.2	FieldCare .....	57	12.3	Diagnostic information on local display .....	86
<b>9</b>	<b>System integration .....</b>	<b>58</b>	12.3.1	Diagnostic message .....	86
9.1	Overview of device description files .....	58	12.3.2	Calling up remedial measures .....	88
9.1.1	Current version data for the device ...	58	12.4	Diagnostic information in the Web browser ..	89
9.1.2	Operating tools .....	58	12.4.1	Diagnostic options .....	89
9.2	Modbus RS485 information .....	58	12.4.2	Calling up remedy information .....	89
9.2.1	Function codes .....	58	12.5	Diagnostic information in FieldCare .....	90
9.2.2	Register information .....	59	12.5.1	Diagnostic options .....	90
9.2.3	Response time .....	59	12.5.2	Calling up remedy information .....	91
9.2.4	Modbus data map .....	59	12.6	Diagnostic information via communication interface .....	91
<b>10</b>	<b>Commissioning .....</b>	<b>62</b>	12.6.1	Reading out diagnostic information ..	91
10.1	Function check .....	62	12.6.2	Configuring error response mode ....	91
10.2	Switching on the measuring device .....	62	12.7	Adapting the diagnostic information .....	92
10.3	Establishing a connection via FieldCare .....	62	12.7.1	Adapting the diagnostic behavior ....	92
10.4	Setting the operating language .....	62	12.8	Overview of diagnostic information .....	92
10.5	Configuring the measuring device .....	63	12.9	Pending diagnostic events .....	94
10.5.1	Defining the tag name .....	63	12.10	Diagnostic list .....	95
10.5.2	Setting the system units .....	64	12.11	Event logbook .....	95
10.5.3	Configuring the local display .....	65	12.11.1	Event history .....	95
10.5.4	Configuring the communication interface .....	67	12.11.2	Filtering the event logbook .....	96
10.5.5	Configuring the low flow cut off ....	68	12.11.3	Overview of information events .....	96
10.5.6	Configuring empty pipe detection ...	70	12.12	Resetting the measuring device .....	97
10.6	Advanced settings .....	71	12.12.1	Function scope of "Device reset" parameter .....	97
10.6.1	Carrying out a sensor adjustment ....	71	12.13	Device information .....	97
10.6.2	Configuring the totalizer .....	72	12.14	Firmware history .....	98
10.6.3	Carrying out additional display configurations .....	73	<b>13</b>	<b>Maintenance .....</b>	<b>99</b>
10.7	Simulation .....	75	13.1	Maintenance tasks .....	99
10.8	Protecting settings from unauthorized access .....	76	13.1.1	Exterior cleaning .....	99
10.8.1	Write protection via access code ....	76	13.1.2	Interior cleaning .....	99
10.8.2	Write protection via write protection switch .....	77	13.1.3	Replacing seals .....	99
<b>11</b>	<b>Operation .....</b>	<b>79</b>	13.2	Measuring and test equipment .....	99
11.1	Reading device locking status .....	79	13.3	Endress+Hauser services .....	99
11.2	Adjusting the operating language .....	79	<b>14</b>	<b>Repair .....</b>	<b>100</b>
11.3	Configuring the display .....	79	14.1	General notes .....	100
11.4	Reading measured values .....	79	14.2	Spare parts .....	100
11.4.1	Process variables .....	79	14.3	Endress+Hauser services .....	100
11.4.2	Totalizer .....	80	14.4	Return .....	100
11.5	Adapting the measuring device to the process conditions .....	80	14.5	Disposal .....	100
11.6	Performing a totalizer reset .....	80	14.5.1	Removing the measuring device ....	100
11.7	Showing data logging .....	81	14.5.2	Disposing of the measuring device ..	101
<b>12</b>	<b>Diagnostics and troubleshooting ...</b>	<b>84</b>	<b>15</b>	<b>Accessories .....</b>	<b>102</b>
12.1	General troubleshooting .....	84	15.1	Device-specific accessories .....	102
			15.1.1	For the transmitter .....	102
			15.1.2	For the sensor .....	102
			15.2	Service-specific accessories .....	102
			15.3	System components .....	103



**16 Technical data ..... 104**

16.1 Application ..... 104

16.2 Function and system design ..... 104

16.3 Input ..... 104

16.4 Output ..... 105

16.5 Power supply ..... 107

16.6 Performance characteristics ..... 108

16.7 Installation ..... 109

16.8 Environment ..... 109

16.9 Process ..... 110

16.10 Mechanical construction ..... 111

16.11 Operability ..... 116

16.12 Certificates and approvals ..... 117

16.13 Application packages ..... 118

16.14 Accessories ..... 119

16.15 Supplementary documentation ..... 119

**17 Appendix ..... 121**

17.1 Overview of the operating menu ..... 121

17.1.1 "Operation" menu ..... 121

17.1.2 "Setup" menu ..... 122

17.1.3 "Diagnostics" menu ..... 125

17.1.4 "Expert" menu ..... 129

**Index ..... 141**







# 1 Document information

## 1.1 Document function







These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

## 1.2 Symbols used




### 1.2.1 Safety symbols

Symbol	Meaning
 <b>DANGER</b>	<b>DANGER!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
 <b>WARNING</b>	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 <b>CAUTION</b>	<b>CAUTION!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
 <b>NOTICE</b>	<b>NOTE!</b> This symbol contains information on procedures and other facts which do not result in personal injury.

### 1.2.2 Electrical symbols












Symbol	Meaning	Symbol	Meaning
	Direct current		Alternating current
	Direct current and alternating current		<b>Ground connection</b> A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.		<b>Equipotential connection</b> A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.

### 1.2.3 Tool symbols





Symbol	Meaning
	Torx screwdriver
	Phillips head screwdriver
	Open-ended wrench





### 1.2.4 Symbols for certain types of information

Symbol	Meaning
	<b>Permitted</b> Procedures, processes or actions that are permitted.
	<b>Preferred</b> Procedures, processes or actions that are preferred.
	<b>Forbidden</b> Procedures, processes or actions that are forbidden.
	<b>Tip</b> Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Series of steps
	Result of a sequence of actions
	Help in the event of a problem
	Visual inspection

### 1.2.5 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3, ...	Item numbers		Series of steps
A, B, C, ...	Views	A-A, B-B, C-C, ...	Sections
	Hazardous area		Safe area (non-hazardous area)
	Flow direction		

## 1.3 Documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
  - The *W@M Device Viewer* : Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
  - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
-  For a detailed list of the individual documents along with the documentation code



### 1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	<b>Planning aid for your device</b> The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	<b>Guide that takes you quickly to the 1st measured value</b> The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.
Modbus RS485 register information	<b>Reference for Modbus RS485 register information</b> The document provides Modbus-specific information for each individual parameter in the operating menu.

### 1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

## 1.4 Registered trademarks

#### **Modbus®**

Registered trademark of SCHNEIDER AUTOMATION, INC.

#### **Microsoft®**

Registered trademark of the Microsoft Corporation, Redmond, Washington, USA

#### **Applicator®, FieldCare®, Field Xpert™, HistoROM®, Heartbeat Technology™**

Registered or registration-pending trademarks of the Endress+Hauser Group



## 2 Basic safety instructions

### 2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions

### 2.2 Designated use


#### Application and media

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5  $\mu\text{S}/\text{cm}$ .

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section (→  7).

#### Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

#### WARNING

#### Danger of breakage of the sensor due to corrosive or abrasive fluids!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any



warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

#### **Residual risks**

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

## **2.3 Workplace safety**

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

## **2.4 Operational safety**

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

#### **Conversions to the device**

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

#### **Repair**

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

#### **Environmental requirements**

If a plastic transmitter housing is permanently exposed to certain steam and air mixtures, this can damage the housing.

- ▶ If you are unsure, please contact your Endress+Hauser Sales Center for clarification.
- ▶ If used in an approval-related area, observe the information on the nameplate.

## **2.5 Product safety**

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.



## **2.6 IT security**

We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.




### 3 Product description

The device consists of a transmitter and a sensor.

Two device versions are available:

- Compact version - the transmitter and sensor form a mechanical unit.
- Remote version – the transmitter and sensor are mounted separately from one another.

#### 3.1 Product design



A0021563


















1 Important components of the compact version


- 1 Display module
- 2 Smart sensor electronics module
- 3 HistoROM DAT (plug-in memory)
- 4 Main electronics module
- 5 Terminals (screw terminals, some available as plug-in terminals)
- 6 Transmitter housing, compact version
- 7 Cable glands
- 8 Sensor, compact version



## 4 Incoming acceptance and product identification

### 4.1 Incoming acceptance

 			<p>Are the order codes on the delivery note (1) and the product sticker (2) identical?</p>
			
 			<p>Are the goods undamaged?</p>
 			<p>Do the nameplate data match the ordering information on the delivery note?</p>
 			<p>Is the CD-ROM with the Technical Documentation (depends on device version) and documents present?</p>

-  ■ If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! The Technical Documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section (→ 14).



### 4.2 Product identification

The following options are available for identification of the measuring device:


- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.




For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" (→  8) and "Supplementary device-dependent documentation" (→  8)
- The *W@M Device Viewer*: Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

#### 4.2.1 Transmitter nameplate




 2 Example of a transmitter nameplate


- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Permitted ambient temperature ( $T_a$ )
- 7 Firmware version (FW) and device revision (Dev.Rev.) from the factory
- 8 Degree of protection
- 9 Permitted temperature range for cable
- 10 2-D matrix code
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Electrical connection data, e.g. available inputs and outputs, supply voltage



### 4.2.2 Sensor nameplate



A0017224

 3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (ser. no.)
- 5 Extended order code (ext. ord. cd.)
- 6 Nominal diameter of sensor
- 7 Nominal pressure
- 8 Fluid temperature range
- 9 Material of lining and electrodes
- 10 Permitted ambient temperature range
- 11 Degree of protection
- 12 2-D matrix code




#### Order code

The measuring device is reordered using the order code.

##### Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE+).

### 4.2.3 Symbols on measuring device


Symbol	Meaning
	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	<b>Reference to documentation</b> Refers to the corresponding device documentation.
	<b>Protective ground connection</b> A terminal which must be connected to ground prior to establishing any other connections.



## 5 Storage and transport


### 5.1 Storage conditions

Observe the following notes for storage:


- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→  109)

### 5.2 Transporting the product

Transport the measuring device to the measuring point in the original packaging.



A0015604

 Do not remove protective covers or caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.


#### 5.2.1 Measuring devices without lifting lugs

##### WARNING

**Center of gravity of the measuring device is higher than the suspension points of the webbing slings.**

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device against slipping or turning.
- ▶ Observe the weight specified on the packaging (stick-on label).



A0015606



### 5.2.2 Measuring devices with lifting lugs

#### ⚠ CAUTION

##### Special transportation instructions for devices with lifting lugs

- ▶ Only use the lifting lugs fitted on the device or flanges to transport the device.
- ▶ The device must always be secured at two lifting lugs at least.


### 5.2.3 Transporting with a fork lift

If transporting in wood crates, the floor structure enables the crates to be lifted lengthwise or at both sides using a forklift.

#### ⚠ CAUTION

##### Risk of damaging the magnetic coil

- ▶ If transporting by forklift, do not lift the sensor by the metal casing.
- ▶ This would buckle the casing and damage the internal magnetic coils.



A0023726

## 5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:

- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
  - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
  - or
  - Carton in accordance with European Packaging Directive 94/62EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
  - Disposable plastic pallet
  - Plastic straps
  - Plastic adhesive strips
- Dunnage: Paper cushion




## 6 Installation

### 6.1 Installation conditions

#### 6.1.1 Mounting position

##### Mounting location



Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow:  $h \geq 2 \times DN$


To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:


- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

##### Installation in down pipes

Install a siphon with a vent valve downstream of the sensor in down pipes whose length  $h \geq 5 \text{ m}$  (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.

 For information on the liner's resistance to partial vacuum (→  110)



 4 Installation in a down pipe

1 Vent valve


2 Pipe siphon

h Length of down pipe

##### Installation in partially filled pipes

A partially filled pipe with a gradient necessitates a drain-type configuration.






A0017063

### Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube.


#### Vertical



A0015591

Optimum for self-emptying pipe systems.

#### Horizontal



A0017195

1 Measuring electrodes for signal detection




The measuring electrode plane must be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.

### Inlet and outlet runs


If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:






Installation dimensions

 For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section


6.1.2 Requirements from environment and process

Ambient temperature range


Transmitter	-40 to +60 °C (-40 to +140 °F)
Local display	-20 to +60 °C (-4 to +140 °F), the readability of the display may be impaired at temperatures outside the temperature range.
Sensor	-20 to +60 °C (-4 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner (→  110).

If operating outdoors:


- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.
- Protect the display against impact.
- Protect the display from abrasion by sand in desert areas.





 A display protector can be ordered from Endress+Hauser: "Accessories" section (→  102)

System pressure



Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.

 Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

-  ■ For information on the liner's resistance to partial vacuum (→  110)
- Information on the shock resistance of the measuring system (→  109)
- Information on the vibration resistance of the measuring system (→  110)




### Vibrations

In the event of very strong vibrations, the pipe and sensor must be supported and fixed. It is also advisable to mount the sensor and transmitter separately.



Information on the shock resistance of the measuring system (→ 109)

Information on the vibration resistance of the measuring system (→ 110)



A0016266

5 Measures to avoid device vibrations ( $L > 10\text{ m}$  (33 ft))


### Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



The nomogram only applies to liquids with a viscosity similar to that of water.

1. Calculate the ratio of the diameters  $d/D$ .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the  $d/D$  ratio.



A0016359



### 6.1.3 Special mounting instructions

#### Display protection

- ▶ To ensure that the optional display protection can be easily opened, maintain the following minimum head clearance: 350 mm (13.8 in)

## 6.2 Mounting the measuring device

### 6.2.1 Required tools

#### For transmitter

- Torque wrench
- For wall mounting:
  - Open-ended wrench for hexagonal screw max. M5
- For pipe mounting:
  - Open-ended wrench AF 8
  - Phillips head screwdriver PH 2
- For turning the transmitter housing (compact version):
  - Phillips head screwdriver PH 2
  - Torx screwdriver TX 20
  - Open-ended wrench AF 7

#### For sensor

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools


### 6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.


### 6.2.3 Mounting the sensor

#### Mounting kit

The sensor is installed between the pipe flanges using a mounting kit. The device is centered using the recesses on the sensor. Centering sleeves are also provided depending on the flange standard or the diameter of the pitch circle.

-  A mounting kit – consisting of mounting bolts, seals, nuts and washers – can be ordered separately (see "Accessories" section (→  102)).
















6 Mounting the sensor




- 1 Nut
- 2 Washer
- 3 Mounting bolts
- 4 Centering sleeve
- 5 Seal

Arranging the mounting bolts and centering sleeves

The device is centered using recesses on the sensor. The arrangement of the mounting bolts and the use of the centering sleeves supplied depend on the nominal diameter, the flange standard and the diameter of the pitch circle.

Nominal diameter		Process connection		
[mm]	[in]5	EN 1092-1 (DIN 2501)	ASME B16.5	JIS B2220
25...40	1...1 ½			
50	2			
65	2 ½		—	
80	3			



Nominal diameter		Process connection		
[mm]	[in]5	EN 1092-1 (DIN 2501)	ASME B16.5	JIS B2220
100	4			
1 = Mounting bolts with centering sleeves 2 = EN (DIN) flange: 4-hole → with centering sleeves 3 = EN (DIN) flange: 8-hole → without centering sleeves				

### Mounting the seals

#### ⚠ CAUTION

**An electrically conductive layer could form on the inside of the measuring tube!**


Risk of measuring signal short circuit.

- Do not use electrically conductive sealing compounds such as graphite.

Comply with the following instructions when installing seals:

- Make sure that the seals do not protrude into the piping cross-section.
- For DIN flanges: only use seals according to DIN EN 1514-1.
- Use seals with a hardness rating of 70° Shore.

### Mounting the ground cable/ground disks

Comply with the information on potential equalization and detailed mounting instructions for the use of ground cables/ground disks (→  38).

### Screw tightening torques

Please note the following:

- The screw tightening torques listed below apply only to lubricated threads and to pipes not subjected to tensile stress.
- Tighten the screws uniformly and in diagonally opposite sequence.
- Overtightening the screws will deform the sealing faces or damage the seals.

The tightening torques apply to situations where an EPDM soft material flat seal (e.g. 70° Shore) is used.

*Screw tightening torques, mounting bolts and centering sleeves for EN 1092-1 (DIN 2501), PN 16*

Nominal diameter [mm]	Mounting bolts [mm]	Length Centering sleeve [mm]	Max. screw tightening torque [Nm] for a process flange with ...	
			smooth seal face	Raised face
25	4 × M12 × 145	54	19	19
40	4 × M16 × 170	68	33	33
50	4 × M16 × 185	82	41	41
65 <sup>1)</sup>	4 × M16 × 200	92	44	44
65 <sup>2)</sup>	8 × M16 × 200	– <sup>3)</sup>	29	29



Nominal diameter [mm]	Mounting bolts [mm]	Length Centering sleeve [mm]	Max. screw tightening torque [Nm] for a process flange with ...	
			smooth seal face	Raised face
80	8 × M16 × 225	116	36	36
100	8 × M16 × 260	147	40	40

- 1) EN (DIN) flange: 4-hole → with centering sleeves
- 2) EN (DIN) flange: 8-hole → without centering sleeves
- 3) A centering sleeve is not required. The device is centered directly via the sensor housing.

#### *Screw tightening torques, mounting bolts and centering sleeves for ASME B16.5, Class 150*

Nominal diameter		Mounting bolts [in]	Length Centering sleeve [in]	Max. screw tightening torque [Nm] ([lbf · ft]) for a process flange with ...	
[mm]	[in]			smooth seal face	Raised face
25	1	4 × UNC ½" × 5.70	– <sup>1)</sup>	19 (14)	10 (7)
40	1 ½	4 × UNC ½" × 6.50	– <sup>1)</sup>	29 (21)	19 (14)
50	2	4 × UNC 5/8" × 7.50	– <sup>1)</sup>	41 (30)	37 (27)
80	3	4 × UNC 5/8" × 9.25	– <sup>1)</sup>	43 (31)	43 (31)
100	4	8 × UNC 5/8" × 10.4	5.79	38 (28)	38 (28)

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

#### *Screw tightening torques, mounting bolts and centering sleeves for JIS B2220, 10K*

Nominal diameter [mm]	Mounting bolts [mm]	Length Centering sleeve [mm]	Max. screw tightening torque [Nm] for a process flange with ...	
			smooth seal face	Raised face
25	4 × M16 × 170	54	24	24
40	4 × M16 × 170	68	32	25
50	4 × M16 × 185	– <sup>1)</sup>	38	30
65	4 × M16 × 200	– <sup>1)</sup>	42	42
80	8 × M16 × 225	– <sup>1)</sup>	36	28
100	8 × M16 × 260	– <sup>1)</sup>	39	37

- 1) A centering sleeve is not required. The device is centered directly via the sensor housing.

## 6.2.4 Mounting the transmitter of the remote version

### **⚠ CAUTION**

#### **Ambient temperature too high!**

Danger of electronics overheating and housing deformation.

- Do not exceed the permitted maximum ambient temperature (→ ☞ 20).
- If operating outdoors: Avoid direct sunlight and exposure to weathering, particularly in warm climatic regions.

### **⚠ CAUTION**

#### **Excessive force can damage the housing!**


- Avoid excessive mechanical stress.

The transmitter of the remote version can be mounted in the following ways:

- Wall mounting
- Pipe mounting



### Wall mounting



7 Engineering unit mm (in)

1. Drill the holes.
2. Insert wall plugs into the drilled holes.
3. Screw in the securing screws slightly at first.
4. Fit the transmitter housing over the securing screws and mount in place.
5. Tighten the securing screws.


### Post mounting

#### **⚠ WARNING**

**Excessive tightening torque applied to the fixing screws on plastic housing!**  
Risk of damaging the plastic transmitter.

- Tighten the fixing screws as per the tightening torque: 2 Nm (1.5 lbf ft)






A0020705


8 Engineering unit mm (in)

### 6.2.5 Turning the transmitter housing

To provide easier access to the connection compartment or display module, the transmitter housing can be turned.






A0021602



A0021603





1. Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque (→ 29)).
2. Open the housing cover.
3. Unlock the display module.
4. Remove the display module.
5. Loosen the fixing screws of the smart sensor electronics module (when reassembling, pay attention to the tightening torque (→ 29)).
6. Remove the smart sensor electronics module (when reassembling, pay attention to the coding of the plug (→ 29)).
7. Loosen the fixing screws of the main electronics module (when reassembling, pay attention to the tightening torque (→ 29)).
8. Remove the main electronics module.



9. Remove the electronics module from the main electronics module.
10. Loosen the fixing screws of the transmitter housing (when reassembling, pay attention to the tightening torque (→ 29)).
11. Lift the transmitter housing.
12. Turn the housing to the desired position in increments of 90°.

### Reassembling the transmitter housing

#### **⚠ WARNING**

#### **Excessive tightening torque applied to the fixing screws!**

Damage to the transmitter.

- When reassembling, tighten the fixing screws as per the tightening torque:


Step	Fixing screw	Tightening torques for housing made of:	
		Aluminum	Plastic
1	Housing cover	2.5 Nm (1.8 lbf ft)	1 Nm (0.7 lbf ft)
5	Smart sensor electronics module	0.6 Nm (0.4 lbf ft)	
7	Main electronics module	1.5 Nm (1.1 lbf ft)	
10	Transmitter housing	5.5 Nm (4.1 lbf ft)	

#### **NOTICE**

#### **Plug of the smart sensor electronics module connected incorrectly!**

No measuring signal is output.

- Plug in the plug of the smart sensor electronics module as per the coding.



A0021585

#### **NOTICE**

#### **Incorrect routing of the connecting cables between the sensor and transmitter in the transmitter housing!**


This can interfere with the measuring signal.

- Route the connecting cables directly at the level of the plugs.
- Reverse the procedure to reassemble the measuring device.

## 6.2.6 Turning the display module

The display module can be turned to optimize display readability and operability.





A0021617

1. Loosen the fixing screws of the housing cover (when reassembling, pay attention to the tightening torque (→ 30)).
2. Open the housing cover.
3. Unlock the display module.
4. Pull out the display module and turn it to the desired position in increments of 90°.

Reassembling the transmitter housing

**⚠ WARNING**

**Excessive tightening torque applied to the fixing screws!**

Damage to the transmitter.

- When reassembling, tighten the fixing screws as per the tightening torque:

Step	Fixing screw	Tightening torque for housing made of:	
		Aluminum	Plastic
1	Housing cover	2.5 Nm (1.8 lbf ft)	1 Nm (0.7 lbf ft)


- Reverse the procedure to reassemble the measuring device.

6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none"> <li>■ Process temperature</li> <li>■ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)</li> <li>■ Ambient temperature</li> <li>■ Measuring range</li> </ul>	<input type="checkbox"/>
Has the correct orientation for the sensor been selected ? <ul style="list-style-type: none"> <li>■ According to sensor type</li> <li>■ According to medium temperature</li> <li>■ According to medium properties (outgassing, with entrained solids)</li> </ul>	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ?	<input type="checkbox"/>
Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Is the device adequately protected from precipitation and direct sunlight?	<input type="checkbox"/>
Have the fixing screws been tightened with the correct tightening torque?	<input type="checkbox"/>



## 7 Electrical connection

 The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

### 7.1 Connection conditions

#### 7.1.1 Required tools

- Torque wrench
- For cable entries: Use corresponding tools
- For housing cover: Torx screwdriver or flat-blade screwdriver
- Wire stripper
- When using stranded cables: crimping tool for ferrule

#### 7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

##### Electrical safety

In accordance with applicable federal/national regulations.

##### Permitted temperature range

- $-40\text{ °C}$  ( $-40\text{ °F}$ ) to  $+80\text{ °C}$  ( $+176\text{ °F}$ )
- Minimum requirement: cable temperature range  $\geq$  ambient temperature  $+20\text{ K}$

##### Power supply cable

Standard installation cable is sufficient.

##### Signal cable

##### *Modbus RS485*

The EIA/TIA-485 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

<b>Cable type</b>	A
<b>Characteristic impedance</b>	135 to 165 $\Omega$ at a measuring frequency of 3 to 20 MHz
<b>Cable capacitance</b>	<30 pF/m
<b>Wire cross-section</b>	>0.34 mm <sup>2</sup> (22 AWG)
<b>Cable type</b>	Twisted pairs
<b>Loop resistance</b>	$\leq 110\text{ }\Omega/\text{km}$
<b>Signal damping</b>	Max. 9 dB over the entire length of the cable cross-section
<b>Shielding</b>	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.




Connecting cable for remote version

Electrode cable

Standard cable	3 ×0.38 mm <sup>2</sup> (20 AWG) with common, braided copper shield (ϕ ~7 mm (0.28 in)) and individual shielded cores
Conductor resistance	≤50 Ω/km (0.015 Ω/ft)
Capacitance: core/shield	≤420 pF/m (128 pF/ft)
Operating temperature	–20 to +80 °C (–68 to +176 °F)

Coil current cable

Standard cable	2 ×0.75 mm <sup>2</sup> (18 AWG) with common, braided copper shield (ϕ ~ 7 mm (0.28")) and individually shielded cores
Conductor resistance	≤37 Ω/km (0.011 Ω/ft)
Capacitance: core/core, shield grounded	≤120 pF/m (37 pF/ft)
Operating temperature	–20 to +80 °C (–68 to +176 °F)
Test voltage for cable insulation	≤ AC 1433 V r.m.s. 50/60 Hz or ≥ DC 2026 V



AO003194

9 Cable cross-section

- a Electrode cable
- b Coil current cable
- 1 Core
- 2 Core insulation
- 3 Core shield
- 4 Core jacket
- 5 Core reinforcement
- 6 Cable shield
- 7 Outer jacket

Operation in zones of severe electrical interference

The measuring system meets the general safety requirements (→ 118) and EMC specifications (→ 110).

Grounding is by means of the ground terminal provided for the purpose inside the connection housing. The stripped and twisted lengths of cable shield to the ground terminal must be as short as possible.

Cable diameter


- Cable glands supplied:
  - For standard cable: M20 × 1.5 with cable ϕ6 to 12 mm (0.24 to 0.47 in)
  - For reinforced cable: M20 × 1.5 with cable ϕ9.5 to 16 mm (0.37 to 0.63 in)
- (Plug-in) spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)



7.1.3 Terminal assignment

Transmitter

Modbus RS485 connection version



- 1 Supply voltage (wide range power unit)
- 2 Modbus RS485


Supply voltage

Order code for "Power supply"	Terminal numbers	
	1 (L+/L)	2 (L-/N)
Option L (wide range power unit)	AC100 to 240 V	
	AC/DC24 V	


Signal transmission Modbus RS485

Order code for "Output" and "Input"	Terminal numbers	
	26 (+)	27 (-)
Option M	A	B



**Remote version**

A0020539


 10 Remote version terminal assignment

- A Transmitter wall-mount housing  
 B Sensor connection housing  
 1 Electrode cable  
 2 Coil current cable  
 n.c. Not connected, insulated cable shields

Terminal No. and cable colors: 6/5 = brown; 7/8 = white; 4 = green

**7.1.4 Shielding and grounding****Modbus**

The shielding and grounding concept requires compliance with the following:

- Electromagnetic compatibility (EMC)
- Explosion protection
- Personal protection equipment
- National installation regulations and guidelines
- Observe cable specification (→  31).
- Keep the stripped and twisted lengths of cable shield to the ground terminal as short as possible.
- Seamless cable shielding.

*Grounding of the cable shield*

To comply with EMC requirements:

- Ensure the cable shield is grounded to the potential matching line at multiple points.
- Connect every local ground terminal to the potential matching line.

**NOTICE**

**In systems without potential matching, the multiple grounding of the cable shield causes mains frequency equalizing currents!**

Damage to the bus cable shield.

- ▶ Only ground the bus cable shield to either the local ground or the protective ground at one end.

**7.1.5 Preparing the measuring device**

1. Remove dummy plug if present.
2. If measuring device is delivered with cable glands:





Observe cable specification (→ 31).

7.1.6 Preparing the connecting cable for the remote version

When terminating the connecting cable, pay attention to the following points:



- In the case of electrode cables, make sure that the ferrules do not touch the core shields on the sensor side. Minimum distance = 1 mm (exception: green “GND” cable)
- In the case of coil current cables, insulate one core of the three-core wire at the level of the core reinforcement. You only require two cores for the connection.
- Fit the fine-wire cores with ferrules.

Transmitter

Electrode cable	Coil current cable
<div><p>11 Engineering unit mm (in)</p><p>A0021324</p></div>	<div><p>12 Engineering unit mm (in)</p><p>A0021325</p></div>
<p>A = Termination of the cables B = Termination of the fine-wire cores with ferrules 1 = Red ferrules, <math>\phi 1.0</math> mm (0.04 in) 2 = White ferrules, <math>\phi 0.5</math> mm (0.02 in) * = Stripping only for reinforced cables</p>	



## Sensor

Electrode cable	Coil current cable
 <p>A = Termination of the cables B = Termination of the fine-wire cores with ferrules 1 = Red ferrules, <math>\phi 1.0</math> mm (0.04 in) 2 = White ferrules, <math>\phi 0.5</math> mm (0.02 in) * = Stripping only for reinforced cables</p>	 <p>A0016488</p>

## 7.2 Connecting the measuring device

### ⚠ WARNING

#### Risk of electric shock! Components carry dangerous voltages!

- ▶ Have electrical connection work carried out by correspondingly trained specialists only.
- ▶ Observe applicable federal/national installation codes and regulations.
- ▶ Comply with local workplace safety regulations.
- ▶ Observe grounding concept of the plant.
- ▶ Never mount or wire the measuring device while it is connected to the supply voltage.
- ▶ Before the supply voltage is applied, connect the protective ground to the measuring device.

### 7.2.1 Connecting the remote version

#### ⚠ WARNING

#### Risk of damaging the electronic components!


- ▶ Ground the remote version: connect the sensor and transmitter to the same potential equalization.
- ▶ Only connect the sensor to a transmitter with the same serial number.
- ▶ Ground the connection housing of the sensor via the external screw terminal.

The following procedure (in the action sequence given) is recommended for the remote version:

1. Mount the sensor and transmitter.
2. Connect the connecting cable.




### 3. Connect the transmitter.



A0017445

13 Transmitter: main electronics module with terminals

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 35).
5. Connect the cable in accordance with the terminal assignment (→ 34).
6. Firmly tighten the cable glands.
7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant.  
Reverse the removal procedure to reassemble the transmitter.



A0017446

14 Sensor: connection module

1. Loosen the securing clamp of the housing cover.
2. Unscrew and lift off the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules (→ 35).
5. Connect the cable in accordance with the terminal assignment (→ 34).
6. Firmly tighten the cable glands.



7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.  
Reverse the procedure to reassemble the sensor.

7.2.2 Connecting the transmitter

- WARNING**  
Housing degree of protection may be voided due to insufficient sealing of the housing.  
► Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.

*Tightening torques for plastic housing*

Housing cover fixing screw	1.3 Nm
Cable entry	4.5 to 5 Nm
Ground terminal	2.5 Nm

1. Loosen the 4 fixing screws on the housing cover.
2. Open the housing cover.
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit wire end ferrules.
5. Firmly tighten the cable glands.
6. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant.  
Reverse the removal procedure to reassemble the transmitter.


7.2.3 Ensuring potential equalization

- CAUTION**  
Electrode damage can result in the complete failure of the device!  
► Make sure that the fluid and sensor have the same electrical potential.  
► Pay attention to internal grounding concepts in the company.  
► Pay attention to the pipe material or grounding.

Connection examples for standard situations

*Metal, grounded pipe*

- This connection method also applies:
- For plastic pipes
  - For pipes with insulating liner



A0017516




### Connection example in special situations

#### *Unlined and ungrounded metal pipe*

This connection method also applies in situations where:

- The customary potential equalization is not used
- Equalizing currents are present

<b>Ground cable</b>	Copper wire, at least $6 \text{ mm}^2$ ( $0.0093 \text{ in}^2$ )
---------------------	--



A0017517

1. Connect both pipe flanges to one another via a ground cable and ground them.
2. Mount the ground cable directly on the conductive flange coating of the pipe with the flange screws.
3. Connect the connection housing of the transmitter or sensor to ground potential by means of the ground terminal provided for the purpose.




For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

#### *Pipe with a cathodic protection unit*

This connection method is only used if the following two conditions are met:

- Metal pipe without liner or pipe with electrically conductive liner
- Cathodic protection is integrated in the personal protection equipment

<b>Ground cable</b>	Copper wire, at least $6 \text{ mm}^2$ ( $0.0093 \text{ in}^2$ )
---------------------	--



A0017518

Prerequisite: The sensor is installed in the pipe in a way that provides electrical insulation.

1. Connect the two flanges of the pipe to one another via a ground cable.
2. Guide the shield of the signal lines through a capacitor.
3. Connect the measuring device to the power supply such that it is floating in relation to the protective ground (isolation transformer).




**i** For remote device versions, the ground terminal in the example always refers to the sensor and **not** to the transmitter.

### 7.3 Special connection instructions

#### 7.3.1 Connection examples

##### Modbus RS485



A0016803

**15** Connection example for Modbus RS485, non-hazardous area and Zone 2/Div. 2


- 1 Control system (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications (→ 31)
- 3 Distribution box
- 4 Transmitter

### 7.4 Hardware settings

#### 7.4.1 Enabling the terminating resistor

##### Modbus RS485

To avoid incorrect communication transmission caused by impedance mismatch, terminate the Modbus RS485 cable correctly at the start and end of the bus segment.



A0023063

**16** Terminating resistor can be enabled via DIP switch on the main electronics module




## 7.5 Ensuring the degree of protection

### 7.5.1 Degree of protection IP66/67, Type 4X enclosure

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:

1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



A0013960

5. Insert dummy plugs into unused cable entries.


## 7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Do the cables comply with the requirements (→ 31)?	<input type="checkbox"/>
Do the cables have adequate strain relief?	<input type="checkbox"/>
Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→ 41) ?	<input type="checkbox"/>
Only for remote version: is the sensor connected to the right transmitter? Check the serial number on the nameplate of the sensor and transmitter.	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate ?	<input type="checkbox"/>
Is the terminal assignment correct ?	<input type="checkbox"/>
If supply voltage is present, do values appear on the display module?	<input type="checkbox"/>
Is the potential equalization established correctly (→ 38)?	<input type="checkbox"/>
Are all housing covers installed and the screws tightened with the correct tightening torque?	<input type="checkbox"/>



## 8 Operation options

### 8.1 Overview of operation options





A0019091


- 1 Local operation via display module
- 2 Computer with Web browser (e.g. Internet Explorer) or with operating tool (e.g. FieldCare, AMS Device Manager, SIMATIC PDM)
- 3 Control system (e.g. PLC)




## 8.2 Structure and function of the operating menu

### 8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters (→  121)



 17 Schematic structure of the operating menu

A0018237-EN



## 8.2.2 Operating philosophy


The individual parts of the operating menu are assigned to certain user roles (operator, maintenance etc.). Each user role contains typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Operation	task-oriented	<b>Role "Operator", "Maintenance"</b> Tasks during operation: Reading measured values	Resetting and controlling totalizers
Setup		<b>"Maintenance" role</b> Commissioning: <ul style="list-style-type: none"> <li>■ Configuration of the measurement</li> <li>■ Configuration of the communication interface</li> </ul>	Submenus for fast commissioning: <ul style="list-style-type: none"> <li>■ Setting the individual system units</li> <li>■ Defining the medium</li> <li>■ Configuration of the digital communication interface</li> <li>■ Configuring the low flow cut off</li> </ul> <b>"Advanced setup" submenu:</b> <ul style="list-style-type: none"> <li>■ For more customized configuration of the measurement (adaptation to special measuring conditions)</li> <li>■ Configuration of totalizers</li> <li>■ <b>"Device reset" submenu</b> Resets the device configuration to certain settings</li> </ul>
Diagnostics		<b>"Maintenance" role</b> Fault elimination: <ul style="list-style-type: none"> <li>■ Diagnostics and elimination of process and device errors</li> <li>■ Measured value simulation</li> </ul>	Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> <li>■ <b>"Diagnostic list" submenu</b> Contains up to 5 currently pending diagnostic messages.</li> <li>■ <b>"Event logbook" submenu</b> Contains 20 event messages that have occurred.</li> <li>■ <b>"Device information" submenu</b> Contains information for identifying the device.</li> <li>■ <b>"Measured values" submenu</b> Contains all current measured values.</li> <li>■ <b>"Simulation" submenu</b> Is used to simulate measured values or output values.</li> </ul>
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> <li>■ Commissioning measurements under difficult conditions</li> <li>■ Optimal adaptation of the measurement to difficult conditions</li> <li>■ Detailed configuration of the communication interface</li> <li>■ Error diagnostics in difficult cases</li> </ul>	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> <li>■ <b>"System" submenu</b> Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication.</li> <li>■ <b>"Sensor" submenu</b> Configuration of the measurement.</li> <li>■ <b>"Communication" submenu</b> Configuration of the digital communication interface.</li> <li>■ <b>"Application" submenu</b> Configuration of the functions that go beyond the actual measurement (e.g. totalizer).</li> <li>■ <b>"Diagnostics" submenu</b> Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.</li> </ul>



### 8.3 Access to the operating menu via the local display

#### 8.3.1 Operational display




#### Status area

The following symbols appear in the status area of the operational display at the top right:

- Status signals(→ 86)
  - F: Failure
  - C: Function check
  - S: Out of specification
  - M: Maintenance required
- Diagnostic behavior(→ 87)
  - ⊗: Alarm
  - ⚠: Warning
- ⚡: Locking (the device is locked via the hardware (→ 77))
- ↔: Communication (communication via remote operation is active)

#### Display area

In the display area, each measured value is prefaced by certain symbol types for further description:



#### Measured variables

Symbol	Meaning
U	Volume flow
m	Mass flow



	Totalizer The measurement channel number indicates which of the three totalizers is displayed.
	Output The measurement channel number indicates which of the outputs is displayed.
	Status input

Measurement channel numbers

Symbol	Meaning
	Measurement channel 1 to 4
The measurement channel number is displayed only if more than one channel is present for the same measured variable type (e.g. Totalizer 1 to 3).	

Diagnostic behavior

The diagnostic behavior pertains to a diagnostic event that is relevant to the displayed measured variable. For information on the symbols (→ 87)

The number and display format of the measured values can be configured via the **"Format display" parameter**(→ 65). "Operation" menu → Display → Format display

8.3.2 Navigation view

In the submenu

1: Navigation view  
2: Navigation path to current position  
3: Status area  
4: Display area for navigation  
5: Operating elements (→ 50)

A0013993-EN

In the wizard

1: Navigation view  
2: Navigation path to current position  
3: Status area  
4: Display area for navigation  
5: Operating elements (→ 50)

A0016327-EN

1 Navigation view  
2 Navigation path to current position  
3 Status area  
4 Display area for navigation  
5 Operating elements (→ 50)

Navigation path

The navigation path - displayed at the top left in the navigation view - consists of the following elements:

■ In the submenu:  
Display symbol for menu

■ In the wizard:  
Display symbol for wizard

↓

Examples

Omission symbol for  
operating menu levels in  
between

↓

Examples

/ .. /

Name of current

■ Submenu

■ Wizard

■ Parameter

↓


Examples



Display

46

Endress+Hauser






	<i>/ ... /</i>	Display
---	----------------	---------

 For more information about the menu icons, refer to the "Display area" section (→  47)

### Status area





The following appears in the status area of the navigation view in the top right corner:

- Of the submenu
  - The direct access code for the parameter you are navigating to (e.g. 0022-1)
  - If a diagnostic event is present, the diagnostic behavior and status signal
- In the wizard
  - If a diagnostic event is present, the diagnostic behavior and status signal





-  ■ For information on the diagnostic behavior and status signal (→  86)
- For information on the function and entry of the direct access code (→  52)

### Display area




#### Menus

Symbol	Meaning
	<b>Operation</b> Appears: <ul style="list-style-type: none"> <li>■ In the menu next to the "Operation" selection</li> <li>■ At the left in the navigation path in the "Operation" menu</li> </ul>
	<b>Setup</b> Appears: <ul style="list-style-type: none"> <li>■ In the menu next to the "Setup" selection</li> <li>■ At the left in the navigation path in the "Setup" menu</li> </ul>
	<b>Diagnostics</b> Appears: <ul style="list-style-type: none"> <li>■ In the menu next to the "Diagnostics" selection</li> <li>■ At the left in the navigation path in the "Diagnostics" menu</li> </ul>
	<b>Expert</b> Appears: <ul style="list-style-type: none"> <li>■ In the menu next to the "Expert" selection</li> <li>■ At the left in the navigation path in the "Expert" menu</li> </ul>

#### Submenus, wizards, parameters

Symbol	Meaning
	Submenu
	Wizard
	Parameters within a wizard  No display symbol exists for parameters in submenus.

#### Locking

Symbol	Meaning
	<b>Parameter locked</b> When displayed in front of a parameter name, indicates that the parameter is locked. <ul style="list-style-type: none"> <li>■ By a user-specific access code (→  76)</li> <li>■ By the hardware write protection switch (→  77)</li> </ul>



Wizard operation

Symbol	Meaning
	Switches to the previous parameter.
	Confirms the parameter value and switches to the next parameter.
	Opens the editing view of the parameter.

8.3.3 Editing view

1

20

01234  
56789  
- . ← C  
X ✓

4

-

+

E

A0013941

1

User

ABC DEFG HIJK  
LMNO PQRS TUVW  
XYZ ↔ C ↔ Aa1@  
C ✓ X

4

-

+

E

A0013999

1 Editing view

2 Display area of the entered values

3 Input mask

4 Operating elements (→ 50)

Input mask

The following input symbols are available in the input mask of the numeric and text editor:

Numeric editor

Symbol	Meaning
	Selection of numbers from 0 to 9.
	Inserts decimal separator at the input position.
	Inserts minus sign at the input position.
	Confirms selection.
	Moves the input position one position to the left.
	Exits the input without applying the changes.
	Clears all entered characters.



*Text editor*








Symbol	Meaning
	Toggle <ul style="list-style-type: none"> <li>Between upper-case and lower-case letters</li> <li>For entering numbers</li> <li>For entering special characters</li> </ul>
 ... 	Selection of letters from A to Z.
 ... 	Selection of letters from a to z.
 ... 	Selection of special characters.
	Confirms selection.
	Switches to the selection of the correction tools.
	Exits the input without applying the changes.
	Clears all entered characters.

*Correction symbols under* 

Symbol	Meaning
	Clears all entered characters.
	Moves the input position one position to the right.
	Moves the input position one position to the left.
	Deletes one character immediately to the left of the input position.



### 8.3.4 Operating elements

Key	Meaning
	<b>Minus key</b> <i>In a menu, submenu</i> Moves the selection bar upwards in a choose list. <i>With a Wizard</i> Confirms the parameter value and goes to the previous parameter. <i>With a text and numeric editor</i> In the input mask, moves the selection bar to the left (backwards).
	<b>Plus key</b> <i>In a menu, submenu</i> Moves the selection bar downwards in a choose list. <i>With a Wizard</i> Confirms the parameter value and goes to the next parameter. <i>With a text and numeric editor</i> Moves the selection bar to the right (forwards) in an input screen.
	<b>Enter key</b> <i>For operational display</i> <ul style="list-style-type: none"> <li>Pressing the key briefly opens the operating menu.</li> <li>Pressing the key for 2 s opens the context menu.</li> </ul> <i>In a menu, submenu</i> <ul style="list-style-type: none"> <li>Pressing the key briefly:               <ul style="list-style-type: none"> <li>Opens the selected menu, submenu or parameter.</li> <li>Starts the wizard.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s for parameter:               <ul style="list-style-type: none"> <li>If present, opens the help text for the function of the parameter.</li> </ul> </li> </ul> <i>With a Wizard</i> Opens the editing view of the parameter. <i>With a text and numeric editor</i> <ul style="list-style-type: none"> <li>Pressing the key briefly:               <ul style="list-style-type: none"> <li>Opens the selected group.</li> <li>Carries out the selected action.</li> </ul> </li> <li>Pressing the key for 2 s confirms the edited parameter value.</li> </ul>
	<b>Escape key combination (press keys simultaneously)</b> <i>In a menu, submenu</i> <ul style="list-style-type: none"> <li>Pressing the key briefly:               <ul style="list-style-type: none"> <li>Exits the current menu level and takes you to the next higher level.</li> <li>If help text is open, closes the help text of the parameter.</li> </ul> </li> <li>Pressing the key for 2 s returns you to the operational display ("home position").</li> </ul> <i>With a Wizard</i> Exits the wizard and takes you to the next higher level. <i>With a text and numeric editor</i> Closes the text or numeric editor without applying changes.
	<b>Minus/Enter key combination (press the keys simultaneously)</b> Reduces the contrast (brighter setting).
	<b>Plus/Enter key combination (press and hold down the keys simultaneously)</b> Increases the contrast (darker setting).
	<b>Minus/Plus/Enter key combination (press the keys simultaneously)</b> <i>For operational display</i> Enables or disables the keypad lock (only SD02 display module).

### 8.3.5 Opening the context menu


Using the context menu, the user can call up the following menus quickly and directly from the operational display:




- Setup
- Simulation



### Calling up and closing the context menu

The user is in the operational display.



1. Press  for 2 s.
  - ↳ The context menu opens.



A0017421-EN

2. Press  +  simultaneously.
  - ↳ The context menu is closed and the operational display appears.

### Calling up the menu via the context menu

1. Open the context menu.
2. Press  to navigate to the desired menu.
3. Press  to confirm the selection.
  - ↳ The selected menu opens.




8.3.6 Navigating and selecting from list

Different operating elements are used to navigate through the operating menu. The navigation path is displayed on the left in the header. Icons are displayed in front of the individual menus. These icons are also shown in the header during navigation.

 For an explanation of the navigation view with symbols and operating elements (→  46)

Example: Setting the number of displayed measured values to "2 values"



A0017448-EN

8.3.7 Calling the parameter directly


A parameter number is assigned to every parameter to be able to access a parameter directly via the onsite display. Entering this access code in the **Direct access** parameter calls up the desired parameter directly.



**Navigation path**

"Expert" menu → Direct access

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1. In the navigation view, this appears on the right-hand side in the header of the selected parameter.



A0017223

1 Direct access code

Note the following when entering the direct access code:

- The leading zeros in the direct access code do not have to be entered.  
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.  
Example: Input of "0914" → Parameter **Totalizer 1**
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.  
Example: Input of "0914-2" → Parameter **Totalizer 2**



For the direct access codes of the individual parameters

**8.3.8 Calling up help text**


For some parameters, help texts exist, which the user can call up from the navigation view. These briefly describe the function of the parameter and thus support fast and reliable commissioning.

**Calling up and closing the help text**

The user is in the navigation view and the selection bar is on a parameter.

1. Press  for 2 s.

↳ The help text for the selected parameter opens.



A0014002-EN

 18 Example: Help text for parameter "Enter access code"

2. Press  +  simultaneously.


↳ The help text is closed.



8.3.9 Changing the parameters

**i** For a description of the editing display - consisting of text editor and numeric editor - with symbols (→ 48), for a description of the operating elements (→ 50)

**Example:** Changing the tag name in the "Tag description" parameter from 001-FT-101 to 001-FT-102



A0014020-EN


A message is displayed if the value entered is outside the permitted value range.



<div> <div>Ent. access code</div> <div>Invalid or out of range input value</div> <div>Min:0</div> <div>Max:9999</div> </div>
--

A0014049-EN

### 8.3.10 User roles and related access authorization


The two user roles "Operator" and "Maintenance" have different write access to the parameters if the customer defines a user-specific access code. This protects the device configuration via the local display from unauthorized access (→  76).

*Access authorization to parameters*



User role	Read access		Write access	
	Without access code (from the factory)	With access code	Without access code (from the factory)	With access code
Operator	✓	✓	✓	-- 1)
Maintenance	✓	✓	✓	✓

- 1) Despite the defined access code, certain parameters can always be modified and thus are excepted from the write protection, as they do not affect the measurement. Refer to the "Write protection via access code" section



If an incorrect access code is entered, the user obtains the access rights of the "Operator" role.

 The user role with which the user is currently logged on is indicated by the **Access status display** parameter. Navigation path: Operation → Access status display

### 8.3.11 Disabling write protection via access code

If the -symbol appears on the local display in front of a parameter, the parameter is write-protected by a user-specific access code and its value cannot be changed at the moment using the local display (→  76).

The locking of the write access via local operation can be disabled by entering the customer-defined access code via the respective access option.

1. After you press , the input prompt for the access code appears.
2. Enter the access code.
  - ↳ The -symbol in front of the parameters disappears; all previously write-protected parameters are now re-enabled.

### 8.3.12 Enabling and disabling the keypad lock

The keypad lock makes it possible to block access to the entire operating menu via local operation. As a result, it is no longer possible to navigate through the operating menu or change the values of individual parameters. Users can only read the measured values on the operational display.

#### Local operation with touch control


The keypad lock is switched on and off via the context menu.




*Switching on the keypad lock*


The keypad lock is switched on automatically:

- Each time the device is restarted.
- If the device has not been operated for longer than one minute in the measured value display.

1. The device is in the measured value display.  
Press the  key for longer than 2 seconds.  
↳ A context menu appears.
2. In the context menu, select the **Keylock on** option.  
↳ The keypad lock is switched on.

 If the user attempts to access the operating menu while the keypad lock is active, the message **Keylock on** appears.

*Switching off the keypad lock*


1. The keypad lock is switched on.  
Press the  key for longer than 2 seconds.  
↳ A context menu appears.
2. In the context menu, select the **Keylock off** option.  
↳ The keypad lock is switched off.

## 8.4 Access to the operating menu via the operating tool

The structure of the operating menu in the operating tools is the same as for operation via the local display.

### 8.4.1 Connecting the operating tool

#### Via service interface (CDI-RJ45)



A0023114

- 1 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server



## 8.4.2 FieldCare

### Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.


Access takes place via:

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

 For details, see Operating Instructions BA00027S and BA00059S


### Source for device description files



See data (→  58)

### Establishing a connection

 For details, see Operating Instructions BA00027S and BA00059S

### User interface



- 1 Header
- 2 Picture of device
- 3 Device tag (→  63)
- 4 Status area with status signal (→  89)
- 5 Event list with additional functions such as save/load, events list and document creation
- 7 Navigation area with operating menu structure
- 8 Operating range


A0021053-EN



## 9 System integration

### 9.1 Overview of device description files

#### 9.1.1 Current version data for the device

Firmware version	01.00.zz	<ul style="list-style-type: none"> <li>On the title page of the Operating instructions</li> <li>On transmitter nameplate(→  13)</li> <li>Parameter <b>firmware version</b> Diagnostics → Device info → Firmware version</li> </ul>
Release date of firmware version	07.2014	---

#### 9.1.2 Operating tools

The suitable device description file for the individual operating tools is listed in the table below, along with information on where the file can be acquired.



The suitable device description file for the operating tool is listed in the table below, along with information on where the file can be acquired.

Operating tool via service interface (CDI)	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> <li><a href="http://www.endress.com">www.endress.com</a> → Download Area</li> <li>CD-ROM (contact Endress+Hauser)</li> <li>DVD (contact Endress+Hauser)</li> </ul>




### 9.2 Modbus RS485 information


#### 9.2.1 Function codes

Function codes are used to define which read or write action is carried out via the Modbus protocol. The measuring device supports the following function codes:


Code	Name	Description	Application
03	Read holding register	<p>Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes</p> <p> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.</p>	<p>Read device parameters with read and write access</p> <p>Example: Read volume flow</p>
04	Read input register	<p>Master reads one or more Modbus registers from the device. A maximum of 125 consecutive registers can be read with 1 telegram: 1 register = 2 bytes</p> <p> The measuring device does not make a distinction between function codes 03 and 04; these codes therefore yield the same result.</p>	<p>Read device parameters with read access</p> <p>Example: Read totalizer value</p>



Code	Name	Description	Application
06	Write single registers	Master writes a new value to <b>one</b> Modbus register of the measuring device.  Use function code 16 to write multiple registers with just 1 telegram.	Write only 1 device parameter Example: reset totalizer
08	Diagnostics	Master checks the communication connection to the measuring device. The following "Diagnostics codes" are supported: <ul style="list-style-type: none"> <li>▪ Sub-function 00 = Return query data (loopback test)</li> <li>▪ Sub-function 02 = Return diagnostics register</li> </ul>	
16	Write multiple registers	Master writes a new value to multiple Modbus registers of the device. A maximum of 120 consecutive registers can be written with 1 telegram.  If the required device parameters are not available as a group, yet must nevertheless be addressed with a single telegram, use Modbus data map (→  59)	Write multiple device parameters
23	Read/Write multiple registers	Master reads and writes a maximum of 118 Modbus registers of the measuring device simultaneously with 1 telegram. Write access is executed <b>before</b> read access.	Write and read multiple device parameters Example: <ul style="list-style-type: none"> <li>▪ Read mass flow</li> <li>▪ Reset totalizer</li> </ul>

 Broadcast messages are only allowed with function codes 06, 16 and 23.

### 9.2.2 Register information

 For an overview on Modbus-specific information of the individual device parameters, please refer to the additional document on Modbus RS485 register information

### 9.2.3 Response time

Response time of the measuring device to the request telegram of the Modbus master: typically 3 to 5 ms

### 9.2.4 Modbus data map

#### Function of the Modbus data map

The device offers a special memory area, the Modbus data map (for a maximum of 16 device parameters), to allow users to call up multiple device parameters via Modbus RS485 and not only individual device parameters or a group of consecutive device parameters.

Grouping of device parameters is flexible and the Modbus master can read or write to the entire data block simultaneously with a single request telegram.



### Structure of the Modbus data map

The Modbus data map consists of two data sets:

- **Scan list: Configuration area**

The device parameters to be grouped are defined in a list in that their Modbus RS485 register addresses are entered in the list.

- **Data area**

The measuring device reads out the register addresses entered in the scan list cyclically and writes the associated device data (values) to the data area.



For an overview of device parameters with their individual Modbus register address, please refer to the additional document on Modbus RS485 register information

### Scan list configuration

For configuration, the Modbus RS485 register addresses of the device parameters to be grouped must be entered in the scan list. Please note the following basic requirements of the scan list:

<b>Max. entries</b>	16 device parameters
<b>Supported device parameters</b>	Only parameters with the following characteristics are supported: <ul style="list-style-type: none"> <li>■ Access type: read or write access</li> <li>■ Data type: float or integer</li> </ul>

#### *Configuring the scan list via FieldCare*

Carried out using the operating menu of the measuring device:

Expert → Communication → Modbus data map → Scan list register 0 -15

Scan list	
No.	Configuration register
0	Scan list register 0
...	...
15	Scan list register 15

#### *Configuring the scan list via Modbus RS485*

Carried out using register addresses 5001 - 5016

Scan list			
No.	Modbus RS485 register	Data type	Configuration register
0	5001	Integer	Scan list register 0
...	...	Integer	...
15	5016	Integer	Scan list register 15

### Reading out data via Modbus RS485

The Modbus master accesses the data area of the Modbus data map to read out the current values of the device parameters defined in the scan list.

<b>Master access to data area</b>	Via register addresses 5051-5081
-----------------------------------	----------------------------------



Data area			
Device parameter value	Modbus RS485 register	Data type*	Access**
Value of scan list register 0	5051	Integer/float	Read/write
Value of scan list register 1	5053	Integer/float	Read/write
Value of scan list register ...	...	...	...
Value of scan list register 15	5081	Integer/float	Read/write
* Data type depends on the device parameters entered in the scan list.			
** Data access depends on the device parameters entered in the scan list. If the device parameter entered supports read and write access, the parameter can also be accessed via the data area.			



## 10 Commissioning

### 10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-installation check" checklist (→ 30)
- "Post-connection check" checklist (→ 41)

### 10.2 Switching on the measuring device

After a successful function check, switch on the measuring device.

After a successful startup, the local display switches automatically from the startup display to the operational display.


If nothing appears on the local display or a diagnostic message is displayed, refer to the section on "Diagnostics and troubleshooting" (→ 84).

### 10.3 Establishing a connection via FieldCare

- For FieldCare connection (→ 56)
- For establishing a connection via FieldCare (→ 57)
- For FieldCare user interface (→ 57)

### 10.4 Setting the operating language

Factory setting: English or ordered local language



A0013996


19 Using the example of the local display



## 10.5 Configuring the measuring device

The **Setup** menu with its guided wizards contains all the parameters needed for standard operation.

Navigation to the **Setup** menu



20 Using the example of the local display

A0017444-EN

Overview of the wizards in the "Setup" menu

Setup	→	Device tag	(→ 63)
		System units	(→ 64)
		Communication	(→ 67)
		Display	(→ 65)
		Low flow cut off	(→ 68)
		Empty pipe detection	(→ 70)
		Advanced setup	(→ 71)


### 10.5.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

**i** The number of characters displayed depends on the characters used.

**i** For information on the tag name in the "FieldCare" operating tool (→ 57)





21 Header of the operational display with tag name  
1 Device tag

Navigation  
"Setup" menu → Device tag


Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag

10.5.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation  
"Setup" menu → System units



Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"><li>Output</li><li>Low flow cut off</li><li>Simulation process variable</li></ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"><li>l/h</li><li>gal/min (us)</li></ul>
Volume unit	Select volume unit. <b>Result</b> The selected unit is taken from: <b>Volume flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"><li>l</li><li>gal (us)</li></ul>



Parameter	Description	Selection	Factory setting
Temperature unit	Select temperature unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Reference temperature</li> <li>■ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ °C (Celsius)</li> <li>■ °F (Fahrenheit)</li> </ul>
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Low flow cut off</li> <li>■ Simulation process variable</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ kg/h</li> <li>■ lb/min</li> </ul>
Mass unit	Select mass unit. <i>Result</i> The selected unit is taken from: <b>Mass flow unit</b> parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ kg</li> <li>■ lb</li> </ul>
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> <li>■ Output</li> <li>■ Simulation process variable</li> <li>■ Density adjustment (in <b>Expert</b> menu)</li> </ul>	Unit choose list	Country-specific: <ul style="list-style-type: none"> <li>■ kg/l</li> <li>■ lb/ft<sup>3</sup></li> </ul>

### 10.5.3 Configuring the local display


The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

#### Navigation

"Setup" menu → Display



Structure of the wizard



22 "Display" wizard in the "Setup" menu

Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"><li>1 value, max. size</li><li>1 bargraph + 1 value</li><li>2 values</li><li>1 value large + 2 values</li><li>4 values</li></ul>	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"><li>Volume flow</li><li>Mass flow</li><li>Totalizer 1</li><li>Totalizer 2</li><li>Totalizer 3</li><li>Current output 1</li></ul>	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	0.025 l/h
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None



Parameter	Description	Selection / User entry	Factory setting
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None

### 10.5.4 Configuring the communication interface

The **"Communication"** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

#### Navigation

"Setup" menu → Communication

► Communication

Bus address

Baudrate

Data transfer mode

Parity

Byte order

Failure mode

#### Parameter overview with brief description

Parameter	Description	User entry / Selection	Factory setting
Bus address	Enter device address.	1 to 247	247
Baudrate	Define data transfer speed.	<ul style="list-style-type: none"> <li>■ 1200 BAUD</li> <li>■ 2400 BAUD</li> <li>■ 4800 BAUD</li> <li>■ 9600 BAUD</li> <li>■ 19200 BAUD</li> <li>■ 38400 BAUD</li> <li>■ 57600 BAUD</li> <li>■ 115200 BAUD</li> </ul>	19200 BAUD
Data transfer mode	Select data transfer mode.	<ul style="list-style-type: none"> <li>■ ASCII Transmission of data in the form of readable ASCII characters. Error protection via LRC.</li> <li>■ RTU Transmission of data in binary form. Error protection via CRC16.</li> </ul>	RTU



Parameter	Description	User entry / Selection	Factory setting
Parity	Select parity bits.	ASCII picklist ■ 0 = even ■ 1 = odd  RTU picklist ■ 0 = even ■ 1 = odd ■ 2 = no parity bit/1 stop bit ■ 3 = no parity bit/2 stop bits	Even
Byte order	Select byte transmission sequence.	■ 0-1-2-3 ■ 3-2-1-0 ■ 1-0-3-2 ■ 2-3-0-1	1-0-3-2
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication.  ⓘ This parameter operates in accordance with the option selected in the <b>Assign diagnostic behavior</b> parameter.  ⓘ NaN: not a number	■ NaN value ■ Last valid value	NaN value


### 10.5.5 Configuring the low flow cut off

The **Low flow cut off** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

#### Navigation

"Setup" menu → Low flow cut off

#### Structure of the wizard



A0020524-EN

23 "Low flow cut off" wizard in the "Setup" menu



**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Assign process variable	Select process variable for low flow cut off.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> </ul>	Volume flow
On value low flow cutoff	Enter on value for low flow cut off.	Signed floating-point number	0 l/h
Off value low flow cutoff	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s




10.5.6 Configuring empty pipe detection

The **Empty pipe detection** wizard guides you systematically through all the parameters that have to be set for configuring the low flow cut off.

Navigation

"Setup" menu → Empty pipe detection

Structure of the wizard



A0017210-EN

24 "Empty pipe detection" wizard in the "Setup" menu

Parameter overview with brief description


Parameter	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	Switch empty pipe detection on and off.	<ul style="list-style-type: none"><li>Off</li><li>On</li></ul>	Off
New adjustment	Select type of adjustment.	<ul style="list-style-type: none"><li>Cancel</li><li>Empty pipe adjust</li><li>Full pipe adjust</li></ul>	Cancel
Progress		<ul style="list-style-type: none"><li>Ok</li><li>Busy</li><li>Not ok</li></ul>	
Switch point empty pipe detection	Enter hysteresis in %, below this value the measuring tube will detected as empty.	0 to 100 %	50 %
Response time empty pipe detection	Enter the time before diagnostic message S862 "Pipe empty" is displayed for empty pipe detection.	0 to 100 s	1 s



### 10.6 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Navigation to the "Advanced setup" submenu



25 Using the example of the local display

#### 10.6.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

**Navigation**

"Setup" menu → Advanced setup → Sensor adjustment

**Structure of the submenu**



**Parameter overview with brief description**

Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<ul style="list-style-type: none"><li>Flow in arrow direction</li><li>Flow against arrow direction</li></ul>	Flow in arrow direction



10.6.2 Configuring the totalizer

In the "Totalizer 1 to 3" submenu the individual totalizers can be configured.

Navigation

"Setup" menu → Advanced setup → Totalizer 1 to 3

► Totalizer 1 to 3

Assign process variable

Unit totalizer

Totalizer operation mode

Failure mode

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Assign process variable	Select process variable for totalizer.	<div>■ Off</div> <div>■ Volume flow</div> <div>■ Mass flow</div>	Volume flow
Mass unit	Select mass unit.	Unit choose list	kg
Volume unit	Select volume unit.	Unit choose list	m³
Corrected volume unit	Select corrected volume unit.	Unit choose list	Nm³
Totalizer operation mode	Select totalizer calculation mode.	<div>■ Net flow total</div> <div>■ Forward flow total</div> <div>■ Reverse flow total</div>	Net flow total
Failure mode	Define totalizer behavior in alarm condition.	<div>■ Stop</div> <div>■ Actual value</div> <div>■ Last valid value</div>	Stop



### 10.6.3 Carrying out additional display configurations

In the **"Display"** submenu you can set all the parameters involved in the configuration of the local display.

#### Navigation

"Setup" menu → Advanced setup → Display

► Display

Format display

Value 1 display

0% bargraph value 1

100% bargraph value 1

Decimal places 1

Value 2 display

Decimal places 2

Value 3 display

0% bargraph value 3

100% bargraph value 3

Decimal places 3

Value 4 display

Decimal places 4

Display language

Display interval

Display damping

Header

Header text

Separator

Backlight



**Parameter overview with brief description**


Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> <li>■ 1 value, max. size</li> <li>■ 1 bargraph + 1 value</li> <li>■ 2 values</li> <li>■ 1 value large + 2 values</li> <li>■ 4 values</li> </ul>	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Totalizer 1</li> <li>■ Totalizer 2</li> <li>■ Totalizer 3</li> <li>■ Current output 1</li> </ul>	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 l/h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	0.025 l/h
Decimal places 1	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>■ x</li> <li>■ x.x</li> <li>■ x.xx</li> <li>■ x.xxx</li> <li>■ x.xxxx</li> </ul>	x.xx
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 2	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>■ x</li> <li>■ x.x</li> <li>■ x.xx</li> <li>■ x.xxx</li> <li>■ x.xxxx</li> </ul>	x.xx
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>■ x</li> <li>■ x.x</li> <li>■ x.xx</li> <li>■ x.xxx</li> <li>■ x.xxxx</li> </ul>	x.xx
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 4	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> <li>■ x</li> <li>■ x.x</li> <li>■ x.xx</li> <li>■ x.xxx</li> <li>■ x.xxxx</li> </ul>	x.xx



Parameter	Description	Selection / User entry	Factory setting
Display language	Set display language.	<ul style="list-style-type: none"> <li>■ English</li> <li>■ Deutsch</li> <li>■ Français</li> <li>■ Español</li> <li>■ Italiano</li> <li>■ Nederlands</li> <li>■ Portuguesa</li> <li>■ Polski</li> <li>■ русский язык (Russian)</li> <li>■ Svenska</li> <li>■ Türkçe</li> <li>■ 中文 (Chinese)</li> <li>■ 日本語 (Japanese)</li> <li>■ 한국어 (Korean)</li> <li>■ العربية (Arabic)</li> <li>■ Bahasa Indonesia</li> <li>■ ภาษาไทย (Thai)</li> <li>■ tiếng Việt (Vietnamese)</li> <li>■ čeština (Czech)</li> </ul>	English (alternatively, the ordered language is preset in the device)
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	0.0 s
Header	Select header contents on local display.	<ul style="list-style-type: none"> <li>■ Device tag</li> <li>■ Free text</li> </ul>	Device tag
Header text	Enter display header text.		-----
Separator	Select decimal separator for displaying numerical values.	<ul style="list-style-type: none"> <li>■ .</li> <li>■ ,</li> </ul>	.
Backlight	Switch the local display backlight on and off.	<ul style="list-style-type: none"> <li>■ Disable</li> <li>■ Enable</li> </ul>	Enable

## 10.7 Simulation

The **"Simulation" submenu** enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

-  The parameters displayed depend on:
- The selected device order
  - The set operating mode of the pulse/frequency/switch outputs

### Navigation

"Diagnostics" menu → Simulation

▶ Simulation

Assign simulation process variable

Value process variable

Simulation device alarm

Diagnostic event category

Simulation diagnostic event



### Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> <li>Off</li> <li>Volume flow</li> <li>Mass flow</li> </ul>	Off
Value process variable	A process variable is selected in the <b>Assign simulation process variable</b> parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0
Simulation device alarm	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> <li>Off</li> <li>On</li> </ul>	Off
Diagnostic event category	–	Select the category of the diagnostic event.	<ul style="list-style-type: none"> <li>Sensor</li> <li>Electronics</li> <li>Configuration</li> <li>Process</li> </ul>	Process
Simulation diagnostic event	–	Switch simulation of the diagnostic event on and off.  For the simulation, you can choose from the diagnostic events of the category selected in the <b>Diagnostic event category</b> parameter.	<ul style="list-style-type: none"> <li>Off</li> <li>Picklist Diagnostic events (depends on the selected category)</li> </ul>	Off

## 10.8 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code for the local display and Web browser (→ 76)
- Write protection via write protection switch (→ 77)
- Write protection via keypad lock (→ 55)

### 10.8.1 Write protection via access code

The effects of the customer-specific access code are as follows:

- Via local operation, the parameters for the measuring device configuration are write-protected and their values can no longer be changed.
- Device access via the Web browser is protected, as are the parameters for the measuring device configuration.


#### Navigation

"Setup" menu → Advanced setup → Administration → Define access code

#### Structure of the submenu

Define access code	→	Define access code
		Confirm access code

#### Defining the access code via local display

- Navigate to the **Enter access code** parameter.
- Define a max. 4-digit numeric code as an access code.
- Enter the access code again to confirm the code.
  - The -symbol appears in front of all write-protected parameters.



The device automatically locks the write-protected parameters again if a key is not pressed for 10 minutes in the navigation and editing view. The device locks the write-protected parameters automatically after 60 s if the user skips back to the operational display mode from the navigation and editing view.



- If write access is activated via access code, it can be also be deactivated only via the access code (→ 55).
- The user role with which the user is currently logged on via the local display is indicated by the **Access status display** parameter. Navigation path: "Operation" menu → Access status display.

### Parameters which can always be modified via the local display

Certain parameters that do not affect the measurement are excepted from write protection via the local display. Despite the defined access code, these parameters can always be modified even if the other parameters are locked.

### Defining the access code via the Web browser

1. Navigate to the **Enter access code** parameter.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
  - ↳ The Web browser switches to the login page.



If no action is performed for 10 minutes, the Web browser automatically returns to the login page.



The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling


## 10.8.2 Write protection via write protection switch

Unlike write protection via user-specific access code, this allows write access to the entire operating menu - other than the **"Contrast display" parameter** - to be locked.

The parameter values are now read only and cannot be edited any more (exception **"Contrast display" parameter**):



Via local display


1. Loosen the 4 fixing screws on the housing cover and open the housing cover.
2. Setting the write protection switch (WP) on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch (WP) on the main electronics module to the OFF position (factory setting) disables the hardware write protection.
  - ↳ If hardware write protection is enabled, the **Hardware locked** option is displayed in the **Locking status** parameter (→ 79). In addition, on the local display the -symbol appears in front of the parameters in the header of the operational display and in the navigation view.



A0015870



If hardware write protection is disabled, no option is displayed in the **Locking status** parameter (→  79). On the local display, the -symbol disappears from in front of the parameters in the header of the operational display and in the navigation view.

3. **WARNING!** Excessive tightening torque applied to the fixing screws! Risk of damaging the plastic transmitter. Tighten the fixing screws as per the tightening torque (→  27).

Reverse the removal procedure to reassemble the transmitter.



# 11 Operation

## 11.1 Reading device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

**Navigation**


"Operation" menu → Locking status

*Function scope of "Locking status" parameter*

Options	Description
None	The access status displayed in " <b>Access status display</b> " parameter applies (→ 55). Only appears on local display.
Hardware locked	The DIP switch for hardware locking is activated on the main electronics module. This prevents write access to the parameters (→ 77).
Temporarily locked	Due to internal processing in the device (e.g. up-/downloading of data, reset), write access to the parameters is blocked for a short time. Once the internal processing has been completed, the parameters can be changed once again.

## 11.2 Adjusting the operating language

Information (→ 62)

 For information on the operating languages supported by the measuring device (→ 117)

## 11.3 Configuring the display

- Basic settings for local display (→ 65)
- Advanced settings for local display (→ 73)

## 11.4 Reading measured values

Using the **Measured values** submenu , it is possible to read all the measured values.

"Diagnostics" menu → Measured values


### 11.4.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

**Navigation**

"Diagnostics" menu → Measured values → Process variables

**Structure of the submenu**





## Structure of the submenu

### Parameter overview with brief description


Parameter	Description	User interface
Volume flow	Displays the volume flow currently measured.	Signed floating-point number
Mass flow	Displays the mass flow currently calculated.	Signed floating-point number

### 11.4.2 Totalizer

The **"Totalizer"** submenu contains all the parameters needed to display the current measured values for every totalizer.

#### Navigation

"Diagnostics" menu → Measured values → Totalizer



### Parameter overview with brief description

Parameter	Description	User interface	Factory setting
Totalizer value @instance	Displays the current totalizer counter value.	Signed floating-point number	0 l
Totalizer overflow @instance	Displays the current totalizer overflow.	-32 000.0 to 32 000.0	0

## 11.5 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu(→ 63)
- Advanced settings using the **Advanced setup** submenu(→ 71)

### 11.6 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:

- Control Totalizer
- Reset all totalizers

#### Function scope of "Control Totalizer" parameter

Options	Description
Totalize	The totalizer is started.
Stop	Totalizing is stopped.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the <b>Preset value</b> parameter.



Options	Description
Reset + totalize	The totalizer is reset to 0 and the totaling process is restarted.
Preset + totalize	The totalizer is set to the defined start value in <b>Preset value</b> parameter and the totaling process is restarted.

#### Function scope of "Reset all totalizers" parameter

Options	Description
Reset + totalize	Resets all totalizers to 0 and restarts the totaling process. This deletes all the flow values previously totaled.

### Navigation

"Operation" menu → Operation

► Totalizer handling

Control Totalizer 1 to 3

Preset value 1 to 3

Reset all totalizers

#### Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Control Totalizer 1 to 3	Control totalizer value.	<ul style="list-style-type: none"> <li>■ Totalize</li> <li>■ Reset + hold</li> <li>■ Preset + hold</li> <li>■ Reset + totalize</li> <li>■ Preset + totalize</li> </ul>	Totalize
Preset value 1 to 3	Specify start value for totalizer.	Signed floating-point number	0 l
Reset all totalizers	Reset all totalizers to 0 and start.	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Reset + totalize</li> </ul>	Cancel

## 11.7 Showing data logging

In the device, the extended function of the HistoROM must be enabled (order option) so that the **"Data logging" submenu** appears. This contains all the parameters for the measured value history.




The data logging history is also available via the FieldCare plant asset management tool (→ 57).

#### Function scope

- A total of 1000 measured values can be stored
- 4 logging channels
- Adjustable logging interval for data logging
- Display of the measured value trend for each logging channel in the form of a chart





26 Chart of a measured value trend

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

**i** If the length of the logging interval or the assignment of the process variables to the channels is changed, the content of the data logging is deleted.

### Navigation

"Diagnostics" menu → Data logging

### "Data logging" submenu

▶ Data logging

Assign channel 1

Assign channel 2

Assign channel 3

Assign channel 4

Logging interval

Clear logging data

▶ Display channel 1

▶ Display channel 2

▶ Display channel 3

▶ Display channel 4



**Parameter overview with brief description**

Parameter	Description	Selection / User entry	Factory setting
Assign channel 1 to 4	Assign process variable to logging channel.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Flow velocity</li> <li>■ Electronic temperature</li> <li>■ Current output 1</li> </ul>	Off
Logging interval	Define the logging interval for data logging. This value defines the time interval between the individual data points in the memory.	1.0 to 3 600.0 s	10.0 s
Clear logging data	Clear the entire logging data.	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Clear data</li> </ul>	Cancel



## 12 Diagnostics and troubleshooting

### 12.1 General troubleshooting

*For local display*

Problem	Possible causes	Remedy
Local display dark and no output signals	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage .
Local display dark and no output signals	No contact between connecting cables and terminals.	Check the connection of the cables and correct if necessary.
Local display dark and no output signals	Terminals are not plugged into the main electronics module correctly.	Check terminals.
Local display dark and no output signals	Main electronics module is defective.	Order spare part (→ 100).
Local display dark and no output signals	The connector between the main electronics module and display module is not plugged in correctly.	Check the connection and correct if necessary.
Local display dark and no output signals	The connecting cable is not plugged in correctly.	1. Check the connection of the electrode cable and correct if necessary. 2. Check the connection of the coil current cable and correct if necessary.
Local display is dark, but signal output is within the valid range	Display is set too bright or too dark.	<ul style="list-style-type: none"> <li>Set the display brighter by simultaneously pressing <math>\boxplus</math> + <math>\boxminus</math>.</li> <li>Set the display darker by simultaneously pressing <math>\boxminus</math> + <math>\boxplus</math>.</li> </ul>
Local display is dark, but signal output is within the valid range	Display module is defective.	Order spare part (→ 100).
Backlighting of local display is red	Diagnostic event with "Alarm" diagnostic behavior has occurred.	Take remedial measures (→ 92)
Text on local display appears in a foreign language and cannot be understood.	Incorrect operating language is configured.	<ol style="list-style-type: none"> <li>Press <math>\boxminus</math> + <math>\boxplus</math> for 2 s ("home position").</li> <li>Press <math>\boxminus</math>.</li> <li>Set the desired language in the <b>Language</b> parameter.</li> </ol>
Message on local display: "Communication Error" "Check Electronics"	Communication between the display module and the electronics is interrupted.	<ul style="list-style-type: none"> <li>Check the cable and the connector between the main electronics module and display module.</li> <li>Order spare part (→ 100).</li> </ul>

*For output signals*

Problem	Possible causes	Remedy
Signal output outside the valid range	Main electronics module is defective.	Order spare part (→ 100).
Device shows correct value on local display, but signal output is incorrect, though in the valid range.	Configuration error	Check and correct parameter configuration.
Device measures incorrectly.	Configuration error or device is operated outside the application.	<ol style="list-style-type: none"> <li>Check and correct parameter configuration.</li> <li>Observe limit values specified in the "Technical Data".</li> </ol>



*For access*

Problem	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position (→ 77).
No write access to parameters	Current user role has limited access authorization	1. Check user role (→ 55). 2. Enter correct customer-specific access code (→ 55).
No connection via Modbus RS485	Modbus RS485 bus cable connected incorrectly	Check the terminal assignment .
No connection via Modbus RS485	Device plug connected incorrectly	Check the pin assignment of the device plug .
No connection via Modbus RS485	Modbus RS485 cable incorrectly terminated	Check terminating resistor (→ 40).
No connection via Modbus RS485	Incorrect settings for the communication interface	Check the Modbus RS485 configuration (→ 67).

## 12.2 Diagnostic information via light emitting diodes

### 12.2.1 Transmitter

Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.


LED	Color	Meaning
Power	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Alarm	Off	Device status is ok
	Flashing red	A device error of diagnostic behavior "Warning" has occurred
	Red	<ul style="list-style-type: none"> <li>■ A device error of diagnostic behavior "Alarm" has occurred</li> <li>■ Boot loader is active</li> </ul>
Communication	Flashing white	Modbus RS485 communication is active
Alarm	Green	Measuring device is ok
	Flashing green	Measuring device not configured
	Off	Firmware error
	Red	Main error
	Flashing red	Error
	Flashing red/green	Start measuring device



## 12.3 Diagnostic information on local display

### 12.3.1 Diagnostic message

Faults detected by the self-monitoring system of the measuring device are displayed as a diagnostic message in alternation with the operational display.



If two or more diagnostic events are pending simultaneously, only the message of the diagnostic event with the highest priority is shown.

- Other diagnostic events that have occurred can be called up in the **Diagnostics** menu:
  - Via parameters (→ 94)
  - Via submenus (→ 95)

### Status signals



The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

- The status signals are categorized according to VDI/VDE 2650 and NAMUR Recommendation NE 107: F = Failure, C = Function Check, S = Out of Specification, M = Maintenance Required

Symbol	Meaning
<b>F</b> A0013956	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
<b>C</b> A0013959	<b>Function check</b> The device is in service mode (e.g. during a simulation).
<b>S</b> A0013958	<b>Out of specification</b> The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
<b>M</b> A0013957	<b>Maintenance required</b> Maintenance is required. The measured value remains valid.




## Diagnostic behavior



Symbol	Meaning
 A0013961	<b>Alarm</b> <ul style="list-style-type: none"> <li>■ Measurement is interrupted.</li> <li>■ Signal outputs and totalizers assume the defined alarm condition.</li> <li>■ A diagnostic message is generated.</li> <li>■ The background lighting changes to red.</li> </ul>
 A0013962	<b>Warning</b> <p>Measurement is resumed. The signal outputs and totalizers are not affected. A diagnostic message is generated.</p>

### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.




## Operating elements

Key	Meaning
 A0013970	<b>Plus key</b> <i>In a menu, submenu</i> Opens the message about the remedial measures.
 A0013952	<b>Enter key</b> <i>In a menu, submenu</i> Opens the operating menu.



### 12.3.2 Calling up remedial measures



27 Message for remedial measures

- 1 Diagnostic information
- 2 Short text
- 3 Service ID
- 4 Diagnostic behavior with diagnostic code
- 5 Operation time of occurrence
- 6 Remedial measures

The user is in the diagnostic message.

1. Press  $\oplus$  (ⓘ symbol).  
↳ The **Diagnostic list** submenu opens.
2. Select the desired diagnostic event with  $\oplus$  or  $\ominus$  and press  $\boxplus$ .  
↳ The message for the remedial measures for the selected diagnostic event opens.
3. Press  $\ominus$  +  $\oplus$  simultaneously.  
↳ The message for the remedial measures closes.

The user is in the **Diagnostics** menu at an entry for a diagnostics event, e.g. in the **Diagnostic list** submenu or the **Previous diagnostics** parameter.

1. Press  $\boxplus$ .  
↳ The message for the remedial measures for the selected diagnostic event opens.
2. Press  $\ominus$  +  $\oplus$  simultaneously.  
↳ The message for the remedial measures closes.



## 12.4 Diagnostic information in the Web browser

### 12.4.1 Diagnostic options

Any faults detected by the measuring device are displayed in the Web browser on the home page once the user has logged on.

1 Status area with status signal  
 2 Diagnostic information (→ 87)  
 3 Remedial measures with Service ID

**i** Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameters (→ 94)
- Via submenus (→ 95)

### Status signals

The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
 A0017271	<b>Failure</b> A device error has occurred. The measured value is no longer valid.
 A0017278	<b>Function check</b> The device is in service mode (e.g. during a simulation).
 A0017277	<b>Out of specification</b> The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
 A0017276	<b>Maintenance required</b> Maintenance is required. The measured value is still valid.

**i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

### 12.4.2 Calling up remedy information


Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly. These measures are displayed in red along with the diagnostic event and the related diagnostic information.



## 12.5 Diagnostic information in FieldCare

### 12.5.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.




- 1 Status area with status signal (→ 86)
- 2 Diagnostic information (→ 87)
- 3 Remedial measures with Service ID

- Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:
- Via parameters (→ 94)
  - Via submenu (→ 95)

### Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault. In addition, the corresponding symbol for the diagnostic behavior is displayed in front of the diagnostic information on the local display.





### 12.5.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page  
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu  
Remedy information can be called up in the working area of the user interface.

The user is in the **Diagnostics** menu.


1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.  
↳ A tool tip with remedy information for the diagnostic event appears.

## 12.6 Diagnostic information via communication interface

### 12.6.1 Reading out diagnostic information

Diagnostic information can be read out via Modbus RS485 register addresses.

- Via register address **6821** (data type = string): diagnosis code, e.g. F270
- Via register address **6859** (data type = integer): diagnosis number, e.g. 270

 For an overview of diagnostic events with diagnosis number and diagnosis code  
(→  92)



### 12.6.2 Configuring error response mode

Error response mode for Modbus RS485 communication can be configured in the **Communication** submenu using 2 parameters.

#### Navigation path

"Setup" menu → Communication

*Parameter overview with brief description*

Parameter	Description	Options	Factory setting
Assign diagnostic behavior	Select diagnostic behavior for MODBUS communication.	<ul style="list-style-type: none"> <li>■ Off</li> <li>■ Alarm or warning</li> <li>■ Warning</li> <li>■ Alarm</li> </ul>	Alarm
Failure mode	Select measured value output behavior when a diagnostic message occurs via Modbus communication.   This parameter operates in accordance with the option selected in the <b>Assign diagnostic behavior</b> parameter.	<ul style="list-style-type: none"> <li>■ NaN value</li> <li>■ Last valid value</li> </ul>  NaN ≡ not a number	NaN value



## 12.7 Adapting the diagnostic information

### 12.7.1 Adapting the diagnostic behavior


Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostic information in the **Diagnostic behavior** submenu.



"Expert" menu → System → Diagnostic handling → Diagnostic behavior

You can assign the following options to the diagnostic number as the diagnostic behavior:

Options	Description
Alarm	Measurement is interrupted. Measured value output via Modbus RS485 and totalizers assume the defined alarm condition. A diagnostic message is generated. The background lighting changes to red.
Warning	Measurement is resumed. Measured value output via Modbus RS485 and totalizers are not affected. A diagnostics message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

## 12.8 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

 In the case of some items of diagnostic information, the status signal and the diagnostic behavior can be changed. Adapt the diagnostic information (→  92)

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
<b>Diagnostic of sensor</b>				
004	Sensor	1. Change sensor 2. Contact service	S	Alarm
022	Sensor temperature	1. Change main electronic module 2. Change sensor	F	Alarm
043	Sensor short circuit	1. Check sensor and cable 2. Change sensor or cable	S	Warning
062	Sensor connection	1. Check sensor connections 2. Contact service	F	Alarm
082	Data storage	1. Check module connections 2. Contact service	F	Alarm
083	Memory content	1. Restart device 2. Contact service	F	Alarm
190	Special event 1	Contact service	F	Alarm
<b>Diagnostic of electronic</b>				
201	Device failure	1. Restart device 2. Contact service	F	Alarm
222	Electronic drift	Change main electronic module	F	Alarm
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm



Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
252	Modules incompatible	1. Check electronic modules 2. Change electronic modules	F	Alarm
262	Module connection	1. Check module connections 2. Change main electronics	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
281	Electronic initialization	Firmware update active, please wait!	F	Alarm
283	Memory content	1. Reset device 2. Contact service	F	Alarm
302	Device verification active	Device verification active, please wait.	C	Warning
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
311	Electronic failure	1. Do not reset device 2. Contact service	M	Warning
322	Electronic drift	1. Perform verification manually 2. Change electronic	S	Warning
382	Data storage	1. Insert DAT module 2. Change DAT module	F	Alarm
383	Memory content	1. Restart device 2. Check or change DAT module 3. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
<b>Diagnostic of configuration</b>				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning
437	Configuration incompatible	1. Restart device 2. Contact service	F	Alarm
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
453	Flow override	Deactivate flow override	C	Warning
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
495	Simulation diagnostic event	Deactivate simulation	C	Warning
500	Electrode 1 potential exceeded	1. Check process cond. 2. Increase system pressure	F	Alarm
500	Electrode difference voltage too high	1. Check process cond. 2. Increase system pressure	F	Alarm
530	Electrode cleaning is running	1. Check process cond. 2. Increase system pressure	C	Warning






Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
531	Empty pipe detection	Execute EPD adjustment	S	Warning
537	Configuration	1. Check IP addresses in network 2. Change IP address	F	Warning
590	Special event 3	Contact service	F	Alarm
<b>Diagnostic of process</b>				
832	Electronic temperature too high	Reduce ambient temperature	S	Warning <sup>1)</sup>
833	Electronic temperature too low	Increase ambient temperature	S	Warning <sup>1)</sup>
834	Process temperature too high	Reduce process temperature	S	Warning <sup>1)</sup>
835	Process temperature too low	Increase process temperature	S	Warning <sup>1)</sup>
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
862	Empty pipe	1. Check for gas in process 2. Adjust empty pipe detection	S	Warning
882	Input signal	1. Check input configuration 2. Check external device or process conditions	F	Alarm
937	EMC interference	Change main electronic module	S	Warning <sup>1)</sup>
938	EMC interference	1. Check ambient conditions regarding EMC influence 2. Change main electronic module	F	Alarm
990	Special event 4	Contact service	F	Alarm


1) Diagnostic status is changeable.

## 12.9 Pending diagnostic events

The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

 To call up the measures to rectify a diagnostic event:


- Via local display (→  88)
- Via "FieldCare" operating tool (→  91)

 Other pending diagnostic events can be displayed in the **Diagnostic list** submenu (→  95)

### Navigation


"Diagnostics" menu

### Structure of the submenu






Parameter overview with brief description


Parameter	Prerequisite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	–
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	–




12.10 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

**Navigation path**  
**Diagnostics** menu→**Diagnostic list** submenu





 28 Illustrated using the example of the local display




- 
- To call up the measures to rectify a diagnostic event:
  - Via local display (→  88)
  - Via "FieldCare" operating tool (→  91)

12.11 Event logbook



12.11.1 Event history



 29 Illustrated using the example of the local display

- 
- To call up the measures to rectify a diagnostic event:
  - Via local display (→  88)
  - Via "FieldCare" operating tool (→  91)



 For filtering the displayed event messages (→  96)

### 12.11.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

#### Navigation path

"Diagnostics" menu → Event logbook → Filter options

#### Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

### 12.11.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1092	Trend data deleted
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1156	Memory error trend
I1157	Memory error event list
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1351	Empty pipe detection adjustment failure
I1353	Empty pipe detection adjustment ok
I1361	Wrong web server login
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1444	Device verification passed
I1445	Device verification failed



Info number	Info name
I1457	Failed:Measured error verification
I1459	Failed: I/O module verification
I1461	Failed: Sensor verification
I1462	Failed:Sensor electronic module verific.

## 12.12 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

### Navigation

"Setup" menu → Advanced setup → Administration → Device reset

The screenshot shows a web interface for device administration. At the top is a grey button labeled '► Administration'. Below it, indented, is another grey button labeled '► Define access code'. Under 'Define access code' are two text input fields: 'Define access code' and 'Confirm access code'. Further down and to the left is a text input field labeled 'Device reset'.

### Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Device reset	Restart or reset device manually.	<ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ To delivery settings</li> <li>■ Restart device</li> </ul>	Cancel

### 12.12.1 Function scope of "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

## 12.13 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

### Navigation

"Diagnostics" menu → Device information



► Device information

Device tag

Serial number

Firmware version

Device name

Order code

Extended order code 1

Extended order code 2

Extended order code 3

ENP version




IP address

Subnet mask

Default gateway

12.14    Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
07.2014	01.00.00	Option ??	Original firmware	Operating Instructions	BA01229D/06/EN/01.14

-  Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) (→ 116).
-  For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.
-  The manufacturer's information is available:

■ In the Download Area of the Endress+Hauser Internet site: [www.endress.com](http://www.endress.com) → Download

■ Specify the following details:

– Text search: Manufacturer's information

– Search range: documentation
- 98
- Endress+Hauser



## 13 Maintenance

### 13.1 Maintenance tasks

No special maintenance work is required.

#### 13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.

##### **WARNING**

**Cleaning agents can damage the plastic transmitter housing!**

- ▶ Do not use high-pressure steam.
- ▶ Only use the permitted cleaning agents specified.

**Permitted cleaning agents for the plastic transmitter housing**

- Commercially available household cleaners
- Methyl alcohol or isopropyl alcohol
- Mild soap solutions


#### 13.1.2 Interior cleaning

No interior cleaning is planned for the device.

#### 13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.


The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory) (→  119)

### 13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.

 For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

### 13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.

 Your Endress+Hauser Sales Center can provide detailed information on the services.



## 14 Repair

### 14.1 General notes

#### Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.


#### Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

### 14.2 Spare parts

 Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu (→  97).

### 14.3 Endress+Hauser services

 Contact your Endress+Hauser Sales Center for information on services and spare parts.

### 14.4 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at <http://www.endress.com/support/return-material>

### 14.5 Disposal

#### 14.5.1 Removing the measuring device

1. Switch off the device.
2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.



Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

### 14.5.2 Disposing of the measuring device

#### **WARNING**

**Danger to personnel and environment from fluids that are hazardous to health.**

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:

- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.




## 15 Accessories

Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).

### 15.1 Device-specific accessories

#### 15.1.1 For the transmitter

Accessories	Description
Display protection	Is used to protect the display against impact or scoring from sand in desert areas.  For details, see Special Documentation SD00333F
Connecting cable for remote version	Coil current and electrode cables, various lengths, reinforced cables available on request.
Post mounting kit	Post mounting kit for transmitter.
Compact → remote conversion kit	For converting a compact device version to a remote device version.



#### 15.1.2 For the sensor

Accessories	Description
Mounting kit	Consists of: <ul style="list-style-type: none"> <li>▪ 2 process connections</li> <li>▪ Threaded fasteners</li> <li>▪ Seals</li> </ul>


### 15.2 Service-specific accessories

Accessories	Description
Applicator	Software for selecting and sizing Endress+Hauser measuring devices: <ul style="list-style-type: none"> <li>▪ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections.</li> <li>▪ Graphic illustration of the calculation results</li> </ul> Administration, documentation and access to all project-related data and parameters throughout the entire life cycle of a project. Applicator is available: <ul style="list-style-type: none"> <li>▪ Via the Internet: <a href="https://wapps.endress.com/applicator">https://wapps.endress.com/applicator</a></li> <li>▪ On CD-ROM for local PC installation.</li> </ul>
W@M	Life cycle management for your plant W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle. The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records. W@M is available: <ul style="list-style-type: none"> <li>▪ Via the Internet: <a href="http://www.endress.com/lifecyclemanagement">www.endress.com/lifecyclemanagement</a></li> <li>▪ On CD-ROM for local PC installation.</li> </ul>



FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> For details, see Operating Instructions BA00027S and BA00059S</p>
Commubox FXA291	<p>Connects Endress+Hauser field devices with a CDI interface (= Endress+Hauser Common Data Interface) and the USB port of a computer or laptop.</p> <p> For details, see "Technical Information" TI00405C</p>

### 15.3 System components

Accessories	Description
Memograph M graphic display recorder	<p>The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <p> For details, see "Technical Information" TI00133R and Operating Instructions BA00247R</p>



## 16 Technical data


### 16.1 Application

The measuring device described in these Instructions is intended only for flow measurement of liquids with a minimum conductivity of 5 µS/cm.

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

### 16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of <i>Faraday's law of magnetic induction</i> .
Measuring system	<p>The device consists of a transmitter and a sensor.</p> <p>Two device versions are available:</p> <ul style="list-style-type: none"><li>■ Compact version - the transmitter and sensor form a mechanical unit.</li><li>■ Remote version – the transmitter and sensor are mounted separately from one another.</li></ul> <p>For information on the structure of the device (→  12)</p>

### 16.3 Input

Measured variable	<p><b>Direct measured variables</b></p> <p>Volume flow (proportional to induced voltage)</p> <p><b>Calculated measured variables</b></p> <p>Mass flow</p>
-------------------	---

Measuring range	<p>Typically v = 0.01 to 10 m/s (0.03 to 33 ft/s) with the specified accuracy</p> <p>Electrical conductivity: 5 to 10 000 µS/cm</p> <p><i>Flow characteristic values in SI units</i></p>
-----------------	--


Nominal diameter		Recommended flow	Factory settings		
[mm]	[in]	min./max. full scale value (v ~ 0.3/10 m/s)	Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
		[dm³/min]	[dm³/min]	[dm³]	[dm³/min]
25	1	9 to 300	75	0.5	1
40	1 ½	25 to 700	200	1.5	3
50	2	35 to 1 100	300	2.5	5
65	–	60 to 2 000	500	5	8
80	3	90 to 3 000	750	5	12
100	4	145 to 4 700	1 200	10	20



*Flow characteristic values in US units*


Nominal diameter		Recommended flow min./max. full scale value (v ~ 0.3/10 m/s)	Factory settings		
			Full scale value current output (v ~ 2.5 m/s)	Pulse value (~ 2 pulse/s)	Low flow cut off (v ~ 0.04 m/s)
[in]	[mm]	[gal/min]	[gal/min]	[gal]	[gal/min]
1	25	2.5 to 80	18	0.2	0.25
1 ½	40	7 to 190	50	0.5	0.75
2	50	10 to 300	75	0.5	1.25
–	65	16 to 500	130	1	2
3	80	24 to 800	200	2	2.5
4	100	40 to 1250	300	2	4

**Recommended measuring range**

"Flow limit" section (→  110)

Operable flow range Over 1000 : 1

**Input signal****External measured values**

Various pressure transmitters and temperature measuring devices can be ordered from Endress+Hauser: see "Accessories" section (→  103)

It is recommended to read in external measured values to calculate the following measured variables:

Corrected volume flow

*Fieldbus*

The measured values are written from the automation system to the measuring device via Modbus RS485.

## 16.4 Output

**Output signal****Modbus RS485**

Physical interface	In accordance with EIA/TIA-485-A standard
Terminating resistor	Integrated, can be activated via DIP switch on the transmitter electronics module

**Signal on alarm**

Depending on the interface, failure information is displayed as follows:

**Modbus RS485**

Failure mode	Choose from: <ul style="list-style-type: none"> <li>■ NaN value instead of current value</li> <li>■ Last valid value</li> </ul>
--------------	---



**Local display**

<b>Plain text display</b>	With information on cause and remedial measures
<b>Backlight</b>	Red backlighting indicates a device error.



Status signal as per NAMUR recommendation NE 107

**Operating tool**

- Via digital communication:  
Modbus RS485
- Via service interface

<b>Plain text display</b>	With information on cause and remedial measures
---------------------------	---

**Light emitting diodes (LED)**

<b>Status information</b>	<p>Status indicated by various light emitting diodes</p> <p>The following information is displayed depending on the device version:</p> <ul style="list-style-type: none"> <li>■ Supply voltage active</li> <li>■ Data transmission active</li> <li>■ Device alarm/error has occurred</li> </ul>
---------------------------	--

Low flow cut off      The switch points for low flow cut off are user-selectable.


Galvanic isolation      The following connections are galvanically isolated from each other:

- Outputs
- Power supply

**Protocol-specific data****Modbus RS485**

Protocol	Modbus Applications Protocol Specification V1.1
Device type	Slave
Slave address range	1 to 247
Broadcast address range	0
Function codes	<ul style="list-style-type: none"> <li>■ 03: Read holding register</li> <li>■ 04: Read input register</li> <li>■ 06: Write single registers</li> <li>■ 08: Diagnostics</li> <li>■ 16: Write multiple registers</li> <li>■ 23: Read/write multiple registers</li> </ul>
Broadcast messages	<p>Supported by the following function codes:</p> <ul style="list-style-type: none"> <li>■ 06: Write single registers</li> <li>■ 16: Write multiple registers</li> <li>■ 23: Read/write multiple registers</li> </ul>
Supported baud rate	<ul style="list-style-type: none"> <li>■ 1 200 BAUD</li> <li>■ 2 400 BAUD</li> <li>■ 4 800 BAUD</li> <li>■ 9 600 BAUD</li> <li>■ 19 200 BAUD</li> <li>■ 38 400 BAUD</li> <li>■ 57 600 BAUD</li> <li>■ 115 200 BAUD</li> </ul>



Data transfer mode	<ul style="list-style-type: none"> <li>■ ASCII</li> <li>■ RTU</li> </ul>
Data access	Each device parameter can be accessed via Modbus RS485.  For Modbus register information

## 16.5 Power supply

Terminal assignment (→  33)

Supply voltage

### Transmitter

Order code for "Power supply"	Terminal voltage	Frequency range
Option L	AC100 to 240 V	50/ 60 Hz, ±4 Hz
	AC/DC24 V	50/ 60 Hz, ±4 Hz

Power consumption

Order code for "Output"	Maximum power consumption
Option M: Modbus RS485	30 VA/8 W


Current consumption


### Transmitter

Order code for "Power supply"	Maximum Current consumption	Maximum switch-on current
Option L: AC 100 to 240 V	145 mA	25 A (< 5 ms)
Option L: AC/DC 24 V	350 mA	27 A (< 5 ms)

Power supply failure

- Totalizers stop at the last value measured.
- Configuration is retained in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Electrical connection (→  36)

Potential equalization (→  38)

Terminals



### Transmitter

- Supply voltage cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Signal cable: plug-in spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Electrode cable: spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)
- Coil current cable: spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)


### Sensor connection housing


Spring terminals for wire cross-sections 0.5 to 2.5 mm<sup>2</sup> (20 to 14 AWG)




Cable entries	<div><b>Cable entry thread</b><ul style="list-style-type: none"><li>■ M20 x 1.5</li><li>■ Via adapter:<ul style="list-style-type: none"><li>– NPT ½"</li><li>– G ½"</li></ul></li></ul><b>Cable gland</b><ul style="list-style-type: none"><li>■ For standard cable: M20 × 1.5 with cable Ø6 to 12 mm (0.24 to 0.47 in)</li><li>■ For reinforced cable: M20 × 1.5 with cable Ø9.5 to 16 mm (0.37 to 0.63 in)</li></ul><div> If metal cable entries are used, use a grounding plate.</div></div>
Cable specification	(→  31)

## 16.6 Performance characteristics

Reference operating conditions	<div><b>In accordance with DIN EN 29104</b><ul style="list-style-type: none"><li>■ Fluid temperature: +28±2 °C (+82±4 °F)</li><li>■ Ambient temperature range: +22±2 °C (+72±4 °F)</li><li>■ Warm-up period:30 min</li></ul><b>Installation</b><ul style="list-style-type: none"><li>■ Inlet run &gt; 10 × DN</li><li>■ Outlet run &gt; 5 × DN</li><li>■ Sensor and transmitter grounded.</li><li>■ The sensor is centered in the pipe.</li></ul></div>
Maximum measured error	<div><b>Error limits under reference operating conditions</b><p>o.r. = of reading</p><b>Volume flow</b><p>±0.5 % o.r. ± 1 mm/s (0.04 in/s)</p><div> Fluctuations in the supply voltage do not have any effect within the specified range.</div></div>



 30 Maximum measured error in % o.r.

**Accuracy of outputs**  
o.r. = of reading  
The outputs have the following base accuracy specifications.



*Current output*

<b>Accuracy</b>	Max. $\pm 5 \mu\text{A}$
-----------------	--------------------------

*Pulse/frequency output*

<b>Accuracy</b>	Max. $\pm 50 \text{ ppm o.r.}$ (across the complete ambient temperature range)
-----------------	--

Repeatability	o.r. = of reading <b>Volume flow</b> Max. $\pm 0.1 \% \text{ o.r.} \pm 0.5 \text{ mm/s}$ (0.02 in/s)
---------------	--


## 16.7 Installation


"Mounting requirements" ( $\rightarrow$   18)

## 16.8 Environment

Ambient temperature range	( $\rightarrow$  20)
---------------------------	---

**Temperature tables**

 Observe the interdependencies between the permitted ambient and fluid temperatures when operating the device in hazardous areas.

 For detailed information on the temperature tables, see the separate document entitled "Safety Instructions" (XA) for the device.

Storage temperature	<p>The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.</p> <ul style="list-style-type: none"> <li>■ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures.</li> <li>■ Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner.</li> <li>■ If protection caps or protective covers are mounted these should never be removed before installing the measuring device.</li> </ul>
---------------------	---


Degree of protection	<b>Transmitter</b> <ul style="list-style-type: none"> <li>■ As standard: IP66/67, type 4X enclosure</li> <li>■ When housing is open: IP20, type 1 enclosure</li> </ul>
----------------------	--

**Sensor**







As standard: IP66/67, type 4X enclosure

Shock resistance	<b>Compact version</b> 6 ms 30 g, according to IEC 60068-2-27  <b>Remote version</b> <ul style="list-style-type: none"> <li>■ Transmitter: 6 ms 30 g, according to IEC 60068-2-27</li> <li>■ Sensor: 6 ms 50 g, according to IEC 60068-2-27</li> </ul>
------------------	---



Vibration resistance	<p><b>Compact version</b></p> <ul style="list-style-type: none"> <li>■ Vibration sinusoidal, 1 g peak, according to IEC 60068-2-6</li> <li>■ Vibration broad-band random, 1.54 g rms, according to IEC 60068-2-64</li> </ul> <p><b>Remote version</b></p> <ul style="list-style-type: none"> <li>■ Transmitter <ul style="list-style-type: none"> <li>– Vibration sinusoidal, 1 g peak, according to IEC 60068-2-6</li> <li>– Vibration broad-band random, 1.54 g rms, according to IEC 60068-2-64</li> </ul> </li> <li>■ Sensor: <ul style="list-style-type: none"> <li>– Vibration sinusoidal, 2 g peak, according to IEC 60068-2-6</li> <li>– Vibration broad-band random, 2.70 g rms, according to IEC 60068-2-64</li> </ul> </li> </ul>
Mechanical load	<ul style="list-style-type: none"> <li>■ Protect the transmitter housing against mechanical effects, such as shock or impact; the use of the remote version is sometimes preferable.</li> <li>■ Never use the transmitter housing as a ladder or climbing aid.</li> </ul>
Electromagnetic compatibility (EMC)	<ul style="list-style-type: none"> <li>■ As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21)</li> <li>■ Complies with emission limits for industry as per EN 55011 (Class A)</li> </ul> <p> For details refer to the Declaration of Conformity.</p>

## 16.9 Process

Medium temperature range	0 to +60 °C (+32 to +140 °F) for polyamide
Pressure-temperature ratings	<p> An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document</p>
Pressure tightness	Measuring tube: 0 mbar abs. (0 psi abs.) at a medium temperature of ≤ +60 °C (+140 °F)
Flow limit	<p>The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:</p> <ul style="list-style-type: none"> <li>■ <math>v &lt; 2</math> m/s (6.56 ft/s): for abrasive fluids (e.g. potter's clay, lime milk, ore slurry)</li> <li>■ <math>v &gt; 2</math> m/s (6.56 ft/s): for fluids producing buildup (e.g. wastewater sludges)</li> </ul> <p> A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.</p> <p> For an overview of the measuring range full scale values, see the "Measuring range" section</p>
Pressure loss	<ul style="list-style-type: none"> <li>■ No pressure loss occurs if the sensor is installed in a pipe with the same nominal diameter.</li> <li>■ Pressure losses for configurations incorporating adapters according to DIN EN 545 (→  21)</li> </ul>
System pressure	(→  20)
Vibrations	(→  21)



## 16.10 Mechanical construction

### Design, dimensions



For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

### Weight

#### Compact version

Weight data:

- Including the transmitter
  - Order code for "Housing", option M, Q: 1.3 kg (2.9 lbs)
  - Order code for "Housing", option A, R: 2.0 kg (4.4 lbs)
- Excluding packaging material

*Weight in SI units*

EN 1092-1 (DIN 2501), JIS B2220		
DN [mm]	Weight [kg]	
	Order code for "Housing", option M, Q: Polycarbonate plastic	Order code for "Housing", option A, R: Aluminum, AlSi10Mg, coated
25	2.50	3.20
40	3.10	3.80
50	3.90	4.60
65	4.70	5.40
80	5.70	6.40
100	8.40	9.10

*Weight in US units*

ASME B16.5		
DN [in]	Weight [lbs]	
	Order code for "Housing", option M, Q: Polycarbonate plastic	Order code for "Housing", option A, R: Aluminum, AlSi10Mg, coated
1	5.51	7.06
1½	6.84	8.40
2	8.60	10.1
3	12.6	14.1
4	18.5	20.1

#### Transmitter remote version

*Wall-mount housing*

Depends on the material of the wall-mount housing:

- Polycarbonate plastic: 1.3 kg (2.9 lb)
- Aluminum, AlSi10Mg, coated: 2.0 kg (4.4 lb)



**Sensor remote version**

Weight data:

- Including sensor connection housing
- Excluding the connecting cable
- Excluding packaging material

*Weight in SI units*

EN 1092-1 (DIN 2501), JIS B2220	
DN [mm]	Weight [kg]
25	2.5
40	3.1
50	3.9
65	4.7
80	5.7
100	8.4

*Weight in US units*

ASME B16.5	
DN [in]	Weight [lbs]
1	5.5
1½	6.8
2	8.6
3	12.6
4	18.5

Measuring tube  
specification**Pressure rating EN (DIN)**

Pressure rating PN 16								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × M12 ×	145	5.71	54	2.13	24	0.94
40	1 ½	4 × M16 ×	170	6.69	68	2.68	38	1.50
50	2	4 × M16 ×	185	7.28	82	3.23	50	1.97
65 <sup>1)</sup>	–	4 × M16 ×	200	7.87	92	3.62	60	2.36
65 <sup>2)</sup>	–	8 × M16 ×	200	7.87	– <sup>3)</sup>	–	60	2.36
80	3	8 × M16 ×	225	8.86	116	4.57	76	2.99
100	4	8 × M16 ×	260	10.24	147	5.79	97	3.82

1) EN (DIN) flange: 4-hole → with centering sleeves

2) EN (DIN) flange: 8-hole → without centering sleeves

3) A centering sleeve is not required. The device is centered directly via the sensor housing.



**ASME pressure rating**

Pressure rating Class 150								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × UNC ½" ×	145	5.70	– <sup>1)</sup>	–	24	0.94
40	1 ½	4 × UNC ½" ×	165	6.50	–	–	38	1.50
50	2	4 × UNC 5/8" ×	190.5	7.50	–	–	50	1.97
80	3	8 × UNC 5/8" ×	235	9.25	–	–	76	2.99
100	4	8 × UNC 5/8" ×	264	10.4	147	5.79	97	3.82

1) A centering sleeve is not required. The device is centered directly via the sensor housing.

**Pressure rating JIS**

Pressure rating 10K								
DN		Mounting bolts			Length Centering sleeves		internal diameter Measuring tube	
[mm]	[in]		[mm]	[in]	[mm]	[in]	[mm]	[in]
25	1	4 × M16 ×	170	6.69	54	2.13	24	0.94
40	1 ½	4 × M16 ×	170	6.69	68	2.68	38	1.50
50	2	4 × M16 ×	185	7.28	– <sup>1)</sup>	–	50	1.97
65	–	4 × M16 ×	200	7.87	–	–	60	2.36
80	3	8 × M16 ×	225	8.86	–	–	76	2.99
100	4	8 × M16 ×	260	10.24	–	–	97	3.82

1) A centering sleeve is not required. The device is centered directly via the sensor housing.

**Materials****Transmitter housing****Order Code for "Housing"**


- Compact version, standard:
  - Option **A**: aluminum, AlSi10Mg, coated
  - Option **M**: polycarbonate plastic
- Compact version, inclined:
  - Option **Q**: polycarbonate plastic
  - Option **R**: aluminum, AlSi10Mg, coated
- Remote version (wall-mount housing):
  - Option **N**: polycarbonate plastic
  - Option **P**: aluminum, AlSi10Mg, coated

*Window material*

Transmitter housing material	Window material
Polycarbonate plastic	Plastic
Aluminum, AlSi10Mg, coated	Glass



Cable entries/cable glands



31 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G 1/2" or NPT 1/2"

Compact and remote versions and sensor connection housing

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Plastic
Remote version: cable gland M20 × 1.5 Option of reinforced connecting cable	<ul style="list-style-type: none"> <li>■ Sensor connection housing: Nickel-plated brass</li> <li>■ Transmitter wall-mount housing: Plastic</li> </ul>
Adapter for cable entry with internal thread G 1/2" or NPT 1/2"	Nickel-plated brass

Connecting cable for remote version

Electrode and coil current cable

- Standard cable: PVC cable with copper shield
- Reinforced cable: PVC cable with copper shield and additional steel wire braided jacket

Sensor housing

Aluminum, AlSi10Mg, coated

Sensor connection housing

Aluminum, AlSi10Mg, coated

Sensor cable entries

Order code for "Housing", option N "Remote, polycarbonate" or option P "Remote, coated aluminum"

The various cable entries are suitable for hazardous and non-hazardous areas.

Electrical connection	Material
Cable gland M20 × 1.5	Nickel-plated brass
Thread G 1/2" via adapter	Nickel-plated brass
Thread NPT 1/2" via adapter	Nickel-plated brass



**Liner**

Polyamide

**Electrodes**

Stainless steel, 1.4435/F316L

**Process connections**

- EN 1092-1 (DIN 2501)
- ASME B16.5
- JIS B2220



List of all available process connections

**Seals**

O-rings made from EPDM

**Accessories**

*Display protection*

Stainless steel, 1.4301 (304L)

*Ground disks*

Stainless steel ,1.4301/304

---

Mounting bolts

**Tensile strength**

- Galvanized steel mounting bolts: strength category 5.6 or 5.8
- Stainless steel mounting bolts: strength category A2-70

---

Fitted electrodes


2 measuring electrodes made of 1.4435 (316L)

---

Process connections

- EN 1092-1 (DIN 2501)
- ASME B16.5
- JIS B2220



For information on the materials of the process connections (→  115)




## 16.11 Operability

---

Local operation

Via display module






A0020538

### Display elements

- 4-line display
- White background lighting; switches to red in event of device errors
- Format for displaying measured variables and status variables can be individually configured
- Permitted ambient temperature for the display:  $-20$  to  $+50$  °C ( $-4$  to  $+122$  °F)  
The readability of the display may be impaired at temperatures outside the temperature range.

### Operating elements

External operation via touch control; 3 optical keys: , , 

### Additional functionality

- Data backup function  
The device configuration can be saved in the display module.
- Data comparison function  
The device configuration saved in the display module can be compared to the current device configuration.
- Data transfer function  
The transmitter configuration can be transmitted to another device using the display module.

---

Remote operation


---

Service interface

Service interface (CDI-RJ45)



Modbus RS485



- 1 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 2 Standard Ethernet connecting cable with RJ45 plug
- 3 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server

Languages	<p>Can be operated in the following languages:</p> <ul style="list-style-type: none"><li>■ Via local display: English, German, French, Spanish, Italian, Dutch, Portuguese, Polish, Russian, Turkish, Chinese, Japanese, Bahasa (Indonesian), Vietnamese, Czech</li><li>■ Via "FieldCare" operating tool: English, German, French, Spanish, Italian, Chinese, Japanese</li></ul>
-----------	--

16.12 Certificates and approvals

CE mark	<p>The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
C-Tick symbol	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Control Drawing" document. Reference is made to this document on the nameplate.</p>
Drinking water approval	<ul style="list-style-type: none"><li>■ ACS</li><li>■ KTW/W270</li><li>■ NSF 61</li><li>■ WRAS BS 6920</li></ul>
Modbus RS485 certification	<p>The measuring device meets all the requirements of the MODBUS/TCP conformity test and has the "MODBUS/TCP Conformance Test Policy, Version 2.0". The measuring device has successfully passed all the test procedures carried out and is certified by the "MODBUS/TCP Conformance Test Laboratory" of the University of Michigan.</p>



## Other standards and guidelines

- EN 60529  
Degrees of protection provided by enclosures (IP code)
- EN 61010-1  
Safety requirements for electrical equipment for measurement, control and laboratory use
- IEC/EN 61326  
Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements).
- ANSI/ISA-61010-1 (82.02.01): 2004  
Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements
- CAN/CSA-C22.2 No. 61010-1-04  
Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use - Part 1 General Requirements
- NAMUR NE 21  
Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment
- NAMUR NE 32  
Data retention in the event of a power failure in field and control instruments with microprocessors
- NAMUR NE 43  
Standardization of the signal level for the breakdown information of digital transmitters with analog output signal.
- NAMUR NE 53  
Software of field devices and signal-processing devices with digital electronics
- NAMUR NE 105  
Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107  
Self-monitoring and diagnosis of field devices
- NAMUR NE 131  
Requirements for field devices for standard applications

## 16.13 Application packages

Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered from Endress+Hauser either directly with the device or subsequently. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: [www.endress.com](http://www.endress.com).

## Diagnostics functions



Package	Description
HistoROM extended function	<p>Comprises extended functions concerning the event log and the activation of the measured value memory.</p> <p>Event log: Memory volume is extended from 20 message entries (basic version) to up to 100 entries.</p> <p>Data logging (line recorder):</p> <ul style="list-style-type: none"> <li>■ Memory capacity for up to 1000 measured values is activated.</li> <li>■ 250 measured values can be output via each of the 4 memory channels. The recording interval can be defined and configured by the user.</li> <li>■ Data logging is visualized via the local display or FieldCare.</li> </ul>




## Heartbeat Technology

Package	Description
Heartbeat Verification +Monitoring	<p><b>Heartbeat Monitoring:</b> Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to:</p> <ul style="list-style-type: none"> <li>■ Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time.</li> <li>■ Schedule servicing in time.</li> <li>■ Monitor the product quality, e.g. gas pockets.</li> </ul> <p><b>Heartbeat Verification:</b> Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process.</p> <ul style="list-style-type: none"> <li>■ Access via onsite operation or other operating interfaces, such as FieldCare for instance.</li> <li>■ End-to-end, traceable documentation of the verification results, including report.</li> <li>■ Makes it possible to extend calibration intervals in accordance with operator's risk assessment.</li> </ul>

## 16.14 Accessories

 Overview of accessories available for order (→  102)

## 16.15 Supplementary documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
  - The *W@M Device Viewer* : Enter the serial number from the nameplate ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer))
  - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

## Standard documentation

### Brief Operating Instructions

Measuring device	Documentation code
Promag D 400	KA01112D

### Technical Information

Measuring device	Documentation code
Promag D 400	TI01044D



## Supplementary device-dependent documentation

### Special Documentation

Contents	Documentation code
Modbus RS485 Register Information	SD01379D
Heartbeat Technology	SD01183D



Installation Instructions

Contents	Documentation code
Installation Instructions for spare part sets	 Overview of accessories available for order (→  102)



# 17 Appendix

## 17.1 Overview of the operating menu

The following tables provide an overview of the entire operating menu structure with menus and parameters. The page reference indicates where a description of the parameter can be found in the manual.

Display language	(→ 75)
Operation	(→ 121)
Setup	(→ 122)
Diagnostics	(→ 125)
Expert	(→ 129)

### 17.1.1 "Operation" menu

Navigation Operation

Operation	(→ 79)
Display language	(→ 75)
Web server language	
Access status display	
Access status tooling	
Locking status	
► Display	(→ 65)
Format display	(→ 66)
Contrast display	
Backlight	(→ 75)
Display interval	(→ 75)
► Totalizer handling	
Control Totalizer 1 to 3	(→ 81)
























<div>Preset value 1 to 3</div>	(→ ⓘ 81)
<div>Reset all totalizers</div>	(→ ⓘ 81)

17.1.2 "Setup" menu
























Navigation ⓘ ⓘ Setup

<div>⚙ Setup</div>	(→ ⓘ 63)
<div>Device tag</div>	(→ ⓘ 64)
<div>▶ System units</div>	(→ ⓘ 64)
<div>Volume flow unit</div>	(→ ⓘ 64)
<div>Volume unit</div>	(→ ⓘ 64)
<div>Conductivity unit</div>	
<div>Temperature unit</div>	(→ ⓘ 65)
<div>Mass flow unit</div>	(→ ⓘ 65)
<div>Mass unit</div>	(→ ⓘ 65)
<div>Density unit</div>	(→ ⓘ 65)
<div>▶ Communication</div>	(→ ⓘ 67)
<div>Bus address</div>	(→ ⓘ 67)
<div>Baudrate</div>	(→ ⓘ 67)
<div>Data transfer mode</div>	(→ ⓘ 67)
<div>Parity</div>	(→ ⓘ 68)
<div>Byte order</div>	(→ ⓘ 68)
<div>Failure mode</div>	(→ ⓘ 68)
<div>▶ Display</div>	(→ ⓘ 65)
<div>Format display</div>	(→ ⓘ 66)
<div>Value 1 display</div>	(→ ⓘ 66)



0% bargraph value 1	(→  66)
100% bargraph value 1	(→  66)
Value 2 display	(→  66)
Value 3 display	(→  67)
0% bargraph value 3	(→  67)
100% bargraph value 3	(→  67)
Value 4 display	(→  67)
<b>► Low flow cut off</b>	(→  68)
Assign process variable	(→  69)
On value low flow cutoff	(→  69)
Off value low flow cutoff	(→  69)
Pressure shock suppression	(→  69)
<b>► Empty pipe detection</b>	(→  70)
Empty pipe detection	(→  70)
New adjustment	(→  70)
Switch point empty pipe detection	(→  70)
Response time empty pipe detection	(→  70)
<b>► Advanced setup</b>	
Enter access code	
<b>► Sensor adjustment</b>	(→  71)
Installation direction	(→  71)
<b>► Totalizer 1 to 3</b>	(→  72)
Assign process variable	(→  72)
Unit totalizer	



Totalizer operation mode	(→  72)
Failure mode	(→  72)
► Display	(→  65)
Format display	(→  66)
Value 1 display	(→  66)
0% bargraph value 1	(→  66)
100% bargraph value 1	(→  66)
Decimal places 1	(→  74)
Value 2 display	(→  66)
Decimal places 2	(→  74)
Value 3 display	(→  67)
0% bargraph value 3	(→  67)
100% bargraph value 3	(→  67)
Decimal places 3	(→  74)
Value 4 display	(→  67)
Decimal places 4	(→  74)
Display language	(→  75)
Display interval	(→  75)
Display damping	(→  75)
Header	(→  75)
Header text	(→  75)
Separator	(→  75)
Backlight	(→  75)
► Electrode cleaning circuit	
Electrode cleaning circuit	



ECC duration

ECC recovery time

ECC cleaning cycle

ECC Polarity

► Administration

(→ ⓘ 97)

► Define access code

(→ ⓘ 76)

Define access code

Confirm access code

Device reset

(→ ⓘ 97)

17.1.3 "Diagnostics" menu

Navigation ⓘ ⓘ Diagnostics

ⓘ Diagnostics

(→ ⓘ 94)

Actual diagnostics

(→ ⓘ 95)

Previous diagnostics

(→ ⓘ 95)

Operating time from restart

Operating time

► Diagnostic list

Diagnostics 1

Timestamp

Diagnostics 2

Timestamp

Diagnostics 3

Timestamp

Diagnostics 4



Timestamp

Diagnostics 5

Timestamp

▶ Event logbook

Filter options

▶ Event list

▶ Device information

(→ ⓘ 97)

Device tag

Serial number

Firmware version

Device name

Order code

Extended order code 1

Extended order code 2

Extended order code 3

ENP version

IP address

Subnet mask

Default gateway

▶ Measured values

▶ Process variables

(→ ⓘ 79)

Volume flow

(→ ⓘ 80)





Mass flow	(→ ⓘ 80)
Conductivity	
► Totalizer	(→ ⓘ 72)
Totalizer value 1 to 3	(→ ⓘ 80)
Totalizer overflow 1 to 3	(→ ⓘ 80)
► Data logging	(→ ⓘ 81)
Assign channel 1	(→ ⓘ 83)
Assign channel 2	
Assign channel 3	
Assign channel 4	
Logging interval	(→ ⓘ 83)
Clear logging data	(→ ⓘ 83)
► Display channel 1	
► Display channel 2	
► Display channel 3	
► Display channel 4	
► Heartbeat	
► Performing verification	
Year	
Month	
Day	
Hour	
AM/PM	
Minute	
Verification mode	



External device information	
External reference voltage 1	
External reference voltage 2	
Start verification	
Progress	
Status	
Overall result	
► Verification results	
Date/time	
Verification ID	
Operating time	
Overall result	
Sensor	
Sensor electronic module	
I/O module	
► Monitoring results	
Noise	
Coil current shot time	
Reference electrode potential against PE	
► Simulation	(→ ⓘ 75)
Assign simulation process variable	(→ ⓘ 76)
Value process variable	(→ ⓘ 76)
Simulation device alarm	(→ ⓘ 76)








<div>Diagnostic event category</div>	(→  76)
<div>Simulation diagnostic event</div>	(→  76)

17.1.4 "Expert" menu





The following tables provide an overview of the **Expert** menu with its submenus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.

Navigation  Expert

<div>Expert</div>	
<div>Direct access (0106)</div>	
<div>Locking status (0004)</div>	
<div>Access status display (0091)</div>	
<div>Access status tooling (0005)</div>	
<div>Enter access code (0003)</div>	
<div>► System</div>	(→  129)
<div>► Sensor</div>	(→  131)
<div>► Communication</div>	(→  136)
<div>► Application</div>	(→  137)
<div>► Diagnostics</div>	(→  137)

"System" submenu


Navigation   Expert → System

<div>► System</div>	
<div>► Display</div>	(→  65)
<div>Display language (0104)</div>	(→  75)
<div>Format display (0098)</div>	(→  66)
<div>Value 1 display (0107)</div>	(→  66)




0% bargraph value 1 (0123)	(→ ⓘ 66)
100% bargraph value 1 (0125)	(→ ⓘ 66)
Decimal places 1 (0095)	(→ ⓘ 74)
Value 2 display (0108)	(→ ⓘ 66)
Decimal places 2 (0117)	(→ ⓘ 74)
Value 3 display (0110)	(→ ⓘ 67)
0% bargraph value 3 (0124)	(→ ⓘ 67)
100% bargraph value 3 (0126)	(→ ⓘ 67)
Decimal places 3 (0118)	(→ ⓘ 74)
Value 4 display (0109)	(→ ⓘ 67)
Decimal places 4 (0119)	(→ ⓘ 74)
Display interval (0096)	(→ ⓘ 75)
Display damping (0094)	(→ ⓘ 75)
Header (0097)	(→ ⓘ 75)
Header text (0112)	(→ ⓘ 75)
Separator (0101)	(→ ⓘ 75)
Contrast display (0105)	
Backlight (0111)	(→ ⓘ 75)
Access status display (0091)	
▶ Diagnostic handling	
Alarm delay (0651)	
▶ Diagnostic behavior	
Assign behavior of diagnostic no. 531 (0741)	
Assign behavior of diagnostic no. 832 (0681)	















"Sensor" submenu










Navigation ⓘ ⓘ Expert → Sensor





<b>► System units</b>		(→  64)
Volume flow unit (0553)		(→  64)
Volume unit (0563)		(→  64)
Conductivity unit (0582)		
Temperature unit (0557)		(→  65)
Mass flow unit (0554)		(→  65)
Mass unit (0574)		(→  65)
Density unit (0555)		(→  65)
Date/time format (2812)		
<b>► User-specific units</b>		
User volume text (0567)		
User volume offset (0569)		
User volume factor (0568)		
User mass text (0560)		
User mass offset (0562)		
User mass factor (0561)		
<b>► Process parameters</b>		
Filter options (6710)		
Flow damping (6661)		
Flow override (1839)		
Conductivity damping (1803)		
Conductivity measurement (6514)		
<b>► Low flow cut off</b>		(→  68)
Assign process variable (1837)		(→  69)
On value low flow cutoff (1805)		(→  69)



Off value low flow cutoff (1804)	(→  69)
Pressure shock suppression (1806)	(→  69)
► Empty pipe detection	(→  70)
Empty pipe detection (1860)	(→  70)
Switch point empty pipe detection (6562)	(→  70)
Response time empty pipe detection (1859)	(→  70)
Empty pipe adjust value (6527)	
Full pipe adjust value (6548)	
Measured value EPD (6559)	
► Empty pipe adjust	
New adjustment (6560)	(→  70)
► Electrode cleaning circuit	
Electrode cleaning circuit (6528)	
ECC duration (6555)	
ECC recovery time (6556)	
ECC cleaning cycle (6557)	
ECC Polarity (6631)	
► External compensation	
Density source (6615)	
External density (6630)	
Fixed density (6623)	
► Sensor adjustment	(→  71)
Installation direction (1809)	(→  71)
Integration time (6533)	



Measuring period (6536)

► Process variable adjustment

Volume flow offset (1831)

Volume flow factor (1832)

Mass flow offset (1841)

Mass flow factor (1846)

Conductivity offset (1848)

Conductivity factor (1849)

► Calibration


Nominal diameter (2807)

Calibration factor (6522)

Zero point (6546)

Conductivity calibration factor (6718)

"Current input" submenu

Navigation  Expert → Input → Current input

► Input

► Current input

Current span (1605)

4 mA value (1606)

20 mA value (1607)

Failure mode (1601)

Failure value (1602)



**► Output****► Pulse/frequency/switch output**

Operating mode (0469)

Assign pulse output (0460)

Value per pulse (0455)

Pulse width (0452)

Failure mode (0480)

Pulse output (0456)

Assign frequency output (0478)

Minimum frequency value (0453)

Maximum frequency value (0454)

Measuring value at minimum  
frequency (0476)Measuring value at maximum  
frequency (0475)

Damping output (0477)

Response time (0491)

Failure mode (0451)

Failure frequency (0474)

Output frequency (0471)

Switch output function (0481)

Assign diagnostic behavior (0482)

Assign limit (0483)

Switch-on value (0466)

Switch-off value (0464)

Assign flow direction check (0484)



Assign status (0485)

Switch-on delay (0467)

Switch-off delay (0465)

Failure mode (0486)

Switch status (0461)

Invert output signal (0470)

► Communication

(→ ⓘ 67)

► Modbus configuration

Bus address (7112) (→ ⓘ 67)

Baudrate (7111) (→ ⓘ 67)

Data transfer mode (7115) (→ ⓘ 67)

Parity (7122) (→ ⓘ 68)

Byte order (7113) (→ ⓘ 68)

Telegram delay (7146)

Failure mode (7116) (→ ⓘ 68)

► Modbus information

Device ID (7153)

Device revision (7154)

► Modbus data map

Scan list register 0 to 15 (7114)

► Web server

Web server language (7221)

MAC address (7214)

IP address (7209)

136

Endress+Hauser



Subnet mask (7211)

Default gateway (7210)

Web server functionality (7222)

► Application

Reset all totalizers (2806)

(→ ⓘ 81)

► Totalizer 1 to 3

(→ ⓘ 72)

Assign process variable (0914-1 to 3)

(→ ⓘ 72)

Unit totalizer (0915-1 to 3)

Totalizer operation mode (0908-1 to 3)

(→ ⓘ 72)

Control Totalizer 1 to 3 (0912-1 to 3)

(→ ⓘ 81)

Preset value 1 to 3 (0913-1 to 3)

(→ ⓘ 81)

Failure mode (0901-1 to 3)

(→ ⓘ 72)

► Diagnostics

(→ ⓘ 94)

Actual diagnostics (0691)

(→ ⓘ 95)

Previous diagnostics (0690)

(→ ⓘ 95)

Operating time from restart (0653)

Operating time (0652)

► Diagnostic list

Diagnostics 1 (0692)

Timestamp (0683)



Diagnostics 2 (0693)

Timestamp (0684)



	Diagnostics 3 (0694)	
	Timestamp (0685)	
	Diagnostics 4 (0695)	
	Timestamp (0686)	
	Diagnostics 5 (0696)	
	Timestamp (0687)	
	► Event logbook	
	Filter options (0705)	
	► Event list	
	► Device information	(→ ⓘ 97)
	Device tag (0011)	
	Serial number (0009)	
	Firmware version (0010)	
	Device name (0013)	
	Order code (0008)	
	Extended order code 1 (0023)	
	Extended order code 2 (0021)	
	Extended order code 3 (0022)	
	Configuration counter (2751)	
	ENP version (0012)	
	► Data logging	(→ ⓘ 81)
	Assign channel 1 (0851)	(→ ⓘ 83)
	Assign channel 2 (0852)	
	Assign channel 3 (0853)	
	Assign channel 4 (0854)	



Logging interval (0856)	(→  83)
Clear logging data (0855)	(→  83)
<b>► Display channel 1</b>	
<b>► Display channel 2</b>	
<b>► Display channel 3</b>	
<b>► Display channel 4</b>	
<b>► Min/max values</b>	
Reset min/max values (6541)	
<b>► Main electronic temperature</b>	
Minimum value (6547)	
Maximum value (6545)	
<b>► Heartbeat</b>	
<b>► Heartbeat base settings</b>	
Plant operator (2754)	
Location (2755)	
<b>► Performing verification</b>	
Year (2846)	
Month (2845)	
Day (2842)	
Hour (2843)	
AM/PM (2813)	
Minute (2844)	
Verification mode (12105)	
External device information (12101)	
External reference voltage 1 (12106)	



External reference voltage 2 (12107)	
Start verification (12127)	
Progress (2808)	
Status (12153)	
Overall result (12149)	
► Verification results	
Date/time (12142)	
Verification ID (12141)	
Operating time (12126)	
Overall result (12149)	
Sensor (12152)	
Sensor electronic module (12151)	
I/O module (12145)	
► Monitoring results	
Noise (12158)	
Coil current shot time (12150)	
Reference electrode potential against PE (12155)	
► Simulation	(→ ⓘ 75)
Assign simulation process variable (1810)	(→ ⓘ 76)
Value process variable (1811)	(→ ⓘ 76)
Simulation device alarm (0654)	(→ ⓘ 76)
Diagnostic event category (0738)	(→ ⓘ 76)
Simulation diagnostic event (0737)	(→ ⓘ 76)



# Index

## A

Access authorization to parameters	
Read access	55
Write access	55
Access code	55
Incorrect input	55
Adapters	21
Adapting the diagnostic behavior	92
Ambient temperature range	20
Application	9, 104
Applicator	104
Approvals	117
Auto scan buffer	
see Modbus RS485 Modbus data map	

## C

C-Tick symbol	117
Cable entries	
Technical data	108
Cable entry	
Degree of protection	41
CE mark	10, 117
Certificates	117
Checklist	
Post-connection check	41
Post-installation check	30
Cleaning	
Exterior cleaning	99
Interior cleaning	99
Commissioning	62
Advanced settings	71
Configuring the measuring device	63
Configuring error response mode, Modbus RS485	91
Connecting cable	31
Connecting the measuring device	36
Connection	
see Electrical connection	
Connection examples, potential equalization	38
Connection preparations	34
Connection tools	31
Context menu	
Closing	50
Explanation	50
Opening	50
Current consumption	107
Current input (Submenu)	134

## D

Declaration of Conformity	10
Define access code	76, 77
Degree of protection	41, 109
Design	
Measuring device	12
Designated use	9
Device components	12
Device description files	58

Device documentation	
Supplementary documentation	8
Device locking, status	79
Device name	
Sensor	15
Transmitter	14
Device repair	100
Device revision	58
Device type ID	58
Diagnostic behavior	
Explanation	87
Symbols	87
Diagnostic information	
Communication interface	91
Design, description	87, 90
FieldCare	90
Light emitting diodes	85
Local display	86
Overview	92
Remedial measures	92
Web browser	89
Diagnostic list	95
Diagnostic message	86
Diagnostics	
Symbols	86
Diagnostics (Menu)	125
DIP switch	
see Write protection switch	
Direct access	52
Direct access code	47
Disabling write protection	76
Display	
Current diagnostic event	94
Previous diagnostic event	94
see Local display	
Display area	
For operational display	45
In the navigation view	47
Display values	
For locking status	79
Disposal	100
Document	
Function	6
Symbols used	6
Document function	6
Down pipe	18
Drinking water approval	117

## E

Electrical connection	
Degree of protection	41
Measuring device	31
Operating tools	
Via service interface (CDI-RJ45)	56
Web server	56
Electromagnetic compatibility	110



Enabling write protection . . . . .	76
Endress+Hauser services	
Maintenance . . . . .	99
Repair . . . . .	100
Environment	
Ambient temperature . . . . .	20
Mechanical load . . . . .	110
Shock resistance . . . . .	109
Storage temperature . . . . .	109
Vibration resistance . . . . .	110
Error messages	
see Diagnostic messages	
Event history . . . . .	95
Events list . . . . .	95
Ex approval . . . . .	117
Expert (Menu) . . . . .	129
Extended order code	
Sensor . . . . .	15
Transmitter . . . . .	14
Exterior cleaning . . . . .	99
<b>F</b>	
Field of application	
Residual risks . . . . .	10
FieldCare . . . . .	57
Device description file . . . . .	58
Establishing a connection . . . . .	57
Function . . . . .	57
User interface . . . . .	57
Filtering the event logbook . . . . .	96
Firmware	
Release date . . . . .	58
Version . . . . .	58
Firmware history . . . . .	98
Fitted electrodes . . . . .	115
Flow direction . . . . .	19
Flow limit . . . . .	110
Function check . . . . .	62
Function codes . . . . .	58
Functions	
see Parameter	
<b>G</b>	
Galvanic isolation . . . . .	106
<b>H</b>	
Hardware write protection . . . . .	77
Help text	
Calling up . . . . .	53
Close . . . . .	53
Explanation . . . . .	53
<b>I</b>	
I/O electronics module . . . . .	12, 38
Identifying the measuring device . . . . .	13
Incoming acceptance . . . . .	13
Information on the document . . . . .	6
Inlet runs . . . . .	19
Input . . . . .	104
Input mask . . . . .	48

Inspection	
Installation . . . . .	30
Received goods . . . . .	13
Inspection check	
Connection . . . . .	41
Installation . . . . .	18
Installation conditions	
Adapters . . . . .	21
Down pipe . . . . .	18
Inlet and outlet runs . . . . .	19
Mounting kit . . . . .	22
Mounting location . . . . .	18
Orientation . . . . .	19
Partially filled pipe . . . . .	18
System pressure . . . . .	20
Vibrations . . . . .	21
Installation dimensions . . . . .	20
Interior cleaning . . . . .	99
<b>K</b>	
Keypad lock	
Disabling . . . . .	55
Enabling . . . . .	55
<b>L</b>	
Languages, operation options . . . . .	117
Line recorder . . . . .	81
Local display . . . . .	116
Editing view . . . . .	48
Navigation view . . . . .	46
see Diagnostic message	
see In alarm condition	
see Operational display	
Low flow cut off . . . . .	106
<b>M</b>	
Main electronics module . . . . .	12
Maintenance tasks . . . . .	99
Replacing seals . . . . .	99
Manufacturer ID . . . . .	58
Manufacturing date . . . . .	14, 15
Materials . . . . .	113
Maximum measured error . . . . .	108
Measured variables	
Calculated . . . . .	104
Measured . . . . .	104
see Process variables	
Measuring and test equipment . . . . .	99
Measuring device	
Configuration . . . . .	63
Conversion . . . . .	100
Design . . . . .	12
Disposal . . . . .	101
Integrating via HART protocol . . . . .	58
Mounting the sensor . . . . .	22
Arranging the mounting bolts and centering sleeves . . . . .	23
Mounting the ground cable/ground disks . . . . .	24
Mounting the seals . . . . .	24



Screw tightening torques . . . . .	24
Preparing for electrical connection . . . . .	34
Preparing for mounting . . . . .	22
Removing . . . . .	100
Repair . . . . .	100
Switch-on . . . . .	62
Measuring principle . . . . .	104
Measuring range . . . . .	104
Measuring system . . . . .	104
Measuring tube specification . . . . .	112
Mechanical load . . . . .	110
Media . . . . .	9
Medium temperature range . . . . .	110
Menu	
Diagnostics . . . . .	94, 125
Expert . . . . .	129
Operation . . . . .	79, 121
Setup . . . . .	63, 122
Menus	
For measuring device configuration . . . . .	63
For specific settings . . . . .	71
Modbus RS485	
Configuring error response mode . . . . .	91
Diagnostic information . . . . .	91
Function codes . . . . .	58
Modbus data map . . . . .	59
Read access . . . . .	58
Reading out data . . . . .	60
Register addresses . . . . .	59
Register information . . . . .	59
Response time . . . . .	59
Scan list . . . . .	60
Write access . . . . .	58
Modbus RS485 certification . . . . .	117
Mounting bolts . . . . .	115
Mounting dimensions	
see Installation dimensions	
Mounting kit . . . . .	22
Mounting location . . . . .	18
Mounting preparations . . . . .	22
Mounting requirements	
Installation dimensions . . . . .	20
Mounting tools . . . . .	22
<b>N</b>	
Nameplate	
Sensor . . . . .	15
Transmitter . . . . .	14
Navigation path (navigation view) . . . . .	46
Navigation view	
In the submenu . . . . .	46
In the wizard . . . . .	46
Numeric editor . . . . .	48
<b>O</b>	
Operable flow range . . . . .	105
Operating elements . . . . .	50, 87
Operating keys	
see Operating elements	

Operating menu	
Menus, submenus . . . . .	43
Overview of menus with parameters . . . . .	121
Structure . . . . .	43
Submenus and user roles . . . . .	44
Operating philosophy . . . . .	44
Operation . . . . .	79
Operation (Menu) . . . . .	121
Operation options . . . . .	42
Operational display . . . . .	45
Operational safety . . . . .	10
Order code . . . . .	14, 15
Orientation (vertical, horizontal) . . . . .	19
Outlet runs . . . . .	19
Output . . . . .	105
Output signal . . . . .	105
Overview	
Operating menu . . . . .	121
<b>P</b>	
Packaging disposal . . . . .	17
Parameter	
Changing . . . . .	54
Enter a value . . . . .	54
Parameter settings	
Administration (Submenu) . . . . .	97
Communication (Submenu) . . . . .	67
Data logging (Submenu) . . . . .	81
Diagnostics (Menu) . . . . .	94
Display (Submenu) . . . . .	73
Display (Wizard) . . . . .	65
Empty pipe detection (Wizard) . . . . .	70
Low flow cut off (Wizard) . . . . .	68
Operation (Submenu) . . . . .	80
Process variables (Submenu) . . . . .	79
Sensor adjustment (Submenu) . . . . .	71
Setup (Menu) . . . . .	63
Simulation (Submenu) . . . . .	75
System units (Submenu) . . . . .	64
Totalizer (Submenu) . . . . .	80
Totalizer 1 to 3 (Submenu) . . . . .	72
Partially filled pipe . . . . .	18
Performance characteristics . . . . .	108
Post-connection check (checklist) . . . . .	41
Post-installation check . . . . .	62
Post-installation check (checklist) . . . . .	30
Potential equalization . . . . .	38
Power consumption . . . . .	107
Power supply failure . . . . .	107
Pressure loss . . . . .	110
Pressure tightness . . . . .	110
Pressure-temperature ratings . . . . .	110
Process conditions	
Flow limit . . . . .	110
Medium temperature . . . . .	110
Pressure loss . . . . .	110
Pressure tightness . . . . .	110
Process connections . . . . .	115
Product safety . . . . .	10



Protecting parameter settings . . . . . 76

## R

Read access . . . . . 55  
 Reading measured values . . . . . 79  
 Reading out diagnostic information, Modbus RS485 . . 91  
 Recalibration . . . . . 99  
 Reference operating conditions . . . . . 108  
 Registered trademarks . . . . . 8  
 Remedial measures  
     Calling up . . . . . 88  
     Closing . . . . . 88  
 Remote operation . . . . . 116  
 Remote version  
     Connecting the signal cables . . . . . 36  
 Repair . . . . . 100  
     Notes . . . . . 100  
 Repair of a device . . . . . 100  
 Repeatability . . . . . 109  
 Replacement  
     Device components . . . . . 100  
 Replacing seals . . . . . 99  
 Requirements for personnel . . . . . 9  
 Return . . . . . 100

## S

Safety . . . . . 9  
 Screw tightening torques . . . . . 24  
 Sensor  
     Mounting . . . . . 22  
 Sensor (Submenu) . . . . . 131  
 Serial number . . . . . 14, 15  
 Service interface (CDI-RJ45) . . . . . 116  
 Setting the operating language . . . . . 62  
 Settings  
     Adapting the measuring device to the process  
         conditions . . . . . 80  
     Advanced display configurations . . . . . 73  
     Communication interface . . . . . 67  
     Device reset . . . . . 97  
     Device tag . . . . . 63  
     Empty pipe detection (EPD) . . . . . 70  
     Local display . . . . . 65  
     Low flow cut off . . . . . 68  
     Operating language . . . . . 62  
     Resetting the totalizer . . . . . 80  
     Sensor adjustment . . . . . 71  
     Simulation . . . . . 75  
     System units . . . . . 64  
     Totalizer . . . . . 72  
     Totalizer reset . . . . . 80  
 Setup (Menu) . . . . . 122  
 Shock resistance . . . . . 109  
 Showing data logging . . . . . 81  
 Signal on alarm . . . . . 105  
 Software release . . . . . 58  
 Spare part . . . . . 100  
 Spare parts . . . . . 100  
 Special connection instructions . . . . . 40

Standards and guidelines . . . . . 118

### Status area

    For operational display . . . . . 45  
     In the navigation view . . . . . 47

Status signals . . . . . 86, 89

Storage conditions . . . . . 16

Storage temperature . . . . . 16

Storage temperature range . . . . . 109

### Structure

    Operating menu . . . . . 43

### Submenu

    Administration . . . . . 97  
     Communication . . . . . 67  
     Current input . . . . . 134  
     Data logging . . . . . 81  
     Define access code . . . . . 76  
     Device information . . . . . 97  
     Display . . . . . 73  
     Events list . . . . . 95  
     Operation . . . . . 80  
     Overview . . . . . 44  
     Process variables . . . . . 79  
     Sensor . . . . . 131  
     Sensor adjustment . . . . . 71  
     Simulation . . . . . 75  
     System . . . . . 129  
     System units . . . . . 64  
     Totalizer . . . . . 80  
     Totalizer 1 to 3 . . . . . 72

Supplementary documentation . . . . . 119

Supply voltage . . . . . 107

### Symbols

    For communication . . . . . 45  
     For correction . . . . . 48  
     For diagnostic behavior . . . . . 45  
     For locking . . . . . 45  
     For measured variable . . . . . 45  
     For measurement channel number . . . . . 45  
     For menus . . . . . 47  
     For parameters . . . . . 47  
     For status signal . . . . . 45  
     For submenu . . . . . 47  
     For wizard . . . . . 47  
     In the status area of the local display . . . . . 45  
     In the text and numeric editor . . . . . 48

System (Submenu) . . . . . 129

### System design

    Measuring system . . . . . 104  
     see Measuring device design

System integration . . . . . 58

System pressure . . . . . 20

## T

Technical data, overview . . . . . 104

### Temperature range

    Ambient temperature range for display . . . . . 116

    Storage temperature . . . . . 16

Terminal assignment . . . . . 33, 36, 38

Terminals . . . . . 107



Text editor . . . . .	48
Tool tip	
see Help text	
Tools	
Electrical connection . . . . .	31
For mounting . . . . .	22
Transport . . . . .	16
Transmitter	
Connecting the signal cables . . . . .	38
Turning the display module . . . . .	29
Turning the housing . . . . .	27
Transporting the measuring device . . . . .	16
Troubleshooting	
General . . . . .	84
Turning the display module . . . . .	29
Turning the electronics housing	
see Turning the transmitter housing	
Turning the transmitter housing . . . . .	27
<b>U</b>	
Use of the measuring device	
Borderline cases . . . . .	9
Incorrect use . . . . .	9
see Designated use	
User roles . . . . .	44
<b>V</b>	
Version data for the device . . . . .	58
Vibration resistance . . . . .	110
Vibrations . . . . .	21
<b>W</b>	
W@M . . . . .	99, 100
W@M Device Viewer . . . . .	13, 100
Weight	
Compact version . . . . .	111
Sensor remote version . . . . .	112
Transport (notes) . . . . .	16
Wizard	
Define access code . . . . .	76
Display . . . . .	65
Empty pipe detection . . . . .	70
Low flow cut off . . . . .	68
Workplace safety . . . . .	10
Write access . . . . .	55
Write protection	
Via access code . . . . .	76
Via write protection switch . . . . .	77
Write protection switch . . . . .	77



[www.addresses.endress.com](http://www.addresses.endress.com)

---