


Operating Instructions

Proline Promag H 100

PROFIBUS DP

Electromagnetic flowmeter



- Make sure the document is stored in a safe place such that it is always available when working on or with the device.
- To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.
- The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Document information	5	6.3	Post-installation check	25
1.1	Document function	5	7	Electrical connection	27
1.2	Symbols used	5	7.1	Connection conditions	27
1.2.1	Safety symbols	5	7.1.1	Required tools	27
1.2.2	Electrical symbols	5	7.1.2	Requirements for connecting cable	27
1.2.3	Tool symbols	6	7.1.3	Terminal assignment	28
1.2.4	Symbols for certain types of information	6	7.1.4	Pin assignment, device plug	29
1.2.5	Symbols in graphics	6	7.1.5	Preparing the measuring device	29
1.3	Documentation	7	7.2	Connecting the measuring device	29
1.3.1	Standard documentation	7	7.2.1	Connecting the transmitter	29
1.3.2	Supplementary device-dependent documentation	7	7.2.2	Ensuring potential equalization	31
1.4	Registered trademarks	7	7.3	Special connection instructions	33
2	Basic safety instructions	8	7.3.1	Connection examples	33
2.1	Requirements for the personnel	8	7.4	Hardware settings	33
2.2	Designated use	8	7.4.1	Setting the device address	33
2.3	Workplace safety	9	7.4.2	Enabling the terminating resistor	34
2.4	Operational safety	9	7.5	Ensuring the degree of protection	35
2.5	Product safety	9	7.6	Post-connection check	35
2.6	IT security	9	8	Operation options	37
3	Product description	11	8.1	Overview of operation options	37
3.1	Product design	11	8.2	Structure and function of the operating menu	38
3.1.1	Device version with PROFIBUS DP communication type	11	8.2.1	Structure of the operating menu	38
4	Incoming acceptance and product identification	12	8.2.2	Operating philosophy	39
4.1	Incoming acceptance	12	8.3	Access to the operating menu via the Web browser	39
4.2	Product identification	12	8.3.1	Function range	39
4.2.1	Transmitter nameplate	13	8.3.2	Prerequisites	40
4.2.2	Sensor nameplate	14	8.3.3	Establishing a connection	40
4.2.3	Symbols on measuring device	15	8.3.4	Logging on	41
5	Storage and transport	16	8.3.5	User interface	41
5.1	Storage conditions	16	8.3.6	Disabling the Web server	42
5.2	Transporting the product	16	8.3.7	Logging out	43
5.3	Packaging disposal	17	8.4	Access to the operating menu via the operating tool	43
6	Mounting	17	8.4.1	Connecting the operating tool	43
6.1	Installation conditions	17	8.4.2	FieldCare	44
6.1.1	Mounting position	17	9	System integration	46
6.1.2	Requirements from environment and process	19	9.1	Overview of device description files	46
6.2	Mounting the measuring device	21	9.1.1	Current version data for the device	46
6.2.1	Required tools	21	9.1.2	Operating tools	46
6.2.2	Preparing the measuring device	21	9.2	Device master file (GSD)	46
6.2.3	Mounting the sensor	22	9.2.1	Manufacturer-specific GSD	46
6.2.4	Turning the display module	24	9.2.2	Profile GSD	47
			10	Commissioning	48
			10.1	Function check	48
			10.2	Establishing a connection via FieldCare	48
			10.3	Configuring the device address via software	48
			10.3.1	PROFIBUS network	48

10.4	Configuring the measuring device	48	13	Maintenance	96
10.4.1	Defining the tag name	49	13.1	Maintenance tasks	96
10.4.2	Setting the system units	49	13.1.1	Exterior cleaning	96
10.4.3	Configuring the local display	50	13.1.2	Interior cleaning	96
10.4.4	Configuring the communication interface	52	13.1.3	Replacing seals	96
10.4.5	Configuring the analog inputs	53	13.2	Measuring and test equipment	96
10.4.6	Configuring the low flow cut off	53	13.3	Endress+Hauser services	96
10.4.7	Configuring empty pipe detection	55	14	Repair	97
10.5	Advanced settings	56	14.1	General notes	97
10.5.1	Carrying out a sensor adjustment	56	14.2	Spare parts	97
10.5.2	Configuring the totalizer	56	14.3	Endress+Hauser services	97
10.5.3	Carrying out additional display configurations	58	14.4	Return	97
10.5.4	Performing electrode cleaning	60	14.5	Disposal	97
10.6	Simulation	61	14.5.1	Removing the measuring device	97
10.7	Protecting settings from unauthorized access	62	14.5.2	Disposing of the measuring device	98
10.7.1	Write protection via access code	62	15	Accessories	99
10.7.2	Write protection via write protection switch	62	15.1	Device-specific accessories	99
11	Operation	64	15.1.1	For the transmitter	99
11.1	Reading device locking status	64	15.1.2	For the sensor	99
11.2	Reading measured values	64	15.2	Communication-specific accessories	100
11.2.1	Process variables	64	15.3	Service-specific accessories	100
11.2.2	Totalizer	65	15.4	System components	100
11.3	Adapting the measuring device to the process conditions	65	16	Technical data	101
11.4	Performing a totalizer reset	66	16.1	Application	101
12	Diagnostics and troubleshooting	67	16.2	Function and system design	101
12.1	General troubleshooting	67	16.3	Input	101
12.2	Diagnostic information via light emitting diodes	68	16.4	Output	102
12.2.1	Transmitter	68	16.5	Power supply	103
12.3	Diagnostic information in FieldCare	68	16.6	Performance characteristics	104
12.3.1	Diagnostic options	68	16.7	Installation	105
12.3.2	Calling up remedy information	69	16.8	Environment	106
12.4	Adapting the diagnostic information	70	16.9	Process	106
12.4.1	Adapting the diagnostic behavior	70	16.10	Mechanical construction	108
12.5	Overview of diagnostic information	72	16.11	Operability	111
12.5.1	Diagnostics for the sensor	74	16.12	Certificates and approvals	113
12.5.2	Diagnostics for the electronics	77	16.13	Application packages	114
12.5.3	Diagnostics for the configuration	82	16.14	Accessories	114
12.5.4	Diagnostics for the process	85	16.15	Supplementary documentation	115
12.6	Pending diagnostic events	90	17	Appendix	116
12.7	Diagnostic list	91	17.1	Overview of the operating menu	116
12.8	Event logbook	91	17.1.1	Main menu	116
12.8.1	Event history	91	17.1.2	"Operation" menu	116
12.8.2	Filtering the event logbook	92	17.1.3	"Setup" menu	117
12.8.3	Overview of information events	92	17.1.4	"Diagnostics" menu	119
12.9	Resetting the measuring device	93	17.1.5	"Expert" menu	122
12.10	Device information	93	Index	139	
12.11	Firmware history	95			





1 Document information

1.1 Document function







These Operating Instructions contain all the information that is required in various phases of the life cycle of the device: from product identification, incoming acceptance and storage, to mounting, connection, operation and commissioning through to troubleshooting, maintenance and disposal.

1.2 Symbols used



1.2.1 Safety symbols

Symbol	Meaning
	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.
	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.












1.2.2 Electrical symbols

Symbol	Meaning
	Direct current A terminal to which DC voltage is applied or through which direct current flows.
	Alternating current A terminal to which alternating voltage is applied or through which alternating current flows.
	Direct current and alternating current <ul style="list-style-type: none"> ▪ A terminal to which alternating voltage or DC voltage is applied. ▪ A terminal through which alternating current or direct current flows.
	Ground connection A grounded terminal which, as far as the operator is concerned, is grounded via a grounding system.
	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.
	Equipotential connection A connection that has to be connected to the plant grounding system: This may be a potential equalization line or a star grounding system depending on national or company codes of practice.





1.2.3 Tool symbols

Symbol	Meaning
	Allen key
	Open-ended wrench




1.2.4 Symbols for certain types of information

Symbol	Meaning
	Permitted Indicates procedures, processes or actions that are permitted.
	Preferred Indicates procedures, processes or actions that are preferred.
	Forbidden Indicates procedures, processes or actions that are forbidden.
	Tip Indicates additional information.
	Reference to documentation Refers to the corresponding device documentation.
	Reference to page Refers to the corresponding page number.
	Reference to graphic Refers to the corresponding graphic number and page number.
	Series of steps
	Result of a sequence of actions
	Help in the event of a problem
	Visual inspection

1.2.5 Symbols in graphics

Symbol	Meaning
1, 2, 3,...	Item numbers
	Series of steps
A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections
	Flow direction
	Hazardous area Indicates a hazardous area.
	Safe area (non-hazardous area) Indicates the non-hazardous area.

1.3 Documentation

-  For an overview of the scope of the associated Technical Documentation, refer to the following:
- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
 - The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
 - The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.
-  For a detailed list of the individual documents along with the documentation code (→  115)

1.3.1 Standard documentation

Document type	Purpose and content of the document
Technical Information	Planning aid for your device The document contains all the technical data on the device and provides an overview of the accessories and other products that can be ordered for the device.
Brief Operating Instructions	Guide that takes you quickly to the 1st measured value The Brief Operating Instructions contain all the essential information from incoming acceptance to initial commissioning.

1.3.2 Supplementary device-dependent documentation

Additional documents are supplied depending on the device version ordered: Always comply strictly with the instructions in the supplementary documentation. The supplementary documentation is an integral part of the device documentation.

1.4 Registered trademarks

PROFIBUS®

Registered trademark of the PROFIBUS User Organization, Karlsruhe, Germany

Applicator®, FieldCare®, Field Xpert™, HistoROM®, Heartbeat Technology™

Registered or registration-pending trademarks of the Endress+Hauser Group

2 Basic safety instructions

2.1 Requirements for the personnel

The personnel for installation, commissioning, diagnostics and maintenance must fulfill the following requirements:

- ▶ Trained, qualified specialists must have a relevant qualification for this specific function and task
- ▶ Are authorized by the plant owner/operator
- ▶ Are familiar with federal/national regulations
- ▶ Before beginning work, the specialist staff must have read and understood the instructions in the Operating Instructions and supplementary documentation as well as in the certificates (depending on the application)
- ▶ Following instructions and basic conditions

The operating personnel must fulfill the following requirements:

- ▶ Being instructed and authorized according to the requirements of the task by the facility's owner-operator
- ▶ Following the instructions in these Operating Instructions


2.2 Designated use

Application and media

Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.

Measuring devices for use in hazardous areas, in hygienic applications or in applications where there is an increased risk due to process pressure, are labeled accordingly on the nameplate.

To ensure that the measuring device remains in proper condition for the operation time:

- ▶ Only use the measuring device in full compliance with the data on the nameplate and the general conditions listed in the Operating Instructions and supplementary documentation.
- ▶ Based on the nameplate, check whether the ordered device is permitted for the intended use in the hazardous area (e.g. explosion protection, pressure vessel safety).
- ▶ Use the measuring device only for media against which the process-wetted materials are adequately resistant.
- ▶ If the measuring device is not operated at atmospheric temperature, compliance with the relevant basic conditions specified in the associated device documentation is absolutely essential: "Documentation" section (→  7).

Incorrect use

Non-designated use can compromise safety. The manufacturer is not liable for damage caused by improper or non-designated use.

WARNING

Danger of breakage of the sensor due to corrosive or abrasive fluids!

- ▶ Verify the compatibility of the process fluid with the sensor material.
- ▶ Ensure the resistance of all fluid-wetted materials in the process.
- ▶ Observe the specified pressure and temperature range.

Verification for borderline cases:

- ▶ For special fluids and fluids for cleaning, Endress+Hauser is glad to provide assistance in verifying the corrosion resistance of fluid-wetted materials, but does not accept any warranty or liability as minute changes in the temperature, concentration or level of contamination in the process can alter the corrosion resistance properties.

Residual risks

The external surface temperature of the housing can increase by max. 10 K due to the power consumption of the electronic components. Hot process fluids passing through the measuring device will further increase the surface temperature of the housing. The surface of the sensor, in particular, can reach temperatures which are close to the fluid temperature.

Possible burn hazard due to fluid temperatures!

- ▶ For elevated fluid temperature, ensure protection against contact to prevent burns.

2.3 Workplace safety

For work on and with the device:

- ▶ Wear the required personal protective equipment according to federal/national regulations.

For welding work on the piping:

- ▶ Do not ground the welding unit via the measuring device.

If working on and with the device with wet hands:

- ▶ It is recommended to wear gloves on account of the higher risk of electric shock.

2.4 Operational safety

Risk of injury.

- ▶ Operate the device in proper technical condition and fail-safe condition only.
- ▶ The operator is responsible for interference-free operation of the device.

Conversions to the device

Unauthorized modifications to the device are not permitted and can lead to unforeseeable dangers.

- ▶ If, despite this, modifications are required, consult with Endress+Hauser.

Repair

To ensure continued operational safety and reliability,

- ▶ Carry out repairs on the device only if they are expressly permitted.
- ▶ Observe federal/national regulations pertaining to repair of an electrical device.
- ▶ Use original spare parts and accessories from Endress+Hauser only.

2.5 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EC directives listed in the device-specific EC Declaration of Conformity. Endress+Hauser confirms this by affixing the CE mark to the device.

2.6 IT security


We only provide a warranty if the device is installed and used as described in the Operating Instructions. The device is equipped with security mechanisms to protect it against any inadvertent changes to the device settings.

IT security measures in line with operators' security standards and designed to provide additional protection for the device and device data transfer must be implemented by the operators themselves.

3 Product description

3.1 Product design

3.1.1 Device version with PROFIBUS DP communication type





A0023153


 1 Important components of a measuring device

- 1 Sensor
- 2 Transmitter housing
- 3 Main electronics module
- 4 Transmitter housing cover
- 5 Transmitter housing cover (version for optional onsite display)
- 6 Onsite display (optional)
- 7 Main electronics module (with bracket for optional onsite display)

4 Incoming acceptance and product identification

4.1 Incoming acceptance



 




1
+
2



1
+
2


Are the order codes on the delivery note (1) and the product sticker (2) identical?



Are the goods undamaged?



 




DELIVERY NOTE



Endress+Hauser

Do the nameplate data match the ordering information on the delivery note?



Is the CD-ROM with the Technical Documentation (depends on device version) and documents present?



-  ■ If one of the conditions is not satisfied, contact your Endress+Hauser Sales Center.
- Depending on the device version, the CD-ROM might not be part of the delivery! In such cases, the technical documentation is available via the Internet or via the *Endress+Hauser Operations App*, see the "Product identification" section (→  13).

4.2 Product identification


The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in *W@M Device Viewer* (www.endress.com/deviceviewer): All information about the measuring device is displayed.
- Enter the serial number from the nameplates into the *Endress+Hauser Operations App* or scan the 2-D matrix code (QR code) on the nameplate with the *Endress+Hauser Operations App*: all the information for the measuring device is displayed.


For an overview of the scope of the associated Technical Documentation, refer to the following:

- The chapters "Additional standard documentation on the device" (→  7) and "Supplementary device-dependent documentation" (→  7)
- The *W@M Device Viewer*: Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

4.2.1 Transmitter nameplate




A0017520


 2 Example of a transmitter nameplate

- 1 Manufacturing location
- 2 Name of the transmitter
- 3 Order code
- 4 Serial number
- 5 Extended order code
- 6 Electrical connection data, e.g. available inputs and outputs, supply voltage
- 7 Permitted ambient temperature range (T_a)
- 8 Degree of protection
- 9 2-D matrix code
- 10 Document number of safety-related supplementary documentation
- 11 Manufacturing date: year-month
- 12 CE mark, C-Tick
- 13 Firmware version (FW)

4.2.2 Sensor nameplate



A0017186

 3 Example of sensor nameplate

- 1 Name of the sensor
- 2 Manufacturing location
- 3 Order code
- 4 Serial number (Ser. no.)
- 5 Extended order code (Ext. ord. cd.)
- 6 Nominal diameter of sensor
- 7 Test pressure of the sensor
- 8 Medium temperature range
- 9 Material of lining and electrodes
- 10 Degree of protection: e.g. IP, NEMA
- 11 Permitted ambient temperature (T_a)
- 12 2-D matrix code
- 13 CE mark, C-Tick
- 14 Flow direction
- 15 Manufacturing date: year-month






Order code

The measuring device is reordered using the order code.

Extended order code

- The device type (product root) and basic specifications (mandatory features) are always listed.
- Of the optional specifications (optional features), only the safety and approval-related specifications are listed (e.g. LA). If other optional specifications are also ordered, these are indicated collectively using the # placeholder symbol (e.g. #LA#).
- If the ordered optional specifications do not include any safety and approval-related specifications, they are indicated by the + placeholder symbol (e.g. XXXXXX-ABCDE +).


4.2.3 Symbols on measuring device

Symbol	Meaning
	WARNING! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.
 A0011194	Reference to documentation Refers to the corresponding device documentation.
 A0011199	Protective ground connection A terminal which must be connected to ground prior to establishing any other connections.

5 Storage and transport

5.1 Storage conditions

Observe the following notes for storage:

- Store in the original packaging to ensure protection from shock.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.
- Protect from direct sunlight to avoid unacceptably high surface temperatures.
- Select a storage location where moisture cannot collect in the measuring device as fungus and bacteria infestation can damage the lining.
- Store in a dry and dust-free place.
- Do not store outdoors.
- Storage temperature(→  106)


5.2 Transporting the product

WARNING


Center of gravity of the measuring device is higher than the suspension points of the webbing slings.

Risk of injury if the measuring device slips.

- ▶ Secure the measuring device from rotating or slipping.
- ▶ Observe the weight specified on the packaging (stick-on label).
- ▶ Observe the transport instructions on the stick-on label on the electronics compartment cover.



A0015606

-  ■ Transport the measuring device to the measuring point in the original packaging.
- Lifting gear
 - Webbing slings: Do not use chains, as they could damage the housing.
 - For wood crates, the floor structure enables these to be loaded lengthwise or broadside using a forklift.
- Use the webbing slings to lift the measuring device at the process connections; do not lift at the transmitter housing.
- Do not remove protective covers or protective caps installed on process connections. They prevent mechanical damage to the sealing surfaces and contamination in the measuring tube.

5.3 Packaging disposal

All packaging materials are environmentally friendly and 100% recyclable:


- Measuring device secondary packaging: polymer stretch film that conforms to EC Directive 2002/95/EC (RoHS).
- Packaging:
 - Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
 - or
 - Carton in accordance with European Packaging Directive 94/62/EC; recyclability is confirmed by the affixed RESY symbol.
- Seaworthy packaging (optional): Wood crate, treated in accordance with ISPM 15 standard, which is confirmed by the affixed IPPC logo.
- Carrying and mounting hardware:
 - Disposable plastic pallet
 - Plastic straps
 - Plastic adhesive strips
- Dunnage: Paper cushion

6 Mounting

6.1 Installation conditions

6.1.1 Mounting position

Mounting location



A0023343

Preferably install the sensor in an ascending pipe, and ensure a sufficient distance to the next pipe elbow: $h \geq 2 \times DN$

To prevent measuring errors arising from accumulation of gas bubbles in the measuring tube, avoid the following mounting locations in the pipe:


- Highest point of a pipeline.
- Directly upstream of a free pipe outlet in a down pipe.

Installation in down pipes

Install a siphon with a vent valve downstream of the sensor in down pipes whose length $h \geq 5 \text{ m}$ (16.4 ft). This precaution is to avoid low pressure and the consequent risk of damage to the measuring tube. This measure also prevents the system losing prime.



For information on the liner's resistance to partial vacuum (→ 107)




A0017064

■ 4 Installation in a down pipe

- 1 Vent valve
- 2 Pipe siphon
- h Length of down pipe

Installation in partially filled pipes

A partially filled pipe with a gradient necessitates a drain-type configuration. The empty pipe detection (EPD) function offers additional protection by detecting empty or partially filled pipes.



A0017063


Orientation

The direction of the arrow on the sensor nameplate helps you to install the sensor according to the flow direction (direction of medium flow through the piping).

An optimum orientation position helps avoid gas and air accumulations and deposits in the measuring tube.


The measuring device also offers the empty pipe detection function to detect partially filled measuring pipes in the event of outgassing fluids or variable process pressures.

Vertical



A0015591

This is the optimum for self-emptying piping systems and for use in conjunction with empty pipe detection.

Horizontal

A0019602

- 1 EPD electrode for empty pipe detection
2 Measuring electrodes for signal detection




- The measuring electrode plane must be horizontal. This prevents brief insulation of the two measuring electrodes by entrained air bubbles.
- The empty pipe detection only works if the transmitter housing is pointing upwards as otherwise there is no guarantee that the empty pipe detection function will actually respond to a partially filled or empty measuring tube.

Inlet and outlet runs

If possible, install the sensor upstream from fittings such as valves, T-pieces or elbows.

Observe the following inlet and outlet runs to comply with accuracy specifications:



A0016275

Installation dimensions

For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

6.1.2 Requirements from environment and process**Ambient temperature range**

Transmitter	-40 to +60 °C (-40 to +140 °F)
Sensor	-20 to +60 °C (-4 to +140 °F)
Liner	Do not exceed or fall below the permitted temperature range of the liner (→ 106).

If operating outdoors:

- Install the measuring device in a shady location.
- Avoid direct sunlight, particularly in warm climatic regions.
- Avoid direct exposure to weather conditions.

Temperature tables


SI units

T _a [°C]	T6 [85 °C]	T5 [100 °C]	T4 [135 °C]	T3 [200 °C]	T2 [300 °C]	T1 [450 °C]
30	50	95	130	150	150	150
50	–	95	130	150	150	150
60	–	95	110	110	110	110

US units

T _a [°F]	T6 [185 °F]	T5 [212 °F]	T4 [275 °F]	T3 [392 °F]	T2 [572 °F]	T1 [842 °F]
86	122	203	266	302	302	302
122	–	203	266	302	302	302
140	–	203	230	230	230	230

System pressure



A0015594

Never install the sensor on the pump suction side in order to avoid the risk of low pressure, and thus damage to the liner.


i Furthermore, install pulse dampers if reciprocating, diaphragm or peristaltic pumps are used.

- i** ■ For information on the liner's resistance to partial vacuum (→ 107)
- Information on the shock resistance of the measuring system (→ 106)
- Information on the vibration resistance of the measuring system (→ 106)

Vibrations

In the event of very strong vibrations, the pipe and sensor must be supported and fixed.

- i** Information on the shock resistance of the measuring system (→ 106)
- Information on the vibration resistance of the measuring system (→ 106)



A0016266

5 Measures to avoid device vibrations (L > 10 m (33 ft))


Adapters

Suitable adapters to DIN EN 545 (double-flange reducers) can be used to install the sensor in larger-diameter pipes. The resultant increase in the rate of flow improves measuring accuracy with very slow-moving fluids. The nomogram shown here can be used to calculate the pressure loss caused by reducers and expanders.



The nomogram only applies to liquids with a viscosity similar to that of water.

1. Calculate the ratio of the diameters d/D .
2. From the nomogram read off the pressure loss as a function of flow velocity (downstream from the reduction) and the d/D ratio.



A0016359

6.2 Mounting the measuring device

6.2.1 Required tools

For sensor

For flanges and other process connections:

- Screws, nuts, seals etc. are not included in the scope of supply and must be provided by the customer.
- Appropriate mounting tools

6.2.2 Preparing the measuring device

1. Remove all remaining transport packaging.
2. Remove any protective covers or protective caps present from the sensor.
3. Remove stick-on label on the electronics compartment cover.


6.2.3 Mounting the sensor

⚠ WARNING

Danger due to improper process sealing!

- ▶ Ensure that the inside diameters of the gaskets are greater than or equal to that of the process connections and piping.
- ▶ Ensure that the gaskets are clean and undamaged.
- ▶ Install the gaskets correctly.


1. Ensure that the direction of the arrow on the sensor matches the flow direction of the medium.
2. To ensure compliance with device specifications, install the measuring device between the pipe flanges in a way that it is centered in the measurement section.
3. Install the measuring device or turn the transmitter housing so that the cable entries do not point upwards.



A0013964

The sensor is supplied to order, with or without pre-installed process connections. Pre-installed process connections are firmly secured to the sensor by 4 or 6 hexagonal-headed bolts.

- i** The sensor may need to be supported or additionally secured depending on the application and pipe length. In particular, it is absolutely essential to secure the sensor additionally if plastic process connections are used. An appropriate wall mounting kit can be ordered separately as an accessory from Endress+Hauser (→ 114).



A0019804

6 Process connection seals



- A Process connections with O-ring seal (→ 110)
 B Process connections with aseptic molded seal, DN 2 to 25 (1/12 to 1") (→ 111)
 C Process connections with aseptic molded seal, DN 40 to 150 (1 1/2 to 6") (→ 111)

Welding the sensor into the pipe (welding connections)

⚠ WARNING

Risk of destroying the electronics!

- ▶ Make sure that the welding system is not grounded via the sensor or transmitter.


1. Tack-weld the sensor to secure it in the pipe. A suitable welding aid can be ordered separately as an accessory (→  114).
 2. Release the screws on the process connection flange and remove the sensor, along with the seal, from the pipe.
 3. Weld the process connection into the pipe.
 4. Reinstall the sensor in the pipe, and in doing so make sure that the seal is clean and in the right position.
-  ■ If thin-walled pipes carrying food are welded correctly, the seal is not damaged by the heat even when mounted. Nevertheless it is advisable to remove the sensor and seal.
- It must be possible to open the pipe by approx. 8 mm (0.31 in) in total to permit disassembly.

Cleaning with pigs



It is essential to take the internal diameters of the measuring tube and process connection into account when cleaning with pigs. All the dimensions and lengths of the sensor and transmitter are provided in the separate "Technical Information" document.

Mounting the seals




Comply with the following instructions when installing seals:


- When mounting the process connections, make sure that the seals concerned are clean and centered correctly.
- In the case of metal process connections, the screws must be tightened securely. The process connection forms a metal connection with the sensor, which ensures a defined compression of the seal.
- In the case of plastic process connections, comply with the max. screw tightening torques for lubricated threads: 7 Nm (5.2 lbf ft). In the case of plastic flanges, always insert a seal between the connection and the counterflange.
- Depending on the application the seals should be replaced periodically, particularly if molded seals are used (aseptic version)! The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature. Replacement seals can be ordered as an accessory (→  114).

Mounting grounding rings (DN 2 to 25 (1/12 to 1"))

-  Pay attention to the information on potential equalization (→  31).

In the case of plastic process connections (e.g. flange connections or adhesive fittings), additional ground rings must be used to ensure the potential between the sensor and fluid is matched. If grounding rings are not installed, this can affect the measuring accuracy or cause the destruction of the sensor as a result of the electrochemical decomposition of the electrodes.

-  ■ Depending on the option ordered, plastic disks are used instead of grounding rings on some process connections. These plastic disks only act as "spacers" and do not have any potential matching function. Furthermore, they also perform a significant sealing function at the sensor/process connection interface. Therefore, in the case of process connections without metal grounding rings, these plastic disks/seals should never be removed and should always be installed!
- Grounding rings can be ordered separately as an accessory from Endress+Hauser (→  114). When ordering make sure that the grounding rings are compatible with the material used for the electrodes, as otherwise there is the danger that the electrodes could be destroyed by electrochemical corrosion! Material specifications (→  110).
 - Grounding rings, including seals, are mounted inside the process connections. Therefore the installation length is not affected.



A0002651

7 Installing grounding rings


- 1 Hexagonal-headed bolts of process connection
- 2 O-ring seals
- 3 Grounding ring or plastic disk (spacer)
- 4 Sensor

1. Release the 4 or 6 hexagonal-headed bolts (1) and remove the process connection from the sensor (4).
2. Remove the plastic disk (3), along with the two O-ring seals (2), from the process connection.
3. Place the first O-ring seal (2) back into the groove of the process connection.
4. Fit the metal grounding ring (3) in the process connection as illustrated.
5. Place the second O-ring seal (2) into the groove of the grounding ring.
6. Mount the process connection back on the sensor. In doing so, make sure you comply with the max. screw tightening torques for lubricated threads: 7 Nm (5.2 lbf ft)


6.2.4 Turning the display module

The display module can be turned to optimize display readability.

Aluminum housing version, AlSi10Mg, coated



Compact and ultra-compact housing version, hygienic, stainless




6.3 Post-installation check

Is the device undamaged (visual inspection)?	<input type="checkbox"/>
Does the measuring device conform to the measuring point specifications? For example: <ul style="list-style-type: none">■ Process temperature■ Process pressure (refer to the section on "Pressure-temperature ratings" in the "Technical Information" document)■ Ambient temperature■ Measuring range	<input type="checkbox"/>
Has the correct orientation for the sensor been selected ? <ul style="list-style-type: none">■ According to sensor type■ According to medium temperature■ According to medium properties (outgassing, with entrained solids)	<input type="checkbox"/>
Does the arrow on the sensor nameplate match the direction of flow of the fluid through the piping ?	<input type="checkbox"/>

Are the measuring point identification and labeling correct (visual inspection)?	<input type="checkbox"/>
Have the fixing screws been tightened with the correct tightening torque?	<input type="checkbox"/>

7 Electrical connection

 The measuring device does not have an internal circuit breaker. For this reason, assign the measuring device a switch or power-circuit breaker so that the power supply line can be easily disconnected from the mains.

7.1 Connection conditions

7.1.1 Required tools

- For cable entries: Use corresponding tools
- For securing clamp (on aluminum housing): Allen screw 3 mm
- For securing screw (for stainless steel housing): open-ended wrench 8 mm
- Wire stripper
- When using stranded cables: crimping tool for ferrule

7.1.2 Requirements for connecting cable

The connecting cables provided by the customer must fulfill the following requirements.

Electrical safety

In accordance with applicable federal/national regulations.

Permitted temperature range

- -40°C (-40°F) to $+80^{\circ}\text{C}$ ($+176^{\circ}\text{F}$)
- Minimum requirement: cable temperature range \geq ambient temperature $+20^{\circ}\text{K}$

Power supply cable

Standard installation cable is sufficient.

Signal cable

PROFIBUS DP

The IEC 61158 standard specifies two types of cable (A and B) for the bus line which can be used for every transmission rate. Cable type A is recommended.

Cable type	A
Characteristic impedance	135 to 165 Ω at a measuring frequency of 3 to 20 MHz
Cable capacitance	<30 pF/m
Wire cross-section	>0.34 mm ² (22 AWG)
Cable type	Twisted pairs
Loop resistance	$\leq 110 \Omega/\text{km}$
Signal damping	Max. 9 dB over the entire length of the cable cross-section
Shielding	Copper braided shielding or braided shielding with foil shield. When grounding the cable shield, observe the grounding concept of the plant.

Cable diameter

- Cable glands supplied:
M20 \times 1.5 with cable \varnothing 6 to 12 mm (0.24 to 0.47 in)
- Spring terminals:
Wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

7.1.3 Terminal assignment

Transmitter


PROFIBUS DP connection version

 For use in the non-hazardous area and Zone 2/Div. 2.

Order code for "Output", option L

Depending on the housing version, the transmitters can be ordered with terminals or device plugs.

Order code for "Housing"	Connection methods available		Possible options for order code "Electrical connection"
	Output	Power supply	
Options A, B	Terminals	Terminals	<div><div>▪ Option A: coupling M20x1</div><div>▪ Option B: thread M20x1</div><div>▪ Option C: thread G ½"</div><div>▪ Option D: thread NPT ½"</div></div>
Options A, B	Device plug	Terminals	<div><div>▪ Option L: plug M12x1 + thread NPT ½"</div><div>▪ Option N: plug M12x1 + coupling M20</div><div>▪ Option P: plug M12x1 + thread G ½"</div><div>▪ Option U: plug M12x1 + thread M20</div></div>
Options A, B, C	Device plug	Device plug	Option Q: 2 x plug M12x1
<div>Order code for "Housing":<div><div>▪ Option A: compact, coated aluminum</div><div>▪ Option B: compact, hygienic, stainless</div><div>▪ Option C: ultra compact, hygienic, stainless, M12 device plug</div></div></div>			



A0022716

 8 PROFIBUS DP terminal assignment

- 1 Power supply: DC 24 V
- 2 PROFIBUS DP


Order code for "Output"	Terminal number			
	Power supply		Output	
	2 (L-)	1 (L+)	26 (RxD/TxD-P)	27 (RxD/TxD-N)
	Option L	DC 24 V	B	A
<div>Order code for "Output":<div>Option L: PROFIBUS DP, for use in non-hazardous areas and Zone 2/div. 2</div></div>				

7.1.4 Pin assignment, device plug


PROFIBUS DP

 For use in the non-hazardous area and Zone 2/Div. 2.



Device plug for supply voltage (device side)

	Pin	Assignment		Coding	Plug/socket
	1	L+	DC 24 V	A	Plug
	2				
	3				
	4	L-	DC 24 V		
	5		Grounding/shielding		

Device plug for signal transmission (device side)

	Pin	Assignment		Coding	Plug/socket
	1			B	Socket
	2	A	PROFIBUS DP		
	3				
	4	B	PROFIBUS DP		
	5		Grounding/shielding		

7.1.5 Preparing the measuring device

1. Remove dummy plug if present.
2. **NOTICE!** Insufficient sealing of the housing! Operational reliability of the measuring device could be compromised. Use suitable cable glands corresponding to the degree of protection.
If measuring device is delivered without cable glands:
Provide suitable cable gland for corresponding connecting cable (→  27).
3. If measuring device is delivered with cable glands:
Observe cable specification (→  27).

7.2 Connecting the measuring device

NOTICE


Limitation of electrical safety due to incorrect connection!

- Have electrical connection work carried out by correspondingly trained specialists only.
- Observe applicable federal/national installation codes and regulations.
- Comply with local workplace safety regulations.
- For use in potentially explosive atmospheres, observe the information in the device-specific Ex documentation.

7.2.1 Connecting the transmitter

The connection of the transmitter depends on the following order codes:


- Housing version: compact or ultra-compact
- Connection version: device plug or terminals



A0016924

9 Device versions and connection versions

- A Housing version: compact, aluminum coated
- B Housing version: compact hygienic, stainless
- 1 Cable entry or device plug for signal transmission
- 2 Cable entry or device plug for supply voltage
- C Housing version: ultra-compact hygienic, stainless, M12 device plug
- 3 Device plug for signal transmission
- 4 Device plug for supply voltage




A0017844

10 Device versions with connection examples

- 1 Cable
- 2 Device plug for signal transmission
- 3 Device plug for supply voltage

For device version with device plug: only pay attention to Step 6.

1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.

2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary (→  111).
3. Push the cable through the cable entry . To ensure tight sealing, do not remove the sealing ring from the cable entry.
4. Strip the cable and cable ends. In the case of stranded cables, also fit ferrules.
5. Connect the cable in accordance with the terminal assignment or the device plug pin assignment .
6. Depending on the device version: tighten the cable glands or plug in the device plug and tighten .
7. **WARNING!** Housing degree of protection may be voided due to insufficient sealing of the housing. Screw in the screw without using any lubricant. The threads on the cover are coated with a dry lubricant.
Reverse the removal procedure to reassemble the transmitter.

7.2.2 Ensuring potential equalization

CAUTION

Electrode damage can result in the complete failure of the device!

- ▶ Make sure that the fluid and sensor have the same electrical potential.
- ▶ Pay attention to internal grounding concepts in the company.
- ▶ Pay attention to the pipe material or grounding.

Connection examples for standard situations

Metal process connections

Potential matching usually takes place via the metallic process connections in contact with medium which are directly mounted on the measuring transmitter. This usually means that additional potential matching measures are unnecessary.


Connection example in special situations

Plastic process connections

In the case of plastic process connections, additional grounding rings or process connections with an integrated grounding electrode must be used to ensure potential matching between the sensor and the fluid. If there is no potential matching, this can affect the measuring accuracy or cause the destruction of the sensor as a result of the electrochemical decomposition of the electrodes.


Note the following when using grounding rings:

- Depending on the option ordered, plastic disks are used instead of grounding rings on some process connections. These plastic disks only act as "spacers" and do not have any potential matching function. Furthermore, they also perform a significant sealing function at the sensor/connection interface. Therefore, in the case of process connections without metal grounding rings, these plastic disks/seals should never be removed and should always be installed!
- Grounding rings can be ordered separately as an accessory from Endress+Hauser . When ordering make sure that the grounding rings are compatible with the material used for the electrodes, as otherwise there is the danger that the electrodes could be destroyed by electrochemical corrosion!
- Grounding rings, including seals, are mounted inside the process connections. Therefore the installation length is not affected.

Potential equalization via additional grounding ring

A0002651

- 1 Hexagonal-headed bolts of process connection
- 2 O-ring seals
- 3 Plastic disk (spacer) or grounding ring
- 4 Sensor

Potential equalization via grounding electrodes on process connection


A0017293

- 1 Hexagonal-headed bolts of process connection
- 2 Integrated grounding electrodes
- 3 O-ring seal
- 4 Sensor

7.3 Special connection instructions

7.3.1 Connection examples

PROFIBUS DP



11 Connection example for PROFIBUS DP, non-hazardous area and Zone 2/Div. 2

- 1 Control system (e.g. PLC)
- 2 Cable shield: the cable shield must be grounded at both ends to comply with EMC requirements; observe cable specifications (→ 27)
- 3 Distribution box
- 4 Transmitter


i If baud rates > 1.5 MBaud an EMC cable entry must be used and the cable shield must continue as far as the terminal wherever possible.

7.4 Hardware settings

7.4.1 Setting the device address

PROFIBUS DP

The address must always be configured for a PROFIBUS DP/PA device. The valid address range is between 1 and 126. In a PROFIBUS DP/PA network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.

Setting the address

A0021265

12 Addressing using DIP switches on the I/O electronics module

1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary (→ 111).
3. Disable software addressing via DIP switch 8 (OFF).
4. Set the desired device address via the corresponding DIP switches.
 - ↳ Example (→ 12, 34): $1 + 16 + 32 = \text{device address } 49$

The device demands rebooting after 10 s. After rebooting, hardware addressing is enabled with the configured IP address.
5. Reverse the removal procedure to reassemble the transmitter.


7.4.2 Enabling the terminating resistor

PROFIBUS DP

To avoid incorrect communication transmission caused by impedance mismatch, terminate the PROFIBUS DP cable correctly at the start and end of the bus segment.

- If the device is operated with a baud rate of 1.5 MBaud and under:
For the last transmitter on the bus, terminate via DIP switch 2 (bus termination) and DIP switch 1 and 3 (bus polarization). Setting: ON – ON – ON (→ 13, 35).
- For baud rates > 1.5 MBaud:
Due to the capacitance load of the user and the line reflections generated as a result, ensure that an external bus terminator is used.

It is generally advisable to use an external bus terminator as the entire segment can fail if a device that is terminated internally is defective.




13 Termination using DIP switches on the I/O electronics module (for baud rates < 1.5 MBaud)

7.5 Ensuring the degree of protection

The measuring device fulfills all the requirements for the IP66/67 degree of protection, Type 4X enclosure.

To guarantee IP66/67 degree of protection, Type 4X enclosure, carry out the following steps after the electrical connection:






1. Check that the housing seals are clean and fitted correctly. Dry, clean or replace the seals if necessary.
2. Tighten all housing screws and screw covers.
3. Firmly tighten the cable glands.
4. To ensure that moisture does not enter the cable entry, route the cable so that it loops down before the cable entry ("water trap").



5. Insert dummy plugs into unused cable entries.


7.6 Post-connection check

Are cables or the device undamaged (visual inspection)?	<input type="checkbox"/>
Do the cables comply with the requirements (\rightarrow 27)?	<input type="checkbox"/>
Do the cables have adequate strain relief?	<input type="checkbox"/>

Are all the cable glands installed, firmly tightened and leak-tight? Cable run with "water trap" (→  35) ?	<input type="checkbox"/>
Depending on the device version: are all the device plugs firmly tightened (→  29)?	<input type="checkbox"/>
Does the supply voltage match the specifications on the transmitter nameplate (→  103)?	<input type="checkbox"/>
Is the terminal assignment or the pin assignment of the device plug correct?	<input type="checkbox"/>
If supply voltage is present, is the power LED on the electronics module of the transmitter lit green (→  11)?	<input type="checkbox"/>
Is the potential equalization established correctly (→  31)?	<input type="checkbox"/>
Depending on the device version, is the securing clamp or fixing screw firmly tightened?	<input type="checkbox"/>

8 Operation options

8.1 Overview of operation options




A0017760

- 1 Computer with Web browser (e.g. Internet Explorer) or with "FieldCare" operating tool
- 2 Automation system, e.g. "RSLogix" (Rockwell Automation) and work station for measuring device operation with Add-on Profile Level 3 for "RSLogix 5000" software (Rockwell Automation)


8.2 Structure and function of the operating menu

8.2.1 Structure of the operating menu

 For an overview of the operating menu with menus and parameters



A0018237-EN

 14 Schematic structure of the operating menu

8.2.2 Operating philosophy

The individual parts of the operating menu are assigned to certain user roles. Each user role corresponds to typical tasks within the device lifecycle.

Menu		User role and tasks	Content/meaning
Language	task-oriented	Role "Operator", "Maintenance" Tasks during operation: <ul style="list-style-type: none"> ■ Configuring the operational display ■ Reading measured values 	Defining the operating language
Operation			<ul style="list-style-type: none"> ■ Configuring the operational display (e.g. display format, display contrast) ■ Resetting and controlling totalizers
Setup		"Maintenance" role Commissioning: <ul style="list-style-type: none"> ■ Configuration of the measurement ■ Configuration of the inputs and outputs 	"Advanced setup" submenu: <ul style="list-style-type: none"> ■ For more customized configuration of the measurement (adaptation to special measuring conditions) ■ Configuration of totalizers ■ Configuration of electrode cleaning (optional) ■ Administration (define access code, reset measuring device)
Diagnostics		"Maintenance" role Fault elimination: <ul style="list-style-type: none"> ■ Diagnostics and elimination of process and device errors ■ Measured value simulation 	Contains all parameters for error detection and analyzing process and device errors: <ul style="list-style-type: none"> ■ "Diagnostic list" submenu Contains up to 5 currently pending diagnostic messages. ■ "Event logbook" submenu Contains up to 20 or 100 (order option "Extended HistoROM") event messages that have occurred. ■ "Device information" submenu Contains information for identifying the device. ■ "Measured values" submenu Contains all current measured values. ■ "Heartbeat Technology" submenu The functionality of the device is checked on demand and the verification results are documented. ■ "Simulation" submenu Is used to simulate measured values or output values.
Expert	function-oriented	Tasks that require detailed knowledge of the function of the device: <ul style="list-style-type: none"> ■ Commissioning measurements under difficult conditions ■ Optimal adaptation of the measurement to difficult conditions ■ Detailed configuration of the communication interface ■ Error diagnostics in difficult cases 	Contains all the parameters of the device and makes it possible to access these parameters directly using an access code. The structure of this menu is based on the function blocks of the device: <ul style="list-style-type: none"> ■ "System" submenu Contains all higher-order device parameters that do not pertain either to measurement or the measured value communication. ■ "Sensor" submenu Configuration of the measurement. ■ "Application" submenu Configuration of the functions that go beyond the actual measurement (e.g. totalizer). ■ "Diagnostics" submenu Error detection and analysis of process and device errors and for device simulation and Heartbeat Technology.



8.3 Access to the operating menu via the Web browser

8.3.1 Function range

Thanks to the integrated Web server the device can be operated and configured via a Web browser. In addition to the measured values, status information on the device is also displayed and allows the user to monitor the status of the device. Furthermore the device data can be managed and the network parameters can be configured.

8.3.2 Prerequisites

Hardware

Connecting cable	Standard Ethernet cable with RJ45 connector
Computer	RJ45 interface
Measuring device:	Web server must be enabled; factory setting: ON  For information on enabling the Web server (→  42)

Software of the computer

Web browsers supported	<ul style="list-style-type: none"> ■ Microsoft Internet Explorer (min. 8.x) ■ Mozilla Firefox ■ Google chrome
Recommended operating systems	<ul style="list-style-type: none"> ■ Windows XP ■ Windows 7
User rights for TCP/IP settings	User rights required for TCP/IP settings (e.g. for changes to IP address, subnet mask)
Computer configuration	<ul style="list-style-type: none"> ■ JavaScript is enabled ■ If JavaScript cannot be enabled, enter <code>http://XXX.XXX.X.XXX/basic.html</code> in the address line of the Web browser, e.g. <code>http://192.168.1.212/basic.html</code>. A fully functional but simplified version of the operating menu structure starts in the Web browser.



When installing a new firmware version:

To enable correct data display, clear the temporary memory (cache) of the Web browser under **Internet options**.


8.3.3 Establishing a connection

Configuring the Internet protocol of the computer

The following information refers to the default Ethernet settings of the device.

IP address of the device: 192.168.1.212 (factory setting)


IP address	192.168.1.XXX; for XXX all numerical values except: 0, 212 and 255 → e.g. 192.168.1.213
Subnet mask	255.255.255.0
Default gateway	192.168.1.212 or leave cells empty

1. Switch on the measuring device and connect to the computer via the cable (→  44).
2. If a 2nd network card is not used: all the applications on the notebook should be closed, or all the applications that require the Internet or network, such as e-mail, SAP applications, Internet or Windows Explorer, i.e. close all open Internet browsers.
3. Configure the properties of the Internet protocol (TCP/IP) as defined in the table above.

Starting the Web browser

1. Start the Web browser on the computer.
2. Enter the IP address of the Web server in the address line of the Web browser: 192.168.1.212

The login page appears.



A0017362

- 1 Device tag (→ 49)
- 2 Picture of device

i If a login page does not appear, or if the page is incomplete (→ 67)


8.3.4 Logging on

- 1. Select the preferred operating language for the Web browser.
- 2. Enter the access code.
- 3. Press **OK** to confirm your entry.

Access code	0000 (factory setting); can be changed by customer (→ 62)
-------------	---

i If no action is performed for 10 minutes, the Web browser automatically returns to the login page.

8.3.5 User interface






A0017757-EN

- 1 Picture of device
- 2 Function row with 6 functions
- 3 Device tag
- 4 Header
- 5 Working area
- 6 Navigation area

Header

The following information appears in the header:

- Device tag (→  49)
- Device status with status signal (→  69)
- Current measured values (→  64)

Function row

Functions	Meaning
Measured values	The measured values of the device are displayed
Menu	Access to the operating menu structure of the device, same as for the operating tool
Device status	Displays the diagnostic messages currently pending, listed in order of priority
Data management	<ul style="list-style-type: none"> ■ Data exchange between PC and measuring device: <ul style="list-style-type: none"> – Upload the configuration from the device (XML format, create configuration back-up) – Save the configuration to the device (XML format, restore configuration) – Export the event list (.csv file) – Export parameter settings (.csv file, create documentation of the measuring point configuration) – Export the Heartbeat verification log (PDF file, only available with the "Heartbeat Verification" application package) ■ Upload the device driver for system integration from the device
Network configuration	Configuration and checking of all the parameters required for establishing the connection to the device: <ul style="list-style-type: none"> ■ Network settings (e.g. IP address, MAC address) ■ Device information (e.g. serial number, firmware version)
Logout	End the operation and call up the login page

Navigation area

If a function is selected in the function bar, the submenus of the function open in the navigation area. The user can now navigate through the menu structure.

Working area

Depending on the selected function and the related submenus, various actions can be performed in this area:

- Configuring parameters
- Reading measured values
- Calling up help text
- Starting an upload/download

8.3.6 Disabling the Web server

The Web server for the measuring device can enabled and disabled as required via the **Web server functionality** parameter.

Navigation

"Expert" menu → Communication → Web server

Parameter overview with brief description


Parameter	Description	Selection	Factory setting
Web server functionality	Switch the Web server on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	On


Enabling the Web server

If the Web server is disabled it can only be re-enabled with the **Web server functionality** parameter via the following operating options:

Via "FieldCare" operating tool

8.3.7 Logging out


 Before logging out, perform a data backup via the **Data management** function (upload configuration from device) if necessary.

1. Select the **Logout** entry in the function row.
↳ The home page with the Login box appears.
2. Close the Web browser.
3. Reset the modified properties of the Internet protocol (TCP/IP) if they are no longer needed (→  40).

8.4 Access to the operating menu via the operating tool

8.4.1 Connecting the operating tool


Via PROFIBUS DP network



- 1 Automation system
 2 Computer with PROFIBUS network card
 3 PROFIBUS DP network
 4 Measuring device

A0020903

Via service interface (CDI-RJ45)



A0021270

15 Connection for order code for "Output", option L: PROFIBUS DP

- 1 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 3 Standard Ethernet connecting cable with RJ45 plug

8.4.2 FieldCare

Function scope

FDT-based plant asset management tool from Endress+Hauser. It can configure all smart field devices in a system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.

Access takes place via:

Service interface CDI-RJ45 (→ 44)

Typical functions:

- Configuring parameters of transmitters
- Loading and saving device data (upload/download)
- Documentation of the measuring point
- Visualization of the measured value memory (line recorder) and event logbook

For details, see Operating Instructions BA00027S and BA00059S

Source for device description files


See data (→ 46)

Establishing a connection


Via service interface (CDI-RJ45)

1. Start FieldCare and launch the project.
2. In the network: Add a device.
 - ↳ The **Add device** window opens.
3. Select the **CDI Communication TCP/IP** option from the list and press **OK** to confirm.
4. Right-click **CDI Communication TCP/IP** and select the **Add device** option in the context menu that opens.
5. Select the desired device from the list and press **OK** to confirm.
 - ↳ The **CDI Communication TCP/IP (Configuration)** window opens.

6. Enter the device address in the **IP address** field and press **Enter** to confirm: 192.168.1.212 (factory setting); if the IP address is not known .
7. Establish the online connection to the device.

 For details, see Operating Instructions BA00027S and BA00059S

User interface




A0021051-EN

- 1 Header
- 2 Picture of device
- 3 Device name
- 4 Device tag (→ 49)
- 5 Status area with status signal (→ 69)
- 6 Display area for current measured values
- 7 Event list with additional functions such as save/load, events list and document creation
- 8 Navigation area with operating menu structure
- 9 Operating range
- 10 Range of action
- 11 Status area

9 System integration

9.1 Overview of device description files

9.1.1 Current version data for the device

Firmware version	01.01.zz	<ul style="list-style-type: none"> On the title page of the Operating instructions On transmitter nameplate (→  13) Parameter firmware version Diagnostics → Device info → Firmware version
Release date of firmware version	10.2014	---
Manufacturer ID	0x11	Manufacturer ID parameter Diagnostics → Device info → Manufacturer ID
Device type ID	0x1560	Device type parameter Diagnostics → Device info → Device type
Profile version	3.02	---

9.1.2 Operating tools

The suitable device description file for the operating tool is listed in the table below, along with information on where the file can be acquired.

Operating tool via PROFIBUS protocol	Sources for obtaining device descriptions
FieldCare	<ul style="list-style-type: none"> www.endress.com → Download Area CD-ROM (contact Endress+Hauser) DVD (contact Endress+Hauser)

9.2 Device master file (GSD)

In order to integrate field devices into a bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate.

These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned. In addition device bit maps, which appear as icons in the network structure, can also be integrated.

With the Profile 3.0 device master file (GSD) it is possible to exchange field devices made by different manufacturers without having to reconfigure.

Generally speaking two different GSD versions are possible with Profile 3.0 and higher.



- Before configuring, the user must decide which GSD should be used to operate the system.
- The setting can be changed via a Class 2 master.

9.2.1 Manufacturer-specific GSD

This GSD guarantees the unrestricted functionality of the measuring device. Device-specific process parameters and functions are therefore available.

Manufacturer-specific GSD	ID number	File name
PROFIBUS DP	0x1561	EH3x1561.gsd

The fact that the manufacturer-specific GSD should be used is specified in the **Ident number selector** parameter by selecting the **Manufacturer** option.



Where to acquire the manufacturer-specific GSD:

www.endress.com → Download Area

9.2.2 Profile GSD

Differs in terms of the number of Analog Input blocks (AI) and the measured values. If a system is configured with a Profile GSD, it is possible to exchange devices made by different manufacturers. However, it is essential to ensure that the order of the cyclic process values is correct.

ID number	Supported blocks	Supported channels
0x9740	<ul style="list-style-type: none"> 1 Analog Input 1 Totalizer 	<ul style="list-style-type: none"> Channel Analog Input: volume flow Channel totalizer: volume flow
0x9741	<ul style="list-style-type: none"> 2 Analog Input 1 Totalizer 	<ul style="list-style-type: none"> Channel Analog Input 1: volume flow Channel Analog Input 2: mass flow Channel totalizer: volume flow
0x9742	<ul style="list-style-type: none"> 3 Analog Input 1 Totalizer 	<ul style="list-style-type: none"> Channel Analog Input 1: volume flow Channel Analog Input 2: mass flow Channel Analog Input 3: corrected volume flow Channel totalizer: volume flow

The Profile GSD that is to be used is specified in the **Ident number selector** parameter by selecting the **Profile 0x9740** option, **Profile 0x9741** option or **Profile 0x9742** option.

10 Commissioning

10.1 Function check

Before commissioning the device, make sure that the post-installation and post-connection checks have been performed.

- "Post-installation check" checklist (→ 25)
- "Post-connection check" checklist (→ 35)

10.2 Establishing a connection via FieldCare

- For FieldCare connection (→ 43)
- For establishing a connection via FieldCare (→ 44)
- For FieldCare user interface (→ 45)

10.3 Configuring the device address via software

In the "Communication" submenu the device address can be set.


Navigation

"Setup" menu → Communication → Device address

10.3.1 PROFIBUS network

At time of delivery, the measuring device has the following factory setting:


Device address	126
----------------	-----

 If hardware addressing is active, software addressing is blocked (→ 33)

10.4 Configuring the measuring device

The **Setup** menu with its submenus contains all the parameters needed for standard operation.



Structure of the "Setup" menu



10.4.1 Defining the tag name

To enable fast identification of the measuring point within the system, you can enter a unique designation using the **Device tag** parameter and thus change the factory setting.

 The number of characters displayed depends on the characters used.

 For information on the tag name in the "FieldCare" operating tool (→  45)

Navigation

"Setup" menu → Device tag

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device tag	Enter the name for the measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).	Promag 100 DP

10.4.2 Setting the system units

In the **System units** submenu the units of all the measured values can be set.

Navigation

"Setup" menu → System units

System units

→

Volume flow unit

Volume unit

Conductivity unit

Temperature unit

Mass flow unit

Mass unit

Density unit

Corrected volume flow unit

Corrected volume unit

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Volume flow unit	Select volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> l/h gal/min (us)
Volume unit	Select volume unit. Result The selected unit is taken from: Volume flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> l gal (us)
Conductivity unit	Select conductivity unit. <i>Result</i> The selected unit applies for: Simulation process variable	Unit choose list	µS/cm
Temperature unit	Select temperature unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Output Reference temperature Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> °C (Celsius) °F (Fahrenheit)
Mass flow unit	Select mass flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg/h lb/min
Mass unit	Select mass unit. <i>Result</i> The selected unit is taken from: Mass flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg lb
Density unit	Select density unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Output Simulation process variable Density adjustment (in Expert menu) 	Unit choose list	Country-specific: <ul style="list-style-type: none"> kg/l lb/ft³
Corrected volume flow unit	Select corrected volume flow unit. <i>Result</i> The selected unit applies for: <ul style="list-style-type: none"> Output Low flow cut off Simulation process variable 	Unit choose list	Country-specific: <ul style="list-style-type: none"> NI/h Sft³/h
Corrected volume unit	Select corrected volume unit. Result The selected unit is taken from: Corrected volume flow unit parameter	Unit choose list	Country-specific: <ul style="list-style-type: none"> NI Sft³


10.4.3 Configuring the local display

The **Display** wizard guides you systematically through all the parameters that can be configured for configuring the local display.

Navigation

"Setup" menu → Display

Structure of the wizard



16 "Display" wizard in the "Setup" menu

A0013797-EN

Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure ■ Steam quality ■ Total mass flow ■ Condensate mass flow ■ Energy flow ■ Heat flow difference ■ Reynolds number ■ Density ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 m ³ /h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	1 m ³ /h
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None

10.4.4 Configuring the communication interface

The **"Communication"** submenu guides you systematically through all the parameters that have to be configured for selecting and setting the communication interface.

Navigation

"Setup" menu → Communication

Structure of the submenu

<div style="border: 1px solid black; background-color: #cccccc; padding: 2px 5px; display: inline-block;">Communication</div>	→	<div style="border: 1px solid black; padding: 2px 5px; display: inline-block;">Device address</div>
---	---	---

Parameter overview with brief description

Parameter	Description	User entry	Factory setting
Device address	Enter device address.	0 to 126	126


10.4.5 Configuring the analog inputs

The **Analog inputs** submenu guides you systematically to the individual **Analog input 1 to 4** submenu. From here you get to the parameters of the individual analog input.

Navigation

"Setup" menu → Analog inputs → Analog input 1 to 4

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Channel	Select the process variable.	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity ■ Conductivity ■ Corrected conductivity ■ Temperature ■ Electronic temperature 	Volume flow
PV filter time	Specify a time to suppress signal peaks. During the specified time the totalizer does not respond to an erratic increase in the process variable.	Positive floating-point number	0
Fail safe type	Select the failure mode.	<ul style="list-style-type: none"> ■ Fail safe value ■ Fallback value ■ Off 	Off
Fail safe value	Specify the value to be output when an error occurs.	Signed floating-point number	0


10.4.6 Configuring the low flow cut off

The **Low flow cut off** submenu contains parameters that must be configured for the configuration of low flow cut off.

Navigation

"Setup" menu → Low flow cut off

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign process variable	–	Select process variable for low flow cut off.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow 	Volume flow
On value low flow cutoff	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow 	Enter on value for low flow cut off.	Signed floating-point number	For liquids: depends on country and nominal diameter
Off value low flow cutoff	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow 	Enter off value for low flow cut off.	0 to 100.0 %	50 %
Pressure shock suppression	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Mass flow ■ Volume flow ■ Corrected volume flow 	Enter time frame for signal suppression (= active pressure shock suppression).	0 to 100 s	0 s


10.4.7 Configuring empty pipe detection

The **Empty pipe detection** submenu contains parameters that must be configured for the configuration of low flow cut off.

Navigation

"Setup" menu → Empty pipe detection

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User interface / User entry	Factory setting
Empty pipe detection	–	Switch empty pipe detection on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
New adjustment	–	Select type of adjustment.	<ul style="list-style-type: none"> ■ Cancel ■ Empty pipe adjust ■ Full pipe adjust 	Cancel
Progress	–		<ul style="list-style-type: none"> ■ Ok ■ Busy ■ Not ok 	–
Switch point empty pipe detection	–	Enter hysteresis in %, below this value the measuring tube will detected as empty.	0 to 100 %	10 %
Response time empty pipe detection	One of the following options is selected in the Assign process variable parameter: <ul style="list-style-type: none"> ■ Density ■ Reference density 	Enter the time before diagnostic message S862 'Pipe empty' is displayed for empty pipe detection.	0 to 100 s	1 s

10.5 Advanced settings

The **Advanced setup** submenu with its submenus contains parameters for specific settings.

Overview of the parameters and submenus in the "Advanced setup" submenu

Advanced setup

→

Enter access code

Sensor adjustment (→ ⓘ 56)

Totalizer 1 to 3 (→ ⓘ 56)

Electrode cleaning circuit (→ ⓘ 60)

Administration

10.5.1 Carrying out a sensor adjustment

The **Sensor adjustment** submenu contains parameters that pertain to the functionality of the sensor.

Navigation

"Setup" menu → Advanced setup → Sensor adjustment

Structure of the submenu

Sensor adjustment

→

Installation direction

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Installation direction	Set sign of flow direction to match the direction of the arrow on the sensor.	<div><div>Flow in arrow direction</div><div>Flow against arrow direction</div></div>	Flow in arrow direction

10.5.2 Configuring the totalizer

In the **"Totalizer 1 to 3"** submenu the individual totalizers can be configured.

Navigation

"Setup" menu → Advanced setup → Totalizer 1 to 3

Totalizer 1 to 3

→

Assign process variable

Unit totalizer

Control Totalizer

Totalizer operation mode

Failure mode

Parameter overview with brief description

Parameter	Description	Selection	Factory setting
Totalizer operation mode	Select totalizer calculation mode.	<ul style="list-style-type: none"> ■ Net flow total ■ Forward flow total ■ Reverse flow total 	Net flow total
Assign process variable	Assignment of a process variable to the totalizer.	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow 	Volume flow
Unit totalizer		Unit choose list	m ³
Control Totalizer #	Control totalizer value.	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold 	Totalize
Totalizer operation mode		<ul style="list-style-type: none"> ■ Net flow total ■ Forward flow total ■ Reverse flow total ■ Last valid value 	Net flow total
Failure mode		<ul style="list-style-type: none"> ■ Stop ■ Actual value ■ Last valid value 	Actual value

10.5.3 Carrying out additional display configurations

In the **"Display"** submenu you can set all the parameters involved in the configuration of the local display.

Navigation

"Setup" menu → Advanced setup → Display

Structure of the submenu

Display	→	Format display
		Value 1 display
		0% bargraph value 1
		100% bargraph value 1
		Decimal places 1
		Value 2 display
		Decimal places 2
		Value 3 display
		0% bargraph value 3
		100% bargraph value 3
		Decimal places 3
		Value 4 display
		Decimal places 4
		Display language
		Display interval
		Display damping
		Header
		Header text
		Separator
		Backlight

Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Format display	Select how measured values are shown on the display.	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values 	1 value, max. size
Value 1 display	Select the measured value that is shown on the local display.	<ul style="list-style-type: none"> ■ Volume flow ■ Corrected volume flow ■ Mass flow ■ Flow velocity ■ Temperature ■ Calculated saturated steam pressure ■ Steam quality ■ Total mass flow ■ Condensate mass flow ■ Energy flow ■ Heat flow difference ■ Reynolds number ■ Density ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 	Volume flow
0% bargraph value 1	Enter 0% value for bar graph display.	Signed floating-point number	0 m ³ /h
100% bargraph value 1	Enter 100% value for bar graph display.	Signed floating-point number	1 m ³ /h
Decimal places 1	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 2 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 2	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 3 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
0% bargraph value 3	Enter 0% value for bar graph display.	Signed floating-point number	0
100% bargraph value 3	Enter 100% value for bar graph display.	Signed floating-point number	0
Decimal places 3	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx
Value 4 display	Select the measured value that is shown on the local display.	Picklist (see 1st display value)	None
Decimal places 4	Select the number of decimal places for the display value.	<ul style="list-style-type: none"> ■ x ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx 	x.xx

Parameter	Description	Selection / User entry	Factory setting
Display language	Set display language.	<ul style="list-style-type: none"> ■ English ■ Deutsch ■ Français ■ Español ■ Italiano ■ Nederlands ■ Portuguesa ■ Polski ■ русский язык (Russian) ■ Svenska ■ Türkçe ■ 中文 (Chinese) ■ 日本語 (Japanese) ■ 한국어 (Korean) ■ العربية (Arabic) ■ Bahasa Indonesia ■ ภาษาไทย (Thai) ■ tiếng Việt (Vietnamese) ■ čeština (Czech) 	English (alternatively, the ordered language is preset in the device)
Display interval	Set time measured values are shown on display if display alternates between values.	1 to 10 s	5 s
Display damping	Set display reaction time to fluctuations in the measured value.	0.0 to 999.9 s	5.0 s
Header	Select header contents on local display.	<ul style="list-style-type: none"> ■ Device tag ■ Free text 	Device tag
Header text	Enter display header text.		-----
Separator	Select decimal separator for displaying numerical values.	<ul style="list-style-type: none"> ■ . ■ , 	.
Backlight	Switch the local display backlight on and off.	<ul style="list-style-type: none"> ■ Disable ■ Enable 	Disable

10.5.4 Performing electrode cleaning

The **Electrode cleaning circuit** submenu contains parameters that must be configured for the configuration of electrode cleaning.




The submenu is only available if the device was ordered with electrode cleaning.

Navigation

"Setup" menu → Advanced setup → Electrode cleaning circuit

Structure of the submenu



Parameter overview with brief description


Parameter	Description	Selection / User entry / User interface	Factory setting
Electrode cleaning circuit	Enable the cyclic electrode cleaning circuit.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
ECC duration	Enter the duration of electrode cleaning in seconds.	0.01 to 30 s	2 s
ECC recovery time	Define recovery time after electrode cleaning. During this time the current output values will be held at last valid value.	1 to 3.0 ⁺³⁸ s	60 s
ECC cleaning cycle	Enter the pause duration between electrode cleaning cycles.	0.5 to 168 h	0.5 h
ECC Polarity	Select the polarity of the electrode cleaning circuit.	<ul style="list-style-type: none"> ■ Positive ■ Negative 	Positive

10.6 Simulation

The "**Simulation**" submenu enables you to simulate, without a real flow situation, various process variables in the process and the device alarm mode and to verify downstream signal chains (switching valves or closed-control loops).

Navigation

"Diagnostics" menu → Simulation



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Assign simulation process variable	–	Select a process variable for the simulation process that is activated.	<ul style="list-style-type: none"> ■ Off ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Conductivity ■ Corrected conductivity ■ Temperature 	Off
Value process variable	A process variable is selected in the Assign simulation process variable parameter.	Enter the simulation value for the selected process variable.	Signed floating-point number	0

Parameter	Prerequisite	Description	Selection / User entry	Factory setting
Simulation device alarm	–	Switch the device alarm on and off.	<ul style="list-style-type: none"> ■ Off ■ On 	Off
Simulation diagnostic event	–	Switch simulation of the diagnostic event on and off. For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter.	<ul style="list-style-type: none"> ■ Off ■ Picklist Diagnostic events (depends on the selected category)	Off

10.7 Protecting settings from unauthorized access

The following options exist for protecting the configuration of the measuring device from unintentional modification after commissioning:

- Write protection via access code for Web browser (→ 62)
- Write protection via write protection switch (→ 62)

10.7.1 Write protection via access code

With the customer-specific access code, access to the measuring device via the Web browser is protected, as are the parameters for the measuring device configuration.

Navigation

"Setup" menu → Advanced setup → Administration → Define access code

Structure of the submenu

Define access code


→


Define access code

Confirm access code

Defining the access code via the Web browser

1. Navigate to the **Enter access code** parameter.
2. Define a max. 4-digit numeric code as an access code.
3. Enter the access code again to confirm the code.
 - ↳ The Web browser switches to the login page.

 If no action is performed for 10 minutes, the Web browser automatically returns to the login page.


 The user role with which the user is currently logged on via the Web browser is indicated by the **Access status tooling** parameter. Navigation path: Operation → Access status tooling

10.7.2 Write protection via write protection switch

The write protection switch makes it possible to block write access to the entire operating menu with the exception of the following parameters:

- External pressure
- External temperature
- Reference density
- All parameters for configuring the totalizer

The parameter values are now read only and cannot be edited any more:
Via service interface (CDI-RJ45)



A0021262

1. Depending on the housing version, loosen the securing clamp or fixing screw of the housing cover.
2. Depending on the housing version, unscrew or open the housing cover and disconnect the local display from the main electronics module where necessary (→ 111).
3. Setting the write protection switch on the main electronics module to the ON position enables the hardware write protection. Setting the write protection switch on the main electronics module to the OFF position (factory setting) disables the hardware write protection.
 - ↳ If hardware write protection is enabled: the **Locking status** parameter displays the **Hardware locked** option(→ 64); if disabled, the **Locking status** parameter does not display any option (→ 64)
4. Reverse the removal procedure to reassemble the transmitter.

11 Operation

11.1 Reading device locking status

The write protection types that are currently active can be determined using the **Locking status** parameter.

Navigation

"Operation" menu → Locking status

Function scope of "Locking status" parameter

Options	Description
Hardware locked	The write protection switch (DIP switch) for hardware locking is activated on the I/O electronic module. This prevents write access to the parameters (→ 62).
Temporarily locked	Due to internal processing in the device (e.g. up-/downloading of data, reset), write access to the parameters is blocked for a short time. Once the internal processing has been completed, the parameters can be changed once again.

11.2 Reading measured values

Using the **Measured values** submenu , it is possible to read all the measured values.

"Diagnostics" menu → Measured values


11.2.1 Process variables

The **Process variables** submenu contains all the parameters needed to display the current measured values for every process variable.

Navigation

"Diagnostics" menu → Measured values → Process variables

Structure of the submenu



Structure of the submenu

Parameter overview with brief description

Parameter	Description	User interface
Volume flow	Displays the volume flow currently measured.	Signed floating-point number
Mass flow	Displays the mass flow currently calculated.	Signed floating-point number

Parameter	Description	User interface
Conductivity	Displays the corrected volume flow currently calculated.	Signed floating-point number
Corrected volume flow	Displays the temperature currently measured.	Signed floating-point number
Temperature	Displays the saturated steam pressure currently calculated.	Positive floating-point number
Corrected conductivity	Displays the steam quality currently calculated.	Positive floating-point number


11.2.2 Totalizer

The **"Totalizer"** submenu contains all the parameters needed to display the current measured values for every totalizer.

Navigation

"Diagnostics" menu → Measured values → Totalizer

Structure of the submenu



Parameter overview with brief description

Parameter	Prerequisite	Description	Selection / User entry / User interface	Factory setting
Assign process variable	–	Assignment of a process variable to the totalizer.	<ul style="list-style-type: none"> Volume flow Mass flow Corrected volume flow 	Volume flow
Totalizer value #	In the Assign process variable parameter one of the following options is selected: <ul style="list-style-type: none"> Volume flow Mass flow Corrected volume flow Total mass flow Condensate mass flow Energy flow Heat flow difference 	Displays the current totalizer counter value.	Signed floating-point number	0 m ³
Totalizer status #	–	Displays the current totalizer status.	<ul style="list-style-type: none"> Good Uncertain Bad 	Good
Totalizer status (Hex) #	–	Displays the current status value (hex) of the totalizer.	0 to 255	128

11.3 Adapting the measuring device to the process conditions

The following are available for this purpose:

- Basic settings using the **Setup** menu(→ 48)
- Advanced settings using the **Advanced setup** submenu(→ 56)

11.4 Performing a totalizer reset

In the **Operation** submenu the totalizers are reset:
Control Totalizer 1 to 3


Function scope of "Control Totalizer " parameter

Options	Description
Totalize	The totalizer is started.
Reset + hold	The totaling process is stopped and the totalizer is reset to 0.
Preset + hold	The totaling process is stopped and the totalizer is set to its defined start value from the Preset value 1 to 3 parameter.

Navigation

"Operation" menu → Operation

Structure of the submenu



Parameter overview with brief description

Parameter	Description	Selection / User entry	Factory setting
Control Totalizer 1	Control totalizer value.	<ul style="list-style-type: none">■ Totalize■ Reset + hold■ Preset + hold■ Reset + totalize■ Preset + totalize	Totalize
Preset value #	Specify start value for totalizer.	Signed floating-point number	0 m³

12 Diagnostics and troubleshooting

12.1 General troubleshooting

For output signals

Problem	Possible causes	Remedy
Green power LED on the main electronics module of the transmitter is dark	Supply voltage does not match that specified on the nameplate.	Apply the correct supply voltage (→ 29).
Device measures incorrectly.	Configuration error or device is operated outside the application.	1. Check and correct parameter configuration. 2. Observe limit values specified in the "Technical Data".

For access

Problem	Possible causes	Remedy
No write access to parameters	Hardware write protection enabled	Set the write protection switch on the main electronics module to the OFF position (→ 62).
No connection via PROFIBUS DP	PROFIBUS DP bus cable connected incorrectly	Check the terminal assignment .
No connection via PROFIBUS DP	Device plug connected incorrectly	Check the pin assignment of the device plug .
No connection via PROFIBUS DP	PROFIBUS DP cable incorrectly terminated	Check terminating resistor (→ 34).
Not connecting to Web server	Incorrect setting for the Ethernet interface of the computer	1. Check the properties of the Internet protocol (TCP/IP) (→ 40). 2. Check the network settings with the IT manager.
Not connecting to Web server	Web server disabled	Via the "FieldCare" operating tool check whether the Web server of the measuring device is enabled and enable it if necessary (→ 42).
No or incomplete display of contents in the Web browser	<ul style="list-style-type: none"> ■ JavaScript not enabled ■ JavaScript cannot be enabled 	1. Enable JavaScript. 2. Enter http://XXX.XXX.X.XXX/basic.html as the IP address.
Web browser frozen and operation no longer possible	Data transfer active	Wait until data transfer or current action is finished.
Web browser frozen and operation no longer possible	Connection lost	1. Check cable connection and power supply. 2. Refresh the Web browser and restart if necessary.
Content of Web browser incomplete or difficult to read	Not using optimum version of Web server.	1. Use the correct Web browser version (→ 40). 2. Clear the Web browser cache and restart the Web browser.
Content of Web browser incomplete or difficult to read	Unsuitable view settings.	Change the font size/display ratio of the Web browser.

12.2 Diagnostic information via light emitting diodes

12.2.1 Transmitter


Various light emitting diodes (LEDs) on the main electronics module of the transmitter provide information on device status.

LED	Color	Meaning
Power	Off	Supply voltage is off or too low
	Green	Supply voltage is ok
Alarm	Off	Device status is ok
	Flashing red	A device error of diagnostic behavior "Warning" has occurred
	Red	<ul style="list-style-type: none"> A device error of diagnostic behavior "Alarm" has occurred Boot loader is active
Communication	Flashing white	PROFIBUS DP communication is active

12.3 Diagnostic information in FieldCare

12.3.1 Diagnostic options

Any faults detected by the measuring device are displayed on the home page of the operating tool once the connection has been established.







- 1 Status area with status signal
- 2 Diagnostic information (→ 69)
- 3 Remedial measures with Service ID

i Furthermore, diagnostic events that have occurred can be viewed in the **Diagnostics** menu:

- Via parameters (→ 90)
- Via submenu (→ 91)

Status signals


The status signals provide information on the state and reliability of the device by categorizing the cause of the diagnostic information (diagnostic event).

Symbol	Meaning
 <small>A0017271</small>	Failure A device error has occurred. The measured value is no longer valid.
 <small>A0017278</small>	Function check The device is in service mode (e.g. during a simulation).
 <small>A0017277</small>	Out of specification The device is operated: Outside its technical specification limits (e.g. outside the process temperature range)
 <small>A0017276</small>	Maintenance required Maintenance is required. The measured value is still valid.

 The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107.

Diagnostic information

The fault can be identified using the diagnostic information. The short text helps you by providing information about the fault.



12.3.2 Calling up remedy information

Remedy information is provided for every diagnostic event to ensure that problems can be rectified quickly:

- On the home page
Remedy information is displayed in a separate field below the diagnostics information.
- In the **Diagnostics** menu
Remedy information can be called up in the working area of the user interface.


The user is in the **Diagnostics** menu.

1. Call up the desired parameter.
2. On the right in the working area, mouse over the parameter.
 - A tool tip with remedy information for the diagnostic event appears.

12.4 Adapting the diagnostic information

12.4.1 Adapting the diagnostic behavior

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for certain diagnostics information in the **Diagnostic behavior** submenu .

 Diagnostic behavior in accordance with Specification PROFIBUS Profile 3.02, Condensed Status.

"Expert" menu → System → Diagnostic handling → Diagnostic behavior


Available diagnostic behaviors


The following diagnostic behaviors can be assigned:

Diagnostic behavior	Description
Alarm	Measurement is interrupted. The totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	Measurement is resumed. Measured value output via PROFIBUS and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is entered in the Event logbook (events list) submenu only and is not displayed in alternation with the measured value display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

Displaying the measured value status

If the Analog Input, Digital Input and Totalizer function blocks are configured for cyclic data transmission, the device status is coded as per PROFIBUS Profile Specification 3.02 and transmitted along with the measured value to the PROFIBUS Master (Class 1) via the coding byte (byte 5). The coding byte is split into three segments: Quality, Quality Substatus and Limits.







 17 Structure of the coding byte

The content of the coding byte depends on the configured failsafe mode in the particular function block. Depending on which failsafe mode has been configured, status information in accordance with PROFIBUS Profile Specification 3.02 is transmitted to the PROFIBUS Master (Class 1) via the coding byte.

Determining the measured value status and device status via the diagnostic behavior

When the diagnostic behavior is assigned, this also changes the measured value status and device status for the diagnostic information. The measured value status and device status depend on the choice of diagnostic behavior and the group in which the diagnostic information is located. The measured value status and device status are firmly assigned to the particular diagnostic behavior and cannot be changed individually.

The diagnostic information is grouped as follows:

- Diagnostic information pertaining to the sensor: diagnostic number 000 to 199
(→  71)
- Diagnostic information pertaining to the electronics: diagnostic number 200 to 399
(→  71)
- Diagnostic information pertaining to the configuration: diagnostic number 400 to 599
(→  71)
- Diagnostic information pertaining to the process: diagnostic number 800 to 999
(→  72)

Depending on the group in which diagnostic information is located, the following measured value status and device status are firmly assigned to the particular diagnostic behavior:

Diagnostic information pertaining to the sensor (diagnostic no.: 000 to 199)

Diagnostic behavior (configurable)	Measured value status (fixed assignment)				Device diagnostics (fixed assignment)
	Quality	Quality Substatus	Coding (hex)	Category (NE107)	
Alarm	BAD	Maintenance alarm	0x24 to 0x27	F (Failure)	Maintenance alarm
Warning	GOOD	Maintenance demanded	0xA8 to 0xAB	M (Maintenance)	Maintenance demanded
Logbook entry only	GOOD	ok	0x80 to 0x8E	–	–
Off					

Diagnostic information pertaining to the electronics (diagnostic no.: 200 to 399)

Diagnostic behavior (configurable)	Measured value status (fixed assignment)				Device diagnostics (fixed assignment)
	Quality	Quality Substatus	Coding (hex)	Category (NE107)	
Alarm	BAD	Maintenance alarm	0x24 to 0x27	F (Failure)	Maintenance alarm
Warning					
Logbook entry only	GOOD	ok	0x80 to 0x8E	–	–
Off					

Diagnostic information pertaining to the configuration (diagnostic no.: 400 to 599)


Diagnostic behavior (configurable)	Measured value status (fixed assignment)				Device diagnostics (fixed assignment)
	Quality	Quality Substatus	Coding (hex)	Category (NE107)	
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTAIN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition



Diagnostic behavior (configurable)	Measured value status (fixed assignment)				Device diagnostics (fixed assignment)
	Quality	Quality Substatus	Coding (hex)	Category (NE107)	
Logbook entry only	GOOD	ok	0x80 to 0x8E	–	–
Off					

Diagnostic information pertaining to the process (diagnostic no.: 800 to 999)

Diagnostic behavior (configurable)	Measured value status (fixed assignment)				Device diagnostics (fixed assignment)
	Quality	Quality Substatus	Coding (hex)	Category (NE107)	
Alarm	BAD	Process related	0x28 to 0x2B	F (Failure)	Invalid process condition
Warning	UNCERTAIN	Process related	0x78 to 0x7B	S (Out of specification)	Invalid process condition
Logbook entry only	GOOD	ok	0x80 to 0x8E	–	–
Off					

12.5 Overview of diagnostic information

 The amount of diagnostic information and the number of measured variables affected increase if the measuring device has one or more application packages.

 In the case of some items of diagnostic information, the diagnostic behavior can be changed. Adapt the diagnostic information (→  70)

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
Diagnostic of sensor				
004	Sensor	1. Change sensor 2. Contact service	S	Alarm
022	Sensor temperature	1. Change main electronic module 2. Change sensor	F	Alarm
043	Sensor short circuit	1. Check sensor and cable 2. Change sensor or cable	S	Warning
062	Sensor connection	1. Check sensor connections 2. Contact service	F	Alarm
082	Data storage	1. Check module connections 2. Contact service	F	Alarm
083	Memory content	1. Restart device 2. Contact service	F	Alarm
190	Special event 1	Contact service	F	Alarm
191	Special event 5	Contact service	F	Alarm
Diagnostic of electronic				
201	Device failure	1. Restart device 2. Contact service	F	Alarm
222	Electronic drift	Change main electronic module	F	Alarm
242	Software incompatible	1. Check software 2. Flash or change main electronics module	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
252	Modules incompatible	1. Check electronic modules 2. Change electronic modules	F	Alarm ¹⁾
262	Module connection	1. Check module connections 2. Change main electronics	F	Alarm
270	Main electronic failure	Change main electronic module	F	Alarm
271	Main electronic failure	1. Restart device 2. Change main electronic module	F	Alarm
272	Main electronic failure	1. Restart device 2. Contact service	F	Alarm
273	Main electronic failure	Change electronic	F	Alarm
281	Electronic initialization	Firmware update active, please wait!	F	Alarm
283	Memory content	1. Reset device 2. Contact service	F	Alarm
302	Device verification active	Device verification active, please wait.	C	Warning ¹⁾
311	Electronic failure	1. Reset device 2. Contact service	F	Alarm
311	Electronic failure	1. Do not reset device 2. Contact service	M	Warning
322	Electronic drift	1. Perform verification manually 2. Change electronic	S	Warning
382	Data storage	1. Insert DAT module 2. Change DAT module	F	Alarm
383	Memory content	1. Restart device 2. Check or change DAT module 3. Contact service	F	Alarm
390	Special event 2	Contact service	F	Alarm
391	Special event 6	Contact service	F	Alarm
Diagnostic of configuration				
410	Data transfer	1. Check connection 2. Retry data transfer	F	Alarm
411	Up-/download active	Up-/download active, please wait	C	Warning
437	Configuration incompatible	1. Restart device 2. Contact service	F	Alarm
438	Dataset	1. Check data set file 2. Check device configuration 3. Up- and download new configuration	M	Warning
453	Flow override	Deactivate flow override	C	Warning
482	Block in OOS	Set Block in AUTO mode	F	Alarm
484	Simulation failure mode	Deactivate simulation	C	Alarm
485	Simulation measured variable	Deactivate simulation	C	Warning
495	Simulation block output	Deactivate simulation	C	Warning
500	Electrode 1 potential exceeded	1. Check process cond. 2. Increase system pressure	F	Alarm
500	Electrode difference voltage too high	1. Check process cond. 2. Increase system pressure	F	Alarm

Diagnostic number	Short text	Remedy instructions	Status signal [from the factory]	Diagnostic behavior [from the factory]
530	Electrode cleaning is running	1. Check process cond. 2. Increase system pressure	C	Warning
531	Empty pipe detection	Execute EPD adjustment	S	Warning ¹⁾
537	Configuration	1. Check IP addresses in network 2. Change IP address	F	Warning
590	Special event 3	Contact service	F	Alarm
591	Special event 7	Contact service	F	Alarm
Diagnostic of process				
832	Ambient temperature too high	Reduce ambient temperature	S	Warning ¹⁾
833	Ambient temperature too low	Increase ambient temperature	S	Warning ¹⁾
834	Process temperature too high	Reduce process temperature	S	Warning ¹⁾
835	Process temperature too low	Increase process temperature	S	Warning ¹⁾
842	Process limit	Low flow cut off active! 1. Check low flow cut off configuration	S	Warning
862	Empty pipe	1. Check for gas in process 2. Adjust empty pipe detection	S	Warning ¹⁾
882	Input signal	1. Check input configuration 2. Check pressure sensor or process conditions	F	Alarm
937	EMC interference	1. Check ambient conditions regarding EMC influence 2. Change main electronic module	S	Warning ¹⁾
937	EMC interference	Change main electronic module	S	Warning ¹⁾
990	Special event 4	Contact service	F	Alarm
991	Special event 8	Contact service	F	Alarm

1) Diagnostic status is changeable.

12.5.1 Diagnostics for the sensor


Diagnostic no. 022

Message: F022 Sensor temperature

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">▪ Change main electronics module.▪ Change sensor.		


Diagnostic no. 044

Message: *044 Sensor drift

Measured value status		Measured variables concerned <ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality:	GOOD	
Quality Substatus:	Maintenance demanded	
Coding (hex):	0xA8	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check or change main electronics module.■ Change sensor.		

Diagnostic no. 046

Message: *046 Sensor limit

Measured value status		Measured variables concerned
Quality:	GOOD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Volume flow
Quality Substatus:	Maintenance demanded	
Coding (hex):	0xA8	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check sensor.■ Check process conditions.		

Diagnostic no. 062

Message: F062 Sensor connection

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">■ Change main electronics module.■ Change sensor.		

Diagnostic no. 082

Message: F082 Data storage


Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none"> ■ Density ■ Partially filled pipe detection ■ Low flow cut off ■ Mass flow ■ Status value pulse/freq./switch output ■ Reference density
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	

Category (NE107):	F (Failure)	<ul style="list-style-type: none">■ Corrected volume flow■ Temperature■ Volume flow
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">■ Check module connections.■ Contact service.		

Diagnostic no. 083**Message: F083 Memory content**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Restart the device.</div> <div>▪ Contact service.</div>		

Diagnostic no. 144**Message: *144 Measuring error too high**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→  70)		
Alarm (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check or change sensor.■ Check process conditions.		

Diagnostic no. 190**Message: F190 Special event 1**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		


Diagnostic no. 191

Message: F191 Special event 5

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 192

Message: *192 Special event 9

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→  70)		
Alarm (factory setting)		
Remedial measures		
Contact service.		

12.5.2 Diagnostics for the electronics

Diagnostic no. 201

Message: F201 Device failure

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Restart the device.</div> <div>▪ Contact service.</div>		

Diagnostic no. 242

Message: F242 Software incompatible

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	

Coding (hex):	0x24
Category (NE107):	F (Failure)
Diagnostic behavior:	Alarm
Remedial measures	
<ul style="list-style-type: none"> ■ Check software. ■ Flash or change main electronic module. 	

Diagnostic no. 252**Message: *252 Modules incompatible**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→ 📄 70)		
Alarm (factory setting)		
Remedial measures		
<ul style="list-style-type: none">▪ Check electronic modules.▪ Change electronics modules.		

Diagnostic no. 262**Message: F262 Module connection**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">▪ Check module connections.▪ Change main electronics.		

Diagnostic no. 270**Message: F270 Main electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		

Change main electronics.	
--------------------------	--

Diagnostic no. 271**Message: F271 Main electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">Restart the device.Change main electronics module.		

Diagnostic no. 272**Message: F272 Main electronic failure**


Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Restart the device.</div> <div>▪ Contact service.</div>		

Diagnostic no. 273**Message: F273 Main electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Replace electronics.		

Diagnostic no. 274**Message: *274 Main electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none"> Mass flow Corrected volume flow

Quality Substatus:	Maintenance alarm, more diagnosis available	■ Volume flow
Coding (hex):	0x24	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Replace electronics.		

Diagnostic no. 283**Message: F283 Memory content**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Reset device.</div> <div>▪ Contact service.</div>		

Diagnostic no. 311**Message: F311 Electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Reset device.</div> <div>▪ Contact service.</div>		

Diagnostic no. 311**Message: M311 Electronic failure**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	M (Maintenance)	
Diagnostic behavior:	Warning	
Remedial measures		

- Do not reset device.
- Contact service.

Diagnostic no. 382**Message: F382 Data storage**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<div>▪ Insert DAT module.</div> <div>▪ Replace DAT module.</div>		

Diagnostic no. 383**Message: F383 Memory content**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">▪ Restart the device.▪ Check or replace DAT module.▪ Contact service.		

Diagnostic no. 390**Message: F390 Special event 2**


Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 391**Message: F391 Special event 6**

Measured value status	Measured variables concerned
-----------------------	------------------------------

Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 392**Message: *392 Special event 10**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">▪ Density▪ Mass flow▪ Reference density▪ Corrected volume flow▪ Temperature
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→  70)		
Alarm (factory setting)		
Remedial measures		
Contact service.		

12.5.3 Diagnostics for the configuration

Diagnostic no. 410**Message: F410 Data transfer**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">■ Check connection.■ Retry data transfer.		

Diagnostic no. 411**Message: C411 Up-/download active**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Function check	
Coding (hex):	0x3C	
Category (NE107):	C (Check)	
Diagnostic behavior:	Warning	

Remedial measures	<ul style="list-style-type: none"> Volume flow
Up-/download active: Wait until the up-/download is complete.	

Diagnostic no. 411**Message: C411 Up-/download active**

Measured value status		Measured variables concerned
Quality:	GOOD	<ul style="list-style-type: none">▪ Density▪ Partially filled pipe detection▪ Low flow cut off▪ Mass flow▪ Status value pulse/freq./switch output▪ Reference density▪ Corrected volume flow▪ Temperature▪ Volume flow
Quality Substatus:	Function check	
Coding (hex):	0x3C	
Category (NE107):	C (Check)	
Diagnostic behavior:	Warning	
Remedial measures		
Up-/download active: Wait until the up-/download is complete.		

Diagnostic no. 437**Message: F437 Configuration incompatible**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">Restart the device.Contact service.		

Diagnostic no. 438**Message: M438 Dataset**

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	
Quality Substatus:	Maintenance demanded	
Coding (hex):	0x68	
Category (NE107):	M (Maintenance)	
Diagnostic behavior:	Warning	
Remedial measures		
<ul style="list-style-type: none">▪ Check data set file.▪ Check device configuration.▪ Up- and download new configuration.		

Diagnostic no. 453**Message: C453 Flow override**

Measured value status	Measured variables concerned
-----------------------	------------------------------

Quality:	GOOD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Function check	
Coding (hex):	0xBC	
Category (NE107):	C (Check)	
Diagnostic behavior:	Warning	
Remedial measures		
Deactivate flow override.		

Diagnostic no. 484**Message: C484 Simulation failsafe mode**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Function check	
Coding (hex):	0x3C	
Category (NE107):	C (Check)	
Diagnostic behavior:	Alarm	
Remedial measures		
Deactivate simulation.		

Diagnostic no. 485**Message: C485 Simulation process variable**

Measured value status		Measured variables concerned
Quality:	GOOD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Function check	
Coding (hex):	0xBC	
Category (NE107):	C (Check)	
Diagnostic behavior:	Warning	
Remedial measures		
Deactivate simulation.		

Diagnostic no. 590**Message: F590 Special event 3**

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	M (Maintenance)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		


Diagnostic no. 591

Message: F591 Special event 7

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	M (Maintenance)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 592

Message: *592 Special event 11

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Function check	
Coding (hex):	0x3C	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→  70)		
Alarm (factory setting)		
Remedial measures		
Contact service.		

12.5.4 Diagnostics for the process

Diagnostic no. 825

Message: S825 Operating temperature

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	All the measured variables available
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior:	Warning	
Remedial measures		
<div>▪ Check ambient temperature.</div> <div>▪ Check process temperature.</div>		

Diagnostic no. 825


Message: F825 Operating temperature

Measured value status		Measured variables concerned
Quality:	BAD	All the measured variables available
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x28	
Category (NE107):	F (Failure)	

Diagnostic behavior:	Alarm
Remedial measures	
<ul style="list-style-type: none"> ■ Check ambient temperature. ■ Check process temperature. 	


Diagnostic no. 830

Message: *830 Ambient temperature

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Reduce the ambient temp. around the sensor housing.		


Diagnostic no. 831

Message: *831 Ambient temperature

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Reduce the ambient temp. around the sensor housing.		

Diagnostic no. 832


Message: *832 Ambient temperature too high

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Reduce ambient temperature.		


Diagnostic no. 833

Message: *833 Ambient temperature too low


Measured value status	Measured variables concerned
-----------------------	------------------------------

Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Increase ambient temperature.		

Diagnostic no. 834**Message: *834 Process temperature too high**

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Reduce process temperature.		

Diagnostic no. 835**Message: *835 Process temperature too low**

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
Increase process temperature.		

Diagnostic no. 842**Message: S842 Process limit**

Measured value status		Measured variables concerned
Quality:	GOOD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	ok	
Coding (hex):	0x80	
Category (NE107):	S (Out of specification)	
Diagnostic behavior:	Warning	
Remedial measures		

Low flow cut off active:
Check settings for low flow cut off.


Diagnostic no. 843

Message: S843 Process limit

Measured value status		Measured variables concerned
Quality:	GOOD	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	ok	
Coding (hex):	0x80	
Category (NE107):	S (Out of specification)	
Diagnostic behavior:	Warning	
Remedial measures		
Check process conditions.		

Diagnostic no. 862

Message: *862 Partly filled pipe

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check for gas in process.■ Check detection limits.		

Diagnostic no. 882

Message: S882 Input signal

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Volume flow
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">■ Check input configuration.■ Check pressure sensor or process conditions.		


Diagnostic no. 910

Message: F910 Measuring tube does not vibrate


Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none"> ■ Density ■ Partially filled pipe detection

Quality Substatus:	Maintenance alarm	<ul style="list-style-type: none">■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
<ul style="list-style-type: none">■ Check electronics.■ Check sensor.		


Diagnostic no. 912**Message: *912 Inhomogeneous**

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Partially filled pipe detection■ Low flow cut off■ Mass flow■ Status value pulse/freq./switch output■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check process conditions.■ Increase system pressure.		

Diagnostic no. 913**Message: *913 Inhomogeneous**

Measured value status		Measured variables concerned <ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature■ Volume flow
Quality:	UNCERTAIN	
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		
<ul style="list-style-type: none">■ Check process conditions.■ Check electronic modules or sensor.		

Diagnostic no. 944**Message: *944 Monitoring failed**

Measured value status		Measured variables concerned
Quality:	UNCERTAIN	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x78	
Category (NE107):	S (Out of specification)	
Diagnostic behavior, configurable (→  70)		
Warning (factory setting)		
Remedial measures		

Check process conditions for Heartbeat Monitoring.	
--	--


Diagnostic no. 990**Message: *990 Special event 4**

Measured value status		Measured variables concerned
Quality:	BAD	–
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 991**Message: *991 Special event 8**





Measured value status		Measured variables concerned
Quality:	BAD	–
Quality Substatus:	Maintenance alarm, more diagnosis available	
Coding (hex):	0x24	
Category (NE107):	F (Failure)	
Diagnostic behavior:	Alarm	
Remedial measures		
Contact service.		

Diagnostic no. 992**Message: *992 Special event 12**

Measured value status		Measured variables concerned
Quality:	BAD	<ul style="list-style-type: none">■ Density■ Mass flow■ Reference density■ Corrected volume flow■ Temperature
Quality Substatus:	Process related, no maintenance	
Coding (hex):	0x28	
Category (NE107):	F (Failure)	
Diagnostic behavior, configurable (→  70)		
Alarm (factory setting)		
Remedial measures		
Contact service.		

12.6 Pending diagnostic events


The **Diagnostics** menu allows the user to view the current diagnostic event and the previous diagnostic event separately.

-  To call up the measures to rectify a diagnostic event:
 - Via Web browser
 - Via "FieldCare" operating tool (→  69)
-  Other pending diagnostic events can be displayed in the **Diagnostic list** submenu(→  91)


Navigation

"Diagnostics" menu

Structure of the submenu



Parameter overview with brief description



Parameter	Prerequisite	Description	User interface	Factory setting
Actual diagnostics	1 diagnostic event has occurred.	Displays the current diagnostic event along with the diagnostic information.  If two or more messages occur simultaneously, the message with the highest priority is shown on the display.	Symbol for diagnostic behavior, diagnostic code and short message.	–
Previous diagnostics	2 diagnostic events have already occurred.	Displays the diagnostic event that occurred prior to the current diagnostic event along with the diagnostic information.	Symbol for diagnostic behavior, diagnostic code and short message.	–

12.7 Diagnostic list

In the **Diagnostic list** submenu, up to 5 currently pending diagnostic events can be displayed along with the related diagnostic information. If more than 5 diagnostic events are pending, the events with the highest priority are shown on the display.

Navigation path

Diagnostics menu → **Diagnostic list** submenu

-  To call up the measures to rectify a diagnostic event:
 - Via Web browser
 - Via "FieldCare" operating tool (→  69)

12.8 Event logbook

12.8.1 Event history



A chronological overview of the event messages that have occurred is provided in the events list which contains a maximum of 20 message entries. This list can be displayed via FieldCare if necessary.

Navigation path




Event list: **F** → Tool box → Additional functions

 For information on the event list, see the FieldCare user interface

This event history includes entries for:

- Diagnostic events (→  72)
- Information events (→  92)


In addition to the operation time of its occurrence and possible troubleshooting measures, each event is also assigned a symbol that indicates whether the event has occurred or is ended:

- Diagnostic event
 - : Event has occurred
 - : Event has ended
- Information event
 - : Event has occurred

A chronological overview of the event messages that have occurred is provided in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Events list

 To call up the measures to rectify a diagnostic event:

- Via Web browser
- Via "FieldCare" operating tool (→  69)

 For filtering the displayed event messages (→  92)

12.8.2 Filtering the event logbook

Using the **Filter options** parameter, you can define which category of event messages is displayed in the **Events list** submenu.

Navigation path

"Diagnostics" menu → Event logbook → Filter options

Filter categories

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

12.8.3 Overview of information events

Unlike a diagnostic event, an information event is displayed in the event logbook only and not in the diagnostic list.

Info number	Info name
I1000	----- (Device ok)
I1089	Power on
I1090	Configuration reset
I1091	Configuration changed
I1110	Write protection switch changed
I1137	Electronic changed
I1151	History reset
I1155	Reset electronic temperature
I1157	Memory error event list


Info number	Info name
I1185	Display backup done
I1186	Restore via display done
I1187	Settings downloaded with display
I1188	Display data cleared
I1189	Backup compared
I1256	Display: access status changed
I1264	Safety sequence aborted
I1335	Firmware changed
I1351	Empty pipe detection adjustment failure
I1353	Empty pipe detection adjustment ok
I1361	Wrong web server login
I1397	Fieldbus: access status changed
I1398	CDI: access status changed
I1443	Coating thickness not determined
I1444	Device verification passed
I1445	Device verification failed
I1446	Device verification active
I1457	Failed: Measured error verification
I1459	Failed: I/O module verification
I1461	Failed: Sensor verification
I1462	Failed: Sensor electronic module verific.

12.9 Resetting the measuring device

Using the **Device reset** parameter it is possible to reset the entire device configuration or some of the configuration to a defined state.

"Setup" menu → Advanced setup → Administration

Function scope of "Device reset" parameter

Options	Description
Cancel	No action is executed and the user exits the parameter.
To delivery settings	<p>Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.</p> <p> This option is not visible if no customer-specific settings have been ordered.</p>
Restart device	The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.
History reset	Every parameter is reset to its factory setting.

12.10 Device information

The **Device information** submenu contains all the parameters that display different information for identifying the device.

Navigation

"Diagnostics" menu → Device information

Device information	→	Device tag
		Serial number
		Firmware version
		Device name
		Order code
		Extended order code 1
		Extended order code 2
		Extended order code 3
		ENP version
		IP address
		Subnet mask
		Default gateway

Parameter overview with brief description


Parameter	Description	User interface	Factory setting
Device tag	Enter tag for measuring point.	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /)	Promag 100 DP
Serial number	Displays the serial number of the measuring device.	Max. 11-digit character string comprising letters and numbers.	79AFF16000
Firmware version	Displays the device firmware version installed.	Character string with the following format: xx.yy.zz	01.00
Device name	Displays the name of the transmitter.	Character string composed of letters, numbers and certain punctuation marks.	Promag 100 DP
Order code	Displays the device order code.	Character string composed of letters, numbers and certain punctuation marks	–
Extended order code 1	Displays the 1st part of the extended order code.	Character string	–
Extended order code 2	Displays the 2nd part of the extended order code.	Character string	-
Extended order code 3	Displays the 3rd part of the extended order code.	Character string	-
ENP version	Displays the version of the electronic nameplate.	Character string in the format xx.yy.zz	2.02.00
PROFIBUS ident number		0 to 65 535	5 472
Status PROFIBUS Master Config		<ul style="list-style-type: none"> ■ Active ■ Not active 	Not active


Parameter	Description	User interface	Factory setting
IP address	Displays the IP address of the Web server of the measuring device.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212
Subnet mask	Displays the subnet mask.	4 octet: 0 to 255 (in the particular octet)	255.255.255.0
Default gateway	Displays the default gateway.	4 octet: 0 to 255 (in the particular octet)	192.168.1.212

12.11 Firmware history

Release date	Firmware version	Order code for "Firmware version"	Firmware changes	Documentation type	Documentation
09.2013	01.01.00	Option 78	Original firmware	Operating Instructions	BA01237D/06/EN/01.13
10.2014	01.01.zz	Option 69	<ul style="list-style-type: none"> ■ Integration of optional onsite display ■ New unit "Beer Barrel (BBL)" ■ Simulation of diagnostic events 	Operating Instructions	BA01237D/06/EN/02.14

 Flashing the firmware to the current version or to the previous version is possible via the service interface (CDI) .

 For the compatibility of the firmware version with the previous version, the installed device description files and operating tools, observe the information about the device in the "Manufacturer's information" document.

 The manufacturer's information is available:

- In the Download Area of the Endress+Hauser Internet site: www.endress.com → Download
- Specify the following details:
 - Product root: e.g. 5H1B
 - Text search: Manufacturer's information
 - Search range: documentation

13 Maintenance

13.1 Maintenance tasks

No special maintenance work is required.

13.1.1 Exterior cleaning

When cleaning the exterior of measuring devices, always use cleaning agents that do not attack the surface of the housing or the seals.


13.1.2 Interior cleaning

No interior cleaning is planned for the device.

13.1.3 Replacing seals

The sensor's seals (particularly aseptic molded seals) must be replaced periodically.

The interval between changes depends on the frequency of the cleaning cycles, the cleaning temperature and the medium temperature.

Replacement seals (accessory) (→  114)

13.2 Measuring and test equipment

Endress+Hauser offers a wide variety of measuring and test equipment, such as W@M or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.



For a list of some of the measuring and test equipment, refer to the "Accessories" chapter of the "Technical Information" document for the device.

13.3 Endress+Hauser services

Endress+Hauser offers a wide variety of services for maintenance such as recalibration, maintenance service or device tests.



Your Endress+Hauser Sales Center can provide detailed information on the services.

14 Repair

14.1 General notes

Repair and conversion concept

The Endress+Hauser repair and conversion concept provides for the following:

- The measuring devices have a modular design.
- Spare parts are grouped into logical kits with the associated Installation Instructions.
- Repairs are carried out by Endress+Hauser Service or by correspondingly trained customers.
- Certified devices can be converted into other certified devices by Endress+Hauser Service or at the factory only.

Notes for repair and conversion

For repair and modification of a measuring device, observe the following notes:

- Use only original Endress+Hauser spare parts.
- Carry out the repair according to the Installation Instructions.
- Observe the applicable standards, federal/national regulations, Ex documentation (XA) and certificates.
- Document every repair and each conversion and enter them into the *W@M* life cycle management database.

14.2 Spare parts



Measuring device serial number:

- Is located on the nameplate of the device.
- Can be read out via the **Serial number** parameter in the **Device information** submenu (→ 93).

14.3 Endress+Hauser services



Contact your Endress+Hauser Sales Center for information on services and spare parts.

14.4 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as an ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with medium.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at

www.services.endress.com/return-material

14.5 Disposal

14.5.1 Removing the measuring device

1. Switch off the device.
2. **WARNING!** Danger to persons from process conditions. Beware of hazardous process conditions such as pressure in the measuring device, high temperatures or aggressive fluids.

Carry out the mounting and connection steps from the chapters "Mounting the measuring device" and "Connecting the measuring device" in the logically reverse sequence. Observe the safety instructions.

14.5.2 Disposing of the measuring device

WARNING

Danger to personnel and environment from fluids that are hazardous to health.

- ▶ Ensure that the measuring device and all cavities are free of fluid residues that are hazardous to health or the environment, e.g. substances that have permeated into crevices or diffused through plastic.

Observe the following notes during disposal:


- Observe valid federal/national regulations.
- Ensure proper separation and reuse of the device components.

15 Accessories


Various accessories, which can be ordered with the device or subsequently from Endress+Hauser, are available for the device. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

15.1 Device-specific accessories

15.1.1 For the transmitter

Accessories	Description
Adapter set	Adapter connections for installing Promag H instead of a Promag 30/33 A or Promag 30/33 H (DN 25) device. Consists of: <ul style="list-style-type: none"> 2 process connections Threaded fasteners Seals
Seal set	For the regular replacement of seals for the sensor.
Spacer	If replacing a DN 80/100 sensor in an existing installation, a spacer is needed if the new sensor is shorter.
Welding jig	Welded connection as process connection: welding jig for installation in pipe.
Grounding rings	Are used to ground the fluid in lined measuring tubes to ensure proper measurement.  For details, see Installation Instructions EA00070D
Mounting kit	Consists of: <ul style="list-style-type: none"> 2 process connections Threaded fasteners Seals
Wall mounting kit	Wall mounting kit for measuring device (only DN 2 to 25 (1/12 to 1"))


15.1.2 For the sensor

Accessories	Description
Adapter set	Adapter connections for installing Promag H instead of a Promag 30/33 A or Promag 30/33 H (DN 25) device. Consists of: <ul style="list-style-type: none"> 2 process connections Threaded fasteners Seals
Seal set	For the regular replacement of seals for the sensor.
Spacer	If replacing a DN 80/100 sensor in an existing installation, a spacer is needed if the new sensor is shorter.
Welding jig	Welded connection as process connection: welding jig for installation in pipe.
Grounding rings	Are used to ground the fluid in lined measuring tubes to ensure proper measurement.  For details, see Installation Instructions EA00070D
Mounting kit	Consists of: <ul style="list-style-type: none"> 2 process connections Threaded fasteners Seals
Wall mounting kit	Wall mounting kit for measuring device (only DN 2 to 25 (1/12 to 1"))


15.2 Communication-specific accessories

Accessories	Description
-------------	-------------

15.3 Service-specific accessories

Accessories	Description
Applicator	<p>Software for selecting and sizing Endress+Hauser measuring devices:</p> <ul style="list-style-type: none"> ■ Calculation of all the necessary data for identifying the optimum flowmeter: e.g. nominal diameter, pressure loss, accuracy or process connections. ■ Graphic illustration of the calculation results <p>Administration, documentation and access to all project-related data and parameters over the entire life cycle of a project.</p> <p>Applicator is available:</p> <ul style="list-style-type: none"> ■ Via the Internet: https://wapps.endress.com/applicator ■ On CD-ROM for local PC installation.
W@M	<p>Life cycle management for your plant</p> <p>W@M supports you with a wide range of software applications over the entire process: from planning and procurement, to the installation, commissioning and operation of the measuring devices. All the relevant device information, such as the device status, spare parts and device-specific documentation, is available for every device over the entire life cycle.</p> <p>The application already contains the data of your Endress+Hauser device. Endress+Hauser also takes care of maintaining and updating the data records.</p> <p>W@M is available:</p> <ul style="list-style-type: none"> ■ Via the Internet: www.endress.com/lifecyclemanagement ■ On CD-ROM for local PC installation.
FieldCare	<p>FDT-based plant asset management tool from Endress+Hauser.</p> <p>It can configure all smart field units in your system and helps you manage them. By using the status information, it is also a simple but effective way of checking their status and condition.</p> <p> For details, see Operating Instructions BA00027S and BA00059S</p>

15.4 System components

Accessories	Description
Memograph M graphic display recorder	<p>The Memograph M graphic display recorder provides information on all relevant measured variables. Measured values are recorded correctly, limit values are monitored and measuring points analyzed. The data are stored in the 256 MB internal memory and also on a SD card or USB stick.</p> <p> For details, see "Technical Information" TI00133R and Operating Instructions BA00247R</p>


16 Technical data

16.1 Application


Depending on the version ordered, the measuring device can also measure potentially explosive, flammable, poisonous and oxidizing media.



To ensure that the device remains in proper operating condition for its service life, use the measuring device only for media against which the process-wetted materials are adequately resistant.

16.2 Function and system design

Measuring principle	Electromagnetic flow measurement on the basis of <i>Faraday's law of magnetic induction</i> .
Measuring system	One device version is available: compact version, transmitter and sensor form a mechanical unit. For information on the structure of the device (→  11)

16.3 Input

Measured variable	Direct measured variables <ul style="list-style-type: none"> ■ Volume flow (proportional to induced voltage) ■ Temperature (DN 15 to 150 (½ to 6")) ■ Electrical conductivity Calculated measured variables <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ Corrected electrical conductivity
Measuring range	Typically $v = 0.01$ to 10 m/s (0.03 to 33 ft/s) with the specified accuracy Electrical conductivity: 5 to $10\,000$ $\mu\text{S/cm/cm}$ Recommended measuring range "Flow limit" section (→  107)
Operable flow range	Over $1000 : 1$
Input signal	External measured values To increase the accuracy of certain measured variables or to calculate the corrected volume flow, the automation system can continuously write different measured values to the measuring device: <ul style="list-style-type: none"> ■ Operating pressure to increase accuracy (Endress+Hauser recommends the use of a pressure measuring device for absolute pressure, e.g. Cerabar M or Cerabar S) ■ Medium temperature to increase accuracy (e.g. iTEMP) ■ Reference density for calculating the corrected volume flow

 Various pressure transmitters and temperature measuring devices can be ordered from Endress+Hauser: see "Accessories" section (→  100)

It is recommended to read in external measured values to calculate the following measured variables:
Corrected volume flow

Fieldbus

The measured values are written from the automation system to the measuring device via PROFIBUS DP.

16.4 **Output**

Output signal	PROFIBUS DP	
	Signal encoding	NRZ code
	Data transfer	9.6 kBaud...12 MBaud

Signal on alarm	Depending on the interface, failure information is displayed as follows:	
	PROFIBUS DP	
	Status and alarm messages	Diagnostics in accordance with PROFIBUS PA Profile 3.02

Local display

Plain text display	With information on cause and remedial measures
Backlight	Red backlighting indicates a device error.

 Status signal as per NAMUR recommendation NE 107

Operating tool

- Via digital communication:
PROFIBUS DP
- Via service interface

Plain text display	With information on cause and remedial measures
--------------------	---

Low flow cut off	The switch points for low flow cut off are user-selectable.
------------------	---

Galvanic isolation	The following connections are galvanically isolated from each other: <ul style="list-style-type: none">■ Outputs■ Power supply
--------------------	---

Protocol-specific data

PROFIBUS DP

Manufacturer ID	0x11
Ident number	0x1561
Profile version	3.02
Device description files (GSD, DTM, DD)	Information and files under: <ul style="list-style-type: none"> ▪ www.endress.com ▪ www.profibus.org
Output values (from measuring device to automation system)	
Input values (from automation system to measuring device)	Analog output 1 (fixed assignment) External density Digital output 1 to 2 (fixed assignment) <ul style="list-style-type: none"> ▪ Digital output 1: switch positive zero return on/off ▪ Digital output 2: start verification Totalizer 1 to 3 <ul style="list-style-type: none"> ▪ Totalize ▪ Reset and hold ▪ Preset and hold ▪ Stop ▪ Operating mode configuration: <ul style="list-style-type: none"> – Net flow total – Forward flow total – Reverse flow total
Supported functions	<ul style="list-style-type: none"> ▪ Identification & Maintenance Simplest device identification on the part of the control system and nameplate ▪ PROFIBUS upload/download Reading and writing parameters is up to ten times faster with PROFIBUS upload/download ▪ Condensed status Simplest and self-explanatory diagnostic information by categorizing diagnostic messages that occur
Configuration of the device address	<ul style="list-style-type: none"> ▪ DIP switches on the I/O electronics module ▪ Via operating tools (e.g. FieldCare)

16.5 Power supply

Terminal assignment (→  28)

Pin assignment, device plug (→  29)

Supply voltage

Transmitter

For device version with all communication types: DC 20 to 30 V

The power unit must be tested to ensure it meets safety requirements (e.g. PELV, SELV).

Power consumption

Transmitter

Order code for "Output"	Maximum Power consumption
Option L: PROFIBUS DP	3.5 W

Current consumption


Transmitter

Order code for "Output"	Maximum Current consumption	Maximum switch-on current
Option L: PROFIBUS DP	145 mA	18 A (<0.125 ms)


Power supply failure

- Totalizers stop at the last value measured.
- Depending on the device version, the configuration is retained in the device memory or in the plug-in memory (HistoROM DAT).
- Error messages (incl. total operated hours) are stored.

Electrical connection

(→  29)

Potential equalization

(→  31)

Terminals


Transmitter

Spring terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)

Cable entries

- Cable gland: M20 × 1.5 with cable Ø6 to 12 mm (0.24 to 0.47 in)
- Thread for cable entry:
 - NPT ½"
 - G ½"
 - M20

Cable specification

(→  27)

16.6 Performance characteristics

Reference operating conditions

In accordance with DIN EN 29104

- Fluid temperature: +28±2 °C (+82±4 °F)
- Ambient temperature range: +22±2 °C (+72±4 °F)
- Warm-up period: 30 min

Installation

- Inlet run > 10 × DN
- Outlet run > 5 × DN
- Sensor and transmitter grounded.
- The sensor is centered in the pipe.

Maximum measured error

Error limits under reference operating conditions


o.r. = of reading

Volume flow

- ±0.5 % o.r. ± 1 mm/s (0.04 in/s)
- Optional: ±0.2 % o.r. ± 2 mm/s (0.08 in/s)



Fluctuations in the supply voltage do not have any effect within the specified range.



18 Maximum measured error in % o.r.

Temperature

$\pm 3\text{ }^{\circ}\text{C}$ ($\pm 5.4\text{ }^{\circ}\text{F}$)

Electrical conductivity

Max. measured error not specified.

Accuracy of outputs

o.r. = of reading; o.f.s. = of full scale value

i The output accuracy must be factored into the measured error if analog outputs are used, but can be ignored for fieldbus outputs (e.g. Modbus RS485, EtherNet/IP).

Current output

Accuracy	Max. $\pm 0.05\text{ }\%$ o.f.s. or $\pm 5\text{ }\mu\text{A}$
----------	--

Pulse/frequency output

Accuracy	Max. $\pm 50\text{ ppm}$ o.r.
----------	-------------------------------

Repeatability

o.r. = of reading

Volume flow

Max. $\pm 0.1\text{ }\%$ o.r. $\pm 0.5\text{ mm/s}$ (0.02 in/s)

Temperature

$\pm 0.5\text{ }^{\circ}\text{C}$ ($\pm 0.9\text{ }^{\circ}\text{F}$)

Electrical conductivity

Max. $\pm 5\text{ }\%$ o.r.




Temperature measurement
response time

$T_{90} < 15\text{ s}$

16.7 Installation


"Mounting requirements" (\rightarrow 17)

16.8 Environment

Ambient temperature range	(→  19)
Storage temperature	<p>The storage temperature corresponds to the operating temperature range of the measuring transmitter and the appropriate measuring sensors.</p> <ul style="list-style-type: none"> ■ Protect the measuring device against direct sunlight during storage in order to avoid unacceptably high surface temperatures. ■ Select a storage location where moisture cannot collect in the measuring device as fungus or bacteria infestation can damage the liner. ■ If protection caps or protective covers are mounted these should never be removed before installing the measuring device.
Degree of protection	<p>Transmitter and sensor</p> <ul style="list-style-type: none"> ■ As standard: IP66/67, type 4X enclosure ■ With the order code for "Sensor options", option CM: IP69K can also be ordered ■ When housing is open: IP20, type 1 enclosure ■ Display module: IP20, type 1 enclosure
Shock resistance	As per IEC/EN 60068-2-31
Vibration resistance	Acceleration up to 2 g following IEC 60068-2-6
Mechanical load	<ul style="list-style-type: none"> ■ Protect the transmitter housing against mechanical effects, such as shock or impact. ■ Never use the transmitter housing as a ladder or climbing aid.
Interior cleaning	<ul style="list-style-type: none"> ■ Cleaning in place (CIP) ■ Sterilization in place (SIP)
Electromagnetic compatibility (EMC)	<ul style="list-style-type: none"> ■ As per IEC/EN 61326 and NAMUR Recommendation 21 (NE 21) ■ Complies with emission limits for industry as per EN 55011 (Class A) ■ Device version with PROFIBUS DP: Complies with emission limits for industry as per EN 50170 Volume 2, IEC 61784 <p> The following applies for PROFIBUS DP: If baud rates > 1.5 MBaud an EMC cable entry must be used and the cable shield must continue as far as the terminal wherever possible.</p> <p> For details refer to the Declaration of Conformity.</p>

16.9 Process

Medium temperature range	-20 to +150 °C (-4 to +302 °F)
--------------------------	--------------------------------



A0019805

T_A Ambient temperature

T_F Medium temperature

1 Harsh environment and IP68 only to +130 °C (+266 °F)

Conductivity $\geq 5 \mu\text{S/cm}$ for liquids in general

Pressure-temperature ratings



An overview of the pressure-temperature ratings for the process connections is provided in the "Technical Information" document

Pressure tightness

Liner: PFA

Nominal diameter		Limit values for absolute pressure in [mbar] ([psi]) for fluid temperatures:				
[mm]	[in]	+25 °C (+77 °F)	+80 °C (+176 °F)	+100 °C (+212 °F)	+130 °C (+266 °F)	+150 °C (+302 °F)
2 to 150	$\frac{1}{16}$ to 6	0 (0)	0 (0)	0 (0)	0 (0)	0 (0)

Flow limit

The diameter of the pipe and the flow rate determine the nominal diameter of the sensor. The optimum velocity of flow is between 2 to 3 m/s (6.56 to 9.84 ft/s). Also match the velocity of flow (v) to the physical properties of the fluid:

- $v < 2 \text{ m/s}$ (6.56 ft/s): for low conductivity values
- $v > 2 \text{ m/s}$ (6.56 ft/s): for fluids producing buildup (e.g. milk with a high fat content)



A necessary increase in the flow velocity can be achieved by reducing the sensor nominal diameter.




For an overview of the measuring range full scale values, see the "Measuring range" section (\rightarrow 101)

Pressure loss


- No pressure loss occurs as of nominal diameter DN 8 (3/8") if the sensor is installed in a pipe with the same nominal diameter.
- Pressure losses for configurations incorporating adapters according to DIN EN 545 (\rightarrow 21)

System pressure

(\rightarrow 20)

Vibrations (→  20)

16.10 Mechanical construction

Design, dimensions  For the dimensions and installation lengths of the device, see the "Technical Information" document, "Mechanical construction" section

Weight **Compact version**

- Including the transmitter
- Weight specifications apply to standard pressure ratings and without packaging material.

Nominal diameter		Weight	
[mm]	[in]	[kg]	[lbs]
2	1/12	2.00	4.41
4	1/8	2.00	4.41
8	3/8	2.00	4.41
15	½	1.90	4.19
25	1	2.80	6.17
40	1 ½	4.10	9.04
50	2	4.60	10.1
65	–	5.40	11.9
80	3	6.00	13.2
100	4	7.30	16.1
125	5	12.7	28.0
150	6	15.1	33.3

Nominal diameter		Pressure rating ¹⁾	Process connection internal diameter	
[mm]	[in]	EN (DIN)	PFA	
		[bar]	[mm]	[in]
2	1/12	PN 16/40	2.25	0.09
4	1/8	PN 16/40	4.5	0.18
8	3/8	PN 16/40	9.0	0.35
15	½	PN 16/40	16.0	0.63
–	1	PN 16/40	22.6	0.89
25	–	PN 16/40	26.0	1.02
40	1 ½	PN 16/25/40	35.3	1.39
50	2	PN 16/25	48.1	1.89
65	–	PN 16/25	59.9	2.36
80	3	PN 16/25	72.6	2.86
100	4	PN 16/25	97.5	3.84
125	5	PN 10/16	120.0	4.72
150	6	PN 10/16	146.5	5.77


1) Depending on process connection and seals used

Materials

Transmitter housing

- Order code for "Housing", option **A** "Compact, aluminum coated":
Aluminum, AlSi10Mg, coated
- Order code for "Housing", option **B** "Compact, hygienic, stainless":
Hygienic version, stainless steel 1.4301 (304)
- Order code for "Housing", option **C** "Ultra compact, hygienic, stainless":
Hygienic version, stainless steel 1.4301 (304)

Cable entries/cable glands



19 Possible cable entries/cable glands

- 1 Cable entry in transmitter housing, wall-mount housing or connection housing with internal thread M20 x 1.5
- 2 Cable gland M20 x 1.5
- 3 Adapter for cable entry with internal thread G 1/2" or NPT 1/2"

Order code for "Housing", option A "Compact, coated aluminum"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Nickel-plated brass
Adapter for cable entry with internal thread G 1/2"	
Adapter for cable entry with internal thread NPT 1/2"	

Order code for "Housing", option B "Compact, hygienic, stainless"

The various cable entries are suitable for hazardous and non-hazardous areas.

Cable entry/cable gland	Material
Cable gland M20 × 1.5	Stainless steel, 1.4404 (316L)
Adapter for cable entry with internal thread G 1/2"	
Adapter for cable entry with internal thread NPT 1/2"	

Device plug

Electrical connection	Material
Plug M12x1	<ul style="list-style-type: none">■ Socket: Stainless steel, 1.4404 (316L)■ Contact housing: Polyamide■ Contacts: Gold-plated brass

Sensor housing

Stainless steel 1.4301 (304)

Measuring tubes



Stainless steel 1.4301 (304)

Liner

PFA (USP Class VI, FDA 21 CFR 177.1550, 3A)

Process connections

- Stainless steel 1.4404 (F316L)
- PVDF
- PVC adhesive sleeve

 List of all available process connections (→  110)

Electrodes

- Standard: 1.4435 (316L)
- Optional: Alloy C22, tantalum, platinum (only up to DN 25 (1"))

Seals

- O-ring seal, DN 2 to 25 (1/12 to 1"): EPDM, FKM, Kalrez
- Aseptic molded seal, DN 2 to 150 (1/12 to 6"): EPDM¹⁾, FKM, silicone¹⁾

Accessories

Grounding rings

- Standard: 1.4435 (F316L)
- Optional: Alloy C22, tantalum

Wall mounting kit

Stainless steel 1.4301 (304)

Spacer

1.4435 (F316L)

Fitted electrodes	<ul style="list-style-type: none">■ 2 measuring electrodes for signal detection■ 1 empty pipe detection electrode for empty pipe detection/temperature measurement (only DN 15 to 150 (½ to 6"))
Process connections	<p>With O-ring seal</p> <ul style="list-style-type: none">■ Welded connection (DIN EN ISO 1127, ODT/SMS, ISO 2037)■ Flange (EN (DIN), ASME, JIS)■ Flange from PVDF (EN (DIN), ASME, JIS)■ External thread■ Internal thread■ Hose connection■ PVC adhesive sleeve

1) USP Class VI, FDA 21 CFR 177.2600, 3A

With aseptic molded seal:

- Welded connection (DIN 11850, ASME BPE, ISO 2037)
- Clamp (ISO 2852, ISO 2853, DIN 32676, L14 AM7)
- Coupling (DIN 11851, DIN 11864-1, ISO 2853, SMS 1145)
- Flange DIN 11864-2



For information on the materials of the process connections (→ 110)

Surface roughness

Stainless steel electrodes, 1.4435 (F316L); Alloy C22, 2.4602 (UNS N06022); platinum; tantalum:

≤ 0.3 to 0.5 µm (11.8 to 19.7 µin)

(All data relate to parts in contact with fluid)

Liner with PFA:

≤ 0.4 µm (15.7 µin)

(All data relate to parts in contact with fluid)

Stainless steel process connections:

≤ 0.8 µm (31 µin)

Optional: ≤ 0.38 µm (15 µin)

(All data relate to parts in contact with fluid)

16.11 Operability

Local display

The local display is only available with the following device version:

Order code for "Display; Operation", option **B**: 4-line; via communication

Display element

- 4-line liquid crystal display with 16 characters per line.
- White background lighting; switches to red in event of device errors.
- Format for displaying measured variables and status variables can be individually configured.
- Permitted ambient temperature for the display: -20 to +60 °C (-4 to +140 °F). The readability of the display may be impaired at temperatures outside the temperature range.

Disconnecting the local display from the main electronics module



In the case of the "Compact, aluminum coated" housing version, the local display must only be disconnected manually from the main electronics module. In the case of the "Compact, hygienic, stainless" and "Ultra compact, hygienic, stainless" housing versions, the local display is integrated in the housing cover and is disconnected from the main electronics module when the housing cover is opened.

"Compact, aluminum coated" housing version

The local display is plugged onto the main electronics module. The electronic connection between the local display and main electronics module is established via a connecting cable.


For some work performed on the measuring device (e.g. electrical connection), it is advisable to disconnect the local display from the main electronics module:

1. Press in the side latches of the local display.
2. Remove the local display from the main electronics module. Pay attention to the length of the connecting cable when doing so.

Once the work is completed, plug the local display back on.

Remote operation

Via PROFIBUS DP network




A0020903

- 1 Automation system
- 2 Computer with PROFIBUS network card
- 3 PROFIBUS DP network
- 4 Measuring device

Service interface

Service interface (CDI-RJ45)

PROFIBUS DP



A0021270

20 Connection for order code for "Output", option L: PROFIBUS DP

- 1 Service interface (CDI -RJ45) of the measuring device with access to the integrated Web server
- 2 Computer with Web browser (e.g. Internet Explorer) for accessing the integrated device Web server or with "FieldCare" operating tool with COM DTM "CDI Communication TCP/IP"
- 3 Standard Ethernet connecting cable with RJ45 plug

Languages

Can be operated in the following languages:

Via "FieldCare" operating tool:

English, German, French, Spanish, Italian, Chinese, Japanese

16.12 Certificates and approvals

CE mark	<p>The measuring system is in conformity with the statutory requirements of the applicable EC Directives. These are listed in the corresponding EC Declaration of Conformity along with the standards applied.</p> <p>Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.</p>
C-Tick symbol	<p>The measuring system meets the EMC requirements of the "Australian Communications and Media Authority (ACMA)".</p>
Ex approval	<p>The devices are certified for use in hazardous areas and the relevant safety instructions are provided in the separate "Safety Instructions" (XA) document. Reference is made to this document on the nameplate.</p>
Sanitary compatibility	<ul style="list-style-type: none"> ■ 3A approval and EHEDG-certified ■ Seals → conform to FDA (apart from Kalrez seals)
Certification PROFIBUS	<p>PROFIBUS interface</p> <p>The measuring device is certified and registered by the PROFIBUS User Organization (PNO). The measuring system meets all the requirements of the following specifications:</p> <ul style="list-style-type: none"> ■ Certified in accordance with PROFIBUS PA Profile 3.02 ■ The device can also be operated with certified devices of other manufacturers (interoperability)
Pressure Equipment Directive	<ul style="list-style-type: none"> ■ With the PED/G1/x (x = category) marking on the sensor nameplate, Endress+Hauser confirms compliance with the "Essential Safety Requirements" specified in Annex I of the Pressure Equipment Directive 97/23/EC. ■ Devices not bearing this marking (PED) are designed and manufactured according to good engineering practice. They meet the requirements of Art.3 Section 3 of the Pressure Equipment Directive 97/23/EC. The range of application is indicated in tables 6 to 9 in Annex II of the Pressure Equipment Directive.
Other standards and guidelines	<ul style="list-style-type: none"> ■ EN 60529 Degrees of protection provided by enclosures (IP code) ■ EN 61010-1 Safety requirements for electrical equipment for measurement, control and laboratory use ■ IEC/EN 61326 Emission in accordance with Class A requirements. Electromagnetic compatibility (EMC requirements). ■ NAMUR NE 21 Electromagnetic compatibility (EMC) of industrial process and laboratory control equipment ■ NAMUR NE 32 Data retention in the event of a power failure in field and control instruments with microprocessors ■ NAMUR NE 43 Standardization of the signal level for the breakdown information of digital transmitters with analog output signal. ■ NAMUR NE 53 Software of field devices and signal-processing devices with digital electronics

- NAMUR NE 105
Specifications for integrating fieldbus devices in engineering tools for field devices
- NAMUR NE 107
Self-monitoring and diagnosis of field devices
- NAMUR NE 131
Requirements for field devices for standard applications

16.13 Application packages



Many different application packages are available to enhance the functionality of the device. Such packages might be needed to address safety aspects or specific application requirements.

The application packages can be ordered from Endress+Hauser either directly with the device or subsequently. Detailed information on the order code in question is available from your local Endress+Hauser sales center or on the product page of the Endress+Hauser website: www.endress.com.

Cleaning	Package	Description
	Electrode cleaning circuit (ECC)	The electrode cleaning circuit (ECC) function has been developed to have a solution for applications where magnetite (Fe_3O_4) deposits frequently occur (e.g. hot water). Since magnetite is highly conductive this build up leads to measuring errors and ultimately to the loss of signal. The application package is designed to AVOID build up of highly conductive matter and thin layers (typical of magnetite).

Heartbeat Technology	Package	Description
	Heartbeat Verification +Monitoring	<p>Heartbeat Monitoring: Continuously supplies monitoring data, which are characteristic of the measuring principle, for an external condition monitoring system. This makes it possible to:</p> <ul style="list-style-type: none"> ■ Draw conclusions - using these data and other information - about the impact the measuring application has on the measuring performance over time. ■ Schedule servicing in time. ■ Monitor the product quality, e.g. gas pockets. <p>Heartbeat Verification: Makes it possible to check the device functionality on demand when the device is installed, without having to interrupt the process.</p> <ul style="list-style-type: none"> ■ Access via onsite operation or other operating interfaces, such as FieldCare for instance. ■ Documentation of device functionality within the framework of manufacturer specifications, for proof testing for instance. ■ End-to-end, traceable documentation of the verification results, including report. ■ Makes it possible to extend calibration intervals in accordance with operator's risk assessment.

16.14 Accessories

 Overview of accessories available for order (→  99)

16.15 Supplementary documentation



For an overview of the scope of the associated Technical Documentation, refer to the following:

- The CD-ROM provided for the device (depending on the device version, the CD-ROM might not be part of the delivery!)
- The *W@M Device Viewer* : Enter the serial number from the nameplate (www.endress.com/deviceviewer)
- The *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the 2-D matrix code (QR code) on the nameplate.

Standard documentation

Brief Operating Instructions

Measuring device	Documentation code
Promag H 100	KA01142D

Technical Information

Measuring device	Documentation code
Promag H 100	TI01101D

Supplementary device-dependent documentation

Safety Instructions

Contents	Documentation code
ATEX/IECEx Ex nA	XA01090D

Special Documentation

Contents	Documentation code
Heartbeat Technology	SD01149D

Installation Instructions

Contents	Documentation code
Installation Instructions for spare part sets	Overview of accessories available for order (→ 99)

17 Appendix

17.1 Overview of the operating menu

The following tables provide an overview of the entire operating menu structure with menus and parameters. The page reference indicates where a description of the parameter can be found in the manual.

* = The submenu only appears if it has been additionally ordered ("Technical Information", Section "Application packages").






























17.1.1 Main menu






























Main menu	→	Display language	(→ 60)
		Operation	(→ 116)
		Setup	(→ 117)
		Diagnostics	(→ 119)
		Expert	(→ 122)























17.1.2 "Operation" menu

Operation	→		
Display language			(→ 60)
Web server language			
Access status display			
Access status tooling			
Locking status			(→ 62)
Display	→		(→ 50)
Format display			(→ 52)
Contrast display			
Backlight			(→ 60)
Display interval			(→ 60)
Totalizer handling	→		(→ 66)
Control Totalizer 1 to 3			(→ 57)
Preset value 1 to 3			(→ 66)
Reset all totalizers			(→ 66)

17.1.3 "Setup" menu



Setup	→	(→  48)
Device tag		(→  49)
System units	→	(→  49)
Volume flow unit		(→  50)
Volume unit		(→  50)
Conductivity unit		(→  50)
Temperature unit		(→  50)
Mass flow unit		(→  50)
Mass unit		(→  50)
Density unit		(→  50)
Corrected volume flow unit		(→  50)
Corrected volume unit		(→  50)
Communication	→	(→  52)
Device address		(→  52)
Display	→	(→  50)
Format display		(→  52)
Value 1 display		(→  52)
0% bargraph value 1		(→  52)
100% bargraph value 1		(→  52)
Value 2 display		(→  52)
Value 3 display		(→  52)
0% bargraph value 3		(→  52)
100% bargraph value 3		(→  52)
Value 4 display		(→  52)
Analog inputs (→  129)	→	
Analog input 1 to 4	→	(→  53)
Channel		(→  53)
PV filter time		(→  53)
Fail safe type		(→  53)

	Fail safe value	(→  53)
Low flow cut off	→	
Assign process variable		(→  54)
On value low flow cutoff		(→  54)
Off value low flow cutoff		(→  54)
Pressure shock suppression		(→  54)
Empty pipe detection	→	(→  55)
Empty pipe detection		(→  55)
New adjustment		(→  55)
Progress		(→  55)
Switch point empty pipe detection		(→  55)
Response time part. filled pipe detect.		(→  55)
Advanced setup	→	(→  56)
Enter access code		(→  62)
Sensor adjustment	→	(→  56)
Installation direction		(→  56)
Totalizer 1 to 3	→	(→  56)
Assign process variable		(→  57)
Unit totalizer		(→  57)
Control Totalizer 1 to 3		(→  57)
Totalizer operation mode		(→  57)
Failure mode		(→  57)
Display	→	(→  58)
Format display		(→  52)
Value 1 display		(→  52)
0% bargraph value 1		(→  52)
100% bargraph value 1		(→  52)
Decimal places 1		(→  59)
Value 2 display		(→  52)
Decimal places 2		(→  59)




Value 3 display		(→  52)
0% bargraph value 3		(→  52)
100% bargraph value 3		(→  52)
Decimal places 3		(→  59)
Value 4 display		(→  52)
Decimal places 4		(→  59)
Display language		(→  60)
Display interval		(→  60)
Display damping		(→  60)
Header		(→  60)
Header text		(→  60)
Separator		(→  60)
Backlight		(→  60)
Electrode cleaning circuit ¹⁾	→	(→  60)
Electrode cleaning circuit		(→  61)
ECC duration		(→  61)
ECC recovery time		(→  61)
ECC cleaning cycle		(→  61)
ECC Polarity		(→  61)
Administration	→	
		Define access code → (→  62)
		Define access code (→  62)
		Confirm access code (→  62)
Device reset		(→  93)

1) Order code for "Application package", option EC "ECC electrode cleaning"

17.1.4 "Diagnostics" menu

Diagnostics	→	(→  67)
Actual diagnostics		(→  91)
Previous diagnostics		(→  91)
Operating time from restart		(→  91)

Operating time		(→ ⓘ 0)
Diagnostic list	→	(→ ⓘ 91)
Diagnostics 1 to 5		(→ ⓘ 91)
Event logbook	→	(→ ⓘ 91)
Filter options		(→ ⓘ 92)
Device information	→	(→ ⓘ 93)
Device tag		(→ ⓘ 94)
Serial number		(→ ⓘ 94)
Firmware version		(→ ⓘ 94)
Device name		(→ ⓘ 94)
Order code		(→ ⓘ 94)
Extended order code 1 to 3		(→ ⓘ 94)
ENP version		(→ ⓘ 94)
IP address		(→ ⓘ 95)
Subnet mask		(→ ⓘ 95)
Default gateway		(→ ⓘ 95)
Measured values	→	
	Process variables	→ (→ ⓘ 64)
	Volume flow	(→ ⓘ 64)
	Mass flow	(→ ⓘ 64)
	Conductivity	(→ ⓘ 65)
	Corrected volume flow	(→ ⓘ 65)
	Temperature	(→ ⓘ 65)
	Corrected conductivity	(→ ⓘ 65)
	Totalizer 1 to 3	→ (→ ⓘ 65)
	Assign process variable	(→ ⓘ 57)
	Totalizer value 1 to 3	(→ ⓘ 65)
	Totalizer status 1 to 3	(→ ⓘ 65)
	Totalizer status (Hex) 1 to 3	(→ ⓘ 65)
Analog inputs	→	(→ ⓘ 53)
	Analog input 1 to 8	→ (→ ⓘ 53)

	Channel	(→  53)
	Out value	
	Out status	
	Out status	
Heartbeat ¹⁾	→	(→  115)
	Performing verification →	
	Year	
	Month	
	Day	
	Hour	
	AM/PM	
	Minute	
	External device information	
	Start verification	
	Progress	
	Status	
	Overall result	
	Verification results →	
	Date/time	
	Verification ID	
	Operating time	
	Overall result	
	Sensor	
	Sensor electronic module	
	I/O module	
	Monitoring results →	
	Noise	
	Coil current shot time	
	Reference electrode potential against PE	
Simulation	→	(→  61)

	Assign simulation process variable	(→ 61)
	Value process variable	(→ 61)
	Simulation device alarm	(→ 62)
	Simulation diagnostic event	(→ 62)

1) Order code for "Application package", option EB "Heartbeat Verification + Monitoring", see the Special Documentation for the device

17.1.5 "Expert" menu



















The following tables provide an overview of the **Expert** menu (→ 122) with its submenus and parameters. The direct access code to the parameter is given in brackets. The page reference indicates where a description of the parameter can be found in the manual.

Overview "Expert" menu

Expert	→	(→ 39)
Direct access (0106)		
Locking status (0004)		(→ 64)
Access status display (0091)		
Access status tooling (0005)		(→ 62)
Enter access code (0092)		
	System	(→ 122)
	Sensor	(→ 124)
	Communication	(→ 127)
	Analog inputs	(→ 129)
	Discrete inputs	(→ 131)
	Analog outputs	(→ 131)
	Discrete outputs	(→ 133)
	Application	(→ 134)
	Diagnostics	(→ 135)

"System" submenu


















System	→	
	Display	→ (→ 58)
	Display language (0104)	(→ 60)












Format display (0098)		(→  52)
Value 1 display (0107)		(→  52)
0% bargraph value 1 (0123)		(→  52)
100% bargraph value 1 (0125)		(→  52)
Decimal places 1 (0095)		(→  59)
Value 2 display (0108)		(→  52)
Decimal places 2 (0117)		(→  59)
Value 3 display (0110)		(→  52)
0% bargraph value 3 (0124)		(→  52)
100% bargraph value 3 (0126)		(→  52)
Value 4 display (0109)		(→  52)
Decimal places 4 (0119)		(→  59)
Display interval (0096)		(→  60)
Display damping (0094)		(→  60)
Header (0097)		(→  60)
Header text (0112)		(→  60)
Separator (0101)		(→  60)
Contrast display (0105)		
Backlight (0111)		(→  60)
Access status display (0091)		
Diagnostic handling	→	(→  67)
Alarm delay (0651)		
	Diagnostic behavior	→
	Assign behavior of diagnostic no. 531 (0741)	
	Assign behavior of diagnostic no. 832 (0681)	
	Assign behavior of diagnostic no. 833 (0682)	

	Assign behavior of diagnostic no. 834 (0700)	
	Assign behavior of diagnostic no. 835 (0702)	
	Assign behavior of diagnostic no. 862 (0745)	
	Assign behavior of diagnostic no. 937 (0743)	
	Assign behavior of diagnostic no. 302 (0739)	
Administration	→	
	Define access code (0093)	(→ ⓘ 62)
Device reset (0000)		(→ ⓘ 93)
Activate SW option (0029)		
Software option overview (0015)		

"Sensor" submenu

Sensor	→	
	Measured values	→ ⓘ 64
	Process variables	→ ⓘ 64
	Volume flow (1847)	→ ⓘ 64
	Mass flow (1838)	→ ⓘ 64
	Conductivity (1850)	→ ⓘ 65
	Corrected volume flow (1851)	→ ⓘ 65
	Temperature (1853)	→ ⓘ 65
	Corrected conductivity (1853)	→ ⓘ 65
	Totalizer 1 to 3	→ ⓘ 65
	Totalizer value 1 to 3 (3827-1 to 3)	→ ⓘ 65
	Totalizer status (Hex) 1 to 3 (3825-1 to 3)	→ ⓘ 65

	Totalizer status 1 to 3 (3826-1 to 3)	(→  65)
System units	→	(→  49)
Volume flow unit (0553)		(→  50)
Volume unit (0563)		(→  50)
Conductivity unit (0582)		(→  50)
Temperature unit (0557)		(→  50)
Mass flow unit (0554)		(→  50)
Mass unit (0574)		(→  50)
Density unit (0555)		(→  50)
Corrected volume flow unit (0558)		(→  50)
Corrected volume unit (0575)		(→  50)
Date/time format (2812)		
Process parameters	→	(→  48)
Filter options (6710)		
Flow damping (6661)		
Flow override (1839)		
Conductivity damping (1803)		
Temperature damping (1886)		
Conductivity measurement (6514)		
Low flow cut off	→	
Assign process variable (1837)		(→  54)
On value low flow cutoff (1805)		(→  54)
Off value low flow cutoff (1804)		(→  54)
Pressure shock suppression (1806)		(→  54)
Empty pipe detection	→	
Empty pipe detection (1860)		(→  55)

	Switch point empty pipe detection (6562)		(→  55)
	Response time part. filled pipe detect. (1859)		(→  55)
	New adjustment (6560)		(→  55)
	Progress (6571)		(→  55)
	Empty pipe adjust value (6527)		
	Full pipe adjust value (6548)		
	Measured value EPD (6559)		
	Electrode cleaning circuit¹⁾	→	(→  60)
	Electrode cleaning circuit (6528)		(→  61)
	ECC duration (6555)		(→  61)
	ECC recovery time (6556)		(→  61)
	ECC cleaning cycle (6557)		(→  61)
	ECC Polarity (6631)		(→  61)
	External compensation	→	
	Temperature source (6712)		
	External temperature (6673)		
	Density source (6615)		
	External density (6630)		
	Fixed density (6623)		
	Reference density (1885)		
	Sensor adjustment	→	
	Installation direction (1809)		(→  56)
	Integration time (6533)		
	Measuring period (6536)		
	Process variable adjustment	→	

	Volume flow offset (1841)	
	Volume flow factor (1846)	
	Mass flow offset (1831)	
	Mass flow factor (1832)	
	Conductivity offset (1848)	
	Conductivity factor (1849)	
	Corrected volume flow offset (1866)	
	Corrected volume flow factor (1867)	
	Temperature offset (1870)	
	Temperature factor (1871)	
Calibration	→	
Nominal diameter (2807)		
Calibration factor (6025)		
Zero point (6195)		
Conductivity calibration factor (6718)		

1) Order code for "Application package", option EC "ECC electrode cleaning"

"Communication" submenu

Communication	→	
PROFIBUS DP configuration	→	(→ ⓘ 52)
Address mode (1468)		
Device address (1462)		(→ ⓘ 52)
Ident number selector (1461)		
PROFIBUS DP info	→	
Status PROFIBUS Master Config (1465)		

PROFIBUS ident number (1464)	
Profile version (1463)	
Base current (1466)	
Baudrate (1504)	
Is Master Online (1517)	
Physical block	→
Device tag (1496)	(→ ⓘ 49)
Static revision (1495)	
Strategy (1494)	
Alert key (1473)	
Target mode (1497)	
Mode block actual (1472)	
Mode block permitted (1493)	
Mode block normal (1492)	
Alarm summary (1474)	
Software revision (1478)	
Hardware revision (1479)	
Manufacturer ID (1502)	
Device ID (1480)	
Serial number (1481)	
Diagnostics (1482)	
Diagnostics mask (1484)	
Device certification (1486)	
Factory reset (1488)	
Descriptor (1489)	
Device message (1490)	
Device install date (1491)	
Ident number selector (1461)	

Hardware lock (1499)	
Feature supported (1477)	
Feature enabled (1476)	
Condensed status diagnostic (1500)	
Web server	→
Web server language (7221)	
MAC address (7214)	
IP address (7209)	(→ ⓘ 95)
Subnet mask (7211)	(→ ⓘ 95)
Default gateway (7210)	(→ ⓘ 95)
Web server functionality (7222)	(→ ⓘ 42)

"Analog inputs" submenu

Analog inputs	→	
Analog input 1 to 4	→	(→ ⓘ 53)
Tag description		
Static revision		
Strategy		
Alert key		
Target mode		
Mode block actual		
Mode block permitted		
Mode block normal		
Alarm summary		
Batch ID		
Batch operation		
Batch phase		
Batch Recipe Unit Procedure		
Out value		

Out status	
Out status	
PV scale lower range	
PV scale upper range	
Out scale lower range	
Out scale upper range	
Lin type	
Channel	(→ ⓘ 53)
Out unit	
Out decimal point	
PV filter time	(→ ⓘ 53)
Fail safe type	(→ ⓘ 53)
Fail safe value	(→ ⓘ 53)
Alarm hysteresis	
Hi Hi Lim	
Hi Lim	
Lo Lim	
Lo Lo Lim	
Hi Hi alarm value	
Hi Hi alarm state	
Hi alarm value	
Hi alarm state	
Lo alarm value	
Lo alarm state	
Lo Lo alarm value	
Lo Lo alarm state	
Simulate enabled	
Simulate value	
Simulate status	
Out unit text	

"Discrete inputs" submenu

Discrete inputs →

Discrete input 1 to 2 →

(→ ⓘ 53)

Tag description

Static revision

Strategy

Alert key

Target mode

Mode block actual

Mode block permitted

Mode block normal

Alarm summary

Batch ID

Batch operation

Batch phase

Batch Recipe Unit Procedure

Out value

Out status

Out status

Channel

Invert

Fail safe type

Fail safe value

Simulate enabled

Simulate value

Simulate status

"Analog inputs" submenu

Analog outputs →

Analog output 1 to 2 →

(→ ⓘ 53)

Tag description

Static revision
Strategy
Alert key
Target mode
Mode block actual
Mode block permitted
Mode block normal
Alarm summary
Batch ID
Batch operation
Batch phase
Batch Recipe Unit Procedure
Set point value
Set point status
PV scale lower range
PV scale upper range
Readback value
Readback status
RCAS in value
RCAS in status
Input channel
Output channel
Fail safe time
Fail safe type
Fail safe value
RCAS out value
RCAS out status
Position value
Position status
Setpoint deviation
Simulate enabled

Simulate value
Simulate status
Increase close
Out value
Out status
Out status
Out scale upper range
Out scale lower range

"Discrete outputs" submenu

Discrete outputs (→ 133)	→		
		Discrete output 1 to 3 →	(→ 53)
		Tag description	
		Static revision	
		Strategy	
		Alert key	
		Target mode	
		Mode block actual	
		Mode block permitted	
		Mode block normal	
		Alarm summary	
		Batch ID	
		Batch operation	
		Batch phase	
		Batch Recipe Unit Procedure	
		Set point value	
		Set point status	
		Out value	
		Out status	
		Out status	
		Readback value	

Readback status
RCAS in value
RCAS in status
Input channel
Output channel
Invert
Fail safe time
Fail safe type
Fail safe value
RCAS out value
RCAS out status
Simulate enabled
Simulate value
Simulate status

"Application" submenu

Application	→	
Totalizer 1 to 3	→	(→ ⓘ 56)
Tag description (3833)		
Static revision (3832)		
Strategy (3831)		
Alert key (3803)		
Target mode (3834)		
Mode block actual (3801)		
Mode block permitted (3828)		
Mode block normal (3824)		
Alarm summary (3809)		
Batch ID (3804)		
Batch operation (3805)		
Batch phase (3806)		



Batch Recipe Unit Procedure (3807)	
Totalizer value 1 to 3 (3827-1 to 3)	
Totalizer status 1 to 3 (3826-1 to 3)	(→  65)
Totalizer status (Hex) 1 to 3 (3825-1 to 3)	(→  65)
Unit totalizer (3835)	(→  57)
Assign process variable (3808)	(→  57)
Control Totalizer 1 to 3 (3830-1 to 3)	(→  57)
Totalizer operation mode (3823)	(→  57)
Failure mode (3810)	(→  57)
Preset value 1 to 3 (3829-1 to 3)	
Alarm hysteresis (3802)	
Hi Hi Lim (3815)	
Hi Lim (3816)	
Lo Lim (3819)	
Lo Lo Lim (3822)	
Hi Hi alarm value (3814)	
Hi Hi alarm state (3813)	
Hi alarm value (3812)	
Hi alarm state (3811)	
Lo alarm value (3818)	
Lo alarm state (3817)	
Lo Lo alarm value (3821)	
Lo Lo alarm state (3820)	

"Diagnostics" submenu

Diagnostics	→	(→  67)
Actual diagnostics (0691)		(→  91)

Timestamp (0667)		
Previous diagnostics (0690)		(→ ⓘ 91)
Timestamp (0672)		
Operating time from restart (0653)		(→ ⓘ 91)
Operating time (0652)		(→ ⓘ 91)
	Diagnostic list →	(→ ⓘ 91)
	Diagnostics 1 to 5 (0692-1 to 5)	(→ ⓘ 91)
	Timestamp 1 to 5 (0683-1 to 5)	
	Event logbook →	(→ ⓘ 91)
	Filter options (0705)	(→ ⓘ 92)
	Device information →	(→ ⓘ 93)
	Device tag (0011)	(→ ⓘ 94)
	Serial number (0009)	(→ ⓘ 94)
	Firmware version (0010)	(→ ⓘ 94)
	Device name (0013)	(→ ⓘ 94)
	Order code (0008)	(→ ⓘ 94)
	Extended order code 1 to 3 (0023-1 to 3)	(→ ⓘ 94)
	ENP version (0012)	(→ ⓘ 94)
	Min/max values →	
	Reset min/max values (6151)	
	Main electronic temperature →	
	Minimum value (6547)	
	Maximum value (6545)	
	Temperature →	
	Minimum value (6030)	
	Maximum value (6029)	
	Heartbeat ¹⁾ →	(→ ⓘ 115)
	Heartbeat base settings →	
	Plant operator (2754)	

	Location (2751)	
	Performing verification →	
	Year (2846)	
	Month (2845)	
	Day (2842)	
	Hour (2843)	
	AM/PM (2813)	
	Minute (2844)	
	External device information (12101)	
	Start verification (12127)	
	Progress (2808)	
	Status (12153)	
	Overall result (12149)	
	Verification results →	
	Date/time (12142)	
	Verification ID (12141)	
	Operating time (12126)	
	Overall result (12149)	
	Sensor (12152)	
	Sensor electronic module (12151)	
	I/O module (12145)	
	Monitoring results →	
	Noise (12158)	
	Coil current shot time (12150)	
	Reference electrode potential against PE (12155)	
Simulation →		(→ ⓘ 61)
	Assign simulation process variable (1810)	(→ ⓘ 61)
	Value process variable (1811)	(→ ⓘ 61)

	Simulation device alarm (0654)	(→  62)
	Simulation diagnostic event (0737)	(→  62)

1) Order code for "Application package", option EB "Heartbeat Verification + Monitoring", see the Special Documentation for the device

Index

A

Adapters	21
Adapting the diagnostic behavior	70
Ambient temperature range	19
Application	8, 101
Applicator	101
Approvals	113

C

C-Tick symbol	113
Cable entries	
Technical data	104
Cable entry	
Degree of protection	35
CE mark	9, 113
Certificates	113
Certification PROFIBUS	113
Checklist	
Post-connection check	35
Post-installation check	25
Cleaning	
Exterior cleaning	96
Interior cleaning	96
Cleaning in place (CIP)	106
Commissioning	48
Advanced settings	56
Configuring the measuring device	48
Compatibility with earlier model	46
Conductivity	107
Connecting cable	27
Connecting the measuring device	29
Connection	
see Electrical connection	
Connection examples, potential equalization	31
Connection preparations	29
Connection tools	27
Current consumption	104

D

Declaration of Conformity	9
Define access code	62
Degree of protection	35, 106
Design	
Measuring device	11
Designated use	8
Device components	11
Device description files	46
Device documentation	
Supplementary documentation	7
Device locking, status	64
Device master file	
GSD	46
Device name	
Sensor	14
Transmitter	13
Device repair	97

Device revision	46
Device type ID	46
Diagnostic information	
Design, description	69
FieldCare	68
Light emitting diodes	68
Overview	72
Remedial measures	72
Diagnostic list	91
DIP switch	
see Write protection switch	
Disabling write protection	62
Display	
Current diagnostic event	90
Previous diagnostic event	90
Display values	
For locking status	64
Disposal	97
Document	
Function	5
Symbols used	5
Document function	5
Down pipe	17

E

ECC	60
Electrical connection	
Degree of protection	35
Measuring device	27
Operating tools	
Via PROFIBUS DP network	43, 112
Via service interface (CDI-RJ45)	44
Web server	44
Electromagnetic compatibility	106
Enabling write protection	62
Endress+Hauser services	
Maintenance	96
Repair	97
Environment	
Ambient temperature range	19
Mechanical load	106
Shock resistance	106
Storage temperature	106
Vibration resistance	106
Error messages	
see Diagnostic messages	
Event history	91
Events list	91
Ex approval	113
Extended order code	
Sensor	14
Transmitter	13
Exterior cleaning	96

F

Field of application	
----------------------	--

Residual risks	9
FieldCare	44
Device description file	46
Establishing a connection	44
Function	44
User interface	45
Filtering the event logbook	92
Firmware	
Release date	46
Version	46
Firmware history	95
Fitted electrodes	110
Flow direction	18
Flow limit	107
Function check	48
Functions	
see Parameter	
G	
Galvanic isolation	102
H	
Hardware write protection	62
I	
I/O electronics module	11, 29
Identifying the measuring device	12
Incoming acceptance	12
Information on the document	5
Inlet runs	19
Input	101
Inspection	
Installation	25
Received goods	12
Inspection check	
Connection	35
Installation conditions	
Adapters	21
Down pipe	17
Inlet and outlet runs	19
Mounting location	17
Orientation	18
Partially filled pipe	18
System pressure	20
Vibrations	20
Installation dimensions	19
Interior cleaning	96, 106
L	
Languages, operation options	112
Low flow cut off	102
M	
Main electronics module	11
Maintenance tasks	96
Replacing seals	96
Manufacturer ID	46
Manufacturing date	13, 14
Materials	109
Maximum measured error	104

Measured variables	
Calculated	101
Measured	101
see Process variables	
Measuring and test equipment	96
Measuring device	
Configuration	48
Conversion	97
Design	11
Disposal	98
Integrating via HART protocol	46
Mounting the sensor	22
Cleaning with pigs	23
Mounting grounding rings	23
Mounting the seals	23
Welding connections	22
Preparing for electrical connection	29
Preparing for mounting	21
Removing	97
Repair	97
Measuring principle	101
Measuring range	101
Measuring system	101
Measuring tube specification	108
Mechanical load	106
Media	8
Medium temperature range	106
menu	
Diagnostics	90
Operation	64
Setup	49
Menus	
For measuring device configuration	48
For specific settings	56
Mounting	17
Mounting dimensions	
see Installation dimensions	
Mounting location	17
Mounting preparations	21
Mounting requirements	
Installation dimensions	19
Mounting tools	21
N	
Nameplate	
Sensor	14
Transmitter	13
O	
Operable flow range	101
Operating menu	
Menus, submenus	38
Overview of menus with parameters	116
Structure	38
Submenus and user roles	39
Operating philosophy	39
Operation	64
Operation options	37
Operational safety	9

Order code	13, 14
Orientation (vertical, horizontal)	18
Outlet runs	19
Output	102
Output signal	102
Overview	
Operating menu	116

P

Packaging disposal	17
Parameter settings	
Analog input 1 to 4 (submenu)	53
Communication (submenu)	52
Device information (submenu)	93
Diagnostics (menu)	90
Display (submenu)	58
Display (wizard)	50
Electrode cleaning circuit (submenu)	60
Empty pipe detection (wizard)	55
Low flow cut off (wizard)	53
Operation (submenu)	66
Process variables (submenu)	64
Sensor adjustment (submenu)	56
Setup (menu)	49
Simulation (submenu)	61
System units (submenu)	49
Totalizer (submenu)	65
Totalizer 1 to 3 (submenu)	56
Web server (submenu)	42
Partially filled pipe	18
Performance characteristics	104
Post-connection check (checklist)	35
Post-installation check	48
Post-installation check (checklist)	25
Potential equalization	31, 104
Power consumption	103
Power supply failure	104
Pressure Equipment Directive	113
Pressure loss	107
Pressure tightness	107
Pressure-temperature ratings	107
Process conditions	
Conductivity	107
Flow limit	107
Medium temperature	106
Pressure loss	107
Pressure tightness	107
Process connections	110
Product safety	9
Protecting parameter settings	62

R

Reading measured values	64
Recalibration	96
Reference operating conditions	104
Registered trademarks	7
Remote operation	112
Repair	97
Notes	97

Repair of a device	97
Repeatability	105
Replacement	
Device components	97
Replacing seals	96
Requirements for personnel	8
Returning devices	97

S

Safety	8
Sanitary compatibility	113
Sensor	
Mounting	22
Serial number	13, 14
Service interface (CDI-RJ45)	112
Settings	
Adapting the measuring device to the process	
conditions	65
Advanced display configurations	58
Analog input	53
Communication interface	52
Device reset	93
Device tag	49
Electrode cleaning circuit (ECC)	60
Empty pipe detection (EPD)	55
Local display	50
Low flow cut off	53
Resetting the totalizer	66
Sensor adjustment	56
Simulation	61
System units	49
Totalizer	56
Totalizer reset	66
Shock resistance	106
Signal on alarm	102
Software release	46
Spare part	97
Spare parts	97
Special connection instructions	33
Standards and guidelines	113
Status signals	69
Sterilization in place (SIP)	106
Storage conditions	16
Storage temperature	16
Storage temperature range	106
Structure	
Operating menu	38
submenu	
Analog input 1 to 4	53
Communication	48, 52
Device information	93
Display	58
Electrode cleaning circuit	60
Operation	66
Process variables	64
Sensor adjustment	56
Simulation	61
System units	49
Totalizer	65

Totalizer 1 to 3	56	Via write protection switch	62
Web server	42	Write protection switch	62
Submenu			
Define access code	62		
Events list	91		
Overview	39		
Process variables	64		
Supplementary documentation	115		
Supply voltage	103		
Surface roughness	111		
System design			
Measuring system	101		
see Measuring device design			
System integration	46		
System pressure	20		
T			
Technical data, overview	101		
Temperature measurement response time	105		
Temperature range			
Storage temperature	16		
Terminal assignment	28, 29		
Terminals	104		
Tools			
Electrical connection	27		
For mounting	21		
Transport	16		
Transmitter			
Connecting the signal cables	29		
Turning the display module	24		
Transporting the measuring device	16		
Troubleshooting			
General	67		
Turning the display module	24		
U			
Use of the measuring device			
Borderline cases	8		
Incorrect use	8		
see Designated use			
User roles	39		
V			
Version data for the device	46		
Vibration resistance	106		
Vibrations	20		
W			
W@M	96, 97		
W@M Device Viewer	12, 97		
Weight			
Transport (notes)	16		
wizard			
Define access code	62		
Display	50		
Empty pipe detection	55		
Low flow cut off	53		
Workplace safety	9		
Write protection			
Via access code	62		

www.addresses.endress.com
