



BA 044D/06/en/12.99
No. 50096060
CV 5.0

Valid as of software version
V01.01.XX (amplifier)
V01.01.XX (communications)

prosonic flow **DMU 93 / DDU 15** **Ultrasonic Flow** **Measuring System**


Operating Manual




Endress + Hauser
The Power of Know How




Preparation for Quick Setup




System variations



INSERTION single path version
INSERTION K1




INSERTION dual path version
IN 1&2 1M.-POINT



INSERTION single path version at two meas. points
IN 1&2 2M.-POINTS

Quick Setup



ba044e01

Contents

1	Safety Instructions	7	7	Functions	45
1.1	Correct usage	7			
1.2	Dangers and notes	7			
1.3	Personnel for installation, start-up and operation	7			
1.4	Repairs, dangerous substances	8			
1.5	Technical improvement	8			
2	Instrument Identification	9			
3	Mounting and Installation	11			
3.1	Explanation of terms	11			
3.2	Applications for ultrasonic sensors	12			
3.3	Mounting	12			
3.4	Insulation	13			
3.5	Mounting location	13			
3.6	Inlet and outlet run	13			
3.7	Mounting the sensors and holders (single path version)	14			
3.8	Mounting the sensors and holders (dual path version)	17			
3.9	Mounting the transmitter	21			
3.10	Rotating the transmitter housing	21			
3.11	Rotating the local display	22			
4	Electrical Connection	23			
4.1	Transmitter protection IP 67	23			
4.2	Sensors protection IP 68	23			
4.3	Connecting the transmitter	24			
4.4	Wiring up the connecting cable to the sensors / transmitters	26			
5	Commissioning	27			
5.1	Switch on	27			
5.2	Programming	27			
5.3	Zero Point Adjustment	28			
5.4	Configuring the relay contacts	29			
6	Operation	31			
6.1	Display and keys	31			
6.2	E+H operating matrix (setting functions)	32			
6.3	Example of programming	35			
6.4	Operation with the "HART handheld terminal DXR 275"	36			
6.5	Commuwin II via HART protocol	38			
6.6	Operation with Commuwin II	39			
8	Trouble-shooting, Repair and Maintenance	79			
8.1	Response of the measuring system on fault or alarm	79			
8.2	Diagnosis flow chart and trouble-shooting	80			
8.3	Error and alarm messages	81			
8.4	Repair	85			
8.5	Exchange of the instrument fuses	85			
8.6	Exchange of transmitter electronics	86			
8.7	Exchanging the sensor element	88			
8.8	Maintenance	88			
9	Dimensions	89			
10	Technical Data	91			
11	Functions at a Glance	95			
12	Index	99			




Registered Trademarks

HART[®]
Registered trademark of HART Communication Foundation, Austin, USA

HASTELLOY[®]
Registered trademark of Haynes International, Inc., Kokomo, USA

1 Safety Instructions

1.1 Correct usage

- The manufacturer assumes no liability for damage caused by incorrect use of the instrument.
- Instruments which are used in the explosion hazardous area are supplied with a separate Ex documentation, which is an integral part of this Operating Manual. The instructions and connected loads provided in this supplement must absolutely be observed. An appropriate icon is shown on the front of this document according to the approval given and the test center ( Europe,  USA,  Canada).

1.2 Dangers and notes

All instruments are designed to meet state-of-the-art safety requirements. They have been tested, and have left the works in an operationally perfectly safe condition. The devices were developed according to EN 61010 Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures. A hazardous situation may occur if the flowmeter is not used for the purpose it was designed for or is used incorrectly. Please carefully note the information provided in this Operating Manual indicated by the following pictograms:

Warning!

“Warning” indicates actions or procedures which, if not performed correctly, may lead to personal injury or a safety hazard. Please strictly observe the instructions supplied and proceed carefully.



Caution!

“Caution” indicates actions or procedures which, if not performed correctly, may lead to faulty operations or the destruction of the instrument. Please strictly observe the respective instructions.



Note!

“Note” indicates actions or procedures which, if not performed correctly, may indirectly affect operations or lead to an unexpected instrument response.



1.3 Personnel for installation, start-up and operation

- Mounting, electrical installation, start-up and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must absolutely and without fail read and understand this Operating Manual before carrying out its instructions.
- The instrument may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this Manual are to be observed without fail.
- The installer has to make sure that the measuring system is correctly wired according to the wiring diagrams. The measuring system is to be grounded.
- Please observe all provisions valid for your country and pertaining to the opening and repairing of electrical devices.

Danger from electric shock!

With the housing cover removed, protection against accidental contact is no longer present.



1.4 Repairs, dangerous substances

If you send the measuring system for repairs to Endress+Hauser, enclose a note with the following data:

- description of the fault
- description of the application
- description of the use of measuring system within the installation

Remove all material which may adhere to the flow measuring system before returning the instrument to Endress+Hauser for repair. This is especially important if the fluid is dangerous to health, e.g. corrosive, poisonous, carcinogenic, radioactive, etc.

No instrument should be returned to us without first taking all possible safety precautions to ensure that all dangerous materials are removed, e.g. in scratches or diffused through plastic. Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc.).

Any costs arising from this will be charged to the operator of the instrument.

1.5 Technical improvement

The manufacturer reserves the right to modify technical data without prior notice. Your local Endress+Hauser Sales Office will supply you with all current information and any updates to this Operating Manual.

2 Instrument Identification

The nameplate on the Prosonic Flow DMU 93 transmitter and the Prosonic Flow DDU 15 ultrasonic sensors has the following information:




Fig. 1
Nameplate:
DMU 93 transmitter




Fig. 2
Nameplate:
DDU 15 sensor

3 Mounting and Installation

Warning!

- All instructions given in this section are to be observed at all times in order to ensure safe and reliable operation of the measuring system.
- Mounting regulations and technical specifications for Ex-certified instruments may differ from those given below. All mounting regulations and connection values in the Ex documentation must, therefore, be strictly observed.



3.1 Explanation of terms

The following diagrams explain in picture form the terms found in the sections that follow.

- Sensor distance
- Arc length
- Path length




Fig. 3
Explanation of terms

3.2 Applications for ultrasonic sensors


Pipe material

Welding steel, e.g. steel Type AISI 304, carbon steel

Properties of the liquid

- Max. 1% air/gas
- Max. 5% solids content

3.3 Mounting



Vertical

The recommended flow direction in a vertical pipe is upwards. Entrained solids sink downward and gases rise away from the measuring section. This also allows the pipe to be completely drained and protects it from solids build-up.

Horizontal

Sensors are to be mounted on a horizontal pipe in the areas shown in the adjacent figure.

This ensures that gases in the upper or solids in the lower part of the pipe have minimum affect on the measurement.

Fig. 4
Mounting

ba044e05

3.4 Insulation

The piping mounted with ultrasonic sensors may at any time be fully insulated whether heated or carrying cryogenics.

Caution!

The temperature of insulated sensors and sensor cable may not rise above or fall below the temperature range stated on the nameplate.



3.5 Mounting location

Air or entrained gases in the measuring pipe may cause errors. Therefore the following mounting locations are to be avoided:

- Do not install at the highest point of the piping.
- Do not install in a vertical pipeline directly upstream of a free pipe outlet.

Correct installation is still possible in a vertical pipeline using the recommendation in the adjacent figure. Restrictions in the piping or an orifice with a smaller cross section than the measuring instrument can prevent the sensor from running empty during measurement.




Fig. 5
Mounting location
(vertical piping)

3.6 Inlet and outlet run

To ensure a fully developed flow profile, the ultrasonic measuring system should be installed upstream from flow obstacles such as bends, reducers or actuators. It should also be ensured that the longest possible straight pipe should be between the obstacle and the measuring instrument. The adjacent figure shows the minimum length of straight pipe downstream from an obstruction as a multiple of the nominal diameter DN of the pipe. The accuracy of measurement can be affected if these values are lower than those given. If there are several obstacles to the flow, then the longest inlet or outlet path must always be used.





Fig. 6
Example of inlet and outlet runs

3.7 Mounting the sensors and holders (single path version)



Note!



Step 1

Determine the mounting space on the pipe section (see Sect. 3.5 and 3.6 mounting location and inlet and outlet run). Space requirements of the measurement point approx. 1 x pipe diameter.

Step 2

Draw a centre line on the pipe at the mounting section and mark the 1st hole.

Note!

Make the lines larger than the hole to be drilled!

Intermedia Step

If the thickness of the pipe is not known, then drill the first hole, e.g. with a plasma cutter, and measure the wall thickness. (Hole Ø65 mm).

If the wall thickness is known, then proceed with Step 3.

Step 3

Carry out the Quick Setup program of the transmitter. The sensor should be installed and the power supply switched on. The Quick Setup program provides the sensor distance. This is the interval between the two holes.

Step 4

Mark on the centre line the sensor distance from the 1st hole.

Fig. 7
Mounting the sensors and holders for the single path version

ba044e08

Mounting the single path version, continued

Step 5

Project the centre line onto the far side of the pipe and mark it.

Step 6

Draw the 2nd hole on the centre line on the far side.

Step 7

Cut the second hole, e.g. with a plasma cutter, and prepare it for welding on the sensor holders (deburr, clean, etc.).

Step 8


Insert the sensor holders into both holes, positioning them with the alignment rod (positioning tool). Tag weld with the welding unit and then weld the two sensor holders permanently.

Note!

To position the alignment rod, the two guides of the sensor holders must be screwed in.

See next page to adjust the depth of weld.

(continued on next page)



Note!

Fig. 8
Mounting the sensors and holders for the single path version
(continued)


Mounting the single path version, continued

Fig. 9
Mounting the sensors and hold-
ers for the single path version
(continued)

Step 8

To adjust the depth of weld, both sensor holders can be attached using the special tools to adjust the insertion depth (optional) and then positioned with the alignment rod.

The sensor holders should be flush with the inner pipe surface.

Tag weld both sensor holders.

Step 9

Weld both sensor holders.

Recheck the sensor distance and the path length after welding.

Note!

The nominal distances are provided by the Quick Setup. If deviations are determined during the recheck, make a note and enter the deviations into the corresponding fields in the function group SENSOR DATA when commissioning.

Step 10

Screw the ultrasonic sensor into the holders by hand.

When using a wrench, the torque must be no more than 30 Nm.

3.8 Mounting the sensors and holders (dual path version)

Step 1

Determine the mounting space on the pipe section (see Sect. 3.5 and 3.6 mounting location and inlet and outlet run). Space requirements of the measurement point approx. 1 x pipe diameter.

Step 2

Draw a centre line on the pipe at the mounting section.

Step 3

Continue the arc at the mounting section of the sensor to one side of the centre line. This should be approx. $\frac{1}{12}$ x pipe circumference for the length of the arc. Mark out the hole. (Hole $\varnothing 81 \dots 82$ mm).

Intermedia step

If the thickness of the pipe is not known, then drill the first hole, e.g. with a plasma cutter, and measure the wall thickness. (Hole $\varnothing 81 \dots 82$ mm).

If the wall thickness is known, then proceed with Step 4.

Step 4

Carry out the Quick Setup program of the transmitter. The sensor should be installed and the power supply switched on. The Quick Setup Program shows the sensor distance. This is the interval between the two holes and also the length of the arc between the sensors of the two measuring groups.





Fig. 10
Mounting the sensors and
holders for the dual path version

Mounting the sensors and holders (dual path version) continued**Step 5**

With the arc length known, you can now correct the centre line.

Step 6

Project the corrected centre line onto the far side of the pipe and mark it (half pipe diameter).

Step 7

Mark on the centre line the sensor distance and project it onto the centre line on the far side of the pipe.

Step 8

Continue the length of the arc to both sides of the centre line and mark the holes.

Step 9

Cut the holes, e.g. with a plasma cutter, and prepare them for welding on the sensor holders (deburr, clean, etc.) (Hole Ø81...82 mm).

Note!

The holes for the sensor holders are paired (CH 1 – CH 1 and CH 2 – CH 2).

Fig. 11
Mounting the sensors and
holders for the dual path version
(continued)

Mounting the sensors and holders (dual path version) continued

Step 10

Insert the sensor holders into both holes and position them with the alignment rod (positioning tool). Tag weld the holders to keep them in place and then weld the two sensor holders permanently.

Note!

To position the alignment rod, the two guides of the sensor holders must be screwed in.

To adjust the depth of weld, both sensor holders can be attached using the special tools to adjust the insertion depth (optional) and then positioned with the alignment rod.

The sensor holders should be flush with the inner pipe surface.

Tag weld both sensor holders.

Step 11


Weld both sensor holders.

Step 12

Insert the second pair of sensor holders in the two remaining holes and position with the alignment rod (positioning tool). Tag weld with the welding unit and then weld the two sensor holders permanently.

Note!

To position the alignment rod, the two guides of the sensor holders must be screwed in.




Note!



Note!

Fig. 12
Mounting the sensors and
holders for the dual path version
(continued)

Mounting the sensors and holders (dual path version) continued**Step 12 continued**

To adjust the insertion depth, both sensor holders can be attached to the insertion depth adjustment tool (optional) and then aligned using the alignment rod. The sensor holders should be flush with the inner pipe surface. Tag weld both sensor holders.

Step 13

Weld both sensor holders.

Step 14

Screw the ultrasonic sensor into the holders by hand. When using a wrench the torque may not exceed 30 Nm.

Recheck the sensor distance, path length and arc length after welding.

Note!

The nominal distances are provided by the Quick Setup. If deviations are determined during the recheck, make a note and enter the deviations into the corresponding fields in the function group SENSOR DATA when commissioning.



Note!

Fig. 13
Mounting the sensors and
holders for the dual path version
(continued)

3.9 Mounting the transmitter

The wall mounting set for the transmitter is delivered as standard. A special mounting set for post mounting can be provided. (Order No.: 50076905)

Caution!

- Observe carefully the electrical connection diagrams on page 25 and 26.
- Fix the cable gland or lay armoured cabling.
- Do not mount cable next to electrical machinery or switching elements.
- The transmitter housing has to be protected from direct sunlight by suitable materials.




Fig. 14
Mounting variants of the transmitter

3.10 Rotating the transmitter housing

1. Loosen the mounting screws (approx. 2 turns)
2. Rotate the transmitter housing as far as the groove of the nut.
3. Carefully pull out the transmitter housing.

Caution!

Do not damage the connecting cable between the transmitter and wall bracket!

4. Rotate the transmitter housing to the position required.
5. Carefully put the transmitter housing onto the wall bracket.
6. Push back the latch again and tighten the two screws securely.





Fig. 15
Rotating the transmitter housing

3.11 Rotating the local display



Warning!



Warning!

Danger from electrical shock!

Switch off power supply before opening the housing.

1. Loosen the safety grip.
(3 mm Allen key)
2. Unscrew the cover to the electronics area.
3. Undo both Phillips screws.
4. Rotate the display to the position required.
5. Tighten the Phillips screws again.
6. Replace the cover of the electronics area on the transmitter housing.
7. Tighten the Allen screws of the safety grip securely.

Fig. 16
Rotating the local display

4 Electrical Connection

Warning!

For instruments with Ex approval for hazardous areas, the installation regulations and technical data may differ from the information given below. Please refer to the separate supplementary Ex documentation.



4.1 Transmitter protection IP 67

The transmitter fulfils all IP 67 requirements (EN 60529). In order to maintain IP 67 protection after installation in the field or after service, the following points must be observed:

- The housing gaskets must be clean and undamaged before placing in the groove. The gaskets may need to be dried, cleaned or replaced if necessary.
- All housing screws and screw covers must be tightly secured.
- The cables used for the connection must have the specified outer diameter.
- Secure all cable glands **1** (see diagram on right).
- Lay the cable in a loop **2** in front of the cable gland. Any moisture forming cannot then reach the entry (see diagram on right).
- Cable glands not used are to be replaced by dummy plugs.
- The protective grommet used may not be removed from the cable entries.




Fig. 17
Protection IP 67

4.2 Sensors protection IP 68

The ultrasonic flow sensors meet all IP 68 requirements (EN 60529). In order to maintain IP 68 protection after installation in the field or after service, the following points must be observed:

- Only cable and connectors **1** supplied by E+H may be used for connecting sensors and transmitters.
- The cable connector gaskets **2** must be clean and undamaged before placing in the groove. The gaskets may need to be dried, cleaned or replaced if necessary.
- Insert the cable connectors so that they do not catch on the side and fix them securely (to the mechanical stop).




Fig. 18
Protection IP 68

4.3 Connecting the transmitter

Warning!

- Danger from electrical shock! Switch off power supply before opening the instrument.
- Connect the ground wire to the ground terminal on the housing before turning on the power supply.
- Check that the local power supply and frequency agree with the information on the nameplate. All relevant national regulations for mounting must also be observed.




Fig. 19
Connecting the transmitter

1. Loosen the screws of the safety grip (3-mm Allen key).
 2. Unscrew the cover of the terminal compartment.
 3. Push the power and signal cables through the appropriate cable glands.
 4. Wire up according to the connection diagrams on page 25 (see also diagram in the screw cover).
- The power supply is connected to Terminal 1 (L1 or L+), Terminal 2 (N or L-) and ground terminal 3:
- Stranded-wire cabling: cover with an end sleeve max. 4 mm²
 - Single wire cabling max. 6 mm²
5. Screw the cover of the terminal compartment securely back onto the transmitter housing.
 6. Tighten the Allen screws of the safety grip.




Fig. 20

Wiring the pc boards:

- HART current output and pulse / frequency output
- HART current output and 2nd current output

HART current output and pulse / frequency output		
1 2	L1 N for AC power supply	L+ L- for DC power supply
3	Ground connection (ground wire)	
20 21	pulse / frequency output	active / passive, $f = 2...10'000$ Hz (max. 16383 Hz) active: 24 V DC, 25 mA (250 mA/20 ms) passive: 30 V DC, 25 mA (250 mA/20 ms)
22 23	Relay 1	max. 60 V AC / 0.5 A max. 30 V DC / 0.1 A can be freely configured. e.g. for fault
24 25	Relay 2	max. 60 V AC / 0.5 A max. 30 V DC / 0.1 A can be freely configured. e.g. for limit value
26 27	Current output 1	active, 0/4...20 mA, $R_L < 700 \Omega$ with HART protocol
28	Ground connection (screen of signal cable)	

HART current output and 2nd current output		
1 2	L1 N for AC power supply	L+ L- for DC power supply
3	Ground connection (ground wire)	
20 21	Current output 2	active, 0/4...20 mA, $R_L < 700 \Omega$
22 23	Relay 1	max. 60 V AC / 0.5 A max. 30 V DC / 0.1 A can be freely configured. e.g. for fault
24 25	Relay 2	max. 60 V AC / 0.5 A max. 30 V DC / 0.1 A can be freely configured. e.g. for limit value
26 27	Current output 1	active, 0/4...20 mA, $R_L < 700 \Omega$ with HART protocol
28	Ground connection (screen of signal cable)	

4.4 Wiring up the connecting cable to the sensors / transmitters

The two sensor cables (including the connectors) from sensors to the transmitter are ready to use and supplied in lengths of 5, 10, 15 or 30 meters.



Warning!

Danger from electrical shock! Switch off the power supply before unscrewing the terminal compartment cover.

1. Loosen the safety claw Allen screw (3 mm Allen key).
Unscrew the cover of the sensor cable / terminal compartment.
2. Remove the dummy cover over the cable entries for channel 1 or 2. Screw in the cable glands
3. Undo the cable glands (delivered with the sensor).
 - Insert the cable through the cover **1** of the cable gland.
 - A threaded cable entry (e.g. for 1/2" NPT) can be used instead of a cover.
 - Place the rubber seal **2** directly up to the tubular rivets **3** and insert the cables in the holes provided (the seal holes have side slots which can be spread open with a screw driver).
 - Place the grounding washer **4** up to the tubular rivets.
 - Insert the rubber seal, the tubular rivets and the grounding ring into the cable gland.
 - Screw down the cover of the cable gland securely.
4. Plug in the cable connectors as shown in the Figure below, View A
5. Secure the cover of the sensor cable terminal compartment.
Tighten the safety claw Allen screw securely.




Fig. 21
Signal cable connection
sensors / transmitters

5 Commissioning

5.1 Switch on

After mounting and installation, the user must check to ensure that the mounting and electrical connections are correct (see Sect. 3 and 4).

When this has been done, the power supply can be switched on and the transmitter can be calibrated for the particular measuring point.

5.2 Programming

For quick commissioning, all basic parameters can be entered via the Quick Setup program. Entries can also be made via the operating matrix. (see Page 3, 33).

One of the following configurations must be selected (see page 52):

- Insertion Channel 1 (Insertion CH1)
- Insertion Channel 1 and Channel 2, one measuring point (IN1&2 1M.-POINT)
- Insertion (Channel 1 and Channel 2, two measuring points (IN1&2 2M.-POINTS)
- Clamp On Channel 1 (Clamp On CH1)
- Clamp On Channel 1 and Channel 2, one measuring point (CI1&2 1M.-POINT)
- Clamp On Channel 1 and Channel 2, two measuring points (CI1&2 2M.-POINTS)

Configuring the outputs according to the requirements of the measuring point.

The following options are available:

- Current output (page 53)
- Pulse/frequency output (page 57)
- Relay output (page 63)

Configuring the output parameters:

- Volume flow
- Sound velocity
- Signal strength

Once it has been configured, the measuring point is ready for operation.

5.3 Zero Point Adjustment

Notes on zero point adjustment

A zero point adjustment is **not** normally required!

In certain cases, experience has shown that a zero point calibration is recommended especially for very high accuracy in the lower flow measurement range ($< 0.5 \text{ m/s}$).


Requirements

Zero point adjustment is carried out using completely filled pipes and a zero flow with e.g. shut-off valves both upstream and downstream. It should be performed with a homogeneous fluid in the pipe. For this reason, with outgassing liquids the zero point adjustment should be performed at operating pressure.



Caution!

Caution!
With very difficult fluids
(higher vapour pressure or high
solids content) it is possible
that a stable zero point can not
be achieved.



ba044y11

Fig. 22
Mounting for carrying out a zero
point adjustment


Carrying out a zero point adjustment

1. Run the plant for as long as necessary until it is operating normally.
2. Stop the flow ($v = 0 \text{ m/s}$).
3. Check the shut-off valves (for leaks).
Check that the operating pressure remain stable during the adjustment.
4. Carry out the adjustment using the local display as follows.
(For zero point adjustment functions see page 74).



Note!

Notes!

- During zero point adjustment the status message S: ZERO ADJUST. CH1 or CH2 RUNNING is shown for 30...60 seconds.
 - If the flow velocity is $> 0.1 \text{ m/s}$ then the error message S: ZERO ADJUST. CH1 or CH2 NOT POSSIBLE is shown on the display and the process is terminated.
 - Once the zero point adjustment has been completed, the new zero point value can immediately be called up with the diagnosis function ( simultaneously pressing).
- The value in the function ZERO POINT is overwritten.

5.4 Configuring the relay contacts

Both relays can be configured freely, i.e. both can be either NC contacts or NO contacts by using a plug-in jumper on the communication board.

Relay 1 (V5):
Factory setting of jumper J5
(Function: FAILURE)

Relay 2 (V6):
Factory setting of jumper J6
(Function: VOLUME FLOW CH1)

Configuring relays			
	2 CUR.	Pulse / frq. (HART)	
NO led out	V5	V5	V6
	V6		
NC led out	V5	V5	V6
	V6		

Version:
2 current outputs
(2 CUR)

Version:
Pulse / frequency output
(HART)

ba044y21

Fig. 23
Configuring the relay contacts
(the appropriate functions
"RELAY 1 or 2" are found on
page 63)

Warning!
If you have a transmitter with Ex approval then please observe the additional separate Ex documentation.




6 Operation

6.1 Display and keys

LC display

- Illuminated, double-spaced with 16 characters
- Displayed are menus, texts and numerical values as well as error, alarm and status messages
- HOME-Position (display during normal operation):
 Upper line → freely selectable measured variable (Factory setting "mass flow CH1")
 Lower line → freely selectable measured variable (Factory setting "total 1")



3 optical operating keys "Touch-Control"

up: Infrared transmitter diode
 down: Infrared receiver diode

+ / - keys



- Select function group
- Select numerical values (if keys are kept pressed, the numbers displayed will begin changing at an accelerated rate)
- Select parameters / settings



Diagnostic and help function
 (activate +/- operating elements simultaneously)

"Enter-key"



Direct access to the operating matrix or on first power up via the QUICK SETUP

Note!

This function can be locked when leaving the QUICK SETUP menu.



Leave operating matrix, Return to HOME position
 (activate E element for more than 3 seconds)



Access function,
 Save entered figures and settings



Note!

ba044y22


Fig. 24
 Display and operating keys

6.2 E+H operating matrix (setting functions)

- ① Access to the operating matrix
- ② Select function group (>GROUP SELECT<)
- ③ Select function (entering / setting data with and saving with)
- ④ Leaving operating matrix, return to the HOME position (from any matrix position, e.g. after programming)



Note!
Operating matrix → see page 33
Programming example → see page 35
Function description → see page 45 ff.



- Notes!
- An automatic return to the HOME position will be made if the operating elements are not pressed for 60 seconds (only when the programming is locked).
 - If the diagnostic function is activated from the HOME position, than an automatic return to the HOME position will be made if the operating elements are not pressed within 60 seconds; whether the programming is enabled or locked.

Fig. 25
Selecting functions in the
E+H operating matrix

ba044y23

Function groups

PROCESS VARIABLE	CALC. VOLUME FLOW CH1 p. 46	VOLUME FLOW CH1 p. 46	VOLUME FLOW CH2 p. 46	NET FLOW p. 47	TOTAL FLOW p. 47	AVE. SOUND VELOC. p. 47	SOUND VELOC. CH1 p. 47	SOUND VELOC. CH2 p. 47	
TOTALIZERS	TOTALIZER 1 p. 48	TOTALIZER 1 OVERFLOW p. 48	TOTALIZER 2 p. 48	TOTALIZER 2 OVERFLOW p. 48	RESET TOTALIZER p. 48	ASSIGN TOTAL 1 p. 48	ASSIGN TOTAL 2 p. 49		
SYSTEM-UNITS	VOLUME FLOW UNIT p. 50	GALLONS/BARREL p. 50	LENGTH UNIT p. 50	CABLE LENGTH UN. p. 50	VELOCITY UNIT p. 50	TEMPERATURE UNIT p. 51	VISCOSITY UNIT p. 51		
SELECTION	SENSOR CONFIG. p. 52	QUICK SETUP p. 52							
CURRENT OUTPUT 1	ASSIGN OUTPUT p. 53	ZERO SCALE p. 53	FULL SCALE 1 p. 53	DUAL RANGE MODE p. 54	FULL SCALE 2 p. 55	ACTIVE RANGE p. 55	TIME CONSTANT p. 55	CURRENT SPAN p. 55	FAILSAFE MODE p. 56
CURRENT OUTPUT 2 (2 CUR. interface)	ASSIGN OUTPUT p. 53	ZERO SCALE p. 53	FULL SCALE 1 p. 53	DUAL RANGE MODE p. 54	FULL SCALE 2 p. 55	ACTIVE RANGE p. 55	TIME CONSTANT p. 55	CURRENT SPAN p. 55	FAILSAFE MODE p. 56
PULS/FREQ. OUTPUT (HART interface)	ASSIGN OUTPUT p. 57	OPERATION MODE p. 57	PULSE VALUE p. 57	PULSE WIDTH p. 58	FULL SCALE FREQ. p. 60	ZERO SCALE p. 60	FULL SCALE p. 59	OUTPUT SIGNAL p. 61	FAILSAFE MODE p. 62
RELAYS	RELAY 1 FUNCTION p. 63	RELAY 1 ON-OFF-VALUE p. 64	RELAY 2 FUNCTION p. 64	RELAY 2 ON-OFF-VALUE p. 64	RELAY 2 OFF-VALUE p. 64				NOMINAL CURRENT 1 p. 56
DISPLAY	ASSIGN LINE 1 p. 66	ASSIGN LINE 2 p. 66	DISPLAY DAMPING p. 66	FORMAT TOTALIZER p. 66	FORMAT TOTALIZER p. 66	LCD CONTRAST p. 67	LANGUAGE p. 67	DISPLAY TEST p. 67	NOMINAL CURRENT 2 p. 56
W. THICKNESS CH1	MODE p. 68	PIPE MATERIAL p. 68	SOUND VEL. LONGI. p. 69	REFERENCE VALUE p. 69	SIG. STRENGTH BAR p. 69	SOUND VEL LONGI. (Display) p. 69	WALL THICKNESS (Display) p. 69	CALIBRATION p. 69	NOMINAL FREQ. p. 62
INSERTION CH1	PIPE DIAMETER p. 70	PIPE WIDTH p. 70	WALL THICKNESS p. 70	VISCOSITY p. 70					
SENSOR DATA CH1	SENSOR TYPE p. 71	CABLE LENGTH p. 71	TRAVERSES p. 71	SENSOR DISTANCE p. 71	DEV. SENSOR DISTANCE p. 71	ARC LENGTH p. 71	DEV. ARC LENGTH p. 71	PATH LENGTH p. 71	DEV. PATH LENGTH p. 71
PROCESS. PARA. CH1 or PROCESSING. PARA.	LOW FLOW CUTOFF p. 72	MEASURING MODE p. 72	FLOW DIRECTION p. 72						
SIGNAL CH1	SIG. STRENGTH BAR p. 73	SIGNAL STRENGTH p. 73							
CALIBR. DATA CH1	CORR. FACTOR p. 74	ZEROPOINT ADJUST p. 74							
W. THICKNESS CH2	MODE p. 68	PIPE MATERIAL p. 68	SOUND VEL. LONGI. p. 69	REFERENCE VALUE p. 69	SIG. STRENGTH BAR p. 69	SOUND VEL LONGI. (Display) p. 69	WALL THICKNESS (Display) p. 69	CALIBRATION p. 69	
INSERTION CH2	PIPE DIAMETER p. 70	PIPE WIDTH p. 70	WALL THICKNESS p. 70	VISCOSITY p. 70					
SENSOR DATA CH2	SENSOR TYPE p. 71	CABLE LENGTH p. 71	TRAVERSES p. 71	SENSOR DISTANCE p. 71	DEV. SENSOR DISTANCE p. 71	ARC LENGTH p. 71	DEV. ARC LENGTH p. 71	PATH LENGTH p. 71	DEV. PATH LENGTH p. 71
PROCESS. PARA. CH2	LOW FLOW CUTOFF p. 72	MEASURING MODE p. 72	FLOW DIRECTION p. 72						
SIGNAL CH2	SIG. STRENGTH BAR p. 73	SIGNAL STRENGTH p. 73							
CALIBR. DATA CH2	CORR. FACTOR p. 74	ZEROPOINT ADJUST p. 74							
COMMUNICATION	PROTOCOL p. 75	BUS ADDRESS p. 75	TAG NUMBER p. 75	TAG NUMBER CH2 p. 75					
SYSTEM PARAMETER	PRESENT SYSTEM CONDITION p. 76	PREVIOUS SYSTEM CONDITIONS p. 76	ACCESS CODE p. 76	DEF. PRIVATE CODE p. 77	POS. ZERO RETURN p. 77	SOFTWARE VERSION p. 78	SOFTWARE COM. p. 78	SERIAL NUMBER p. 78	SYSTEM RESET p. 78

These functions are only displayed if other functions have been configured accordingly

ba044s28







These functions are only displayed if other functions have been configured accordingly

Further information on programming

For the Prosonic Flow measuring system there is a wide choice of functions available which the user can set individually and adapt to the process conditions. The transmitter is fitted with various electronic modules, depending on the specifications when ordering (communications module "HART"; "2 CUR."). Depending on the module, certain functions and function groups are not available or are only available on the display once other functions have been configured.

Please note the following points when programming:

- If the power supply fails, then all calibrated and set values are safely stored in the EEPROM (without requiring batteries).
- Functions which are not required, e.g. current or pulse/frequency output, can be set to OFF. The appropriate functions in other function groups then no longer appear on the display.
- If, when programming you wish to undo a setting carried out with , then select CANCEL. This is only possible for settings which have not yet been stored by pressing .
- In certain functions, for safety reasons a prompt is given after entering data. Select  "SURE [YES]" with the keys and confirm by pressing  again. The setting is now stored or a function, e.g. zero point adjustment, is activated.
- The Prosonic Flow DMU 93 may not show values with all decimal places as this depends on the unit used and the number of decimal places selected (see function "FORMAT FLOW.", on page 66).
When programming, an arrow is therefore shown between the measured value and the unit (e.g. 1.2 → dm³/h).




Caution!

Enable programming(entering the code number)

Normally programming is locked. Any unauthorised changes to the instrument functions, values or factory settings are therefore not possible. Only when a code has been entered (factory setting = 93) can parameters be entered or changed. The use of a personal code number which can be freely chosen prevents unauthorised personnel from gaining access to data (see page 77).

Caution!


- If programming is locked and the  keys are pressed in a given function, then prompt to enter the code automatically appear on the display.
- With code = 0 the program is always enabled!
- If the personnel code number is no longer available, then please contact the Endress+Hauser service organisation for assistance.

Locking programming

- After returning to HOME position, programming is again locked after 60 seconds if no keypad is pressed.
- Programming can also be locked by entering any number (not the customer code number) in the function ACCESS CODE.

6.3 Example of programming

If you wish to change the factory set current output “4–20 mA” to “0–20 mA” proceed as shown:



ba044y24

P	R	O	C	E	S	S	V	A	R	I	A	B	L	E
>		G	R	O	U	P	S	E	L	E	C	T	.	<

E Access to the operating matrix.

C	U	R	R	E	N	T	O	U	T	P	U	T		
>		G	R	O	U	P	S	E	L	E	C	T	.	<

+
- Select the desired function group (“CURRENT OUTPUT”).

4	-	2	0		m	A								
C	U	R	R	E	N	T	S	P	A	N				

E Select function “CURRENT SPAN”.

					0									
A	C	C	E	S	S	C	O	D	E					

+
- On pressing + or – the entry of the code is automatically prompted.

					9	3								
A	C	C	E	S	S	C	O	D	E					

+
- Enter the code number (Factory setting is 93).

								I						
E	D	I	T	I	N	G	E	N	A	B	L	E	D	

E Programming now is enabled.

The programmed value flashes.

4	-	2	0		m	A								
C	U	R	R	E	N	T	S	P	A	N				

+
- Select desired current span. the display stops flashing.

0	-	2	0		m	A								
C	U	R	R	E	N	T	S	P	A	N				

E Save the input. The display flashes and the value can be changed once again.

I	N	P	U	T	S	T	O	R	E	D				

0	-	2	0		m	A								
C	U	R	R	E	N	T	S	P	A	N				

E Return to the “HOME” position (press the E key for more than 3 sec.)
In the “HOME” position the programming level is locked again after 1 minute if none of the operating keys is pressed.

or

E Select another function
Following the last function there is an automatic return to the related function group.

	B	A	C	K	T	O	G	R	O	U	P			
			S	E	L	E	C	T	I	O	N			

6.4 Operation with the “HART handheld terminal DXR 275”

Prosonic Flow DMU 93 functions are selected with the HART handheld terminal over a number of menu levels as well as a special operating matrix for HART handheld terminals (see Fig. 26)



Note!

Notes!

- All functions are accessible with the HART handheld terminal, i.e. programming is not locked. You can, however, lock the HART operating matrix by entering the value 1 in the function ACCESS CODE. The data can then no longer be altered. This is the status even after a power failure. The operating matrix can again be enabled by entering the code 93.
- The HART protocol requires a 4...20-mA setting of the current output (see page 55). The setting 0...20 mA is then only available if the setting HART is switched off in the function PROTOCOL (see page 75).
- Prosonic Flow can only be operated when using a HART handheld terminal DXR 275 equipped with a 4 MB flash RAM.

Further information on the HART handheld terminal is given in the appropriate operating manual in the carrying case.

Procedure

1. Switch on handheld terminal:
 - a. Transmitter is not yet connected → HART main menu is displayed → Continue with “Online”
 - b. Transmitter is already connected → the menu level “Online” is displayed
2. “Online” menu level:
 - Actual measurement data including flow, totalizer sum etc.
 - Via “Matrix group sel.” you have access to the HART operating matrix (s. page 37) and to the function group (e.g. CURRENT OUTPUT) and finally to the desired function, e.g. “Full scale 1”.
3. Enter values or change the setting.
4. The field “SEND” is shown by pressing the F2 function key. By pressing this key, all values and settings entered with the handheld terminal are registered by the Prosonic measuring system.
5. Press the F3 HOME function key to return to the “Online” menu level. The actual values measured by the Prosonic flow measuring system with the new settings can now be read off.




Fig. 26
Operating the HART
handheld terminal

ba044y25

Matrix group sel.

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

6.5 Commuwin II via HART protocol

Commuwin II is a universal program for remote operation of field and control room devices. Use of the Commuwin II operating program is possible independent of the type of instrument or communication (HART, PROFIBUS, etc.). Operation is done over a personal computer using the special Commuwin II program as well as the "Commubox FXA 191" HART modem with the RS 232 C serial interface.

Commuwin II offers the following functions:

- calibration of functions
- visualisation of measured values
- data backup of instrument parameters
- device diagnostics
- measuring point diagnosis

Commuwin II may also be combined with other software packages to visualise processes.

For additional information on Commuwin II, see the following E+H documentation:

- System Information: SI 018F/00/en "Commuwin II"
- Operating manual: BA 124F/00/en "Commuwin II Operating Program"





Fig. 28
Operating with "Commuwin II"

The Commuwin II operating matrix for Prosonic Flow DMU 93 is found on the following pages.

6.6 Operation with Commuwin II

For operating Prosonic Flow DMU 93 with the Commuwin II software all instrument functions are clearly organised in a matrix.

Various sections of the complete matrix containing various function groups and functions can be called up using the SELECTION (V3H0) function.



Operation matrix for Commuwin II

		H0	H1	H2	H3
V0	MEASURED VALUE	CALC. VOLUME FLOW or VOLUME FLOW CH1	VOLUME FLOW CH1 or VOLUME FLOW CH2	VOLUME FLOW CH2 or NET FLOW	AVE.SOUND VELOC. or TOTAL FLOW
V1	TOTALIZER	TOTALIZER 1	TOTAL. 1 OVERFLOW	TOTALIZER 2	TOTAL. 2 OVERFLOW
V2	SYSTEM UNITS	VOLUME FLOW UNIT	VOLUME UNITS	GALLON/BARREL	LENGTH UNIT
V3	SELECTION	SELECTION: DISPLAY VALUES OUTPUTS CHANNEL CH1 SERVICE CH1 CHANNEL CH2 SERVICE CH2		SENSOR CONFIG.	
V4					
V5					
V6					
V7					
V8	COMMUNICATION	PROTOCOL	BUS ADDRESS		
V9	SYSTEM P ARAMETER	DIAGNOSTIC CODE		ACCESS CODE	
VA	TAG NUMBER	TAG NUMBER	TAG NUMBER CH 2		

Commuwin II partial matrix “OUTPUTS”

V3	SELECTION	SELECTION: OUTPUTS		SENSOR CONFIG.	
V4	CURRENT OUTPUT or CURRENT OUTPUT 1	ASSIGN OUTPUT	ZERO SCALE	FULL SCALE 1	DUAL RANGE MODE
V5	PULSE/FREQ. OUTPUT or CURRENT OUTPUT 2	ASSIGN PULS/FREQ.	OPERATION MODE	IPULSE VALUE	PULSE WIDTH
V6	RELAY	RELAY 1 FUNCTION	SWITCH-ON PT. RE 1	SWITCH-OFF RE RE 1	RELAY 2 FUNCTION
V7	DISPLAY	DISPLAY LINE 1	DISPLAY LINE 2	DISPLAY DAMPING	FORMAT FLOW

Commuwin II partial matrix “CHANNEL CH1”

V3	SELECTION	SELECTION: CHANNEL CH1		SENSORKONFIG.	
V4	INSERTION CH1	PIPE DIAMETER	PIPE CIRCUMFERENCE	WALL THICKNESS	
V5					
V6	SENSOR DATA CH1	SENSOR TYPE		CABLE LENGTH	TRAVERSES
V7	PROZESSING PARA. or PROZESSPARA. CH1	LOW FLOW CUTOFF	MEASURING MODE	FLOW DIRECTION	

H4	H5	H6	H7	H8	H9
SOUND VELOC. CH1	SOUND VELOC. CH2		NOMINAL CURRENT 1	NOMINAL CURRENT 2	ACTUAL FREQUENCY
RESET TOTALIZER	ASSIGN TOTAL 1	ZASSIGN TOTAL 2			
CABLE LENGTH UN.	VELOCITY UNIT	TEMPERATURE UNIT	VISCOSITY UNIT		
		COMMODUL HW-TYPE			
POS. ZERO RETURN	SOFTWARE VERSION	SOFTWARE VER. COM	SERIAL NUMBER		

FULL SCALE 2	ACTIVE RANGE	TIME CONSTANT	CURRENT RANGE	FAIL SAFE MODE	SIMULATION CURR.
FULL SCALE FREQ.	ZERO SCALE	FULL SCALE FLOW	OUTPUT SIGNAL	FAIL SAFE MODE	SIMULATION FREQ.
SWITCH-ON PT. RE2	SWITCH-OFF PT. RE 2				
	FORMAT TOTALIZER	LCD CONTRAST	LANGUAGE	TEST DISPLAY	

	VISCOSITY				
SENSOR DISTANCE	DEV. SENSOR DISTANCE	ARC LENGTH	DEV. ARC LENGTH	PATH LENGTH	DEV. PATH LENGTH

Commuwin II partial matrix “SERVICE CH1”

		H0	H1	H2	H3
V3	SELECTION	SELECTION: SERVICE CH1		SENSORKONFIG.	
V4					
V5	SIGNAL CH1		SIGNAL STRENGTH		
V6	CALIBR.DATA CH1		CORR. FACTOR	ZERO POINT	
V7	W.THICKNESS CH1	MODE	PEMATERIAL *	SOUND VEL. LONGI *	REFERENCE VALUE **

Commuwin II partial matrix “CHANNEL CH2”

V3	SELECTION	SELECTION: CHANNEL CH2		SENSOR CONFIG.	
V4	INSERTION K2	PIPE DIAMETER	PIPE CIRCUMFERENCE	WALL THICKNESS	
V5					
V6	SENSOR DATA CH2	SENSOR TYPE		CABLE LENGTH	TRAVERSES
V7	PROZESS PARA CH2	LOW FLOW CUTOFF		MEASURING MODE	FLOW DIRECTION

Commuwin II partial matrix “SERVICE CH2”

V3	SELECTION	SELECTION: SERVICE CH2		SENSORKONFIG.	
V4					
V5	SIGNAL CH2		SIGNAL STRENGTH		
V6	CALIBR. DATA CH2		CORRECTION FACTOR	ZERO POINT	
V7	W.THICKNESS CH2	MODE	PEMATERIAL *	SOUND VEL. LONGI *	REFERENCE VALUE **

* Mode = WALL THICKNESS

** Mode = SOUND VEL.. LONGI

H4	H5	H6	H7	H8	H9
STATIC ADJUST					
	SOUND VEL. LONGI **	WALL THICKNESS *	CALIBRATION */**		

		VISCOSITY			
SENSOR DISTANCE	DEV. SENSOR DISTANCE	ARC LENGTH	DEV. ARC LENGTH	PATH LENGTH	DEV. PATH LENGTH

STATIC ADJUST					
	SOUND VEL. LONGI **	WALL THICKNESS *	CALIBRATION */**		



* Mode = WALL THICKNESS
** Mode = SOUND VEL. LONGI

7 Functions

This section lists in detail a description as well as all the information required for the individual functions of the Prosonic Flow DMU 93.
Factory settings are shown in ***bold italics***. Factory set values/settings shown here may differ from those instruments with parameters requested by the customer when ordering.

Function group.....	Page
PROCESS VARIABLE.....	46
TOTALIZER	48
SYSTEM UNITS.....	50
SELECTION	52
CURRENT OUTPUT 1	53
CURRENT OUTPUT 2.....	53
PULS / FREQUENCY OUTPUT	57
RELAY	63
DISPLAY.....	66
WALL THICKNESS CHANNEL 1.....	68
INSERTION CHANNEL 1	70
SENSOR DATA CHANNEL 1	71
PROCESS PARAMETER CHANNEL 1 or PROCESS PARAMETER.....	72
WALL THICKNESS CHANNEL 2.....	68
INSERTION CHANNEL 2	70
SENSOR DATA CHANNEL 2.....	71
PROCESS PARAMETER CHANNEL 2	72
SIGNAL CHANNEL 1	73
CALIBRATION DATA CHANNEL 1	74
SIGNAL CHANNEL 2.....	73
CALIBRATION DATA CHANNEL 2.....	74
COMMUNICATION	75
SYSTEM PARAMETER	76

Version: INSERTION CH1 IN1&2 1M.-POINT IN1&2 2M.-POINTS







ba044y43

Note!
If no special reference is made in the cell, then it applies to all three versions:
(INSERTION CH1, IN1&2 1M.-POINT and IN1&2 2M.-POINTS).








Function group PROCESS VARIABLE	
<p>Notes!</p> <ul style="list-style-type: none"> The engineering units of all variables shown here can be set in the Function group "SYSTEM UNITS". You may set the maximum number of displayed decimals in function FORMAT FLOW (see page 66). If the fluid in the piping flows backwards, then the flow rate value is indicated by a negative sign. 	
<p>VOLUME FLOW CH1</p> <p>only for version: INSERTION CH1 IN1&2 2M.POINTS</p> <p>or</p> <p>CALC. VOLUME FLOW only for version: IN1&2 1M.POINT</p>	<p>Version INSERTION CH1 and IN1&2 2M.POINTS: Display of the current measured volume flow.</p> <p>Version IN1&2 1M.POINTS: Display of the average volume flow derived from the "VOLUME FLOW CH1" and "VOLUME FLOW CH2"</p> <p>5-digit number with floating decimal point, incl. units and arithmetical sign (e.g. 5,1145 m³/h)</p> <p>  for VOLUME FLOW CH1: FLOW VELOCITY from CH1  for CALC. VOL. FLOW: none </p> <p>Note! System response in special cases: In Version IN1&2 1M.POINT a single channel failure response is available. If one channel fails or wall thickness measurement is activated, then the operating channel is duplicated to the other channel. Only when both channels are defective does the instrument show a fault.</p> <p><i>Example 1:</i> Channel 2 fails due to defective sensor. – Flashing message: F: SENSOR CURRENT DROP CH2 – Fault relay 1 or 2 does not de-energise – Current outputs or frequency output do not switch to error response – The volume flow CH1 replaces Channel 2 for STD.VOL. FLOW → all assigned outputs respond accordingly. – For Channel 2: Volume flow CH2, sound velocity CH2 as well as signal strength CH2 assume to zero → all assigned outputs assume zero.</p> <p><i>Example 2:</i> Channel 1 and Channel 2 fail due to defective sensors – Flashing message: F: SENSOR CH1 CURRENT DROP and F: SENSOR CH2 CURRENT DROP – Fault relay 1 or 2 de-energise – Current outputs or frequency output switch to error response – Volume flow CH1 or CH2, sound velocity CH1 or CH2, signal strength CH1 or CH2, standard volume FLOW as well as average sound velocity assume zero → all assigned outputs assume zero.</p>
<p>VOLUME FLOW CH1</p> <p>only for version: IN1&2 1M.POINT</p>	<p>Display of current measured volume flow on Channel 1.</p> <p>5-digit number with floating decimal point, incl. units and arithmetical sign (e.g. 1.3549 m³/h)</p> <p>  FLOW VELOCITY of CH1 </p>
<p>VOLUME FLOW CH2</p> <p>only for version: IN1&2 1M.POINT IN1&2 2M.POINTS</p>	<p>Display of current measured volume flow on Channel 2.</p> <p>5-digit number with floating decimal point, incl. units and arithmetical sign (e.g. 0.7305 m³/h)</p> <p>  FLOW VELOCITY of CH2 </p>

Function group PROCESS VARIABLE	
AVE. SOUND VELOC. only for version: IN1&2 1M.STELLE	<p>Display of average, sound velocity (sound velocity in fluids!), derived from "SOUND VELOCITY CH1" and "SOUND VELOCITY CH2".</p> <p>4-digit number with floating decimal point, incl. units (e.g. 1400 m/s)</p> <p>Note! System response in special cases: In Version IN1&2 1M.POINT a single channel failure response is available. If one channel fails or wall thickness measurement is activated, then the operating channel is duplicated to the other channel. Only when both channels are defective does the instrument show a fault.</p> <p><i>Example 1:</i> Channel 2 fails due to defective sensor. – Flashing message: F: SENSOR CURRENT DROP CH2 – Fault relay 1 or 2 does not de-energise – Current outputs or frequency output do not switch to error response – The volume flow CH1 replaces Channel 2 for STD.VOL. FLOW → all assigned outputs respond accordingly. – For Channel 2: Volume flow CH2, sound velocity CH2 as well as signal strength CH2 assume to zero → all assigned outputs assume zero.</p> <p><i>Example 2:</i> Channel 1 and Channel 2 fail due to defective sensors – Flashing message: F: SENSOR CH1 CURRENT DROP and F: SENSOR CH2 CURRENT DROP – Fault relay 1 or 2 de-energise – Current outputs or frequency output switch to error response – Volume flow CH1 or CH2, sound velocity CH1 or CH2, signal strength CH1 or CH2, standard volume FLOW as well as average sound velocity assume zero → all assigned outputs assume zero.</p>
NET FLOW. only for version: IN1&2 2M.POINTS	<p>Display of flow as a result of Channel 2 flow rate minus Channel 1 flow rate.</p> <p>5-digit number with floating decimal point, incl. units (e.g. 0.1549 m³/h)</p> <p>Note! The same value for creep suppression and flow direction must be set on both channels.</p>
TOTAL FLOW only for version: IN1&2 2M.POINTS	<p>Display of flow as a result of Channel 2 flow rate plus Channel 1 flow rate.</p> <p>5-digit number with floating decimal point, incl. units (e.g. 1.3549 m³/h)</p> <p>Note! The same value for creep suppression and flow direction must be set on both channels.</p>
SOUND VELOC. CH1	<p>Display of sound velocity for Channel 1, (sound velocity in fluids!).</p> <p>4-digit number with floating decimal point, incl. units (e.g. 1400 m/s)</p>
SOUND VELOC. CH2 only for version: IN1&2 1M.POINT IN1&2 2M.POINTS	<p>Display of sound velocity for Channel 2, (sound velocity in fluids!).</p> <p>4-digit number with floating decimal point, incl. units (e.g. 1400 m/s)</p>












Function group TOTALIZER	
TOTALIZER 1 TOTALIZER 2	<p>Display of the totalised flow quantity from when measurement began or since the last totalizer reset. This value is either positive or negative depending on the direction of flow:</p> <p>max. 7-digit number with floating decimal point, incl. units</p> <p>Notes!</p> <ul style="list-style-type: none"> • If the count has more figures than can be shown beyond 9'999'999, then the symbol ">" (pos. pos. values) or ">-" (neg. values) are shown before the value. The number of totalizer overflows is shown in the function "TOTAL. OVERFLOW". • If the function "MEASURING MODE" is set to "UNIDIRECTIONAL" (see page 72), then the following applies: <p><i>Flow direction function → FORWARD (see page 72):</i> The totalizer takes into account positive flow directions only.</p> <p><i>Flow direction function → REVERSE (see page 72):</i> The totalizer takes into account negative flow directions only.</p> <ul style="list-style-type: none"> • In cases of error the totalizer is coupled to the error response of the pulse/frequency output 1 (see page 62). <p>  ASSIGN TOTAL. 1 or 2 Display showing which measuring variable is assigned to the totalizer. </p>
TOTAL 1 or 2 OVERFLOW	<p>Display of totalizer overruns.</p> <p>On the display the totalised flow is shown as a max. 7-digit number with floating decimal point. Larger numbers (>9'999'999) can be read off in this function as overflows. The effective amount is calculated from the sum of the value shown in the function "TOTAL. OVERFLOW" and in the function "TOTALIZER 1, 2".</p> <p><i>Example:</i> Display of two overruns: $2 \text{ e7 dm}^3 = 2 \cdot 10^7 \text{ dm}^3 = 20'000'000 \text{ dm}^3$ The value shown in the function "TOTALIZER 1" = $196'845.7 \text{ dm}^3$ Total amount = $20'196'845.7 \text{ dm}^3$</p> <p>max. 7-digit total</p> <p>  ASSIGN TOTAL. 1 or 2 Display showing which measuring variable is assigned to the totalizer. </p>
RESET TOTALIZER	<p>Totalizer 1 or 2 as well as totalizer 1/2 deleted individually (i.e. the values are set to zero).</p> <p>  CANCEL TOTAL. 1 TOTAL. 2 TOTAL. 1 & 2 </p>




Function group TOTALIZER	
ASSIGN TOTAL. 1 or 2	<p>Assigning the totalised flow amount.</p> <p>Totalizer 1 or totalizer 2 is reset to zero (deleted) if the assignment of this function is changed again.</p> <div><div><div></div><div></div></div><div>CANCEL OFF** CALC. VOLUME CALC. VOLUME(+) CALC. VOLUME(-) VOLUME CH1* VOLUME(+) CH1 VOLUME(-) CH1 VOLUME CH2 VOLUME(+) CH2 VOLUME(-) CH2 NET VOLUME TOTAL VOLUME TOTAL VOLUME(+) TOTAL VOLUME(-)</div><div><div>}</div><div>IN1&2 1M.POINT</div><div>}</div><div>IN1&2 1M.POINT and IN1&2 2M.POINTS</div><div>}</div><div>IN1&2 2M.POINTS</div></div><p>*Totalizer 1 / ** Totalizer 2</p><p>Notes!</p><ul style="list-style-type: none">• When selecting NET VOLUME and TOTAL VOLUME functions, it is necessary to set the same values for the low flow cut off and the flow direction functions on both channels.• TOTAL VOLUME (+) is the total volume from VOL1 + VOL2 measured in the flow direction.• TOTAL VOLUME (-) is the total volume from VOL1 + VOL2 measured against the flow direction.</div>



Note!

Function group SYSTEM UNITS	
VOLUME FLOW UNIT	<p>In this function the engineering units for volumetric flowrate 1 and volumetric flowrate 2 are selected.</p> <p> CANCEL dm^3/s – dm^3/min – dm^3/h l/s – l/min – l/h hl/min – hl/h m^3/s – m^3/min – m^3/h gal/min – gal/hr – gal/day gpm – gph – gpd – mgd bbl/min – bbl/hr – bbl/day</p>
VOLUME UNIT	<p>Selecting the engineering units for flow quantity.</p> <p> CANCEL – dm^3 – l – hl – m^3 – gal – bbl</p>
GALLONS/ BARREL	<p>Selecting between US and IMP units. In the USA and UK, the ratio of barrels (bbl) to gallons (gal) is defined according to the specific industry.</p> <p> CANCEL US: 31.0 gal/bbl for beer US: 31.5 gal/bbl for liquids (used in normal cases) US: 42.0 gal/bbl for oil (petrochemicals) US: 55.0 gal/bbl for filling tanks IMP: 36.0 gal/bbl for beer IMP: 42.0 gal/bb for oil (petrochemicals)</p> <p> US: 1 gal = 3.785 l IMP: 1 gal = 4.546 l</p>
LENGTH UNIT	<p>Selecting the engineering units for a defined length such as the outer diameter "wall thickness".</p> <p> CANCEL mm inch</p>
CABLE LENGTH UNIT	<p>Selecting the engineering units for a defined length of cable connection from the sensor to the transmitter.</p> <p> CANCEL m ft</p>
VELOCITY UNIT	<p>Selecting the engineering units for transversal and longitudinal sound velocity as well as the velocity of the fluid to be measured.</p> <p> CANCEL m/s ft/s</p>

Function group SYSTEM UNITS	
TEMPERATURE UNIT	<div>Selecting the engineering units for the temperature of the medium to be entered.</div> <div><div><div>+</div><div>-</div></div><div>CANCEL °C (°Celsius) K (Kelvin) °F (°Fahrenheit) °R (°Rankine)</div></div>
VISCOSITY UNIT	<div>Selecting the units for the kinematic viscosity to be entered.</div> <div><div><div>+</div><div>-</div></div><div>CANCEL mm²/s cSt St</div></div>

Function group SELECTION	
SENSOR CONFIG.	<div>Selecting the ensor configuration.</div> <div><div><div><div></div><div></div></div><div></div></div><div>CANCEL</div></div> <div><div>INSERTION CH1</div><div><div>ba044y52</div></div></div> <div><div>IN1&2 1M.POINT</div><div><div>ba044y53</div></div></div> <div><div>IN1&2 2M.POINTS</div><div><div>ba044y54</div></div></div> <div><div>Notes!</div><div>For the Insertion version the following selections are available: INSERTION CH1 CL1&2 1M.POINT and CL1&2 2M.POINTS</div></div> <div><div>Note!</div><div>INSERTION CH1 is not visible in the selection when channel 2 is assigned either the totalizer, display, current output, frequency/pulse output or relays. The following functions indirectly assign an output to channel 2: NET FLOW, TOTAL FLOW, NET VOLUME, TOTAL VOLUME or AVERAGE SOUND VELOCITY. Remove any reference to channel 2 in all outputs to make the INSERTION CH1 visible and selectable in the configuration selection matrix.</div></div>
QUICK SETUP	<div>Calling up this function enables that distance between sensors to be calculated using the least amount of data for mounting the system for the application.</div> <div><div>Note!</div><div>Please closely observe the procedure on page 2.</div></div> <div><div>Notes for IN1&2 1M.POINT:</div><div>After a complete run through of the set-up selection "PROCESS PARAMETER" (returning to the Setup selection), the parameters shown for Channel 1 and Channel 2 are the same.</div></div> <div><div><div><div></div><div></div></div><div></div></div><div>CANCEL START</div></div>




Note!



Note!



Note!

Function group CURRENT OUTPUT 1 or 2	
ASSIGN OUTPUT	<p>In this function any variable required can be assigned to the current output 1 or 2.</p> <div><div><div>+</div><div>-</div></div><div>CANCEL OFF** CALC. VOLUME FLOW VOLUME FLOW CH1* VOLUME FLOW CH2 AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG.STRENGTH CH1 SIG.STRENGTH CH2 NET FLOW TOTAL FLOW</div></div> <p>*Current output 1 / **Current output 2</p> <p>In the diagnostic function the following display is shown the flow assignment:</p> <div><div><div>ψ</div><div>+</div><div>-</div></div><div>MEASUREMENT MODE (see page 72)</div></div> <p>Note! NET and TOTAL FLOW require that low flow cut off and the flow direction is set to the same value for both channels.</p>
ZERO SCALE or FULL SCALE 1	<p>In these two functions define the following values for the variable assigned to the current outputs:</p> <ul style="list-style-type: none">• 0/4 mA-quiescent current → <i>zero value of the measured value</i>• 20 mA → <i>full scale value of the measured value</i> <p>These values apply to both flow directions (bi-directional).</p> <p>Notes!</p> <ul style="list-style-type: none">• The flow direction can be indicated by the configurable relay outputs (see page 63).• The zero value and full range value are freely programmable.• The zero scale value may be higher or lower than the full scale value or can even be negative.• The span between the zero and the full scale value should not fall below a set minimum as, otherwise, very small measured value changes may cause large jumps of the output signal: <div></div> <div><div><div>+</div><div>-</div></div><div>5-digit number with floating decimal point (e.g. 1.2345 dm³/h)</div></div> <div><div><div>ψ</div><div>+</div><div>-</div></div><div>Display showing which process variable is assigned to the current output.</div></div>



Note!



Note!

Function group CURRENT OUTPUT 1 or 2

DUAL RANGE
MODE

For specific applications the scaling of a second full scale value is useful or possibly required especially with flow rate variables. In this function the two full scale values are selected with which the measuring system operates. The setting "AUTOMATIC" allows the measuring system to switch between two full scale values.

Applications:

- Frequent measurement of two different fluids with widely differing flow velocities. The operator defines a full scale value for each of these two fluids which can be activated in this function as required.
- Higher resolution of the measuring signal with very small flow velocities. The setting "AUTOMATIC" allows the Prosonic Flow DMU 93 transmitter to switch automatically between two full scale values depending on the flow velocity.




Note!

Note!

The actual full scale value can be supplied by the relay if this is configured accordingly (see figure below as well as page 63).

Example (0...20 mA; full scale 1 < full scale 2)



CANCEL

FULL SCALE 1 The measuring system operates with full scale value 1 only

FULL SCALE 2 The measuring system operates with full scale value 2

AUTOMATIC The measuring system operates with full scale value 1 or 2; Automatic switching between fully scale values 1 and 2








Display showing which process variable is assigned to the current output.







ba44y31

Function group CURRENT OUTPUT 1 or 2	
FULL SCALE 2	<p>For description of function → see "FULL SCALE 1" function (see page 53)</p> <p>Notes!</p> <ul style="list-style-type: none"> This function is only available if Full scale 2 has been activated in the function "DUAL RANGE MODE" (see page 54). Full scale 2 may be larger or smaller than zero scale or full scale 1.
ACTIVE RANGE	<p>Display of actual full scale from current output 1 or 2.</p> <p>Note!</p> <p>The actual full scale can also be supplied by the relays they are configured accordingly (see page 63).</p> <div> FULL SCALE 1 FULL SCALE 2 </div> <div> Display showing which process variable is assigned to the current output. </div>
TIME CONSTANT	<p>Selecting the time constant (τ). To determine whether the current output signal reacts quickly (small time constant) or slowly (large time constant) to rapidly fluctuating variables. The time constant does not affect the behaviour of the display. The time constant is activated if the large flow or sound velocity is assigned to the current output.</p> <div> 5-digit number with fixed decimal point (0.5...100.00 s) Factory setting: 5.00 s </div> <div> Display showing which process variable is assigned to the current output. </div>
CURRENT SPAN	<p>Setting the 0/4-mA quiescent current. The current for the scaled full scale volume (= 100%) is always 20 mA.</p> <p>Note!</p> <p>The 0–20 mA current output can only be selected if the HART protocol is inactivated (see page 75).</p> <div> CANCEL 0–20 mA (25 mA) → max. 25 mA 4–20 mA (25 mA) → max. 25 mA 0–20 mA → max. 20.5 mA (NAMUR) 4–20 mA → max. 20.5 mA (NAMUR) </div> <div> Display showing which process variable is assigned to the current output. </div>





Function group CURRENT OUTPUT 1 or 2	
<p>FAIL SAFE MODE</p>	<p>It is advisable for safety reasons that the current output in cases of an instrument error assumes a previously defined status which can be set in this function.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>CANCEL</p> <p>MIN. CURRENT Current signal is set to 0 mA (0...20 mA) or 2 mA (4...20 mA) on error.</p> <p>MAX. CURRENT Current signal is set to 25 mA for 0/4...20 mA (25 mA) or to 22 mA for 0/4...20 mA.</p> <p>HOLD VALUE Last valid measured value is held</p> <p>ACTUAL VALUE Normal measured value given despite error</p> </div> </div> <div style="margin-top: 10px;">  <p>Display indicates the to the current output, assigned process variable.</p> </div> <p>Note!</p> <p>The setting given here effects only the particular current output. Other outputs as well as the display (e.g. totalizer display) are not affected.</p> <p>The failsafe mode also operates in conjunction with "Assign Output" by the configuration IN1&2 2M.POINTS":</p> <p>CH1: General instrument fault + sensor-specific fault CH1 CH2: General instrument fault + sensor-specific fault CH2</p>
<p>SIMULATION CURRENT</p>	<p>Simulation of the output current corresponding to 0%, 50% or 100% of the set current range. Errors may also be simulated.</p> <p><i>Application examples:</i></p> <ul style="list-style-type: none"> • Checking instruments connected • Checking the adjustment of the internal current signal <p><i>Notes!</i></p> <ul style="list-style-type: none"> • After activating the simulation mode, the message "S: CURRENT OUTPUT SIMUL. ACTIVE" appears on the display (HOME position). • The selected simulation mode affects only the current output. The flowmeter remains fully operational for measurement, i.e. totalizer flow display etc. are operating normally. • Positive zero return to (see page 77) interrupts any simulation being carried out and sets the output current to 0 mA or 4 mA. <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>At 0–20 (25 mA): OFF – 0 mA – 10 mA – 20 mA – 25 mA –</p> <p>At 4–20 (25 mA): OFF – 2 mA – 4 mA – 12 mA – 20 mA – 25 mA – CANCEL</p> </div> </div> <p><i>Current output acc. to NAMUR</i></p> <p>At 0–20 mA: OFF – 0 mA – 10 mA – 20 mA – 22 mA –</p> <p>At 4–20 mA: OFF – 2 mA – 4 mA – 12 mA – 20 mA – 22 mA – CANCEL</p>
<p>NOMINAL CURRENT 1 or 2</p>	<p>In this function the current and calculated target value of the output current is shown.</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;">  </div> <div> <p>Number with fixed decimal point and one decimal place, incl. unit (e.g. 4.0 mA)</p> </div> </div> <div style="margin-top: 10px;">  <p>Display showing which process variable is assigned to the current output.</p> </div>





Function group PULS / FREQ. OUTPUT	
ASSIGN OUTPUT	<p>In this function a particular variable can be assigned to the pulse/frequency output.</p> <div>  <div> CANCEL OFF CALC.VOLUME* VOLUME CH1* VOLUME CH2* NET VOLUME TOTAL VOLUME </div> <div> } (Measurement mode frequency and pulse) </div> </div> <div> <div> AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 </div> <div> } (Measurement mode frequency only) </div> </div> <div>  <p>The diagnosis function only applies to the option marked with *: Display showing whether the flowmeter measures in one or in both flow directions (see function "MEASURING MODE" on page 72).</p> <p>Note! NET FLOW and TOTAL FLOW require that low flow cut off and the flow direction is set to the same value for both channels.</p> </div>
OPERATION MODE	<p>In this function the output is configured as a pulse or frequency output. Various functions are available in this function group depending on the variable selected.</p> <div>  <div> CANCEL PULSE FREQUENCY </div> </div> <div>  <p>Display showing which flow variable is assigned to the pulse output.</p> </div>
PULSE VALUE	<p>Every output pulse is assigned a flow quantity. By means of an external counter the sum of these pulses can be totalised and the total quantity determined since the start of measurement.</p> <p>Note! This function is only available if the setting "PULSE" is selected in the function "OPERATION MODE"</p> <div>  <div> 5-digit number with floating decimal point, incl. units (e.g. 240.00 dm³/p) </div> </div> <div>  <p>Display showing which flow variable is assigned to the pulse output.</p> </div>
















Function group PULS / FREQ. OUTPUT	
PULSE WIDTH	<div>The maximum pulse width can be set for example for external counter with max. possible input frequency. The pulse width is limited to the set value.</div> <div>Note! This function is only available if the setting "PULSE" is selected in the function "OPERATION MODE" (see page 57).</div> <div><div><div></div><div></div></div>3-digit number with fixed decimal point (0.05...2.00 s) Factory setting: 0.25 s</div> <div><div><div></div><div></div></div>Display: $T/2 < \text{PULSE} \implies \text{PULSE/PAUSE} = 1:1$ If the frequency resulting from the selected pulse value and current flowrate is too high ($T/2$ selected pulse width B), the pulses emitted are automatically reduced to half a cycle. The pulse/pause ratio is then 1:1 (see figure below).</div> <div><div><div><div>$T/2 > B$</div><div></div></div><div><div>$T/2 \leq B$</div><div></div></div><div>ba044y32</div></div><div>B = Pulse width (The above figure applies to positive pulses)</div><div>Example: Pulse width B = 1 second<ul style="list-style-type: none">For T = 3 s → Pulse width = 1 s; pause = 2 sFor T = 1 s → Pulse width = 0.5 s; pause = 0.5 s</div></div>

Function group PULS / FREQ. OUTPUT	
FULL SCALE FREQ.	<div><p>The full scale frequency (2...10,000 Hz) can be set. The value for this variable is defined in the function "FULL SCALE" (see page 60).</p><p>Note!</p><ul style="list-style-type: none">• This function is only available if the setting "FREQUENCY" is selected in the function "OPERATION MODE" (see page 57).• An extension up to 163% of the selected full scale frequency is possible.</div> <div><div><div><div></div><div></div></div><div></div></div><div>max. 5-digit number (2...10'000 Hz) Factory setting: 10000 Hz</div></div> <div><div><div><div></div><div></div></div><div></div></div><div>Display: $T/2 < 2s \implies \text{PULSE/PAUSE} = 1:1$</div><div><p>In the FREQUENCY mode the output signal is symmetrical (pulse/pause ratio = 1:1). At low frequencies the pulse duration is limited to max. 2 seconds i.e. the pulse/pause ratio is no longer symmetric (see figure below).</p><div><div><div>$T/2 < 2s$</div></div><div><div>$T/2 > 2s$</div></div></div><div>ba04y33</div></div><div><p>The above figure applies to positive pulses.</p></div></div>



Note!

Function group PULS / FREQ. OUTPUT	
<div> <div>ZERO SCALE</div> <div>or</div> <div>FULL SCALE</div> </div> <div>  <div>Note!</div> </div>	<div> <p>With these two functions the following values can be set for the measured variables assigned to the output:</p> <ul style="list-style-type: none"> 0 Hz → <i>zero scale value</i> of the measured variable End frequency → <i>full scale value</i> of the measured variable <p>The measuring range required is defined by the zero scale value and full scale value.</p> <p>Note!</p> <ul style="list-style-type: none"> This function is only available if the setting "FREQUENCY" is selected in the function "OPERATION MODE" (see page 57). The zero scale value cannot be larger than the full scale value. The full scale value cannot be smaller than the zero scale value. The span between the zero and full scale value should not fall below a minimum value. <div> <div>Full scale frequency [%]</div>  <div>ba044y34</div> </div> <div> <div>Zero scale</div> <div> <div></div> <div>5-digit number with floating decimal point (e.g. 0.5700 dm³/s)</div> </div> <div> <div>Full scale</div> <div> <div></div> <div>5-digit number with floating decimal point according to variable (e.g. 1.85 dm³/s)</div> </div> <div> <div></div> <div>Display showing which measured variable is assigned to the frequency output.</div> </div> </div> </div> </div>

Function group PULS / FREQ. OUTPUT	
OUTPUT SIGNAL	<div><p>The pulse/frequency output can be configured as required, for example for an external counter.</p><p>ACTIVE: Internal power supply used (+24 V). PASSIVE: External power supply required.</p></div>
	<div><div><p>ACTIVE</p><p>24 V DC internal power supply</p><p>20</p><p>21</p><p>Short circuit-resistance output</p><p>15783</p><p>e.g. mechanical counter</p><p>Recommended:</p><ul style="list-style-type: none">– for high output frequencies and– a continuous flow up to 25 mA ($I_{max} = 250\text{ mA}$ for 20 ms)</div><div><p>ACTIVE POSITIVE pulses</p><p>24 V</p><p>0 V</p><p>U</p><p>t</p><p>B</p></div><div><p>ACTIVE NEGATIVE pulses</p><p>24 V</p><p>0 V</p><p>U</p><p>t</p><p>B</p><p>B = Pulse width</p></div></div> <div><p>PASSIVE</p><p>Open Collector</p><p>20</p><p>21</p><p>External power supply $U_{max} = 30\text{ V DC}$</p><p>15783</p><p>e.g. electronic counter or PLC</p><p>Recommended:</p><ul style="list-style-type: none">– for low output frequencies and– a continuous flow up to 25 mA ($I_{max} = 250\text{ mA}$ for 20 ms)</div> <div><p>PASSIVE NEGATIVE pulses</p><p>Transistor</p><p>conductive</p><p>non-conductive</p><p>t</p><p>B</p></div> <div><p>PASSIVE POSITIVE pulses</p><p>Transistor</p><p>conductive</p><p>non-conductive</p><p>t</p><p>B</p><p>B = Pulse width</p></div> <div><div><div><div></div><div></div></div><div>CANCEL</div></div><div><div><div></div><div></div></div><div>PASSIVE-POSITIVE</div></div><div><div><div></div><div></div></div><div>PASSIVE-NEGATIVE</div></div><div><div><div></div><div></div></div><div>ACTIVE-POSITIVE</div></div><div><div><div></div><div></div></div><div>ACTIVE-NEGATIVE</div></div></div> <div><div><div><div></div><div></div></div><div>+</div><div>-</div></div><div>Display: PASSIVE = OPEN-COLL or ACTIVE = PUSH-PULL (see above figures for details)</div></div>



Note!



Note!

Function group PULS / FREQ. OUTPUT	
<div> <div> <div> <div>+</div> <div>-</div> </div> </div> <div> <div>+</div> <div>-</div> </div> </div>	<div> <div> <div> <div>+</div> <div>-</div> </div> </div> <div> <div>+</div> <div>-</div> </div> </div>


Function group RELAY		
RELAY 1 or 2 FUNCTION	Selection or assignment of relay function.	
	Caution!	
	<ul style="list-style-type: none">Take into account information on pages 64 and 65 on the relay switching response.For safety reasons we recommend configuring Relay 1 or relay 2 as the error output and to define the failsafe mode of the outputs (see pages 56 and 62).	
	<div><div><div>+</div><div>-</div></div><div>CANCEL</div></div>	
	OFF	Relay switched off
	ON	Relay switched on, but without function assignment, e.g. for test purposes
	FAILURE *	(Instrument as well as CH1 and CH2)
	FAILURE CH1 (applies to IN1&2 2M.POINTS)	(Instrument as well as CH1)
	FAILURE CH2 (applies to IN1&2 2M.POINTS)	(Instrument as well as CH2)
	DUAL RANGE MODE. DUAL RANGE MODE. 2	Registering active full scale value (1 / 2) of current output 1 or 2
	FLOW DIRECTION (applies to IN1&2 1M.POINT)	Registering flow direction (forward/reverse). On unidirectional measurement the relay also switches in the negative flow direction.
	FLOW DIRECT. CH1	Registering flow direction Channel 1
	FLOW DIRECT. CH2 (applies to IN1&2 1M.POINT and IN1&2 2M.POINTS)	Registering flow direction Channel 2
	CALC.VOLUME FLOW VOLUME FLOW CH1** VOLUME FLOW CH2 AVE. SOUND VELOC. (applies to IN1&2 1M.POINT)	} Registering if present limit value is outside range
	SOUND VELOC. CH1 SOUND VELOC. CH2 SIGNAL STRENGTH CH1 SIGNAL STRENGTH CH2	
	NET FLOW TOTAL FLOW (applies to IN1&2 2M.POINTS)	
	* Factory setting Relay 1 ** Factory setting Relay 2	
	Note!	
<ul style="list-style-type: none">Specifications such as how the plug-in jumper on the communication board is to be set are found in the Section Commissioning on page 27NET FLOW and TOTAL FLOW require that low flow cut off and the direction is set to the same value for both channels.		







Note!

Function group RELAY	
<div> <div>RELAY 1 or 2</div> <div>ON_VALUE</div> </div> <div>or</div> <div> <div>RELAY 1 or 2</div> <div>OFF-VALUE</div> </div>	<p>If you have configured the relay for "LIMIT" or "FLOW DIRECTION" you can define the necessary switching points in this function. If the respective measured value reaches these present values, the relay will switch as shown in the figures below.</p> <p>Note! The value for the switch-on point can be larger or smaller than for the switch-off point. A negative switch-on or switch-off point may be entered.</p> <p>Relay → FLOW DIRECTION The value entered in the function "SWITCH-ON POINT REL" also defines the switch-on point for the positive andnegative flow direction. If the switching point entered is for example 1 dm³/s, the relay de-energises at and energises again at -1 dm³/s and energises again at +1 dm³/s. If a direct switchover is required (no hysteresis), then set the switching point to the value "0". If creep suppression is activated (see page), then it is recommended that the hysteresis is set to a value either larger or the same as the low flow cutoff.</p> <div> <div> <div>a → Relay energised</div> <div>b → de-energised</div> </div> </div> <p>Relay → LIMIT (volumetric flow) The relay switches as soon as the actual measured variable moves outside the limits of a specific switching point.</p> <p>Applications: monitoring flowrate.</p> <div> </div> <div> <div> <div>+</div> <div>-</div> </div> <div> 5-digit number with floating decimal point, incl. units (e.g. 2.5800 dm³/s) Factory settings: at flow direction 2 l/s at volumetric flow 20 l/s </div> </div> <div> <div> <div>+</div> <div>-</div> </div> <div>Display showing which function is assigned to particular relay.</div> </div>








Assignment Relay 1 or 2	Relay contacts	
	Energised	De-energised
NO contact (Normally Open contact)		
NC contact (Normally Closed contact)		
Failure FAILURE CH1 FAILURE CH2	System OK 	 Failure: System error, power failure, etc.
DUAL RANGE MODE 1 DUAL RANGE MODE 2		
FLOW DIRECTION FLOW DIRECT. CH1 FLOW DIRECT. CH2	forward 	reverse
RELAY 1 OFF-VALUE RELAY 2 OFF-VALUE	Switch-off point not above or below set value 	Switch-off point above or below set value



Note!
This page describes relay configurations produced by the factory setting with the plug-in jumper on page 29.

Function group DISPLAY	
ASSIGN LINE 1 or 2	<p>Select the measured variables which are to appear during normal measuring operation in the various lines of the display (1 or 2).</p> <p>  CANCEL OFF (only ASSIGN LINE 2) CALC .VOLUME FLOW VOLUME FLOW CH1* VOLUME FLOW CH2 AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 SIGNAL BAR CH1 (Signal strength as bargraph) SIGNAL BAR CH2 (Signal strength as bargraph) TOTALIZER 1** TOTAL. 1 OVERFLOW TOTALIZER 2 TOTAL. 2 OVERFLOW NET FLOW TOTAL FLOW </p> <p>* Line 1 ** Line 2</p> <p>Note! NET FLOW and TOTAL FLOW require that low flow cut off and the flow direction is set to the same value for both channels.</p>
DISPLAY DAMPING	<p>Selecting a time constant for damping the display. Selecting a time constant determines whether the display reacts quickly (small time constant τ) or slowly (large time constant τ).</p> <p>Note! Damping is inactivated when set to zero. The time constant does not affect the response of the outputs.</p> <p>  max. 2-digit number, incl. units setting: Factory setting: 5 s </p>
FORMAT FLOW	<p>Selecting the number of decimal places of all measured variables and parameters of flow rates. The decimal places calculated by the Prosonic Flow DMU 93 cannot always be shown as they depend on the settings and the engineering unit selected. The number of decimal places selected here, however, only affects the display, not the internal calculation accuracy of the system! If the measuring system calculates on the basis of more decimal places than are shown, then an arrow symbol is displayed between the numerical value and measuring unit (e.g. 1.2 → m³/h).</p> <p>  CANCEL - XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXX </p>
FORMAT TOTALIZER	<p>Selecting the number of decimal places of the totalizer displays. The decimal places calculated by the Prosonic Flow DMU 93 cannot always be shown as they depend on the settings and the engineering unit selected. The number of decimal places selected here, however, only affects the display, not the internal calculation accuracy of the system! If the measuring system calculates on the basis of more decimal places than are shown, then an arrow symbol is displayed between the numerical value and measuring unit (e.g. 1.2 → m³).</p> <p>  CANCEL - XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXX </p>



Function group DISPLAY	
LCD CONTRAST	<p>The display contrast can be optimally adjusted to match prevailing operating conditions on site, e.g. daylight, ambient temperature (the contrast is dependent on temperature).</p> <p>Caution! In cases of low temperatures the visibility of the LCD is no longer assured. The display contrast is at a maximum if the  are simultaneously pressed when starting up the flowmeter.</p> <div>  <div>  <p>Any change in contrast is immediately seen with the adjustable bar graph.</p> </div> </div>
LANGUAGE	<p>Selecting the appropriate language in which all text, parameters and operating messages are to be displayed.</p> <p>Note! “ENGLISH” is selected if the  keys are simultaneously pressed when starting up the Prosonic Flow DMU 93.</p> <div>  <div> <p>CANCEL – ENGLISH – DEUTSCH – FRANCAIS – ESPANOL – ITALIANO – NEDERLANDS – DANSK – NORSK – SWENSKA – SUOMI – BAHASA INDONESIA – JAPANESE</p> </div> </div>
DISPLAY TEST	<p>Display operations can be certified with this function. The following displays are visible on all lines throughout the test:</p> <ol style="list-style-type: none">  888888888888888888 _____ 0000000000000000 <div>  <div> <p>CANCEL – START</p> </div> </div>



Caution!





Note!









Caution!



Note!






Function group W.THICKNESS CH1 or CH2	
MODE	<p>Selecting whether flow, longitudinal sound velocity, or the wall thickness is to be measured. After determining the wall thickness switch over again to the flow measurement mode (OFF).</p> <p>Caution! After a power failure or a restart of the measuring system, flow is always measured.</p> <p>  CANCEL OFF (flow measurement) SOUND VEL. LONGI WALL THICKNESS </p> <p>Note! During "WALL THICKNESS MEASUREMENT" the longitudinal sound velocity or the wall thickness is shown in the HOME position in the first line and the signal strength is shown as a bar graph in the second line. Signals from the current output, pulse output, frequency output of the totalizer and displays go into the quiescent mode.</p> <p>System responses in special cases: In version IN1&2 1M.POINT a single channel failure response is available. If one channel fails or wall thickness measurement is activated, then the operating channel is duplicated to the other channel. Only when both channels are defective does the instrument show a fault.</p> <p>For versions INSERTION CH1 and IN1&2 2M.POINTS the output corresponds to the assigned outputs of the appropriate channel:</p> <ul style="list-style-type: none"> – Current outputs → 0 mA or 4 mA – Pulse / frequency output → fall-back level – Totalizer → stop – Relay 1 or 2 → energise (exceptions Off, Fault, Fault CH1, Fault CH2, i.e. fault detection can still be carried out) <p>With the wall thickness sensor, the wall thickness can be determined if the sound velocity of the pipe is known or the sound velocity of the pipe can be determined if the wall thickness is known.</p>
PIPE MATERIAL (used for the selection WALL THICKNESS)	<p>Selecting the pipe material since ultrasonic waves pass through different pipe materials at different velocities. The longitudinal sound velocities of the most important materials are stored in the communications module and do not have to be entered separately. Select from the following materials.</p> <p>  CANCEL – CARBON STEEL – STAINLESS STEEL – HASTELLOY C – PA – PE – LDPE – HDPE – PP – PVC – PTFE – PVDF – ABS – GLASS FLINT – GLASS PYREX – GLASS CROWN – OTHERS </p>






Function group W.THICKNESS CH1 or CH2	
SOUND VEL. LONGI (used for the selection WALL THICKNESS)	<p>Determining the longitudinal sound velocity in the pipe material. If the pipe material does not agree with a previous function field then the sound velocity can be entered here manually (otherwise the corresponding sound velocity will be adopted for the material).</p> <p> max. 4-digit number without decimal point, incl. unit (m/s) Factory setting: 5900 m/s</p> <p>Note! If none of the pipe material corresponds to your application, then by using the wall thickness sensor, the sound velocity of the pipe material can be determined as follows: If the pipe flange is accessible and it is the same as the pipe material, you can determine the value of the pipe material from the thickness of the flange.</p>
REFERENCE VALUE (used for the selection SOUND VEL. LONGI)	<p>Entering the pipe thickness as basis for measuring the longitudinal sound velocity.</p> <p> max. 2-digit number with two decimal points, incl. unit Factory setting: 5.00 mm</p> <p>Range: lower limit 1.5 mm, upper limit 75.00 mm</p>
SIG. STRENGTH BARG	<p>Display of signal strength as a bar graph.</p> <p></p> <p>  Display of longitudinal sound velocity or wall thickness.</p>
SOUND VEL. LONGI. (display only) (used for the selection SOUND VEL. LONGI)	<p>Display of longitudinal sound velocity in pipe material.</p> <p>4-digit number, incl. unit</p>
WALL THICKNESS (used for the selection WALL THICKNESS)	<p>Display of the pipe thickness determined through measurement.</p> <p>max. 2-digit number with max. two decimal places, incl. unit</p>
CALIBRATION	<p>Adjusting (calibrating) the sensor for measuring the pipe thickness using the calibration unit supplied. This is carried out as follows: Hold the sensor on the calibration unit, select the function START and then press "Enter" The procedure is completed as soon as the message "Entry stored" appears for a few seconds.</p> <p> CANCEL START</p>





Note!



Function group INSERTION CH1 or CH2	
PIPE DIAMETER	<p>Entering the outer diameter of the pipe.</p> <p> max. 4-digit number with two decimal places, incl. unit Factory setting: 88.9 mm</p> <p>Note! The pipe circumference is automatically calculated by the program when the pipe diameter is entered.</p>
CIRCUMFERENCE	<p>Entering the pipe circumference if the outer diameter of the pipe is not given.</p> <p> max. 4-digit number with two decimal places, incl. unit Factory setting: 279.3 mm</p> <p> Displaying the pipe diameter.</p> <p>Note! The pipe diameter is automatically calculated by the program when the pipe circumference is entered.</p>
WALL THICKNESS	<p>Entering the wall thickness of the piping.</p> <p> max. 2-digit number with two decimal places, incl. unit Factory setting: 2.60 mm</p>
VISCOSITY	<p>By entering the viscosity an improvement of the accuracy / linearity in applications with lower Reynolds Numbers (<10,000) or higher viscosities (>10 cSt) can be achieved.</p> <p> max. 4-digit number with floating decimal point, incl. unit Factory setting: 1.000 mm²/s</p>

Function group SENSOR DATA CH1 or CH2	
SENSOR TYPE	<p>Selecting the sensor type depending on the application. The information is found on the nameplate of the sensor.</p> <p> CANCEL – W1LIA-W_S08</p>
CABLE LENGTH	<p>Entering the cable length to be used to connect sensors and transmitter. This affects the compensation for data loss. Choose between 5 m, 10 m, 15 m and 30 m</p> <p> max. 3-digit number with one decimal place, incl. unit Factory setting: 5.0 m</p>
TRAVERSES (display only)	<p>Displaying the traverses, (i.e. how often the sound wave is to pass through the fluid). The insertion version has only one traverse.</p>
SENSOR DISTANCE (display only)	<p>Displaying the sensor distance for mounting the ultrasonic sensors. The length of distance is the path along the piping surface from the centre of the 1st sensor holder to its corresponding sensor holder. This value is given when doing a QUICK SETUP.</p> <p>max. 5-digit number (e.g. 375 mm)</p>
DEV. SENSOR DISTANCE	<p>Entering the deviation between the sensor distance given by the instrument in QUICK SETUP and the actual sensor distance after insertion. Using this deviation, the transmitter calculates the correct sonic path. The deviation is negative if the actual sensor distance is smaller than the calculated value and positive if it is larger.</p> <p> max. 3-digit number with one decimal place, incl. unit Factory setting: 0.0 mm</p>
ARC LENGTH (display only)	<p>Displaying the length of arc for mounting the ultrasonic sensor for a dual path version (IN 1&2M.-POINTS). The length of arc is the path along the piping surface from the centre of the 1st sensor holder to its corresponding sensor holder. This value is given when doing a QUICK SETUP.</p> <p>max. 5-digit number (e.g. 115 mm)</p>
DEV. ARC LENGTH	<p>Entering the deviation between the path given by the instrument in QUICK SETUP and the actual path after insertion. The transmitter calculates the correct sonic path using this deviation. The deviation is negative if the actual path is smaller than the calculated value and positive if it is larger.</p> <p> max. 3-digit number with one decimal place, incl. unit Factory setting: 0.0 mm</p>
PATH LENGTH (display only)	<p>Displaying the path length for mounting the sensor at the correct distance, (see Page 17 , Step 2 and 3). The path length is the distance between the surface of the two sensor holders along the sonic path.</p> <p>max. 5-digit number incl. unit (z.B. 885 mm)</p>
DEV. PATH LENGTH	<p>Entering the deviation between the path length given by the instrument in QUICK SETUP and the actual path length after insertion. The transmitter calculates the correct sonic path using this deviation. The deviation is negative if the actual path length is smaller than the calculated value and positive if it is larger.</p> <p> max. 3-digit number with one decimal place, incl. unit Factory setting: 0.0 mm</p>



<div> <div>Function group</div> <div>PROCESS. PARA. CH1 (INSERTION CH1 and IN1&2 2M.POINTS)</div> <div>Function group PROCESSING PARA. (IN1&2 1M.POINT)</div> <div>Function group PROCESSING PARA. CH2 (IN1&2 2M.POINTS)</div> </div>	
<div>LOW FLOW CUTOFF</div>	<div> <div> <div> <div>Set the desired switching points for creep suppression. The creep suppression prevents the flow rate from being registered in the lowest measuring range, e.g. a variable column of liquid at standstill. When creep suppression is active, the sign of the flow appears optically inverted on the display.</div> <div> <div> <div>Q (mass/time)</div> <div> <div> <div>Hysteresis = -50% of creepage</div> <div>1 = switch-on point</div> <div>2 = switch-off point</div> </div> </div> <div> <div> <div>Creepage</div> <div>100%</div> <div>50%</div> </div> <div> <div>t</div> </div> </div> <div> <div>Suppression active</div> <div>Suppression active</div> </div> </div> </div> <div> <div> <div> <div>5-digit number with floating decimal point (e.g. 25.000 dm³/min)</div> <div>Factory setting: 0.4 l/s</div> </div> <div> <div> <div>HYSTERESIS = 50%</div> <div>Creep suppression operates with a negative hysteresis of 50% (see above figure).</div> </div> </div> </div> </div></div></div></div>
<div>MEASURING MODE</div>	<div> <div> <div>Selecting whether the system measures in both directions or in one direction only.</div> <div>The measuring can measure in both flow directions, i.e. bi-directional.</div> <div>The signal outputs (current output 1, current output 2, pulse/frequency output, totalizer) can, if assigned for volume units, be switched to unidirectional mode; i.e. a signal will only be given if flow is in the positive direction.</div> </div> <div> <div> <div>CANCEL – UNIDIRECTIONAL – BIDIRECTIONAL</div> </div> </div> </div>
<div>FLOW DIRECTION</div>	<div> <div> <div>Selecting the flow direction.</div> <div>The arithmetical sign of the volume flow can be changed.</div> </div> <div> <div> <div>CANCEL – FORWARD – REVERS</div> </div> </div> </div>

Function group SIGNAL CH1 or CH2	
SIG.STRENGTH BAR	<div>Display of signal strength as a bar graph.</div> <div></div> <div> Signal strength as a number.</div>
SIGNAL STRENGTH	<div>Display of signal strength as a number.</div> <div>Display: 0...100</div> <div>Prosonic Flow needs a signal strength greater than 35 to achieve a correct measurement.</div>

Function group CALIBR. DATA CH1 or CH2	
CORR. FACTOR	<p>Volumetric flow is corrected in this function. The volumetric flow can be multiplied by a factor for correction purposes.</p> <div> <div> <div>+</div> <div>-</div> </div> <div> 5-digit number with four decimal places, dimensionless (0.5000...2.0000) Factory setting: 1.0000 </div> </div>
ZEROPOINT	<p>The actual zero point correction used by the transmitter can be called up or changed manually in this function if required.</p> <div> <div> <div>+</div> <div>-</div> </div> <div>max. 4-digit number (-1000 ns...+1000 ns)</div> </div> <div> <div> <div> <div>↕</div> <div>+</div> <div>-</div> </div> </div> <div>Display of actual run time difference measured by the system.</div> </div>
ZEROPOINT ADJUST	<p>A zero point adjustment can be automatically carried out in this function. The new zero point determined by the measuring system is adopted by the function "ZEROPOINT".</p> <p>Note!</p> <ul style="list-style-type: none"> • Programming is locked during zero point adjustment and the display shows "S: ZERO ADJUST CH1" or "CH2 RUNNING". • If the zero point adjustment is not possible (e.g. with flow velocity $v > 0.1$ m/s) or has been cancelled, then the alarm message "A: ZERO ADJUST CH1" or "CH2 NOT POSSIBLE" will appear. • The selection "UNDO" means that the previously set value before adjustment is again used. • After a successful zero point calibration the new zero point value can immediately be called up with the diagnosis function (<div>↕</div> <div>+</div> <div>-</div> press simultaneously). <p>The value in the function ZERO POINT is overwritten.</p> <div> <div> <div>+</div> <div>-</div> </div> <div>CANCEL – START – UNDO</div> </div> <div> <div> <div> <div>↕</div> <div>+</div> <div>-</div> </div> </div> <div>Display showing the zero point used by the measuring system.</div> </div> <p>For a detailed procedure for carrying out zero point adjustment see section Commissioning on page 27.</p>














Note!

Function group COMMUNICATION	
PROTOCOL	<p>Various data transmission protocols are available for digital communication which can be activated or switched off in this function.</p> <p>Note! The HART protocol can only be switched on if the current output current output 1 is set to "4–20 mA or 4–20 mA (25 mA)".</p> <p> CANCEL – OFF – HART</p>
BUS ADDRESS	<p>Selecting the bus address for data transmission with HART protocol.</p> <p>Note! The current output is set to 4 mA if the address is not set to the value "0".</p> <p> 2-digit number (HART: 0...15) Factory setting: 0</p>
TAG NUMBER	<p>Display of the actual measuring point tag (name, max. 8 places). This can be only entered over the serial interface.</p> <p>Note! This function is only available if the function "PROTOKOLL" is set to "HART".</p> <p>Character field with 8 places Factory setting: REINACH</p>
TAG NUMBER CH2 only for version: IN1&2 2M.POINTS	<p>Display of actual measuring point tag (name, max. 8 places) of Channel 2. This can be only entered over the serial interface.</p> <p>Note! This function is only available if the function "PROTOCOL" is set to "HART".</p> <p>Character field with 8 places Factory setting: REINACH</p>





Function group SYSTEM PARAMETER	
PRESENT SYSTEM CONDITION	<p>All error and status messages which occur while measurement is in progress can be called up according to their priority. Error and status messages are displayed in the HOME position alternately with the actual measurement variable.</p> <p>Note!</p> <ul style="list-style-type: none"> By pressing the diagnosis keys  in the HOME position there is automatically a jump to this function. A complete listing of all possible system, process errors and status messages is given on page 81 ff. <p> Calling up other current errors or status messages: "+" → messages with higher display priority "-" → messages with lower display priority When the listing is complete the display shows the message "END OF LIST".</p> <p> When a system error occurs you can also call up error descriptions by pressing the diagnosis function again. In such cases a diagnosis symbol (stethoscope ) is visible.</p>
PREVIOUS SYSTEM CONDITIONS	<p>All process errors and status messages that have occurred so far are listed in chronological order (error history max. 15 entries).</p> <p>Note!</p> <ul style="list-style-type: none"> A complete list of all possible error and alarm messages is given on page 81ff. If no error or status messages have occurred since the measuring system was last started up then the display shows the message "S: NO ENTRY EXISTING". With more than 15 entries the oldest is overwritten. Storage of this list is volatile and is lost if there is a power failure. <p> Calling up other system/process errors and errors and status messages: "+" Listing is done chronologically with the oldest, second oldest ... etc. message "-" Listing is done chronologically with the latest, second latest ... etc. message. When listing is complete the display shows the message "END OF LIST".</p>
ACCESS CODE	<p>Entering the code number to release the programming via local operation. All data of the Prosonic Flow measuring system are protected against any inadvertent changes.</p> <p>If you press the  operating keys and the operating matrix is still locked, this function is automatically displayed with the request to enter the code: → Enter code number 93 (factory setting) or → Enter personal code number</p> <p>Note!</p> <ul style="list-style-type: none"> After return to the HOME position programming is again locked after 60 seconds if no operating element is pressed during this time. Programming can also be locked by entering any number in this function but not the customer code. If you can no longer find your personal code number, then the Endress+Hauser service organisation will be pleased to help you. <p> max. 4-digit number (0...9999) Factory setting: 0</p>

Function group SYSTEM PARAMETER	
DEF. PRIVATE CODE	<p>Entering a personal code number with which programming can be enabled.</p> <p>Note!</p> <ul style="list-style-type: none"> • Programming is always enabled with the code number "0". • When programming is locked this function is not available and access to the personal code number by third parties is not possible. • The code number can only be altered when programming has been enabled. <p> max. 4-digit number (0...9999) Factory setting: 93</p>
POS. ZERO RETURN	<p>This function enables signals to be set from the current, pulse/frequency output to the fallback value, e.g. for interrupting the measurement for cleaning the piping. During this time the following applies:</p> <ul style="list-style-type: none"> • Current output → set to 0 mA or 4 mA • Pulse/frequency output → at the fallback value • Display flow → 0 • Display totalizers → Remain at the last applicable value. <p>Note!</p> <ul style="list-style-type: none"> • This function has top priority above all other functions of the instrument. Simulations, for example are suppressed. • After positive zero return is activated, the display shows the message (HOME position) "S: POS. ZERO-RET. ACTIVE" or "S: POS. ZERO-RET. ACTIVE CH1 or CH2". • During positive zero return the relays are energised (except for OFF). Any error messages occurring, such as fault or alarm, can then only be called up using the diagnosis function or in the function "PRESENT SYSTEM CONDITION": These do not however affect the outputs. <p> CANCEL – OFF – ON – CHANNEL CH1* – CHANNEL CH2*</p> <p>*In version IN1&2 2M.POINTS only</p> <p> ALL SIGNALS SET TO ZERO (for description see above)</p>
SOFTWARE VERSION	<p>Display of the current software which is installed in the amplifier. The numbers version have the following meaning:</p> <p>V 1 . 01. 00 (amplifier)</p>  <ul style="list-style-type: none"> V 1 : Number changes if minor alterations are made to the new software version. 01 : Number changes if the new software contains additional functions. 00 : Number changes if basic alterations have to be made to the software, e.g. owing to technical modifications to the instrument.



Note!



Note!



Note!

8 Trouble-shooting, Repair and Maintenance

8.1 Response of the measuring system on fault or alarm

Error indications which occur during operation are indicated in the HOME position alternately with the measured values. Prosonic Flow DMU 93 recognises two types of error:

Type of error	Response of the instrument
Fault (failure) Errors due to failure of the instrument	<ul style="list-style-type: none"> Error message displayed → see page 81 Relay 1/2 dead (for "FAILURE" and "FAILURE CH1 or CH2") → see page 63 Signal outputs respond according to the set failsafe mode → see page 56 and 62
Alarm (process error) Error due to process conditions	<ul style="list-style-type: none"> Alarm message displayed → see page 83 Response of relays according to configuration → see page 63

Redundant response on fault

For two-channel measurement at one measuring point (IN1&2 1M.POINT) the following is to be noted:

- If one channel fails or wall thickness measurement is activated, then the operating channel is duplicated to the other channel (for examples see page 46). The fault message is however shown.
- The instrument enters into fault mode with two defective channels.

Caution!

Please note the following points on active **positive zero return** or active **simulation**:



Positive zero return (PZR)


- This function has top priority above all other instrument functions. Simulations, for example, are suppressed.
- After activating PZR the display shows the message "S: POS. ZERO-RET. ACTIVE".
- During positive zero return all relays are energised, except in the option "OFF". Any error messages occurring (fault, alarm) can then only be called up using the diagnostic function or in the function "PRESENT SYSTEM CONDITION". These do not, however, affect the outputs.
- Positive zero return (IN1&2 2M.POINTS) is possible for separate channels.

Simulation











- This function has the second highest priority, just as the related status messages. Any error messages occurring during this time can only be called up and shown using the diagnostic function.
- Normal output of system error if Relay 1 is configured for fault output. Normal function of the remaining relays (according to configuration).










8.2 Diagnosis flow chart and trouble-shooting

All instruments undergo various stages of quality control during production. However should an error or fault occur during set-up or operation, then refer to the flow chart below to identify possible causes.




8.3 Error and alarm messages

Error message F: (System error)	Cause Call up by 	Remedy
F: SYSTEM ERROR AMPLIFIER	<p> : EEPROM FAILURE</p> <p>Error on access to EEPROM data.</p> <p> : RAM FAILURE</p> <p>Error on access to working memory (RAM) of the processor.</p> <p> : ASIC FAILURE</p> <p>Error on access to AISIC of amplifier.</p>	<p>Replace amplifier board (see Chap. 8.6).</p> <p>Replace amplifier board (see Chap. 8.6).</p> <p>Replace amplifier board (see Chap. 8.6).</p>
F: SIGNAL CH1 or CH2 TOO LOW	<p> : NO DIAGNOSIS</p> <p>Damping of the acoustic measuring path too large.</p>	<ul style="list-style-type: none"> • The product possibly has a too high damping effect. • Check the distance between the sensors (mounting dimensions).
F: SOUND VELOCITY CH1 or CH2 OUT OF RANGE	<p> : NO DIAGNOSIS</p> <p>The sound velocities lie outside the measuring range.</p>	<ul style="list-style-type: none"> • Check the sensor distance (mounting dimensions). • Check - if possible - the sound velocity of the liquid by means of a pair of sound velocity sensors or see for specific literature. If the actual sound velocity is greater than 1800 m/s contact E+H Service.
F: SENSOR CH1 or CH2 DOWNSTREAM	<p> : NO DIAGNOSIS</p> <p>Connection between sensor and transmitter broken.</p>	<ul style="list-style-type: none"> • Check the cable connection between sensor and transmitter. • Check whether the plug has been inserted right to the mechanical stop. • The sensor is possibly defective. • Wrong sensor connected.
F: SENSOR CH1 or CH2 UPSTREAM	<p> : NO DIAGNOSIS</p> <p>Connection between sensor and transmitter broken.</p>	<ul style="list-style-type: none"> • Check the cable connection between sensor and transmitter. • Check whether the plug has been inserted right to the mechanical stop. • The sensor is possibly defective. • Wrong sensor connected.
F: SYSTEM ERROR POWER SUPPLY	<p> : LOW VOLTAGE DETECTED</p> <p>The power supply board is supplying a too low voltage.</p>	<p>Replace power supply board. (see Chap. 8.6).</p>
F: NO AMPLIFIER RESPONSE	<p> : NO DIAGNOSIS</p> <p>Data transfer between amplifier and communications module not possible.</p>	<p>Restarting the measuring system may be required (switch off the power supply and then switch it on again)</p> <p>Otherwise change electronics module, see Chap. 8.6).</p> <p>(continued next page)</p>

Error message F: (System error)	Cause Call up by 	Remedy
F: VALUE NOT ACCEPTED	<p> : NO DIAGNOSIS</p> <p>An internally stored value cannot be read by the communications module.</p>	Restarting the measuring system may be required (switch off the power supply and then switch it on again) Otherwise change electronics module, see Chap. 8.6).
F: SYSTEM ERROR COM-MODUL	<p> : EEPROM FAILURE</p> <p>Error on access to EEPROM data (process and calibration data of communications module).</p> <p> : RAM FAILURE</p> <p>Error on access to working memory (RAM).</p> <p> : ROM FAILURE</p> <p>Error on access to program memory (ROM).</p> <p> : LOW VOLTAGE DETECTED</p> <p>DC/DC converter on the communications module is supplying a power voltage which is too low.</p> <p> : VOLTAGE REFERENCE</p> <p>Reference voltage of the communications module outside tolerance, i.e. correct functioning of the current output is no longer guaranteed.</p> <p> : EEPROM HW DATA ERROR</p> <p>A part of the EEPROM data of the communications module is damaged or has been overwritten. Default values from the ROM are written in. The measuring system can still operate on a makeshift basis using these values.</p> <p> : SENSOR CONFIG. NOT POSSIBLE</p> <p>Incompatibility of Com-modules by mixing V1.01.00 with amplifier board V1.00.00</p>	<p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p> <p>The amplifier version V1.00.00 does not work with INSERTION version.</p>

(continued on next page)

Error message F: (System error)	Cause Call up by 	Remedy
F: SYSTEM ERROR COM-MODUL (continued)	<p>🔧 : EEPROM PARA. DATA ERR</p> <p>A part of the EEPROM data of the communications module is damaged or has been overwritten. Default values from the ROM are written in. The measuring system can still operate on a makeshift basis using these values.</p> <p>🔧 : EEPROM TOT. DATA ERROR</p> <p>A part of the EEPROM data of the communications module (totalizer block) is damaged or has been overwritten. Default values from the ROM are written in. The measuring system can still operate on a makeshift basis using these values.</p>	<p>Replace Com-module (see Chap. 8.6).</p> <p>Replace Com-module (see Chap. 8.6).</p>
Alarm messages A: (Process error)	Cause	Remedy
A: CURRENT OUTPUT OVERFLOW	The actual measured value is outside the range preset by the scaled zero and full scale values.	Change scaled zero and full scale values (see page 53ff) or change measured variable.
A: FREQ. OUTPUT 1 OVERFLOW	The actual measured value is outside the range preset by the scaled zero and full scale values.	Change scaled zero and full scale values (see page 60ff) or change measured variable.
A: ZERO ADJT. CH1 or CH2 NOT POSSIBLE	The static zero point calibration is not possible or has been cancelled.	Check the flow velocity = 0 m/s (see page 74)

Status messages S:.....	Cause	Remedy
S: POS. ZERO-RET. ACTIVE	Positive zero return is activated. This message has highest priority for the PROSONIS FLOW DMU 93.	Not required
S: POS. ZERO-RET. ACTIVE CH1	Positive zero return is activated for Channel 1. This only applies to configuration: IN1&2 2M.POINTS.	Not required
S: POS. ZERO-RET. ACTIVE CH2	Positive zero return is activated for Channel 2. This only applies to configuration: IN1&2 2M.POINTS.	Not required
S: SENSOR CH1 INCOMPATIBLE	Incorrectly, the flow sensor was installed for measuring wall thickness.	Change round the flowmeter and wall thickness sensor.
S: SENSOR CH2 INCOMPATIBLE	Incorrectly, the flow sensor was installed for measuring wall thickness.	Change round the flowmeter and wall thickness sensor.
S: CURRENT OUTPUT SIMUL. ACTIVE	Current simulation is activated.	Not required
S: FREQ. OUTPUT SIMUL. ACTIVE	Frequency simulation is activated.	Not required
S: ZERO ADJT. CH11 or CH2 RUNNING	Static zero point calibration is running	Not required
S: W.STHICKN CH1 or CH2 RUNNING	Wall thickness measurement is activated	Not required
S: CALIBRATION CH1 or CH2 RUNNING	Calibration of wall thickness sensor is activated.	Not required
S: CALIBR. CH1 or CH2 NOT POSSIBLE	Calibration of wall thickness sensor not possible.	Sensor connection Calibration unit Coupling medium

8.4 Repair

Repairs can be carried out on the transmitter and the sensor. For exchange of the electronics module, the sensor element or other components, see page 86 or the spare parts catalog.

(For Order-No. see Technical Data on page 94).

8.5 Exchange of the instrument fuses

Warning!

- Danger of electric shock! Turn off the power supply before the transmitter housing is opened.
- For instruments with Ex approvals, instructions according to the separate Ex documentation is to be observed.



There are two instrument fuses:

- The first can be found on the wiring terminal board in the terminal compartment of the DMU 93 transmitter housing (see Fig. 30).
- The second can be found on the electronic module power supply board in the electronics compartment (behind the local display) of the DMU 93 transmitter housing.

Procedure:

1. Turn off the power supply.
2. Remove the electronics module as described on page 86.
Use only the following fuse types:
 - For 20...55 V AC / 20...62 V DC power supply:
2 A slow blow/250 V, switching capacity 1500 A; 5 x 20 mm
 - For 85...260 V AC:
1 A slow blow/250 V, switching capacity 1500 A; 5 x 20 mm
3. Slide the electronics module back into the transmitter housing and fasten.
4. Turn on the power supply again.




Fig. 30
Wiring compartment with
location of the fuse

8.6 Exchange of transmitter electronics



Warning!

- Danger of electric shock! Turn off the power supply before opening the transmitter housing.
- Danger of electronics component damage (ESD protection)! Use an anti-static work area with a grounded work surface.
- The local power voltage and frequency must correspond to the technical data of the power supply board in question.
- For Ex instruments, instructions according to the separate Ex documentation are to be observed.

Procedure:

- ❶ Turn off power supply.
- ❷ Loosen the Allen head screw holding the safety claw (3 mm Allen key).
- ❸ Unscrew the electronic compartment cover (glass cover) from the transmitter housing.
- ❹ Remove the local display:
 - a) Loosen the display module fastening screws.
 - b) Disconnect the display module flat cable from the communications module.
- ❺ Disconnect the power supply cables two-pole connector from the power supply PCB (while simultaneously depressing the connector locking mechanism).
- ❻ Disconnect the sensor cable connector from the amplifier PCB (while simultaneously depressing the connector locking mechanism).
- ❼ Remove the two PCB carrier plate screws. Carefully pull the carrier plate approx. 4...5 cm out of the transmitter housing. The complete transmitter electronics can now, together with the PCB carrier plate, be pulled completely out of the housing.
- ❽ The electronics module can now be separated (unscrewed) into the three components (power supply A, preamplifier B and Com-module C). Exchange the defective module or component.



Note!

When ordering PCBs, observe the order code in the form of a 500xxxxx number written on a label on the corresponding PCB. Use only those PCBs with the same order number.

After exchanging the transmitter electronics, reassembly is in reverse order.




Fig. 31
Exchange of the Prosonic Flow
DMU 93 transmitter electronics

8.7 Exchanging the sensor element

Procedure:

- Remove the plug **1** from the sensor cover **3**.
- The retaining ring **2** must now be removed. It sits on the upper edge of the sensor collar **6** and holds the sensor in place.
- Lift the sensor cover **3** and spring **4**.
- Remove the retaining ring **5**, which holds the sensor collar **6**.
- The sensor collar can now be removed. Some force may need to be applied.
- Remove the sensor element **7** from the holder **8** and replace.
- Reassemble the parts.




Fig. 32
Exchange of the sensor element

8.8 Maintenance

The Prosonic Flow system is maintenance-free.

9 Dimensions

Note!

Dimensions and weights given for the transmitter with Ex approvals may differ from those given in the specifications.
Please not therefore the separate Ex documentation.



Note!

Dimensions of single path version




Fig. 33
Dimensions Prosonic Flow
Single path version

Weights

Transmitter DMU 93 = 4.7 kg
Sensors DDU 15
Single path version = 4.5 kg

Dimensions dual path version




Fig. 34
Dimensions Prosonic Flow
Dual path version

Weights

Transmitter DMU 93 = 4.7 kg
Sensors DDU 15
Dual path version = 12.0 kg

10 Technical Data

Application	
<i>Instrument name</i>	"Prosonic Flow" ultrasonic measuring system
<i>Instrument function</i>	Prosonic Flow DMU 93 transmitter processes and displays measuring data supplied by the Prosonic Flow sensor DDU 15
Function and system design	
<i>Measuring principle</i>	Measuring system according to the ultrasonic transit time principle
<i>Measuring system</i>	The complete measuring system consists of: <ul style="list-style-type: none"> • Transmitter Prosonic Flow DMU 93 • Sensors Prosonic Flow DDU 15 Flow sensor (Insertion type)
General	
<i>Measured variables</i>	<ul style="list-style-type: none"> • Volumetric flow (proportional to time differential) • Sound velocity • Signal strength
<i>Measuring range</i>	Freely adjustable from 0...1 m/s to 0...15 m/s. DN [mm] Maximum measuring range 200 (4") 0...1.875 m ³ /h 1000 (40") 0...42.400 m ³ /h 2000 (80") 0...169.600 m ³ /h 2500 (98") 0...265.000 m ³ /h 3000 (120") 0...380.000 m ³ /h
<i>Operable flow range</i>	150 : 1
Outputs	
<i>Outputs</i>	<ul style="list-style-type: none"> • <i>Current output 1</i> 0/4...20 mA (also acc. to NAMUR recommendations), $R_L < 700 \Omega$ ($R_L > 250 \Omega$ with HART), freely assignable to different measured values (see page 53), time constant freely selectable (0.5...100.00 s), full scale value selectable, with HART protocol. • <i>Current output 2</i> 0/4...20 mA (also acc. to NAMUR recommendations), $R_L < 700 \Omega$, freely assignable to different measured values (see page 53), time constant freely selectable (0.5...100.00 s), full scale value selectable. • <i>Relay output 1</i> max. 60 V AC / 0.5 A or max. 30 V DC / 0.1 A NC or NO contact available Configurable for: fault, full scale switching, flow direction, limit values • <i>Relay output 2</i> max. 60 V AC / 0.5 A or max. 30 V DC / 0.1 A; NC or NO contact available Configurable for: fault, full scale switching, flow direction, limit values <p style="text-align: right;">(continued next page)</p>

Outputs (continued)	
<i>Outputs (continued)</i>	<ul style="list-style-type: none"> • <i>Pulse / frequency output</i> active / passive selectable, one measured variable freely assignable (see page 57) active: 24 V DC, 25 mA (250 mA for 20 ms), $R_L > 100 \Omega$, passive: 30 V DC, 25 mA (250 mA for 20 ms) <ul style="list-style-type: none"> – <i>Frequency output</i>: f_{End} selectable up to 10000 Hz, On / off ratio 1:1, pulse width max. 2 s – <i>Pulse output</i>: pulse weighting adjustable, pulse polarity adjustable, pulse width adjustable (50 ms...2 s). Above a frequency of $1/(2 \times \text{pulse width})$ the on / off ratio is 1:1
<i>Signal on alarm</i>	<p>The following applies until the fault has been cleared:</p> <ul style="list-style-type: none"> • Current output → failure mode selectable • Pulse / frequency output → failure mode selectable (coupled with totalisers) • Relay 1 or 2 → de-energised, if configured to fault detection failure mode selectable
<i>Load</i>	$R_L < 700 \Omega$ (current output) $R_L > 250 \Omega$ (current output with HART)
<i>Creep suppression</i>	<p>Selectable switch points for low flow cut-off (see page 72). Hysteresis: –50 %</p>
Accuracy (process data)	
<i>Reference conditions</i>	<p>Error limits based on ISO/DIN 11631</p> <ul style="list-style-type: none"> • +25...+35 °C, 2...4 bar • Calibration rig based on national standards
<i>Measured error</i>	<p>For flow velocities > 0.3 m/s and a Reynolds number > 10000 Dry calibration better than $\pm 2\%$ o.r. typical.</p> <ul style="list-style-type: none"> • Verification of accuracy: $\pm 0.5\%$ o.r. plus $\pm 0.05\%$ o.f.s. under reference conditions (stainless steel pipe and water) • Reference conditions: Pipe Insertion: <ul style="list-style-type: none"> Single path DN 250 Dual path DN 400 Pipe material Stainless steel Fluid Water Fluid temperature +30 °C <p>o.r. = of reading o.f.s. = of full scale (15 m/s)</p> • Repeatability: $\pm 0.4\%$
Operating conditions	
Installation conditions	
<i>Installation instructions</i>	For further details see page 11 ff
<i>Sensor cable length</i>	max. 30 m between sensors / transmitter, screened cable is to be used
Ambient conditions	
<i>Ambient temperature (transmitter)</i>	DMU 93 –20...+60 °C (An all-weather cover should be used to protect the housing from direct sunlight when mounting in the open. This is especially important in warmer climates and with high ambient temperatures).
<i>Ambient temperature (sensors incl. cable)</i>	DDU 15 –40...+80 °C

Operating conditions (continued)			
Storage temperature (sensors incl. cable)	Transmitter Sensor	DMU 93 DDU 15	−40...+80 °C −40...+80 °C
Degree of protection to EN 60529	Transmitter Sensors	DMU 93 DDU 15	IP 67 / (NEMA 4X) IP 68 / (NEMA 6P)
Shock resistance	according to IEC 68-2-31		
Vibrational resistance	up to 1 g, 10...150 Hz according to IEC 68-2-6		
Electromagnetic compatibility	According to EN 50081 Part 1 and 2 / EN 50082 Part 1 and 2 as well as to the NAMUR recommendations. Interference resistance to EN 61000-4-6; 3 V for sensor cable ≥ 30 m.		
Process conditions			
Fluid temperature	Sensors	DDU 15	−40...+80 °C
Nominal pressure	PN 16		
Pressure drop	not applicable		
Fluid properties	Homogenous liquid max. gas content <1% vol. max solid content <5% vol.		
Mechanical construction			
Design, dimensions (L x W x H)	Dimensional drawings → see page 89 and 90		
Weights	see page 89 and 90		
Materials	<ul style="list-style-type: none">• Transmitter Housing DMU 93:<ul style="list-style-type: none">– Powder coated die-cast aluminum• Sensor DDU 15:<ul style="list-style-type: none">– Sensor holderW1.4301 (AISI 304)– Sensor housing (wetted parts)W1.4435/1.4404 (AISI 316L)– Sensor housing (non-wetted parts)W1.4301 (AISI 304)– ConnectorW1.4301 (AISI 304)– Sensor cablePVC or PTFE		
Electrical connection	<ul style="list-style-type: none">• Wiring diagrams: see page 25 Transmitter cable entries: PG 13.5 (5...15 mm) cable gland or thread for cable glands ½" NPT, M20 x 1.5 (8...15 mm), G ½"• Galvanic isolation: All circuits for outputs, power supply and sensors are galvanically isolated from one another.• Cable specifications: The ready-to-use factory supplied cables are to be used for every pair of sensors. Connection of sensors / transmitter see page 26. Cables are available in PTFE or PVC.		

User interface																	
<i>Operation</i>	On-site operation: <ul style="list-style-type: none"> • 3 operating keys for interactive programming of all instrument functions in the instrument operating matrix (see page 31ff.) • Diagnosis and help function (→) 																
<i>Display</i>	LC display, illuminated, two 16-character lines																
<i>Communication</i>	<ul style="list-style-type: none"> • E+H Commuwin II (via HART protocol over a communications box, e.g. E+H Commubox FXA 191) • HART protocol via current output 																
Power supply																	
<i>Supply voltage</i> <i>Frequency</i>	<i>Transmitter:</i> 20... 55 V AC (50...60 Hz), 16...62 V DC 85...260 V AC (50...60 Hz) <i>Sensor:</i> <ul style="list-style-type: none"> • supplied by the transmitter 																
<i>Power consumption</i>	AC: <15 VA (incl. sensors) DC: <15 W (incl. sensors)																
<i>Power supply failure</i>	Bridges min. 1 power cycle (22 ms). <ul style="list-style-type: none"> • EEPROM saves measuring system data on power failure (no batteries required). 																
Certificates and approvals																	
<i>Ex approvals</i>	Information on available Ex versions (e.g. ATEX, CENELEC, FM, CSA) can be supplied by your E+H Sales Centre on request. All explosion protection data are given in separate documentation available on request.																
<i>CE mark</i>	By attaching the CE mark, Endress+Hauser confirms that the instrument has been successfully tested and fulfils all legal requirements of the relevant EC directives.																
Ordering																	
<i>Accessories</i>	<ul style="list-style-type: none"> • Post mounting for transmitter housing (Order No. 50076905) • Alignment tool (Order No. 50095132) • Alignment rod (Order No. 50094911) • Insertion depth adjustment tool (Order No. 50095088) • Spare sensor element (Order No. 50095133) 																
<i>Supplementary documentation</i> <i>Prosonic Flow</i>	<table> <tr> <td>System Information</td><td>SI 025D/06/en</td></tr> <tr> <td>Operating Manual Clamp On</td><td>BA 038D/06/en</td></tr> <tr> <td>Technical Information</td><td>TI 042D/06/en</td></tr> <tr> <td>Ex documentations:</td><td></td></tr> <tr> <td>ATEX/CENELEC</td><td>XA001D/06/ (II2G/Zone 1)</td></tr> <tr> <td>ATEX</td><td>XA002D/06/ (II3G)</td></tr> <tr> <td>FM</td><td>EX 042D/06/a2</td></tr> <tr> <td>CSA</td><td>EX 043D/06/d2</td></tr> </table>	System Information	SI 025D/06/en	Operating Manual Clamp On	BA 038D/06/en	Technical Information	TI 042D/06/en	Ex documentations:		ATEX/CENELEC	XA001D/06/ (II2G/Zone 1)	ATEX	XA002D/06/ (II3G)	FM	EX 042D/06/a2	CSA	EX 043D/06/d2
System Information	SI 025D/06/en																
Operating Manual Clamp On	BA 038D/06/en																
Technical Information	TI 042D/06/en																
Ex documentations:																	
ATEX/CENELEC	XA001D/06/ (II2G/Zone 1)																
ATEX	XA002D/06/ (II3G)																
FM	EX 042D/06/a2																
CSA	EX 043D/06/d2																
Other standards and guidelines																	
EN 60529	Degree of protection by housing (IP code)																
EN 61010	Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory Procedures																
EN 50081	Part 1 and 2 (interference emission)																
EN 50082	Part 1 and 2 (interference immunity)																
NAMUR	Association of Standards for Control and Regulation in the Chemical Industry																

11 Functions at a Glance

PROCESS VARIABLE	
VOLUME FLOW CH1 (p. 46) only for version: INSERTION CH1 IN1&2 2M.POINTS <i>or</i> CALC. VOLUME FLOW (p. 46) only for version: IN1&2 1M.POINT	Display: 5-digit number with decimal point (e.g. 5.1145 m ³ /h)
VOLUME FLOW CH1 (p. 46) only for version: IN1&2 1M.POINT	Display: 5-digit number with decimal point (e.g. 1.3549 m ³ /h)
VOLUME FLOW CH2 (p. 46) only for version: IN1&2 1M.POINT IN1&2 2M.POINTS	Display: 5-digit number with decimal point (e.g. 0.7305 m ³ /h)
NET FLOW (p. 47) only for version: IN1&2 2M.POINTS	Display: 5-digit number with decimal point (e.g. 1.4549 m ³ /h)
TOTAL FLOW (p. 47) only for version: IIN1&2 2M.POINTS	Display: 5-digit number with decimal point (e.g. 1.3549 m ³ /h)
AVE. SOUND VELOC. (p. 47) only for version: IN1&2 1M.POINT	Display: 4-digit number (e.g. 1300 m/s)
SOUND VELOC. CH1 (p. 47)	Display: 4-digit number (e.g. 1200 m/s)
SOUND VELOC. CH2 (p. 47) only for version: IN1&2 1M.STELLE IN1&2 2M.POINTS	Display: 4-digit number (e.g. 1400 m/s)
TOTALIZER	
TOTALIZER 1 TOTALIZER 2 (p. 48)	Display: 7-digit number with floating decimal point
TOTAL 1 or 2 OVERFLOW (p. 48)	Display: max 7-digit number
RESET TOTALIZER (p. 48)	CANCEL – TOTAL. 1 – TOTAL. 2 – TOTAL. 1 & 2

ASSIGN TOTAL: 1 or 2 (p. 49)	CANCEL OFF** CALC.VOLUME } CALC.VOLUME(+) } IN1&2 1M.POINT CALC.VOLUME(-) } VOLUME CH1* VOLUME(+)CH1 VOLUME(-)CH1 VOLUME CH2 } VOLUME(+)CH2 } IN1&2 1M.POINT VOLUME(-)CH2 } IN1&2 2M.POINTS NET VOLUME } TOTAL VOLUME } IN1&2 2M.POINTS TOTAL VOLUME(+) TOTAL VOLUME(-) *Totalizer 1 / ** Totalizer 2 Client setting:.....
SYSTEM UNITS	
VOLUME FLOW UNIT (p. 50)	CANCEL $\text{dm}^3/\text{s} - \text{dm}^3/\text{min} - \text{dm}^3/\text{h}$ l/s – l/min – l/h hl/min – hl/h $\text{m}^3/\text{s} - \text{m}^3/\text{min} - \text{m}^3/\text{h}$ gal/min – gal/hr – gal/day gpm – gph – gpd – mgd bbl/min – bbl/hr – bbl/day Client setting:.....
VOLUME UNIT (p. 50)	CANCEL – dm^3 – l – hl – m^3 – gal – bbl Client setting:.....
GALLONS/BARREL (p. 50)	CANCEL – US: 31.0 gal/bbl – US: 31.5 gal/bbl – US: 42.0 gal/bbl – US: 55.0 gal/bbl – IMP: 36.0 gal/bbl – IMP: 42.0 gal/bb Client setting:.....
LENGTH UNIT (p. 50)	CANCEL – mm – inch Client setting:.....
CABLE LENGTH UN. (p. 50)	CANCEL – m – ft Client setting:.....
VELOCITY UNIT (p. 50)	CANCEL – m/s – ft/s Client setting:.....
TEMPERATURE UNIT (p. 51)	CANCEL – °C – K – °F – °R Client setting:.....
VISCOSITY UNIT (p. 51)	CANCEL – mm²/s – cSt – St Client setting:.....
SELECTION	
SENSOR CONFIG. (p. 52)	CANCEL – INSERTION CH1 – IN1&2 1M.POINT – IN1&2 2M.POINTS Client setting:.....
QUICK SETUP (p. 52)	CANCEL – START

CURRENT OUTPUT 1 or 2	
ASSIGN OUTPUT (p. 53)	CANCEL OFF** CALC.VOLUME FLOW VOLUME FLOW CH1* VOLUME FLOW CH2 AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 NET FLOW TOTAL FLOW *Current output 1 / **Current output 2 Client setting:.....
ZERO SCALE or FULL SCALE 1 (p. 53)	5-digit number with floating decimal point (e.g. 1.2345 dm ³ /h) Client setting:.....
DUAL RANGE MODE (p. 54)	CANCEL – FULL SCALE 1 – FULL SCALE 2 –AUTOMATIC Client setting:.....
FULL SCALE 2 (p. 55)	5-digit number with floating decimal point (e.g. 1.2345 dm ³ /h) Client setting:.....
ACTIVE RANGE (p. 55)	FULL SCALE 1 FULL SCALE 2
TIME CONSTANT (p. 55)	5-digit number with fixed decimal point (0.5...100.00 s) Factory setting: 5,00 s Client setting:.....
CURRENT SPAN (p. 55)	CANCEL 0–20 mA (25 mA) → max. 25 mA 4–20 mA (25 mA) → max. 25 mA 0–20 mA → max. 20.5 mA (NAMUR) 4–20 mA → max. 20.5 mA (NAMUR) Client setting:.....
FAILSAFE MODE (p. 56)	CANCEL – MIN. CURRENT – MAX. CURRENT – HOLD VALUE – ACTUAL VALUE Client setting:.....
SIMULATION CURR. (p. 56)	At 0–20 (25 mA): OFF – 0 mA – 10 mA – 20 mA – 25 mA At 4–20 (25 mA): OFF – 2 mA – 4 mA – 12 mA – 20 mA – 25 mA CANCEL <i>Current output acc. to NAMUR</i> At 0–20 mA: OFF – 0 mA – 10 mA – 20 mA – 22 mA At 4–20 mA: OFF – 2 mA – 4 mA – 12 mA – 20 mA – 22 mA – CANCEL
NOMINAL CURRENT 1 or 2 (p. 56)	Number with fixed decimal point and one decimal place, incl. unit (e.g. 4.0 mA)

PULSE/FREQ. OUTPUT	
ASSIGN OUTPUT (p. 57)	CANCEL AUS CALC.VOLUME VOLUME CH1 VOLUME CH2 NET VOLUME TOTAL VOLUME AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 Client setting:..... Meas. mode freq. and pulse Meas. mode freq. only
OPERATION MODE (p. 57)	CANCEL – PULSE – FREQUENCY Client setting:.....
PULSE VALUE (p. 57)	5-digit number with floating decimal point, incl. unit (e.g. 240.00 dm ³ /p) Client setting:.....
PULSE WIDTH (p. 58)	3-digit number with fixed decimal point (0.05...2.00 s) Factory setting: 0.25 s Client setting:.....
FULL SCALE FREQ. (p. 59)	max. 5-digit number (2...10'000 Hz) Factory setting: 10000 Hz Client setting:.....
ZERO SCALE or FULL SCALE (p. 60)	5-digit number with floating decimal point (e.g. 0.5700 dm ³ /s) Client setting:.....
OUTPUT SIGNAL (p. 61)	CANCEL – PASSIVE-POSITIVE – PASSIVE-NEGATIVE – ACTIVE-POSITIVE – ACTIVE-NEGATIVE Client setting:.....
FAILSAFE MODE (p. 62)	CANCEL – FALLBACK VALUE – HOLD VALUE – ACTUAL VALUE Client setting:.....
SIMULATION FREQ. (p. 62)	CANCEL – OFF – 0 Hz – 2 Hz – 10 Hz – 1 kHz – 10 kHz
NOMINAL FREQ. (p. 62)	Display: floating decimal point number (e.g.: 811.30 Hz)

RELAY		FORMAT FLOW (p. 66)	CANCEL – XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Client setting:.....
RELAY 1 or 2 FUNCTION (p. 63)	CANCEL OFF ON FAILURE * FAILUTRE CH1 (applies to IN1&2 2M.POINTS) FAILURE CH2 (applies to IN1&2 2M.POINTS) DUAL RANGE MODE 1 DUAL RANGE MODE 2 FLOW DIRECTION (applies to IN1&2 1M.POINT) FLOW DIRECT.CH1 FLOW DIRECT.CH2 (applies to IN1&2 1M.POINT and IN1&2 2M.POINTS) CALC .VOLUME FLOW VOLUME FLOW CH1** VOLUME FLOW CH2 AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 NET FLOW TOTAL FLOW (applies to IN1&2 2M.POINTS) *Factory setting Relais 1 **Factory setting Relais 2 Client setting:.....	FORMAT TOTALIZER (p. 66)	CANCEL – XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Client setting:.....
		LCD CONTRAST (p. 67)	■■■■■■■■
		LANGUAGE (p. 67)	CANCEL – ENGLISH – DEUTSCH – FRANCAIS – ESPANOL – ITALIANO – NEDERLANDS – DANSK – NORSK – SWENSKA – SUOMI – BAHASA INDONESIA – JAPANESE Client setting:.....
		DISPLAY TEST (p. 67)	1. ■■■■■■■■■■■■■■■■■■■■■■ 2. 888888888888888888 3. _____ 4. 0000000000000000
W. THICKNESS CH1 or CH2			
		MODE (p. 68)	CANCEL – OFF – SOUND VEL. LONGI – W.THICKNESS
		PIPE MATERIAL (p. 68)	CANCEL – CARBON STEEL – STAINLESS STEEL – HASTELLOY C – PA – PE – LDPE – HDPE – PP – PVC – PTFE – PVDF – ABS – GLASS FLINT – GLASS PYREX – GLASS CROWN – OTHER Client setting:.....
		SOUND VEL. LONGI (p. 69)	max. 4-digit number Factory setting: 5900 m/s Client setting:.....
		REFERENCE VALUE (p. 69)	max. 2-digit number Factory setting: 5.00 mm Client setting:.....
		SIG.STRENGTH BARG (p. 69)	■■■■■■■■
		SOUND VEL. LONGI (p. 69)	Display: 4-digit number
		WALL THICKNESS (p. 69)	Display: max. 2-digit number
		CALIBRATION (p. 69)	CANCEL – START
INSERTION CH1 or CH2			
		PIPE DIAMETER (p. 70)	max. 4-digit number Factory setting: 88.9 mm Client setting:.....
RELAY 1 or 2 ON-VALUE or RELAY 1 or 2 OFF-VALUE (p. 64)	5-digit number with floating decimal point (e.g. 2.5800 dm ³ /s) Client setting:.....		
DISPLAY			
ASSIGN LINE 1 or 2 (p. 66)	CANCEL OFF CALC .VOLUME FLOW VOLUME FLOW CH1** VOLUME FLOW CH2 AVE.SOUND VELOC. SOUND VELOC. CH1 SOUND VELOC. CH2 SIG. STRENGTH CH1 SIG. STRENGTH CH2 SIGNAL BAR CH1 SIGNAL BAR CH2 TOTALIZER 1** TOTAL. 1 OVERFLOW TOTALIZER 2 TOTAL. 2 OVERFLOW NET FLOW TOTAL FLOW * Line 1 ** Line 2 Client setting:.....	(line 2 only)	
DISPLAY DAMPING (p. 66)	max. 2-digit number, incl. units Factory setting: 5 s Client setting:.....		

CIRCUMFERENCE (p. 70)	max. 4-digit number Factory setting: 279.3 mm Client setting:.....
WALL THICKNESS (p. 70)	max. 2-digit number Factory setting: 2.60 mm Client setting:.....
VISCOSITY (p. 70)	max. 4-digit number with floating decimal point Factory setting: 1.000 mm²/s Client setting:.....
SENSOR DATA CH1 or CH2	
SENSOR TYPE (p. 71)	CANCEL – W1LIA-W_S08
CABLE LENGTH (p. 71)	max. 3-digit number Factory setting: 5.0 m Client setting:.....
TRAVERSES (p. 71)	Display: 1
SENSOR DISTANCE (p. 71)	Display: max. 4-digit number
DEV. SENSOR DISTANCE (p. 71)	max. 3-digit number with decimal point Factory setting: 0.0 mm
ARC LENGTH (p. 71)	Display: max. 4-digit number
DEV. ARC LENGTH (p. 71)	max. 3-digit number with decimal point Factory setting: 0.0 mm
PATH LENGTH (p. 71)	Display: max. 4-digit number
DEV. PATH LENGTH (p. 71)	max. 3-digit number with decimal point Factory setting: 0.0 mm
PROZESS.PARA. CH1 PROZESSING PARA. PROZESS. PARA. CH2	
LOW FLOW CUTOFF (p. 72)	5-digit number with floating decimal point (e.g. 25,000 dm ³ /min) Factory setting: 0.4 l/s Client setting:.....
MEASURING MODE (p. 72)	CANCEL – UNIDIRECTIONAL – BIDIRECTIONAL Client setting:.....
FLOW DIRECTION (p. 72)	CANCEL – FORWARD – REVERS Client setting:.....
SIGNAL CH1 or CH2	
SIG. STRENGTH BAR (p. 73)	■■■■■■■■
SIGNAL STRENGTH (p. 73)	Display: 0...100

CALIBR.DATA CH1 or CH2	
CORR. FACTOR (p. 74)	5-digit number with 4 decimal places Factory setting: 1.0000 Client setting:.....
ZERO POINT (p. 74)	max. 4-digit number Client setting:.....
ZEROPOINT ADJUST (p. 74)	CANCEL – START – UNDO
COMMUNICATION	
PROTOCOL (p. 75)	OFF – HART Client setting:.....
BUS ADDRESS (p. 75)	2-digit number Factory setting: 0 Client setting:.....
TAG NUMBER (p. 75)	8-digit character field Factory setting: REINACH
TAG NUMBER CH2 (p. 75)	8-digit character field Factory setting: REINACH
SYSTEM PARAMETER	
PRESENT SYSTEM CONDITION (p. 76)	Calling up other current errors or status messages: “+”→message with higher display priority “–”→ message with lower display priority
PREVIOUS SYSTEM CONDITION (p. 76)	Calling up other system/process errors and errors and status messages: “+”Listing is done chronologically with the oldest, second oldest...etc. message. “–”Listing is done chronologically with the oldest, second oldest...etc. message
ACCESS CODE (p. 76)	max. 4-digit number (0...9999) Factory setting: 0
DEF. PRIVATE CODE (p. 77)	max. 4-digit number (0...9999) Factory setting: 93 Client setting:.....
POS. ZERO RETURN (p. 77)	CANCEL – OFF – ON – CHANNEL1* – CHANNEL2* *In version IN1&2 2M.POINTS only
SOFTWARE VERSION (p. 77)	Display: Software Version amplifier
SOFTWARE VER. COM (p. 78)	Display: Software Version Com (communications board)
SERIAL NUMBER (p. 78)	Display: 6-digit number (1...999999)

Index

A

Access code	76
Accuracy	92
Active range	55
Alarm (Process errors)	79
Alarm messages	83
Application	91
Approvals	94
Arc length	11, 71
Assign current output	53
Assign display	66
Assign puls/freq. output	57
Assign totalizer	49
Average sound velocity	47

B

Barrel	50
Bus Address	75

C

Cable length	71
Calibration	69
Certificates	94
Commissioning	27, 28, 29, 30
Commuwin II	38
Commuwin II matrix	40
Configuration sensor	52
Configuring relay contacts	29
Connecting sensor and transmitter	26
Connecting the transmitter	24
Connection electrical	23, 24, 25, 26
Connection housing	25
Construction	93
Correct usage	7
Current span	55

D

Dangerous substances	8
Dangers and notes	7
Diagnosis	80
Dimensions dual path version	90
Dimensions single path version	89
Display	22
Display damping	66
Display elements	31
Display test	67
Dual range mode	54

E

Electrical connection	23
Error messages	81
Example of programming	35
Exchange electronics	86
Exchange fuses	85
Exchange sensor element	88
Explanation of terms	11

F

Failsafe current	56
Failsafe frequency	62
Flow direction	72
Format flow	66
Format totalizer	66
Full scale	53
Full scale frequency	59, 60
Function group CALIBRATION DATA	74
Function group COMMUNICATION	75
Function group CURRENT OUTPUT	53
Function group DISPLAY	66
Function group INSERTION	70
Function group PROCESS VARIABLE	46
Function group PROCESSING PARAMETERS	72
Function group PULS/FREQ. OUTPUT	57
Function group RELAY	63
Function group SELECTION	52
Function group SENSOR DATA	71
Function group SIGNAL	73
Function group SYSTEM PARAMETER	76
Function group SYSTEM UNITS	50
Function group TOTALIZER	48
Function group W. THICKNESS	68
Functions	45
Functions at a glance	95
Fuses	85

G

Gallons / Barrel	50
----------------------------	----

H

HART	36
HART handheld terminal	36
HART operating matrix	37

I

Inlet run	13
Installation	11
Instrument identification	9
Insulation	13

J

Jumper	29
------------------	----

K

Keys for operation	31
------------------------------	----

L

Language setting	67
LC display	31
LCD contrast	67
Local display	22
Low flow cutoff	72

M

Maintenance	79
Matrix for programming	33
Matrix HART	37
Measuring mode	72
Mode	68
Mounting	11
Mounting dual path version	17
Mounting location	13
Mounting single path version	14
Mounting the transmitter	21

N

Nameplate	9
Net flow	47
Nominal frequency	62

O

Operating conditions	92
Operating matrix	33
Operating with Commuwin II	39
Operating with HART handheld terminal	36
Operation	31
Operation mode	57
Operation with Commuwin II	39
Order code	9, 94
Outlet run	13
Output signal frequency	61
Outputs	91

P

Path length	11, 71
Pipe diameter	70
Pipe material	68
Positive zero return	77, 79
Private code	77
Programming example	35
Programming for commissioning	27
Protection class IP 67 transmitter	23
Protection class IP 68 sensor	23
Protocol	75
Pulse value	57
Pulse width	58
Pulse/Frequency output	25

Q

Quick Setup	3, 52
-----------------------	-------

R

Reference value	69
Relay 1	25
Relay 2	25
Relay contacts	29, 65
Relay function	63
Relay Off value	64
Relay On value	64
Repair	79
Reset system	78
Reset totalizer	48

Response on fault or alarm	79
Rotating the local display	22
Rotating the transmitter housing	21

S

Safety instructions	7
Sensor configuration	52
Sensor distance	71
Sensor type	71
Serial number	78
Setting functions	32
Signal strength	73
Signal strength bargraph	73
Simulation	79
Simulation Current	56
Simulation Frequency	62
Software version	77
Sound velocity	47
Sound velocity longitudinal	69
Span	55
Status messages	84
Switch on	27
System Reset	78

T

Tag number	75
Technical data	91
Time constant	55
Torque	16, 20
Total flow	47
Total overflow	48
Totalizer	48
Totalizer format	66
Touch control	31
Transmitter housing	21
Traverse	71
Trouble-shooting	79

U

Unit Temperature	51
Units	50
User interface	94

V

Viscosity	70
Volume flow	46
Volume flow CH2	46

W

Weight dual path version	90
Weight single path version	89
Wiring sensor and transmitter	26

Z

Zero point	74
Zero point adjust	74
Zero point adjustment	28
Zero scale	53
Zero scale frequency	60

Europe		
Austria □ Endress+Hauser GmbH Wien Tel. (01) 880560, Fax (01) 8805635	Poland □ Endress+Hauser Polska Sp. z o.o. Warsaw Tel. (022) 720 1090, Fax (022) 720 1085	Brazil □ Samson Endress+Hauser Ltda. Sao Paulo Tel. (011) 536 3455, Fax (011) 536 3067
Belarus Belorgintez Minsk Tel. (0172) 263166, Fax (0172) 263111	Portugal Tecnisis - Tecnica de Sistemas Industriais Linda a Velha Tel. (01) 4172637, Fax (01) 4185278	Canada □ Endress+Hauser (Canada) Ltd. Burlington / Ontario Tel. (905) 681 9292, Fax (905) 681 9444
Belgium / Luxembourg □ Endress+Hauser S.A./N.V. Bruxelles Tel. (02) 248 0600, Fax (02) 248 0553	Romania Romconseng S.R.L. Bucharest Tel. (01) 410 1634, Fax (01) 410 1634	Chile DIN Instrumentos Ltda. Santiago Tel. (02) 205 01 00, Fax (02) 225 81 39
Bulgaria INTERTECH-Automation Sofia Tel. (02) 624834, Fax (02) 688186	Russia □ Endress+Hauser GmbH+Co Moscow Tel. + Fax see E+H Instruments International	Colombia Colsein Ltd. Bogota D.C. Tel. (01) 236 7659, Fax (01) 610 7868
Croatia □ Endress+Hauser GmbH+Co. Zagreb Tel. (01) 660 1418, Fax (01) 660 1418	Slovak Republic Transcom Technik s.r.o. Bratislava Tel. (07) 44888684, Fax (07) 44887112	Costa Rica EURO-TEC S.A. San Jose Tel. 296 1542, Fax 296 1542
Cyprus I+G Electrical Services Co. Ltd. Nicosia Tel. (02) 484788, Fax (02) 484690	Slovenia □ Endress+Hauser D.O.O. Ljubljana Tel. (061) 1592217, Fax (061) 1592298	Ecuador INSETEC Cia. Ltda. Quito Tel. (02) 25 1242, Fax (02) 46 1833
Czech Republic □ Endress+Hauser Czech s.r.o. Praha Tel. (02) 66784200, Fax (02) 66784179	Spain □ Endress+Hauser S.A. Sant Just Desvern Tel. (93) 4803366, Fax (93) 4733839	Guatemala ACISA Automatizacion y Control Industrial S.A. Guatemala Tel. (03) 345985, Fax (03) 327431
Denmark □ Endress+Hauser A/S Soborg Tel. 70131132, Fax 70132133	Sweden □ Endress+Hauser AB Sollentuna Tel. (08) 6261600, Fax (08) 6269477	Mexico □ Endress+Hauser GmbH+Co., Instruments International, Mexico City Office, Mexico City Tel. (5) 568 9658, Fax (5) 568 4183
Estonia Elvi-Aqua Tartu Tel. (7) 422726, Fax (7) 422727	Switzerland □ Endress+Hauser AG Reinach/BL 1 Tel. (061) 7157575, Fax (061) 7111650	Paraguay Incoel S.R.L. Asuncion Tel. (021) 213989, Fax (021) 2126583
Finland □ Endress+Hauser Oy Espoo Tel. (9) 8596155, Fax (9) 8596055	Turkey Intek Endüstriyel Ölçü Ve Kontrol Sistemleri Levent/Istanbul Tel. (0212) 2751355, Fax (0212) 2662775	Peru Esim S.A. Lima Tel. (1) 4714661, Fax (1) 4710993
France □ Endress+Hauser S.A. Huningue Tel. (0389) 696768, Fax (0389) 694802	Ukraine Photonika GmbH Kiev Tel. (44) 2688102, Fax (44) 2690805	Uruguay Circular S.A. Montevideo Tel. (02) 925785, Fax (02) 929151
Germany □ Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 97501, Fax (07621) 975555	United Kingdom □ Endress+Hauser Ltd. Manchester Tel. (0161) 2865000, Fax (0161) 9981841	USA □ Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 5357138, Fax (317) 5358498
Greece I & G Building Services Automation S.A. Athens Tel. (01) 9241500, Fax (01) 9221714	Yugoslavia Republic Meris d.o.o. Beograd Tel. (11) 4442966, Fax (11) 430043	Venezuela Controlval C.A. Caracas Tel. (02) 9440966, Fax (02) 9444554
Hungary MILE Ipari-Elektro Budapest Tel. (01) 2615535, Fax (01) 2615535	Africa	
Iceland BIL ehf. Reykjavik Tel. (05) 619616, Fax (05) 619617	Egypt Anasia Cairo Tel. (02) 4179007, Fax (02) 4179008	Asia
Ireland Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182	Morocco Oussama S.A. Casablanca Tel. (02) 241338, Fax (02) 402657	Brunei American International Industries (B) Sdn Bhd Lorong Tengah Tel. (3) 223737, Fax (3) 225458
Italy □ Endress+Hauser S.p.A. Cernusco s/N Milano Tel. (02) 92106421, Fax (02) 92107153	Nigeria J F Technical Invest. Nig. Ltd. Lagos Tel. (1) 62234546, Fax (1) 62234548	China □ Endress+Hauser Shanghai Shanghai Tel. (021) 64646700, Fax (021) 64747860
Kazakhstan AO "Elmo" Kazakhstan Tel. (3272) 425363, Fax (3272) 428044	Rep. South Africa □ Endress+Hauser (Pty.) Ltd. Sandton Tel. (011) 4441386, Fax (011) 4441977	Hong Kong □ Endress+Hauser (H.K.) Ltd. Hong Kong Tel. 25283120, Fax 28654171
Latvia Rino Riga Tel. (07) 312897, Fax (07) 312894	Tunisia Contrôle, Maintenance et Regulation Tunis Tel. (01) 793077, Fax (01) 788595	India □ Endress+Hauser India Branch Office Mumbai Tel. (022) 8521458, Fax (022) 8521927
Lithuania Agava Ltd. Kaunas Tel. (07) 202410, Fax (07) 207414	America	
Netherlands □ Endress+Hauser B.V. Naarden Tel. (035) 6958611, Fax (035) 6958825	Argentina □ Endress+Hauser Argentina S.A. Buenos Aires Tel. (01) 5227970, Fax (01) 5227909	Indonesia PT Grama Bazita Jakarta Tel. (21) 7975083, Fax (21) 7975089
Norway □ Endress+Hauser A/S Lierskogen Tel. (032) 859850, Fax (032) 859851	Bolivia Tritec Cochabamba Tel. (042) 56993, Fax (042) 50981	Japan □ Sakura Endress Co. Ltd. Tokyo Tel. (0422) 540611, Fax (0422) 550275
		Malaysia □ Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 7334848, Fax (03) 7338800
		Myanmar Sein Pyinsayupa Gen. Tranding & Agency Co-op. Soc. Ltd. Myanmar Tel. (1) 242325, Fax (1) 250594
		Pakistan Speedy Automation Karachi Tel. (021) 7722953, Fax (021) 7736884
		Papua-Neuguinea SBS Electrical Pty Ltd. PNG Port Moresby Tel. 3251188, Fax 3259556
		Philippines □ Endress+Hauser Philippines Inc. Manila Tel. (2) 6388041, Fax (2) 6388042
		Singapore □ Endress+Hauser (S.E.A.) Pte. Ltd. Singapore Tel. 5668222, Fax 5666848
		Korea □ Endress+Hauser (Korea) Co. Ltd. Seoul Tel. (02) 6587200, Fax (02) 6592838
		Taiwan Kingjarl Corporation Taipei Tel. (2) 27183938, Fax (02) 27134190
		Thailand □ Endress+Hauser (Thailand) Ltd. Bangkok Tel. (2) 9967811-20, Fax (2) 9967810
		Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8335225, Fax (08) 8335227
		Iran Telephone Technical Services Co. Ltd. (TTS) Tehran Tel. (021) 8746750, Fax (021) 8737295
		Israel Instrumetrics Industrial Control Ltd. Tel Aviv Tel. (03) 6480205, Fax (03) 6471992
		Jordan A.P. Parpas Engineering S.A. Amman Tel. (06) 5539283, Fax (06) 5539205
		Kuwait Kuwait Maritime & Mercantile Co. K.S.C. Safat Tel. 2434752, Fax 2441486
		Lebanon Network Engineering Co. Jbeil Tel. 3254051, Fax 9944080
		Sultanate of Oman Mustafa & Jawad Sience & Industry Co. LLC Ruwi Tel. 602009, Fax 607066
		United Arab Emirates Descon Trading Est. Dubai Tel. (04) 653651, Fax (04) 653264
		Yemen Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 230664, Fax (04) 212338
		Australia + New Zealand
		Australia ALSTOM Australia Ltd. Villawood N.S.W. Tel. (02) 97224777, Fax (02) 97224883
		New Zealand EMC Industrial Group Limited Auckland Tel. (09) 4155110, Fax (09) 4155115
		All other countries □ Endress+Hauser GmbH+Co. Instruments International Weil am Rhein, Germany Tel. (07621) 97502, Fax (07621) 975345

