BA 033D/06/en/03.00 No. 50085722 CV 5.0

Valid as of software version: V 4.00.XX (amplifier) V 3.02.XX PBUS (communication)

promass 63 (PROFIBUS-DP/-PA) Mass Flow Measuring System

Operating Manual





Brief Operating Instructions

Based on the following instructions, you may quickly configure your measuring instrument and easily.



continued: next column

Contents

1	Safe	ety Instructions	5
	1.1 1.2 1.3 1.4	Correct usage	5 5 5
	1.5 1.6	operation	6 6 6
2	Des	cription of the System	7
	2.1 2.2 2.3	Application <th< td=""><td>7 7 9</td></th<>	7 7 9
3	Μοι	unting and Installation	11
	3.1 3.2 3.3	General information	11 12 13
	3.4	Rotating the transmitter housing and local display	16
4	Elec	ctrical Connection	17
	4.1 4.2 4.3 4.4 4.5	General Information	17 17 18 20 21
5	Con	nmunication	23
•	5.1 5.2 5.3	PROFIBUS-DP interface	23 24
	5.4 5.5 5.6 5.7 5.8 5.9 5.10	PROFIBUS-DP/-PA	25 26 27 28 32 33 36 50
6	Оре	eration	57
	6.1 6.2 6.3	Display and operating elements E+H operating matrix (select functions) Example of programming	57 58 62
7	Con	nmissioning	63
	7.1 7.2	Zero-Point adjustment	63 65

8	Fun	ction Description	•	67
9	Diag	gnosis and Trouble-shooting		99
	9.1	Response of the measuring system on fault or alarm		99
	9.2 9.3	trouble-shooting	•	100 101
	9.4 9.5	Replacing the transmitter electronics Replacing the COM-Modul		107
	9.6	PROFIBUS-DP/-PA		108 109
10	Dim	ensions		111
	10.1 10.2 10.3	Dimensions Promass 63 A Dimensions Promass 63 I Dimensions Promass 63 M		111 113 114
	10.4	(high pressure)		115
	10.6	(without process connection) Dimensions Promass 63 F		116 117
	10.7	Promass 63 I, M, F		118
		(pressure vessel monitoring)	•	125
11	Tec	hnical Data		127
12	Fun	ctions at a glance		137
13	Inde	ex		145

Registered Trademarks

KALREZ [®] Registered Trademark of E.I. Du Pont de Nemours & Co., Wilmington, USA

PROFIBUS [®] Registered Trademark of PROFIBUS Trade Organization PTO, Karlsruhe, Germany

SWAGELOK [®] Registered Trademark of Swagelok & Co., Solon, USA

TRI-CLAMP [®] Registered Trademark of Ladish & Co., Inc., Kenosha, USA

VITON [®] Registered Trademark of E.I. Du Pont de Nemours & Co., Wilmington, USA

1 Safety Instructions

1.1 Correct usage

- The Promass 63 is only to be used to measure the mass flow rate of liquids and gases. At the same time, the system also measures the density and the temperature of fluids and thus allows the calculation of other parameters such as volumetric flow, solids content, or density units (°Brix, °Baumé, etc.).
- The manufacturer assumes no liability for damage caused by an incorrect use of the instrument.
- Instruments which are used in hazardous areas (only PROFIBUS-PA) are supplied with a separate "Ex documentation", which is an *integral part of this Operating Manual*. The instructions and connected loads provided in this supplement must absolutely be observed.

An appropriate icon is shown on the front of this document according to the approval given and the corresponding test center.

1.2 Dangers and notes

All instruments are designed to meet state-of-the-art safety requirements. They have been tested, and have left the factory in an operational perfectly safe condition. The devices were developed according to EN 61010 "Protection Measures for Electronic Equipment for Measurement, Control, Regulation, and Laboratory Procedures". A hazardous situation may occur if the flowmeter is not used for the purpose it was designed for or is used incorrectly. Carefully note the information provided in this Operating Manual indicated by the following pictograms:

Warning!

A "Warning" indicates actions or procedures which, if not performed correctly, may lead to personal injury or a safety hazard. Strictly observe the instructions supplied and proceed carefully.

Caution!

A "Caution" indicates actions or procedures which, if not performed correctly, may lead to faulty operations or the destruction of the instrument. Strictly observe the respective instructions.

Note!

A "Note" indicates actions or procedures which, if not performed correctly, may indirectly affect operations or lead to an unexpected instrument response.

1.3 Operational safety

- The Promass 63 measuring system fulfills the general EMC requirements according to the European Standard EN 50081 Parts 1 and 2 / EN 50082 Parts 1 and 2 as well as the NAMUR recommendations.
- Extensive self-monitoring of the measuring system provides complete operational safety. Existing errors can be automatically called up and their cause determined using the diagnosis function.
- Upon a power failure, all data of the measuring system are safely stored in the EEPROM (no batteries required).









1.4 Personnel for installation, start-up and operation

- Any mounting, electrical installation, start-up, and maintenance of the instrument may only be carried out by trained personnel authorized by the operator of the facility. Personnel must without fail read and understand this Operating Manual before carrying out its instructions.
- The instrument may only be operated by personnel who are authorized and trained by the operator of the facility. All instructions in this Manual are to be observed without fail.
- In case of corrosive fluids, the resistance of the material of all wetted parts such as measuring tubes, gaskets, and process connections is to be verified. This also applies to fluids used to clean the Promass sensor (for wetted parts materials, see chapter 10, 11).

The user is responsible for the correct selection of suitable wetted parts materials having suitable resistance within the process. The manufacturer assumes no liability! Endress+Hauser will be glad to provide additional information and help.

- The installer has to make sure that the measuring system is correctly wired according to the wiring diagrams. The measuring system is to be grounded.
- Observe all provisions valid for your country and pertaining to the opening and repairing of electrical devices.



Danger from electric shock!

With the housing cover removed, protection against accidental contact is no longer assured.

1.5 Repairs, dangerous chemicals

The following procedures must be carried out before a Promass 63 flowmeter is sent to Endress+Hauser for repair:

- A note must always be enclosed with the instrument, containing a description of the fault, the application, and the chemical and physical properties of the product being measured.
- Remove all residue which may be present. Pay special attention to the gasket grooves and crevices where fluid may be present. This is especially important if the fluid is dangerous to health, e.g. corrosive, poisonous, carcinogenic, radioactive, etc.
- No instrument should be returned without all dangerous material being removed first, e.g. in scratches or diffused through plastic.

Incomplete cleaning of the instrument may result in waste disposal or cause harm to personnel (burns, etc.). Any costs arising from this will be charged to the operator of the instrument.

1.6 Technical improvement

The manufacturer reserves the right to modify technical data without prior notice. Your local E+H Sales Office will supply you with all current information and any updates to this Operating Manual.

2 Description of the System

2.1 Application

The Promass 63 measuring system measures the mass and volume flow of fluids with widely differing characteristics:

- chocolate, condensed milk, syrup
- oils, fats
- acids, alkalis, varnishes, paints
- pharmaceuticals, catalysts, inhibitors
- suspensions, gases, etc.

The system also measures the density and temperature of fluids so that other variables can be calculated such as volumetric flow rate, solids content, and density (standard density, °Brix, °Baumé, °API).

The Promass 63 is used wherever mass flow measurement is of critical importance:

- mixing and batching of various raw materials
- controlling of processes
- measurement of fluids with quickly changing densities
- control and monitoring of product quality

The advantages of this measurement process are demonstrated by its successful use in food processing, the pharmaceutical industry, the chemical and petrochemical industry, waste disposal, energy production, etc.

2.2 Measuring principle

The measuring principle is based on the controlled generation of Coriolis forces. These forces are always present when both translational (straight line) and angular (rotational) movement occur simultaneously.

 $\vec{F}_{C} = 2 \cdot \Delta m (\vec{\omega} \cdot \vec{v})$

 \vec{F}_{C} = Coriolis force

 $\Delta m = mass of moving body$

 $\vec{\omega}$ = angular velocity

 \vec{v} = radial velocity in a rotating or oscillating system

The amplitude of the Coriolis force depends on the moving mass Δm , its velocity in the system \vec{v} and, therefore, its mass flow.





Fig. 2 Phase shift of tube vibration with mass flow.

Balanced Measuring Systems

Two-tube system (Promass M, F)

The system balance is ensured by the two measuring tubes vibrating in antiphase.

Single tube system (Promass A, I)

For single tube systems, other design solutions are necessary for system balance than for two-tube systems.

Promass A:

For Promass A, an internal reference mass is used for this purpose.

Promass I:

For Promass I, the system balance necessary for flawless measurement is generated by exciting an eccentrically located, counter-oscillating pendulum mass.

This TMBTM (Torsion Mode Balanced) system is patented and guarantees accurate measurement, also with changing process and ambient conditions. For this reason the installation of Promass I is just as easy as with two-tube systems! Special fastening measures before and after the meter are, therefore, not necessary.



Density measurement

The measuring tubes are always made to oscillate at their resonant frequency. This excitation frequency automatically adjusts as soon as the mass, and, therefore, the density of the oscillating system changes (measuring tubes *and* fluid). The resonant frequency is, thus, a function of the fluid density and enables the microprocessor to produce a density signal.

Temperature measurement

The temperature of the measuring tubes is measured and used to compensate for temperature effects. The signal produced corresponds to the process temperature and can be used for external purposes.

The Promass uses an oscillation instead of a constant angular velocity $\vec{\omega}$. Promass M and F sensors use two parallel measuring tubes with fluid flowing through them, and are made to oscillate in antiphase so that they act like a tuning fork.

The Coriolis forces produced at the measuring tubes cause a phase shift in the tube oscillation (see Fig. 2):

- When there is zero flow, i.e. with the fluid standing still, both tubes oscillate in phase (1).
- When there is mass flow, the tube oscillation is decelerated at the inlet (2) and accelerated at the outlet (3).

As the mass flow rate increases, the phase difference also increases (**A-B**). The oscillations of the measuring tubes at the inlet and outlet are determined using electrodynamic sensors.

Unlike Promass M and F, Promass A and I only have a single measuring tube. However, the measuring principle and function of all sensors are identical.

The operating principle is independent of temperature, pressure, viscosity, or flow profile.

2.3 Promass 63 measuring system

Mechanically and electronically, the Promass 63 measuring system is designed for maximum flexibility. Transmitters and sensors can be combined in any variation.

The measuring system consists of:

- transmitter Promass 63
- sensor Promass A, I, M or F



The Promass 63 PROFIBUS-PA measuring system is available with various approvals. Your Endress+Hauser representative will be pleased to supply information on the approvals presently available. All Ex information and specifications are included in a separate documentation which can be obtained from Endress+Hauser on request. Fig. 3 Promass 63 measuring system



Endress+Hauser

Caution!

Mounting and Installation 3

Warning!

- All instructions provided in this section are to be observed at all times in order to ensure safe and reliable operation of the measuring system.
- Mounting regulations and technical specifications for Ex-certified instruments (PROFIBUS-PA) may differ from those shown below. All mounting regulations and connection values in the Ex documentation must, therefore, be strictly observed.

3.1 General information

Protection IP 67 (EN 60529)

The instruments fulfil all IP 67 requirements . After successful installation in the field or after servicing, the following points always have to be observed in order to guarantee IP 67 protection:

- Housing gaskets must be clean and undamaged when inserted in the gasket groove. The gaskets may need to be dried, cleaned, or replaced.
- All housing screws and the housing cover must be firmly tightened.
- The cables used for connecting must have the correct outer diameter.
- The cable gland must be firmly tightened (see Fig. 4).
- The cable must loop down before entering the cable gland to ensure that no moisture can enter it (see Fig. 4).
- Any cable glands not used are to be replaced with a blind plug.
- The protective bush should not be removed from the cable gland.



Temperature ranges

- The maximum approved ambient and fluid temperatures must to be observed (see page 131).
- An all-weather cover should be used to protect the housing from direct sunlight when mounting in the open. This is especially important in warmer climates and with high ambient temperatures.

Tracing, thermal insulation

With certain fluids, heat transfer at the sensor has to be avoided. A wide range of materials can be used to provide the necessary insulation. Heating can be provided either electrically, e.g. by heating sheets or supplied by copper pipes with heated water or steam. Heating elements for heat tracing are available for all sensors.

Caution!

Danger of the electronics overheating! The connector between the sensor/transmitter housings of the compact version must not be insulated or heated. The connection housing of the remote version should also be kept free.

Depending on the fluid temperature, certain installation positions are to be observed (see Fig. 8).





033y07

System pressure

It is important to avoid cavitation as this can affect the oscillation of the measuring tubes.

- No special measures need to be taken for fluids which have properties similar to those of water under normal conditions.
- With volatile liquids (hydrocarbons, solvents, liquified gas), the vapour pressure must not drop below a point where the liquid begins to boil. It is also important not to release gases which are found naturally in many liquids. This can be prevented by maintaining a sufficiently high system pressure.

Note!

The sensor is, therefore, best mounted:

- on the discharge side of pumps (avoiding low pressure)
- at the lowest point in vertical piping

Purge connections

The pressure vessel of the sensor is filled with dry nitrogen (N2). The purge connection may only be opened if the pressure vessel is to be immediately filled with a dry, inert gas (corrosion protection!)

3.2 Transporting to the measuring point (DN 40...100)

For transport, instruments with nominal diameters of DN 40...100 are not to be lifted by the transmitter housing or by the connection housing of the remote version.

Use shoulder straps for transport to the measuring points and wrap them around both process connections (see Fig. 5). Avoid using chains as this might damage the housing, e.g. scratch the paint.

Warning!

Danger of injury by instrument slipping! The centre of gravity of the entire device is higher than the two suspension points of the shoulder straps. Make sure that the device does not turn or slip due to the higher centre of gravity during transport.



Fig. 5 Transporting of the sensor DN 40...100





3.3 Mounting

- No special fittings such as brackets are required. External forces are absorbed by the construction of the device, e.g. by the containment vessel.
- For mechanical reasons, and to protect the pipeline, support is recommended for heavy sensors.
- Due to the high frequency of the measuring pipes, the Promass 63 measuring system is unaffected by plant vibration.
- When mounting, no special precautions need to be taken for turbulence-generating devices (valves, bends T-pieces, etc.) as long as no cavitation occurs.

The following installation instructions are to be carried out for correct operation of the measuring system:

Orientation (Promass A)

Vertical

This is best with the flow direction upwards. Entrained solids sink downward and gases rise away from the measuring pipe when the fluid is not flowing. This also allows the measuring pipe to be completely drained and protects it from solids build-up.

Horizontal

When correctly installed, the transmitter housing is either above or below the piping. This assures that no gas bubbles may collect or solids be deposited in the curved measuring tube.

Wall and post mounting

To avoid excessive stress on the material around the process connection, the sensor should not be suspended in the piping, without support or fixation.

The sensor housing base plate permits table, wall, or post mounting. The post mounting requires a special mounting set:

DN 1, 2: Order No. 50077972 DN 4: Order No. 50079218

DN	A [mm]	B [mm]
1	145	160
2	145	160
4	175	220



Fig. 6 Orientation Promass A



Orientation (Promass I, M, F)

Vertical

This is best with the flow direction upwards. Entrained solids sink downward and gases rise away from the measuring pipes when the fluid is not flowing. This also allows the measuring pipes to be completely drained and protects them from solids build-up.

Horizontal

- Promass I (single pipe) Because of the straight measuring tube, the sensor can be mounted in any position in the piping.
- Promass M, F

The measuring pipes must lie side by side. When correctly installed, the transmitter housing is either above or below the piping (see view A).

Promass F

Promass F measuring pipes are slightly curved. Therefore, for horizontal installation the sensor position is to be adapted to the fluid properties:

- F1: not suitable for outgassing fluids
- F2: not suitable for fluids with solids content

Fig. 7 Promass M, F orientation



Fluid temperature/Orientation

To ensure that the permitted ambient temperature range for the transmitter is not exceeded (-25...+60 °C) positioning is recommended as follows:

High fluid temperature

- Vertical piping: Position A
- Horizontal piping: Position C

Low fluid temperature

- Vertical piping: Position A
- Horizontal piping: Position B

Mounting location

With liquid flows, air or entrained gases in the measuring tube may cause errors in measurement and, therefore, the following mounting locations are to be avoided:

- Do not install at the highest point of the piping.
- Do not install in a vertical pipeline directly upstream of an open pipe outlet.

Correct installation is still possible in a vertical pipeline using the recommendation in the adjacent Figure. Restrictions in the piping or an orifice with a smaller cross section than the flowmeter can prevent the sensor from running empty during measurement.

Diameter	Ø orifice / pipe restriction
DN 1	0.8 mm
DN 2	1.5 mm
DN 4	3.0 mm
DN 8	6.0 mm
DN 15	10.0 mm
DN 15*	15.0 mm
DN 25	14.0 mm
DN 25 *	24.0 mm
DN 40	22.0 mm
DN 40*	35.0 mm
DN 50	28.0 mm
DN 80	50.0 mm
DN 100	65.0 mm

* DN 15, 25, 40 "FB"= full bore versions of Promass I

Mounting the transmitter

A wall bracket for the transmitter housing and a 10 or 20 m ready-to-use cable to the sensor is delivered with the remote version.

For post mounting, the transmitter, a special mounting set is available (order no. 50076905).

Caution!

- Please pay attention to page 21 "Connecting the remote version".
- Fix the cable or lay it in a conduit.
- Do not lay cable in the vicinity of electrical machines or switching elements.
- In case of the remote version, the connection housing of the sensor should not be insulated.
- Ensure potential equalization between sensor and transmitter (see page 21).





Fig. 9 Mounting location (vertical piping)

Fig. 10 Mounting the transmitter (remote version)

ba033v65

3.4 Rotating the transmitter housing and local display

The Promass 63 transmitter and display field can be rotated in 90° steps so that the instrument can be mounted in almost any position in the piping to ensure easier handling and viewing.

Warning!

The following procedure cannot be used for units with an explosion proof housing. The separate Ex-documentation has to be strictly observed.

Rotating the transmitter housing 1. Loosen the mounting screws (approx. two turns). 1 2. Rotate the transmitter housing as far as the screw slots. 3. Carefully pull out the transmitter housing. Caution! Do not damage the connection cable between the transmitter and sensor! Rotate the transmitter housing in the position 4 required. 3 5. Push back in the latch again and tighten the two srews securely. 4 0a033y13 Rotating the local display 2 6 Warning! ᡅ Danger of electrical shock! (7)Switch off power supply before opening the housing. 1. Loosen the safety claw (3 mm Allen screw). 2. Unscrew the electronics compartment cover. 3. Undo both Phillips screws. 4 4. Rotate the display. 3 5. Retighten the Phillips screws. 6. Replace the electronics compartment cover. (3) 7. Securely tighten the safety claw Allen screws. (5)



Caution!



Fig. 11 Rotating the transmitter housing and the local display

Endress+Hauser

ba033y14

R

(5)

4 Electrical Connection

4.1 General Information

Warning!

- The information in Section 3.1 must be observed in order to maintain IP 67 protection.
- When connecting flowmeters with Ex approval (PROFIBUS-PA), all appropriate instructions and connecting diagrams in the seperate Ex documentation to this Operating Manual must be observed. The E+H representative will be pleased to help you.
- When using the remote version, only sensor and transmitter with the same serial number are to be connected together. Communication errors can occur if this is not the case.

4.2 Connecting the transmitter

Warning!

- Danger of electric shock! Switch off the power supply before unsrewing the cover.
- Connect the ground wire to the ground terminal on the housing before turning on the power
- supply.Check that the local power supply and frequency agree with the information on the nameplate. All relevant national regulations for mounting must be observed.
- 1. Loosen the screws of the safety grip (3 mm Allen key)
- 2. Unscrew the cover of the terminal compartment.
- 3. Push the power and signal cables through the appropriate cable glands.
- Wire up according to the connection diagrams (see diagram in the srew cover or page 18 resp. 20):

Power supply is connected to Terminal 1 (L1 or L+), Terminal 2 (N or L–) and the ground Terminal.

- Stranded-wire cabling: cover with an end sleeve max. 4 mm²
- Single wire cabling: max. 6 mm²
- 5. Screw the cover of the terminal compartment securely back onto the transmitter housing.
- 6. Tighten the Allen screws of the safety grip securely.









4.3 Connection diagram for PROFIBUS-DP



Warning! Risk of electric shock! Switch off the power supply before unscrewing the cover of the terminal compartment of the transmitter.



Fig. 13 Electrical Connection Promass 63 PROFIBUS-DP

Setting the end-of-line resistors of the bus cable

Because incorrect adjustments of impedance lead to reflections along the cabling, and can thus cause faulty communication, it is important to have the correct end-of-line resistors on the cabling.

Warning!

Risk of electric shock! Switch off the power supply before unscrewing the cover of the terminal compartment of the transmitter.

The switches (termination switches SW1) are on the communication board PROFIBUS-DP RS 485 (see Fig. below).

For transmission rates up to 1.5 MBaud, the end-of-line resistor on the last transmitter on the bus is set by the termination switch SW1 to: ON - ON - ON - ON.



If the transmitter is to operate at a baud rate greater than 1.5 MBaud, then because of reflections along the cabling caused by the capacitive load of the peripherals, an external end-of-line connector is to be used, e.g. with a 9-pole Sub D connector with integrated inductance.

Note!

It is generally recommended to use an external terminator, because in case of an instrument defect this prevents a failure of the entire bus.

Transmission cabling

The maximum permissible cable length (segment length) of a PROFIBUS system depends on the speed of transmission. Only 32 transmitters, according to the fieldbus standard PROFIBUS-DP, may be operated within any one segment.

Maximum length of segment as a function of the baud rate:

Baud rate [kBit/s]	9.6 – 187.5	500	1500	12000
Length of a segment [m]	1000	400	200	100

The specifications on the maximum segment length in the table above refer to cable Type A specified in the PROFIBUS standard given in the table below with the following parameters:

Spezifications of PROFIBUS RS 485 cat	ole Type A:	
---------------------------------------	-------------	--

Characteristic impedance	135 to 165 $\Omega,$ at a measurement from 3 to 20 MHz
Cable capacitance	< 30 pF per meter
Cross section area	> 0.34 mm ² , to AWG 22
Cable type	Twisted pairs, 1 x 2, 2 x 2 or 1 x 4 cable
Loop resistance	110 Ω per km
Signal attenuation	max. 9 dB over the entire lenght of the cable section
Screening	Braided copper screening, or braided and film screening



Fig. 14 Setting transmitter resistors



4.4 Connection diagram for PROFIBUS-PA



Warning! Risk of electric shock! Switch off the power supply before unscrewing the cover of the terminal compartment of the transmitter.



Fig. 15 Electrical Connection Promass 63 PROFIBUS-PA

4.5 Connection the remote version PROFIBUS-DP/-PA

The remote version is supplied with a ready-to-use cable of 10 or 20 metres which is already connected to the sensor.



Fig. 16 Connecting the remote version

5 Communication

5.1 PROFIBUS-DP interface



Fig. 17 General layout of the PROFIBUS-DP

General

The Promass 63 can be equipped with a PROFIBUS-DP (Decentralised Peripheral) interface according to the fieldbus standard PROFIBUS-DP, EN 50170 Volume 2. This enables the exchange of data with process control systems which comply with this standard. Integration into a control system must be performed in accordance with the specifications for PROFIBUS-PA profiles 2.0.

Transmission speed

The maximum PROFIBUS-DP bus speed of the Promass 63 is 12 MBaud.

Note!

- The Promass 63 can automatically identify the speed of data transmission. The instrument must be reset before loading a new speed of data transmission ("SYSTEM RESET" in the function group "SYSTEM PARAMETERS" or else the power should be switched off for a short time and than switched on again.
- Information on bus end-of-line resistors is given on page 19.

Communication partner

The Promass 63 always acts as a slave in a control system and, depending on the type of application, can therefore exchange data with one or several masters. The master can be a process control system, a PLC or a PC with a PROFIBUS-DP plug-in communication board.

Batching function

In contrast to the instrument functions of the Promass 63 without PROFIBUS, the internal batching procedure is not integrated into PROFIBUS-DP functions as the instrument has no relay function. However, for certain applications, it is possible to have a batching procedure using the function of the totaliser.

Note!

Additional specification details about PROFIBUS-PA Profile 2.0 fieldbus can be found in Operating Manual BA 198F/00/en "Field Communication PROFIBUS-DP/-PA: Guidelines for planning and commissioning".







5.2 PROFIBUS-PA Interface

Fig. 18 General layout of the PROFIBUS-PA

General

The Promass 63 can be equipped with a PROFIBUS-PA (EN 50170) interface according to the fieldbus standard PROFIBUS-DP, EN 50170 Volume 2. This enables the exchange of data with process control systems which comply to this standard. Integrating into a control system must be in accordance with the specifications for PROFIBUS-PA profiles 2.0.

Communication partner

The Promass 63 always acts as a slave in a control system and, depending on the type of application, can therefore exchange data with one or several masters. The master can be a process control system, a PLC or a PC with a PROFIBUS-DP plug-in communication board.



Caution

Note! In pro

In project management, note that the current consumption of the Promass 63 is 12 mA.

Caution!

In order to protect the PROFIBUS-PA segment from the effects of any serious faults occurring in the instrument (e.g. short circuiting), the IEC 1158-2 interface is equipped with a safety fuse. When the fuse blows, the instrument is permanently separated from the bus. The COM module must then be replaced (see also page 108).

Batching function

In contrast to the instrument functions of the Promass 63 without PROFIBUS, the internal batching procedure is not integrated into PROFIBUS-PA functions as the instrument has no relay function. However, for certain applications, it is possible to have a batching procedure using the function of the totaliser.



Note!

Additional specification details about PROFIBUS-PA Profile 2.0 fieldbus can be found in Operating Manual BA 198F/00/en "Field Communication PROFIBUS-DP/-PA: Guidelines for planning and commissioning".

5.3 Setting the device addresses on the PROFIBUS-DP /-PA

Note!

• Adressing:

The address must always be set for PROFIBUS-DP/PA transmitters. Valid addresses are 0...125. Every address can only be assigned once in a PROFIBUS-DP/-PA network. If an address is not correctly set, then the transmitter is not recognised by the master.

The address 126 is reserved for the initial start-up and for service purposes.

• Setting when delivered:

All transmitters are sent from the factory with the address 126 and software addressing. In the function group "COMMUNICATION" the option <local> is activated in the function "SYSTEM CONFIG.". In this setting, the transmitter can be addressed either locally via local operation.

PROFIBUS-DP/-PA addressing through local operation

See page 89, Function "BUS ADDRESS".

PROFIBUS-DP/-PA addressing using the DIP switches

Procedure







oa033y74

5.4 Switching on the instrument

Before switching on the measuring system, the following checks should be carried out again:

• Installation

Check that the directional arrow on the nameplate agree with the actual flow direction in the piping.

• Electrical connection

Check electrical connections and terminal coding. Check that the local power supply and the frequency agree with the information stated on the nameplate.

If these checks are successful, then switch on the power supply.

The measuring system runs though a series of internal checks and is ready for use. During this procedure the following sequence of messages is shown on the display:

Ρ	R	0	М	A	s	S		6	3					
v	3		0	2		0	0		Ρ	в	U	s		

 S
 :
 S
 T
 A
 R
 T
 U
 P

 R
 U
 N
 N
 I
 N
 G
 Image: Compare the second s

Display of the currently installed software version on the communication board and the identification of the communication board.

Having started up successfully, normal operation begins. On the display two freely selectable measured variables appear simultaniously.

5	9		8	7	0		k	g	1	m	i	n	
		1	7	8	3	0		5		k	g		

Example: Line 1 \rightarrow Mass flow Line 2 \rightarrow Totaliser

2	9	0		8	2		k	g	1	h		\leftrightarrow
		2	-	1	0	8	0		k	g		

Communication with PROFIBUS-DP master is displayed in the "Home position" by an alternatively flashing double arrow. During configuration and in case of error reports, the double arrow is masked out.



Caution!

Note!

- If the keys 🗄 have been simultaniously activated during start up, the display messages are shown in english and with maximum contrast.
- If the start up is not successful, an error message is shown indicating the cause.

Caution!

The type of access to the instrument is set in the function "SYSTEM CONFIG.", within the function group "COMMUNICATION".

Operation

- In mode **<local>**, the instrument is operated on site.
- In mode **<remote>**, the instrument is operated via the PROFIBUS network using an acyclic Class II master such as Commuwin II.

Switching between <local> and <remote> modes does not affect the cyclic exchange of measured values. When switching over, only the value of the status, the 5th byte of the actual measured value block, is changed (see Table on page 30).

5.5 System integration

The device specific data file (GSD) is required for engineering a PROFIBUS-DP network. The GSD (plain text file) contains, for example, a description of the speed the instrument used to transmit data and in which format the PLC is to receive the digital information from the transmitter.

Each instrument is given an identification number (ID No.) by the PROFIBUS Trade Organization (PTO). The name of the device master file (GSD) is derived from this. For Endress+Hauser, this ID No. always starts with "15XX".

Name of the instrument	ID-No.:	GSD	Type-File	Bitmaps
Promass 63 PROFIBUS-PA	1506 (hex)	EH1506.gsd	EH_1506.200	EH_1506_d.bmp EH_1506_n.bmp EH_1506_s.bmp
Promass 63 PROFIBUS-DP	1512 (hex)	EH1512.gsd	EH_1512.200	EH_1512_d.bmp EH_1512_n.bmp EH_1512_s.bmp

The GSD-Files of all Endress+Hauser data can be obtained as follows:

• Internet: Endress+Hauser \rightarrow http://www.endress.com

PTO (Product Avenue \rightarrow Downloadstreet \rightarrow Field Communication St.) \rightarrow http://www.profibus.com (GSD libary)

• As a diskette from Endress+Hauser: Order number 943157-0000

Contents of the download file from the internet and on the diskette:

- All Endress+Hauser GSDs
- Endress+Hauser type files
- Endress+Hauser bitmap files
- Comprehensive information on the instruments

Handling GSD/type files

GSD files must be loaded in a specific subdirectory of the PROFIBUS-DP project management software of your PLC.

Example 1

The project management software Siemens STEP 7 of the Siemens PLC S7-300/400 is in the subdirectory ...\siemens\step7\s7data\gsd.

Bitmap files also belong to the GSD files. The measuring point is shown graphically using these bitmap files. These files must be loaded into the subdirectory ...\siemens\step7\s7data\nsbmp.

Example 2

Type files (x.200 files) are required if a Siemens S5 PLC is being used and the PROFIBUS-PA network is being designed with the project management software COM ET 200.

Example 3

There is a subdirectory in the GSD directory containing GSD files with a standard DP identification code (0 x 94). These files are to be used with, e.g. a PLC 5 from Allen-Bradley.

For other project management software, please contact the manufacturer of your PLC for the correct subdirectory.

5.6 Cyclic data exchange

Structure of a cyclic file telegram

Using Data_Exchange, a PLC can send the output data to a Promass 63 and read the input files in an answer telegram. For optimum configuration of the Promass 63, the cyclic file telegram has the following structure:

$\textbf{PLC} \rightarrow \textbf{Promass 63}$ (Output-Data)

Byte	Data	Access	Data format	Units
0	Control	write	Every time this byte is changed from 00h to another digit, a binary control is carried out by the cyclic service. Changing from any digit to 00h has no effect. $0 \rightarrow 1$: Reset Totalizer 1 $0 \rightarrow 2$: Reset Totalizer 2 $0 \rightarrow 3$: Reset Totalizer 1 & 2 $0 \rightarrow 4$: Zero point adjustment $0 \rightarrow 5$: Activate positive zero return $0 \rightarrow 6$: Deactivate positive zero return $0 \rightarrow 7255$: Reserved	

Promass $\mathbf{63} \rightarrow \textbf{PLC}$ (Input-Data)

Byte	Data	Access	Data format	Units
0, 1, 2, 3	Mass flow	read	32-digit floating point number (IEEE-754)	kg/s
4	Status Mass flow	read	see the status code on page 31	_
5, 6, 7, 8	Totalizer 1	read	32-digit floating point number (IEEE-754)	default: kg
9	Status Totalizer	read	see the status code on page 31	—
10, 11, 12, 13	Density	read	32-digit floating point number (IEEE-754)	kg/m3
14	Status Density	read	see the status code on page 31	_
15, 16, 17, 18	Temperature	read	32-digit floating point number (IEEE-754)	K
19	Status Temperature	read	see the status code on page 31	_
20, 21, 22, 23	Totalizer 2	read	32-digit floating point number (IEEE-754)	default: off
24	Status Totalizer	read	see the status code on page 31	
25, 26, 27, 28	Volumeflow	read	32-digit floating point number (IEEE-754)	l/s
29	Status Volumeflow	read	see the status code on page 31	
30, 31, 32, 33	31, 32, 33 Std. Volumeflow		32-digit floating point number (IEEE-754)	NI/s
34	Status Std. Volumeflow	read	see the status code on page 31	—
35, 36, 37, 38	Targetflow	read	32-digit floating point number (IEEE-754)	kg/s or l/s
39	Status Targetflow	read	see the status code on page 31	
40, 41, 42, 43	Carrierflow	read	32-digit floating point number (IEEE-754)	kg/s or l/s
44	Status Carrierflow	read	see the status code on page 31	
45, 46, 47, 48	Std. Density	read	32-digit floating point number (IEEE-754)	%
49	Status Std. Density	read	see the status code on page 31	_



Note!

The system units in the table above correspond to the default factory units which are transmitted in the cyclic data exchange. They are only in part identical to the default units shown on the local display.

General Information

The appropriate function in the instrument must be activated in order to reserve measured values for those data blocks dependent on device settings. When the instrument is delivered, the data blocks mass flow, Totaliser 1, density and temperature are activated. Data blocks still available must be set via local operation or by using project management software Class II master, such as Commuwin II.

If not all output variables of the Promass 63 are used, then individual data blocks can be deactivated using the "FREE PLACE" block in the project management software (Class I master). In order to achieve the appropriate structures for the cyclic data telegram, the specification FREE PLACE (00h) must be sent to the transmitter for these non-activated blocks (see also the example for constructing a data telegram on page 30).

The FREE PLACE block is contained in the GSD.

Note!

The status 08 hexadecimal (hex) in Class I master is shown for those data blocks which are not activated.

Only those data blocks should be activated which are to be processed in the control system. This increases the data rate in a PROFIBUS-DP/-PA network. The cyclic exchange of data to the Class I master (e.g. PLC) is shown on the local display by a flashing double arrow.

Caution!

- When data blocks are activated, their place in the sequence must be noted.
- The instrument must be reset before loading a new device configuration ("SYSTEM RESET" in the function group "SYSTEM PARAMETERS" or else the power should be switched off for a short time and then switched on again).

Note!

The measured values are transmitted to the Class I master in the system units as shown in the table on page 28 using the cyclic data exchange. If the unit of a measured value is changed by local operation, then this has no effect on the unit of this measured value in Class I master communication. Only after activating the function "UNIT TO BUS" in the function group "COMMUNICATION" is the modified system of units of the measured value transmitted to the Class I master.

IEEE floating point numbers

For converting a hex value into an IEEE floating point number for processing measured values. Measured values are transmitted to the Class I master in the IEEE-754 number format as shown below:

Byte n			Byte n + 1	Byte n + 2	Byte n + 3		
Bit 7	Bit 6 Bit 0 Bit 7 Bit 6 Bit 0		Bit 7 Bit 0	Bit 7 Bit 0			
VZ	2 ⁷ 2 ⁶ 2 ⁵ 2 ⁴ 2 ³ 2 ² 2 ¹	2 ⁰	2 ⁻¹ 2 ⁻² 2 ⁻³ 2 ⁻⁴ 2 ⁻⁵ 2 ⁻⁶ 2 ⁻⁷	2 ⁻⁸ 2 ⁻⁹ 2 ⁻¹⁰ 2 ⁻¹¹ 2 ⁻¹² 2 ⁻¹³ 2 ⁻¹⁴ 2 ⁻¹⁵	2 ⁻¹⁶ 2 ⁻¹⁷ 2 ⁻¹⁸ 2 ⁻¹⁹ 2 ⁻²⁰ 2 ⁻²¹ 2 ⁻²² 2 ⁻²³		
Index Mantissa		Mantissa	Mantissa				

Formula = (-1) ^{VZ} * 2 ^(Index -127) * (1 + Mantissa)





Caution

Example for construction a data telegram

The configuration data (CHK_CFG) used in this example are: [42h, 84h, 08h, 05h]; [42h, 84h, 08h, 05h]; [42h, 84h, 08h, 05h]; [42h, 84h, 08h, 05h]; [00h]; [0

The cyclic data telegram contains 26 bytes of device data, with 6 blocks activated and 5 blocks deactivated.

Byte Lenght	Data blocks	Status	Access	GSD block name	Configuration data (dependent on the PROFIBUS Master)
04	Massflow + Status	active	read	Massflow Block	42h, 84h, 08h, 05h
59	Totalizer 1 + Status	active	read	Totalizer 1 Block	42h, 84h, 08h, 05h
1014	Density + Status	active	read	Density Block	42h, 84h, 08h, 05h
	Temperature + Status	inactive	read	Temperature Block	00h
15 19	Totalizer 2 + Status	active	read	Totalizer 2 Block	42h, 84h, 08h, 05h
2024	Volumeflow + Status	active	read	Volumeflow Block	42h, 84h, 08h, 05h
	Std. Volumeflow + Status	inactive	read	Std. Volflow Block	00h
	Targetflow + Status	inactive	read	Targetflow Block	00h
	Carrierflow + Status	inactive	read	Carrierflow Block	00h
	Calc. Density + Status	inactive	read	Calc. Density Block	00h
0	Control	active	write	Control Block	20h

Example in an engineering software:

Slave Info Modules	Cfg and User Data			
Modul Max.	es useable Modules: 11 Used Modules: 11	/0	Data Max. Input Length: Max. Output Length: x. In/Output Length:	50 1 51
Available Modules:			Used Modules:	
Description Massflow Block Totalizer 1 Block Density Block Tamperature Block Totalizer 2 Block Volumeflow Block Targetflow Block Cartierflow Block Carteng Block Free Place	Configbytes specific format:5 byte(s specific format:5 byte(s) 1 byte(s) Dut, not consi specific format; byte(s)	Add>>> <	Description Massflow Block Totalizer I Block Density Block Free Place Totalizer 2 Block Volumeflow Block Free Place Free Place Free Place Control Block	Contigbytes specific format:5 byte(s) specific format:5 byte(s) specific format:5 byte(s) specific format:5 byte(s) specific format:5 byte(s) specific format; empty, specific format; empty, specific format; empty, specific format; empty, 1 byte(s) Out, not consis
•	Þ		∢	Down

Example 1:

With this configuration, the following blocks will be transmitted to the DP master, with a data length of 25 input bytes and 1 output byte:

- Massflow + Status
- Totalizer 1 + Status
- Density + Status
- Totalizer 2 + Status
- Volumeflow + Status
- Control

FREE PLACE is to be selected for blocks which are not required:

ilave Info Modules Cfg a	nd User Data			
Modules Max. useab Usi	le Modules: 11 ed Modules: 3	Ma) Data Max. Input Length: Max. Output Length: x. In/Output Length:	50 1 51
Available Modules:			Used Modules:	
Description Massiflow Block Totalizer 1 Block Urenzy Block Totalizer 2 Block Volumeflow Block Std Vollow Block Std Vollow Block Carriefflow Block Carriefflow Block Carriefflow Block Control Block Free Place	Configbytes specific for specific for specific for specific for specific for specific for specific for specific for pecific for	Add>> << Remove << Remove All	Description Massflow Block Totalizer 1 Block Density Block	Confightes specific for specific for specific for
			Up	Down

Example 2:

With this configuration, the following blocks will be transmitted to the DP master, with a data length of 15 input bytes:

- Massflow + Status
- Totalizer 1 + Status
- Density + Status

Status code

Encoding the status according to PROFIBUS profiles "PROFIBUS-PA Profiles for Process Control Devices - General Requirements" V 2.0:

Status Code	Meaning	Condition of the instrument
00 Hex	non-specific	BAD
04 Hex	configuration-error	BAD
08 Hex	not connected	BAD
0C Hex	device failure	BAD
10 Hex	sensor failure	BAD
14 Hex	no communication (last usable value)	BAD
18 Hex	no communication (no usable value)	BAD
1C Hex	out of service	BAD
20 Hex	configuration error, variable not supported	BAD
40 Hex	non-specific	UNCERTAIN
44 Hex	last usable value	UNCERTAIN
48 Hex	substitute-set	UNCERTAIN
4C Hex	initial value	UNCERTAIN
50 Hex	sensor conversion not accurate	UNCERTAIN
54 Hex	engineering unit range violation	UNCERTAIN
58 Hex	sub-normal	UNCERTAIN
5C Hex	configuration error, value adapted	UNCERTAIN
64 Hex	empty pipe detection	UNCERTAIN
68 Hex	pos. zero return active	UNCERTAIN
80 Hex	ok	GOOD
81 Hex	LO_LIM (Alarm active)	GOOD
82 Hex	HI_LIM (Alarm active)	GOOD
83 Hex	low and high limit bit set value constant	GOOD
84 Hex	active block alarm	GOOD
88 Hex	active advisory alarm	GOOD
8C Hex	active critical alarm	GOOD
90 Hex	unacknowleged block alarm	GOOD
94 Hex	unacknowleged advisory alarm	GOOD
98 Hex	unacknowleged critical alarm	GOOD
9C Hex	good-local operating possible	GOOD
9D Hex	LO_LIM (Alarm active)	GOOD
9E Hex	HI_LIM (Alarm active)	GOOD
9F Hex	good-local operating possible low and high limit bit set value constant	GOOD
AC Hex	initiate fail safe	GOOD

Note!

- If the instrument detects the process error EPD (Empty Pipe Detection), in the mode **>remote**< (80 Hex) or in the mode **>local**< (9C Hex), the status of the measured value will be set to 64 Hex.
- If the zero point return is be activated in the mode **>remote**< (80 Hex) or in the mode **>local**< (9C Hex), the status of the measured value will be set to 68 Hex.
- To optimize a subsequent control process, it is recommended that the status of the measured value be analyzed.



5.7 Acyclic data exchange

Using acyclic functions, the Class II master is able to change the parameters in the blocks shown below, e.g. time constant of flow rate, type of function, deleting totalisers, etc.

The Promass 63 software consists of four different blocks corresponding to PROFIBUS-PA profile definitions:

• 1 Physical block

The physical block contains device-specific information such as measuring point ID, software version, etc.

- 1 Transducer block for flow rate, temperature and density. The transducer block contains sensor data such as the calibration factor or nominal diameter.
- 2 *Function* blocks for totalizer The totaliser blocks enable the control system direct access to the totaliser of the Promass 63.
- *Al* block (AI = Analogue Input) This universal function block makes available to the control system all parameters required for the processing of measured variables given below (filtering, scaling, mode and status handling).

These AI blocks make available to the control system the parameters for determining mass, flow, temperature and density.

The Promass 63 software contains the following block model: 8 AI blocks (AI = Analog Input)

These analogue input blocks include:

- Massflow
- Density
- Temperature
- Volumeflow
- Std. Volumeflow
- Targetflow
- Carrierflow
- Calc. Densitye



Fig. 20 Function block model of the Promass 63 PROFIBUS-PA

5.8 Cycle times

Processing of the internal measured value and data communication of the Promass 63 is carried out in three steps:



• 1st step: Signal processing

In the signal processing block, the primary measured variables of mass flow, density and temperature are calculated from the sensor signals. The length of the sampling interval depends on the type of sensor, the nominal diameter and the actual flow (mass and density) of the medium.

31 1	0			
Sensor	Scanning ir	Measurement [ms]		
	SELF CHECKING "CYCLIC" * interval (2 s)	SELF CHECKING "SMART PLUS" * interval (5 min)	Time interval for "CYCLIC" and "SMART PLUS"	
Promass F	38 ms	19 ms	60 ms	
Promass M	38 ms	19 ms	60 ms	
Promass A	68 ms	34 ms	100 ms	
Promass I	28 ms	28 ms	60 ms	

Typical processing times of Promass 63:

* The "CYCLIC" or "SMART PLUS" functions are set in the function group "SYSTEM PARAMETER", in the function "SELF CHECKING" (see page 89).

2nd step: AI block evaluation

With the measured values calculated from the signal processing (mass flow, density and temperature), the output values of the AI blocks and the totalisers are evaluated in this step and copied into a cyclic data telegram.

The AI block evaluation has a delay of max. 3 ms per block.

Note!

Only one AI block or totaliser is calculated per cycle. Only the AI blocks or totaliser block are calculated (see page 30). By deactivating parameters not required in the cyclic data telegram, the real time response of the measurement unit is improved.





• 3rd step: PROFIBUS protocol chip

The cyclic data telegram is transferred to the protocol chip and sent on request to the master at the appropriate data transmission speed.

Note!

An automatic calibration (Measurement) of the signal processing is carried out at appropriate intervals. No signal processing is carried out during this calibration procedure and the last value determined is held.

ШS

ծիկուսովուսիսութութ

265

245

155 155 150

140 145

135

-15

100

105

- 8

1 75 70

35

25

- 8

C

30

240

250 260

5.9 Slot / Index lists

The PTO profile is used as the basis for the definition. All parameters in **Slot 1**, the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
Device Management									
Directory_Header/ Composite_Directory_Entries		0	Х		Record	М	Unsigned 16	12	С
Composite_Directory_Entry/ Composite_Directory_Entries		1	Х		Record	М	Unsigned 16	60	С
not used		2							
not used		3							
not used		4							
not used		5							
not used		6							
not used		7							
not used		8							
not used		9							
not used		10							
not used		11							
not used		12							
not used		13							
* Parameter: O = Optional M = Mandatory									

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
Physical Block									
BLOCK OBJECT		14	Х		Record	М	DS-32	20	С
ST_REV	V8H1	15	Х		Simple	М	Unsigned 16	2	Ν
TAG_DESC	V8H0	16	Х	Х	Simple	М	Octet String	32	S
STRATEGY		17	Х	Х	Simple	М	Unsigned 16	2	S
ALERT_KEY		18	Х	Х	Simple	М	Unsigned 8	1	S
TARGET_MODE		19	Х	Х	Simple	М	Unsigned 8	1	S
MODE_BLK		20	Х		Record	М	DS-37	3	
ALARM_SUM	V7H0/1	21	Х		Record	М	DS-42	8	D
SOFTWARE_REVISION	V9H6	22	Х		Simple	М	Octet String	16	Cst
HARDWARE_REVISION	V9H7	23	Х		Simple	М	Octet String	16	Cst
DEVICE_MAN_ID	VAH1	24	Х		Simple	М	Unsigned 16	2	Cst
DEVICE_ID	VAH2	25	Х		Simple	М	Octet String	16	Cst
DEVICE_SER_Num	VAH3	26	Х		Simple	М	Octet String	16	Cst
DIAGNOSIS	V9H0	27	Х		Simple	М	Octet String	4	D
DIAGNOSIS_EXTENSION	V9H8	28	Х		Simple	0	Octet String	6	D
DIAGNOSIS_MASK	V9H3	29	Х		Simple	М	Octet String	4	Cst
DIAGNOSIS_MASK_ EXTENSION	V9H9	30	Х		Simple	0	Octet String	6	Cst
DEVICE_CERTIFICATION	VAH6	31	Х	Х	Simple	0	Octet String	16	Ν
SECURITY_LOCKING	VAH7	32	Х	Х	Simple	0	Unsigned 16	2	Ν
FACTORY_RESET	VAH8	33		Х	Simple	0	Unsigned 16	2	S
not used		34							
not used		35							
* Parameter: O = Optional M = Mandatory									
Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
--	---------------	-------	------	-------	---------------	------------------	--------------	---------------	---------------
Physical Block (continued)									
not used		36							
not used		37							
not used		38							
not used		39							
not used		40							
not used		41							
not used		42							
not used		43							
DESCRIPTOR	VAHO	44	Х	Х	Simple	М	Octet String	32	S
DEVICE_MESSAGE	VAH5	45	Х	Х	Simple	М	Octet String	32	S
DEVICE_INSTAL_DATE	VAH4	46	Х	Х	Simple	М	Octet String	8	S
not used		47							
not used		48							
not used		49							
not used		50							
not used		51							
Actual Error		52	Х		Simple	0	Unsigned 16	2	D
not used		53							
UpDownFeaturesSupported		54	Х		Simple	М	Octet String	1	Cst
UpDownCtrl parameter		55		Х	Simple	0	Unsigned 8	1	D
UpDown parameter		56	Х	Х	Record	0	UpDownData	20	D
Device Bus Address		57	Х		Simple	0	Unsigned 8	1	D
not used		58							
not used		59							
not used		60							
not used		61							
not used		62							
not used		63							
not used		64							
* Parameter: O = Optional M = Mandatory									

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
		05	X		Deserved		D0.00	00	0
	VOLIA	65	X		Record	M	DS-32	20	C
SI_REV	V8HT	66	X	V	Simple	IVI	Unsigned 16	2	N
TAG_DESC	V8H0	67	X	X	Simple	IVI	Octet String	32	S
		68	X	X	Simple	IVI	Unsigned 16	2	5
		69	X	X	Simple	IVI	Unsigned 8	1	5
		70	X	X	Simple	IVI		1	5
	1/7/10/1	70			Record	IVI	DS-37	0	
		72			Simple	IVI N4	DS-42	0	
		73		V	Simple		Float	4	0
NUMINAL_SIZE		74		×	Simple		Fille	4	5
		75			Simple	0	Unsigned 8	1	<u> </u>
	VOLIA	70		X	Simple		Unsigned 8	1	5
FLOWRATE_UNITS	VOLI	70	X	X	Simple		Unsigned 16	2	5
SELF_CHECKING	V9HT	78	X	X	Simple	0	Unsigned 8	1	5
CALIBRATION_FACTOR	V4H0	79	X	X	Simple	M	Float	4	5
ZERO_POINT	V9H3	08	X	X	Simple	0	Float	4	N
FLOW_DIRECTION	V5H3	81	X	X	Simple	0	Unsigned 8	1	S
(not used)		82	X		Simple	M	Float	4	S
LOWER_SENSOR_LIMIT (not used)		83	Х		Simple	М	Float	4	S
SAMPLE_RATE (not used)		84	Х	Х	Simple	0	Float	4	S
EPD_THRESHOLD	V5H2	85	Х	Х	Simple	0	Float	4	S
LOW_FLOW_CUTOFF	V5H1	86	Х	Х	Simple	0	Float	4	S
MASS_FLOWRATE	V1H0	87	Х		Simple	Μ	Float	4	D
MASS_FLOWRATE_UNITS	V1H1	88	Х	Х	Simple	Μ	Unsigned 16	2	S
ZERO_POINT_ADJUST	V9H2	89	Х	Х	Simple	0	Unsigned 8	1	Ν
OSCILLATION_FREQ.	V5H0	90	Х		Simple	0	Float	4	D
VORTEX_FREQ. (not used)		91	Х		Simple	0	Float	4	D
VOLUME_FLOW		92	Х		Simple	0	Float	4	D
VOLUME FLOW UNITS		93	Х	Х	Simple	0	Unsigned 16	2	S
TEMPERATURE	V3H2	94	Х		Simple	0	Float	4	D
TEMPERATURE UNITS	V3H3	95	Х	Х	Simple	0	Unsigned 16	2	S
DENSITY	V3H0	96	Х		Simple	0	Float	4	D
DENSITY_UNITS	V3H1	97	Х	Х	Simple	0	Unsigned 16	2	S
not used		98							
not used		99							
TB_DENSC		100	Х		Simple	0	Float	4	D
TB_TARGET_FLOW		101	Х		Simple	0	Float	4	D
TB_CARRIER_FLOW		102	Х		Simple	0	Float	4	D
TB_STDVOL_FLOW		103	Х		Simple	0	Float	4	D
TB_TOT1_OV		104	Х		Simple	0	Signed 16	2	D
TB_TOT2_OV		105	Х		Simple	0	Signed 16	2	D
TB_GAL_BAR		106	Х	Х	Simple	0	Unsigned 16	2	S
TB_STDVOL_FLOW_UNITS		107	Х	Х	Simple	0	Unsigned 16	2	S
TB_STDDENS_UNITS		108	Х	Х	Simple	0	Unsigned 16	2	S
TB_DIA_UNITS		109	Х	Х	Simple	0	Unsigned 16	2	S
TB_MASS_UNITS		110	Х	Х	Simple	0	Unsigned 16	2	S
TB_VOLUME_UNITS		111	Х	Х	Simple	0	Unsigned 16	2	S
TB_STDVOLUME_UNITS		112	Х	Х	Simple	0	Unsigned 16	2	S

Parameter: O = Optional M = Mandatory

Endress+Hauser

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
Transducer Block (continued	n								
	.,	113	Y	V	Simple		Unsigned 16	2	9
		11/	X	X	Simple		Unsigned 8	1	N
		115			Simple	0	Unsigned 8	1	C 11
		110		^	Simple	0	Onsigned 8	16	Cot
		117			Simple	0	Uppigpod 9	10	N
TB_SENS_DAT_SEL		110			Simple	0		1	
		110			Simple		Float	4	
TB_DENS_ADJ_VAL		119	X	X	Simple	0	Float	4	
		120	X	X	Simple	0	Unsigned 8	1	5
TB_VOLUMEFLOW_MEAS		121	X	X	Simple	0	Unsigned 8	1	S
TB_STDVOL_CALC		122	X	X	Simple	0	Unsigned 8	1	S
TB_REF_TEMP		123	X	X	Simple	0	Float	4	S
TB_EXP_COEFF		124	X	X	Simple	0	Float	4	S
TB_FIX_STD_DENS		125	Х	Х	Simple	0	Float	4	S
TB_CARRIER_DENS		126	Х	Х	Simple	0	Float	4	S
TB_CARRIER_EXP_COEFF		127	Х	Х	Simple	0	Float	4	S
TB_TARGET_DENS		128	Х	Х	Simple	0	Float	4	S
TB_TARGET_EXP_COEFF		129	Х	Х	Simple	0	Float	4	S
TB_ASSIGN_DISP_LINE1		130	Х	Х	Simple	0	Unsigned 8	1	N
TB_ASSIGN_DISP_LINE2		131	Х	Х	Simple	0	Unsigned 8	1	N
TB_ASSIGN_LANGUAGE		132	X	X	Simple	0	Unsigned 8	1	N
TB_DISP_CONTRAST		133	Х	Х	Simple	0	Unsigned 8	1	N
TB_DISP_DAMP		134	Х	Х	Simple	0	Float	4	N
TB_DISP_FORM_FLOW		135	Х		Simple	0	Unsigned 8	1	N
TB_ASSIGN_TOT1		136	Х	Х	Simple	0	Unsigned 8	1	S
TB_ASSIGN_TOT2		137	Х	Х	Simple	0	Unsigned 8	1	S
TB_IOUT_ASSIGN		138	Х	Х	Simple	0	Unsigned 8	1	S
TB_IOUT_LRV		139	Х	Х	Simple	0	Float	4	S
TB_IOUT_URV		140	Х	Х	Simple	0	Float	4	S
TB IOUT TAU		141	Х	Х	Simple	0	Float	4	S
TB IOUT CURR RANGE		142	X	Х	Simple	0	Unsigned 8	1	S
TB IOUT FAILSAVE		143	X	X	Simple	0	Unsigned 8	1	S
		144	X	X	Simple	0	Unsigned 8	1	N
		145	X		Simple	0	Float	4	D
		146	X	X	Simple	0	Float	4	
		147	X	X	Simple	0	Float	4	D
		148	X	X	Simple	0	Float	4	
		1/0	X	X	Simple	0	Float		
		143	X	X	Simple		Float	4	
		151			Simple	0	Float	4	
		150			Simple	0	Fillal	4	
		152			Simple		Circled 16	0	
TR TOT 1		103			Simple			2	
		154	X		Simple		FIDAT	4	
IB_101_2		155	X		Simple	0	Float	4	
not used		156							
not used		15/							
not used		158							
not used		159							
* Parameter: O = Optional M = Mandatory									

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
AL - Massflow Block									
		160	X		Record	M	DS-32	20	C
ST REV	V8H1	161	X		Simple	M	Unsigned 16	2	N
TAG DESC	V8H0	162	X	Х	Simple	M	Octet String	32	S
STRATEGY		163	X	X	Simple	M	Unsigned 16	2	S
ALERT KEY		164	X	X	Simple	M	Unsigned 8	1	S
TARGET MODE	V6H0	165	X	X	Simple	M	Unsigned 8	1	S
MODE BLK	V6	166	Х		Record	M	DS-37	3	
ALARM SUM	V7	167	Х		Record	М	DS-42	8	D
not used		168							
not used		169							
OUT	VO	170	Х		Record	М	DS-33	5	D
PV_SCALE	V0H5/6	171	Х	Х	Record	М	DS-36	11	S
OUT SCALE	V0H2/3	172	Х	Х	Record	М	DS-36	11	S
not used		173							
CHANNEL		174	Х	Х	Simple	М	Unsigned 16	2	S
not used		175							
PV FTIMF	V0H8	176	Х	Х	Simple	M	Float	4	N
not used		177							
not used		178							
ALARM HYS	V1H0	179	X	X	Simple	M	Float	4	S
not used	V II IO	180	~	~	Giripio		Tiour		0
	V2H0	181	X	X	Simple	M	Float	4	S
notused	VZIIO	182	~	~	Omple	IVI	Tiout	-	
	V3H0	183	X	X	Simple	М	Float	1	5
not used	VOLIO	184	~	~	Ompic	IVI	Tioat	-	
	V4H0	185	X	X	Simple	М	Float	4	S
not used	V II IO	186	~	~	Giripio		Tiour		0
	V5H0	187	X	X	Simple	М	Float	4	s
not used	10110	188			Gimpio				0
not used		189							
HI HI AI M	V2	190	Х		Record	M	DS-39	16	D
	V3	191	X		Record	M	DS-39	16	D
	V0 V4	192	X		Record	M	DS-39	16	D
	V5	193	X		Record	M	DS-39	16	D
	 	194	X	X	Record	M	DS-50	6	N
not used		195	~	~	1100010		20.00	0	
not used		196							
not used		197							
not used		198							
not used		199							
		200	X		Simple	0	Unsigned	2	Cet
		200	X		Becord	M	Unsigned 16	17	
VIEW_FITISICAL BLOCK		201	~		necoru	IVI	DS-37,DS-42, Octet String [4]	17	
VIEW_TRANSDUCER BLOCK		202	Х		Record	M	Unsigned 16, DS-37,DS-42, Float	17	D
VIEW_AI		203	Х		Record	М	Unsigned 16, DS-37,DS-42, DS-33	18	D
* Parameter: O = Optional M = Mandatory									

Il parameters in Slot 2 , the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
Totalizer 1 Block									
BLOCK OBJECT		0	Х		Record	Μ	DS-32	20	С
ST_REV		1	Х		Simple	Μ	Unsigned 16	2	Ν
TAG_DESC		2	Х	Х	Simple	Μ	Octet String	32	S
STRATEGY		3	Х	Х	Simple	Μ	Unsigned 16	2	S
ALERT_KEY		4	Х	Х	Simple	Μ	Unsigned 8	1	S
TARGET_MODE		5	Х	Х	Simple	Μ	Unsigned 8	1	S
MODE_BLK		6	Х		Record	Μ	DS-37	3	
ALARM_SUM		7	Х		Record	Μ	DS-42	8	D
not used		8							
not used		9							
OUT_TOTAL		10	Х		Record	Μ	DS-33	5	D
not used		11							
TOT_UNITS		12	Х	Х	Index	Μ	Unsigned 16	2	S
not used		13							
CHANNEL		14	Х	Х	Simple	Μ	Unsigned 16	2	S
RESET_TOT		15	Х	Х	Simple	Μ	Unsigned 8	1	Ν
MODE_TOT		16	Х	Х	Simple	М	Unsigned 8	1	S
not used		17							
FAIL_TOT		18	Х	Х	Simple	Μ	Unsigned 8	1	S
not used		19							
POLAR_TOT		20	Х	Х	Simple	Μ	Unsigned 8	1	S
not used		21							
ALARM_HYS		22	Х	Х	Simple	Μ	Float	4	S
HI_HI_LIM		23	Х	Х	Simple	Μ	Float	4	S
HI_LIM		24	Х	Х	Simple	Μ	Float	4	S
HI_HI_ALM		25	Х		Record	Μ	DS-39	16	D
HI_ALM		26	Х		Record	Μ	DS-39	16	D
not used		27							
not used		28							
not used		29							
not used		30							
not used		31							
TOT1_TYPE		32	Х		Simple	0	Unsigned 16	2	Cst
VIEW_TOT		33	Х		Record	М	Unsigned 16	18	D
* Parameter: O = Optional M = Mandatory									

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
ALQ Density Block									
	1	0	V		Pegerd	N/	00.00	20	C
	\/оЦ1	1			Simplo	N/	Lincignod 16	20	N
		2	∧ ∨	V	Simple	N/	Octot String	20	C N
STRATEGY	V0110	2	×	×	Simple	M	Unsigned 16	2	<u> </u>
		1	X	X	Simple	M	Unsigned 8	1	<u> </u>
	<u>V6H0</u>	5	X	X	Simple	M	Unsigned 8	1	S
	Ve	6	X	~	Becord	M		3	0
ALARM SUM	V7	7	X		Record	M	DS-42	8	D
not used	• /	8	~		neoora	IVI	00 42	0	
not used		9							
	VO	10	X		Record	M	DS-33	5	D
PV SCALE	V0H5/6	11	X	Х	Record	M	DS-36	11	S
OUT SCALE	V0h2/3	12	Х	Х	Record	М	DS-36	11	S
not used	- ,-	13							
CHANNEL		14	Х		Simple	Μ	Unsigned 16	2	S
not used		15							
PV_FTIME	V0H8	16	Х	Х	Simple	М	Float	4	N
not used		17			-				
not used		18							
ALARM_HYS	V1H0	19	Х	Х	Simple	Μ	Float	4	S
not used		20							
HI_HI_LIM	V2H0	21	Х	Х	Simple	Μ	Float	4	S
not used		22							
HI_LIM	V3H0	23	Х	Х	Simple	Μ	Float	4	S
not used		24							
LO_LIM	V4H0	25	Х	Х	Simple	Μ	Float	4	S
not used		26							
LO_LO_LIM	V5H0	27	Х	Х	Simple	Μ	Float	4	S
not used		28							
not used		29							
HI_HI_ALM	V2	30	Х		Record	Μ	DS-39	16	D
HI_ALM	V3	31	Х		Record	Μ	DS-39	16	D
LO_ALM	V4	32	Х		Record	Μ	DS-39	16	D
LO_LO_ALM	V5	33	Х		Record	Μ	DS-39	16	D
SIMULATE	V9	34	Х	Х	Record	Μ	DS-50	6	N
not used		35							
not used		36							
not used		37							
not used		38							
not used		39			<u></u>	-			
AI2_TYPE		40	X		Simple	0	Unsigned 16	2	Cst
VIEW_AI		41	X		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D
* Parameter: O = Optional									

All parameters in **Slot 3**, the index are derived from the following tables:

M = Mandatory

All parameters in **Slot 4**, the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class	
ALO, Tama anatura Dia ak										
		0	V		Pegerd	NA	00.00	20	C	
BLOCK OBJECT	VOLI	1	× ×		Circula		DS-32	20		
		1		V	Simple	IVI		2		
TAG_DESC	V8H0	2	X	X	Simple	IVI	Octet String	32	5	
		3	X	X	Simple		Unsigned 16	2	5	
	1/01/10	4	X	X	Simple	IVI	Unsigned 8	1	5	
	V6HU	5	X	X	Simple	IVI	Unsigned 8	1	5	
	V6	0	X		Record	IVI	DS-37	3		
	V7	/	X		Record	IVI	DS-42	8	D	
not used		8								
not used	1/0	9	X		Descul		D0 00			
	V0	10	X	X	Record	M	DS-33	5	D	
PV_SCALE	V0H5/6	11	X	X	Record	IVI	DS-36		5	
OUT_SCALE	V0h2/3	12	X	X	Record	M	DS-36	11	S	
not used		13			01					
CHANNEL		14	Х	Х	Simple	M	Unsigned 16	2	S	
not used		15			01					
PV_FIIME	V0H8	16	Х	Х	Simple	M	Float	4	N	
not used		17								
not used		18								
ALARM_HYS	V1H0	19	Х	Х	Simple	M	Float	4	S	
not used		20								
HI_HI_LIM	V2H0	21	X	X	Simple	M	Float	4	S	
not used		22								
HI_LIM	V3H0	23	Х	Х	Simple	M	Float	4	S	
not used		24								
LO_LIM	V4H0	25	Х	Х	Simple	M	Float	4	S	
not used		26								
	V5H0	27	Х	Х	Simple	M	Float	4	S	
not used		28								
not used		29								
HI_HI_ALM	V2	30	Х		Record	M	DS-39	16	D	
HI_ALM	V3	31	Х		Record	M	DS-39	16	D	
LO_ALM	V4	32	Х		Record	M	DS-39	16	D	
LO_LO_ALM	V5	33	Х		Record	M	DS-39	16	D	
SIMULATE	V9	34	Х	Х	Record	M	DS-50	6	N	
not used		35								
not used		36								
not used		37								
not used		38								
not used		39								
AI3_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst	
VIEW_AI		41	Х		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D	
* Parameter: O = Optional M = Mandatory										

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
Totalizer 2 Block									
BLOCK OBJECT		0	Х		Record	М	DS-32	20	С
ST_REV		1	Х		Simple	М	Unsigned 16	2	Ν
TAG_DESC		2	Х	Х	Simple	М	Octet String	32	S
STRATEGY		3	Х	Х	Simple	М	Unsigned 16	2	S
ALERT_KEY		4	Х	Х	Simple	М	Unsigned 8	1	S
TARGET_MODE		5	Х	Х	Simple	М	Unsigned 8	1	S
MODE_BLK		6	Х		Record	М	DS-37	3	
ALARM_SUM		7	Х		Record	М	DS-42	8	D
not used		8							
not used		9							
OUT_TOTAL		10	Х		Record	М	DS-33	5	D
not used		11							
TOT_UNITS		12	Х	Х	Index	М	Unsigned	2	S
not used		13							
CHANNEL		14	Х	Х	Simple	М	Unsigned 16	2	S
RESET_TOT		15	Х	Х	Simple	М	Unsigned 8	1	Ν
MODE_TOT		16	Х	Х	Simple	М	Unsigned 8	1	S
not used		17							
FAIL_TOT		18	Х	Х	Simple	М	Unsigned 8	1	S
not used		19							
POLAR_TOT		20	Х	Х	Simple	М	Unsigned 8	1	S
not used		21							
ALARM_HYS		22	Х	Х	Simple	М	Float	4	S
HI_HI_LIM		23	Х	Х	Simple	М	Float	4	S
HI_LIM		24	Х	Х	Simple	М	Float	4	S
HI_HI_ALM		25	Х		Record	М	DS-39	16	D
HI_ALM		26	Х		Record	М	DS-39	16	D
not used		27							
not used		28							
not used		29							
not used		30							
not used		31							
TOT2_TYPE		32	Х		Simple	0	Unsigned 16	2	Cst
VIEW_TOT		33	Х		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D
* Parameter: $\Omega = \Omega D D D D D D D D D D D D D D D D D $									

All parameters in **Slot 5**, the index are derived from the following tables:

M = Mandatory

All parameters in **Slot 6**, the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class	
AI 4 - Volumeflow Block	1									
BLOCK OBJECT		0	Х		Record	M	DS-32	20	С	
ST_REV	V8H1	1	Х		Simple	M	Unsigned 16	2	N	
TAG_DESC	V8H0	2	Х	Х	Simple	М	Octet String	32	S	
STRATEGY		3	Х	Х	Simple	M	Unsigned 16	2	S	
ALERT_KEY		4	Х	Х	Simple	М	Unsigned 8	1	S	
TARGET_MODE	V6H0	5	Х	Х	Simple	М	Unsigned 8	1	S	
MODE_BLK	V6	6	Х		Record	М	DS-37	3		
ALARM_SUM	V7	7	Х		Record	Μ	DS-42	8	D	
not used		8								
not used		9								
OUT	VO	10	Х		Record	Μ	DS-33	5	D	
PV_SCALE	V0H5/6	11	Х	Х	Record	М	DS-36	11	S	
OUT_SCALE	V0h2/3	12	Х	Х	Record	М	DS-36	11	S	
not used		13								
CHANNEL		14	Х	Х	Simple	М	Unsigned 16	2	S	
not used		15								
PV_FTIME	V0H8	16	Х	Х	Simple	М	Float	4	N	
not used		17								
not used		18								
ALARM_HYS	V1H0	19	Х	Х	Simple	М	Float	4	S	
not used		20								
HI_HI_LIM	V2H0	21	Х	Х	Simple	М	Float	4	S	
not used		22								
HI_LIM	V3H0	23	Х	Х	Simple	М	Float	4	S	
not used		24								
LO_LIM	V4H0	25	Х	Х	Simple	M	Float	4	S	
not used		26								
LO_LO_LIM	V5H0	27	Х	Х	Simple	Μ	Float	4	S	
not used		28								
not used		29								
HI_HI_ALM	V2	30	Х		Record	Μ	DS-39	16	D	
HI_ALM	V3	31	Х		Record	Μ	DS-39	16	D	
LO_ALM	V4	32	Х		Record	М	DS-39	16	D	
LO_LO_ALM	V5	33	Х		Record	Μ	DS-39	16	D	
SIMULATE	V9	34	Х	Х	Record	Μ	DS-50	6	N	
not used		35								
not used		36								
not used		37								
not used		38								
not used		39								
AI4_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst	
VIEW_AI		41	Х		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D	
* Parameter: O = Optional M = Mandatory										

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
ALE - Std. Volumoflow Block									
		0	X		Becord	М	DS-32	20	C
ST REV	V8H1	1	X		Simple	M	Linsigned 16	20	N
	V8H0	2	X	X	Simple	M	Octet String	32	S S
STRATEGY	V0110	2	×	×	Simple	M	Unsigned 16	2	5 Q
		4	×	×	Simple	M		- 1	<u> </u>
	<u>V6H0</u>	5	×	×	Simple	M	Unsigned 8	1	5 Q
	Ve	6	X	~	Becord	M		3	5
	V0 \/7	7	×		Popord	M	DS-37	0	
not used	V7	8	~		necoru	IVI	D0-42	0	
not used		9							
		10	Y		Record	N/	DS-33	5	
		11	X	Y	Record	M	DS-36	11	S
	V0h2/3	12	X	X	Record	M	DS-36	11	<u> </u>
pot used	V0112/3	12	~	~	necoru	IVI	D0-00		5
		1/	X	X	Simple	N/	Unsigned 16	2	ç
		14	^	^	Simple	IVI	Unsigned to	2	3
	<u>МОН8</u>	16	Y	Y	Simple	NA	Float	1	N
	10110	17	~	~	Simple	IVI	Tioat	4	IN
not used		18							
	V1H0	10	V	V	Simplo	N/	Float	1	c
not used	VIIIO	20	~	~	Simple	IVI	Tioat	4	5
	V2H0	20	X	X	Simple	M	Float	1	S
not used	V2110	21	~	~	Ompic		Tioat	-	0
	V3H0	23	X	X	Simple	М	Float	1	S
not used	VOLIO	24	~	~	Omple		Tiout	-	0
	VAHO	25	X	X	Simple	М	Float	1	S
not used	VIIIO	26	~	~	Omple	IVI	Tiout	-	0
	V5H0	27	X	X	Simple	М	Float	4	S
not used	VOLIO	28	~	~	Omple	IVI	Tiout	-	0
not used		29							
	V2	30	X		Record	M	DS-39	16	D
	V3	31	X		Record	M	DS-39	16	D
LO ALM	V4	32	X		Record	M	DS-39	16	D
	V5	33	X		Record	M	DS-39	16	D
SIMULATE	V9	34	Х	Х	Record	M	DS-50	6	N
not used		35						-	
not used		36							
not used		37							
not used		38							
not used		39							
AI5_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst
VIEW_AI		41	Х		Record	M	Unsigned 16,	18	D
_							DS-37, DS-42, DS-33		
* Parameter: $\Omega = \Omega D tional$									

All parameters in **Slot 7**, the index are derived from the following tables:

M = Mandatory

All parameters in **Slot 8**, the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
AI 6 - Targetflow Block									
BLOCK OBJECT		0	Х		Record	M	DS-32	20	С
ST_REV	V8H1	1	Х		Simple	M	Unsigned 16	2	N
TAG_DESC	V8H0	2	Х	Х	Simple	M	Octet String	32	S
STRATEGY		3	Х	Х	Simple	M	Unsigned 16	2	S
ALERT_KEY		4	Х	Х	Simple	M	Unsigned 8	1	S
TARGET_MODE	V6H0	5	Х	Х	Simple	M	Unsigned 8	1	S
MODE_BLK	V6	6	Х		Record	М	DS-37	3	
ALARM_SUM	V7	7	Х		Record	M	DS-42	8	D
not used		8							
not used		9							
OUT	VO	10	Х		Record	M	DS-33	5	D
PV_SCALE	V0H5/6	11	Х	Х	Record	М	DS-36	11	S
OUT_SCALE	V0h2/3	12	Х	Х	Record	M	DS-36	11	S
not used		13							
CHANNEL		14	Х	Х	Simple	M	Unsigned 16	2	S
not used		15							
PV_FTIME	V0H8	16	Х	Х	Simple	M	Float	4	N
not used		17							
not used		18							
ALARM_HYS	V1H0	19	Х	Х	Simple	M	Float	4	S
not used		20							
HI_HI_LIM	V2H0	21	Х	Х	Simple	М	Float	4	S
not used		22							
HI_LIM	V3H0	23	Х	Х	Simple	M	Float	4	S
not used		24							
LO_LIM	V4H0	25	Х	Х	Simple	M	Float	4	S
not used		26							
LO_LO_LIM	V5H0	27	Х	Х	Simple	M	Float	4	S
not used		28							
not used		29							
HI_HI_ALM	V2	30	Х		Record	M	DS-39	16	D
HI_ALM	V3	31	Х		Record	M	DS-39	16	D
LO_ALM	V4	32	Х		Record	M	DS-39	16	D
LO_LO_ALM	V5	33	Х		Record	M	DS-39	16	D
SIMULATE	V9	34	Х	Х	Record	M	DS-50	6	N
not used		35							
not used		36							
not used		37							
not used		38							
not used		39							
AI6_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst
VIEW_AI		41	Х		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D
^r Parameter: O = Optional M = Mandatory									

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
AI 7 - Carrierflow Block	1			1			I		
BLOCK OBJECT		0	Х		Record	M	DS-32	20	С
ST_REV	V8H1	1	Х		Simple	М	Unsigned 16	2	N
TAG_DESC	V8H0	2	Х	Х	Simple	Μ	OctetString	32	S
STRATEGY		3	Х	Х	Simple	Μ	Unsigned 16	2	S
ALERT_KEY		4	Х	Х	Simple	М	Unsigned 8	1	S
TARGET_MODE	V6H0	5	Х	Х	Simple	М	Unsigned 8	1	S
MODE_BLK	V6	6	Х		Record	М	DS-37	3	
ALARM_SUM	V7	7	Х		Record	Μ	DS-42	8	D
not used		8							
not used		9							
OUT	VO	10	Х		Record	Μ	DS-33	5	D
PV_SCALE	V0H5/6	11	Х	Х	Record	Μ	DS-36	11	S
OUT_SCALE	V0h2/3	12	Х	Х	Record	М	DS-36	11	S
not used		13							
CHANNEL		14	Х	Х	Simple	М	Unsigned 16	2	S
not used		15							
PV_FTIME	V0H8	16	Х	Х	Simple	М	Float	4	Ν
not used		17							
not used		18							
ALARM_HYS	V1H0	19	Х	Х	Simple	Μ	Float	4	S
not used		20							
HI_HI_LIM	V2H0	21	Х	Х	Simple	Μ	Float	4	S
not used		22							
HI_LIM	V3H0	23	Х	Х	Simple	М	Float	4	S
not used		24							
LO_LIM	V4H0	25	Х	Х	Simple	М	Float	4	S
not used		26							
LO_LO_LIM	V5H0	27	Х	Х	Simple	М	Float	4	S
not used		28							
not used		29							
HI_HI_ALM	V2	30	Х		Record	М	DS-39	16	D
HI_ALM	V3	31	Х		Record	М	DS-39	16	D
LO_ALM	V4	32	Х		Record	М	DS-39	16	D
LO_LO_ALM	V5	33	Х		Record	М	DS-39	16	D
SIMULATE	V9	34	Х	Х	Record	М	DS-50	6	Ν
not used		35							
not used		36							
not used		37							
not used		38							
not used		39							
AI7_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst
VIEW_AI		41	Х		Record	М	Unsigned 16,	18	D
_							DS-37, DS-42, DS-33		
* Parameter: O = Optional									

All parameters in **Slot 9**, the index are derived from the following tables:

M = Mandatory

All parameters in ${\bf Slot} \ {\bf 10},$ the index are derived from the following tables:

Name	E+H Matrix	Index	Read	Write	Object typ	* Para- meter	Data type	Size bytes	Storage class
AI 8 - Calc. Density Block		0	V		Deservel	N.4	DC 00	00	0
BLOCK OBJECT	VOLIA	0	X		Record	IVI	DS-32	20	
SI_REV	V8H1	1	X	V	Simple	IVI	Unsigned 16	2	N C
IAG_DESC	V8H0	2	X	X	Simple	IVI	Octet String	32	5
		3	X	X	Simple	IVI	Unsigned 16	2	5
	VCLIO	4	X	X	Simple	IVI	Unsigned 8	1	5
	V6HU	5	X	×	Simple			1	5
	V6	0	X		Record	IVI	DS-37	3	
	V /	/	X		Record	IVI	DS-42	8	D
		8							
not used	1/0	9	X		Descul	N 4	D0 00		
	V0	10	X	X	Record	M	DS-33	5	D
PV_SCALE	V0H5/6	11	X	X	Record	M	DS-36	11	S
OUT_SCALE	V0h2/3	12	X	X	Record	M	DS-36	11	S
not used		13			0. 1				0
CHANNEL		14	Х	X	Simple	M	Unsigned 16	2	S
not used		15			0. 1				N.1
PV_FIIME	V0H8	16	Х	X	Simple	M	Float	4	N
not used		17							
not used		18							
ALARM_HYS	V1H0	19	Х	X	Simple	M	Float	4	S
not used		20							
	V2H0	21	X	X	Simple	M	Float	4	S
not used		22							
HI_LIM	V3H0	23	X	X	Simple	M	Float	4	S
not used		24							-
LO_LIM	V4H0	25	Х	X	Simple	M	Float	4	S
not used		26							
	V5H0	27	Х	X	Simple	M	Float	4	S
not used		28							
not used		29							
HI_HI_ALM	V2	30	X		Record	M	DS-39	16	D
HI_ALM	V3	31	Х		Record	M	DS-39	16	D
LO_ALM	V4	32	Х		Record	M	DS-39	16	D
LO_LO_ALM	V5	33	Х		Record	M	DS-39	16	D
SIMULATE	V9	34	Х	X	Record	M	DS-50	6	N
not used		35							
not used		36							
not used		37							
not used		38							
not used		39							
AI8_TYPE		40	Х		Simple	0	Unsigned 16	2	Cst
VIEW_AI		41	Х		Record	M	Unsigned 16, DS-37, DS-42, DS-33	18	D
* Parameter: O = Optional M = Mandatory									

Note

5.10 Commuwin II operating matrix

Note!

Several operating matrixes are available in Commuwin II. They are all shown with their basic settings. Additional functions might become available depending on selection of specific functions.

Transmitter Device-Block (evaluation mode 1), PROFIBUS-DP

	ЮН	Ŧ	H2	H3	H4	H5	9H	2Н	H8	6Н
V0 MEASURED VALUE	MASS FLOW	TOTALIZER 1	TOTALIZER 1 OVERFLOW							
V1 MEASURED VALUE	DENSITY	TEMPERATURE								
V2 COMMUNI- CATION	EVALUATION MODE	ACCESS CODE	DIAGNOSTIC CODE	LOC OPERATION	BUS ADDRESS		SW-VERSION COM	HW-VERSION DP		
V3 SYSTEM UNITS	MASS FLOW UNIT	MASS UNIT			GALLON / BARREL			PIPE SIZE UNIT		
V4 DISPLAY	RESET TOTALIZER	ASSIGN TOTAL 1	ASSIGN TOTAL 2	LCD CONTRAST	LANGUAGE	DISPLAY DAMPING	DISPLAY LINE 1	DISPLAY LINE 2	FORMAT FLOW	
V5										
V6										
V7 PROCESSING PARAMETER	LOW FLOW CUTOFF	NOISE SUPPRESSION	DEVICE MODE	FLOW DIRECTION	EPD THRESHOLD	DENSITY FILTER	SELF CHECK			
V8 SYSTEM PARAMETER		ZERO ADJUST			POS. ZERO RETURN					
V9 SENSOR DATA	CALIBR. FACTOR	ZERO POINT	NOMINAL DIAMETER	SENSOR DATA		SERIAL NUMBER	SOFTWARE VERSION			
VA SENSOR	TAG NUMBER									

Commuwin II Operating matrix Transmitter Device Block (evaluation mode 2), PROFIBUS-DP

бH											
H8					FORMAT FLOW						
H7			HW-VERSION DP		DISPLAY LINE 2						
9H			SW-VERSION COM		DISPLAY LINE 1					SOFTWARE VERSION	
H5					DISPLAY DAMPING					SERIAL NUMBER	
H4			BUS ADDRESS		LANGUAGE				POS. ZERO RETURN		
НЗ			LOC OPERATION		LCD CONTRAST					SENSOR DATA	
H2	TOTALIZER 1 OVERFLOW		DIAGNOSTIC CODE	TEMPERATURE UNIT	ASSIGN TOTAL 2					NOMINAL DIAMETER	
Ħ	TOTALIZER 1	TEMPERATURE	ACCESS CODE		ASSIGN TOTAL 1		VOLUME FLOW MEAS.	CALIBR. MODE	ZERO ADJUST	ZERO POINT	
ОН	MASS FLOW	DENSITY	EVALUATION MODE	DENSITY UNIT	RESET TOTALIZER		CALC. DENSITY	DENS. ADJ. VALUE		CALIBR. FACTOR	TAG NUMBER
	V0 MEASURED VALUE	V1 MEASURED VALUE	V2 COMMUNI- CATION	V3 SYSTEM UNITS	V4 DISPLAY	V5	V6 DENSITY FUNCTION	V7 DENSITY FUNCTION	V8 SYSTEM PARAMETER	V9 SENSOR DATA	VA SENSOR

	:	:		:	:	:		!		
	ЮН	Ŧ	H2	H3	H4	H5	H6	Η	H8	H9
V0 MEASURED VALUE	MASS FLOW	TOTALIZER 1	TOTALIZER 1 OVERFLOW							
V1 MEASURED VALUE	DENSITY	TEMPERATURE								
V2 COMMUNI- CATION	EVALUATION MODE	ACCESS CODE	DIAGNOSTIC CODE	LOC OPERATION	BUS ADDRESS		SW-VERSION COM	HW-VERSION PA		
V3 SYSTEM UNITS	MASS FLOW UNIT	MASS UNIT			GALLON / BARREL			PIPE SIZE UNIT		
V4 DISPLAY	RESET TOTALIZER	ASSIGN TOTAL 1	ASSIGN TOTAL 2	LCD CONTRAST	LANGUAGE	DISPLAY DAMPING	DISPLAY LINE 1	DISPLAY LINE 2	FORMAT FLOW	
V5 SELECT CURRENT	ASSIGN OUTPUT	VALUE FOR 0/4 mA	FULL SCALE 1				TIME CONSTANT	CURRENT RANGE	FAILSAFE MODE	SIMULATION CURR.
V6										
V7 PROCESSING PARAMETER	LOW FLOW CUTOFF	NOISE SUPPRESSION	DEVICE MODE	FLOW DIRECTION	EPD THRESHOLD	DENSITY FILTER	SELF CHECK			
V8 SYSTEM PARAMETER		ZERO ADJUST			POS. ZERO RETURN					
V9 SENSOR DATA	CALIBR. FACTOR	ZERO POINT	NOMINAL DIAMETER	SENSOR DATA		SERIAL NUMBER	SOFTWARE VERSION			
VA SENSOR	TAG NUMBER									

Commuwin II Operating matrix Transmitter Device-Block (evaluation mode 1), PROFIBUS-PA

Commuwin II Operating matrix Transmitter Device-Block (evaluation mode 2), PROFIBUS-PA

бН						SIMULATION CURR.					
H8					FORMAT FLOW	FAILSAFE MODE					
H7			HW-VERSION PA		DISPLAY LINE 2	CURRENT RANGE					
НG			SW-VERSION COM		DISPLAY LINE 1	TIME CONSTANT				SOFTWARE VERSION	
H5					DISPLAY DAMPING					SERIAL NUMBER	
H4			BUS ADDRESS		LANGUAGE				POS. ZERO RETURN		
H3			LOC OPERATION		LCD CONTRAST					SENSOR DATA	
H2	TOTALIZER 1 OVERFLOW		DIAGNOSTIC CODE	TEMPERATURE UNIT	ASSIGN TOTAL 2	FULL SCALE 1				NOMINAL DIAMETER	
Ħ	TOTALIZER 1	TEMPERATURE	ACCESS CODE		ASSIGN TOTAL 1	VALUE FOR 0/4 mA	VOLUME FLOW MEAS.	CALIBR. MODE	ZERO ADJUST	ZERO POINT	
Ю	MASS FLOW	DENSITY	EVALUATION MODE	DENSITY UNIT	RESET TOTALIZER	ASSIGN OUTPUT	CALC. DENSITY	DENS. ADJ. VALUE		CALIBR. FACTOR	TAG NUMBER
	V0 MEASURED VALUE	V1 MEASURED VALUE	V2 COMMUNI- CATION	V3 SYSTEM UNITS	V4 DISPLAY	V5 SELECT CURRENT	V6 DENSITY FUNCTION	V7 DENSITY FUNCTION	V8 SYSTEM PARAMETER	V9 SENSOR DATA	VA SENSOR

H8										AGNOSIS DIAG MA	DFTWARE- ESET
H7										HARDWARE D VERSION E)	SECURITY SC LOCKING RI
9H										SOFTWARE VERSION	DEVICE CERTIFICAT
H5										MASK 3	MESSAGE
H4										MASK 2	INSTALLATION DATE
H3										MASK	SERIAL NUMBER
H2										DIAGNOSIS 3	DEVICE
H								DISABLE	ST REVISION	DIAGNOSIS 2	MANU- FACTURER ID
ОН								CURRENT	TAG NUMBER	DIAGNOSIS	DESCRIPTOR
	٨٥	17	V2	V3	V4	V5	VG	V7 ALARM- STATUS	V8 BLOCK ARAMETER	V9 DIAGNOSIS	VA DEVICE DATA

Commuwin II Operating matrix Transmitter Physical Block, PROFIBUS-DP/-PA Commuwin II Operating matrix Transmitter Flow Block, PROFIBUS-DP/-PA

Commuwin II Operating matrix

Transmitter Analog Input Block, PROFIBUS-DP /-PA (here only one Transmitter Analog Input Block is shown, all other Transmitter Analog Input Blocks are identical).

	ОН	H	H2	H3	H4	H5	ЭН	H7	H8	Н
V0 OUT	OUT VALUE	OUT STATUS	OUT MIN	OUT MAX	OUT UNIT	PV MIN	PV MAX	PV SCALE UNIT	INTEGRATION TIME	
V1 Alarm- Limits	ALARM HYSTERESE									
V2 HI_HI_ALARM	ні_ні_LіМ	VALUE	ALARM STATUS	SWITCH ON POINT	SWITCH OFF POINT					
V3 HI_ALARM	HI_LIM	VALUE	ALARM STATUS	SWITCH ON POINT	SWITCH OFF POINT					
V4 LO_ALARM	MITO	VALUE	ALARM STATUS	SWITCH ON POINT	SWITCH OFF POINT					
V5 LO_LO_ALARM	WI7_LO_LO_	VALUE	ALARM STATUS	SWITCH ON POINT	SWITCH OFF POINT					
V6 BLOCK MODE	TARGET MODE	ACTUAL	PERMITTED	NORMAL						
V7 ALARM- SUMMARY	CURRENT	DISABLE								
V8 BLOCK- PARAMETER	TAG NUMBER	ST REVISION								
V9 SIMULATION	VALUE	STATUS	ON OFF							
VA										

6 Operation

6.1 Display and operating elements



Fig. 21 Display and operating elements

6.2 E+H operating matrix (select functions)







Fig. 22 Selecting functions in the E+H operating matrix



DENSITY UNIT

STAND. VOLUME UNIT p. 73

STDVOL. FLOW UNIT p. 73

GALLONS/ BARREL p. 73

VOLUME UNIT

p. 72

VOL. FLOW UNIT p. 72

MASS UNIT

MASS FLOW UNIT p. 72

1

SYSTEM UNITS

p. 72

p. 74

FIXED STD. DENSITY p. 85

EXP. COEF. p. 85

REFERENCE TEMP. p. 84

STD. VOLUME CALC. p. 84

VOLUME FLOW MEAS. p. 84

CALC. DENSITY

DENSITY ADJUST

p. 84

p. 81

DENS. ADJUST VALUE p. 81

1

DENSITY FUNCTION

LANGUAGE

LCD CONTRAST

FORMAT FLOW

p. 88

p. 87

p. 87

DISPLAY DAMPING p. 87

ASSIGN LINE 2

ASSIGN LINE 1

p. 87

p. 87

1

DISPLAY

UNIT TO BUS

SYSTEM CONFIG.

TAG NUMBER

BUS ADDRESS

p. 89

p. 89

p. 89

p. 89

Î

COMMUNICATION

TEMPERATURE

CALC. DENSITY

DENSITY p. 69

CARRIER FLOW

TARGET FLOW

STD. VOLUME FLOW p. 68

VOLUME FLOW

MASS FLOW

1

PROCESS VARIABLE

p. 68

p. 68

p. 69

p. 68

p. 69

p. 69

ASSIG. TOTAL. 2

TOTAL. 1

ASSIG. 7

RESET TOTALIZER

p. 71

p. 71

p. 70

TOTALIZER 2 OVERFLOW p. 70

TOTALIZER 2

p. 70

TOTALIZER 1 OVERFLOW p. 70

TOTALIZER 1

1

TOTALIZER

p. 70

p.95

p. 95

SW-VERSION COM p. 95

PREVIOUS SYSTEM CONDITIONS p. 94

PRESENT SYSTEM P CONDITION p. 94

ACCESS CODE

DEF. PRIVATE CODE p. 93

POS. ZERO RETURN p. 93

ZEROPOINT ADUUST p. 93

1

SYSTEM PARAMETER

p. 94

SOFTWARE VERSION p. 97

SERIAL NUMBER

SENSOR COEF.

p. 97

p. 96

NOMINAL DIAMETER p. 96

ZEROPOINT p. 96

K-FACTOR

p. 96

↑

SENSOR DATA

SYSTEM RESET

PRES. PULSE SUPPR. p. 92

SELF CHECKING

DENSITY FILTER

EPD THRESHOLD

FLOW DIRECTION

MEASURING MODE p. 90

NOISE SUPPRESS. p. 90

LOW FLOW CUTOFF p. 90

1

PROCESSING PARAMETER

p. 91

p. 91

p. 91

p. 91





Further information on programming

For the Promass 63 measuring system, there is a wide choice of functions available which the user can set individually and adapt to process conditions.

Please follow the listed important programming notes:

- If the power supply cuts out, all calibrated and set values are safely stored in the EEPROM (without requiring batteries).
- Functions which are not required, e.g. volume flow, can be set to "OFF".
 In this case the appropriate functions in other function groups do no longer appear on the display.
- If, while programming, you wish to undo a setting carried out with "CANCEL" option. This is only possible for settings which have not yet been saved by pressing E.
- In certain functions, a prompt is given after entering data for safety reasons.
 Select "SURE? [YES]" with the ⊕ keys and confirm by pressing E again.
 The setting is now saved or a function, e.g. zero point calibration, is activated.
- The Promass may not show values with all decimal places as this depends on the engineering unit used and the number of decimal places selected, see function "FORMAT FLOW", page 87). During data input an arrow is, therefore, shown between the measured value and the engineering unit (e.g. 1.2 → kg/h).

Enable programming (entering the code number)

Normally programming is locked. Any unauthorized changes to the instrument functions, values, or factory settings are, therefore, not possible. Only a code has been entered (factory setting = 63), parameters can be entered or changed. The use of a personal code number, which can be freely chosen, prevents unauthorized personnel from gaining access to data (see page 93).

Caution!

- If programming is locked and the [⊕] keys are pressed in a given function a prompt to enter the code is automatically displayed.
- With code "0" (zero), the programming is **aways** enabled!
- If the personal code number is no longer available, please contact the Endress+Hauser service organization, which will pleased to help you.

Locking the programming function

- After returning to the HOME position, programming is again locked after 60 seconds if no operating element is pressed.
- Programming can also be locked by entering any number (other than the customer code number) in the "ACCESS CODE" function.



6.3 Example of programming

If you want to change the bus address setting from "126" to "25", proceed as follows:

						/			DRESS+I OMASS	HAUSER							
				/	/	ł		NK E	נ [פ	2)()	$\Big\rangle$				
		,	/				/	\sim) 	/					\backslash	
E)	Enter the operating matrix	P	R	0	С	F	S	S		v	Δ	R	1	Δ	в	I	F
		>		G	R	0	U	P		s	E	L	Ē	C	Т		<
_			_							_		_	-				
+	select the desired function aroup "COMMUNICATION"	C	0	M	M	U	N	I D	С	A c	T	1	0	N	т	\vdash	
	9.00p 00	_		u	n	U	U	r		3	E	-	L	C	•	•	_
E	Select function "BUS ADDRESS"					1	2	6									
		В	U	S		A	D	D	R	Е	S	S					
+)	On pressing $+$ or $-$ the entry of the							0									
Ċ	code is automatically prompted.	A	С	С	Е	s	s	•	С	0	D	Е					
		_															
+	Enter the code number				_		6	3	_	_	_	_					
	1 actory setting = 05	Α	С	С	E	S	S		С	0	D	E					
E	Programming is now enabled.																
		Е	D	I	т	I	Ν	G		Е	Ν	A	в	L	Е	D	
						4		•									(
	The programmable value hashes.	В	U	S		1 4	2 D	6 D	R	F	S	S					
_			•					_		-	•	-					
+]	Select the desired address. The display stops flashing.						2	5									
	Setting: 25	В	U	S		Α	D	D	R	Ε	S	S					
E)	Save the input.																
<u> </u>		I	N	Ρ	U	т		s	т	0	R	Е	D				
	The display flashes and the value	_															
	can be changed once again.	-		-			2	5	_	_	_	•					
		в	U	S		A	D	D	к	E	S	S			[
ស្ម	Return to the "HOME" position (press	the	E) ke	ΞV	for	m	ore	e th	nan	13	se	c.)).			
E	In the "HOME" position, the programm	ning	le	ve	l is	lo	cke	ed	ag	jair	٦a	fte	er 6	i0 s	sec	c. if	fn
	of the operating keys are pressed.																

E Select other functions. Following the last function, there is an automatic return to >GROUP SELECT.<.

в	Α	С	κ		т	0		G	R	0	U	Ρ	
		s	Е	L	Е	С	т	I	0	Ν			

7 Commissioning

7.1 Zero-Point adjustment

All Promass 63 transmitters are calibrated using the most up-to-date technology available. The zero-point is printed on the nameplate. Calibration is carried out at reference conditions (see page 129). Therefore, a zero-point adjustment for Promass is basically **not** necessary!

Practical experience has shown that a zero-point adjustment is recommended only in special cases:

- to achieve the highest possible measuring accuracy
- for extreme process conditions (e.g in case of very high fluid temperatures or very high viscosity of the liquid).

Requirements for zero-point adjustment

- Fluids without gas or solids.
- Zero-point adjustment is carried out using completely filled measuring tubes and at no-flow with e.g. shut-off valves both upstream and downstream of the sensor or by using existing shut-off and sliding valves, etc.:

Normal operation

• Open valves A and B

Zero-point calibration **with** pump pressure

- Open valve A
- Close valve B

Zero-point calibration **without** pump pressure

- Close valve A
- Open valve B

Caution!

With difficult fluids (outgassing fluids or fluids with solids content), it is possible that a stable zero-point cannot be achieved despite carrying out a number of zero-point adjustments. In such cases, please contact your E+H Service Centre.

Actual zero-point \rightarrow see page 96





Fig. 23 Zero-point adjustment and shut-off valves

ba033y11

Carrying out a zero-point adjustment

- 1. Run the plant for as long as necessary until it is operating normally.
- 2. Stop the flow.
- 3. Check the shut-off valves (for leaks). Also check the operating pressure.
- 4. Carry out the adjustment using the local display as follows:

Display / Operating keys

স E	PROCESS VARIABLE > GROUP SELECT. <	Enter the operating matrix
+	SYSTEM PARAMETER > GROUP SELECT. <	Select function group "SYSTEM PARAMETER"
+	CANCEL ZERO-POINT ADJUST	Select function "ZERO-POINT ADJUST"
+	0 ACCESS CODE	On pressing 🗄
+	63 ACCESS CODE	Enter access code (63 = factory setting, access code can be changed)
E	EDITING ENABLE	Press "ENTER"
	CANCEL ZERO-POINT ADJUST	Display flashes
+	START ZERO-POINT ADJUST	Select "START"
E	SURE? [NO] ZERO-POINT ADJUST	Safety query on the display
+	SURE? [YES] ZERO-POINT ADJUST	Select "YES" and press "ENTER"
E	S: ZERO ADJUST RUNNING	This message is displayed during zero-point adjustment for approx. 3060 sec. If the velocity of the fluid is >0.1 m/s, an error message is displayed.
	CANCEL ZERO-POINT ADJUST	Zero-point calibration is completed. The new zero-point value can immediately be called up with the diagnosis function (simultaneously pressing $\stackrel{[*]}{=}$). The value in the function "ZERO-POINT" is overwritten.
۲ E	Back to HOME position (= disp	' ay during normal measuring operation)

7.2 Gas measurement

Introductory remarks

The Promass 63 is not only suitable for measuring liquids. Direct mass flow measurement using the Coriolis principle is also useful for gases.

In contrast to liquids, other flow ranges and accuracies are to be noted when using it for gas applications.

Specific settings for gas measurement

- Deactivate EPD (in function group "PROCESSING PARA.", see page 91)
 In order to measure even at low gas pressures, the EPD function must be switched off. This is done by entering an EPD response value of 0.0000 kg/l.
- Adapt low flow cutoff (in function group "PROCESSING PARA.", see page 90) Due to the low flow rate with gas flow measurement, the low flow cutoff value must be set accordingly.

3) Standard volume measurement

If the standard volume flow is to be displayed and made available at the output (e.g. in Nm³/h) instead of the mass flow rate (e.g. in kg/h), then the following settings are to be selected or values entered:

- Function "VOLUME FLOW MEAS." (see page 84) → Select "STD. VOLUME FLOW"
- Function "STD. VOL. CALC." (see page 84) → Select "FIXED STD. DENSITY"
- Function "FIXED STD. DENSITY" (see page 85) → Input of the gas-dependent standard density (i.e. the density calculated from the reference temperature and pressure).
 Example for air: Standard density = 1.2928 kg/Nm³ (at 0 °C and 1.013 bar)
- Function "STD. DENSITY UNIT" (see page 74) \rightarrow Select the desired unit
- Function "STD. VOLUME UNIT" (see page 73) \rightarrow Select the desired unit
- Normal volume flow can now be assigned to
 → a display line (see page 87)
 → the current output PROFIBUS-PA (see page 73)

8 Function Description

This section lists in detail a description as well as all information required for the individual functions of the Promass 63. Factory settings are shown in *bold italics*. On request, Promass 63 measuring instruments are also available with customised parameterisation. In such case, values/settings may differ from the factory setting shown here.

Function group	PROCESS VARIABLE	\rightarrow	page 68
Function group	TOTALIZER	\rightarrow	page 70
Function group	SYSTEM UNITS	\rightarrow	page 72
Function group	CURRENT OUTPUT	\rightarrow	page 75
Function group	DENSITY FUNCTION	\rightarrow	page 79
Function group	DISPLAY	\rightarrow	page 87
Function group	COMMUNICATION	\rightarrow	page 89
Function group	PROCESSING PARAMETER	\rightarrow	page 90
Function group	SYSTEM PARAMETER	\rightarrow	page 93
Function group	SENSOR DATA	\rightarrow	page 96

Caution! Important when programming

- Many functions and options are only displayed when other functions have been adequately configured.
- Functions not required, e.g. current output, can be switched "OFF". Corresponding functions in other function groups will then not be displayed. Functions can only be switched off if the appropriate settings in other functions have been **previously** reconfigured.

Example 1:

The function "VOLUME FLOW MEAS" (see page 84) is set to "OFF". Therefore, the functions "VOL.FLOW UNIT / VOLUME UNIT / STD.VOL.FLOW UNIT", etc. do not appear on the display. As a result, the "VOLUME FLOW" option in the "ASSIGN OUTPUT" function can no longer be selected.

Example 2:

The "ASSIGN TOTAL. 1" function is set to "VOLUME" (see page 71). In the "VOLUME FLOW MEAS." function, the "OFF" option can no longer be selected.

- If, while programming, you wish to undo a setting carried out with "CANCEL". This is only possible for settings which have not yet been saved by pressing E.
- In certain functions, a prompt is given after entering data for safety reasons. Select "SURE? [YES]" with the [↑] keys and confirm by pressing ^E again. The setting is now saved or a function, e.g. zero-point calibration, is activated.
- The Promass may not show values with all decimal places as this depends on the engineering unit used and the number of decimal places selected. During data input an arrow is, therefore, shown between the measured value and the engineering unit (e.g. $1.2 \rightarrow kg/h$).





Notes!



Function group PROCESS VARIABLE

• The engineering units of all variables shown here can be set in the "SYSTEM-UNITS" function group.





Function group PROCESS VARIABLE		
CARRIER FLOW	After selecting this function, the display automatically shows the currently measured flow rate of the carrier fluid as a mass or volumetric flow rate. <i>Carrier fluid</i> = transporting material, e.g. water (see page 79). Display: 5-digit number with floating decimal point, incl. units and arithmetical sign	
	(e.g. 0.0835 m ³ /h; 16.4359 t/h; etc.) Note! This function is only available if the setting "%-MASS", "%-ALCOHOL", "%-BLACK LIQUOR" or "%-VOLUME" is selected in the function "CALC. DENSITY" within the function group "DENSITY FUNCTION".	
DENSITY	Selecting this function automatically displays the current fluid density or its specific gravity. Display: 5-digit number with fixed decimal point, incl. engineering units corresponding to 0.100006.0000 kg/dm ³ (e.g. 1.2345 kg/dm ³ ; 993.5 kg/dm ³ ; 1.0015 SG_20 °C; etc.)	
CALC. DENSITY	After selecting this function, the display automatically shows the calculated value using a density function (see function group "DENSITY FUNCTION", page 79 ff.). Display: 5-digit number with fixed decimal point, incl. units (e.g. 76.409 °Brix; 39.170 %v; 1391.7 kg/Nm ³ ; etc.) Display of current density function used by the measuring system, e.g. °BRIX, %-VOLUME, etc. Note! This function is only available, if a density function is selected in the function "CALC. DENSITY" within the function group "DENSITY FUNCTION".	
TEMPERATURE	Selecting this function the current temperature of the fluid is automatically displayed. Display: max. 4-digit number with fixed decimal point, incl. engineering units and arithmetic sign (e.g23.40 °C; 160.0 °F; 295.4 K, etc.)	





	Function group TOTALIZER		
	TOTALIZER 1	Selecting this function automatically displays the totalised flow quantity from when measurement began. This value is either positive or negative depending on the direction of flow.	
7		 Notes! If the count has more figures than can be shown, e.g. with overflow, then the symbols ">" (pos. values) or "-" (neg. values) are shown before the value. If the function "MEASURING MODE" is set to "UNIDIRECTIONAL" (see page 90), then the totalizer only registers flow in the positive direction. 	
		Display: max. 7-digit number with floating decimal point, incl. engineering units (e.g. 1.546704 t; -4925.631 kg)	
		ASSIGN TOTAL. 1 • Display of which measuring variable is assigned to totalizer 1.	
	TOTAL. 1 OVERFLOW	The totalised flow is shown as a max. 7-digit number with floating decimal point. Larger numbers (>9 999 999) can be read off in this function as overruns. The effective amount is calculated from the sum of the 'overrun' and the value shown in the function "TOTALIZER 1".	
		Example: Display of 2 overruns: 2 e7 kg (= 20,000,000 kg). The value shown in the function "TOTALIZER 1" is 196,845.7 kg. Total amount = 20,196,845.7 kg	
7		 Note! This function is displayed only if overruns have occurred. The value 0 e7 (incl. units) is shown in the HOME position, if <i>no</i> overrun occurs. 	
		Display: Integer to a decimal power e.g. 10 e7 kg	
		ASSIGN TOTAL. 1 • • • Display of which measuring variable is assigned to totalizer 1.	
	TOTALIZER 2	Function description \rightarrow corresponding to function "TOTALIZER 1"	
	TOTAL. 2 OVERFLOW	Function description \rightarrow corresponding to "TOTAL. 1 OVERFLOW"	
<u>}</u>	RESET TOTALIZER	The totalizers can be reset to 'Zero' in this function (= reset). Note! The OVERFLOW as well as the value shown in the "TOTALIZER 1" function are reset to zero. CANCEL – TOTALIZER 1 – TOTALIZER 2 – TOTALIZERS 1&2	







Note!

Function group TOTALIZER			
ASSIGN TOTAL. 1	 With this function, a desired variable can be assigned to totalizer 1. Note! The totalizer is reset to zero if the assignment in this function is changed again. OFF - MASS - MASS (+) - VOLUME - STD. VOLUME VOLUME (+) - STD. VOLUME (+) - TARGET MATERIAL - TARGET MAT. (+) - CARRIER FLUID - CARRIER FLUID (+) CANCEL (+): The totalizer only registers flow in the positive direction. INIDIRECTIONAL or BIDIRECTIONAL (+): Display to show whether the flowmeter measures in one or in both flow directions (see "MEASURING MODE" function, page 90). 		
ASSIGN TOTAL. 2	 With this function, a variable required can be assigned to totalizer 2. Note! The totalizer is reset to zero if the assignment in this function is changed again. OFF - MASS - MASS (·) - VOLUME - STD. VOLUME VOLUME (·) - STD. VOLUME (·) - TARGET MATERIAL - TARGET MAT (·) - CARRIER FLUID - CARRIER FLUID (·) CANCEL (·): The totalizer only registers flow in the <i>negative</i> direction. UNIDIRECTIONAL or BIDIRECTIONAL Display to show whether the flowmeter measures in one or in both flow directions (see "MEASURING MODE" function, page 90). 		

	Function group SYSTEM-UNITS
MASS FLOW UNIT	 With this function, select the engineering units required from those displayed mass flow rate (mass/time). The engineering units selected here also define those for: zero and full scale value for current creep rate flow rate of the target and carrier fluid g/min - g/h - kg/s - kg/min - kg/h - t/min - t/h - t/d - lb/s lb/min - lb/hr - ton/min - ton/hr - ton/day - CANCEL Display of current mass flow rate. The total flow rate is always display also with two-phase media.
MASS UNIT	 This function select the engineering units from those displayed for mass. The engineering units selected here also define those for: totalizer g - kg - t - lb - ton - CANCEL
VOLUME FLOW UNIT	 With this function, the units required for flow rate (volume/time) can be select from those displayed. The volumetric flow rate is derived from the measured fluid density and the mass flow rate. The units selected here also define those for: zero and full-scale value of the current output flow rate of the target and carrier fluid t cm³/min - cm³/h - dm³/s - dm³/min - dm³/h - I/s - I/min I/h - hI/min - hI/h - m³/min - m³/h - cc/min - cc/hr - gal/min gal/hr - gal/day - gpm - gph - gpd - mgd - bbl/min - bbl/hr bbl/day - CANCEL Display of actual volumetric flow rate. The total flow rate is always displayed, also with two-phase media.
VOLUME	Note! This function is only available if the setting "VOLUME FLOW" or "VOLUME & STD.VOL" is selected in the function "VOLUME FLOW MEAS" within the function group "DENSITY FUNCTION". In this function, the units required for volume are selected from those displayed
UNIT	The volumetric flow rate is derived from the measured fluid density and the mass flow rate. The engineering units selected here also define those for the totalizers. (*) $cm^3 - dm^3 - 1 - hl - m^3 - cc - gal - bbl - CANCEL$ Note! This function is only available if the setting "VOLUME FLOW" or "VOLUME & STD.VOL" is selected in the function "VOLUME FLOW MEAS" within the function group "DENSITY FUNCTION".



Note!
Function group SYSTEM-UNITS	
GALLONS/ BARREL	In the US and the UK, the ratio of barrels (bbl) to gallons (gal) is defined according to the fluid used and the specific industry. Therefore, the following definitions have to be selected: • US or imperial gallons • ratio gallons/barrel
	Note! The definition selected here also determines the engineering unit in other functions e.g. in "VOLUME UNIT, VOLUME FLOW UNIT, DENSITY UNIT". If a new definition is selected, the values in the display will change accordingly.
	$\begin{array}{c c} \bullet & US: 31.0 \text{ gal/bbl} \rightarrow & \text{for beer} \\ \hline \textbf{US: 31.5 gal/bbl} \rightarrow & \text{for liquids (used in normal cases)} \\ US: 42.0 \text{ gal/bbl} \rightarrow & \text{for oil (petrochemicals)} \\ US: 55.0 \text{ gal/bbl} \rightarrow & \text{for filling tanks} \end{array}$
	Imp: 36.0 gal/bbl \rightarrow for beer and similar liquids Imp: 42.0 gal/bbl \rightarrow for oil (petrochemicals)
	US: 1 gal = 3.785 l (litre) + - Imp: 1 gal = 4.546 l (litre)
STDVOL. FLOW UNIT	With this function, the units required for a standard volumetric flow rate (standardized volume/time) are selected from those displayed. The standard volumetric flow rate is derived from the measured fluid density (see page 79) and the mass flow rate. The units selected here also define those for: • zero and full-scale value of the current output
	 NI/s - NI/min - NI/h - NI/d - Nm³/s - Nm³/min - Nm³/h - Nm³/d - scm/s - scm/min - scm/hr - scm/day - scf/s - scf/min - scf/hr - scf/day - CANCEL
	 Display of the actual standardized volumetric flow rate.
	Note! This function is only available if the setting "STD. VOLUME FLOW" or "VOLUME & STD.VOL" is selected in the function "VOLUME FLOW MEAS" within the function group "DENSITY FUNCTION".
STD. VOLUME UNIT	With this function, the units required for standardized volume are selected from those displayed. The standardised volume is derived from the standardized density (see page 79) and the mass flow rate.
	+ Nm ³ - NI - scm - scf - CANCEL
	Note! This function is only available if the setting "STD. VOLUME FLOW" or "VOLUME & STD.VOL" is selected in the function "VOLUME FLOW MEAS" within the function group "DENSITY FUNCTION".





Function group SYSTEM-UNITS	
DENSITY UNIT	 With this function, select the required engineering units from those displayed for density. The units selected here also define those for: zero and full-scale value for current density response value for Empty Pipe Detection density adjustment value
	 + g/cm³ - kg/dm³ - kg/l - kg/m³ - SD_4 °C - SD_15 °C - SD_20 °C g/cc - lb/cf - lb/USgal resp. lb/gal * - lb/bbl - SG_59 °F - SG_60 °F - SG_68 °F - SG_4 °C - SG_15 °C - SG_20 °C - CANCEL
	* see "GALLON/BARREL" function, page 73
	SD = Specific Density, SG = Specific Gravity The specific gravity is the ratio between the density of the fluid and the density of water (at water temperatures = 4, 15, 20 °C or 59, 60, 68 °F
	 Display showing current density or specific gravity.
STD. DENSITY UNIT	 With this function, the units required for the standardized fluid density are selected from those displayed. The units selected here also define those for: zero and full-scale value for current fixed standard density (to measure standard volume flow)
	+ kg/Nm³ - kg/NI - g/scc - kg/scm - Ib/scf - CANCEL
	 Display of actual standard density value.
	Note! This function is only available, if a density function is selected in the function "CALC. DENSITY" within the function group "DENSITY FUNCTION".
TEMPERATURE UNIT	With this function, select the required engineering units from those displayed for temperature. The units selected here also define those for: • zero and full scale value for current • reference temperature (for density functions) • min./max. temperatures (sensor coefficients)
	+ °C (CELSIUS) – K (KELVIN) – °F (FAHRENHEIT) – °R (RANKINE) – CANCEL
	 Display showing the current medium temperature
NOM. DIAM. UNIT	With this function, select the required engineering units from those shown for the nominal diameter of the sensor.
	mm – inch – CANCEL
	Display showing the nominal diameter of the sensor in current use.



Function group CURRENT OUTPUT (only with PROFIBUS-PA available)		
ASSIGN OUTPUT	In this function, any variable required can be assigned to the current output. OFF - MASS FLOW - VOLUME FLOW - STD. VOLUME FLOW TARGET FLOW - CARRIER FLOW - DENSITY - CALC. DENSITY - TEMPERATURE - CANCEL	
	 Diagnosis (for flow rate variables only): UNIDIRECTIONAL or BIDIRECTIONAL: Display showing if the flowmeter is measuring in one or both flow directions. With unidirectional measurement a 0/420 mA current signal is only produced for the positive flow direction (forward); the current stays at 0 or 4 mA for the negative direction. 	
ZERO SCALE	 In this function, assign the 0/4 mA quiescent current to the required zero value. Notes! The zero value can be larger or smaller than the "full scale value". (see function "FULL SCALE", page 76) The range between the zero and full scale value should not fall below a minimum value (see Figure): 	
	20.5 20.5 20.5 20.5 20.5 20.5 20 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	
	Negative measured values Negative measured values	
	Min. set value Min. range Max. set value $Q = -180 \text{ t/h}^{**}$ $Q = 0.5 \text{ m/s}^{*}$ $Q = 180 \text{ t/h}^{**}$ $\rho = 0.0 \text{ kg/dm}^3$ $\rho = 0.1 \text{ kg/dm}^3$. $\rho = 5.999 \text{ kg/dm}^3$ $T = -273.15 \text{ °C}$ $T = 10 \text{ K}$ $T = 300.00 \text{ °C}$ ① Zero scale value 020 mA * depent on density ? Zero scale value 420 mA ** depentent on nominal diameter ③ Full scale value 0/420 mA **	
	 5-digit number with floating decimal point and arithmetic sign (e.g1.500 kg/h; 245.92 kg/m³; 105.60 °C) Factory setting: 0.0000 kg/h resp. 0.0000 kg/l resp50.000 °C Display showing which process variable is assigned to the current output. 	





Function group CURRENT OUTPUT (only with PROFIBUS-PA available)		
TIME CONSTANT	Selecting the time constant quickly (small time constant slowly (long time constant). of the display.	determines whether the current output signal reacts) to rapidly fluctuating variables e.g. flow rate or The time constant does not influence the behaviour
	+ 3-digit number with Factory setting: 1.00	floating decimal point (0.01100.00 s)) s
	Display showing wh	ich process variable is assigned to
CURRENT SPAN	With this function, set the 0/- full-scale value (100%) is all current output correspondin the current output with a ma	4 mA quiescent current. The current for the scaled ways 20 mA. A choice can be made between the g to NAMUR recommendations (max. 20.5 mA) or ximum of 25 mA.
	Note! The current output can be d the full scale value depending	riven up to 125% (25 mA) or 102.5% (20.5 mA) of ng on the current span selected here.
	+ 0–20 mA (25 mA) 4–20 mA (25 mA) 0–20 mA 4–20 mA CANCEL	→ maximum 25 mA → maximum 25 mA → maximum 20.5 mA (NAMUR) → maximum 20.5 mA (NAMUR)
	Display showing wh	ich process variable is assigned to
FAILSAFE MODE	In cases of an instrument er output assumes a previously The setting chosen only affe (e.g. totalizer) are not affect	ror it is advisable for safety reasons that the current y defined status which can be set in this function. cts the current output. Other outputs or the display ed.
	+ MIN. CURRENT	Current signal is set to 0 mA (020 mA) or 2 mA (420 mA) on error.
	MAX. CURRENT	Current signal set to 25 mA for 0/420 mA (25 mA) or to 22 mA for 420 mA on error.
	HOLD VALUE	Last valid measured value is held
	ACTUAL VALUE	Normal measured value given despite error
	CANCEL	
	Display showing wh the current output.	ich process variable is assigned to

Function group CURRENT OUTPUT (only with PROFIBUS-PA available)		
SIMULATION CURR.	In this function, the output current can be simulated corresponding to 0%, 50% or 100% of the set current range. The error mode 2 mA (for 420 mA) and 25 mA (maximum possible value) or 22 mA for NAMUR can also be simulated.	
	Application example: Checking instruments connected or checking the internal adjustment of the current signal.	
	 Note! After activating the simulation mode, the message "S: CURRENT OUTPUT SIMUL. ACTIVE" appears on the display in the HOME position. The selected simulation mode affects only the current output. The flowmeter remains fully operational for measurement, i.e. totalizer, flow display etc. are operating normally. Positive zero return interrupts any simulation being carried out and sets the output current to 0 mA or 4 mA (see function "POS.ZERO RETURN", page 93). Current output according to NAMUR → the 22 mA value only can be selected, not the 25 mA value. 	
	 OFF - 0 mA - 10 mA - 20 mA - 22 mA - 25 mA (at 020 mA) 2 mA - 4 mA - 12 mA - 20 mA - 22 mA - 25 mA (at 420 mA) CANCEL 	
NOMINAL CURRENT	With this function, the calculated value of the output current is displayed (0.0025.0 mA). The effective current can vary slightly due to external effects such as temperature. Display: calculated current (0.0025.0 mA)	

Function group DENSITY FUNCTION

Introduction

The Promass 63 determines three variables simultaneously: mass flow - density - temperature.

This, for example, allows *volumetric flow* to be calculated. It also offers a wide variety of other calculations to be done, especially for *special density calculations* in various applications:

- calculating temperature-compensated density values (standard density).
- calculating percentage contents in two-phase media (carrier fluid and target fluid)
 converting fluid density into special density units, such as "Brix, "Baumé, "API, etc.
- converting huid density into special density units, such as "Brix, "Baume, "API, e (see following explanations)

Standard density

Many density calculations are mathematically derived from temperature-compensated standard densities. Standard density is calculated as follows:

 $\rho_N = \rho \cdot (1 + \alpha \Delta t)$; where $\Delta t = t - t_N$

- ρ_N = standard density
- ρ = actual measured fluid density (measured value Promass 63)
- t = actual measured fluid temperature (measured value Promass 63)
- t_N = standard temperature for calculating standard density (e.g. 15 °C)
- α = fluid volumetric expansion coefficient. Unit = [1/K]; K = Kelvin

°API (= American Petroleum Institute)

Density units specifically used in North America for liquefied oil products.

°BAUME

This density unit or scale is mainly used for acidic solutions, e.g. ferric chloride solutions. Two Baumé scales are used in practice:

- BAUME > 1 kg/l: for solutions heavier than water
- BAUME < 1 kg/l: for solutions lighter than water

°BRIX

Density units used for the foodstuffs industry which deal with the saccharose content of aqueous solutions, e.g. for measuring solutions containing sugar such as fruit juice, etc. The ICUMSA table for Brix units given on page 136 is the basis for calculations.

%-MASS and %-VOLUME

By using the functions for two-phase-media, it is possible to calculate the percentage mass or volume contents of the carrier fluid or the target fluid.

The basic formula (without temperature compensation) are:

mass
$$[\%] = \frac{D2 \cdot (\rho - D1)}{\rho \cdot (D2 - D1)} \cdot 100 \%$$
 volume $[\%] = \frac{(\rho - D1)}{(D2 - D1)} \cdot 100 \%$

D1 = density of carrier fluid \rightarrow transporting liquid, e.g. water

D2 = density of target fluid \rightarrow material transported, e.g. lime powder or a second liquified material to be measured

 ρ = total density measured

%-BLACK LIQUOR

The units of concentration used in the paper industry for black liquor in % by mass. The formula used for the calculation is the same as for %-MASS.

%-ALCOHOL

Density measurement for units of concentration for alcohol-containing solutions in % by volume. The formula used for the calculation is the same as for %-VOLUME, however **does not** allow for a possible volume concentration.

Field density adjustment (calibration)

Promass 63 offers the option of "field calibration" carried out in the "DENSITY ADJUST" function to provide optimum accuracy for calculating density functions \rightarrow see page 81.

Caution!

- A field density adjustment alters the factory-set density calibration values.
- These calculations assume a linear responce of two-phase flow, which is not always in case in praxis.





Fig. 24 Procedure for setting density functions

Note

	Function group DENSITY FUNCTION	
DENS. ADJ. VALUE	In this function, enter the "target density" (= density adjust value) of the particular fluid for which you want to carry out a field density adjustment. Implementation and procedure of this field adjustment is described in detail in the following function "DENSITY ADJUST".	
	 Note! With two-point density adjustment, a target density value is to be given in this function for each of the two media. The two target density values must differ from each other by at least 0.2 kg/dm³. The preset density entered here should vary from the actual fluid density by a maximum ±10%. 	
	5-digit number with floating decimal point, incl. units corresponding to 0.15.9999 kg/l	
	MANUAL DENSITY CALIBRATION	
DENSITY ADJUST	With this function a density adjustment can be carried out on site. The density adjustment values will thus be recalculated and stored. This ensures that the values dependent on density calculations are as accurate as possible. Two types of adjustment are to be distinguished:	
	 1-point density adjustment (with <i>one</i> fluid) This type of density adjustment is necessary under the following conditions: The sensor does not measure the density accurately which the operator expects from laboratory trials. The characteristics of the fluid are outside the measuring points set at the factory or reference conditions under which the flowmeter has been calibrated. The plant is used solely for measuring a fluid whose density is to be determined very accurately under constant conditions. <i>Examples:</i> Brix density measurement for apple juice. 	
	 2-point density adjustment (with <i>two</i> fluids) This type of adjustment is always to be carried out if the measuring tubes have been mechanically altered by, e.g. material build-up abrasion corrosion 	
	In such cases, the resonant frequency of the measuring tubes has been affected by these factors and is no longer compatible with the calibration data set at the factory. The 2-point density adjustment allows for these mechanical changes and recalculates new revised data.	
	CANCEL - SAMPLE FLUID 1 - SAMPLE FLUID 2 - DENSITY ADJUST	
	Display of actual target density value (see function "DENS. ADJ. VALUE")	
	(continued on next page)	





Fig. 25

Carrying out density adjustment (flow diagram) 1-point and 2-point density adjustment

Function group DENSITY FUNCTION	
CALC. DENSITY	In this function, select the density function required with which the special density values or the percentage contents of components in the two-phase fluid are calculated.
	 [] → displayed measuring unit Display of actual value to be calculated using the density function and variables selected above.
VOLUME FLOW MEAS	Volume and standard volume measurement are only available in other functions if the appropriate setting is activated here.
	OFF - VOLUME FLOW - STD. VOLUME FLOW - VOLUME & STD. VOL CANCEL
STD.VOL.CALC.	This function is used to set the standard density for calculating the standardised volumetric flow. Note! This function is only available if the setting "STD. VOLUME FLOW" or "VOLUME & STD.VOL." has been selected in the above function.
	 CALC. STD.DENS. FIXED STD.DENS. CANCEL The standard density is determined from the process data measured. The standard density is entered as a fixed (known) value → see page 85
	Display of the actual calculated standard volumetric flow.
REFERENCE TEMP.	Input of the reference temperature for calculation standard volume flow measurement, standard volumes and the density functions °BAUME >1.0 SG, °BAUME <1.0 SG, °API, %-MASS, %-VOLUME, %-BLACK LIQUOR, %-ALCOHOL and STD. DENSITY.
	 5-digit number with fixed decimal point, units and arithmetical sign (e.g. 25.000 °C; -10.500 °C; 60.000 °F; etc.) Factory setting: 15.000 °C
	Display of actual engineering units used for the medium temperature (see Function "TEMPERATURE UNIT", page 74)
	Note! This function is only available if a density function is selected in the group "CALC.DENSITY" or "VOLUME FLOW MEAS." within the function group "DENSITY FUNCTION".



	Function group DENSITY FUNCTION
EXP. COEF.	For temperature-compensated calculations of the standard density, the expansion coefficient specific to the fluid is required and can be entered in this function.
	Note! This function is only displayed if you have configured other functions, accordingly: • CALC. DENSITY → °API, °BAUME, °BRIX, °PLATO, °BALLING
	• STD. VOL. CALC. \rightarrow CALC. STD. DENS.
	 5-digit number with floating decimal point, incl. units and arithmetical sign (e.g. 0.4400 e-3 1/K) Factory setting: 0.5000 e-3 1/K
FIXED STD. DENSITY	In this function, a fixed value for the standard density can be entered, with which the standard volumetric flow rate or the standard volume is calculated.
	Note! This function is displayed only if the setting "FIXED STD.DENS." is set in the function "STD.VOL.CALC." (see page 84).
	 5-digit number with fixed decimal point, incl. units (e.g. 1.0000 kg/sl; 1000.0 kg/Nm³) Factory setting: 1000.0 kg/Nm³
	Display showing actual units used for the standard density (see Function "STD. DENSITY UNIT", page 74)
CARRIER DENSITY	In this function, the density for the carrier fluid is entered. This density value is required for calculating the target fluid contained in a two-phase fluid. (calculation formula \rightarrow see page 79).
	Carrier fluid=transporting liquid (e.g. water)Target fluid=material transported (e.g. lime powder)
	 5-digit number with fixed decimal point, incl. units (e.g.1.0000 kg/dm³; 1.0016 SG) Factory setting: <i>1.0000 kg/l</i>
	Display showing the actual density units (see Function "DENSITY UNIT", page 74)
	Note! This function is only available if the setting "%-MASS", "%-ALCOHOL", "%-BLACK LIQUOR" or "%-VOLUME" is selected in the function "CALC. DENSITY" within the function group "DENSITY FUNCTION".
EXP. COEF. CARRIER	In this function, the expansion coefficient of the carrier fluid is entered. This value is required for the <i>temperature-compensated</i> calculation of the target fluid contents in a two-phase fluid.
	Carrier fluid=transporting liquid (e.g. water)Target fluid=material transported (e.g. lime powder)
	 5-digit number with floating decimal point, incl. arithmetical sign and units (e.g. 0.5000 e-3 1/K) Factory setting: 0.0000 e-3 1/K
	Note! This function is only available if the setting "%-MASS", "%-ALCOHOL", "%-BLACK LIQUOR" or "%-VOLUME" is selected in the function "CALC. DENSITY" within the function group "DENSITY FUNCTION".









Note

Caution!

Function group DISPLAY		
ASSIGN LINE 1	With this function the variable is defined which should be displayed on the <i>upper</i> display line during normal operation ("HOME" position). MASS FLOW – VOLUME FLOW – STD. VOLUME FLOW – TARGET FLOW – CARRIER FLOW – DENSITY – CALC. DENSITY – TEMPERATURE – TOTALIZER 1 – TOTAL. 1 OVERFLOW – TOTALIZER 2 – TOTAL. 2 OVERFLOW – CANCEL	
ASSIGN LINE 2	With this function the variable is defined which should be displayed on the <i>lower</i> display line during normal operation ("HOME" position). • OFF – MASS FLOW – VOLUME FLOW – STD. VOLUME FLOW – TARGET FLOW – CARRIER FLOW – DENSITY – CALC. DENSITY – TEMPERATURE – TOTALIZER 1 – TOTAL. 1 OVERFLOW – TOTALIZER 2 – TOTAL. 2 OVERFLOW – BATCH PRESET – CANCEL	
DISPLAY DAMPING	 Selecting a time constant determines whether the display reacts quickly (small time constant) or slowly (large time constant) to widely changing flow variables. Note! Damping is inactivated when set to "zero". The time constant does not affect the behaviour of the current output. Max. 2-digit number: 099 seconds Factory setting: <i>1 s</i> 	
FORMAT FLOW	 In this function set the maximum number of decimal places of all measured values and parameters of flow variables. Note! The settings carried out here only affect the display. They do not affect the accuracy of the calculation within the system itself. The decimal places calculated by the Promass cannot be shown always as they depend on the settings and the engineering unit selected. In these cases an arrow is shown between the measured value and the engineering unit (e.g. 1.2 → kg/h). This means the measuring system calculates internally using more decimal places than can be shown. ★ XXXXX XXXXX XXXXX XXXXX - XXXXX - CANCEL 	
LCD CONTRAST	The display contrast can be optimally adjusted to match prevailing operating conditions on site (ambient temperature). Caution! Below freezing point (< 0 °C), the visibility of the LCD is no longer assured. The display contrast is at a maximum if the + keys are simultaneously pressed when starting up the flowmeter.	

	Function group DISPLAY		
LANGUAGE	In this function the appropriate language is selected in which all text, parameters and operating messages are to be displayed.		
	Note! English is selected if the 🗄 keys are simultaneously pressed when starting up the flowmeter.		
	 ENGLISH – DEUTSCH – FRANCAIS – ESPANOL – ITALIANO NEDERLANDS – DANSK – NORSK – SVENSKA – SUOMI BAHASA INDONESIA – JAPANESE (in original alphabet) CANCEL 		

Function group COMMUNICATION		
BUS ADDRESS	This function sets the bus address.	
	The configuration for local operation can be deactivated using a miniature switch on the communications board (see page 25). If this is done, "SELECTION SWITCH" is displayed.	
	 3-digit number: 0126 Factory setting: <i>126</i> 	
	In case the address is assigned with the selection switch, the configured bus address is displayed	
TAG NUMBER	This function displays the actual measuring-point designation (name), which can only be assigned by a PROFIBUS master, e.g. Commuwin II.	
	The measuring-point designation corresponds to the TAG-DESC of the physical block as defined in the PROFIBUS-PA profile B.	
	Up to 32 characters of the full measuring-point designation are displayed	
SYSTEM CONFIG.	Using this function, it is possible to switch between local operation with E+H matrix and remote operation via PROFIBUS-DP /-PA.	
	The device can only be operated either via local operation in >local < mode or via PLC (Class I master / Class II master) in >remote < mode at one time. The system configuration and parameters are independent from the operation mode and valid even in the event of a change of the operating mode.	
	LOCAL – REMOTE	
UNIT TO BUS	In this function the system units set on the instrument are transmitted to the bus or to Class I master. This function is only required if the system unit have been changed via the local operation and this change shall be propagated to the AI blocks.	
	Changes to the system units via local operation are not automatically transmitted to the bus or master. Only after the function "UNIT TO BUS" is activated, the system units will be transmitted to the bus or master and updated there.	
	CANCEL - UNIT TO BUS	

	Function group PROCESSING PARA.		
LOW FLOW CUTOFF	In this function, the required switching point for creep suppression (low flow cutoff) can be entered. The creep suppression prevents the flow rate being measured in the lower part of measuring range (e.g. a variable column of liquid at standstill). When creep suppression is active, the sign of the flow appears optically inverted on the display.		
	Q (mass/time) Hysteresis = -50 % of creep rate 1 = switch-on point 2 = switch-off point		
	Creep rate		
	 5-digit number with floating decimal point (e.g. 25.000 kg/min) Factory setting: <i>dependent on</i> the nominal diameter HYSTERESIS = 50% Creep suppression operates with a negative hysteresis of 50% (see above figure). 		
NOISE SUPPRESS.	Using the interference blanking (= time constant for exponential filter) the sensitivity of the flow measurement signal to transient flows and interference peaks can be reduced; e.g. with media containing solids or gas bubbles. Small negative parts will be smoothed.		
	0 seconds \rightarrow OFF 2 seconds \rightarrow high damping		
MEASURING MODE	 The Promass 63 measuring system generally measures flow in both directions. Unidirectional: Signal output in the positive direction only (forward). Flows in a negative direction (backwards) are not included or totalised by the Promass measuring system. Bidirectional: Signal output in both directions (forward and reverse). 		
	• UNIDIRECTIONAL - BIDIRECTIONAL - CANCEL		

	Function group PROCESSING PARA.	
FLOW DIRECTION	In special cases it is possible that the arrow marked on the sensor nameplate does not agree with the actual flow direction of the fluid. In this function you have the option to change the arithmetical sign of the flow variable.	
	+ FORWARD - REVERSE - CANCEL	
EPD THRESHOLD	EPD = Empty Pipe Detection: With empty measuring tubes the fluid density falls below a specified value (= response or threshold value) which can be specified in this function.	
	 Note! When the preset response value is reached or exceeded the display shows the error message "A: EMPTY PIPE". The flow is then set to the value '0.0000' and the density to the EPD threshold value. Switching on and off the EPD operates at a time constant of 1 second. Empty Pipe Detection is switched off if the EPD threshold value is set to the value '0.0000'. 	Note!
	 Caution! Select a correspondingly low EPD response value so that the difference to the effective density of the medium is sufficiently large enough. This ensures that totally empty measuring tubes and not partially filled ones are detected. For gas measurement we strictly recommend to switch off empty pipe detection (set "EPD THRESHOLD" to 0.0000 kg/l). 	Caution!
	 5-digit number with fixed decimal point, incl. engineering units corresponding to 0.00005.9999 kg/l Factory setting: 0.2000 kg/l 	
DENSITY FILTER	The density filter allows the sensitivity of the density measuring signal to be lowered with respect to variations in the density of the medium, e.g. with heterogeneous liquids.	
	• OFF - LOW - MEDIUM - HIGH - CANCEL	
SELF CHECKING	Better reproducibility for short batching cycles (<60 s) can be guaranteed by activating the selection "SMART PLUS".	
	Note! Select "CYCLIC" for batching times >60 s and for continuous measuring mode.	Note!
	CYCLIC - SMART PLUS - CANCEL	

	PROCESSING PARA.
PRES. PULSE SUPPR.	When closing a valve, there may be a sudden but strong rush of liquid in the piping which is then detected by the measuring system. The pulses will be counted, especially those from filling cycles, and produce an incorrect result in the totaliser. Because of this, the Promass 63 has a function for pressure pulse suppression (= transient signal suppression) which can eliminate interference coming from the plant. The time interval of the active pressure pulse suppression is defined in this function:
	 Switch-on point Pressure pulse suppression is activated after the flow velocity falls below 50% of the creepage value (see page 88). The following applies during the pressure pulse suppression: Current output → is set to 0 mA or 4 mA (only with PROFIBUS-PA) Display flow = 0 Display totaliser → both totalisers (TOTALIZER 1 and 2) remain at the last applicable value. Temperature and density values continue to be shown.
	Switch-off point The pressure pulse suppression is again deactivated after the set time interval.
	Mass flow
	 Max. 4-digit number, incl. units (0.0010.00 seconds) Factory setting: 0.00 s Note! When using the pressure pulse suppression, the low flow cutoff must be set to a value > 0.



Caution!

Note

Note!

Note

Function group SYSTEM PARAMETER				
ZEROPOINT ADJUST	This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the function "ZEROPOINT". In the function "SELECT ZEROPOINT" specify which zero point (1 or 2) should be recalibrated.			
	Caution! Before carrying out the calibration please refer to chapter 7, where a detailed description of the zero point adjustment is given.			
	 Note! Programming is locked during zero point adjustment and the display shows "S: ZERO ADJUST RUNNING". If the zeropoint adjustment is not possible, e.g. with a flow velocity > 0.1 m/s, or has been cancelled, then the alarm message "A: ZERO ADJUST NOT POSSIBLE" is shown on the display. 			
	CANCEL - START			
	 Display showing the current zero point value used by the measuring system. 			
POS. ZERO RETURN	 This function assigns 0 to the corresponding data items of the PROFIBUS-PA function blocks and sets from the current output to the fallback value, e.g. for interrupting the measurement for cleaning the piping. Flow rate = 0 for the Analog In Blocks of the PROFIBUS-PA interface Current output → set to 0 mA or 4 mA Display flow = 0 Both totalizers remain at the last applicable value. Temperature and density values are still shown. Note! This function has top priority over all other functions of the instrument. Simulations are suppressed for example. After positive zero return is activated, the display shows the message "S: POS. ZERO-RET. ACTIVE". ● <i>OFF</i> - ON ● ALL SIGNALS SET TO ZERO (for description: see above) 			
DEF. PRIVATE CODE	 This function enables a personal code number to be selected with which programming can be enabled. Note! Programming is always enabled with the code number "0". When programming is locked this function is not available and access to the personal code number by third parties is not possible. The code number can only be altered when programming has been enabled. Max. 4-digit number (09999) Factory setting: 63 			

	Function group SYSTEM PARAMETER		
	ACCESS CODE	All data of the Promass 63 measuring system are protected against unauthorised access. Only by first entering a code number in this function programming with Commuwin II resp local operation is enabled and the settings of the instrument can then be altered. If in any function the ⊕ operating elements are pressed, then the measuring system jumps automatically into this function and the display shows the prompt to enter the code number (if programming is locked): → Enter code number 63 (factory setting) or → Enter personal code number (see function "DEF. PRIVATE CODE", page 93)	
Note!		 Note! After jumping to the HOME position programming is again locked after 60 seconds if no operating element is pressed during this time. Programming can also be locked by entering any number (not the customer code number) in this function. If you can no longer find your personal code number, then the Endress+Hauser service organisation will be pleased to help you. 	
		 Max. 4-digit number (09999) Factory setting: <i>0</i> 	
	PRESENT SYSTEM CONDITION	System/process errors as well as status messages which occur while measurement is in progress can be called up according to their priority. Error and status messages are displayed in the HOME position alternately with the actual measurement variable.	
Note!		 Note! On activating the diagnosis function in there is automatically a jump to this function. A complete listing of all possible system/process errors and status messages is found on page 101 ff. 	
		 Calling up other current errors or status messages "+" → message with higher display priority "-" → message with lower display priority When the listing is complete the display shows the message "END OF LIST". 	
		By pressing the diagnosis function again when a system error occurs you can also call up error descriptions. In such cases a diagnosis symbol (stethoscope 94) is shown on the display.	
	PREVIOUS SYSTEM CONDITIONS	In this function, all system/process errors and status messages that have occurred so far are listed in <i>chronological</i> order (error history with max. 15 entries).	
Note!		 Note! A complete list of all possible system/process errors and status messages is given on page 101 ff. If no error or status messages have occurred since the measuring system was last started up then the display shows the message "S: NO ENTRY EXISTING". With more than 15 entries the oldest message is overwritten. 	
		 Storage of this list is volatile and is lost if there is a supply failure. Calling up other system/process errors and status messages "-" Listing is done chronologically with the oldest, second oldestetc. message "-" Listing is done chronologically with the latest, second latestetc. message When the listing is complete the display shows the message "END OF LIST". 	
		By activating the diagnosis function when a system error occurs you can also call up error descriptions.	

	Function group SYSTEM PARAMETER	
SOFTWARE VER. COM	In this function, the current software is shown which is installed on the communications board. The numbers of the software version have the following meaning: V 3 . 02. XX PBUS Communication interface Number changes if minor alterations are made to the new software versions. Number changes if the new software contains additional functions. Number changes if basic alterations have to be made to the software, e.g. due to technical modifications to the instrument.	
	Note! If the display does not show "PBUS" there is no PROFIBUS-DP/-PA communication board installed, but another type.	Note!
SYSTEM RESET	With this function the Promass 63 can be restarted without the power supply being switched off and on again. Note! With a "restart" all error entries in the function "PREVIOUS SYSTEM CONDITIONS" are deleted. CANCEL – RESTART SYSTEM	Note!
ALARM DELAY	 With this function a time interval can be defined (0100 seconds), in which an error message is suppressed when faults or alarms occur. Depending on the setting and type of error, this suppression effects: display current output (only PROFIBUS-PA) PROFIBUS interface PROFIBUS interface Range: 0100 seconds (in one second steps) Factory setting: 0 s Caution! When using this function, error and alarm messages are sent to higher control systems (PLC, etc.) only after a preset delay. It must first be determined if the safety of the process permits this. If no delay is permitted for fault and alarm messages, then a value of 0 seconds must be set.	Caution!



\square
Caution!

Function group SENSOR DATA				
K-FACTOR	In this function, the current calibration factor of the sensor is shown:			
	Max. 5-digit number with fixed decimal point (0.10005.9999) Factory setting: <i>dependent</i> on the nominal diameter of sensor and its calibration			
	Caution! The calibration factor may only be altered under special circumstances. The appropriate E+H Service Centre should first be contacted before this is done.			
ZEROPOINT	In this function, the zero point correction currently used by the sensor can be called up and/or changed.			
	Note! The zero point adjustment is described in detail in chapter 7.			
	 Max. 5-digit number (-10000+10000) Factory setting: <i>dependent</i> on the nominal diameter of sensor and its calibration 			
	Example: Correction factor 100 = 1% of Q_{ref} with v = 1 m/s (ρ = 1 kg/l) Correction factor 100 = 0.5% of Q_{ref} with v = 2 m/s (ρ = 1 kg/l)			
	 ZEROPOINT 1 or ZEROPOINT 2 Display showing the active zero point 			
NOMINAL DIAMETER	In this function, the actual nominal diameter of the sensor is shown (e.g. 25 mm, 2 inch, etc.).			
SENSOR COEF.	In this function, other calibration data and information on the sensor can be called up. Changes to the calibration values shown in this function can only be carried out by an E+H service technician. This also applies to resetting calibration values originally done in the factory. Caution! A density adjustment on site (see page 81) can alter the calibration values C0, C1, C2, C3, C4 and C5.			
	CANCEL By selecting "CANCEL" and confirming with E you jump to the next function.			
	DENSITY COEF. C 1 DENSITY COEF. C 2 DENSITY COEF. C 3 DENSITY COEF. C 4 DENSITY COEF. C 5 TEMP. COEF. Km TEMP. COEF. Kt CAL. COEF. Kd1 CAL. COEF. Kd2			
	MIN. TEMPERATURE (lowest fluid temperature measured) MAX. TEMPERATURE (highest fluid temperature measured)			
	E For each of these calibration coefficients you can call up the particular value by pressing E. You jump back to the options by pressing E.			

9 Diagnosis and Trouble-shooting

9.1 Response of the measuring system on fault or alarm

Error indications which occur during operation are indicated in the HOME position alternately with the measured values. The Promass 63 measuring system has two types of error:

Type of error	Response of the instrument	
Fault (system error, failure) Errors due to failure of the instrument	 An appropriate error message is shown on the display (see page 101). The current output responds according to set failure mode (see page 77). 	
Alarm (process errors) Errors due to process conditions	→ An appropriate alarm message is shown on the display (see page 105).	

Caution! Please note the following points on **positive zero return** or active **simulation**:

Positive Zero return

- This function has top priority above all other instrument functions. Simulations are suppressed for example.
- After measurand suppression is activated, the display shows the message "S: POS. ZERO-RET. ACTIVE".

Simulation

• This function has the second highest priority. Specific status messages can still only be called up and shown using the diagnosis function.



9.2 Diagnosis flow chart and trouble-shooting

All instruments undergo various stages of quality control during production. However, should an error or fault occur during set-up or operation, then refer to the flow chart below to identify possible causes.

Error type

Remedy

 Check the power supply on Terminal No. 1 and No. 2.
 Check the power line fuses: 85...260 V AC: 1 A slow-acting 20... 55 V AC: 2.5 A slow-acting 16... 62 V DC: 2.5 A slow-acting
 Replace electronics module (see page 107).

Poor contrast on the display. Output signals functioning correctly. \rightarrow

• No indication on the display. \rightarrow

• No output signal. \rightarrow

- No understandable language on the display. →
- 1. Check connector No. 3b (see page 107).
- 2. Replace display.
- 3. Replace electronics module (see page 107).
- 1. Change the language :
 - a) Switch off the power supply.
 - b) Press the t-keys at the same time.
 c) Keep the -keys pressed while
 - turning on the power supply again.
 - $\rightarrow~$ Display is reset to English.
- No current output despite a message on the display (only with PROFIBUS-PA). \rightarrow
- Flow- or density display unsteady with continuous flow. →
- Error, alarm- or status messages shown which are not described in Section 9.3. →
- Check connector No. 8 (see page 107).
 Replace electronics module (see page 107).

See Notes on page 106.

Please contact your E+H service organisation (see also Notes below).

Notes on remedying errors together with E+H Service

When requesting a customer service engineer, the following informations are required \rightarrow

When returning the instrument, the following informations are required $\,\rightarrow\,$

When ordering an electronics module, the following informations are required \rightarrow

- Short decription of the error
- Order code stated on the nameplate
- Delivery note
- Description of the error
- Order code for electronics module: Promass 63 A MOD - XXXX Promass 63 F MOD - XXXX Promass 63 M MOD - XXXX Promass 63 I MOD - XXXX

XXXX = the last four characters on the code as stated on the transmitter nameplate.

9.3 Error, alarm and status messages

Error message F: (System error, failure)	Error code	Cause Call up by +-	Remedy
	0	No system error or failure	-
F: SYSTEM ERROR AMPLIFIER	1	 Y : LOW VOLTAGE DETECTED The amplifier is detecting a too low voltage. Power supply or amplifier defective. 	 Check the power supply voltage. Replace the electronics module (see page 107).
F: TUBES NOT OSCILLATING	2	পুঁ ∙ : NO DIAGNOSIS Instrument error or application problem.	 Mount the instrument on the pressure side of the pump. Using the valve, choke the piping downstream from the instrument and thus increase the pressure in the instrument. Install an orifice plate down- stream from the instrument. Provide suitable equipment to increase the pressure in the system. Refer to notes on trouble- shooting.
F: SYSTEM ERROR AMPLIFIER	3	[™] : DAT FAILURE Error on access to data in DAT (calibration values of sensor).	 Check to see if the DAT is plug in. Replace the electronics module (see page 107). Order a new DAT using the serial number and the order code and then replace.
F: SYSTEM ERROR AMPLIFIER	4	Y	 Check to see if the DAT is plug in. Replace the electronics module. Order an new DAT using the serial number and the order code and then replace.
F: SYSTEM ERROR AMPLIFIER	5	^Y ^I ^I ^I ^{RAM} FAILURE Error on access to working memory (RAM) of the processor	Replace the electronics module.
F: PICK-UP FAILURE	6	ਊ• : NO DIAGNOSIS	 Check Connection No. 7 (see Fig. 26, see page 107) For remote version, check Terminal No. 4, 5, 6 and 7 on the sensor and transmitter. Refer to notes on trouble- shooting.
F: SYSTEM ERROR AMPLIFIER	8	Y : TEMP. SENSOR MEAS. TUBES The temperature sensor of the measuring tube(s) is defective.	Replace the electronics module (see page 107).

Error message F: (System error, failure)	Error code	Cause Call up by +-	Remedy
F:SYSTEM ERROR AMPLIFIER	9	Y : ASIC FAILURE The ASIC on the amplifier board is defective.	Replace the electronics module (see page 107).
F: SYSTEM ERROR AMPLIFIER	10	[™] : TEMP. CIRCUIT FAILURE Temperature switching of the amplifier is defective.	 Check Connection No. 5 (see Fig. 26, on page 107). For remote version, check Terminal No. 9 and No. 10 on the sensor and transmitter.
F: SYSTEM ERROR AMPLIFIER	11	^Y ^I : TEMP. SENSOR CARRIER TUBE The temperature sensor of the secondary containment is defective.	 Check Connection No. 5 (see Fig. 26, on page 107). For remote version, check Terminal No. 11 and No. 12 on the sensor and transmitter.
F: SYSTEM ERROR AMPLIFIER	13	र्थि⁴ : HW-TYPE INCOMPATIBLE	 Check to see if the electronics module is suitable for the sensor types: A, M, F or I. Replace the electronics module (see page 107).
F: NO AMPLIFIER RESPONSE	24	Y : NO DIAGNOSIS Data transfer between amplifier and communications module is not possible.	 Check Connection No. 5 (see Fig. 26, on page 107). If there is already one of above error messages present then the system pressure is possibly too low. If there is still an error message, then replace the electronics module. Refer to notes on trouble- shooting.
F: SYSTEM ERROR AMPLIFIER	34	ິ່∀⁴: SW-TYPE INCOMPATIBLE	Replace the electronics module (see page 107).
F: SYSTEM ERROR AMPLIFIER	35	ିିY : HW-VERSION INCOMPATIBLE	Replace the electronics module (see page 107).
F: SYSTEM ERROR AMPLIFIER	36	ିିିY⁴ : SW-VERSION INCOMPATIBLE	Replace the electronics module (see page 107).
F: SYSTEM ERROR POWER SUPPLY	42		 Check the power supply voltage. Replace the electronics module (see page 107).

Error message F: (System error, failure)	Error code	Cause Call up by +-	Remedy
F: VALUE NOT ACCEPTED	25	Yr : NO DIAGNOSIS An internally stored value can not be read by the communications module.	 Restart the measuring system (switch the power supply off and then on). Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	26	Y: EEPROM FAILURE Error on access to EEPROM data. (process and calibration data of communications module).	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	27	Y₁ : RAM FAILURE Error on access to working memory (RAM).	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	28	প্ৰ : ROM FAILURE Error on access to program memory (ROM).	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	29	Yet : LOW VOLTAGE DETECTED DC/DC converter on the communications module is supplying a power voltage which is too low.	 Check the power supply voltage. Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	30	Y : VOLTAGE REFERENCE The reference voltage of the communications module is outside the tolerance, i.e. correct functioning of the current output is no longer guaranteed.	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	31	 Ŷi : EEPROM HW DATA ERROR A part of the EEPROM data of the communications module is damaged or has been over- written. Default values from the ROM are written in. The measuring system can still operate on a makeshift basis using these values. 	Replace the electronics module (see page 107).

Error message F: (System error, failure)	Error code	Cause Call up by +-	Remedy
F: SYSTEM ERROR COM-MODULE	32	Yr : EEPROM PARA. DATA ERR A part of the EEPROM data of the communications module is damaged or has been over- written. Default values from the ROM are written in. The measuring system can still operate on a makeshift basis using these values.	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	33	 Y ■: EEPROM TOT. DATA ERROR A part of the EEPROM data of the communications module (totaliser block) is damaged or has been overwritten. Default values "0" is entered in the totaliser. 	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	37	ਿੱਖ : EEPROM DEFAULT VALUE	 Switch the instrument off and then on. Reconfigure the instrument.
F: SYSTEM ERROR COM-MODULE	38	ଐଏ : HW-TYPE INCOMPATIBLE	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	40	∀ੱ∙: SW-TYPE REPLACED	Replace the electronics module (see page 107).
F: SYSTEM ERROR COM-MODULE	41	ି [∿] : SW-DOWNGRADE NOT POSSIBLE	Replace the electronics module (see page 107).

Alarm message A: (Processor error)	Alarm code	Cause	Remedy
A: DAT CONTAINS DEFAULT DATA	49	Empty DAT on the amplifier board. The instrument is operating with the default values (factory settings).	 Check to see if the DAT is plug in. Replace the electronics module (see page 107). Order a new DAT using the serial number and the order code and then replace
A: EXCIT. CURRENT LIMIT	50	The maximum excitation current for the excitation coil has been attained with specified fluid characteristics at limit values (e.g. gas or solid content). The instrument is continuing to operate correctly.	 Mount the instrument on the pressure side of the pump. Using the valve, choke the piping downstream from the instrument and thus increase the pressure in the instrument. Install an orifice plate down- stream from the instrument. Provide suitable equipment to increase the pressure in the system. Refer to notes on trouble- shooting.
A: SLUG FLOW CONDITIONS	51	The medium is heterogeneous (gas or solids content). The current needed to excite the measuring tube(s) therefore varies significantly.	 Mount the instrument on the pressure side of the pump. Using the valve, choke the piping downstream from the instrument and thus increase the pressure in the instrument. Install an orifice plate down- stream from the instrument. Provide suitable equipment to increase the pressure in the system. Refer to notes on trouble- shooting.
A: EMPTY PIPE	52	 Applicational problem: gas in the measuring tubes density too low (s. page 91, Empty Pipe Detection). 	 Fill the measuring pipe and ensure that no gas bubbles are in the medium. Set the parameter for EPD threshold value to be the same as the density of the medium.
A: FLOW TOO HIGH	53	Velocity of liquid in the measuring tubes is >12,5 m/s. Measuring range of transmitter electronics is exceeded.	Lower the flowrate.
A: ZERO ADJUST NOT POSSIBLE	54	The zero point calibration is not possible or has been cancelled.	Check if fluid velocity = 0 m/s.
A: CURRENT OUTPUT OVERFLOW (only PROFIBUS-PA)	72	The actual measured value is outside the range preset by the scaled zero and full scale values.	 Change scaled zero and full values (see pages 75, 76) or change measured variable. Refer to notes on trouble- shooting.
A: DENSITY ADJUST FAILURE	75	Both target density values are not different from each other by at least 0.2 kg/l.	 Change density adjust value. Repeat measurement

Status message S: (status)	Status code	Cause	Remedy
S: POS. ZERO-RET. ACTIVE	96	Positive zero return is activated. This message has highest priority for the measuring system.	1. Switch off the function "POS. ZERO RETURN" (see page 93).
S: CURRENT OUTPUT SIMUL. ACTIVE	101	Current output simulation is activated.	Switch off the current output simulation (see page 78).
S: ZERO ADJUST RUNNING	_	Zero point adjustment is running.	Not required

If the following messages occur: "EXCIT. CURRENT LIMIT", "TUBES NOT OSCILLATING", "SLUG FLOW CONDITIONS", "NO AMPLIFIER RESPONSE", either singly or in combination, then it is possible that the measuring pipes are too strongly dampened by the fluid whereas the measuring system itself is not sufficiently dampened

Possible causes:

- Partially filled pipe
- High gas content in the fluid
- Pressure is below the vapour pressure of the fluid
- Cavitation
- Highly viscous medium (from experience also with high gas component)

Possible remedies:

- Ensure that there is sufficient pressure in the system (see page 12).
- Install the flowmeter downstream from the pump on the pressure side.
- Use a valve to choke the piping downstream from the flowmeter.
- Install an orifice plate downstream from the flowmeter (see page 15).
- Install the flowmeter vertically into the piping (see page 14).

Warning

Caution!

9.4 Replacing the transmitter electronics

War • D • Tł su • W oł	rning! anger of electrical shock! Switch of the power supply before opening the elctronics housing. he local power supply voltage and frequency must agree with the technical data of the power upply boards used. /hen using Ex instruments, the regulations given in the separate Ex documentation have to be oserved.	
0	Loosen the screw of the safety claw (3 mm Allen key).	
0	Unscrew the cover of the transmitter electronics compartment.	
€	Remove the local display (if present): a) Loosen the mounting screws of the display module. b) Unplug the ribbon cable of the display module from the communications board.	
4	Unplug the two-pole plug of the power supply cable by pressing down the vatch from the power supply board.	
6	Remove cable board of the screened signal cable (incl. the DAT module connected) from the amplifier board.	
6	Loosen the two Phillips screws of the board support plate. Carefully remove the board plate approx. 45 cm out of the transmitter housing.	
7	Remove the excitation current cable plug from the power supply board.	
8	Remove the ribbon cable plug (connection cable to the terminal area) from the communications board.	
9	The entire transmitter electronics, together with the board support plate, can now be completely removed from the housing.	
	Caution! The Promass M and F electronics are not identical with those of Promass A or I.	
0	Replace the old transmitter electronics and reassemble in reverse sequence.	
2		
		ba033y37



Fig. 26 Replacing the Promass 63 transmitter electronics 9.5 Replacing the COM-Modul PROFIBUS-DP/-PA




9.6 Replacing the fuse

Warning!

- Danger of electrical shock! Switch off the power supply before opening the housing of the transmitter housing.
- When using Ex instruments, the regulations given in the separate Ex documentation have to be observed.

The instrument fuse can be found in the terminal compartment \rightarrow see page 18 resp. page 20.

Exclusively use the following types of fuses:

- Power supply 20...55 V DC / 16...62 V DC 2.5 A slow acting / 250 V; 5.2×20 mm
- Power supply 85...230 V AC ±10%
 1 A slow acting / 250 V; 5.2×20 mm



10 Dimensions

Note!

Information on dimensions and weights of Ex instruments may differ from that shown. Please refer to the separate Ex documentation.



10.1 Dimensions Promass 63 A



Fig. 28 Dimensions Promass 63 A Compact version

Process connection	L 4-VCO-4 fittings	L1 ¹ /2" Tri- Clamp	L2 ¹ /4" NPT-F	L3 SWAGELOK DN 1, 2: ¹ /8" or ¹ /4"; DN 4: ¹ /4"	L4 L5 ¹ /2" flange (ANSI)		L6 DN 15 (DIN	L7 flange , JIS)
					CI 150	CI 300	PN 40	10 K
DN 1 DN 2 DN 4	290 372 497	296 378 503	361 443 568	359.6 441.6 571.6	393 475 600	393 475 600	393 475 600	393 475 600

Diame DIN	e ter ANSI	di	Α	В	С	E	F	G	н	к	М	Weight [kg]
DN 1 DN 2 DN 2* DN 4 DN 4*	¹ /24" ¹ /12" ¹ /12" ¹ /8" ¹ /8"	1.1 1.8 1.4 3.5 3.0	32 32 32 32 32	165 165 165 195 195	269.5 269.5 269.5 279.5 279.5 279.5 All d * Hig	120 120 120 150 150 imensio h press	145 145 145 175 175 ns in [m ure vers	160 160 220 220 220 im]	301.5 301.5 301.5 311.5 311.5	180 180 180 240 240	228 310 310 435 435	10 11 15 15



Fig. 29 Dimensions Promass 63 A Remote version

Diameter		B1	N	L
DIN	ANSI	[mm]	[mm]	
DN 1 DN 2 DN 4	¹ /24" ¹ /12" ¹ /8"	122 122 132	154 154 164	Dimensions dependent on the process connections (see previous page)

Wetted parts materials:

Measuring tube:	SS 1.4539 (904L), Alloy C-22 2.4602 (N 06022)
4-VCO-4 fittings:	SS 1.4539 (904L), Alloy C-22 2.4602 (N 06022)
¹ /2" Tri-Clamp:	SS 1.4539 (904L)
Adapter sets:	SS 1.4401 (316)
¹ /8" or ¹ /4" SWAGELOK	SS 1.4539 (904L), Alloy C-22 2.4602 (N 06022)
¹ /4" NPT-F	SS 1.4539 (904L), Alloy C-22 2.4602 (N 06022)
Flange DIN, ANSI, JIS	Iap joint flanges (not wetted) in SS 1.4404 (316L)
Gasket (O-ring):	Viton (–15+200 °C), Kalrez (–30+210 °C), Silicone (–60+200 °C), EPDM (–40+160 °C)

10.2 Dimensions Promass 63 I



Fig. 30 Dimensions Promass 63 I

Diameter		L	x	B	B1	di	Weight				
DIN	ANSI			fuuul	fuuui	fuuul	[kg]				
DN 8	³ /8"			288.0	138.5	8.55	12				
DN 15	¹ /2"			288.0	138.5	11.38	15				
DN 15*	¹ /2"	Dimensions	dependent	288.0	138.5	17.07	20				
DN 25	1"	on process	connections	288.0	138.5	17.07	20				
DN 25*	1"	(see pag	e 118 ff.)	301.5	152.0	25.60	41				
DN 40	1 ¹ /2"			301.5	152.0	25.60	41				
DN 40*	1 ¹ /2"			316.5	167.0	35.62	67				
DN 50	2"			316.5	167.0	35.62	67				
DN 8: with DN 15 flanges as standard; * DN 15, 25, 40 "FB" = Full bore versions of Promass I; All weights stated are those for the compact version											



10.3 Dimensions Promass 63 M



Diameter		L	x	L1	В	B1	di	Weight
DIN	ANSI			[mm]	[mm]	[mm]	[mm]	[kg]
DN 8	³ /8"			256	262.5	113.0	5.53	11
DN 15	¹ /2"			286	264.5	114.5	8.55	12
DN 25	1"	Dimensions	dependent	310	268.5	119.0	11.38	15
DN 40	$1^{1}/2^{"}$	on process	connections	410	279.5	130.0	17.07	24
DN 50	2"	(see pag	ie 118 ff.)	544	289.5	140.0	25.60	41
DN 80	3"			644	305.5	156.0	38.46	67
DN 100 *	4"			-	305.5	156.0	38.46	71

DN 8: with DN 15 flanges as standard;

* DN 100 / 4": nominal diameter DN 80 / 3" with DN 100 / 4" flanges;

All weights stated are those for the compact version

209 190.5 Compact version (185) 171 56.5 m $\overline{\bigcirc}$ -Ō $\overline{\oplus}$ ba033y56 Ν Ν L 7/8-14 UNF L1 000 ÓO L5 L2 L3 L4 246 Remote version (222) 156.5 334 177.5 100 Ø 8.6 (M8) 133 25 100 123 max. 20 m 137.5 118.5 đ ħf Ш る _ € $\leftarrow \bigcirc$ ()-1 ba033y59 Ν Ν 7/8-14 UNF L1

10.4 Dimension Promass 63 M (high pressure)

Process Ν L1 L2 L4 L5 L L3 connection VCO with ³/8" NPT G ³/8" without with 1/2" SWAGELOK ¹/₂" NPT connector [mm] [mm] [mm] [mm] 355.8 DN 8 24 256 304 355.8 366.4 370 DN 15 24 286 334 396.4 400 385.8 385.8 DN 25 34 310 378 429.8 440.4 444 429.8

Process connection materials

 $\begin{array}{rcl} \mbox{Connectors} \rightarrow & \mbox{SS 1.4404 (316L)} \\ \mbox{Fittings} & \rightarrow & \mbox{SS 1.4401 (316)} \end{array}$

Couplings and connectors optimized for CNG (Compressed Natural Gas) applications.

Diameter		B	B1	di	Weight
DIN ANSI		[mm]	[mm]	[mm]	[kg]
DN 8	³ /8"	262.5	113.0	4.93	11
DN 15	¹ /2"	264.5	114.5	7.75	12
DN 25	1"	268.5	119.0	10.20	15

Fig. 32 Dimensions Promass 63 M (High pressure version)



10.5 Dimensions Promass 63 M (without process connection)

Fig. 33 Dimensions Promass 63 M without process connections

Dian D	neter N	ter Dimensions		Coupli	Coupling		Torque	Lubricated thread	0-	ring		
DIN	ANSI	ØL [mm]	Ø J [mm]	ØK [mm]	Screws M	Depth b [mm]	[mm]	[Nm]	yes / no	Diam. [mm]	Inside-Ø [mm]	
8 8* 15 15* 25 25* 40 50 80	³ /8" 3/8" 1/2" 1" 1" 1" 1"/2" 2" 3"	256 256 286 310 310 410 544 644	27 27 35 35 40 40 53 73 102	54 54 56 62 62 80 94 128	6 × M 8 6 × M 8 8 × M 10 8 × M 10 12 × M 12	12 12 12 12 12 12 12 15 15 15 18	10 10 10 10 10 10 13 13 13 15	30.0 19.3 30.0 19.3 30.0 19.3 60.0 60.0 100.0	no yes no yes no yes yes	2.62 2.62 2.62 2.62 2.62 2.62 2.62 2.62	21.89 21.89 29.82 34.60 34.60 47.30 67.95 94.84	
	* High pressure version; Permissible thread: A4 - 80; Lubricant: Molykote P37											

10.6 Dimensions Promass 63 F



Fig. 34
Dimensions Promass 63 P

Diame	ter	L	x	Α	В	B1	di	Weight
DIN	ANSI			[mm]	[mm]	[mm]	[mm]	[kg]
DN 8	³ /8"			75	262.5	113.0	5 35	11
DN 15	$^{1}/^{2}$			75	262.5	113.0	8.30	12
DN 25	1"			75	262.5	113.0	12.00	14
DN 40	$1^{1}/2^{"}$	Dimensions	dependent	105	267.5	118.0	17.60	19
DN 50	2"	on process	connections	141	279.5	130.0	26.00	30
DN 80	3"	(see pag	e 118 ff.)	200	301.0	151.5	40.50	55
DN 100 *	4"			200	301.0	151.5	40.50	61
DN 100	4"			247	320.0	163.0	51.20	96
DN 100 **	6"			247	320.0	163.0	51.20	108
					ļ.		1	I.
		D	N 8. with DN	15 flancies a	s standard.			
		All weigh	nts stated are t	hose for the	e compact v	rersion.		
	* [DN 100 / 4": no	ominal diamete	er DN 80 / 3	with DN 1	00 / 4" flang	es:	
	** [DN 150 / 6": no	ominal diamete	er DN 100 /	4" with DN	150 / 6" flang	ges;	

10.7 Dimensions: process connections Promass 63 I, M, F

DIN 2501 process connections

Promass I Wetted parts materials: Welded process connections:

Promass M Flange material: Gasket material:

Promass F Flange material:

Welded process connections:

Surface finish of the flanges

DIN 2526 Form C, Ra 6.3...12.5 µm

DIN 2526 Form E, Ra 1.6...3.2 µm

For PN 16, PN 40:

For PN 64, PN 100:

titanium Grade 9 no internal gaskets

SS 1.4404 (316L), titanium Grade 2 O-rings in Viton (-15...+200 °C), Kalrez (-30...+210 °C), Silicone (-60...+200 °C), EPDM (-40...+160 °C), FEP coated (-60...+200 °C)

(DN 8...100) SS 1.4404 (316L), (DN 8...80) Alloy C-22 2.4602 (N 06022) no internal gaskets



PN 40 PN 64 PN 100 L L Х х х [mm] [mm] [mm] [mm] [mm] DN 8 402 402 25 20 DN 15 438 20 438 25 _ _ DN 15 * 572 19 578 26 _ _ DN 25 578 23 _ 578 29 _ DN 25 * 22 700 706 31 _ _ DN 40 _ 708 708 26 _ 32 DN 40 * 819 24 825 33 DN 50 827 28 832 34 832 36

Promass I

DN 8: with DN 15 flanges as standard; * DN 15, 25, 40 "FB" = Full bore version of Promass I

Promass M, F													
	PN 16		PN 40		PN	64	PN 100						
Diameter	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]					
DN 8 ** DN 15 ** DN 25 DN 40 DN 50 DN 80 DN 100 *** DN 100 DN 150 ****	- - - 874 1128 1168	- - - 20 22	370 404 550 715 840 874 1128 1168	16 16 18 20 24 24 24 24 24 28	400 420 470 590 724 875 - 1128 -	20 20 24 26 28 - 30 -	400 420 470 590 740 885 - 1128 -	20 20 24 26 28 32 - 36 -					

DN 8: with DN 15 flanges as standard; Nominal Diameter DN 100: only for Promass F available; ** DN 8, 15: also available with DN 25, PN 40 flanges (L = 440 mm, x = 18 mm); *** DN 100: diameter DN 80 with DN 100 flanges;

**** DN 150: diameter DN 100 with DN 150 flanges

Fig. 35 Dimensions DIN process connections ba033y43

ANSI B 16.5 process connections

Promass IWetted parts materials:titanium Grade 9Welded process connections:no internal gaskets

Promass M Flange material: Gasket material:

SS 1.4404 (316L), titanium Grade 2 O-rings in Viton (-15...+200 °C), Kalrez (-30...+210 °C), Silicone (-60...+200 °C), EPDM (-40...+160 °C), FEP coated (-60...+200 °C)

Promass F Flange material:

Welded process connections:

(DN 8...100) SS 1.4404 (316L), (DN 8...80) Alloy C-22 2.4602 (N 06022) no internal gaskets



Surface finish of the flanges

For Class 150, Class 300, Class 600: R_a 3.2...6.3 μm

Promass I												
Dian	neter	Class	s 150	Class	s 300	Class 600						
ANSI	DIN	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]					
³ /8" 1/2" 1/2" * 1" 1" * 1 ¹ /2" 1 ¹ /2" * 2"	DN 8 DN 15 DN 15 * DN 25 DN 25 * DN 40 DN 40 * DN 50	402 438 572 578 700 708 819 827	20 20 19 23 22 26 24 28	402 438 572 578 700 708 819 827	20 20 19 23 22 26 24 28	402 438 578 578 706 708 825 832	20 20 22 23 25 28 29 33					

 3 8 : with 1 2 flanges as standard; * DN 15, 25, 40 "FB" = Full bore versions of Promass I

	Promass M, F						
Diar	neter	Class 150		Class	s 300	Class 600	
ANSI	DIN	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]
³ /8" 1/2" 1" 1 ¹ /2" 2" 3" 4" ** 4" 6" ***	DN 8 DN 15 DN 25 DN 40 DN 50 DN 80 DN 100 ** DN 100 DN 150 ***	370 404 550 715 840 874 1128 1168	11.2 11.2 14.2 17.5 19.1 23.9 23.9 23.9 23.9 25.4	370 404 440 550 715 840 894 1128 -	14.2 14.2 17.5 20.6 22.3 28.4 31.7 31.7 -	400 420 490 600 742 900 - 1158 -	20.6 20.6 23.9 28.7 31.8 38.2 - 48.4 -

³/₈" with ¹/₂" flanges as standard; Nominal diameter 4" / DN 100: only for Promass F available; ** 4"/DN 100: nominal diameter 3"/DN 80 with 4"/DN 100 flanges;

*** 6"/DN 150: nominal diameter 4"/DN 100 with 6"/DN 150 flanges

Fig. 36 Dimensions ANSI process connections

JIS B2238 process connections

Promass I titanium Grade 9 Wetted parts materials: Welded process connections: no internal gaskets

Promass M Flange material: Gasket material:

SS 1.4404 (316L), titanium Grade 2 O-rings in Viton (-15...+200 °C), Kalrez (-30...+210 °C), Silicone (-60...+200 °C), EPDM (-40...+160 °C), FEP coated (-60...+200 °C)

Promass F Flange material:

(DN 8...100) SS 1.4404 (316L), (DN 8...80) Alloy C-22 2.4602 (N 06022)

Welded process connections: no internal gaskets



Surface finish of the flanges

For 10K, 20K, 40K, 63K: Ra 3.2...6.3 µm

	Promass I							
Diameter	10	10K		ЭK	40K		63K	
	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]
DN 8 DN 15 DN 15 * DN 25 DN 25 * DN 40 DN 40 * DN 50	- - - - - - - - - - - 827	- - - - - - 28	402 438 572 578 700 708 819 827	20 20 19 23 22 26 24 28	404 440 580 580 706 708 826 828	20 20 23 23 25 26 29 28	404 440 580 580 706 708 826 828	20 20 23 23 25 26 29 28

DN 8: with DN 15 flanges as standard;

* DN 15, 25, 40 "FB" = Full bore versions of Promass I

	Promass M, F							
	10	Ж	20	ЭK	40	Ж	63K	
Diameter	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]	L [mm]	x [mm]
DN 8 DN 15 DN 25 DN 40 DN 50 DN 80 DN 100 ** DN 100	- - 715 832 864 1128	- - 16 18 18 18	370 404 550 715 832 - 1128	14 14 16 18 18 22 - 24	400 425 485 600 760 890 - 1168	20 20 22 24 26 32 - 36	420 440 494 620 775 915 - 1168	23 23 27 32 34 40 - 44
DN 150 ***	1168	22	-	-	-	-	-	-

DN 8: with DN 15 flanges as standard; Nominal diameter DN 100: only for Promass F available; ** DN 100: diameter DN 80 with DN 100 flanges; *** DN 150: diameter DN 100 with DN 150 flanges

JIS process connections

Fig. 37

Dimensions

PVDF process connections (DIN 2501 / ANSI B 16.5 / JIS B2238)

This process connection is only available for Promass M

Flange material: Gasket material: PVDF O-rings in Viton (–15...+200 °C), Kalrez (–30...+210 °C), Silicone (–60...+200 °C), EPDM (–40...+160 °C)





Fig. 38 Dimensions and screw tightening torques PVDF process connections

Dimensions Process Connections according to VCO

Promass I

Process connection materials: titanium Grade 2 Welded process connections: no internal gaskets

Promass M

Process connection materials: SS 1.4404 (316L) Gasket materials: O-rings in Viton (–

s: SS 1.4404 (316L) O-rings in Viton (–15...+200 °C), Kalrez (–30...+210 °C), Silicone (–60...+200 °C), EPDM (–40...+160 °C)

Promass F

Process connection materials: SS 1.4404 (316L) Welded process connections: no internal gaskets



Diameter /	Promass M	Promass F
Connection	L [mm]	L [mm]
DN 8 8-VCO-4 (¹ / ₂ ")	390	390
DN 15 12-VCO-4 (³ / ₄ ")	430	430



Fig. 39 Dimensions VCO-process connection (Promass M, F)

Fig. 40 Dimensions VCO-process connection (Promass I)

Hygienic coupling (DIN 11851 / SMS 1145)

Promass I (completely welded version) Coupling: titanium Grade 2

Promass M(connections with internal gaskets)Coupling:SS 1.4404 (316L)Gasket:Silicone flat gasket (-60...+200 °C) or
EPDM (-40...+160 °C), FDA licensed gasket materials

Promass F (completely welded version) Coupling: SS 1.4404 (316L)

	_					50			ba033y50
			Proma	ss M, F					
D	iameter	L [r	mm]	ØC DIN 1	G 1851	ØG SMS 11	145		
	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$								
			Prom	nass I					
		DIN 1	1851			SMS	1145		
Diameter	L [m	im]	Ø	íG	L	[mm]		ØG	_
DN 8 DN 8 DN 15 DN 15 DN 15 DN 25 DN 25 DN 25 DN 40 DN 40 DN 40 *	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$								
	** DN 15 3	, 25, 40 " A version	FB" = Full n with R _a ≤	bore vers 0.8 μm a	sions of F s standa	Promass I; rd			

Fig. 41 Dimensions Hygienic coupling DIN 11851 / SMS 1145

Tri-Clamp

DN 80 M

3"

Promass I (completely welded version) Tri-Clamp: titanium Grade 2

Promass M (connections with internal gaskets)Tri-Clamp:SS 1.4404 (316L)Gasket:Silicone flat gasket (-60...+200 °C) or
EPDM (-40...+160 °C), FDA licensed gasket materials

Promass F (completely welded version)Tri-Clamp:SS 1.4404 (316L)



801

* Nominal diameter DN 100: only for Promass F available

3"

		Pron	nass I				
Dian	neter	Clamp	L	ØG	ØD		
DIN	ANSI		[mm]	[mm]	[mm]		
DN 8 DN 8 DN 15 DN 15 DN 15 DN 15 DN 15 ** DN 25 DN 25 ** DN 40 DN 40 **	3/8" $3/8"$ $3/8"$ $1/2"$ $1/2"$ $1/2"$ $1/2"$ $1/2"$ $1/2"$ $1/2"$ $1'/2"$ $1'/2"$ $1'/2"$ $1'/2"$	1/2" 3/4" 1" 1/2" 3/4" 1" 3/4" 1" 3/4" 1" 1" 1"/2" 1'/2" 1'/2" 2"	426 427 462 462 463 602 603 730 731 849	25.0 25.0 50.4 25.0 25.0 50.4 25.0 50.4 50.4 50.4 50.4 50.4 62.0	9.5 16.0 22.1 9.5 16.0 22.1 16.0 22.1 22.1 22.1 34.8 34.8 475		
	DN 50 2 2 850 63.9 47.5 ** DN 15, 25, 40 "FB" = Full bore versions of Promass I; 3A version with $B_{e} \le 0.8$ µm or $B_{e} \le 0.4$ µm as standard						

Fig. 42 Dimensions Tri-Clamp

72.9

90.9

ba033y52



10.8 Dimensions of purge connections (pressure vessel monitoring)

Fig. 43 Dimensions of purge connections (pressure vessel monitoring)

Diame	ter	Prom	ass A	Prom	nass I	Promass M		Promass F		Connection
DIN	ANSI	L	Н	L	Н	L	н	L	н	G
DN 1 DN 2 DN 4 DN 8 DN 15 DN 15* DN 25* DN 25* DN 40 DN 40* DN 50 DN 80 DN 100	$\begin{array}{c} {}^{1/24"}\\ {}^{1/12"}\\ {}^{1/8"}\\ {}^{3/8"}\\ {}^{1/2"}\\ {}^{1/2"}\\ {}^{1/2"}\\ {}^{1'}\\ {}^{1'}\\ {}^{2"}\\ {}^{1'/2"}\\ {}^{2"}\\ {}^{3"}\\ {}^{3"}\\ {}^{4"}\end{array}$	92.0 130.0 192.5 - - - - - - - - - - - - - - - - - - -	87.0 87.0 97.1 - - - - - - - - - - - - - - - - - - -	- 61 79 79 148 148 196 196 254 -	- 78.15 78.15 78.15 78.15 78.15 78.15 90.85 90.85 105.25 - -	- 85 100 - 110 - 155 - 210 210 -	- 44.0 46.5 - 50.0 - 59.0 - 67.5 81.5 -	- - 108 110 - 130 - 155 - 226 280 342	- 47 47 - 47 - 52 - 64 86 100	1/2" NPT 1/2" NPT
	* DN 15, 25, 40 "FB" = Full bore versions of Promass I									

11 Technical Data

Application							
Instrument name	Flow mea	Flow measuring system Promass 63 PROFIBUS-DP/-PA					
Instrument function	Mass and piping.	d volumetric flow m	easurement of liquids and gases in closed				
	F	unction and sys	tem design				
Measuring principle	Mass flov (see page	v measurement acc e 7 ff.)	cording to the Coriolis measuring principle				
Measuring system	Instrumer Transmitte Sensors:	nt family "Promass er: Promass 63 Promass A, I, M ar	63" consisting of: Id F				
	• Promas	ss A DN 1, 2, 4 a Single tube	nd DN 2, 4 (high pressure version) system in SS or Alloy C-22				
	• Promas	ss I DN 8, 15, 28 Straight sing DN 15 "FB", Full bore ve (see table b	5, 40, 50 (completely welded version) gle tube system in titanium DN 25 "FB", DN 40 "FB": rsions with a higher full scale value elow)				
	• Promas	ss F DN 8, 15, 28 Two slightly Alloy C-22 (5, 40, 50, 80, 100 (completely welded versions) curved measuring tubes in SS or only for DN 880)				
	 Promass M DN 8, 15, 25, 40, 50, 80 Two straight measuring tubes in titanium Containment vessel up to 100 bar. DN 8, 15, 25 high pressure version for operating pressures up to 350 bar. 						
	Two versi	ons are available:	Compact versionRemote version (max. 20 m)				
		Input varia	bles				
Measured variables	 Mass floor the Fluid d tubes) Fluid te 	low rate (is proport measuring tube wh ensity (is proportio emperature (is mea	inal to the phase difference of the two sensors nich detect differences in its oscillation) nal to the resonance frequency of the measuring sured with temperature sensors)				
Measuring range			Range for full scale values				
	DN [mm]	Liquid ṁ _{min(L)} ṁ _{max(L)}	Gas m _{min(G)} m _{max(G)}				
	1 2 4 8 15 25 25 40 40 * 50 80 100	0 20.0 kg/h 0 100.0 kg/h 0 450.0 kg/h 0 2.0 t/h 0 6.5 t/h 0 18.0 t/h 0 45.0 t/h 0 45.0 t/h 0 70.0 t/h 0 70.0 t/h 0 350.0 t/h	The full scale depends on the density of the gas. The full scale value can be determined with the following formula: $\dot{m}_{max(G)} = \frac{\dot{m}_{max(L)} \cdot \rho_{(G)}}{x \cdot 16}$ $\dot{m}_{max(G)} =$ Full scale value gas [t/h] $\dot{m}_{max(L)} =$ Full scale value liquid [t/h] (value from table) $\rho_{(G)} =$ gas density [kg/m ³] (at operating condition) $x = \text{constant} [kg/m^3]$ Promass A $x = 20$ Promass I, M, F $x = 100$ 'FB" = Full bore versions of Promass I				

Input variables (continued)						
Measuring range (continued)	Example for calculating a gas full scale: Sensor: Promass F $\rightarrow x = 100$ Nominal diameter DN 50 \rightarrow 70.0 t/h (full scale value liquid from table on page 125).					
	Gas: Air with a density of 60.3 kg/m ³ (at 20°C and 50 bar)					
	$\dot{m}_{max(G)} = \frac{\dot{m}_{max(L)} \cdot \rho_{(G)}}{x \cdot 1.6} = \frac{70.0 \cdot 60.3}{100 \cdot 1.6} = 26.4 \text{ t/h}$					
Operable flow range	up to 1000 : 1 This enables totalizer values to be accurately determined even in pulsating systems, e.g. reciprocating pumps.					
	Output variables PROFIBUS-DP					
Output signal	PROFIBUS-DP interface: PROFIBUS-DP according EN 50170 Volume 2, RS 485					
Signal on alarm	PROFIBUS-DP interface: Status message according to PROFIBUS profile version 2					
Speed of transmision	<i>Baud rate used:</i> 9.6 kBaud; 19.2 kBaud; 93.75 kBaud; 187.5 kBaud; 500 kBaud; 1.5 MBaud; 3 MBaud; 6 MBaud; 12 MBaud					
Signal encoding	NRZ code					
	Output variables PROFIBUS-PA					
Output signal	$\begin{array}{l} eq:problem_probl$					
Signal on alarm	PROFIBUS-PA interface: Status and alarms according to PROFIBUS profile version 2. Current output:					
	In case of an alarm the current output delivers the previous defined signal.					
Permissble power voltage	Non intrinsically safe = 9 V32 V					
FDE (Fault Disconnection Electronic)	0 mA					
Speed of transmision	Baud rate used = 31.25 kBaud					
Signal encoding	Manchester II					
	Output variables general					
Creep suppression	Switch points for low flow selectable (see page 90). Hysteresis: –50 %					

		Accu	iracy				
Reference conditions	Error limit 2030 Calibra Zero po Field d	 Error limits based on ISO / DIS 11631: 2030 °C; 24 bar Calibration rig based on national standards Zero point calibrated under operating conditions Field density calibration carried out (for special density calibration) 					
Measured error	• <i>Mass f</i> Promas Promas	<i>low rate (liquids</i> ss A, M, F ss I	s): ± 0.10% ± [zero stabi ± 0.15% ± [zero stabi	lity / flow rate) x 100]% of rate lity / flow rate) x 100]% of rate			
	• Mass f Promas	<i>low rate (gas):</i> ss A, I, M, F	± 0.50% ± [zero stabi	lity / flow rate) x 100]% of rate			
	Volume Promas Promas Promas	e flow rate (liqui ss A, M ss I ss F	ds): ±0.25% ± [zero stabi ±0.50% ± [zero stabi ±0.15% ± [zero stabi	lity / flow rate) x 100]% of rate lity / flow rate) x 100]% of rate lity / flow rate) x 100]% of rate			
	zero sta	ability \rightarrow see ta	ble below				
	Note! • The va • Additio	lues refer to the nal measuring	PROFIBUS-PA interfa error of the current out	ce. put: ±5 μA typical.			
	DN [mm]	Max. full scale [kg/h] or [l/h]	Zero stability Promass A, M, F [kg/h] or l/h]	Zero stability Promass I [kg/h] or [l/h]			
	1 2 4 8 15 15 * 25 25 * 40 40 * 50 80 100	20 100 450 2000 6500 18000 18000 45000 45000 70000 70000 180000 350000	0.0010 0.0050 0.0225 0.1000 0.3250 0.90 2.25 3.50 9.00 14.00	 0.200 0.650 1.800 1.800 4.500 4.500 7.000 7.000 			
	100	100 350000 14.00 * DN 15, 25, 40 "FB" = Full bore versions of Promass I					
	Example Promass DN 25, Q Measure	for calculating $F \rightarrow \pm 0.10\% = 3.6 t/h = 360t/h = 360t/$	the measuring error: ± [zero stability / flow ra 00 kg/h 0% ± <u>0.9 kg / h</u>	ate) x 100]% of rate 100 % = ±0.125 %			
	Density (I	liquid):					
	 Standa Promas 	rd calibration: ss A, I, M ss F	± 0.02 g/cc ± 0.01 g/cc	(1 g/cc = 1 kg/l)			
	 Specia Calibra Promas Promas 	l calibration (op tion range = 0. s A, M ss I ss F	otional): 81.8 kg/l, 580 °C ± 0.002 g/cc ± 0.004 g/cc ± 0.001 g/cc				
	Density Promas Promas Promas	/ calibration in t ss A, M ss I ss F	the field: ± 0.0010 g/cc ± 0.0020 g/cc ± 0.0005 g/cc				
	<i>Temperat</i> Promass	<i>ture:</i> A, I, M, F	± 0.5 °C ± 0.005 · T	(T = fluid temperature in °C)			

	Accuracy (continued)						
Repeatability	• <i>Mass flow</i> Promass / ± 0.05% ±	<i>r rate (liquids,</i> A, I, M, F : [¹ / ₂ x (zero s): tability / flow	rate) x 100]%	6 of rate		
	• <i>Mass flow</i> Promass / ± 0.25% ±	<i>r rate (gas):</i> A, I, M, F : [¹ / ₂ x (zero s	tability / flow	rate) x 100]%	6 of rate		
	Volume flo Promass / Promass I Promass F	ow rate (liquic A, M, ± 0.1 ± 0.2 = ± 0.0	<i>ds):</i> 0% ± [¹ / ₂ x (z 0% ± [¹ / ₂ x (z 5% ± [¹ / ₂ x (z	ero stability / ero stability / ero stability /	flow rate) x 1 flow rate) x 1 flow rate) x 1	100]% of rate 100]% of rate 100]% of rate	
	zero stabi	lity $ ightarrow$ (see ta	ble page 129))			
	<i>Example for</i> Promass F – DN 25, Q =	<i>calculating r</i> → ± 0.05% ± [3.6 t/h = 3600	e <i>peatability:</i> ¹ / ₂ x (zero sta) kg/h	ability / flow ra	ate) x 100]%	of rate	
	Repeatability	$y \rightarrow \pm 0.05 \%$	$\pm \frac{1}{2} \cdot \frac{0.9 \text{ kg}}{3600 \text{ kg}}$	/h g/h · 100 %	$= \pm 0.0625$	%	
	Density m Promass / Promass I Promass I	easurement (A, M ± ± = ±	(<i>liquids</i>): 0.00050 g/cc 0.00100 g/cc 0.00025 g/cc	c (1 g	I/cc = 1 kg/l)		
	Temperation Promass /	ure measurer A, I, M, F ±(<i>nent:</i> 0.25 °C ±0.00	025 · T (T =	fluid temper	ature in °C)	
Process effects	Process te The below temperatur was carrier	 Process temperature effects: The below value represents the zero point error due the changing process temperature away from the temperature at which a zero point adjustment was carried out: Promass A, I, M, F typical = ± 0.0002 % / °C 					
	Process pi The below due to cha in % of rate	ressure effect defined value nging proces e / bar).	<i>s:</i> es represent t s pressure av	the effect on way from cali	accuracy of r bration press	mass flow sure (values	
	Diameter	Promass A	Promass I	Promass M	Promass MP	Promass F	
	DN [mm]	Flow rate % o.r.** / bar	Flow rate % o.r.** / bar	Flow rate % o.r.** / bar	Flow rate % o.r.** / bar	Flow rate % o.r.** / bar	
	1	none	_		_	_	
	2 4	none	_		_	_	
	8		0.006	0.009	0.006	none	
	15 *	_	0.006			_	
	25 25 *	_	0.006 none	0.009	0.003	none	
	40	—	none	0.005	—	-0.003	
	50	_	0.006	none	_	-0.008	
	80 100	_	_	none	_	-0.009 -0.012	
		* DN 15, 25	5, 40 "FB" = Ful ** o.r. =	l bore version o of rate	of Promass I	I	
		Operating c	onditions				
Installation conditions							
Installation instructions	Orientation: Restrictions	vertical or ho and other rec	rizontal commendatio	ns → see pa	ge 11 ff.		
Inlet and outlet sections	Installation s	ite is indeper	ndent of inlet	and outlet se	ctions		
Connection cable length	max. 20 m (i	remote versio	n)				

	Operating conditions (continued)
Ambient conditions	
Ambient temperature	Transmitter and Sensor: -25+60 °C (version with enhanced climate resistance: -40+60 °C)
	 Depending on the product temperature, certain installation positions are to be observed to ensure that the permitted ambient temperature range for the transmitter is not exceeded (see page 14). An all-weather cover should be used to protect the housing from direct sunlight when mounting in the open. This is especially important in warmer climates and with high ambient temperatures. If the ambient temperature is below -25 °C, it is not recommended to use a version with display.
Storage temperature	-40+80 °C
Degree of protection (EN 60529)	Transmitter: IP 67; NEMA 4X Sensor: IP 67; NEMA 4X
Shock resistance	according to IEC 68-2-31
Vibrational resistance	up to 1 g, 10150 Hz according to IEC 68-2-6
Electromagnetic compatibility (EMC)	According to EN 50081 Part 1 and 2 / EN 50082 Part 1 and 2 as well as to NAMUR recommendations
Process conditions	
Fluid temperature	 Sensor Promass A -50+200 °C Promass I -50+150 °C Promass M -50+150 °C Promass F -50+200 °C Gaskets Viton (-15+200 °C), EPDM (-40+160 °C), Silicone (-60+200 °C), Kalrez (-30+210 °C), FEP coated (-60+200 °C)
Nominal pressure	 Promass A Fittings: max. 160 bar (standard version), max. 400 bar (high pressure version) Flanges: DIN PN 40 / ANSI CI 150, CI 300 / JIS 10K Containment vessel: 25 bar resp. 375 psi Promass I Flanges: DIN PN 40PN 100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: 25 bar (optional 40 bar) resp. 375 psi (optional 600 psi) Promass M Flanges: DIN PN 40100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: DIN PN 40100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: 40 bar (optional 100 bar) resp. 600 psi (optional 1500 psi) Promass M (High pressure version) Measuring tubes, connectors, fittings: maximum 350 bar Containment vessel: 100 bar resp. 1500 psi Promass F Flanges: DIN PN 16100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: DN PN 16100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: DIN PN 16100 / ANSI CI 150, CI 300, CI 600 / JIS 10K, 20K, 40K, 63K Containment vessel: DN 850: optional 40 bar resp. 600 psi) Caution! The material load curves (p-T-load diagrams) for all process connections can be found in the Technical Information TI 030D/06/en for Promass 63.
Pressure loss	Dependent on nominal diameter and sensor type (see page 134 ff.)

Caution!

	Mechanical construction			
Design / Dimensions	see page 111 ff.			
Weights	see page 111 ff.			
Materials	 Transmitter hous Powder-coated Sensor housing Promass A, I, F Promass M 	sing die-cast aluminium / containment vessel Surface resistance to acids and alkalis SS 1.4301 (304L) Surface resistance to acids and alkalis DN 850: chemically nickel-plated steel DN 80: SS 1.4313		
	 Sensor connect SS 1.4301 (304) Process connect Promass A Promass M (high Promass I, M, F 	ion housing (remote version) -) stions: \rightarrow see page 111 h pressure) \rightarrow see page 115 \rightarrow see page 118 ff.		
	 Measuring tube Promass A Promass I Promass M Promass F Gaskets: Promass A, F Promass I, M Promass M 	s SS 1.4539 (904L), Alloy C-22 2.4602 (N 06022) titanium Grade 9 titanium Grade 2 (DN 80), titanium Grade 9 (DN 850) (DN 8100) SS 1.4539 (904L), (DN 880) Alloy C-22 2.4602 (N 06022) no internal seals see page 118–124 (for high pressure version) Silicone, Viton		
Process connections	Promass A	Welded process connections: 4-VCO-4 fittings, ¹ / ₂ " Tri-Clamp <i>Screw-on process connections:</i> Flanges (DIN, ANSI, JIS B2238), NPT-F and SWAGELOK fittings		
	Promass I	<i>Welded process connections:</i> 12-VCO-4 fittings, Flanges (DIN 2501, ANSI B16.5, JIS B2238) <i>Sanitary connections:</i> Tri-Clamp, Hygienic coupling DIN 11851 / SMS 1145		
	Promass M	Screw-on process connections: 8-VCO-4 fittings, 12-VCO-4 fittings, Flanges (DIN 2501, ANSI B16.5, JIS B2238) Sanitary connections: Tri-Clamp, Hygienic coupling DIN 11851 / SMS 1145		
	Promass M High pressure	<i>Screw-on process connections:</i> G ³ / ₈ ", ¹ / ₂ " NPT, ³ / ₈ " NPT or ¹ / ₂ " SWAGELOK coupling; connector with 7/8 14UNF internal thread		
	Promass F	<i>Welded process connections:</i> 8-VCO-4 fittings, 12-VCO-4 fittings, Flanges (DIN 2501, ANSI B16.5, JIS B2238) <i>Sanitary connections:</i> Tri-Clamp, Hygienic coupling DIN 11851 / SMS 1145		
Electrical connection	 Wiring diagram: see Chapter 4 Cable glands (In-/outputs; remote version): PG 13.5 cable glands (515 mm) or ¹/₂" NPT, M20 x 1.5 (815 mm), G ¹/₂" threads for cable glands Galvanic isolation: All circuits for inputs, outputs, power supply, and sensor are galvanically isolated from each other. Cable specifications (remote version): see page 21 			

User interface			
Operation	On-site operation with 3 operating elements for setting all instrument functions in the E+H operating matrix (see page 59 resp. 60)		
Display	LC-display, illuminated, double-spaced with 16 characters each		
Communication	PROFIBUS-DP/-PA		
	Power supply		
Supply voltage, frequency	<i>Transmitter:</i> 85260 V AC (5060 Hz) 2055 V AC, 1662 V DC <i>Sensor:</i>		
Power consumption	AC: <15 VA (incl. sensor) DC: <15 W (incl. sensor)		
Power supply failure	Bridges min. one power cycle (22 ms).		
	 EEPROM saves measuring system data on power failure (no batteries required) DAT = exchangeable data storage module which stores all sensor data such as calibration data, nominal diameter, sensor version, etc. When replacing the transmitter or its electronics, the old DAT module is simply inserted into the new transmitter. When the system is restarted, the measuring point then operates using the variables stored in the DAT. 		
	Certificates and approvals		
Ex approvals (only for PROFIBUS-PA)	Information on presently available Ex versions (e.g. ATEX / CENELEC, FM, CSA) can be supplied by your E+H Sales Centre on request. All explosion protection data are given in separate documentation available on request.		
CE mark	By attaching the CE-mark, Endress+Hauser confirms that the Promass 63 PROFIBUS-DP/-PA measurement system has been successfully tested and fulfils all legal requirements of the relevant EC directives.		
	Order information		
Accessories Post mounting set for Promass A: DN 1, 2: Order No. 500 77972 DN 4: Order No. 500 79218 Post mounting set for remote transmitter housing: Order No. 500 76905 			
Supplementary documentation	System Information PromassSI014D/06/enTechnical Information Promass 60TI029D/06/enTechnical Information Promass 63TI030D/06/enOperating Manual Promass 60BA013D/06/en		
	Other standards and guidelines		
EN 50170PROFIBUS, Volume 2EN 60529Degree of protectionEN 61010Protection Measures for Electronic Equipment for Measurement, Control, Regulation and Laboratory ProceduresEN 50081Part 1 and 2 (interference emission)EN 50082Part 1 und 2 (interference immunity)NAMURAssociation of Standards for Control and Regulation in the Chemical Industry			

Pressure loss

The pressure loss is dependent on the characteristics of the fluid and its flow rate. The following formulae can be used for liquids to approximately calculate the pressure loss:

	Promass A / I	Promass M / F	
Reynolds No.	$Re = \frac{4 \cdot \dot{m}}{\pi \cdot d \cdot \upsilon \cdot \rho}$	$Re = \frac{2 \cdot \dot{m}}{\pi \cdot d \cdot \upsilon \cdot \rho}$	
Re≥2300 *	$\Delta p = K \cdot \upsilon^{0.25} \cdot \dot{m}^{1.75} \cdot \rho^{-0.75} + \frac{K_3 \cdot \dot{m}^2}{\rho}$	$\Delta p = K \cdot \upsilon^{0.25} \cdot \dot{m}^{1.85} \cdot \rho^{-0.86}$	
Re < 2300	$\Delta p = K1 \cdot \upsilon \cdot \dot{m} + \frac{K3 \cdot \dot{m}^2}{\rho}$	$\Delta p = K1 \cdot \upsilon \cdot \dot{m} + \frac{K2 \cdot \upsilon^{0.25} \cdot \dot{m}^2}{\rho}$	
$\begin{array}{llllllllllllllllllllllllllllllllllll$			
* For gases the pressure loss has always to be calculated by use of the formula for $Re \ge 2300$.			

	Diameter	d [m]	K	K1	K2	K3
Promass A	DN 1 DN 2 DN 4	1.10 · 10 ⁻³ 1.80 · 10 ⁻³ 3.50 · 10 ⁻³	1.2 · 10 ¹¹ 1.6 · 10 ¹⁰ 9.4 · 10 ⁸	1.3 · 10 ¹¹ 2.4 · 10 ¹⁰ 2.3 · 10 ⁹		0 0 0
Promass A High press.	DN 2 DN 4	1.40 · 10 ⁻³ 3.00 · 10 ⁻³	5.4 · 10 ¹⁰ 2.0 · 10 ⁹	6.6 · 10 ¹⁰ 4.3 · 10 ⁹	-	0 0
Promass I	DN 8 DN 15 DN 15 * DN 25 DN 25 * DN 40 DN 40 * DN 50	$\begin{array}{c} 8.55 \cdot 10^{-3} \\ 11.38 \cdot 10^{-3} \\ 17.07 \cdot 10^{-3} \\ 17.07 \cdot 10^{-3} \\ 25.60 \cdot 10^{-3} \\ 25.60 \cdot 10^{-3} \\ 35.62 \cdot 10^{-3} \\ 35.62 \cdot 10^{-3} \end{array}$	$\begin{array}{c} 8.1 \cdot 10^{6} \\ 2.3 \cdot 10^{6} \\ 4.1 \cdot 10^{5} \\ 4.1 \cdot 10^{5} \\ 7.8 \cdot 10^{4} \\ 7.8 \cdot 10^{4} \\ 1.3 \cdot 10^{4} \\ 1.3 \cdot 10^{4} \end{array}$	$\begin{array}{c} 3.9 \cdot 10^{7} \\ 1.3 \cdot 10^{7} \\ 3.3 \cdot 10^{6} \\ 3.3 \cdot 10^{6} \\ 8.5 \cdot 10^{5} \\ 8.5 \cdot 10^{5} \\ 2.0 \cdot 10^{5} \\ 2.0 \cdot 10^{5} \\ 2.0 \cdot 10^{5} \end{array}$	- - - - - - - -	$\begin{array}{c} 129.95 \cdot 10^{4} \\ 23.33 \cdot 10^{4} \\ 0.01 \cdot 10^{4} \\ 5.89 \cdot 10^{4} \\ 0.11 \cdot 10^{4} \\ 1.19 \cdot 10^{4} \\ 0.08 \cdot 10^{4} \\ 0.25 \cdot 10^{4} \end{array}$
Promass M	DN 8 DN 15 DN 25 DN 40 DN 50 DN 80	$\begin{array}{c} 5.53 \cdot 10^{-3} \\ 8.55 \cdot 10^{-3} \\ 11.38 \cdot 10^{-3} \\ 17.07 \cdot 10^{-3} \\ 25.60 \cdot 10^{-3} \\ 38.46 \cdot 10^{-3} \end{array}$	$\begin{array}{c} 5.2 \cdot 10^{7} \\ 5.3 \cdot 10^{6} \\ 1.7 \cdot 10^{6} \\ 3.2 \cdot 10^{5} \\ 6.4 \cdot 10^{4} \\ 1.4 \cdot 10^{4} \end{array}$	$\begin{array}{c} 8.6 \cdot 10^{7} \\ 1.7 \cdot 10^{7} \\ 5.8 \cdot 10^{6} \\ 1.2 \cdot 10^{6} \\ 4.5 \cdot 10^{5} \\ 8.2 \cdot 10^{4} \end{array}$	$\begin{array}{c} 1.7 \cdot 10^{7} \\ 9.7 \cdot 10^{5} \\ 4.1 \cdot 10^{5} \\ 1.2 \cdot 10^{5} \\ 1.3 \cdot 10^{4} \\ 3.7 \cdot 10^{3} \end{array}$	
Promass M High press.	DN 8 DN 15 DN 25	$\begin{array}{r} 4.93 \cdot 10^{-3} \\ 7.75 \cdot 10^{-3} \\ 10.20 \cdot 10^{-3} \end{array}$	6.0 · 10 ⁷ 8.0 · 10 ⁶ 2.7 · 10 ⁶	1.4 · 10 ⁸ 2.5 · 10 ⁷ 8.9 · 10 ⁶	$\begin{array}{c} 2.8 \cdot 10^{7} \\ 1.4 \cdot 10^{6} \\ 6.3 \cdot 10^{5} \end{array}$	
Promass F	DN 8 DN 15 DN 25 DN 40 DN 50 DN 80 DN 100	$\begin{array}{c} 5.35 \cdot 10^{-3} \\ 8.30 \cdot 10^{-3} \\ 12.00 \cdot 10^{-3} \\ 17.60 \cdot 10^{-3} \\ 26.00 \cdot 10^{-3} \\ 40.50 \cdot 10^{-3} \\ 51.20 \cdot 10^{-3} \end{array}$	$\begin{array}{c} 5.70 \cdot 10^{7} \\ 5.80 \cdot 10^{6} \\ 1.90 \cdot 10^{6} \\ 3.50 \cdot 10^{5} \\ 7.00 \cdot 10^{4} \\ 1.10 \cdot 10^{4} \\ 3.54 \cdot 10^{3} \end{array}$	$\begin{array}{c} 9.60 \cdot 10^{7} \\ 1.90 \cdot 10^{7} \\ 6.40 \cdot 10^{6} \\ 1.30 \cdot 10^{6} \\ 5.00 \cdot 10^{5} \\ 7.71 \cdot 10^{4} \\ 3.54 \cdot 10^{4} \end{array}$	$\begin{array}{c} 1.90 \cdot 10^{7} \\ 10.60 \cdot 10^{5} \\ 4.50 \cdot 10^{5} \\ 1.30 \cdot 10^{5} \\ 1.40 \cdot 10^{4} \\ 1.42 \cdot 10^{4} \\ 5.40 \cdot 10^{3} \end{array}$	- - - - -

Pressure loss data **inclusive** interface measuring tube(s) / piping Pressure loss diagrams for water can be found on the following page.

* DN 15, 25, 40 "FB" = Full bore versions of Promass I



Fig. 44 Pressure loss with water

Density of hydrous saccharose solution in kg/m ³								
°Brix	10 °C	20 °C	30 °C	40 °C	50 °C	60 °C	70 °C	80 °C
0	999.70	998.20	995.64	992.21	988.03	983.19	977.76	971.78
5	1019.56	1017.79	1015.03	1011.44	1007.14	1002.20	996.70	989.65
10	1040.15	1038.10	1035.13	1031.38	1026.96	1021.93	1016.34	1010.23
15	1061.48	1059.15	1055.97	1052.08	1047.51	1042.39	1036.72	1030.55
20	1083.58	1080.97	1077.58	1073.50	1068.83	1063.60	1057.85	1051.63
25	1106.47	1103.59	1099.98	1095.74	1090.94	1085.61	1079.78	1073.50
30	1130.19	1127.03	1123.20	1118.80	1113.86	1108.44	1102.54	1096.21
35	1154.76	1151.33	1147.58	1142.71	1137.65	1132.13	1126.16	1119.79
40	1180.22	1176.51	1172.25	1167.52	1162.33	1156.71	1150.68	1144.27
45	1206.58	1202.61	1198.15	1193.25	1187.94	1182.23	1176.14	1169.70
50	1233.87	1229.64	1224.98	1219.93	1214.50	1208.70	1202.56	1196.11
55	1262.11	1257.64	1252.79	1247.59	1242.05	1236.18	1229.98	1223.53
60	1291.31	1286.61	1281.59	1276.25	1270.61	1264.67	1258.45	1251.88
65	1321.46	1316.56	1311.38	1305.93	1300.21	1294.21	1287.96	1281.52
70	1352.55	1347.49	1342.18	1336.63	1330.84	1324.80	1318.55	1312.13
75	1384.58	1379.38	1373.88	1368.36	1362.52	1356.46	1350.21	1343.83
80	1417.50	1412.20	1406.70	1401.10	1395.20	1389.20	1383.00	1376.60
85	1451.30	1445.90	1440.80	1434.80	1429.00	1422.90	1416.80	1410.50

Density Calculation / °Brix

Table of °Brix used in the Brix density calculation

Source:

A.&L. Emmerich, Technical University of Brunswick; officially recommended by ICUMSA, 20th Session, 1990.

12 Functions at a glance

PROCESS VARIABLE		
MASS FLOW (p. 68)	Display: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 462.87 kg/h; -731.63 lb/min. etc.)	
VOLUME FLOW (p. 68)	Display: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 5.5445 dm ³ /min; 1.4359 m ³ /h; etc.)	
STD. VOLUME FLOW (p. 68	Display: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 1.3459 Nm ³ /h; 7.9846 scm/day; etc.)	
TARGET FLOW (p. 68)	Display: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 0.1305 m ³ /h; 1.4359 t/h; etc.)	
CARRIER FLOW (p. 69)	Display: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 0.0835 m ³ /h; 16.4359 t/h; etc.)	
DENSITY (p. 69)	Display: 5-digit number with fixed decimal point; incl. engineering units (corresp. to 0.100006.0000 kg/dm ³) (e.g. 1.2345 kg/dm ³ ; 993.5 kg/m ³ ; 1.0015 SG_20 °C; etc.)	
CALC. DENSITY (p. 69)	Display: 5-digit number with fixed decimal point; incl. engineering units (e.g. 76.409 °Brix; 39.170 %v; 1391.7 kg/Nm ³ ; etc.)	
TEMPERATURE (p. 69)	Display: 4-digit number with fixed decimal point; incl. engineering units and arithmetic sign (e.g23.40 °C; 160.0 °F; 295.4 K, etc.)	

TOTALIZER	
TOTALIZER 1 (p. 70)	Display: max. 7-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 1.546704 t; -4925.631 kg; etc.)
TOTAL. 1 OVERFLOW (p. 70)	Display: Integer to a decimal power e.g. 10 e7 kg
TOTALIZER 2 (p. 70)	Display: max. 7-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 1.546704 t; -4925.631 kg)
TOTAL. 2 OVERFLOW (p. 70)	Display: Integer to a decimal power e.g. 10 e7 kg
RESET TOTALIZER (p. 70)	CANCEL – TOTALIZER 1 – TOTALIZER 2 – TOTALIZER 1&2 Your setting:
ASSIGN TOTAL. 1 (p. 71)	OFF - MASS - MASS (+) - VOLUME - STD.VOLUME - VOLUME (+) - STD.VOLUME (+) - TARGET MATERIAL - TARGET MAT.(+) - CARRIER FLUID - CARRIER FLUID (+) - CANCEL (+) = The totalizer only registers flow in <i>positive</i> direction.
	Your setting:
ASSIGN TOTAL. 2 (p. 71)	OFF – MASS – MASS (-) – VOLUME – STD.VOLUME – VOLUME (-) – STD.VOLUME (-) – TARGET MATERIAL – TARGET MAT.(-) – CARRIER FLUID – CARRIER FLUID (-) – CANCEL
	 (-) = The totalizer only registers flow in <i>negative</i> direction.
	Your setting:

Promass 63	PROFIBUS-DP/-PA
------------	-----------------

SYSTEM-UNITS		CURRENT OUTP	CURRENT OUTPUT (only with PROFIBUS-PA available)		
MASS FLOW UNIT (p. 72)	g/min – g/h – kg/s – kg/min – kg/h – t/min – t/h – t/d – lb/s – Ib/min – lb/hr – ton/min – ton/hr – ton/day – CANCEL Your setting:	ASSIGN OUTPUT (p. 75)	OFF - MASS FLOW - VOLUME FLOW - STD.VOLUME FLOW - TARGET FLOW - CARRIER FLOW - DENSITY - STD. DENSITY - TEMPERATURE - CANCEL		
(p. 72)	g - kg - i - ib - ion - CANCEL		Your setting:		
VOLUME FLOW UNIT (p. 72)	$cm^{3}/min - cm^{3}/h - dm^{3}/s - dm^{3}/min - dm^{3}/h - 1/s - 1/min - 1/h - h1/min- h1/h - m^{3}/min - m^{3}/h - cc/min - cc/hr - gal/min - gal/hr - gal/day - gpm - gph - gpd - mgd - bb1/min - bb1/hr - bb1/day - CANCEL Your setting:$	ZERO SCALE (p. 75)	5-digit number with floating decimal point, incl. arithmetic sign (e.g1.500 kg/h; 245.92 kg/m ³ ; 105.60 °C) Factory setting: Mass flow: 0.0000 kg/h Density: 0.0000 kg/l Temperature: -50.000 °C		
	cm ³ - dm³ - I - hI - m ³ - cc - gal - bbl - CANCEL		Your setting:		
(p. 72) GALLONS / BARREL (p. 73)	Your setting: US: 31.0 gal/bbl – US: 31.5 gal/bbl – US: 42.0 gal/bbl – US: 55.0 gal/bbl – Imp: 36.0 gal/bbl – Imp: 42.0 gal/bbl – CANCEL Your setting:	FULL SCALE (p. 76)	5-digit number with floating decimal point, incl. arithmetic sign, depending on the variable (e.g566.00 kg/min; 0.9956 kg/dm ³ ; 105.60 °C) Factory setting: Mass flow: <i>dependent</i> on the nom. diam. Density: <i>2.0000 kg/l</i>		
STDVOL. FLOW UNIT (p. 73)	Nl/s – Nl/min – Nl/h – Nl/d – Nm ³ /s – Nm³/min – Nm ³ /h – Nm ³ /d – scm/s – scm/min – scm/hr – scm/day – scf/s –		Temperature: 200.00 °C Your setting:		
	scf/min – scf/hr – scf/day – CANCEL Your setting:	TIME CONSTANT (p. 77)	3- to 5-digit with fixed decimal point (0.01100.00 s) Factory setting: 1.00 s		
STD.VOLUME UNIT (p. 73)	Nm ³ - NI - scm - scf - CANCEL		Your setting:		
DENSITY UNIT (p. 74)	Your setting: g/cm ³ - kg/dm ³ - kg/l - kg/m ³ - SD_4 °C - SD_15 °C - SD_20 °C - g/cc - lb/cf - lb/USgal bzw. lb/gal * - lb/bbl - SG_59 °F - SG_60 °F - SG_68 °F - SG_4 °C - SG_15 °C - SG_20 °C - CANCEL * see function "GALLONS/BARREL" Your setting:	FAILSAFE MODE (p. 77)	0-20 mA (25 mA) - 4-20 mA (25 mA) - 0-20 mA - 4-20 mA - CANCEL Your setting: MIN. CURRENT Current signal is set to 0 mA (020 mA) or 2 mA (420 mA) on error. MAX. CURRENT		
STD.DENSITY UNIT (p. 74)	kg/Nm³ – kg/NI – g/scc – kg/scm – Ib/scf – CANCEL Your setting:		Current signal is set to 25 mA for 0/420 mA (25 mA) or 22 mA for 420 mA on error.		
TEMPERATUREE UNIT (p. 74)	° C (CELSIUS) – K (KELVIN) – °F (FAHRENHEIT) – °R (RANKINE)– CANCEL Your settina:		HOLD VALUE Last valid measured value is held. ACTUAL VALUE		
NOM.DIAM. UNIT (p. 74)	<i>mm</i> – inch – CANCEL Your setting:		Normal measured value is given despite error. CANCEL		
			Your setting:		

CURRENT OUTPL	JT (only with PROFIBUS-PA available)	DENSITY FUNCT	ION
SIMULATION CURR. (p. 78)	OFF - 0 mA - 10 mA - 20 mA - 22 mA - 25 mA (bei 020 mA) - 2 mA - 4 mA - 12 mA - 20 mA - 22 mA - 25 mA (bei 4, 20 mA)	DENS. ADJ. VALUE (p. 81)	5-digit number with floating decimal point; incl. engineering units (corresponding to 0.15.9999 kg/l)
NOMINAL	CANCEL Your setting:	DENSITY- ADJUST (p. 81)	CANCEL – SAMPLE FLUID 1 – SAMPLE FLUID 2 – DENSITY ADJUST
CURRENT (p. 78)	3-digit number with floating decimal point (0.0025.0 mA)	CALC. DENSITY (p. 84)	Your setting: OFF – %-MASS – %-VOLUME – STD. DENSITY – °BRIX – °BAUME >1kg/dm ³ – °BAUME <1kg/dm ³ – °API – %-BLACK LIQUOR – %-ALCOHOL – °PLATO °BALLING CANCEL
		VOLUME FLOW MEAS (p. 84)	Your setting: OFF - VOLUME FLOW - STD.VOLUME FLOW - VOLUMEN & STD. VOL CANCEL Your setting:
		STD. VOL. CALC. (p. 84)	CALC. STD. DENSITY – FIXED STD. DENSITY – CANCEL Your setting:
		REFERENCE TEMP. (p. 84)	5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 25.000 °C; -10.500 °C; 60.000 °F) Factory setting: 15.000 °C
		EXP. COEF. (p. 85)	Your setting: 5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 0.4400 e-3 1/K) Factory setting: 0.5000 e-3 1/K Your setting:
		FIXED STD. DENSITY (p. 85)	5-digit number with floating decimal point; incl. engineering units and arithmetic sign (e.g. 1.0000 kg/sl; 1000.0 kg/Nm ³) Factory setting: 1000.0 kg/Nm³ Your setting:
		CARRIER DENSITY (p. 85)	5-digit number with floating decimal point; incl. engineering units (e.g.1.0000 kg/dm ³ ; 1.0016 SG) Factory setting: 1.0000 kg/l Your setting:

DENSITY FUNC	TION	DISPLAY
EXP. COEF. CARRIER (p. 85)	5-digit number with floating decimal point; incl. engineering units and arithmetic sign	ASSIGN LINE 1 (p. 87)
	(e.g. 0.5000 e-3 1/K)	()
	Factory setting: 0.0000 e-3 1/K	
	Your setting:	
TARGET MAT. DENSITY	5-digit number with floating decimal point; incl. engineering units and arithmetic sign	
(p. 86)	(e.g.1.0000 kg/dm ³ ; 1.0016 SG)	
	Factory setting: 2.0000 kg/l	
	Your setting:	ASSIGN
EXP. COEF. TARGET	5-digit number with floating decimal point; incl. engineering units and arithmetic sign	LINE 2 (p. 87)
(p. 66)	(e.g. 0.5000 e-3 1/K)	
	Factory setting: 0.0000 e-3 1/K	
	Your setting:	
		DISPLAY
		(p. 87)
		FORMAT
		(p. 87)
		(p. 87)
		LANGUAGE
		(p. 66)

DISPLAY	
ASSIGN LINE 1 (p. 87)	MASS FLOW – VOLUME FLOW – STD. VOLUME FLOW – TARGET FLOW – CARRIER FLOW – DENSITY – STD. DENSITY – TEMPERATURE – TOTALIZER 1 – TOTALIZER 1 OVERFLOW – TOTALIZER 2 – TOTALIZER 2 OVERFLOW – CANCEL
ASSIGN LINE 2 (p. 87)	OFF - MASS FLOW - VOLUME FLOW - STD. VOLUME FLOW - TARGET FLOW - CARRIER FLOW - DENSITY - STD. DENSITY - TEMPERATURE - TOTALIZER 1 - TOTALIZER 1 OVERFLOW - TOTALIZER 2 - TOTALIZER 2 OVERFLOW - CANCEL Your setting:
	rour setting:
DISPLAY DAMPING (p. 87)	max. 2-digit number (099 seconds) Factory setting: <i>1 s</i> Your setting:
FORMAT FLOW (p. 87)	xxxxx. – xxxx.x – xxx.xx – xx.xxx – x.xxxx – CANCEL Your setting:
LCD CONTRAST (p. 87)	Any change in contrast is immediately seen with the adjustable bar graph.
LANGUAGE (p. 88)	ENGLISH – DEUTSCH – FRANCAIS – ESPANOL – ITALIANO – NEDERLANDS – DANSK – NORSK – SVENSKA – SUOMI – BAHASA INDONESIA – JAPANESE (in orginal alphabet) – CANCEL Your setting:

COMMUNICATION		PROCESSING PARA.	
BUS-ADDRESS (p. 89)	3-digit number (0126) Factory setting: 126	LOW FLOW CUTOFF (p. 90)	5-digit number with floating decimal point (e.g. 25.000 kg/min)
TAG NUMBER (p. 89) This function displays the actual measuring-point designation (name), which can only be assigned by a PROFINIS Recent the second	This function displays the actual measuring-point designation (name), which can only be assigned by a PROEIBLIS master e.g. Communication		<i>dependent</i> on the nominal diameter Your setting:
SYSTEM CONFIG. (p. 89)	Possibility to change between >local < operation with E+H matrix and >remote < operation via PROFIBUS-DP /-PA.	MOISE SOF PRESS. (p. 90) MEASURING MODE	HIGH - CANCEL Your setting: UNIDIRECTIONAL - BIDIRECTIONAL - CANCEL
UNIT TO BUS (p. 89)	The system units localy set on the instrument are transmitted to the bus or to Class I master after activation of this function. CANCEL – UNIT TO BUS	FLOW DIRECTION (p. 91)	Your setting: FORWARD – REVERSE – CANCEL Your setting:
		EPD THRESHOLD (p. 91)	5-digit number with floating decimal point; incl. engineering units and arithmetic sign (corresponding 0.00005.9999 kg/l) Factory setting: 0.2000 kg/l Your setting:
		DENSITY FILTER (p. 91)	OFF – LOW – MEDUIM – HIGH – CANCEL Your setting:
		SELF CHECKING (p. 91)	CYCLIC – SMART – CANCEL Your setting:
		PRES. PULSE SUPPR. (p. 92)	Max. 4-digit number, incl. unit 0.00 10.00 seconds Your setting:

SYSTEM PARAMETER		SENSOR DATA	
ZEROPOINT ADJUST (p. 93)	CANCEL – START	K-FACTOR (p. 96)	5-digit number with fixed decimal point (0.10005.9999)
POS. ZERO RETURN (p. 93)	<i>OFF</i> – ON Your setting:		Factory setting: <i>dependent</i> on the nominal diameter and calibration
DEF. PRIVATE CODE (p. 93) ACCESS CODE (p. 94)	Max. 4-digit number (09999) Factory setting: 63	ZEROPOINT (p. 96)	Your setting: Max. 5-digit number (-10000+10000)
	Your setting: Max. 4-digit number (09999) Factory setting: 0		Factory setting: <i>dependent</i> on the nominal diameter and calibration
PRESENT SYSTEM CONDITION (p. 94)	Your setting: Display (listed in priority): F := Error message (System error) A:= Alarm message (Processor error) S := Status message	NOMINAL DIAMETER (p. 96)	Your setting: [actual nominal diameter of the sensor] – <i>CANCEL</i> Factory setting: <i>dependent</i> on the nominal diameter and calibration
PREVIOUS SYSTEM CONDITION (p. 94) SOFTWARE VER. COM	Display (listed in chronological): F := Error message (System error) A:= Alarm message (Processor error) S := Status message Display: e.g. V3.02.XX PBUS	SENSOR COEF. (p. 96)	CANCEL DENSITY COEF. (C 0)* – DENSITY COEF. (C 1)* – DENSITY COEF. (C 2)* – DENSITY COEF. (C 3)* – DENSITY COEF. (C 4)* – DENSITY COEF. (C 5)* – TEMP. COEF. KC – CAL. COEF. Kd – CAL. COEF. Kd – CAL. COEF. Kd2 – MIN. TEMPERATURE – MAX. TEMPERATURE –
SYSTEM RESET (p. 95)	CANCEL – RESTART SYSTEM		
ALARM DELAY (p. 95)	Max. 3-digit number 0 100 seconds (in one second steps) Your setting:		* A local density calibration can alter these values.
		SERIAL NUMBER (p. 97)	Display: 6-digit serial number of the sensor (100 000999 999)
		SOFTWARE VERSION (p. 97)	Display: e.g. V 4.00.XX F





Operating matrix Promass 63 PROFIBUS-PA:


Index

Α	
Access code	94
Acyclic data exchange	32
Addressing PROFIBUS-DP/-PA	25
Alarm (process error)	99
Alarm delay	95
All-weather cover	11
Ambient temperature	131
Analog input blocks	32
API (density calculation)	79
Application	. 7
B	
D Raumá (donaity calculation)	70
Pidiroctional mode	19
Priv (density coloulation)	90 70
	79
С	
Cable specificationen (remote version)	21
Calibration data	96
Calibration factor	96
Chemical resistance	. 6
Code number (enabling programming)	61
Communication	133
Community II operating matrix	50
Connection diagram PROFIBUS-DP	18
Connection diagram PROFIBUS-PA	20
Connection remote version	21
Coriolis force	7
	. ,
Corrosion resistance	. 0
	128
Creep suppression (low flow outoff)	120
Creep suppression (low now cuton)	100
	120
Current output (assign process variables)	75
Current output (zero scale)	/5
Current span	77
Cycle times	33
Cyclic data exchange	28
D	
Dangerous chemicals	. 6

Dangerous chemicals .										. 6
DAT (Data storage)										133
Data exchange (acyclic)										32
Data exchange (cyclic)										28
Density adjustment (1- a	nd	2-	рс	oint	a	dj.))			81
Density adjustment (proc	ceo	dur	e)							82
Density adjustment value	Э									81
Density calculation in %	(m	as	S,	vol	un	ne))			79
Density function (selectin	ng))								84
Density functions (descr	ipt	ion	I)							79
Density measurement .										. 8
Diagnosis flow chart										100
Diagnosis function										94
Dimensions										111
Dimensions Promass 63	А									111

Dimensions Promass 63 F					117
Dimensions Promass 63 I					113
Dimensions Promass 63 M					114
Dimensions Promass 63 M (high press.)					115
Dimensions Promass 63 M (without proce	ess	5			
connections)					116
DIP switches					25
					57
Display configuring					87
Display contrast	·	·	·	·	85
Dual range mode	•	·	·	•	74
	·	·	·	·	
E Electromagnetic compatibility (EMC) . Empty pipe detection (EPD) Enabling programming End value (see full scale value) End-of-line resistor Error limits Exversions (documentation) Expansion coefficient (carrier fluid) Expansion coefficient (standard density) Expansion coefficient (target medium) .		· · · ·	· · · · · · · · · · · · · · · · · · ·	• • • • • • • •	131 91 76 19 129 . 5 85 85 86
F Failsafe mode (current output) Fault (system error) FDE (Fault Disconnection Electronic) .		•	•		77 99 128

	_	
I		
	н.	
	ь.	
	-	

Failsafe mode (current output)					77
Fault (system error)					99
FDE (Fault Disconnection Electronic) .					128
Flow direction					91
Fluid temperature					131
Full scale (current output)					76
Function group CURRENT OUTPUT 1/2					75
Function group DENSITY FUNCTION					79
Function group DISPLAY					87
Function group PROCESS VARIABLE					68
Function group PROCESSING PARA.					90
Function group SENSOR DATA					96
Function aroup SYSTEM-UNITS	·	·	•		72
Function group TOTALIZERS	÷			÷	70
Function group COMMUNICATION	•	·	•	•	80
Funktion group SYSTEM PARAMETER	·	·	·	·	93
Funktions at a glance	•	·	•	·	137
	•	•	•	·	107
G					
GSD files					27
U					
LOME position					57
	·	·	·	·	57

HOME position										57
Hygienic coupling E	DIN	118	351,	/SM	IS	114	45			123

Ι

IEEE floating p	oint	: ทเ	Jm	be	ers					29
Input variables										127

Promass	63	PROFIBUS-DP/-PA
---------	----	-----------------

L Locking programming	61 90
MMaterial load curves13Materials13Measured error14Measured variables14Measuring mode (uni-/bidirectional)14Measuring principle14Measuring range14Measuring system14Mounting (remote version)14Mounting location13,	31 32 29 27 90 7 27 9 15 11 15
NNAMUR recommendations13Nominal current14Nominal pressure14	33 78 31
O Operable flow range	28 58 57 38 59 60 57 5 28
PPermissible power voltage12Phase difference12Pos. zero return (measurand suppression)9Post mounting (Promass A)13Post mounting (transmitter)14Power supply15Pressure loss16Pressure pulse suppression16Process conditions16Process connections Promass A16Process connections Promass I, M, F17Process connections Promass M (high pressure)17ProfIBUS-DP interface16Programming (general information)16Promass 63 measuring system17Protection IP 6717	28 93 15 33 93 11 18 22 61 59 11
R Reference conditions (accuracy)	31 84 15

Repairs).	•	•	•	•	•	•	•	•	•	•	. 6 130
Resonant frequency .	<i>.</i>											. 8
Rotating the local displ	av											16
Rotating the transmitter	ho	us	inc)								16
S												
Safety instructions												5
Setting the device add	'ASS		•	•	•	•	•	·	·	·	•	. 25
Setting when delivered	000	,	·	·	·	·	·	•	·	•	·	25
Shock resistance	•	•	•	•	•	•	•	•	·	•	•	131
Signal encoding		·	÷	÷		÷	÷		÷			128
Signal on alarm		÷		÷			÷					128
Simulation (current)												78
Slot / Index lists												36
Software version											9	5, 97
Speed of transmission												128
Standard density												79
Status code												31
Storage temperature .												131
Switching on the instru	mer	nt										26
System condition												94
System integration												27
System pressure												12
System units (SI/US) .												72
Т												
Technical data												127
Temperature measurem	nen	t										. 8
Temperature ranges .												11
Tanana analysisa nama a state												404

Temperature ranges				11
Temperature ranges for gaskets .				131
Thermal insulation				11
Time constant				77
Totaliser				70
Totaliser (assign process variables)				70
Totaliser overflow				70
Totaliser reset				70
Tracing				11
Transmission cabling				19
Transmission speed				23
Transporting to the measuring point				12
Trouble-shooting				99

U

Unidirectional Mode							90
Units (SI/US)							72

V

Vibrational resistance							131
Volume flow measuremen	t						84
Volumetric flow							79

W

Wall mounting (Promass A)					13
Wall mounting (transmitter)					15
Weights					132

Z						
Zero point calibration	85					63, 93
Zero point correction						. 96

Europe

Austria Endress+Hauser GmbH
 Wien

Tel. (01) 88 05 60, Fax (01) 88 05 635 Belarus Belorgsintez Minsk

Tel. (0172) 263166, Fax (0172) 263111 Belgium / Luxembourg Endress+Hauser S.A./N.V. Bruxelles

Tel. (02) 2480600, Fax (02) 2480553 Bulgaria INTERTECH-Automation Sofia

Tel. (02) 624834, Fax (02) 688186 Croatia

Endress+Hauser GmbH+Co. Zagreb Tel. (01) 6 60 14 18, Fax (01) 6 60 14 18

Cyprus I+G Electrical Services Co. Ltd. Nicosia

Tel. (02) 484788, Fax (02) 484690 Czech Republic Endress+Hauser Czech s.r.o

Praha Tel. (02) 66 78 42 00, Fax (02) 66 78 41 79 Denmark Endress+Hauser A/S

Søborg Tel. 70131132, Fax 70132133

Estonia Elvi-Aqua Tartu Tel. (7) 4227 26, Fax (7) 4227 27

Finland

Endress+Hauser Ov Espoo Tel. (9) 8596155, Fax (9) 8596055

France □ Endress+Hauser S.A. Huningue Tel. (0389) 696768, Fax (0389) 694802

Germany □ Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 97501, Fax (07621) 975555 **Greece** I & G Building Services Automation S.A. Athens Tel. (01) 924 1500, Fax (01) 922 1714

Hungary MILE Ipari-Elektro Budapest Tel. (01) 261 55 35, Fax (01) 261 55 35

Iceland BIL ehf Reykjavi Tel. (05) 61 96 16, Fax (05) 61 96 17

Ireland Flomeaco Company Ltd. Kildare Tel. (045) 868615, Fax (045) 868182

 Italy

 □ Endress+Hauser S.p.A.

 Cernusco s/N Milano

 Tel. (02) 92106421, Fax (02) 92107153

Kazakhstan AO "Elmo"

Kazakhstan Tel. (3272) 425363, Fax (3272) 428044 Latvia

Rino Riga Tel. (07) 31 28 97, Fax (07) 31 28 94

Lithuania Agava Ltd

Kaunas Tel. (07) 20 24 10, Fax (07) 20 74 14 Netherlands Endress+Hauser B.V.

Naarden Tel. (035) 6958611, Fax (035) 6958825

Norway Endress+Hauser A/S Lierskogen Tel. (032) 85 98 50, Fax (032) 85 98 51

Portugal Tecnisis - Tecnica de Sistemas Industriais Linda a Velha Tel. (01) 4172637, Fax (01) 4185278 Romania Romconsend S R L Buchares Tel. (01) 4101634, Fax (01) 4101634 Russia □ Endress+Hauser GmbH+Co Moscow Tel. + Fax see E+H Instruments International Slovak Republic Transcom Technik s.r.o. Bratislava Tel. (07) 44888684, Fax (07) 44887112 Slovenia Endress+Hauser D.O.O. Ljubljana Tel. (061) 1 59 22 17, Fax (061) 1 59 22 98 **Spain** ☐ Endress+Hauser S.A. Sant Just Desvern Tel. (93) 480 33 66, Fax (93) 473 38 39 Sweden Endress+Hauser AB Sollentuna Tel. (08) 6261600, Fax (08) 6269477 Switzerland Gui Endress+Hauser AG Reinach/BL 1 Tel. (061) 7 15 75 75, Fax (061) 7 11 16 50 Turkey Intek Endüstriyel Ölcü Ve Kontrol Sistemleri Levent/Istanbul Tel. (0212) 2 75 13 55, Fax (02 12) 2 66 27 75 Ukraine Photonika GmbH Kiev Tel. (44) 268 81 02, Fax (44) 269 08 05 United Kingdom Endress+Hauser Ltd. Manchester

Tel. (0161) 2865000, Fax (0161) 9981841 Yugoslavia Republic Meris d.o.o. Beograd Tel. (11) 4442966, Fax (11) 430043

Africa

Poland

War

Endress+Hauser Polska Sp. z o.o.

Tel. (022) 7 20 10 90, Fax (022) 7 20 10 85

Egypt Anasia Cairo Tel. (02) 4179007, Fax (02) 4179008

Morocco Oussama S.A. Casablanca Tel. (02) 241338, Fax (02) 402657

Nigeria J F Technical Invest. Nig. Ltd.

Lagos Tel. (1) 62 23 45 46, Fax (1) 62 23 45 48 Rep. South Africa

Endress+Hauser (Ptv.) Ltd. Sandtor Tel. (011) 444 13 86, Fax (011) 444 1977

Tunisia Controle, Maintenance et Regulation Tunis Tel. (01) 793077, Fax (01) 788595

America

Argentina □ Endress+Hauser Argentina S.A.

Buenos Aires Tel. (01) 5227970, Fax (01) 5227909 Rolivia

Tritec Cochabamba Tel. (042) 5 69 93, Fax (042) 5 09 81

Samson Endress+Hauser Ltda Sao Paulo Tel. (011) 5363455, Fax (011) 5363067 Canada □ Endress+Hauser (Canada) Ltd. Burlington / Ontario Tel. (905) 681 92 92, Fax (905) 681 94 44 Chile DIN Instrumentos Ltda. Santiago Tel. (02) 2 05 01 00, Fax (02) 2 25 81 39 Colombia Colsein Ltd Bogota D.C. Tel. (01) 2 36 76 59, Fax (01) 6 10 78 68

Costa Rica EURO-TEC S.A. San Jose Tel. 296 15 42, Fax 296 15 42

Brazil

Ecuador INSETEC Cia. Ltda. Quito Tel. (02) 25 12 42, Fax (02) 46 18 33

Guatemala ACISA Automatizacion y Control Industrial S.A. Guatemala

Tel. (03) 345985, Fax (03) 327431 Mexico

 Endress+Hauser GmbH+Co., Instruments International, Mexico City Office, Mexico City Tel. (5) 5 68 96 58, Fax (5) 5 68 41 83

Paraguay Incoel S.R.L. Tel. (021) 21 39 89, Fax (021) 2 12 65 83

Peru Esim S.A. Lima Tel. (1) 471 4661, Fax (1) 471 09 93

Uruguay Circular S.A. Montevideo Tel. (02) 92 57 85, Fax (02) 92 91 51

USA USA □ Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 5 35 71 38, Fax (317) 5 35 84 98

Venezuela Controval C.A. Caracas Tel. (02) 9 44 09 66, Fax (02) 9 44 45 54

Asia

Brunei American International Industries (B) Sdn Bhd Lorong Tengah Tel. (3) 22 37 37, Fax (3) 22 54 58

China China Endress+Hauser Shanghai Shanghai Tel. (021) 64 64 67 00, Fax (021) 64 74 78 60 Hong Kong Endress+Hauser (H.K.) Ltd.

Hong Kong Tel. 25 28 31 20, Fax 28 65 41 71 India Endress+Hauser India Branch Office Mumbai

Tel. (022) 8521458, Fax (022) 8521927 Indonesia

PT Grama Bazita Tel. (21) 7 97 50 83, Fax (21) 7 97 50 89 Japan Sakura Endress Co. Ltd.

Tokyo Tel. (0422) 54 06 11, Fax (0422) 55 02 75

Malaysia Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 7 33 48 48, Fax (03) 7 33 88 00

Pakistan Speedy Automation Karachi Tel. (021) 772 2953, Fax (021) 773 6884 Papua-Neuguinea SBS Electrical Pty Ltd. PNG Port Moresby Tel. 3251188, Fax 3259556 Philippines □ Endress+Hauser Philippines Inc. Manila Tel. (2) 6388041, Fax (2) 6388042 Singapore Endress+Hauser (S.E.A.) Pte. Ltd. Singapore

Sein Pyinsayupa Gen. Tranding & Agency Co-op. Soc. Ltd.

Tel. (1) 242325, Fax (1) 250594

Myanmar

Tel. 5668222, Fax 5666848

Korea □ Endress+Hauser (Korea) Co. Ltd. Seoul Tel. (02) 6587200, Fax (02) 6592838

Taiwan Kingjarl Corporation Taipei Tel. (02) 27 18 39 38, Fax (02) 27 13 41 90 Thailand Endress+Hauser (Thailand) Ltd. Bangkok Tel. (2) 9967811-20, Fax (2) 9967810

Vietnam Tan Viet Bao Co. Ltd. Ho Chi Minh City Tel. (08) 8 33 52 25, Fax (08) 8 33 52 27

Iran Telephone Technical Services Co. Ltd. (TTS) Tehran Tel. (021) 8746750, Fax (021) 8737295 Israel Instrumetrics Industrial Control Ltd. Tel Aviv

Tel. (03) 6 48 02 05, Fax (03) 6 47 19 92 Jordan

A.P. Parpas Engineering S.A. Amma Tel. (06) 5 53 92 83, Fax (06) 5 53 92 05

Kuwait Kuwait Maritime & Mercantile Co. K.S.C. Safa

Tel. 2434752, Fax 2441486

Lebanon Network Engineering Co. Jbeil Tel. 3254051, Fax 9944080

Sultanate of Oman Mustafa & Jawad Sience & Industry Co. LLC Ruwi

Tel. 60 20 09, Fax 60 70 66 United Arab Emirates Descon Trading Est. Dubai

Tel. (04) 65 36 51, Fax (04) 65 32 64 Yemen

Yemen Company for Ghee and Soap Industry Taiz Tel. (04) 23 06 64, Fax (04) 21 23 38

Australia + New Zealand

Australia ALSTOM Australia Ltd. Villawood N.S.W. Tel. (02) 97 22 47 77, Fax (02) 97 22 48 83 New Zealand EMC Industrial Group Limited Auckland Tel. (09) 4 15 51 10, Fax (09) 4 15 51 15

All other countries

Endress+Hauser GmbH+Co. Instruments International Weil am Rhein, Germany Tel. (07621) 97502, Fax (07621) 975345

http://www.endress.com

