

Description of Device Functions

Levelflex M FMP40, FMP41C, FMP43, FMP45

Guided Level-Radar with HART, PROFIBUS PA and FOUNDATION Fieldbus





Endress+Hauser

People for Process Automation

Valid as of software version: V 01.04.02

Basic Setup



Table of contents

1	Notes on use
1.1	Using the table of contents to locate a function
1.2	description
1.3	Using the index of the function menu to locate a function description
1.4 1.5 1.6	General structure of the operating menu
2	Function menu Levelflex M 12
3	Function group "basic setup" (00) 15
3.1 3.2 3.3 3.4 3.5 3.6 3.7 3.8 3.9 3.10 3.11 3.12 3.13 3.14 3.15 3.16	Function "measured value" (000) 15 Function "tank properties" (002) 15 Function "medium property" (003) 16 Function "process propert." (004) 18 Function "end of probe" (030) 18 Function "probe length" (031) 19 Function "probe length" (032) 19 Function "probe length" (033) 19 Function "determine length" (034) 19 Function "full calibr." (005) 20 Function "full calibr." (006) 21 Display (008) 21 Function "range of mapping" (052) 23 Function "start mapping" (053) 24
4	Function group "safety settings" (01) . 25
4.1 4.2 4.3 4.4 4.5 4.6 4.7 4.8 4.9 4.10	Function "output on alarm" (010) 25 Function "output on alarm" (011), HART only 27 Function "outp. echo loss" (012) 27 Function "ramp %span/min" (013) 28 Function "delay time" (014) 29 Function "safety distance" (015) 29 Function "in safety dist." (016) 29 Function "ackn. alarm" (017) 31 Function "broken probe det" (019) 31
5	Function group
	"length adjustment" (03) 32
5.1 5.2 5.3 5.4 5.5	Function "end of probe" (030) 32 Function "probe length" (031) 32 Function "probe" (032) 33 Function "probe length" (033) 33 Function "determine length" (034) 33

6	Function group "linearisation" (04) 34	ŀ
6.1 6.2 6.3	Function "level/ullage" (040)34Function "linearisation" (041)35Function "customer unit" (042)38	5
6.4	Function "table no." (043) 39)
6.5 6.6	Function "input level" (044))
6.7	Function "max. scale" (046)	,)
6.8	Function "diameter vessel" (047) 40)
7	Function group	
	"extended calibr." (05) 41	
7.1	Function "selection" (050) 41	L
7.2	Function "check distance" (051) 41	
7.3 7.4	Function "range of mapping" (052)	2
7.5	Function "pres. map dist." (054)	3
7.6	Function "delete mapping" (055) 43	3
7.7	Function "echo quality" (056) 44	ļ
7.8	Function "offset" (057) 44	1
7.9	Function "output damping" (058)	ł
7.10		,
8	Function group "output" (06),	
	- "PROFIBUS param." (06),	
	PROFIBUS PA only 48	3
8.1	Function "commun. address" (060), HART only 48	3
8.2	PROFIBUS PA only	3
8.3	Function "no. of preambels" (061), HART only 49)
8.4	Function "ident number" (061), PROFIBUS PA only 49)
8.5	Function "low output limit" (062), HART only 50)
0.0	only)
8.7	Function "curr. output mode" (063), HART only 51	L
8.8	Function "out value" (063), PROFIBUS PA only 51	
8.9	Function "fixed cur. value" (064), HARI only 52	2
0.10 8.11	Function "simulation" (065)	2 R
8.12	Function "simulation value" (066)	, 1
8.13	Function "output current" (067), HART only 54	ļ
8.14	Function "2nd cyclic value" (067),	
0.15	PROFIBUS PA only	ļ
8.15	Function "4mA value" (068), HART only 54	+
8.10 8.17	Function "20mA value" (060) HART only 55)
8.18	Function "display value" (069), PROFIBUS PA only 55	5
9	Function group	
-	"envelope curve" (OE) 56	5

9.2 9.3	Function "recording curve" (0E2)56Function "envelope curve display" (0E3)57
10	Function group "display" (09) 59
10.1 10.2 10.3 10.4 10.5 10.6	Function "language" (092) 59 Function "back to home" (093) 59 Function "format display" (094) 60 Function "no.of decimals" (095) 60 Function "sep. character" (096) 60 Function "display test" (097) 61
11	Function group "diagnostics" (0A) 62
11 11.1 11.2 11.3 11.4 11.5 11.6 11.7 11.8 	Function group "diagnostics" (0A) 62 Function "present error" (0A0) 63 Function "previous error" (0A1) 63 Function "clear last error" (0A2) 63 Function "reset" (0A3) 64 Function "unlock parameter" (0A4) 65 Function "measured dist." (0A5) 66 Function "measured level" (0A6) 67 Function "detection window" (0A7)

12 Function group

"system parameters" (0C) 69
Function "tag no." (0C0) 69
Function "device tag" (0C0),
FOUNDATION Fieldbus only
Function "Profile Version" (UCI),
$ FROFIDUS PA OIIIy \dots 09 $ $ Function "protocol usu no " (0C2) $
Function "serial no " $(0C4)$ 70
Function "device id" (0C4)
FOUNDATION Fieldbus only
Function "distance unit" (0C5)
Function "download mode" (0C8)
Function group "service" (0D) 72
Envelope curve
The envelope curve window in the ToF Tool \ldots 73
Trouble-shooting 74
Troubleshooting instructions
System error messages
Application errors
Software history

1 Notes on use

You have various options for accessing the descriptions of instrument functions or how to enter parameters.

1.1 Using the table of contents to locate a function description

All the functions are listed in the table of contents sorted by function group (e.g. basic setup, safety settings, etc.). You can access a more detailed description of a function by using a page reference / link.

The table of contents is on $\rightarrow \ge 4$.

1.2 Using the graphic of the function menu to locate a function description

This guides you step by step from the highest level, the function groups, to the exact function description you require.

All the available function groups and instrument functions are listed in the table ($\rightarrow \equiv 12$). Select your required function group or function. You can access an exact description of the function group or function by using a page reference / link.

1.3 Using the index of the function menu to locate a function description

To simply navigation within the function menu, each function has a position which is shown in the display. You can access each function via a page reference/link in the function menu index $(\rightarrow \exists 83)$ which lists all the function names alphabetically and numerically.

1.4 General structure of the operating menu

The operating menu is made up of two levels:

■ Function groups (00, 01, ..., 0C, 0D):

The individual operating Selection of the instrument are split up roughly into different function groups. The function groups that are available include, e.g.: "basic setup", "safety settings", "output", "display", etc.

■ Functions (001, 002, 003, ..., 0D8, 0D9):

Each function group consists of one or more functions. The functions perform the actual operation or parameterisation of the instrument. Numerical values can be entered here and parameters can be selected and saved. The available functions of the **"basic setup (00)"** function group include, e.g.: **"tank shape (002)"**, **"medium property (003)"**, **"process cond. (004)"**, **"empty calibr. (005)**", etc.

If, for example, the application of the instrument is to be changed, carry out the following procedure:

- 1. Select the **"basic setup (00)**" function group.
- 2. Select the "tank properties" (002) (where the existing tank properties is selected).

1.4.1 Identifying the functions

For simple orientation within the function menus ($\rightarrow \ge 12$), for each function a position is shown on the display.



The first two digits identify the function group:

- basic setup 00
- safety settings 01
- lenght adjustment 02

•••

he third digit numbers the individual functions within the function group:

basic setup	00	\rightarrow	tank properties	002
			medium property	003
			process cond.	004

Hereafter the position is always given in brackets (e.g. "tank properties" (002)) after the described function.

1.5 Display and operating elements



Four lines with 20 characters each. Display contrast adjustable through key combination.

Abb. 1: Layout of the display and operating elements

The VU331 LCD display can be removed to ease operation by simply pressing the snap-fit (see graphic above). It is connected to the device by means of a 500 mm cable.

1.5.1 Display

Liquid crystal display (LCD):

Four lines with 20 characters each. Display contrast adjustable through key combination.



Abb. 2: Display

1.5.2 Display symbols

The following table describes the symbols that appear on the liquid crystal display:

Symbols	Meaning
Ч	ALARM_SYMBOL This alarm symbol appears when the instrument is in an alarm state. If the symbol flashes, this indicates a warning.
5	LOCK_SYMBOL This lock symbol appears when the instrument is locked, i.e. if no input is possible.
٦	COM_SYMBOL This communication symbol appears when a data transmission via e.g. HART, PFOFIBUS-PA or FOUN- DATION Fieldbus is in progress.
*	SIMULATION_SWITCH_ENABLE This communication symbol appears when simulation in FOUNDATION Fieldbus is enabled via the DIP switch.

Tab. 1-1 Meaning of Symbols

1.5.3 Key assignment

The operating elements are located inside the housing and are accessible for operation by opening the lid of the housing.

Function of the keys

Key(s)	Meaning
+ or +	Navigate upwards in the selection list Edit numeric value within a function
- or +	Navigate downwards in the selection list Edit numeric value within a function
	Navigate to the left within a function group
E or E	Navigate to the right within a function group, confirmation.
+ and $E-$ and E	Contrast settings of the LCD
+ and - and E	Hardware lock / unlock After a hardware lock, an operation of the instrument via display or communication is not possible! The hardware can only be unlocked via the display. An unlock parameter must be entered to do so.

Tab. 1-2 Function of the keys





Abb. 3: Selection and configuration in operation menu

1.6 Commissioning

1.6.1 Switching on the measuring device

When the instrument is switched on for the first time, the following messages appear on the display:



2 Function menu Levelflex M

Function gro	up		Function			Description
basic setup	00	\Rightarrow	measured value	000	\rightarrow	Page 15
(siehe Seite 15)			tank properties	002	\rightarrow	Page 15
\downarrow		-4	medium property	003	\rightarrow	Page 16
			process cond.	004	\rightarrow	Page 18
			end of probe	030	\rightarrow	Page 18
			probe length	031	\rightarrow	Page 19
			probe	032	\rightarrow	Page 19
			probe length	033	\rightarrow	Page 19
			determine length	034	\rightarrow	Page 19
			empty calibr.	005	\rightarrow	Page 20
			full calibr.	006	\rightarrow	Page 21
			check distance	051	\rightarrow	Page 22
			range of mapping	052	\rightarrow	Page 23
			start mapping	053	\rightarrow	Page 23
		-				
safety settings	01	\Rightarrow	output on alarm	010	\rightarrow	Page 25
(siehe Seite 25)			output on alarm (HART only)	011	\rightarrow	Page 27
\Downarrow			outp. echo loss	012	\rightarrow	Page 27
			ramp %span/min	013	\rightarrow	Page 28
			delay time	014	\rightarrow	Page 29
			safety distance	015	\rightarrow	Page 29
			in safety dist.	016	\rightarrow	Page 29
			ackn. alarm	017	\rightarrow	Page 31
			overspill prot.	018	\rightarrow	Page 31
			brocken probe det	019		Page 31
		٦			1	
length adjustment	03	\Rightarrow	end of probe	030	\rightarrow	Page 32
(siehe Seite 32)			probe length	031	\rightarrow	Page 32
\Downarrow			probe	032	\rightarrow	Page 33
			probe length	033	\rightarrow	Page 33
			determine length	034	\rightarrow	Page 33
Linearisation	04] ⇒	level/ullage	040	\rightarrow	Page 34
(siehe Seite 34)			linearisation	041	\rightarrow	Page 35
↓		1	customer unit	042	\rightarrow	Page 38
			table no.	043	\rightarrow	Page 39
			input level	044	\rightarrow	Page 39
			input volume	045	\rightarrow	Page 40
			max. scale	046	\rightarrow	Page 40
			diameter vessel	047	\rightarrow	Page 40

Function grou	ıp		Function		Description
extended calibr.	05	\Rightarrow	selection	050	\rightarrow Page 41
(siehe Seite 41)			check distance	051	\rightarrow Page 41
\downarrow		-	range of mapping	052	\rightarrow Page 42
			start mapping	053	\rightarrow Page 42
			pres. map dist.	054	\rightarrow Page 43
			delete map.	055	\rightarrow Page 43
			echo quality	056	\rightarrow Page 44
			offset	057	\rightarrow Page 44
			output damping	058	\rightarrow Page 44
			upper block.dist	059	\rightarrow Page 45
		1			- 1
output	06	\Rightarrow	commun. address (HART only)	060	\rightarrow Page 48
PROFIBUS param.	06		instrument addr. (PROFIBUS PA only)	060	\rightarrow Page 48
PROFIBUS PA only			no. of preambels (HART only)	061	\rightarrow Page 49
(siehe Seite 48)			ident number (PROFIBUS PA only)	061	\rightarrow Page 49
Ų			low output limit (HART only)	062	\rightarrow Page 50
			set unit to bus (PROFIBUS PA only)	062	\rightarrow Page 50
			curr. output mode	063	Page 51
			out value (PROFIBUS PA only)	063	\rightarrow Page 51
			fixed cur. value (HART only)	064	\rightarrow Page 52
			out status (PROFIBUS PA only)	064	\rightarrow Page 52
			simulation	065	\rightarrow Page 53
			simulation value	066	\rightarrow Page 54
			output current (HART only)	067	\rightarrow Page 54
			2nd cyclic value (PROFIBUS PA only)	067	\rightarrow Page 54
			4mA value (HART only)	068	Page 54
			select v0h0 (PROFIBUS PA only)	068	\rightarrow Page 55
			20mA value (HART only)	069	\rightarrow Page 55
			display value (PROFIBUS PA only)	069	\rightarrow Page 55
envelope curve	0E	∣⇒	plot settings	0E1	\rightarrow Page 56
(siehe Seite 56)			recording curve	0E2	\rightarrow Page 56
↓		1	envelope curve	0E3	\rightarrow Page 57
			*]
display	09	\Rightarrow	language	092	\rightarrow Page 59
(siehe Seite 59)			back to home	093	\rightarrow Page 59
\Downarrow			format display	094	\rightarrow Page 60
			no.of decimals	095	\rightarrow Page 60
			sep. character	096	\rightarrow Page 60
			display test	097	\rightarrow Page 61
	~ •	1		0.1.0	
diagnostics	0A	\Rightarrow	present error	0A0	\rightarrow Page 03
		J	previous error	UAI	\rightarrow Page 03
Ų			ciear last error	UA2	\rightarrow Page 63
			reset	0A3	\rightarrow Page 64
			UTHOCK parameter	UA4	\rightarrow Page 65
			measured dist.	0A5	\rightarrow Page 66
			measured level	0A6	\rightarrow Page 67
			detection window	0A7	Page 67
			application par.	0A8	\rightarrow Page 68

Function grou	р		Function			Description
system parameters	0C	\Rightarrow	tag no.	0C0	\rightarrow	Page 69
(siehe Seite 69)			device tag (FOUNDATION Fieldbus only)	0C0	\rightarrow	Page 69
\downarrow		•	Profile Version (PROFIBUS PA only)	0C1	\rightarrow	Page 69
			protocol+sw-no.	0C2	\rightarrow	Page 69
			serial no.	0C4	\rightarrow	Page 70
			device id (FOUNDATION Fieldbus only)	0C4	\rightarrow	Page 70
			distance unit	0C5	\rightarrow	Page 70
			download mode	0C8	\rightarrow	Page 71
		-				
service	D00	\Rightarrow	service level	D00		Page 72

3 Function group "basic setup" (00)



3.1 Function "measured value" (000)



This function displays the current measured value in the selected unit (see "customer unit" (042) function). The number of places after decimal point can be selected in the "no.of decimals" (095) function.

3.2 Function "tank properties" (002)



This function is used to select the tank properties.

Selection:

- standard
- aluminium tank
- plastic tank
- bypass / pipe
- coax probe
- concrete wall

standard

The "standard" option is recommended for normal containers for rod and rope probes.

aluminium tank

The "aluminium tank" option is designed especially for high aluminium silos that cause an increased level of noise when empty. This option is only useful for probes longer than (< 4 m). For short probes (< 4 m) select the "standard" option.

Note!

Note!

If "**aluminium tank**" is selected, the device calibrates of its own accord when first filled, depending on the medium's properties. Slope errors can, therefore, occur when beginning the first filling procedure.

plastic tank

Select the "**plastic tank**" option when installing probes in wood or plastic containers **without** metallic surfaces at the process connection (see installation in plastic containers). When using a metallic surface at the process connection, the "**standard**" option is sufficient.

In principle the employment of a metallic surface area should be preferred at the process connection!

bypass / pipe

The "**bypass** / **pipe**" option is designed especially for the installation of probes in a bypass or a stilling well. If this option is selected, the upper blocking distance is preset to 100 mm.

coax probe (not relevant for FMP43)

Select the "**coax probe**" option when using a coaxial probe. When this setting is made, the evaluation is adapted to the high sensitivity of the coax probe. This option should, therefore, **not** be selected when using rope or rod probes.

concrete wall

The **"concrete wall"** option takes into account the signal-damping property of concrete walls when mounting with < 1 m distance to the wall.

3.3 Function "medium property" (003)



This function is used to select the dielectric constant.

Selection:

- unknown
- 1.4 ... 1.6

FMP40: for coaxial and Rod probe with installation in metallic pipes \leq DN 150 FMP41C, FMP45: 1,4 for installation in metallic pipes)

- **1**.6 ... 1.9
- **1**.9 ... 2.5
- **2.5** ... 4.0
- **4.0** ... 7.0
- > 7.0

FMP40:

Modia group		Turnical built solida	Tymical liquida	Measuring range		
weula group	DC (81)	Typical bulk solids	i ypicai iiquius	bare metallic probes	PA-coated rope probes	
1	1.41.6		Condensed gases, e.g. N_2 , CO_2	4 m / 157", only coax probe	—	
2	1.61.9	Plastic granulate White lime, special cement Sugar	Liquefied gas, e.g. Propane Solvent Frigen / Freon Palm oil	2530 m / 9841181"	12,515 m / 492590"	
2	10.25	Portland cement, plaster	Mineral oils, fuels	3035 m / 11811378"	—	
3	1.92.5	Flour	_	—	1525 m / 590984"	
		Grain, seeds			2530 m / 9841181"	
4	2.54	Ground stones Sand	Benzene, styrene, toluene Furan Naphthalene	35 m / 1378"	2530 m / 9841181"	
5	47	Naturally moist (ground) stones, ores Salt	Chlorobenzene, chloroform Cellulose spray Isocyanate, aniline	35 m / 1378"	35 m / 1378"	
6	> 7	Metallic powder Carbon black Coal	Aqueous solutions Alcohols Ammonia	35 m / 1378"	35 m / 1378"	

Media group	DC (Er)	Typical liquids	Typ. measuring range
1	1.4 to 1.6	Condensed gases, e.g. N_2 , CO_2	
2	1.6 to 1.9	Liquefied gas, e.g. propane Solvent Frigen / Freon Palm oil	
3	1.9 to 2.5	Mineral oils, fuels	
4	2.5 to 4	Benzene, styrene, toluene Furan Naphthalene	4 m (354")
5	4 to 7	Chlorobenzene, chloroform Cellulose spray Isocyanate, aniline	
6	> 7	Aqueous solutions Alcohols Acids, alkalis	

FMP41C, FMP45:

Media group	DC (Er)	Typical liquids	Typ. measuring range
1	1.41.6	Condensed gases, e.g. N ₂ , CO ₂	4 m (157"), when installed in metallic pipes
2	1.61.9	Liquefied gas, e.g. Propane Solvent Frigen / Freon Palm oil	9 m (354")
3	1.92.5	Mineral oils, fuels	12 m (472")
4	2.54	Benzene, styrene, toluene Furan Naphthalene	16 m (629")
5	47	Chlorobenzene, chloroform Cellulose spray Isocyanate, aniline	25 m (984")
6	> 7	Aqueous solutions Alcohols Acids, alkalis	30 m (1181")

The lower group applies to very loose or loosened bulk solids.

Reduction of the max. possible measuring range by means of:

- extremely loose surfaces of bulk solids, e.g. bulk solids with low piled density when filled pneumatically.
- Build-up, primarily of moist products.

Note!

Due to the high diffusion rate of ammonia it is recommended to use the FMP45 with gas-tight bushing for measurements in this medium.

3.4 Function "process propert." (004)



	proces	<u>s propert.</u>	P N N
~	asi (Sin	epe	
-	fast	chan9e	
	slow	chan9e	

Use this function to adapt the device reaction to the filling speed in the tank. The setting impacts on an intelligent filter.

Selection:

- standard
- fast change
- slow change
- test:no filter

Selection:	standard	fast change	slow change	test:no filter
Application:	For all normal applications, bulk solids and fluids at low to medium filling speed and suffi- ciently large tanks.	Small tanks, primarily with flu- ids, at high filling speeds.	Applications with strong surface movement, e.g. caused by stir- rer, primarily large tanks with slow to medium filling speed.	Shortest reaction time:For test purposesMeasurement in small tanks at high filling speeds, if "rapid change" setting is too slow.
2-wire electronics:	Dead time: 4 s	Dead time: 2 s	Dead time: 6 s	Dead time: 1 s
	Slewrate: 18 s	Slewrate: 5 s	Slewrate: 40 s	Slewrate: 0 s
4-wire electronics:	Dead time: 2 s	Dead time: 1 s	Dead time: 3 s	Dead time: 0,7 s
	Slewrate: 11 s	Slewrate: 3 s	Slewrate: 25 s	Slewrate: 0 s

3.5 Function "end of probe" (030)



Use this function to select the polarity of the probe end signal. If the probe end is uncovered or in an insulated attachment, there is a negative probe end signal. The signal from the probe end is positive if the attachment is grounded. Only the setting "**free** " is permitted for the FMP41C/FMP43.

Selection:

- free
- tie down isol.¹
- tie down gnd.¹

^{1.}FMP41C/FMP43: These settings lead to a false output signal for empty tanks.





Use this function to select whether the probe length was changed after factory calibration. Only then is it necessary to enter or correct the probe length.

Selection:

not modified

modified

Note!

S

If "modified" was selected in the "**probe length**" (031) function, the probe length is defined in the next step.

3.7 Function "probe" (032)



Use this function to select whether the probe is uncovered or covered.

If the probe is uncovered, the Levelflex can determine the probe length automatically "**determine length**" (034). function. If the probe is covered, a correct entry is required in the "**probe length**" (033) function

Selection:

- free
- covered

3.8 Function "probe length" (033)



With this function, the probe length can be entered manually.

3.9 Function "determine length" (034)



Use this function to determine the probe length automatically.

Due to the mounting conditions, the automatically determined probe length may be larger than the actual probe (typically 20.. 30 mm longer). This has no influence on the measuring accuracy. When entering the empty value for a linerisation, please use the "empty calibration" instead of the automatically determined probe length.

Selection:

- Iength ok
- too short
- too long

After selection "length too short" or "length too long", the calculation of the new value need approx. 10 s.

3.10 Function "empty calibr." (005)





This function is used to enter the distance from the flange (reference point of the measurement) to the minimum level (=zero).



3.11 Function "full calibr." (006)



This function is used to enter the distance from the minimum level to the maximum level (=span).



3.12 Display (008)



The **distance** measured from the reference point to the product surface and the **meas. value** calculated with the aid of the empty adjustment are displayed. Check whether the values correspond to the actual meas. value or the actual distance. The following cases can occur:

- Distance correct meas. value correct -> continue with the next function, "check distance" (051)
- Distance correct meas. value incorrect -> Check "empty calibr." (005)
- Distance incorrect meas. value incorrect -> continue with the next function, "check distance" (051)

3.13 Function "check distance" (051)





This function triggers the mapping of interference echoes. To do so, the measured distance must be compared with the actual distance to the product surface. The following options are available for selection:

Selection:

- distance = ok
- dist. too small
- dist. too big
- dist. unknown
- manual
- probe free



distance = ok

Use this function at part-covered probe. Choosing function "**manual**" or "**probe free**" at free probe. • mapping is carried out up to the currently measured echo

• The range to be suppressed is suggested in the "**range of mapping (052)**" function Anyway, it is wise to carry out a mapping even in this case.

Note!

At free probe, the mapping should be confirmed with the choice "probe free".

dist. too small

- At the moment, an interference is being evaluated
- Therefore, a mapping is carried out including the presently measured echoes
- The range to be suppressed is suggested in the "range of mapping (052)" function

dist. too big

- This error cannot be remedied by interference echo mapping
- Check the application parameters (002), (003), (004) and "empty calibr." (005)

dist. unknown

If the actual distance is not known, no mapping can be carried out.

manual

A mapping is also possible by manual entry of the range to be suppressed. This entry is made in the "range of mapping (052)" function.



Caution!

The range of mapping must end 0.3 m (20") before the echo of the actual level. In case of empty vessel it is possible to make a map over the whole probe length.

probe free

If the probe is uncovered, mapping is carried out along the whole probe length.

Ċ

Caution!

Only begin mapping in this function if the probe is safely uncovered. Otherwise, the device will not make correct measurements.

3.14 Function "range of mapping" (052)



This function displays the suggested range of mapping. The reference point is always the reference point of the measurement ($\rightarrow \square$ 1). This value can be edited by the operator. For manual mapping, the default value is 0,3 m.

3.15 Function "start mapping" (053)



This function is used to start the interference echo mapping up to the distance given in **"range of mapping" (052)**.

Selection:

- off: no mapping is carried out
- on: mapping is started

3.16 Display (008)





The distance measured from the reference point to the product surface and the meas. value calculated with the aid of the empty alignment are displayed again. Check whether the values correspond to the actual meas. value or the actual distance. The following cases can occur:

- Distance correct meas. value correct -> basic setup completed
- Distance incorrect meas. value incorrect -> a further interference echo mapping must be carried out "check distance" (051).
- Distance correct meas. value incorrect -> check "empty calibr." (005)



After 3 s, the following message appears

After the basic setup, an evaluation of the measurement with the aid of the envelope curve ("envelope curve" (OE)" function group) is recommended.

4 Function group "safety settings" (01)



4.1 Function "output on alarm" (010)



This function is used to select the reaction of output on an alarm.

Selection:

- MIN (<= 3.6mA)
- MAX (22mA)
- hold
- user specific

MIN (<= 3.6mA)



If the instrument is in alarm state, the output changes as follows:

- HART:PROFIBUS PA:
 - MIN-Alarm 3.6 mA MIN-Alarm -99999
- FOUNDATION Fieldbus: MIN-Alarm -99999

MAX 110% 22mA



If the instrument is in alarm state, the output changes as follows:

- HART: MAX-Alarm 22 mA
- PROFIBUS PA: MAX-Alarm +99999
- FOUNDATION Fieldbus: MAX-Alarm +99999

hold



If the instrument is in alarm state, the last measured value is held.

user specific



If the instrument is in alarm state, the output is set to the value configured in "**output on alarm**" **(011)** (x mA).



Caution!

This selection is available for HART devices only!



4.2 Function "output on alarm" (011), HART only

On alarm, the output current is in mA. This function is active when you selected "**user specific**" in the "**output on alarm**" (010) function.



Caution!

This function is available for HART devices only!

4.3 Function "outp. echo loss" (012)



Use this function to set the output response on echo loss.

Selection:

- ∎ alarm
- hold
- ramp %/min

alarm



On echo loss, the instrument switches to alarm state after an adjustable "**delay time**" (014). The output response depends on the configuration set in "**output on alarm**" (010).

hold



On echo loss, a warning is generated after a definable "delay time" (014). Output is held.

ramp %/min



On echo loss, a warning is generated after a definable "**delay time**" (014). The output is changed towards 0% or 100% depending on the slope defined in "**ramp %span/min**" (013).

4.4 Function "ramp %span/min" (013)



Ramp slope which defines the output value on echo loss. This value is used if "**ramp %span/min**" is selected in "**outp. echo loss**" (012). The slope is given in % of the measuring range per minute.

4.5 Function "delay time" (014)



Use this function to enter the delay time (Default = 30 s) after which a warning is generated on echo loss, or after which the instrument switches to alarm state.

4.6 Function "safety distance" (015)

A configurable safety distance is placed before the "**blocking dist.**" (059) ($\rightarrow \ge 45$). This distance warns you that any further level increase would make the measurement invalid.





Enter the size of the safety distance here. The default value is: 0.1 m.

4.7 Function "in safety dist." (016)



This function defines the response when the level enters the safety distance .

Selection:

- ∎ alarm
- warning
- self holding

alarm



Instrument enters the defined alarm state ("output on alarm" (011)). The alarm message E651 – "level in safety distance – risk of overspill" is displayed.

If the level drops out of the safety distance, the alarm warning disappears and the instrument starts to measure again.

warning



Instrument displays a warning **E651** – "**level in safety distance** – **risk of overspill**", but continues to measure. If the level leaves the safety distance, the warning disappears.

self holding



Instrument switches to defined alarm state ("output on alarm" (011)). The alarm message E651 – "level in safety distance – risk of overspill" is displayed.

If the level leaves the safety distance, the measurement continues only after a reset of the self holding (function: "ackn. alarm" (017)).

$\Rightarrow \frac{ackn. alarm 017}{VMO}$

This function acknowledges an alarm in case of "self holding".

Function "ackn. alarm" (017)

Selection:

∎ no

4.8

yes

no

The alarm is not acknowledged.

yes

Acknowledgement takes place.

4.9 Function "overspill prot." (018)



When "**german WHG**" is selected, various parameters relating to WHG overflow protection are defaulted and the instrument is locked against further operation. Select "**Standard**" to unlock, the WHG parameter settings are retained.

4.10 Function "broken probe det" (019)



This function activates the automatic recognition of broken probes. Before updating the broken probe detection a mapping must be performed (function "**range of mapping**" (052) and "**start mapping**" (053)).

Selection:



After 3 s, the following message appears

5 Function group "length adjustment" (03)



5.1 Function "end of probe" (030)



Use this function to select the polarity of the probe end signal. If the probe end is uncovered or in an insulated attachment, there is a negative probe end signal. The signal from the probe end is positive if the attachment is grounded.

Only the setting "free " is permitted for the FMP41C.

Selection:

- free
- tie down isol.¹
- tie doen gnd.¹

5.2 Function "probe length" (031)



Use this function to select whether the probe length was changed after factory calibration. Only then is it necessary to enter or correct the probe length.

Selection:

modified

Note!

not modified

Ś

If "modified" was selected in the "probe length" (031) function, the probe length is defined in the next step.

^{1.}FMP41C: These settings lead to a false output signal for empty tanks.

5.3 Function "probe" (032)



Use this function to select whether the probe is at the time of the commisioning uncovered or covered. If the probe is uncovered, the Levelflex can determine the probe length automatically "determine length" (034). function. If the probe is covered, a correct entry is required in the "probe length" (033) function

- Selection:
- free
- covered

5.4 Function "probe length" (033)



Use this function to enter the probe length.

5.5 Function "determine length" (034)

determine Sisisisi	length 034
LN: 0.3	c 399m

Use this function to determine the probe length automatically.

Due to the mounting conditions, the automatically determined probe length may be larger than the actual probe (typically 20 .. 30 mm longer). This has no influence on the measuring accuracy. When entering the empty value for a linerisation, please use the "empty calibration" instead of the automatically determined probe length.

Selection:

- Iength ok
- too short
- too long

After selecting "length too short" or "length too long" the calculation of the new probe length takes up to approx. 10 s.

6 Function group "linearisation" (04)



6.1 Function "level/ullage" (040)



Selection:

- Ievel CU
- level DU
- ullage CU
- ullage DU

level CU

Level in customer units. The measured value can be linearised. The "linearisation" (041) default value is set to a linear 0...100%.

level DU

Level in the selected "distance unit" (0C5).

ullage CU

Ullage in customer units. The value can be linearised. The "**linearisation**" **(041)** default value is set to a linear 0...100%.

ullage DU

Ullage in the selected "distance unit" (0C5).

Note!

Reference point for the ullage is "full calibr." (006) (=span).



6.2 Function "linearisation" (041)

Linearisation defines the ratio of level to container volume or product weight and allows a measurement in customer units, e.g. metres, hectolitres etc. The measured value in (000) is then displayed in the selected unit.



This function is used to select the linearisation modes.

Selection:

- linear
- horizontal cyl
- manual
- semi-automatic
- table on
- clear table

linear

The tank is linear e.g. a cylindrical vertical tank. You can measure in customer units by entering a maximum volume/weight.

You can select the "customer unit" (042). Define the volume value corresponding to the calibration in "max. scale" (046). This value corresponds to an output of 100% (= 20 mA for HART).



horizontal cyl

The volume, mass etc. are calculated automatically in cylindrical horizontal tanks by entering the "diameter vessel" (047), the "customer unit" (042) and the "max. scale" (046). The "max. scale" (046) corresponds to an output of 100% (= 20 mA for HART).



manual

If the level is not proportional to the volume or weight within the set measuring range, you can enter a linearisation table in order to measure in customer units. The requirements are as follows:

- The 32 (max.) value pairs for the linearisation curve points are known.
- The level values must be given in ascending order. The curve is monotonously increasing.
- The level heights for the first and last points on the linearisation curve correspond to empty and full calibration respectively.
- The linearisation takes place in the basic setup unit ("distance unit" (0C5)).



Each point (2) in the table is described by a value pair: level (3) and, for example, volume (4). The last value pair defines the 100% output (= 20 mA for HART).


Continue until "next point" (045) is answered with no.

S

Note!

After making entries into the table, activate it with "**table on**". The 100% value (=20 mA for HART) is defined by the last point in the table.

Ś

Note!

Before confirming 0.00 m as the level or 0.00% as the volume, activate the Edit mode with + or -.

Entries can be made into the linearisation table in ToF Tool using the table editor. You can also display the contents graphically. In addition, linearisation curves can be calculated for any tank shape.

semi-automatic

The tank is filled in stages when the linearisation curve is entered semi-automatically. The Levelflex automatically detects the level and the corresponding volume/weight has to be entered. The procedure is similar to manual table entry, where the level value for each table point is given automatically by the instrument.

Note!

If the tank is emptied, pay attention to the following points:

- The number of points must be known in advance.
- The first table number = (32 number of points).
- Entries in "Tab. no." (043) are made in reverse order (last entry = 1).

table on

An entered linearisation table only becomes effective when activated.

clear table

Note!

Before making entries into the linearisation table, any existing tables must be deleted. The linearisation mode automatically switches to linear.

A linearisation table can be deactivated by selecting "linear" or "horizontal cyl" (or the "level/ullage" (040) function = "level DU", "ullage DU"). It is not deleted and can be reactivated at any time by selecting "table on".

6.3 Function "customer unit" (042)



You can select the customer unit with this function.

Selection:

- ∎ %
- **1**
- ∎ hl
- ∎ m3
- ∎ dm3
- ∎ cm3
- ∎ ft3
- us_gal
- ∎ i_gal
- ∎ kg
- ∎ t
- ∎ lb
- ton
- ∎ m
- ∎ ft
- mm
- inch

Dependence

The units of the following parameters are changed:

- measured value (000)
- input volume (045)
- max. scale (046)
- simulation value (066)

6.4 Function "table no." (043)



Position of the value pair in the linearisation table.

Dependence

Updates "input level" (044), "input volume" (045).

6.5 Function "input level" (044)



You can enter the level for each point of the linearisation curve with this function. When the linearisation curve is entered semi-automatically, Levelflex detects the level automatically.

User input:

Level in "distance unit" (0C5).



6.6 Function "input volume" (045)

Specify the volume for each point of the linearisation curve with this function.

User input:

Volume in "customer unit" (042).

6.7 Function "max. scale" (046)



You can enter the end value of the measuring range with this function. This input is necessary if you selected "linear" or "horizontal cyl" in the "linearisation" (041) function.

6.8 Function "diameter vessel" (047)



Enter the tank diameter with this function. This entry is necessary if you selected "horizontal cyl" in the "linearisation" (041) function.

Function group "extended calibr." (05)



7

7.1 Function "selection" (050)



Select the function of the extended calibration.

Selection:

- **common** (e.g. "Level correction", "Output damping", etc.)
- mapping
- delete mapping

7.2 Function "check distance" (051)



This function triggers the mapping of interference echoes. To do so, the measured distance must be compared with the actual distance to the product surface. The following options are available for selection:

Selection:

- distance = ok
- dist. too small
- dist. too big
- dist. unknown
- manual
- probe free



distance = ok

- mapping is carried out up to the currently measured echo
- The range to be suppressed is suggested in the **"range of mapping (052)**" function Anyway, it is wise to carry out a mapping even in this case.

Ì

Note!

At free probe, the mapping should be confirmed with the choice "probe free".

dist. too small

- At the moment, an interference is being evaluated
- Therefore, a mapping is carried out including the presently measured echoes
- The range to be suppressed is suggested in the "range of mapping (052)" function

dist. too big

- This error cannot be remedied by interference echo mapping
- Check the application parameters (002), (003), (004) and "probe length" (033)

dist. unknown

If the actual distance is not known, no mapping can be carried out.

manual

A mapping is also possible by manual entry of the range to be suppressed. This entry is made in the **"range of mapping (052)**" function.

Caution!

The range of mapping must end 0.3 m (12") before the echo of the actual level.

7.3 Function "range of mapping" (052)



This function displays the suggested range of mapping. The reference point is always the reference point of the measurement ($\rightarrow \square$ 1). This value can be edited by the operator. For manual mapping, the default value is 0.3 m.

7.4 Function "start mapping" (053)



 $\Rightarrow \frac{\text{start mapping}}{\text{off}} 053$

This function is used to start the interference echo mapping up to the distance given in **"range of mapping" (052)**.

Selection:

- off: no mapping is carried out
- on: mapping is started

7.5 Function "pres. map dist." (054)



Displays the distance up to which a mapping has been recorded. A value of 0 indicates that no mapping was recorded so far.



7.6 Function "delete mapping" (055)



This function allows cancellation of the available mapping.

Selection:

- ∎ no
- ∎ yes

no

The available mapping is not cancelled and remains active.

yes

After mapping is cancelled, the device skips to the "dist./meas.value" (008) display.



7.7 Function "echo quality" (056)



The echo quality is the benchmark for measurement reliability. It describes the amount of reflected energy and depends primarily on the following conditions:

- Dielectric constant of the medium
- probe type
- Distance between sensor and product

Low values increase the probability that the echo is lost through a change in measurement conditions, e.g. angel s of repose or large measuring distance.

7.8 Function "offset" (057)



This function corrects the measured level by a constant value. The entered value is added to the measured level.

7.9 Function "output damping" (058)



Influences the time an output requires to react to a sudden level jump (63% of steady state). A high value attenuates, for example, the influences of rapid changes on the measured variable.

User input:

0...255 s

The default value depends on the selected application parameter "process cond." (004).

7.10 Function "upper block. dist" (059)





For rod probes and for rope probes with lengths of up to 8 m, the upper blocking distance is preset to 0.2 m on delivery.

For rope probes with lengths of more than 8 m, the upper blocking distance is preset to 2.5% of the probe length.

For media with DC > 7, the upper blocking distance for rod and rope probes can be reduced to 0.1 m, if the probe is mounted flush with the wall or in a nozzle of maximum 50 mm (exception: FMP43).

Blocking distance and measuring range

At the lower end of the probe there is no blocking distance but a transition region with reduced accuracy, see section "Maximum measured error" on $\rightarrow \triangleq 46$.

FMP40	LN [m]		UB [m]	
	min	max	min	
Rope probe	1	35 ^{a)}	0,2 ^{b)}	
6 mm rod probe	0,3		0,2 ^{b)}	
16 mm rod probe	0,3	4	0,2 ^{b)}	
Coax probe	0,3	4	0	

a. Larger measuring range available on request.

b. The indicated blocking distances are preset. At media with DC > 7, the upper blocking distance UB can be reduced to 0.1 mm for rod and rope probes. The upper blocking distance UB can be entered manually.

FMP43	LN [m]		UB [m]	
	min	max	min	
Rod probe	0.3	4	0.2 ^{a)}	

a. The indicated blocking distances are preset. The blocking distance can be reduced if the probe is mounted flush with the wall or in a nozzle, max. 50 mm in height. When using a spray ball the blocking distance may not be smaller than 50 mm.

FMP41C	LN [m]		UB [m]	
	min	max	min	
Rod probe	0,3	4	0,2 ^{a)}	
Rope probe	1	30	0,2 ^{a)}	

a. The indicated blocking distances are preset. At media with DC > 7, the upper blocking distance UB can be reduced to 0.1 mm for rod and rope probes. The upper blocking distance UB can be entered manually.

FMP45	LN [m]		UB [m]	
	min	max	min	
Rod probe	0,3	4	0,2 ^{a)}	
Rope probe	1	35	0,2 ^{a)}	
Coax probe	0,3	4	0	

a. The indicated blocking distances are preset. At media with DC > 7, the upper blocking distance UB can be reduced to 0.1 mm for rod and rope probes. The upper blocking distance UB can be entered manually.

Ś

Note!

Within the upper and lower blocking distance, a reliable measurement can not be guaranteed.

For stilling well applications

The upper blocking distance (UB) is preset to 100 mm when the "bypass/pipe" parameter has been selected in the "tank properties" (002) function.

Maximum measured error

Typical statements for reference conditions: DIN EN 61298-2, percentage of the span.

Output:	digital	analogue
sum of non-linearity, non-repeatability and hysteresis	<pre>measurig range FMP40, FMP45:</pre>	± 0.06 %
Offset / Zero	±4 mm	± 0.03 %

If the reference conditions are not met, the offset/zero arising from the mounting situation may be up to ± 12 mm. This additional offset/zero can be compensated for by entering a correction (function "offset" (057)) during commissioning.

Differing from this, the following measuring error is present in the vicinity of the probe end:



Note!

Please reenter the blocking distance in the function group "**extended calibr**." **(05)** function "**upper block.dist**" **(059)** when installing the device in a high nozzle: upper blocking distance (UB) = nozzle height (H) + 50 mm.



8 Function group "output" (06), - "PROFIBUS param." (06), PROFIBUS PA only



Display at HART and FOUNDATION Fieldbus instrument

Display at PROFIBUS PA instrument

8.1 Function "commun. address" (060), HART only



Enter the communication address for the instrument with this function.

- Standard: 0
- Multidrop: 1-15

In multidrop mode, the standard output current is 4 mA. This can be changed in the "**fixed cur. value**" **(064)** function.

Caution!

This function is available for HART devices only!

8.2 Function "instrument addr." (060), PROFIBUS PA only





The PA bus address is displayed in this field. The address is set either directly on the instrument using DIP switches (see instrument operating instructions) or using a special SetSlaveAddress command via the bus, e.g. by the ToF Tool.

Caution!

This function is available for PROFIBUS PA devices only!

8.3 Function "no. of preambels" (061), HART only



Enter the number of preambles for the HART protocol with this function. An increase in the value is advisable for "bad" lines with communications problems.



Caution!

This user input is available for HART devices only!

8.4 Function "ident number" (061), PROFIBUS PA only



- manufacturer
- profile

manufacturer

Set to 1522 hex according to manufacturer (PNO registered).

profile

Setting defined as in PA Profile 3.0: 9700 hex - instrument with one AI block.

Caution! This function is available for PROFIBUS PA devices only!

8.5 Function "low output limit" (062), HART only



The output of negative level values can be suppressed with this function.

Selection:

- off minimum output -10% (3.8 mA for HART)
- on minimum output 0% (4 mA for HART)



()

Caution!

This user input is available for HART devices only!

8.6 Function "set unit to bus" (062), PROFIBUS PA only



■ confirm

After confirming this function, the unit of the measured variable is taken over in the AI block (PV scale -> Out scale).

This function must always be executed after changing the unit.



Caution!

This function is available for PROFIBUS PA devices only!

8.7 Function "curr. output mode" (063), HART only



Use this function to specify the current output mode for HART devices.

Selection:

- standard
- curr. turn down
- fixed current

standard

This selection displays the complete measuring range (0...100%) across the full current interval (4...20 mA).

curr. turn down

This selection only displays a part of the measuring range across the full current interval (4...20 mA). This range is specified using the "**4mA value**" (068) and "**20mA Value**" (069) functions.

fixed current

Selecting this outputs a fixed current. The measured value is only transmitted using the HART signal. The current output value is set using the "fixed cur. value" (064) function.

Caution!

This selection is available for HART devices only!







This displays the AI block output.



Caution!

This function is available for PROFIBUS PA devices only!

8.9 Function "fixed cur. value" (064), HART only



(¹)



Set the fixed current value with this function. This data is necessary if you have selected the "**fixed current**" option in the "**curr. output mode**" (063) function.

User input:

3,8...20,5 mA

Caution!

This user input is available for HART devices only!

8.10 Function "out status" (064), PROFIBUS PA only



Displays the current output status (for value, see operating instructions of relevant instrument).

ſ

Caution! This function is available for PROFIBUS PA devices only!

8.11 Function "simulation" (065)



If necessary, linearisation, the output signal and the current output can be tested with the simulation function. You have the following simulation options:

Selection:

- ∎ sim. off
- ∎ sim. level
- sim. volume
- sim. current (HART only)



sim. off

Simulation is switched off.

sim. level

Enter the level value in "simulation value" (066). The functions

- measured value (000)
- measured level (0A6)
- output current" (067) only with HART instruments! follow the entered values.

sim. volume

Enter the volume value in "**simulation value**" (066). The functions

■ measured value (000)

• output current" (067) - only with HART instruments! follow the entered values.

sim. current (HART only)

Enter the current value in "**simulation value**" **(066)**. The function

• output current" (067) – only with HART instruments! follows the entered values.



8.12 Function "simulation value" (066)

After selecting the "**sim. level**" option in the "**simulation**" (065) function, the following message appears in the display: you can enter the level.

After selecting the "sim. volume" option in the "simulation" (065) function, the following message appears in the display: you can enter the volume.

After selecting the "**sim. current**" option in the "**simulation**" (065) function, the following message appears in the display: Enter the output current (only for HART instruments).

8.13 Function "output current" (067), HART only



Displays the output current in mA.

 \square

Caution! This function is available for HART devices only!

8.14 Function "2nd cyclic value" (067), PROFIBUS PA only



2nd cyclic yalue 067 **Birshaharahara**

Selects the second cyclical value.

■ height/dist.

Levelflex always transmits the distance as the second cyclical value.

Caution!

This function is available for PROFIBUS PA devices only!

8.15 Function "4mA value" (068), HART only



In this function, enter the level (or volume, weight) at which the output current should be 4 mA. This entry is only required if you selected the "current turn down" option in the "curr. output mode" (063) function.

8.16 Function "select v0h0" (068), PROFIBUS PA only



Selects the value displayed in "measured value" (000).

Selection:

- measured value
- display value

measured value

The configured measured value is displayed in the "measured value" (000) function.

display value

The value in "display value" (069) is displayed in the "measured value" (000) function.

Caution!

This function is available for PROFIBUS PA devices only!

8.17 Function "20mA value" (069), HART only



In this function, enter the level (or volume, weight) at which the output current should be 20 mA. This entry is only required if you have selected the

"current turn down" option in the "curr. output mode" (063) function.

069

8.18 Function "display value" (069), PROFIBUS PA only



This field can be set externally, e.g. from a PLC. The value is then displayed as the main measured variable in the display by selecting the "**select v0h0**" (068) = "**display value**" function.

Caution!

This function is available for PROFIBUS PA devices only!

ay value AVAILABLE

9 Function group "envelope curve" (0E)



9.1 Function "plot settings" (0E1)



Here select which information is displayed in the LCD:

- envelope curve
- substracted signal
- mapping

9.2 Function "recording curve" (0E2)

This function defines whether the envelope curve is read as a

- single curve
- or

Note!

• cyclic.



recording curve 95 Seinele Curve cyclic

If the cyclical envelope curve is active in the display, the measured variable is refreshed in a slower cycle time. It is therefore recommended to exit the envelope curve display after optimising the measuring point.

9.3 Function "envelope curve display" (0E3)

You can obtain the following information from the envelope curve display in this function:



Navigation in the envelope curve display

Using navigation, the envelope curve can be scaled horizontally and vertically and shifted to the left or the right. The active navigation mode is indicated by a symbol in the top left hand corner of the display.



Horizontal-Zoom-Modus

Press + or -, to switch to the envelope curve navigation. You are then in Horizontal Zoom mode. Either + is displayed.

- You now have the following options:
- + increases the horizontal scale.
- - decreases the horizontal scale.



Move-Modus

Then press E, to switch to Move mode. Either 🕨 🕨 or 📲 🖷 is displayed.

- You now have the following options:
- + shifts the curve to the right.
- — shifts the curve to the left.



Vertical-Zoom-Modus

Press [, once more to switch to Vertical Zoom mode $\ddagger 1$ is displayed.

You now have the following options:

• + increases the vertical scale.

 \blacksquare \Box decreases the vertical scale.

The display icon shows the current zoom factor ($\textcircled{\label{eq:constraint}}$ to $\textcircled{\label{eq:constraint}}$).



Exiting the navigation

■ Press [•] again to run through the different modes of the envelope curve navigation. Press ⁺ and ⁻ to exit the navigation. The set increases and shifts are retained. Only when you reactivate the **"recording curve" (0E2)** function does the Levelflex use the standard display again.



After 3 s, the following message appears

10 Function group "display" (09)



10.1 Function "language" (092)



Selects the display language.

Selection:

- English
- Deutsch
- Français
- Español
- Italiano
- Nederlands
- Katakana (japanese)

Dependence

All texts are changed.

Caution! This function is not visualised in Commuwin II!

10.2 Function "back to home" (093)



If no entry is made using the display during the specified time period, the display returns to the measured value display.

 $9999\ s$ means that there is no return.

User input: 3...9999 s

Caution! This function is not visualised in Commuwin II!

10.3 Function "format display" (094)



format display 094 Zecimal ft-in-1/16''

Selects the display format.

Selection:

- decimal
- ft-in-1/16"

decimal

The measured value is given in decimal form in the display (e.g. 10.70%).

ft-in-1/16"

The measured value is given in the display in this format (e.g 5'05-14/16''). This option is only possible for "distance unit" (0C5) - "ft" and "in"!



Caution!

This function is not visualised in Commuwin II!

10.4 Function "no.of decimals" (095)



Selection:

- X
- X.X
- X.XX
- X.XXX

10.5 Function "sep. character" (096)



Selection:

- ■.
- ∎,

The decimal place is separated by a point.

The decimal place is separated by a comma.

10.6 Function "display test" (097)



All display pixels are switched on. If the whole LCD is dark, it is working correctly.



After 3 s, the following message appears $% \left(f_{1}, f_{2}, f_{3}, f_{$

11 Function group "diagnostics" (0A)





In the "diagnostics" function group, you can display and confirm error messages.

Type of error

Errors that occur during commissioning or measuring are displayed immediately on the local display. If two or more system or process errors occur, the error with the highest priority is the one shown on the display.

The measuring system distinguishes between two types of error:

- A (Alarm):
 - Instrument goes into a defined state (e.g. MAX) Indicated by a constant **4** symbol.

(For a description of the codes, see Table 15.2 \rightarrow \supseteq 76)

• W (Warning):

Instrument continue measuring, error message is displayed.

Indicated by a flashing symbol.

(For a description of the codes, see Table 15.2 \rightarrow \square 76)

• E (Alarm / Warning):

Configurable (e.g. loss of echo, level within the safety distance) Indicated by a constant/flashing $\[\] symbol. \]$ (For a description of the codes, see Table 15.2 $\rightarrow \[\] 76 \]$

Error messages

Error messages appear as four lines of plain text on the display. In addition, a unique error code is also output. A description of the error codes is given on $\rightarrow \triangleq 76$.

- The "diagnostics (OA)" function group can display current errors as well as the last errors that occurred.
- If several current errors occur, use + or = to page through the error messages.
- The last occurring error can be deleted in the "diagnostics (0A)" function group with the function"clear last error" (0A2).

11.1 Function "present error" (0A0)



The present error is shown using this function.

11.2 Function "previous error" (0A1)



The last error presented is shown with this function.

11.3 Function "clear last error" (0A2)



Selection:

- keep
- erase

11.4 Function "reset" (0A3)

Caution!

A reset sets the instrument back to the factory settings. This can lead to an impairment of the measurement. Generally, you should perform a basic setup again following a reset.

A reset is only necessary:

- if the instrument no longer functions
- if the instrument must be moved from one measuring point to another
- if the instrument is being de-installed /put into storage/installed



Entry ("reset" (0A3)):

- 333 = customer parameters (HART)
- 33333 = customer parameters (PROFIBUS PA and FOUNDATION Fieldbus)

333 = reset customer parameters for HART

33333 = reset customer parameters for PROFIBUS PA and FOUNDATION Fieldbus

This reset is recommended whenever an instrument with an unknown 'history' is to be used in an application:

- The Levelflex is reset to the default values.
- The customer specific tank map is not deleted.
- A linearisation is switched to "linear" although the table values are retained. The table can be reactivated in the "linearisation" (04) function group.

List of functions that are affected by a reset:

- tank properties (002)
- medium cond. (003)
- process proper. (004)
- empty calibr. (005)
- full calibr. (006)
- output on alarm (010)
- output on alarm (011)
- outp. echo loss (012)
- ramp %span/min (013)
- delay time (014)
- safety distance (015)
- in safety dist. (016)
- overspill protection (018)
- end of probe (030)
- level/ullage (040)
- linearisation (041)
- customer unit (042)

- max. scale (046)
- diameter vessel (047)
- check distance (051)
- range of mapping (052)
- start mapping (053)
- offset (057)
- output damping (058)
- low output limit (062)
- curr. output mode (063)
- fixed cur. value (064)
- 4mA value (068)
- language (092)
- back to home (093)
- back to holle (093)
 format display (094)
- = 101111at utspiay (0.94)
- no of decimals (095)sep. character (096)
- = sep. character (090)
- unlock parameter (0A4)

The mapping can also be deleted in the "cust. tank map" (055) function of the "extended calibr." (05) function group.

A complete "basic setup" (00) must be activated.

11.5 Function "unlock parameter" (0A4)



Set-up can be locked and unlocked with this function.

11.5.1 Locking of the configuration mode

The Levelflex can be protected in two ways against unauthorised changing of instrument data, numerical values or factory settings:

"unlock parameter" (0A4):

A value <> 100 for HART (e.g. 99) or <> 2457 for PROFIBUS PA and FOUNDATION Fieldbus (e.g. 2456) must be entered in "unlock parameter" (0A4) in the "diagnostics" (0A) function group. The lock is shown on the display by the . symbol and can be released again either via the display or by communication.

Hardware lock:

The instrument is locked by pressing the $\stackrel{+}{_}$ and $\stackrel{-}{_}$ and $\stackrel{-}{_}$ keys at the same time. The lock is shown on the display by the $\stackrel{-}{_}$ symbol and can **only** be unlocked again via the display by pressing the $\stackrel{+}{_}$ and $\stackrel{-}{_}$ and $\stackrel{-}{_}$ keys at the same time again. It is **not** possible to unlock the hardware by communication. All parameters can de displayed even if the instrument is locked.



11.5.2 Unlocking of configuration mode

If an attempt is made to change parameters when the instrument is locked, the user is automatically requested to unlock the instrument:

"unlock parameter" (0A4):

By entering the unlock parameter (on the display or via communication)

100 =for HART devices

2457 = for PROFIBUS PA and FOUNDATION Fieldbus devices

the Levelflex is released for operation.

Hardware-lock:

After pressing the <code>+</code> and <code>-</code> and <code>e</code> keys at the same time, the user is asked to enter the unlock parameter

100 = for HART devices2457 = for PROFIBUS PA and FOUNDATION Fieldbus devices.



Changing certain parameters such as all sensor characteristics, for example, influences numerous functions of the entire measuring system, particularly measuring accuracy. There is no need to change these parameters under normal circumstances and consequently, they are protected by a special code known only to the E+H service organization. Please contact Endress+Hauser if you have any questions.

11.6 Function "measured dist." (0A5)



Display of measured distance in the selected "distance unit" (0C5).

11.7 Function "measured level" (0A6)



Display of measured level in the selected "distance unit" (0C5).



11.8 Function "detection window" (0A7) (from Software 01.04.00)

ENDRESS + HAUSER	\rightarrow	detection Voff	window	0A7
	on reset			

Is used to switch the detection window on and off and to reset an existing detection window. If this function is switched on, a window is defined surrounding the current level echo (typical width: 1 to 2.5 m; depending on the application parameters).

The window always moves togehter with a rising a falling echo.

Echos beyond the limits of the window are ignored for a certain time.

Selection:

- off
- ∎ on
- ∎ reset

After selection of this option, the current window is reset, the level echo is looked for in the complete measuring range and a new window is defined surrounding the current level echo.

11.9 Function "application par." (0A8)



application par. 0A8 √not modified modified

Displays whether or not one of the settings dependent on the "tank shape" (002), "medium property" (003) and "process cond." (004) application parameters has been changed or not.

If, for example, the "output damping" (058) is changed, the "application par." shows "modified".

Selection:

not modified

modified



After 3 s, the following message appears $% \left(f_{1}, f_{2}, f_{3}, f_{$

12 Function group "system parameters" (0C)



12.1 Function "tag no." (0C0)



You can define the tag number with this function.

User input:

- 16 alphanumeric characters for HART instruments (8 using the HART universal command)
- 32 alphanumeric characteristics for PROFIBUS PA instruments

12.2 Function "device tag" (0C0), FOUNDATION Fieldbus only

This function displays the tag number.

12.3 Function "Profile Version" (0C1), PROFIBUS PA only



The PA Profile version is shown using this function (Profile 3.0).



Caution!

This function is available for PROFIBUS PA devices only!

12.4 Function "protocol+sw-no." (0C2)

ИC



This function shows the protocol and the hardware and software version: Vxx.yy.zz.prot.

Display:

xx: hw-version yy: sw-version zz: sw-revision prot: protocoll type (e.g. HART)

12.5 Function "serial no." (0C4)



This function displays the instrument serial number.

12.6 Function "device id" (0C4), FOUNDATION Fieldbus only

This function displays the instrument serial number.

12.7 Function "distance unit" (0C5)



You can select the basic distance unit with this function.

Selection:

- ∎ m
- ∎ ft
- ∎ mm
- inch

Dependence

m, mm: "format display" (094) can only be "decimal".

The units are changed for the following parameters:

- empty calibr. (005)
- full calibr. (006)
- safety distance (015)
- input level (044)
- diameter vessel (047)
- range of mapping (052)
- cust. tank map (055)
- offset (057)
- simulation value (066)
- measured dist. (0A5)
- measured level(0A6)



This parameter defines which values are written to the instrument during a ToF Tool or Commuwinn II configuration download.

Selection:

- parameter only
- param+cust.map
- mapping only

Note!

S

This parameter must not be described explicitly in ToF Tool. The various possibilities can be selected from the download dialog.



After 3 s, the following message appears

13 Function group "service" (0D)

You can find a detailed description of the "Service" function group as well as a detailed overview of the function menu in the Service Manual for Levelflex M.
14 Envelope curve

14.1 The envelope curve window in the ToF Tool

Signal analysis via envelope curve



To the envelope representation on the local display see $\rightarrow \ge 56$.

15 Trouble-shooting

If you have followed the instructions in this operating manual, the Levelflex should work correctly. If this is not the case, Levelflex has facilities for analysing and correcting errors. You can find a structured approach for locating errors on $\rightarrow \square$ 75 ff. or in the appropriate instrument operating manual.





15.2 System error messages

Code	Description	Possible cause	Remedy
A102	checksum error total reset & new calibr. required.	device was switched off before data were stored; EMC problem; E ² PROM defective	reset avoid EMC problems; if alarm prevails after reset, exchange electronics
W103	initializing – please wait	E ² PROM storage not yet finished	wait a few seconds; if warning prevails, exchange electronics
A106	downloading – please wait	downloading data	wait, message disappears after downloading operation
A110	checksum error total reset & new calibr. required.	device was switched off before data were stored; EMC problem; E ² PROM defective	reset avoid EMC problems; if alarm prevails after reset, exchange electronics
A111	electronics defective	RAM defective	reset if alarm prevails after reset, exchange electronics
A113	electronics defective	ROM defective	reset if alarm prevails after reset, exchange electronics
A114	electronics defective	E ² PROM defective	reset if alarm prevails after reset, exchange electronics
A115	electronics defective	general hardware problem	reset if alarm prevails after reset, exchange electronics
A116	download error repeat download	checksum of stored data not correct	restart download of data
A121	electronics defective	no factory calibration available; E ² PROM cleared	contact service
W153	initializing – please wait	initialization of electronics	wait a few seconds; if warning prevails, switch power off and on again
A160	checksum error total reset & new calibr. required.	device was switched off before data were stored; EMC problem; E ² PROM defective	reset avoid EMC problems; if alarm prevails after reset,
A164	electronics defective	hardware problem	exchange electronics reset if alarm prevails after reset, exchange electronics
A171	electronics defective	hardware problem	reset if alarm prevails after reset, exchange electronics
A221	probe pulse deviates from normal values	HF module or cable between HF module and electronics defective	check contacts on HF module if fault cannot be eliminated: replace HF module
A241	Broken probe	rod probe broken, rope probe broken/torn or value entered for probe length is too short	check the probe length in 033, check the probe mechanically, if the probe is broken, change the probe or change to a non contact system
		probe break monitoring enabled without mapping beforehand	disable probe break monitoring, perform mapping and then reactivate probe break monitoring
A251	feedthrough	lost contact in the process feedthrough	replace process feedthrough

Code	Description	Possible cause	Remedy
A261	HF cable defective	HF cable defective or HF connector loose	check HF connector, replace cable if defective
W275	offset too high	temperature at the electronics too high or HF module defective	check temperature, replace HF module if defective
W512	recording of mapping – please wait	recording active	wait a few seconds until alarm disappears
W601	linearization ch1 curve not monotone	linearization not monotonously increasing	correct linearization table
W611	less than 2 linearization points for channel 1	number of entered linearization points < 2	correct linearization table
W621	simulation ch. 1 on	simulation mode is active	switch off simulation mode
E641	no usable echo channel 1 check calibr.	echo lost due to application conditions or buildup on probe	check basic setup; clean probe (see Operating Instructions, Troubleshooting)
W650	signal/noise ratio too low or no echo	noise amplitude too high	eliminate electromagnetic interference
E651	level in safety distance – risk of overfill	level in safety distance	alarm will disappear as soon as level leaves safety distance perform reset where necessary
A671	linearization ch1 not complete, not usable	linearization table is in edit mode	activate linearization table
W681	current ch1 out of range	current out of range (3.8 mA to 21.5 mA)	check basic setup and linearization

Possible cause Error Output Remedy A warning or alarm Depending on the configuration See table of 1. See table of error messages (→ 🖹 76) has occurred. error messages (→ 1 76) Measured value Measured distance yes \rightarrow 1. Check empty calibr. (005) and (00) is incorrect (008) OK? full calibr. (006) Ţ ſ 20 mA/100% F m/ft 2. Check linearization: m/ft (008) \rightarrow Level/ullage (040) \rightarrow Max. scale (046) expected →Diameter vessel (047) \rightarrow Check table actual E m/ft 4 mA/0% t \rightarrow L00-FMP4xxxx-19-00-00-en-019 no 🗸 1. Carry out tank mapping An interference echo yes \rightarrow may have been → Basic setup evaluated. Interference echo from No change of 1. Carry out tank mapping measured value on tank internals, nozzle → Basic setup 20 mA/100% filling/emptying or buildup on the 2. If necessary, clean probe probe Ô 3. If necessary, select better mounting position actual 2 expected 4 mA/0% † → L00-FMR2xxxx-19-00-00-en-014 E 641 (loss of If the device is configured to HOLD in the event Noise level during the Repeat empty calibr. (005) once echo) after of echo loss the output is set to any initialization phase too more. switching on the value/current. high. Caution! power supply Before confirmation change with + or $\fbox{}$ to the edit mode.

15.3 Application errors



15.4 Software history

Levelflex M FMP40

Date	Software	Software modifications	Documentation				
	version		HART	PA	FF	HART, PA, FF	
04.2002	V 01.02.00	Original software. Operated via: – ToF Tool – Commuwin II (as of Version 2.05.03) – HART-Communicator DXR375 with Rev. 1, DD 1.	BA242F/00/en/03.02 52011929 BA242F/00/en/06.02 52011929 BA242F/00/en/01.03 52011929 BA242F/00/en/02.03 52011929 BA242F/00/en/02.04 52011929	BA243F/00/en/04.02 52011931 BA243F/00/en/06.02 52011931 BA243F/00/en/02.03 52011931 BA243F/00/en/02.04 52011931	BA244F/00/en/06.02 52011933 BA244F/00/en/02.03 52011933 BA244F/00/en/02.04 52011933	BA245F/00/en/03.02 52011935 BA245F/00/en/06.02 52011935 BA245F/00/en/02.03 52011935 BA245F/00/en/02.04 52011935	
08.2003	V 01.02.02	 Function group: envelope curve display: Katakana (japanese) current turn down (HART only) the customer tank map can be edited Operated via: ToF Tool Commuwin II (as of Version 2.08-1 Update C) HART-Communicator DXR375 with Rev. 1, DD 1. 					
07.2004	V 01.02.04	 "mapping" function improved Specification of the measuring accuracy at the end of probe 	BA242F/00/en/06.04 52011929 BA242F/00/en/01.06 52011929	BA243F/00/en/06.04 52011931 BA243F/00/en/04.05 52011931 BA243F/00/en/01.06 52011931	BA244F/00/en/06.04 52011933 BA244F/00/en/04.05 52011933 BA244F/00/en/01.06 52011933	BA245F/00/en/06.04 BA245F/00/en/01.06	
01.2005	V 01.02.06	Function "echo lost" improved	—	—	—	—	
03.2006	V 01.04.00	 function "detection window" Description of Instrument Functions Operating menu extended 	BA242F/00/en/05.06 52011929 BA242F/00/en/11.06 52011929	BA243F/00/en/05.06 52011931 BA243F/00/en/11.06 52011931	BA244F/00/en/05.06 52011933 BA244F/00/en/11.06 52011933	BA245F/00/en/06.06	

Date	Software	Software modifications	Documentation			
	version		HART	РА	FF	HART, PA, FF
04.2002	V 01.02.00	Original software. Operated via: – ToF Tool – Commuwin II (as of Version 2.05.03) – HART-Communicator DXR375 with Rev. 1, DD 1.	BA276F/00/en/11.03 52021032	BA277F/00/en/11.03 52021034	BA278F/00/en/11.03 52021036	BA245F/00/en/02.04 52011935
08.2003	V 01.02.02	 Funktionsgruppe: Hüllkurvendarstellung Katakana (Japanisch) Stromlupe (nur HART) editierbare Störechoausblendung Operated via: ToF Tool Commuwin II (as of Version 2.08-1 Update C) HART-Communicator DXR375 with Rev. 1, DD 1. 	BA276F/00/en/02.04 52021032	BA277F/00/en/02.04 52021034	BA278F/00/en/02.04 52021036	
07.2004	V 01.02.04	 "mapping" function improved Specification of the measuring accuracy at the end of probe 	BA276F/00/en/06.04 52021032 BA276F/00/en/01.06 52021032	BA277F/00/en/06.04 52021034 BA277F/00/en/04.05 52021034 BA277F/00/en/01.06 52021034	BA278F/00/en/06.04 52021036 BA278F/00/en/04.05 52021036 BA278F/00/en/01.06 52021036	BA245F/00/en/06.04 BA245F/00/en/01.06
01.2005	V 01.02.06	Function "echo lost" improved	—	—	—	—
03.2006	V 01.04.00	 function "detection window" Description of Instrument Functions Operating menu extended 	BA276F/00/en/05.06 52021032 BA276F/00/en/11.06 52021032	BA277F/00/en/05.06 52021034 BA277F/00/en/11.06 52021034	BA278F/00/en/05.06 52021036 BA278F/00/en/11.06 52021036	BA245F/00/en/06.06

Levelflex M FMP41C

Levelflex M FMP43

Date	Software	Software modifications	Documentation			
	version		HART	РА	FF	HART, PA, FF
07.2007	V 01.04.02	Original software.	BA357F/00/en/07.07 71040912	BA358F/00/en/07.07 71041163	BA359F/00/en/07.07 71041165	BA245F/00/en/07.07 52011935

Levelflex M FMP45

Date	Software	Software modifications	Documentation				
	version		HART	PA	FF	HART, PA, FF	
08.2003	V 01.02.02	Original software. Operated via: – ToF Tool – Commuwin II (as of Version 2.08-1 Update C) – HART-Communicator DXR375 with Rev. 1, DD 1.	BA279F/00/en/04.04 52021038	BA280F/00/en/04.04 52021040	BA281F/00/en/04.04 52021042		
07.2004	V 01.02.04	 "mapping" function improved Specification of the measuring accuracy at the end of probe 	BA279F/00/en/06.04 52021038 BA279F/00/en/01.06 52021038	BA280F/00/en/06.04 52021040 BA280F/00/en/04.05 52021040 BA280F/00/en/01.06 52021040	BA281F/00/en/06.04 52021042 BA281F/00/en/04.05 52021042 BA281F/00/en/01.06 52021042	BA245F/00/en/06.04 BA245F/00/en/01.06	
01.2005	V 01.02.06	Function "echo lost" improved	—	—	—	—	
03.2006	V 01.04.00	 function "detection window" Description of Instrument Functions Operating menu extended 	BA279F/00/en/05.06 52021038 BA279F/00/en/11.06 52021038 BA279F/00/en/12.06 52021038	BA280F/00/en/05.06 52021040 BA280F/00/en/11.06 52021040 BA280F/00/en/12.06 52021040	BA281F/00/en/05.06 52021042 BA281F/00/en/11.06 52021042 BA281F/00/en/12.06 52021042	BA245F/00/en/06.06	

Index function menu

0 1	
00 = basic setup	15
01 = safety settings	25
03 = length adjustment	32
$04 = linearisation \dots \dots$	34
05 = extended calibr	41
06 = output	48
06 = PROFIBUS Param. (PROFIBUS PA only)	48
OE = envelope curve	56
09 = display	59
0A = diagnostics	62
OC = system parameter	69

Function

15
15
16
18
20
21
25
27
27
28
29
29
29
31
31
31
32
32
33
33
33
34
35
38
39
39
40
40
40
41
41
42
42
43
43
44
44
45
48
48
49
49

062 - low output limit (HAPT only)	50
062 = 1000 output minit (HART Only)	50 50
063 = curr output mode (HART only)	50 51
063 - out value (PROFIBUS PA only)	51 ST
064 = fixed cur value (HART only)	52
064 = 0.01 status (PROFIBLIS PA only)	<u>52</u> 52
065 = simulation	<u>5</u> 3
066 = simulation value	
067 = output current (HART only).	
067 = 2nd cvclic value (PROFIBUS PA only)	54
068 = 4mA value (HART only)	54
068 = select v0h0 (PROFIBUS PA only)	55
069 = 20mA value (HART only)	55
069 = display value (PROFIBUS PA only)	55
092 = language	59
093 = back to home	59
094 = format display	60
095 = no.of decimals	60
096 = sep. character	60
$097 = display test \dots \dots \dots \dots$	61
$0A0 = present error \dots \dots \dots \dots$	63
$OA1 = previous \ error \dots \dots \dots \dots$	63
0A2 = clear last error	63
0A3 = reset	64
$0A4 = unlock parameter \dots$	65
0A5 = measured dist.	66
0A6 = measured level	67
0A7= detection window	67
0A8 = application par	68
$0C0 = tag no. \dots$	69
$0C0 = device tag (FOUNDATION Fieldbus only) \dots$	69
OC1 = Profile Version (PROFIBUS PA only)	69
OC2 = protocoll+sw-no.	69
0C4 = serial no	70
OC4 = device id. (FOUNDATION Fieldbus only)	70
OC5 = distance unit	70
0C8 = download mode	71
UE1 = plot settings	56
UE2 = recording curve	56
OE3 = envelope curve display	57
$D00 = service level \dots$	72

www.endress.com/worldwide



People for Process Automation



BA245F/00/en/07.07 No. 71040940 CCS / FM+SGML 6.0