


















Description of Device Functions

Proline Promag 53 FOUNDATION Fieldbus

Electromagnetic Flow Measuring System





Operation Promag 53 FF

with local operation: \rightarrow Page 5

with FOUNDATION Fieldbus: \rightarrow Page 71

Registered trademarks

FOUNDATION Fieldbus $^{\rm TM}$ Registered trademark of the Fieldbus Foundation, Austin, USA

 $\label{eq:historom} \mbox{HistoROM$^{\sc tm}$, S-DAT$^{\sc tm}$, T-DAT$^{\sc tm}$, F-CHIP$^{\sc tm}$, FieldCare$^{\sc tm}$, Fieldcheck$^{\sc tm}$, Applicator$^{\sc tm}$ Registered or registration-pending trademarks of Endress+Hauser Flowtec AG, Reinach, CH$

Table of contents for local operation

I	Using the manual
1.1	Using the table of contents to locate a function description
1.2	Using the graphic of the function matrix to locate a function description
1.3	Using the index of the function matrix to locate a function description
2	Function matrix 8
2.1	General layout of the function matrix 8 2.1.1 Blocks (A, B, C, etc.) 8 2.1.2 Groups (AAA, AEA, CAA, etc.) 8 2.1.3 Function groups (000, 020, 060, etc.) 8 2.1.4 Functions (0000, 0001, 0002, etc.) 8 2.1.5 Codes identifying cells 9 Function matrix 10
3	BlockMEASURED VARIABLES 11
3.1	Group MEASURING VALUES
3.2	Group SYSTEM UNITS
3.3	Group SPECIAL UNITS
4	Block QUICK SETUP 17
4.1 4.2	"Commissioning" Quick Setup menu
5	Block USER INTERFACE 21
5.1	Group CONTROL
5.2	Group MAIN LINE
5.3	5.2.2 Function group MULTIPLEX
5.4	5.3.2 Function group MULTIPLEX
6	Block TOTALIZER 37
6.1	Group TOTALIZER (1 to 3)
6.2	Group HANDLING TOTALIZER
7	Block BASIC FUNCTION 42

7.1	Group FOUNDATION FIELDBUS
7.2	Group PROCESS PARAMETER
7.3	Group SYSTEM PARAMETER
7.4	Group SENSOR DATA
8	Block SUPERVISION 57
8.1 8.2	Group SYSTEM
	8.2.1Function group DEVICE618.2.2Function group SENSOR618.2.3Function group AMPLIFIER628.2.4Function group F-CHIP628.2.5Function group I/O MODULE63
9	Index key words (Index function matrix) 65
10	Index (local operation) 67
	5.2.6 Simulation of input/output 123

1 Using the manual

There are various ways of locating the description of a function of your choice in the manual:

1.1 Using the table of contents to locate a function description

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as USER INTERFACE, INPUTS, OUTPUTS, etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents can be found on Page 5.

1.2 Using the graphic of the function matrix to locate a function description

This step-by-step, top-down approach starts with the blocks, the highest level, and works down through the matrix to the description of the function you need:


- 1. All available blocks, and their corresponding groups, are illustrated on Page 10. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
- 2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

1.3 Using the index of the function matrix to locate a function description

Each "cell" in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected "cell" appears at the top right on the local display.

Example:





A0004750-EN


The function matrix index lists the codes for all the available "cells" in alphabetic and consecutive order, complete with the page references for the corresponding functions. The index to the function matrix is on Page 65.

2 Function matrix

2.1 General layout of the function matrix

The function matrix consists of four levels:

Blocks -> Groups -> Function groups -> Functions



A0000961

2.1.1 Blocks (A, B, C, etc.)

The blocks are the highest-level grouping of the operation options for the device. The blocks include, for example: MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZER, etc.

2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the USER INTERFACE block, for example, include: CONTROL, MAIN LINE, ADDITIONAL LINE, etc.

2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups available in the CONTROL group are for example: BASIC CONFIGURATION, UNLOCKING/LOCKING, OPERATION, etc.

2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the device. Numerical values can be entered here or parameters selected and saved. The functions in the BASIC CONFIGURATION function group include LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc. The procedure for changing the language of the user interface, for example, is as follows:

- 1. Select the USER INTERFACE block
- 2. Select the CONTROL group
- 3. Select the BASIC CONFIGURATION function group
- 4. Select the LANGUAGE function (here you can set the language required).

2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

Blocks:

The code is a letter (A, B, C, etc.)

Groups:

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A $_$; the codes of the groups in block B start with a B $_$, etc.). The other two letters are for identifying the group within the respective block.

Function groups:


The code consists of three digits (000, 001, 100, etc.).

Functions:

The code consists of four digits (0000, 0001, 0201, etc.).


The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).




A0001251

2.2 Function matrix



3 BlockMEASURED VARIABLES



3.1 Group MEASURING VALUES


3.1.1 Function group MAIN VALUES



	Function description	
MEA	SURED VARIABLES → MEASURING VALUES → MAIN VALUES	
 Note! The engineering units of all the measured variables shown here can be set in the SYSTEM UNITS group. If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display. 		
CALCULATED MASS FLOW (0000)	Use this function to view the calculated mass flow. The mass flow is derived from the measured volume flow and the fixed (or temperature-compensated) density. User interface: 5-digit floating-point number, including unit and sign (e.g. 462.87 kg/h; -731.63 lb/min; etc.)	
VOLUME FLOW (0001)	Use this function to view the actual measured volume flow. User interface: 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm³/min; 1.4359 m³/h; -731.63 gal/d; etc.)	
DENSITY (0005)	Use this function to view the set density. User interface: 5-digit floating-point number, including unit (corresponding to 0.10000 to 0.0000 kg/dm³) e.g. 1.2345 kg/dm³; 993.5 kg/m³; 1.0015 SG_20 °C; etc.	

3.2 Group SYSTEM UNITS

3.2.1 Function group CONFIGURATION



Function description MEASURED VARIABLES \rightarrow SYSTEM UNITS \rightarrow CONFIGURATION You can select the units for measured variables in this function group. \otimes The units selected here have no effect on the fieldbus. They are only used for the local display and for assigned instrument functions. UNIT MASS FLOW Use this function to select the unit for displaying the calculated mass flow (mass/time). The mass flow is derived from the preset (compensated) specific fluid density and the (0400)measured volume flow. The unit you select here is also valid for: ■ Switch points (limit value for mass flow, flow direction) ■ Low flow cut off Options: Metric: Gram \rightarrow g/s; g/min; g/h; g/day $Kilogram \rightarrow kg/s; kg/min; kg/h; kg/day$ Metric ton \rightarrow t/s; t/min; t/h; t/day Ounce \rightarrow oz/s; oz/min; oz/h; oz/day Pound \rightarrow lb/s; lb/min; lb/h; lb/day Ton \rightarrow ton/s; ton/min; ton/h; ton/day Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff. **UNIT MASS** Use this function to select the unit for displaying the calculated mass. The mass is derived (0401)from the preset (compensated) specific fluid density and the measured volume. Options: Metric \rightarrow g; kg; t US \rightarrow oz; lb; ton Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff. Note! The unit for the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.

Function description

MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION

UNIT VOLUME FLOW (0402)

Use this function to select the unit for displaying the volume flow (volume/time).

The unit you select here is also valid for:

■ Low flow cut off

Options:

Metric:

Cubic centimeter \rightarrow cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter \rightarrow dm³/s; dm³/min; dm³/h; dm³/day Cubic meter \rightarrow m³/s; m³/min; m³/h; m³/day Milliliter \rightarrow ml/s; ml/min; ml/h; ml/day Liter \rightarrow 1/s; l/min; l/h; l/day Hectoliter \rightarrow hl/s; hl/min; hl/h; hl/day

Hectoniter \rightarrow ni/s; ni/min; ni/n; ni/day Megaliter \rightarrow Ml/s; Ml/min; Ml/h; Ml/day

Cubic centimeter \rightarrow cc/s; cc/min; cc/h; cc/day

US:

Acre foot \rightarrow af/s; af/min; af/h; af/day Cubic foot \rightarrow ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce \rightarrow oz f/s; oz f/min; oz f/h; oz f/day Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Kilo gallon \rightarrow Kgal/s; Kgal/min; Kgal/h; Kgal/day Million gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (normal fluids: 31.5 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 31.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Barrel (filling tanks: 55.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Imperial:

Gallon \rightarrow gal/s; gal/min; gal/h; gal/day Mega gallon \rightarrow Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 36.0 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 34.97 gal/bbl) \rightarrow bbl/s; bbl/min; bbl/h; bbl/day

Factory setting:

Depends on nominal diameter and country \rightarrow Page 130 ff.

UNIT VOLUME (0403)

Use this function to select the unit for displaying the volume.

Options:

Metric \rightarrow cm³; dm³; m³; ml; l; hl; Ml Mega

US \rightarrow cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals) \rightarrow bbl (filling tanks)

 $Imperial \rightarrow gal; Mgal; bbl (beer); bbl (petrochemicals)$


Factory setting:

Depends on nominal diameter and country \rightarrow Page 130 ff.



The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.


3.2.2 Function group ADDITIONAL CONFIGURATION



MEASUR	Function description Measured variables $ ightarrow$ system units $ ightarrow$ additional configuration		
UNIT DENSITY (0420)	Use this function to select the unit for displaying the fluid density. The unit you select here is also valid for: Fluid density entry Options: Metric → g/cm³; g/l; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C; g/l US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks)		
	Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals) Factory setting: kg/l (SI units: not for USA and Canada) g/cc (US units: only for USA and Canada) SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C).		
UNIT LENGTH (0424)	Use this function to select the unit for displaying the length of the nominal diameter. The unit you select here is also valid for: Nominal diameter of sensor (function NOMINAL DIAMETER (6804) on Page 55) Options: MILLIMETER INCH Factory setting: MILLIMETER (SI units: not for USA and Canada) INCH (US units: only for USA and Canada)		
FORMAT DATE TIME (0429)	Use this function to select the format for the date and the time. The unit you select here is also valid for: Displaying the current calibration date (function CALIBRATION DATE (6808) on Page 55) Options: DD.MM.YY 24H MM/DD/YY 12H A/P DD.MM.YY 12H A/P MM/DD/YY 24H Factory setting: DD.MM.YY 24H (SI units) MM/DD/YY 12H A/P (US units)		

3.3 Group SPECIAL UNITS

3.3.1 Function group DENSITY PARAMETER



Function description

MEASURED VARIABLES ightarrow SPECIAL UNITS ightarrow DENSITY PARAMETER

Use this function group to calculate a mass flow from a volume flow.

Note!

It is advisable to enter the density factor at process temperature for calculating the mass flow without compensating for thermal expansion.

Example of calculated mass flow without compensation for thermal expansion of the fluid:

 $\dot{m} = \dot{V} \cdot \rho = 1 \text{ [dm}^3/\text{h]} \cdot 0.900 \text{ [kg/l]} = 0.900 \text{ [kg/h] (mass flow at 20 °C)}$

 $\dot{m}=\dot{V}\cdot\rho=1~[dm^3/h]\cdot0.783~[kg/l]=0.783~[kg/h]$ (mass flow at 150 °C)

DENSITY VALUE (0700)

Use this function to enter a density value preferably at process temperature. This density value is used to convert the volume flow to a mass flow.

User input:

5-digit floating-point number

Factory setting:

1 [unit]

🖎 Note

The appropriate unit is taken from the function UNIT DENSITY (0420), (see Page 15).


4 Block QUICK SETUP

Block	Group	Function groups	Functions
QUICK SETUP (B)	⇒	⇒	OS COMMISS. (1002) P. 17 ⇒ T-DAT SAVE/LOAD (1009) P. 17

Function description OUICK SETUP		
QUICK SETUP COMMISSIONING (1002)	Use this function to start the Setup menu for commissioning. Options: YES NO Factory setting: NO Note! You will find a flowchart of the COMMISSIONING Setup menu on Page 18. For more detailed information on Setup menus, please refer to Operating Instructions Promag 53, BA 047D/06.	
T-DAT SAVE/LOAD (1009)	Use this function to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual security function). Application examples: • After commissioning, the actual measuring point parameters can be saved to the T-DAT as a backup. • If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from the T-DAT into EEPROM) Factory setting: CANCEL • Note! • If the target device has an older software version, the message "TRANSM. SW-DAT" is displayed during startup. Then only the SAVE option is available. • LOAD This option is only possible if: - The target device has the same software version as, or a more recent software version than, the source device or - The T-DAT contains valid data that can be retrieved • SAVE This option is always available.	

4.1 "Commissioning" Quick Setup menu

The "Commissioning" Quick Setup menu guides you systematically through all the important device functions that have to be configured for standard operation.



Note!

- The display returns to the cell SETUP COMMISSIONING (1002) if you press the 🗀 key combination during parameter interrogation. The stored parameters remain valid.
- The system units selected via the Quick Setup only apply for displaying on the local display and for parameters in the Transducer Blocks. They do not affect the process variables (volume flow, calculated mass flow, totalizer) that are transmitted via FOUNDATION Fieldbus.
- $\hbox{ \begin{tabular}{ll} $\textcircled{$\mathbb{Q}$} & The DELIVERY SETTINGS option sets every selected unit to the factory setting. } \\ & The ACTUAL SETTING option accepts the units you previously configured. } \\ \end{aligned} }$
- ② Only units not yet configured in the current Setup are offered for selection in each cycle. The unit for mass and volume is derived from the corresponding flow unit.
- ③ The YES option remains visible until all the units have been configured. NO is the only option displayed when no further units are available.
- The "automatic parameterization of the display" option contains the following basic settings/factory settings:

YES Main line = Volume flow Additional line = Totalizer 1 Information line = Operating/system condition

NO The existing (selected) settings remain.

4.2 Data backup/transmission

Using the T-DAT SAVE/LOAD function, you can transfer data (device parameters and settings) between the T-DAT (exchangeable memory) and the EEPROM (device storage unit).


This is required in the following instances:

- Creating a backup: current data are transferred from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

Installing and removing T-DAT \rightarrow See Operating Instructions for Proline Promag 53 FOUNDATION Fieldbus.



Data backup/transmission with T-DAT SAVE/LOAD function

a0001221-er

Information on the LOAD and SAVE options available:

LOAD:

Data are transferred from the T-DAT to the EEPROM.




- Any settings already saved on the EEPROM are deleted.
- This option is only available if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same or newer than that of the EEPROM. Otherwise, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE:

Data are transferred from the EEPROM to the T-DAT

5 Block USER INTERFACE



5.1 Group CONTROL

5.1.1 Function group BASIC CONFIGURATION

USER INTERFACE CONTROL BASIC CONFIGURATION 200 С \Rightarrow CAA **Function description** USER INTERFACE \rightarrow CONTROL \rightarrow BASIC CONFIGURATION LANGUAGE Use this function to select the language for all texts, parameters and messages shown on (2000)the local display. Note! The displayed options depend on the available language group shown in the LANGUAGE GROUP (8226) function. **OPTIONS:** Language group WEST EU / USA: ENGLISH **DEUTSCH FRANCAIS ESPANOL** ITALIANO **NEDERLANDS** PORTUGUESE Language group EAST EU / SCAND: **ENGLISH** NORSK SVENSKA SUOMI POLISH RUSSIAN **CZECH** Language group ASIA: **ENGLISH** BAHASA INDONESIA JAPANESE (syllabary) Language group CHINA: **ENGLISH** CHINESE Factory setting: Country-dependent (\rightarrow Page 130 ff.) ■ If you press the 🗓 key combination at startup, the language defaults to ENGLISH. ■ You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions. **DISPLAY DAMPING** Use this function to enter a time constant defining how the display reacts to severely (2002)fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant). User input: 0 to 100 seconds Factory setting: 1 s Note! Setting the time constant to zero seconds switches off damping.


Function description USER INTERFACE $ ightarrow$ Control $ ightarrow$ Basic Configuration		
CONTRAST LCD (2003)	Use this function to optimize display contrast to suit local operating conditions. User input: 10100%	
	Factory setting: 50%	
BACKLIGHT (2004)	Use this function to optimize the backlight to suit local operating conditions. User input: 0100% Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.	
	Factory setting: 50%	

5.1.2 Function group LOCKING/UNLOCKING



US	Function description SER INTERFACE $ ightarrow$ Control $ ightarrow$ Locking/unlocking
ACCESS CODE (2020)	Note! This function is only relevant for local operation. If functions or parameters are to be changed via the fieldbus, programming must be enabled separately via the parameter "Access - Code"/Transducer Blocks. All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the key combination in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled). You can enable programming by entering your personal code (factory seting = 53, see DEFINE PRIVATE CODE function, 2021). User input: Max. 4-digit number: 0 to 9999 Note! The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position. You can also disable programming in this function by entering any number (other than the defined private code). The Endress+Hauser service organization can be of assistance if you mislay your personal code.
DEFINE PRIVATE CODE (2021)	Use this function to specify a personal code for enabling programming in the function ACCESS CODE (2020). User input: 0 to 9999 (max. 4-digit number) Factory setting: 53 Note! Programming is always enabled with the code "0". Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.
STATUS ACCESS (2022)	Use this function to check the access status for the function matrix. User interface: ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)
ACCESS CODE COUNTER (2023)	Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the function matrix. User interface: Max. 7-digit number: 0 to 9999999 Factory setting: 0


5.1.3 Function group OPERATION



TEST DISPLAY (2040)

5.2 Group MAIN LINE


5.2.1 Function group CONFIGURATION



26

Function description		
FORMAT	USER INTERFACE \rightarrow MAIN LINE \rightarrow CONFIGURATION Use this function to define the maximum number of places after the decimal point	
(2202)	displayed for the reading in the main line.	
	Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX	
	Factory setting: X.XXXX	
	 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. 	


5.2.2 Function group MULTIPLEX




	Franchism described
	Function description USER INTERFACE \rightarrow MAIN LINE \rightarrow MULTIPLEX
ASSIGN (2220)	Use this function to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the ASSIGN function (2200).
	Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW IN % TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) Factory setting:
100%-VALUE (2221)	OFF Note! This function is only available if VOLUME FLOW IN % or MASS FLOW IN % was
	selected in the function ASSIGN (2220). Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number
	Factory setting: Depends on nominal diameter and country → Page 130 ff.
FORMAT (2222)	Use this function to define the maximum number of places after the decimal point for the second value displayed in the main line. Options:
	XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting:
	X.XXXX Note!
	 Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

5.3 Group ADDITIONAL LINE


5.3.1 Function group CONFIGURATION





Function description USER INTERFACE \rightarrow ADDITIONAL LINE \rightarrow CONFIGURATION 100%-VALUE (2401)This function is not available unless one of the following was selected in the ASSIGN function (2400): ■ VOLUME FLOW IN % ■ MASS FLOW IN % ■ VOLUME FLOW BARGRAPH IN % ■ MASS FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff. **FORMAT** (2402)This function is not available unless a number was selected in the ASSIGN function (2400).Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXXFactory setting: X.XXXX Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. $1.2 \rightarrow \text{kg/h}$), indicating that the measuring system is computing with more decimal places than can be shown on the display. **DISPLAY MODE** \otimes (2403)This function is only available if VOLUME FLOW BARGRAPH IN % or MASS FLOW BARGRAPH IN % was selected in the function ASSIGN (2400). Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). A0001259 Factory setting: STANDARD

5.3.2 Function group MULTIPLEX




Function description USER INTERFACE $ ightharpoonup$ Additional Line $ ightharpoonup$ Multiplex		
ASSIGN (2420)	Use this function to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined ASSIGN function (2400).	
	Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW IN % VOLUME FLOW BARGRAPH IN % MASS FLOW BARGRAPH IN % FLOW VELOCITY TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. Once the fault is eliminated, the measuring device resumes operation in Multiplex mode and the error message is no longer displayed on the local display.	
100%-VALUE (2421)	This function is not available unless one of the following was selected in the ASSIGN function (2420): ■ VOLUME FLOW IN % ■ MASS FLOW IN % ■ VOLUME FLOW BARGRAPH IN % ■ MASS FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country → Page 130 ff.	


Function description USER INTERFACE \rightarrow ADDITIONAL LINE \rightarrow MULTIPLEX **FORMAT** Note! (2422)This function is not available unless a number was selected in the ASSIGN function (2420).Use this function to define the maximum number of places after the decimal point for the second value displayed in the additional line. Options: XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXXFactory setting: X.XXXX Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. $1.2 \rightarrow \text{kg/h}$), indicating that the measuring system is computing with more decimal places than can be shown on the display. **DISPLAY MODE** Note! (2423)This function is only available if VOLUME FLOW BARGRAPH IN % or MASS FLOW BARGRAPH IN % was selected in the function ASSIGN (2420). Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). +50 +75 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). A0001259 Factory setting: **STANDARD**

32

5.4 Group INFORMATION LINE


5.4.1 Function group CONFIGURATION






Function description USER INTERFACE \rightarrow INFORMATION LINE \rightarrow CONFIGURATION 100%-VALUE (2601)This function is not available unless one of the following was selected in the ASSIGN function (2600): ■ VOLUME FLOW IN % ■ MASS FLOW IN % ■ VOLUME FLOW BARGRAPH IN % ■ MASS FLOW BARGRAPH IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff. **FORMAT** (2602)This function is not available unless a number was selected in the ASSIGN function (2600).Use this function to define the maximum number of places after the decimal point displayed for the reading in the information line. XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXXFactory setting: X.XXXX Note! ■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. $1.2 \rightarrow \text{kg/h}$), indicating that the measuring system is computing with more decimal places than can be shown on the display. **DISPLAY MODE** (2603)This function is only available if VOLUME FLOW BARGRAPH IN % or MASS FLOW BARGRAPH IN % was selected in the function ASSIGN (2600). Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). A0001259 Factory setting: STANDARD


5.4.2 Function group MULTIPLEX





Function description USER INTERFACE \rightarrow INFORMATION LINE \rightarrow MULTIPLEX **FORMAT** (2622)This function is not available unless a number was selected in the ASSIGN function Use this function to define the maximum number of places after the decimal point for the second value displayed in the information line. Options: XXXXX.-XXXX.X-XXX.XX-XX.XXX-X.XXXXFactory setting: X.XXXX Note! • Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. ■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. $1.2 \rightarrow \text{kg/h}$), indicating that the measuring system is computing with more decimal places than can be shown on the display. **DISPLAY MODE** \otimes Note! (2623)This function is only available if VOLUME FLOW BARGRAPH IN % or MASS FLOW BARGRAPH IN % was selected in the function ASSIGN (2620). Use this function to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). +50 -50 A0001258 Factory setting: STANDARD

6 Block TOTALIZER



6.1 Group TOTALIZER (1 to 3)

6.1.1 Function group CONFIGURATION




Function description TOTALIZER \rightarrow TOTALIZER (1 to 3) \rightarrow CONFIGURATION The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable. **ASSIGN** Use this function to assign a measured variable to the totalizer in question. (3000)Options: OFF MASS FLOW VOLUME FLOW Factory setting: VOLUME FLOW Note! ■ The totalizer is reset to "0" as soon as the selection is changed. • If you select OFF, the function group CONFIGURATION (300) of the totalizer in question only displays the ASSIGN (3000) function. **UNIT TOTALIZER** Use this function to define the unit for the totalizer's measured variable, as selected (3001)beforehand. Options: (for MASS FLOW assignment): Metric \rightarrow g; kg; t US \rightarrow oz; lb; ton Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff. Options (for VOLUME FLOW assignment): Metric \rightarrow cm³; dm³; m³; ml; l; hl; Ml Mega $US \rightarrow cc$; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff.

38

Function description TOTALIZER \rightarrow TOTALIZER (1 to 3) \rightarrow CONFIGURATION	
TOTALIZER MODE	Use this function to define how the flow components are to be totalized.
(3002)	Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.
	FORWARD Positive flow components only
	REVERSE Negative flow components only
	Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
RESET TOTALIZER (3003)	Use this function to reset the sum and the overflow of the totalizer to zero.
	Options: NO YES
	Factory setting: NO

6.1.2 **Function group OPERATION**



Function description

TOTALIZER \rightarrow TOTALIZER (1 to 3) \rightarrow OPERATION

The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.

SHM (3040)

Use this function to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the "TOTALIZER MODE" function (3002), and the direction of flow.

User interface:

Max. 7-digit floating-point number, including sign and unit (e.g. 15467.04 m³; -4925.631 kg)



- lacktriangle The effect of the setting in the TOTALIZER MODE function (ightarrow Page 39) is as
 - If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions.
 - If the setting is "FORWARD", the totalizer registers only flow in the positive direction.
 - If the setting is "REVERSE", the totalizer registers only flow in the negative direction.
- The totalizer's response to faults is defined in the FAILSAFE ALL TOT. function (3801) $(\rightarrow Page 41).$

OVERFLOW (3041)

Use this function to view the overflow for the totalizer aggregated since measuring commenced.


Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (>9999999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.

Example:

Reading for 2 overflows: $2 \cdot 10^7 \text{ dm}^3 (= 20000000 \text{ dm}^3)$ The value displayed in the function $SUM = 196845.7 \text{ dm}^3$ Effective total quantity = 20196845.7 dm^3


Integer with exponent, including sign and unit, e.g. $2 \cdot 10^7$ dm³

6.2 Group HANDLING TOTALIZER



Function description TOTALIZER \rightarrow HANDLING TOTALIZER \rightarrow Handling totalizer functions	
RESET ALL TOTALIZERS (3800)	Use this function to reset the totals (including all overflows) of the totalizers (1 to 3) to zero (= RESET). Options: NO YES Factory setting: NO
FAILSAFE ALL TOT. (3801)	Use this function to define the common response of all totalizers (1 to 3) in case of error. Options: STOP The totalizer is paused until the fault is rectified. ACTUAL VALUE The totalizers continue to count based on the actual flow measured value. The fault is ignored. HOLD VALUE The totalizers continue to count the flow based on the last valid flow value (before the fault occurred). Factory setting: STOP

7 Block BASIC FUNCTION



620


7.1 Group FOUNDATION FIELDBUS

7.1.1 Function group CONFIGURATION

BASIC FUNCTION G \Rightarrow FOUNDATION FIELDBUS GGA \Rightarrow CONFIGURATION


Function description BASIC FUNCTION $ ightarrow$ Foundation fieldbus $ ightarrow$ configuration	
WRITE PROTECT (6200)	Use this function to check whether the measuring device can be write-accessed via the fieldbus.
	User interface: OFF → Write access via FOUNDATION Fieldbus possible ON → Write access via FOUNDATION Fieldbus not possible
	Factory setting: OFF
	Note! Hardware write protection is activated and deactivated by means of a jumper on the I/O board (\rightarrow see Operating Instructions for Proline Promag 53 FOUNDATION Fieldbus).
SIMULATION (6201)	Use this function to check whether a simulation in the Analog Input or Discrete Output function block is possible.
	User interface: OFF → Simulation in the Analog Input and Discrete Output function block is not possible. ON →Simulation in the Analog Input and Discrete Output function block is possible
	Factory setting: ON
	 Note! The simulation mode is enabled and disabled by means of a jumper on the I/O board (→ see also Operating Instructions for Proline Promag 53 FOUNDATION Fieldbus). The status of the simulation mode is also shown in the parameter BLOCK_ERR of the Resource Block.
DEVICE PD-TAG (6203)	Use this function to enter a tag name for the measuring device.
	User input: Max. 32-character text, permissible: A-Z, 0-9, +,-, punctuation marks
	Factory setting: E+H_PROMAG_53_XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX

7.1.2 Function group FUNCTION BLOCKS



	FUNCTION BLOCKS 622
BASIC	Function description FUNCTION \rightarrow FOUNDATION FIELDBUS \rightarrow FUNCTION BLOCKS
BLOCK SELECTION (6120)	Use this function to select a function block whose value and status is shown in the subsequent functions.
	Options: ANALOG INPUT 1 to 5 ANALOG OUTPUT 1 PID BLOCK
	Factory setting: ANALOG INPUT 1
OUT VALUE (6121)	Use this function to display the output value OUT, incl. unit and status, of the function block selected in the BLOCK SELECTION function (6120).
DISPLAY VALUE (6122)	Note! This function is not available unless the ANALOG OUTPUT 1 option was selected in the BLOCK SELECTION function (6120).
	User interface: The measured variable (DISPLAY_VALUE module) transmitted from the FOUNDATION Fieldbus master to the measuring device, including the unit and status, is displayed. This is the measured variable to be shown on the local display.
PID_IN VALUE (6222)	Note! This function is not available unless the PID BLOCK option was selected in the BLOCK SELECTION (6120) function.
	User interface: Use this function to display the controlled variable IN, incl. unit and status, of the PID function block.
CASCADE_IN (6223)	Note! This function is not available unless the PID option was selected in the BLOCK SELECTION (6120) function.
	User interface: Display of an analog set value, incl. units and status, taken over from an external function block.
SETPOINT VALUE (6224)	 Note! This function is not available unless the PID selection was selected in the BLOCK SELECTION (6220) function. If the service code is used to call this function, this value can be edited.
	User interface: Use this function to display the internal set value, incl. unit and status, for the PID function block.


7.1.3 Function group INFORMATION



Function description BASIC FUNCTION \rightarrow FOUNDATION FIELDBUS \rightarrow INFORMATION	
Use this function to view the manufacturer ID in decimal numerical format.	
User interface: 452B48 (hex) for Endress+Hauser	
Use this function to view the device ID in hexadecimal numerical format.	
User interface: 1042 (hex) for Promag 53 FF	
Use this function to view the serial number. User interface: 11-digit number	
Use this function to view the device revision number.	
Note! The information displayed here can be used to ensure that the correct system files (DD = Device Description) are used for integration into the host system. The system files can be downloaded free of charge from the Internet at www.endress.com.	
Example: Information displayed in the DEVICE REVISION function (6243) \rightarrow 04 Information displayed in the DD REVISION function (6244) \rightarrow 01 Required device description files (DD) \rightarrow 0401.sym / 0401.ffo	
Use this function to view the revision number of the device description. Note! The information displayed here can be used to ensure that the correct system files (DD = Device Description) are used for integration into the host system. The system files can be downloaded free of charge from the Internet at www.endress.com. Example: Information displayed in the DEVICE REVISION function $(6243) \rightarrow 04$ Information displayed in the DD REVISION function $(6244) \rightarrow 01$ Required device description files (DD) $\rightarrow 0401$.sym $/ 0401$.ffo	

7.2 Group PROCESS PARAMETER

7.2.1 Function group CONFIGURATION



E		
BASIO	Function description BASIC FUNCTION \rightarrow PROCESS PARAMETER \rightarrow CONFIGURATION	
ASSIGN LOW FLOW CUT	Use this function to assign the switch point for the low flow cut off.	
OFF (6400)	Options: OFF MASS FLOW VOLUME FLOW Factory setting: VOLUME FLOW	
ON-VALUE LOW FLOW	Use this function to enter the switch-on point for low flow cut off.	
CUT OFF (6402)	Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.	
	User input: 5-digit floating-point number [unit]	
	Factory setting: Depends on nominal diameter and country \rightarrow Page 130 ff.	
	Note! The appropriate unit is taken from the function UNIT VOLUME FLOW (0402) or UNIT MASS FLOW (0400) (\rightarrow Page 14 or Page 13).	
OFF-VALUE LOW FLOW CUT OFF (6403)	Use this function to enter the switch-off point (\mathbf{b}) for low flow cut off. Enter the switch-off point as a positive hysteresis (\mathbf{H}) from the switch-on point (\mathbf{a}) .	
(0403)	User input: Integer 0 to 100%	
	Factory setting: 50%	
	Q ① = switch-on point, ② = switch-off point a Low flow cut off is switched on b Low flow cut off is switched off $(a + a \cdot H)$ H Hysteresis value: 0 to 100% Low flow cut off active Q Flow	

Function description

BASIC FUNCTION \rightarrow PROCESS PARAMETER \rightarrow CONFIGURATION

PRESSURE SHOCK SUPPRESSION (6404)

The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".

Note!

Note that pressure shock suppression cannot be used unless the low flow cut off is active (see ON-VALUE LOW FLOW CUT OFF function on Page 46).

Use this function to define the time span for active pressure shock suppression.

Activation of pressure shock suppression

Pressure shock suppression is activated once the flow falls below the switch-on point of the low flow cut off (see point \mathbf{a} in graphic).

While pressure shock suppression is active, the following conditions apply:

- Flow reading on display \rightarrow 0
- Totalizer reading → The totalizers are pegged at the last correct value.


Deactivation of pressure shock suppression

The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point \mathbf{b}).

Note!

The actual flow value is displayed and output

when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point ${\bf c}$ in graphic).



 $\textcircled{1} = on \ value \ (low \ flow \ cut \ off), \ \textcircled{2} = off \ value \ (low \ flow \ cut \ off)$

a Activated when the on-value for low flow cut off is undershot

b Deactivated once the time specified expires

Flow values are taken into account again for calculating the pulses

Suppressed values

Q Flow


User input:

Max. 4-digit number, incl. unit: 0.00 to 100.0 $\ensuremath{\text{s}}$

Factory setting:

0.00 s

7.2.2 Function group EPD PARAMETER



Function description

BASIC FUNCTION \rightarrow PROCESS PARAMETER \rightarrow EPD PARAMETER

EMPTY PIPE DET. (6420)

Flow cannot be measured correctly unless the measuring tube is completely full. This status can be monitored at all times with the Empty Pipe Detection function. To do this, the empty pipe detection (EPD, empty pipe detection by means of EPD electrode) can be activated in this function:

Options:

OFF

ON STANDARD

Factory setting:

OFF



- The option ON STANDARD is not available unless the sensor is equipped with an EPD electrode.
- The default setting for the EPD function when the device is delivered is OFF. The function must be activated as required.
- The devices are already calibrated at the factory with water (approx. $500 \mu S/cm$). If the conductivity of certain fluids deviates from this reference, empty pipe/full pipe adjustment must be performed again on site (see function EPD/OED ADJUSTMENT (6481) on Page 52).
- The adjustment coefficients must be valid before you can switch on the EPD function.
 If these coefficients are not available, the function EPD/OED ADJUSTMENT (see Page 52) is displayed.
- If there are problems with the adjustment, the following error messages appear on the screen:
 - ADJUSTMENT FULL = EMPTY:
 - The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment **must** be carried out **again**.
 - ADJÚSTMENT NOT OK:
 - Adjustment is not possible as the fluid conductivity values are outside the permitted range.

Notes on empty pipe detection (EPD)

- Flow cannot be measured correctly unless the measuring tube is completely full. This status can be monitored at all times with the EPD function.
- An empty or partially filled pipe is a process error. A default factory setting defines that
 a fault message is issued and that this process error has an effect on the outputs.
- A plausibility check of the adjustment values will only be executed by activating the empty pipe detection. If an empty or full pipe adjustment is performed when empty pipe detection is active, the empty pipe detection has to be deactivated and activated again after finishing the adjustment in order to start the plausibility check.


Response to partially filled pipes


If the EPD is switched on and responds to a partially filled or empty pipe, the notice message "EMPTY PIPE" appears on the display. If the pipe is partially empty and the EPD is **not** switched on, the response can vary in identically configured systems:

- Flow reading fluctuates
- Zero flow
- Excessively high flow values

Function description BASIC FUNCTION \rightarrow PROCESS PARAMETER \rightarrow EPD PARAMETER **EPD RESPONSE TIME** (6425)The function is only available if the function EMPTY PIPE DET. (6420) has been switched on. Use this function to enter the time span for which the criteria for an "empty" pipe have to be satisfied without interruption before a notice message or fault message is generated. User input: fixed point number: 1.0 to 100 s $\,$ Factory setting: 1.0 s

7.2.3 Function group ECC PARAMETER





50

Function description

BASIC FUNCTION → PROCESS PARAMETER → ECC PARAMETER

ECC RECOVERY TIME (6442)



Note!

This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the recovery time for which the last flow value measured prior to cleaning is retained. A recovery time is necessary as the signal outputs can fluctuate after electrode cleaning on account of electrochemical interference voltages.

User input:

Max. 3-digit number: 1 to 600 s

Factory setting:

60 s



Caution!

The last value measured prior to cleaning is output for the duration of the recovery time (max. 600 s). This in turn means that the measuring system does not register changes in flow, e.g. stoppage, during this time span.

ECC CLEANING CYCLE (6443)



Note!

This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC).

Use this function to specify the cleaning cycle for electrode cleaning.


User input:

Integer: 30 to 10080 min

Factory setting:

40 min

7.2.4 Function group ADJUSTMENT




Function description BASIC FUNCTION \rightarrow PROCESS PARAMETER \rightarrow ADJUSTMENT **EPD/OED ADJUSTMENT** Use this function to activate the EPD adjustment for an empty or full measuring tube. (6481)A detailed description of the empty pipe detection function can be found on Page 48. Options: OFF FULL PIPE ADJUST EMPTY PIPE ADJUST Factory setting: Procedure for EPD empty pipe / full pipe adjustment 1. Empty the piping. In case of an EPD adjustment, the wall of the measuring tube should be wetted with fluid. 2. Start empty pipe adjustment: Select "EMPTY PIPE ADJUST" and press [■] to confirm. 3. After empty pipe adjustment, fill the piping with fluid. 4. Start full pipe adjustment: Select "FULL PIPE ADJUST" and press 🗉 to confirm. 5. Having completed the adjustment, select the setting "OFF" and exit the function by pressing 🗉 . 6. Now select the EMPTY PIPE DET. function (see Page 48). Switch on the empty pipe detection by selecting ON STANDARD and press E to confirm. The adjustment coefficients must be valid before you can activate the EPD function. If adjustment is incorrect the following messages might appear on the display: - FULL = EMPTY The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment must be carried out again. ADJUSTMENT NOT OK Adjustment is not possible because the fluid's conductivity is out of range.

660

7.3 Group SYSTEM PARAMETER

7.3.1 Function group CONFIGURATION



Function description BASIC FUNCTION \rightarrow SYSTEM PARAMETER \rightarrow CONFIGURATION	
INSTALLATION DIRECTION SENSOR (6600)	Use this function to reverse the sign of the flow measured variable, if necessary. Options: NORMAL (flow as indicated by the arrow) INVERSE (flow opposite to direction indicated by the arrow) Factory setting: NORMAL Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).
SYSTEM DAMPING (6603) INTEGRATION TIME (6604)	Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The reaction time of the measuring system increases with every increase in the filter setting. User input: 015 Factory setting: 7 Note! The system damping acts on all functions and outputs of the measuring device. Use this function to view the set integration time. The integration time defines the duration of internal totaling of the induced voltage in the fluid (measured by the measuring electrode), i.e. the time in which the measuring device records the true flow (afterwards the magnetic field for the next integration is created
POSITIVE ZERO RETURN (6605)	from the opposite pole). User interface: Max. 2-digit number: 1 to 65 ms Factory setting: 5 ms Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device. Options: OFF ON → Signal output is set to the "ZERO FLOW" value. Factory setting: OFF

Function description

BASIC FUNCTION \rightarrow SYSTEM PARAMETER \rightarrow CONFIGURATION

SPECIAL FILTER (6606)

There is the option of activating two signal filters in this function. These filters make it possible to either suppress the signal caused by severely fluctuating flows (STANDARD option) or to reproduce it completely – both on the display and at the FOUNDATION Fieldbus output (DYNAMIC FLOW option).

Options:

STANDARD

For signal output with normal, stable flow.

DYNAMIC FLOW

For signal output with severely fluctuating or pulsating flow.

Factory setting:

STANDARD




Caution!

- The signal behavior at the outputs also depends on the SYSTEM DAMPING (6603) function.
- Additional filter settings (e.g. STANDARD CIP or DYNAMIC FLOW CIP) can only be selected with the aid of a special service code. Such settings, which are normally made by a service technician, are deleted, however, when the private code is entered again and can then no longer be activated!

7.4 Group SENSOR DATA

7.4.1 Function group CONFIGURATION



Function description

BASIC FUNCTION \rightarrow SENSOR DATA \rightarrow CONFIGURATION

All sensor data (calibration factors, zero (point) and nominal diameter) are set at the factory and saved on the S-DAT sensor memory chip.



Note!

The individual values of the functions are also provided on the sensor nameplate.




Caution!

Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code. Contact the Endress+Hauser service organization if you have any questions about these functions.

CALIBRATION DATE Use this function to view the current calibration date and time for the sensor. (6808)User interface: Calibration date and time Factory setting: Calibration date and time of the current calibration. The calibration date and time format is defined in the FORMAT DATE TIME (0429)function, \rightarrow Page 15. K-FACTOR Use this function to display the actual calibration factor (positive and negative flow (6801)direction) for the sensor. The calibration factor is determined and set at the factory. User interface: 5-digit fixed point number: 0.5000 to 2.0000 Factory setting: Depends on nominal diameter and calibration ZERO POINT Use this function to view the actual zero-point correction value for the sensor. (6803)Zero-point correction is determined and set at the factory. User interface: Max. 4-digit number: -1000 to +1000Factory setting: Depends on nominal diameter and calibration NOMINAL DIAMETER Use this function to view the nominal diameter of the sensor. The nominal diameter (6804)depends on the size of the sensor and is set at the factory. User interface: 2 to 2000 mm or 1/12 to 78" Factory setting: Depends on the size of the sensor

7.4.2 Function group OPERATION



Function description

BASIC FUNCTION \rightarrow SENSOR DATA \rightarrow OPERATION

All sensor data (measuring period, overvoltage time, etc.) are set at the factory and saved on the S-DAT (sensor memory chip).


Caution!

Under normal circumstances you should not change the following parameter settings, because changes affect numerous functions of the entire measuring facility in general and the accuracy of the measuring system in particular. For this reason, the functions described below cannot be changed even when you enter your personal code.

Contact the Endress+Hauser service organization if you have any questions about these functions.


MEASURING PERIOD Use this function to view the measuring period. The duration of the measuring period is (6820)calculated from the rise time of the magnetic field, the brief recovery time, the integration ${\bf r}$ time and the empty pipe detection time. User interface: Max. 4-digit number: 10 to 1000 ms Factory setting: Depends on nominal diameter **EPD ELECTRODE** Use this function to check whether the sensor is equipped with an EPD electrode. (6822)User interface: NO Factory setting: YES \rightarrow Electrode fitted as standard

8 Block SUPERVISION



8.1 Group SYSTEM

8.1.1 Function group CONFIGURATION



8.1.2 Function group OPERATION




Function description SUPERVISION → SYSTEM → OPERATION	
ACTUAL SYSTEM CONDITION (8040)	Use this function to check the present system condition. User interface: SYSTEM OK or the fault/notice message with the highest priority.
PREV. SYSTEM CONDITIONS (8041)	Use this function to view the fifteen most recent fault and notice messages since measuring last started. User interface: The 15 most recent error or notice messages
SIMULATION FAILSAFE MODE (8042)	Use this function to set the Analog Input and Totalizer function blocks to their defined flow-response modes in order to check whether they respond correctly. During this time, message no. 691 "SIMULATION FAILSAFE MODE" appears on the display. Options: OFF ON Factory setting: OFF Note! With the fieldbus, an active simulation is relayed to downstream function blocks and higher-order control systems by means of the status "UNCERTAIN" of the output value OUT (AI Block).
SIMULATION MEASURAND (8043)	Use this function to set all inputs, outputs and totalizers to their defined flow-response modes in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display. Options: OFF MASS FLOW VOLUME FLOW Factory setting: OFF Caution! The measuring device cannot be used for measuring while this simulation is in progress. The setting is not saved if the power supply fails.

	Function description SUPERVISION \rightarrow SYSTEM \rightarrow OPERATION
VALUE SIMULATION MEASURAND (8044)	Note! The function is not visible unless the SIMULATION MEASURAND function (8043) is active.
	Use this function to specify a selectable value (e.g. $12~\mathrm{m}^3/\mathrm{s}$). This is used to test the associated functions in the device itself and downstream signal loops.
	User input: 5-digit floating-point number [unit]
	Factory setting: 0 [unit]
	Caution! The setting is not saved if the power supply fails. The appropriate unit is taken from the function group SYSTEM UNITS (ACA), (see Page 13).
SYSTEM RESET (8046)	Use this function to perform a reset of the measuring system.
(0040)	Options: NO RESTART SYSTEM (restart without interrupting power supply)
	Factory setting: NO
OPERATION HOURS (8048)	User interface: Depends on the number of hours of operation elapsed: Hours of operation < 10 hours → display format = 0.00:00 (hr:min:sec) Hours of operation 10 to 10,000 hours → display format = 0000:00 (hr:min) Hours of operation >10,000 hours → display format = 000000 (hr)


8.2 Group VERSION INFO

8.2.1 Function group DEVICE




Function description SUPERVISION \rightarrow VERSION INFO \rightarrow DEVICE	
DEVICE SOFTWARE (8100)	Use this function to view the current device software version.

8.2.2 Function group SENSOR




Function description SUPERVISION $ ightharpoonup$ VERSION INFO $ ightharpoonup$ SENSOR	
SERIAL NUMBER (8200)	Use this function to view the serial number of the sensor.
SENSOR TYPE (8201)	Use this function to view the sensor type.
SOFTWARE REVISION NUMBER S- DAT (8205)	Use this function to view the software revision number of the software used to create the content of the S-DAT.

8.2.3 Function group AMPLIFIER




Function description SUPERVISION \rightarrow VERSION INFO \rightarrow AMPLIFIER	
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Use this function to view the software revision number of the amplifier.
SOFTWARE REVISION NUMBER T- DAT (8225)	Use this parameter to view the software revision number of the software used to create the content of the T-DAT.
LANGUAGE GROUP (8226)	Use this function to view the language group. The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA, CHINA. User interface: available language group Note! The language options of the available language group are displayed in the LANGUAGE (2000) function. You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.

8.2.4 Function group F-CHIP



Function description SUPERVISION \rightarrow VERSION INFO \rightarrow F-CHIP	
STATUS F-CHIP (8240)	Use this function to check whether an F-CHIP is installed and which software options are available.

8.2.5 Function group I/O MODULE



Function description SUPERVISION \rightarrow VERSION INFO \rightarrow I/O MODULE		
I/O MODULE TYPE (8300)	Use this function to view the configuration of the I/O module complete with terminal numbers.	
SOFTWARE REVISION NUMBER I/O MODULE (8303)	Use this function to view the software revision number of the I/O module.	

9 Index key words (Index function matrix)

Numerics	
0000= CALCULATED MASS FLOW	2
0001 = VOLUME FLOW	2
0005 = DENSITY	2
0400 = UNIT MASS FLOW 1	3
0401 = UNIT MASS	
	4
	14
	15
	15
0429 = FORMAT DATE TIME	
0700 = DENSITY VALUE	
1002 = QUICK SETUP COMMISSION	
1009 = T DAT SAVE/LOAD	
2000 = LANGUAGE	22
2002 = DISPLAY DAMPING	
2003 = CONTRAST LCD	
2004 = BACKLIGHT	
2020 = ACCESS CODE	24
2021 = DEFINE PRIVATE CODE	
2022 = STATUS ACCESS	
2023 = ACCESS CODE COUNTER	24
2040 = TEST DISPLAY	25
2200 = ASSIGN	26
2201 = 100% VALUE	26
2202 = FORMAT	27
2220 = ASSIGN	
2221 = 100% VALUE	
2222 = FORMAT	
2400 = ASSIGN	
2401 = 100% VALUE	
2402 = FORMAT	
2403 = DISPLAY MODE	≀O ≀O
2420 = ASSIGN	
2421 = 100% VALUE	
2422 = FORMAT	
$2422 = FURNAI \dots \dots$	32
	33
2601 = 100% VALUE	
	34
	34
	35
	35
	36
	36
	38
	38
3002 = TOTALIZER MODE	
3003 = RESET TOTALIZER 3	39
3040 = SUM	10
3041 = OVERFLOW	10
	11
3801 = FAILSAFE ALL TOT	11
6120 = BLOCK SELECTION	
6121 = OUT VALUE	

6122 = DISPLAY VALUE	. 44
6200 = WRITE PROTECTION	. 43
6201 = SIMULATION	. 43
6203 = DEVICE PD-TAG	. 43
6222 = PID_IN VALUE	. 44
6223 = CASCADE_IN	. 44
6224 = SETPOINT VALUE	
6240 = MANUFACTURER ID	
6241 = DEVICE TYPE	
6242 = SERIAL NUMBER	
6243 = DEVICE REVISION	
6244 = DD REVISION	
6400 = ASSIGN LOW FLOW CUT OFF	
6402 = ON-VALUE LOW FLOW CUT OFF	. 46
6403 = OFF-VALUE LOW FLOW CUT OFF	
6404 = PRESSURE SHOCK SUPPRESSION	
6420 = EMPTY PIPE DETECTION (EPD)	
6425 = EPD RESPONSE TIME	
6440 = ECC (electrode cleaning)	
6441 = ECC DURATION	. 50
6442 = ECC RECOVERY TIME	
6443 = ECC CLEANING CYCLE	
6481 = EPD ADJUSTMENT	
6600 = INSTALLATION DIRECTION SENSOR	
6603 = SYSTEM DAMPING	
6604 = INTEGRATION TIME	
6605 = POSITIVE ZERO RETURN	
6606 = SPECIAL FILTER	
6801 = K-FACTOR	
6803 = ZERO POINT	
6804 = NOMINAL DIAMETER	
6820 = MEASURING PERIOD	
6822 = EPD ELECTRODE	
8005 = ALARM DELAY	
8007 = PERMANENT SAVING	. 58
8040 = ACTUAL SYSTEM CONDITION	
8041 = PREVIOUS SYSTEM CONDITIONS	
8042 = SIMULATION FAILSAFE MODE	
8043 = SIMULATION MEASURAND	
8044 = VALUE SIMULATION MEASURAND	
8046 = SYSTEM RESET	
8048 = OPERATION HOURS	
8100 = DEVICE SOFTWARE	
8200 = SERIAL NUMBER	
8201 = SENSOR TYPE	
8205 = SOFTWARE REV. NO. S-DAT	
8222 = SOFTWARE REV. NO. AMPLIFIER	-
8225 = SOFTWARE REV. NO. T-DAT	
8226 = LANGUAGE GROUP	
8240 = STATUS F-CHIP	. UZ 62
8300 = I/O MODULE TYPE	
OSUS = SUFI WAKE KEV. NU. I/U MUDULE	. 03
A	
A = MEASURED VARIABLES	11
B = QUICK SETUP	
C = USER INTERFACE	
D = TOTALIZER	
G = BASIC FUNCTION	
	. +/.

J = SUPERVISION	57
В	
AAA = MEASURING VALUES	12
ACA = SYSTEM UNITS	
AEA = SPECIAL UNITS	
CAA = CONTROL	
CCA = MAIN LINE	
CEA = ADDITIONAL LINE	
CGA = INFORMATION LINE	
DAA = TOTALIZER 1	
DAB = TOTALIZER 2	
DAC = TOTALIZER 3	
DJA = HANDLING TOTALIZER	
GAA = FOUNDATION Fieldbus	
GIA = PROCESS PARAMETER	
GLA = SYSTEM PARAMETER	
GNA = SENSOR DATA	
JAA = SYSTEM	
JCA = VERSION-INFO	
С	
000 = MAIN VALUES	12
040 = CONFIGURATION	
042 = ADDITIONAL CONFIGURATION	
070 = DENSITY PARAMETER	16
200 = BASIC CONFIGURATION	
202 = LINLOCKING/LOCKING	

204 = OPERATION
220 = CONFIGURATION
222 = MULTIPLEX28
240 = CONFIGURATION29
242 = MULTIPLEX31
260 = CONFIGURATION
262 = MULTIPLEX35
300 = CONFIGURATION
304 = OPERATION
610 = CONFIGURATION
620 = CONFIGURATION43
622 = FUNCTION BLOCKS44
624 = INFORMATION
640 = CONFIGURATION
642 = EPD PARAMETER
644 = ECC PARAMETER50
648 = ADJUSTMENT52
660 = CONFIGURATION53
680 = CONFIGURATION55
682 = OPERATION
800 = CONFIGURATION58
804 = OPERATION
810 = DEVICE61
820 = SENSOR61
822 = AMPLIFIER
824 = F-CHIP
830 = I/O MODULE

10	Index (local operation)	System parameter	13
Nume	ri co	Totalizer	
		Control	23
	alue flow tional line	Basic configuration	22
	tional line (Multiplex)	Operation	
	mation line	Unlocking/locking	
	mation line (Multiplex)		
	n line	D	
	n line (Multiplex)	Damping	
	•	Display	
Α		System, reaction time	
	ystem condition	DD Revision	
	nal configuration (system units)	Define private code	24
Addition		Density Density parameter (introduction)	16
	figuration	Density parameter (introduction) Density value (display)	
	tiplex	Density value (input)	
	elay	Device (version info)	
	eray	Device PD-Tag	
Assign	(VCISIOII IIIIO)	Device Revision	
	tional line	Device software	
	tional line (Multiplex)	Device type	45
	rmation line	Display	
Info	rmation line (Multiplex)	Contrast LCD	
Low	flow cut off	Display test	
	n line	Lighting (back lighting)	23
	n line (Multiplex)	See User interface	
Tota	lizer	Display mode	20
В		Additional line	
_	nfiguration (user interface)	Information line	
	action	Information line (Multiplex)	
Block	.tctioii	Display Value	
	c function	2 septiaj - kalao - 11 septiaj - kalao - 12 septiaj - kalao - 12 septiaj - 12 septiaj - 12 septiaj - 12 septiaj	•
	sured variables	E	
	k Setup	ECC (electrode cleaning)	50
Supe	ervision	Cleaning cycle	51
Tota	lizer	Duration	
	interface	Parameter	
	lection	Recovery time	51
Block St	pervision	Electrode cleaning	
С		See ECC EMPTY PIPE DET.	
	IN Value	see Empty pipe detection	
Cascade	iiv value	Empty pipe detection (EPD)	
	ess	Empty/Full pipe adjustment	52
	ne private code	EPD electrode	
	sioning 17	General information	
	nication (Quick Setup)	Response time	49
Configu	ration	Switching on/off	
	tional line	E	
	NDATION Fieldbus	F	<i>.</i> ~
	rmation line	Factory settings	ეკ
	1 line	Failsafe	<i>/</i> 1
	ess parameter	All totalizers	
	or data	F-Chir (version inio)	υZ
Syste	em 58		30

Additional line (Multiplex)	Special units	16
Date and time	System	
Information line	System parameter	
Information line (Multiplex)	System units	
Main line	Version Info	
Main line (Multiplex)		
FOUNDATION FIELDBUS	H	
Function group	Handling Totalizer	41
Additional configuration (system units)	.	
Adjustment52	I	
Amplifier	I/O module type	
Basic configuration (user interface)	IN Value, Cascade	44
Configuration	Information line	
Additional line	Configuration	
FOUNDATION Fieldbus43	Multiplex	35
Information line	Installation direction sensor	
Main line	Integration time	
Operation	17	
Process parameter	K	
Sensor data55	K-factor	
System58	L	
System parameter53	-	
System units	Language	100
Totalizer38	Factory settings (SI units)	
Density parameter	Language group (display)	
Device	Selection	
ECC parameter50	LCD contrast	
EPD parameter	Low flow cut off	46
F-CHIP62	М	
Function blocks		
I/O module	Main line	24
Information	Configuration	
Main values	Multiplex	
Multiplex	Main values	
Additional line	Manufacturer ID	
Information line	Mass flow (calculated)	
Main line	Measured variables (block A)	
Operation	Measuring period, sensor	
System59	Measuring values	
Totalizer	Main values	12
User interface	Multiplex	0.1
Sensor	Additional line	
Unlocking/locking (display)	Information line	
Function matrix	Main line	28
Identification code9	N	
Layout8		
Overview	Nominal diameter	
Overview	0	
G	Off-value	
Group	Low flow cut off	16
Additional line	On-value	40
Control (user interface)22	Low flow cut off	16
FOUNDATION Fieldbus	Operation	40
Handling Totalizer	•	E 4
Information line	Sensor data	
Main line	System	
Measuring values	Totalizer	
Process parameter	User interface	
Sensor data	Operation hours	
ochool data	OUT Value	44

Overflow	Damping 53 Operation 59
P	Operation hours
Positive zero return	Reset
Pressure shock suppression	System condition
Previous system conditions	Actual
Process parameter	Previous
Adjustment	System parameters, configuration
Configuration	System units
ECC parameter 50	Additional configuration
EPD parameter	Configuration
Q	T
Quick Setup	T-DAT save/load
Commissioning	Test display
Quick Setup (Block B)	Totalizer
(210011 2)	Configuration
R	Handling totalizer (Reset, etc.)
Reset	Operation
All totalizers	Reset
System	
Totalizer	Sum (display)
10tmi201 07	Totalizer mode
S	Type I/O Module
Sensor	See I/O module type
Configuration	U
Installation direction	Unit
Measuring period	
Operating data	Density
see Sensor	Length
Version Info	Mass
Zero point	Mass flow
Serial number	Totalizer
	Volume
Measuring device (FF)	Volume flow
Serial number sensor	Unlocking/locking (display)
Setpoint value	User interface
Simulation Failsafe	Language selection
	77
Measurand	V
Simulation, display	Value simulation
Software revision number	Measurand 60
Amplifier	Version Info
I/O module	Amplifier
S-DAT	F-CHIP 62
T-DAT	I/O module
Special filter	Sensor
Special units	Volume flow (display)
Arbitrary unit	***
Density parameter	W
Status access	Write protect
Status F-CHIP	7
Storage	Z
System	Zero point
Configuration	

Contents (FOUNDATION Fieldbus)

I	Operation via FOUNDATION Fieldbus 73
1.1	Block model
2	Resource Block
2.1 2.2 2.3 2.4 2.5	Selecting the operating mode75Block status75Write protection and simulation76Alarm detection and processing76Parameters of the Resource Block77
3	Transducer Block 78
3.1 3.2 3.3 3.4 3.5 3.6	Signal processing
4	Function blocks 118
5	Analog Input function block 119
5.1 5.2	Signal processing
6	Discrete Output Function block 126
6.1 6.2	Signal processing
7	Additional function blocks 129
8	Factory settings
8.1 8.2	SI units (not for USA and Canada)

1 Operation via FOUNDATION Fieldbus

1.1 Block model

In the FOUNDATION Fieldbus all the device parameters are categorized according to their functional properties and task and are generally assigned to three different blocks. A block may be regarded as a container in which parameters and the associated functionalities are contained. A FOUNDATION Fieldbus device has the following block types:

■ A Resource Block

The Resource Block contains all the device-specific characteristics of the device.

• One or more Transducer Blocks (transmission blocks)
The Transducer Block contains all the measuring technology and device-specific parameters of the device. The measurement principles (e.g. flow, temperature) are depicted in the Transducer Blocks in accordance with the FOUNDATION Fieldbus specification.

One or more function blocks

Function blocks contain the automation functions of the device. We distinguish between different function blocks, e.g. Analog Input function block, Analog Output function block, PID function block (PID controller), etc. Each of these function blocks is used to process different application functions.

Different automation tasks can be realized depending on the arrangement and connection of the individual blocks. In addition to these blocks, a field device may have any number of other blocks, e.g. several Analog Input function blocks if more than one process variable is available from the field device.

Blocks used by the ProdType:

- One Resource Block
- Four Transducer Blocks
- Eleven function blocks comprising:
 - Five Analog Input function blocks for the process variables volume flow, calculated mass flow and totalizer 1 to 3.
 - One Discrete Output function block
 - One PID function block (PID controller)
 - One Arithmetic function block
 - One Input Selector function block
 - One Signal Characterizer function block
 - One Integrator function block




Fig. 1: Promag 53 FOUNDATION Fieldbus blocks

A0006559-EN

The sensor signal is first prepared specifically for the flow in the measuring block (the **Transducer Block**). The process variables are then passed to the **Analog Input function blocks** for control-related processing (e.g. scaling, limit value processing).

The process variables go through the complete function block algorithm and are available to other function blocks, e.g. the PID block, as a starting variable for connecting the desired application function.

Using the Discrete **Output function block (DO)**, various actions and functions can be initiated and controlled via FOUNDATION Fieldbus in the Device Functions Proline Promag 53 FOUNDATION Fieldbus.



Note!

Other function blocks such as the PID, Arithmetic, Input Selector, Signal Characterizer and Integrator function block are described in the "FOUNDATION Fieldbus Overview" (BA013S) Operating Instructions (acquired at: \rightarrow www.endress.com \rightarrow Download).

2 Resource Block

A Resource Block contains all the data that uniquely identifies and characterizes the field device. It is an electronic version of a nameplate on the field device. Parameters of the Resource Block include device type, device name, manufacturer ID, serial number, etc.

A further task of the Resource Blocks is the management of overall parameters and functions that have an influence on the execution of the remaining blocks in the field device. The Resource Block is thus the central unit that also checks the device status and thereby influences or controls the operability of the other blocks and thus also of the device. Since the Resource Block has no block input and block output data, it cannot be linked with other blocks.

The major functions and parameters of the Resource Block are listed below; you will find an overview of all the available parameters starting on Page 77.

2.1 Selecting the operating mode

The operation mode is set by means of the MODE_BLK parameter group. The Resource Block supports the following operating modes:

- AUTO (automatic mode)
- OOS (out of service)



Note!

The block status OOS is also shown via the parameter BLOCK_ERR. In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

2.2 Block status

The current operating status of the Resource Block is shown in the parameter RS_STATE.

The Resource Block can take on the following states:

- STANDBY The Resource Block is in OOS operating mode.

The remaining blocks cannot be executed.

- ONLINE LINKING The connections configured between the function blocks have not

yet been linked.

- ONLINE Normal operating status; the Resource Block is in operating mode

AUTO. The configured connections between the function blocks

have been established.

2.3 Write protection and simulation

Write protection of the device parameters and simulation in the Analog Input and Discrete Output function block can be locked or unlocked via a jumper setting on the FOUNDATION Fieldbus I/O board (\rightarrow Operating Instructions for Proline Promag 53 FOUNDATION Fieldbus, BA126D).

The parameter WRITE_LOCK shows the status of the hardware write protection. The following statuses are possible:

LOCKED = Device data cannot be modified by means of the FOUNDATION

Fieldbus interface.

- NOT LOCKED = Device data can be modified by means of the FOUNDATION

Fieldbus interface.

The parameter BLOCK_ERR indicates whether a simulation is possible in the Analog Input and Discrete Output function block.

- Simulation Active = Simulation possible in the Analog Input function block via the

SIMULATE parameter and in the Discrete Output function block via

the SIMULATE_D parameter.

2.4 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK_ALM. The parameter ACK_OPTION specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Resource Block:

Block process alarms

The following block process alarms of the Resource Block are shown via the parameter BLOCK_ALM:

- OUT OF SERVICE
- SIMULATE ACTVE

Write protect process alarm

If write protection is disabled on the FOUNDATION Fieldbus I/O board, then prior to communicating the change of status to the fieldbus host system the alarm priority specified in the parameter WRITE_PRI is checked. The alarm priority specifies the action taken when the write protection alarm WRITE_ALM is enabled.



Note!

- If the option of a process alarm has **not** been enabled in the parameter ACK_OPTION, this process alarm only has to be acknowledged in the parameter BLOCK_ALM.
- The parameter ALARM_SUM shows the current status of all the process alarms.

2.5 Parameters of the Resource Block

The following table shows all the Endress+Hauser-specific parameters of the Resource Block.



Note

FOUNDATION Fieldbus parameters are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor - Serial Number	read only	Use this function to view the sensor serial number.
Amp HW Rev.Number	read only	Use this parameter to view the hardware revision number of the amplifier.
Amp HW Identification	read only	Use this parameter to view the hardware ID number of the amplifier.
Amp SW Rev.Number	read only	Use this function to view the software revision number of the amplifier.
Amp SW Identification	read only	Use this parameter to view the software ID number of the amplifier.
Amp ProdNumber	read only	Use this parameter to view the production number of the amplifier.
Amp SW-Rev.No. T-DAT	read only	Use this parameter to view the software revision number of the software used to create the content of the T-DAT.
Amp Language Group	read only	Use this function to view the language group.
I/O - Type	read only	Use this function to view the I/O module type.
I/O - HW Rev. Number	read only	Use this parameter to view the hardware revision number of the I/O module.
I/O - HW Identification	read only	Use this parameter to view the hardware ID number of the I/O module.
I/O - SW Rev. Number	read only	Use this parameter to view the software revision number of the I/O module.
I/O - SW Identification	read only	Use this parameter to view the software ID number of the I/O module.
I/O - Prod.Number	read only	Use this parameter to view the production number of the I/O module.

3 Transducer Block

The Transducer Blocks contain all the measurement– and device–specific parameters of the flowmeter. All the settings directly connected with the flow measurement/application are made here. They form the interface between the sensor–specific measured value preprocessing and the Analog Input function blocks required for automation.

A Transducer Block allows you to influence the input and output values of a function block. The parameters of a Transducer Block include information on the sensor type, sensor configuration, physical units, calibration, damping, diagnosis, etc. as well as the device-specific parameters. The device-specific parameters and functions are split into several Transducer Blocks that cover different task areas.

"Flow" Transducer Block/base index 1400:

This Block contains all the flow-specific parameters and functions, e.g. calibration functions, sensor data etc. \rightarrow Page 82

"Diagnosis" Transducer Block/base index 1600:

This Block contains all the parameters for system diagnosis, e.g. current system condition etc. \rightarrow Page 97

"Display" Transducer Block/base index 1800:

This Block contains all the parameters for the configuration of the local display \rightarrow Page 101

"Totalizer" Transducer Block/base index 1900:

This Block contains all the parameters for the configuration of the totalizers \rightarrow Page 115

3.1 Signal processing

The following figure shows the internal structure of the individual Transducer Blocks:




Fig. 2: Internal structure of the individual Transducer Blocks

The "Flow" Transducer Block receives a signal variable (volume) from the sensor as the input signal. The amplifier converts this input signal to volume flow. The amplifier calculates the current mass flow via the "Density Param. - Fixed Value" parameter (\rightarrow Page 94) by deriving the value from the measured volume flow.

Optionally, the empty pipe detection function can be adjusted and switched on or off by means of the EPD parameter group.

The parameter "Simulate - Value Measurand" (\rightarrow Page 95) allows you to specify a simulation value in order to test assigned parameters in the device and downstream function blocks. The process variable (volume or mass flow) to be simulated is selected by means of the "Simulation - Measurand" parameter (\rightarrow Page 95).

The parameter "Low Flow Cut Off - On-Value" (see \rightarrow Page 87) allows you to define a limit value for low flow cut off. If the measured flow value is below this limit value then the output value of 0 is output.

In addition, the parameter "Sys. - Positive Zero Return" (\rightarrow Page 86) allows you to switch the measured value to "Zero Flow". This is necessary when a piping system is being cleaned, for example.

The "Flow" Transducer Block makes the process variables volume and mass flow available to the downstream function blocks. Depending on these two process variables, the "Totalizer" Transducer Block derives the integrated measured variables Totalizer 1 to 3 which are then also made available as a process variable at the output for further processing. In addition, the totalizers are also configured in this Block; for example all totalizers can be reset simultaneously by means of the "Tot. – Reset All" parameter (\rightarrow Page 117 ff.).

The "Diagnosis" Transducer Block comprises all the parameters and functions necessary for the diagnosis and maintenance of the device. For example, the "Diag. – Act.Sys.Condition" parameter displays the current system condition or, if an error occurs, provides a detailed reason for the error (\rightarrow Page 97 ff.).

If the measuring device is equipped with a local display, various display parameters can be configured by means of the "Display" Transducer Block, e.g. display language, contrast etc. (\rightarrow Page 101 ff.).

The "Diagnosis" and "Display" Transducer Blocks do not have any output variables, i.e. they only affect the measuring device itself.

The primary functions and parameters of the Transducer Blocks are listed below. You will find an overview of all the available Endress+Hauser-specific parameters starting on \rightarrow Page 82 ff.

3.2 Important functions and parameters of the Transducer Blocks

3.2.1 Block output values

The Transducer Blocks make the following output variables (process variables) available:

- "Flow" Transducer Block:
 - Calculated mass flow
 - Volume flow
- "Totalizer" Transducer Block
 - Totalizer 1
 - Totalizer 2
 - Totalizer 3
- The "Diagnosis" and "Display" Transducer Blocks do not have any output variables.

The CHANNEL parameter in the Analog Input function block is used to assign which process variable is read in and processed in the downstream Analog Input function block:

Process variable calculated mass flow
 Process variable volume flow
 Process variable totalizer 1
 Process variable totalizer 2
 Process variable totalizer 3
 → CHANNEL 1 (Analog Input function block)
 → CHANNEL 7 (Analog Input function block)
 → CHANNEL 8 (Analog Input function block)
 → CHANNEL 9 (Analog Input function block)

3.2.2 Selecting the operating mode

The operation mode is set by means of the MODE_BLK parameter group. The Transducer Blocks support the following operation modes:

- AUTO (automatic mode)
- OOS (out of service)



Note!

- The block status OOS is also shown via the parameter BLOCK_ERR. In operating mode OOS, if write protection is not enabled and the access code is entered, you can access all the write parameters without restriction.
- The following applies for the "Flow" and "Totalizer" Transducer Blocks: With the "OOS" operating mode, the process variables are updated but the status of the output value OUT (AI Block) changes to "BAD".
- If problems occur during the configuration of the function blocks \rightarrow see Operating Instructions for Promag 53 FF (BA126D), "Troubleshooting" section.

3.2.3 Alarm detection and processing

The Transducer Blocks do not generate any process alarms. The status of the process variables is evaluated in the downstream Analog Input function blocks. If the Analog Input function block does not receive an input value that can be evaluated from the "Flow" or "Totalizer" Transducer Blocks, then a process alarm is generated. This process alarm is displayed in the BLOCK_ERR parameter of the Analog Input function block (BLOCK_ERR = Input Failure).

The parameter BLOCK_ERR of the Transducer Blocks displays the device error that produced the input value that could not be evaluated and thus triggered the process alarm in the Analog Input function block.

In addition, the active device error is displayed via the "Diagnosis" Transducer Block in the "Diagnosis - Act.Sys. Condition" parameter (\rightarrow Page 97).

For further information on rectifying errors \rightarrow see Operating Instructions for Promag 53 FF (BA126D), "Troubleshooting" section.

3.2.4 Diagnosis

The status of the device is displayed via the following parameters specified in the FOUNDATION Fieldbus specification:

- BLOCK ERR
- Transducer Error

More detailed information on the current device status is displayed via the "Diagnosis" Transducer Block in the manufacturer-specific parameter "Diag. - Act.Sys. Condition" (\rightarrow Page 97).

For further information on rectifying errors \rightarrow see Operating Instructions for Promag 53 FF (BA126D), "Troubleshooting" section.

3.2.5 Accessing the device-specific parameters

To access the device-specific parameters the following requirements must be met:

- 1. Hardware write protection must be deactivated \rightarrow see Operating Instructions for Proline Promag 53 FOUNDATION Fieldbus (BA126D).
- 2. The correct code must be entered by means of the corresponding Transducer Block in the "Access Code" parameter.

3.3 Parameters of the "Flow" Transducer Block

The following table shows all the Endress+Hauser-specific parameters of the "Flow" Transducer Block. These can only be changed after entering an enabling code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

	"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Access - Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified. You can enable programming by entering: ■ Code 53 (factory setting) ■ Personal code (→ Page 102) User input: Max. 4-digit number (0 to 9999) Note! ■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ see Operating Instructions for Promag 53 FF, BA126D). ■ You can disable programming again by entering any number (other than the access code) in this parameter. ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code. ■ Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification. ■ The entry made here does not affect the local display. Thus, programming via the function matrix must be enabled separately.	
Access - Status	read only	Use this parameter to display the current status of the possibilities for accessing the manufacturer-specific parameters of the device. User interface: LOCKED (parameterization disabled) ACCESS CUSTOMER (parameterization enabled) ACCESS SERVICE (parameterization enabled, access to service level)	

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Value - Volume Flow	read only	Use this parameter to view the current volume flow. The volume flow is made available as a process variable to the downstream Analog Input function blocks.
		Note! The unit is displayed in the "System Unit - Volume Flow" parameter ($ ightarrow$ Page 83).
System Unit - Volume Flow	AUTO - OOS	Use this parameter to select the unit for the volume flow (volume/time). The unit you select here is also valid for: Simulation Low flow cut off Display value (local display) Options: Metric: Cubic centimeter → cm³/s; cm³/min; cm³/h; cm³/day Cubic decimeter → dm³/s; dm³/min; dm³/h; dm³/day Cubic meter → m³/s; m³/min; m³/h; m³/day Milliliter → ml/s; ml/min; ml/h; ml/day Liter → l/s; l/min; l/h; l/day Hectoliter → hl/s; hl/min; hl/h; hl/day Megaliter → Ml/s; Ml/min; Ml/h; Ml/day US: Cubic centimeter → cc/s; cc/min; cc/h; cc/day Acre foot → af/s; af/min; af/h; af/day Cubic foot → ft³/s; ft³/min; ft³/h; ft³/day Fluid ounce → oz f/s; oz f/min; oz f/h; oz f/day Gallon → gal/s; gal/min; gal/h; gal/day Kilo gallon → Kgal/s; Kgal/min; Kgal/h; Kgal/day Million gallon → Mgal/s; Mgal/min; Mgal/h; Mgal/day Barrel (beer: 31.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (petrochemicals: 42.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (filling tanks: 55.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl/h; bbl/h; bbl/day Barrel (beer: 36.0 gal/bbl) → bbl/s; bbl/min; bbl/h; bbl
System Value - Mass Flow	read only	AI Block in the XD_SCALE parameter group. Use this function to view the calculated mass flow. The mass flow is derived from the measured volume flow and the fixed density value (→ Page 94). The calculated mass flow is made available as a process variable to the downstream Analog Input function blocks. Note! The unit is displayed in the "System Unit - Mass Flow" parameter

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Unit - Mass Flow	AUTO - OOS	Use this parameter to select the unit for the mass flow (mass/time). The unit you select here is also valid for: Simulation Low flow cut off Display value (local display) Options: Metric: gram → g/s; g/min; g/h; g/day kilogram → kg/s; kg/min; kg/h; kg/day Metric ton → t/s; t/min; t/h; t/day US: ounce → oz/s (US); oz/min (US); oz/h (US); oz/day (US) Pound → lb/s; lb/min; lb/h; lb/day
System Value - Fixed Density	read only	Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! The unit selected here does not have any effect on the desired mass flow unit which should be transmitted by means of the FOUNDATION Fieldbus interface. This setting is made separately by means of the corresponding AI Block in the XD_SCALE parameter group. Use this function to view the set density. This density value can be modified by means of the "Density Param Fixed Value" parameter (→ Page 94). Factory setting: Note! The unit is displayed in the "System Unit - Fixed Density" parameter
System Unit - Fixed Density	AUTO - OOS	Use this parameter to select the unit for displaying the fluid density. The unit you select here is also valid for: ■ Density entry "Density Param Fixed Value", → Page 94) Options: Metric → g/cm³; g/cc; kg/dm³; kg/l; kg/m³; SD 4 °C, SD 15 °C, SD 20 °C; SG 4 °C, SG 15 °C, SG 20 °C; g/l US → lb/ft³; lb/gal; lb/bbl (normal fluids); lb/bbl (beer); lb/bbl (petrochemicals); lb/bbl (filling tanks) Imperial → lb/gal; lb/bbl (beer); lb/bbl (petrochemicals) Factory setting: kg/l (SI units: not for USA and Canada) g/cc (US units: only for USA and Canada) SD = Specific Density, SG = Specific Gravity The specific density is the ratio of fluid density to water density (at water temperature = 4, 15, 20 °C).

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
System Unit - Length	AUTO - OOS	Use this parameter to select the unit for displaying the length of the nominal diameter.
		The unit you select here is also valid for: Nominal diameter of sensor ("Sensor Data - Nominal Diameter", → Page 94)
		Options: MILLIMETER INCH
		Factory setting: MILLIMETER (SI units: not for USA and Canada) INCH (US units: only for USA and Canada)
Sys Install. Direction Sensor	AUTO - OOS	Use this parameter to reverse the sign of the flow measured variable, if necessary.
		Options: NORMAL FORWARD (flow as indicated by the arrow) INVERSE REVERSE (flow opposite to direction indicated by the arrow)
		Factory setting: NORMAL FORWARD
		Note! Ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor (nameplate).
Sys System Damping	AUTO - OOS	Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The reaction time of the measuring system increases with every increase in the filter setting. The damping acts on all parameters and on all downstream function blocks.
		User input: 015
		Factory setting: 7
		Note! The system damping acts on all functions and outputs of the measuring device.
Sys Integration Time	AUTO - OOS	Use this function to view the set integration time.
Time		The integration time defines the duration of internal totaling of the induced voltage in the fluid (measured by the measuring electrode), i.e. the time in which the measuring device records the true flow (afterwards the magnetic field for the next integration is created from the opposite pole).
		User interface: Max. 2-digit number: 1 to 65 ms
		Factory setting: 5 ms

	"Flow	" Transducer Block/base index 1400
Parameter	Write access with operating mode (MODE_BLK)	Description
Sys Positive Zero Return	AUTO - OOS	Use this parameter to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all parameter and calculations of the measuring device. Options: Off (signal output not interrupted) ON (signal output is set to the value for "Positive zero return" or "Zero flow") Factory setting: OFF Note! If positive zero return is active, a flow value of "0" is output via the output value OUT (AI Block). Active positive zero return is relayed to downstream function blocks or higher-order process control systems by means of the status UNCERTAIN of the output value OUT (AI Block). Positive zero return can also be controlled using cyclic data transfer via the Discrete Output function block.
Sys Special Filter	AUTO - OOS	There is the option of activating two signal filters in this parameter. These filters make it possible to either suppress the signal caused by severely fluctuating flows (STANDARD option) or to reproduce it completely – both on the display and at the FOUNDATION Fieldbus output (DYNAMIC FLOW option). Options: STANDARD For signal output with normal, stable flow. DYNAMIC FLOW For signal output with severely fluctuating or pulsating flow. Factory setting: STANDARD Caution! The signal behavior at the outputs also depends on the "SysFlow Damping" parameter. Additional filter settings (e.g. STANDARD CIP or DYNAMIC FLOW CIP) can only be selected with the aid of a special service code. Such settings, which are normally made by a service technician, are deleted, however, when the private code is entered again and can then no longer be activated!
Sys CIP Samples	AUTO - OOS	This parameter is only used in the event of a service.
Sys Permanent Storage	read only	This parameter indicates whether permanent saving of all parameters in the EEPROM is switched on or off. User interface: OFF ON Factory setting: ON

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
Low Flow Cut Off - Assign	AUTO - OOS	Use this parameter to assign the switch point for the low flow cut off. Options: OFF VOLUME FLOW MASS FLOW
Low Flow Cut Off - On Value	AUTO - OOS	Factory setting: VOLUME FLOW Use this function to specify the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0.
		User input: 5-digit floating-point number [unit] Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! When the low flow cut off is triggered, a flow value of "0" is output via the output value OUT (AI Block). In addition, the status changes to UNCERTAIN. Choice of unit: see "Low Flow Cut Off - Unit" parameter (→ Page 87).
Low Flow Cut Off - Unit	read only	Use this parameter to view the unit for the low flow cut off.
Low Flow Cut Off - Off Value	AUTO - OOS	Use this function to enter the switch-off point (b) for low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a). User input: Integer 0 to 100% Factory setting: 50% Q 2 2 3 4 4 4 4 A0003882 Description: According to the switch-off point a low flow cut off is switched on b low flow cut off is switched off (a + a · H) H Hysteresis value: 0 to 100% Low flow cut off active Q Flow

	"Flow	" Transducer Block/base index 1400
Parameter	Write access with operating mode (MODE_BLK)	Description
Process - Pressure Shock Suppression	mode	The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions". Note! Note that pressure shock suppression cannot be used unless the low flow cut off is active (see the "Low Flow Cut Off - On Value" parameter → Page 87). Use this function to define the time span for active pressure shock suppression. Activation of pressure shock suppression Pressure shock suppression is activated once the flow falls below the switch-on point of the low flow cut off (see point a in graphic). While pressure shock suppression is active, the following conditions apply: Flow reading on display → 0 Totalizer reading → The totalizers are pegged at the last correct value. Deactivation of pressure shock suppression The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point b). Note! The actual flow value is displayed and output, when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point c in graphic).
		Max. 4-digit number, incl. unit: 0.00 to 100.0 s Factory setting: 0.00 s

	"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description	
EPD - Adjustment	AUTO - OOS	Use this parameter to perform EPD adjustment for an empty or full measuring tube. Options: OFF FULL PIPE ADJUST EMPTY PIPE ADJUST Factory setting: OFF Procedure for empty pipe / full pipe adjustment 1. Make sure that hardware write protection is switched off (→ see Operating Instructions for Promag 53 FF, BAO126). 2. In the configuration program, open the "Flow" Transducer Block. 3. Enable the configuration or the device by means of the "Access - Code" parameter (→ Page 82). Check the status by means of the "Access - Status" parameter → ACCESS CUSTOMER (→ Page 82). 4. Empty the pipe. For the following empty pipe adjustment, the wall of the measuring tube should still be wetted with fluid. 5. Start empty pipe adjustment: In this parameter, select the " EMPTY PIPE ADJUST" setting and start empty pipe adjustment by sending the setting to the field device. 6. After empty pipe adjustment, fill the piping with fluid. 7. Start full pipe adjustment with fluid at a standstill: In this parameter, select the " FULL PIPE ADJUST" setting and start full pipe adjustment by sending the setting to the field device. 8. Having completed the adjustment, select the setting "OFF" and exit the function by sending the setting to the field device. 8. Having completed the adjustment, select the setting "OFF" and exit the function by sending the setting to the field device. 9. Select "EPD — Empty Pipe Detection" parameter (→ Page 90) and switch on empty pipe detection by selecting the setting "ON". Caution! The adjustment values must be valid before you can switch on the EPD function. If calibration is faulty, the following messages are output in the "Diagnosis" Transducer Block via the "Diag. – Act.Sys.Condition" parameter (→ Page 97): ■ EPD adjustment wrong – Err. No. 463: The adjustment wrong – Err. No. 463: The adjustment wrong – Err. No. 461: Adjustment is not possible as the fluid conductivity values are outside the permitted range. This error is relayed to downstream function blocks or higher-order proces	

	"Flow	" Transducer Block/base index 1400
Parameter	Write access with operating mode (MODE_BLK)	Description
EPD - Empty Pipe Detection	AUTO - OOS	This status can be monitored at all times with the Empty Pipe Detection function. To do this, the empty pipe detection (EPD, empty pipe detection by means of EPD electrode) can be activated in this function:
		Options: OFF ON STANDARD
		Factory setting: OFF
		 Note! The option ON STANDARD is not available unless the sensor is equipped with an EPD electrode (see "EPD - Electrode" parameter, → Page 91). The default setting for the EPD function when the device is delivered is OFF. The function must be activated as required. The devices are already calibrated at the factory with water (approx. 500 μS/cm). If the conductivity of certain fluids deviates from this reference, empty pipe/full pipe adjustment must be performed again on site (see "EPD - Adjustment" parameter → Page 89). The adjustment coefficients must be valid before you can switch on the EPD function (see "EPD - Adjustment" → Page 89). If there are problems with the adjustment, the following error messages appear on the screen: EPD adjustment wrong - Err. No. 463: The adjustment values for empty pipe and full pipe are identical. In such instances, empty pipe adjustment/full pipe adjustment must be carried out again. EPD adjustment not possible - Err. No. 461:
		Notes on empty pipe detection (EPD) Flow cannot be measured correctly unless the measuring tube is completely full. This status can be monitored at all times with the EPD function. An empty or partially filled pipe is a process error. A default factory setting defines that a notice message is issued and that this process error has no effect on the outputs. A plausibility check of the adjustment values will only be executed by activating the empty pipe detection. If an empty or full pipe adjustment is performed when empty pipe detection is active, the empty pipe detection has to be deactivated and activated again after finishing the adjustment in order to start the plausibility check. Response to partially filled pipes If the EPD function is switched on and is triggered by a partially empty or completely empty pipe, this is indicated in the "Diag Act.Sys.Condition" parameter (→ Page 97) of the "Diagnosis" Transducer Block with the error message "Empty Pipe detected - Err. No. 401". This process error is relayed to downstream function blocks or higher-order process control systems by means of the status "UNCERTAIN" of the output value OUT (AI Block). If the pipe is partially empty and the EPD is not switched on, the response can vary in identically configured systems: Flow reading fluctuates Zero flow Excessively high flow values

	"Flow	" Transducer Block/base index 1400
Parameter	Write access with operating mode (MODE_BLK)	Description
EPD - Response Time	AUTO - OOS	Use this parameter to enter the time span in which the criteria for an empty pipe have to be satisfied without interruption before an error message is generated. User input: fixed point number: 1.0 to 100 s Factory setting:
EPD - Threshold	read only	1.0 s This parameter is only used in the event of a service.
EPD - Electrode	AUTO - OOS	Use this parameter to check whether the sensor is equipped with an EPD electrode. User interface: YES - NO Factory setting:
EDD E . D'	. 1 . 1	YES → Electrode fitted as standard
EPD - Empty Pipe Coef.	read only	This parameter is only used in the event of a service.
EPD - Full Pipe Coef.	read only	This parameter is only used in the event of a service.
OED - Period	read only	This parameter is only used in the event of a service.
OED - Empty Value	read only	This parameter is only used in the event of a service.
OED - Full Value	read only	This parameter is only used in the event of a service.
System Option - ECC	read only	This parameter is only used in the event of a service.

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
ECC	AUTO - OOS	Note! This function is only available if the measuring device is equipped with an electrode cleaning function (optional). Use this function to enable cyclic electrode cleaning (ECC). Options: ON (only with the optional electrode cleaning function ECC) OFF Factory setting: ON (only if the optional electrode cleaning function ECC is available) Notes on electrode cleaning (ECC) Conductive deposits on the electrodes and on the walls of the measuring tube (e.g. magnetite) can falsify measurement values. The Electrode Cleaning Circuitry (ECC) was developed to prevent such conductive deposits accreting in the vicinity of the electrodes. ECC functions as described above for all available electrode materials except tantalum. If tantalum is used as the electrode material, the ECC protects the electrode surface only against oxidation. Caution! If the ECC is switched off for a prolonged period in applications with conductive deposits, a layer forms inside the measuring tube and this can falsify measurement values. If the layer is allowed to accrete beyond a certain level, it might no longer be possible to remove it by switching on the ECC. If this happens the measuring tube must be cleaned and the layer removed.
ECC - Duration	AUTO - OOS	Note! This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC). Use this function to specify the electrode cleaning duration. User input: Fixed-point number: 0.01 to 30.0 s Factory setting: 2.0 s

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
ECC - Recovery Time	AUTO - OOS	Note! This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC). Use this function to specify the recovery time for which the last flow value measured prior to cleaning is retained. A recovery time is necessary as the signal outputs can fluctuate after electrode cleaning on account of
		electrochemical interference voltages. User input: Max. 3-digit number: 1 to 600 s Factory setting:
		Caution! The last value measured prior to cleaning is output for the duration of the recovery time (max. 600 s). This in turn means that the measuring system does not register changes in flow, e.g. stoppage, during this time span.
ECC - Cycle	AUTO - OOS	Note! This function is not available unless the measuring device is equipped with the optional electrode cleaning function (ECC). Use this function to specify the cleaning cycle for electrode cleaning.
		User input: Integer: 30 to 10080 min Factory setting:
ECC - Polarity	read only	Use this function to display the actual current polarity for optional electrode cleaning (ECC). Electrode cleaning uses either a positive or negative current, depending on the electrode material. The measuring device automatically selects the correct polarity on the basis of the electrode material data stored in the S-DAT.
		User interface: POSITIVE For electrodes made of 1.4435/316L, Alloy C-22, platinum, titanium, tungsten carbide coating (for electrodes made of 1.4435), 1.4310/302. NEGATIVE
		For electrodes made of tantalum. Caution! If the incorrect current is applied to the electrodes, the electrode material is destroyed.

	"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Density Param Fixed Value	AUTO - OOS	Use this parameter to enter a density factor (preferably at process temperature or reference temperature) which is used to convert the volume flow to a mass flow. Note! The unit is taken from the "Density Param Unit" parameter (→ Page 94). User input: 5-digit floating-point number Factory setting: 1 [unit]	
Density Param Unit	read only	Use this function to display the unit selected in the "System Unit - Fixed Density" parameter for the fixed density value (\rightarrow Page 84).	
Sensor Data - K-Factor	AUTO - OOS	Use this function to display the actual calibration factor (positive and negative flow direction) for the sensor. The calibration factor is determined and set at the factory. User interface: 5-digit fixed point number: 0.5000 to 2.0000 Factory setting: Depends on nominal diameter and calibration	
Sensor Data - Zero Point	AUTO - OOS	Use this function to view the actual zero-point correction value for the sensor. Zero-point correction is determined and set at the factory. User interface: Max. 4-digit number: -1000 to +1000 Factory setting: Depends on nominal diameter and calibration	
Sensor Data - Nominal Diameter	AUTO - OOS	Use this function to view the nominal diameter of the sensor. The nominal diameter depends on the size of the sensor and is set at the factory. User interface: 2 to 2000 mm or 1/12 to 78" Factory setting: Depends on the size of the sensor	

"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Data - Measuring Period	AUTO - OOS	Use this function to view the measuring period. The duration of the measuring period is calculated from the rise time of the magnetic field, the brief recovery time, the integration time and the empty pipe detection time. User interface: Max. 4-digit number: 10 to 1000 ms Factory setting: Depends on nominal diameter Note! The system checks the time entered and sets the measuring period which is actually used internally to a plausible value. If you enter 0 ms, the system automatically computes the shortest time.
Sensor Data - Overvoltage Time	read only	This parameter is only used in the event of a service.
Simulation - Measurand	AUTO - OOS	Use this parameter to activate the simulation of the volume flow/mass flow. Options: OFF VOLUME FLOW MASS FLOW Factory setting: OFF Caution! The measuring device cannot be used for measuring while this simulation is in progress. The simulation acts independently of the position of the jumpers on the I/O board (→ see Operating Instructions for Promag 53 FF, BA126D). The setting is not saved if the power supply fails. Note! Active simulation is relayed to downstream function blocks or higher-order process control systems by means of the status UNCERTAIN of the output value OUT (AI Block).
Simulation - Value Measurand	AUTO - OOS	Use this parameter to specify a selectable value (e.g. 12 m³/s). This is used to test the associated parameters in the device itself and downstream signal loops. User input: 5-digit floating-point number Factory setting: 0 [unit] Note! The unit is taken from the "System Unit - Volume Flow" or "System Unit - Mass Flow" parameter (→ Page 83 ff.). Caution! The setting is not saved if the power supply fails.

	"Flow" Transducer Block/base index 1400		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Simulation - Unit	read only	Use this parameter to display the current unit for the simulation value in the "Simulation - Measurand Value" parameter. Note! The unit can be selected in the "System Unit - Volume Flow" or "System Unit - Mass Flow" parameter (→ Page 83).	
Service/Analys Measuring Period	read only	This parameter is only used in the event of a service.	
Service/Analys Risetime	read only	This parameter is only used in the event of a service.	
Service/Analys Electrode Pot. 1	read only	This parameter is only used in the event of a service.	
Service/Analys Electrode Pot. 2	read only	This parameter is only used in the event of a service.	
Sensor - Type	read only	Use this function to view the sensor type.	
Sensor - SW Rev.No.S-DAT	read only	Use this function to view the software revision number of the software used to create the content of the S-DAT.	
Sensor - HW Rev.Number.	read only	Use this parameter to view the hardware revision number of the sensor.	
Sensor - HW Identification	read only	Use this parameter to view the hardware ID number of the sensor.	
Sensor - Prod.Number	read only	Use this parameter to view the production number of the sensor.	
Amp. Device Type	read only	This parameter is only used in the event of a service.	

3.4 Parameters of the "Diagnosis" Transducer Block

The following table shows all the Endress+Hauser-specific parameters of the "Diagnosis" Transducer Block. These can only be changed after entering an enabling code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

	"Diagnosis" Transducer Block/base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Diag Act. Sys. Condition	read only	Displays the current system status. Note! An exact error description as well as information on rectifying errors can be found in the Operating Instructions for Promag 53 FF (BA126D).	
Diag Prev. Sys. Condition	read only	Displays the last error message that occurred.	
Access - Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified. You can enable programming by entering: ■ Code 53 (factory setting) ■ Personal code (→ Page 102) User input: Max. 4-digit number (0 to 9999) Note! ■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ see Operating Instructions for Promag 53 FF, BA126D). ■ You can disable programming again by entering any number (other than the access code) in this parameter. ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code. ■ Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification. ■ The entry made here does not affect the local display. Thus, programming via the function matrix must be enabled separately.	
Access - Status	read only	Use this parameter to display the current status of the possibilities for accessing the manufacturer-specific parameters of the device. User interface: LOCKED (parameterization disabled) ACCESS CUSTOMER (parameterization enabled) ACCESS SERVICE (parameterization enabled, access to service level)	

	"Diagnos	sis" Transducer Block/base index 1600
Parameter	Write access with operating mode (MODE_BLK)	Description
Sys Alarm Delay	AUTO - OOS	Use this parameter to define a time span in which the criteria for a fault have to be satisfied without interruption before a fault or notice message is generated. Depending on the setting and the type of fault, this suppression acts on: Display Output blocks (AI Blocks) FOUNDATION Fieldbus interface User input: 0 to 100 s (in steps of one second) Factory setting: 0 s Caution! If this parameter is used, fault and notice messages are delayed by the time corresponding to the setting before being forwarded to the downstream function blocks or the fieldbus host system. It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If fault and notice messages cannot be suppressed, a value of 0 seconds must be entered here.
Sys Sim. Failsafe Mode	AUTO - OOS	Use this parameter to set the Analog Input and Totalizer function blocks to their defined failsafe modes in order to check whether they respond correctly. The failsafe mode of the totalizers is determined via the "Tot Failsafe All" parameter (→ Page 117). Options: OFF ON Factory setting: OFF Note! The active simulation mode is relayed to downstream function blocks or higher-order process control systems by means of the status "UNCERTAIN" of the output value OUT (Al Block).
Sys Reset	AUTO - OOS	Use this parameter to perform a reset of the measuring system. Options: NO RESTART SYSTEM (restart without interrupting power supply) ORIGINAL TRANSMITTER DATA Factory setting: NO

	"Diagnos	sis" Transducer Block/base index 1600
Parameter	Write access with operating mode (MODE_BLK)	Description
Sys Troubleshooting	AUTO - OOS	Use this parameter to rectify errors occurring in the EEPROM. The EEPROM is split into a number of blocks. The error is rectified by selecting the block in question and acknowledging. Caution! When eliminating faults in a block, the parameters of the block selected are also reset to the factory setting. Options: CANCEL MEASURING VALUES SYSTEM UNITS DENSITY PARAMETERS OUICK SETUP USER INTERFACE TOTALIZER COMMUNICATION PROCESSPARAMETER SYSTEM PARAMETER SYSTEM PARAMETER SENSOR DATA BATCH FUNCTION ADVANCED DIAGNOSIS AMPLIFIER PARAMETERS SUPERVISION VERSION-INFO SERVICE & ANALYSIS PRODUCTION INFO FILTER PARAMETER Factory setting: CANCEL
Sys Operation Time	read only	Use this function to view the total operating time since the flowmeter was commissioned (in seconds).
Sys Time Since Reset	read only	This parameter is only used in the event of a service.

"Diagnosis" Transducer Block/base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sys T-DAT Save/Load	AUTO - OOS	Use this parameter to save the parameter settings/configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (manual backup function). Application examples: • After commissioning, the actual measuring point parameters can be saved to the T-DAT as a backup. • If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM). Options: CANCEL SAVE (from EEPROM to T-DAT) LOAD (from the T-DAT into EEPROM) Factory setting: CANCEL • Note! • If the target device has an older software version, the message "TRANSM. SW-DAT" is displayed during startup. Then only the SAVE option is available. • LOAD This option is only possible if: - The target device has the same software version as, or a more recent software version than, the source device or - The T-DAT contains valid data that can be retrieved • SAVE This option is always available.

100

3.5 Parameters of the "Display" Transducer Block

The following table shows all the Endress+Hauser-specific parameters of the "Display" Transducer Block. These can only be changed after entering an enabling code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

	"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Access - Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified. You can enable programming by entering: ■ Code 53 (factory setting) ■ Personal code (→ Page 102) User input: Max. 4-digit number (0 to 9999) Note! ■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ see Operating Instructions for Promag 53 FF). ■ You can disable programming again by entering any number (other than the access code) in this parameter. ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code. ■ Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification. ■ The entry made here does not affect the local display. Thus, programming via the function matrix must be enabled separately.	
Access - Status Access - Code	read only	Use this parameter to display the current status of the possibilities for accessing the manufacturer-specific parameters of the device. User interface: LOCKED (parameterization disabled) ACCESS CUSTOMER (parameterization enabled) ACCESS SERVICE (parameterization enabled, access to service level)	
Access - Code Counter	read only	Displays how often the customer code, service code or the digit "0" (codefree) has been entered to gain access to the function matrix. User interface: Max. 7-digit number: 0 to 9999999 Factory setting: 0	

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
Access - Def.Private Code	AUTO - OOS	Use this function to specify a personal code for enabling configuration. This applies to both manufacturer-specific parameters in the Transducer Blocks and to operating via the onsite display.
		User input: 0 to 9999 (max. 4-digit number)
		Factory setting: 53
		 Note! Programming is always enabled with the code "0". Parameter configuration has to be enabled before this code can be changed.
Config Language	AUTO - OOS	Use this parameter to select the language for all texts, parameters and messages shown on the local display.
		Note! The displayed options depend on the available language group shown in the "Amp Language Group" parameter.
		OPTIONS: Language group WEST EU / USA: ENGLISH DEUTSCH FRANCAIS ESPANOL ITTALIANO NEDERLANDS PORTUGUESE Language group EAST EU / SCAND: ENGLISH NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH Language group ASIA: ENGLISH BAHASA INDONESIA JAPANESE (syllabary) Language group CHINA: ENGLISH CHINESE Factory setting: Depends on country → Page 130 ff. Note! You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.
		Depends on country → Page 130 ff. Note! You can change the language group via the configuration program FieldCare Please do not hesitate to contact your Endress+Hauser sales office if you

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
Config Display Damping	AUTO - OOS	Use this parameter to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).
		User input: 0 to 100 seconds
		Factory setting: 1 s
		Note! Setting the time constant to zero seconds switches off damping.
Config Contrast LCD	AUTO - OOS	Use this parameter to optimize display contrast to suit local operating conditions.
		User input: 10100%
		Factory setting: 50%
Config Backlight	AUTO - OOS	Use this parameter to optimize the backlight to suit local operating conditions.
		User input: 0100%
		Note! Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.
		Factory setting: 50%
Operation - Test Display	AUTO - OOS	Use this parameter to test the operability of the local display and its pixels.
Tout Biophay		Options: ON OFF
		Factory setting: OFF
		Test sequence: 1. Start the test by selecting ON.
		All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds.
		3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds.
		4. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds.
		5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds.
		When the test is completed, the local display returns to its initial state.

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
1 = Main line 2 = Additional line 3 = Information line		1 2 3 3
Main Line - Assign	AUTO - OOS	In this parameter, a value to be displayed is assigned to the main line (top line in the local display). This value is displayed during normal operation. Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW IN % TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) Factory setting: VOLUME FLOW
Main Line - 100%-Value	AUTO - OOS	The entry is not active unless one of the following was selected in the parameter "Main Line - Assign": ■ MASS FLOW IN % ■ VOLUME FLOW IN % Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! The unit is taken from the "System Unit - Volume Flow" or "System Unit - Mass Flow" parameter (→ Page 83 ff.).

104

"Display" Transducer Block/base index 1800:			
Write access with operating mode (MODE_BLK)	Description		
AUTO - OOS	Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line.		
	Options: XXXXX XXXX.X - XXX.XX - XX.XXX		
	Factory setting: X.XXXX		
	 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. 		
AUTO - OOS	Use this parameter to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the parameter "Main Line - Assign".		
	Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW IN % TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable)		
	Factory setting: OFF		
AUTO - OOS	Note! The entry is not active unless one of the following was selected in the parameter "Main Line Mux - Assign": MASS FLOW IN % VOLUME FLOW IN %		
	Use this parameter to define the flow value to be shown on the display as the 100% value.		
	User input: 5-digit floating-point number		
	Factory setting: Depends on nominal diameter and country → Page 130 ff.		
	Note! The unit is taken from the "System Unit - Volume Flow" or "System Unit - Mass Flow" parameter (→ Page 83 ff.).		
	Write access with operating mode (MODE_BLK) AUTO - OOS		

"Display" Transducer Block/base index 1800:			
Parameter	Write access with operating mode (MODE_BLK)	Description	
Main Line Mux - Format	AUTO - OOS	Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX Factory setting:	
		 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display. 	
1 = Main line 2 = Additional line 3 = Information line		1 2 3 3	
		A0001253	
Add. Line - Assign	AUTO - OOS	Use this parameter to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW BARGRAPH IN % FLOW VELOCITY TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: TOTALIZER 1	

106

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line - 100%-Value	AUTO - OOS	Note! The entry is not active unless one of the following was selected in the parameter "Add. Line - Assign": ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. Use this function to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! The unit is taken from the corresponding system unit ("System Unit - Volume Flow" or "System Unit - Mass Flow").
Add. Line - Format	AUTO - OOS	The option is not active unless a number was selected in the parameter "Add. Line - Assign". Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX XXXX.X - XXX.XX - XX.XXX - X.XXXX Factory setting: X.XXXX Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

	"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description	
Add. Line - Display Mode	AUTO - OOS	Note! The option is not active unless one of the following was selected in the parameter "Add. Line - Assign": MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). **A0001258** SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). **A0001258** **A0	
		Factory setting: STANDARD	
Add. Line Mux - Assign	AUTO - OOS	Use this parameter to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the parameter "Add. Line - Assign" (→ Page 106). Options: OFF VOLUME FLOW MASS FLOW VOLUME FLOW IN % MASS FLOW BARGRAPH IN % FLOW VELOCITY TOTALIZER (1 to 3) A1 (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. Once the fault is eliminated, the measuring device resumes operation in Multiplex mode and the error message is no longer displayed on the local display.	

108

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line Mux - 100%-Value	AUTO - OOS	Note! The entry is not active unless one of the following was selected in the parameter "Add. Line Mux - Assign": ■ MASS FLOW IN % ■ VOLUME FLOW IN % ■ MASS FLOW BARGRAPH IN % ■ VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! The unit is taken from the corresponding system unit ("System Unit - Volume Flow" or "System Unit - Mass Flow").
Add. Line Mux - Format	AUTO - OOS	The option is not active unless a number was selected in the parameter "Add. Line Mux - Assign" (→ Page 108). Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line. Options: XXXXX. − XXXX.X − XXX.XX − XXX.XXX − XXXXXX Factory setting: X.XXXX Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

	"Display	y" Transducer Block/base index 1800:
Parameter	Write access with operating mode (MODE_BLK)	Description
Add. Line Mux - Display Mode	AUTO - OOS	Note! The option is not active unless one of the following was selected in the parameter "Add. Line Mux - Assign" (→ Page 108): MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). **Page 108): Note! A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). **Page 108): A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). **Page 108): A0001258 SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign). **Page 108): **A0001259 **Pactory setting: STANDARD
1 = Main line 2 = Additional line 3 = Information line		1 2 3 A0001253
Info Line - Assign	AUTO - OOS	Use this parameter to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation. Options: OFF VOLUME FLOW IN % MASS FLOW IN % VOLUME FLOW BARGRAPH IN % MASS FLOW BARGRAPH IN % FLOW VELOCITY OPERATING/SYSTEM CONDITIONS DISPLAY FLOW DIRECTION TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OPERATING/SYSTEM CONDITIONS

110

"Display" Transducer Block/base index 1800:		
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line - 100%-Value	AUTO - OOS	Note! The entry is not active unless one of the following was selected in the parameter "Info Line - Assign" (→ Page 110): MASS FLOW IN % VOLUME FLOW IN % MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN %
		Use this parameter to define the flow value to be shown on the display as the 100% value.
		Use this function to define the flow value to be shown on the display as the 100% value.
		User input: 5-digit floating-point number
		Factory setting: Depends on nominal diameter and country → Page 130 ff.
		Note! The unit is taken from the corresponding system unit ("System Unit - Volume Flow" or "System Unit - Mass Flow").
Info Line - Format	AUTO - OOS	Note! The option is not active unless a number was selected in the parameter "Info Line - Assign" (→ Page 110).
		Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line.
		Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX
		Factory setting: X.XXXX
		 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

"Display" Transducer Block/base index 1800:			
Parameter	Write access with operating mode (MODE_BLK)	Description	
Info Line - Display Mode	AUTO - OOS	Note! The option is not active unless one of the following was selected in the parameter "Info Line - Assign" (→ Page 110): • MASS FLOW BARGRAPH IN % • VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Factory setting: STANDARD Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign). **Another Symmetrical bar graph for positive and negative directions flow, with -50 / 0 / +50% gradations and integrated sign).	
Info Line Mux - Assign	AUTO - OOS	Use this parameter to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the parameter "Info. Line - Assign" (→ Page 110). Options: OFF VOLUME FLOW IN % MASS FLOW IN % VOLUME FLOW BARGRAPH IN % FLOW VELOCITY OPERATING/SYSTEM CONDITIONS DISPLAY FLOW DIRECTION TOTALIZER (1 to 3) AI (1 to 5) - OUT VALUE AO - DISPLAY VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (manipulated variable) DEVICE PD-TAG (tag name) Factory setting: OFF Note! Multiplex mode is suspended as soon as a fault / notice message is generated. The message in question appears on the display. Once the fault is eliminated, the measuring device resumes operation in Multiplex mode and the error message is no longer displayed on the local display.	

112

	"Display	y" Transducer Block/base index 1800:
Parameter	Write access with operating mode (MODE_BLK)	Description
Info Line Mux - 100%-Value	AUTO - OOS	Note! The entry is not active unless one of the following was selected in the parameter "Info Line Mux - Assign" (→ Page 112): MASS FLOW IN % VOLUME FLOW IN % MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % Use this parameter to define the flow value to be shown on the display as the 100% value. User input: 5-digit floating-point number Factory setting: Depends on nominal diameter and country → Page 130 ff.
		Note! The unit is taken from the corresponding system unit ("System Unit - Volume Flow" or "System Unit - Mass Flow").
Info Line Mux - Format	AUTO - OOS	Note! The option is not active unless a number was selected in the parameter "Info Line Mux - Assign" (→ Page 112). Use this parameter to define the maximum number of places after the
		decimal point for the second value displayed in the information line. Options: XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX
		Factory setting: X.XXXX
		 Note! Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations. The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In these instances an arrow appears on the display between the measured value and the engineering unit (e.g. 1.2 → kg/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.

Write access with operating Parameter Description	
mode (MODE_BLK)	
Info Line Mux - Display Mode AUTO - OOS Note! The option is not active unless one of the following was selected in the parameter "Info Line Mux - Assign" (→ Page 112): MASS FLOW BARGRAPH IN % VOLUME FLOW BARGRAPH IN % Use this parameter to define the format of the bar graph. Options: STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign). **Page 112** SYMMETRY (Symmetrical bar graph for positive and negative direction flow, with -50 / 0 / +50% gradations and integrated sign).	A0001258

3.6 Parameters of the "Totalizer" Transducer Block

The following table shows all the Endress+Hauser-specific parameters of the "Totalizer" Transducer Block. These can only be changed after entering an enabling code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

"Totalizer" Transducer Block/base index 1900:				
Parameter	Write access with operating mode (MODE_BLK)	Description		
Access - Code	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified. You can enable programming by entering: ■ Code 53 (factory setting) ■ Personal code (→ Page 102) User input: Max. 4-digit number (0 to 9999) Note! ■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ see Operating Instructions for Promag 53 FF, BA126D). ■ You can disable programming again by entering any number (other than the access code) in this parameter. ■ The Endress+Hauser service organization can be of assistance if you mislay your personal code. ■ Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification. ■ The entry made here does not affect the local display. Thus, programming via the function matrix must be enabled separately.		
Access - Status	read only	Use this parameter to display the current status of the possibilities for accessing the manufacturer-specific parameters of the device. User interface: LOCKED (parameterization disabled) ACCESS CUSTOMER (parameterization enabled) ACCESS SERVICE (parameterization enabled, access to service level)		

"Totalizer" Transducer Block/base index 1900:			
Parameter	Write access with operating mode (MODE_BLK)	Description	
Tot. 1 to 3 - Sum	AUTO - OOS	Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the parameter "Tot. 1 to 3 - Mode" (→ Page 117), and the direction of flow. Note! Note! The effect of the setting in the parameter "Tot. 1 to 3 - Mode" is as follows: If the setting is "BALANCE", the totalizer balances flow in the positive and negative directions. If the setting is "FORWARD", the totalizer registers only flow in the positive direction. If the setting is "REVERSE", the totalizer registers only flow in the negative direction. The totalizer's response to faults is defined in the parameter "Tot Failsafe All".	
Tot. 1 to 3 - Unit	AUTO - OOS	Use this parameter to define the unit for the totalizer's measured variable, as selected beforehand. Options: (for MASS FLOW assignment): Metric → g; kg; t US → oz; lb; ton Factory setting: Depends on nominal diameter and country → Page 130 ff. Options (for VOLUME FLOW assignment): Metric → cm³; dm³; m³; ml; l; hl; Ml Mega US → cc; af; ft³; oz f; gal; Kgal; Mgal; bbl (normal fluids); bbl (beer); bbl (petrochemicals); bbl (filling tanks) Imperial → gal; Mgal; bbl (beer); bbl (petrochemicals) Factory setting: Depends on nominal diameter and country → Page 130 ff. Note! The unit selected here does not have any effect on the desired volume unit which should be transmitted by means of the FOUNDATION Fieldbus interface. This setting is made separately by means of the corresponding AI Block in the XD_SCALE parameter group. Use this parameter to assign a measured variable to the totalizer.	
		Options: OFF MASS FLOW VOLUME FLOW Factory setting: VOLUME FLOW Note! The totalizer is reset to "0" as soon as the selection is changed.	

	"Totalize	er" Transducer Block/base index 1900:
Parameter	Write access with operating mode (MODE_BLK)	Description
Tot. 1 to 3 - Mode	AUTO - OOS	Use this parameter to define how the flow components are to be totaled by the totalizer.
		Options: BALANCE Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.
		FORWARD Positive flow components only
		REVERSE Negative flow components only
		Factory setting: Totalizer 1 = BALANCE Totalizer 2 = FORWARD Totalizer 3 = REVERSE
Tot. 1 to 3 - Reset	AUTO - OOS	Resets the totalizer ("Tot. 1 to 3 - Sum" parameter) to zero.
		Options: NO YES
		Factory setting: NO
		Note! Totalizer resetting can also be controlled or triggered by means of cyclic data transfer via the Discrete Output function block.
Tot Reset All	AUTO - OOS	Resets all totalizers ("Tot. 1 to 3 - Sum" parameter) simultaneously to zero.
		Options: NO YES
		Factory setting: NO
		Note! Totalizer resetting can also be controlled or triggered by means of cyclic data transfer via the Discrete Output function block.
Tot Failsafe All	AUTO - OOS	Use this parameter to define the common response of all totalizers (1 to 3) in case of error.
		$\begin{array}{c} \textbf{Options} \\ \textbf{STOP} \rightarrow \textbf{The totalizers are paused until the fault is rectified.} \end{array}$
		ACTUAL VALUE \rightarrow The totalizers continue to count based on the actual flow measured value. The fault is ignored.
		${ m HOLD\ VALUE} ightarrow { m The\ totalizers\ continue\ to\ count\ the\ flow\ based\ on\ the\ last\ valid\ flow\ value\ (before\ the\ fault\ occurred).}$
		Factory setting: STOP

4 Function blocks

The function blocks contain the basic automation functions of the field device. We distinguish between different function blocks, e.g. Analog Input function block, PID function block (PID controller), etc.

Each of these function blocks is used to execute different application functions. This means that local control functions, for example, can be carried out directly in the field, and device errors such as amplifier errors are reported to the automation system automatically.

The function blocks process the input values in accordance with their specific algorithm and their internally available parameters. They generate output values that are made available to other function blocks for further processing by linking the individual function blocks with each other.

5 Analog Input function block

In the Analog Input function block (AI) the process variables from the Transducer Block are prepared for the subsequent automation functions (e.g. scaling, limit value processing). The automation function is defined by the connections of the outputs.



OUT = output value and output status of the Analog Input function block

A0003800

5.1 Signal processing

The figure shows the internal structure of the Analog Input function blocks:




Fig. 3: Internal structure of the individual Analog Input function blocks

The Analog Input function block receives its input value from the Transducer Block. The parameter CHANNEL is used to select which input value is to be processed by the Analog Input function block. The ProdType is configured in the factory as follows:

- CHANNEL = $1 \rightarrow$ Calculated mass flow
- CHANNEL = $2 \rightarrow \text{Volume flow}$
- CHANNEL = $7 \rightarrow$ Totalizer 1
- CHANNEL = $8 \rightarrow$ Totalizer 2
- CHANNEL = $9 \rightarrow$ Totalizer 3

The parameter group SIMULATE allows you to replace the input value with a simulation value and to activate simulation. By specifying the status and the simulation value the reaction of the complete Analog Input function block can be tested.



Note!

The simulation mode is enabled by means of the corresponding jumpers on the I/O board (\rightarrow see Operating Instructions for Promag 53 FF, BA126D).

The parameter L_TYPE is used to select the linearization type of the input or simulation value:

■ Direct signal conversion

The value is forwarded without conversion (XD_SCALE = OUT_SCALE). Select this option if the input value is already in the physical unit you want.

■ Indirect signal conversion

With this setting the measured value from the Transducer Block (input value) is re-scaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE (further information on rescaling of the input value can be found on \rightarrow Page 123).

■ Indirect signal conversion with square root

With this setting the measured value from the Transducer Block (input value) is re-scaled via the parameter group XD_SCALE and recalculated using a square root function. It is then rescaled again to the desired output range via the parameter group OUT_SCALE.

The parameter LOW_CUT allows a limit value to be specified for the low flow cut off. The low flow cut off is activated via the parameter IO_OPTS. If the converted primary value (PV) is below the limit value then it is set to a value of "Zero".

In the parameter PV_FTIME a filter time can be specified for filtering the converted primary value (PV). If a time of 0 seconds is specified then no filtration takes place.

The parameter group MODE_BLK is used to select the operating mode of the Analog Input function block. If the operating mode MAN (manual) is selected then the output value OUT can be specified directly.

The output value OUT is compared with warning and alarm limits (e.g. HI_LIM, LO_LO_LIM, etc.) that can be entered via various parameters. If one of these limit values is violated then a limit value process alarm (e.g. HI_ALM, LO_LO_ALM, etc.) is triggered.

5.2 Important functions and parameters of the Analog Input function blocks

The primary functions and parameters of the Analog Input function blocks are listed below.



Note!

All FOUNDATION Fieldbus parameters available are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

5.2.1 Selecting the operating mode

The operation mode is set by means of the MODE_BLK parameter group. The Analog Input function block supports the following operation modes:

- AUTO (automatic mode)
- MAN (manual mode)
- OOS (out of service)



Notel

The block status OOS is also shown via the parameter BLOCK_ERR. In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

5.2.2 Assignment of the process variable

The ProdType has five Analog Input function blocks. The process variables of the Transducer Block that are to be processed are assigned via the parameter CHANNEL. The ProdType is configured in the factory as follows:

- CHANNEL = $1 \rightarrow$ Calculated mass flow
- CHANNEL = $2 \rightarrow \text{Volume flow}$
- CHANNEL = $7 \rightarrow$ Totalizer 1
- CHANNEL = $8 \rightarrow$ Totalizer 2
- CHANNEL = $9 \rightarrow$ Totalizer 3

5.2.3 Linearization types

In the Analog Input function block the input value can be linearized by the Transducer Block using the parameter L_TYPE. The following types of linearization are available:

■ Direct

With this setting the measured value from the Transducer Block (input value) avoids the linearization function and is looped unchanged with the same unit through the Analog Input function block.

■ Indirect

With this setting the measured value from the Transducer Block (input value) is re-scaled linearly via the input scaling XD_SCALE to the desired output range OUT_SCALE.

■ Indirect Square Root

With this setting the measured value from the Transducer Block (input value) is re-scaled via the parameter group XD_SCALE and recalculated using an evolution function. It is then rescaled again to the desired output range via the parameter group OUT_SCALE.

5.2.4 Selection of units

The XD_SCALE parameter group is used to determine with which physical unit the input value from the Transducer Blocks should be read in and processed in the Analog Input function block. The output value OUT is defined via the OUT_SCALE parameter group \rightarrow For an example for rescaling the input value, see Page 123.

The choice of units depends on the corresponding channel:

- Channel = $1 \rightarrow$ Only units for the mass flow are valid
- Channel = $2 \rightarrow$ Only units for the volume flow are valid
- Channel = $7 \rightarrow$ Only units for totalizer 1 are valid
- Channel = $8 \rightarrow$ Only units for totalizer 2 are valid
- Channel = $9 \rightarrow$ Only units for totalizer 3 are valid

If an unsuitable unit is selected, the function block changes to the OOS (out of service) operating mode.



Note!

- If the "Direct" type of linearization is selected via the L_TYPE parameter, the setting for the XD_SCALE and OUT_SCALE parameter groups must be identical; otherwise, the function block remains in the OOS mode and the "BLOCK CONFIG ERROR" block error is displayed in the BLOCK ERROR parameter.
- The system units selected in the Transducer Blocks in question do not have any effect on the setting of the system units in the Analog Input function block. The units are specified independently of one another and must be configured separately. The unit selected in the Transducer Blocks is only used for the local display, EPD adjustment, low flow cut off and for simulation.

5.2.5 Status of the output value OUT

The status of the parameter group OUT communicates to the downstream function blocks the status of the Analog Input function block and the validity of the output value OUT. The following status values can be displayed:

■ GOOD NON CASCADE

The output value OUT is valid and can be used for further processing.

■ UNCERTAIN

The output value OUT can only be used for further processing to a limited extent. The status signals to the downstream function blocks that a "notice message" is present in the device, e.g. arising from active positive zero return or simulation.

■ BAD

The output value OUT is invalid. The following causes are possible:

- The Analog Input function block is in the OOS operating mode.
- The Resource Block is in operating mode OOS.
- The status "BLOCK CONFIG ERROR" is displayed via the BLOCK ERR parameter.
- The "Flow" or "Totalizer" Transducer Block is in the OOS operating mode. The Analog Input function block can only process the input value of the Transducer Block in question if the operating mode is set to AUTO.
- A "fault message" is present in the device arising from a critical device error, e.g. an electronics module defect.



Note!

In the "Diagnosis" Transducer Block, the cause of the error message (notice/fault message) is displayed via the "Diag. - Act. Sys. Condition" parameter. A list of all the error messages, including remedial measures, is provided in the Operating Instructions for Promag 53 FF (BA126D).

5.2.6 Simulation of input/output

Parameters of the Analog Input function block allow simulation of the input and output of the function block:

Simulation of the input of the Analog Input function block:
 The parameter group SIMULATE can be used to specify the input value (measured value and status). Since the simulation value runs through the entire function block, all the parameter settings of the block can be checked.



Note!

If simulation is blocked by the jumper on the I/O board then simulation mode cannot be activated in the parameter SIMULATE. In the Resource Block, the parameter BLOCK_ERROR shows whether simulation of the Analog Input function block is possible.

2. Simulation of the output of the Analog Input function block:
Set the operating mode in the parameter group MODE_BLK to MAN and specify the desired output value directly in the parameter OUT.

5.2.7 Diagnosis

Block errors and diagnosis information are displayed in the Analog Input function block via the BLOCK_ERR parameter.



Note!

Further information on troubleshooting during the configuration of the Analog Input function block is provided in the Operating Instructions for Promag 53 FOUNDATION Fieldbus (BA0126).

5.2.8 Rescaling the input value

In the Analog Input function block the input value or input range can be scaled in accordance with the automation requirements.

Example:

- The system unit in the Transducer Block is m^3/h .
- The measuring range of the sensor is 0 to 30 m^3/h .
- The output range to the process control system should be 0 to 100%.

The Analog Input function block must be configured as follows:

■ Parameter CHANNEL

Option: CHANNEL \rightarrow 2 = Volume flow

■ Parameter L_TYPE

Option: $L_TYPE = Indirect$

The "Volume flow" process variable of the "Flow" Transducer Block is rescaled linearly in the AI Block via the input scaling XD_SCALE to the desired output range OUT_SCALE.

■ XD_SCALE parameter group

■ OUT_SCALE parameter group

 $OUT_SCALE 0 \% = 0$ $OUT_SCALE 100\% = 100$ $OUT_SCALE UNIT = \%$

The result is that with an input value of, for example, $15 \text{ m}^3/\text{h}$ a value of 50% is output via the parameter OUT.




Fig. 4: Example for rescaling the input value

5.2.9 Limit values

The limit values are based on the output value OUT. If the output value OUT exceeds or does not reach the defined limit values then an alarm is sent to the fieldbus host system via the limit value process alarms.

The following limit values can be defined:

- HI_HI_LIM (upper alarm limit)
- HI_LIM (upper early warning limit)
- LO_LO_LIM (lower alarm limit)
- LO_LIM (lower early warning limit)

5.2.10 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK_ALM. The parameter ACK_OPTION specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Analog Input function block:

Block process alarms

A block process alarm is triggered via the BLOCK_ERR parameter. The parameter BLOCK_ALM is used to show the block process alarms and communicate them to the fieldbus host system. The following process alarms can be generated by the Analog Input function block:

- SIMULATE ACTIVE
- INPUT FAILURE
- OUT OF SERVICE
- BLOCK CONFIG ERROR

If the option of the process alarm (BLOCK ALM) has **not** been enabled in the parameter ACK_OPTION, the process alarms must be acknowledged in the parameter BLOCK_ALM.

Limit value process alarms

If a limit value is infringed then the priority specified for the limit value alarm will be checked before the limit value violation is communicated to the fieldbus host system. The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

- HI_HI_PRI
- HI PRI
- LO_LO_PRI
- LO_PRI

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

- HI_HI_ALM
- HI_ALM
- LO_LO_ALMI
- LO_ALM

If the option of a limit value process alarm has **not** been enabled in the parameter ACK_OPTION then this must be acknowledged directly in its parameter (see list).



Note!

The parameter ALARM_SUM shows the current status of all the process alarms.

6 Discrete Output Function block

The Discrete Output function block (DO, Discrete Output) processes a discrete setpoint value received from an upstream function block or higher level process control system, with which various instrument functions (e.g. zero point adjustment or totalizer reset) can be initiated in the downstream Transducer Block.



A0003816-en

CAS_IN _D = Remote setpoint value from another function block

OUT_D = Discrete output value and status

BKCAL_OUT_D = Discrete output value and status required by BKCAL_IN_D input of another block for output

6.1 Signal processing

The figure shows the internal structure of the Discrete Output function blocks ProdType:




Fig. 5: Signal processing in the Discrete Output function block

In the CAS operating mode (cascade operation), the Discrete Output function block receives, via the function block input CAS_IN_D, a discrete signal from an upstream function block. This signal controls the setpoint value (parameter SP_D) of the function block, and after internal calculation is sent as an output signal (parameter OUT_D) to the Transducer Block for control of instrument functions (e.g. zero point adjustment). The output value and status of the Discrete Output function block is communicated to the upstream block via the output BKCAL_OUT_D.

Signal processing in the RCAS operating mode (remote cascade operation) is largely identical to the CAS operating mode. However, in this operating mode, control of the parameter SP_D does not take place via an upstream function block but through a process control system. The output value and status of the Discrete Output function block is communicated to the process control system as an answer message via parameter RCAS_OUT_D.

In the AUTO operating mode (automatic operation), the set point value (parameter SP_D) is prescribed directly in the Discrete Output function block. In this case, the parameter CAS_IN_D is not taken into consideration in the internal calculation.

In the MAN operating mode (HAND), the output value (parameter OUT_D) can be prescribed directly in the Discrete Output function block. No internal calculation takes place.

6.2 Important functions and parameters of the Discrete Output function block

The primary functions and parameters of the Discrete Output function block are listed below.



Note!

All FOUNDATION Fieldbus parameters available are described in the "FOUNDATION Fieldbus Overview" Operating Instructions (BA013S) (acquired at: \rightarrow www.endress.com \rightarrow Download).

6.2.1 Selecting the operating mode

The operation mode is set by means of the MODE_BLK parameter group. The Discrete Output function block supports the following operation modes:

- AUTO
- MAN
- CAS
- RCAS
- OOS

6.2.2 Safety behavior

There is a safety default available (fault state) for the Discrete Output function block. This is activated when a fault condition (of the corresponding valid set point value) exists longer than defined in the parameter FSTATE_TIME, or when the parameter SET_FSTATE in the Resource Block is activated. The safety operation is determined via the parameters FSTATE_TIME, FSTATE_VAL_D, and IO_OPTS.

6.2.3 Assignment between the Discrete Output Function block and the Transducer Block

The assignment or connection between the Discrete Output function block and the Transducer Block takes place in the Discrete Output function block via the parameter CHANNEL.

→ Parameter CHANNEL → 16 (= Discrete Output function block)

6.2.4 Values for the parameters CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D

Via the Discrete Output function block, different instrument functions in the Transducer Block can be initiated via manufacturer-specific, fixed set point values from an upstream function block.

Here it must be observed that the desired function is only then executed when a status change from the value 0 (Discrete state 0) to the corresponding function value (following table) takes place. The value 0 always serves as the starting point for the corresponding control of instrument functions. A status change from a value not equal to zero to another value has no effect.

Input allocation of the parameter CAS_IN_D, RCAS_IN_D, OUT_D, SP_D

Status changes			Action
Discrete state 0	\rightarrow	Discrete state 1	Reserved
Discrete state 0	\rightarrow	Discrete state 2	Positive Zero Return ON
Discrete state 0	\rightarrow	Discrete state 3	Positive Zero Return OFF
Discrete state 0	\rightarrow	Discrete state 4	Reserved
Discrete state 0	\rightarrow	Discrete state 5	Reserved
Discrete state 0	\rightarrow	Discrete state 6	Reserved
Discrete state 0	\rightarrow	Discrete state 7	Reset Totalizers 1, 2, 3
Discrete state 0	\rightarrow	Discrete state 8	Reset Totalizer 1
Discrete state 0	\rightarrow	Discrete state 9	Reset Totalizer 2
Discrete state 0	\rightarrow	Discrete state 10	Reset Totalizer 3

Example for the control of positive zero return via the Discrete Output function block.

The following example is intended to illustrate how positive zero return can be activated and deactivated during a rinsing process by an upstream function block via the Discrete Output function block.

- 1. In the first step, the connection between the Discrete Output function block and the Transducer Block must be established. Here, the value 16 must be assigned to the parameter CHANNEL in the Discrete Output function block.
 - \rightarrow Parameter CHANNEL \rightarrow 16 (= Discrete Output function block)
- 2. In the CAS operating mode, the Discrete Output function block processes the set point value prescribed at the input CAS_IN_D by the upstream function block and transfers it to the Transducer Block.

Activating positive zero return

With a starting value of 0 (Discrete state 0), the positive zero return is activated by a status change from 0 to 2 at input CAS_IN_D.

Deactivating positive zero return

Positive zero return can only then be deactivated when the input value at CAS_IN_D has first been set to output value 0 (Discrete state 0). Only then can positive zero return be deactivated through a status change from 0 to 2 at input CAS_IN_D.

7 Additional function blocks



Note!

Other function blocks such as the PID, Arithmetic, Input Selector, Signal Characterizer and Integrator function block are described in the "FOUNDATION Fieldbus Overview" (BA013S) Operating Instructions (acquired at: \rightarrow www.endress.com \rightarrow Download).

8 Factory settings

8.1 SI units (not for USA and Canada)

Low flow cut off, full scale value

Nominal diameter	Low flow cut off		Fu	ill scale val	ue	
	(approx. v = 0.04 m/s)		(approx. v = 2.5 m/s)			
[mm]		Volume	Mass		Volume	Mass
15	0.5	dm ³ /min	kg/min	25	dm ³ /min	kg/min
25	1	dm ³ /min	kg/min	75	dm ³ /min	kg/min
32	2	dm ³ /min	kg/min	125	dm ³ /min	kg/min
40	3	dm ³ /min	kg/min	200	dm ³ /min	kg/min
50	5	dm ³ /min	kg/min	300	dm ³ /min	kg/min
65	8	dm ³ /min	kg/min	500	dm ³ /min	kg/min
80	12	dm ³ /min	kg/min	750	dm ³ /min	kg/min
100	20	dm ³ /min	kg/min	1200	dm ³ /min	kg/min
125	30	dm ³ /min	kg/min	1850	dm ³ /min	kg/min
150	2.5	m ³ /h	t/h	150	m ³ /h	t/h
200	5.0	m ³ /h	t/h	300	m ³ /h	t/h
250	7.5	m ³ /h	t/h	500	m ³ /h	t/h
300	10	m ³ /h	t/h	750	m ³ /h	t/h
350	15	m ³ /h	t/h	1000	m ³ /h	t/h
400	20	m ³ /h	t/h	1200	m ³ /h	t/h
450	25	m ³ /h	t/h	1500	m ³ /h	t/h
500	30	m ³ /h	t/h	2000	m ³ /h	t/h
600	40	m ³ /h	t/h	2500	m ³ /h	t/h

Language

Country	Language
Australia	English
Austria	Deutsch
Belgium	English
China	Chinese
Czech Republic	Czech
Denmark	English
England	English
Finland	Suomi
France	Français
Germany	Deutsch
Hong Kong	English
Hungary	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Netherlands	Nederlands
Norway	Norsk

Country	Language
Poland	Polish
Portugal	Portuguese
Russia	Russian
Singapore	English
South Africa	English
Spain	Espanol
Sweden	Svenska
Switzerland	Deutsch
Thailand	English

Density, length, temperature

	Unit
Density	kg/l
Length	mm
Temperature	° C

8.2 US units (only for USA and Canada)

Low flow cut off, full scale value

Nominal diameter	Low flow cut off		Full scale value			
	(approx. $v = 0.13 \text{ ft/s}$)		(appr	vox. v = 8.2	ft/s)	
[inch]		Volume	Mass		Volume	Mass
1/2"	0.10	gal/min	lb/min	6	gal/min	lb/min
1"	0.25	gal/min	lb/min	18	gal/min	lb/min
1 1/4"	0.50	gal/min	lb/min	30	gal/min	lb/min
1 1/2"	0.75	gal/min	lb/min	50	gal/min	lb/min
2"	1.25	gal/min	lb/min	75	gal/min	lb/min
2 1/2"	2.0	gal/min	lb/min	130	gal/min	lb/min
3"	2.5	gal/min	lb/min	200	gal/min	lb/min
4"	4.0	gal/min	lb/min	300	gal/min	lb/min
5"	7.0	gal/min	lb/min	450	gal/min	lb/min
6"	12	gal/min	lb/min	600	gal/min	lb/min
8"	15	gal/min	lb/min	1200	gal/min	lb/min
10"	30	gal/min	lb/min	1500	gal/min	lb/min
12"	45	gal/min	lb/min	2400	gal/min	lb/min
14"	60	gal/min	lb/min	3600	gal/min	lb/min
16"	60	gal/min	lb/min	4800	gal/min	lb/min
18"	90	gal/min	lb/min	6000	gal/min	lb/min
20"	120	gal/min	lb/min	7500	gal/min	lb/min
24"	180	gal/min	lb/min	10500	gal/min	lb/min

Language, density, length, temperature

	Unit
Language	English
Density	g/cc
Length	inch
Temperature	°F

Index (FOUNDATION Fieldbus)

A
Access
Transducer Block 82
Access - Code
"Flow" Transducer Block 82, 97, 101
"Totalizer" Transducer Block
Access - Code Counter
"Flow" Transducer Block
Access - Def.Private Code
"Display" Transducer Block
Access - Status
"Flow" Transducer Block 82, 97, 101
"Totalizer" Transducer Block
Access code counter
Add. Line
"Display" Transducer Block 106
Alarm delay 98
Alarm detection
AI Function block
Resource Block
Transducer Block
Alarm processing
AI Function block
Resource Block
Transducer Block
Amp HW Identification
Resource Block
Amp HW Rev.Number
Resource Block
Amp Language Group
Resource Block
Amp Prod.Number
Resource Block
Amp SW Identification
Resource Block
Amp SW Rev.No. T-DAT
Resource Block
Amp SW Rev. Number
Resource Block
Amplifier 777
Hardware identification number
Hardware revision number
Language Group
Production number
Software identification number
Software revision number
Assign
DO Function block
В
_
Backlight
Display
Block
Totalizer
Block model

Block output values
Transducer Block
Block status
Resource Block
C
Calibration factor
Code
Access code counter
Counter (matrix enabling)
Code entry
See Access - Code
Code entry, personal private code
Config Backlight
"Display" Transducer Block
Config Contrast LCD
"Display" Transducer Block
Config Display Damping
"Display" Transducer Block
Config Language
"Display" Transducer Block 102
D
-
Damping
Display
Flow, measuring signal
Density O4
Display, unit
Enter density factor (for mass flow)
Density Param Fixed Value "Flow" Transducer Block
Density Param Unit "Flow" Transducer Block
Diag Prev. Sys. Condition "Diagnosis" Transducer Block
DiagAct. Sys. Condition
"Diagnosis" Transducer Block
AI Function block
Transducer Block
Discrete Output Function block
Discrete Output Function block
Display
Backlight
Configuration
Additional line
Information line
Main line
Contrast
Damping
Density value, fixed
Format (display number of decimal places)
Additional line
Information line
Main line
Language cotting 100

Mass flow (calculated)	Length
Test function	Temperature
Volume flow	
	Fault message See Operating Instructions for Proline Promag 55
E	FOUNDATION FIELDBUS (BA026D)
ECC	Function blocks
"Flow" Transducer Block 92	
ECC - Cycle	G
"Flow" Transducer Block	Group
ECC - Duration	Totalizer (1 to 3)
"Flow" Transducer Block 92	I
ECC - Polarity	
"Flow" Transducer Block	I/O - HW Identification
ECC - Recovery Time	Resource Block
"Flow" Transducer Block	I/O - HW Rev. Number
Electrode cleaning (ECC)	Resource Block
Cleaning cycle	I/O - Prod.Number
Duration	Resource Block
Polarity (display only)	I/O - SW Identification
Recovery time	Resource Block
System options	I/O - SW Rev. Number
Electrodes	Resource Block
EPD electrode	I/O - Type
Empty pipe detection (EPD)	Resource Block
Empty Pipe Coef	I/O Module
Empty pipe/full pipe adjustment	Hardware identification number
EPD electrode	Hardware revision number
Full Pipe Coef	Production number
General information	Software identification number
Response time	Software revision number
Switching on/off	Identification number
EPD - Adjustment	Amplifier hardware
"Flow" Transducer Block	Amplifier software
EPD - Electrode	I/O module hardware
"Flow" Transducer Block	I/O module software
EPD - Empty Pipe Coef.	Sensor 96
"Flow" Transducer Block	Info Line
EPD - Full Pipe Coef.	"Display" Transducer Block
"Flow" Transducer Block	Information line (group CGA)
EPD - Param. Mode	Multiplex
"Flow" Transducer Block 90	Installation direction, sensor
EPD - Param. Time	Integration time
"Flow" Transducer Block	L
Error messages	
See System condition	Language group amplifier
T.	Limit values
F	AI Function block
Factory settings (SI units)	Low flow cut off
Density	Assign (mass flow/volume flow)
Full scale value	Off-value
Language	On-value
Length	Unit
Low flow cut off	Low Flow Cut Off - Assign
Temperature	"Flow" Transducer Block
Factory settings (US units)	Low Flow Cut Off - Off Value
Density	"Flow" Transducer Block
Full scale value	Low Flow Cut Off - On Value
Language	"Flow" Transducer Block 87

Low Flow Cut Off - Unit "Flow" Transducer Block	S Safety behavior
M	DO Function block
M Material trans	Selecting units ("Flow" Transducer Block)
Main Line	Density value, fixed
"Display" Transducer Block	Mass flow
Measuring period, time entry	Nominal diameter (mm, inch)
N	Volume flow
Nominal diameter	Sensor
Notice message	Calibration factor
See Operating Instructions for Proline Promag 55	Display device type
FOUNDATION FIELDBUS (BA026D)	Hardware production number
0	Hardware revision number
0	Installation direction
OED - Empty Value	Measuring period95
"Flow" Transducer Block	Nominal diameter
"Flow" Transducer Block	Revision Number Software S-DAT
OED - Period	Serial number
"Flow" Transducer Block	Zero point
Open electrode detection (OED)	Sensor - HW Identification
Empty Value	"Flow" Transducer Block
Full Pipe Coef	Sensor - HW-Rev.Number
Period	"Flow" Transducer Block
Operating time, measuring device	Sensor - Prod.Number "Flow" Transducer Block
Operation - Test Display	Sensor - Serial Number
"Display" Transducer Block	Resource Block
Operation mode	Sensor - SW-Rev.No. S-DAT
AI Function block	"Flow" Transducer Block
DO Function block	Sensor - Type
Resource Block	"Flow" Transducer Block
Transducer Block	Sensor Data - K-Factor
Time field	"Flow" Transducer Block
Time neid	Sensor Data – Measuring Period
P	"Flow" Transducer Block
Parameter	Sensor Data - Nominal Diameter
Resource Block	"Flow" Transducer Block
Positive zero return	Sensor Data - Overvoltage Time
Pressure shock suppression	"Flow" Transducer Block
Process - Pressure Shock Suppression	"Flow" Transducer Block
"Flow" Transducer Block	Serial number sensor
Process variable assignment	Service/Analys Electrode Pot. 1 - Value Measurand
AI Function block	"Flow" Transducer Block
Production number	Service/Analys Electrode Pot. 2 - Value Measurand
Amplifier 77 I/O Module 77	"Flow" Transducer Block96
Sensor	Service/Analys Measuring Period
JC11301 90	"Flow" Transducer Block
R	Service/Analys Risetime - Value Measurand
Rescaling	"Flow" Transducer Block
AI Function block	Service/analysis functions
Resource Block	Set points
Resource Block parameters	DO Function block
Revision number	Signal filter
Amplifier hardware	Signal processing AI Function block
Amplifier software	DO Function block
Hardware	Transducer Block
S-DAT software 96	17411044001 510011

Cimoulation	Creations I Instit. Malarman Electric
Simulation Al Function block	System Unit - Volume Flow
AI Function block	"Flow" Transducer Block
Display measured value	System Value – Fixed Density
Measured value for test purposes	"Flow" Transducer Block 84
Resource Block	System Value - Mass Flow
Totalizer failsafe mode	"Flow" Transducer Block
Volume flow/mass flow	System Value - Volume Flow
Simulation - Measurand	"Flow" Transducer Block
"Flow" Transducer Block	System–Reset (without disconnecting main power) 98
Simulation – Unit	T
"Flow" Transducer Block	
Simulation – Value Measurand	T-DAT
"Flow" Transducer Block	Amplifier software revision number
Status OUT	Loading/saving data
AI Function block	Tot. – Failsafe All
Storage	"Totalizer" Transducer Block
Sys Alarm Delay	Tot. – Reset All
"Diagnosis" Transducer Block	"Totalizer" Transducer Block 117
Sys CIP Samples	Tot. 1 to 3 - Assign
"Flow" Transducer Block 86	"Totalizer" Transducer Block
Sys Flow Damping	Tot. 1 to 3 - Mode
"Flow" Transducer Block 85	"Totalizer" Transducer Block
Sys Install. Direction Sensor	Tot. 1 to 3 - Reset
"Flow" Transducer Block	"Totalizer" Transducer Block 117
Sys Integration Time	Tot. 1 to 3 - Sum
"Flow" Transducer Block	"Totalizer" Transducer Block 116
Sys Operation Time	Tot. 1 to 3 - Unit
"Diagnosis" Transducer Block	"Totalizer" Transducer Block 116
Sys Permanent Storage	Totalizer
"Flow" Transducer Block	Define failsafe mode
Sys Positive Zero Return	Reset (all)
"Flow" Transducer Block	Simulation failsafe mode 98
Sys Reset	Totalizer (block D)
"Diagnosis" Transducer Block	Totalizer 1
Sys Sim. Failsafe Mode	Reset 117
"Diagnosis" Transducer Block	Totalizer 1 to 3
Sys Special Filter	Assign (volume, mass)
"Flow" Transducer Block	Balancing mode
Sys T-DAT Save/Load	Display value
"Diagnosis" Transducer Block	Unit
Sys Time Since Reset	Transducer Block
"Diagnosis" Transducer Block	Troubleshooting, EEPROM
Sys Troubleshooting	Type of linearization
"Diagnosis" Transducer Block	AI Function block
System condition	
Actual	U
Previous (error history)	Units
System Option - ECC	AI Function block
"Flow" Transducer Block	
System Unit - Fixed Density	W
"Flow" Transducer Block	Write protect
System Unit - Length	Resource Block
"Flow" Transducer Block	-
System Unit - Mass Flow	Z
"Flow" Transducer Block	Zero point 94
110W 11d115ddcc1 D10Ch 04	

www.endress.com/worldwide



People for Process Automation