



Level



Pressure



Flow



Temperature

Liquid
Analysis

Registration

Systems
Components

Services



Solutions

Operating Instructions

ControlCare Application Designer

IEC 61131-3 Structured Text (ST) Tutorial





Table of Contents

Revision History	2	5 Parameter the Devices	41
Product Version	2	5.1 Field Controller Hardware Configuration block	41
Registered Trademarks	2	5.2 TMT162 temperature transmitter	43
1 Safety	3	5.3 Micropilot M level transmitter	44
1.1 Designated use	3	5.4 Metso ND9103FN positioner	45
1.2 Installation, commissioning and operation	3	5.5 Export tags	46
1.3 Operational safety	3	6 Program the Hybrid Function Block .	47
1.4 Conventions and icons	4	6.1 Set the IEC 61131-3 programming language	47
1.5 ControlCare documents	5	6.2 Program the hybrid function block	48
2 Task Description	6	6.2.1 OpenPCS programming tool	48
2.1 Valve control for tank level	6	6.2.2 Declare additional variables	50
2.1.1 Control strategy	7	6.2.3 Activate the libraries	52
2.1.2 Control algorithm	8	6.2.4 Create the structured text program	53
2.1.3 Aliasing	8	6.2.5 Trouble-shoot the project	55
2.1.4 Network	9	6.3 IEC 61131-3 Simulation	56
2.2 Preliminaries	10	6.3.1 Resources	56
2.2.1 Installation and commissioning	10	6.3.2 Go "Online"	57
2.2.2 Rack assembly	10	6.3.3 Watch list	58
2.2.3 External devices	10	6.4 Optimize performance	59
3 Create a FOUNDATION Fieldbus Network	11	7 Go On-line	60
3.1 Create a FF project	11	7.1 Connect to the Field Controller	60
3.2 Determine the naming preferences	12	7.2 Generate the live lists	65
3.3 Add a bridge (SFC162)	13	7.3 Download the project	69
3.4 Add a fieldbus segment	14	7.4 Check the control strategy	73
3.5 Add the devices	15	7.5 Modify the project	75
3.6 Export tags	17	7.6 Packing and unpacking the project	77
4 Create a Control Strategy	18	7.7 Export the configuration	78
4.1 Add a Process Cell	18	7.8 Close Application Designer and OpenPCS	81
4.2 Add a Control Module	19	8 Trouble-Shooting	82
4.3 Create the function blocks	20	8.1 Factory initialisation and reset	82
4.4 Add the Function Block Links	22	8.2 Trouble-shooting tables	83
4.5 Configure the strategy	25	8.2.1 Field Controller	83
4.5.1 Changing parameters	25	8.2.2 Application Designer	84
4.5.2 Constant block (flow simulation)	26	Index	88
4.5.3 Analog Input (temperature)	27		
4.5.4 Cascade Signal Characterizer (temperature/ density)	28		
4.5.5 Analog Input (level)	30		
4.5.6 Analog Alarm (level)	31		
4.5.7 Multiple Discrete Input block (level limits, emergency stop)	32		
4.5.8 Hybrid Embedded I/O block	33		
4.5.9 Multiple Discrete Output block	34		
4.5.10 PID Control (level control of valve)	35		
4.5.11 Analog Output (valve positioner)	37		
4.6 Store the strategy as a template	38		
4.7 Attach the Function Blocks to the devices	39		

Revision History

Product version	Manual	Changes	Remarks
2.03.xx	BA056S/04/en/08.05	Original manual	
2.04.xx	BA056S/04/en/12.08	Application Designer	<ul style="list-style-type: none"> ■ Aliasing added and described in Chapters 2.1.3 , 3.2, 4.4 and 4.5 ■ Mixed hybrid block now embedded hybrid block
		OpenPCS	<ul style="list-style-type: none"> ■ Chapter I/O mapping deleted, replaced by aliasing
2.05.xx	BA056S/04/en/06.10	Editorial	<ul style="list-style-type: none"> ■ Version, documentation table, Windows support ■ Webserver screenshot updated
		Trouble-Shooting	<ul style="list-style-type: none"> ■ FRC LED description updated for battery power

Product Version

Details of product version and the individual components of Application Designer Suite can be seen in the About ControlCare dialog:

Start=>Programs=>Endress+Hauser=>ControlCare=>Tools=>About ControlCare

Registered Trademarks

PROFIBUS®

Registered trademark of the PROFIBUS User Organisation, Karlsruhe Germany.

FOUNDATION™ Fieldbus

Trademark of the Fieldbus Foundation, Austin, TX 78759, USA

Microsoft®, Windows®, Windows 2000®, Windows XP®, Windows 2003 Server®, Windows 2008 Server®, Windows 7®, Windows Vista® and the Microsoft logo are registered trademarks of the Microsoft Corporation.

Acrobat Reader® is a registered trade mark of the Adobe Systems Incorporated.

All other brand and product names are trademarks or registered trademarks of the companies and organisations in question

1 Safety

1.1 Designated use

ControlCare is a field-based control system comprising hardware and software components. It can be used to visualize, monitor and control production processes. The approved usage of the individual units used in the system can be taken from the corresponding parts of the operating instructions.

The software described in this particular manual allows the programming of the hybrid function block in IEC 61131-3 language as well as the engineering, configuring and commissioning of a ControlCare SFC162 FOUNDATION Fieldbus. The same procedures can be used for the SFC173 PROFIBUS Field Controller. Structured Text has been taken as an example, and the building of appropriate control strategies using it and the function blocks contained in the Field Controller and connected devices are described.

1.2 Installation, commissioning and operation

ControlCare Field Controllers have been designed to operate safely in accordance with current technical safety and EU directives. Essential to their use is the ControlCare Application Designer software suite, which allows control strategies to be created for FOUNDATION Fieldbus and PROFIBUS I/O applications. Field devices, links, junction boxes, cables and other hardware comprising the Fieldbus system must also be designed to operate safely in accordance with current technical safety and EU directives.

If devices are installed incorrectly or used for applications for which they are not intended, or if the controller is not configured correctly, it is possible that dangers may arise. For this reason, the system must be installed, connected, configured, operated and maintained according to the instructions in this and the associated manuals: personnel must be authorised and suitably qualified.

1.3 Operational safety

Location

Field Controllers must be mounted in a permanent and weather-protected location in a safe area. The environment shall be a metal cabinet or an installation frame with a well grounded mounting plane. The environment shall be protected.

Hazardous areas

The controller must be connected to networks operating in explosion hazardous areas via barriers or other safety components. When installing components in explosion hazardous areas:

- Ensure that all installation and maintenance personnel are suitably qualified
- Check that all equipment has the appropriate safety certificates
- Observe the specifications in the device certificates as well as national and local regulations.

This topic is discussed in BA013S (FF Guidelines) and BA034S (PROFIBUS Guidelines).

EMC

All modules are suitable for industrial use and conform with the following standard, see Appendix:

- EN 61326: 1997/A1: 1998
 - Interference emission: Class A apparatus
 - Interference immunity: as per Annex A, industrial environment

Depending upon the environment in which the bus is operating, particular attention should be paid to the grounding of the bus cables. This topic is discussed in BA013S (FF Guidelines) and BA034S (PROFIBUS Guidelines).

IP Address

A ControlCare Field Controller is normally configured from a workstation connected into the control system backbone. You will require a unique IP address to set it up.



Warning

- The use of IP addresses is strictly controlled. Usually your system administrator will be authorised to allocate unique addresses. Assigning an unauthorised address to a Field Controller may result in conflicts within your system and the failure of the associated devices!

It is recommended that ControlCare Field Controllers and OPC servers are not installed in an office network, as the large data packets exchanged between office equipment may lead to timeouts and intermittent communication errors. Ideally, the ControlCare system network should operate within its own IP domain; if this is not possible it should be separated from other parts of the network by a managed switch.

Since the system can be accessed and manipulated through the various ControlCare tools, it is advisable to control access both to the workstation and the folders in which the configuration is stored. Always make a back-up of the project.

Technical improvement

Endress+Hauser reserves the right to make technical improvements to its software and equipment at any time and without prior notification. Where such improvements have no effect on the operation of the equipment, they are not documented. If the improvements effect operation, a new version of the operating instructions is normally issued.

1.4 Conventions and icons

In order to highlight safety relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding icon in the margin.

Safety conventions

Icon	Meaning
	A note highlights actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned
	Caution! Caution highlights actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the instrument
	Warning! A warning highlights actions or procedures which, if not performed correctly, will lead to personal injury, a safety hazard or destruction of the instrument

1.5 ControlCare documents

Table 1.1 indicates the documents, planned and realized, containing safety relevant information, installation, commissioning and operating instructions for the equipment and software associated with ControlCare.

All documentation available at the time of release is included on the ControlCare CD-ROM and is installed in **Start=>Programs=>Endress+Hauser=ControlCare=Manuals** during set-up.

Component	Description	Document type	Designation	Order No.
System	ControlCare System Overview	Operating manual	BA016S/04/en	56004883
	ControlCare System Design	Operating manual	BA039S/04/en	Planned
	ControlCare System Specifications	Operating manual	BA040S/04/en	56004888
Software	Application Designer Overview	Operating manual	BA017S/04/en	70104301
	Application Designer: Local I/O Tutorial	Operating manual	BA032S/04/en	71095009
	Application Designer: FF Tutorial	Operating manual	BA019S/04/en	70101151
	Application Designer: PROFIBUS Tutorial	Operating manual	BA036S/04/en	70101152
	Application Designer: MODBUS Tutorial	Operating manual	BA037S/04/en	70101153
	Application Designer: IEC 61131-3 Ladder Logic Tutorial	Operating manual	BA038S/04/en	70101386
	Application Designer: IEC 61131-3 Structured Text Tutorial	Operating manual	BA056S/04/en	71060063
	Field Control (OPC) Servers	Operating manual	BA018S/04/en	71031428
	SFC162 Visitor	Operation manual	BA069S/04/en	71113457
Field Controller	Hardware Installation Guide	Operating manual	BA021S/04/en	56004885
	Commissioning and Configuration	Operating manual	BA035S/04/en	56004887
Function Blocks	Function Block Manual	Operating manual	BA022S/04/en	56004886
Set-Up	Getting Started	Operating manual	BA020S/04/en	56004884
General	FOUNDATION Fieldbus Guidelines	Operating manual	BA013S/04/en	70100707
	PROFIBUS Guidelines	Operating manual	BA034S/04/en	56004242

Tab. 1-1: ControlCare Documentation

2 Task Description

This tutorial describes the steps necessary for setting up the project described below. It does not aim to give an exhaustive account of Application Designer functions, but rather shows you one of a number of methods to reach your goal. The tags and names used in the tutorial are imaginary and will be different in a proper application. A full description of Application Designer functions is to be found in Application Designer Overview BA017S/04/en. Function block descriptions are to be found in BA022/04/en, Function Block manual.

2.1 Valve control for tank level

For this tutorial, the case of valve control for a tank level will be used, see Fig. 2-1.




Fig. 2-1: Overview of valve control for tank filling

A buffer tank provides a head of liquid for a downstream process. It is filled by recirculated and fresh liquid streams. The fresh liquid is added only when the level falls below 30%. The level of liquid in the tank is monitored by a level transmitter and controlled by a valve: ideally the level should be 60% of total capacity. The values monitored are the level and mass of liquid in the tank, the total flowrate of liquid and the number of times the pumps are switched on.

If the level of liquid exceeds 80%, the pumps are switched off. Similarly, if the level drops below 30%, the valve is closed and Pump 1 switched on. The hysteresis in both cases is 10%. In the event of the failure of the level transmitter, protection is provided against tank overspill and dry running of downstream pumps by two limit switches. An emergency stop is also possible.

The signals are acquired as follows:

- Temperature, level and valve position by appropriate FF devices
- Overspill protection, dry run protection and emergency stop to DI-0 to DI-2 inputs of a Field Controller SFC432 Mixed Discrete I/O module: 0 V = False, 24 V = True
- Pump output current from DO-0 and DO-1 outputs of the Field Controller SFC432 Mixed Discrete I/O module: NO relay, False = Pump ON, True = Pump OFF, Fail Safe = Pump OFF

For the tutorial all control is done in a FOUNDATION Fieldbus SFC162 Field Controller. The temperature and level devices provide only the measured values, the valve positioner responds to the output of the PID block. For this reason, the project can be replicated in the PROFIBUS SFC173 Field Controller, with PROFIBUS devices providing the measured values. The only differences lies in the creation of the FOUNDATION Fieldbus and Profibus networks, see the appropriate tutorials.

2.1.1 Control strategy

Fig. 2-2 shows a schematic diagram of the level control application. The analog level input is fed to the first Analog Alarm block which generates a true signal when the 30% LO limit is reached, the second Analog Alarm block generates a true signal when the 80% HI level is reached. The resulting discrete input signals are used to switch the pumps on and off as required. This is a standard function block, and eliminates the need to provide a similar signal conditioning program within the hybrid block.

The level and temperature signals are fed into the hybrid block which is used to calculate the various functions. Two constant blocks are used to simulate the liquid flow rates. The calculations of mass, flow and counter incrementation are all made within the hybrid block, which then outputs the results. The level signal is simply fed through the hybrid block to the PID block.

The Overspill, Dry Run and Emergency signals are collected in a Multiple Discrete Input block and the pump output control signal is fed to a Multiple Discrete Output block. The valve is closed on dry run or emergency by using the tracking parameter of the PID block. The control algorithm is programmed in the hybrid block.




Fig. 2-2: Schematic diagram of level control application

2.1.2 Control algorithm

The truth table for the hybrid function block has is as follows:

Function	IN_D1	IN_D2	IN_D3	IN_D4	IN_D5	OUT_D1	OUT_D2	OUT_D3
Overspill	True	–	–	–	–	True	True	–
Dry Run	–	True	–	–	–	–	–	True
Emergency	–	–	True	–	–	True	True	True
Tank 30%	–	–	–	True	–	–	–	True
Tank 80%	–	–	–	–	True	True	True	–

Overspill and 80% tank level must lead to the pumps being switched off. On emergency, the valve must be closed in addition. For Dry Run and 30% tank level the valve must be closed.

The calculations to be performed in the hybrid block are as follows:

- Mass of liquid = Volume x Density
for a horizontal cylinder of diameter 2 m and height of 3 m (0% to 100%)
Volume = $\pi r^2 l = (22/7) \times 1^2 \times 3 \times (\%Level/100)$
whereby the density of the liquid (kg/m³) is dependent upon temperature

0°C	4°C	10°C	20°C	30°C	40°C	50°C	60°C	70°C	80°C	90°C	100°C
999.9	1000	999.7	998.2	995.7	992.2	988.1	983.2	977.8	971.8	965.3	958.4

- Total flow = Flow_1 + Flow_2
- No. pump starts
No. of times pump switched on = No. of times OUT_D1 and OUT_D2 change from TRUE to FALSE

2.1.3 Aliasing

For this tutorial the signals to and from the multiple hybrid block will be aliased as follows:

Block	Signal	Block	Signal	Alias
AALM_2	OUT	HY_EMB_IO	IN_1	Product_Level
CCHAR	OUT		IN_2	Product_Density
CT_2	OUT		IN_3	Flow_1
CT_1	OUT		IN_4	Flow_2
MDI	OUT_D1		IN_D1	Tank_Overspill
	OUT_D2		IN_D2	Pump_Dry_Run
	OUT_D3		IN_D3	Emergency_Stop
AALM_1	OUT_ALM		IN_D4	LO_Level
AALM_2	OUT_ALM		IN_D5	HI_Level
Output from HSE server			IN_D6	Operator_Entry_Emergency
		–	Pump_Start_Counter_Reset	
HY_EMB_IO	OUT_1	PID	IN	Level_Output
	OUT_2	Output to IEC server		Product_Mass
	OUT_3			Total_Flow
	OPC retained			Number_Pump_Starts
	OUT_D1	MDO	IN_D1	Pump_1_Control
	OUT_D2		IN_D2	Pump_2_Control
	OUT_D3	PID	TRACK_IN_D	Close_Valve

The aliasing may be performed when characterizing the blocks, as described in the ladder Logic tutorial, BA038S/04/en, or in the creation of the strategy. Since for FOUNDATION Fieldbus it is normal to create the strategy before characterizing the blocks, the aliasing for links between blocks will be performed here. Contained parameters that are to be monitored by the supervisory system, however, must still be set up during characterization of the hybrid block.

2.1.4 Network

The project uses a FOUNDATION Fieldbus SFC162 with local I/O. The control strategy has been designed such that it can be transferred to a PROFIBUS SFC173 Field Controller, i.e. no control is done in the field. The network is assumed to be constructed as shown in Fig. 2-4.

- Temperature and level signals are supplied by FOUNDATION Fieldbus devices
- Flow signals would normally be supplied by FOUNDATION Fieldbus flowmeters, in our example however, they will be simulated by using Constant Blocks in the Field Controller
- The level overspill, dry rin and pump signals are acquired by a SFC432 Discrete Input/Output module
- The pump power supplies are connected to a SFC432 Discrete Input/Output module.




Fig. 2-3 Network for application example

2.2 Preliminaries

2.2.1 Installation and commissioning

Before you can start the IEC 61131-3 Structured Text tutorial, the Application Designer Suite must be installed on your computer, the SFC162 FOUNDATION Fieldbus Controller installed and commissioned and a connection made to your computer. Instructions on how to do this are to be found in:

- Operating Instructions BA020S/04/en, Getting Started
- Operating Instructions BA021S/04/en, Field Controller: Hardware Installation
- Operating Instructions BA035S/04/en, Field Controller: Commissioning and Configuration

Not all project steps are described in detail, so it is recommended that you also have the FOUNDATION Fieldbus or PROFIBUS tutorials at hand:

- Operating Instructions BA019S/04/en, Application Designer: FOUNDATION Fieldbus tutorial
- Operating Instructions BA036S/04/en, Application Designer: PROFIBUS tutorial

2.2.2 Rack assembly

The SFC162 Field Controller and SFC432 Discrete I/O module have combined power demand of 132 mA @ 24 VDC and 760 mA @ 5 VDC. Even allowing for a tolerance of 20%, this is easily covered by a SFC050 or SFC056 rack power module (300 mA @ 24 VDC and 3000 mA @ 5 VDC). The SFC353 module is powered by the SFC252 fieldbus power supply and need not be considered in the calculation. See Chapter 10 of BA040S/04/en, ControlCare, System Specifications.

The Field Controller and local I/O are mounted on two SFC901A rack assemblies with **addresses 0 and 1** (I/O cannot be mounted on a rack with the address "0".) The parameters for commissioning the Field Controller are shown in Table 2-1.

	Rack 0				Rack 1			
	Slot 0	Slot 1	Slot 2	Slot 3	Slot 0	Slot 1	Slot 2	Slot 3
Module	SFC050	SFC162	SFC252	SFC353	SFC432	Dummy	Dummy	Dummy
IO_TYPE_Rx	No I/O	No I/O	No I/O	No I/O	8 DisIn 4 DiscOut	No I/O	No I/O	No I/O
Channel Group A	–	–	–	–	1009	–	–	–
Channel Group B	–	–	–	–	1019	–	–	–

Tab. 2-1: Parameter settings for rack in hardware configuration and function blocks

Note!



- The channels used to connect to the modules to the function blocks are given by the Rack (R), Slot (S), Group (G) and I/O point (P) indices = RRGSP, whereby counting starts at "0".
- Since Multiple Discrete Input and Output blocks are being used for the discrete signals, the I/O point index is "9", see BA035S/04/en, Field Controller, Commissioning and Configuration.


2.2.3 External devices

ControlCare local I/O modules are available with passive electrical circuits only, so that any connected devices or external circuits must have their own power supply, see BA035S/04/en, Field Controller, Commissioning and Configuration.


3 Create a FOUNDATION Fieldbus Network

3.1 Create a FF project


- 1 Start ControlCare Application Designer by clicking on the icon on your desktop or via **Start => Programs => Endress+Hauser => ControlCare => ControlCare Application Designer**
- 2 The project starts from a blank application screen
 - With the right mouse key select **Project File=>New**



- 1 The **Document Type** box appears: Click the option **Project**



- 2 The **New Project** dialog box opens:




1. Choose the folder where the project will be saved.
 2. Type the name of the project in the File Name box.
 3. Click **Save**.
If the new project is not to be created, click **Cancel**.
- 3 ControlCare Application Designer automatically creates a folder with the entered file name within the selected folder.

3.2 Determine the naming preferences

Before you start, you can set preferences for the way your project is created. Of particular interest at this stage is the labelling of the function blocks.

- 1 Press **Project File => Preferences**
 - The **Preferences** Dialog appears



Tag Policy

Tag Policy determines how the blocks are labelled by default if no tag names are entered

- 1 Select the folder **Block** and the subfolder **Tag Policy**, then check the following buttons
 - **Device**
 - **Update Block Tag**
- 2 Press **OK** to confirm your selection
 - Application Designer will now automatically rename any blocks created in the control strategy window as they are assigned to the devices by adding the device tag as prefix.

Tag Composition

Tag Composition determines how the block identifiers are added to the block tag if no block name is entered.

- 1 Select the subfolder **Tag Composition**:
 - Enter a mnemonic separator: for this manual the setting was "-"
Default setting is "_" and mandatory for if flexible function blocks are to be used
 - Check **Prefix**
- 2 Press **OK** to confirm your selection
 - Application Designer will now automatically compose the blocks according to your selection, e.g. TagName-Block-n or TagName_Block_n.

Export Tag

Export Tag causes tags to be automatically exported every time the project goes online

- 1 Select the subfolder **Export Tag**
 - Check the **Automatic** button
 - Press **OK** to confirm your selection


Strategy

Strategy determines the default shape of the function block icons in the strategy window and also whether the aliasing function is enabled


- 1 Select the subfolder **Strategy**
 - Select the default shape for function block objects
 - Select "Aliasing Input Dialog Box"
 - Press **OK** to confirm your selection

3.3 Add a bridge (SFC162)


- On saving, ControlCare Application Designer automatically creates a project, adding the HSE fieldbus network and the HSE Host
 - Click on + to expand the tree:



- Now right-click on the **HSE Network** leaf and select **New=>Bridge**



- The **New Bridge** dialog box appears:
Select the SFC162 Field Controller and type in a device TAG, in our case FC_01




If you do not type in a tag, the default will be "Bridge n", where n is a consecutive number.


- Press **OK** to create the Bridge.
- Repeat Steps 1 to 4 for as many SFC162 Field Controllers as you have in your network.

3.4 Add a fieldbus segment


- 1 The project now looks like this:



- 2 Right click on the bridge you just created, here "FC_01", and select **New Fieldbus**.



- 3 The **New Fieldbus** dialog box appears:
 - Enter a Fieldbus TAG,
 - Select the fieldbus port on the SFC162




- If you do not type in a tag, the default will be "Fieldbus n", where n is a consecutive number.


- 4 Press **OK** to create the Fieldbus.
- 5 Open **Project File**, then press **Save**, to save the project.
- 6 Repeat Steps 1 to 5 for as many fieldbus segments as are in use.

3.5 Add the devices


- 1 Click on the newly created **Fieldbus 1** leaf and select **Expand**



- 2 A new work space Fieldbus 1 opens:
 - Right-click on the **Fieldbus 1** leaf and select **New** then **Device**



- 3 The **New Device** dialog appears




- Select the **Device Manufacturer** = Endress+Hauser
- Select the **Device Type** = TMT162
- Enter the **Device Tag** = TT100
If you do not type in a tag, the default will be "Device n", where n is a consecutive number
- Press **OK** to create the device

Note!



- Application Designer follows the latest DD and CF revisions by default.
- If you are working with devices with older DD and CF revisions, uncheck the checkbox and select the correct Device Revision.


4 Your project now looks like this:



5 Repeat Steps 2 and 3 for the Micropilot M and the ND9103FN positioner

- Micropilot M:
Manufacturer = Endress+Hauser
Device Type = Micropilot M
Device Tag = LT101
- ND9103FN:
Manufacturer = Metso Automation
Device Type = Metso FBLK Interface
Device Tag = FCV102
- Note: If the flowmeters existed, they would now be added to the project with the tags FT103 and FT104

6 Your project should now look like this:



7 Open **Project File**, then press **Save**, to save the project.


3.6 Export tags




Note!

- You should use the **Export Tags** function everytime you change the configuration of the project, so that the OPC server information is always up-to-date.
- Application Designer can be set up to automatically export tags everytime the system goes online, see Chapter 3.2

- 1 Active the project view by clicking in its workspace



- 2 Right click on the project name, a context menu appears



- 3 Select the option **Export Tags...**
 - The Export Tags dialog confirms the successful export




- Press **OK** to close the dialog
- 4 Open **Project File**, then press **Save**, to save the project

4 Create a Control Strategy


Having created a physical view of the process, the next step is to create control strategy. This is done in the logical view of the plant. This represents the plant as Areas/Process Cells in accordance with ISA S88/IEC 61518.

4.1 Add a Process Cell

- 1 Click on the "Area 1" leaf in the project and select **Attributes...**




- 2 The **Attributes** dialog box appears




- Enter a name for the area, e.g. Sterilization
- Click **OK** to store your changes

- 3 Click on the Area leaf again and select **New Process Cell...**



- 4 The **Process Cell** dialog box appears




- Enter a name for the process cell, e.g. Buffer tank
- Click **OK** to store your changes

- 5 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.2 Add a Control Module


- 1 Right-click on the Process Cell leaf you just created and select **Expand**




- 1 A new window with the name of the leaf opens
 - Right-click on the top leaf and select **New Control Module**



- 2 The **Control Module** dialog box appears



- Enter a name for the control module, e.g. Level control
 - Click **OK** to store your changes
- 3 The project now looks something like this:




- 4 For a real project, Step 2 and 3 would be repeated until all the required control modules for a particular process cell have been added.
- 5 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.3 Create the function blocks


Note!




- The function blocks used in the tutorial are selected from the device manufacturer's device list. It is also possible to select standard function blocks from the "Fieldbus Foundation" list. This ensures that the control strategy can be executed in any FF device that supports a particular standard block, irrespective of vendor.
 - Endress+Hauser devices support standard function blocks and offer them in the manufacturer specific list.
- 1 Double-click on the control module leaf or right-click and select **Expand** to open the **Control Strategy** workspace - this has the same name as the leaf



- 2 Press the Function Block button  in the toolbar and click in the workspace
 - The **New Block** dialog appears




- Select the **Manufacturer** = Endress+Hauser
 - Select the **Device Type** = TMT162
 - Select the **Block Type** = Analog Input
 - Press **OK** to create the function block
- 3 The block now appears in the strategy window with the default name



4 Repeat Steps 2 and 3 for the following blocks

Device	Number	Manufacturer	Device Type	Block Type
iTemp TMT162	1x	Endress+Hauser	TMT162	Analog Input (AI)
Micropilot M	1x	Endress+Hauser	Micropilot M	Analog Input (AI)
ND9103FN	1x	Metso Automatioin	FBLK Interface	Analog Output (AO)
SFC162	2x	Endress+Hauser	SFC162	Constant (CT)
	2x	Endress+Hauser	SFC162	Analog Alarm (AALM)
	1x	Endress+Hauser	SFC162	Multiple Discrete Input (MDI)
	1x	Endress+Hauser	SFC162	Multiple Discrete Output (MDO)
	1x	Endress+Hauser	SFC162	Hybrid With Mixed I/Os (HY_EMB_IO)
	1x	Endress+Hauser	SFC162	PID Control (PID)
	1x	Endress+Hauser	SFC162	Cascade Characterizer (CCHAR)


5 The control strategy now looks like this




6 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.4 Add the Function Block Links


- 1 In the Control Strategy workspace position the blocks according to your strategy




- The blocks can be dragged and dropped by selecting and holding down the right mouse key
- The blocks can be aligned by selecting, then via **Tools => Alignment => e.g. Middle** followed by a click on the block to which the alignment is to be made
- The **Tools** menu also contains other standard drawing functions such as toolbars, standard shapes, line thickness, colours etc.




- Texts can be added to the strategy by opening the drawing toolbar via **Tools => Tool Boxes => Drawing** then clicking on the "ABC" button and placing the cursor at the desired position in the strategy workspace




- The text font can be changed by activating the text box in the strategy and right clicking: **Properties => Text Attributes => Font**

- 2 Click on **Function Block Link**  button in the tool bar, the cursor changes to a cross
 - Select the **Level control AI_1** block: the **Output Parameter Selection** dialog appears




- 3 Click the box next to **OUT** – it changes color – then click on **OK**
 - The **Output Parameter Selection** dialog closes
 - The cursor is now connected to a blue dotted line
 - Place the Cursor in the **Level control CCHAR_1** block and click to make the link
- 4 When the link is made, the **Input Parameter Selection** dialog for the CCHAR block appears




Click the box next to **IN_1** – it changes color – then click on **OK**

- 5 The **Rename** dialog now appears: for the
 - For the link between AI_1 and CCHAR_1 we have no alias, so press **OK** without making an entry - the link retains the standard name
 - For the links with an alias, enter the alias name then press **OK**
- 6 When the **Rename** dialog disappears, the link is made and appears as below:



- The link appears as a dotted line because the function block has yet to be attached to a device
- The parameter legends "IN_1" and "OUT" by moved by drag & drop

- 7 Repeat steps 2 to 5 and make the following links between the function blocks:
- CCHAR1 and HY_EMB_IO_1 = **OUT_1** to **IN_2**, Alias name: Product_Density
 - AI_2 and AALM_1 = **OUT** to **IN**, No alias name
 - AALM_1 and AALM_2 = **OUT** to **IN**, No alias name
 - AALM_1 and HY_EMB_IO_1 = **OUT_ALM** to **IN_D4**, Alias name: LO_Level
 - AALM_2 and HY_EMB_IO_1 = **OUT_ALM** to **IN_D5**, Alias name: HI_Level
 - AALM_2 and HY_EMB_IO_1 = **OUT** to **IN_1**, Alias name: Product_Level
 - MDI_1 and HY_EMB_IO_1 = **OUT_D1** to **IN_D1**, Alias name: Tank_Overspill
 - MDI_1 and HY_EMB_IO_1 = **OUT_D2** to **IN_D2**, Alias name: Pump_Dry_Run
 - MDI_1 and HY_EMB_IO_1 = **OUT_D3** to **IN_D3**, Alias name: Emergency_Stop
 - CT_2 and HY_EMB_IO_1 = **OUT_1** to **IN_3**, Alias name: Flow_1
 - CT_1 and HY_EMB_IO_1 = **OUT_1** to **IN_4**, Alias name: Flow_2
 - HY_EMB_IO_1 and PID_1 = **OUT_1** to **IN**, Alias name: Level_Output
 - HY_EMB_IO_1 and PID_1 = **OUT_D3** to **TRK_IN_D**, Alias name: Close_Valve
 - HY_EMB_IO_1 and MDO_1 = **OUT_D1** to **IN_D1**, Alias name: Pump_1_Control
 - HY_EMB_IO_1 and MDO_1 = **OUT_D2** to **IN_D2**, Alias name: Pump_2_Control
 - PID_1 and AO_1 = **OUT** to **CAS_IN**, No alias name
 - AO_1 to PID_1 = **BKCAL_OUT** to **BKCAL_IN**, No alias name
- 8 Since the input and output signals for a particular link now have the same names, you may want to hide some:
- Right click on the link, select **Labels** and click on the parameter you want to hide
 - The label is hidden when there is no tick on the "Show...." parameter
- 9 Your Control Strategy now looks something like this (only outputs shown)



- 10 Open **Project File**, then press **Save Entire Configuration**, to save the project.


4.5 Configure the strategy

At this point we have created a network with devices and a control strategy. In this section, we describe how the strategy is configured. You may prefer to configure the devices first, see Chapter 5, then the strategy. In strategies using many blocks and links you may decide that it is simpler to create and configure the devices and strategy piece by piece. Application Designer allows all these options.


4.5.1 Changing parameters

Procedure

- 1 Right click on the function block and select **Offline Characterization**
 - The Offline Characterization dialog opens with a predefined list of parameters



- If required, the complete set of parameters can be viewed by pressing the **All** button
- 2 If necessary expand the parameter tree
 - Double-click on the "Value space" next to the parameter
 - Either select a parameter offered by the drop-down menu, or if no menu is present enter the parameter by hand



- 3 Press **End Edit** to register your change
 - **Cancel Edit** will cancel the Edit and close the value space
 - **Clear** will delete the selected parameter
 - When all parameters have been edited, press **Close** to close the dialog

Order of parameters

Some block parameters have a write check based on the value of other parameters. It is therefore important to set the parameters in the order in which they are displayed in the **Off Line Characterization** dialog. After characterization of the block, the parameters will appear in the FOUNDATION Fieldbus and Process Cell trees. If you find a parameter in the wrong position, it can be moved by dragging and dropping to the correct one.

4.5.2 Constant block (flow simulation)

In our tutorial, the flow meters will be simulated by two Constant blocks (CT1 and CT2), which represent the Analog Input blocks that would normally supply the measured values to the strategy. Each Constant block allows up to six analog values (floating point) and two discrete values (0, 1) to be simulated.

The parameters to be set are shown in Table 4-1 below, whereby any block parameters renamed during the creation of the strategy appear with their alias names:

Parameter	Function	Value
Level Control_CT_1 (= Flow_1)		
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
CT_VAL_1	Value to be output as OUT_1 by the constant block	35
Level Control_CT_2 (= Flow_2)		
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
CT_VAL_1	Value to be output as OUT_1 by the constant block	48

Tab. 4-1: Parameters for Constant blocks


Note!

- The block already contains the alias names of any link parameters renamed in the strategy



Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_CT_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Set **CT_VAL_1** to 35
 - Remember to press **End Edit** after every change
 - When all parameters have been entered, press **Close** to quit the Characterization dialog
- 3 Repeat Steps 1 to 2 for the parameters in the **Level control_CT_2** block, see table 4.1.
 - 4 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.3 Analog Input (temperature)

The Analog Input function block **Level control_AI_1** for the TMT162 must now be configured, see Table 4-2. A full description of the parameters is to be found in Operating Instructions BA224REN.


Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
XD_SCALE/EU_100*	Upper range value for process variable	100 (max.850)
XD_SCALE/EU_0	Lower range value for process variable	0 (min. -200)
XD_SCALE/UNITS_INDEX	Unit of process variable	°C
OUT_SCALE/EU_100	Upper range limit for output variable	100
OUT_SCALE/EU_0	Lower range limit for output variable	0
OUT_SCALE/UNITS_INDEX	Unit of output variable	%
CHANNEL	Output channel of TMT162 Transducer Block connected to Analog Input Block. ■ Sensor Value 1: direct acquisition of temperature measured by thermoelement 1	Sensor Value 1
L_TYPE	Selects the type of linearisation for the input value. ■ Indirect: PV value scaled to OUT value	Indirect

*The range limits for the TMT162 temperature transmitter are determined by the transducer block parameters SENSOR_TYPE and PRIMARY_OUTPUT_TYPE. For SENSOR_TYPE = Pt100 and PRIMARY_OUTPUT_TYPE = SV_1 the transducer block outputs a temperature signal in the range -200°C to +850°C. The XD_SCALE and OUT_SCALE parameters generate the OUT value of the Analog Input block from any part of this range, in our case -50°C to 150°C.

Tab. 4-2: Basic parameters for Analog Input blocks

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_AI_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
- Expand the **XD_SCALE** node and enter the parameters in Table 4-2
- Expand the **OUT_SCALE** node and enter the parameters in Table 4-2
- Set **Channel** to **Sensor Value 1**
- Set **L_TYPE** to **Indirect**
- Remember to press **End Edit** after every change
- When all parameters have been entered, press **Close** to quit the Characterization dialog

- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.4 Cascade Signal Characterizer (temperature/density)

The Cascade Signal Characterizer block **Level control_CCHAR_1** allows the entry of a strapping table of up to 51 values for conversion of one variable to another, e.g. a linearization from % level to volume. The resolution of the characteristic curve can be increased by using several blocks in cascade.

In our case it will be used to calculate the density of the liquid at the measured temperature according to the table in Section 2.1.2. The density is then be used to calculate the mass of liquid in the tank. The parameters to be set are shown in Table 4-3, whereby any block parameters renamed during the creation of the strategy appear with their alias names:.

Parameter	Function	Value
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
X_RANGE/EU_100*	Upper range value for input variable	100
X_RANGE/EU_0	Lower range value for process variable	0
X_RANGE/UNITS_INDEX	Unit of process variable	%
Y_RANGE/EU_100	Upper range limit for output variable	1000
Y_RANGE/EU_0	Lower range limit for output variable	958.4
Y_RANGE/UNITS_INDEX	Unit of output variable	kg/m ³
E_CURVE_X/[1] E_CURVE_X/[2] E_CURVE_X/[3] E_CURVE_X/[4] E_CURVE_X/[5] E_CURVE_X/[6] E_CURVE_X/[7] E_CURVE_X/[8] E_CURVE_X/[9] E_CURVE_X/[10] E_CURVE_X/[11] E_CURVE_X/[12]	X values (input variable) of strapping table <ul style="list-style-type: none"> Values must rise or fall monotonically Values must be within the range defined by X_RANGE Unedited values are automatically set to infinity, which means they are not used 	0 (%) 4 10 20 30 40 50 60 70 80 90 100
E_CURVE_Y/[1] E_CURVE_Y/[2] E_CURVE_Y/[3] E_CURVE_Y/[4] E_CURVE_Y/[5] E_CURVE_Y/[6] E_CURVE_Y/[7] E_CURVE_Y/[8] E_CURVE_Y/[9] E_CURVE_Y/[10] E_CURVE_Y/[11] E_CURVE_Y/[12]	Y values (input variable) of strapping table^ <ul style="list-style-type: none"> Exactly the same number of values must be entered as for the X_CURVE Values must be within the range defined by Y_RANGE Unedited values are automatically set to infinity, which means they are not used 	999.9 (kg/m ³) 1000 999.7 998.2 995.7 992.2 988.1 983.1 977.8 971.8 965.3 958.4
CAS_CONTROL	Determines whether the block is cascaded with others and what position it has in the chain <ul style="list-style-type: none"> None: block is used on its own 	None

Tab. 4-3: Basic parameters for Cascade Characterization blocok


Note!



- The temperature range in the table is 0°C to 100°C and corresponds exactly to the 0% to 100% signal output by the Level control AI_1 block. If a different range were required, the XD_SCALE and OUT_SCALE values of the AI block could be adjusted accordingly.
- The standard FOUNDATION Fieldbus block Signal Characterizer (SC) performs the same function, but has only 20 points and cannot be cascaded. The corresponding parameters are missing.

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_CCHAR_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Expand the **XD_SCALE** node and enter the parameters in Table 4-3
 - Expand the **OUT_SCALE** node and enter the parameters in Table 4-3
 - Expand the **E_CURVE_X** node and enter the parameters in Table 4-3
 - Expand the **E_CURVE_Y** node and enter the parameters in Table 4-3
 - Click on **CAS_CONTROL** and select **None** from the drop-down menu
 - Remember to press **End Edit** after every change
 - When all parameters have been entered, press **Close** to quit the Characterization dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project. Basic PID parameters

4.5.5 Analog Input (level)


The Analog Input function block **Level control_AI_2** for the Micropilot M must now be configured, see Table 4-4. A full description of the parameters is to be found in the FOUNDATION Fieldbus Operating Instructions for the Micropilot M BA278F/00/en.

Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
XD_SCALE/EU_100*	Upper range value for process variable	100
XD_SCALE/EU_0	Lower range value for process variable	0
XD_SCALE/UNITS_INDEX	Unit of process variable	%
OUT_SCALE/EU_100	Upper range limit for output variable	100
OUT_SCALE/EU_0	Lower range limit for output variable	0
OUT_SCALE/UNITS_INDEX	Unit of output variable	%
CHANNEL	Output channel of Micropilot Transducer Block connected to Analog Input Block. ■ Measured value: level as measured according to full and empty calibration	Measured value
L_TYPE	Selects the type of linearisation for the input value. ■ Indirect: PV value scaled to OUT value	Indirect

Tab. 4-4: Basic parameters for Analog Input blocks

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_AI_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Expand the **XD_SCALE** node and enter the parameters in Table 4-2
 - Expand the **OUT_SCALE** node and enter the parameters in Table 4-2
 - Set **Channel** to **Measured value**
 - Set **L_TYPE** to **Indirect**
 - Remember to press **End Edit** after every change
 - When all parameters have been entered, press **Close** to quit the Characterization dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.6 Analog Alarm (level)

The Analog Alarm function blocks **Level control_AALM_1** and **Level control_AALM_2** for the Micropilot M must now be configured, see Table 4-5, whereby any block parameters renamed during the creation of the strategy appear with their alias names. These blocks monitor the incoming level signal. If the signal drops below a LO or LO_LO limit, the OUT_ALM signal changes from FALSE to TRUE (**Level control_AALM_1**). If the signal exceeds a HI or HI_HI limit, the OUT_ALM signal changes from FALSE to TRUE (**Level control_AALM_2**). The change from FALSE to TRUE can be used by a downstream block to initiate some process, in our case to switch off the pumps or close the valve, see Chapter 2.1.2.


In order to avoid flutter due to changes in level around the switching points, an alarm hysteresis is set. Thus OUT_ALM will switch from FALSE to TRUE when the level drops below 30%, but will not switch back from TRUE to FALSE until the level has reached 32%. For the HI limit, the corresponding values are 80% and 78% respectively.

Parameter	Function	Value
Level control_AALM_1		
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
OUT_ALM_SUM	Alarms to be monitored in the alarm summary	LO
ALARM_HYS	Alarm hysteresis as percentage of span	2 (%)
LO_LIM	Value of LO limit in units of the incoming variable	30 (%)
Level control_AALM_2		
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
OUT_ALM_SUM	Alarms to be monitored in the alarm summary	HI
ALARM_HYS	Alarm hysteresis as percentage of span	2 (%)
HI_LIM	Value of HI limit in units of the incoming variable	80 (%)

Tab. 4-5: Basic parameters for Analog Input blocks

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_AALM_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Select the **OUT_ALM_SUM** node and select LO from the drop-down menu
 - Set **ALARM_HYS** to 2
 - Set **LO_LIM** to 30
- 3 Repeat the procedure for Level control_AALM_2 using the parameters in Table 4-5
 - 4 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.7 Multiple Discrete Input block (level limits, emergency stop)


The MDI block connects the signals from the SFC432 Discrete Input/Output module to the control strategy. This delivers FALSE for a 0 VDC signal and TRUE for a 24 VDC signal. The channel parameter is that in Table 2-1, Chapter 2.2.2. Any block parameters renamed during the creation of the strategy appear with their alias names.

Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
CHANNEL	Signal channel: Rack, Slot, Group, 9 = all inputs	1009

Tab. 4-6: Basic parameters for Multiple Discrete Input block

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_MDI_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Set **CHANNEL** to 1009
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.8 Hybrid Embedded I/O block

The HY_EMB_IO block adds the logic to the control strategy. It contains a flexible function block which connects the various inputs to its outputs via a logical algorithm that may be programmed in any of the IEC 61131-3 function block languages. The programming is described in Chapter 5.


At this point only the MODE_BLK target should be set.

Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
HYB_STATUS_OPTS	Sets status options of IEC 61131-3 variables <ul style="list-style-type: none"> None: the status will be set within the block Set Outputs to Good Non Cascade: all outputs will be automatically set to good, irrespective of input 	None
EXEC_TIME_TARGET	Target time for execution of the hybrid block	30 ms (default)

Tab. 4-7: Basic parameters for Multiple Discrete Input block

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_MDI_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and check that the **Target** is set to **Auto**
 - Set the parameter **HYB_STATUS_OPTS** to **None**
- In the exercise, the status of the outputs will be considered in the ST program.
If this is not the case, the parameter should be set to **Set Outputs to Good Non Cascade**

- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.9 Multiple Discrete Output block


The MDO block is attached to the SFC432 Discrete Input/Output module to which the pump power is connected. The SFC432 has normally closed (NC) relays. A FALSE (=0) signal causes the relay to open and the pump stops. A TRUE (=1) signal causes the relay to close and the pump starts. In the event of a power failure, the pump fails to safe = stop. The channel parameter is that in Table 2-1, Chapter 2.2.2. Any block parameters renamed during the creation of the strategy appear with their alias names.

Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
CHANNEL	Signal channel: Rack, Slot, Group, 9 = all outputs	1019

Tab. 4-8: Basic parameters for Multiple Discrete Input block

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_HY_EMB_IO_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**

– Set **CHANNEL** to 1019
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.10 PID Control (level control of valve)

The Field Controller PID blocks must now be characterized. In practice, the values for the GAIN, RESET and RATE as well as the setpoint value SP for the level loop will be known. The other values determine the way the control is handled when the block moves from Auto/Cas to Man or another mode or when a process value has a bad status. See also ControlCare Function Block manual BA022S/04/en.

In case of an emergency stop or dry run, we want the valve to close. This is done by overriding the automatic mode and forcing the valve to close. To this end, output tracking must be enabled in the CONTROL_OPS parameter and the appropriate ranges and value set for the TRK parameters. Now when the TRK_IN_D signal is true, the valve is forced into the TRK_VAR position.

Note!

- The TRK_IN_D parameter has alias name "Close_Valve", since it was renamed in the strategy




Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block	Auto
SP/VALUE	Setpoint for ideal level	60%
PV_SCALE/EU_100	Upper range limit for process variable	100
PV_SCALE/EU_0	Lower range limit for process variable	0
PV_SCALE/UNITS_INDEX	Unit of process variable	%
OUT_SCALE/EU_100	Upper range limit for output variable	100
OUT_SCALE/EU_0	Lower range limit for output variable	0
OUT_SCALE/UNITS_INDEX	Unit of output variable	%
CONTROL_OPTS	Sets control options for bad input Enables output tracking	Bypass Enable Track Enable
STATUS_OPTS	Sets the way the status of the tracking value is used	Use uncertain as good
BYPASS	When ON, SP value is transferred to the OUT without the calculation of PID terms.	OFF
SP_RATE_DN	Rate of change from old to new, higher SP	0
SP_RATE_UP	Rate of change from old to new, lower SP	0
GAIN	Tuning constants for the P, I and D terms, of the PID block respectively.	1.5
RESET		0.1 s
RATE		0.5 s
SHED_OPT	Behaviour when shedding from remote mode	Normal shed, normal return
TRK_SCALE/EU_100	Upper range limit for tracking variable	100
TRK_SCALE/EU_0	Lower range limit for tracking variable	0
TRK_SCALE/UNITS_INDEX	Unit of tracking variable	%
TRK_VAL/STATUS	Status to be sent with tracking value	GoodCascade:Local
TRK_VAL/VALUE	Value to be forced on OUT, 0 = closed	0

Tab. 4-9: Basic parameters for temperature and flow PID blocks

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_PID_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1
 - Press the **All** button to reveal all parameters



- Expand the **Mode Block** node and set the **Target** to **Auto**
 - Expand the **SP** node and set the **SP_VALUE** to 60
 - Expand the **PV_SCALE** node and enter the parameters in Table 4-9
 - Expand the **OUT_SCALE** node and enter the parameters in Table 4-9
 - Click on **CONTROL_OPS** and tick **Bypass Enable** and **Track Enable** from the drop-down menu
 - Click on **STATUS_OPS** and tick **Use uncertain as Good** from the drop-down menu
 - Click on **BYPASS** and select **OFF** from the drop-down menu
 - Click on **SP_RATE_DN** and set to zero
 - Click on **SP_RATE_UP** and set to zero
 - Click on **GAIN** and set to 1.5
 - Click on **RESET** and set to 0.1
 - Click on **RATE** and set to 0.5
 - Click on **SHED_OPT** and select **NormalShed:NormalReturn** from the drop-down menu
 - Expand the **TRK_SCALE** node and enter the parameters in Table 4-9
 - Expand the **TRK_VAR** node and enter the parameters in Table 4-9
 - Remember to press **End Edit** after every change
 - When all parameters have been entered, press **Close** to quit the Characterization dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.5.11 Analog Output (valve positioner)

The Analog Output block **Level control_AO_1** for the ND9103FN now has to be configured. The basic parameters required are shown in Table 4-10. A full description of the parameters are to be found in the Operating Instructions


- ND9000F Users Guide, downloadable from www.metso.com

Parameter	Function	Positioner FCV102
MODE BLOCK/TARGET	Normal operating mode of block	Cas
PV_SCALE/EU_100	Upper range limit for process variable	100
PV_SCALE/EU_0	Lower range limit for process variable	0
PV_SCALE/UNITS_INDEX	Unit of process variable	%
XD_SCALE/EU_100	Upper range limit for output variable	15
XD_SCALE/EU_0	Lower range limit for output variable	3
XD_SCALE/UNITS_INDEX	Unit of output variable	psi
CHANNEL	Defines the signal configuration between the AO block and transducer block.	AO: valve control (not writable if DO channel active)
SHED_OPT	Behaviour when shedding from remote mode	Normal shed, normal return

Tab. 4-10: Basic parameters for Analog Output block

Procedure

- 1 In the Control strategy workspace, double-click on the **Level control_AO_1** block
- 2 The **Off Line Characterization** dialog opens, see Chapter 4.5.1



- Expand the **Mode Block** node and set the **Target** to **Auto**
- Expand the **PV_SCALE** node and enter the parameters in Table 4-10
- Expand the **OUT_SCALE** node and enter the parameters in Table 4-10
- Click on **CHANNEL** and select **AO: valve control (not writable if DO channel active)** from the drop-down menu
- Click on **SHED_OPT** and select **NormalShed:NormalReturn** from the drop-down menu
- Remember to press **End Edit** after every change
- When all parameters have been entered, press **Close** to quit the Characterization dialog


Tab. 4-11: Open **Project File**, then press **Save Entire Configuration**, to save the project.

4.6 Store the strategy as a template


FOUNDATION Fieldbus offers the possibility of storing complete control strategies as fully configured generic templates. This is especially useful when particular control strategies occur several times within a project. The strategies are stored independent of device assignment, which is performed as a separate step. The IEC 61131-3 algorithm is not stored in the template.


After configuration, the strategy can be stored as a template for similar applications using the same devices.

- 1 In the Strategy workspace, drag the mouse across the complete strategy with the left button depressed, until all function blocks are selected



- 2 Now press the **Strategy Export** button  in the toolbar
 - The **Save As** dialog appears



- If appropriate, browse to another folder
 - Enter a **File Name**
 - Press **Save** to save the strategy
- 3 The strategy can be imported again pressing the **Strategy Import** button  in the toolbar and double-clicking on the appropriate file name.


4.7 Attach the Function Blocks to the devices

Now attach the function blocks in the control strategy to the devices where they are to run. The order of attachment determines the order of execution in the Field Controller and FF devices.

- First attach the input blocks
- Then attach the control and logic blocks in the order of execution
- Finally attach the output blocks


If necessary, the order of the blocks can be adjusted by drag & drop.

- 1 Expand the **Fieldbus** workspace (Fieldbus 1) and the **Process Cell** workspace (Heat exchanger)




- Note that the Buffer Tank tree now contains all the function blocks that you created in the Control Strategy workspace.
 - A question mark in a block means that the block has still to be attached to a device.
- 2 Now drag and drop the **Level control_AI_1** block to the greyed Function Block Application leaf of the TT100 tree
 - When you drop the block, it is attached to tree
 - Its name changes to TT100-AI-1 in both views
 - You have now assigned the Temperature AI block to the temperature transmitter
 - 3 Repeat Step 2 for the other function blocks, dragging them across in the required order of execution:
 - **Level control_AI_2** => LT101
 - **Level control_CT_1** => FC_01
 - **Level control_CT_2** => FC_01
 - **Level control_AALM_1** => FC_01
 - **Level control_AALM_2** => FC_01
 - **Level control_CCHAR_1** => FC_01
 - **Level control_MDI_1** => FC_01
 - **Level control_HY_EMB_IO_1** => FC_01
 - **Level control_PID_1** => FC_01
 - **Level control_MDO_1** => FC_01
 - **Level control_AO_1** => FCV102

4 Your project now looks like this



and the strategy looks like this:



5 Click on the **Project View** workspace and **Export Tags...**, see Chapter 3.5

6 Open **Project File**, then press **Save Entire Configuration**, to save the project.

Note!



- Function blocks can also be attached to devices by right-clicking on the FB VFD or FBAP node of the appropriate device in the Fieldbus workspace and selecting **Attach Block...**

5 Parameter the Devices

It is important to remember that the device parameters in the Transducer Block are an integral part of any FOUNDATION Fieldbus project. This has consequences in the way the devices can be parameterized:

- The most secure method is to parametrize offline with the Application Designer – this ensures that you are downloading a complete set of parameters to the devices
- For devices with display operation or a service interface, it is possible to parametrize at the device itself. If you wish to parametrize by this method, it is important that only the Mode Block Target is parametrized in Application Designer.
- If the device has a HistoROM, this must be activated in the offline configuration, otherwise the device will show a HistoROM error after the download.
- Application Designer does not support device parameter upload at the moment: this means that if you have used a service tool or the display to parametrize, the device parameters are not stored centrally in the project. A device failure means that the replacement device has to be parametrized anew. This can be avoided by ensuring that the parameters are downloaded to the DAT or HistoROM, or by manually transferring the parameters displayed in the Online Characterization to the Offline Characterization dialog.

This tutorial tells you how to parametrize offline with Application Designer. but it is also possible to parametrize online.


Order of parameters

Some block parameters have a write check based on the value of others parameters. It is therefore important to set the parameters in the order shown in the various tables, i.e. the same order in which they are displayed in the **Off Line Characterization** dialog.

After parametrization of the block, the parameters will appear in the FOUNDATION Fieldbus tree. If you find a parameter in the wrong position, it can be moved by dragging and dropping to the correct one.


5.1 Field Controller Hardware Configuration block

- 1 Double click on the **HSE Network** leaf, the HSE Network window opens:
 - Expand the **FC_01** and **FBAP** leaves




- 2 Double-click on the **FC_01_HC_1** leaf to open the **Off Line Characterization** dialog. To change parameters, see Chapter 4.5.1:
 - Expand the parameter leaf
 - Double click on value space
 - Enter the parameter or select it from the drop-down menu
 - Confirm with End **Edit**

- 3 Expand the **MODE_BLK** parameter leaf and check that **Target** is set to **Auto**
- 4 Expand the **IO_TYPE_R0** parameter leaf and set the following parameters, see Table 2-1, Chapter 2.2.2
 - **Slot_0**: No I/O
 - **Slot_1**: No I/O
 - **Slot_2**: No I/O
 - **Slot_3**: No I/O
- 5 Expand the **IO_TYPE_R1** parameter leaf and set the following parameters, see Table 2-1, Chapter 2.2.2
 - **Slot_0**: 8 DiscIn 4 DiscOut
 - **Slot_1**: No I/O
 - **Slot_2**: No I/O
 - **Slot_3**: No I/O



- 6 Click **Close**, then save the configuration
 - Right-click on the **Project File** menu and select **Save Entire Configuration** to save the project, which now looks like this.



5.2 TMT162 temperature transmitter


Full details of how to parametrize the TMT162 temperature transmitter are to be found Operating Instructions BA224R/06/en, which can be downloaded from www.endress.com. Table 5-1 shows the basic parameters that must be set in the TMT162 TEMP_1 transducer block

Parameter	Function	Temperature TT100
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
PRIMARY_VALUE_TYPE	Calculation method for primary process value <ul style="list-style-type: none"> ■ Process temperature SV1 or SV2 ■ Average 0.5 (SV1 + SV2) with/without redundancy ■ Differential (SV1 - SV2) ■ Conditional (SV1 or SV2), (SV2 if SV1 > T) 	Sensor Value 1
SENSOR_TYPE	Type of sensor connected to the transmitter <ul style="list-style-type: none"> ■ All types of standardized temperature sensors 	Pt 100 IEC 751
SENSOR_CONNECTION	Way in which the sensor is connected <ul style="list-style-type: none"> ■ 4-wire (if two sensors are connected only one can be 4-wire) ■ 3-wire ■ 2-wire 	2-wire

Tab. 5-1: Basic parameters for TMT162 transducer block

Procedure

- 1 In the Fieldbus network workspace, expand the TT100 tree until the function blocks are visible
 - Right click on the **TT100-TEMP-1** block and select **Off Line Characterization...**
- 2 The **Off Line Characterization** dialog opens



- Expand the **Mode Block** parameter tree and set **Target** to **Auto**.
 - Set **PRIMARY_VALUE_TYPE** = PV = Sensor value 1 (SV1)
 - Set **SENSOR_TYPE** = Pt 100 IEC (a=3.85 E-03)
 - Set **SENSOR_CONNECTION** = 2-wire
 - Remember to press **End Edit** after every change
 - Press **Close** to quit the Characterization dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.

5.3 Micropilot M level transmitter

Full details of how to parametrize the Micropilot M level transmitter are to be found Operating Instructions BA278F/00/en, which can be downloaded from www.endress.com. Table 5-2 shows the parameters that must be set in the Micropilot M transducer block.



Note!

- Currently, Endress+Hauser level devices do not support offline parametrization within Application Designer. The procedures described here must be performed online, preferably after the allocation of the Device ID, but before download of the project.
- In the case of time-of-flight devices, i.e. Micropilot, Levelflex, Prosonic, the tank must be mapped and the measurement checked when the device is online.

Fig. 5-1 shows the basic calibration parameters. For all other parameters the default values will be accepted, i.e. in our case the default value for suppression distance (SD) will be used, i.e. the associated parameter PARSUPPRESSIONDISTANCE will not be changed (default = 0.1 m).

The parametrization procedure is described in Chapter 7.3.4.




Fig. 5-1: Calibration parameters of Micropilot M level transmitter

Parameter	Function	Value
MODE BLOCK/TARGET	Normal operating mode of block <ul style="list-style-type: none"> ■ During online parametrization this must be set to OOS ■ After parameterization reset to Auto 	Auto
PAROPERATIONCODE	Sets the parameters to RW in on-line operation	2457
PARTANKSHAPE	Configures the application for tank shape, bypass, stilling well	flat ceiling
PARDIELECTRICCONSTANT	Sets the dielectric constant of the liquid to be measured	D.C. 1.9 – 4
PARPROCESSCONDITIONS	Configures the device to conditions within tank	calm surface
PAREMPTYCALIBRATION	Distance from top of Micropilot process connection to desired zero level of tank – Parameter E in Fig. 5-1	e.g. 3.5
PARFULLCALIBRATION	Distance from selected zero level to desired 100% level of tank – Parameter F in Fig. 5-1	e.g. 3.0

Tab. 5-2: Basic parameters for Micropilot M transducer block

5.4 Metso ND9103FN positioner

Full details of how to parametrize the Metso ND9103FN valve positioner are to be found in the ND900F User Guide which can be downloaded from www.metso.com.

In the tutorial, you have probably only the valve positioner, but not the valve itself. In real life, the positioner must be told what it is driving and certain assembly information must always be entered into the transducer block. The rotary valve parameters are included in Table 5-3. For instructions on how all other parameters can be used, see the User Guide.

Parameter	Function	Positionere FCV102
MODE_BLOCK/TARGET	Normal operating mode of block	Auto
VALVE_TYPE	Type of valve the positioner is actuating ■ Select from drop-down menu	Rotary
FINAL_VALUE_RATE_DN	Maximum travel rate in closing direction ■ 0 = parameter not in use	0
FINAL_VALUE_RATE_UP	Maximum travel rate in opening direction ■ 0 = parameter no in use	0
POSITIONER_FAIL_ACTION	Action of position on loss of electrical power or reception of an output signal with a bad status ■ Select from drop-down menu	Close
POS_SENSOR_ROT	Relationship between valve action and position sensor rotation ■ Select from drop-down menu	Standard: Clockwise to close
DEAD_ANGLE_COMP	Dead angle for segment and rotary valves	0
ACT_TYPE	Type of positioner action ■ Select from drop-down menu	Double-acting actuator
PERFORMANCE_LEVEL	Target performance level of valve position control Select from drop-down menu	Optimum
CHAR_TYPE	Type of linearization ■ Select from drop-down menu	No characterization

Tab. 5-3: Basic parameters for ND9103FN positioner transducer block

Procedure

- 1 In the Fieldbus network workspace, expand the FCV102 tree until the function blocks are visible
 - Right click on the **FCV102_BLK_2** block and select **Off Line Characterization...**
- 2 The **Off Line Characterization** dialog opens
 - Expand the **Mode Block** parameter tree and set Target to Auto
 - Set VALVE_TYPE = Rotary
 - Set POSITIONER_FAIL_ACTION = Close
 - SET CT_TYPE = Double-acting actuator
 - Press **Close** to quit the Characterization dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.


5.5 Export tags




Note!

- You should use the Export Tags function everytime you change the configuration of the project, so that the OPC server information is always up-to-date.
- Application Designer can be set to automatically export the tags every time the project goes online, see Chapter 3.2.

- 1 Activate the project view by clicking in its workspace
 - Right click on the project name, a context menu appears



- 2 Select the option **Export Tags...**
 - The Export Tags dialog confirms the successful export




- Press **OK** to close the dialog
- 3 Open **Project File**, then press **Save Entire Configuration**, to save the project.


6 Program the Hybrid Function Block

6.1 Set the IEC 61131-3 programming language

- 1 In the **HSE Network 1** tree, right click on **FC_01_HY_EMB_IO_1** and select **Attributes**



- 2 The **Attributes** dialog opens:




- In the **IEC 61131-3 Programming Language** menu select **ST** (Structured Text)
- Tick the box "Map as FF Data Structure"
- Press **OK** to confirm the selection


6.2 Program the hybrid function block

6.2.1 OpenPCS programming tool

- 1 In the **HSE Network 1** tree, right click on **FC_01_HY_EMB_IO_1** and select **Program Hybrid Block**




- 2 The OpenPCS programming tool opens:



- The **Files** pane of the Project window shows the program files
- The **Resources** pane shows the hybrid block task attached to the Field Controller
- The **Lib** pane shows the libraries available
- The **Help** pane opens the Online help tree
- The **Catalog** window might also appear – it can be closed by pressing the "x"
- The **Log** window tracks program events – it can be closed by pressing the "x"

- 3 Double-click on **FC_01_HY_EMB_IO_1.ST**: the editor opens with the declared external variables (the log window at the bottom was closed for this screenshot)
 - The upper right-hand pane contains the external variables we just declared, Chapter 6.1
 - The lower right-hand pane contains the structured text program, which is empty on starting



6.2.2 Declare additional variables

Additional variables used by the structured text program must be declared with name and data type in the upper right-hand pane before programming starts. Table 6-1 lists the various types of declaration supported. The declaration opens with the variable type and is closed with END_VAR. The various types are created with default value zero for real and integer variables and FALSE for booleans.

Variable type	Access Rights		Function
	External	Internal	
VAR	–	RW	Local variable that is readable and writable to its own block only
VAR_INPUT	RW	R	Input variable that is readable and writable to an external block, but only readable to its own block
VAR_OUTPUT	R	RW	Output variable that is readable and writable to its own block, but only readable to an external block
VAR_IN_OUT	RW	RW	I/O variable readable and writable to its own and an external block (call be reference)
VAR_EXTERNAL	RW	RW	External I/O variable, declared as global in its own block, that is readable and writable to its own and an external block, whereby any change is immediately effective in all blocks where it is used
VAR_GLOBAL	RW	RW	Global I/O variable, declared as external in its own block, that is readable and writable to it own and an external block, whereby any change is immediately effective in all blocks where it is used
VAR_ACCESS	RW	RW	Global I/O variable (access path) that is readable and writable in its own and an external block resident in a different controller, whereby any change is immediately effective in all blocks where it is used

Tab. 6-1: Variable declaration types

Attributes

The declarations can be modified to define a particular behaviour of the variables contained within them by adding one of the attributes in Table 6.2.

Attribute type	Function
RETAIN	Variable that retains its value when the controller is switched off or restarted
CONSTANT	Variable that retains a constant value, i.e. not writable
OPC	Variable that is readable and writable in the IEC OPC Server – Local variables declared with the prefix OPC_ are also visible in the IEC OPC server

Tab. 6-2: Declaration attribute types

Example

For this exercise, we will declare the boolean "Reset_Pump_Start_Counter" as an OPC variable to enable a SCADA program to reset the variable "Number_Pump_Starts" to zero. It begins with the status "0" = "FALSE"

In order to detect the change from TRUE (stop) to FALSE (start) for the variables Pump_1_Control and Pump_2_Control, we need to determine the state at the last execution of the block. For this we require two variables State_Pump_1 and State_Pump_2 that are retained should the controller be switched off. Since they are to be compared with FF variables, they must be declared as FF discrete values, i.e. DS 66. Real values have the format DS 65.

Finally the integer Number_Pump_Starts must be readable in the IEC OPC server and retained should the controller be switched off (power down).

Procedure

In the upper right-hand pane do the following:

- 1 Declare Pump_Start_Counter_Reset as boolean and an IEC OPC Server variable


```
VAR OPC
    Pump_Start_Counter_Reset: BOOL;
END_VAR
```

- 2 Declare the two retained booleans State_Pump_1 and State_Pump_2

```
VAR RETAIN
    State_Pump_1: DS_66;
    State_Pump_2: DS_66;
END_VAR
```

- 3 Declare the integer Number_Pump_Starts as retained and an IEC OPC Server variable

```
VAR RETAIN OPC
    Number_Pump_Starts: INT;
END_VAR
```

**Note!**

- An alternative method to declare IEC OPC Server variables not used in this tutorial is to add the OPC_ prefix:

```
VAR
    OPC_Pump_Start_Counter_Reset: BOOL;
END_VAR
```


```
VAR_RETAIN
    OPC_Number_Pump_Starts: INT;
END_VAR
```

6.2.3 Activate the libraries

The FF variables used in IEC 61131-3 programming must be converted to a data type appropriate to programming language. To this end ControlCare activates two libraries by default:

- **CC_FF_CUSTOM_LIB** to map the custom FF function blocks
(Data type conversion DS65, DS66)
- **CC_FF_STANDARD_LIB** to map the standard FF function blocks
(FF status handling)

These appear red in the library pane (select the **Lib** tab)



Note!




- For ControlCare Product Version 2.01.xx, the libraries have to be activated by hand
- For SFC programming the sfclib must be activated, see below and the OpenPCS online help

Activating a library

In order to activate additional libraries, e.g. sfclib for SFC programming, the following procedure is used:

- 1 Select the **Lib** pane:
 - Right-click on e.g. **sfclib** and select **Use in Current Project**
 - The project book turns red = active



Installing a library

If the libraries are not installed:

- 1 Right-click on **Libraries**, select **Install New...**,
- 2 Browse to the folder containing the LIB files and select the library required
- 3 Press **OK** twice to install.

6.2.4 Create the structured text program

For simplicity, the structured text program will be written

- first for the pump and valve control
- then for the calculation of the measured values
- finally for the pump start counter.

The conditions for the discrete logic are as follows:

- Overspill protection, dry run protection and emergency stop to DI-0 to DI-2 inputs of a Field Controller SFC432 Mixed Discrete I/O module: 0 V = False, 24 V = True
- Pump output current from DO-0 and DO-1 outputs of the Field Controller SFC432 Mixed Discrete I/O module: NO relay, 0 = Pump OFF, 1 = Pump ON, Fail Safe = Pump OFF

The strategy is created according to the truth table in Chapter 2.1.2.

Pump and valve control

- 1 Enter the following text in the lower right-hand pane:

```
(*HI_HI and LO_LO level handling*)
IF Tank_Overspill.value = 1 THEN
    Pump_1_Control.value := 0;          (*Pump OFF*)
    Pump_2_Control.value := 0;          (*Pump OFF*)
END_IF;

IF Pump_Dry_Run.value = 1 THEN
    Close_Valve.value := 1;              (*Valve CLOSED, TRACK_IN_D = TRUE*)
END_IF;

IF Operator_Entry_Emergency.value = 1 OR Emergency_Stop.value = 1 THEN
    Pump_1_Control.value := 0;          (*Pump OFF*)
    Pump_2_Control.value := 0;          (*Pump OFF*)
    Close_Valve.value := 1;              (*Valve CLOSED, TRACK_IN_D = TRUE*)
END_IF;

(*HI and LO level handling*)
IF HI_Level.value = 1 THEN
    Pump_1_Control.value := 0;          (*Pump OFF*)
    Pump_2_Control.value := 0;          (*Pump OFF*)
ELSIF Operator_Entry_Emergency.value = 0
AND Emergency_Stop.value = 0
AND Tank_Overspill.value = 0 THEN
    Pump_2_Control.value := 1;          (*Pump ON*)
END_IF;

IF LO_Level.value = 1 THEN
    Close_Valve.value := 1;              (*Valve CLOSED, TRACK_IN_D = TRUE*)
    Pump_1_Control.value := 1;          (*Pump ON*)
ELSIF Operator_Entry_Emergency.value = 0
AND Emergency_Stop.value = 0
AND Pump_Dry_Run.value = 0 THEN
    Close_Valve.value := 0;              (*Valve OPEN, PID control*)
END_IF;


(*Set status to good, e.g. GoodNC NonSpecific = 128*)
Pump_1_Control.status := 128;
Pump_2_Control.status := 128;
Close_Valve.status := 128;
```

Measured values

- 2 Now perform the calculations as shown in Chapter 2.1.2
 (*Product mass = Product volume x Product density, Level = Level value from Micropilot*)
 $\text{Product_Mass.value} := 66.0 * \text{Product_Level.value} * \text{Product_Density.value} / 700.0;$
 $\text{Level_Output.value} := \text{Product_Level.value};$
 (*Total flow*)
 $\text{Total_Flow.value} := \text{Flow_1.value} + \text{Flow_2.value};$
 (*Status propagation, 64 = Uncertain NonSpecific*)
 $\text{Level_Output.status} := \text{Product_Level.status};$
 IF $\text{Product_Level.status} := \text{Product_Density.status}$ THEN
 $\text{Product_Mass.status} := \text{Product_Level.status};$
 ELSE $\text{Product_Mass.status} := 64;$
 END_IF;
 IF $\text{Flow_1.status} = \text{Flow_2.status}$ THEN
 $\text{Total_Flow.status} := \text{Flow_1.status};$
 ELSE $\text{Total_Flow.status} := 64;$
 END_IF;

Pump start counter


- 3 The counter is now set up
 (*If Pump_Start_Counter_Reset is true, the counter is set to zero*)
 IF $\text{Pump_Start_Counter_Reset}$ THEN
 $\text{Number_Pump_Starts} := 0;$
 $\text{Pump_Start_Counter_Reset} := 0;$
 END_IF;
 (*Counter incremented when State_Pump is true - was off - and Pump_Control is false - is now on*)
 IF $\text{State_Pump_1.value} = 1$ AND $\text{Pump_1_Control.value} = 0$ THEN
 $\text{Number_Pump_Starts} := \text{Number_Pump_Starts} + 1;$
 END_IF;
 IF $\text{State_Pump_2.value} = 1$ AND $\text{Pump_2_Control.value} = 0$ THEN
 $\text{Number_Pump_Starts} := \text{Number_Pump_Starts} + 1;$
 END_IF;
 (*Remember current state*)
 $\text{State_Pump_1.value} := \text{Pump_1_Control.value};$
 $\text{State_Pump_2.value} := \text{Pump_2_Control.value};$
- 4 The program is now complete




6.2.5 Troubleshoot the project

Now that the project is complete, it is recommended that the project is checked for errors.

- 1 Open the **File** menu and select **Check Syntax**



- 2 OpenPCS runs a check on all syntax in your program and publishes a log at the bottom of the workspace.
 - If errors are found eliminate them and check the syntax again
 - You can move from error to error with the F4 and Shift F4 keys
- 3 When the program is free of errors, this is reported in the log at the bottom of the workspace




- 4 Now open the **File** menu and select **Save All**.

6.3 IEC 61131-3 Simulation


OpenPCS allows the simulation of the IEC 61131-3 program without the need for hardware. It is recommended that the program is tested with this function before it is downloaded to the Field Controller.

6.3.1 Resources

- 1 Click on **PLC** and select **Resource Properties** from the PLC menu
 - The **Edit Resource Specifications** dialog opens




- 2 In the **Edit Resource Specifications** dialog




- Select Hardware Module: **ControlCare SIM/Rev 3**
 - Select Network Connection: **EHSIM**
 - Select Optimization: **Size only**
 - Press **OK** to confirm the changes and close the dialog
- 3 Click on **PLC** and select **Rebuild Active Resources** (alternatively, press CTRL+F7)
 - You can now go "Online" with the simulation.

6.3.2 Go "Online"

- 1 Click on **PLC** and select **Online** from the PLC menu
 - If appropriate an **OpenPCS Online Server 32** message appears



- Press **Yes** to download the resource to the server
- 2 Press the **Resource** tab and click on the Field Controller in the project window




Note!



- If there is more than one Field Controller in the project, it appears green and the others red.
- To activate different Field Controller, right click on it and select **Set Active**, its colour changes to green

- 3 Click on **PLC** and select **Coldstart** from the PLC menu
 - The Field Controller simulation now runs




- The buttons Power Off, Run and Stop simulate the corresponding operating modes of the Field Controller
 - The Cycles display show number of cycles simulated and cycle time in ms
 - The LEDs simulate the LEDs on the Field Controller
 - To change the macrocycle time, press the >> button and enter a new value in the **Cycle Time** dialog, confirming with **OK**
- 4 The simulation is closed by clicking on **PLC** and select **Offline** from the PLC menu

6.3.3 Watch list

By placing selected input and output variables in a watch list, the logic can then be checked.

- 1 Press the **Resource** tab and expand the **FC_01_HY_EMB_IO_1** node
 - A list of input and output variables appears



- 2 Double-click on a parameter to place it in the watch list
 - Right-click on the watch list "value field" and enter a value in the **Set Variable** dialog
 - Press **OK** to confirm the entry and close the dialog

Instancepath	Name	Value	Type	Address	Force	Comment
FC_01_HY_EMB_IO_1.TOTAL_FLOW	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.TOTAL_FLOW	VALUE	35	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_MASS	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_MASS	VALUE	6.5141997	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_LEVEL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_LEVEL	VALUE	70	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_DENSITY	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_DENSITY	VALUE	0.987	REAL			
FC_01_HY_EMB_IO_1.LEVEL_OUTPUT	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.LEVEL_OUTPUT	VALUE	70	REAL			
FC_01_HY_EMB_IO_1.FLOW_2	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.FLOW_2	VALUE	15	REAL			
FC_01_HY_EMB_IO_1.FLOW_1	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.FLOW_1	VALUE	20	REAL			

- Parameters can be deleted by selecting the parameter line and pressing DEL

- 3 Check the logic of each action by seeing the effect of parameter changes on the outputs

Instancepath	Name	Value	Type	Address	Force	Comment
FC_01_HY_EMB_IO_1.LO_LEVEL	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.LO_LEVEL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.HI_LEVEL	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.HI_LEVEL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.CLOSE_VALVE	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.CLOSE_VALVE	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1	PUMP_START_COUNTER	FALSE	BOOL			
FC_01_HY_EMB_IO_1	NUMBER_PUMP_STARTS	5	INT			
FC_01_HY_EMB_IO_1.TANK_OVERSPILL	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.TANK_OVERSPILL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_2	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_2	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_1	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_1	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.PUMP_DRY_RUN	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.PUMP_DRY_RUN	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1.PUMP_2_CONTROL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PUMP_2_CONTROL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.PUMP_1_CONTROL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PUMP_1_CONTROL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.OPERATOR_ENTRY_EMERGENCY	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.OPERATOR_ENTRY_EMERGENCY	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.EMERGENCY_STOP	STATUS	0	BYTE			

- 4 When you are satisfied that the program does what it should, prepare for download by optimizing the performance

6.4 Optimize performance

If the IEC 61131-3 simulation was used, the resources must be respecified before the project is compiled and downloaded, see Chapter 6.


OpenPCS allows the hybrid function block to be optimized for speed or size during compilation. Default setting is optimized for speed. Optimizing for size causes the block to run slower than if it is speed optimized, and is recommended only when there are memory problems, e.g. when a large number of hybrid function blocks with long programs are in use or when simulating without Field Controller hardware, see Chapter 5.3.

The settings below are those recommended for normal applications.


Changing the performance settings

The settings are made in both the resources and the hybrid function block

- 1 Click on the **Resources** tab, then right-click on **Controller** leaf and select **Properties**




- 2 The **Edit Resource Specifications** dialog appears



- Select Hardware Module: **ControlCare SFC162/Rev 4**
- Select Network Connection: **FC_01**
- Select Optimization: **Speed only**
- Press **OK** to confirm the changes and close the dialog

- 3 Now right-click on the **Function Block** leaf and select **Properties**
 - The **Edit Task Specifications** dialog appears



- In the **Optimization** pull-down menu select e.g. "**speed only**", then press **OK**

- 4 Save your settings and close OpenPCS

7 Go On-line

7.1 Connect to the Field Controller

In order to download the project, the host computer and Field Controllers must be allocated IP addresses in the same address range. It is possible to do this on the workbench before installation or after the Field Controller and other components have been physically installed in the Fieldbus network (subnet).



Warning

- The use of IP addresses is strictly controlled. Usually your system administrator will be authorised to allocate unique addresses. Assigning an unauthorised address to a Field Controller may result in conflicts within your system and the failure of the associated devices!



Note!

- The tools that setup the network use Ethernet services that may be blocked by Windows Firewall. Normally the firewall will be unblocked for the tools during installation, but it might be necessary to stop the firewall should they not function properly. If you are not sure how to stop the firewall, consult your system administrator.

Before starting, check the following:

- **Internet Protocol TCP/IP** is installed on your computer
- You have administration rights for your computer
- You have an set of IP addresses that have been authorized by your IT department
- Any proxy server for your Internet Browser is disabled

The procedures described in this chapter are for Windows XP. For other Windows systems consult your system administrator.



Note!

- When the Field Controllers are physically connected together with the Host computer via Ethernet, HSE Network Setup will see the them irrespective of the IP address domain to which they belong

7.1.1 Set the IP address of the host computer


SFC162 Field Controllers are delivered with the default IP address:

- 192.168.164.100


In order that the host computer can communicate with the Field Controller Web Server, it must be allocated an IP address in the same address domain, e.g. 192.168.164.200. If you are not sure how to do this, consult your network administrator.

Procedure

- 1 Right-click **Start =>Settings =>Control Panel =>Network Connections**




- 2 Right-click **Local Area Connection => Properties**



- 3 Using the left mouse button, double-click **Internet Protocol (TCP/IP)** or click once, then click **Properties**.
- 4 Note the original values of IP address and Subnet Mask of the computer to restore them if necessary at end of the operation.

- 5 Change the IP address and the Subnet Mask of the host computer to those required by the application. In the example, an address in the same subnet as the Field Controller.
 - IP Address 192.168.164.XXX and network mask (Subnet Mask) 255.255.255.0.
 - Do not use the address 192.168.164.100, as these are reserved as default addresses for Field Controller SFC162



- 6 Click on the **OK** button to complete the procedure, close the other dialogs with **OK** and **Close**.


7.1.2 Set the Field Controller IP address

Note!




- It is recommended that Field Controllers of the same type are introduced one by one to the network.

- 1 Call HSE Network Setup:
Programs =>Endress+Hauser=>ControlCare=>Tools=>HSE Network Setup
- 2 HSE Network Setup is launched and searches for Field Controllers in the Ethernet network.



- All Field Controllers in the network appear, irrespective of their IP domain.
If this is not the case:
 - Check that the proxy server of your Internet Browser is switched off
 - Check that the windows firewall is not blocking the program (switch off)
 - Check all cables and switches
 - If you find two or more Field Controllers with the same IP address, disconnect all but one from the network
- 3 If your computer has more than one NIC card, select the one you want to use for communication with the Field Controllers by ticking "Active NIC" and Press .

- 4 Right-click on the Field Controller, the address of which is to be changed:
the Field Controller Web Server opens



- The Web Server will only open if the host computer and the Field Controller have IP addresses in the same IP domain.
- 5 Expand the **Setup** node and click **Network**
 - Enter User Name "pcps" and Password "pcps" to open the **Network Configuration** dialog


Network Configuration	
DHCP:	<input type="checkbox"/> Enabled
IP address:	<input type="text" value="10.125.35.180"/>
Netmask:	<input type="text" value="255.255.255.0"/>
MAC address:	<input type="text" value="00:07:05:43:00:C5"/>
Default gateway:	<input type="text" value="10.125.35.1"/>
<input type="button" value="Update"/>	


- Enter the required IP address, in our example 10.125.35.180
 - Enter a netmask, normally 255.255.255.0
 - If required, enter a default gateway, usually address xxx.xxx.xxx.1 in the selected domain
- 6 Press **Update** to change the IP address
 - You are now asked to restart the Field Controller
 - Select the **Restart** node

Firmware restart options	
Choose one restart option and press restart button:	
<div> <input type="button" value="No additional options"/> <input type="button" value="Restart"/> </div> <div> <input type="button" value="Factory init"/> </div> <div> <input type="button" value="Hold"/> </div> <div> <input type="button" value="Disable web server"/> </div>	

- Select "**No additional options**" from the drop-down menu and press **Restart**
- Close the Web Browser
- The Field Controller disappears from HSE Network Setup and reappears with the new IP address

- 7 Now set the address of the host computer to the same domain as the Field Controllers, see Chapter 6.1.1 – in our example 10.125.35.200
 - Restart **HSE Network Setup**



- Tick the Field Controller, so that it appears in the HSE Live List associated with the computer's active NIC card.
- Press  to save the configuration.
- You are now ready to download the project

Note!


- If you have more than one Field Controller on the network, Repeat Steps 4 to 6 for all other Field Controllers, introducing them one by one to the network.

7.2 Generate the live lists


7.2.1 HSE live list

Once the Computer and Field Controller are able to communicate with each other, the connection to the network can be checked by creating a live list.


- 1 Press the **On-Line** button  in the menu toolbar
 - The project goes on on-line



- A red cross appears against the Field Controller in the Project workspace



- 2 In the Project workspace, right click on **HSE Network** and select **Live List**



- A live list is generated of the devices on the HSE network

HSE Live List - HSE Network 1							
Device Tag	Device Class	Device Address	Device Id	Manufacture Id	Type Id	Dev. Rev.	DD Rev.
HSE HOST 1	Host	10.125.35.200	0000000001:FF-HSE HOST:0000000001				
71003024030	Bridge	10.125.35.180	452B482010E++5FC162:71003024030	452B48 (Endress+Hauser GmbH)	2010 (5FC162)	02	04


Note!




- It may take sometime to generate the live list
 - The devices found first go grey
 - Their profiles (all important device-specific data) including IP address are read
 - On successful completion of profile reading, the devices are shown in full black

7.2.2 Assign the HSE Device IDs

- 1 In the Project workspace, right click on the **Field Controller** (CO104) and select **Attributes...**



- 2 The **Attributes** dialog opens
 - Open the drop-down menu of the **Device ID** and select the Field Controller associated with the displayed TAG (in our case FC_01) – the serial number is on the front panel
 - Do this even though the correct ID is already displayed – the program expects it!



- Confirm your choice with **OK**
- If Application Designer detects a mismatch in version, this is logged at the bottom of the page (for remedy, see Chapter 7.2)


- 3 In the HSE Live list, the Controller Icon goes grey, then reappears with the correct tag

Device Tag	Device Class	Device Address	Device Id	Manufacture Id	Type Id	Dev. Rev.	DD Rev.
HSE HOST 1	Host	10.125.35.200	0000000001:FF-HSE HOST:0000000001				
FC_01	Bridge	10.125.35.180	452B482010E+H-SFC162-71003024030	452B48 (Endress+Hauser GmbH)	2010 (SFC162)	02	04

- 4 If several SFC162s were in use, Steps 1 and 4 would be repeated for all.
- 5 Click on the **Project View** workspace and **Export Tags...**, see Chapter 3.10
 - Open **Project File**, then press **Save Entire Configuration**, to save the project.

7.2.3 Create the FOUNDATION Fieldbus live list

- 1 In the Fieldbus network workspace, right-click on **Fieldbus 1** and select the option **Live List**




- 2 The Fieldbus live list is created
 - Check that devices in the project appear in the live list. If not, check connections etc.


FF H1 Live List - Fieldbus 1 (FC_01 Port 1)							
Device Tag	Device Class	Device Address	Device Id	Manufacture Id	Type Id	Dev. Rev.	DD Rev.
TT100	Basic	24 (0x18)	452B4810CC-82005F04223	452B48 (Endress+Hauser GmbH)	10CC (TMT162)	01	01
LT101	Basic	25 (0x19)	452B48100F-63012001080	452B48 (Endress+Hauser GmbH)	100F (Micrologix M)	03	01
FC_01	Bridge	16 (0x10)	452B482010E+H-SPC162-71003024030	452B48 (Endress+Hauser GmbH)	2010 (SPC162)	03	01
FCV102	Basic	26 (0x1A)	000E052328ND9000550010330	E05 (Metso Automation)	2328 (ND9000F)	03	01

7.2.4 Assign the Fieldbus Device IDs

- 1 In the fieldbus workspace, right click on **TT100** and select **Attributes...**




- 2 The **Attributes** dialog opens
 - Open the drop-down menu of the **Device ID** and select the device ID associated with the displayed TAG (in our case TT100) – the serial number is on the nameplate




- Confirm your choice with **OK**
 - After a period of time, the red cross disappears from the device in the Fieldbus network
 - If Application Designer detects a mismatch in version, this is logged at the bottom of the page (for remedy, see Chapter 7.2)
- 3 Repeat the process for the rest of the devices in the Fieldbus network (FT101, FCV102)
 - After a period of time, the red cross disappears from the device in the Fieldbus network
 - 4 Click on the **Project View** workspace and **Export Tags...**, see Chapter 3.10
 - Open **Project File**, then press **Save Entire Configuration**, to save the project.

7.2.5 Assign All Tags

- 1 In the Fieldbus workspace, right-click on the Fieldbus node at the top of the tree and select **Assign All Tags**



- 2 The Assign All Tags dialog appears with the list of device and a progress bar



- On completion, the message "Profile reading done" stands next to the Field Controller and "Tag has been confirmed" next to the devices
 - If there are any failures in tag assignment these are logged with reasons at the bottom of the screen.
- 3 As the assignment proceeds, the Field Controller transmits the change to the device
 - The device goes grey in the live list
 - The Field Controller initiates a new network scan
 - After about 1 - 2 minutes, the device goes black and appears with the new tag
 - 4 At the end of the process the live list looks like this

FF H1 Live List - Fieldbus 1 (FC_01 Port 1)							
Device Tag	Device Class	Device Address	Device Id	Manufacture Id	Type Id	Dev. Rev.	DO Rev.
TT100	Basic	24 (0x18)	452B4810CC-82005F04223	452B48 (Endress+Hauser GmbH)	10CC (TMT162)	01	01
LT101	Basic	25 (0x19)	452B48100F-6301200108D	452B48 (Endress+Hauser GmbH)	100F (Microplot M)	03	01
FC_01	Bridge	16 (0x10)	452B482010E-H-SFC162:71003024030	452B48 (Endress+Hauser GmbH)	2010 (SFC162)	03	01
FCV102	Basic	26 (0x1A)	000E052328ND90000550010330	E05 (Metso Automation)	2328 (ND9000F)	03	01

- The "bright" dot next to the SFC162 Field Controller indicates that it is the ACTIVE LAS of this segment

7.3 Download the project

Both the project in ControlCare Application Designer and that in Open PCS must be downloaded to the Field Controller. The downloads can be made in any order.


Note!




- The procedure below describes the initial download for the entire HSE network.
- Partial downloads can be made later from lower leaves, when changes are confined to this level
- Incremental downloads can be made to a running project by checking the boxes **Incremental Download** and **Compare Parameters**: Unaffected Local I/Os will hold their last values.

7.3.1 Download the control strategy

- 1 In the Project workspace right-click on **HSE Network 1** and select **Download**



- 2 The **Download** dialog appears



- Press **Start** to start the download
- 3 The download will be interrupted if the project has not been configured properly, e.g.
 - The Controller Tag has not been assigned correctly => Assign Field Controller tags, Chapter 6.2.2
 - The I/O modules have not been correctly defined, see Chapter 4.6
 - 4 When the download is successfully completed, the dialog is closed, and you are ready to download the hybrid block configuration

7.3.2 Configure device class

In our project the Field Controller acts as the Link Active Scheduler by default. The FOUNDATION fieldbus protocol allows other devices to take over this role should the Field Controller fail. This ensures that any control loop not involving function blocks in the controller will continue to function in this event. A device can be setup to be a backup LAS by using the Configure Device Class function. This function is only effective when the device is online.


Note!



- If you are offline, the process finishes at Step 2. The change is registered in the project but is not downloaded with it. The procedure must then be repeated with the device online, otherwise a mismatch when you try to download.


Procedure

- 1 In the Fieldbus window, right click on the Fieldbus node to open the context menu



- Select the menu **Configure Device Class**

- 2 The **Device Class** dialog opens




- Select the device(s) you want as backup LAS (usually one with few FB links, in our case TT100)
- Press >> to transfer the device to the righthand pane (if the device does not support LAS functionality, an error message appears)
- Press **Apply** to confirm the choice and close the dialog.

- 3 When online, the **Change Device Class** dialog appears and shows the download progress
- 4 On completion the TT100 device appears in the live list with a dot indicating backup LAS functionality


FF H1 Live List - Fieldbus 1 (FC_01 Port 1)							
Device Tag	Device Class	Device Address	Device Id	Manufacture Id	Type Id	Dev. Rev.	DO Rev.
TT100	Link Master	24 (0x18)	452B4810CC-82005F04223	452B48 (Endress+Hauser GmbH)	10CC (TMT162)	01	01
LT101	Basic	25 (0x19)	452B48100F-63012001080	452B48 (Endress+Hauser GmbH)	100F (Microplot M)	03	01
FC_01	Bridge	16 (0x10)	452B482010E+H+SPC162:71003024030	452B48 (Endress+Hauser GmbH)	2010 (SPC162)	03	01
FCV102	Basic	26 (0x1A)	000E052328ND90000550010330	E05 (Metso Automation)	2328 (ND9000F)	03	01

7.3.3 Download the OpenPCS project

- 1 Start OpenPCS by right clicking on **FC_01_HY_EMB_IO_1** in the **HSE Network 1** tree and selecting **Program Hybrid Block**:
 - If OpenPCS is already running, close it before performing this step
 - The attribute settings are exported to OpenPCS
 - Click **OK** to open the OpenPCS workspace
- 1 Click on **PLC** and select **Online** from the PLC menu
 - If appropriate an **OpenPCS Online Server 32** message appears



- Press **Yes** to download the resource to the server
- 2 Press the **Resource** tab and click on the Field Controller in the project window



- 3 Click on **PLC** and select **Coldstart** from the menu: the hybrid block is started (set to Auto).
- 4 If there is more than one controller in the project, each must be cold-started as follows:
 - Right click on the controller and select **Set Active**, its colour changes from red to green
 - Click on **PLC** and select **Coldstart** from the menu
 - All hybrid blocks attached to the controller are forced to Auto
- 5 Now check the project files
 - You will see that the names in watch list are now replaced by values

Instancepath	Name	Value	Type	Address	Force	Comment
FC_01_HY_EMB_IO_1.TOTAL_FLOW	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.TOTAL_FLOW	VALUE	83	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_MASS	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_MASS	VALUE	2878.6653	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_LEVEL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_LEVEL	VALUE	30.610788	REAL			
FC_01_HY_EMB_IO_1.PRODUCT_DENSITY	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PRODUCT_DENSITY	VALUE	997.4033	REAL			
FC_01_HY_EMB_IO_1.LEVEL_OUTPUT	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.LEVEL_OUTPUT	VALUE	30.610788	REAL			
FC_01_HY_EMB_IO_1.FLOW_2	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.FLOW_2	VALUE	35	REAL			
FC_01_HY_EMB_IO_1.FLOW_1	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.FLOW_1	VALUE	48	REAL			
FC_01_HY_EMB_IO_1.LO_LEVEL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.LO_LEVEL	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1.HI_LEVEL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.HI_LEVEL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.CLOSE_VALVE	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.CLOSE_VALVE	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1	PUMP_START_COUNTER_RESET	FALSE	BOOL			
FC_01_HY_EMB_IO_1	NUMBER_PUMP_STARTS	1	INT			
FC_01_HY_EMB_IO_1.TANK_OVERSPILL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.TANK_OVERSPILL	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_2	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_2	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_1	STATUS	0	BYTE			
FC_01_HY_EMB_IO_1.STATE_PUMP_1	VALUE	1	BYTE			
FC_01_HY_EMB_IO_1.PUMP_DRY_RUN	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PUMP_DRY_RUN	VALUE	0	BYTE			
FC_01_HY_EMB_IO_1.PUMP_2_CONTROL	STATUS	128	BYTE			
FC_01_HY_EMB_IO_1.PUMP_2_CONTROL	VALUE	1	BYTE			

- 6 OpenPCS offers a number of options for monitoring values and changing the program without stopping execution, e.g. on-line editing –see the on-line help for details.


7.3.4 Parametrize the Micropilot

The basic parameters for this exercise are shown in the table below

Parameter	Function	Value
PAROPERATIONCODE	Sets the parameters parameters to RW in on-line operation	2457
PARTANKSHAPE	Configures the application for tank shape, bypass, stilling well	flat ceiling
PARDIELECTRICCONSTANT	Sets the dielectric constant of the liquid to be measured	D.C. 1.9 - 4
PARPROCESSCONDITIONS	Configures the device to conditions within tank	calm surface
PAREMPTYCALIBRATION	Distance from top of Micropilot process connection to desired zero level of tank – Parameter E in Fig. 5-1, Chapter 5.3	e.g. 3.5
PARFULLCALIBRATION	Distance from selected zero level to desired 100% level of tank – Parameter F in Fig. 5-1 Chapter 5.3	e.g. 3.0

Procedure


- 1 In the Fieldbus network workspace, expand the LT101 tree until the function blocks are visible
 - Right click on the **LT101_TBRL_1** block and select **On Line Characterization...**
- 2 The **On Line Characterization** dialog opens
 - The default parameters appear in the value column
- 3 Expand the **Mode Block** parameter tree and set **Target** to **OOS**
 - Set PAROPERATIONCODE = 2457; the calibration parameters become read/write
 - Set PARTANKSHAPE to "flat ceiling"
 - Set PARDIELECTRICCONSTANT to 1.9 - 4
 - Set PARPROCESSCONDITIONS to "calm surface"
 - Set PAREMPTYCALIBRATION to 3.5
 - Set PARFULLCALIBRATION to 3




- 4 At this point in a real application a map of the empty tank would be made to suppress any spurious reflections from objects built into the tank, see BA235F/00/en for details
- 5 Expand the **Mode Block** parameter tree and set **Target** to **Auto**
- 6 Press **Close** to quit the **On Line Characterization** dialog
 - Answer **Yes** to the request to store the parameters: are settings are then retained for any subsequent download to the device
- 7 Open **Project File**, then press **Save Entire Configuration**, to save the project.

7.4 Check the control strategy


7.4.1 Control strategy


- 1 Click in the Control Strategy workspace (Pump control) and press the button  in the menu toolbar – the control strategy also goes "on-line"




- Values appear in green when the status is good
 - Values appear in red if the status is bad – at this stage this is an indication of a communication, block configuration, strategy configuration or device parametrization error
- 2 If you have the possibility of changing the signals, change each input in turn and check the effect on your strategy.

7.4.2 Optimization of hybrid block execution time

- 1 Open the **HSE Network 1** dialog, then click on the "details" icon  in the menu bar
 - The execution times are shown next to each block
 - The **FC_01_HY_EMB_IO_1** block executes at the default time of 30 ms



- 2 Right-click on the **FC_01_HY_EMB_IO_1** block and select **On Line Characterization**



- The parameter **EXEC_TIME_ACTUAL** shows the time in which the block is executing
 - Observe the value for a couple of minutes and note the highest value
- 3 Now change the function block execution time to the new value
 - Right-click on **FC_01_HY_EMB_IO_1** and select **On Line Characterization**
 - Double-click on the "value space" next to the parameter **EXEC_TIME_TARGET**
 - Enter a value 10% to 20% higher than the highest observed actual execution time
 - Press **End Edit** to store the value and **Close** to quit the dialog.
 - 4 Right-click on the Bridge node (FC_01) and select **FB Schedule Download**
 - The new value is downloaded to the Field Controller
 - The strategy now runs with the new target execution time
 - 5 Repeat Steps 1 to 4 for all hybrid blocks in the strategy

Note!



- **EXEC_TIME_ACTUAL** will be too high if the ST program is being monitored on-line by OpenPCS. Close the application before checking the value.

7.5 Modify the project



7.5.1 On-line characterization

Once the project is on-line you may want to change parameters to e.g. tune the control-loop or eliminate configuration errors. With the exception of the **SP** parameter, the function block must be put out of service before the parameter is changed:

- 1 In the Control strategy workspace double-click on the function block you want to modify, or in the HSE network 1 or Control module workspace, right-click on the function block and select **On-line Characterization**
- 2 The function block **On-line Characterization** dialog appears:
 - Open the **Mode** leaf and double-click in the space next to **Target**
 - Set the Target to **OOS** (Out of Service)
 - Click **End Edit** to set the parameter
- 3 Change the parameters you wish to modify
 - If appropriate, open the parameter leaf and double-click in the space next to the parameter you require
 - Enter the new parameter or select it from the drop-down menu
 - Click **End Edit** to set the parameter
 - Repeat the procedure for all the parameters you wish to modify
- 4 Put the function block back into standard operating mode
 - Open the **Mode** leaf and double-click in the space next to **Target**
 - Set the Target back to the original value (**Auto** (Automatic) or **Cas** (Cascade))
 - Click **End Edit** to set the parameter
 - Check that the **Mode** really changes to the Target Mode (failure to do so indicates a configuration error)
 - Press **Close** to store the values (if you are prompted – answer with **Yes**)
- 5 Click on the **Project View** workspace and **Export Tags...**, see Chapter 3.10
 - Open **Project File**, then press **Save Entire Configuration** to save the project
- 6 Put the Control strategy back "on-line" to check the results of your modification, Chapter 6.4.

7.5.2 Off-line characterization


You may prefer to change parameters off-line, e.g. when modifying the control strategy or adding new functions to the project.

- 1 If you are on-line, press the **Off-line** button  in the menu toolbar
alternatively, in the PROFIBUS network or Control module workspace, right-click on the function block and select **Off-line Characterization**
 - The function block **Off-line Characterization** dialog appears
- 2 Change the parameters you wish to modify
 - If appropriate, open the parameter leaf and double-click in the space next to the parameter you require
 - Enter the new parameter or select it from the drop-down menu
 - Click **End Edit** to set the parameter
 - Repeat the procedure for all the parameters you wish to modify
 - Press **Close** to store the values
- 3 Click on the **Project View** workspace and **Export Tags...**, see Chapter 3.10
 - Open **Project File**, then press **Save Entire Configuration** to save the project
- 4 Press the **On-line** button  in the menu toolbar to go on-line again
- 5 Download the modified project
 - In the Project workspace right-click on **HSE Network 1** and select **Download**
 - Follow the procedure in Chapter 6.3
- 6 Put the Control strategy back "on-line" to check the results of your modification, Chapter 6.4.


7.6 Packing and unpacking the project

In order to install the project at the customer's site, the project can be packed and unpacked. It is important to remember, especially if you have not been using the actual project devices to test your project, that the instruments on site may have newer (or even older) DD/GSD/CFF files than the ones you use. The latest DD/GSD/CFF files must then be uploaded to the project and corresponding corrections must be made to configuration, before it is downloaded to the Field Controller. This is done with the **Import Device Support...** item in the **Project File** menu, see Operating Instructions BA017S/04/en, Chapter 3.1.5.

7.6.1 Pack the project

- 1 Select **Project File => Pack Project...**
 - The **Pack Project** dialog appears
 - Browse to the folder where the files will be created
You can create a folder with the Make New Folder button 
 - Enter the name of the project
 - Press **Save** to save the packed project
 - Press **OK** to close the successful packing message dialog


7.6.2 Unpack the project

- 1 Select **Project File => Unpack Project...**
 - In the **Unpack Project** dialog
 - Browse to the folder where the packed project is located
 - Click on the name of the project
 - Press **Open** to save the packed project
- 2 In the **Browse for Folder** dialog:
 - Browse to the folder where the project is to be installed
You can create a folder with the Make New Folder button 
 - Press **OK** to start unpacking
 - Press **OK** to acknowledge the successful unpacking of the project

7.6.3 Unpack the OPC data base only

For some applications it may be necessary to update the OPC data base of a SCADA program that has no provision for importing new DDs etc.. This can be done in Application Designer, which allows the separate unpacking of the OPC data base.

- 1 Go online, then right-click on the **HSE OPC Server** icon in the system tray



- 2 Select **Unpack Configuration...**:
 - Unpack the OPC data base to the folder required according to the Steps 1 and 2 in Chapter 7.6.2 above.


7.7 Export the configuration

For documentation purposes, the project configuration can be exported to an existing ODBC file data source, e.g. Oracle, a machine database, e.g. Excel to provide a record of the current status of the project or to an XML sheet for viewing with a browser.


7.7.1 File data source folder

The file data source must have been created before the export.

- 1 In the Project window, right-click on the Project icon and select **Export Configuration**:



- 2 The **Select Data Source** dialog box appears
- 3 In the **File Data Source** folder, select the source that describes the driver that you wish to connect to. You can use any file data source that refers to an ODBC driver which is installed on your machine.
 - Use the **New...** button and **Look In** dropdown menu to browse or
 - Click the data source icon to select the driver:




- Press **OK** to make the connection

7.7.2 Machine data source folder


The **Machine Data Source** is specific to the machine, and cannot be shared. "User" data sources are specific to a user on the machine; "System" data sources can be used by all users on the machine, or by a system-wide service. The Machine Data Source must have been created before export.

Procedure


- 1 In the Project window, right-click on the Project icon and select **Export Configuration**:



- 2 The **Select Data Source** dialog box appears
 - Click on the **Machine Data Source** tab to open the folder
 - Double-click the data source name to select the machine, e.g. Excel:



- 3 The **Select Workbook** dialog box will appear:
 - Select the folder where the data file is and double-click the workbook icon.




- Your project configuration will be exported to the workbook file.
 - A message box appears on completion – press OK
- 4 Open the Excel file to check the result:


	A	B	C	D
	BlockTag	ParamName	ParamMember	ParamValue
1	TT100-DP_MAI_1	MODE_BLK	Target	Auto
2	TT100-DP_MAI_1	SCALE_LOC_OUT_1	ACTIVE_FLAG	Enabled
3	TT100-DP_MAI_1	SCALE_LOC_OUT_1	PB_DATATYPE	Integer16
4	TT100-DP_MAI_1	SCALE_LOC_OUT_1	PI_INP_VAL_OFFSET	20
5	TT100-DP_MAI_1	SCALE_LOC_OUT_1	FROM_EU_0	0
6	TT100-DP_MAI_1	OUT_1	Status	Bad: NonSpecific: NotLimited
14	TT100-DP_MAI_1	OUT_1	Value	2.4178609E+24
15	TT100-DP_MAI_1	MODE_BLK	Target	Auto
16	FCV102-PA_AO_1	PI_OUT_SP_OFFSET	Target	2
17	FCV102-PA_AO_1	PI_OUT_SP_STAT_OFFSET		6
18	FCV102-PA_AO_1	PI_INP_RD_BACK_OFFSET		10
19	FCV102-PA_AO_1	PI_INP_RD_BACK_OFFSET		10

7.7.3 XML file

- 1 Click in the Project workspace and select **Project File => Export => Configuration as XML**
 - The **Export Configuration as XML** dialog appears




- 2 Enter a **File Name** and **Save In** location, then press **Save**
 - The project is saved as an XML file at the selected location



7.8 Close Application Designer and OpenPCS

When you have completed your session, close Application Designer and OpenPCS

7.8.1 Application Designer



- 1 If you are on-line, press the **Off-line** button  in the menu toolbar
- 2 If you have made any modifications while you were on line, you will be prompted to store them
 - If appropriate answer with **Yes**
- 3 Close the project by clicking on **Project File => Close**
- 4 Exit Application Designer by clicking on **Project File => Exit**
- 5 The Field Controller continues to operate with the project configured according to the last download/on-line correction
 - If you switch off the Controller, the project remains stored in its memory (provided the battery DIP switch is on, see BA021S/04/en: Field Controller, Hardware Installation)
 - It is initialized and re-executed as soon as the Controller is switched on again

7.8.2 OpenPCS

- 1 Open the **PLC** menu and select **Offline**
- 2 Open the **File** menu and select **Exit**
 - You will be prompted to save if your project has been changed since the last download

7.8.3 Reconnecting Application Designer

Provided your computer is operating in the same IP address domain as the Field Controller, you can reconnect at any time.

- 1 Start up Application Designer and select the Project you require
- 2 Press the **On-line** button  in the menu toolbar
- 3 Expand the various workplaces as required
- 4 Click in the **Control Strategy** workspace and press the button  in the menu toolbar – the control strategy goes "on-line" with the last configuration that was downloaded.

7.8.4 Reconnecting OpenPCS

Provided your computer is operating in the same IP address domain as the Field Controller, you can reconnect at any time.

- 1 Start up OpenPCS, open the **File** menu and select the project you require
 - Open the **File** menu and run **Check Syntax**
- 2 Open the **PLC** menu and select **Online**


8 Trouble-Shooting

8.1 Factory initialisation and reset



Warning!

- Do not use the pushbuttons located in the Field Controller unless you are certain that you want to reset the system.



Two pushbuttons located on the SFC173 module, see Fig 8.1, allow the system to be initialised and reset. The function and effect of the buttons is described in the table below.

- To "click " the pushbuttons use a pointed instrument (e.g. a ballpoint pen).

Other functions of the two buttons are to be found Chapter 7 of the Operating Instructions BA035S/04/en, Field Controller: Commissioning and Configuration..

Function	Effect	Procedure
Reset	Resets system: the last configured IP Address is used	<ul style="list-style-type: none">■ Click the right pushbutton - the system resets (takes several seconds)■ If no IP Address is found, a new one is assigned automatically■ Verify that the RUN and ETH LNK LEDs are lit.
Factory Init	Deletes application, the last configured IP Address is retained	<ul style="list-style-type: none">■ Keeping the left pushbutton pressed, click the right pushbutton■ Check that the FORCE LED flashes once a second.■ Release the left push button. The system resets, see above.

8.2 Trouble-shooting tables

8.2.1 Field Controller

	Problem	Remedy
1	HSE Network Setup/FC Tools does not find any Field Controller	<ul style="list-style-type: none"> ■ Disable the Windows firewall (normally a message appears ask whether you should unblock the program) ■ Disable the proxy server for your Internet browser ■ Check that you are using the correct Ethernet cables, see ETH LINK below ■ Check that all ethernet switches are powered up ■ Check that the network adapter is on and OK: Execute a PING command to its own IP, via DOS PROMPT. ■ Check if the Ethernet connection is OK: Execute a PING command to the Field Controller.
2	Field Controller appears intermittently in FC Tools	Host and Field Controller are in different subnets. <ul style="list-style-type: none"> ■ Normal behaviour, but for firmware download both host and Field Controller must be in the same subnet
3	HSE Network Setup/FC Tools does not show all the Field Controllers that are in the network	There is probably an IP address conflict in the network. <ul style="list-style-type: none"> ■ Disconnect all the Field Controllers except one from the from the sub-network ■ If necessary, change its IP address ■ Now reconnect the other Field Controllers one after the other, if necessary changing their IP addresses
4	Field Controller Web Server does not open	No Ethernet connection <ul style="list-style-type: none"> ■ Disable the Windows firewall ■ Disable the proxy server for your Internet browse ■ Wrong subnet IP address Host and Field Controller must be in same subnet ■ Wrong subnet mask Host and Field Controller must have same subnet mask
5	Firmware begins to execute but after a certain time it stops	It might be a configuration problem. <ul style="list-style-type: none"> ■ Use the Factory Init procedure and configure the Field Controller again. ■ If the problem persists, see the relevant chapter in Operating Instructions BA035S/04/en, Field Controller, Commissioning and Configuration
6	HOLD LED remains lit	If the HOLD LED remains lit after the Field Controller has been turned on, the firmware may be invalid. <ul style="list-style-type: none"> ■ Update the firmware, see the relevant chapter in Operating Instructions BA035S/04/en, Field Controller, Commissioning and Configuration
7	ETH LNK LED does not light	Check if the cable is connected correctly, or that the cable is not damaged. Check the specification of the cables: <ul style="list-style-type: none"> ■ SFC954 - Cable Standard. To be used in a network between the Field Controller and a Switch/Hub. (preferred configuration) ■ SFC955 - Crossed Cable (Cross). To be used point to point between a PC and the Field Controller (some PCs/laptops may have problems with crossed cable)
8	FRC LED is flashing (Force)	Field Controller is powered up for the first time <ul style="list-style-type: none"> ■ Battery is not switched on (see BA021S/04/en, p50) Field Controller is in reset mode <ul style="list-style-type: none"> ■ Complete the RESET procedure Field Controller is in normal operation <ul style="list-style-type: none"> ■ Battery is flat: <ul style="list-style-type: none"> – No problem if controller remains powered up – If power is switched off, the project will be lost and must be downloaded again from Application Designer on repowering

8.2.2 Application Designer

	Problem	Remedy
1	Field Controller does not appear in HSE live list	No connection to Field Controller <ul style="list-style-type: none"> See Remedies for Items 1, 2 and 4, Chapter 7.3.1 Field Controller is on HOLD, set it to RUN mode IP address is not configured correctly, use PING to check
2	Field Controller appears but always stays grey in HSE Live List	No connection to Field Controller <ul style="list-style-type: none"> Check that host and Field Controller are in same subnet
3	Red cross appears on the Field Controller	No communication with Field Controller <ul style="list-style-type: none"> No Ethernet connection with Field Controller, check connection, IP address etc, see above No Device ID set in the Field Controller (Attributes)
4	Red cross appears on Fieldbus/Profibus	No communication with fieldbus/Profibus <ul style="list-style-type: none"> No communication with Field Controller, see above Fieldbus/Profibus not connected to controller
5	Red cross appears on field device	No communication with fieldbus device <ul style="list-style-type: none"> No communication with Field Controller, see above No communication with fieldbus, see above No Device ID set (Attributes) Tag not assigned (Assign Tag)
6	A device does not appear in the live list	Communication error <ul style="list-style-type: none"> The device is not powered up The project has been updated but no download has been made yet
7	Configuration will not download	You have either a communication problem or the configuration is not complete <ul style="list-style-type: none"> Check that you are on-line – press the On-line button Check that your computer is in the same address subnet Check that you have assigned the Field Controller tag Check that you have exported all tags OPC server Check that the parameters are in the recommended order Check that the OPC server is running (look for icon in bottom line) Try "Update" from the Field Controller node and download again
9	Parameter appears red in the on-line control strategy	The parameter has a bad status <ul style="list-style-type: none"> Check that the Block Mode is Auto (or Cas) Check that the block has been correctly configured Check that the device is still live (live list) Check that the device address is the same as that you have in your configuration (live list) Check that the parameter has been correctly configured Check that the tags were exported (Export Tags)
10	FB links do not work	Project not downloaded correctly, e.g. partial download when bridge has HSE links <ul style="list-style-type: none"> Repeat full download from the HSE Network node

For your notes

For your notes

For your notes

Index

A

Activating a library	52
Analog Input	27, 30, 31
Analog Output Block	37
Application Designer	81, 84
Assign All Tags	68
Assigning an IP address	60
Attributes	66, 67

C

Cascade Signal Characterizer	28
Close	81
Commissioning	3
Configuration	83
Configuration as XML	80
Configure device class	70
Constant block	26
Control module	19
Control Strategy	18, 73
ControlCare documents	5

D

Device ID	66, 67
Document Type	11
Download	69

E

Edit Resource Specifications	59
Edit Task Specifications	59
Exit	81
Export Configuration	78, 79
Export Tag	12, 17, 46

F

Factory initialisation and reset	82
FF project	11
Field Controller	5, 60
Field Controller Web Server	63
FieldController set-up	60
Function Block assignment	39
Function Block links	22

H

HSE live list	65
HSE Network	13, 69
HSE Network Setup	62
Hybrid block execution time	74
Hybrid Discrete I/Os block	33
Hybrid function block	47, 48

I

Input Parameter Selection	23
Installation	3
Installing a library	52
IP address of Field Controller	62
IP address of the host computer	61

L

Live List	67
-----------------	----

M

Micropilot M	44
Multiple Discrete Input block	32
Multiple Discrete Output block	34

N

ND9103FN positioner	45
Network	9
New Block	20
New Bridge	13
New Control Module	19
New Device	15
New Fieldbus	14
New Process Cell	18
New Project	11

O

On-Line button	65
OPC data base	77
Open PCS	81
OpenPCS	48, 71
Operation	3
Optimize for speed	59
Output Parameter Selection	23

P

Pack Project	77
Preferences	12
Process cell	18
PROFIBUS Configurator	84
PROFIBUS live list	67

S

Safety	3
Safety conventions	4
SP	75
Strategy Export	38
Strategy Import	38
Strategy template	38

T

Tag Composition	12
Tag Policy	12
TMT162 temperature transmitter	43
Trouble-shooting	55

U

Unpack Project	77
----------------------	----

www.endress.com/worldwide
