



Level



Pressure



Flow



Temperature



Liquid  
Analysis



Registration



Systems  
Components



Services




Solutions

Description of Device Functions

# Proline Prosonic Flow 93 FOUNDATION Fieldbus

Ultrasonic flow measuring system



BA00079D/06/EN/14.11  
71139012

Valid as of version:  
V 2.03.XX

Endress+Hauser

People for Process Automation

## **Operation of Proline Prosonic Flow 93 FOUNDATION Fieldbus**

- with local operation: **see Page 3**
- with FOUNDATION Fieldbus: **see Page 84**

## Content for Local operation

<b>1</b>	<b>Using this Manual</b>	<b>5</b>
1.1	Using the table of contents to locate a function description	5
1.2	Using the graphic of the function matrix to locate a function description	5
1.3	Using the index of the function matrix to locate a function description	5
<b>2</b>	<b>Function matrix</b>	<b>6</b>
2.1	General layout of the function matrix	6
2.1.1	Blocks (A, B, C, etc.)	6
2.1.2	Groups (AAA, AEA, CAA, etc.)	6
2.1.3	Function groups (000, 020, 060, etc.)	6
2.1.4	Functions (0000, 0001, 0002, etc.)	6
2.1.5	Codes identifying cells	7
2.2	Illustration of the function descriptions	7
2.3	Display lines on the local display	8
2.4	Function matrix of the Prosonic Flow 93 FOUNDATION Fieldbus	8
<b>3</b>	<b>Block MEASURED VARIABLES</b>	<b>9</b>
3.1	Group MEASURING VALUES	10
3.1.1	Function group MAIN VALUES CH1	10
3.1.2	Function group MAIN VALUES CH2	11
3.1.3	Function group CALCULATED MAIN VALUES	12
3.2	SYSTEM UNITS groups	13
3.2.1	Function group CONFIGURATION	13
3.2.2	Function group ADDITIONAL CONFIGURATION	15
<b>4</b>	<b>Block QUICK-SETUP</b>	<b>17</b>
4.1	Quick Setup	18
4.1.1	Quick Setup "Sensor Installation"	18
4.1.2	Quick Setup "Commissioning"	20
4.1.3	Data backup/transmission	21
<b>5</b>	<b>Block USER INTERFACE</b>	<b>22</b>
5.1	Group CONTROL	23
5.1.1	Function group BASIC CONFIGURATION	23
5.1.2	Function group UNLOCKING/LOCKING	25
5.1.3	Function group OPERATION	26
5.2	Group MAIN LINE	27
5.2.1	Function group CONFIGURATION	27
5.2.2	Function group MULTIPLEX	29
5.3	Group ADDITION LINE	31
5.3.1	Function group CONFIGURATION	31
5.3.2	Function group MULTIPLEX	33
5.4	Group INFORMATION LINE	35
5.4.1	Function group CONFIGURATION	35
5.4.2	Function group MULTIPLEX	37
<b>6</b>	<b>Block TOTALIZERS</b>	<b>39</b>
6.1	Group TOTALIZER (1 to 3)	40
6.1.1	Function group CONFIGURATION	40
6.1.2	Function group OPERATION	43
6.2	Group HANDLING TOTAL	44

<b>7</b>	<b>Block BASIC FUNCTION</b>	<b>45</b>
7.1	Group FOUNDATION FIELDBUS	46
7.1.1	Function group CONFIGURATION	46
7.1.2	Function group FUNCTION BLOCKS	47
7.1.3	Function group INFORMATION	48
7.2	Group PROCESS PARAMETER (CH1 to CH2)	49
7.2.1	Function group CONFIGURATION	49
7.2.2	Function group ADJUSTMENT	51
7.2.3	Function group PIPE DATA	52
7.2.4	Function group LIQUID DATA	57
7.3	Group SYSTEM PARAMETER (CH1 to CH2)	60
7.3.1	Function group CONFIGURATION	60
7.4	Group SENSOR DATA (CH1 to CH2)	62
7.4.1	Function group CONFIGURATION	62
7.4.2	Function group SENSOR PARAMETER	63
7.4.3	Function group CALIBRATION DATA	67
7.4.4	Function group ORIG. FACT. CALIBR.	69
<b>8</b>	<b>Block SUPERVISION</b>	<b>70</b>
8.1	Group SYSTEM (SYSTEM CH2)	71
8.1.1	Function group CONFIGURATION	71
8.1.2	Function group OPERATION	72
8.2	Group VERSION INFO	75
8.2.1	Function group DEVICE	75
8.2.2	Function group SENSOR	75
8.2.3	Function group AMPLIFIER	75
8.2.4	Function group F-CHIP	76
8.2.5	Function group I/O MODULE	76
<b>9</b>	<b>Factory settings</b>	<b>77</b>
9.1	SI units	77
9.2	US units (for USA and Canada only)	77
9.3	Language	77
<b>10</b>	<b>Index Function matrix</b>	<b>78</b>
<b>11</b>	<b>Index Local operation</b>	<b>80</b>

# 1 Using this Manual

There are various ways of locating the description of a function of your choice in the manual:

## 1.1 Using the table of contents to locate a function description

The designations of all the cells in the function matrix are listed in the table of contents. You can use these unambiguous designations (such as USER INTERFACE, INPUTS, OUTPUTS, etc.) to choose whichever functions are applicable to a particular set of conditions. The page references show you exactly where to find the detailed descriptions of the functions in question. The table of contents is on Page 3.

## 1.2 Using the graphic of the function matrix to locate a function description


This step-by-step, top-down approach starts with the blocks, the highest level, and works down through the matrix to the description of the function you need:

1. All blocks available, and their related groups, are illustrated on Page 6. Select the block (or the group within the block) which you need for your application and use the page reference to locate the information corresponding to the next level.
2. The page in question contains a graphic showing of the block with all its subordinate groups, function groups and functions. Select the function which you need for your application and use the page reference to locate the detailed function description.

## 1.3 Using the index of the function matrix to locate a function description

Each "cell" in the function matrix (blocks, groups, function groups, functions) has a unique identifier in the form of a code consisting of one or three letters or a three- or four-digit number. The code identifying a selected "cell" appears at the top right on the local display.

Example:



A0001653-EN


The function matrix index lists the codes for all the available "cells" in alphabetic and consecutive order, complete with the page references for the corresponding functions. The index to the function matrix is on Page 78.

## 2 Function matrix

### 2.1 General layout of the function matrix

The function matrix consists of four levels:

**Blocks -> Groups -> Function groups -> Functions**



A0000961

#### 2.1.1 Blocks (A, B, C, etc.)

The blocks are the "highest-level grouping" of the operation options for the device.

Examples of blocks available are MEASURED VARIABLES, QUICK SETUP, USER INTERFACE, TOTALIZERS, etc.

#### 2.1.2 Groups (AAA, AEA, CAA, etc.)

A block consists of one or more groups. Each group represents a more detailed selection of the operation options in the higher-order block. The groups in the "USER INTERFACE" block, for example, include: CONTROL, MAIN LINE, ADDITION LINE, etc.

#### 2.1.3 Function groups (000, 020, 060, etc.)

A group consists of one or more function groups. Each function group represents a more detailed selection of the operation options in the higher-order group. The function groups in the "CONTROL" group, for example, include: BASIC CONFIGURATION, UN-/LOCKING, OPERATION, etc.

#### 2.1.4 Functions (0000, 0001, 0002, etc.)

Each function group consists of one or more functions. The functions are used to operate and parameterize the device. Numerical values can be entered or parameters selected and saved. The functions in the "BASIC CONFIGURATION" function group include LANGUAGE, DISPLAY DAMPING, CONTRAST LCD, etc. The procedure for changing the language of the user interface, for example, is as follows:

1. Select the block "USER INTERFACE".
2. Select the group "CONTROL".
3. Select the function group "BASIC CONFIGURATION".
4. Select the function "LANGUAGE" (here you can set the language required).

### 2.1.5 Codes identifying cells

Each cell (block, group, function group and function) in the function matrix has an individual, unique code.

**Blocks:**

The code is a letter (A, B, C, etc.)

**Groups:**

The code consists of three letters (AAA, ABA, BAA, etc.).

The first letter matches the block code (i.e. each group in block A has a code starting with an A\_ \_; the codes of the groups in block B start with a B\_ \_, and so on). The other two letters are for identifying the group within the respective block.

**Function groups:**


The code consists of three digits (000, 001, 100, etc.)

**Functions:**

The code consists of four digits (0000, 0001, 0201, etc.).


The first three digits are the same as the code for the function group.

The last digit in the code is a counter for the functions in the function group, incrementing from 0 to 9 (e.g. function 0005 is the sixth function in group 000).



A0001251

## 2.2 Illustration of the function descriptions



A0004822-EN

Fig. 1: Example for the description of a function

- 1 Name of the function
- 2 Number of the function (appears on the local display)
- 3 Description of the function
- 4 Selection or entry options or display
- 5 Factory setting (the measuring device is delivered with this setting/selected option)

## 2.3 Display lines on the local display

The local display is split into various display lines.




Fig. 2: Local display

- 1 Main line
- 2 Additional line
- 3 Information line


A0001253

The values are assigned to the individual lines in the USER INTERFACE block, → Page 22.

## 2.4 Function matrix of the Prosonic Flow 93 FOUNDATION Fieldbus

BLOCKS	GROUPS	FUNCTION GROUPS
<b>MEASURED VARIABLES A</b> (→ Page 9)	→ MEASURING VALUES AAA	→ Page 10
	→ SYSTEM UNITS ACA	→ Page 13
↓		
<b>QUICK-SETUP B</b> (→ Page 17)	→ Commissioning and application setups	→ Page 17
↓		
<b>USER INTERFACE C</b> (→ Page 22)	→ CONTROL CAA	→ Page 23
	→ MAIN LINE CCA	→ Page 27
	→ ADDITION LINE CEA	→ Page 31
	→ INFORMATION LINE CGA	→ Page 35
↓		
<b>TOTALIZERS D</b> (→ Page 39)	→ TOTALIZER 1 DAA	→ Page 40
	→ TOTALIZER 2 DAB	→ Page 40
	→ TOTALIZER 3 DAC	→ Page 40
	→ HANDLING TOTALIZER DJA	→ Page 44
↓		
<b>BASIC FUNCTION G</b> (→ Page 45)	→ FOUNDATION FIELDBUS GGA	→ Page 46
	→ PROCESS PARAMETER (CH1 to CH2) GIA, GIB	→ Page 49
	→ SYSTEM PARAMETER (CH1 to CH2) GLA, GLB	→ Page 60
	→ Sensor data (CH1 to CH2) GNA, GNB	→ Page 62
↓		
<b>SUPERVISION J</b> (→ Page 70)	→ SYSTEM JAA	→ Page 71
	→ SYSTEM CH2 JAB	→ Page 71
	→ VERSION INFO JCA	→ Page 75

### 3 Block MEASURED VARIABLES



### 3.1 Group MEASURING VALUES

#### 3.1.1 Function group MAIN VALUES CH1



<b>Functional description</b>	
MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES CH1	
<p>The measuring values of channel 1 currently being measured are displayed in this function group.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group.</li> <li>■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.</li> </ul>	
<b>VOLUME FLOW CH1 (0001)</b>	<p>The volume flow currently measured appears on the display (channel 1).</p> <p><b>Display:</b> 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>
<b>SOUND VELOCITY CH1 (0002)</b>	<p>The sound velocity currently measured in the liquid appears on the display (channel 1).</p> <p><b>Display:</b> 5-digit fixed-point number, incl. units (e.g. 1400.0 m/s, 5249.3 ft/s)</p>
<b>FLOW VELOCITY CH1 (0003)</b>	<p>The flow velocity currently measured appears on the display (channel 1).</p> <p><b>Display:</b> 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)</p>
<b>SIGNAL STRENGTH CH1 (0007)</b>	<p>The signal strength appears on the display (channel 1).</p> <p><b>Display:</b> 4-digit fixed point number (e.g. 80.0)</p> <p> <b>Note!</b> To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of &gt; 30.</p>

### 3.1.2 Function group MAIN VALUES CH2



<b>Functional description</b>	
MEASURED VARIABLES → MEASURING VALUES → MAIN VALUES CH2	
<p>The measuring values of channel 2 currently being measured are displayed in this function group.</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group.</li> <li>■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.</li> </ul>	
<b>VOLUME FLOW CH2 (0061)</b>	<p>The volume flow currently measured appears on the display (channel 2).</p> <p><b>Display:</b> 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>
<b>SOUND VELOCITY CH2 (0062)</b>	<p>The sound velocity currently measured in the liquid appears on the display (channel 2).</p> <p><b>Display:</b> 5-digit fixed-point number, incl. units (e.g. 1400.0 m/s, 5249.3 ft/s)</p>
<b>FLOW VELOCITY CH2 (0063)</b>	<p>The flow velocity currently measured appears on the display (channel 2).</p> <p><b>Display:</b> 5-digit floating-point number, including unit and sign (e.g. 8.0000 m/s, 26.247 ft/s)</p>
<b>SIGNAL STRENGTH CH2 (0067)</b>	<p>The signal strength appears on the display (channel 2).</p> <p><b>Display:</b> 4-digit fixed-point number (e.g. 80.0)</p> <p> Note! To ensure reliable measurement takes place, Prosonic Flow requires a signal strength of &gt; 30.</p>


### 3.1.3 Function group CALCULATED MAIN VALUES



<b>Functional description</b>	
MEASURED VARIABLES → MEASURING VALUES → CALCULATED MAIN VALUES	
<p>The calculated measured values appear on the display. The measured values of both channels are used when calculating the values.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The engineering units of all the measured variables shown here can be set in the "SYSTEM UNITS" group.</li> <li>■ If the fluid in the pipe flows backwards, a negative sign prefixes the flow reading on the display.</li> </ul>	
<b>VOLUME FLOW AVG (0083)</b>	<p>The average volume flow appears on the display. Calculated from the measured values:  <math>(\text{VOLUME FLOW CH1} + \text{VOLUME FLOW CH2}) \cdot 1/2</math></p> <p><b>Display:</b>            5-digit floating-point number, including unit and sign            (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>
<b>VOLUME FLOW SUM (0084)</b>	<p>The total volume flow appears on the display. Calculated from the measured values:  <math>(\text{VOLUME FLOW CH1} + \text{VOLUME FLOW CH2})</math></p> <p><b>Display:</b>            5-digit floating-point number, including unit and sign            (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>
<b>VOLUME FLOW DIFFERENCE (0085)</b>	<p>The difference between the volume flows appears on the display. Calculated from the measured values:  <math>\text{VOLUME FLOW CH1} - \text{VOLUME FLOW CH2}</math></p> <p><b>Display:</b>            5-digit floating-point number, including unit and sign            (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p>
<b>SOUND VELOCITY AVERAGE (0086)</b>	<p>The average sound velocity appears on the display. Calculated from the measured values:  <math>(\text{SOUND VELOCITY CH1} + \text{SOUND VELOCITY CH2}) \cdot 1/2</math></p> <p><b>Display:</b>            5-digit fixed-point number, incl. units            (e.g. 1400.0 m/s, 5249.3 ft/s)</p>
<b>FLOW VELOCITY AVERAGE (0087)</b>	<p>The average flow velocity appears on the display. Calculated from the measured values:  <math>(\text{FLOW VEL. CH1} + \text{FLOW VEL. CH2}) \cdot 1/2</math></p> <p><b>Display:</b>            5-digit floating-point number, including unit and sign            (e.g. 8.0000 m/s, 26.247 ft/s)</p>

### 3.2 SYSTEM UNITS groups


#### 3.2.1 Function group CONFIGURATION



<b>Functional description</b>	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
<p>You can select the units for measured variables in this function group.</p> <p> <b>Note!</b> The units selected here have no effect on the FOUNDATION Fieldbus. They are only used for the local display and for assigned instrument functions.</p>	
<p><b>UNIT VOLUME FLOW (0402)</b></p>	<p>Use this function to select the unit for displaying the volume flow.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Simulation</li> <li>■ Low flow cut off</li> </ul> <p><b>Options:</b></p> <p> <b>Note!</b> The following units of time (...) can be selected: s = second, m = minute, h = hour, d = day</p> <p><i>Metric:</i> Cubic centimeter → cm<sup>3</sup>/... Cubic decimeter → dm<sup>3</sup>/... Cubic meter → m<sup>3</sup>/... Milliliter → ml/... Liter → l/... Hectoliter → hl/... Megaliter → Ml/... MEGA</p> <p><i>US:</i> Cubic centimeter → cc/... Acre foot → af/... Cubic foot → ft<sup>3</sup>/... Fluid ounce → oz f/... Gallon → US gal/... Million gallon → US Mgal/... Barrel (normal fluids: 31.5 gal/bbl) → US bbl/... NORM. Barrel (beer: 31.0 gal/bbl) → US bbl/... BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl/... PETR. Barrel (filling tanks: 55.0 gal/bbl) → US bbl/... TANK</p> <p><i>Imperial:</i> Gallon → imp. gal/... Mega gallon → imp. Mgal/... Barrel (beer: 36.0 gal/bbl) → imp. bbl/... BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl/... PETR.</p> <p><b>Factory setting:</b> Depends on country (dm<sup>3</sup>/m...m<sup>3</sup>/h or US gal/m...US Mgal/d)</p>

<b>Functional description</b>	
MEASURED VARIABLES → SYSTEM UNITS → CONFIGURATION	
<b>UNIT VOLUME (0403)</b>	<p>Use this function to select the unit for displaying the volume.</p> <p><b>Options:</b></p> <p><i>Metric:</i>  Cubic centimeter → cm<sup>3</sup>  Cubic decimeter → dm<sup>3</sup>  Cubic meter → m<sup>3</sup>  Milliliter → ml  Liter → l  Hectoliter → hl  Megaliter → Ml MEGA</p> <p><i>US:</i>  Cubic centimeter → cc  Acre foot → af  Cubic foot → ft<sup>3</sup>  Fluid ounce → oz f  Gallon → US gal  Million gallon → US Mgal  Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL.  Barrel (beer: 31.0 gal/bbl) → US bbl BEER  Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH.  Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK</p> <p><i>Imperial:</i>  Gallon → imp. gal  Mega gallon → imp. Mgal  Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER  Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH.</p> <p><b>Factory setting:</b>  Depends on country (dm<sup>3</sup>/m...m<sup>3</sup>/h or US gal/m...US Mgal/d)→ Page 77.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The unit of the totalizers is independent of your choice here. The unit for each totalizer is selected separately for the totalizer in question.</li> <li>■ The unit selected in this function is only for showing the values on the local display, i.e. the measuring system does not use it for further processing of the measured variables.</li> </ul>

### 3.2.2 Function group ADDITIONAL CONFIGURATION



<b>Functional description</b>	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
<p> <b>Note!</b> The units selected here have no effect on the FOUNDATION Fieldbus. They are only used for the local display and for assigned instrument functions.</p>	
<p><b>UNIT TEMPERATURE (0422)</b></p>	<p>Use this function to select the unit for displaying the fluid temperature.</p> <p> <b>Note!</b> The fluid temperature is entered in the TEMPERATURE function (→ Page 57).</p> <p><b>Options:</b> °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine)</p> <p><b>Factory setting:</b> Depends on country (°C or °F) → Page 77</p>
<p><b>UNIT VISCOSITY (0423)</b></p>	<p>Use this function to select the unit for fluid viscosity.</p> <p> <b>Note!</b> The viscosity is entered in the function (→ Page 58).</p> <p><b>Options:</b> mm<sup>2</sup>/s cSt St</p> <p><b>Factory setting:</b> mm<sup>2</sup>/s</p>
<p><b>UNIT LENGTH (0424)</b></p>	<p>Use this function to select the unit for the measure of length.</p> <p>The unit you select here is valid for:</p> <ul style="list-style-type: none"> <li>■ Nominal diameter</li> <li>■ Diameter</li> <li>■ Wall thickness</li> <li>■ Liner thickness</li> <li>■ Path length</li> <li>■ Wire length</li> <li>■ Sensor spacing</li> </ul> <p><b>Options:</b> MILLIMETER INCH</p> <p><b>Factory setting:</b> Depends on country (MILLIMETER or INCH) → Page 77</p>

<b>Functional description</b>	
MEASURED VARIABLES → SYSTEM UNITS → ADDITIONAL CONFIGURATION	
<b>UNIT VELOCITY (0425)</b>	<p>Use this function to select the unit for displaying the velocity.</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Sound velocity</li> <li>■ Flow velocity</li> </ul> <p><b>Options:</b> m/s ft/s</p> <p><b>Factory setting:</b> m/s</p>
<b>FORMAT DATE/TIME (0429)</b>	<p>Use this function to select the date and time format of the calibration history.</p> <p><b>Options:</b> DD.MM.YY 24 H MM/DD/YY 12 H A/P DD.MM.YY 12 H A/P MM/DD/YY 24 H</p> <p><b>Factory setting:</b> DD.MM.YY 24 H</p>

## 4 Block QUICK-SETUP


Block	Group	Function groups	Functions					
QUICK-SETUP (B)	→	→	<table border="1"> <tr> <td>SETUP SENSOR (1001) P. 17</td> <td>→</td> <td> <table border="1"> <tr> <td>QS-COMMISSION. (1002) P. 17</td> <td>T-DAT SAVE/LOAD (1009) P. 17</td> </tr> </table> </td> </tr> </table>	SETUP SENSOR (1001) P. 17	→	<table border="1"> <tr> <td>QS-COMMISSION. (1002) P. 17</td> <td>T-DAT SAVE/LOAD (1009) P. 17</td> </tr> </table>	QS-COMMISSION. (1002) P. 17	T-DAT SAVE/LOAD (1009) P. 17
SETUP SENSOR (1001) P. 17	→	<table border="1"> <tr> <td>QS-COMMISSION. (1002) P. 17</td> <td>T-DAT SAVE/LOAD (1009) P. 17</td> </tr> </table>	QS-COMMISSION. (1002) P. 17	T-DAT SAVE/LOAD (1009) P. 17				
QS-COMMISSION. (1002) P. 17	T-DAT SAVE/LOAD (1009) P. 17							

Functional description QUICK-SETUP	
<b>QUICK SETUP SENSOR (1001)</b>	<p>Use this function to start the Quick Setup menu for assembling the ultrasonic sensors.</p> <p><b>Options:</b> YES NO</p> <p><b>Factory setting:</b> NO</p> <p> Note! You will find a flowchart of the "SENSOR INSTALLATION" Quick Setup menu on Page 18. Please refer to the Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA0078D, for more information on Quick Setup menus.</p>
<b>SETUP COMMISSIONING (1002)</b>	<p>Use this function to start the Quick Setup menu for commissioning.</p> <p><b>Options:</b> YES NO</p> <p><b>Factory setting:</b> NO</p> <p> Note! You will find a flowchart of the "SENSOR INSTALLATION" Quick Setup menu on Page 18. Please refer to the Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA0078D, for more information on Quick Setup menus.</p>
<b>T-DAT SAVE/LOAD (1009)</b>	<p>Use this function to save the parameter settings / configuration of the <b>transmitter</b> in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM (<b>manual</b> security function).</p> <p>Application examples:</p> <ul style="list-style-type: none"> <li>■ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup.</li> <li>■ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM).</li> </ul> <p><b>Options:</b> CANCEL SAVE (from EEPROM to T-DAT) LOAD (from the T-DAT into EEPROM)</p> <p><b>Factory setting:</b> CANCEL</p> <p> Note!  <ul style="list-style-type: none"> <li>■ If the power supply fails, the totalizer readings are automatically saved to the EEPROM.</li> <li>■ The option "LOAD" cannot be executed if the T-DAT is empty or faulty.</li> <li>■ The option "LOAD" and "SAVE" cannot be executed if no T-DAT is present.</li> </ul> </p>

## 4.1 Quick Setup

In the case of measuring devices without a local display, the individual parameters and functions must be configured via the operating program, e.g. FieldCare.  
 If the measuring device is equipped with a local display, all the important device parameters for standard operation, as well as additional functions, can be configured quickly and easily by means of the following Quick Setup menus.

### 4.1.1 Quick Setup "Sensor Installation"



A0008714-en

**Note!**


The display returns to the cell SETUP SENSOR (1001) if you press the ESC key combination during interrogation.

- ① If a channel is selected for which a Quick Setup has already been executed, the previous values are overwritten.
- ② During each run, all the options can be selected. If settings were made during a previous run, these are overwritten.
- ③ "Save?" prompt for pipe sound velocity:
  - YES = The value measured during Quick Setup is accepted in the appropriate function.
  - NO = The measurement is discarded and the original value remains.
- ④ The SOUND VELOCITY LINER (6529) only appears if:
  - The LINER MATERIAL is selected to something other than NONE (6528).
- ⑤ The LINER THICKNESS (6530) only appears if:
  - The LINER MATERIAL is selected to something other than NONE (6528).
- ⑥ The POSITION SENSOR function (6884) only appears if:
  - The CLAMP ON option is selected in the MEASUREMENT function (6880)
  - and**
  - Two traverses are selected in the SENSOR CONFIGURATION function (6882)
- ⑦ The WIRE LENGTH function (6885) only appears if:
  - The CLAMP ON option is selected in the MEASUREMENT function (6880)
  - and**
  - One traverse is selected in the SENSOR CONFIGURATION function (6882)
- ⑧ The ARC LENGTH function (6887) only appears if:
  - The INSERTION option is selected in the MEASUREMENT function (6880)
  - and**
  - The DUAL-PATH option is selected in the SENSOR CONFIGURATION function (6882)

### 4.1.2 Quick Setup "Commissioning"

The installation distances needed to install the sensors can be determined using the "Sensor Installation" Quick Setup menu.

In the case of measuring devices without a local display, the installation distances can be determined via the FieldCare operating program or with the Applicator online tool.



a0014889-en

Note!

- The display returns to the function SETUP COMMISSIONING (1002) if you press the ESC key combination during parameter interrogation.
- The "Commissioning" Quick Setup must be carried out before one of the Quick Setups explained below is run.

- ① The "DELIVERY SETTINGS" option sets every selected unit to the factory setting. The "ACTUAL SETTINGS" accepts the units you configured beforehand.
- ② Only units not yet configured in the current Quick Setup are offered for selection in each cycle. The volume unit is derived from the volume flow unit.
- ③ The "YES" option remains visible until all the units have been configured. "NO" is the only option displayed when no further units are available.
- ④ The "automatic parameterization of the display" option contains the following basic settings/factory settings
 

YES	Main line = volume flow
	Additional line = Totalizer 1
	Information line = Operating/system condition
NO	The existing (selected) settings remain.
- ⑤ The execution of other Quick Setups is described in the following sections.

### 4.1.3 Data backup/transmission

Using the T-DAT SAVE/LOAD function, you can transfer data (device parameters and settings) between the T-DAT (exchangeable memory) and the EEPROM (device storage unit).


This is required in the following instances:

- Creating a backup: current data are transferred from an EEPROM to the T-DAT.
- Replacing a transmitter: current data are copied from an EEPROM to the T-DAT and then transferred to the EEPROM of the new transmitter.
- Duplicating data: current data are copied from an EEPROM to the T-DAT and then transferred to EEPROMs of identical measuring points.



Note!

For information on installing and removing the T-DAT, see Operating Instructions Prosonic Flow 93 FOUNDATION Fieldbus, BA0078D.



a0001221-en

Fig. 3: Data backup/transmission with T-DAT SAVE/LOAD function

Information on the LOAD and SAVE options available:

LOAD: Data are transferred from the T-DAT to the EEPROM.




Note!

- Any settings already saved on the EEPROM are deleted.
- This option is only available, if the T-DAT contains valid data.
- This option can only be executed if the software version of the T-DAT is the same or newer than that of the EEPROM. Otherwise, the error message "TRANSM. SW-DAT" appears after restarting and the LOAD function is then no longer available.

SAVE:

Data are transferred from the EEPROM to the T-DAT

# 5 Block USER INTERFACE



## 5.1 Group CONTROL


### 5.1.1 Function group BASIC CONFIGURATION

USER INTERFACE C → CONTROL CAA → BASIC CONFIGURATION 200

<b>Functional description</b>																																							
USER INTERFACE → CONTROL → BASIC CONFIGURATION																																							
<b>LANGUAGE (2000)</b>	<p>Use this function to select the language for all texts, parameters and messages shown on the local display.</p> <p> <b>Note!</b> The displayed options depend on the available language group shown in the LANGUAGE GROUP function (8226).</p> <p><b>Options:</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 40%;">Language group</td> <td>ENGLISH</td> </tr> <tr> <td>WEST EU / USA</td> <td>DEUTSCH</td> </tr> <tr> <td></td> <td>FRANCAIS</td> </tr> <tr> <td></td> <td>ESPANOL</td> </tr> <tr> <td></td> <td>ITALIANO</td> </tr> <tr> <td></td> <td>NEDERLANDS</td> </tr> <tr> <td></td> <td>PORTUGUESE</td> </tr> <tr> <td>Language group</td> <td>ENGLISH</td> </tr> <tr> <td>EAST EU / SCAND.</td> <td>NORSK</td> </tr> <tr> <td></td> <td>SVENSKA</td> </tr> <tr> <td></td> <td>SUOMI</td> </tr> <tr> <td></td> <td>POLISH</td> </tr> <tr> <td></td> <td>CZECH</td> </tr> <tr> <td></td> <td>RUSSIAN</td> </tr> <tr> <td>Language group ASIA</td> <td>ENGLISH</td> </tr> <tr> <td></td> <td>BAHASA INDONESIA</td> </tr> <tr> <td></td> <td>JAPANESE (syllabary)</td> </tr> <tr> <td>Language group</td> <td>CHINESE</td> </tr> <tr> <td>CHINESE</td> <td>ENGLISH</td> </tr> </table> <p><b>Factory setting:</b> Depends on country → Page 77</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ If you press the  keys simultaneously when starting, the language is set to ENGLISH.</li> <li>■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</li> </ul>	Language group	ENGLISH	WEST EU / USA	DEUTSCH		FRANCAIS		ESPANOL		ITALIANO		NEDERLANDS		PORTUGUESE	Language group	ENGLISH	EAST EU / SCAND.	NORSK		SVENSKA		SUOMI		POLISH		CZECH		RUSSIAN	Language group ASIA	ENGLISH		BAHASA INDONESIA		JAPANESE (syllabary)	Language group	CHINESE	CHINESE	ENGLISH
Language group	ENGLISH																																						
WEST EU / USA	DEUTSCH																																						
	FRANCAIS																																						
	ESPANOL																																						
	ITALIANO																																						
	NEDERLANDS																																						
	PORTUGUESE																																						
Language group	ENGLISH																																						
EAST EU / SCAND.	NORSK																																						
	SVENSKA																																						
	SUOMI																																						
	POLISH																																						
	CZECH																																						
	RUSSIAN																																						
Language group ASIA	ENGLISH																																						
	BAHASA INDONESIA																																						
	JAPANESE (syllabary)																																						
Language group	CHINESE																																						
CHINESE	ENGLISH																																						
<b>DISPLAY DAMPING (2002)</b>	<p>Use this function to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p><b>User input:</b> 0 to 100 seconds</p> <p><b>Factory setting:</b> 1 s</p> <p> <b>Note!</b> Setting the time constant to zero seconds switches off damping.</p>																																						


<b>Functional description</b>	
USER INTERFACE → CONTROL → BASIC CONFIGURATION	
<b>CONTRAST LCD</b> (2003)	<p>Use this function to optimize display contrast to suit local operating conditions.</p> <p><b>User input:</b> 10...100%</p> <p><b>Factory setting:</b> 50%</p>
<b>BACKLIGHT</b> (2004)	<p>Use this function to optimize the backlight to suit local operating conditions.</p> <p><b>User input:</b> 10...100%</p> <p><b>Factory setting:</b> 50%</p>
<b>X-LINE CALCULATED MAIN VALUES</b> (2009)	<p>Use this function to indicate which "calculated main value" from the measured values of both channels is displayed. The option CALCULATED VOLUME FLOW must be selected in the ASSIGN function (2200, main line), (2400, additional line), (2600, information line) so that the value appears in the line desired.</p> <p> <b>Note!</b> This function does <b>not</b> appear if OFF was selected on at least one channel in the MEASUREMENT function (6880).</p> <p><b>Options:</b> (CH1 + CH2)/2 CH1 + CH2 CH1 - CH2</p> <p><b>Factory setting:</b> (CH1 + CH2)/2</p>

### 5.1.2 Function group UNLOCKING/LOCKING



<b>Functional description</b>	
DISPLAY → CONTROL → UNLOCKING/LOCKING	
<b>ACCESS CODE (2020)</b>	<p>All data of the measuring system are protected against inadvertent change. Programming is disabled and the settings cannot be changed until a code is entered in this function. If you press the  keys in any function, the measuring system automatically goes to this function and the prompt to enter the code appears on the display (when programming is disabled).</p> <p>You can enable programming by entering your personal code (<b>factory setting = 93</b>, see DEF.PRIVATE CODE (2021)).</p> <p><b>User input:</b> max. 4-digit number: 0 to 9999</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The programming levels are disabled if you do not press a key within 60 seconds following automatic return to the HOME position.</li> <li>■ You can also disable programming in this function by entering any number (other than the defined private code).</li> <li>■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.</li> <li>• In this function, access to programming is only valid for local configuration. If functions or parameters are to be changed via the FOUNDATION Fieldbus, programming must be enabled separately in the parameter "Un/Locking - Access Code" (Transducer Blocks).</li> </ul>
<b>DEF. PRIVATE CODE (2021)</b>	<p>Use this function to specify a personal code number for enabling programming in the ACCESS CODE function.</p> <p><b>User input:</b> 0 to 9999 (max. 4-digit number)</p> <p><b>Factory setting:</b> 93</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Programming is always enabled with the code "0".</li> <li>■ Programming has to be enabled before this code can be changed. When programming is disabled this function is not available, thus preventing others from accessing your personal code.</li> </ul>
<b>STATUS ACCESS (2022)</b>	<p>Use this function to check the access status for the function matrix.</p> <p><b>Display:</b> ACCESS CUSTOMER (parameterization possible) LOCKED (parameterization disabled)</p>
<b>ACCESS CODE COUNTER (2023)</b>	<p>The number of times the private or service code was entered to access the device appears on the display.</p> <p><b>Display:</b> Integer (delivery status: 0)</p>


### 5.1.3 Function group OPERATION



<b>Functional description</b>	
USER INTERFACE → CONTROL → OPERATION	
<b>TEST DISPLAY (2040)</b>	<p>Use this function to test the operability of the local display and its pixels.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p>Test sequence:</p> <ol style="list-style-type: none"> <li>1. Start the test by selecting ON.</li> <li>2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds.</li> <li>3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds.</li> <li>4. Main line, additional line and information line show a "0" in each field for minimum 0.75 seconds.</li> <li>5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds.</li> </ol> <p>When the test completes the local display returns to its initial state and the setting changes to OFF.</p>

## 5.2 Group MAIN LINE

### 5.2.1 Function group CONFIGURATION




<b>Functional description</b> DISPLAY → MAIN LINE → CONFIGURATION	
<p>1 = Main line 2 = Additional line 3 = Information line</p>	
<p><b>ASSIGN (2200)</b></p>	<p>Use this function to define the display value assigned to the main line (the top line of the local display) during normal measuring operation.</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALCULATED VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALCULATED VOLUME FLOW IN %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVERAGE            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVERAGE            TOTALIZER 1 TO 3            AI1 to AI8 - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)</p> <p> Note!            If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</p> <p><b>Factory setting:</b>            VOLUME FLOW CH1</p>
<p><b>100% VALUE (2201)</b></p>	<p> Note!            This function is only available if VOLUME FLOW % or CALCULATED VOLUME FLOW % is selected in the ASSIGN function (2200).</p> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>            5-digit floating-point number</p> <p><b>Factory setting:</b>            Depends on country [10 l/s or 200 us.gal/min] → Page 77.</p>

A0001253

<b>Functional description</b>	
DISPLAY → MAIN LINE → CONFIGURATION	
<b>FORMAT (2202)</b>	<p>Use this function to define the maximum number of places after the decimal point displayed for the reading in the main line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"><li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li><li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li></ul>

### 5.2.2 Function group MULTIPLEX




<b>Functional description</b> USER INTERFACE → MAIN LINE → MULTIPLEX	
<b>ASSIGN</b> <b>(2220)</b>	<p>Use this function to define a second reading to be displayed in the main line alternatively (every 10 seconds) with the reading defined in the ASSIGN function (2200).</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALCULATED VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALCULATED VOLUME FLOW IN %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVERAGE            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVERAGE            TOTALIZER 1 TO 3            AI1 to AI8 - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)</p> <p> Note!            If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</p> <p><b>Factory setting:</b>            OFF</p>
<b>100% VALUE</b> <b>(2221)</b>	<p> Note!            This function is only available if VOLUME FLOW % or CALCULATED VOLUME FLOW % is selected in the ASSIGN function (2200).</p> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>            5-digit floating-point number</p> <p><b>Factory setting:</b>            Depends on country [10 l/s or 200 us.gal/min] → Page 77.</p>

<b>Functional description</b> USER INTERFACE → MAIN LINE → MULTIPLEX	
<b>FORMAT</b> <b>(2222)</b>	<p>Use this function to define the maximum number of places after the decimal point for the second value displayed in the main line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"><li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li><li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li></ul>

## 5.3 Group ADDITION LINE

### 5.3.1 Function group CONFIGURATION




Functional description	
DISPLAY → ADDITIONAL LINE → CONFIGURATION	
<p>1 = Main line  <b>2 = Additional line</b>            3 = Information line</p>	
<p><b>ASSIGN (2400)</b></p>	<p>Use this function to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation.</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALCULATED VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALCULATED VOLUME FLOW IN %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVERAGE            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVERAGE            VOLUME FLOW BARGRAPH IN % (CH1 to CH2)            CALCULATED VOLUME FLOW BARGRAPH %            SIGNAL STRENGTH BARGRAPH % (CH1 to CH2)            TOTALIZER (1 to 3)            FLOW DIRECTION (CH1 to CH2)            CALCULATED FLOW DIRECTION            AI1 to AI8 - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)            DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>            TOTALIZER 1</p> <p> <b>Note!</b>            If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</p>

A0001253

<b>Functional description</b> DISPLAY → ADDITIONAL LINE → CONFIGURATION	
<b>100% VALUE (2401)</b>	<p> <b>Note!</b> This function is not available unless one of the following was selected in the ASSIGN function (2400):</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH %</li> <li>■ CALCULATED VOLUME FLOW IN %</li> <li>■ CALCULATED VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> Depends on country [10 l/s or 200 us.gal/min] → Page 77.</p>
<b>FORMAT (2402)</b>	<p> <b>Note!</b> This function is not available unless a number was selected in the ASSIGN function (2400).</p> <p>Use this function to define the maximum number of places after the decimal point displayed for the reading in the additional line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>DISPLAY MODE (2403)</b>	<p> <b>Note!</b> This function is only available if VOLUME FLOW BARGRAPH IN % or CALCULATED VOLUME FLOW BARGRAPH IN % was selected in the ASSIGN function (2420).</p> <p>Use this function to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin: 10px 0;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin: 10px 0;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>

### 5.3.2 Function group MULTIPLEX




<b>Functional description</b>	
USER INTERFACE → ADDITION LINE → MULTIPLEX	
<b>ASSIGN</b> (2420)	Use this function to define a second reading to be displayed in the additional line alternatively (every 10 seconds) with the reading defined in the ASSIGN function (2400).  <b>Options:</b> OFF VOLUME FLOW (CH1 to CH2) CALCULATED VOLUME FLOW VOLUME FLOW % (CH1 to CH2) CALCULATED VOLUME FLOW IN % SOUND VELOCITY (CH1 to CH2) SOUND VELOCITY AVERAGE SIGNAL STRENGTH (CH1 to CH2) FLOW VELOCITY (CH1 to CH2) FLOW VELOCITY AVERAGE VOLUME FLOW BARGRAPH IN % (CH1 to CH2) CALCULATED VOLUME FLOW BARGRAPH % SIGNAL STRENGTH BARGRAPH % (CH1 to CH2) TOTALIZER (1 to 3) FLOW DIRECTION (CH1 to CH2) CALCULATED FLOW DIRECTION AI1 to AI8 - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable) DEVICE PD-TAG (tag name)  <b>Factory setting:</b> OFF  Note! <ul style="list-style-type: none"> <li>■ Multiplex mode is suspended as soon as a fault / notice message is generated.</li> <li>■ If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</li> </ul>
<b>100% VALUE</b> (2421)	Note! This function is not available unless one of the following was selected in the ASSIGN function (2420): <ul style="list-style-type: none"> <li>■ VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH %</li> <li>■ CALCULATED VOLUME FLOW IN %</li> <li>■ CALCULATED VOLUME FLOW BARGRAPH %</li> </ul> Use this function to define the flow value to be shown on the display as the 100% value.  <b>User input:</b> 5-digit floating-point number  <b>Factory setting</b> Depends on country [10 l/s or 200 us.gal/min] → Page 77.

<b>Functional description</b>	
USER INTERFACE → ADDITION LINE → MULTIPLEX	
<b>FORMAT (2422)</b>	<p> <b>Note!</b> This function is not available unless a number was selected in the ASSIGN function (2420).</p> <p>Use this function to define the maximum number of places after the decimal point for the second value displayed in the additional line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>▪ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>▪ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>DISPLAY MODE (2423)</b>	<p> <b>Note!</b> This function is only available if VOLUME FLOW BARGRAPH IN % or CALCULATED VOLUME FLOW BARGRAPH IN % was selected in the ASSIGN function (2420).</p> <p>Use this function to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin: 10px 0;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with –50 / 0 / +50% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; display: inline-block; margin: 10px 0;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>

## 5.4 Group INFORMATION LINE


### 5.4.1 Function group CONFIGURATION



Functional description DISPLAY→ INFORMATION LINE→ CONFIGURATION	
<p>1 = Main line 2 = Additional line 3 = <b>Information line</b></p>	<p style="text-align: right; font-size: small;">A0001253</p>
<p><b>ASSIGN</b> (2600)</p>	<p>Use this function to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation.</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALCULATED VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALCULATED VOLUME FLOW IN %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVERAGE            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVERAGE            VOLUME FLOW BARGRAPH IN % (CH1 to CH2)            CALCULATED VOLUME FLOW BARGRAPH %            SIGNAL STRENGTH BARGRAPH % (CH1 to CH2)            TOTALIZER (1 to 3)            OPERATING/SYSTEM CONDITIONS            FLOW DIRECTION (CH1 to CH2)            CALCULATED FLOW DIRECTION            AI1 to AI8 - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)            DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>            OPERATING/SYSTEM CONDITIONS</p> <p> <b>Note!</b>            If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</p>

<b>Functional description</b>	
DISPLAY → INFORMATION LINE → CONFIGURATION	
<b>100% VALUE (2601)</b>	<p> <b>Note!</b> This function is not available unless one of the following was selected in the ASSIGN function (2400):</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH %</li> <li>■ CALCULATED VOLUME FLOW IN %</li> <li>■ CALCULATED VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> Depends on country [10 l/s or 200 us.gal/min] → Page 77.</p>
<b>FORMAT (2602)</b>	<p> <b>Note!</b> This function is not available unless a number was selected in the ASSIGN function (2600).</p> <p>Use this function to define the maximum number of places after the decimal point displayed for the reading in the information line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>DISPLAY MODE (2603)</b>	<p> <b>Note!</b> This function is only available if VOLUME FLOW BARGRAPH IN % or CALCULATED VOLUME FLOW BARGRAPH IN % was selected in the ASSIGN function (2600).</p> <p>Use this function to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>


### 5.4.2 Function group MULTIPLEX



<b>Functional description</b>	
USER INTERFACE → INFORMATION LINE → MULTIPLEX	
<b>ASSIGN (2620)</b>	<p>Use this function to define a second reading to be displayed in the information line alternatively (every 10 seconds) with the reading defined in the ASSIGN function (2600).</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALCULATED VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALCULATED VOLUME FLOW IN %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVERAGE            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVERAGE            VOLUME FLOW BARGRAPH IN % (CH1 to CH2)            CALCULATED VOLUME FLOW BARGRAPH % (CH1 to CH2)            SIGNAL STRENGTH BARGRAPH % (CH1 to CH2)            TOTALIZER (1 to 3)            OPERATING/SYSTEM CONDITIONS            FLOW DIRECTION (CH1 to CH2)            CALCULATED FLOW DIRECTION            AI1 to AI8 - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)            DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>            OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Multiplex mode is suspended as soon as a fault / notice message is generated.</li> <li>■ If a channel is not visible, it does not appear in the options. Channels can be displayed or hidden by means of the MEASUREMENT function (6880).</li> </ul>


<b>Functional description</b> USER INTERFACE → INFORMATION LINE → MULTIPLEX	
<b>100% VALUE (2621)</b>	<p> <b>Note!</b>                      This function is not available unless one of the following was selected in the ASSIGN function (2400):</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH %</li> <li>■ CALCULATED VOLUME FLOW IN %</li> <li>■ CALCULATED VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this function to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>                      5-digit floating-point number</p> <p><b>Factory setting:</b>                      Depends on country [10 l/s or 200 us.gal/min] → Page 77.</p>
<b>FORMAT (2622)</b>	<p> <b>Note!</b>                      This function is not available unless a number was selected in the ASSIGN function (2600).</p> <p>Use this function to define the maximum number of places after the decimal point for the second value displayed in the information line.</p> <p><b>Options:</b>                      XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b>                      X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → m<sup>3</sup>/h), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>DISPLAY MODE (2623)</b>	<p> <b>Note!</b>                      This function is only available if VOLUME FLOW BARGRAPH IN % or CALCULATED VOLUME FLOW BARGRAPH IN % was selected in the ASSIGN function (2620).</p> <p>Use this function to define the format of the bar graph.</p> <p><b>Options:</b>                      STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: 10px auto;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b>                      STANDARD</p>

# 6 Block TOTALIZERS



## 6.1 Group TOTALIZER (1 to 3)

### 6.1.1 Function group CONFIGURATION




<b>Functional description</b>	
TOTALIZERS → TOTALIZERS (1...3) → CONFIGURATION	
The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.	
<b>ASSIGN (3000)</b>	<p>Use this function to assign a measured variable to the totalizer.</p> <p><b>Options (standard):</b>            OFF            VOLUME FLOW (CH1 to CH2)            VOLUME FLOW AVERAGE            VOLUME FLOW SUM            VOLUME FLOW DIFFERENCE</p> <p><b>Factory setting:</b>            VOLUME FLOW CH1</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The totalizer is reset to "0" as soon as the selection is changed.</li> <li>■ If you select OFF, the only function shown in the CONFIGURATION function group is the ASSIGN function (3000).</li> </ul>

<b>Functional description</b>	
TOTALIZERS → TOTALIZERS (1...3) → CONFIGURATION	
<b>UNIT TOTALIZER (3001)</b>	<p>Use this function to define the unit for the totalizer's measured variable, as selected beforehand.</p> <p><b>Options:</b></p> <p><i>Metric:</i>                      Cubic centimeter → cm<sup>3</sup>                      Cubic decimeter → dm<sup>3</sup>                      Cubic meter → m<sup>3</sup>                      Milliliter → ml                      Liter → l                      Hectoliter → hl                      Megaliter → Ml MEGA</p> <p><i>US:</i>                      Cubic centimeter → cc                      Acre foot → af                      Cubic foot → ft<sup>3</sup>                      Fluid ounce → oz f                      Gallon → US gal                      Million gallon → US Mgal                      Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL.                      Barrel (beer: 31.0 gal/bbl) → US bbl BEER                      Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH.                      Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK</p> <p><i>Imperial:</i>                      Gallon → imp. gal                      Mega gallon → imp. Mgal                      Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER                      Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH.</p> <p><b>Factory setting:</b>                      Depends on country [m<sup>3</sup> or us.gal] → Page 77.</p> <p> <b>Note!</b>                      The unit selected here has no effect on the FOUNDATION Fieldbus. It is only used for the local display and for assigned instrument functions.</p>
<b>TOTALIZER MODE (3002)</b>	<p>Use this function to define how the flow components are to be totaled by the totalizer.</p> <p><b>Options:</b>                      BALANCE                      Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>FORWARD Only positive flow components</p> <p>REVERSE                      Negative flow components only</p> <p><b>Factory setting:</b>                      Totalizer 1 = BALANCE                      Totalizer 2 = FORWARD                      Totalizer 3 = REVERSE</p>


<b>Functional description</b> TOTALIZERS → TOTALIZERS (1...3) → CONFIGURATION	
<b>RESET TOTALIZER (3003)</b>	Use this function to reset the sum and the overflow of the totalizer to zero.  <b>Options:</b> NO YES  <b>Factory setting:</b> NO

### 6.1.2 Function group OPERATION



<b>Functional description</b>	
TOTALIZERS → TOTALIZERS (1...3) → OPERATION	
The function descriptions below apply to totalizers 1 to 3; the totalizers are independently configurable.	
<p><b>SUM (3040)</b></p>	<p>Use this function to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the function TOTALIZER MODE (3002) and the flow direction.</p> <p><b>Display:</b> Max. 7-digit floating-point number, including unit and sign (e.g. 15467.04m<sup>3</sup>; -4925.631 kg)</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The effect of the setting in the TOTALIZER MODE function (3002) is as follows:               <ul style="list-style-type: none"> <li>- If the setting is BALANCE, the totalizer balances flow in the positive and negative directions.</li> <li>- If the setting is FORWARD, the totalizer registers only flow in the positive direction.</li> <li>- If the setting is REVERSE, the totalizer registers only flow in the negative direction.</li> </ul> </li> <li>■ The totalizers' response to faults is defined in the "FAILSAFE MODE" function (3801).</li> </ul>
<p><b>OVERFLOW (3041)</b></p>	<p>Use this function to view the totaled overflow for the totalizer aggregated since measuring commenced.</p> <p>Total flow quantity is represented by a floating-point number consisting of max. 7 digits. You can use this function to view higher numerical values (&gt;9999999) as overflows. The effective quantity is thus the total of OVERFLOW plus the value returned by the SUM function.</p> <p>Example: Reading for 2 overflows: 2 10<sup>7</sup> kg (= 20000000 kg). The value returned by the SUM function = 196845.7 kg Effective total quantity = 20196845.7 kg</p> <p><b>Display:</b> Integer with exponent, including sign and unit, e.g. 2 10<sup>7</sup> kg</p>

## 6.2 Group HANDLING TOTAL.



<b>Functional description</b>	
TOTALIZERS→ HANDLING TOTALIZER→ Handling totalizer functions	
<b>RESET ALL TOTALIZERS (3800)</b>	<p>Use this function to reset the totals (including all overflows) of the totalizers (1 to 3) to zero (= RESET).</p> <p><b>Options:</b> NO YES</p> <p><b>Factory setting:</b> NO</p>
<b>FAILSAFE MODE (3801)</b>	<p>Use this function to define the common response of all totalizers (1 to 3) in case of error.</p> <p><b>Options:</b> STOP The totalizers are paused until the fault is rectified.</p> <p>ACTUAL VALUE The totalizers continue to count based on the current flow measured value. The fault is ignored.</p> <p>HOLD VALUE The totalizers continue to count the flow based on the last valid flow value (before the fault occurred).</p> <p><b>Factory setting:</b> STOP</p>

# 7 Block BASIC FUNCTION

Block	Groups	Function groups	Functions	
BASIC FUNCTION (G)	FOUNDATION FIELDBUS (GGA) P. 46	CONFIGURATION (620) P. 46	WRITE PROTECT (6200) P. 46	
			SIMULATION (6201) P. 46	
			DEVICE PD-TAG (6203) P. 46	
	PROCESS PARAMETER (CH1 to CH2) (GAG,GB) P. 49	FUNCTION BLOCKS (614) P. 47	BLOCK SELECTION (6220) P. 47	PID_OUT VALUE (6221) P. 47
				PID_IN VALUE (6222) P. 47
				CASCADE IN (6223) P. 47
	SYSTEM PARAMETER (CH1 to CH2) (GLA,GLB) P. 60	INFORMATION (614) P. 48	MANUFACTURER ID (6240) P. 48	DEVICE TYPE (6241) P. 48
				SERIAL NUMBER (6242) P. 48
				DD REVISION (6244) P. 48
	SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	CONFIGURATION (640) P. 49	ASSIGN LF CUT OFF (6400) P. 49	ON-VALUE LF CUT OFF (6402) P. 49
				OFF-VALUE LF CUT OFF (6403) P. 49
				PRESS. SHOCK SUPP. (6404) P. 50
	SENSOR PARAM. (888) P. 62	ADJUSTMENT (648) P. 51	ZEROPOINT ADJUST (6480) P. 51	
	SENSOR DATA (CH1 to CH2) (GLA,GLB) P. 60	PIPE DATA (652) P. 52	PIPE STANDARD (6520) P. 52	NOMINAL DIAMETER (6521) P. 53
				PIPE MATERIAL (6522) P. 53
				REFERENCE VALUE (6523) P. 53
	SENSOR DATA (CH1 to CH2) (GLA,GLB) P. 60	LIQUID DATA (654) P. 57	LIQUID (6540) P. 57	TEMPERATURE (6541) P. 57
				SOUND VEL. LIC. (6542) P. 58
				VISCOSITY (6543) P. 58
	SYSTEM PARAMETER (CH1 to CH2) (GLA,GLB) P. 60	CONFIGURATION (660) P. 60	INSTL. DIR. SENSOR (6600) P. 60	MEASURING MODE (6601) P. 60
				FLOW DAMPING (6603) P. 60
				POS. ZERO RETURN (6605) P. 61
	SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	CONFIGURATION (680) P. 63	CALIBRATION DATE (6808) P. 62	K-FACTOR (6800) P. 62
				ZERO POINT (6803) P. 63
				SENSOR TYPE (6881) P. 64
	SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	SENSOR PARAM. (888) P. 62	MEASUREMENT (6880) P. 63	CABLE LENGTH (6883) P. 65
				POSITION SENSOR (6884) P. 65
				WIRE LENGTH (6885) P. 66
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	CALIBRATION DATA (689) P. 67	P-FACTOR (6890) P. 67	DEV. SENSOR DISTANCE (6894) P. 67	
			CORRECTION FACTOR (6893) P. 67	
			DEV. ARC LENGTH (6895) P. 68	
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	ORIG. FACT. CALIBR. (691) P. 69	CALIBRATION DATE (6910) P. 69	DEV. PATH LENGTH (6886) P. 66	
			ARC LENGTH (6887) P. 66	
			PATH LENGTH (6888) P. 66	
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	ORIG. FACT. CALIBR. (691) P. 69	CALIBRATION DATE (6910) P. 69	SENSOR DISTANCE (6886) P. 66	
			WIRE LENGTH (6885) P. 66	
			DEV. PATH LENGTH (6896) P. 68	
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	ORIG. FACT. CALIBR. (691) P. 69	CALIBRATION DATE (6910) P. 69	PIPE DIAMETER (6526) P. 54	
			WALL THICKNESS (6527) P. 55	
			LINER MATERIAL (6528) P. 55	
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	ORIG. FACT. CALIBR. (691) P. 69	CALIBRATION DATE (6910) P. 69	CIRCUMFERENCE (6525) P. 54	
			SOUND VEL. PIPE (6524) P. 54	
			SOUND VEL. POS. (6546) P. 59	
SENSOR DATA (CH1 to CH2) (GNAG,NB) P. 62	ORIG. FACT. CALIBR. (691) P. 69	CALIBRATION DATE (6910) P. 69	LINEAR THICKNESS (6530) P. 56	
			SOUND VEL. LINER (6529) P. 56	
			LINEAR THICKNESS (6530) P. 56	


## 7.1 Group FOUNDATION FIELDBUS

### 7.1.1 Function group CONFIGURATION

BASIC FUNCTION	G	→	FOUNDATION FIELDBUS	GGA	→	CONFIGURATION	620
----------------	---	---	---------------------	-----	---	---------------	-----


Functional description	
BASIC FUNCTION → FOUNDATION FIELDBUS → CONFIGURATION	
<b>WRITE PROTECT</b> (6200)	Use this function to check whether the measuring device can be write accessed via the fieldbus.  <b>Display:</b> OFF Write access via FOUNDATION Fieldbus possible  ON Write protection via FOUNDATION Fieldbus blocked  <b>Factory setting:</b> OFF   Note! Hardware write protection is activated and deactivated by means of a jumper on the I/O module (see Operating Instructions Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D).
<b>SIMULATION</b> (6201)	Use this function to check whether a simulation in the Analog Input function block is possible.  <b>Display:</b> OFF Simulation in the Analog Input and Discrete Output function block is <b>not</b> possible.  ON Simulation in the Analog Input and Discrete Output function block is possible.  <b>Factory setting:</b> ON   Note! <ul style="list-style-type: none"> <li>■ Simulation mode is enabled and disabled by means of a jumper on the I/O module (see Operating Instructions Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D).</li> <li>■ The status of the simulation mode is also shown in the parameter BLOCK_ERR of the Resource Block.</li> </ul>
<b>DEVICE PD-TAG</b> (6203)	Use this function to enter a tag name for the measuring device.  <b>User input:</b> max. 32-character text, permissible: A-Z, 0-9, +,-, punctuation marks  <b>Factory setting:</b> E+H_PROSONIC_FLOW_93_XXXXXXXXXX  (XXXXXXXXXXXX = Serial number)

### 7.1.2 Function group FUNCTION BLOCKS



<b>Functional description</b>	
BASIC FUNCTION → FOUNDATION FIELDBUS → FUNCTION BLOCKS	
<b>BLOCK SELECTION (6220)</b>	<p>In this function, a function block can be selected, whose value and status is shown in the following functions.</p> <p><b>Options:</b> ANALOG INPUT 1 to 8 PID</p> <p><b>Factory setting:</b> ANALOG INPUT 1</p>
<b>OUT VALUE (6221)</b>	<p>Displays the output value OUT, incl. unit and status of the Analog Input or PID function block selected in the function BLOCK SELECTION (6220).</p>
<b>IN VALUE (6222)</b>	<p> Note! This function is not available unless the PID option was selected in the BLOCK SELECTION (6220) function.</p> <p><b>Display:</b> Displays the controlled variable IN, incl. unit and status of the Analog Input or PID function block selected in the function BLOCK SELECTION (6220).</p>
<b>CASCADE_IN VALUE (6223)</b>	<p> Note! This function is not available unless the PID option was selected in the BLOCK SELECTION (6220) function.</p> <p><b>Display:</b> Displays an analog set value, incl. units and status, taken over from an external function block.</p>
<b>SETPOINT VALUE (6224)</b>	<p> Note!</p> <ul style="list-style-type: none"> <li>■ This function is not available unless the PID option was selected in the BLOCK SELECTION (6220) function.</li> <li>■ If the service code is used to call this function, this value can be edited.</li> </ul> <p><b>Display:</b> Displays the internal set value, incl. units and status, for the PID function block.</p>


### 7.1.3 Function group INFORMATION




<b>Functional description</b> BASIC FUNCTION → FOUNDATION FIELDBUS → INFORMATION	
<b>MANUFACT ID</b> (6240)	<p>Use this function to view the manufacturer ID in decimal numerical format.</p> <p><b>Display:</b> 452B48 (hex) for Endress+Hauser</p>
<b>DEVICE TYPE</b> (6241)	<p>Use this function to view the device ID in hexadecimal numerical format.</p> <p><b>Display:</b> 1059 (hex) for Prosonic Flow 93 FOUNDATION Fieldbus</p>
<b>SERIAL NUMBER</b> (6242)	<p>Use this function to view the serial number.</p> <p><b>Display:</b> 11-digit number</p>
<b>DEVICE REVISION</b> (6243)	<p>Use this function to view the device revision number.</p> <p><b>Display:</b> 1</p> <p> <b>Note!</b> The information displayed here helps ensure that the correct system files (DD = Device Description) are used for integration into the host system. The system files can be downloaded from the Internet free of charge (<a href="http://www.endress.com">www.endress.com</a>).</p> <p>Example: Display in the function DEVICE REVISION (6243) → 03 Information displayed in the function DD REVISION (6244) → 01 Device description files required (DD) → 0301.sym / 0301.ffo</p>
<b>DD REVISION</b> (6244)	<p>Use this function to view the revision number of the Device Description.</p> <p><b>Display:</b> 1</p> <p> <b>Note!</b> The information displayed here helps ensure that the correct system files (DD = Device Description) are used for integration into the host system. The system files can be downloaded from the Internet free of charge (<a href="http://www.endress.com">www.endress.com</a>).</p> <p>Example: Display in the function DEVICE REVISION (6243) → 03 Information displayed in the function DD REVISION (6244) → 01 Device description files required (DD) → 0301.sym / 0301.ffo</p>


## 7.2 Group PROCESS PARAMETER (CH1 to CH2)

### 7.2.1 Function group CONFIGURATION




<b>Functional description</b> BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → CONFIGURATION	
<b>ASSIGN LOW FLOW CUTOFF (6400)</b>	<p>Use this function to assign the switching point for low flow cut off.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> VOLUME FLOW</p>
<b>ON-VALUE LOW FLOW CUT OFF (6402)</b>	<p>Use this function to assign a value to the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0. The sign of the flow value is highlighted on the display to indicate that low flow cut off is active.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 0 l/s</p> <p> <b>Note!</b> The appropriate unit is taken from the UNIT VOLUME FLOW (0402) function → Page 13.</p>
<b>OFF-VALUE LOW FLOW CUT OFF (6403)</b>	<p>Use this function to enter the switch-off (b) point for low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a).</p> <p><b>User input:</b> Integer 0 to 100%</p> <p><b>Factory setting:</b> 50%</p> <p>Example:</p> <div style="text-align: center;">  </div> <p>Q = Flow [volume/time] t = Time a = ON-VALUE LOW FLOW CUT OFF (6402) = 200 dm<sup>3</sup>/h b = OFF-VALUE LOW FLOW CUT OFF (6403) = 10% c = Low flow cut off active 1 = Low flow cut off is switched on at 200 dm<sup>3</sup>/h 2 = Low flow cut off is switched off at 220 dm<sup>3</sup>/h</p>

A0001245


<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → CONFIGURATION	
<p><b>PRESSURE SHOCK SUPPRESSION (6404)</b></p>	<p>The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".</p> <p> <b>Note!</b> Note that pressure shock suppression cannot be used unless the low flow cut off is active, (see function ON-VALUE LOW FLOW CUT OFF on Page 49).</p> <p>Use this function to define the time span for active pressure shock suppression.</p> <p><b>Activation of the pressure shock suppression</b> Pressure shock suppression is activated after the flow falls below the switch-on point of the low flow cut off (see point <b>a</b> in graphic).</p> <p>While pressure shock suppression is active, the following conditions apply:</p> <ul style="list-style-type: none"> <li>■ Flow reading on display = → 0.</li> <li>■ Totalizer reading → the totalizers are pegged at the last correct value.</li> </ul> <p><b>Deactivation of the pressure shock suppression</b> The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point <b>b</b> in graphic).</p> <p> <b>Note!</b> The actual flow value is displayed and output when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point <b>c</b> in graphic).</p> <div style="text-align: center;">  </div> <p style="text-align: right;">A0001285-EN</p> <p>① = off-value (low flow cut off), ② = on-value (low flow cut off)  <b>a</b> Activated when the on-value for low flow cut off is undershot  <b>b</b> Deactivated once the time specified passes  <b>c</b> Flow values are taken into account again for calculating the pulses  <span style="display: inline-block; width: 10px; height: 10px; background-color: #cccccc; border: 1px solid black;"></span> Suppressed values  <b>Q</b> Flow</p> <p><b>User input:</b> max. 4-digit number, incl. unit: 0.00 to 100.0 s</p> <p><b>Factory setting:</b> 0.00 s</p>

### 7.2.2 Function group ADJUSTMENT



<b>Functional description</b> BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → ADJUSTMENT	
<b>ZERO POINT (6480)</b>	<p>This function enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the ZERO POINT function (→ Page 67).</p> <p><b>User input:</b>                      CANCEL                      START</p> <p><b>Factory setting:</b>                      CANCEL</p> <p> <b>Caution!</b>                      Before carrying out an adjustment, please refer to the Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA0078D, where a detailed description of zero point adjustment is given.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Programming is locked during zero point adjustment. The message "ZERO ADJUST RUNNING" appears on the display.</li> <li>■ If the zero point adjustment is not possible, e.g. with a flow velocity &gt; 0.1 m/s, or has been canceled, then the alarm message "ZERO ADJUST NOT POSSIBLE" is shown on the display. This error is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.</li> </ul>

### 7.2.3 Function group PIPE DATA



<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → PIPE DATA	
<b>PIPE STANDARD (6520)</b>	<p>Use this function to select a pipe standard.</p> <p><b>Options:</b>            OTHERS            DIN:            PN10, PN16, 28610, 28614, 28615, 28619            ANSI:            SS SCH 40S            SS SCH 80S            SS SCH 5S            SS SCH 10S              CS SCH 20            CS SCH 40            CS SCH 80            CS SCH 120              AWWA:            CLASS 50, CLASS 53, CLASS 55</p> <p> <b>Note!</b>            The selection specifies the values for the following functions:            ■ PIPE MATERIAL (6522)            ■ SOUND VELOCITY PIPE (6524)            ■ LINER MATERIAL (6528)            If you edit these functions the pipe standard will be reset to the option OTHERS.</p> <p><b>Factory setting:</b>            DIN PN10</p>


<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → PIPE DATA	
<b>NOMINAL DIAMETER (6521)</b>	<p> <b>Note!</b> This function does <b>not</b> appear if the option OTHERS was selected in the PIPE STANDARD function (6520).</p> <p>Use this function to select the nominal diameter of the pipe.</p> <p><b>Options:</b> OTHERS DN: 15/½", 25/1", 40/1½", 50/2", 80/3", 100/4", 150/6", 200/8", 250/10", 300/12", 400/16", 450/18", 500/20", 600/24", 700/28", 750/30", 800/32", 900/36", 1000/40", 1200/48", 1400/54", 1500/60", 1600/64", 1800/72", 2000/80"</p> <p> <b>Note!</b> The selection specifies the values for the following functions:</p> <ul style="list-style-type: none"> <li>■ CIRCUMFERENCE (6525)</li> <li>■ PIPE DIAMETER (6526)</li> <li>■ WALL THICKNESS (6527)</li> </ul> <p>If you edit these functions the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p><b>Factory setting:</b> 80/3"</p>
<b>PIPE MATERIAL (6522)</b>	<p>This function displays the pipe material determined via the option selected in the PIPE STANDARD function (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The pipe material must be selected if the OTHERS option was selected in the PIPE STANDARD function (6520), and thus no pipe standard is defined.</p> <p><b>Options:</b> CARBON STEEL, DUCTILE IRON, STAINLESS STEEL, SS ANSI 304, SS ANSI 316, SS ANSI 347, SS ANSI 410, SS ANSI 430, HASTELLOY C, PVC, PE, LDPE, HDPE, GRP, PVDF, PA, PP, PTFE, GLASS PYREX, COPPER, ASBESTOS CEMENT, OTHERS</p> <p><b>Factory setting:</b> STAINLESS STEEL</p>
<b>REFERENCE VALUE (6523)</b>	<p>Use this function to enter the thickness of the reference component (e.g. flange) as the basis for measuring the sound velocity of the pipe.</p> <p> <b>Note!</b> This function does not appear unless the option SOUND VELOCITY PIPE was selected in the MEASUREMENT function (6880, → Page 63).</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> 5 mm</p>

<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → PIPE DATA	
<b>SOUND VELOCITY PIPE (6524)</b>	<p>This function displays the sound velocity in the pipe determined via the option selected in the PIPE STANDARD function (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The sound velocity in the pipe must be entered if the OTHERS option was selected in the PIPE STANDARD function (6520), and thus no pipe standard is defined.</p> <p><b>Measuring the sound velocity in the pipe</b> If the sound velocity in the pipe is unknown, it can be measured. For this purpose, the option SOUND VELOCITY PIPE must be selected in the MEASUREMENT function (6880, → Page 63). The sound velocity in the pipe is measured by calling up the SOUND VELOCITY PIPE function (6524). The measured sound velocity, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function by pressing the  key, the SAVE prompt appears. To accept the measured sound velocity, select the option YES by means of the  or  key.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ To measure the sound velocity, you require the ultrasonic sensors "DDU18" which you can order as an accessory from Endress+Hauser.</li> <li>■ A reference value is used as a basis for measuring the sound velocity. This reference value can be edited (→ Page 53).</li> </ul> <p><b>User input:</b> Fixed-point number 800 to 6500 m/s</p> <p><b>Factory setting:</b> 3120 m/s</p>
<b>CIRCUMFERENCE (6525)</b>	<p>This function displays the outer circumference of the pipe determined via the option selected in the NOMINAL DIAMETER function (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The pipe outer circumference must be entered here if the OTHERS option was selected in the NOMINAL DIAMETER function (6521), and thus no pipe standard is defined.</p> <p><b>User input:</b> Fixed-point number 31.4 to 15708.0 mm</p> <p><b>Factory setting:</b> 279.3 mm</p>
<b>PIPE DIAMETER (6526)</b>	<p>This function displays the outer diameter of the pipe determined via the option selected in the NOMINAL DIAMETER function (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The pipe outer diameter must be entered here if the OTHERS option was selected in the NOMINAL DIAMETER function (6521), and thus no pipe standard is defined.</p> <p><b>User input:</b> Fixed-point number 10.0 to 5000.0 mm</p> <p><b>Factory setting:</b> 88.9 mm</p>


<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → PIPE DATA	
<b>WALL THICKNESS (6527)</b>	<p>This function displays the thickness of the pipe walls determined via the option selected in the NOMINAL DIAMETER function (6521). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The wall thickness must be entered here if the OTHERS option was selected in the NOMINAL DIAMETER function (6521), and thus no pipe standard is defined.</p> <p><b>Measuring the wall thickness</b>                      If the wall thickness is unknown, it can be measured. For this purpose, the option WALL THICKNESS must be selected in the MEASUREMENT function, (6880, → Page 63). The wall thickness is measured by calling up the WALL THICKNESS function (6527). The measured wall thickness, the signal strength and a bar graph appear on the local display. The measurement is valid if 100% is achieved in the bar graph. If you confirm the function by pressing the <input type="checkbox"/> key, the SAVE prompt appears. To accept the measured wall thickness, select the option YES by means of the <input type="checkbox"/> or <input type="checkbox"/> key.</p> <p> <b>Note!</b>                      To measure the wall thickness, you require the ultrasonic sensors "DDU19" which you can order as an accessory from Endress+Hauser.</p> <p><b>User input:</b>                      Fixed-point number 0.1 to 100.0 mm</p> <p><b>Factory setting:</b>                      3.2 mm</p>
<b>LINER MATERIAL (6528)</b>	<p>This function displays the liner material of the pipe determined via the option selected in the PIPE STANDARD function (6520). If you edit the predetermined value the pipe standard will be reset to the option OTHERS and the NOMINAL DIAMETER function (6521) does not appear.</p> <p>The liner material must be specified if the OTHERS option was selected in the PIPE STANDARD function (6520), and thus no pipe standard is defined.</p> <p><b>Options:</b>                      LINER NONE                      MORTAR                      RUBBER                      TAR EPOXY                      OTHERS</p> <p><b>Factory setting:</b>                      LINER NONE</p>

<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → PIPE DATA	
<b>SOUND VELOCITY LINER (6529)</b>	<p> Note! This function does <b>not</b> appear if the option LINER NONE was selected in the LINER MATERIAL function (6528).</p> <p>This function displays the sound velocity of the liner This is defined by the selection in the function LINER MATERIAL (6528). If you change the default value, the liner material is reset to the value OTHER. The sound velocity of the liner must be entered if the OTHERS option was selected in the LINER MATERIAL function (6528).</p> <p><b>User input:</b> Fixed-point number 800 to 6500 m/s</p> <p><b>Factory setting:</b> Depending on the selection in the LINER MATERIAL function (6528)</p>
<b>LINER THICKNESS (6530)</b>	<p> Note! This function does <b>not</b> appear if the option LINER NONE was selected in the LINER MATERIAL function (6528).</p> <p>Use this function to enter the thickness of the liner.</p> <p><b>User input:</b> Fixed-point number 0.1 to 100.0 mm</p> <p><b>Factory setting:</b> 0 mm</p>

### 7.2.4 Function group LIQUID DATA




<b>Functional description</b> BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → LIQUID DATA	
<b>LIQUID (6540)</b>	<p>Use this function to select the liquid in the pipe.</p> <p><b>Options:</b> WATER, SEA WATER, DISTILLED WATER, AMMONIA, ALCOHOL, BENZENE, BROMIDE, ETHANOL, GLYCOL, KEROSENE, MILK, METHANOL, TOLUENE, LUBE OIL, DIESEL, PETROL, OTHERS</p> <p> <b>Note!</b> The selection specifies the values for the sound velocity and viscosity. If OTHERS is selected, these values must be entered via the SOUND VELOCITY LIQUID (6542) and VISCOSITY (6543) functions.</p> <p><b>Factory setting:</b> WATER</p>
<b>TEMPERATURE (6541)</b>	<p>Use this function to enter the process temperature of the liquid. Via the sound velocity, the value influences the determination of the sensor distance. Enter the process temperature at normal operating conditions to achieve an optimum configuration of the measuring system.</p> <p><b>User input:</b> Fixed-point number -273.15 to 726.85 °C (0 to 1000 K)</p> <p><b>Factory setting:</b> 20 °C</p>

<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → LIQUID DATA	
<p><b>SOUND VELOCITY LIQUID (6542)</b></p>	<p>This function displays the sound velocity of the liquid. This is determined via the values entered in the LIQUID (6540) and TEMPERATURE (6541) functions. If you edit the predetermined value the LIQUID function (6540) will be reset to the option OTHERS. The sound velocity of the liquid must be entered if the liquid is not listed in the LIQUID function (6540) and the OTHERS option was selected.</p> <p><b>Measuring the sound velocity of the liquid</b>                      If the sound velocity of the liquid is unknown, it can be measured. For this purpose, the option SOUND VELOCITY LIQUID must be selected in the MEASUREMENT function (6880, → Page 63). The sound velocity in the liquid is measured by calling up the SOUND VELOCITY LIQUID function (6542). The result of the measurement appears on the local display. If you confirm the function by pressing the <input type="checkbox"/> key, the SAVE prompt appears. To accept the measured sound velocity, select the option YES by means of the <input type="checkbox"/> or <input type="checkbox"/> key.</p> <p> <b>Note!</b>                      To measure the sound velocity, you require the ultrasonic sensors "DDU18" which you can order as an accessory from Endress+Hauser.</p> <p><b>Transmitter search range:</b>                      The measuring device searches for the measuring signal within a defined sound velocity range. You specify the search range in the SOUND VELOCITY NEGATIVE (6545) or SOUND VELOCITY POSITIVE (6546) functions. An error message is displayed if the sound velocity of the liquid exceeds the search range.</p> <p> <b>Note!</b>                      We recommend you select a smaller search range for unfavorable signal conditions (signal strength &lt; 50%).</p> <div style="text-align: center;">  <p>1 = Sound velocity of the liquid                      2 = Lower search range: is specified in the SOUND VEL. NEGATIVE function (6545)                      3 = Upper search range: is specified in the SOUND VEL. POSITIVE function (6546)</p> </div> <p style="text-align: right;"><small>A0001246</small></p> <p><b>User input:</b>                      Fixed-point number 400 to 3000 m/s</p> <p><b>Factory setting:</b>                      1485 m/s</p>
<p><b>VISCOSITY (6543)</b></p>	<p>This function displays the viscosity of the liquid. This is determined via the values entered in the LIQUID (6540) and TEMPERATURE (6541) functions. If you edit the predetermined value the LIQUID function (6540) will be reset to the option OTHERS. The viscosity must be entered if the liquid is not listed in the LIQUID function (6540) and the OTHERS option was selected.</p> <p><b>User input:</b>                      Fixed-point number 0.0 to 5000.0 mm<sup>2</sup>/s (cSt)</p> <p><b>Factory setting:</b>                      1 mm<sup>2</sup>/s</p>

<b>Functional description</b>	
BASIC FUNCTION → PROCESS PARAMETER (CH1 to CH2) → LIQUID DATA	
<b>SOUND VELOCITY NEGATIVE (6545)</b>	<p>Use this function to specify the lower search range for the sound velocity of the liquid.</p> <p><b>User input:</b> Fixed-point number 400 to 3000 m/s</p> <p><b>Factory setting:</b> 500 m/s</p> <p> <b>Note!</b> See the explanations in the SOUND VELOCITY LIQUID function (6542).</p>
<b>SOUND VELOCITY POSITIVE (6546)</b>	<p>Use this function to specify the upper search range for the sound velocity of the liquid.</p> <p><b>User input:</b> Fixed-point number 400 to 3000 m/s</p> <p><b>Factory setting:</b> 300 m/s</p> <p> <b>Note!</b> See the explanations in the SOUND VELOCITY LIQUID function (6542).</p>

## 7.3 Group SYSTEM PARAMETER (CH1 to CH2)

### 7.3.1 Function group CONFIGURATION




<b>Functional description</b>	
BASIC FUNCTION → SYSTEM PARAMETER CH1 → CONFIGURATION	
<b>INSTALLATION DIRECTION SENSOR (6600)</b>	<p>Use this function to reverse the sign of the flow quantity, if necessary.</p> <p><b>Options:</b> NORMAL INVERSE (REVERSE)</p> <p><b>Factory setting:</b> NORMAL</p>
<b>MEASURING MODE (6601)</b>	<p>Use this function to specify the flow direction for outputting the signal:</p> <p>Unidirectional: Signal is only output if the flow direction is positive (forward flow). Flow in the negative flow direction (reverse flow) is not taken into account or totaled by the measuring system.</p> <p>Bidirectional: Signal is output with flow in both directions (forward and reverse flow).</p> <p><b>Options:</b> UNIDIRECTIONAL BIDIRECTIONAL</p> <p><b>Factory setting:</b> UNIDIRECTIONAL</p>
<b>FLOW DAMPING (6603)</b>	<p> Note! The system damping acts on all functions and FOUNDATION Fieldbus outputs of the measuring device.</p> <p>Use this function to set the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time increases with the filter setting.</p> <p><b>User input:</b> 0 to 100 s</p> <p><b>Factory setting:</b> 0 s</p>

<b>Functional description</b>	
BASIC FUNCTION → SYSTEM PARAMETER CH1 → CONFIGURATION	
<b>POSITIVE ZERO RETURN (6605)</b>	<p>Use this function to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all function and outputs of the measuring device.</p> <p>The selection has an effect on the volume flow and the totalizer and the corresponding device functions and outputs of the FOUNDATION Fieldbus interface.</p> <p><b>Options:</b> OFF ON (signal output is set to the "zero flow" value)</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b> An active positive zero return is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.</p>


## 7.4 Group SENSOR DATA (CH1 to CH2)

### 7.4.1 Function group CONFIGURATION



<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → CONFIGURATION	
<p> Note! The function group is only available for measuring devices in "Clamp on" version..</p>	
<p><b>CALIBRATION DATE (6808)</b></p>	<p>Use this function to view the calibration date (last calibration).</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ If the measuring device is delivered without calibration, the display shows the value 1.0.</li> <li>■ If the calibration is reset via the function CALIBRATION DATE (6910), the date is overwritten.</li> </ul> <p><b>Display:</b> Format depends on the selection in function FORMAT DATE/TIME (0429)</p>
<p><b>K-FACTOR (6800)</b></p>	<p>Use this function to view the current calibration factor for the measuring tube and the measuring sensors.</p> <p><b>Display:</b> 5-digit floating-point number, (including sign)</p> <p><b>Factory setting:</b> depends on the nominal diameter and the calibration</p>
<p><b>ZERO POINT (6803)</b></p>	<p>Use this function to view the zero-point correction value for the measuring tube and the measuring sensors The calibration at the factory determines the zero-point correction value.</p> <p> Note! If the measuring device is delivered without calibration, the display shows the value 0</p> <p><b>Display:</b> 5-digit floating-point number, (including sign)</p> <p><b>Factory setting:</b> depends on the nominal diameter and the calibration</p>

### 7.4.2 Function group SENSOR PARAMETER




<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → SENSOR PARAMETER	
<b>MEASUREMENT (6880)</b>	<p><b>Options:</b>            OFF            CLAMP ON            INSERTION            SOUND VELOCITY LIQUID            SOUND VELOCITY PIPE            WALL THICKNESS</p> <p><b>Factory setting:</b>            CLAMP ON (for channel 1)            OFF (for channel 2)</p>

<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → SENSOR PARAMETER	
<b>SENSOR TYPE (6881)</b>	<p> <b>Note!</b> This function is only available if the OFF setting was <b>not</b> selected in the MEASUREMENT function.</p> <p>Select the appropriate type of measuring sensor. As a rule, a selection is not necessary as the type of measuring sensor has already been set according to the order data (order code).</p> <p><b>Options:</b> (CLAMP ON in the MEASUREMENT function) W-CL-05F-L-B W-CL-1F-L-B W-CL-1F-L-C W-CL-2F-L-B P-CL-05F-L-B P-CL-05F-M-B P-CL-1F-L-B P-CL-1F-M-B P-CL-2F-L-B P-CL-2F-M-B P-CL-6F-L-C P-CL-6F-M-C U-CL-2F-L-A</p> <p><b>Options:</b> (INSERTION in the MEASUREMENT function) W-IN-1F-L-B</p> <p><b>Options:</b> (SOUND VELOCITY LIQUID in the MEASUREMENT function) P-CL-1S-L-B P-CL-1S-M-B</p> <p><b>Options:</b> (SOUND VELOCITY PIPE or WALL THICKNESS in the MEASUREMENT function) P-CL-4W-L-B</p> <p><b>Factory setting:</b> depends on the order code</p>

<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → SENSOR PARAMETER	
<p><b>SENSOR CONFIGURATION (6882)</b></p>	<p>Use this function to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the clamp-on design) or whether single-path or dual-path configuration is present (in the insertion design).</p> <p> <b>Note!</b> This function is not available unless one of the following options was selected in the MEASUREMENT function (6880):</p> <ul style="list-style-type: none"> <li>■ CLAMP ON</li> <li>■ SOUND VELOCITY LIQUID</li> <li>■ INSERTION</li> </ul> <p><b>Options:</b> NO. TRAVERSE: 1 <sup>1)</sup> NO. TRAVERSE: 2 <sup>2)</sup> NO. TRAVERSE: 3 <sup>1)</sup> NO. TRAVERSE: 4 <sup>2)</sup> SINGLE PATH <sup>3)</sup> DUAL PATH <sup>3)</sup></p> <p><b>Factory setting:</b> NO. TRAVERSE: 2</p> <p> <b>Note!</b> ■ In principle, setting "NO. TRAVERSE: 2" is for the P-sensor DN15 ... DN 65 necessary. ■ For sound velocity measurement it is always required to set this function to "NO. TRAVERSE: 1" or "NO. TRAVERSE: 3". ■ For flow measurement it is basically not recommended to set this function to "NO. TRAVERSE: 3".</p> <p><sup>1)</sup> This option is not available unless CLAMP ON or SOUND VELOCITY LIQUID was selected in the MEASUREMENT function. <sup>2)</sup> This option is not available unless CLAMP ON was selected in the MEASUREMENT function. <sup>3)</sup> This option is not available unless INSERTION was selected in the MEASUREMENT function.</p>
<p><b>CABLE LENGTH (6883)</b></p>	<p>Use this function to select the length of the sensor cable.</p> <p><b>Options:</b> LENGTH 5m/15 feet LENGTH 10m/30 feet LENGTH 15m/45 feet LENGTH 30m/90 feet</p> <p><b>Factory setting:</b> Depends on the order code</p>
<p><b>POSITION SENSOR (6884)</b></p>	<p>Use this function to view the position of both sensors on the rail.</p> <p> <b>Note!</b> This option is not available unless CLAMP ON is set in the MEASUREMENT function and the number of traverses is 2 or 4 (see the SENSOR CONFIGURATION function (6882)).</p> <p><b>Display:</b> 5-digit number combination</p>

<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → SENSOR PARAMETER	
<b>WIRE LENGTH (6885)</b>	<p>The wire length for assembling the sensors at the correct distance apart appears on the display.</p> <p> <b>Note!</b> This option is not available unless CLAMP ON is set in the MEASUREMENT function and the number of traverses is 1 or 3 (see the SENSOR CONFIGURATION function (6882)).</p> <p><b>Display:</b> max. 5-digit number, including unit (e.g. 200 mm)</p>
<b>SENSOR DISTANCE (6886)</b>	<p>The distance between sensor 1 and sensor 2 as a length measurement appears on the display.</p> <p><b>Display:</b> max. 5-digit number, including unit (e.g. 200 mm)</p>
<b>ARC LENGTH (6887)</b>	<p>The arc length on the pipe appears on the display.</p> <p> <b>Note!</b> This function is not available unless INSERTION was set in the MEASUREMENT function (6880) and the DUAL PATH option was selected in the SENSOR CONFIGURATION function (6882).</p> <p><b>Display:</b> max. 5-digit number, including unit (e.g. 200 mm)</p>
<b>PATH LENGTH (6888)</b>	<p>The path length appears on the display.</p> <p> <b>Note!</b> This function is not available unless INSERTION was selected in the MEASUREMENT function.</p> <p><b>Display:</b> max. 5-digit number, including unit (e.g. 200 mm)</p>


### 7.4.3 Function group CALIBRATION DATA



<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → CALIBRATION DATA	
<b>P-FACTOR</b> (6890)	<p>Use this function to display the P-factor.</p> <p>The P-factor describes the effect of the speed distribution of the flow profile in the pipe and depends on the Reynolds number. The P-factor varies in the range from 0.75 to 0.95. If the displayed value is in the range between 0.75 and 0.94, the measurement must be expected to have less linearity.</p>
<b>ZERO POINT</b> (6891)	<p>Use this function to call up or manually change the zero point correction currently being used.</p> <p><b>User input:</b> 5-digit floating-point number, including unit and sign (e.g. +10.0 ns)</p>
<b>CORRECTION FACTOR</b> (6893)	<p>Use this function to enter a correction factor at the client's site.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 1.0000 (no correction)</p>
<b>DEV. SENSOR DISTANCE</b> (6894)	<p>Use this function to enter a deviation value for the sensor distance.</p> <p> <b>Note!</b> This option is not available unless INSERTION was selected in the MEASUREMENT function (6880).</p> <p><b>User input:</b> 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm)</p> <p><b>Factory setting:</b> 0 mm</p>


<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → CALIBRATION DATA	
<b>DEV. ARC LENGTH (6895)</b>	<p>Use this function to enter a deviation value for the arc length.</p> <p> <b>Note!</b> This function is not available unless INSERTION was set in the MEASUREMENT function (6880) and the DUAL PATH option was selected in the SENSOR CONFIGURATION function (6882).</p> <p><b>User input:</b> 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm)</p> <p><b>Factory setting:</b> 0 mm</p>
<b>DEV. PATH LENGTH (6896)</b>	<p>Use this function to enter a deviation value for the path length.</p> <p> <b>Note!</b> This option is not available unless INSERTION was selected in the MEASUREMENT function (6880).</p> <p><b>User input:</b> 5-digit floating-point number, including unit and sign (e.g. +2.0000 mm)</p> <p><b>Factory setting:</b> 0 mm</p>

### 7.4.4 Function group ORIG. FACT. CALIBR.



<b>Functional description</b>	
BASIC FUNCTION → SENSOR DATA (CH1 to CH2) → ORIG. FACT. CALIBR.	
<b>CALIBRATION DATE (6910)</b>	<p>This function resets the calibration data of the measuring device to the factory settings.</p> <p>Procedure:</p> <ol style="list-style-type: none"> <li>1. Enter current date.</li> <li>2. Store it.</li> </ol> <p>The measuring device resets the calibration data to the factory settings and restarts automatically.</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The calibration data reset is recorded in the calibration history.</li> <li>■ The date of the function CALIBRATION DATE (6808) is overwritten.</li> </ul> <p><b>User input:</b> Format depends on the selection in function FORMAT DATE/TIME (0429)</p>

# 8 Block SUPERVISION




## 8.1 Group SYSTEM (SYSTEM CH2)

### 8.1.1 Function group CONFIGURATION



<b>Functional description</b> SUPERVISION → SYSTEM → CONFIGURATION	
<b>ALARM DELAY (8005)</b>	<p>Use this function to specify a time period for suppressing the appearance of fault or notice messages .</p> <p>This suppression acts on:</p> <ul style="list-style-type: none"> <li>■ Display</li> <li>■ Output values (AI blocks) FF interface</li> </ul> <p><b>User input:</b> 0 to 100 s (in steps of one second)</p> <p><b>Factory setting:</b> 0 s</p> <p> <b>Caution!</b> If this function is activated, error and notice messages are delayed by the time corresponding to the setting before being forwarded to the higher-order controller (process controller, etc.). It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.</p>
<b>PERMANENT STORAGE (8007)</b>	<p>This function displays whether permanent storage of all parameters in the EEPROM is switched on or off.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> ON</p>

### 8.1.2 Function group OPERATION




<b>Functional description</b> SUPERVISION → SYSTEM [CH2] → OPERATION	
<b>ACTUAL SYSTEM CONDITION (8040)</b>	<p>Use this function to check the present system condition.</p> <p><b>Display:</b> SYSTEM OK or the fault/notice message with the highest priority.</p>
<b>PREVIOUS SYSTEM CONDITIONS (8041)</b>	<p>Use this function to view the fifteen most recent error and notice messages since measuring last started.</p> <p><b>Display:</b> The last 15 fault/notice messages appear on the display.</p>
<b>SIMULATION FAILSAFE MODE (8042)</b>	<p> <b>Note!</b> This function is available in groups SYSTEM+SYSTEM CH2.</p> <p>Use this function to set all totalizers to their defined failsafe modes, in order to check whether they respond correctly. During this time, the words "SIMULATION FAILSAFE MODE" appear on the display.</p> <p><b>Options:</b> ON OFF FAILURE (CH1 to CH2)</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b> With the fieldbus, an active simulation is relayed to downstream function blocks or higher-level process control systems by means of the status UNCERTAIN of the output value OUT (AI Block).</p>

<b>Functional description</b> SUPERVISION → SYSTEM [CH2] → OPERATION	
<b>SIMULATION MEASURAND (8043)</b>	<p> <b>Note!</b> This function is available in groups SYSTEM+SYSTEM CH2.</p> <p>Use this function to set all totalizers to their defined flow-response modes, in order to check whether they respond correctly. During this time, the words "SIMULATION MEASURAND" appear on the display.</p> <p><b>Options:</b> OFF VOLUME FLOW (CH1 to CH2) SOUND VELOCITY (CH1 to CH2) SIGNAL STRENGTH (CH1 to CH2)</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Caution!</b></p> <ul style="list-style-type: none"> <li>■ The measuring device cannot be used for measuring while this simulation is in progress.</li> <li>■ The setting is not saved in the event of a power failure.</li> </ul> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ An active simulation of the measurand is communicated to the subsequent function blocks via the status "UNCERTAIN" for the process variables.</li> <li>■ The simulation is independent of the position of the jumper for the simulation mode on the I/O board.</li> </ul>
<b>VALUE SIMULATION MEASURAND (8044)</b>	<p> <b>Note!</b> This function is available in groups SYSTEM+SYSTEM CH2.</p> <p> <b>Note!</b> The function is not visible unless the function SIMULATION MEASURAND (8043) is active.</p> <p>Use this function to specify a selectable value (e.g. 12 m<sup>3</sup>/s). This is used to test the associated functions in the device itself and downstream FOUNDATION Fieldbus function blocks.</p> <p><b>User input:</b> 5-digit floating-point number, [unit]</p> <p><b>Factory setting:</b> 0 [unit]</p> <p> <b>Caution!</b></p> <ul style="list-style-type: none"> <li>■ The setting is not saved in the event of a power failure.</li> <li>■ The appropriate unit is taken from the SYSTEM UNITS (ACA) function group, → Page 13.</li> </ul>
<b>SYSTEM RESET (8046)</b>	<p>Use this function to perform a reset of the measuring system.</p> <p><b>Options:</b> NO RESTART SYSTEM (restart without interrupting power supply)</p> <p><b>Factory setting:</b> NO</p>

<b>Functional description</b>	
SUPERVISION → SYSTEM [CH2] → OPERATION	
<b>TROUBLESHOOTING (8047)</b>	<p>This function allows you to remedy errors that occur in the EEPROM. The EEPROM is divided into various blocks. Only blocks in which an error has occurred are displayed. Troubleshooting takes place by selecting the respective block and acknowledging using the  key.</p> <p> <b>Caution!</b> When troubleshooting a block, the parameters of the selected block are reset to the values according to the factory setting.</p> <p><b>Options:</b> CANCEL "Faulty block"</p>
<b>OPERATION HOURS (8048)</b>	<p>The hours of operation of the device appear on the display.</p> <p><b>Display:</b> Depends on the number of hours of operation elapsed: Hours of operation &lt; 10 hours → display format = 00:00:00 (hr:min:sec) Hours of operation 10 to 10,000 hours → display format = 0000:00 (hr:min) Hours of operation &gt; 10,000 hours → display format = 000000 (hr)</p>


## 8.2 Group VERSION INFO

### 8.2.1 Function group DEVICE




Functional description	
SUPERVISION → VERSION INFO → DEVICE	
DEVICE SOFTWARE (8100)	Displays the current device software version.

### 8.2.2 Function group SENSOR



Functional description	
SUPERVISION → VERSION INFO → SENSOR	
SERIAL NUMBER (8200)	Use this function to view the serial number of the sensor.


### 8.2.3 Function group AMPLIFIER



Functional description	
SUPERVISION → VERSION INFO → AMPLIFIER	
SOFTWARE REVISION NUMBER AMPLIFIER (8222)	Use this function to view the software revision number of the amplifier.
SOFTWARE REVISION NUMBER T-DAT (8225)	Use this function to view the software revision number of the software used to create the content of the T-DAT.


<b>Functional description</b> SUPERVISION → VERSION INFO → AMPLIFIER	
<b>LANGUAGE GROUP (8226)</b>	<p>Use this function to view the language group.</p> <p>The following language groups can be ordered: WEST EU / USA, EAST EU / SCAND., ASIA, CHINESE.</p> <p><b>Display:</b> available language group</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ The language options of the available language group are displayed in the LANGUAGE function (2000).</li> <li>■ You can change the language group via the configuration software FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</li> </ul>

### 8.2.4 Function group F-CHIP



<b>Functional description</b> SUPERVISION → VERSION INFO → F-CHIP	
<b>STATUS F-CHIP (8240)</b>	Use this function to check whether an F-CHIP is installed.

### 8.2.5 Function group I/O MODULE



<b>Functional description</b> SUPERVISION → VERSION INFO → I/O-MODUL	
<b>I/O MODULE TYPE (8300)</b>	Use this function to view the configuration of the I/O module complete with terminal numbers.
<b>SOFTWARE REVISION NUMBER I/O MODULE (8303)</b>	Use this function to view the software revision number of the I/O module.

## 9 Factory settings

### 9.1 SI units

Parameter	Factory setting
Nominal diameter	80 [mm]
Low flow cut off ( $v \approx 0.04$ m/s)	12 [dm <sup>3</sup> /min]
Unit totalizer	dm <sup>3</sup>
Unit length	mm
Unit temperature	°C

### 9.2 US units (for USA and Canada only)

Parameter	Factory setting
Nominal diameter	3"
Low flow cut off ( $v \approx 0.04$ m/s)	2.5 [gal/min]
Unit totalizer	gal
Unit length	inch
Unit temperature	F

### 9.3 Language

Country	Language
Australia	English
Belgium	English
Canada	English
China	Chinese
Denmark	English
Germany	Deutsch
England	English
Finland	Suomi
France	Francais
Netherlands	Nederlands
Hong Kong	English
India	English
Indonesia	Bahasa Indonesia
Instruments International	English
Italy	Italiano
Japan	Japanese
Malaysia	English
Norway	Norsk
Poland	Polish
Portugal	Portuguese
Austria	Deutsch
Russia	Russian
Sweden	Svenska
Switzerland	Deutsch
Singapore	English
Spain	Espanol
South Africa	English
Thailand	English
Czech Republic	Czech
Hungary	English
USA	English

## 10 Index Function matrix

<b>Blocks</b>	
A = MEASURED VARIABLES .....	9
B = QUICK SETUP .....	17
C = USER INTERFACE .....	22
D = TOTALIZER .....	39
G = BASIC FUNCTION .....	45
J = SUPERVISION .....	70
<b>Groups</b>	
AAA = MEASURING VALUES .....	10
ACA = SYSTEM UNITS .....	13
CAA = CONTROL .....	23
CCA = MAIN LINE .....	27
CEA = ADDITIONAL LINE .....	31
CGA = INFORMATION LINE .....	35
DAA = TOTALIZER 1 .....	40
DAB = TOTALIZER 2 .....	40
DAC = TOTALIZER 3 .....	40
DJA = HANDLING TOTALIZER .....	44
GGA = FOUNDATION FIELDBUS .....	46
GIA, GIB = PROCESS PARAMETER (CH1 to CH2) .....	49
GLA, GLB = SYSTEM PARAMETER (CH1 to CH2) .....	60
GNA, GNB = SENSOR DATA (CH1 to CH2) .....	62
JAA = SYSTEM .....	71
JAB = SYSTEM CH2 .....	72
JCA = VERSION INFO .....	75
<b>Function Groups</b>	
000 = MAIN VALUES CH1 .....	10
006 = MAIN VALUES CH2 .....	11
008 = CALCULATED MAIN VALUES .....	12
040 = CONFIGURATION .....	13
042 = ADDITIONAL CONFIGURATION .....	15
200 = BASIC CONFIGURATION .....	23
202 = UNLOCKING/LOCKING .....	25
204 = OPERATION .....	26
220 = CONFIGURATION .....	27
222 = MULTIPLEX .....	29
240 = CONFIGURATION .....	31
242 = MULTIPLEX .....	33
260 = CONFIGURATION .....	35
262 = MULTIPLEX .....	37
300 = CONFIGURATION .....	40
304 = OPERATION .....	43
620 = CONFIGURATION .....	46
622 = FUNCTION BLOCKS .....	47
624 = INFORMATION .....	48
640 = CONFIGURATION .....	49
648 = ADJUSTMENT .....	51
652 = PIPE DATA .....	52
654 = LIQUID DATA .....	57
660 = CONFIGURATION .....	60
680 = CONFIGURATION .....	62
688 = SENSOR PARAMETER .....	63
689 = CALIBRATION DATA .....	67
691 = ORIG. FACT. CALIBRATION .....	69
800 = CONFIGURATION .....	71
804 = OPERATION .....	72
810 = DEVICE .....	75
820 = SENSOR .....	75
822 = AMPLIFIER .....	75
824 = F-CHIP .....	76
830 = I/O MODULE .....	76
<b>Functions 0...</b>	
0001 = VOLUME FLOW CH1 .....	10
0002 = SOUND VELOCITY CH1 .....	10
0003 = FLOW VELOCITY CH1 .....	10
0007 = SIGNAL STRENGTH CH1 .....	10
0061 = VOLUME FLOW CH2 .....	11
0062 = SOUND VELOCITY CH2 .....	11
0063 = FLOW VELOCITY CH2 .....	11
0067 = SIGNAL STRENGTH CH2 .....	11
0083 = AVERAGE VOLUME FLOW .....	12
0084 = VOLUME FLOW SUM .....	12
0085 = VOLUME FLOW DIFFERENCE .....	12
0086 = AVERAGE SOUND VELOCITY .....	12
0087 = AVERAGE FLOW VELOCITY .....	12
0402 = UNIT VOLUME FLOW .....	13
0403 = UNIT VOLUME .....	14
0422 = UNIT TEMPERATURE .....	15
0423 = UNIT VISCOSITY .....	15
0424 = UNIT LENGTH .....	15
0425 = UNIT VELOCITY .....	16
0429 = FORMAT DATE/TIME .....	16
<b>1...</b>	
1001 = QUICK SETUP SENSOR .....	17
1002 = QUICK SETUP COMMISSIONING .....	17
1009 = T-DAT SAVE/LOAD .....	17
<b>2...</b>	
2000 = LANGUAGE .....	23
2002 = DISPLAY DAMPING .....	23
2003 = CONTRAST LCD .....	24
2004 = BACKLIGHT .....	24
2009 = X-LINE CALCULATED MAIN VALUES .....	24
2020 = ACCESS CODE .....	25
2021 = DEFINE PRIVATE CODE .....	25
2022 = STATUS ACCESS .....	25
2023 = ACCESS CODE COUNTER .....	25
2040 = TEST DISPLAY .....	26
2200 = ASSIGN .....	27
2201 = 100% VALUE .....	27
2202 = FORMAT .....	28
2220 = ASSIGN .....	29
2221 = 100% VALUE .....	29
2222 = FORMAT .....	30
2400 = ASSIGN .....	31
2401 = 100% VALUE .....	32

2402 = FORMAT ..... 32  
 2403 = DISPLAY MODE ..... 32  
 2420 = ASSIGN ..... 33  
 2421 = 100% VALUE ..... 33  
 2422 = FORMAT ..... 34  
 2423 = DISPLAY MODE ..... 34  
 2600 = ASSIGN ..... 35  
 2601 = 100% VALUE ..... 36  
 2602 = FORMAT ..... 36  
 2603 = DISPLAY MODE ..... 36  
 2620 = ASSIGN ..... 37  
 2621 = 100% VALUE ..... 38  
 2622 = FORMAT ..... 38  
 2623 = DISPLAY MODE ..... 38

**3...**

3000 = ASSIGN ..... 40  
 3001 = UNIT TOTALIZER ..... 41  
 3002 = TOTALIZER MODE ..... 41  
 3003 = RESET TOTALIZER ..... 42  
 3040 = SUM ..... 43  
 3041 = OVERFLOW ..... 43  
 3800 = RESET ALL TOTALIZERS ..... 44  
 3801 = FAILSAFE MODE ..... 44

**6...**

6200 = WRITE PROTECTION ..... 46  
 6201 = SIMULATION ..... 46  
 6203 = DEVICE PD-TAG ..... 46  
 6220 = BLOCK SELECTION ..... 47  
 6221 = OUT VALUE ..... 47  
 6222 = IN VALUE ..... 47  
 6223 = CASCADE IN VALUE ..... 47  
 6224 = SETPOINT VALUE ..... 47  
 6240 = MANUFACTURER ID ..... 48  
 6241 = DEVICE TYPE ..... 48  
 6242 = SERIAL NUMBER ..... 48  
 6243 = DEVICE REVISION ..... 48  
 6244 = DD REVISION ..... 48  
 6400 = ASSIGN LOW FLOW CUT OFF ..... 49  
 6402 = ON-VALUE LOW FLOW CUT OFF ..... 49  
 6403 = OFF-VALUE LOW FLOW CUT OFF ..... 49  
 6404 = PRESSURE SHOCK SUPPRESSION ..... 50  
 6480 = ZEROPOINT ADJUSTMENT ..... 51  
 6520 = PIPE STANDARD ..... 52  
 6521 = NOMINAL DIAMETER ..... 53  
 6522 = PIPE MATERIAL ..... 53  
 6523 = REFERENCE VALUE ..... 53  
 6524 = SOUND VELOCITY PIPE ..... 54  
 6525 = CIRCUMFERENCE ..... 54  
 6526 = PIPE DIAMETER ..... 54  
 6527 = WALL THICKNESS ..... 55

6528 = LINER MATERIAL ..... 55  
 6529 = SOUND VELOCITY LINER ..... 56  
 6530 = LINER THICKNESS ..... 56  
 6540 = LIQUID ..... 57  
 6541 = TEMPERATURE ..... 57  
 6542 = SOUND VELOCITY LIQUID ..... 58  
 6543 = VISCOSITY ..... 58  
 6545 = SOUND VELOCITY NEGATIVE ..... 59  
 6546 = SOUND VELOCITY POSITIVE ..... 59  
 6600 = INSTALLATION DIRECTION SENSOR ..... 60  
 6601 = MEASURING MODE ..... 60  
 6603 = FLOW DAMPING ..... 60  
 6605 = POSITIVE ZERO RETURN ..... 61  
 6800 = K-FACTOR ..... 62  
 6803 = ZERO POINT ..... 62  
 6808 = CALIBRATION DATE ..... 62  
 6880 = MEASUREMENT ..... 63  
 6881 = SENSOR TYPE ..... 64  
 6882 = SENSOR CONFIGURATION ..... 65  
 6883 = CABLE LENGTH ..... 65  
 6884 = POSITION SENSOR ..... 65  
 6885 = WIRE LENGTH ..... 66  
 6886 = SENSOR DISTANCE ..... 66  
 6887 = ARC LENGTH ..... 66  
 6888 = PATH LENGTH ..... 66  
 6890 = P-FACTOR ..... 67  
 6891 = ZERO POINT ..... 67  
 6893 = CORRECTION FACTOR ..... 67  
 6894 = DEVIATION SENSOR SPACING ..... 67  
 6895 = DEVIATION ARC LENGTH ..... 68  
 6896 = DEVIATION PATH LENGTH ..... 68  
 6910 = CALIBRATION DATE ..... 69

**8...**

8005 = ALARM DELAY ..... 71  
 8007 = PERMANENT STORAGE ..... 71  
 8040 = ACTUAL SYSTEM CONDITION ..... 72  
 8041 = PREVIOUS SYSTEM CONDITIONS ..... 72  
 8042 = SIMULATION FAILSAFE MODE ..... 72  
 8043 = SIMULATION MEASURAND ..... 73  
 8044 = VALUE SIMULATION MEASURAND ..... 73  
 8046 = SYSTEM RESET ..... 73  
 8047 = TROUBLESHOOTING ..... 74  
 8048 = OPERATION HOURS ..... 74  
 8100 = DEVICE SOFTWARE ..... 75  
 8200 = SERIAL NUMBER ..... 75  
 8222 = SOFTWARE REVISION NUMBER AMPLIFIER ... 75  
 8225 = SOFTWARE REVISION NUMBER T-DAT ..... 75  
 8226 = LANGUAGE GROUP ..... 76  
 8240 = STATUS F-CHIP ..... 76  
 8300 = I/O MODULE TYPE ..... 76  
 8303 = SOFTWARE REVISION NUMBER I/O MODULE . 76

# 11 Index Local operation

## A

- Actual system condition ..... 72
- Additional configuration ..... 15
- Additional line
  - Configuration ..... 31
  - Multiplex ..... 33
- Adjustment
  - Function group ..... 51
  - Zero point ..... 51
- Alarm delay ..... 71
- Amplifier (version info) ..... 75
- Assign
  - Additional line ..... 31
  - Additional line (Multiplex) ..... 33
  - Information line ..... 35
  - Information line (Multiplex) ..... 37
  - Low flow cut off ..... 49
  - Main line ..... 27
  - Main line (Multiplex) ..... 29
  - Totalizer ..... 40
- Available functions ..... 8
- Average flow velocity ..... 12
- Average sound velocity ..... 12
- Average volume flow ..... 12

## B

- Basic configuration (user interface) ..... 23
- Basic functions
  - FOUNDATION Fieldbus
    - Function blocks ..... 47
    - Information ..... 48
- Basic functions (Block) ..... 45
- Block
  - Basic function ..... 45
  - Display ..... 22
  - Measured variables ..... 9
  - Quick Setup ..... 17
  - Supervision ..... 70
  - Totalizer ..... 39
- Block Selection ..... 47

## C

- Cable length ..... 65
- Calculated main values (displaying) ..... 24
- Calibration
  - Factory calibration ..... 69
- Calibration data
  - Correction factor ..... 67
  - Deviation arc length ..... 68
  - Deviation path length ..... 68
  - Deviation sensor distance ..... 67
  - P-factor ..... 67
  - Sensor data ..... 63, 67
  - Zero point ..... 67
- Calibration date ..... 62, 69
- Cascade IN Value ..... 47

## Code

- Access ..... 25
- Access counter ..... 25
- Customer ..... 25
- Configuration
  - Additional line ..... 31
  - FOUNDATION Fieldbus ..... 46
  - Information line ..... 35
  - Main line ..... 27
  - Process parameter ..... 49
  - Sensor data (CH1 to CH2) ..... 62
  - System ..... 71
  - System parameter (CH1 to CH2) ..... 60
  - System units ..... 13
  - Totalizer ..... 40
- Contrast LCD ..... 24
- Control
  - Operation ..... 26
  - Unlocking/locking ..... 25
- Control (group CAA)
  - Basic configuration ..... 23
- Correction factor ..... 67

## D

- Damping
  - Display ..... 23
  - Flow ..... 60
- DD Revision ..... 48
- Define private code ..... 25
- Deviation
  - Arc length ..... 68
  - Path length ..... 68
  - Sensor spacing ..... 67
  - Volume flow ..... 12
- Device PD-Tag ..... 46
- Device revision ..... 48
- Device software ..... 75
- Device type ..... 48
- Device (version info) ..... 75
- Display
  - Calculated main values ..... 24
  - Damping ..... 23
  - Language selection ..... 23
  - Lighting (back lighting) ..... 24
  - See Display
  - Test ..... 26
  - User interface (Block C) ..... 22
- Display lines of local operation ..... 8
- Display mode
  - Additional line ..... 32
  - Additional line (Multiplex) ..... 34
  - Information line ..... 36
  - Information line (Multiplex) ..... 38
- F**
  - Factory calibration ..... 69

Factory settings	77	Unlocking/locking (user interface)	25
Failsafe mode		Function matrix	
All totalizers	44	General layout	6
F-CHIP (version info)	76	Identification code	7
Flow damping	60	Overview	8
Flow velocity		<b>G</b>	
Average	12	Group	
Channel 1	10	Additional line	31
Channel 2	11	Control (User interface)	23
Format		FOUNDATION Fieldbus	46
Additional line	32	Handling Totalizer	44
Additional line (Multiplex)	34	Information line	35
Date/Time	16	Main line	27
Information line	36	Measuring values	10
Information line (Multiplex)	38	PROCESS PARAMETER (CH1 to CH2)	49
Main line	28	Sensor data (CH1 to CH2)	62
Main line (Multiplex)	30	System	71
FOUNDATION Fieldbus		System parameter (CH1 to CH2)	60
Configuration	46	System units	13
Function blocks	47	Totalizer (1 to 3)	40
Information	48	Version info	75
Function group		<b>H</b>	
Additional configuration	15	Handling Totalizer	44
Adjustment	51	<b>I</b>	
Amplifier	75	Illustration of function description	7
Basic configuration (user interface)	23	IN Value	47
Calculated main values	12	Information line	
Configuration		Configuration	35
Additional line	31	Multiplex	37
Calibration data	63, 67	Information (FOUNDATION Fieldbus)	48
FOUNDATION Fieldbus	46	Installation direction sensor	60
Information line	35	I/O Module	76
Main line	27	<b>K</b>	
Process parameter	49	K-Factor	62
Sensor data (CH1 to CH2)	62	<b>L</b>	
Sensor parameter	63	Language	
System	71	Factory settings (country)	77
System parameter (CH1 to CH2)	60	Language groups (display)	76
System units	13	Options	23
Totalizer	40	Liner	
F-CHIP	76	Material	55
Function blocks (FOUNDATION Fieldbus)	47	Sound velocity	56
Information (FOUNDATION Fieldbus)	48	Thickness	56
I/O Module	76	Liquid	
Liquid data	57	Measurement of the sound velocity	58
Main values	10	Liquid data (function group)	57
Measuring values		Local operation (display lines)	8
Main values CH2	11	Low flow cut off	
Multiplex		Assign	49
Additional line	33	Off-value	49
Information line	37	On-value	49
Main line	29	<b>M</b>	
Operation		Main line	
Display	26		
System	72		
Totalizer	43		
Original factory calibration	69		
Pipe data	52		
Sensor	75		

Configuration .....	27	Pipe data .....	52
Multiplex .....	29	Temperature .....	57
Main values .....	10	<b>Q</b>	
Manufacturer ID .....	48	Quick Setup (Block B)	
Measured variables (block A) .....	9	Commission .....	17
Measurement .....	63	Overview .....	17
Measurement of the ...		Sensor installation .....	17
sound velocity liquid .....	58	<b>R</b>	
Measuring mode .....	60	Reset	
Measuring values .....	10	All totalizers .....	44
Calculated main values .....	12	System .....	73
Main values .....	10	Totalizer .....	42
Main values CH2 .....	11	<b>S</b>	
Multiplex		Sensor	
Additional line .....	33	Distance .....	66
Information line .....	37	Position .....	65
Main line .....	29	Type .....	64
<b>N</b>		Sensor data (group GNA, GNB)	
Nominal diameter .....	53	Configuration .....	62
<b>O</b>		Original factory calibration .....	69
Off-value, low-flow cutoff .....	49	Sensor settings .....	65
On-value, low-flow cutoff .....	49	Sensor type .....	64
Operation		Sensor parameter .....	63
Display .....	26	Sensor settings .....	65
System .....	72	Sensor (version info) .....	75
Totalizer .....	43	Serial number .....	48
Operation hours .....	74	Serial number sensor .....	75
OUT Value .....	47	Setpoint value .....	47
Overflow		Signal strength	
Totalizer .....	43	Channel 1 .....	10
<b>P</b>		Channel 2 .....	11
Permanent storage .....	71	Simulation .....	46
P-factor .....	67	Failsafe mode .....	72
Pipe circumference .....	54	Measured variable .....	73
Pipe data .....	52	Value measured variable .....	73
Circumference .....	54	Software revision number	
Diameter .....	54	Amplifier .....	75
Liner material .....	55	I/O Module .....	76
Liner thickness .....	56	T-DAT .....	75
Nominal diameter .....	53	Sound velocity	
Pipe material .....	53	Average .....	12
Sound velocity liner .....	56	Channel 1 .....	10
Sound velocity pipe .....	53, 54	Channel 2 .....	11
Standard pipe .....	52	Liner .....	56
Wall thickness .....	55	Liquid .....	58
Pipe diameter .....	54	Negative .....	59
Pipe material .....	53	Pipe .....	53, 54
Position sensor .....	65	Positive .....	59
Positive zero return .....	61	Standard pipe .....	52
Pressure shock suppression .....	50	Status access .....	25
Previous system conditions .....	72	Status F-CHIP .....	76
Process parameter		Sum	
Configuration .....	49	Totalizer .....	43
Process parameter (CH1 to CH2), (Group GIA, GIB)		Supervision (Block J) .....	70
Adjustment .....	51	System condition	
Liquid .....	57	Actual .....	72
Liquid data .....	57	Previous .....	72

System parameter (Group GLA, GLB)  
 Configuration ..... 60

System units  
 Additional configuration ..... 15  
 Configuration ..... 13

System (group JAA)  
 Configuration ..... 71  
 Operation ..... 72  
 Reset ..... 73

**T**

T-DAT Save/Load ..... 17, 21

Temperature (liquid) ..... 57

Test display ..... 26

Totalizer  
 Assign ..... 40  
 Configuration ..... 40  
 Failsafe mode ..... 44  
 Handling Totalizer ..... 44  
 Operation ..... 43  
 Overflow ..... 43  
 Reset ..... 42  
 Sum ..... 43  
 Totalizer Mode ..... 41  
 Unit ..... 41

Totalizer Mode ..... 41

Troubleshooting 74

Type  
 Device ..... 48  
 I/O Module ..... 76  
 Sensor ..... 64

**U**

Unit  
 Length ..... 15  
 Temperature ..... 15  
 Totalizer ..... 41  
 Velocity ..... 16  
 Viscosity ..... 15  
 Volume ..... 14  
 Volume flow ..... 13

Unlocking/locking (user interface) ..... 25

**V**

Value simulation  
 Measured variable ..... 73

Version info (group JCA)  
 Amplifier ..... 75  
 F-CHIP ..... 76  
 I/O Module ..... 76  
 Sensor ..... 75

Viscosity ..... 58

Volume flow  
 Average ..... 12  
 Channel 1 ..... 10  
 Channel 2 ..... 11  
 Deviation ..... 12  
 Sum ..... 12  
 Unit ..... 13

Volume flow Sum ..... 12

**W**

Wall thickness ..... 55

Wire length ..... 66

Write protection ..... 46

**X**

Xline calculated main values ..... 24

**Z**

Zero point ..... 62, 67

Zero point adjustment ..... 51

**Numbers**

100% value flow  
 Additional line ..... 32  
 Additional line (Multiplex) ..... 33  
 Information line ..... 36  
 Information line (Multiplex) ..... 38  
 Main line ..... 27  
 Main line (Multiplex) ..... 29

# Content FOUNDATION Fieldbus

<b>1</b>	<b>Operation via FOUNDATION Fieldbus</b>	<b>86</b>
1.1	Block model	86
<b>2</b>	<b>Resource Block</b>	<b>88</b>
2.1	Selecting the operating mode	88
2.2	Block status	88
2.3	Write protection and simulation	89
2.4	Alarm detection and processing	89
2.5	Resource Block parameters	90
<b>3</b>	<b>Transducer Blocks</b>	<b>91</b>
3.1	Signal processing	92
3.2	Important functions and parameters of the Transducer Blocks	94
3.2.1	Block output values	94
3.2.2	Selecting the operating mode	94
3.2.3	Alarm detection and processing	95
3.2.4	Diagnosis	95
3.2.5	Accessing the device-specific parameters	95
3.3	Parameters for Transducer Blocks "Flow Channel 1" and "Channel 2"	96
3.4	"Diagnosis" Transducer Block parameters	115
3.5	"Service" Transducer Block parameters	118
3.6	"Display" Transducer Block parameters	118
3.7	"Totalizer" Transducer Block parameters	133
<b>4</b>	<b>Function blocks</b>	<b>137</b>
4.1	Signal processing	138
4.2	Important functions and parameters of the Analog Input function blocks	140
4.2.1	Selecting the operating mode	140
4.2.2	Assignment of the process variable	140
4.2.3	Linearization types	140
4.2.4	Selection of units	141
4.2.5	Status of the output value OUT	141
4.2.6	Simulation of input/output	142
4.2.7	Diagnosis	142
4.2.8	Rescaling the input value	142
4.2.9	Limit values	143
4.2.10	Alarm detection and processing	143
<b>5</b>	<b>Discrete Output function block</b>	<b>145</b>
5.1	Signal processing	145
5.2	Important functions and parameters of the Discrete Output function block	146
5.2.1	Selecting the operating mode	146
5.2.2	Safety behavior	146
5.2.3	Assignment between the Discrete Output function block and Transducer Block	146
5.2.4	Values for the parameters CAS_IN_D, RCAS_IN_D, OUT_D, and SP_D	146
<b>6</b>	<b>Additional function blocks</b>	<b>148</b>
<b>7</b>	<b>Index FOUNDATION Fieldbus</b>	<b>150</b>



# 1 Operation via FOUNDATION Fieldbus

## 1.1 Block model

In the fieldbus all the device parameters are categorized according to their functional properties and task and are generally assigned to three different blocks. A block may be regarded as a container in which parameters and the associated functionalities are contained.

A FOUNDATION Fieldbus device has the following block types:

- One Resource Block  
The Resource Block contains all the device-specific characteristics of the device.
- One or more Transducer Blocks  
The Transducer Block contains all the metrology-specific and device-specific parameters of the device. The measurement principles (e.g. flow, temperature etc.) are depicted in the Transducer Blocks in accordance with the FOUNDATION Fieldbus specification.
- One or more Function Blocks  
Function blocks contain the automation functions of the device. We distinguish between different Function Blocks, e.g. Analog Input Function Block, Analog Output Function Block, PID Function Block (PID controller), etc. Each of these Function Blocks is used to process different application functions.

Different automation tasks can be realized depending on the arrangement and connection of the individual Function Blocks. In addition to these blocks, a field device may have any number of further Function Blocks e.g. several Analog Input Function Blocks, if more than one process variable is available from the field device.

The Prosonic Flow 93 FOUNDATION Fieldbus has the following blocks:

- One Resource Block
- Six Transducer Blocks
- Ten function blocks consisting of:
  - Eight Analog Input function blocks
  - One Discrete Output
  - One PID function block




Fig. 1: Prosonic Flow 93 FOUNDATION Fieldbus block model

A0009871

The sensor signal is first prepared specifically for the flow in the measuring block, the **Transducer Block**. The process variables are then passed to the **Analog Input Function Blocks** for technical processing (e.g. scaling, limit value processing).

The process variables go through the complete Function Block algorithm and are available to other Function Blocks, e.g. the PID block, as a starting variable for connecting the desired application function.

Using the **Discrete Output function block (DO)** various actions and functions in the device functions of the Proline Prosonic Flow 93 FOUNDATION Fieldbus can be triggered and controlled.



Note!

Additional function blocks such as the PID, Arithmetic, Input Selector, Signal Characterizer and Integrator function block are described in the "FOUNDATION Fieldbus Overview" (BA013S) Operating Instructions (acquired at: → [www.endress.de](http://www.endress.de) → download).

## 2 Resource Block

A Resource Block contains all the data that uniquely identifies and characterizes the field device. It is an electronic version of a nameplate on the field device. Parameters of the Resource Block include device type, device name, manufacturer ID, serial number etc.

A further task of the Resource Block is the management of overall parameters and functions that have an influence on the execution of the remaining blocks in the field device. The Resource Block is thus the central unit that also checks the device status and thereby influences or controls the operability of the other blocks and thus also of the device. Since the Resource Block has no block input and block output data, it cannot be linked with other blocks.

The most important functions and parameters of the Resource Block are listed below; you will find an overview of all the available parameters starting on Page 88.

### 2.1 Selecting the operating mode

The operating mode is configured via the MODE\_BLK parameter group. The Resource Block supports the following operating modes:

- AUTO (automatic mode)
- OOS (out of service)



Note!

The operating mode OOS is also shown via the parameter BLOCK\_ERR. In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

### 2.2 Block status

The current operating status of the Resource Block is shown in the parameter RS\_STATE.

The Resource Block can take on the following states:

- STANDBY                      The Resource Block is in the OOS mode.  
It is not possible to execute the remaining blocks.
- ONLINE LINKING            The connections configured between the Function Blocks have not  
yet been linked.
- ONLINE                      Normal operating status, the Resource Block is in the AUTO  
operating mode. The configured connections between the  
Function Blocks have been established.

## 2.3 Write protection and simulation

Write protection of the device parameters and simulation in the Analog Input and Discrete Output Function Block can be locked or unlocked via jumper settings on the FOUNDATION Fieldbus I/O board (see Operating Instructions Proline Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D).

The parameter WRITE\_LOCK shows the status of the hardware write protection. The following statuses are possible:

- LOCKED Device data cannot be modified via the FOUNDATION Fieldbus interface.
- NOT LOCKED Device data can be modified via the FOUNDATION Fieldbus interface.

The parameter BLOCK\_ERR indicates whether a simulation is possible in the Analog Input and Discrete Output function block.

- Simulation Active Simulation possible in the Analog Input function block via the SIMULATE parameter and in the Discrete Output function block via the SIMULATE\_D parameter.

## 2.4 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK\_ALM. The parameter ACK\_OPTION specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Resource Block:

### Block process alarms

The following block process alarms of the Resource Block are shown via the parameter BLOCK\_ALM:

- OUT OF SERVICE
- SIMULATE ACTIVE

### Write protection process alarm

If write protection is disabled on the FOUNDATION Fieldbus I/O board, then prior to communicating the change of status to the fieldbus host system the alarm priority specified in the parameter WRITE\_PRI is checked. The alarm priority specifies the action taken when the write protection alarm WRITE\_ALM is enabled.



Note!

- If the option of a process alarm has **not** been enabled in the parameter ACK\_OPTION, this process alarm only has to be acknowledged in the parameter BLOCK\_ALM.
- The parameter ALARM\_SUM shows the current status of all the process alarms.

## 2.5 Resource Block parameters

The following table shows the Endress+Hauser-specific parameters of the Resource Block.



Note!

FOUNDATION Fieldbus parameters are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).

Resource Block		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Sensor - Serial Number</b>	read only	Use this function to view the sensor serial number.
<b>Amp. - HW Rev.Number</b>	read only	Use this parameter to view the hardware revision number of the amplifier.
<b>Amp. - HW Identification</b>	read only	Use this parameter to view the hardware ID number of the amplifier.
<b>Amp. - SW Rev.Number</b>	read only	Use this function to view the software revision number of the amplifier.
<b>Amp. - SW Identification</b>	read only	Use this function to view the software ID number of the amplifier.
<b>Amp. - Prod.-Number</b>	read only	Use this parameter to view the production number of the amplifier.
<b>Amp. - SW-Rev.No. T-DAT</b>	read only	Use this function to view the software revision number of the software used to create the content of the T-DAT.
<b>Amp. - Language Group</b>	read only	Use this function to view the language group.
<b>I/O - Type</b>	read only	Use this function to view the I/O module type.
<b>I/O - HW Rev. Number</b>	read only	Use this function to view the hardware revision number of the I/O module.
<b>I/O - HW Identification</b>	read only	Use this parameter to view the hardware ID number of the I/O module.
<b>I/O - SW Rev. Number</b>	read only	Use this function to view the software revision number of the I/O module.
<b>I/O - SW Identification</b>	read only	Use this parameter to view the software ID number of the I/O module.
<b>I/O - Prod.Number</b>	read only	Use this function to view the production number of the I/O module.
<b>Device Software</b>	read only	Display of the device software number.

## 3 Transducer Blocks

The Transducer Blocks contain all the measurement- and device-specific parameters of the flowmeter. All the settings directly connected with the flow measurement/application are made here. They form the interface between the sensor-specific measured value preprocessing and the Analog Input function blocks required for automation.

A Transducer Block allows you to influence the input and output values of a function block. The parameters of a Transducer Block include information on the sensor type, sensor configuration, physical units, calibration, damping, diagnosis, etc. as well as the device-specific parameters. The device-specific parameters and functions are split into several Transducer Blocks, each covering different task areas.

**"Flow Channel 1" Transducer Block/base index 1400:**

This block contains all the flow-specific parameters and functions, e.g. calibration functions, sensor data etc. for the first channel → Page 96

**"Flow Channel 2" Transducer Block/base index 1500:**

This block contains all the flow-specific parameters and functions, e.g. calibration functions, sensor data, etc. for the second channel → Page 96

**"Diagnosis" Transducer Block/base index 1600:**

This block contains all the parameters for system diagnosis, e.g. current system status etc.  
→ Page 115

**"Service" Transducer Block/base index 1700:**

This block contains all the parameters for service  
→ Page 118

**"Display" Transducer Block/base index 1800:**

This Block contains all the parameters for the configuration of the local display  
→ Page 118

**"Totalizer" Transducer Block/base index 1900:**

This Block contains all the parameters for the configuration of the totalizers  
→ Page 133

### 3.1 Signal processing

The following figure shows the internal structure of the individual Transducer Blocks:




Fig. 2: Internal structure of the individual Transducer Blocks

A0014887-EN

The Transducer Blocks "Flow Channel 1" and "Flow Channel 2" receive several signals from the sensor as input values (sound velocity, flow velocity). Other process variables are derived from these signals. The input signals are further processed via an amplifier.

The parameter "Simulation - Value Measurand" (see Page 114) allows you to specify a simulation value for the Transducer Block "Flow Channel 1" or "Flow Channel 2" in order to test assigned parameters in the device and subsequent function blocks.

The parameter "Low Flow Cut Off - On Value" (Page 100) allows you to define a limit value for the low flow cut off. If the measured flow value is below this limit value then the output value of "0" is output.

In addition, the parameter "System Param. - Positive Zero Return" (see Page 99) allows you to switch the measured value to "zero flow". This is necessary when a piping system is being cleaned, for example.

The Transducer Blocks "Flow Channel 1" and "Flow Channel 2" provide the following process variables for the subsequent Function Blocks:

- Volume flow channel 1 and Volume flow channel 2
- Sound velocity channel 1 and Sound velocity channel 2
- Flow velocity channel 1 and Flow velocity channel 2
- Signal strength channel 1 and Signal strength channel 2

If the measuring device is working in two-channel mode, the following calculated process variables are also made available:

- Average volume flow
- Volume flow Sum
- Volume flow difference
- Average sound velocity
- Average flow velocity

In the Transducer Block "Totalizer", a process variable can be assigned to each individual totalizer (e.g. Volume flow channel 1 etc.). The totalizers are also configured here; for example, the parameter "Totalizer Handling - Reset All" can be used to reset all totalizers simultaneously. For an overview of all block output variables, refer to → Page 94.

The "Diagnosis" Transducer Block comprises all the parameters and functions necessary for the diagnosis and maintenance of the device. For example, the parameter "Diag. - Act.Sys.Condition" indicates the actual system condition and, in case of error, a detailed cause of the error (see → Page 115).

If the measuring device is equipped with a local display, the Transducer Block "Display" can be used to configure various display parameters such as display language, contrast etc.



Note!

The Transducer Blocks "Diagnosis" and "Diagnosis" do not have any output variables, i.e. these have an effect on the measuring device itself only.

The most important functions and parameters of the Transducer Block are listed below. You will find an overview of all the available parameters starting on → Page 96 ff..

## 3.2 Important functions and parameters of the Transducer Blocks

### 3.2.1 Block output values

The Transducer Blocks make the following output variables (process variables) available. The CHANNEL parameter in the Analog Input function block is used to assign which process variable is read in and processed in the downstream Analog Input function block.



Note!

The "Diagnosis" and "Display" Transducer Blocks do not have any output variables.

Block	Process variable	Channel parameter (AI Block)
Transducer Block "CH1"	Volume flow channel 1	2
	Sound velocity channel 1	21
	Flow velocity channel 1	23
	Average volume flow	25
	Volume flow sum	26
	Volume flow difference	27
	Average sound velocity	28
	Average flow velocity	29
	Signal strength channel 1	30
Transducer Block "CH2"	Volume flow channel 2	20
	Sound velocity channel 2	22
	Flow velocity channel 2	24
	Signal strength channel 2	31
"Totalizer" Transducer Block	Totalizer 1	7
	Totalizer 2	8
	Totalizer 3	9

### 3.2.2 Selecting the operating mode

The operating mode is configured via the MODE\_BLK parameter group. The Transducer Blocks support the following operating modes:

- AUTO (automatic mode)
- OOS (out of service)



Note!

- The block status OOS is also shown via the parameter BLOCK\_ERR. In operating mode OOS, if write protection is not enabled and the release code is entered, you can access all the write parameters without restriction.
- The following applies for the "Flow Channel 1", "Flow Channel 2" and "Totalizer" Transducer Blocks: In the "OOS" operating mode, the process variables are updated but the status of the output value OUT (AI Block) changes to "BAD".
- If problems occur during the configuration of the function blocks → See Operating Instructions Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D), "Troubleshooting" section.

### 3.2.3 Alarm detection and processing

The Transducer Blocks do not generate any process alarms. The status of the process variables is evaluated in the subsequent Analog Input function blocks. If the Analog Input function block does not receive an input value that can be evaluated from the Transducer Blocks "Flow Channel 1", "Flow Channel 2" or "Totalizer", then a process alarm is generated. This process alarm is displayed in the BLOCK\_ERR parameter of the Analog Input function block (BLOCK\_ERR = Input Failure).

The parameter BLOCK\_ERR of the "Diagnosis" Transducer Block displays the device error that produced the input value that could not be evaluated and thus triggered the process alarm in the Analog Input function block.

In addition, the active device error is displayed via the "Diagnosis" Transducer Block in the "Diag. - Act.Sys.Condition" parameter ( → Page 115).

For more information on rectifying errors → See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D), "Troubleshooting" section.

### 3.2.4 Diagnosis

The status of the device is displayed via the following parameters specified in the FOUNDATION Fieldbus specification:

- BLOCK\_ERR
- Transducer Error

Detailed information on the current device status is displayed via the "Diagnosis" Transducer Block in the manufacturer-specific parameter "Diag. - Act.Sys.Condition" ( → Page 115).

For more information on rectifying errors → See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D), "Troubleshooting" section.

### 3.2.5 Accessing the device-specific parameters

To access the device-specific parameters the following requirements must be met:

1. The hardware write protection must be disabled → see Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D).
2. The correct code must be entered in the parameter "Access - Code" via the corresponding Transducer Block.

### 3.3 Parameters for Transducer Blocks "Flow Channel 1" and "Channel 2"

The following table shows the Endress+Hauser-specific parameters of the "Flow Channel 1" and "Flow Channel 2" Transducer Blocks. These can only be changed after entering a release code in the "Access - Code" parameter.



Note!


FOUNDATION Fieldbus parameters are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).


Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Un-/Locking - Access Code</b>	AUTO - OOS	<p>All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters be programmed and the device configuration modified.</p> <p>You can enable programming by entering:</p> <ul style="list-style-type: none"> <li>■ Code 93 (factory setting)</li> <li>■ Personal code ("Access - Def.Private Code" parameter → Page 119)</li> </ul> <p><b>Access</b> max. 4-digit number: 0 to 9999</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ If the hardware write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered.</li> <li>■ You can disable programming again by entering any number (other than the release code) in this parameter.</li> <li>■ The Endress+Hauser service organization can be of assistance if you mislay your personal code.</li> <li>■ Certain parameters are not accessible unless a special service code is entered. This service code is known only to the Endress+Hauser service organization. Please contact your Endress+Hauser service center if you require clarification.</li> </ul>
<b>Un-/Locking - Access Status</b>	read only	<p>Displays the current status of access to the manufacturer-specific parameters of the device.</p> <p><b>Display:</b> LOCKED (parameterization disabled) ACCESS CUSTOMER (parameterization enabled) ACCESS SERVICE (parameterization enabled)</p>
<b>System Value Volume Flow</b>	read only	<p>Use this parameter to view the current volume flow. The volume flow is provided to the subsequent Analog Input function blocks as a process variable.</p> <p><b>Display:</b> 5-digit floating-point number, including unit and sign (e.g. 5.5445 dm<sup>3</sup>/min; 1.4359 m<sup>3</sup>/h; -731.63 gal/d; etc.)</p> <p> Note! The unit is selected in the parameter "System Unit - Volume Flow".</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>System Unit - Volume Flow</b>	AUTO - OOS	<p>For displaying the desired unit for the volume flow (volume/time).</p> <p>The unit you select here is also valid for:</p> <ul style="list-style-type: none"> <li>■ Switching points (limit value, flow direction)</li> <li>■ Low flow cut off</li> </ul> <p><b>Options:</b></p> <p> Note! The following units of time can be selected: s = second, m = minute, h = hour, d = day</p> <p><i>Metric:</i> Cubic centimeter → cm<sup>3</sup>/... Cubic decimeter → dm<sup>3</sup>/... Cubic meter → m<sup>3</sup>/... Milliliter → ml/... Liter → l/... Hectoliter → hl/... Megaliter → Ml/... MEGA</p> <p><i>US:</i> Cubic centimeter → cc/... Acre foot → af/... Cubic foot → ft<sup>3</sup>/... Fluid ounce → oz f/... Gallon → US gal/... Million gallon → US Mgal/... Barrel (normal fluids: 31.5 gal/bbl) → US bbl/... NORM. Barrel (beer: 31.0 gal/bbl) → US bbl/... BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl/... PETR. Barrel (filling tanks: 55.0 gal/bbl) → US bbl/... TANK</p> <p><i>Imperial:</i> Gallon → imp. gal/... Mega gallon → imp. Mgal/... Barrel (beer: 36.0 gal/bbl) → imp. bbl/... BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl/... PETR.</p> <p><b>Factory setting:</b> Depends on country (dm<sup>3</sup>/m...m<sup>3</sup>/h or US gal/m...US Mgal/d)</p> <p> Note! The unit selected here does not have any effect on the desired volume unit which should be transmitted by means of the FF interface. This setting is made separately by means of the corresponding Analog Input Function Block in the XD_SCALE parameter group.</p>
<b>System Value - Sound Velocity</b>	read only	<p>Displays the current sound velocity. The sound velocity is provided to the subsequent Analog Input function blocks as a process variable.</p> <p> Note! The unit is displayed and selected in the parameter "System Unit - Sound Velocity".</p>
<b>System Unit - Sound Velocity</b>	AUTO - OOS	<p>For selecting the unit for the sound velocity.</p> <p><b>Options:</b> m/s ft/s</p> <p><b>Factory setting:</b> m/s</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>System Value - Flow Velocity</b>	read only	Displays the current flow velocity. The flow velocity is provided to the subsequent Analog Input function blocks as a process variable.  <b>Note!</b> The unit is displayed and selected in the parameter "System Unit - Flow Velocity".
<b>System Unit - Flow Velocity</b>	AUTO - OOS	For selecting the unit for the flow velocity.  <b>Options:</b> m/s ft/s  <b>Factory setting:</b> m/s
<b>System Value - Signal Strength</b>	read only	Displays the current signal strength. The signal strength is provided to the subsequent Analog Input function blocks as a process variable.
<b>System Unit Temperature</b>	AUTO - OOS	For selecting the unit for the fluid temperature.  <b>Options:</b> °C (Celsius) K (Kelvin) °F (Fahrenheit) R (Rankine)  <b>Factory setting:</b> Depends on country (°C or °F) → Page 77 ff.
<b>System Unit - Viscosity</b>	AUTO - OOS	For selecting the unit for the viscosity of the fluid.  <b>Options:</b> mm <sup>2</sup> /s cSt St  <b>Factory setting:</b> mm <sup>2</sup> /s
<b>System Unit - Length</b>	AUTO - OOS	For selecting the unit for the length measurement.  The unit you select here is valid for: <ul style="list-style-type: none"> <li>■ Nominal diameter</li> <li>■ Diameter</li> <li>■ Wall thickness</li> <li>■ Liner thickness</li> <li>■ Path length</li> <li>■ Wire length</li> <li>■ Sensor distance</li> </ul> <b>Options:</b> MILLIMETER INCH  <b>Factory setting:</b> Depends on country (MILLIMETER or INCH) → Page 77 ff.
<b>System Param. - Installation Direction Sensor</b>	AUTO - OOS	Use this parameter to reverse the sign of the flow measured variable, if necessary.  <b>Options:</b> NORMAL (FORWARD) INVERSE (REVERSE)  <b>Factory setting:</b> NORMAL (FORWARD)

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>System Param. - Flow Damping</b>	AUTO - OOS	<p> <b>Note!</b> The system damping acts on all functions of the measuring device.</p> <p>Specifies the filter depth of the digital filter. This reduces the sensitivity of the measuring signal to interference peaks (e.g. high solids content, gas bubbles in the fluid, etc.). The system reaction time increases with the filter setting. The damping acts on all parameters and on all downstream function blocks.</p> <p><b>User input:</b> 0 to 100 s</p> <p><b>Factory setting:</b> 0 s</p>
<b>System Param. - Positive Zero Return</b>	AUTO - OOS	<p>Use this parameter to interrupt evaluation of measured variables. This is necessary when a piping system is being cleaned, for example. This setting acts on all parameter and calculations of the measuring device.</p> <p><b>Options:</b> Off (signal output not interrupted) ON (signal output is set to the ZERO FLOW value)</p> <p><b>Factory setting:</b> OFF</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ An active positive zero return is relayed to downstream function blocks or higher-level process control systems by means of the status UNCERTAIN of the output value OUT (AI Block).</li> <li>■ Positive zero return can also be controlled using cyclic data transfer via the Discrete Output function block.</li> </ul>
<b>Adjustment - Adjust Zeropoint</b>	AUTO - OOS	<p>This parameter enables a zero point adjustment to be automatically carried out. The new zero point determined by the measuring system is adopted by the "Calibration Data - Zero Point" parameter ( → Page 112).</p> <p><b>Options:</b> CANCEL START</p> <p><b>Factory setting:</b> CANCEL</p> <p> <b>Caution!</b> Before carrying out an adjustment, please refer to the Operating Instructions for Proline Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D), where a detailed description of zero point adjustment is given.</p>
<b>Low Flow Cut Off - Assign</b>	AUTO - OOS	<p>Use this parameter to assign the switch point for the low flow cutoff.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> OFF</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Low Flow Cut Off - On-Value</b>	AUTO - OOS	<p>Use this function to specify the switch-on point for low flow cut off. Low flow cut off is active if the value entered is not equal to 0.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 0.0000</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>When the low flow cut off is triggered, a flow value of "0" is output via the output value OUT (AI Block). In addition, the status changes to UNCERTAIN.</li> <li>The unit used is displayed in the parameter "Low Flow Cut Off - Unit" and determined in the "System Unit - Volume Flow" parameter ( → Page 96).</li> </ul>
<b>Low Flow Cut Off - Unit</b>	read only	<p>Use this parameter to view the unit for the low flow cut off.</p> <p> <b>Note!</b></p> <p>The unit for the low flow cut off is defined using the parameter "System Unit - Volume Flow" ( → Page 96).</p>
<b>Low Flow Cut Off - Off-Value</b>	AUTO - OOS	<p>Use this function to enter the switch-off point (b) for low flow cut off. Enter the switch-off point as a positive hysteresis (H) from the switch-on point (a).</p> <p><b>User input:</b> Integer 0 to 100%</p> <p><b>Factory setting:</b> 50%</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0003882</p> <p>① = on-value, ② = off-value</p> <p><i>a</i> Low flow cut off is switched on  <i>b</i> Low flow cut off is switched off (<math>a + a \cdot H</math>)  <i>H</i> Hysteresis value: 0 to 100%   Low flow cut off active  <i>Q</i> Flow</p>
<b>Process - Pressure Shock Suppression</b>	AUTO - OOS	<p>The closure of a valve can cause brief but severe movements of the fluid in the piping system, movements which the measuring system registers. The pulses totaled in this way result in a totalizer reading error, particularly in the case of batching processes. For this reason, the measuring device is equipped with pressure shock suppression (= short-term signal suppression) which can eliminate system-related "disruptions".</p> <p> <b>Note!</b></p> <p>Note that pressure shock suppression cannot be used unless the low flow cut off is active (see parameter "Low Flow Cut Off - On-Value" → Page 100).</p> <p>(Continued on next page)</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Process - Pressure Shock Suppression</b> (Continued)	AUTO - OOS	<p>Use this parameter to define the time span for active pressure shock suppression.</p> <p><b>Activation of the pressure shock suppression</b>                      Pressure shock suppression is activated once the flow falls below the switch-on point of the low flow cut off (see point <b>a</b> in graphic).</p> <p>While pressure shock suppression is active, the following conditions apply:</p> <ul style="list-style-type: none"> <li>■ Flow reading on display = → 0.</li> <li>■ Totalizer reading → the totalizers are pegged at the last correct value.</li> </ul> <p><b>Deactivation of the pressure shock suppression</b>                      The pressure shock suppression is deactivated after the time interval, set in this function, has passed (see point <b>b</b> in graphic).</p> <p> <b>Note!</b>                      The actual flow value is displayed and output when the time interval for the pressure shock suppression has passed and the flow exceeds the switch-off point of the low flow cut off (see point <b>c</b> in graphic).</p>  <p style="text-align: right; font-size: small;">A0001285-EN</p> <p>① = on-value (low flow cut off), ② = off-value (low flow cut off)                      a Activated when the on-value for low flow cut off is undershot                      b Deactivated once the time specified passes                      c Flow values are taken into account again for calculating the pulses                      ■ Suppressed values                      Q Flow</p> <p><b>User input:</b>                      max. 4-digit number, incl. unit: 0.00 to 100.0 s</p> <p><b>Factory setting:</b>                      0.00 s</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Pipe Standard	AUTO - OOS	For selecting the standard pipe.  <b>Options:</b> OTHERS DIN PN10 DIN PN16 DIN 28610 DIN 28614 DIN 28615 DIN 28619 ANSI SCHEDULE 40 ANSI SCHEDULE 80 AWWA CLASS 50 AWWA CLASS 53 AWWA CLASS 55  <b>Factory setting:</b> DIN PN10
Pipe Data - Nominal Diameter	AUTO - OOS	Use this function to select the nominal diameter of the pipe.  <b>Options:</b> OTHERS 15/½ IN DN 25/1IN DN 40/1½IN DN 50/2IN DN 80/3IN DN 100/4IN DN 150/6IN DN 200/8IN DN 250/10IN DN 300/12IN DN 400/16IN DN 450/18IN DN 500/20IN DN 600/24IN DN 700/28IN DN 750/30IN DN 800/32IN DN 900/36IN DN 1000/40IN DN 1200/48IN DN 1400/54IN DN 1500/60IN DN 1600/64IN DN 1800/72IN DN 2000/80IN  <b>Factory setting:</b> DN 80/3IN
Pipe Data - Unit Nominal Diameter	read only	Displays the unit used in the parameter "Pipe Data - Nominal Diameter".   Note! The unit is selected in the parameter "System Unit - Length" → Page 98.

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Pipe Material	AUTO - OOS	<p>For selecting the pipe material.</p> <p><b>Options:</b>                      CARBON STEEL                      DUCTILE IRON                      STAINLESS STEEL                      SS ANSI 304                      SS ANSI 316                      SS ANSI 347                      SS ANSI 410                      SS ANSI 430                      HASTELLOY C                      PVC                      PE                      LDPE                      HDPE                      GRP                      PVDF                      PA                      PP                      PTFE                      GLASS PYREX                      ASBESTOS CEMENT                      OTHERS</p> <p><b>Factory setting:</b>                      STAINLESS STEEL</p>
Pipe Data - Reference Value	AUTO - OOS	<p> Note!                      This parameter is active only if the option "Sound Vel. Pipe" has been selected in the parameter "Sensor Param. - Measurement" ( → Page 108).</p> <p>For entering the thickness of the reference piece (e.g. flange), this serves as the basis for measuring the sound velocity of the pipes (see Page 104).</p> <p><b>User input:</b>                      5-digit floating-point number</p> <p><b>Factory setting:</b>                      5 (mm)</p> <p> Note!                      The unit used is displayed in the parameter "Pipe Data - Unit Reference Value".</p>
Pipe Data - Unit Reference Value	read only	<p>Displays the unit for the thickness of the reference piece.</p> <p> Note!                      The unit is selected in the parameter "System Unit - Length" → Page 98.</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Pipe Data - Sound Velocity Pipe</b>	AUTO - OOS	<p>For entering the sound velocity in the pipe.</p> <p><b>Measuring the sound velocity in the pipe</b> The measurement can be carried out via:</p> <ul style="list-style-type: none"> <li>■ Local display (Quick Setup "Sensor") → Page 17.</li> <li>■ The FieldTool configuration and service software.</li> </ul> <p> <b>Note!</b> A reference value is used as a basis for measuring the sound velocity. This reference value can be edited ( → Page 103).</p> <p><b>User input:</b> Fixed-point number 800 to 6500 (m/s)</p> <p><b>Factory setting:</b> 3120 (m/s)</p> <p> <b>Note!</b> The unit used is displayed in the parameter "Pipe Data - Unit Sound Velocity Pipe".</p>
<b>Pipe Data - Unit Sound Velocity Pipe</b>	read only	<p>For displaying the unit for the sound velocity in the pipe.</p> <p> <b>Note!</b> The unit is selected in the parameter "System Unit - Sound Velocity" → Page 97.</p>
<b>Pipe Data - Circumference</b>	AUTO - OOS	<p>For entering the pipe circumference.</p> <p><b>User input:</b> Fixed-point number 31.4 to 15708.0 (mm)</p> <p><b>Factory setting:</b> 279.3 (mm)</p> <p> <b>Note!</b> The unit used is displayed in the parameter "Pipe Data - Unit Circumference".</p>
<b>Pipe Data - Unit Circumference</b>	read only	<p>Use this parameter to view the unit for the pipe circumference.</p> <p> <b>Note!</b> The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
<b>Pipe Data - Pipe Diameter</b>	AUTO - OOS	<p>For entering the pipe diameter.</p> <p><b>User input:</b> Fixed-point number 10.0 to 5000.0 (mm)</p> <p><b>Factory setting:</b> 88.9 (mm)</p> <p> <b>Note!</b> The unit used is displayed in the parameter "Pipe Data - Unit Pipe Diameter".</p>
<b>Pipe Data - Unit Pipe Diameter</b>	read only	<p>Use this parameter to view the unit for the pipe circumference.</p> <p> <b>Note!</b> The unit is selected in the parameter "System Unit - Length" → Page 98.</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Pipe Data - Wall Thickness	AUTO - OOS	<p>For entering the wall thickness of the pipe.</p> <p><b>Measuring the wall thickness</b> The measurement can be carried out via:</p> <ul style="list-style-type: none"> <li>■ Local display (Quick Setup "Sensor") → Page 17.</li> <li>■ The FieldTool configuration and service software.</li> </ul> <p><b>User input:</b> Fixed-point number 0.1 to 100.0 (mm)</p> <p><b>Factory setting:</b> 3.2 (mm)</p> <p> Note! The unit used is displayed in the parameter "Pipe Data - Unit Wall Thickness".</p>
Pipe Data - Unit Wall Thickness	read only	<p>Displays the unit for the wall thickness of the pipe.</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
Pipe Data - Liner Material	AUTO - OOS	<p>Use this parameter to select the material with which the pipe is lined.</p> <p><b>Options:</b> LINER NONE MORTAR RUBBER TAR EPOXY OTHERS</p> <p><b>Factory setting:</b> LINER NONE</p>
Pipe Data - Sound Velocity Liner	AUTO - OOS	<p> Note! The entry is not active unless a liner was selected in the "Pipe Data - Liner Material" parameter.</p> <p>For entering the sound velocity in the liner.</p> <p><b>User input:</b> Fixed-point number 800 to 6500</p> <p><b>Factory setting:</b> Depends on the selection in the parameter "Pipe Data - Liner Material".</p> <p> Note! The unit used is displayed in the parameter "Pipe Data - Unit Sound Velocity Liner".</p>
Pipe Data - Unit Sound Velocity Liner	read only	<p>For displaying the unit for the sound velocity in the liner.</p> <p> Note! The unit is selected in the parameter "System Unit - Sound Velocity" → Page 97.</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Pipe Data - Liner Thickness</b>	AUTO - OOS	<p> Note! The entry is not active unless a measured variable was selected in the "Pipe Data - Liner Material" parameter.</p> <p>For entering the thickness of the liner.</p> <p><b>User input:</b> Fixed-point number 0.1 to 100.0</p> <p><b>Factory setting:</b> 0</p> <p> Note! The unit used is displayed in the parameter "Pipe Data - Unit Liner Thickness".</p>
<b>Pipe Data - Unit Liner Thickness</b>	read only	<p>Use this parameter to display the unit for selecting the thickness of the liner in the parameter "Pipe Data - Liner Thickness".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
<b>Liquid Data - Liquid</b>	AUTO - OOS	<p>Use this function to select the fluid in the pipe.</p> <p><b>Options:</b> WATER SEAWATER DEST. WATER AMMONIA ALCOHOL BENZENE BROMIDE ETHANOL GLYCOL KEROSENE MILK METHANOL TOLUOL (toluene) LUBE OIL FUEL OIL (diesel) PETROL (gasoline) OTHERS</p> <p><b>Factory setting:</b> WATER</p>
<b>Liquid Data - Temperature</b>	AUTO - OOS	<p>For entering the temperature of the liquid.</p> <p><b>User input:</b> Fixed-point number -273.15 to 726.85 °C (0 to 1000 K)</p> <p><b>Factory setting:</b> 20</p> <p> Note! The unit used is displayed in the parameter "Liquid Data - Unit-Temperature".</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Liquid Data - Unit Temperature</b>	read only	Use this parameter to display the unit for selecting the temperature of the liquid in the parameter "Liquid Data - Temperature".   <b>Note!</b> The unit is selected in the parameter "System Unit --Temperature" → Page 98.
<b>Liquid Data - Sound Velocity Liquid</b>	AUTO - OOS	For entering the sound velocity of the liquid.  <b>Measuring the sound velocity of the liquid</b> The measurement can be carried out via: <ul style="list-style-type: none"> <li>■ Local display (Quick Setup "Sensor").</li> <li>■ The FieldTool configuration and service software.</li> </ul> <b>User input:</b> Fixed-point number 400 to 3000  <b>Factory setting:</b> 1487   <b>Note!</b> The unit used is displayed in the parameter "Liquid Data - Unit Sound Velocity Liquid".
<b>Liquid Data - Unit Sound Velocity Liquid</b>	read only	Use this parameter to display the unit for selecting the sound velocity of the liquid in the parameter "Liquid Data - Sound Velocity Liquid".   <b>Note!</b> The unit is selected in the parameter "System Unit - Sound Velocity" → Page 97.
<b>Liquid Data - Min. Sound Velocity Liquid</b>	AUTO - OOS	For entering the minimum sound velocity of the liquid.  <b>User input:</b> Fixed-point number 400 to 3000  <b>Factory setting:</b> 500   <b>Note!</b> The unit used is displayed in the parameter "Liquid Data - Unit Min. Sound Velocity Liquid".
<b>Liquid Data - Unit Min. Sound Velocity Liquid</b>	read only	Use this parameter to display the unit for selecting the minimum sound velocity of the liquid in the parameter "Liquid Data - Min. Sound Velocity Liquid".   <b>Note!</b> The unit is selected in the parameter "System Unit - Sound Velocity" → Page 97.
<b>Liquid Data - Max. Sound Velocity Liquid</b>	AUTO - OOS	For entering the maximum sound velocity of the liquid.  <b>User input:</b> Fixed-point number 400 to 3000  <b>Factory setting:</b> 300   <b>Note!</b> The unit used is displayed in the parameter "Liquid Data - Unit Max. Sound Velocity Liquid".

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Liquid Data - Unit Max. Sound Velocity Liquid</b>	read only	<p>Use this parameter to display the unit for selecting the maximum sound velocity of the liquid in the parameter "Liquid Data - Max. Sound Velocity Liquid".</p> <p> <b>Note!</b> The unit is selected in the parameter "System Unit - Sound Velocity" → Page 97.</p>
<b>Sensor Param. - Measurement</b>	AUTO - OOS	<p>Use this parameter to select which measurement method is to be carried out.</p> <p><b>Options:</b> OFF CLAMP ON INSERTION</p> <p><b>Factory setting for channel 1:</b> CLAMP ON</p> <p><b>Factory setting for channel 2:</b> OFF</p> <p> <b>Caution!</b> The following options likewise appear as a selection in this parameter, but may be selected via the local display ( ) or the FieldTool configuration and service software only:</p> <ul style="list-style-type: none"> <li>■ SOUND VEL. LIQUID</li> <li>■ SOUND VEL. PIPE</li> <li>■ WALL THICKNESS</li> </ul>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Sensor Param. - Sensor Type	AUTO - OOS	<p> <b>Note!</b> This parameter is active only if the option "OFF" has not been selected in the parameter "Sensor Param. - Measurement".</p> <p>For selecting the sensor type. The selection in this parameter depends on the measurement method selected in the parameter "Sensor Param. - Measurement", ( → Page 108).</p> <p><b>Options:</b> (if "CLAMP ON" has been selected in the "Sensor Param. - Measurement" parameter) W-CL-05F-L-B W-CL-1F-L-B W-CL-1F-L-C W-CL-2F-L-B P-CL-05F-L-B P-CL-05F-M-B P-CL-1F-L-B P-CL-1F-M-B P-CL-2F-L-B P-CL-2F-M-B P-CL-6F-L-C P-CL-6F-M-C U-CL-2F-L-A</p> <p><b>Options:</b> (if "INSERTION" has been selected in the "Sensor Param. - Measurement" parameter) W-IN-1F-L-B</p> <p><b>Factory setting:</b> W-CL-2F-L-B</p> <p> <b>Caution!</b> The following options likewise appear as a selection in this parameter, but may be selected via the local display ( → Page 64) or the FieldTool configuration and service software only:</p> <ul style="list-style-type: none"> <li>■ P-CL-1S-L-B</li> <li>■ P-CL-1S-M-B</li> <li>■ P-CL-4W-L-B</li> </ul>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Sensor Param. - Sensor Configuration</b>	AUTO - OOS	<p> Note! This parameter is active only if one of the following options has been selected in the parameter "Sensor Param. - Measurement".</p> <ul style="list-style-type: none"> <li>■ CLAMP ON</li> <li>■ INSERTION</li> </ul> <p>Use this parameter to select the configuration for the ultrasonic sensors, e.g. the number of traverses (in the clamp-on design) or whether single-path or dual-path configuration is present (in the insertion design). The selection in this parameter depends on the measurement method selected in the parameter "Sensor Param. - Measurement", ( → Page 108).</p> <p><b>Options:</b> (if "CLAMP ON" has been selected in the "Sensor Param. - Measurement" parameter) NO. TRAVERSE: 1 NO. TRAVERSE: 2 NO. TRAVERSE: 3 NO. TRAVERSE: 4</p> <p><b>Options:</b> (if "INSERTION" has been selected in the "Sensor Param. - Measurement" parameter) SINGLE PATH DUAL PATH</p> <p><b>Factory setting:</b> NO. TRAVERSE: 2</p>
<b>Sensor Param. - Cable Length</b>	AUTO - OOS	<p>Use this function to select the length of the sensor cable.</p> <p><b>Options:</b> LEN. 5m/15 feet LEN. 10m/30 feet LEN. 15m/45 feet LEN. 30m/90 feet</p> <p><b>Factory setting:</b> LEN. 5m/15 feet</p>
<b>Sensor Param. - Position Sensor</b>	read only	<p> Note! This parameter is active only if the option "CLAMP ON" has been selected in the parameter "Sensor Param. - Measurement" and the number of traverses has been selected as 2 or 4 in the parameter "Sensor Param. - Sensor Configuration".</p> <p>Displays the position of both sensors on the rail.</p> <p><b>Display:</b> 5-digit number combination</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Sensor Param. - Wire Length</b>	read only	<p> Note! This parameter is active only if the option "CLAMP ON" has been selected in the parameter "Sensor Param. - Measurement" and the number of traverses has been selected as 1 or 3 in the parameter "Sensor Param. - Sensor Configuration".</p> <p>The wire length for assembling the sensors at the correct distance apart appears on the display.</p> <p><b>Display:</b> Max. 5-digit number</p> <p> Note! The unit used is displayed in the parameter "Sensor Data - Unit Wire Length".</p>
<b>Sensor Param. - Unit Wire Length</b>	read only	<p>Displays the unit used for the selection in the parameter "Sensor Data - Wire Length".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
<b>Sensor Param. - Sensor Distance</b>	read only	<p>The distance between sensor 1 and sensor 2 as a length measurement appears on the display.</p> <p><b>Display:</b> Max. 5-digit number</p> <p> Note! The unit used is displayed in the parameter "Sensor Param. - Unit Sensor Distance".</p>
<b>Sensor Param. - Unit Sensor Distance</b>	read only	<p>Displays the unit used for the selection in the parameter "Sensor Param. - Sensor Distance".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
<b>Sensor Param. - ARC Length</b>	read only	<p> Note! This parameter is active only if the option "INSERTION" has been selected in the parameter "Sensor Param. - Measurement" and the option "DUAL PATH" has been selected in the parameter "Sensor Param. - Sensor Configuration".</p> <p>The arc length on the pipe appears on the display.</p> <p><b>Display:</b> Max. 5-digit number</p> <p> Note! The unit used is displayed in the parameter "Sensor Param. - Unit ARC Length".</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Sensor Param. - Unit ARC Length</b>	read only	Displays the unit used for the selection in the parameter "Sensor Param. - ARC Length".   Note! The unit is selected in the parameter "System Unit - Length" → Page 98.
<b>Sensor Param. - Path Length</b>	read only	 Note! This parameter is active only if the option "INSERTION" has been selected in the parameter "Sensor Param. - Measurement".  The path length appears on the display.  <b>Display:</b> Max. 5-digit number   Note! The unit used is displayed in the parameter "Sensor Param. - Unit Path Length".
<b>Sensor Param. - Unit Path Length</b>	read only	Displays the unit used for the selection in the parameter "Sensor Param. - Path Length".   Note! The unit is selected in the parameter "System Unit - Length" → Page 98.
<b>Calibration Data - Calibration Factor</b>	read only	Use this function to view the current calibration factor for the measuring sensors.
<b>Calibration Data - Zero Point</b>	AUTO - OOS	Display or manual change of the value for the currently used zero point correction.  <b>User input:</b> 5-digit floating-point number, including unit and sign (e.g. +10.0 ns)
<b>Calibration Data - Correction Factor</b>	AUTO - OOS	For entering a correction factor defined by the customer.  <b>User input:</b> 5-digit floating-point number
<b>Calibration Data - Deviation Sensor Distance</b>	AUTO - OOS	 Note! This parameter is active only if the option "INSERTION" has not been selected in the parameter "Sensor Param. - Measurement".  Use this function to enter the deviation of the sensor distance.  <b>User input:</b> 5-digit floating-point number  <b>Factory setting:</b> 0   Note! The unit used is displayed in the parameter "Calibration Data - Unit Deviation Sensor Distance".

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
Calibration Data - Unit Deviation Sensor Distance	read only	<p>Displays the unit used for the selection in the parameter "Calibration Data - Deviation Sensor Distance".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
Calibration Data - Deviation ARC Length	AUTO - OOS	<p> Note! This parameter is active only if the option "INSERTION" has been selected in the parameter "Sensor Param. - Measurement" and the option "DUAL PATH" has been selected in the parameter "Sensor Param. - Sensor Configuration".</p> <p>Use this function to enter the deviation of the arc length.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 0</p> <p> Note! The unit used is displayed in the parameter "Calibration Data - Unit Deviation ARC Length".</p>
Calibration Data - Unit Deviation ARC Length	read only	<p>Displays the unit used for the selection in the parameter "Calibration Data - Deviation ARC Length".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>
Calibration Data - Deviation Path Length	AUTO - OOS	<p> Note! This parameter is active only if the option "INSERTION" has not been selected in the parameter "Sensor Param. - Measurement".</p> <p>Use this function to enter the deviation of the path length.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 0</p> <p> Note! The unit used is displayed in the parameter "Calibration Data - Unit Deviation Path Length".</p>
Calibration Data - Unit Deviation Path Length	read only	<p>Displays the unit used for the selection in the parameter "Calibration Data - Deviation Path Length".</p> <p> Note! The unit is selected in the parameter "System Unit - Length" → Page 98.</p>

Transducer Blocks "Flow Channel 1" and "Flow Channel 2" / base indexes 1400 and 1500		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Simulation - Measurand</b>	AUTO - OOS	<p>Activation of simulation for volume flow.</p> <p><b>Options:</b> OFF VOLUME FLOW</p> <p><b>Factory setting:</b> OFF</p> <p> Caution!</p> <ul style="list-style-type: none"> <li>■ The measuring device cannot be used for measuring while this simulation is in progress.</li> <li>■ The simulation is active <b>independently</b> of the position of the corresponding jumpers of the I/O board (see Operating Instructions for Proline Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D, Chapter 5.4).</li> <li>■ The setting is not saved in the event of a power failure.</li> </ul> <p> Note! An active simulation mode is relayed to downstream function blocks or higher-level process control systems by means of the status UNCERTAIN of the output value OUT (AI Block).</p>
<b>Simulation - Value Measurand</b>	AUTO - OOS	<p>Use this parameter to specify a selectable value (e.g. 12 m<sup>3</sup>/s). This is used to test the associated parameters in the flowmeter itself and downstream function blocks.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> 0</p> <p> Note! The unit used is displayed in the parameter "Simulation - Unit".</p> <p> Caution! The setting is not saved in the event of a power failure.</p>
<b>Simulation - Unit</b>	read only	<p>Displays the unit used in the parameter "Simulation - Value Measurand".</p> <p> Note! The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>
<b>Amp. Device Family</b>	read only	<p>This parameter is only used for service purposes.</p>

### 3.4 "Diagnosis" Transducer Block parameters

The following table shows the Endress+Hauser-specific parameters of the "Diagnosis" Transducer Block. These can only be changed after entering a release code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).

"Diagnosis" Transducer Block/base index 1600		
Parameter	Write access with operating mode (MODE BLK)	Description
<b>Diagnosis - Actual System Condition</b>	read only	Displays the current system status.  Note! A precise error description as well as notes on remedying errors can be found in the Operating Instructions for the Proline Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D.
<b>Diagnosis - Previous System Condition</b>	read only	Displays the last error message that occurred.
<b>Un-/Locking - Access Code</b>	AUTO - OOS	All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified.  You enable programming by entering: <ul style="list-style-type: none"> <li>■ Code 93 (factory setting)</li> <li>■ Personal code ( → Page 119)</li> </ul> <b>User input:</b> max. 4-digit number (0 to 9999)  Note! <ul style="list-style-type: none"> <li>■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA00078).</li> <li>■ You can disable programming again by entering any number (other than the access code) in this parameter.</li> <li>■ The E+H service organization can be of assistance if you mislay your personal code.</li> <li>■ The entry made here does not affect the local display. Programming via the function matrix thus has to be enabled separately.</li> </ul>
<b>Un-/Locking - Access Status</b>	read only	Displays the current status of access to the manufacturer-specific parameters of the device.  <b>Display:</b> <ul style="list-style-type: none"> <li>■ LOCKED (parameterization disabled)</li> <li>■ ACCESS CUSTOMER (parameterization enabled)</li> <li>■ ACCESS SERVICE (parameterization enabled, access to service level)</li> </ul>

"Diagnosis" Transducer Block/base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>System - Alarm Delay</b>	AUTO - OOS	<p>Use this function to define a time span for which the criteria for an error have to be satisfied without interruption before a fault or notice message is generated.</p> <p> <b>Note!</b> This alarm delay has an effect – depending on the configuration and type of error – both on the display and the output values of the FOUNDATION Fieldbus.</p> <p><b>User input:</b> 0 s to 100 s (in one-second increments)</p> <p><b>Factory setting:</b> 0 s</p> <p> <b>Caution!</b> If this parameter is used, fault and notice messages are delayed by the time corresponding to the setting before being forwarded to the downstream function blocks or the fieldbus host system. It is therefore imperative to check in advance in order to make sure whether a delay of this nature could affect the safety requirements of the process. If error and notice messages cannot be suppressed, a value of 0 seconds must be entered here.</p>
<b>System - Simulation Failsafe Mode</b>	AUTO - OOS	<p>Use this function to set the totalizers to their defined failsafe modes, in order to check whether they respond correctly. The failsafe mode of the totalizers is defined via the "Totalizer Handling - Failsafe All" parameter ( → Page 136).</p> <p> <b>Note!</b> With the fieldbus, an active simulation is relayed to downstream function blocks or higher-level process control systems by means of the status UNCERTAIN of the output value OUT (AI Block).</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p>
<b>System - Reset</b>	AUTO - OOS	<p>Use this parameter to perform a reset of the measuring system.</p> <p><b>Options:</b> NO RESTART SYSTEM (new startup without network interruption)</p> <p><b>Factory setting:</b> NO</p>

"Diagnosis" Transducer Block/base index 1600		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>System - Troubleshooting</b>	AUTO - OOS	<p>Use this parameter to rectify errors occurring in the EEPROM. The EEPROM is divided into various blocks. The error is rectified by selecting the block in question and acknowledging.</p> <p> <b>Caution!</b> When troubleshooting a block, the parameters of the selected block are reset to the values according to the factory setting.</p> <p><b>Options:</b> CANCEL MEASURING VALUES SYSTEM UNITS DENSITY PARAMETERS QUICK SETUP USER INTERFACE TOTALIZER COMMUNICATION PROCESSPARAMETER SYSTEM PARAMETER SENSOR DATA BATCH FUNCTION ADVANCED DIAGNOSIS AMPLIFIER PARAMETERS SUPERVISION VERSION-INFO SERVICE &amp; ANALYSIS PRODUCTION INFO FILTER PARAMETER</p> <p><b>Factory setting:</b> CANCEL</p>
<b>System - Operation Time</b>	read-only	The total operating time since the flowmeter was commissioned appears on the display (in seconds).
<b>T-DAT Save/Load</b>	AUTO - OOS	<p>Use this parameter to save the parameter settings / configuration of the transmitter in a transmitter DAT (T-DAT), or to load the parameter settings from the T-DAT into the EEPROM.</p> <p>Application examples:</p> <ul style="list-style-type: none"> <li>■ After commissioning, the current measuring point parameters can be saved to the T-DAT as a backup.</li> <li>■ If the transmitter is replaced for some reason, the data from the T-DAT can be loaded into the new transmitter (EEPROM).</li> </ul> <p><b>Options:</b> CANCEL SAVE (from EEPROM to the T-DAT) LOAD (from the T-DAT to the EEPROM)</p> <p><b>Factory setting:</b> CANCEL</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ If the power supply fails, the totalizer readings are automatically saved to the EEPROM.</li> <li>■ The option "LOAD" cannot be executed if the T-DAT is empty or faulty.</li> <li>■ The option "LOAD" and "SAVE" cannot be executed if no T-DAT is present.</li> </ul>
<b>Amp. Device Family</b>	read only	This parameter is only used for service purposes.

### 3.5 "Service" Transducer Block parameters

The Transducer Block "Service" (base index 1700) contains all the parameters necessary for service purposes. Because these parameters affect the accuracy and function of the measuring device, they may be modified by E+H service technicians only. The parameters of the Transducer Block "TRANSDUCER\_SERV" are not described in these Operating Instructions.

### 3.6 "Display" Transducer Block parameters

The following table shows the Endress+Hauser-specific parameters of the "Display" Transducer Block. These can only be changed after entering a release code in the "Access - Code" parameter.



Note!


FOUNDATION Fieldbus parameters are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Un-/Locking - Access Code</b>	AUTO - OOS	<p>All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified.</p> <p>You enable programming by entering:</p> <ul style="list-style-type: none"> <li>■ Code 93 (factory setting)</li> <li>■ Personal code ( → Page 119)</li> </ul> <p><b>User input:</b> max. 4-digit number (0 to 9999)</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus).</li> <li>■ You can disable programming again by entering any number (other than the access code) in this parameter.</li> <li>■ The E+H service organization can be of assistance if you mislay your personal code.</li> <li>■ The entry made here does not affect the local display. Programming via the function matrix thus has to be enabled separately.</li> </ul>
<b>Un-/Locking - Access Status</b>	read only	<p>Displays the current status of access to the manufacturer-specific parameters of the device.</p> <p><b>Display:</b></p> <ul style="list-style-type: none"> <li>■ LOCKED (parameterization disabled)</li> <li>■ ACCESS CUSTOMER (parameterization enabled)</li> <li>■ ACCESS SERVICE (parameterization enabled, access to service level)</li> </ul>
<b>Access - Code Counter</b>	read only	<p>Displays how often the customer code, service code or the digit "0" (code-free) has been entered to gain access to the measuring device.</p> <p><b>Display:</b> max. 7-digit number: 0 to 9999999</p> <p><b>Factory setting:</b> 0</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Un-/Locking - Define Private Code</b>	AUTO - OOS	<p>Use this function to enter a personal code to enable configuration. This applies both to manufacturer-specific parameters in the Transducer Blocks and to operating via the local display.</p> <p><b>User input:</b> 0...9999 (max. 4-digit number)</p> <p><b>Factory setting:</b> 93</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Programming is always enabled with the code "0".</li> <li>■ Parameter configuration has to be enabled before this code can be changed.</li> </ul>
<b>Configuration - Language</b>	AUTO - OOS	<p>Use this parameter to select the language for all texts, parameters and messages shown on the local display.</p> <p> Note!</p> <p>The displayed options depend on the language group available which is shown in the "Amp. - Language Group" parameter.</p> <p><b>Options:</b></p> <p>Language group WEST EU / USA: ENGLISH DEUTSCH FRANCAIS ESPANOL ITALIANO NEDERLANDS PORTUGUESE</p> <p>Language group EAST EU / SCAND: ENGLISH NORSK SVENSKA SUOMI POLISH RUSSIAN CZECH</p> <p>Language group ASIA: ENGLISH BAHASA INDONESIA JAPANESE (syllabary)</p> <p>Language group CHINA: ENGLISH CHINESE</p> <p><b>Factory setting:</b> Depends on country → Page 77 ff.</p> <p> Note!</p> <p>You can change the language group via the configuration program FieldCare. Please do not hesitate to contact your Endress+Hauser sales office if you have any questions.</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Configuration- Display Damping</b>	AUTO - OOS	<p>Use this parameter to enter a time constant defining how the display reacts to severely fluctuating flow variables, either very quickly (enter a low time constant) or with damping (enter a high time constant).</p> <p><b>User input:</b> 0...100 seconds</p> <p><b>Factory setting:</b> 1 s</p> <p> <b>Note!</b> Setting the time constant to "0" seconds switches off damping.</p>
<b>Configuration - Contrast LCD</b>	AUTO - OOS	<p>Use this function to optimize display contrast to suit local operating conditions.</p> <p><b>User input:</b> 10...100%</p> <p><b>Factory setting:</b> 50%</p>
<b>Config. - Backlight</b>	AUTO - OOS	<p>Use this parameter to optimize the backlight to suit local operating conditions.</p> <p><b>User input:</b> 0...100%</p> <p> <b>Note!</b> Entering the value "0" means that the backlight is "switched off". The display then no longer emits any light, i.e. the display texts can no longer be read in the dark.</p> <p><b>Factory setting:</b> 50%</p>
<b>Configuration - Xline Calculated</b>	AUTO - OOS	<p>Use this parameter to indicate which "calculated main value" from the measured values of both channels is displayed.</p> <p>For the value to be displayed in the desired line, the option "CALC. VOLUME FLOW" must be selected in one of the following parameters:</p> <ul style="list-style-type: none"> <li>■ For the display in the main line, parameter "Main Line - Assign"</li> <li>■ For the display in the addition line, parameter "Add. Line - Assign"</li> <li>■ For the display in the information line, parameter "Info Line - Assign"</li> </ul> <p> <b>Note!</b> This parameter is <b>not</b> active if on one channel, "OFF" has been selected in the parameter "Sensor Param. - Measurement" ( → Page 108).</p> <p><b>Options:</b> (CH1 + CH2)/2 CH1 + CH2 CH1 - CH2</p> <p><b>Factory setting:</b> (CH1 + CH2)/2</p>


"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Operation - Test Display</b>	AUTO - OOS	<p>Use this parameter to test the operability of the local display and its pixels.</p> <p><b>Options:</b> OFF ON</p> <p><b>Factory setting:</b> OFF</p> <p>Test sequence:</p> <ol style="list-style-type: none"> <li>1. Start the test by selecting ON.</li> <li>2. All pixels of the main line, additional line and information line are darkened for minimum 0.75 seconds.</li> <li>3. Main line, additional line and information line show an "8" in each field for minimum 0.75 seconds.</li> <li>4. Main line, additional line and information line show an "0" in each field for minimum 0.75 seconds.</li> <li>5. Main line, additional line and information line show nothing (blank display) for minimum 0.75 seconds.</li> </ol> <p>When the test is completed, the display returns to its initial state. Parameter → OFF.</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<p>1 = Main line 2 = Additional line 3 = Info line</p> 		
A0001253		
<b>Main Line - Assign</b>	AUTO - OOS	<p>Use this parameter to define the display value assigned to the main line (the top line of the local display) during normal measuring operation.</p> <p><b>Options:</b> OFF VOLUME FLOW (CH1 to CH2) CALC. VOLUME FLOW VOLUME FLOW % (CH1 to CH2) CALC. VOLUME FLOW % SOUND VELOCITY (CH1 to CH2) SOUND VELOCITY AVG. SIGNAL STRENGTH (CH1 to CH2) FLOW VELOCITY (CH1 to CH2) FLOW VELOCITY AVG. TOTALIZER (1 to 3) AI (1 to 8) - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable)</p> <p><b>Factory setting:</b> VOLUME FLOW CH1</p>
<b>Main Line - 100%-Value</b>	AUTO - OOS	<p> <b>Note!</b> The entry is not active unless one of the following was selected in the parameter "Main - Line - Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % CH1</li> <li>■ VOLUME FLOW % CH2</li> <li>■ CALC. VOLUME FLOW %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> Depends on country (10 l/s or 200 us.gal/min)</p> <p style="text-align: center;"><b>Note!</b></p> <p>The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Main Line - Format</b>	AUTO - OOS	<p>Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the main line.</p> <p><b>Options:</b> XXXXX. - XXXX.X - XXX.XX - XX.XXX - X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>Main Line Multiplex - Assign</b>	AUTO - OOS	<p>Use this parameter to define the second reading to be displayed in the main line alternately (every 10 seconds) with the value defined in the parameter "User Interface Main - Line Assign".</p> <p><b>Options:</b> OFF VOLUME FLOW (CH1 to CH2) CALC. VOLUME FLOW VOLUME FLOW % (CH1 to CH2) CALC. VOLUME FLOW % SOUND VELOCITY (CH1 to CH2) SOUND VELOCITY AVG. SIGNAL STRENGTH (CH1 to CH2) FLOW VELOCITY (CH1 to CH2) FLOW VELOCITY AVG. TOTALIZER (1 to 3) AI (1 to 8) - OUT VALUE PID - IN VALUE (controlled variable) PID - CAS IN VALUE (external set point) PID - OUT VALUE (manipulated variable)</p> <p><b>Factory setting:</b> OFF</p>
<b>Main Line Multiplex - 100%-Value</b>	AUTO - OOS	<p> Note!</p> <p>The entry is not active unless one of the following was selected in the parameter "Main - Multiplex Line Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % CH1</li> <li>■ VOLUME FLOW % CH2</li> <li>■ CALC. VOLUME FLOW %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b> 5-digit floating-point number</p> <p><b>Factory setting:</b> Depends on country [10 l/s or 200 us.gal/min]</p> <p> Note!</p> <p>The unit is taken from the parameter "System Unit - Volume Flow" (Page 97).</p>


"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Main Line Multiplex - Format</b>	AUTO - OOS	<p>Use this parameter to define the maximum number of places after the decimal point of the second value displayed for the reading in the main line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>


"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<p>1 = Main line  <b>2 = Additional line</b>                      3 = Info line</p> <div style="text-align: center;"> </div> <p style="text-align: right;">A0001253</p>		
<b>Add. Line - Assign</b>	AUTO - OOS	<p>Use this parameter to define the display value assigned to the additional line (the middle line of the local display) during normal measuring operation.</p> <p><b>Options:</b>                      OFF                      VOLUME FLOW (CH1 to CH2)                      CALC. VOLUME FLOW                      VOLUME FLOW % (CH1 to CH2)                      CALC. VOLUME FLOW %                      SOUND VELOCITY (CH1 to CH2)                      SOUND VELOCITY AVG.                      SIGNAL STRENGTH (CH1 to CH2)                      FLOW VELOCITY (CH1 to CH2)                      FLOW VELOCITY AVG.                      VOLUME FLOW BARGRAPH % (CH1 to CH2)                      CALC. VOLUME FLOW BARGRAPH %                      SIGNAL BARGRAPH (CH1 to CH2)                      TOTALIZER (1 to 3)                      FLOW DIRECTION (CH1 to CH2)                      CALC. FLOW DIRECTION                      AI (1 to 8) - OUT VALUE                      PID - IN VALUE (controlled variable)                      PID - CAS IN VALUE (external set point)                      PID - OUT VALUE (manipulated variable)                      DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>                      TOTALIZER 1</p>
<b>Add. Line - 100% - Value</b>	AUTO - OOS	<p> Note!                      The entry is not active unless one of the following was selected in the parameter "Add. Line - Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>                      5-digit floating-point number</p> <p><b>Factory setting:</b>                      Depends on country (10 l/s or 200 us.gal/min)</p> <p> Note!                      The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Add. Line - Format</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless a number was selected in the parameter "Add. Line - Assign".</p> <p>Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>Add. Line - Display Mode</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless one of the following was selected in the parameter "Add. Line - Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> <li>■ SIGNAL BARGRAPH (CH1 to CH2)</li> </ul> <p>Use this parameter to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Add. Line Multiplex - Assign</b>	AUTO - OOS	<p>Use this parameter to define the second reading to be displayed in the additional line alternately (every 10 seconds) with the value defined in the parameter "User Interface Add. Line - Assign".</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALC. VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALC. VOLUME FLOW %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVG.            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVG.            VOLUME FLOW BARGRAPH % (CH1 to CH2)            CALC. VOLUME FLOW BARGRAPH %            SIGNAL BARGRAPH (CH1 to CH2)            TOTALIZER (1 to 3)            FLOW DIRECTION (CH1 to CH2)            CALC. FLOW DIRECTION            AI (1 to 8) - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)            DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>            OFF</p> <p> Note!            Multiplex mode is suspended as soon as a fault or notice message is generated. The message in question appears on the display.</p> <ul style="list-style-type: none"> <li>■ Fault message (identified by a lightning flash symbol):                Multiplex mode is resumed as soon as the fault is no longer active.</li> <li>■ Notice message (identified by an exclamation mark):                Multiplex mode is resumed as soon as the notice message is no longer active.</li> </ul>
<b>Add. Line Multiplex - 100%-Value</b>	AUTO - OOS	<p> Note!            The entry is not active unless one of the following was selected in the parameter "Add. Line - Multiplex Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>            5-digit floating-point number</p> <p><b>Factory setting:</b>            Depends on country (10 l/s or 200 us.gal/min)</p> <p> Note!            The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Add. Line Multiplex - Format</b>	AUTO - OOS	<p> Note! The option is not active unless a number was selected in the parameter "Add. Line - Multiplex Assign".</p> <p>Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>Add. Line Multiplex - Display Mode</b>	AUTO - OOS	<p> Note! The option is not active unless one of the following was selected in the parameter "Add. Line - Multiplex Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> <li>■ SIGNAL BARGRAPH (CH1 to CH2)</li> </ul> <p>Use this parameter to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<p>1 = Main line 2 = Additional line 3 = Info line</p>  <p style="text-align: right;">A0001253</p>		
<b>Info Line - Assign</b>	AUTO - OOS	<p>Use this parameter to define the display value assigned to the information line (the bottom line of the local display) during normal measuring operation.</p> <p><b>Options:</b>                      OFF                      VOLUME FLOW (CH1 to CH2)                      CALC. VOLUME FLOW                      VOLUME FLOW % (CH1 to CH2)                      CALC. VOLUME FLOW %                      SOUND VELOCITY (CH1 to CH2)                      SOUND VELOCITY AVG.                      SIGNAL STRENGTH (CH1 to CH2)                      FLOW VELOCITY (CH1 to CH2)                      FLOW VELOCITY AVG.                      VOLUME FLOW BARGRAPH % (CH1 to CH2)                      CALC. VOLUME FLOW BARGRAPH %                      SIGNAL BARGRAPH (CH1 to CH2)                      TOTALIZER (1 to 3)                      OPERATING/SYSTEM CONDITIONS                      FLOW DIRECTION (CH1 to CH2)                      CALC. FLOW DIRECTION                      AI (1 to 8) - OUT VALUE                      PID - IN VALUE (controlled variable)                      PID - CAS IN VALUE (external set point)                      PID - OUT VALUE (manipulated variable)                      DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>                      OPERATING/SYSTEM CONDITIONS</p>
<b>Info Line - 100%-Value</b>	AUTO - OOS	<p> Note!                      The entry is not active unless one of the following was selected in the parameter "Info Line - Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>                      5-digit floating-point number</p> <p><b>Factory setting:</b>                      Depends on country (10 l/s or 200 us.gal/min)</p> <p> Note!                      The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Info Line - Format</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless a number was selected in the parameter "Info Line - Assign".</p> <p>Use this parameter to define the maximum number of places after the decimal point displayed for the reading in the additional line.</p> <p><b>Options:</b> XXXXX. – XXXX.X – XXX.XX – XX.XXX – X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>Info Line - Display Mode</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless one of the following was selected in the parameter "Info Line - Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> <li>■ SIGNAL BARGRAPH (CH1 to CH2)</li> </ul> <p>Use this parameter to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001259</p> <p><b>Factory setting:</b> STANDARD</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Info Line Multiplex - Assign</b>	AUTO - OOS	<p>Use this parameter to define the second reading to be displayed in the information line alternately (every 10 seconds) with the value defined in the parameter "Info Line - Assign".</p> <p><b>Options:</b>            OFF            VOLUME FLOW (CH1 to CH2)            CALC. VOLUME FLOW            VOLUME FLOW % (CH1 to CH2)            CALC. VOLUME FLOW %            SOUND VELOCITY (CH1 to CH2)            SOUND VELOCITY AVG.            SIGNAL STRENGTH (CH1 to CH2)            FLOW VELOCITY (CH1 to CH2)            FLOW VELOCITY AVG.            VOLUME FLOW BARGRAPH % (CH1 to CH2)            CALC. VOLUME FLOW BARGRAPH %            SIGNAL BARGRAPH (CH1 to CH2)            TOTALIZER (1 to 3)            OPERATING/SYSTEM CONDITIONS            FLOW DIRECTION (CH1 to CH2)            CALC. FLOW DIRECTION            AI (1 to 8) - OUT VALUE            PID - IN VALUE (controlled variable)            PID - CAS IN VALUE (external set point)            PID - OUT VALUE (manipulated variable)            DEVICE PD-TAG (tag name)</p> <p><b>Factory setting:</b>            OFF</p> <p> Note!            Multiplex mode is suspended as soon as a fault or notice message is generated. The message in question appears on the display.</p> <ul style="list-style-type: none"> <li>■ Fault message (identified by a lightning flash symbol):                Multiplex mode is resumed as soon as the fault is no longer active.</li> <li>■ Notice message (identified by an exclamation mark):                Multiplex mode is resumed as soon as the notice message is no longer active.</li> </ul>
<b>Info Line Multiplex - 100%-Value</b>	AUTO - OOS	<p> Note!            The entry is not active unless one of the following was selected in the parameter "Info Line - Multiplex Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW %</li> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> </ul> <p>Use this parameter to define the flow value to be shown on the display as the 100% value.</p> <p><b>User input:</b>            5-digit floating-point number</p> <p><b>Factory setting:</b>            Depends on country (10 l/s or 200 us.gal/min)</p> <p> Note!            The unit is taken from the parameter "System Unit - Volume Flow" ( → Page 97).</p>

"Display" Transducer Block/base index 1800		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Info Line Multiplex - Format</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless a number was selected in the parameter "Info Line - Multiplex Assign".</p> <p>Use this parameter to define the maximum number of places after the decimal point for the second value displayed in the information line.</p> <p><b>Options:</b> XXXXX. — XXXX.X — XXX.XX — XX.XXX — X.XXXX</p> <p><b>Factory setting:</b> X.XXXX</p> <p> <b>Note!</b></p> <ul style="list-style-type: none"> <li>■ Note that this setting only affects the reading as it appears on the display, it has no influence on the accuracy of the system's calculations.</li> <li>■ The places after the decimal point as computed by the measuring device cannot always be displayed, depending on this setting and the engineering unit. In such instances an arrow appears on the display between the measuring value and the engineering unit (e.g. 1.2 → dm<sup>3</sup>/s), indicating that the measuring system is computing with more decimal places than can be shown on the display.</li> </ul>
<b>Info Line Multiplex - Display Mode</b>	AUTO - OOS	<p> <b>Note!</b> The option is not active unless one of the following was selected in the parameter "Info Line - Multiplex Assign":</p> <ul style="list-style-type: none"> <li>■ VOLUME FLOW BARGRAPH % (CH1 to CH2)</li> <li>■ CALC. VOLUME FLOW BARGRAPH %</li> <li>■ SIGNAL BARGRAPH (CH1 to CH2)</li> </ul> <p>Use this parameter to define the format of the bar graph.</p> <p><b>Options:</b> STANDARD (Simple bar graph with 25 / 50 / 75% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p>SYMMETRY (Symmetrical bar graph for positive and negative directions of flow, with -50 / 0 / +50% gradations and integrated sign).</p> <div style="text-align: center;">  </div> <p style="text-align: right; font-size: small;">A0001258</p> <p><b>Factory setting:</b> STANDARD</p>
<b>Amp. Device Family</b>	read only	This parameter is only used for service purposes.

### 3.7 "Totalizer" Transducer Block parameters

The following table shows the Endress+Hauser-specific parameters of the "Totalizer" Transducer Block. These can only be changed after entering a release code in the "Access - Code" parameter.



Note!

FOUNDATION Fieldbus parameters are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → www.endress.de → Download).

"Totalizer" Transducer Block/base index 1900		
Parameter	Write access with operating mode (MODE BLK)	Description
<b>Un-/Locking - Access Code</b>	AUTO - OOS	<p>All data of the measuring system are protected against inadvertent change. Only when the code has been entered in this parameter can the manufacturer-specific parameters (E+H parameters) be programmed and the device configuration modified.</p> <p>You enable programming by entering:</p> <ul style="list-style-type: none"> <li>■ Code 93 (factory setting)</li> <li>■ Personal code ( → Page 119)</li> </ul> <p><b>User input:</b> max. 4-digit number (0 to 9999)</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ If the write protection is enabled then access to the manufacturer-specific parameters is blocked even if the right code is entered. Write protection can be activated and deactivated by means of jumpers on the I/O board (→ See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA00078).</li> <li>■ You can disable programming again by entering any number (other than the access code) in this parameter.</li> <li>■ The E+H service organization can be of assistance if you mislay your personal code.</li> <li>■ The entry made here does not affect the local display. Programming via the function matrix thus has to be enabled separately.</li> </ul>
<b>Un-/Locking - Access Status</b>	read only	<p>Displays the current status of access to the manufacturer-specific parameters of the device.</p> <p><b>Display:</b></p> <ul style="list-style-type: none"> <li>■ LOCKED (parameterization disabled)</li> <li>■ ACCESS CUSTOMER (parameterization enabled)</li> <li>■ ACCESS SERVICE (parameterization enabled, access to service level)</li> </ul>

"Totalizer" Transducer Block/base index 1900		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Totalizer 1 to 3 - System Value</b>	AUTO - OOS	<p>Use this parameter to view the total for the totalizer's measured variable aggregated since measuring commenced. The value can be positive or negative, depending on the setting selected in the parameter "Totalizer 1 to 3 - Mode" ( → Page 135) and the direction of flow.</p> <p><b>Display:</b> Max. 7-digit floating-point number, including unit and sign (e.g. 15467.04m<sup>3</sup>; -4925.631 kg)</p> <p> Note!</p> <ul style="list-style-type: none"> <li>■ The effect of the setting in the parameter "Totalizer 1 to 3 - Mode" is as follows: <ul style="list-style-type: none"> <li>- If the setting is BALANCE, the totalizer balances flow in the positive and negative directions.</li> <li>- If the setting is FORWARD, the totalizer registers only flow in the positive direction.</li> <li>- If the setting is REVERSE, the totalizer registers only flow in the negative direction.</li> </ul> </li> <li>■ The totalizers' response to faults is defined in the parameter "Totalizer - Failsafe All".</li> </ul>
<b>Totalizer 1 to 3 - System Unit</b>	AUTO - OOS	<p>Use this parameter to define the unit for the totalizer's measured variable as selected.</p> <p><b>Options:</b></p> <p><i>Metric:</i> Cubic centimeter → cm<sup>3</sup> Cubic decimeter → dm<sup>3</sup> Cubic meter → m<sup>3</sup> Milliliter → ml Liter → l Hectoliter → hl Megaliter → Ml MEGA</p> <p><i>US:</i> Cubic centimeter → cc Acre foot → af Cubic foot → ft<sup>3</sup> Fluid ounce → oz f Gallon → US gal Million gallon → US Mgal Barrel (normal fluids: 31.5 gal/bbl) → US bbl NORM.FL. Barrel (beer: 31.0 gal/bbl) → US bbl BEER Barrel (petrochemicals: 42.0 gal/bbl) → US bbl PETROCH. Barrel (filling tanks: 55.0 gal/bbl) → US bbl TANK</p> <p><i>Imperial:</i> Gallon → imp. gal Mega gallon → imp. Mgal Barrel (beer: 36.0 gal/bbl) → imp. bbl BEER Barrel (petrochemicals: 34.97 gal/bbl) → imp. bbl PETROCH.</p> <p><b>Factory setting:</b> Depends on country (m<sup>3</sup> or us.gal) → Page 77</p> <p> Note!</p> <p>The unit selected here does not have any effect on the desired volume unit which should be transmitted by means of the FF interface. This setting is made separately by means of the corresponding AI Block in the XD_SCALE parameter group.</p>

"Totalizer" Transducer Block/base index 1900		
Parameter	Write access with operating mode (MODE_BLK)	Description
<b>Totalizer 1 to 3 - Assign</b>	AUTO - OOS	<p>Assign a measured variable to the totalizer.</p> <p><b>Options:</b>                      OFF                      VOLUME FLOW CH1                      VOLUME FLOW CH2                      VOLUME FLOW AVERAGE                      VOLUME FLOW SUM                      VOLUME FLOW DIFF.</p> <p><b>Factory setting:</b>                      VOLUME FLOW CH1</p> <p> <b>Note!</b>                      The totalizer is reset to "0" as soon as the selection is changed.</p>
<b>Totalizer 1 to 3 - Mode</b>	AUTO - OOS	<p>Use this parameter to define how the flow components are to be totaled by the totalizer.</p> <p><b>Options:</b>                      BALANCE                      Positive and negative flow components. The positive and negative flow components are balanced. In other words, net flow in the flow direction is registered.</p> <p>FORWARD                      Only positive flow components</p> <p>REVERSE                      Negative flow components only</p> <p><b>Factory setting:</b>                      Totalizer 1 = BALANCE                      Totalizer 2 = FORWARD                      Totalizer 3 = REVERSE</p>
<b>Totalizer 1 to 3 - Reset</b>	AUTO - OOS	<p>Reset the totalizer ("Totalizer 1 to 3 - System Value" parameter) to zero.</p> <p><b>Options:</b>                      NO                      YES</p> <p><b>Factory setting:</b>                      NO</p> <p> <b>Note!</b>                      Totalizer resetting can also be controlled or initiated using cyclic data transmission via the Discrete Output function block ( → Page 145).</p>

<b>"Totalizer" Transducer Block/base index 1900</b>		
<b>Parameter</b>	<b>Write access with operating mode (MODE_BLK)</b>	<b>Description</b>
<b>Totalizer Handling - Reset All</b>	AUTO - OOS	<p>Simultaneously reset all totalizers ("Totalizer 1 to 3 - System Value" parameter) to zero.</p> <p><b>Options:</b> NO YES</p> <p><b>Factory setting:</b> NO</p> <p> Note! Totalizer resetting can also be controlled or initiated using cyclic data transmission via the Discrete Output function block ( → Page 145).</p>
<b>Totalizers Handling - Failsafe All</b>	AUTO - OOS	<p>Use this parameter to define the common response of all totalizers in case of error.</p> <p><b>Options:</b> STOP The totalizers are paused until the fault is rectified.</p> <p>ACTUAL VALUE The totalizers continue to count based on the current flow measured value. The fault is ignored.</p> <p>HOLD VALUE The totalizers continue to count the flow based on the last valid flow value (before the fault occurred).</p> <p><b>Factory setting:</b> STOP</p>
<b>Amp. Device Family</b>	read only	This parameter is only used for service purposes.


## 4 Function blocks

The function blocks contain the basic automation functions of the field device. We distinguish between different function blocks, e.g. Analog Input function block, PID function block (PID controller), etc.

Each of these function blocks is used to execute different application functions. This means that local control functions, for example, can be carried out directly in the field, and device errors such as amplifier errors are reported to the automation system automatically.

The function blocks process the input values in accordance with their specific algorithm and their internally available parameters. They generate output values that are made available to other function blocks for further processing by linking the individual function blocks with each other.

In the Analog Input function block (AI) the process variables from the Transducer Block are prepared for the subsequent automation functions (e.g. scaling, limit value processing). The automation function is defined by the connections of the outputs.




OUT = output value and output status of the Analog Input function block

A0003800

### 4.1 Signal processing

The figure shows the internal structure of the Analog Input function blocks available:



A0014888-EN

Fig. 3: Internal structure of the individual Analog Input function blocks

The Analog Input function blocks "Flow Channel 1", "Flow Channel 2" and "Totalizer" receive their input values from the **Transducer Blocks**. The parameter CHANNEL is used to select which input value is to be processed in an **Analog Input function block**.

Factory-based configuration of the Transducer Blocks → Page 94 ff.

The parameter group SIMULATE allows you to replace the input value with a simulation value and to activate simulation. By specifying the status and the simulation value the reaction of the complete Analog Input function block can be tested.



Note!

The simulation mode is activated by means of jumpers on the I/O board (→ Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus, BA00078D).

The parameter L\_TYPE is used to select the linearization type of the input or simulation value:

- Direct signal conversion  
The input value is forwarded without conversion ( $XD\_SCALE = OUT\_SCALE$ ). Select this option if the input value is already in the physical unit you want.
- Indirect signal conversion  
With this setting the input value is re-scaled linearly via the input scaling  $XD\_SCALE$  to the desired output range  $OUT\_SCALE$  (further information on rescaling of the input value can be found on → Page 142).
- Indirect signal conversion with square root  
With this setting the input value is re-scaled via the parameter group  $XD\_SCALE$  and recalculated using a square root function. It is then rescaled again to the desired output range via the parameter group  $OUT\_SCALE$ .

The parameter LOW\_CUT allows a limit value to be specified for the low flow cut off. The low flow cut off is activated via the parameter IO\_OPTS. If the converted primary value (PV) is below the limit value then it is set to a value of "0".

In the parameter PV\_FTIME a filter time can be specified for filtering the converted primary value (PV). If a time of 0 seconds is specified then no filtration takes place.

The parameter group MODE\_BLK is used to select the operating mode of the Analog Input function block. If the operating mode MAN (manual) is selected then the output value OUT can be specified directly.

The output value OUT is compared with warning and alarm limits (e.g. HI\_LIM, LO\_LO\_LIM, etc.) that can be entered via various parameters. If one of these limit values is violated then a limit value process alarm (e.g. HI\_ALM, LO\_LO\_ALM, etc.) is triggered.

## 4.2 Important functions and parameters of the Analog Input function blocks

The most important functions and parameters of the Analog Input function blocks are listed below.



Note!

All the FOUNDATION Fieldbus parameters available are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).

### 4.2.1 Selecting the operating mode

The operating mode is configured via the MODE\_BLK parameter group. The Analog Input function block supports the following operating modes:

- AUTO (automatic mode)
- MAN (manual mode)
- OOS (out of service)



Note!

The block status OOS is also shown via the parameter BLOCK\_ERR. In operating mode OOS, if write protection is not enabled, you can access all the write parameters without restriction.

### 4.2.2 Assignment of the process variable

The Prosonic Flow 93 FOUNDATION Fieldbus has eight Analog Input function blocks. The process variables of the Transducer Block that are to be processed are assigned via the parameter CHANNEL.

Factory-based configuration of the Transducer Blocks → Page 94 ff.

### 4.2.3 Linearization types

In an Analog Input function block, the input value of a Transducer Block can be linearized using the parameter L\_TYPE. The following types of linearization are available:

- Direct  
With this setting the measured value from the Transducer Block (input value) bypasses the linearization function and is looped unchanged with the same unit through the Analog Input function block.
- Indirect  
With this setting the measured value from the Transducer Block (input value) is re-scaled linearly via the input scaling XD\_SCALE to the desired output range OUT\_SCALE.
- Indirect Square Root  
With this setting the measured value from the Transducer Block (input value) is re-scaled via the parameter group XD\_SCALE and recalculated using an evolution function. It is then rescaled again to the desired output range via the parameter group OUT\_SCALE.

#### 4.2.4 Selection of units

A change in the unit for a process variable is defined in the relevant Analog Input function block, in the parameter group XD\_SCALE via the element UNIT.

If an unsuitable unit is selected, the function block changes to the OOS mode (out of service).



Note!

- If the "Direct" type of linearization was selected via the L\_TYPE parameter, the setting of the XD\_SCALE and OUT\_SCALE parameter groups must be identical; otherwise, the function block remains in the OOS operating mode and the "BLOCK CONFIG ERROR" block error is displayed in the BLOCK\_ERROR parameter.
- The system units selected in the Transducer Blocks in question do not have any effect on the setting of the system units in the Analog Input function block. The units are specified independently of one another and must be configured separately. The unit selected in the Transducer Blocks is only used for the local display, low flow cut off and for simulation.



#### 4.2.5 Status of the output value OUT

The status of the parameter group OUT transmits to the subsequent function blocks the status of the Analog Input function block and the validity of the output value OUT. The following status values can be displayed during this process:

- GOOD\_NON\_CASCADE  
The output value OUT is valid and can be used for further processing.
- UNCERTAIN  
The output value OUT can only be used for further processing to a limited extent. The status UNCERTAIN tells the downstream function blocks that a "notice message" is present in the device, e.g. arising from active positive zero return or simulation.
- BAD  
The output value OUT is invalid. The following causes are possible:
  - The Analog Input function block is in the OOS operating mode.
  - The "Flow Channel 1", "Flow Channel 2" or "Totalizer" Transducer Block is in the OOS operating mode. The Analog Input function block can only process the input value of the Transducer Block in question if the operating mode is set to AUTO.
  - A "fault message" is present in the device arising from a critical device error, e.g. an electronics module defect.



Note!

- The status of the device (block error) is displayed by means of the BLOCK\_ERR parameter.
- Detailed information on the current device status is displayed via the "Diagnosis" Transducer Block in the parameter "Diag. - Act.Sys.Condition". A list of all the error messages, including remedial measures, can be found in the Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D).

### 4.2.6 Simulation of input/output

Certain parameters of the Analog Input function block allow simulation of the input and output of the function block:

1. Simulation of the input of the Analog Input function block:  
The parameter group SIMULATE can be used to specify the input value (measured value and status). Since the simulation value runs through the entire function block, all the parameter settings of the block can be checked.



#### Note!

If simulation is blocked by the jumper on the I/O board then simulation mode cannot be activated in the parameter SIMULATE. In the Resource Block, the parameter BLOCK\_ERROR shows whether simulation of the Analog Input function block is possible.

2. Simulation of the output of the Analog Input function block:  
Set the operating mode in the parameter group MODE\_BLK to MAN and specify the desired output value directly in the parameter OUT.

### 4.2.7 Diagnosis

The status of the device is displayed via the BLOCK\_ERR parameter specified in the FOUNDATION Fieldbus specification.

Detailed information on the current device status is displayed via the "Diagnosis" Transducer Block in the manufacturer-specific parameter "Diag. - Act.Sys.Condition" ( → Page 115).

For more information on rectifying errors → See Operating Instructions for Prosonic Flow 93 FOUNDATION Fieldbus (BA00078D), "Troubleshooting" section.

### 4.2.8 Rescaling the input value

In the Analog Input function block the input value or input range can be scaled in accordance with the automation requirements.

#### Example:

- The measurement range of the channel 1 sensor is 0 to 30 m<sup>3</sup>/h.
- The output range to the process control system should be 0 to 100%.

The Analog Input function block must be configured as follows:

- Select the input value in the parameter CHANNEL  
Selection: Channel = 2 → Volume flow channel 1
- Parameter L\_TYPE  
Select: L\_TYPE = Indirect  
The process variable "Volume flow channel 1" from the "Flow Channel 1" Transducer Block is rescaled linearly via input scaling XD\_SCALE to the desired output range OUT\_SCALE.
- Parameter group XD\_SCALE
 

XD_SCALE 0 %	= 0
XD_SCALE 100 %	= 30
XD_SCALE UNIT	= m <sup>3</sup> /h

- Parameter group OUT\_SCALE
  - OUT\_SCALE 0 % = 0
  - OUT\_SCALE 100 % = 100
  - OUT\_SCALE UNIT = %

The result is that with an input value of, for example, 15 m<sup>3</sup>/h, a value of 50% is output via the parameter OUT.




Fig. 4: Rescaling the input value (example)

A0009872-EN

## 4.2.9 Limit values

The full scale values are based on the output value OUT. If the output value OUT exceeds or does not reach the defined limit values then an alarm is sent to the fieldbus host system via the limit value process alarms. The following limit values can be defined:

- HI\_HI\_LIM (upper alarm limit)
- HI\_LIM (upper pre-warning limit)
- LO\_LO\_LIM (lower alarm limit)
- LO\_LIM (lower pre-warning limit)

## 4.2.10 Alarm detection and processing

Process alarms provide information on particular block statuses and block events. The status of the process alarms is communicated to the fieldbus host system via the parameter BLOCK\_ALM. The parameter ACK\_OPTION specifies whether an alarm must be acknowledged via the fieldbus host system.

The following process alarms are generated by the Analog Input function block:

### Block process alarms

A block process alarm is triggered via the BLOCK\_ERR parameter. The parameter BLOCK\_ALM is used to show the block process alarms and communicate them to the fieldbus host system. The following process alarms can be generated by the Analog Input function block:

- SIMULATE ACTIVE
- INPUT FAILURE
- OUT OF SERVICE
- BLOCK CONFIG ERROR

If the option of the process alarm (BLOCK ALM) has **not** been enabled in the parameter ACK\_OPTION, the process alarms must be acknowledged in the parameter BLOCK\_ALM.

**Limit value process alarms**

If a limit value is infringed then the priority specified for the limit value alarm will be checked before the limit value violation is communicated to the fieldbus host system. The priority that specifies the action in the event of an active limit value violation is determined by the following parameters:

- HI\_HI\_PRI (upper alarm limit)
- HI\_PRI (upper pre-warning limit)
- LO\_LO\_PRI (lower alarm limit)
- LO\_PRI (lower pre-warning limit)

The status of the limit value process alarms is communicated to the fieldbus host system via the following parameters:

- HI\_HI\_ALM (upper alarm limit)
- HI\_ALM (upper pre-warning limit)
- LO\_LO\_ALMI (lower alarm limit)
- LO\_ALM (lower pre-warning limit)

If the option of a limit value process alarm has **not** been enabled in the parameter ACK\_OPTION then this must be acknowledged directly in its parameter (see list).



Note!

The parameter ALARM\_SUM shows the current status of all the process alarms.

## 5 Discrete Output function block

The Discrete Output function block (DO, Discrete Output) processes a discrete setpoint value received from an upstream function block or higher level process control system, with which various instrument functions (e.g. zero point adjustment or totalizer reset) can be initiated in the subsequent Transducer Block.




A0003816-en

- CAS\_IN\_D = Remote setpoint value from another function block
- OUT\_D = Discrete output value and status
- BKCAL\_OUT\_D = Discrete output value and status required by BKCAL\_IN\_D input of another block for output

### 5.1 Signal processing

The figure shows the internal structure of the Discrete Output function blocks Prosonic Flow 93 FOUNDATION Fieldbus:



A0004771-en

Fig. 5: Signal processing in the Discrete Output function block

In the CAS operating mode (cascade operation), the **Discrete Output function block** receives, via the function block input CAS\_IN\_D, a discrete signal from an upstream function block. This signal controls the setpoint value (parameter SP\_D) of the function block, and after internal calculation is sent as an output signal (parameter OUT\_D) to the Transducer Block for control of instrument functions (e.g. zero point adjustment). The output value and status of the **Discrete Output function block** is communicated to the upstream block via the output BKCAL\_OUT\_D.

Signal processing in the RCAS operating mode (remote cascade operation) is largely identical to the CAS operating mode. However, in this operating mode, control of the parameter SP\_D does not take place via an upstream function block but through a fieldbus host system. The output value and status

of the Discrete Output function block is communicated to the process control system as an answer message via parameter RCAS\_OUT\_D.

In the AUTO operating mode (automatic operation), the set point value (parameter SP\_D) is prescribed directly in the Discrete Output function block. In this case, the parameter CAS\_IN\_D is not taken into consideration in the internal calculation.

In the MAN operating mode (HAND), the output value (parameter OUT\_D) can be prescribed directly in the Discrete Output function block. No internal calculation takes place.

## 5.2 Important functions and parameters of the Discrete Output function block

The most important functions and parameters of the Discrete Output function block are listed below.



Note!

All the FOUNDATION Fieldbus parameters available are described in the Operating Instructions "FOUNDATION Fieldbus Overview" (BA013S) (acquired at: → [www.endress.de](http://www.endress.de) → Download).

### 5.2.1 Selecting the operating mode

The operating mode is configured via the MODE\_BLK parameter group. The Discrete Output function block supports the following operating modes:

- AUTO
- MAN
- CAS
- RCAS
- OOS

### 5.2.2 Safety behavior

There is a safety default available (fault state) for the Discrete Output function block.

This is activated when a fault condition (of the corresponding valid set point value) exists longer than defined in the parameter FSTATE\_TIME, or when the parameter SET\_FSTATE in the Resource Block is activated. The safety operation is determined via the parameters FSTATE\_TIME, FSTATE\_VAL\_D, and IO\_OPTS.

### 5.2.3 Assignment between the Discrete Output function block and the Transducer Block

The assignment or connection between the Discrete Output function block and the Transducer Block takes place in the Discrete Output function block via the parameter CHANNEL.

→ Parameter CHANNEL → 16 (= Discrete Output function block)

### 5.2.4 Values for the parameters CAS\_IN\_D, RCAS\_IN\_D, OUT\_D, and SP\_D

Via the Discrete Output function block, different instrument functions in the Transducer Block can be initiated via manufacturer-specific, fixed set point values from an upstream function block.

Here it must be observed that the desired function is only then executed when a status change from the value 0 (Discrete state 0) to the corresponding function value (following table) takes place. The value 0 always serves as the starting point for the corresponding control of instrument functions. A status change from a value not equal to zero to another value has no effect.

**Input assignment of the CAS\_IN\_D, RCAS\_IN\_D, OUT\_D, SP\_D parameters**

Status changes	Action
Discrete state 0 → Discrete state 1	Reserved
Discrete state 0 → Discrete state 2	Positive zero return channel 1: On
Discrete state 0 → Discrete state 3	Positive zero return channel 1: Off
Discrete state 0 → Discrete state 4	Zero point adjustment channel 1
Discrete state 0 → Discrete state 5	Reserved
Discrete state 0 → Discrete state 6	Reserved
Discrete state 0 → Discrete state 7	Reset totalizers 1, 2, 3
Discrete state 0 → Discrete state 8	Reset totalizer 1
Discrete state 0 → Discrete state 9	Reset totalizer 2
Discrete state 0 → Discrete state 10	Reset totalizer 3
Discrete state 0 → Discrete state 11	Reserved
Discrete state 0 → Discrete state 12	Reserved
Discrete state 0 → Discrete state 13	Reserved
Discrete state 0 → Discrete state 14	Reserved
Discrete state 0 → Discrete state 15	Reserved
Discrete state 0 → Discrete state 16	Positive zero return channel 2: On
Discrete state 0 → Discrete state 17	Positive zero return channel 2: Off
Discrete state 0 → Discrete state 18	Zero point adjustment channel 2
Discrete state 0 → Discrete state 27	Permanent storage: Off
Discrete state 0 → Discrete state 28	Permanent storage: On

Example for controlling positive zero return via the Discrete Output function block.

The following example shows how positive zero return can be activated or deactivated via the Discrete Output function block during a cleaning procedure.

1. In the first step, the connection between the Discrete Output function block and the Transducer Block must be established. Here, the value 16 must be assigned to the parameter CHANNEL in the Discrete Output function block.
2. In the CAS operating mode, the Discrete Output function block processes the set point value specified at the input CAS\_IN\_D by the upstream function block and transfers it to the Transducer Block.

**Activating the positive zero return channel 1**

With a starting value of 0 (Discrete state 0), positive zero return is activated by a status change from 0 → 2 at input CAS\_IN\_D.

**Deactivating the positive zero return channel 1**

Positive zero return can only then be deactivated when the input value at CAS\_IN\_D has first been set to output value 0 (Discrete state 0). Only then can positive zero return be deactivated through a status change from 0 → 3 at input CAS\_IN\_D.

## 6 Additional function blocks



Note!

Additional function blocks such as the PID, Arithmetic, Input Selector, Signal Characterizer and Integrator function block are described in the "FOUNDATION Fieldbus Overview" (BA013S) Operating Instructions (acquired at: → [www.endress.de](http://www.endress.de) → download).

# 7 Index FOUNDATION Fieldbus

## A

- Access - Code
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 96
- Access - Code Counter
  - "Display" Transducer Block . . . . . 118
- Access counter . . . . . 25
- Add. Line - 100%-Value
  - "Display" Transducer Block . . . . . 125
- Add. Line - Assign
  - "Display" Transducer Block . . . . . 125
- Add. Line - Display Mode
  - "Display" Transducer Block . . . . . 126
- Add. Line - Format
  - "Display" Transducer Block . . . . . 126
- Add. Line Multiplex - 100%-Value
  - "Display" Transducer Block . . . . . 127
- Add. Line Multiplex - Assign
  - "Display" Transducer Block . . . . . 127
- Add. Line Multiplex - Display Mode
  - "Display" Transducer Block . . . . . 128
- Add. Line Multiplex - Format
  - "Display" Transducer Block . . . . . 128
- Additional line
  - 100% Value . . . . . 125
  - 100% value (multiplex) . . . . . 127
  - Assign . . . . . 125
  - Assign (multiplex) . . . . . 127
  - Display mode . . . . . 126
  - Display mode (multiplex) . . . . . 128
  - Format . . . . . 126
  - Format (multiplex) . . . . . 128
- Alarm delay . . . . . 116
- Alarm detection
  - AI function block . . . . . 143
  - Resource Block . . . . . 89
  - Transducer Block . . . . . 95
- Alarm processing
  - AI function block . . . . . 143
  - Resource Block . . . . . 89
  - Transducer Blocks . . . . . 95
- Amp. - HW Identification
  - Resource Block . . . . . 90
- Amp. - HW Rev.Number
  - Resource Block . . . . . 90
- Amp. - Language Group
  - Resource Block . . . . . 90
- Amp. - Prod.Number
  - Resource Block . . . . . 90
- Amp. - SW Identification
  - Resource Block . . . . . 90
- Amp. - SW Rev.No. T-DAT
  - Resource Block . . . . . 90
- Amp. - SW Rev.Number
  - Resource Block . . . . . 90
- Amp. Device Family
  - "Display" Transducer Block . . . . . 132

- "Totalizer" Transducer Block . . . . . 136
- Transducer Blocks "Channel 1" and "Channel 2" . . . . . 114
- Amp. Device Family - Transducer Block "Diagnosis" . . . . . 117
- Amplifier
  - Hardware identification number . . . . . 90
  - Hardware revision number . . . . . 90
  - Language Group . . . . . 90
  - Production number . . . . . 90
  - Software identification number . . . . . 90
  - Software revision number . . . . . 90
- Analog Input function block
  - Alarm detection, processing . . . . . 143
  - Diagnosis . . . . . 142
  - General description . . . . . 137
  - Limit values . . . . . 143
  - Rescaling . . . . . 142
  - Signal processing . . . . . 138
  - Simulation of input/output . . . . . 142
  - Status, output value OUT . . . . . 141
- Arc length . . . . . 111
- Assign
  - DO function block . . . . . 146
  - Totalizer 1 to 3 . . . . . 135

## B

- Backlight
  - Display . . . . . 120
- Base index
  - 1700 Transducer Block "Service" . . . . . 118
- Block model . . . . . 86
- Block output values
  - Transducer Block . . . . . 94

## C

- Cable length . . . . . 110
- Calibration Data - Calibration Factor
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 112
- Calibration Data - Correction Factor
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 112
- Calibration Data - Deviation ARC Length
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 113
- Calibration Data - Deviation Path Length
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 113
- Calibration Data - Deviation Sensor Distance
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 112
- Calibration Data - Unit Deviation ARC Length
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 113
- Calibration Data - Unit Deviation Path Length
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 113
- Calibration Data - Unit Deviation Sensor Distance
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 113
- Calibration Data - Zero Point
  - Transducer Blocks "Channel 1" and "Channel 2" . . . . . 112
- Calibration factor . . . . . 112
- Code
  - Access counter . . . . . 25



Transducer Blocks "Channel 1" and "Channel 2" .... 107

Liquid Data - Min. Sound Velocity  
 Transducer Blocks "Channel 1" and "Channel 2" .... 107

Liquid Data - Sound Velocity  
 Transducer Blocks "Channel 1" and "Channel 2" .... 107

Liquid Data - Temperature  
 Transducer Blocks "Channel 1" and "Channel 2" .... 106

Liquid Data - Unit Max. Sound Velocity  
 Transducer Blocks "Channel 1" and "Channel 2" .... 108

Liquid Data - Unit Min. Sound Velocity  
 Transducer Blocks "Channel 1" and "Channel 2" .... 107

Liquid Data - Unit Sound Velocity  
 Transducer Blocks "Channel 1" and "Channel 2" .... 107

Liquid Data - Unit Temperature  
 Transducer Blocks "Channel 1" and "Channel 2" .... 107

Low flow cut off  
 Assign ..... 99  
 Off-value ..... 100  
 On-value ..... 100  
 Unit ..... 100

Low Flow Cut Off - Assign  
 Transducer Blocks "Channel 1" and "Channel 2" ..... 99

Low Flow Cut Off - Unit  
 Transducer Blocks "Channel 1" and "Channel 2" .... 100

Low Flow Cut Off - Off-Value  
 Transducer Blocks "Channel 1" and "Channel 2" .... 100

Low Flow Cut Off - On-Value  
 Transducer Blocks "Channel 1" and "Channel 2" .... 100

**M**

Main line  
 100% Value ..... 122  
 100% value (multiplex) ..... 123  
 Assign ..... 122  
 Assign (multiplex) ..... 123  
 Format ..... 123  
 Format (multiplex) ..... 124

Main Line - 100%-Value  
 "Display" Transducer Block ..... 122

Main Line - Assign  
 "Display" Transducer Block ..... 122

Main Line - Format  
 "Display" Transducer Block ..... 123

Main Line Multiplex - 100%-Value  
 "Display" Transducer Block ..... 123

Main Line Multiplex - Assign  
 "Display" Transducer Block ..... 123

Main Line Multiplex - Format  
 "Display" Transducer Block ..... 124

Main values (calculated) ..... 120

Measurement method ..... 108

Mode  
 Totalizer 1 to 3 ..... 135

**O**

Operating hours ..... 117

Operation - Test Display  
 "Display" Transducer Block ..... 121

Operation mode

AI function block ..... 140

DO function block ..... 146

Resource Block ..... 88

Transducer Block ..... 94

**P**

Parameter  
 Discrete Output function block ..... 148  
 Resource Block ..... 90

Path length ..... 112

Pipe  
 Circumference ..... 104  
 Diameter ..... 104  
 Liner material ..... 105  
 Material ..... 103  
 Nominal diameter ..... 102  
 Sound velocity ..... 104  
 Standard ..... 102  
 Wall thickness ..... 105

Pipe Data - Circumference  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Liner Material  
 Transducer Blocks "Channel 1" and "Channel 2" .... 105

Pipe Data - Liner Thickness  
 Transducer Blocks "Channel 1" and "Channel 2" .... 106

Pipe Data - Nominal Diameter  
 Transducer Blocks "Channel 1" and "Channel 2" .... 102

Pipe Data - Pipe Diameter  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Pipe Material  
 Transducer Blocks "Channel 1" and "Channel 2" .... 103

Pipe Data - Pipe Standard  
 Transducer Blocks "Channel 1" and "Channel 2" .... 102

Pipe Data - Reference Value  
 Transducer Blocks "Channel 1" and "Channel 2" .... 103

Pipe Data - Sound Velocity Liner  
 Transducer Blocks "Channel 1" and "Channel 2" .... 105

Pipe Data - Sound Velocity Pipe  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Unit Circumference  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Unit Liner Thickness  
 Transducer Blocks "Channel 1" and "Channel 2" .... 106

Pipe Data - Unit Nominal Diameter  
 Transducer Blocks "Channel 1" and "Channel 2" .... 102

Pipe Data - Unit Pipe Diameter  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Unit Reference Value  
 Transducer Blocks "Channel 1" and "Channel 2" .... 103

Pipe Data - Unit Sound Velocity Pipe  
 Transducer Blocks "Channel 1" and "Channel 2" .... 104

Pipe Data - Unit Wall Thickness  
 Transducer Blocks "Channel 1" and "Channel 2" .... 105

Pipe Data - Wall Thickness  
 Transducer Blocks "Channel 1" and "Channel 2" .... 105

Positive zero return ..... 99

Pressure shock suppression ..... 100, 101

Process - Pressure Shock Suppression  
 Transducer Blocks "Channel 1" and "Channel 2" 100, 101

Process variable assignment			
AI function block	.....	140	
Production number			
Amplifier	.....	90	
I/O Module	.....	90	
<b>R</b>			
Reference value	.....	103	
Rescaling the input value (AI funct. block)	.....	142	
Reset			
All totalizers	.....	136	
System	.....	116	
Totalizer 1 to 3	.....	135	
Resource Block	.....	88	
Resource block block status	.....	88	
Revision number			
Amplifier hardware	.....	90	
Amplifier software	.....	90	
<b>S</b>			
Selecting units			
Volume flow	.....	97	
Sensor			
Arc length	.....	111	
Cable length	.....	110	
Configuration	.....	110	
Distance	.....	111	
Path length	.....	112	
Position	.....	110	
Serial number	.....	90	
Type (selection)	.....	109	
Wire length	.....	111	
Sensor - Serial Number			
Resource Block	.....	90	
Sensor installation direction	.....	98	
Sensor Param. - ARC Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	111	
Sensor Param. - Cable Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	110	
Sensor Param. - Measurement			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	108	
Sensor Param. - Path Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	112	
Sensor Param. - Position Sensor			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	110	
Sensor Param. - Sensor Configuration			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	110	
Sensor Param. - Sensor Distance			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	111	
Sensor Param. - Sensor Type			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	109	
Sensor Param. - Unit ARC Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	112	
Sensor Param. - Unit Path Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	112	
Sensor Param. - Unit Sensor Distance			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	111	
Sensor Param. - Unit Wire Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	111	
Sensor Param. - Wire Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	111	
Sensor, installation direction	.....	98	
Serial number sensor	.....	90	
Signal processing			
AI function block	.....	138	
DO function block	.....	145	
Transducer Block	.....	92	
Simulation			
AI function block	.....	142	
Error	.....	116	
Measured variable	.....	114	
Resource Block	.....	89	
Value measured variable	.....	114	
Simulation - Measurand			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	114	
Simulation - Unit			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	114	
Simulation - Value Measurand			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	114	
System - Alarm Delay			
"Diagnosis" Transducer Block	.....	116	
System - Operation Time			
"Diagnosis" Transducer Block	.....	117	
System - Reset			
"Diagnosis" Transducer Block	.....	116	
System - Simulation Failsafe Mode			
"Diagnosis" Transducer Block	.....	116	
System - Troubleshooting			
"Diagnosis" Transducer Block	.....	117	
System condition			
Actual	.....	115	
Previous	.....	115	
System Param. - Adjust Zeropoint			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	99	
System Param. - Flow Damping			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	99	
System Param. - Installation Direction Sensor			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Param. -Positive Zero Return			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	99	
System Unit - Flow Velocity			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Unit - Length			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Unit - Sound Velocity			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	97	
System Unit - Viscosity			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Unit Temperature			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Unit Volume Flow			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	97	
System Value - Flow Velocity			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Value - Signal Strength			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	98	
System Value - Sound Velocity			
Transducer Blocks "Channel 1" and "Channel 2"	... ..	97	

System Value Volume Flow		"Totalizer" Transducer Block	133
Transducer Blocks "Channel 1" and "Channel 2"	96	Un-/Locking - Access Status	
<b>T</b>		"Diagnosis" Transducer Block	115
T-DAT		"Display" Transducer Block	118
Amplifier software revision number	90	"Totalizer" Transducer Block	133
Loading/saving data	117	Un-/Locking - Define Private Code	
Save/load (data back-up, e.g. for replacing devices)	21	"Display" Transducer Block	119
T-DAT - Save/Load		Unit (display)	
"Diagnosis" Transducer Block	117	Arc length	112
Test display	121	Deviation arc length	113
Tot. 1 to 3 - Assign		Deviation path length	113
"Totalizer" Transducer Block	135	Deviation sensor distance	113
Tot. 1 to 3 - Mode		Liner material thickness	106
"Totalizer" Transducer Block	135	Max. sound velocity (liquid)	108
Tot. 1 to 3 - Sum		Min. sound velocity (liquid)	107
"Totalizer" Transducer Block	134, 135	Nominal diameter	102
Totalizer 1 to 3		Path length	112
Assign	135	Pipe circumference	104
Display value	134	Pipe diameter	104
Mode	135	Reference value	103
Reset	135	Sensor distance	111
Unit	134	Simulation measurand	114
Totalizer Handling		Sound velocity (liquid)	107
Reset All	136	Sound velocity (pipe)	104
Totalizer Handling - Failsafe All		Temperature (liquid)	107
"Totalizer" Transducer Block	136	Wall thickness (pipe)	105
Transducer		Wire length	111
Block	91	Unit (selection)	
Transducer Block		Flow velocity	98
"Diagnosis" Transducer Block	115	Length	98
Transducer Blocks	91	Sound velocity	97
Alarm detection, processing	95	Temperature	98
Diagnostics (error messages)	95	Totalizer 1 to 3	134
E+H parameters	96	Viscosity	98
FOUNDATION Fieldbus parameters	96	Units	
Transducer Blocks "Channel 1" and "Channel 2"	96	AI function block	141
Troubleshooting (EEPROM)	117	<b>W</b>	
Type of linearization		Wire length	111
AI function block	140	Write protection and simulation	89
<b>U</b>		<b>Z</b>	
Un-/Locking - Access Code		Zero point	112
"Diagnosis" Transducer Block	115	Zero point adjustment	99
"Display" Transducer Block	118		





[www.endress.com/worldwide](http://www.endress.com/worldwide)

---

**Endress + Hauser**   
People for Process Automation

---