

Description of Device Parameters

Proline Prowirl 200

FOUNDATION Fieldbus

Vortex flowmeter




Table of contents

1 Document information	4	3.10.8 "Simulation" submenu	288
1.1 Document function	4		
1.2 Target group	4		
1.3 Using this document	4		
1.3.1 Information on the document structure	4		
1.3.2 Structure of a parameter description	6		
1.4 Symbols used	6		
1.4.1 Symbols for certain types of information	6		
1.4.2 Symbols in graphics	7		
2 Overview of the Expert operating menu	8		
3 Description of device parameters ...	11		
3.1 "System" submenu	14		
3.1.1 "Display" submenu	14		
3.1.2 "Configuration backup display" submenu	27		
3.1.3 "Diagnostic handling" submenu	30		
3.1.4 "Administration" submenu	50		
3.2 "Sensor" submenu	55		
3.2.1 "Measured values" submenu	56		
3.2.2 "System units" submenu	69		
3.2.3 "Process parameters" submenu	82		
3.2.4 "Measurement mode" submenu	85		
3.2.5 "External compensation" submenu	112		
3.2.6 "Sensor adjustment" submenu	117		
3.2.7 "Calibration" submenu	119		
3.3 "Output" submenu	120		
3.3.1 "Pulse/frequency/switch output" submenu	120		
3.4 "Communication" submenu	139		
3.4.1 "Resource block" submenu	140		
3.5 "Analog inputs" submenu	161		
3.5.1 "Analog input 1 to 4" submenu	161		
3.6 "Discrete inputs" submenu	210		
3.6.1 "Discrete input 1 to 2" submenu	211		
3.7 "Analog outputs" submenu	239		
3.7.1 "Multiple analog output" submenu	239		
3.8 "Discrete outputs" submenu	247		
3.8.1 "Multiple discrete output" submenu	248		
3.9 "Application" submenu	256		
3.9.1 "Totalizer 1 to 3" submenu	257		
3.10 "Diagnostics" submenu	262		
3.10.1 "Diagnostic list" submenu	265		
3.10.2 "Event logbook" submenu	268		
3.10.3 "Device information" submenu	271		
3.10.4 "Sensor information" submenu	275		
3.10.5 "Data logging" submenu	275		
3.10.6 "Min/max values" submenu	281		
3.10.7 "Heartbeat" submenu	287		
4 Country-specific factory settings ..	294		
4.1 SI units	294		
4.1.1 System units	294		
4.1.2 Full scale values	294		
4.1.3 Pulse value	295		
4.2 US units	296		
4.2.1 System units	296		
4.2.2 Full scale values	296		
4.2.3 Pulse value	297		
5 Explanation of abbreviated units ..	298		
5.1 SI units	298		
5.2 US units	299		
5.3 Imperial units	300		
5.4 Other units	301		
Index	302		

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document


1.3.1 Information on the document structure

The document lists the submenus and their parameters according to the structure from the **Expert** menu (→  8).



 1 *Sample graphic*

 For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→  262), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code)  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Options	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	User interface value/data for parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics


Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 11
Locking status (0004)	→ 12
Access status display (0091)	→ 12
Enter access code (0092)	→ 14
System	→ 14
▶ Display	→ 14
▶ Configuration backup display	→ 27
▶ Diagnostic handling	→ 30
▶ Administration	→ 50
Sensor	→ 55
▶ Measured values	→ 56
▶ System units	→ 69
▶ Process parameters	→ 82
▶ Measurement mode	→ 85
▶ External compensation	→ 112
▶ Sensor adjustment	→ 117
▶ Calibration	→ 119
Output	→ 120
▶ Pulse/frequency/switch output	→ 120

▶ Communication	→ 139
Device address (11061)	→ 139
▶ Resource block	→ 140
▶ Analog inputs	→ 161
▶ Analog input 1 to 4	→ 161
▶ Discrete inputs	→ 210
▶ Discrete input 1 to 2	→ 211
▶ Analog outputs	→ 239
▶ Multiple analog output	→ 239
▶ Discrete outputs	→ 247
▶ Multiple discrete output	→ 248
▶ Application	→ 256
Reset all totalizers (2806)	→ 257
▶ Totalizer 1 to 3	→ 257
▶ Diagnostics	→ 262
Actual diagnostics (0691)	→ 262
Previous diagnostics (0690)	→ 263
Operating time from restart (0653)	→ 264
Operating time (0652)	→ 264
▶ Diagnostic list	→ 265
▶ Event logbook	→ 268
▶ Device information	→ 271
▶ Sensor information	→ 275
▶ Data logging	→ 275
▶ Min/max values	→ 281



3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

 Expert	
Direct access (0106)	→  11
Locking status (0004)	→  12
Access status display (0091)	→  12
Enter access code (0092)	→  14
▶ System	→  14
▶ Sensor	→  55
▶ Output	→  120
▶ Communication	→  139
▶ Analog inputs	→  161
▶ Discrete inputs	→  210
▶ Analog outputs	→  239
▶ Discrete outputs	→  247
▶ Application	→  256
▶ Diagnostics	→  262

Direct access



Navigation

 Expert → Direct access (0106)

Description

Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears in the navigation view on the right in the header of the selected parameter.

User entry

0 to 65 535

Additional information*User entry*

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1



- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Enter 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Enter 0914-3 → **Assign process variable** parameter

Locking status

Navigation

Expert → Locking status (0004)

Description

Use this function to view the active write protection.

User interface

- Hardware locked
- Temporarily locked

Additional information*User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display.

In the operating tool all active types of write protection are selected.



- If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→ 12).

"Hardware locked" option (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).



Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

"Temporarily locked" option (priority 2)

Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status display

Navigation

Expert → Access stat.disp (0091)

Prerequisite

A local display is provided.

Description

Use this function to view the access authorization to the parameters via the local display.

User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the Enter access code parameter (→  14).</p> <p> For information on the Enter access code parameter (→  14), see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12).</p>
	<p><i>User interface</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Access status tooling

Navigation	 Expert → Access stat.tool (0005)
Description	Use this function to view the access authorization to the parameters via the operating tool.
User interface	<ul style="list-style-type: none"> ▪ Operator ▪ Maintenance
Factory setting	Maintenance
Additional information	<p><i>Description</i></p> <p> The access authorization can be modified via the Enter access code parameter (→  14).</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12).</p>
	<p><i>Display</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p>

Enter access code**Navigation** Expert → Ent. access code (0092)**Description**

Use this function to enter the user-specific release code to remove parameter write protection on the local display.

User entry

0 to 9 999

Enter access code**Navigation** Expert → Ent. access code (0003)**Description**

Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.

User entry

0 to 9 999

3.1 "System" submenu

Navigation  Expert → System

 System	
 Display	→  14
 Configuration backup display	→  27
 Diagnostic handling	→  30
 Administration	→  50

3.1.1 "Display" submenu

Navigation  Expert → System → Display

 Display	
Language (0104)	→  15
Format display (0098)	→  16
Value 1 display (0107)	→  18

0% bargraph value 1 (0123)	→ 18
100% bargraph value 1 (0125)	→ 19
Decimal places 1 (0095)	→ 19
Value 2 display (0108)	→ 20
Decimal places 2 (0117)	→ 20
Value 3 display (0110)	→ 21
0% bargraph value 3 (0124)	→ 21
100% bargraph value 3 (0126)	→ 22
Decimal places 3 (0118)	→ 22
Value 4 display (0109)	→ 22
Decimal places 4 (0119)	→ 23
Display interval (0096)	→ 23
Display damping (0094)	→ 24
Header (0097)	→ 24
Header text (0112)	→ 25
Separator (0101)	→ 25
Contrast display (0105)	→ 26
Backlight (0111)	→ 26
Access status display (0091)	→ 26

Language

Navigation

Expert → System → Display → Language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English *
- Deutsch *
- Français *
- Español *
- Italiano
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- Bahasa Indonesia *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting

English (alternatively, the ordered language is preset in the device)

Format display**Navigation**

 Expert → System → Display → Format display (0098)

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→  18)...**Value 4 display** parameter (→  22) parameters are used to specify which measured values are shown on the display and in which order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured using the **Display interval** parameter (→  23) parameter.

Possible measured values shown on the local display:


* Visibility depends on order options or device settings

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option



A0016530


"2 values" option



A0016531


■ 3

"1 value large + 2 values" option



A0016532

"4 values" option



A0016533

Value 1 display

Navigation	Expert → System → Display → Value 1 display (0107)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	<ul style="list-style-type: none">▪ Volume flow▪ Corrected volume flow▪ Mass flow▪ Flow velocity▪ Temperature▪ Calculated saturated steam pressure *▪ Steam quality *▪ Total mass flow *▪ Condensate mass flow *▪ Energy flow *▪ Heat flow difference *▪ Reynolds number *▪ Density *▪ Totalizer 1▪ Totalizer 2▪ Totalizer 3
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

0% bargraph value 1

Navigation	Expert → System → Display → 0% bargraph 1 (0123)
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number

* Visibility depends on order options or device settings

Factory setting	Country-specific: ■ 0 m ³ /h ■ 0 ft ³ /h
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

100% bargraph value 1



Navigation	  Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 294
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

Decimal places 1



Navigation	  Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is specified in the Value 1 display parameter (→ 18).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none"> ■ X ■ X.X ■ X.XX ■ X.XXX ■ X.XXXX
Factory setting	X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display (0108)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

Picklist, see **Value 1 display** parameter (→ 18)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ 69).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2 (0117)

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display (0110)
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist, see Value 1 display parameter (→ 18)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

0% bargraph value 3

Navigation	Expert → System → Display → 0% bargraph 3 (0124)
Prerequisite	A selection has been made in the Value 3 display parameter (→ 21).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: ■ 0 m ³ /h ■ 0 ft ³ /h
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

100% bargraph value 3



Navigation

Expert → System → Display → 100% bargraph 3 (0126)

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 21).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information

Description

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 69).

Decimal places 3



Navigation

Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 21).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information

Description

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display



Navigation

Expert → System → Display → Value 4 display (0109)

Prerequisite

A local display is provided.

Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist, see Value 1 display parameter (→ 18)
Factory setting	None
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 69).</p>

Decimal places 4



Navigation	 Expert → System → Display → Decimal places 4 (0119)
Prerequisite	A measured value is specified in the Value 4 display parameter (→ 22).
Description	Use this function to select the number of decimal places for measured value 4.
Selection	<ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX
Factory setting	x.xx
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Display interval

Navigation	 Expert → System → Display → Display interval (0096)
Prerequisite	A local display is provided.
Description	Use this function to enter the length of time the measured values are displayed if the values alternate on the display.
User entry	1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 18)...**Value 4 display** parameter (→ 22) are used to specify which measured values are shown on the display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Display damping



Navigation Expert → System → Display → Display damping (0094)

Prerequisite A local display is provided.

Description Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 5.0 s

Additional information *User entry*

A time constant is entered:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

Header



Navigation Expert → System → Display → Header (0097)

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.


Selection

- Device tag
- Free text

Factory setting Device tag

Additional information *Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 271).
- Free text
Is defined in the **Header text** parameter (→ 25).

Header text**Navigation**

Expert → System → Display → Header text (0112)

Prerequisite
 The **Free text** option is selected in the **Header** parameter (→ 24).
Description

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator**Navigation**

Expert → System → Display → Separator (0101)

Prerequisite

A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation  Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 80 %

Factory setting Depends on the display

Additional information Set the contrast via the push-buttons:

- Brighter: Press and hold down the   

Backlight

Navigation  Expert → System → Display → Backlight (0111)

Prerequisite Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"

Description Option for switching the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting Disable

Access status display

Navigation  Expert → System → Display → Access stat.disp (0091)

Prerequisite A local display is provided.

Description Use this function to view the access authorization to the parameters via the local display.

User interface	■ Operator ■ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <ul style="list-style-type: none">  The access authorization can be modified via the Enter access code parameter (→  14).  For information on the Enter access code parameter (→  14), see the "Disabling write protection via access code" section of the Operating Instructions for the device  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  12). <p><i>User interface</i></p> <ul style="list-style-type: none">  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1.2 "Configuration backup display" submenu

Navigation

  Expert → System → Conf.backup disp

► Configuration backup display	
Operating time (0652)	→  27
Last backup (0102)	→  28
Configuration management (0100)	→  28
Comparison result (0103)	→  29

Operating time

Navigation

  Expert → System → Conf.backup disp → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

The maximum number of days is 9999, which is equivalent to 27 years.

Last backup

Navigation	  Expert → System → Conf.backup disp → Last backup (0102)
Prerequisite	A local display is provided.
Description	Use this function to display the time since a backup copy of the data was last saved to the display module.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Configuration management



Navigation	  Expert → System → Conf.backup disp → Config. managem. (0100)
Prerequisite	A local display is provided.
Description	Use this function to select an action to save the data to the display module.
Selection	<ul style="list-style-type: none">■ Cancel■ Execute backup■ Restore■ Duplicate■ Compare■ Clear backup data■ Display incompatible
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p>Configuration via the local display is disabled while the action is performed.</p> <p> For information on the status message in the operating tool, see: Backup state parameter (→  29)</p> <p><i>Selection</i></p> <ul style="list-style-type: none">■ Cancel<ul style="list-style-type: none">No action is executed and the user exits the parameter.■ Execute backup<ul style="list-style-type: none">- A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.- The following message appears on local display: Backup active, please wait!■ Restore<ul style="list-style-type: none">- The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device.- The following message appears on local display: Restore active! Do not interrupt power supply!

- Duplicate
 - The transmitter configuration from another device is duplicated to the device using the display module.
 - The following message appears on local display: Copy active! Do not interrupt power supply!
 - Compare
 - The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
 - The following message appears on local display: Comparing files
 - The result can be viewed in **Comparison result** parameter (→ 29).
 - Clear backup data
 - The backup copy of the device configuration is deleted from the display module of the device.
 - The following message appears on local display: Deleting file
 - Display incompatible
 - This option is displayed if the display module is incompatible. All of the other options are not available. Selection is therefore not possible.
 - This option is displayed if it is not possible to save the device and fieldbus data.
 - The display module should be updated to the latest software version so that the data can be saved.
- i** For information on updating the display module to the latest software version, please contact your Endress+Hauser service organization.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state

Navigation  Expert → System → Conf.backup disp → Backup state (0121)

Prerequisite A local display is provided.

Description Use this function to view the status of the data backup process.

User interface

- None
- Store in progress
- Restore in progress
- Import in progress
- Delete in progress
- Compare in progress

Factory setting None

Comparison result

Navigation   Expert → System → Conf.backup disp → Compar. result (0103)

Prerequisite A local display is provided.

Description Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.

- User interface**
- Settings identical
 - Settings not identical
 - No backup available
 - Backup settings corrupt
 - Check not done
 - Dataset incompatible

Factory setting Check not done

Additional information *Description*

 The comparison is started via the **Compare** option in the **Configuration management** parameter (→ 28).

Selection

- Settings identical
 - The current device configuration of the HistoROM is identical to the backup copy in the display module.
 - If the transmitter configuration of another device has been copied to the device via the display module and the **Duplicate** option in the **Configuration management** parameter (→ 28), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical.
- Settings not identical

The current device configuration of the HistoROM is not identical to the backup copy in the display module.
- No backup available

There is no backup copy of the device configuration of the HistoROM in the display module.
- Backup settings corrupt

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.
- Check not done

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.
- Dataset incompatible

The backup copy in the display module is not compatible with the device.


HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagnostic handling" submenu

Navigation

Expert → System → Diagn. handling



► Diagnostic behavior	→ 32
► Diagnostic limits	→ 48

Alarm delay



Navigation

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry 0 to 60 s

Factory setting 0 s

Additional information

Description

This setting affects the following diagnostic messages:

- 046 Sensor limit exceeded
- 828 Ambient temperature too low
- 829 Ambient temperature too high
- 832 Electronic temperature too high
- 833 Electronic temperature too low
- 834 Process temperature too high
- 835 Process temperature too low
- 841 Flow velocity too high
- 841 Sensor range
- 844 Sensor range exceeded
- 870 Measuring inaccuracy increased
- 871 Near steam saturation limit
- 872 Wet steam detected
- 873 No steam detected
- 874 Wet steam detection uncertain
- 945 Sensor range exceeded
- 946 Vibration detected
- 947 Vibration exceeded

"Diagnostic behavior" submenu

 For a list of all the diagnostic events, see the Operating Instructions for the device.

 Modifying the diagnostic behavior of a diagnostic event. Each diagnostic event is assigned a certain diagnostic behavior at the factory. The user can change this assignment for certain diagnostics events.

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

- **Off** option

The diagnostic event is ignored; it is neither entered into the Event logbook, nor is a diagnostic message generated.

- **Alarm** option

The device continues to measure. The signal outputs assume the defined alarm condition. A diagnostic message is generated.

- **Warning** option

The device continues to measure. A diagnostic message is generated.

- **Logbook entry only** option

The device continues to measure. The diagnostic message is entered in the **Event logbook** submenu (→ 268) (**Event list** submenu (→ 270)) only and is not displayed in alternation with the measured value display.

 Assignment of the status of a diagnostic event.

The following options are available in the **Assign status of diagnostic no. xxx** parameters:

- **Bad**

The status of the input value (PV) is Bad.

- **Uncertain**

The status of the input value (PV) is Uncertain.

- **Good**

The status of the input value (PV) is Good.

Navigation

 Expert → System → Diagn. handling → Diagn. behavior

 Diagnostic behavior

Assign behavior of diagnostic no. 022 (0751)	→  34
Assign behavior of diagnostic no. 122 (0752)	→  35
Assign behavior of diagnostic no. 350 (0756)	→  35
Assign behavior of diagnostic no. 371 (0757)	→  36
Assign behavior of diagnostic no. 442 (0658)	→  36
Assign behavior of diagnostic no. 443 (0659)	→  36
Assign behavior of diagnostic no. 828 (0755)	→  37

Assign behavior of diagnostic no. 829 (0754)	→ 37
Assign behavior of diagnostic no. 832 (0675)	→ 37
Assign behavior of diagnostic no. 833 (0676)	→ 38
Assign behavior of diagnostic no. 834 (0677)	→ 38
Assign behavior of diagnostic no. 835 (0678)	→ 39
Assign behavior of diagnostic no. 841 (0729)	→ 39
Assign behavior of diagnostic no. 844 (0747)	→ 39
Assign behavior of diagnostic no. 870 (0726)	→ 40
Assign behavior of diagnostic no. 871 (0748)	→ 40
Assign behavior of diagnostic no. 872 (0746)	→ 40
Assign behavior of diagnostic no. 873 (0749)	→ 41
Assign behavior of diagnostic no. 945 (0750)	→ 41
Assign behavior of diagnostic no. 947 (0753)	→ 42
Assign status of diagnostic number 022 (11041)	→ 42
Assign status of diagnostic number 122 (11042)	→ 42
Assign status of diagnostic number 350 (11000)	→ 43
Assign status of diagnostic number 371 (11014)	→ 43
Assign status of diagnostic number 828 (11015)	→ 43

Assign status of diagnostic number 829 (11001)	→ 44
Assign status of diagnostic number 832 (11002)	→ 44
Assign status of diagnostic number 833 (11003)	→ 44
Assign status of diagnostic number 834 (11004)	→ 45
Assign status of diagnostic number 835 (11005)	→ 45
Assign status of diagnostic number 841 (11006)	→ 45
Assign status of diagnostic number 844 (11007)	→ 46
Assign status of diagnostic number 870 (11008)	→ 46
Assign status of diagnostic number 871 (11009)	→ 46
Assign status of diagnostic number 872 (11010)	→ 47
Assign status of diagnostic number 873 (11011)	→ 47
Assign status of diagnostic number 945 (11012)	→ 47
Assign status of diagnostic number 947 (11013)	→ 48

Assign behavior of diagnostic no. 022 (Temperature sensor defective)



Navigation

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 022 (0751)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Use this function to change the diagnostic behavior of the diagnostic message **022 Temperature sensor defective**.

Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Alarm
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 122 (Temperature sensor defective)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 122 (0752)
Prerequisite	For the following order code: "Sensor version", option "Mass flow"
Description	Use this function to change the diagnostic behavior of the diagnostic message 122 Temperature sensor defective .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 350 (Pre-amplifier defective)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 350 (0756)
Description	Use this function to change the diagnostic behavior of the diagnostic message 350 Pre-amplifier defective .
Selection	<ul style="list-style-type: none">■ Off■ Alarm■ Warning■ Logbook entry only
Factory setting	Alarm
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 371 (Temperature sensor defective)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 371 (0757)

Description

Use this function to change the diagnostic behavior of the diagnostic message **371 Temperature sensor defective**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 442 (Frequency output)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the diagnostic message **442 Frequency output**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 443 (Pulse output)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Use this function to change the diagnostic behavior of the diagnostic message **443 Pulse output**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 828 (Ambient temperature too low)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 828 (0755)

Description Use this function to change the diagnostic behavior of the diagnostic message **828 Ambient temperature too low**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 829 (Ambient temperature too high)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 829 (0754)

Description Use this function to change the diagnostic behavior of the diagnostic message **829 Ambient temperature too high**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting Warning

Additional information  For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 832 (Electronic temperature too high)

Navigation  Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

Description Use this function to change the diagnostic behavior of the diagnostic message **832 Electronic temperature too high**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 833 (Electronic temperature too low)**Navigation** Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)**Description**

Use this function to change the diagnostic behavior of the diagnostic message
833 Electronic temperature too low.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 834 (Process temperature too high)**Navigation** Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)**Description**

Use this function to change the diagnostic behavior of the diagnostic message **834 Process temperature too high.**

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 835 (Process temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)
Description	Use this function to change the diagnostic behavior of the diagnostic message 835 Process temperature too low .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 841 (Flow velocity too high)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 841 (0729)
Description	Use this function to change the diagnostic behavior of the diagnostic message 841 Flow velocity too high .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 844 (Sensor range exceeded)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 844 (0747)
Description	Use this function to change the diagnostic behavior of the diagnostic message 844 Sensor range exceeded .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 870 (Measuring inaccuracy increased)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 870 (0726)

Description

Use this function to change the diagnostic behavior of the diagnostic message **870 Measuring inaccuracy increased**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 871 (Near steam saturation limit)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 871 (0748)

Prerequisite

In the **Select medium** parameter (→ [85](#)), the **Steam** option is selected.

Description

Use this function to change the diagnostic behavior of the diagnostic message **871 Near steam saturation limit**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available for selection: → [32](#)

Assign behavior of diagnostic no. 872 (Wet steam detected)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 872 (0746)

Prerequisite

The **Wet steam detection** application package has been enabled.

The software options currently enabled are displayed in the **Software option overview** parameter (→ [54](#)).

Description

Use this function to change the diagnostic behavior of the diagnostic message **872 Wet steam detected**.

Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 873 (Water detected)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 873 (0749)
Prerequisite	In the Select medium parameter (→ 85), the Steam option is selected.
Description	Use this function to change the diagnostic behavior of the diagnostic message 873 Water detected .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Off
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 945 (Sensor range exceeded)



Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 945 (0750)
Prerequisite	For the following order code: "Sensor version", option "Mass flow"
Description	Use this function to change the diagnostic behavior of the diagnostic message 945 Sensor range exceeded .
Selection	<ul style="list-style-type: none"> ■ Off ■ Alarm ■ Warning ■ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available for selection: → 32

Assign behavior of diagnostic no. 947 (Vibration exceeded)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 947 (0753)

Description

Use this function to change the diagnostic behavior of the diagnostic message **947 Vibration exceeded**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Alarm

Additional information

For a detailed description of the options available for selection: → [32](#)

Assign status of diagnostic number 022 (Temperature sensor defective)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Status diag. 022 (11041)

Description

Option for changing the status of the diagnostic message **022 Temperature sensor defective**.

Selection

- Bad
- Uncertain
- Good

Factory setting

Bad

Additional information

Detailed description of the options available for selection: → [32](#)

Assign status of diagnostic number 122 (Temperature sensor defective)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Status diag. 122 (11042)

Description

Option for changing the status of the diagnostic message **122 Temperature sensor defective**.

Selection

- Bad
- Uncertain
- Good

Factory setting

Good

Additional information

Detailed description of the options available for selection: → [32](#)

Assign status of diagnostic number 350 (Pre-amplifier defective)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 350 (11000)
Description	Option for changing the status of the diagnostic message 350 Pre-amplifier defective .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Bad
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 371 (Temperature sensor defective)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 371 (11014)
Description	Option for changing the status of the diagnostic message 371 Temperature sensor defective .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Bad
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 828 (Ambient temperature too low)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 828 (11015)
Description	Option for changing the status of the diagnostic message 828 Ambient temperature too low .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 829 (Ambient temperature too high)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 829 (11001)
Description	Option for changing the status of the diagnostic message 829 Ambient temperature too high.
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 832 (Electronic temperature too high)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 832 (11002)
Description	Option for changing the status of the diagnostic message 832 Electronic temperature too high.
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 833 (Electronic temperature too low)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 833 (11003)
Description	Option for changing the status of the diagnostic message 833 Electronic temperature too low.
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 834 (Process temperature too high)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 834 (11004)
Description	Option for changing the status of the diagnostic message 834 Process temperature too high .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 835 (Process temperature too low)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 835 (11005)
Description	Option for changing the status of the diagnostic message 835 Process temperature too low .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 841 (Flow velocity too high)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 841 (11006)
Description	Option for changing the status of the diagnostic message 841 Flow velocity too high .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 844 (Sensor range exceeded)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 844 (11007)
Description	Option for changing the status of the diagnostic message 844 Sensor range exceeded .
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 870 (Measuring inaccuracy increased)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 870 (11008)
Description	Option for changing the status of the diagnostic message 870 Measuring inaccuracy increased .
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 871 (Near steam saturation limit)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 871 (11009)
Description	Option for changing the status of the diagnostic message 871 Near steam saturation limit .
Selection	<ul style="list-style-type: none">▪ Bad▪ Uncertain▪ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: → 32

Assign status of diagnostic number 872 (Wet steam detected)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 872 (11010)
Description	Option for changing the status of the diagnostic message 872 Wet steam detected .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: →  32

Assign status of diagnostic number 873 (No steam detected)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 873 (11011)
Description	Option for changing the status of the diagnostic message 873 No steam detected .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: →  32

Assign status of diagnostic number 945 (Sensor range exceeded)


Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Status diag. 945 (11012)
Description	Option for changing the status of the diagnostic message 945 Sensor range exceeded .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Uncertain
Additional information	 Detailed description of the options available for selection: →  32

Assign status of diagnostic number 947 (Vibration exceeded)

Navigation	  Expert → System → Diagn. handling → Diagn. behavior → Status diag. 947 (11013)
Description	Option for changing the status of the diagnostic message 947 Vibration exceeded .
Selection	<ul style="list-style-type: none">■ Bad■ Uncertain■ Good
Factory setting	Bad
Additional information	 Detailed description of the options available for selection: →  32

"Diagnostic limits" submenu

Navigation   Expert → System → Diagn. handling → Diagn. limits



Reynolds number limit

Navigation   Expert → System → Diagn. handling → Diagn. limits → Re number limit (7646)

Prerequisite For the following order code:
"Sensor version", option "Mass flow (integrated temperature measurement)"

Description Use this function to enter the lower limit value for the Reynolds number. If the Reynolds number falls short of this limit value, the diagnostic message **870 Measuring inaccuracy increased** is triggered.

User entry 4 000 to 100 000

Factory setting 5 000

Additional information *Limit value*

 If the Reynolds number falls short of the limit value configured here, the diagnostic behavior selected in the **Assign behavior of diagnostic no. 870** parameter (→  40) is triggered.

Steam quality limit

Navigation Expert → System → Diagn. handling → Diagn. limits → SteamQualLimit (7717)

Prerequisite The following conditions are met:
 ■ In the **Select medium** parameter (→ 85), the **Steam** option is selected.
 ■ In the **Steam quality** parameter (→ 116), the **Calculated value** option is selected.

Description Use this function to enter the threshold value for the steam quality which, if undershot, triggers the diagnostic message **△S872 Wet steam detected**.

User entry 80 to 100 %

Factory setting 80 %

Additional information *Limit value*

This limit value has a hysteresis of 5 %, i.e. the diagnostic message is reset at a threshold value of +5 % or if 100 % is reached (for factory setting of 80 % at 85 %).

If the steam quality has dropped below the limit value configured here, the diagnostic behavior selected in the **Assign behavior of diagnostic no. 872** parameter (0746) (→ 40) is triggered.

Degrees of superheat limit

Navigation Expert → System → Diagn. handling → Diagn. limits → Degr.superh.lim. (7737)

Prerequisite In the **Select medium** parameter (→ 85), the **Steam** option is selected.

Description Use this function to enter the threshold value for the degree of superheat which, if exceeded, triggers the diagnostic message **972 Degrees of superheat limit exceeded**.

User entry 0 to 500 K

Factory setting 5 K


Additional information *Limit value*

This limit value has a hysteresis of 1 K, i.e. the diagnostic message is triggered if the threshold value +1 K is reached and is reset again when the value drops below the threshold value.

If the degree of superheat has exceeded the limit value configured here, the diagnostic behavior selected in the **Assign behavior of diagnostic no. 972** parameter is triggered.

3.1.4 "Administration" submenu


Navigation

 Expert → System → Administration


"Define access code" wizard

i The **Define access code** wizard is only available if operating using the local display. If you are operating using the operating tool, the **Define access code** parameter (→ 51) is directly in the **Administration** submenu. The **Confirm access code** parameter is not available if you are operating using the operating tool.

Navigation

 Expert → System → Administration → Def. access code


Define access code



Navigation

 Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol. On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  14).

 If you lose the access code, please contact your Endress+Hauser Sales Center.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code**Navigation**

 Expert → System → Administration → Def. access code → Confirm code

Description

Enter the defined release code a second time to confirm the release code.

User entry

0 to 9 999

Factory setting

0

Further parameters in the "Administration" submenu**Define access code****Navigation**

 Expert → System → Administration → Def. access code (0093)

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

User entry

0 to 9 999

Factory setting

0

Additional information*Description*

The write protection affects all parameters in the document marked with the  symbol.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  14).

 If you lose the access code, please contact your Endress+Hauser Sales Center.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Restart

Navigation

  Expert → System → Administration → Restart (10800)

Description

Use this function to select a manual restart or a manual device reset.

Selection

- Uninitialized
- Run
- Resource
- Defaults
- Processor
- To factory defaults
- To delivery settings
- ENP restart
- To transducer defaults
- Factory Default Blocks

Factory setting

Uninitialized

Additional information*"Uninitialized" option*

The selection does not affect configuration.

"Run" option

The selection does not affect configuration.

"Resource" option

The selection does not affect configuration.

"Defaults" option

All fieldbus function blocks are reset to their factory setting (e.g. Analog input channel to the **Uninitialized** option).

"Processor" option

The device is restarted.

"To factory defaults" option

Advanced fieldbus parameters (fieldbus function blocks, schedule information) and device parameters are reset to their factory setting.

"To delivery settings" option

Advanced fieldbus parameters (fieldbus function blocks, schedule information) and device parameters for which a customer-specific default setting was ordered are reset to this customer-specific value.

"ENP restart" option

The parameters of the electronic name plate (ENP = Electronic Name Plate) to be entered are adopted. The device is restarted.

"To transducer defaults" option

Certain (measured-value specific) device parameters are reset. The parameters of the fieldbus function blocks remain unchanged.

"Factory Default Blocks" option

Advanced fieldbus parameters (fieldbus function blocks, schedule information) are reset to their factory setting.

Activate SW option**Navigation**

Expert → System → Administration → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

0

Additional information*User entry*

Endress+Hauser provides the corresponding activation code for the software option with the order.

NOTICE! This activation code varies depending on the measuring device and the software option. If an incorrect or invalid code is entered, this can result in the loss of software options that are already been activated. After commissioning the measuring device: in this parameter only enter activation codes which Endress+Hauser has provided (e.g. when a new software option was ordered). If an incorrect or invalid activation code is entered, enter the activation code from the parameter protocol again and contact your Endress+Hauser sales organization, quoting the serial number of your device.

Example for a software option

Order code for "Application package", option EA "Extended HistoROM"

Software option overview

Navigation  Expert → System → Administration → SW option overv. (0015)

Description Displays all the software options that are enabled in the device.

User interface

- Extended HistoROM
- Mass flow
- Natural gas
- Air + industrial gas
- Wet steam detection
- Heartbeat Verification

Additional information *Description*
Displays all the options that are available if ordered by the customer.

"Extended HistoROM" option

Order code for "Application package", option EA "Extended HistoROM"

"Mass flow" option

Order code for "Sensor version"

- For Prowirl D, F, R: option 3 "Mass flow (integrated temperature measurement)"
- For Prowirl C, O: option 6 "Mass flow Alloy 718"

"Natural gas" option

Order code for "Application package", option EN "Natural gas"

"Air + industrial gas" option

Order code for "Application package", option ET "Air+industrial gases (single gas+gas mixtures)"

"Wet steam detection" option

 Only available for Prowirl F.

Order code for "Application package", option ES "Wet steam detection"

"Heartbeat Verification" option

Order code for "Application package", option EB "Heartbeat Verification"

Activate sensor emergency mode



Navigation  Expert → System → Administration → Sens. emerg.mode (7712)

Prerequisite The device has identified an error during verification of the characteristics in the sensor data storage or electronics module. A diagnostic message of status type **XF** is output.

Description Use this function to switch on the emergency mode of the sensor to use the backup of the sensor characteristics or main electronics characteristics stored in the HistoROM.

Selection	<ul style="list-style-type: none"> ▪ Cancel ▪ Ok
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p> This parameter becomes visible if the data in the S-DAT or on-board memory cannot be read on account of a defect or error. There is a copy of the data on the HistoROM (FT10). If the emergency mode is activated, this copy is used and the device measure correctly again at least up until the next device switch-off/switch-on. After switch-on/switch-off, the emergency mode would have to be reactivated again. This ensures that the client can operate the device until a new spare part arrives.</p> <p>The status signal of the output diagnostic message changes from F (failure) to M (maintenance required), the diagnostic behavior changes from Alarm to Warning: ΔM. The diagnostic message is output until the characteristics in the sensor data storage are again correct.</p> <p> Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the -button.</p> <p> Information on status signals and diagnostic behavior: Operating Instructions about the device, "Diagnostic message" chapter</p>

3.2 "Sensor" submenu

Navigation

  Expert → Sensor

 Sensor	
 Measured values	→  56
 System units	→  69
 Process parameters	→  82
 Measurement mode	→  85
 External compensation	→  112
 Sensor adjustment	→  117
 Calibration	→  119

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

► Measured values	
► Process variables	→ 56
► Totalizer	→ 66
► Output values	→ 67

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

► Process variables	
Volume flow (1838)	→ 57
Corrected volume flow (1850)	→ 57
Mass flow (1847)	→ 58
Flow velocity (1865)	→ 59
Temperature (1851)	→ 59
Calculated saturated steam pressure (1852)	→ 60
Steam quality (1853)	→ 60
Total mass flow (1854)	→ 60
Condensate mass flow (1857)	→ 61
Energy flow (1872)	→ 61
Heat flow difference (1863)	→ 61
Reynolds number (1864)	→ 62
Density (7607)	→ 62
Pressure (7696)	→ 63
Saturation temperature (7709)	→ 63

Compressibility factor (7729)	→ 64
Vortex frequency (7722)	→ 64

Volume flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Volume flow (1838)
Description	Use this function to view the volume flow currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	The unit is taken from the Volume flow unit parameter (→ 70)

Corrected volume flow

Navigation	Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1850)
Description	Displays the corrected volume flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Description</i>
	To calculate the corrected volume flow, the measured volume flow is multiplied by the ratio of the density (Density parameter (→ 62)) to the reference density. The density and reference density here depend on the sensor version and the selected medium (see table). Outputting the corrected volume flow cannot be used for gases that condense (e.g. steam).

Sensor version	Medium	Medium type	Density	Reference density
Volume flow	All ¹⁾	–	ρ	ρ_{Ref}
Mass flow	Steam	–	$f(p, T)$	–
	Gas	All except ²⁾	$f(p, T)$	$f(p_{\text{Ref}}, T_{\text{Ref}})$
	Liquid	All except ²⁾	$f(T)$	$f(T_{\text{Ref}})$
	Gas	²⁾	$f(p, T, z, \rho_{\text{Ref}}, T_{\text{Ref}}, z_{\text{Ref}}, \rho_{\text{Ref}})$	ρ_{Ref}

Sensor version	Medium	Medium type	Density	Reference density
	Liquid	2)	$f(T, a_{lin}, T_{Ref}, \rho_{Ref})$	ρ_{Ref}
ρ			Fixed density (→ 114)	
ρ_{Ref}			Reference density (→ 94)	
p			Pressure (→ 63)	
p_{Ref}			Reference pressure (→ 95)	
T			Temperature (→ 59)	
T_{Ref}			Reference temperature (→ 96)	
z			Z-factor (→ 94)	
z_{Ref}			Reference Z-factor (→ 96)	
a_{lin}			Linear expansion coefficient (→ 91)	
$f(\dots)$			Calculation method as function of ...	

1) Outputting the corrected volume flow cannot be used for gases that condense.

2) User-specific gas or liquid

Dependency

 The unit is taken from the **Corrected volume flow unit** parameter (→ 73)

Mass flow

Navigation

 Expert → Sensor → Measured val. → Process variab. → Mass flow (1847)

Description

Displays the mass flow currently calculated.

User interface

Signed floating-point number

Additional information

Description

To calculate the mass flow, the measured volume flow is multiplied by the density (**Density** parameter (→ 62)). The density depends on the sensor version and the selected medium (see table).

Sensor version	Medium	Medium type	Density
Volume flow	All	–	ρ
Mass flow	Steam	–	$f(p, T)$
	Gas	All except ¹⁾	$f(p, T)$
	Liquid	All except ¹⁾	$f(T)$
	Gas	¹⁾	$f(p, T, z, p_{Ref}, T_{Ref}, z_{Ref}, \rho_{Ref})$
	Liquid	¹⁾	$f(T, a_{lin}, T_{Ref}, \rho_{Ref})$
ρ			Fixed density (→ 114)
ρ_{Ref}			Reference density (→ 94)
p			Pressure (→ 63)
p_{Ref}			Reference pressure (→ 95)
T			Temperature (→ 59)
T_{Ref}			Reference temperature (→ 96)
z			Z-factor (→ 94)
z_{Ref}			Reference Z-factor (→ 96)
a_{lin}			Linear expansion coefficient (→ 91)
$f(\dots)$			Calculation method as function of ...

1) User-specific gas or liquid

Dependency

 The unit is taken from the **Mass flow unit** parameter (→ 72)

Flow velocity


Navigation  Expert → Sensor → Measured val. → Process variab. → Flow velocity (1865)

Description Displays the flow velocity currently calculated.

User interface Signed floating-point number

Additional information *Description*

The flow velocity is calculated based on the aspect ratio of the vortex measuring tube (DS) to the process connection of the sensor (DI), or to the **Mating pipe diameter** parameter (→ 118) (DM) if this has been entered by the customer; the DS and DI are production data that are defined by the shape and size of the meter body.



A0025829

- 1 Process connection
- 2 Vortex measuring tube
- DM Mating pipe diameter (→ 118)
- DI Process connection of the sensor
- DS Vortex measuring tube

Dependency

 The unit is taken from the **Velocity unit** parameter (→ 79)

Temperature

Navigation  Expert → Sensor → Measured val. → Process variab. → Temperature (1851)

Description Displays the temperature currently measured.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ 75).

Calculated saturated steam pressure

Navigation	 Expert → Sensor → Measured val. → Process variab. → CalcSatSteamPres (1852)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">▪ Order code for "Sensor version", option "Mass flow"▪ In the Select medium parameter (→  85), the Steam option is selected.
Description	Displays the saturated steam pressure currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Pressure unit parameter (→  74)

Steam quality

Navigation	 Expert → Sensor → Measured val. → Process variab. → Steam quality (1853)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">▪ Order code for "Sensor version", option "Mass flow"▪ In the Select medium parameter (→  85), the Steam option is selected.
Description	Displays the current steam quality. Depends on the compensation mode of the steam quality (Steam quality parameter (→  116))).
User interface	Signed floating-point number

Total mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Total mass flow (1854)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">▪ Order code for "Application package", option EU "Wet steam measurement"▪ In the Select medium parameter (→  85), the Steam option is selected.
Description	Displays the total mass flow (steam and condensate) currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→  72)

Condensate mass flow

Navigation	  Expert → Sensor → Measured val. → Process variab. → CondensMassFlow (1857)
Prerequisite	The following conditions are met: ■ Order code for "Application package", option EU "Wet steam measurement" ■ In the Select medium parameter (→  85), the Steam option is selected.
Description	Displays the condensate mass flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Mass flow unit parameter (→  72)

Energy flow

Navigation	  Expert → Sensor → Measured val. → Process variab. → Energy flow (1872)
Prerequisite	For the following order code: "Sensor version", option "Mass flow"
Description	Displays the energy flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Energy flow unit parameter (→  76)

Heat flow difference

Navigation	  Expert → Sensor → Measured val. → Process variab. → Heat flow diff. (1863)
Prerequisite	The following conditions are met: Order code for "Sensor version", option "Mass flow" One of the following options is selected in the Select gas type parameter (→  86): ■ Single gas ■ Gas mixture ■ Natural gas ■ User-specific gas
Description	Displays the heat flow difference currently calculated.
User interface	Signed floating-point number

Additional information*Description*

The measuring device requires the following to calculate the heat flow difference correctly:

1. Select the type of calculation in the **Delta heat calculation** parameter (→ [114](#)).
2. Enter the value in the **2nd temperature delta heat** parameter (→ [115](#)).

Dependency

 The unit is taken from the **Energy flow unit** parameter (→ [76](#))

Reynolds number**Navigation**

 Expert → Sensor → Measured val. → Process variab. → Reynolds number (1864)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Displays the Reynolds number currently calculated.

User interface

Signed floating-point number

Additional information*Description*

$$Re = \frac{\rho \cdot v \cdot d}{\eta}$$

Where:

- ρ is the density of the medium (**Density** parameter (→ [62](#)))
- v is the flow velocity of the fluid in relation to the body (**Flow velocity** parameter (→ [59](#)))
- d is the characteristic length of the body
- η is the viscosity of the medium
 - For gases: **Dynamic viscosity** parameter (→ [93](#))
 - For liquids: **Dynamic viscosity** parameter (→ [92](#))
- The mating pipe diameter is taken as the characteristic length (**Mating pipe diameter** parameter (→ [118](#)))

Density**Navigation**

 Expert → Sensor → Measured val. → Process variab. → Density (7607)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Displays the density currently calculated.

User interface

Positive floating-point number

Additional information*Description*

Depending on the selected medium the density is calculated with pressure and temperature and the corresponding method (e.g. IAPWS, NEL40...).

Dependency

 The unit is taken from the **Density unit** parameter (→ 79)

Pressure**Navigation**

 Expert → Sensor → Measured val. → Process variab. → Pressure (7696)

Prerequisite

For the following order code:

- "Sensor version", option "Mass flow"
- In the **External value** parameter (→ 113), the **Pressure** option is selected.

Description

Displays the current process pressure.

User interface

0 to 250 bar

Additional information*Description*

The value of the pressure which is read in (e.g. via the current input module) is displayed..

If the **Pressure** option is not selected as the external value in the **External value** parameter (→ 113), the input value for the fixed process pressure (**Fixed process pressure** parameter (→ 115)) is displayed.

Dependency

 The unit is taken from the **Pressure unit** parameter (→ 74)

Saturation temperature**Navigation**

 Expert → Sensor → Measured val. → Process variab. → Saturation temp. (7709)

Prerequisite

In the **Select medium** parameter (→ 85), the **Steam** option is selected.

Description

Displays the saturation temperature currently calculated.

User interface

Country-specific:

- °C
- °F

Additional information

The saturation temperature describes the temperature limit at which steam begins to condense. This value is calculated using the current process pressure (**Pressure** parameter (→ 63)) according to IAPWS-IF97.

Dependency

 The unit is taken from the **Temperature unit** parameter (→ 75).

Compressibility factor

Navigation

  Expert → Sensor → Measured val. → Process variab. → CompressFactor (7729)

Prerequisite

The following conditions are met:

Order code for "Sensor version", option "Mass flow"

In the **Select medium** parameter (→  85), the **Gas** option or **Steam** option is selected.

Description

Displays the compressibility factor currently calculated.

User interface

0 to 2

Additional information

Description

The compressibility factor describes the deviation of the medium from the ideal behavior under the current process conditions. If the medium is a user-specific gas/liquid, the compressibility factor is entered as the Z-factor (**Z-factor** parameter (→  94)).

Vortex frequency

Navigation

  Expert → Sensor → Measured val. → Process variab. → Vortex frequency (7722)

Description

Displays the measured variable for the flow in the measuring tube which is recorded directly with the DSC sensor.

User interface

Measuring range depending on the nominal diameter:

0.1 to 3 100 Hz

Additional information

Description

The filter settings specify the measuring range of the vortex frequency depending on the nominal diameter.

Filter settings for liquids

Nominal diameter	Minimum vortex frequency	Maximum vortex frequency
	f_{vmin} [Hz]	f_{vmax} [Hz]
DN 15 (½") DN 25 (1") > DN 15 (½") DN 40 (1½") >> DN 15 (½")	11.5	666.5
DN 25 (1") DN 40 (1½") > DN 25 (1") DN 50 (2") >> DN 25 (1")	6.7	388.8
DN 40 (1½") DN 50 (2") > DN 40 (1½") DN 80 (3") >> DN 40 (1½")	3.9	224.3
DN 50 (2") DN 80 (3") > DN 50 (2") DN 100 (4") >> DN 50 (2")	3.0	172.8
DN 80 (3") DN 100 (4") > DN 80 (3") DN 150 (6") >> DN 80 (3")	2.1	122.8

Nominal diameter	Minimum vortex frequency	Maximum vortex frequency
	f_{vmin} [Hz]	f_{vmax} [Hz]
DN 100 (4") DN150 (6") > DN 100 (4") DN 200 (8") >> DN 100 (4")	1.7	101.4
DN150 (6") DN 200 (8") > DN150 (6") DN 250 (10") >> DN150 (6")	1.1	66.6
DN 200 (8")	0.7	41.7
DN 250 (10")	0.6	34.3
DN 300 (12")	0.5	28.9


Filter settings for gases/steam

DN [mm (in)]	Minimum vortex frequency	Maximum vortex frequency
	f_{vmin} [Hz]	f_{vmax} [Hz]
DN 15 (½") DN 25 (1") > DN 15 (½") DN 40 (1½") >> DN 15 (½")	209.9	3 100
DN 25 (1") DN 40 (1½") > DN 25 (1") DN 50 (2") >> DN 25 (1")	67.1	3 100
DN 40 (1½") DN 50 (2") > DN 40 (1½") DN 80 (3") >> DN 40 (1½")	13.7	1 869.1
DN 50 (2") DN 80 (3") > DN 50 (2") DN 100 (4") >> DN 50 (2")	10.5	2 303.8
DN 80 (3") DN 100 (4") > DN 80 (3") DN150 (6") >> DN 80 (3")	7.5	1 636.9
DN 100 (4") DN150 (6") > DN 100 (4") DN 200 (8") >> DN 100 (4")	6.2	1 352.3
DN150 (6") DN 200 (8") > DN150 (6") DN 250 (10") >> DN150 (6")	4.1	888.6
DN 200 (8")	2.5	555.4
DN 250 (10")	2.1	457.3
DN 300 (12")	1.8	385.3

Totalizer

Navigation

Expert → Sensor → Measured val. → Totalizer



Totalizer value 1 to 3



Navigation

Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3 (0911-1 to 3)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 257) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information

Description

As it is only possible to display a maximum of 7 digits, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow 1 to 3** parameter if the display range is exceeded.

i In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 261).

User interface

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 258).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 1 · 10⁶ (1 overflow) = 1 000 000 [m³]
- Current totalizer reading: 1 196 845.7 m³

* Visibility depends on order options or device settings

Totalizer overflow 1 to 3**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow 1 to 3 (0910-1 to 3)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [257](#)) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current reading has more than 7 digits, which is the maximum value range that can be displayed, the value above this range is given as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value 1 to 3** parameter.

User interface

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [258](#)).


Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range:

- Value in the **Totalizer value 1** parameter: 196 845.7 m³
- Value in the **Totalizer overflow 1** parameter: 2 · 10⁶ (2 overflows) = 2 000 000 [m³]
- Current totalizer reading: 2 196 845.7 m³

"Output values" submenu*Navigation*

Expert → Sensor → Measured val. → Output values



* Visibility depends on order options or device settings

Output frequency (0471)	→ 69
Switch status (0461)	→ 69

Terminal voltage 1

Navigation

Expert → Sensor → Measured val. → Output values → Terminal volt. 1 (0662)

Description

Use this function to view the actual terminal voltage that is present at the current output.

User interface

0.0 to 50.0 V

Pulse output

Navigation

Expert → Sensor → Measured val. → Output values → Pulse output (0456)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ [121](#)).

Description

Displays the pulse frequency currently output.


User interface

Positive floating-point number

Additional information

Description

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ [124](#)) and the **Pulse width** parameter (→ [124](#)) can be used to define the value (i.e. the amount of the measured value that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive
 1 Conductive
 NC NC contact (normally closed)
 NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 138), i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→ 125)) can be configured.

Output frequency

Navigation	Expert → Sensor → Measured val. → Output values → Output freq. (0471)
Prerequisite	In the Operating mode parameter (→ 121), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0 to 1 250 Hz

Switch status

Navigation	Expert → Sensor → Measured val. → Output values → Switch status (0461)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 121).
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation Expert → Sensor → System units

▶ System units	
Volume flow unit (0553)	→ 70
Volume unit (0563)	→ 72
Mass flow unit (0554)	→ 72

Mass unit (0574)	→ 73
Corrected volume flow unit (0558)	→ 73
Corrected volume unit (0575)	→ 74
Pressure unit (0564)	→ 74
Temperature unit (0557)	→ 75
Energy flow unit (0565)	→ 76
Energy unit (0559)	→ 77
Calorific value unit (0552)	→ 77
Calorific value unit (0606)	→ 78
Velocity unit (0566)	→ 79
Density unit (0555)	→ 79
Dynamic viscosity unit (0577)	→ 80
Specific heat capacity unit (0604)	→ 80
Length unit (0551)	→ 81
Date/time format (2812)	→ 81

Volume flow unit**Navigation**

Expert → Sensor → System units → Volume flow unit (0553)

Description

Use this function to select the unit for the volume flow.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ cm ³ /s	■ af/s	■ gal/s (imp)
	■ cm ³ /min	■ af/min	■ gal/min (imp)
	■ cm ³ /h	■ af/h	■ gal/h (imp)
	■ cm ³ /d	■ af/d	■ gal/d (imp)
	■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)
	■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)
	■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)
	■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)
	■ m ³ /s	■ fl oz/s (us)	■ bbl/s (imp;beer)
	■ m ³ /min	■ fl oz/min (us)	■ bbl/min (imp;beer)
	■ m ³ /h	■ fl oz/h (us)	■ bbl/h (imp;beer)
	■ m ³ /d	■ fl oz/d (us)	■ bbl/d (imp;beer)
	■ ml/s	■ gal/s (us)	■ bbl/s (imp;oil)
	■ ml/min	■ gal/min (us)	■ bbl/min (imp;oil)
	■ ml/h	■ gal/h (us)	■ bbl/h (imp;oil)
	■ ml/d	■ gal/d (us)	■ bbl/d (imp;oil)
	■ l/s	■ kgal/s (us)	
	■ l/min	■ kgal/min (us)	
	■ l/h	■ kgal/h (us)	
	■ l/d	■ kgal/d (us)	
	■ hl/s	■ Mgal/s (us)	
	■ hl/min	■ Mgal/min (us)	
	■ hl/h	■ Mgal/h (us)	
	■ hl/d	■ Mgal/d (us)	
	■ Ml/s	■ bbl/s (us;liq.)	
	■ Ml/min	■ bbl/min (us;liq.)	
	■ Ml/h	■ bbl/h (us;liq.)	
	■ Ml/d	■ bbl/d (us;liq.)	
		■ bbl/s (us;beer)	
		■ bbl/min (us;beer)	
		■ bbl/h (us;beer)	
		■ bbl/d (us;beer)	
		■ bbl/s (us;oil)	
		■ bbl/min (us;oil)	
		■ bbl/h (us;oil)	
		■ bbl/d (us;oil)	
		■ bbl/s (us;tank)	
		■ bbl/min (us;tank)	
		■ bbl/h (us;tank)	
		■ bbl/d (us;tank)	
Factory setting	Country-specific:		
	■ m ³ /h		
	■ ft ³ /min		
Additional information	<i>Result</i>		
	The selected unit applies for: Volume flow parameter (→  57)		
	<i>Selection</i>		
	 For an explanation of the abbreviated units: →  298		

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit (0563)

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- ft³

Additional information*Selection*

For an explanation of the abbreviated units: → 298

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Factory setting

Country-specific:

- kg/h
- lb/min

Additional information*Result*

The selected unit applies for:

- **Mass flow** parameter (→ 58)
- **Total mass flow** parameter (→ 60)
- **Condensate mass flow** parameter (→ 61)

Selection

For an explanation of the abbreviated units: → 298

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

For an explanation of the abbreviated units: → 298

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection*SI units*

- NL/s
- NL/min
- NL/h
- NL/d
- Nm³/s
- Nm³/min
- Nm³/h
- Nm³/d
- Sm³/s
- Sm³/min
- Sm³/h
- Sm³/d

US units

- Sft³/s
- Sft³/min
- Sft³/h
- Sft³/d

Factory setting

Country-specific:

- Nm³/h
- Sft³/h

Additional information*Result*

The selected unit applies for:

Corrected volume flow parameter (→ 57)*Selection*

For an explanation of the abbreviated units: → 298

Corrected volume unit**Navigation**

Expert → Sensor → System units → Corr. vol. unit (0575)

Description

Use this function to select the unit for the corrected volume.

Selection*SI units*

- NL
- Nm³
- Sm³

*US units*Sft³**Factory setting**

Country-specific:

- Nm³
- Sft³

Additional information*Selection*

For an explanation of the abbreviated units: → 298

Pressure unit**Navigation**

Expert → Sensor → System units → Pressure unit (0564)

Prerequisite

For the following order code:

"Sensor version", option "Mass flow"

Description

Use this function to select the unit for the pipe pressure.

Selection	<i>SI units</i>	<i>US units</i>	<i>Other units</i>
	<ul style="list-style-type: none"> ■ Pa ■ kPa ■ MPa ■ mbar a ■ bar ■ torr ■ atm ■ gf/cm² ■ kgf/cm² 	psi	<ul style="list-style-type: none"> ■ mmH2O (4°C) ■ mmH2O (68°F) ■ mmHg (0°C) ■ inH2O (4°C) ■ inH2O (68°F) ■ ftH2O (68°F) ■ inHg (0°C)
Factory setting	Country-specific:		
	<ul style="list-style-type: none"> ■ bar ■ psi 		

Additional information*Result*

The unit is taken from:

- Calculated saturated steam pressure parameter (→ 60)
- Atmospheric pressure parameter (→ 113)
- Maximum value parameter (→ 287)
- Fixed process pressure parameter (→ 115)
- Pressure parameter (→ 63)
- Reference pressure parameter (→ 95)

Selection

 For an explanation of the abbreviated units: → 298

Temperature unit**Navigation**

Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
<ul style="list-style-type: none"> ■ °C ■ K 	<ul style="list-style-type: none"> ■ °F ■ °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Result*

The selected unit applies for:

- Temperature parameter (→ 59)
- Maximum value parameter (→ 284)
- Minimum value parameter (→ 284)
- Average value parameter (→ 284)
- Maximum value parameter (→ 285)
- Minimum value parameter (→ 285)
- Maximum value parameter (→ 286)
- Minimum value parameter (→ 286)

- **2nd temperature delta heat** parameter (→ [115](#))
- **Fixed temperature** parameter (→ [114](#))
- **Reference combustion temperature** parameter (→ [94](#))
- **Reference temperature** parameter (→ [96](#))
- **Saturation temperature** parameter (→ [63](#))

Selection

 For an explanation of the abbreviated units: → [298](#)

Energy flow unit



Navigation

 Expert → Sensor → System units → Energy flow unit (0565)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Use this function to select the unit for the energy flow.

Selection

<i>SI units</i>	<i>Imperial units</i>
■ kW	■ Btu/s
■ MW	■ Btu/min
■ GW	■ Btu/h
■ kJ/s	■ Btu/day
■ kJ/min	■ MBtu/s
■ kJ/h	■ MBtu/min
■ kJ/d	■ MBtu/h
■ MJ/s	■ MBtu/d
■ MJ/h	■ MMBtu/s
■ MJ/min	■ MMBtu/min
■ MJ/d	■ MMBtu/h
■ GJ/s	■ MMBtu/d
■ GJ/min	
■ GJ/h	
■ GJ/d	
■ kcal/s	
■ kcal/min	
■ kcal/h	
■ kcal/d	
■ Mcal/s	
■ Mcal/min	
■ Mcal/h	
■ Mcal/d	
■ Gcal/s	
■ Gcal/min	
■ Gcal/h	
■ Gcal/d	

Factory setting

Country-specific:

- kW
- Btu/h

Additional information*Result*

The selected unit applies for:

- **Heat flow difference** parameter (→ 61)
- **Energy flow** parameter (→ 61)

Selection

 For an explanation of the abbreviated units: → 298

Energy unit**Navigation**

Expert → Sensor → System units → Energy unit (0559)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Use this function to select the unit for energy.

Selection*SI units*

- kWh
- MWh
- GWh
- kJ
- MJ
- GJ
- kcal
- Mcal
- Gcal

Imperial units

- Btu
- MBtu
- MMBtu

Factory setting

Country-specific:

- kWh
- Btu

Additional information*Selection*

 For an explanation of the abbreviated units: → 298

Calorific value unit**Navigation**

Expert → Sensor → System units → Cal. value unit (0552)

Prerequisite

The following conditions are met:

- Order code for "Sensor version", option "Mass flow"
- The **Gross calorific value volume** option or the **Net calorific value volume** option is selected in the **Calorific value type** parameter (→ 90).

Description

Use this function to select the unit for the calorific value.

Selection

- SI units*
- kJ/Nm³
 - MJ/Nm³
 - kWh/Nm³
 - MWh/m³
 - kJ/m³
 - MJ/m³
 - kWh/m³
 - MWh/m³

- Imperial units*
- Btu/Sm³
 - MBtu/Sm³
 - Btu/Sft³
 - MBtu/Sft³

Factory setting

Country-specific:

- kJ/Nm³
- Btu/Sft³

Additional information*Result*

The selected unit applies for:

Reference gross calorific value parameter (→ 95)

Selection
 For an explanation of the abbreviated units: → 298
Calorific value unit (Mass)**Navigation**
 Expert → Sensor → System units → Cal. value unit (0606)
Prerequisite

The following conditions are met:

- Order code for "Sensor version", option "Mass flow"
- The **Gross calorific value mass** option or the **Net calorific value mass** option is selected in the **Calorific value type** parameter (→ 90).

Description

Use this function to select the unit for the calorific value (mass).

Selection

- SI units*
- kJ/kg
 - MJ/kg
 - kWh/kg
 - MWh/kg

- US units*
- kJ/lb
 - MJ/lb
 - kWh/lb
 - MWh/lb

- Imperial units*
- Btu/lb
 - MBtu/lb

Factory setting

Country-specific:

- kJ/kg
- Btu/lb

Additional information*Selection*
 For an explanation of the abbreviated units: → 298

Velocity unit**Navigation**

Expert → Sensor → System units → Velocity unit (0566)

Description

Use this function to select the unit for the flow velocity.

Selection*SI units*

m/s

US units

ft/s

Factory setting

Country-specific:

- m/s
- ft/s

Additional information*Result*

The selected unit applies for:

- **Flow velocity** parameter (→ 59)
- **Maximum value** parameter (→ 287)

Selection

For an explanation of the abbreviated units: → 298

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- kg/dm³
- kg/l
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/m³
- lb/ft³

Additional information*Result*

The selected unit applies for:

- **Density** parameter (→ 62)
- **Fixed density** parameter (→ 114)
- **Reference density** parameter (→ 94)

Selection

- SD = specific density
The specific density is the ratio of the fluid density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).
- SG = specific gravity
The specific gravity is the ratio of the fluid density to the water density at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

 For an explanation of the abbreviated units: → [298](#)

Dynamic viscosity unit

**Navigation**

 Expert → Sensor → System units → Dyn. visc. unit (0577)

Description

Use this function to select the unit for dynamic viscosity.

Selection*SI units*

- Pa s
- cP
- P

Factory setting

Pa s

Additional information*Result*

The selected unit applies for:

- **Dynamic viscosity** parameter (→ [93](#)) (gases)
- **Dynamic viscosity** parameter (→ [92](#)) (liquids)

Additional information*Selection*

 For an explanation of the abbreviated units: → [298](#)

Specific heat capacity unit

**Navigation**

 Expert → Sensor → System units → SpecHeatCapaUnit (0604)

Prerequisite

The following conditions are met:

- Selected medium:
 - The **User-specific gas** option is selected in the **Select gas type** parameter (→ [86](#)).
Or
 - The **User-specific liquid** option is selected in the **Select liquid type** parameter (→ [87](#)).
- The **Heat** option is selected in the **Enthalpy type** parameter (→ [90](#)).

Description

Use this function to select the unit for the specific heat capacity.

Selection	<i>SI units</i> ■ kJ/(kgK) ■ MJ/(kgK) ■ kWh/(kgK) ■ kcal/(kgK)	<i>Imperial units</i> Btu/(lb°R)
Factory setting	kJ/(kgK)	
Additional information	<i>Result</i> The selected unit applies for: Specific heat capacity parameter (→ 97)	
Additional information	<i>Selection</i>  For an explanation of the abbreviated units: → 298	

Length unit

Navigation	 Expert → Sensor → System units → Length unit (0551)	
Description	Use this function to select the unit of length for the nominal diameter.	
Selection	<i>SI units</i> ■ mm ■ m	<i>US units</i> ■ in ■ ft
Factory setting	Country-specific: ■ mm ■ in	
Additional information	<i>Result</i> The selected unit applies for: ■ Inlet run parameter (→ 117) ■ Mating pipe diameter parameter (→ 118) <i>Selection</i>  For an explanation of the abbreviated units: → 298	

Date/time format

Navigation	 Expert → Sensor → System units → Date/time format (2812)
Description	Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm


Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

 For an explanation of the abbreviated units: → [298](#)

3.2.3 "Process parameters" submenu

Navigation
  Expert → Sensor → Process param.
**Flow override***Navigation*
  Expert → Sensor → Process param. → Flow override (1839)
Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning process of a pipeline, for example.

Selection

- Off
- On

Factory setting

Off

Additional information*Result*

 This setting affects all the functions and outputs of the measuring device.

*Description***Flow override is active**

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: Proceeding output
 - Totalizers 1-3: Stop being totalized

Flow damping**Navigation**

Expert → Sensor → Process param. → Flow damping (1802)

Description

Use this function to enter flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 5 s

Additional information *Result*

The damping has an effect on the following variables of the device:


- Outputs
- Low flow cut off → 83
- Totalizer → 256

User entry

- Value = 0: no damping
- Value > 0: damping is increased

"Low flow cut off" submenu**Navigation**

Expert → Sensor → Process param. → Low flow cut off

**Assign process variable****Navigation**

Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

Description

Use this function to select a process variable for low flow cut off.

Selection	<ul style="list-style-type: none">■ Off■ Volume flow■ Corrected volume flow■ Mass flow■ Reynolds number *
------------------	---

Factory setting	Off
------------------------	-----

On value low flow cutoff 

Navigation  Expert → Sensor → Process param. → Low flow cut off → On value (1805)

Prerequisite	One of the following options is selected in the Assign process variable parameter (→  83): <ul style="list-style-type: none">■ Volume flow■ Corrected volume flow■ Mass flow■ Reynolds number *
---------------------	--

Description Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 →  84.

User entry Positive floating-point number

Factory setting 0

Additional information *Dependency*

 The unit depends on the process variable selected in the **Assign process variable** parameter (→  83).

Off value low flow cutoff 

Navigation  Expert → Sensor → Process param. → Low flow cut off → Off value (1804)


Prerequisite	One of the following options is selected in the Assign process variable parameter (→  83): <ul style="list-style-type: none">■ Volume flow■ Corrected volume flow■ Mass flow■ Reynolds number *
---------------------	--

Description Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value →  84.

User entry 0 to 100.0 %

Factory setting 50 %

* Visibility depends on order options or device settings

Additional information*Example*

A0012887

- Q Flow
 t Time
 H Hysteresis
 A Low flow cut off active
 1 Low flow cut off is activated
 2 Low flow cut off is deactivated
 3 On value entered
 4 Off value entered

3.2.4 "Measurement mode" submenu*Navigation*

Expert → Sensor → Measurement mode

► Measurement mode	
Select medium (7653)	→ 85
Select gas type (7635)	→ 86
Select liquid type (7636)	→ 87
Select steam type (7637)	→ 87
Density calculation (7608)	→ 88
Enthalpy calculation (7619)	→ 88
Saturated steam calculation mode (7708)	→ 89
► Medium properties	

Select medium*Navigation*

Expert → Sensor → Measurement mode → Select medium (7653)

Description

Use this function to select the type of medium for the measuring application.

Selection	<ul style="list-style-type: none"> ▪ Gas ▪ Liquid ▪ Steam
Factory setting	Steam

Select gas type



Navigation Expert → Sensor → Measurement mode → Select gas type (7635)

Prerequisite The following conditions are met:

- Order code
 - "Sensor version", option "Mass flow"
 - "Application package", option "Air + Industrial gases" or option "Natural gas"
- The **Gas** option is selected in the **Select medium** parameter (→ 85).

Description Use this function to select the type of gas for the measuring application.

Selection	<ul style="list-style-type: none"> ▪ Single gas ▪ Gas mixture ▪ Air ▪ Natural gas ▪ User-specific gas
Factory setting	User-specific gas

Additional information *"User-specific gas" option*
 Applications: calculation of the mass flow of a user-specific gas
 Calculated variables: the mass flow, the density, the corrected volume flow and the heat quantity are calculated from the measured volume flow and the measured temperature. Either the specific thermal capacity or the calorific value must be entered for calculating the heat quantity.

Formulae for calculation:

- Mass flow: $m = q \cdot \rho (T)$
- Density: $\rho = \rho_1 (T_1) / (1 + \beta_p \cdot [T - T_1])$
- Corrected volume flow: $v_n = q \cdot (\rho (T) / \rho_{ref})$
- Heat quantity in the case of delta heat: $E = q \cdot \rho (T) \cdot c_p \cdot \Delta T$
- Heat quantity in the case of combustion: $E = q \cdot \rho (T) \cdot h$

m = Mass flow

q = Volume flow (measured)

v_n = Corrected volume flow

T = Process temperature (measured)

T_1 = Temperature (→ 59) at which the value for ρ_1 applies.

ρ = Density

ρ_{ref} = Reference density

β_p = Density (→ 62) at which the value for T_1 applies.

c_p = Linear expansion coefficient (→ 91) of the liquid at T_1

Possible combinations of these values: **Linear expansion coefficient** parameter (→ 91)

Select liquid type

Navigation Expert → Sensor → Measurement mode → Sel. liquid type (7636)

Prerequisite The following conditions are met:

- Order code for "Sensor version", option "Mass flow"
- The **Liquid** option is selected in the **Select medium** parameter (→ 85) parameter.

Description Use this function to select the type of liquid for the measuring application.

Selection

- Water
- LPG (Liquefied Petroleum Gas)
- User-specific liquid

Factory setting Water

Additional information *"User-specific liquid" option*

Applications: calculation of the mass flow of a user-specific liquid, such as thermal oil.

Calculated variables: the mass flow, the density, the corrected volume flow and the heat quantity are calculated from the measured volume flow and the measured temperature. Either the specific thermal capacity or the calorific value must be entered for calculating the heat quantity.

Formulae for calculation:

- Mass flow: $m = q \cdot \rho (T)$
- Density: $\rho = \rho_1 (T_1) / (1 + \beta_p \cdot [T - T_1])$
- Corrected volume flow: $v_n = q \cdot (\rho (T) / \rho_{ref})$
- Heat quantity in the case of delta heat: $E = q \cdot \rho (T) \cdot c_p \cdot \Delta T$
- Heat quantity in the case of combustion: $E = q \cdot \rho (T) \cdot h$

m = Mass flow

q = Volume flow (measured)

v_n = Corrected volume flow

T = Process temperature (measured)

T_1 = Temperature (→ 59) at which the value for ρ_1 applies.

ρ = Density

ρ_{ref} = Reference density

= Density (→ 62) at which the value for T_1 applies.

β_p = Linear expansion coefficient (→ 91) of the liquid at T_1

Possible combinations of these values: **Linear expansion coefficient** parameter (→ 91)

Select steam type

Navigation Expert → Sensor → Measurement mode → Sel. steam type (7637)

Prerequisite The following conditions are met:

- Order code for "Sensor version", option "Mass flow (integrated temperature measurement)"
- In the **Select medium** parameter (→ 85), the **Steam** option is selected.

Description Use this function to select the type of steam for the measuring application.

Selection

- Wet steam
- Superheated steam
- Saturated steam

Factory setting Saturated steam

Density calculation



Navigation Expert → Sensor → Measurement mode → Density calc. (7608)

Prerequisite The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.

Description Use this function to select the standard on the basis of which the density is calculated.

Selection

- AGA Nx19
- ISO 12213- 2
- ISO 12213- 3

Factory setting AGA Nx19

Enthalpy calculation



Navigation Expert → Sensor → Measurement mode → Enthalpy calc. (7619)

Prerequisite The following conditions are met:

- Order code
 - "Sensor version", option "Mass flow (integrated temperature measurement)"
 - "Application package", option "Natural gas"
- In the **Select medium** parameter (→ 85), the **Gas** option is selected and in the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.

Description Use this function to select the standard on the basis of which the enthalpy is calculated.

Selection

- AGA5
- ISO 6976

Factory setting AGA5

Saturated steam calculation mode**Navigation**

Expert → Sensor → Measurement mode → SatSteamCalcMode (7708)

Prerequisite

In the **Select steam type** parameter (→ 87), the **Wet steam** option or **Saturated steam** option is selected.

Description

Use this function to select the calculation method for the saturated steam application.

Selection

- Temperature
- Pressure

Factory setting

Temperature

"Medium properties" submenu*Navigation*

Expert → Sensor → Measurement mode → Medium property

► Medium properties	
Enthalpy type (7620)	→ 90
Calorific value type (7698)	→ 90
Reference combustion temperature (7699)	→ 94
Reference density (7700)	→ 94
Reference gross calorific value (7701)	→ 95
Reference pressure (7702)	→ 95
Reference temperature (7703)	→ 96
Reference Z-factor (7704)	→ 96
Linear expansion coefficient (7621)	→ 91
Relative density (7705)	→ 96
Specific heat capacity (7716)	→ 97
Calorific value (7626)	→ 92
Z-factor (7631)	→ 94

Dynamic viscosity (7733)	→ 92
Dynamic viscosity (7732)	→ 93
► Gas composition	→ 97

Calorific value type



Navigation

Expert → Sensor → Measurement mode → Medium property → Cal. value type (7698)

Prerequisite

The **Calorific value type** parameter (→ 90) is visible.

Description

Use this function to select whether the net calorific value or the gross calorific value is used as the basis for calculation.

Selection

- Gross calorific value volume
- Net calorific value volume
- Gross calorific value mass
- Net calorific value mass

Factory setting

Gross calorific value mass

Enthalpy type



Navigation

Expert → Sensor → Measurement mode → Medium property → Enthalpy type (7620)

Prerequisite

The following conditions are met:

- In the **Select gas type** parameter (→ 86), the **User-specific gas** option is selected.
Or
- In the **Select liquid type** parameter (→ 87), the **User-specific liquid** option is selected.

Description

Use this function to select the type of enthalpy.

Selection

- Heat
- Calorific value

Factory setting

Heat

Linear expansion coefficient**Navigation**

Expert → Sensor → Measurement mode → Medium property → Linear exp coeff (7621)

Prerequisite

The following conditions are met:

- The **Liquid** option is selected in the **Select medium** parameter (→ 85).
- The **User-specific liquid** option is selected in the **Select liquid type** parameter (→ 87).

Description

Use this function to enter the linear, medium-specific expansion coefficient for calculating the reference density for user-specific liquids.

User entry

1.0⁻⁶ to 2.0⁻³

Factory setting

2.06⁻⁴

Additional information

User entry

- If the value in this parameter is changed, it is advisable to reset the totalizer.
- The expansion coefficient can be determined using the Applicator.
- If two density and temperature value pairs are known (density ρ_1 at temperature T_1 and density ρ_2 at temperature T_2), the expansion coefficient can be calculated according to the following formula:

$$\beta_p = ((\rho_1/\rho_2) - 1)/(T_1 - T_2)$$

Sample values

The closer the process temperature is to the specific temperature value, the better the calculation of the density for application-specific liquids. If the process temperature deviates greatly from the value indicated, the expansion coefficient should be calculated according to the formula (see above).

Medium (liquid)	Temperature value [K]	Density value [kg/m ³]	Expansion coefficient [10 ⁻⁴ 1/K]
Air	123.15	594	18.76
Ammonia	298.15	602	25
Argon	133.15	1028	111.3
n-butane	298.15	573	20.7
Carbon dioxide	298.15	713	106.6
Chlorine	298.15	1398	21.9
Cyclohexane	298.15	773	11.6
n-decane	298.15	728	10.2
Ethane	298.15	315	175.3
Ethylene	298.15	386	87.7
n-heptane	298.15	351	12.4
n-hexane	298.15	656	13.8
Hydrogen chloride	298.15	796	70.9
i-butane	298.15	552	22.5
Methane	163.15	331	73.5
Nitrogen	93.15	729	75.3
n-octane	298.15	699	11.1

Medium (liquid)	Temperature value [K]	Density value [kg/m ³]	Expansion coefficient [10 ⁻⁴ 1/K]
Oxygen	133.15	876	95.4
n-pentane	298.15	621	16.2
Propane	298.15	493	32.1
Vinyl chloride	298.15	903	19.3

Table values according to Carl L. Yaws (2001): Matheson Gas Data Book, 7th edition

Calorific value**Navigation**

Expert → Sensor → Measurement mode → Medium property → Calorific value (7626)

Prerequisite

The following conditions are met:

- Selected medium:
 - In the **Select gas type** parameter (→ 86), the **User-specific gas** option is selected.
Or
 - In the **Select liquid type** parameter (→ 87), the **User-specific liquid** option is selected.
- In the **Enthalpy type** parameter (→ 90), the **Calorific value** option is selected.
- In the **Calorific value type** parameter (→ 90), the **Gross calorific value volume** option or **Gross calorific value mass** option is selected.

Description

Use this function to enter the calorific value for calculating the energy flow.

User entry

Positive floating-point number

Factory setting

50000 kJ/kg

Dynamic viscosity (Liquids)**Navigation**

Expert → Sensor → Measurement mode → Medium property → Dynam. viscosity (7733)

Prerequisite

The following conditions are met:

- Order code for "Sensor version", option "Volume flow"
- The **Liquid** option is selected in the **Select medium** parameter (→ 85) parameter.
Or
- The **User-specific liquid** option is selected in the **Select liquid type** parameter (→ 87).

Description

Use this function to enter a fixed value for the dynamic viscosity for a liquid.

User entry

Positive floating-point number

Factory setting

1 cP

Additional information*Description*

The viscosity entered is used to linearize the measured error in the lower Reynolds number range if the calculated viscosity is not available e.g. "Volume flow" sensor version or the fluid is a user-specific liquid (see table).

Dependencies

Sensor version	Medium	Dyn. viscosity
Volume flow	All	x
Mass flow	All except ¹⁾	-
	1)	x
x	Dynamic viscosity as the input value	

1) User-specific liquid

Dependency

 The unit is taken from the **Dynamic viscosity unit** parameter (→ 80)

Dynamic viscosity (Gases)**Navigation**

 Expert → Sensor → Measurement mode → Medium property → Dynam. viscosity (7732)

Prerequisite

The following conditions are met:

- Order code for "Sensor version", option "Volume flow"
- The **Gas** option or the **Steam** option is selected in the **Select medium** parameter (→ 85).
Or
- The **User-specific gas** option is selected in the **Select gas type** parameter (→ 86).

Description

Use this function to enter a fixed value for the dynamic viscosity for a gas or steam.

User entry

Positive floating-point number

Factory setting

0.015 cP

Additional information*Description*

The viscosity entered is used to linearize the measured error in the lower Reynolds number range if the calculated viscosity is not available e.g. "Volume flow" sensor version or the fluid is a user-specific gas (see table).

Dependencies

Sensor version	Medium	Dyn. viscosity
Volume flow	All	x
Mass flow	All except ¹⁾	-
	1)	x
x	Dynamic viscosity as the input value	

1) User-specific gas

Dependency

 The unit is taken from the **Dynamic viscosity unit** parameter (→ 80)

Z-factor

Navigation	 Expert → Sensor → Measurement mode → Medium property → Z-factor (7631)
Prerequisite	In the Select gas type parameter (→ 86), the User-specific gas option is selected.
Description	Use this function to enter the real gas constant Z for gas under operating conditions.
User entry	0.1 to 2.0
Factory setting	1

Reference combustion temperature

Navigation	 Expert → Sensor → Measurement mode → Medium property → Ref. comb. temp. (7699)
Prerequisite	The Reference combustion temperature parameter (→ 94) is visible.
Description	Use this function to enter the reference combustion temperature for calculating the natural gas energy value.
User entry	-200 to 450 °C
Factory setting	20 °C
Additional information	<i>Dependency</i>
	 The unit is taken from the Temperature unit parameter (→ 75)

Reference density

Navigation	 Expert → Sensor → Measurement mode → Medium property → Ref.density (7700)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ In the Select gas type parameter (→ 86), the User-specific gas option is selected. Or■ In the Select liquid type parameter (→ 87), the Water option or User-specific liquid option is selected.
Description	Use this function to enter a fixed value for the reference density.

User entry 0.01 to 15 000 kg/m³

Factory setting 1 000 kg/m³

Additional information *Dependency*



The unit is taken from the **Density unit** parameter (→ 79)

Reference gross calorific value



Navigation Expert → Sensor → Measurement mode → Medium property → Ref. GrossCalVal (7701)

Prerequisite The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ 88), the **ISO 12213- 3** option is selected.

Description Use this function to enter the reference gross calorific value of the natural gas.

User entry Positive floating-point number

Factory setting 50 000 kJ/Nm³

Additional information *Dependency*



The unit is taken from the **Calorific value unit** parameter (→ 77)

Reference pressure



Navigation Expert → Sensor → Measurement mode → Medium property → Ref. pressure (7702)

Prerequisite The following conditions are met:

- Order code for "Sensor version", option "Mass flow (integrated temperature measurement)"
- The **Gas** option is selected in the **Select medium** parameter (→ 85).

Description Use this function to enter the reference pressure for calculating the reference density.

User entry 0 to 250 bar

Factory setting 1.01325 bar

Additional information *Dependency*



The unit is taken from the **Pressure unit** parameter (→ 74)

Reference temperature



Navigation

Expert → Sensor → Measurement mode → Medium property → Ref. temperature (7703)

Prerequisite

The following conditions are met:

- The **Gas** option is selected in the **Select medium** parameter (→ 85).
Or
- The **Liquid** option is selected in the **Select medium** parameter (→ 85).

Description

Use this function to enter the reference temperature for calculating the reference density.

User entry

-200 to 450 °C

Factory setting

20 °C

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ 75)

Reference Z-factor



Navigation

Expert → Sensor → Measurement mode → Medium property → Ref. Z-factor (7704)

Prerequisite

In the **Select gas type** parameter (→ 86), the **User-specific gas** option is selected.

Description

Use this function to enter the real gas constant Z for gas under reference conditions.

User entry

0.1 to 2

Factory setting

1

Relative density



Navigation

Expert → Sensor → Measurement mode → Medium property → Relative density (7705)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ 88), the **ISO 12213- 3** option is selected.

Description

Use this function to enter the relative density of the natural gas.

User entry

0.55 to 0.9

Factory setting

0.664

Specific heat capacity**Navigation**

Expert → Sensor → Measurement mode → Medium property → Spec. heat cap. (7716)

Prerequisite

The following conditions are met:

- Selected medium:
 - In the **Select gas type** parameter (→ [86](#)), the **User-specific gas** option is selected.
Or
 - In the **Select liquid type** parameter (→ [87](#)), the **User-specific liquid** option is selected.
- In the **Enthalpy type** parameter (→ [90](#)), the **Heat** option is selected.

Description

Use this function to enter the specific heat capacity of the medium.

User entry

0 to 50 kJ/(kgK)

Factory setting

4.187 kJ/(kgK)

Additional information

Dependency

The unit is taken from the **Specific heat capacity unit** parameter (→ [80](#))

*"Gas composition" submenu**Navigation*

Expert → Sensor → Measurement mode → Medium property → Gas composition

► Gas composition	
Gas type (7714)	→ 99
Gas mixture (7640)	→ 99
Mol% Ar (7663)	→ 100
Mol% C2H3Cl (7664)	→ 100
Mol% C2H4 (7665)	→ 101
Mol% C2H6 (7666)	→ 101
Mol% C3H8 (7667)	→ 102
Mol% CH4 (7668)	→ 102
Mol% Cl2 (7707)	→ 102

Mol% CO (7669)	→ 103
Mol% CO2 (7670)	→ 103
Mol% H2 (7671)	→ 104
Mol% H2O (7672)	→ 104
Mol% H2S (7673)	→ 104
Mol% HCl (7674)	→ 105
Mol% He (7675)	→ 105
Mol% i-C4H10 (7676)	→ 106
Mol% i-C5H12 (7677)	→ 106
Mol% Kr (7678)	→ 106
Mol% N2 (7679)	→ 107
Mol% n-C10H22 (7680)	→ 107
Mol% n-C4H10 (7681)	→ 108
Mol% n-C5H12 (7682)	→ 108
Mol% n-C6H14 (7683)	→ 108
Mol% n-C7H16 (7684)	→ 109
Mol% n-C8H18 (7685)	→ 109
Mol% n-C9H20 (7686)	→ 109
Mol% Ne (7687)	→ 110
Mol% NH3 (7688)	→ 110
Mol% O2 (7689)	→ 111
Mol% SO2 (7691)	→ 111
Mol% Xe (7692)	→ 111
Mol% other gas (7690)	→ 112
Relative humidity (7731)	→ 112

Gas type**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Gas type (7714)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Single gas** option is selected.

Description

Use this function to select the type of gas for the measuring application.

Selection

- Hydrogen H₂
- Helium He
- Neon Ne
- Argon Ar
- Krypton Kr
- Xenon Xe
- Nitrogen N₂
- Oxygen O₂
- Chlorine Cl₂
- Ammonia NH₃
- Carbon monoxide CO
- Carbon dioxide CO₂
- Sulfur dioxide SO₂
- Hydrogen sulfide H₂S
- Hydrogen chloride HCl
- Methane CH₄
- Ethane C₂H₆
- Propane C₃H₈
- Butane C₄H₁₀
- Ethylene C₂H₄
- Vinyl Chloride C₂H₃Cl

Factory setting

Methane CH₄

Gas mixture**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Gas mixture (7640)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.

Description

Use this function to select the gas mixture for the measuring application.

Selection

- Hydrogen H₂
- Helium He
- Neon Ne
- Argon Ar
- Krypton Kr
- Xenon Xe
- Nitrogen N₂

- Oxygen O₂
- Chlorine Cl₂
- Ammonia NH₃
- Carbon monoxide CO
- Carbon dioxide CO₂
- Sulfur dioxide SO₂
- Hydrogen sulfide H₂S
- Hydrogen chloride HCl
- Methane CH₄
- Ethane C₂H₆
- Propane C₃H₈
- Butane C₄H₁₀
- Ethylene C₂H₄
- Vinyl Chloride C₂H₃Cl
- Others

Factory setting Methane CH₄

Mol% Ar



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% Ar (7663)

Prerequisite

The following conditions are met:

In the **Select medium** parameter (→ 85), the **Gas** option is selected.

- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Argon Ar** option is selected.

Or

- In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% C₂H₃Cl



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% C₂H₃Cl (7664)

Prerequisite

The following conditions are met:

■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.

■ In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.

■ In the **Gas mixture** parameter (→ 99), the **Vinyl Chloride C₂H₃Cl** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting	0 %
-----------------	-----

Mol% C2H4



Navigation	Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% C2H4 (7665)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ In the Select medium parameter (→ 85), the Gas option is selected.■ In the Select gas type parameter (→ 86), the Gas mixture option is selected.■ In the Gas mixture parameter (→ 99), the Ethylene C2H4 option is selected.
Description	Use this function to enter the amount of the gas constituent in the gas mixture.
User entry	0 to 100 %
Factory setting	0 %

Mol% C2H6



Navigation	Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% C2H6 (7666)
Prerequisite	The following conditions are met: In the Select medium parameter (→ 85), the Gas option is selected. <ul style="list-style-type: none">– In the Select gas type parameter (→ 86), the Gas mixture option is selected and in the Gas mixture parameter (→ 99), the Ethane C2H6 option is selected. Or– In the Select gas type parameter (→ 86), the Natural gas option is selected and in the Density calculation parameter (→ 88), the ISO 12213- 2 option is selected.
Description	Use this function to enter the amount of the gas constituent in the gas mixture.
User entry	0 to 100 %
Factory setting	0 %

Mol% C3H8**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% C3H8 (7667)

Prerequisite

The following conditions are met:

In the **Select medium** parameter (→ 85), the **Gas** option is selected.

– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Propane C3H8** option is selected.

Or

– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% CH4**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% CH4 (7668)

Prerequisite

The following conditions are met:

In the **Select medium** parameter (→ 85), the **Gas** option is selected.

– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Methane CH4** option is selected.

Or

– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

100 %

Mol% Cl2**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% Cl2 (7707)

Prerequisite

The following conditions are met:

■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.

■ In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.

■ In the **Gas mixture** parameter (→ 99), the **Chlorine Cl2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% CO



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% CO (7669)

Prerequisite The following conditions are met:
In the **Select medium** parameter (→ 85), the **Gas** option is selected.
– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Carbon monoxide CO** option is selected.
Or
– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% CO2



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% CO2 (7670)

Prerequisite The following conditions are met:
In the **Select medium** parameter (→ 85), the **Gas** option is selected.
– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Carbon dioxide CO2** option is selected.
Or
– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% H₂**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% H₂ (7671)

Prerequisite

The following conditions are met:

In the **Select medium** parameter (→ 85), the **Gas** option is selected.

– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Hydrogen H₂** option is selected.

Or

– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **AGA Nx19** option is **not** selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% H₂O**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% H₂O (7672)

Prerequisite

The following conditions are met:

■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.

■ In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.

■ In the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% H₂S**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% H₂S (7673)

Prerequisite

The following conditions are met:

In the **Select medium** parameter (→ 85), the **Gas** option is selected.

– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Hydrogen sulfide H₂S** option is selected.

Or

– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% HCl



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% HCl (7674)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
■ In the **Gas mixture** parameter (→ 99), the **Hydrogen chloride HCl** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% He



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% He (7675)

Prerequisite The following conditions are met:
In the **Select medium** parameter (→ 85), the **Gas** option is selected.
– In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Helium He** option is selected.
Or
– In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% i-C4H10**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% i-C4H10 (7676)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
- In the **Select gas type** parameter (→ [86](#)), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ [88](#)), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% i-C5H12**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% i-C5H12 (7677)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
- In the **Select gas type** parameter (→ [86](#)), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ [88](#)), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% Kr**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% Kr (7678)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
- In the **Select gas type** parameter (→ [86](#)), the **Gas mixture** option is selected.
- In the **Gas mixture** parameter (→ [99](#)), the **Krypton Kr** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% N2**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% N2 (7679)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Nitrogen N2** option is selected.
Or
 - In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **AGA Nx19** option or the **ISO 12213-2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% n-C10H22**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C10H22 (7680)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ 88), the **ISO 12213-2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% n-C4H10**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C4H10 (7681)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
 - In the **Select gas type** parameter (→ [86](#)), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ [99](#)), the **Butane C4H10** option is selected.
Or
 - In the **Select gas type** parameter (→ [86](#)), the **Natural gas** option is selected and in the **Density calculation** parameter (→ [88](#)), the **ISO 12213- 2** option is selected.
- Or
 - In the **Select medium** parameter (→ [85](#)), the **Liquid** option is selected and in the **Select liquid type** parameter (→ [87](#)), the **LPG** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% n-C5H12**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C5H12 (7682)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
- In the **Select gas type** parameter (→ [86](#)), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ [88](#)), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% n-C6H14**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C6H14 (7683)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ [85](#)), the **Gas** option is selected.
- In the **Select gas type** parameter (→ [86](#)), the **Natural gas** option is selected.
- In the **Density calculation** parameter (→ [88](#)), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% n-C7H16



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C7H16 (7684)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
■ In the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% n-C8H18



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C8H18 (7685)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
■ In the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% n-C9H20



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% n-C9H20 (7686)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected.
■ In the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% Ne



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% Ne (7687)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
■ In the **Gas mixture** parameter (→ 99), the **Neon Ne** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% NH3



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% NH3 (7688)

Prerequisite The following conditions are met:
■ In the **Select medium** parameter (→ 85), the **Gas** option is selected.
■ In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
■ In the **Gas mixture** parameter (→ 99), the **Ammonia NH3** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Mol% O₂**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% O₂ (7689)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected and in the **Gas mixture** parameter (→ 99), the **Oxygen O₂** option is selected.
 - Or
 - In the **Select gas type** parameter (→ 86), the **Natural gas** option is selected and in the **Density calculation** parameter (→ 88), the **ISO 12213- 2** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% SO₂**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% SO₂ (7691)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
- In the **Gas mixture** parameter (→ 99), the **Sulfur dioxide SO₂** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting

0 %

Mol% Xe**Navigation**

Expert → Sensor → Measurement mode → Medium property → Gas composition → Mol% Xe (7692)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
- In the **Gas mixture** parameter (→ 99), the **Xenon Xe** option is selected.

Description

Use this function to enter the amount of the gas constituent in the gas mixture.

User entry

0 to 100 %

Factory setting 0 %

Mol% other gas



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Mol% other gas (7690)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Gas mixture** option is selected.
- In the **Gas mixture** parameter (→ 99), the **Others** option is selected.

Description Use this function to enter the amount of the gas constituent in the gas mixture.

User entry 0 to 100 %

Factory setting 0 %

Relative humidity



Navigation Expert → Sensor → Measurement mode → Medium property → Gas composition
→ Rel. humidity (7731)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85), the **Gas** option is selected.
- In the **Select gas type** parameter (→ 86), the **Air** option is selected.


Description Use this function to enter the humidity content of the air in %.

User entry 0 to 100 %

Factory setting 0 %

3.2.5 "External compensation" submenu

Navigation Expert → Sensor → External comp.



Fixed density (7627)	→ 114
Fixed temperature (7628)	→ 114
2nd temperature delta heat (7625)	→ 115
Fixed process pressure (7629)	→ 115
Steam quality (7605)	→ 116
Steam quality value (7630)	→ 116

External value**Navigation**

Expert → Sensor → External comp. → External value (7622)

Prerequisite

For the following order code:
"Sensor version", option "Mass flow"

Description

Use this function to select the process variable which is taken from an external device.

For detailed information on setting the parameter in steam applications, see the Special Documentation for the **Wet Steam Detection** application package.

Selection

- Off
- Pressure
- Relative pressure
- Density
- Temperature
- 2nd temperature delta heat

Factory setting

Off

Atmospheric pressure**Navigation**

Expert → Sensor → External comp. → Atmosph. press. (7601)

Prerequisite

In the **External value** parameter (→ [113](#)), the **Relative pressure** option is selected.

Description

Use this function to enter the value for the ambient pressure to be used for pressure correction.

User entry

0 to 250 bar

Factory setting

1.01325 bar

Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ 74)

Delta heat calculation**Navigation**

Expert → Sensor → External comp. → Delta heat calc. (7736)

Prerequisite

The **Delta heat calculation** parameter (→ 114) is visible.

Description

Use this function to select the option for calculating the heat transferred via a heat exchanger (=delta heat).

Selection

- Off
- Device on cold side
- Device on warm side

Factory setting

Device on warm side

Fixed density**Navigation**

Expert → Sensor → External comp. → Fixed density (7627)

Prerequisite

For the following order code:
"Sensor version", option "Volume flow"

Description

Use this function to enter a fixed value for the density.

User entry

0.01 to 15 000 kg/m³

Factory setting

1000 kg/m³

Additional information*Description*

The density entered is used to linearize the measured error in the lower Reynolds number range if the calculated density is not available e.g. "Volume flow" sensor version or the fluid is a user-specific gas (see table).

Dependency

The unit is taken from the **Density unit** parameter (→ 79)

Fixed temperature**Navigation**

Expert → Sensor → External comp. → Fixed temp. (7628)

Description

Use this function to enter a fixed value for the process temperature.

User entry	-200 to 450 °C
Factory setting	20 °C
Additional information	<p><i>Dependency</i></p>  The unit is taken from the Temperature unit parameter (→ 75)

2nd temperature delta heat



Navigation	  Expert → Sensor → External comp. → 2ndTempDeltaHeat (7625)
Prerequisite	The 2nd temperature delta heat parameter (→ 115) is visible.
Description	Use this function to enter the second temperature value for calculating the delta heat.
User entry	-200 to 450 °C
Factory setting	20 °C
Additional information	<p><i>Dependency</i></p>  The unit is taken from the Temperature unit parameter (→ 75)

Fixed process pressure



Navigation	  Expert → Sensor → External comp. → Fix. proc.press. (7629)
Prerequisite	<p>The following conditions are met:</p> <ul style="list-style-type: none"> ■ Order code for "Sensor version", option "Mass flow (integrated temperature measurement)" ■ In the External value parameter (→ 113) the Pressure option is not selected.
Description	Use this function to enter a fixed value for the process pressure.
User entry	0 to 250 bar abs.
Factory setting	0 bar abs.
Additional information	<p><i>User entry</i></p>  For detailed information on setting the parameter in steam applications, see the Special Documentation for the Wet Steam Detection application package.
Dependency	<p><i>Dependency</i></p>  The unit is taken from the Pressure unit parameter (→ 74)

Steam quality



Navigation

Expert → Sensor → External comp. → Steam quality (7605)

Prerequisite

The following conditions are met:

- Order code for "Application package":
 - Option ES "Wet steam detection"
 - Option EU "Wet steam measurement"
- In the **Select medium** parameter (→ 85) the **Steam** option is selected.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 54).

Description

Use this function to select the compensation mode for the steam quality.

Selection

- Fixed value
- Calculated value

Factory setting

Fixed value

Additional information

Selection

For detailed information on setting the parameter in steam applications, see the Special Documentation for the **Wet Steam Detection** application package.

Steam quality value



Navigation

Expert → Sensor → External comp. → Steam qual. val. (7630)

Prerequisite

The following conditions are met:

- In the **Select medium** parameter (→ 85) the **Steam** option is selected.
- In the **Steam quality** parameter (→ 116) the **Fixed value** option is selected.

Description

Use this function to enter a fixed value for the steam quality.

User entry

0 to 100 %

Factory setting

100 %

Additional information

User entry

For detailed information on setting the parameter in steam applications, see the Special Documentation for the **Wet Steam Detection** application package.

3.2.6 "Sensor adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm.

▶ Sensor adjustment	
Inlet configuration (7641)	→ 117
Inlet run (7642)	→ 117
Mating pipe diameter (7648)	→ 118
Installation factor (7616)	→ 119

Inlet configuration



Navigation

Expert → Sensor → Sensor adjustm. → Inlet config. (7641)

Prerequisite

The **inlet run correction** feature:

- Is a standard feature and can only be used in Prowirl F 200.
- Can be used for the following pressure ratings and nominal diameters:
DN 15 to 150 (1 to 6")
– EN (DIN)
– ASME B16.5, Sch. 40/80

Description

Use this function to select the inlet configuration.

Selection

- Off
- Single elbow
- Double elbow
- Double elbow 3D
- Reduction

Factory setting

Off

Inlet run



Navigation

Expert → Sensor → Sensor adjustm. → Inlet run (7642)

Prerequisite

The **inlet run correction** feature:

- Is a standard feature and can only be used in Prowirl F 200.
- Can be used for the following pressure ratings and nominal diameters:
DN 15 to 150 (1 to 6")
– EN (DIN)
– ASME B16.5, Sch. 40/80

Description

Use this function to enter the length of the straight inlet run.

User entry 0 to 20 m

Factory setting 0 m

Additional information *Dependency*

 The unit is taken from the **Length unit** parameter (→ 81)

Mating pipe diameter



Navigation   Expert → Sensor → Sensor adjustm. → D mating pipe (7648)

Description Use this function to enter the diameter of the mating pipe to enable diameter mismatch correction.

User entry 0 to 1 m (0 to 3 ft)

Factory setting Country-specific:
■ 0 m
■ 0 ft

Additional information *Description*

The device has diameter mismatch correction. This can be enabled by entering the actual internal diameter of the mating pipe in the **Mating pipe diameter** parameter.

User entry

If the value entered is **0**, diameter mismatch correction is disabled. If the standard internal diameter of the ordered process connection differs from the internal diameter of the mating pipe, an additional measuring uncertainty of up to 2 % must be expected if diameter mismatch correction is disabled.

Limit values

Diameter mismatch correction should be enabled only within the following limit values:

Flange connection:

- DN 15 (½)": ±20 % of the internal diameter
- DN 25 (1)": ±15 % of the internal diameter
- DN 40 (1½)": ±12 % of the internal diameter
- DN ≥ 50 (2)": ±10 % of the internal diameter

Disc (wafer version):

- DN 15 (½)": ±15 % of the internal diameter
- DN 25 (1)": ±12 % of the internal diameter
- DN 40 (1½)": ±9 % of the internal diameter
- DN ≥ 50 (2)": ±8 % of the internal diameter

Dependency

 The unit is taken from the **Length unit** parameter (→ 81)

Installation factor**Navigation**

Expert → Sensor → Sensor adjustm. → Install. factor (7616)

Description

Use this function to enter the factor to adjust installation conditions.

User entry

Positive floating-point number

Factory setting


1.0

Additional information*Description*

The calculated volume flow and all measured variables derived from this are multiplied by the installation factor.

3.2.7 "Calibration" submenu*Navigation*

Expert → Sensor → Calibration

**Calibration factor****Navigation**

Expert → Sensor → Calibration → Cal. factor (7604)

Description

Displays the calibration factor. The calibration factor is determined during device calibration.

User interface

Positive floating-point number

Factory setting

This value is always > 0 when the device is delivered from the factory.

Additional information*Description*

Factor by which the measured vortex frequency must be divided in order to calculate the volume flow.

Unit

In 1/m³, or vortex pulses per cubic meter

Meter body properties

Navigation  Expert → Sensor → Calibration → Meter body prop. (7658)

Description Displays informative text about the measuring tube.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting -----

Additional information *Description*


Summarized information about the meter body.

Example

DN25F-PN40: nominal diameter DN25, flange type, pressure rating 40 bar


3.3 "Output" submenu

Navigation  Expert → Output



3.3.1 "Pulse/frequency/switch output" submenu

Navigation  Expert → Output → PFS output



Maximum frequency value (0454)	→ 128
Measuring value at minimum frequency (0476)	→ 128
Measuring value at maximum frequency (0475)	→ 129
Damping output (0477)	→ 130
Response time (0491)	→ 130
Failure mode (0451)	→ 131
Failure frequency (0474)	→ 132
Output frequency (0471)	→ 132
Switch output function (0481)	→ 132
Assign diagnostic behavior (0482)	→ 133
Assign limit (0483)	→ 134
Switch-on value (0466)	→ 135
Switch-off value (0464)	→ 136
Assign flow direction check (0484)	→ 136
Assign status (0485)	→ 137
Switch-on delay (0467)	→ 137
Switch-off delay (0465)	→ 137
Failure mode (0486)	→ 138
Switch status (0461)	→ 138
Invert output signal (0470)	→ 138

Operating mode



Navigation

Expert → Output → PFS output → Operating mode (0469)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse


Additional information*"Pulse" option*

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume, corrected volume, mass, total mass, energy or heat is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Total flow approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s

**Fig. 4** Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses


"Frequency" option

Flow-proportional frequency output with 1:1 on/off ratio

An output frequency is output that is proportional to the value of a process variable, such as volume flow, corrected volume flow, mass flow, flow velocity, temperature, calculated saturated steam pressure, steam quality, total mass flow, energy flow or heat flow difference.


Example

- Total flow approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz

**Fig. 5** Flow-proportional frequency output*"Switch" option*

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)


Example
Alarm response without alarm



A0026884

图 6 No alarm, high level

Example
Alarm response in case of alarm



A0026885

图 7 Alarm, low level

Assign pulse output



Navigation

图 2 Expert → Output → PFS output → Assign pulse (0460)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 图 121).

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Energy flow *
- Heat flow difference *

Factory setting

Volume flow

* Visibility depends on order options or device settings

Value per pulse**Navigation**

Expert → Output → PFS output → Value per pulse (0455)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign pulse output** parameter (→ 123):

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter → 295

Additional information

User entry

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width**Navigation**

Expert → Output → PFS output → Pulse width (0452)

Prerequisite

In the **Operating mode** parameter (→ 121), the **Pulse** option is selected and one of the following options is selected in the **Assign pulse output** parameter (→ 123):

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to enter the duration of the output pulse.

User entry

5 to 2 000 ms


Factory setting

100 ms

* Visibility depends on order options or device settings

Additional information*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to 2**.



B Pulse width entered

P Intervals between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

i The pulse width is not relevant for **Automatic pulse** option.

Failure mode**Navigation**

Expert → Output → PFS output → Failure mode (0480)

Prerequisite

In the **Operating mode** parameter (→ 121), the **Pulse** option is selected and one of the following options is selected in the **Assign pulse output** parameter (→ 123):

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting

No pulses

* Visibility depends on order options or device settings

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a fault.

*Options***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output**Navigation**
 Expert → Output → PFS output → Pulse output (0456)
Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 121).

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 124) and the **Pulse width** parameter (→ 124) can be used to define the value (i.e. the amount of the measured value that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 138), i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of an error (**Failure mode** parameter (→ 125)) can be configured.

Assign frequency output



Navigation

Expert → Output → PFS output → Assign freq. (0478)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121).

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Factory setting

Off

Minimum frequency value



Navigation

Expert → Output → PFS output → Min. freq. value (0453)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to enter the start value frequency.

User entry

0 to 1 000 Hz

* Visibility depends on order options or device settings

Factory setting	0 Hz
-----------------	------

Maximum frequency value



Navigation Expert → Output → PFS output → Max. freq. value (0454)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description Use this function to enter the end value frequency.

User entry 0 to 1 000 Hz

Factory setting 1 000 Hz

Measuring value at minimum frequency



Navigation Expert → Output → PFS output → Val. at min.freq (0476)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description Use this function to enter the measured value for the start value frequency.

User entry Signed floating-point number

* Visibility depends on order options or device settings

Factory setting Depends on country and nominal diameter

Additional information *Dependency*

 The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 127).

Measuring value at maximum frequency



Navigation  Expert → Output → PFS output → Val. at max.freq (0475)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):
■ Volume flow
■ Corrected volume flow
■ Mass flow
■ Flow velocity
■ Temperature
■ Calculated saturated steam pressure *
■ Steam quality *
■ Total mass flow *
■ Energy flow *
■ Heat flow difference *

Description Use this function to enter the measured value for the end value frequency.

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter

Additional information *Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

Dependency

 The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 127).

* Visibility depends on order options or device settings

Damping output



Navigation

Expert → Output → PFS output → Damping out. (0477)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to enter the reaction time of the output signal to fluctuations in the measured value.

User entry

0 to 999.9 s

Factory setting

5.0 s

Additional information

Description

Use this function to enter a time constant (PT1 element) for frequency output damping. The frequency output is subject to separate damping that is independent of all preceding time constants.

Response time

Navigation

Expert → Output → PFS output → Response time (0491)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.

* Visibility depends on order options or device settings

User interface	Positive floating-point number
----------------	--------------------------------

Additional information	<i>Description</i>
------------------------	--------------------



- The response time is made up of the time specified for the following dampings:
- Damping of pulse/frequency/switch output and
 - Depending on the measured variable assigned to the output.
- Flow damping

Failure mode



Navigation Expert → Output → PFS output → Failure mode (0451)

Prerequisite The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description Use this function to select the failure mode of the frequency output in the event of a device alarm.

- Selection**
- Actual value
 - Defined value
 - 0 Hz

Factory setting 0 Hz

Additional information *Selection*

- Actual value
In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The fault is ignored.
- Defined value
In the event of a device alarm, the frequency output continues on the basis of a predefined value. This Failure frequency (→ 132) replaces the current measured value and the alarm can be bypassed in this way. The actual measurement is switched off for the duration of the alarm.
- 0 Hz
In the event of a device alarm, the frequency output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

* Visibility depends on order options or device settings

Failure frequency



Navigation

Expert → Output → PFS output → Failure freq. (0474)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 121), and one of the following options is selected in the **Assign frequency output** parameter (→ 127):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 1250.0 Hz

Factory setting

0.0 Hz

Output frequency

Navigation

Expert → Output → PFS output → Output freq. (0471)

Prerequisite

In the **Operating mode** parameter (→ 121), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0 to 1250 Hz

Switch output function



Navigation

Expert → Output → PFS output → Switch out funct (0481)

Prerequisite

In the **Operating mode** parameter (→ 121) the **Switch** option is selected.

Description

Use this function to select a function for the switch output.

* Visibility depends on order options or device settings

Selection	<ul style="list-style-type: none"> ▪ Off ▪ On ▪ Diagnostic behavior ▪ Limit ▪ Status
Factory setting	Off
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off The switch output is permanently switched off (open, non-conductive). ▪ On The switch output is permanently switched on (closed, conductive). ▪ Diagnostic behavior Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level. ▪ Limit Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level. ▪ Status Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior



Navigation	Expert → Output → PFS output → Assign diag. beh (0482)
Prerequisite	<ul style="list-style-type: none"> ▪ The Switch option is selected in the Operating mode parameter (→ 121). ▪ The Diagnostic behavior option is selected in the Switch output function parameter (→ 132).
Description	Use this function to select the diagnostic event category that is displayed for the switch output.
Selection	<ul style="list-style-type: none"> ▪ Alarm ▪ Alarm or warning ▪ Warning
Factory setting	Alarm
Additional information	<p><i>Description</i></p> <p> If no diagnostic event is pending, the switch output is closed and conductive.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> ▪ Alarm The switch output signals only diagnostic events in the alarm category. ▪ Alarm or warning The switch output signals diagnostic events in the alarm and warning category. ▪ Warning The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS output → Assign limit (0483)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch output function** parameter (→ 132).

Description

Use this function to select a process variable for the limit function.

Selection

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Energy flow *
- Heat flow difference *
- Reynolds number *
- Totalizer 1
- Totalizer 2
- Totalizer 3


Factory setting

Volume flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive




A0026891

- | | |
|---|------------------|
| 1 | Switch-on value |
| 2 | Switch-off value |
| 3 | Conductive |
| 4 | Non-conductive |
| A | Process variable |
| B | Status output |

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive


* Visibility depends on order options or device settings



- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS output → Switch-on value (0466)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch output function** parameter (→ 132).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³/h
- 0 ft³/h

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

 When using a hysteresis: Switch-on value > Switch-off value.

Dependency

 The unit depends on the process variable selected in the **Assign limit** parameter (→ [134](#)).

Switch-off value**Navigation**

 Expert → Output → PFS output → Switch-off value (0464)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [121](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [132](#)).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 m³/h
- 0 ft³/h

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).

 When using a hysteresis: Switch-on value > Switch-off value.

Dependency

 The unit depends on the process variable selected in the **Assign limit** parameter (→ [134](#)).

Assign flow direction check**Navigation**

 Expert → Output → PFS output → Assign dir.check (0484)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [121](#)).
- The **Flow direction check** option is selected in the **Switch output function** parameter (→ [132](#)).

Description

Use this function to select a process variable for monitoring the flow direction.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting	Volume flow
------------------------	-------------

Assign status

Navigation Expert → Output → PFS output → Assign status (0485)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Status** option is selected in the **Switch output function** parameter (→ 132).

Description Use this function to select a device status for the switch output.

Selection

- Low flow cut off
- Digital output 6

Factory setting Low flow cut off

Additional information *Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay

Navigation Expert → Output → PFS output → Switch-on delay (0467)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch output function** parameter (→ 132).

Description Use this function to enter a delay time for switching on the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Switch-off delay

Navigation Expert → Output → PFS output → Switch-off delay (0465)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 121).
- The **Limit** option is selected in the **Switch output function** parameter (→ 132).

Description Use this function to enter a delay time for switching off the switch output.

User entry 0.0 to 100.0 s

Factory setting 0.0 s

Failure mode**Navigation**

Expert → Output → PFS output → Failure mode (0486)

Description

Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Options*

- Actual status
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed
In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status**Navigation**

Expert → Output → PFS output → Switch status (0461)

Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 121).

Description

Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

- Open
The switch output is not conductive.
- Closed
The switch output is conductive.

Invert output signal**Navigation**

Expert → Output → PFS output → Invert outp.sig. (0470)

Description

Use this function to select whether to invert the output signal.


Selection

- No
- Yes

Factory setting No


Additional information Selection

No option (passive - negative)



A0026693

Yes option (passive - positive)




A0026692

3.4 "Communication" submenu

Navigation



Expert → Communication



Device address

Navigation



Expert → Communication → Device address (11061)

Description

Displays the device address.

User interface

1 to 255

3.4.1 "Resource block" submenu

Navigation

Expert → Communication → Resource block

► Resource block	
Block tag (10702)	→ 140
Target mode (10728)	→ 141
Actual mode (10725)	→ 143
Manufacturer Id (10721)	→ 146
Device type (10711)	→ 146
Device Revision (10710)	→ 147
DD Revision (10709)	→ 147
Restart (10800)	→ 148
Write Lock (10747)	→ 154
ITK Version (10794)	→ 161

Block tag

Navigation

Expert → Communication → Resource block → Block tag (10702)

Description

Use this function to enter the Block tag: Used for specifying a "label" for identifying the function block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static Revision

Navigation

Expert → Communication → Resource block → Static Revision (10735)

Description

Displays the Static Revision: Each instance of a static block parameter being accessed with write access is counted (event counter).

User interface

0 to FFFF

Additional information*Description*

Static parameters are parameters that are not changed by the process.

Tag Description

Navigation

Expert → Communication → Resource block → Tag Description (10736)

Description

Use this function to enter the Tag Description: Used for defining a user-specific text for detailed description of the function block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Strategy

Navigation

Expert → Communication → Resource block → Strategy (10734)

Description

Use this function to enter the Strategy: Enables blocks to be grouped by entering identical numbers.

User entry

0 to FFFF

Factory setting

0

Alert Key

Navigation

Expert → Communication → Resource block → Alert Key (10696)

Description

Use this function to enter the Alert Key: Identifies the plant unit where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

1

Target mode

Navigation

Expert → Communication → Resource block → Target mode (10728)

Description

Use this function to select the Target mode: The selection indicates which operating mode is used for this function block. This mode is generally set by a control application.

Selection	<ul style="list-style-type: none">■ ROut■ RCas■ Cas■ Auto■ Man■ LO■ IMan■ OOS
Factory setting	OOS
Additional information	<p><i>Options</i></p> <ul style="list-style-type: none">■ ROut In the ROut operating mode, the set point (SP) for the function block is controlled by the field bus host system, which runs over an interface, via the RIn parameter. The set point (SP) is used as an output signal after internal calculations. The output value and the status of the function block is communicated to the field bus host system as feedback via the ROut parameter. The set point can be initiated or retained for the value of the process variables.■ RCas In the RCas operating mode (external cascade mode), the set point (SP) for the function block is controlled by the field bus host system, which runs over an interface, via the RCas-In parameter. The set point (SP) is used as an output signal after internal calculations. The output value and status of the function block is communicated to the field bus host system as feedback via the RCas-Out parameter.■ Cas In the Cas (cascade mode) operating mode, the function block receives a discrete signal via the function block input, which is provided by the Cas-In parameter of an upstream function block. This signal controls the set point (SP) of the function block and is used as an output signal after internal calculations. The output is used to communicate the output value and status to the upstream function block.■ Auto The Auto operating mode is the normal operating mode of the function block. The set point (SP) is specified locally in the function block and is used as an output signal after internal calculations. This set point can be specified by the user via an interface.■ Man In the Man operating mode, the output value can be specified directly in the function block. This is specified by the user via an interface. There is no internal calculation. The algorithm is initiated in such a way that there is no interruption when the operating mode is changed. The set point can be retained or initiated for the value of the process variables or for the set point of the previous operating mode if the system is switched back to it.

- LO

The **LO** operating mode is used in control and output blocks that support a track input parameter. The manufacturer can also provide a local lock switch on the device to enable the **LO** operating mode. Tracking must be supported in the group of control parameters and is initiated by a discrete track-in parameter.

In local bridge mode, the output value of the function block is set in order to track the value of the track-input parameter. The algorithm is initiated in such a way that there is no interruption when the operating mode switches from **LO** back to the previous operating mode. The set point can be initiated or retained for the value of the process variables.

- IMan

In the **IMan** operating mode, the output value of the function block is performed as a reaction to the status of the back-calculation-input parameter. When this status indicates that there is no signal for the final output element, the control blocks ensure that there is a smooth transition. The back-calculation-input parameter is supported by all control and output blocks. The set point can be initiated or retained for the value of the process variables.

- OOS

In the **OOS** operating mode, implementation of the function block is blocked. Either the last valid value or, in the case of an output block, the last valid set point is retained as the output value. This operating mode is used during configuration of the device.

Actual mode

Navigation

 Expert → Communication → Resource block → Actual mode (10725)

Description

Displays the Actual mode: Under certain conditions, a function block may not work in the operating mode to be used. In this case, the Actual mode shows the actual operating mode that the function block is currently operating in. By comparing the Actual mode with the Target mode, users can see whether it was possible to reach the Target mode (→  141).

User interface

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Additional information

User interface

 Detailed description of the options displayed: **Target mode** parameter (→  141)

Permitted mode

Navigation

 Expert → Communication → Resource block → Permitted mode (10727)

Description

Use this function to select the Permitted mode: The selection defines which operating modes are available in Target mode (→  141) for the function block. The operating modes that are supported vary depending on the type and function of the block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

- Auto
- OOS

Additional information*Options*

Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Normal mode**Navigation**

Expert → Communication → Resource block → Normal mode (10726)

Description

Use this function to select the Normal mode: This is available to enable the user to select the Normal mode from the available operating modes. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Additional information*Options*

Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Block Error**Navigation**

Expert → Communication → Resource block → Block Error (10703)

Description

Displays the short text for the Block Error that has occurred in the function block.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance

- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Resource State

Navigation	 Expert → Communication → Resource block → Resource State (10730)
Description	Displays the Resource State: Displays the current operating mode of the resource block.
User interface	<ul style="list-style-type: none">■ Uninitialized■ StartRestart■ Initialization■ Online Linking■ Online■ Standby■ Failure
Additional information	<p><i>User interface</i></p> <ul style="list-style-type: none">■ Uninitialized The resource block is in an invalid operating mode.■ StartRestart The resource block is in the start-up or restore phase. The necessary memory and hardware tests are carried out for the current operation. If these tests are successful, the resource block switches to the Initialization operating mode. If these tests are not successful, the resource block switches to the Failure operating mode.■ Initialization The resource block is in this operating mode if the block successfully passes the hardware tests from the StartRestart or Failure status. In this operating mode, all alarms of the function block that are not displayed are automatically confirmed and acknowledged. When system management is operational, the implementation of the block can be planned and the resource block switches to the Online Linking operating mode.■ Online Linking The resource block is in this operating mode when the block switches from the Initialization or Online operating mode. The configured connections between the function blocks are not yet established. When all configured connections have been established, the resource block switches to the Online operating mode.

- Online
Normal operating mode, the resource block is in the Auto operating mode. The configured connections between the function blocks have been established. If one of the connections could not be established, the resource block switches back to the Online Linking operating mode.
- Standby
The Resource Block is in the **OOS** option operating mode. It is not possible to implement the remaining blocks. The operating mode of the transducer block is not necessarily affected by this. Switching the resource block to the Auto mode causes the resource block to switch back to the StartRestart operating mode.
- Failure
The resource block is in the fault state. It switches to this operating mode if a memory or hardware fault that would hinder current operation has been detected in the block. The fault can affect the block or the entire device. When this operating mode is active, blocks with an output function are also in the fault state. The hardware test is carried out again. If the error does not reoccur, the resource block switches back to the Initialization operating mode.

DD Resource

Navigation

 Expert → Communication → Resource block → DD Resource (10708)

Description

Displays the DD Resource: Indicates the reference source for the device description (DD).

User interface

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Additional information

User interface

 Zero: No device description is stored on the device.

Manufacturer Id

Navigation

  Expert → Communication → Resource block → Manufacturer Id (10721)

Description

Manufacturer Id display: is used by the interface to assign the right DD file for the resource.

User interface

Endress+Hauser

Device type

Navigation

  Expert → Communication → Resource block → Device type (10711)

Description

Use this function to view the device type with which the measuring device is registered with FOUNDATION Fieldbus.

User interface

Prowirl 200

Device Revision

Navigation  Expert → Communication → Resource block → Device Revision (10710)

Description Use this function to view the device revision with which the measuring device is registered with FOUNDATION Fieldbus.

User interface 1

DD Revision

Navigation  Expert → Communication → Resource block → DD Revision (10709)

Description Displays the revision number of the device description (DD).

User interface 1

Additional information *Description*

 This display can be used to ensure that the right system files (DD = device description) are used for integration into the host system. The system files can be downloaded free of charge online at: www.endress.com.

Grant

Navigation  Expert → Communication → Resource block → Grant (10718)

Description Option for releasing certain access authorizations of the field bus host system on the device.

Selection

- Program
- Tune
- Alarm
- Local
- Operate
- Service
- Diagnostic

Deny

Navigation  Expert → Communication → Resource block → Deny (10717)

Description Option for restricting certain access authorizations of the field bus host system on the device.

Selection

- Program Denied
- Tune Denied
- Alarm Denied
- Local
- Operate Denied

Hard Types

Navigation

 Expert → Communication → Resource block → Hard Types (10719)

Description

Displays the input signal type for the Analog input block.

User interface

- Scalar Input
- Scalar Output
- Discrete Input
- Discrete Output

Restart

Navigation

  Expert → Communication → Resource block → Restart (10800)

Description

Use this function to select a manual restart or a manual device reset.

Selection

- Uninitialized
- Run
- Resource
- Defaults
- Processor
- To factory defaults
- To delivery settings
- ENP restart
- To transducer defaults
- Factory Default Blocks

Factory setting

Uninitialized

Features

Navigation

 Expert → Communication → Resource block → Features (10713)

Description

Displays the additional options that are supported by the measuring device.

User interface

- Reports
- Faultstate
- Soft W Lock
- Hard W Lock
- Change Bypass in Auto

- MVC Report Distribution supported
- Multi-bit Alarm (Bit-Alarm) Support
- Defer Inter-Parameter Write Checks

Feature Selection

Navigation

 Expert → Communication → Resource block → Feature Select (10714)

Description

Use this function to select additional options that are supported by the measuring device.

Selection

- Reports
- Faultstate
- Soft W Lock
- Hard W Lock
- Change Bypass in Auto
- MVC Report Distribution supported
- Multi-bit Alarm (Bit-Alarm) Support
- Defer Inter-Parameter Write Checks

Cycle Type

Navigation

 Expert → Communication → Resource block → Cycle Type (10707)

Description

Displays the implementation methods for the block that are supported by the measuring device.

User interface

- Scheduled
- Block Execution

Cycle Selection

Navigation

 Expert → Communication → Resource block → Cycle Selection (10706)

Description

Use this function to select the implementation method for the block that is used by the field bus host system. This implementation method is selected by the field bus host system.

Selection

- Scheduled
- Block Execution

Minumum Cycle Time

Navigation  Expert → Communication → Resource block → Minumum Cyc.Time (10724)

Description Displays the implementation time of all function blocks that are available in the measuring device.

User interface Positive integer

Memory Size

Navigation  Expert → Communication → Resource block → Memory Size (10723)

Description Displays the available configuration memory in kilobytes.

User interface 0 to 65 535 Kbytes

Nonvolatile Cycle Time

Navigation  Expert → Communication → Resource block → Nonvolat CycTime (10729)

Description Displays the time interval during which the dynamic device parameters are stored in the non-volatile memory.

User interface Positive integer

Free Space

Navigation  Expert → Communication → Resource block → Free Space (10715)

Description Displays the free system memory volume available for implementing further function blocks as a percentage.

User interface 0.000000 to 100.000 %

Free Time

Navigation  Expert → Communication → Resource block → Free Time (10716)

Description Displays the free system time available for implementing further function blocks as a percentage.

User interface	0.000000 to 100.000 %
----------------	-----------------------

Clear Fault State

Navigation	 Expert → Communication → Resource block → Clear Fault Stat (10704)
------------	--

Description	Use this function to select the fault state for the Discrete outputs (→  247) block.
-------------	---

Selection	<ul style="list-style-type: none">■ Uninitialized■ Off■ Clear
-----------	---

Factory setting	Uninitialized
-----------------	---------------

Additional information	<i>Options</i>
	 The fault state can be disabled with Clear option.

Confirm Time

Navigation	 Expert → Communication → Resource block → Confirm Time (10705)
------------	--

Description	Use this function to enter a time interval for confirming the event report. If the measuring device does not receive a confirmation within this interval, the event report is sent to the field bus host system again.
-------------	--

User entry	Positive integer
------------	------------------

Factory setting	0 1/32 ms
-----------------	-----------

Fault State

Navigation	 Expert → Communication → Resource block → Fault State (10712)
------------	---

Description	Displays the current status of the fault state for the Discrete outputs (→  247) block.
-------------	--

User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear■ Active
----------------	--

Additional information	<i>User interface</i> <ul style="list-style-type: none">■ Uninitialized■ Clear The fault state is disabled.■ Active The fault state is enabled.
------------------------	---

Limit Notify

Navigation	 Expert → Communication → Resource block → Limit Notify (10720)
Description	Use this function to enter the maximum number of event reports that may be pending at the same time without confirmation.
User entry	0 to 255
Factory setting	0

Max Notify

Navigation	 Expert → Communication → Resource block → Max Notify (10722)
Description	Displays the maximum number of event reports that are supported by the measuring device and may be pending at the same time without confirmation.
User interface	0 to 255

Set Fault State

Navigation	 Expert → Communication → Resource block → Set Fault State (10731)
Description	Option for manually enabling or disabling the fault state for the Discrete outputs (→  247) function block.
Selection	<ul style="list-style-type: none">▪ OFF▪ SET
Factory setting	OFF
Additional information	<i>Options</i> <ul style="list-style-type: none">▪ OFF The fault state is disabled.▪ SET The fault state is enabled.

Shed Remote Cascade

Navigation	 Expert → Communication → Resource block → Shed Remote Casc (10732)
Description	Use this function to enter the time interval after which the computer stops writing to function blocks with RCas points.

User entry Positive integer

Factory setting 0 1/32 ms

Shed Remote Out

Navigation  Expert → Communication → Resource block → Shed Remote Out (10733)

Description Use this function to enter the time interval after which the computer stops writing to function blocks with ROut points.

User entry Positive integer

Factory setting 0 1/32 ms

Unacknowledged

Navigation  Expert → Communication → Resource block → Unacknowledged (10740)

Description Option for manually acknowledging an update of the static block parameter.

Selection

- Uninitialized
- Acknowledged
- Unacknowledged

Factory setting Uninitialized

Additional information *Description*



- If a new diagnostic event occurs, the measuring device sets **Unacknowledged** option.
- If the diagnostic event has been acknowledged, the user can set **Acknowledged** option.

Update State

Navigation  Expert → Communication → Resource block → Update State (10741)

Description Displays the status of an update of the static block parameter. The status indicates whether the update was communicated or not.

User interface

- Uninitialized
- Reported
- Not Reported

Time Stamp

Navigation	 Expert → Communication → Resource block → Time Stamp (10739)
Description	Displays the time stamp indicating when the analysis of the block was started and when a status change of an update to the static block parameter that has not yet been communicated was identified. The time stamp is retained until the update confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Static revision

Navigation	 Expert → Communication → Resource block → Static revision (10738)
Description	Displays the Static revision: Each instance of a static block parameter being accessed with write and report access due to an update is counted (event counter).
User interface	0 to 65 535

Relative Index

Navigation	 Expert → Communication → Resource block → Relative Index (10737)
Description	Displays the relative index of the static block parameter that triggered the alarm (OD index minus field bus start index).
User interface	0 to 65 535

Write Lock

Navigation	  Expert → Communication → Resource block → Write Lock (10747)
Description	Option for enabling and disabling the hardware write protection.
Selection	<ul style="list-style-type: none">■ Not Locked■ Locked
Factory setting	Not Locked

Additional information*Description*

Option for enabling and disabling write access to the measuring device via the FOUNDATION Fieldbus (acyclic data transmission, e.g. via the "FieldCare" operating program).



For detailed information on hardware write protection, see the "Write protection via write protection switch" section of the Operating Instructions.

Options

■ Not Locked

Device data can be changed via the FOUNDATION Fieldbus interface.

■ Locked

Device data cannot be changed via the FOUNDATION Fieldbus interface.

Unacknowledged**Navigation**

█ Expert → Communication → Resource block → Unacknowledged (10700)

Description

Option for manually acknowledging a block alarm.

Selection

- Uninitialized
- Acknowledged
- Unacknowledged

Factory setting

Uninitialized

Additional information*Description*

- If a new alarm occurs, the measuring device sets **Unacknowledged** option.
- If the alarm has been acknowledged, the user can set **Acknowledged** option.

Alarm State**Navigation**

█ Expert → Communication → Resource block → Alarm State (10697)

Description

Displays the status of the block alarm. The status indicates whether the block alarm is active and whether it has already been communicated to the field bus host system.

User interface

- Uninitialized
- Clear-Reported
- Clear-Not Reported
- Active-Reported
- Active-Not Reported

Time Stamp

Navigation  Expert → Communication → Resource block → Time Stamp (10699)

Description Displays the time stamp indicating when the analysis of the block was started and when a status change of the block alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.

User interface Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation  Expert → Communication → Resource block → Subcode (10698)

Description Displays the specific cause of the block alarm.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Value

Navigation  Expert → Communication → Resource block → Value (10701)

Description Displays the value of the affected parameter at the time at which the block alarm was detected.

User interface 0 to 255

Current

Navigation  Expert → Communication → Resource block → Current (10692)

Description Use this function to view the current status of the process alarms.

User interface

- Discrete Alarm
- Block Alarm
- Fail Alarm
- Off Spec Alarm
- Maintenance Alarm
- Check Alarm

Unacknowledged

Navigation  Expert → Communication → Resource block → Unacknowledged (10694)

Description Displays an unacknowledged process alarm.

User interface

- Disc Alm Unack
- Block Alm Unack
- Fail Alm Unack
- Off Spec Alm Unack
- Maint Alm Unack
- Check Alm Unack

Unreported

Navigation  Expert → Communication → Resource block → Unreported (10695)

Description Displays a process alarm that has not been communicated.

User interface

- Disc Alm Unrep
- Block Alm Unrep
- Fail Alm Unrep
- Off Spec Alm Unrep
- Maint Alm Unrep
- Check Alm Unrep

Disabled

Navigation  Expert → Communication → Resource block → Disabled (10693)

Description Option for disabling a process alarm category.

Selection

- Disc Alm Disabled
- Block Alm Disabled
- Fail Alm Disabled
- Off Spec Alm Disabled
- Maint Alm Disabled
- Check Alm Disabled

Acknowledge Option

Navigation

 Expert → Communication → Resource block → Ack. Option (10691)

Description

Option for automatic acknowledgment of process alarms in a specific category.

Selection

- Disc Alm Auto Ack
- Blk Alm Auto Ack
- Fail Alm Auto Ack
- Off Spec Alm Auto Ack
- Maint Alm Auto Ack
- Check Alm Auto Ack

Additional information*Description*

Use this function to determine whether an alarm must be acknowledged via the field bus host system.

 If the process alarm option has not been enabled in this parameter, this process alarm must only be acknowledged in **Unacknowledged** parameter (→  155).
Current parameter (→  157) indicates the current status of all process alarms.

Write Priority

Navigation

 Expert → Communication → Resource block → Write Priority (10748)

Description

Use this function to enter the priority for the write protection alarm.

User entry

0 to 15

Factory setting

0

Additional information*Description*

If write protection is disabled on the FOUNDATION Fieldbus I/O board, the alarm priority entered here is checked before the status change is transferred to the field bus host system. The alarm priority determines the behavior in the event of an active write protection alarm.

 The alarm is triggered when the write protection is disabled.

Unacknowledged

Navigation	 Expert → Communication → Resource block → Unacknowledged (10745)
Description	Option for manually acknowledging a write protection alarm.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Acknowledged■ Unacknowledged
Factory setting	Uninitialized
Additional information	<i>Description</i>  ■ If a new alarm occurs, the measuring device sets Unacknowledged option. ■ If the alarm has been acknowledged, the user can set Acknowledged option.

Alarm State

Navigation	 Expert → Communication → Resource block → Alarm State (10742)
Description	Displays the status of the write protection alarm. The status indicates whether the write protection alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear-Reported■ Clear-Not Reported■ Active-Reported■ Active-Not Reported

Time Stamp

Navigation	 Expert → Communication → Resource block → Time Stamp (10744)
Description	Displays the time stamp indicating when the analysis of the block was started and when the status change of a write protection alarm that has not yet been communicated was identified. The time stamp is retained until the alarm confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation	 Expert → Communication → Resource block → Subcode (10743)
Description	Displays the specific cause of the write protection alarm, which is to be communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Other■ BlockConfiguration■ LinkConfiguration■ SimulationActive■ LocalOverride■ DeviceFaultState■ DeviceMaintenance■ SensorFailure■ OutputFailure■ MemoryFailure■ LostStaticData■ LostNVData■ ReadbackCheck■ MaintenanceNeeded■ PowerUp■ OutOfService

Discrete Value

Navigation	 Expert → Communication → Resource block → Discrete Value (10746)
Description	Displays the discrete value of the affected parameter at the time at which the write protection alarm was detected.
User interface	<ul style="list-style-type: none">■ State 0■ State 1■ State 2■ State 3■ State 4■ State 5■ State 6■ State 7■ State 8■ State 9■ State 10■ State 11■ State 12■ State 13■ State 14■ State 15■ State 16

ITK Version

Navigation  Expert → Communication → Resource block → ITK Version (10794)

Description Displays the revision status of the Interoperability Test Kits (ITK).

User interface 6

3.5 "Analog inputs" submenu

In the analog input function block (AI function block), the process variables from the transducer block are prepared in terms of control for the subsequent automation functions (e.g. scaling, limit value processing). The automation function is defined by interconnecting the outputs.

Navigation  Expert → Analog inputs

► Analog inputs

► Analog input 1 to 4

→  161

3.5.1 "Analog input 1 to 4" submenu

Navigation  Expert → Analog inputs → Analog input 1 to 4

► Analog input 1 to 4

Block tag (6901-1 to 4)

→  162

Status (6906-1 to 4)

→  168

Value (6907-1 to 4)

→  170

Channel (6902-1 to 4)

→  190

Linearization Type (6905-1 to 4)

→  191

Process Value Filter Time
(6909-1 to 4)

→  196

Block tag

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Block tag (6901–1 to 4)

Description Use this function to enter the Block tag: Used for specifying a "label" for identifying the function block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static Revision

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Static Revision (6973–1 to 4)

Description Displays the Static Revision: Each instance of a static block parameter being accessed with write access is counted (event counter).

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Tag Description

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Tag Description (6974–1 to 4)

Description Use this function to enter the Tag Description: Used for defining a user-specific text for detailed description of the function block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Strategy

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Strategy (6972–1 to 4)

Description Use this function to enter the Strategy: Enables blocks to be grouped by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert Key

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alert Key (6916-1 to 4)
Description	Use this function to enter the Alert Key: Identifies the plant unit where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	1

Target mode

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Target mode (6960-1 to 4)
Description	Use this function to select the Target mode: The selection indicates which operating mode is used for this function block. This mode is generally set by a control application.
Selection	<ul style="list-style-type: none"> ■ ROut ■ RCas ■ Cas ■ Auto ■ Man ■ LO ■ IMan ■ OOS
Factory setting	OOS
Additional information	<p><i>Options</i></p>  Detailed description of the options available for selection: Target mode parameter (→  141)

Actual mode

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Actual mode (6957-1 to 4)
Description	Displays the Actual mode: Under certain conditions, a function block may not work in the operating mode to be used. In this case, the Actual mode shows the actual operating mode in which the function block is currently operating. By comparing the Actual mode with the Target mode, users can see whether it was possible to reach the Target mode (→  163).
User interface	<ul style="list-style-type: none"> ■ ROut ■ RCas ■ Cas ■ Auto ■ Man

- LO
- IMan
- OOS

Additional information*User interface*Detailed description of the options displayed: **Target mode** parameter (→ 141)

Permitted mode**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Permitted mode (6959–1 to 4)

Description

Use this function to select the Permitted mode: The selection defines which operating modes are available in Target mode (→ 163) for the function block. The operating modes that are supported vary depending on the type and function of the block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

- Auto
- OOS

Additional information*Options*Detailed description of the options available for selection: **Target mode** parameter (→ 141)

Normal mode**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Normal mode (6958–1 to 4)

Description

Use this function to select the Normal mode: This is available to enable the user to select the Normal mode from the available operating modes. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

Auto

Additional information*Options*

Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Block Error

Navigation

Expert → Analog inputs → Analog input 1 to 4 → Block Error (6922–1 to 4)

Description

Displays the short text for the Block Error that has occurred in the function block.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Status

Navigation

Expert → Analog inputs → Analog input 1 to 4 → Status (6964–1 to 4)

Description

Displays the status of the input value (PV).

User interface

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited
- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited
- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited

- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- BadNoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurate HighLimit
- Uncertain SensConvNotAccurate Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit

- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Value (6965–1 to 4)
Description	Displays the input value (PV).
User interface	Signed floating-point number

Additional information*Dependency*

The unit is taken from the: **Units index** parameter (→ 180)

Status

Navigation

Expert → Analog inputs → Analog input 1 to 4 → Status (6906-1 to 4)

Description

Displays the status of the output value (OUT).

User interface

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited
- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited
- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Comm WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- Bad NoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited

- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurate HighLimit
- Uncertain SensConvNotAccurate Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLimit
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant

- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Value

Navigation	  Expert → Analog inputs → Analog input 1 to 4 → Value (6907-1 to 4)
Description	Input for the output value (OUT).
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  180)

Simulate Status

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Simulate Status (6967-1 to 4)
Description	Use this function to select the status that is used for the transducer block simulation.
Selection	<ul style="list-style-type: none">■ Bad NonSpecific NotLimited■ Bad NonSpecific LowLimited■ Bad NonSpecific HighLimited■ Bad NonSpecific Constant■ Bad ConfigurationError NotLimited■ Bad ConfigurationError LowLimited■ Bad ConfigurationError HighLimited■ Bad ConfigurationError Constant■ Bad NotConnected NotLimited■ Bad NotConnected LowLimited

- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- BadNoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurat HighLimit
- Uncertain SensConvNotAccurat Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit

- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Factory setting

Bad NonSpecific NotLimited

Simulate Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Simulate Value (6968–1 to 4)
Description	Use this function to enter the value that is used for the transducer block simulation.
User entry	Signed floating-point number
Factory setting	0 %
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  176)

Transducer Status

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Transducer Stat (6969–1 to 4)
Description	Displays the current status of the transducer block.
User interface	<ul style="list-style-type: none">■ Bad NonSpecific NotLimited■ Bad NonSpecific LowLimited■ Bad NonSpecific HighLimited■ Bad NonSpecific Constant■ Bad ConfigurationError NotLimited■ Bad ConfigurationError LowLimited■ Bad ConfigurationError HighLimited■ Bad ConfigurationError Constant■ Bad NotConnected NotLimited■ Bad NotConnected LowLimited■ Bad NotConnected HighLimited■ Bad NotConnected Constant■ Bad DeviceFailure NotLimited■ Bad DeviceFailure LowLimited■ Bad DeviceFailure HighLimited■ Bad DeviceFailure Constant■ Bad SensorFailure NotLimited■ Bad SensorFailure LowLimited■ Bad SensorFailure HighLimited■ Bad SensorFailure Constant■ Bad NoComm WithLastUsableValue NotLimit■ Bad No Com WithLastUsableValue LowLim■ Bad No Com WithLastUsableValue HighLim■ Bad No Com WithLastUsableValue Const■ Bad NoComm WithNoUsableValue NotLimit■ Bad NoComm WithNoUsableValue LowLimit■ BadNoComm WithNoUsableValue HighLimit■ Bad NoComm WithNoUsableValue Constant■ Bad OutOfService NotLimited■ Bad OutOfService LowLimited■ Bad OutOfService HighLimited■ Bad OutOfService Constant■ Uncertain NonSpecific NotLimited

- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurate HighLimit
- Uncertain SensConvNotAccurate Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLimit
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant

- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Transducer Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Transducer Value (6970-1 to 4)
Description	Displays the current value of the transducer block.
User interface	Signed floating-point number
Factory setting	0 %
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  176)

Simulate En/Disable

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Sim. En/Disable (6966-1 to 4)
Description	Use this function to enable or disable the function block simulation.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Disabled■ Active
Factory setting	Uninitialized

EU at 100%

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → EU at 100% (6982-1 to 4)
Description	Use this function to enter the upper limit value of the output value measuring range.
User entry	Signed floating-point number
Factory setting	0 %
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→ 176)

EU at 0%

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → EU at 0% (6981-1 to 4)
Description	Use this function to enter the lower limit value of the output value measuring range.
User entry	Signed floating-point number
Factory setting	0 %
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→ 176)

Units index

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Units index (6983-1 to 4)
Description	Use this function to select the unit for the output value.

Selection	SI units	US units	Imperial units
■ g/s	■ oz/s	■ gal/s (imp)	
■ g/min	■ oz/min	■ gal/min (imp)	
■ g/h	■ oz/h	■ gal/h (imp)	
■ g/d	■ oz/d	■ gal/d (imp)	
■ kg/s	■ lb/s	■ Mgal/s (imp)	
■ kg/min	■ lb/min	■ Mgal/min (imp)	
■ kg/h	■ lb/h	■ Mgal/h (imp)	
■ kg/d	■ lb/d	■ Mgal/d (imp)	
■ t/s	■ STon/s	■ bbl/d (imp;oil)	
■ t/min	■ STon/min	■ bbl/h (imp;oil)	
■ t/h	■ STon/h	■ bbl/min (imp;oil)	
■ t/d	■ STon/d	■ bbl/s (imp;oil)	
■ l/s	■ af/s	■ lb/gal (imp)	
■ l/min	■ af/min	■ lb/bbl (imp;oil)	
■ l/d	■ af/h	■ MMBtu/min	
■ l/h	■ af/d	■ MMBtu/h	
■ hl/s	■ ft ³ /s	■ MMBtu/d	
■ hl/min	■ ft ³ /min	■ MBtu/s	
■ hl/h	■ ft ³ /h	■ MBtu/min	
■ hl/d	■ ft ³ /d	■ MBtu/h	
■ Ml/s	■ fl oz/s (us)	■ MBtu/d	
■ Ml/min	■ fl oz/min (us)	■ MMBtu/s	
■ Ml/h	■ fl oz/h (us)	■ Btu/s	
■ Ml/d	■ fl oz/d (us)	■ Btu/min	
■ m ³ /s	■ gal/s (us)	■ Btu/h	
■ m ³ /min	■ gal/min (us)	■ Btu/day	
■ m ³ /h	■ gal/h (us)	■ Mgal (imp)	
■ m ³ /d	■ gal/d (us)	■ Sgal (imp)	
■ cm ³ /s	■ Mgal/s (us)	■ bbl (imp;oil)	
■ cm ³ /min	■ Mgal/min (us)	■ gal (imp)	
■ cm ³ /h	■ Mgal/h (us)	■ MBtu	
■ cm ³ /d	■ Mgal/d (us)	■ Btu	
■ dm ³ /s	■ bbl/s (us;oil)	■ MMBtu	
■ dm ³ /min	■ bbl/min (us;oil)		
■ dm ³ /h	■ bbl/h (us;oil)		
■ dm ³ /d	■ bbl/d (us;oil)		
■ ml/s	■ bbl/s (us;liq.)		
■ ml/min	■ bbl/min (us;liq.)		
■ ml/h	■ bbl/h (us;liq.)		
■ ml/d	■ bbl/d (us;liq.)		
■ NL/s	■ bbl/s (us;beer)		
■ NL/d	■ bbl/min (us;beer)		
■ NL/h	■ bbl/h (us;beer)		
■ NL/min	■ bbl/d (us;beer)		
■ Nm ³ /s	■ bbl/s (us;tank)		
■ Nm ³ /min	■ bbl/min (us;tank)		
■ Nm ³ /h	■ bbl/h (us;tank)		
■ Nm ³ /d	■ bbl/d (us;tank)		
■ Sm ³ /s	■ kgal/s (us)		
■ Sm ³ /min	■ kgal/min (us)		
■ Sm ³ /h	■ kgal/h (us)		
■ Sm ³ /d	■ kgal/d (us)		
■ MSft ³ /d	■ Sft ³ /s		
■ kg/l	■ Sft ³ /min		
■ kg/m ³	■ Sft ³ /h		
■ kg/dm ³	■ Sft ³ /d		
■ g/cm ³	■ MSft ³ /D		
■ g/m ³	■ lb/ft ³		

- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG20°C
- SG15°C
- K
- °C
- m/s
- bar
- mbar a
- Pa
- MPa
- kPa
- torr
- atm
- %
- kW
- MW
- MJ/h
- GJ/d
- Gcal/h
- MJ/s
- MJ/min
- MJ/d
- kJ/s
- kJ/min
- kJ/h
- kJ/d
- GJ/s
- GJ/min
- GJ/h
- kcal/s
- kcal/min
- kcal/h
- kcal/d
- Mcal/s
- Mcal/min
- Mcal/h
- Mcal/d
- Gcal/s
- Gcal/min
- Gcal/d
- W
- TW
- GW
- mW
- μW
- nW
- pW
- g
- NI
- Nm³
- Sl
- Sm³
- ml
- Ml Mega
- kg
- l
- lb/gal (us)
- lb/bbl (us;tank)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- °F
- °R
- ft/s
- psi
- inH2Og(4°C)
- inH2Og(68°F)
- ftH2Og(68°F)
- hp
- oz
- af
- fl oz (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;tank)
- Sgal (us)
- Sbbl (us;liq.)
- Sft³
- kgal (us)
- lb
- ft³
- gal (us)
- bbl (us;beer)
- STon

- t
- m³
- dm³
- cm³
- hl
- kWh
- MWh
- MJ
- GJ
- kgf/cm²
- GWh
- kcal
- Mcal
- gf/cm²
- kJ
- Gcal

Other units

- mmH2O (4°C)
- mmH2O (68°F)
- inHg (0°C)
- mmHg (0°C)
- mmH2Oa(4°C)
- mmH2Oa(68°F)
- inH2O (4°C)
- inH2O (68°F)
- ftH2O (4°C)
- ftH2O (68°F)

Factory setting %

Additional information *Result*

The selected unit applies for:

- **Simulate Value** parameter (→ 173)
- **Transducer Value** parameter (→ 175)
- **EU at 0%** parameter (→ 176)
- **EU at 100%** parameter (→ 176)

Decimal

Navigation	█ Expert → Analog inputs → Analog input 1 to 4 → Decimal (6980–1 to 4)
Description	Use this function to enter the number of decimal places for the output value.
User entry	-128 to 127
Factory setting	0

EU at 100%

Navigation  Expert → Analog inputs → Analog input 1 to 4 → EU at 100% (6963–1 to 4)

Description Use this function to enter the upper limit value of the input value measuring range from the transducer block (input value).

User entry Signed floating-point number

Factory setting 0

Additional information *Dependency*

 The unit is taken from the: **Units index** parameter (→  180)

EU at 0%

Navigation  Expert → Analog inputs → Analog input 1 to 4 → EU at 0% (6962–1 to 4)

Description Function for entering the lower limit value of the input value measuring range from the transducer block (input value).

User entry Signed floating-point number

Factory setting 0

Additional information *Dependency*

 The unit is taken from the: **Units index** parameter (→  180)

Units index

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Units index (6908–1 to 4)

Description Use this function to select the unit for the input value from the transducer block (input value).

Selection	SI units	US units	Imperial units
■ K	■ mils	■ lbf/in	
■ m	■ °F	■ gal (imp)	
■ m ³	■ °R	■ Btu	
■ Pa s	■ ft	■ LTon	
■ m ² /s	■ in	■ datherm	
■ P	■ bbl (us;liq.)	■ Btu/h	
■ cP	■ Sft ³	■ Btu/day	
■ St	■ in/min	■ Btu/min	
■ cSt	■ oz	■ Btu/s	
■ Wbm	■ STon	■ LTon/d	
■ Ns/m	■ lb/d	■ LTon/h	
■ 1/Jm ³	■ lb/h	■ LTon/min	
■ e/Vm ³	■ lb/min	■ LTon/s	
■ m ³ /C	■ lb/s	■ gal/d (imp)	
■ (1/32 millisecond)/min	■ STon/d	■ gal/h (imp)	
■ °C	■ STon/h	■ gal/min (imp)	
■ '	■ STon/min	■ gal/s (imp)	
■ "	■ STon/s	■ lb/gal (imp)	
■ rad	■ mile	■ Mgal/min (imp)	
■ °	■ yd	■ Mgal/h (imp)	
■ gon	■ ft ²	■ Mgal/d (imp)	
■ µm	■ in ²	■ kgal/d (imp)	
■ mm	■ mile ²	■ kgal/h (imp)	
■ cm ³	■ yd ²	■ kgal/min (imp)	
■ dm ³	■ ft ³	■ kgal/s (imp)	
■ hl	■ gal (us)	■ µgal/d (imp)	
■ l	■ quart	■ µgal/h (imp)	
■ ml	■ pint	■ µgal/min (imp)	
■ s	■ yd ³	■ µgal/s (imp)	
■ min	■ mile ³	■ mgal/d (imp)	
■ d	■ in ³	■ mgal/h (imp)	
■ h	■ bushel	■ mgal/min (imp)	
■ ks	■ bbl (us;oil)	■ mgal/s (imp)	
■ µs	■ ft/s	■ Mgal/s (imp)	
■ ms	■ ft/h	■ µbbl/d (us;oil)	
■ m/h	■ lb	■ µbbl/h (us;oil)	
■ m/s	■ ft/min	■ µbbl/min (us;oil)	
■ mm/s	■ in/h	■ µbbl/s (us;oil)	
■ Hz	■ in/s	■ kImpGal	
■ g	■ yd/h	■ Btu/lb	
■ kg	■ yd/min	■ oz/ft	
■ GWh	■ yd/s		
■ J	■ lb/in ³		
■ kWh	■ lb/gal (us)		
■ MWh	■ STon/yd ³		
■ kcal	■ psi		
■ Mcal	■ psi a		
■ kW	■ psi g		
■ MW	■ ftlbf		
■ W	■ hp		
■ MJ/h	■ lb/ft ³		
■ mV	■ MPH		
■ Ohm	■ ft ³ /d		
■ pF	■ ft ³ /h		
■ V	■ ft ³ /min		
■ Ml Mega	■ ft ³ /s		
■ mbar a	■ Sft ³ /h		
■ bar	■ Sft ³ /min		

- dB
- kPa a
- kPa g
- MPa a
- MPa g
- Pa a
- Pa g
- g/d
- g/h
- g/min
- g/s
- kg/d
- kg/h
- kg/min
- kg/s
- cm
- km
- nm
- pm
- a
- ha
- cm²
- dm²
- km²
- m²
- mm²
- mm³
- cl
- t
- kg/m³
- kg/dm³
- g/cm³
- g/m³
- kg/l
- kgf/cm²
- GJ
- kJ
- MJ
- km/h
- kt
- m/s²
- GHz
- kHz
- MHz
- 1/min
- 1/s
- THz
- rad/s
- 1/s²
- Mg
- mg
- g/l
- g/ml
- Mg/m³
- t/m³
- mg/m
- tex
- kg/m
- kgm/s
- gal/d (us)
- gal/h (us)
- gal/min (us)
- gal/s (us)
- Mgal/d (us)
- bbl/d (us;oil)
- bbl/h (us;oil)
- bbl/min (us;oil)
- bbl/s (us;oil)
- Mgal/h (us)
- Mgal/min (us)
- Mgal/s (us)
- Mgal (us)
- af
- af/d
- af/h
- af/min
- af/s
- bbl/d (us;beer)
- bbl/h (us;beer)
- bbl/min (us;beer)
- bbl/s (us;beer)
- kgal/d (us)
- kgal/h (us)
- kgal/min (us)
- kgal/s (us)
- µgal/d (us)
- µgal/h (us)
- µgal/min (us)
- µgal/s (us)
- mgal/d (us)
- mgal/h (us)
- mgal/min (us)
- mgal/s (us)
- Mbbl/d (us;oil)
- Mbbl/h (us;oil)
- Mbbl/min (us;oil)
- Mbbl/s (us;oil)
- mbbl/d (us;oil)
- mbbl/h (us;oil)
- mbbl/min (us;oil)
- mbbl/s (us;oil)
- kft³/d
- kft³/h
- kft³/min
- kft³/s
- mft³/d
- mft³/h
- mft³/min
- mft³/s
- kbbl(US Beer)/d
- kbbl(US Beer)/h
- kbbl(US Beer)/min
- ubbl(US Beer)/min
- ubbl(US Beer)/s
- mbbl(US Beer)/d
- mbbl(US Beer)/h
- mbbl(US Beer)/min
- mbbl(US Beer)/s

- kgm²
- kgm²/s
- kNm
- MNm
- mNm
- Nm
- kN
- MN
- μ N
- mN
- N
- mN/m
- N/m
- atm
- GPa
- hPa
- kPa
- MPa
- μ Pa
- mPa
- Pa
- torr
- gf/cm²
- cal
- EJ
- mJ
- PJ
- TJ
- TWh
- Wh
- GW
- μ W
- mW
- nW
- pW
- TW
- Mcal/h
- kcal/d
- kcal/h
- kcal/min
- kcal/s
- Mcal/d
- Mcal/min
- Mcal/s
- kJ/d
- kJ/h
- kJ/min
- kJ/s
- A
- mA
- kA
- μ A
- nA
- pA
- C
- kC
- MC
- μ C
- nC
- kgal (us)
- ac-in/d
- ac-in/h
- ac-in/m
- ac-in/s
- Mft³/d
- ac-in
- Mft³
- inH2Oa
- inH2Og
- inH2O a(4°C)
- inH2Og(4°C)
- inH2O a(68°F)
- inH2Og(68°F)
- ftH2Oa
- ftH2Og
- ftH2O a(4°C)
- ftH2Og(4°C)
- ftH2O a(68°F)
- ftH2Og(68°F)
- inHga
- inHgg
- inHg a(0°C)
- inHgg(0°C)
- klb(US)/d
- klb(US)/h
- klb(US)/min
- klb(US)/s
- MSft³/D
- mils/yr
- ft/s²
- MLB/H
- lbf-in/deg

- pC
- Ah
- W/mK
- m2K/W
- W/m²K
- J/K
- kJ/K
- J/(kgK)
- kJ/(kgK)
- J/kg
- kJ/kg
- MJ/kg
- C/cm³
- C/m³
- C/mm³
- kC/m³
- μ C/m³
- mC/m³
- C/cm²
- C/m²
- C/mm²
- kC/m²
- μ C/m²
- mC/m²
- kV/m
- MV/m
- μ V/m
- mV/m
- V/cm
- V/m
- kV
- MV
- μ V
- F
- μ F
- mF
- nF
- F/m
- A/cm²
- kA/m²
- MA/m²
- A/cm
- A/m
- kA/m
- μ T
- mT
- nT
- T
- mWb
- Wb
- kWb/m
- Wb/m
- H
- μ H
- mH
- nH
- pH
- H/m
- μ H/m

- nH/m
- Am²
- GOhm
- kOhm
- MOhm
- μ Ohm
- mOhm
- kS
- μ S
- μ S/cm
- mS
- S
- t/d
- t/h
- t/min
- t/s
- %
- m³/d
- m³/h
- m³/min
- m³/s
- GOhmm
- kOhmm
- MOhmm
- μ Ohmm
- mOhmm
- nOhmm
- Ohmcm
- Ohmm
- kS/m
- MS/m
- μ S/mm
- mS/cm
- S/m
- sr
- l/d
- l/h
- l/min
- l/s
- Ml/d
- kW/m²
- W/(sr·m²)
- cd
- cd/m²
- lm
- lm/m²
- lm/W
- lmh
- lms
- lx
- lxs
- μ W/m²
- mW/m²
- pW/m²
- Pas/m³
- Pas/m
- ppm
- MJ/d
- MJ/min

- MJ/s
- cm³/d
- cm³/h
- cm³/min
- cm³/s
- Nm³
- Nm³/d
- Nm³/h
- Nm³/min
- Nm³/s
- Sm³
- Sm³/d
- Sm³/h
- Sm³/min
- Sm³/s
- NI
- NI/d
- NI/h
- NI/min
- NI/s
- Sl
- ml/min
- B
- ppb
- ppt
- Balling
- km³/d
- km³/h
- km³/min
- km³/s
- Mm³/d
- Mm³/h
- Mm³/min
- Mm³/s
- µm³/d
- µm³/h
- µm³/min
- µm³/s
- mm³/d
- mm³/h
- mm³/min
- mm³/s
- kl/d
- kl/h
- kl/min
- kl
- Sl/d
- Sl/h
- Sl/min
- Sl/s
- kL/s
- Ml/h
- Ml/min
- Mm³/d
- Mm³
- GPa a
- GPa g
- mPa a
- mPa g

- μPa a
- μPa g
- hPa a
- hPa g
- gf/cm² a
- gf/cm² g
- kgf/cm² a
- kgf/cm² g
- mBarg
- μbar
- Gy
- kcal/kg
- mGy
- mSv
- rad
- rem
- Sv
- Bq
- kBq
- MBq
- cnt/s
- MSft³/d
- SCCM
- dm
- mm/yr
- g/m
- $\mu\text{g}/\text{m}^3$
- $\mu\text{g}/\text{l}$
- mg/m³
- kmol
- μmol
- mmol
- mol
- mol/dm³
- mol/m³
- mol/l
- cm³/mol
- dm³/mol
- m³/mol
- g/mol
- kg/mol
- l/mol
- mmol/kg
- mol/kg
- mg/l
- $\mu\text{S}/\text{m}$
- mS/m
- nS/cm
- S/cm
- kOhmcm
- MOhmcm
- l/m³
- L/m
- $\mu\text{L}/\text{L}$
- ml/m³
- ml/l
- %Sat
- % sol/vol
- % sol/mass

- %vol
- WT-%
- J/mol
- kJ/mol
- J/(molK)
- Bq/kg
- kBq/kg
- MBq/kg
- mV/K
- V/K
- J/g
- mV/pH
- pH
- pH/°C
- mV/%
- %/s
- %/V
- nA/ppm
- 1/32 ms
- 1/H
- /cm
- 1/K
- 1/m
- 1/mm
- A/hPa
- A/Pa
- Nm²/A
- Pa/A
- pA/hPa
- C/kg
- mC/kg
- dyne-cm/deg
- newton-m/deg
- bar a
- bar g

Custom-specific units
PV/Sec

Factory setting

K

Additional information

Result

The selected unit applies for:

- **Value** parameter (→ [167](#))
- **Value** parameter (→ [170](#))
- **EU at 100%** parameter (→ [176](#))
- **EU at 0%** parameter (→ [176](#))
- **Low Cutoff** parameter (→ [193](#))
- **High High Limit** parameter (→ [201](#))
- **Float Value** parameter (→ [205](#))
- **High Limit** parameter (→ [202](#))
- **Float Value** parameter (→ [207](#))
- **Low Limit** parameter (→ [203](#))
- **Float Value** parameter (→ [208](#))
- **Low Low Limit** parameter (→ [203](#))
- **Float Value** parameter (→ [210](#))

Decimal

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Decimal (6961–1 to 4)

Description Use this function to select the number of decimal places for the input value from the transducer block (input value).

User entry -128 to 127

Factory setting 0

Grant

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Grant (6926–1 to 4)

Description Option for releasing certain access authorizations of the field bus host system on the device.

Selection

- Program
- Tune
- Alarm
- Local
- Operate
- Service
- Diagnostic

Deny

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Deny (6925–1 to 4)

Description Option for restricting certain access authorizations of the field bus host system on the device.

Selection

- Program Denied
- Tune Denied
- Alarm Denied
- Local
- Operate Denied

I/O Options

Navigation  Expert → Analog inputs → Analog input 1 to 4 → I/O Options (6941–1 to 4)

Description Option for activating the low flow cut off.

Selection Low Cutoff

Additional information *Description*

The limit value for the low flow cut off is defined in **Low Cutoff** parameter
(→ 193).

Channel**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Channel (6902–1 to 4)

Description

Use this function to select the input value that should be processed in the analog input function block.

Selection

- Uninitialized
- Mass flow
- Flow velocity
- Volume flow
- Corrected volume flow
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *
- Reynolds number *
- Totalizer 1
- Totalizer 2
- Totalizer 3

Factory setting

Uninitialized

Status Options**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Status Options (6971–1 to 4)

Prerequisite

The measuring device must be in the OOS operating mode so that the parameter can be edited.

Description

Use this function to select an option for the status of the output value that is supported by the analog input block.

Selection

- Propagate Fault Fwd
- Uncertain if Limited
- Bad if Limited
- Uncertain if Man.

* Visibility depends on order options or device settings

Additional information*Options*

■ Propagate Fault Fwd

If the measuring device has the status **Bad DeviceFailure** or **Bad SensorFailure**, the device continues to measure and no alarm is triggered. The use of this substatus in the output value (OUT) is defined by **Propagate Fault Fwd** option. With the aid of this option, the user/operator can specify whether the alarm generation (sending an alarm) is triggered by the block or is forwarded downstream.

■ Uncertain if Limited

If the measured or calculated value reaches a limit value, **Uncertain if Limited** option is used for the output status.

■ Bad if Limited

If the measured value exceeds or falls below an upper or lower limit value, **Bad if Limited** option is used as the output status.

■ Uncertain if Man.

If the Actual mode of the function block is in the **Man** option operating mode, **Uncertain if Man.** option is used as the output status.

Linearization Type**Navigation**
 Expert → Analog inputs → Analog input 1 to 4 → Lin Type (6905–1 to 4)
Description

Use this function to select the type of linearization of the input or simulation value.

Selection

■ Uninitialized

■ Direct

■ Indirect

■ Indirect Sq Root

Factory setting

Uninitialized

Additional information*"Uninitialized" option*

The function block does not switch to Auto operating mode.

"Direct" option

The measured value from the transducer block (input value) bypasses the linearization function and is routed unchanged through the analog input function block ($Xd_Scale = Out_Scale$). This is selected if the input value already has the required physical units.

PV = Input value

The units in Units index (→  176) (Xd_Scale) and Units index (→  180) (Out_Scale) must be the same. Otherwise, the function block will remain in the OOS operating mode and the BlockConfiguration block error is displayed in Block Error (→  165).

"Indirect" option

The measured value from the transducer block (input value) is linearly rescaled via the Xd_Scale input scaling to the required Out_Scale output range.

$$PV = \frac{X}{100} \cdot (Y - Z) - Z$$

A0024820

PV Primary value

X Value (→ 196) (Field_Val)

Y EU at 100% (→ 180) (Out_Scale)

Z EU at 0% (→ 180) (Out_Scale)

"Indirect Sq Root" option

The measured value from the transducer block (input value) is rescaled via the Xd_Scale parameter group and recalculated using a root function. It is then rescaled again to the required output range via the Out_Scale parameter group.

$$PV = \sqrt{\frac{X}{100}} \cdot (Y - Z) - Z$$

A0024847

PV Primary value

X Value (→ 196) (Field_Val)

Y EU at 100% (→ 180) (Out_Scale)

Z EU at 0% (→ 180) (Out_Scale)


Example

- System unit in transducer block: kg/h
- Sensor measuring range: 0 to 30 kg/h
- Output range for the automation system: 0 to 100 %

The analog input function block must be configured as follows:

1. In **Channel** parameter (→ 190), select **Mass flow** option.
2. In **Linearization Type** parameter (→ 191), select **Indirect** option.
 - ↳ The "Volume Flow" process variable of the transducer block "Flow" is linearly rescaled in the AI block to the required Out_Scale output range via the Xd_Scale input scaling.
3. In the Xd_Scale parameter group:
 - ↳ **EU at 0%** parameter (→ 176), enter the value 0.
 - In **EU at 100%** parameter (→ 176), enter the value 30.
 - In **Units index** parameter (→ 176), select **kg/h** option.
4. In the Out_Scale parameter group:
 - ↳ **EU at 0%** parameter (→ 180), enter the value 0.
 - In **EU at 100%** parameter (→ 180), enter the value 100.
 - In **Units index** parameter (→ 180), select **%** option.

The result is that an input value of 15 kg/h, for example, outputs a value of 50 % via the **Value** parameter (→ 170).



8 Engineering unit in kg/h

Low Cutoff

Navigation Expert → Analog inputs → Analog input 1 to 4 → Low Cutoff (6956–1 to 4)

Description Use this function to enter a limit value for low flow cut off.

User entry Positive floating-point number

Factory setting 0

Additional information *Description*

If the converted input value (PV) falls below this limit value, then it is set to zero.

The low flow cut off is enabled via **I/O Options** parameter (→ 189).

Dependency

The unit is taken from the: **Units index** parameter (→ 180)

Status

Navigation Expert → Analog inputs → Analog input 1 to 4 → Status (6923–1 to 4)

Description Displays the status of the unprocessed measured value from the device, which reflects the status of the transducer before signal transmission.

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited
- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited

- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- BadNoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurat HighLimit
- Uncertain SensConvNotAccurat Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit

- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Value (6924–1 to 4)
Description	Displays the unprocessed measured value from the device as a % of the primary value (PV).
User interface	Signed floating-point number

Process Value Filter Time

Navigation	  Expert → Analog inputs → Analog input 1 to 4 → PV Filter Time (6909–1 to 4)
Description	Use this function to enter the filter time specification for the filtering of the unconverted input value (PV).
User entry	Positive floating-point number
Factory setting	0 s
Additional information	<i>Factory setting</i>  If the value 0 s is entered, filtering will not be performed.

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6978–1 to 4)
Description	Option for manually acknowledging an update of the static block parameter.
Selection	<ul style="list-style-type: none">▪ Uninitialized▪ Acknowledged▪ Unacknowledged
Factory setting	Uninitialized
Additional information	<i>Description</i>  ▪ If a new diagnostic event occurs, the measuring device sets Unacknowledged option. ▪ If the diagnostic event has been acknowledged, the user can set Acknowledged option.

Update State

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Update State (6979–1 to 4)
Description	Displays the status of an update of the static block parameter. The status indicates whether the update was communicated or not.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Reported■ Not Reported

Time Stamp

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6977–1 to 4)
Description	Displays the time stamp indicating when the analysis of the block was started and when a status change of an update to the static block parameter that has not yet been communicated was identified. The time stamp is retained until the update confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Static revision

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Static revision (6976–1 to 4)
Description	Displays the Static revision: Each instance of a static block parameter being accessed with write and communicate access due to an update is counted (event counter).
User interface	0 to 65 535

Relative Index

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Relative Index (6975–1 to 4)
Description	Displays the relative index of the static block parameter that triggered the alarm (OD index minus field bus start index).
User interface	0 to 65 535

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6920-1 to 4)
Description	Description for manually acknowledging a block alarm.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Acknowledged■ Unacknowledged
Factory setting	Uninitialized
Additional information	<i>Description</i> If Blk Alm Auto Ack option is not enabled in Acknowledge Option parameter (→  200), the process alarm must be manually acknowledged in this parameter.  <ul style="list-style-type: none">■ If a new alarm occurs, the measuring device sets Unacknowledged option.■ If the alarm has been acknowledged, the user can set Acknowledged option.

Alarm State

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm State (6917-1 to 4)
Description	Displays the status of the block alarm. The status indicates whether the block alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear-Reported■ Clear-Not Reported■ Active-Reported■ Active-Not Reported

Time Stamp

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6919-1 to 4)
Description	Displays the time stamp indicating when the analysis of the block was started and when a status change of the block alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Subcode (6918-1 to 4)
Description	Displays the specific cause of the block alarm.
User interface	<ul style="list-style-type: none">■ Other■ BlockConfiguration■ LinkConfiguration■ SimulationActive■ LocalOverride■ DeviceFaultState■ DeviceMaintenance■ SensorFailure■ OutputFailure■ MemoryFailure■ LostStaticData■ LostNVData■ ReadbackCheck■ MaintenanceNeeded■ PowerUp■ OutOfService

Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Value (6921-1 to 4)
Description	Displays the value of the affected parameter at the time at which the block alarm was detected.
User interface	0 to 255

Current

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Current (6912-1 to 4)
Description	Use this function to view the current status of the process alarms.
User interface	<ul style="list-style-type: none">■ HiHi Alarm■ Hi Alarm■ LoLo Alarm■ Lo Alarm■ Block Alarm

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6914–1 to 4)
Description	Displays an unacknowledged process alarm.
User interface	<ul style="list-style-type: none">▪ HiHi Alarm Unack▪ Hi Alm Unack▪ LoLo Alm Unack▪ Lo Alm Unack▪ Block Alm Unack

Unreported

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unreported (6915–1 to 4)
Description	Displays a process alarm that has not been communicated.
User interface	<ul style="list-style-type: none">▪ HiHi Alm Unrep▪ Hi Alm Unrep▪ LoLo Alm Unrep▪ Lo Alm Unrep▪ Block Alm Unrep

Disabled

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Disabled (6913–1 to 4)
Description	Option for disabling a process alarm category.
Selection	<ul style="list-style-type: none">▪ HiHi Alm Disabled▪ Hi Alm Disabled▪ LoLo Alm Disabled▪ Lo Alm Disabled▪ Block Alm Disabled

Acknowledge Option

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Ack. Option (6910–1 to 4)
Description	Option for automatic acknowledgment of process alarms in a specific category.
Selection	<ul style="list-style-type: none">▪ HiHi Alm Auto Ack▪ Hi Alm Auto Ack▪ LoLo Alm Auto Ack▪ Lo Alm Auto Ack

- Blk Alm Auto Ack
- Fail Alm Auto Ack
- Off Spec Alm Auto Ack
- Maint Alm Auto Ack
- Check Alm Auto Ack

Additional information*Description*

Use this function to determine whether an alarm must be acknowledged via the field bus host system.

 If the process alarm option has not been enabled in this parameter, this process alarm must only be acknowledged in **Unacknowledged** parameter (→ 200). **Current** parameter (→ 199) indicates the current status of all process alarms.

Alarm Hysteresis

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm Hysteresis (6911–1 to 4)
Description	Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.
User entry	0.000000 to 50.0000 %
Factory setting	0 %

High High Priority

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Hi Hi Priority (6938–1 to 4)
Description	Use this function to enter the priority for the upper alarm limit, which determines the behavior in the event of an active limit value violation.
User entry	0 to 15
Factory setting	0

High High Limit

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → High High Limit (6937–1 to 4)
Description	Use this function to enter the value for the upper alarm limit.
User entry	Signed floating-point number
Factory setting	0

Additional information*Dependency*

The unit is taken from the: **Units index** parameter (→ 180)

High Priority

Navigation

Expert → Analog inputs → Analog input 1 to 4 → High Priority (6940–1 to 4)

Description

Use this function to enter the priority for the upper early warning limit, which determines the behavior in the event of an active limit value violation.

User entry

0 to 15

Factory setting

0

High Limit

Navigation

Expert → Analog inputs → Analog input 1 to 4 → High Limit (6939–1 to 4)

Description

Use this function to enter the value for the upper early warning limit.

User entry

Signed floating-point number

Factory setting

0

Additional information*Dependency*

The unit is taken from the: **Units index** parameter (→ 180)

Low Priority

Navigation

Expert → Analog inputs → Analog input 1 to 4 → Low Priority (6955–1 to 4)

Description

Use this function to enter the priority for the lower early warning limit, which determines the behavior in the event of an active limit value violation.

User entry

0 to 15

Factory setting

0

Low Limit

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Low Limit (6947–1 to 4)
Description	Use this function to enter the value for the lower early warning limit.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  180)

Low Low Priority

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Low Low Priority (6954–1 to 4)
Description	Use this function to enter the priority for the lower alarm limit, which determines the behavior in the event of an active limit value violation.
User entry	0 to 15
Factory setting	0

Low Low Limit

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Low Low Limit (6953–1 to 4)
Description	Use this function to enter the value for the lower alarm limit.
User entry	Signed floating-point number
Factory setting	0
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  180)

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6935–1 to 4)
Description	Option for manually acknowledging a process alarm that has exceeded the upper alarm limit (High High Limit (→  201)).

Selection	<ul style="list-style-type: none">■ Uninitialized■ Acknowledged■ Unacknowledged
Factory setting	Uninitialized
Additional information	<p><i>Description</i></p> <p>If HiHi Alm Auto Ack option is not enabled in Acknowledge Option parameter (→ 200), the process alarm must be manually acknowledged in this parameter.</p> <p> ■ If a new alarm occurs, the measuring device sets Unacknowledged option. ■ If the alarm has been acknowledged, the user can set Acknowledged option.</p>

Alarm State

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm State (6932-1 to 4)
Description	Displays the status of the process alarm for the upper alarm limit. The status indicates whether the process alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear-Reported■ Clear-Not Reported■ Active-Reported■ Active-Not Reported

Time Stamp

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6934-1 to 4)
Description	Displays the time stamp of the process alarm for the upper alarm limit. This records the time at which analysis of the block was started and at which a status change of the process alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Subcode (6933-1 to 4)
Description	Displays the specific cause of the process alarm for the upper alarm limit.
User interface	<ul style="list-style-type: none">■ Other■ BlockConfiguration■ LinkConfiguration

- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Float Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Float Value (6936–1 to 4)
Description	Displays the value of the affected parameter at the time at which the process alarm for the upper alarm limit was triggered.
User interface	Signed floating-point number
Additional information	<p><i>Dependency</i></p>  The unit is taken from the: Units index parameter (→  180)

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6930–1 to 4)
Description	Option for manually acknowledging a process alarm that has exceeded the upper early warning limit (High Limit (→  202)).
Selection	<ul style="list-style-type: none"> ■ Uninitialized ■ Acknowledged ■ Unacknowledged
Factory setting	Uninitialized
Additional information	<p><i>Description</i></p> <p>If Hi Alm Auto Ack option is not enabled in Acknowledge Option parameter (→  200), the process alarm must be manually acknowledged in this parameter.</p>  <ul style="list-style-type: none"> ■ If a new alarm occurs, the measuring device sets Unacknowledged option. ■ If the alarm has been acknowledged, the user can set Acknowledged option.

Alarm State

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Alarm State (6927–1 to 4)

Description Displays the status of the process alarm for the upper early warning limit. The status indicates whether the process alarm is active and whether it has already been communicated to the field bus host system.

User interface

- Uninitialized
- Clear-Reported
- Clear-Not Reported
- Active-Reported
- Active-Not Reported

Time Stamp

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6929–1 to 4)

Description Displays the time stamp of the process alarm for the upper early warning limit. This records the time at which analysis of the block was started and at which a status change of the process alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.

User interface

Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Subcode (6928–1 to 4)

Description Displays the specific cause of the process alarm for the upper early warning limit.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Float Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Float Value (6931–1 to 4)
Description	Displays the value of the affected parameter at the time at which the process alarm for the upper early warning limit was triggered.
User interface	Signed floating-point number
Additional information	<p><i>Dependency</i></p>  The unit is taken from the: Units index parameter (→  180)

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6945–1 to 4)
Description	Option for manually acknowledging a process alarm that has exceeded the lower early warning limit (Low Limit (→  203)).
Selection	<ul style="list-style-type: none"> ▪ Uninitialized ▪ Acknowledged ▪ Unacknowledged
Factory setting	Uninitialized
Additional information	<p><i>Description</i></p> <p>If Lo Alm Auto Ack option is not enabled in Acknowledge Option parameter (→  200), the process alarm must be manually acknowledged in this parameter.</p>  <ul style="list-style-type: none"> ▪ If a new alarm occurs, the measuring device sets Unacknowledged option. ▪ If the alarm has been acknowledged, the user can set Acknowledged option.

Alarm State

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm State (6942–1 to 4)
Description	Displays the status of the process alarm for the lower early warning limit. The status indicates whether the process alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none"> ▪ Uninitialized ▪ Clear-Reported ▪ Clear-Not Reported ▪ Active-Reported ▪ Active-Not Reported

Time Stamp

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6944–1 to 4)

Description Displays the time stamp of the process alarm for the lower early warning limit. This records the time at which analysis of the block was started and at which a status change of the process alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.

User interface Days (d), hours (h), minutes (m), seconds (s)

Subcode

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Subcode (6943–1 to 4)

Description Displays the specific cause of the process alarm for the lower early warning limit.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Float Value

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Float Value (6946–1 to 4)

Description Displays the value of the affected parameter at the time at which the process alarm for the lower early warning limit was triggered.

User interface Signed floating-point number

Additional information *Dependency*

 The unit is taken from the: **Units index** parameter (→  180)

Unacknowledged

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Unacknowledged (6951–1 to 4)
Description	Option for manually acknowledging a process alarm that has exceeded the lower alarm limit (Low Low Limit (→  203)).
Selection	<ul style="list-style-type: none"> ■ Uninitialized ■ Acknowledged ■ Unacknowledged
Factory setting	Uninitialized
Additional information	<p><i>Description</i></p> <p>If LoLo Alm Auto Ack option is not enabled in Acknowledge Option parameter (→  200), the process alarm must be manually acknowledged in this parameter.</p> <p> ■ If a new alarm occurs, the measuring device sets Unacknowledged option. ■ If the alarm has been acknowledged, the user can set Acknowledged option.</p>

Alarm State

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm State (6948–1 to 4)
Description	Displays the status of the process alarm for the lower alarm limit. The status indicates whether the process alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none"> ■ Uninitialized ■ Clear-Reported ■ Clear-Not Reported ■ Active-Reported ■ Active-Not Reported

Time Stamp

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Time Stamp (6950–1 to 4)
Description	Displays the time stamp of the process alarm for the lower alarm limit. This records the time at which analysis of the block was started and at which a status change of the process alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Subcode


Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Subcode (6949–1 to 4)
Description	Displays the specific cause of the process alarm for the lower alarm limit.
User interface	<ul style="list-style-type: none">▪ Other▪ BlockConfiguration▪ LinkConfiguration▪ SimulationActive▪ LocalOverride▪ DeviceFaultState▪ DeviceMaintenance▪ SensorFailure▪ OutputFailure▪ MemoryFailure▪ LostStaticData▪ LostNVData▪ ReadbackCheck▪ MaintenanceNeeded▪ PowerUp▪ OutOfService

Float Value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Float Value (6952–1 to 4)
Description	Displays the value of the affected parameter at the time at which the process alarm for the lower alarm limit was triggered.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the: Units index parameter (→  180)

3.6 "Discrete inputs" submenu


Navigation   Expert → Discrete inputs



3.6.1 "Discrete input 1 to 2" submenu

Navigation

Expert → Discrete inputs → Discrete input 1 to 2



Block tag

Navigation

Expert → Discrete inputs → Discrete input 1 to 2 → Block tag (6851-1 to 2)

Description

Use this function to enter the Block tag: Used for specifying a "label" for identifying the function block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static Revision

Navigation

Expert → Discrete inputs → Discrete input 1 to 2 → Static Revision (6884-1 to 2)

Description

Displays the Static Revision: Each instance of a static block parameter being accessed with write access is counted (event counter).

User interface

0 to FFFF

Additional information

Description

Static parameters are parameters that are not changed by the process.

Tag Description

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Tag Description (6885–1 to 2)
Description	Use this function to enter the Tag Description: Used for defining a user-specific text for detailed description of the function block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Strategy

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Strategy (6883–1 to 2)
Description	Use this function to enter the Strategy: Enables blocks to be grouped by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert Key

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Alert Key (6846–1 to 2)
Description	Use this function to enter the Alert Key: Identifies the plant unit where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	1

Target mode

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Target mode (6873–1 to 2)
Description	Use this function to select the Target mode: The selection indicates which operating mode is used for this function block. This mode is generally set by a control application.
Selection	<ul style="list-style-type: none">■ ROut■ RCas■ Cas■ Auto■ Man■ LO■ IMan■ OOS

Factory setting OOS

Additional information *Options*



Detailed description of the options available for selection: **Target mode** parameter
 (→ [图 141](#))

Actual mode

Navigation Expert → Discrete inputs → Discrete input 1 to 2 → Actual mode (6870–1 to 2)

Description Displays the Actual mode: Under certain conditions, a function block may not work in the operating mode to be used. In this case, the Actual mode shows the actual operating mode in which the function block is currently operating. By comparing the Actual mode with the Target mode, users can see whether it was possible to reach the Target mode (→ [图 212](#)).

User interface

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Additional information *User interface*



Detailed description of the options available for selection: **Target mode** parameter
 (→ [图 141](#))

Permitted mode

Navigation Expert → Discrete inputs → Discrete input 1 to 2 → Permitted mode (6872–1 to 2)

Description Use this function to select the Permitted mode: The selection defines which operating modes are available in Target mode (→ [图 212](#)) for the function block. The operating modes that are supported vary depending on the type and function of the block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

- Auto
- OOS

Additional information*Options*

Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Normal mode**Navigation**

Expert → Discrete inputs → Discrete input 1 to 2 → Normal mode (6871–1 to 2)

Description

Use this function to select the Normal mode: This is available to enable the user to select the Normal mode from the available operating modes. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Additional information*Options*

Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Block Error**Navigation**

Expert → Discrete inputs → Discrete input 1 to 2 → Block Error (6857–1 to 2)

Description

Displays the short text for the Block Error that has occurred in the function block.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Status

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Status (6875-1 to 2)
Description	Displays the status of the discrete input value (PV).
User interface	<ul style="list-style-type: none">▪ Bad NonSpecific NotLimited▪ Bad NonSpecific LowLimited▪ Bad NonSpecific HighLimited▪ Bad NonSpecific Constant▪ Bad ConfigurationError NotLimited▪ Bad ConfigurationError LowLimited▪ Bad ConfigurationError HighLimited▪ Bad ConfigurationError Constant▪ Bad NotConnected NotLimited▪ Bad NotConnected LowLimited▪ Bad NotConnected HighLimited▪ Bad NotConnected Constant▪ Bad DeviceFailure NotLimited▪ Bad DeviceFailure LowLimited▪ Bad DeviceFailure HighLimited▪ Bad DeviceFailure Constant▪ Bad SensorFailure NotLimited▪ Bad SensorFailure LowLimited▪ Bad SensorFailure HighLimited▪ Bad SensorFailure Constant▪ Bad NoComm WithLastUsableValue NotLimit▪ Bad No Com WithLastUsableValue LowLim▪ Bad No Com WithLastUsableValue HighLim▪ Bad No Com WithLastUsableValue Const▪ Bad NoComm WithNoUsableValue NotLimit▪ Bad NoComm WithNoUsableValue LowLimit▪ BadNoComm WithNoUsableValue HighLimit▪ Bad NoComm WithNoUsableValue Constant▪ Bad OutOfService NotLimited▪ Bad OutOfService LowLimited▪ Bad OutOfService HighLimited▪ Bad OutOfService Constant▪ Uncertain NonSpecific NotLimited▪ Uncertain NonSpecific LowLimited▪ Uncertain NonSpecific HighLimited▪ Uncertain NonSpecific Constant▪ Uncertain LastUsableValue NotLimited▪ Uncertain LastUsableValue LowLimited▪ Uncertain LastUsableValue HighLimited▪ Uncertain LastUsableValue Constant▪ Uncertain SubstituteValue NotLimited▪ Uncertain SubstituteValue LowLimited▪ Uncertain SubstituteValue HighLimited▪ Uncertain SubstituteValue Constant▪ Uncertain initialValue NotLimited▪ Uncertain initialValue LowLimited▪ Uncertain initialValue HighLimited▪ Uncertain initialValue Constant▪ Uncertain SensConvNotAccurate NoLimit▪ Uncertain SensConvNotAccurate LowLimit▪ Uncertain SensConvNotAccurat HighLimit▪ Uncertain SensConvNotAccurat Const

- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited

- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Value

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Value (6876–1 to 2)

Description Displays the discrete process variable that is used for the block implementation.

User interface

- State 0
- State 1
- State 2
- State 3
- State 4
- State 5
- State 6
- State 7
- State 8
- State 9
- State 10
- State 11
- State 12
- State 13
- State 14
- State 15
- State 16

Status

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → Status (6853–1 to 2)

Description Displays the status of the discrete output value.

User interface

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited

- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited
- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- BadNoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurat HighLimit
- Uncertain SensConvNotAccurat Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit

- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Value

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Value (6854–1 to 2)

Description Use this function to select the discrete output value.

Selection

- State 0
- State 1
- State 2
- State 3
- State 4
- State 5
- State 6
- State 7
- State 8
- State 9
- State 10
- State 11
- State 12
- State 13
- State 14
- State 15
- State 16

Factory setting

State 0

Simulate Status

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Simulate Status (6878–1 to 2)

Description Use this function to select the status that is used for the transducer block simulation.

Selection

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited
- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited
- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit

- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- BadNoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurat HighLimit
- Uncertain SensConvNotAccurat Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLim
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const

- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Factory setting

Bad NonSpecific NotLimited

Simulate Value

Navigation Expert → Discrete inputs → Discrete input 1 to 2 → Simulate Value (6879–1 to 2)**Description**

Use this function to select the simulation value that is used for the transducer block simulation.

Selection	<ul style="list-style-type: none"> ■ State 0 ■ State 1 ■ State 2 ■ State 3 ■ State 4 ■ State 5 ■ State 6 ■ State 7 ■ State 8 ■ State 9 ■ State 10 ■ State 11 ■ State 12 ■ State 13 ■ State 14 ■ State 15 ■ State 16
Factory setting	State 0

Transducer Status

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Transducer Stat (6880-1 to 2)
Description	Displays the current status of the transducer block.
User interface	<ul style="list-style-type: none"> ■ Bad NonSpecific NotLimited ■ Bad NonSpecific LowLimited ■ Bad NonSpecific HighLimited ■ Bad NonSpecific Constant ■ Bad ConfigurationError NotLimited ■ Bad ConfigurationError LowLimited ■ Bad ConfigurationError HighLimited ■ Bad ConfigurationError Constant ■ Bad NotConnected NotLimited ■ Bad NotConnected LowLimited ■ Bad NotConnected HighLimited ■ Bad NotConnected Constant ■ Bad DeviceFailure NotLimited ■ Bad DeviceFailure LowLimited ■ Bad DeviceFailure HighLimited ■ Bad DeviceFailure Constant ■ Bad SensorFailure NotLimited ■ Bad SensorFailure LowLimited ■ Bad SensorFailure HighLimited ■ Bad SensorFailure Constant ■ Bad NoComm WithLastUsableValue NotLimit ■ Bad No Com WithLastUsableValue LowLim ■ Bad No Com WithLastUsableValue HighLim ■ Bad No Com WithLastUsableValue Const ■ Bad NoComm WithNoUsableValue NotLimit ■ Bad NoComm WithNoUsableValue LowLimit ■ BadNoComm WithNoUsableValue HighLimit ■ Bad NoComm WithNoUsableValue Constant ■ Bad OutOfService NotLimited

- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain initialValue NotLimited
- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurate HighLimit
- Uncertain SensConvNotAccurate Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLimit
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const

- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant
- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Transducer Value

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Transducer Value (6881-1 to 2)
Description	Displays the current value of the transducer block.
User interface	<ul style="list-style-type: none">■ State 0■ State 1■ State 2■ State 3■ State 4■ State 5■ State 6■ State 7■ State 8■ State 9■ State 10■ State 11

- State 12
- State 13
- State 14
- State 15
- State 16

Factory setting State 0

Simulate En/Disable

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Sim. En/Disable (6877–1 to 2)
Description	Use this function to enable or disable the function block simulation.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Disabled■ Active
Factory setting	Uninitialized

Transducer State

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Transducer State (6891–1 to 2)
Description	Use this function to enter the transducer state: this is required by FieldValD (Status parameter (→ 229), Value parameter (→ 231)) to display the actual on/off status of the hardware.
User entry	0 to 65 535
Factory setting	0

Output State

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Output State (6874–1 to 2)
Description	Use this function to enter the output state: This is required for scaling the discrete input value (PV).
User entry	0 to 65 535
Factory setting	0

Deny

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Deny (6867–1 to 2)

Description Option for restricting certain access authorizations of the field bus host system on the device.

Selection

- Program Denied
- Tune Denied
- Alarm Denied
- Local
- Operate Denied

Grant

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Grant (6868–1 to 2)

Description Option for releasing certain access authorizations of the field bus host system on the device.

Selection

- Program
- Tune
- Alarm
- Local
- Operate
- Service
- Diagnostic

I/O Options

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → I/O Options (6869–1 to 2)

Description Option for activating the inversion of the signal.

Selection Invert

Additional information *Description*

This selection determines whether the discrete input is inverted before it is stored as a process variable. Normally a discrete value of 0 is regarded as a logical value of 0 and a discrete value that is not equal to 0 is regarded as a logical value of 1. If inversion is enabled, this correlation is reversed. A field device input value that is not equal to 0 results in a discrete output value of 0 and an input value of 0 results in a discrete output value of 1.

Status Options

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Status Options (6882–1 to 2)

Prerequisite The measuring device must be in the OOS operating mode so that the parameter can be edited.

Description For selecting an option for the status of the output value that is supported by the Discrete input block.

Selection

- Propagate Fault Fwd
- Uncertain if Man.

Additional information *Options*

- Propagate Fault Fwd
If the measuring device indicates the status **Bad DeviceFailure** or **Bad SensorFailure**, the device continues to measure and no alarm is triggered. The use of this substatus in the output value (OUT) is defined by **Propagate Fault Fwd** option. With the aid of this option, the user/operator can specify whether the alarm generation (sending an alarm) is triggered by the block or is forwarded downstream.
- Uncertain if Man.
If the Actual mode of the function block is in the **Man** option operating mode, **Uncertain if Man**. option is used as the output status.

Channel

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → Channel (6852–1 to 2)

Description Use this function to select the input value that should be processed in the discrete input function block.

Selection

- Uninitialized
- Low flow cut off
- Switch output status
- Verification status

Factory setting Switch output status

Process Value Filter Time

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → PV Filter Time (6855–1 to 2)

Description Use this function to enter the filter time specification for the filtering of the unconverted input value (PV).

User entry Positive floating-point number

Factory setting 0 s

Additional information*Factory setting*

If the value 0 s is entered, filtering will not be performed.

Status**Navigation**

█ Expert → Discrete inputs → Discrete input 1 to 2 → Status (6865–1 to 2)

Description

Displays the status of the discrete input value from a measuring device in the field.

User interface

- Bad NonSpecific NotLimited
- Bad NonSpecific LowLimited
- Bad NonSpecific HighLimited
- Bad NonSpecific Constant
- Bad ConfigurationError NotLimited
- Bad ConfigurationError LowLimited
- Bad ConfigurationError HighLimited
- Bad ConfigurationError Constant
- Bad NotConnected NotLimited
- Bad NotConnected LowLimited
- Bad NotConnected HighLimited
- Bad NotConnected Constant
- Bad DeviceFailure NotLimited
- Bad DeviceFailure LowLimited
- Bad DeviceFailure HighLimited
- Bad DeviceFailure Constant
- Bad SensorFailure NotLimited
- Bad SensorFailure LowLimited
- Bad SensorFailure HighLimited
- Bad SensorFailure Constant
- Bad NoComm WithLastUsableValue NotLimit
- Bad No Com WithLastUsableValue LowLim
- Bad No Com WithLastUsableValue HighLim
- Bad No Com WithLastUsableValue Const
- Bad NoComm WithNoUsableValue NotLimit
- Bad NoComm WithNoUsableValue LowLimit
- Bad NoComm WithNoUsableValue HighLimit
- Bad NoComm WithNoUsableValue Constant
- Bad OutOfService NotLimited
- Bad OutOfService LowLimited
- Bad OutOfService HighLimited
- Bad OutOfService Constant
- Uncertain NonSpecific NotLimited
- Uncertain NonSpecific LowLimited
- Uncertain NonSpecific HighLimited
- Uncertain NonSpecific Constant
- Uncertain LastUsableValue NotLimited
- Uncertain LastUsableValue LowLimited
- Uncertain LastUsableValue HighLimited
- Uncertain LastUsableValue Constant
- Uncertain SubstituteValue NotLimited
- Uncertain SubstituteValue LowLimited
- Uncertain SubstituteValue HighLimited
- Uncertain SubstituteValue Constant
- Uncertain InitialValue NotLimited

- Uncertain initialValue LowLimited
- Uncertain initialValue HighLimited
- Uncertain initialValue Constant
- Uncertain SensConvNotAccurate NoLimit
- Uncertain SensConvNotAccurate LowLimit
- Uncertain SensConvNotAccurate HighLimit
- Uncertain SensConvNotAccurate Const
- Uncertain EngUnitRangeViolation NotLimit
- Uncertain EngUnitRangeViolation LowLimit
- Uncertain EngUnitRangeViolation HighLimit
- Uncertain EngUnitRangeViolation Const
- Uncertain Subnormal NotLimited
- Uncertain Subnormal LowLimited
- Uncertain Subnormal HighLimited
- Uncertain Subnormal Constant
- Good NonCAS NonSpecific NotLimited
- Good NonCAS NonSpecific LowLimited
- Good NonCAS NonSpecific HighLimited
- Good NonCAS NonSpecific Constant
- Good NonCAS ActiveBlockAlarm NotLimit
- Good NonCAS ActiveBlockAlarm LowLimit
- Good NonCAS ActiveBlockAlarm HighLimit
- Good NonCAS ActiveBlockAlarm Const
- Good NonCAS ActiveAdvisoryAlarm NotLimit
- Good NonCAS ActiveAdvisoryAlarm LowLimit
- Good NonCAS ActAdvisoryAlarm HighLimit
- Good NonCAS ActAdvisoryAlarm Const
- Good NonCAS ActiveCriticalAlarm NotLimit
- Good NonCAS ActiveCriticalAlarm LowLimit
- Good NonCAS ActiveCriticalAlarm HL
- Good NonCAS ActiveCriticalAlarm Con.
- Good NonCAS UnackBlockAlarm NotLimit
- Good NonCAS UnackBlockAlarm LowLimit
- Good NonCAS UnackBlockAlarm HighLimit
- Good NonCAS UnackBlockAlarm Const
- Good NonCAS UnackAdvisoryAlarm NotLimit
- Good NonCAS UnackAdvisoryAlarm LowLimit
- Good NonCAS UnackAdvisoryAlarm HighLimit
- Good NonCAS UnackAdvisoryAlarm Const
- Good NonCAS UnackCriticalAlarm NotLimit
- Good NonCAS UnackCriticalAlarm LowLimit
- Good NonCAS UnackCriticalAlarm HighLimit
- Good NonCAS UnackCriticalAlarm Const
- Good Cascade NonSpecific NotLimited
- Good Cascade NonSpecific LowLimited
- Good Cascade NonSpecific HighLimited
- Good Cascade NonSpecific Constant
- Good Cascade InitAcknowledge NotLimit
- Good Cascade InitAcknowledge LowLimit
- Good Cascade InitAcknowledge HighLimit
- Good Cascade InitAcknowledge Const
- Good Cascade InitRequest NotLimit
- Good Cascade InitRequest LowLimit
- Good Cascade InitRequest HighLimit
- Good Cascade InitRequest Const
- Good Cascade NotInvited NotLimited
- Good Cascade NotInvited LowLimited
- Good Cascade NotInvited HighLimited
- Good Cascade NotInvited Constant

- Good Cascade NotSelected NotLimited
- Good Cascade NotSelected LowLimited
- Good Cascade NotSelected HighLimited
- Good Cascade NotSelected Constant
- Good Cascade DoNotSelect NotLimited
- Good Cascade DoNotSelect LowLimited
- Good Cascade DoNotSelect HighLimited
- Good Cascade DoNotSelect Constant
- Good Cascade LocalOverride NotLimited
- Good Cascade LocalOverride LowLimited
- Good Cascade LocalOverride HighLimited
- Good Cascade LocalOverride Constant
- Good Cascade FaultStateActive NotLimit
- Good Cascade FaultStateActive LowLimit
- Good Cascade FaultStateActive HighLimit
- Good Cascade FaultStateActive Constant
- Good Cascade InitFaultState NotLimited
- Good Cascade InitFaultState LowLimited
- Good Cascade InitFaultState HighLimited
- Good Cascade InitiateFaultState Constant

Factory setting Bad NonSpecific NotLimited

Additional information *Description*

An output parameter can be linked to an input parameter from another function block. Both the input parameter and the output parameter have a field value and status. The status of the input parameter is taken from the linked output parameter.

Value

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Value (6866–1 to 2)

Description Displays the discrete input value from a measuring device in the field.

- User interface**
- State 0
 - State 1
 - State 2
 - State 3
 - State 4
 - State 5
 - State 6
 - State 7
 - State 8
 - State 9
 - State 10
 - State 11
 - State 12
 - State 13
 - State 14
 - State 15
 - State 16

Factory setting State 0

Unacknowledged

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Unacknowledged (6889–1 to 2)
Description	Option for manually acknowledging an update of the static block parameter.
Selection	<ul style="list-style-type: none">▪ Uninitialized▪ Acknowledged▪ Unacknowledged
Factory setting	Uninitialized
Additional information	<i>Description</i>  <ul style="list-style-type: none">▪ If a new diagnostic event occurs, the measuring device sets Unacknowledged option.▪ If the diagnostic event has been acknowledged, the user can set Acknowledged option.

Update State

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Update State (6890–1 to 2)
Description	Displays the status of an update of the static block parameter. The status indicates whether the update was communicated or not.
User interface	<ul style="list-style-type: none">▪ Uninitialized▪ Reported▪ Not Reported

Time Stamp

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Time Stamp (6888–1 to 2)
Description	Displays the time stamp indicating when the analysis of the block was started and when a status change of an update to the static block parameter that has not yet been communicated was identified. The time stamp is retained until the update confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Static revision

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Static revision (6887–1 to 2)
Description	Displays the Static revision: Each instance of a static block parameter being accessed with write and communicate access due to an update is counted (event counter).
User interface	0 to 65 535

Relative Index

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Relative Index (6886–1 to 2)
Description	Displays the relative index of the static block parameter that triggered the alarm (OD index minus field bus start index).
User interface	0 to 65 535

Acknowledge Option

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Ack. Option (6841–1 to 2)
Description	Option for automatic acknowledgment of process alarms in a specific category.
Selection	<ul style="list-style-type: none"> ■ Disc Alm Auto Ack ■ Blk Alm Auto Ack ■ Fail Alm Auto Ack ■ Off Spec Alm Auto Ack ■ Maint Alm Auto Ack ■ Check Alm Auto Ack
Additional information	<p><i>Description</i></p> <p>Use this function to determine whether an alarm must be acknowledged via the field bus host system.</p> <p> If the process alarm option has not been enabled in this parameter, this process alarm must only be acknowledged in Unacknowledged parameter (→  200). Current parameter (→  199) indicates the current status of all process alarms.</p>

Current

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Current (6842–1 to 2)
Description	Use this function to view the current status of the process alarms.

User interface

- Discrete Alarm
- Block Alarm
- Fail Alarm
- Off Spec Alarm
- Maintenance Alarm
- Check Alarm

Disabled

Navigation

█ Expert → Discrete inputs → Discrete input 1 to 2 → Disabled (6843–1 to 2)

Description

Option for disabling a process alarm category.

Selection

- Disc Alm Disabled
- Block Alm Disabled
- Fail Alm Disabled
- Off Spec Alm Disabled
- Maint Alm Disabled
- Check Alm Disabled

Unacknowledged

Navigation

█ Expert → Discrete inputs → Discrete input 1 to 2 → Unacknowledged (6844–1 to 2)

Description

Displays an unacknowledged process alarm.

User interface

- Disc Alm Unack
- Block Alm Unack
- Fail Alm Unack
- Off Spec Alm Unack
- Maint Alm Unack
- Check Alm Unack

Unreported

Navigation

█ Expert → Discrete inputs → Discrete input 1 to 2 → Unreported (6845–1 to 2)

Description

Displays a process alarm that has not been communicated.

User interface

- Disc Alm Unrep
- Block Alm Unrep
- Fail Alm Unrep
- Off Spec Alm Unrep
- Maint Alm Unrep
- Check Alm Unrep

Alarm State

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Alarm State (6847–1 to 2)
Description	Displays the status of the block alarm. The status indicates whether the block alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear-Reported■ Clear-Not Reported■ Active-Reported■ Active-Not Reported

Subcode

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Subcode (6848–1 to 2)
Description	Displays the specific cause of the block alarm.
User interface	<ul style="list-style-type: none">■ Other■ BlockConfiguration■ LinkConfiguration■ SimulationActive■ LocalOverride■ DeviceFaultState■ DeviceMaintenance■ SensorFailure■ OutputFailure■ MemoryFailure■ LostStaticData■ LostNVDATA■ ReadbackCheck■ MaintenanceNeeded■ PowerUp■ OutOfService

Time Stamp

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Time Stamp (6849–1 to 2)
Description	Displays the time stamp indicating when the analysis of the block was started and when a status change of the block alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.
User interface	Days (d), hours (h), minutes (m), seconds (s)

Unacknowledged

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Unacknowledged (6850–1 to 2)
Description	Option for manually acknowledging a block alarm.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Acknowledged■ Unacknowledged
Factory setting	Uninitialized
Additional information	<i>Description</i> If Blk Alm Auto Ack option is not enabled in Acknowledge Option parameter (→  233), the process alarm must be manually acknowledged in this parameter.  <ul style="list-style-type: none">■ If a new alarm occurs, the measuring device sets Unacknowledged option.■ If the alarm has been acknowledged, the user can set Acknowledged option.

Value

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Value (6856–1 to 2)
Description	Displays the value of the affected parameter at the time at which the block alarm was detected.
User interface	0 to 255

Alarm State

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Alarm State (6858–1 to 2)
Description	Displays the status of the block alarm. The status indicates whether the block alarm is active and whether it has already been communicated to the field bus host system.
User interface	<ul style="list-style-type: none">■ Uninitialized■ Clear-Reported■ Clear-Not Reported■ Active-Reported■ Active-Not Reported

Subcode

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Subcode (6859–1 to 2)
Description	Displays the specific cause of the discrete alarm.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVDATA
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Time Stamp**Navigation**

 Expert → Discrete inputs → Discrete input 1 to 2 → Time Stamp (6860-1 to 2)

Description

Displays the time stamp indicating when the analysis of the function block was started and when a status change of the discrete alarm that has not yet been communicated to the field bus host system was detected. The time stamp is retained until the alarm confirmation is received.

User interface

Days (d), hours (h), minutes (m), seconds (s)

Unacknowledged**Navigation**

 Expert → Discrete inputs → Discrete input 1 to 2 → Unacknowledged (6861-1 to 2)

Description

Option for manually acknowledging a discrete alarm.

Selection

- Uninitialized
- Acknowledged
- Unacknowledged

Factory setting

Uninitialized

Additional information*Description*

If **Disc Alm Auto Ack** option is not enabled in **Acknowledge Option** parameter (→  233), the process alarm must be manually acknowledged in this parameter.



- If a new alarm occurs, the measuring device sets **Unacknowledged** option.
- If the alarm has been acknowledged, the user can set **Acknowledged** option.

Discrete Value

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Discrete Value (6862–1 to 2)
Description	Displays the value of the associated parameter at the time at which the alarm was detected.
User interface	<ul style="list-style-type: none">▪ State 0▪ State 1▪ State 2▪ State 3▪ State 4▪ State 5▪ State 6▪ State 7▪ State 8▪ State 9▪ State 10▪ State 11▪ State 12▪ State 13▪ State 14▪ State 15▪ State 16

Discrete Limit

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Discrete Limit (6863–1 to 2)
Description	Use this to enter the status of the discrete input value that triggers an alarm.
User entry	0 to 255
Factory setting	0


Discrete Priority

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Discrete Prio (6864–1 to 2)
Description	Use this to enter the priority of a discrete alarm.
User entry	0 to 15
Factory setting	0

3.7 "Analog outputs" submenu

Navigation


Diagram Expert → Analog outputs



3.7.1 "Multiple analog output" submenu

Navigation

Diagram Expert → Analog outputs → Multiple AO



Block tag

Navigation

Diagram Expert → Analog outputs → Multiple AO → Block tag (11351)

Description

Use this function to enter the Block tag: specify a "label" for identifying the function block.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Static Revision

Navigation	 Expert → Analog outputs → Multiple AO → Static Revision (11371)
Description	Displays the Static Revision: every write access to a static block parameter is counted (event counter).
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Tag Description

Navigation	 Expert → Analog outputs → Multiple AO → Tag Description (11372)
Description	Use this function to enter the Tag Description: define a user-specific text for the detailed description of the function block.
User entry	Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Strategy

Navigation	 Expert → Analog outputs → Multiple AO → Strategy (11370)
Description	Use this function to enter the Strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert Key

Navigation	 Expert → Analog outputs → Multiple AO → Alert Key (11365)
Description	Use this function to enter the Alert Key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	1

Target mode

Navigation	 Expert → Analog outputs → Multiple AO → Target mode (11369)
Description	Use this function to select the Target mode: the selection specifies which operating mode is used for this block. This mode is generally set by a control application.
Selection	<ul style="list-style-type: none">■ ROut■ RCas■ Cas■ Auto■ Man■ LO■ IMan■ OOS
Factory setting	OOS
Additional information	<i>Selection</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Actual mode

Navigation	 Expert → Analog outputs → Multiple AO → Actual mode (11366)
Description	Displays the Actual mode: under certain conditions a block may not work in the operating mode to be used. In this case, the Actual mode represents the valid mode in which the block is currently operating. A comparison of the Actual mode with the Target mode indicates whether the Target mode (→  241) could be reached.
User interface	<ul style="list-style-type: none">■ ROut■ RCas■ Cas■ Auto■ Man■ LO■ IMan■ OOS
Additional information	<i>Selection</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Permitted mode

Navigation	 Expert → Analog outputs → Multiple AO → Permitted mode (11368)
Description	Use this function to select the Permitted mode: the selection defines which operating modes are available for the function block in the Target mode (→  241). The operating modes that are supported vary depending on the type and function of the block.
Selection	<ul style="list-style-type: none">▪ ROut▪ RCas▪ Cas▪ Auto▪ Man▪ LO▪ IMan▪ OOS
Factory setting	<ul style="list-style-type: none">▪ Auto▪ OOS
Additional information	<i>Selection</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Normal mode

Navigation	 Expert → Analog outputs → Multiple AO → Normal mode (11367)
Description	Use this function to select the Normal mode: this mode is provided to enable the user to select the Normal mode among the operating modes available. This can be set using an operating tool in order to help the user configure the operating mode of a block.
Selection	<ul style="list-style-type: none">▪ ROut▪ RCas▪ Cas▪ Auto▪ Man▪ LO▪ IMan▪ OOS
Factory setting	Auto
Additional information	<i>Selection</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Block Error

Navigation	Expert → Analog outputs → Multiple AO → Block Error (11364)
Description	Displays the short text for the Block Error that occurred in the function block.
User interface	<ul style="list-style-type: none">■ Other■ BlockConfiguration■ LinkConfiguration■ SimulationActive■ LocalOverride■ DeviceFaultState■ DeviceMaintenance■ SensorFailure■ OutputFailure■ MemoryFailure■ LostStaticData■ LostNVData■ ReadbackCheck■ MaintenanceNeeded■ PowerUp■ OutOfService

Channel

Navigation	Expert → Analog outputs → Multiple AO → Channel (11352)
Description	Use this function to select the assignment or connection between the Analog Output function block and the Transducer Block.
Selection	<ul style="list-style-type: none">■ Uninitialized■ Channel_0
Factory setting	Channel_0

Status Options

Navigation	Expert → Analog outputs → Multiple AO → Status Options (11363)
Description	Option for determining the fault state of the function block.
Selection	<ul style="list-style-type: none">■ Faultstate to value 1■ Faultstate to value 2■ Faultstate to value 3■ Faultstate to value 4■ Faultstate to value 5■ Faultstate to value 6■ Faultstate to value 7■ Faultstate to value 8■ Use faultstate value on restart 1

- Use faultstate value on restart 2
- Use faultstate value on restart 3
- Use faultstate value on restart 4
- Use faultstate value on restart 5
- Use faultstate value on restart 6
- Use faultstate value on restart 7
- Use faultstate value on restart 8

Additional information*Description*

This behavior is activated if an error condition of the set point that applies is present for longer than defined in the **Fault State Time** parameter (→ 244) or if the **Set Fault State** parameter (→ 152) is activated in the Resource block.

The fault state is defined via the following parameters:

- Fault State Time (→ 244)
- Fault State Val 1 to 8

Selection

- Faultstate to value 1...8

The value predefined in the **Fault State Val 1 to 8** parameter is used instead of the analog set point. The fault state is enabled if there is an error condition.

- Use faultstate value on restart 1...8

The value predefined in the **Fault State Val 1 to 8** parameter is used if the device is restarted. The non-volatile value is used otherwise. The fault state is not enabled and only the predefined value is used.

Fault State Time

Navigation

  Expert → Analog outputs → Multiple AO → Fault State Time (11354)

Description

Use this function to enter a time range during which an error condition (of the currently valid set point) must be met without interruption before an error message is generated.

User entry

Positive floating-point number

Factory setting

0 s

Fault State Val 1

Navigation

  Expert → Analog outputs → Multiple AO → FaultState Val 1 (11355)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 1 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 1** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 2

Navigation

Expert → Analog outputs → Multiple AO → FaultState Val 2 (11356)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 2 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 2** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 3

Navigation

Expert → Analog outputs → Multiple AO → FaultState Val 3 (11357)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 3 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 3** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 4

Navigation

Expert → Analog outputs → Multiple AO → FaultState Val 4 (11358)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 4 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 4** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 5**Navigation**

Expert → Analog outputs → Multiple AO → FaultState Val 5 (11359)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 5 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 5** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 6**Navigation**

Expert → Analog outputs → Multiple AO → FaultState Val 6 (11360)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 6 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

This value is ignored if the **Faultstate to value 6** option is not selected in the **Status Options** parameter (→ 243).

Fault State Val 7**Navigation**

Expert → Analog outputs → Multiple AO → FaultState Val 7 (11361)

Description

Use this function to enter a predefined analog value to be used if an error condition of the analog set point 7 is present.

User entry

Signed floating-point number

Factory setting

0

Additional information	Description
	 This value is ignored if the Faultstate to value 7 option is not selected in the Status Options parameter (→ 243).

Fault State Val 8


Navigation	 Expert → Analog outputs → Multiple AO → FaultState Val 8 (11362)
Description	Use this function to enter a predefined analog value to be used if an error condition of the analog set point 8 is present.
User entry	Signed floating-point number
Factory setting	0
Additional information	Description
	 This value is ignored if the Faultstate to value 8 option is not selected in the Status Options parameter (→ 243).

Fault State Status


Navigation	 Expert → Analog outputs → Multiple AO → FaultStateStatus (11353)
Description	Displays the values for which the fault state is enabled.
User interface	<ul style="list-style-type: none"> ■ Value 1 is in Fault State ■ Value 2 is in Fault State ■ Value 3 is in Fault State ■ Value 4 is in Fault State ■ Value 5 is in Fault State ■ Value 6 is in Fault State ■ Value 7 is in Fault State ■ Value 8 is in Fault State

3.8 "Discrete outputs" submenu

The Discrete outputs function block (DO, discrete output) processes a discrete set point received from an upstream function block or a higher-level process control system that enables various device functions (e.g. zero point adjustment or reset of the totalizer) to be triggered in the downstream transducer block.

Navigation Expert → Discrete outputs

3.8.1 "Multiple discrete output" submenu

Navigation Expert → Discrete outputs → Multiple DO

Block tag

Navigation Expert → Discrete outputs → Multiple DO → Block tag (11252)**Description**

Use this function to enter the Block tag: Used for specifying a "label" for identifying the function block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static Revision

Navigation	 Expert → Discrete outputs → Multiple DO → Static Revision (11270)
Description	Displays the Static Revision: Each instance of a static block parameter being accessed with write access is counted (event counter).
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Tag Description

Navigation	 Expert → Discrete outputs → Multiple DO → Tag Description (11271)
Description	Use this function to enter the Tag Description: Used for defining a user-specific text for detailed description of the function block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Strategy

Navigation	 Expert → Discrete outputs → Multiple DO → Strategy (11269)
Description	Use this function to enter the Strategy: Enables blocks to be grouped by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert Key

Navigation	 Expert → Discrete outputs → Multiple DO → Alert Key (11251)
Description	Use this function to enter the Alert Key: Identifies the plant unit where the transmitter is located. This helps in pinpointing events.
User entry	0 to 0xFF
Factory setting	1

Target mode

Navigation	 Expert → Discrete outputs → Multiple DO → Target mode (11267)
Description	Use this function to select the Target mode: The selection indicates which operating mode is used for this function block. This mode is generally set by a control application.
Selection	<ul style="list-style-type: none">▪ ROut▪ RCas▪ Cas▪ Auto▪ Man▪ LO▪ IMan▪ OOS
Factory setting	OOS
Additional information	<i>Options</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Actual mode

Navigation	 Expert → Discrete outputs → Multiple DO → Actual mode (11264)
Description	Displays the Actual mode: Under certain conditions, a function block may not work in the operating mode to be used. In this case, the Actual mode shows the actual operating mode that the function block is currently operating in. By comparing the Actual mode with the Target mode, users can see whether it was possible to reach the Target mode (→  250).
User interface	<ul style="list-style-type: none">▪ ROut▪ RCas▪ Cas▪ Auto▪ Man▪ LO▪ IMan▪ OOS
Additional information	<i>User interface</i>  Detailed description of the options available for selection: Target mode parameter (→  141)

Permitted mode

Navigation

Expert → Discrete outputs → Multiple DO → Permitted mode (11266)

Description

Use this function to select the Permitted mode: The selection defines which operating modes are available in Target mode (→ 250) for the function block. The operating modes that are supported vary depending on the type and function of the block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

- Auto
- OOS

Additional information*Options*

 Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Normal mode

Navigation

Expert → Discrete outputs → Multiple DO → Normal mode (11265)

Description

Use this function to select the Normal mode: This is available to enable the user to select the Normal mode from the available operating modes. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

Selection

- ROut
- RCas
- Cas
- Auto
- Man
- LO
- IMan
- OOS

Factory setting

Auto

Additional information*Options*

 Detailed description of the options available for selection: **Target mode** parameter
(→ 141)

Block Error

Navigation  Expert → Discrete outputs → Multiple DO → Block Error (11272)

Description Displays the short text for the Block Error that has occurred in the function block.

User interface

- Other
- BlockConfiguration
- LinkConfiguration
- SimulationActive
- LocalOverride
- DeviceFaultState
- DeviceMaintenance
- SensorFailure
- OutputFailure
- MemoryFailure
- LostStaticData
- LostNVData
- ReadbackCheck
- MaintenanceNeeded
- PowerUp
- OutOfService

Channel

Navigation   Expert → Discrete outputs → Multiple DO → Channel (11253)

Description Option for the assignment or connection between the discrete output function block and the transducer block.

Selection

- Uninitialized
- Channel_D0

Factory setting Channel_D0

Status Options

Navigation   Expert → Discrete outputs → Multiple DO → Status Options (11268)

Description Option for determining the fault state of the function block.

Selection

- Faultstate to value 1
- Faultstate to value 2
- Faultstate to value 3
- Faultstate to value 4
- Faultstate to value 5
- Faultstate to value 6
- Faultstate to value 7
- Faultstate to value 8
- Use faultstate value on restart 1

- Use faultstate value on restart 2
- Use faultstate value on restart 3
- Use faultstate value on restart 4
- Use faultstate value on restart 5
- Use faultstate value on restart 6
- Use faultstate value on restart 7
- Use faultstate value on restart 8

Additional information*Description*

This behavior is enabled if an error condition of the valid set point persists for longer than the time specified in **Fault State Time** parameter (→ 253) or if **Set Fault State** parameter (→ 152) is enabled in Resource block.

The fault state is defined via the following parameters:

- Fault State Time (→ 253)
- Fault State Value Discrete 1 to 8

Options

- Faultstate to value 1...8

The value predefined in **Fault State Value Discrete 1 to 8** parameter is used in place of the discrete set point. The fault state is enabled if there is an error condition.

- Use faultstate value on restart 1...8

The value predefined in **Fault State Value Discrete 1 to 8** parameter is used if the device is restarted. The non-volatile value is used otherwise. The fault state is not enabled and only the predefined value is used.

Fault State Time**Navigation**

  Expert → Discrete outputs → Multiple DO → Fault State Time (11255)

Description

Use this function to enter a time range during which an error condition (of the currently valid set point) must be met without interruption before an error message is generated.

User entry

Positive floating-point number

Factory setting

0 s

Fault State Value Discrete 1**Navigation**

  Expert → Discrete outputs → Multiple DO → FStateValue DO 1 (11256)

Description

Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 1 is present.

User entry

0 to 255

Factory setting

0

Additional information *Description*

 If **Faultstate to value 1** option is not selected in **Status Options** parameter (→ 252), this value is ignored.

Fault State Value Discrete 2

Navigation  Expert → Discrete outputs → Multiple DO → FStateValue DO 2 (11257)

Description Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 2 is present.

User entry 0 to 255

Factory setting 0

Additional information *Description*

 If **Faultstate to value 2** option is not selected in **Status Options** parameter (→ 252), this value is ignored.

Fault State Value Discrete 3

Navigation  Expert → Discrete outputs → Multiple DO → FStateValue DO 3 (11258)

Description Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 3 is present.

User entry 0 to 255

Factory setting 0

Additional information *Description*

 If **Faultstate to value 3** option is not selected in **Status Options** parameter (→ 252), this value is ignored.

Fault State Value Discrete 4

Navigation  Expert → Discrete outputs → Multiple DO → FStateValue DO 4 (11259)

Description Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 4 is present.

User entry 0 to 255

Factory setting 0

Additional information *Description*

If **Faultstate to value 4** option is not selected in **Status Options** parameter
(→ 252), this value is ignored.

Fault State Value Discrete 5

Navigation Expert → Discrete outputs → Multiple DO → FStateValue DO 5 (11260)**Description** Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 5 is present.**User entry** 0 to 255**Factory setting** 0**Additional information** *Description*

If **Faultstate to value 5** option is not selected in **Status Options** parameter
(→ 252), this value is ignored.

Fault State Value Discrete 6

Navigation Expert → Discrete outputs → Multiple DO → FStateValue DO 6 (11261)**Description** Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 6 is present.**User entry** 0 to 255**Factory setting** 0**Additional information** *Description*

If **Faultstate to value 6** option is not selected in **Status Options** parameter
(→ 252), this value is ignored.

Fault State Value Discrete 7

Navigation Expert → Discrete outputs → Multiple DO → FStateValue DO 7 (11262)**Description** Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 7 is present.**User entry** 0 to 255**Factory setting** 0

Additional information*Description*

If **Faultstate to value 7** option is not selected in **Status Options** parameter
(→ 252), this value is ignored.

Fault State Value Discrete 8

Navigation

Expert → Discrete outputs → Multiple DO → FStateValue DO 8 (11263)

Description

Use this function to enter a predefined discrete value to be used if an error condition of the discrete set point 8 is present.

User entry

0 to 255

Factory setting

0

Additional information*Description*

If **Faultstate to value 8** option is not selected in **Status Options** parameter
(→ 252), this value is ignored.

Fault State Status

Navigation

Expert → Discrete outputs → Multiple DO → FaultStateStatus (11254)

Description

Displays the values for which the fault state is enabled.


User interface

- Value 1 is in Fault State
- Value 2 is in Fault State
- Value 3 is in Fault State
- Value 4 is in Fault State
- Value 5 is in Fault State
- Value 6 is in Fault State
- Value 7 is in Fault State
- Value 8 is in Fault State

3.9 "Application" submenu

Navigation

Expert → Application



Reset all totalizers**Navigation**

Expert → Application → Reset all tot. (2806)

Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting

Cancel

Additional information

Selection

- Cancel
No action is executed and the user exits the parameter.
- Reset + totalize
All totalizers are reset to 0 and the totaling process is restarted.

3.9.1 "Totalizer 1 to 3" submenu*Navigation*

Expert → Application → Totalizer 1 to 3

► Totalizer 1 to 3	
Assign process variable (0914-1 to 3)	→ 257
Unit totalizer (0915-1 to 3)	→ 258
Control Totalizer 1 to 3 (0912-1 to 3)	→ 260
Preset value 1 to 3 (0913-1 to 3)	→ 260
Failure mode (0901-1 to 3)	→ 261

Assign process variable**Navigation**

Expert → Application → Totalizer 1 to 3 → Assign variable (0914-1 to 3)

Description

Use this function to select a process variable for the Totalizer 1 to 3.

Selection

- Off
- Volume flow
- Corrected volume flow
- Mass flow

- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Factory setting

- Totalizer 1: Volume flow
- Totalizer 2: Mass flow
- Totalizer 3: Corrected volume flow

Additional information*Description*

-  If the option selected is changed, the device resets the totalizer to 0.

Selection

If the **Off** option is selected, only **Assign process variable** parameter (→ 257) is still displayed in the **Totalizer 1 to 3** submenu. All other parameters in the submenu are hidden.

Unit totalizer**Navigation**

 Expert → Application → Totalizer 1 to 3 → Unit totalizer (0915-1 to 3)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 257) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to select the unit for the process variable of totalizer 1-3.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

or

* Visibility depends on order options or device settings

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³	■ af	■ gal (imp)
■ dm ³	■ ft ³	■ Mgal (imp)
■ m ³	■ fl oz (us)	■ bbl (imp;beer)
■ ml	■ gal (us)	■ bbl (imp;oil)
■ l	■ kgal (us)	
■ hl	■ Mgal (us)	
■ Ml Mega	■ bbl (us;liq.)	
	■ bbl (us;beer)	
	■ bbl (us;oil)	
	■ bbl (us;tank)	

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ Nl	■ Sft ³	Sgal (imp)
■ Nm ³	■ Sgal (us)	
■ Sl	■ Sbbl (us;liq.)	
■ Sm ³		

or

<i>SI units</i>	<i>Imperial units</i>
■ kWh	■ Btu
■ MWh	■ MBtu
■ GWh	■ MMBtu
■ kJ	
■ MJ	
■ GJ	
■ kcal	
■ Mcal	
■ Gcal	

Factory setting

Country-specific:

- m³
- ft³

Additional information*Description*

 The unit is selected separately for each totalizer. The unit is independent of the option selected in the **System units** submenu (→ 69).

Selection

The selection depends on the process variable selected in the **Assign process variable** parameter (→ 257).

Control Totalizer 1 to 3

Navigation

  Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3 (0912-1 to 3)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [257](#)) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Description

Use this function to select the control of totalizer value 1-3.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize

Factory setting

Totalize

Additional information

Selection

- Totalize
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter (→ [260](#)).
- Reset + totalize
The totalizer is reset to 0 and the totaling process is restarted.
- Preset + totalize
The totalizer is set to the defined start value in **Preset value** parameter (→ [260](#)) and the totaling process is restarted.

Preset value 1 to 3

Navigation

  Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3 (0913-1 to 3)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [257](#)) of the **Totalizer 1 to 3** submenu:

- Volume flow
- Corrected volume flow
- Mass flow
- Total mass flow *

* Visibility depends on order options or device settings

- Condensate mass flow *
- Energy flow *
- Heat flow difference *

Description Use this function to enter a start value for totalizer 1-3.

User entry Signed floating-point number

Factory setting Country-specific:
 ■ 0 m³
 ■ 0 ft³

Additional information *User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 258).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode



Navigation  Expert → Application → Totalizer 1 to 3 → Failure mode (0901-1 to 3)

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ 257) of the **Totalizer 1 to 3** submenu:
 ■ Volume flow
 ■ Corrected volume flow
 ■ Mass flow
 ■ Total mass flow *
 ■ Condensate mass flow *
 ■ Energy flow *
 ■ Heat flow difference *

Description Use this function to select how a totalizer behaves in an alarm condition.

Selection
 ■ Stop
 ■ Actual value
 ■ Last valid value

Factory setting Stop

Additional information *Description*

 This setting does not affect the error response mode of other totalizers and the outputs. This is specified in separate parameters.

* Visibility depends on order options or device settings

Selection

- Stop
Totalizing is stopped in an alarm condition.
- Actual value
The totalizer continues to count based on the actual measured value; the error is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the error occurred.

3.10 "Diagnostics" submenu

Navigation

Expert → Diagnostics

► Diagnostics	
Actual diagnostics (0691)	→ 262
Previous diagnostics (0690)	→ 263
Operating time from restart (0653)	→ 264
Operating time (0652)	→ 264
► Diagnostic list	→ 265
► Event logbook	→ 268
► Device information	→ 271
► Sensor information	→ 275
► Data logging	→ 275
► Min/max values	→ 281
► Heartbeat	→ 287
► Simulation	→ 288

Actual diagnostics

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description	Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p>  Additional pending diagnostic messages can be displayed in the Diagnostic list submenu (→ 265).
	 Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the  -button.

Example

For the display format:
☒F271 Main electronic failure

Timestamp

Navigation	☒ Expert → Diagnostics → Timestamp (0667)
Description	Displays the operating time when the current diagnostic message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<p><i>User interface</i></p>  The diagnostic message can be displayed via the Actual diagnostics parameter (→ 262).
	<p><i>Example</i></p> <p>For the display format: 24d12h13m00s</p>

Previous diagnostics

Navigation	☒☒ Expert → Diagnostics → Prev.diagnostics (0690)
Prerequisite	Two diagnostic events have already occurred.
Description	Displays the diagnostic message that occurred before the current message.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<p><i>User interface</i></p>  Information on what is causing the diagnostic message, and remedy measures, can be viewed by pressing the  -button.
	<p><i>Example</i></p> <p>For the display format: ☒F271 Main electronic failure</p>

Timestamp

Navigation	  Expert → Diagnostics → Timestamp (0672)
Description	Displays the operating time when the last diagnostic message before the current message occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i>  The diagnostic message can be displayed via the Previous diagnostics parameter (→  263). <i>Example</i> For the display format: 24d12h13m00s

Operating time from restart

Navigation	  Expert → Diagnostics → Time fr. restart (0653)
Description	Use this function to display the time the device has been in operation since the last device restart.
User interface	Days (d), hours (h), minutes (m) and seconds (s)


Operating time

Navigation	  Expert → Diagnostics → Operating time (0652)
Description	Use this function to display the length of time the device has been in operation.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>User interface</i> The maximum number of days is 9999, which is equivalent to 27 years.

3.10.1 "Diagnostic list" submenu

Navigation

Expert → Diagnostics → Diagnostic list



Diagnostics 1

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description

Use this function to display the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Examples

For the display format:

- Δ S442 Frequency output
- \times F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp (0683)

Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

 The diagnostic message can be displayed via the **Diagnostics 1** parameter (→ 265).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation   Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

Description Use this function to display the current diagnostics message with the second-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Examples*

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Timestamp

Navigation   Expert → Diagnostics → Diagnostic list → Timestamp (0684)

Description Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

 The diagnostic message can be displayed via the **Diagnostics 2** parameter (→  266).

Example

For the display format:

24d12h13m00s

Diagnostics 3

Navigation   Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description Use this function to display the current diagnostics message with the third-highest priority.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Examples*

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp (0685)

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

 The diagnostic message can be displayed via the **Diagnostics 3** parameter (→  266).

Example

For the display format:
24d12h13m00s

Diagnostics 4

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)

Description

Use this function to display the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Examples

For the display format:

- △S442 Frequency output
- ⊗F276 I/O module failure

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp (0686)

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

 The diagnostic message can be displayed via the **Diagnostics 4** parameter (→  267).

Example

For the display format:
24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Use this function to display the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Examples

For the display format:

- Δ S442 Frequency output
- \otimes F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp (0687)

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

 The diagnostic message can be displayed via the **Diagnostics 5** parameter (→  268).

Example


For the display format:

24d12h13m00s

3.10.2 "Event logbook" submenu

Navigation

Expert → Diagnostics → Event logbook



Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information*Description*

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options (0656)

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting


All

Additional information*Description*

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu**Navigation**

Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

Expert → Diagnostics → Event logbook → Event list

Description

Use this function to display the history of event messages of the category selected in the **Filter options** parameter (→ 269).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information*Description*

A maximum of 20 event messages are displayed in chronological order. If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- △S442 Frequency output
⊖ 01d04h12min30s

Additional information, such as remedial measures, can be retrieved via the key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

To order the **HistoROM advanced capabilities** application package, see the "Accessories" section of the "Technical Information" document.

3.10.3 "Device information" submenu

Navigation

Expert → Diagnostics → Device info

► Device information	
Device tag (10799)	→ 271
Serial number (10798)	→ 272
Device type (10711)	→ 272
Device Revision (10710)	→ 272
DD Revision (10709)	→ 272
Firmware version (10792)	→ 273
Hardware revision (10793)	→ 273
ITK Version (10794)	→ 273
Extended order code (10795)	→ 273
Extended order code 1 (10796)	→ 274
Extended order code 2 (10797)	→ 274
ENP version (10791)	→ 275


Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (10799)

Description

Use this function to enter a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header:



A0013375

9 Header text

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Prowirl 200

Additional information*User entry*

The number of characters displayed depends on the characters used.

Serial number**Navigation**

  Expert → Diagnostics → Device info → Serial number (10798)

Description

Displays the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer: www.endress.com/deviceviewer

User interface

Max. 11-digit character string comprising letters and numbers.

Additional information*Factory setting*

 This information varies depending on the device. Only an example is given here.

Device type**Navigation**

  Expert → Diagnostics → Device info → Device type (10711)

Description

Use this function to view the device type with which the measuring device is registered with FOUNDATION Fieldbus.

User interface

Prowirl 200

Device Revision**Navigation**

  Expert → Diagnostics → Device info → Device Revision (10710)

Description

Use this function to view the device revision with which the measuring device is registered with FOUNDATION Fieldbus.

User interface

1

DD Revision**Navigation**

  Expert → Diagnostics → Device info → DD Revision (10709)

Description

Displays the revision number of the device description (DD).

User interface	1
----------------	---

Additional information	<i>Description</i>
------------------------	--------------------



This display can be used to ensure that the right system files (DD = device description) are used for integration into the host system. The system files can be downloaded free of charge online at: www.endress.com.

Firmware version

Navigation	Expert → Diagnostics → Device info → Firmware version (10792)
------------	---

Description	Displays the device firmware version installed.
-------------	---

User interface	Character string with the following format: xx.yy.zz
----------------	---

Hardware revision

Navigation	Expert → Diagnostics → Device info → Hardware rev. (10793)
------------	--

Description	Displays the Hardware revision.
-------------	---------------------------------

User interface	Character string in the format xx.yy.zz
----------------	---

ITK Version

Navigation	Expert → Diagnostics → Device info → ITK Version (10794)
------------	--

Description	Displays the revision status of the Interoperability Test Kits (ITK).
-------------	---

User interface	6
----------------	---

Extended order code

Navigation	Expert → Diagnostics → Device info → Ext. order cd. (10795)
------------	---

Description	Use this function to enter the device order code.
-------------	---



The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

User entry	Character string composed of letters, numbers and certain punctuation marks
------------	---

Additional information*Description*

The order code is generated from the extended order code, which defines all the device features of the product structure. In contrast, the device features cannot be read directly from the order code.

i **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1

Navigation

  Expert → Diagnostics → Device info → Ext. order cd. 1 (10796)

Description

Use this function to enter the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 2 parameters.

i The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

User entry

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

i The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2

Navigation

  Expert → Diagnostics → Device info → Ext. order cd. 2 (10797)

Description

Use this function to enter the second part of the extended order code.

i Deletion of the ordered customer-specific parameter set that was preconfigured before delivery. This parameter set cannot be reset. It can only be restored to the factory setting.

User entry

Character string

Additional information

For additional information, see **Extended order code 1** parameter

ENP version**Navigation**

  Expert → Diagnostics → Device info → ENP version (10791)

Description

Displays the version of the electronic nameplate. This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

User interface

Character string in the format xx.yy.zz

3.10.4 "Sensor information" submenu*Navigation*

  Expert → Diagnostics → Sensor info

 ▶ Sensor information

DSC sensor serial number (7728)

→  275

DSC sensor serial number**Navigation**

  Expert → Diagnostics → Sensor info → DSC serial no. (7728)

Description

Displays the serial number of the DSC sensor that is used in the measuring tube.

User interface

Character string

Additional information*Description*

The serial number and other individual values of the DSC sensor, such as temperature range and reference values, are stored on the S-DAT.

 If the DSC sensor is replaced, the S-DAT must also always be replaced.

3.10.5 "Data logging" submenu*Navigation*

  Expert → Diagnostics → Data logging

 ▶ Data logging

Assign channel 1 (0851)

→  276

Assign channel 2 (0852)

→  277

Assign channel 3 (0853)	→ 277
Assign channel 4 (0854)	→ 278
Logging interval (0856)	→ 278
Clear logging data (0855)	→ 279
▶ Display channel 1	→ 279
▶ Display channel 2	→ 280
▶ Display channel 3	→ 281
▶ Display channel 4	→ 281

Assign channel 1



Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ [54](#)).

Description

Use this function to select a process variable for the data logging channel.

Selection

- Off
- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *
- Reynolds number *
- Density *
- Vortex frequency
- Electronic temperature

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Description*

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

 The log contents are cleared if the option selected is changed.

Assign channel 2**Navigation**

  Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  54).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→  276)

Factory setting

Off

Assign channel 3**Navigation**

  Expert → Diagnostics → Data logging → Assign chan. 3 (0853)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  54).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→  276)

Factory setting

Off

Assign channel 4



Navigation

Expert → Diagnostics → Data logging → Assign chan. 4 (0854)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 54).

Description

Options for the assignment of a process variable to the data logging channel.

Selection

Picklist, see **Assign channel 1** parameter (→ 276)

Factory setting

Off

Logging interval



Navigation

Expert → Diagnostics → Data logging → Logging interval (0856)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 54).

Description

Use this function to enter the logging interval t_{log} for data logging.

User entry

1.0 to 3 600.0 s

Factory setting

10.0 s

Additional information

Description

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{log} :

- If 1 logging channel is used: $T_{log} = 1000 \times t_{log}$
- If 2 logging channels are used: $T_{log} = 500 \times t_{log}$
- If 3 logging channels are used: $T_{log} = 333 \times t_{log}$
- If 4 logging channels are used: $T_{log} = 250 \times t_{log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{log} always remains in the memory (ring memory principle).

The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data**Navigation**

Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ [54](#)).

Description

Option to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel

Additional information*Selection*

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

"Display channel 1" submenu*Navigation*

Expert → Diagnostics → Data logging → Displ.channel 1

**Display channel 1****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ [54](#)).

One of the following options is selected in the **Assign channel 1** parameter (→ [276](#)):


- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature
- Calculated saturated steam pressure *
- Steam quality *

* Visibility depends on order options or device settings

- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *
- Reynolds number *
- Density *
- Pressure *
- Vortex frequency
- Electronic temperature

Description

Displays the measured value trend for the logging channel in the form of a chart.

Additional information*Description*

A0016222

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu*Navigation*

Expert → Diagnostics → Data logging → Displ.channel 2

**Display channel 2****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite

A process variable is defined in the **Assign channel 2** parameter.

Description

See the **Display channel 1** parameter → 279

* Visibility depends on order options or device settings

"Display channel 3" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign channel 3** parameter.

Description

See the **Display channel 1** parameter → 279

"Display channel 4" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign channel 4** parameter.

Description


See the **Display channel 1** parameter → 279

3.10.6 "Min/max values" submenu

Navigation



Expert → Diagnostics → Min/max val.



▶ Terminal voltage	→ 282
▶ IO module temperature	→ 283
▶ Pre-amplifier temperature	→ 285
▶ Medium temperature	→ 286
▶ Flow velocity	→ 286
▶ External pressure	→ 287

Reset min/max values**Navigation**

Expert → Diagnostics → Min/max val. → Reset min/max (7706)

Description

Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection

- Cancel
- Terminal voltage 1
- Temperature
- Flow velocity
- Pressure

Factory setting

Cancel

"Terminal voltage" submenu*Navigation*

Expert → Diagnostics → Min/max val. → Terminal volt.

▶ Terminal voltage	
Minimum value (0689)	→ 283
Maximum value (0663)	→ 283
Average value (0698)	→ 283

Minimum value

Navigation	Expert → Diagnostics → Min/max val. → Terminal volt. → Minimum value (0689)
Description	Use this function to display the smallest previously measured terminal voltage value in Volts.
User interface	0.0 to 50.0 V

Maximum value


Navigation	Expert → Diagnostics → Min/max val. → Terminal volt. → Maximum value (0663)
Description	Use this function to view the largest previously measured terminal voltage value in Volts.
User interface	0.0 to 50.0 V

Average value

Navigation	Expert → Diagnostics → Min/max val. → Terminal volt. → Average value (0698)
Description	Use this function to view the average of all previously measured terminal voltage values in Volts.
User interface	Signed floating-point number

"IO module temperature" submenu

Navigation Expert → Diagnostics → Min/max val. → IO module temp.



Minimum value


Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Minimum value (0688)
Description	Displays the lowest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  75)

Maximum value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Maximum value (0665)
Description	Displays the highest previously measured temperature value of the I/O electronics module.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  75)

Average value

Navigation	 Expert → Diagnostics → Min/max val. → IO module temp. → Average value (0697)
Description	Displays the average value of all previously measured temperature values of the I/O electronics module.
User interface	-1273.15 to 726.85 °C
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  75)

"Pre-amplifier temperature" submenu**Navigation** Expert → Diagnostics → Min/max val. → Pre-amplif. temp

Minimum value

Navigation Expert → Diagnostics → Min/max val. → Pre-amplif. temp → Minimum value (7724)**Description**

Displays the lowest previously measured temperature value of the pre-amplifier module.

User interface

0 to 1 000 °C

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 75).

Maximum value


Navigation Expert → Diagnostics → Min/max val. → Pre-amplif. temp → Maximum value (7723)**Description**

Displays the highest previously measured temperature value of the pre-amplifier module.

User interface

0 to 1 000 °C

Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 75).

"Medium temperature" submenu*Navigation* Expert → Diagnostics → Min/max val. → Medium temp.

Minimum value**Navigation** Expert → Diagnostics → Min/max val. → Medium temp. → Minimum value (7655)**Description**

Displays the lowest previously medium temperature.

User interface

0 to 1 000 °C


Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 75).

Maximum value**Navigation** Expert → Diagnostics → Min/max val. → Medium temp. → Maximum value (7654)**Description**

Displays the highest previously medium temperature.

User interface

0 to 1 000 °C


Additional information*Dependency* The unit is taken from the **Temperature unit** parameter (→ 75).**"Flow velocity" submenu***Navigation* Expert → Diagnostics → Min/max val. → Flow velocity

Maximum value

Navigation	Diagram Expert → Diagnostics → Min/max val. → Flow velocity → Maximum value (7633)
Description	Displays the highest previously measured flow velocity.
User interface	Positive floating-point number
Additional information	<p><i>Dependency</i></p>  The unit is taken from the Velocity unit parameter (→ 79)

"External pressure" submenu

Navigation Diagram Expert → Diagnostics → Min/max val. → External press.




Maximum value


Navigation	Diagram Expert → Diagnostics → Min/max val. → External press. → Maximum value (7623)
Description	Displays the highest previously measured external pressure.
User interface	Positive floating-point number
Additional information	<p><i>Dependency</i></p>  The unit is taken from the Pressure unit parameter (→ 74)

3.10.7 "Heartbeat" submenu

 For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device

Navigation Diagram Expert → Diagnostics → Heartbeat






3.10.8 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation



Assign simulation process variable



Navigation

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity
- Temperature

- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Condensate mass flow *
- Energy flow
- Heat flow difference *
- Reynolds number

Factory setting Off

Additional information *Description*

-  The simulation value of the selected process variable is specified in the **Value process variable** parameter (→ 289).

Value process variable



Navigation  Expert → Diagnostics → Simulation → Value proc. var. (1811)

Prerequisite One of the following options is selected in the **Assign simulation process variable** parameter (→ 288):

- Volume flow
- Corrected volume flow
- Mass flow
- Flow velocity *
- Temperature *
- Calculated saturated steam pressure *
- Steam quality *
- Total mass flow *
- Condensate mass flow *
- Energy flow *
- Heat flow difference *
- Reynolds number *

Description Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry Depends on the process variable selected

Factory setting 0

Additional information *User entry*

-  The unit of the displayed measured value is taken from the **System units** submenu (→ 69).

* Visibility depends on order options or device settings

Frequency simulation



Navigation

Expert → Diagnostics → Simulation → Frequency sim. (0472)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ [290](#) 121).

Description

Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Frequency value** parameter (→ [290](#) 290).

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Frequency value



Navigation

Expert → Diagnostics → Simulation → Freq. value (0473)

Prerequisite

The **On** option is selected in the **Frequency simulation** parameter (→ [290](#) 290).

Description

Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry

0.0 to 1250.0 Hz

Factory setting

0.0 Hz

Pulse simulation



Navigation

Expert → Diagnostics → Simulation → Pulse sim. (0458)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ [290](#) 121).

Description	Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ Fixed value ▪ Down-counting value
Factory setting	Off
Additional information	<p><i>Description</i></p> <p> The desired simulation value is specified in the Pulse value parameter (→ 291).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated. ▪ Fixed value Pulses with the pulse width specified in the Pulse width parameter (→ 124) are output continuously. ▪ Down-counting value The pulses specified in the Pulse value parameter (→ 291) are output.

Pulse value



Navigation	 Expert → Diagnostics → Simulation → Pulse value (0459)
Prerequisite	In the Pulse simulation parameter (→ 290), the Down-counting value option is selected.
Description	Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.
User entry	0 to 65 535

Switch output simulation



Navigation	 Expert → Diagnostics → Simulation → Switch sim. (0462)
Prerequisite	The Switch option is selected in the Operating mode parameter (→ 121).
Description	Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On

Factory setting	Off
Additional information	<i>Description</i>
	 The desired simulation value is specified in the Switch status parameter (→ 292).

Selection

- Off
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Switch simulation is active.

Switch status	
Navigation	 Expert → Diagnostics → Simulation → Switch status (0463)
Prerequisite	The On option is selected in the Switch output simulation parameter (→ 291).
Description	Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.
Selection	<ul style="list-style-type: none">▪ Open▪ Closed
Factory setting	Open
Additional information	<i>Options</i>
	<ul style="list-style-type: none">▪ Open Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.▪ Closed Switch simulation is active.

Simulation device alarm	
Navigation	 Expert → Diagnostics → Simulation → Sim. alarm (0654)
Description	Use this function to switch the device alarm on and off.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<i>Description</i>
	In this way, users can verify the correct function of downstream switching units.

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category

Navigation	 Expert → Diagnostics → Simulation → Event category (0738)
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Simulation diagnostic event parameter (→  293).
Selection	<ul style="list-style-type: none">■ Sensor■ Electronics■ Configuration■ Process
Factory setting	Sensor

Simulation diagnostic event

Navigation	  Expert → Diagnostics → Simulation → Sim. diag. event (0737)
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	<ul style="list-style-type: none">■ Off■ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<i>Description</i>  For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→  293).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	m ³ /h
Volume	m ³
Mass flow	kg/h
Mass	kg
Corrected volume flow	Nm ³ /h
Corrected volume	Nm ³
Pressure	bar
Temperature	°C
Energy flow	kW
Energy	kWh
Calorific value (volume)	kJ/Nm ³
Calorific value (mass)	kJ/kg
Velocity	m/s
Density	kg/m ³
Dynamic viscosity	Pa s
Specific heat capacity	kJ/(kgK)
Length	mm

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	[m ³ /h]
15 25 > 15 40 >> 15	25
25 40 > 25 50 >> 25	125
40 50 > 40 80 >> 40	308
50 80 > 50 100 >> 50	513
80 100 > 80 150 >> 80	1 152

Nominal diameter [mm]	[m ³ /h]
100 150 > 100 200 >> 100	1995
150 200 > 150 250 >> 150	4539
200 250 > 200 300 >> 200	8713
250 300 > 250 350 >> 250	13735
300 350 > 300 400 >> 300	19701

4.1.3 Pulse value

Nominal diameter [mm]	Volume flow (~ 2 pulse/s) [m ³ /pulse]	Mass flow (~ 2 pulse/s) [kg/pulse]
15 25 > 15 40 >> 15	0.00067	0.0034
25 40 > 25 50 >> 25	0.0035	0.018
40 50 > 40 80 >> 40	0.0085	0.044
50 80 > 50 100 >> 50	0.023	0.12
80 100 > 80 150 >> 80	0.051	0.26
100 150 > 100 200 >> 100	0.089	0.46
150 200 > 150 250 >> 150	0.20	1.04
200 250 > 200 300 >> 200	0.39	1.99
250 300 > 250 350 >> 250	0.61	3.14
300 350 > 300 400 >> 300	0.88	4.51

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	ft ³ /min
Volume	ft ³
Mass flow	lb/min
Mass	lb
Corrected volume flow	Sft ³ /min
Corrected volume	Sft ³
Pressure	psi
Temperature	°F
Energy flow	Btu/h
Energy	Btu
Calorific value (volume)	Btu/Sft ³
Calorific value (mass)	Btu/lb
Velocity	ft/s
Density	lb/ft ³
Length	in

4.2.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	[ft ³ /h]
½ 1 > ½ 1½ >> ½	882
1 1½ > 1 2 >> 1	4414
1½ 2 > 1½ 3 >> 1½	10876
2 3 > 2 4 >> 2	18116
3 4 > 3 6 >> 3	40682
4 6 > 4 8 >> 4	70452
6 8 > 6 10 >> 6	160293

Nominal diameter [in]	[ft ³ /h]
8 10 > 8 12 >> 8	307696
10 12 > 10 14 >> 10	485046
12 14 > 12 16 >> 12	695734

4.2.3 Pulse value

Nominal diameter [in]	Volume flow	Volume flow
	~ 2 pulse/s [gal/pulse]	~ 2 pulse/s [lb/pulse]
½ 1 > ½ 1½ >> ½	0.18	0.0076
1 1½ > 1 2 >> 1	0.92	0.039
1½ 2 > 1½ 3 >> 1½	2.25	0.097
2 3 > 2 4 >> 2	6.02	0.26
3 4 > 3 6 >> 3	13.50	0.58
4 6 > 4 8 >> 4	23.42	1.01
6 8 > 6 10 >> 6	53.29	2.29
8 10 > 8 12 >> 8	102.29	4.40
10 12 > 10 14 >> 10	161.26	6.93
12 14 > 12 16 >> 12	231.30	9.94

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Calorific value (volume)	kWh/Nm ³ , MWh/Nm ³ , kJ/Nm ³ , MJ/Nm ³	Kilowatt hour, megawatt hour, kilojoule, megajoule/standard cubic meter
	kWh/Sm ³ , MWh/Sm ³ , kJ/Sm ³ , MJ/Sm ³	Kilowatt hour, megawatt hour, kilojoule, megajoule/standard cubic meter
Calorific value (mass)	kWh/kg, MWh/kg, kJ/kg, MJ/kg	Kilowatt hour, megawatt hour, kilojoule, megajoule/kilogram
Density	g/cm ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the fluid density to the water density at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the fluid density to the water density at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Pressure	Pa, kPa, MPa	Pascal, kilopascal, megapascal
	mbar a	Millibar (absolute)
	bar, torr, atm	Bar, torr, physical atmosphere
	gf/cm ² , kgf/cm ²	Gram force, kilogram force/square centimeter
Dynamic viscosity	Pa s	Pascal second
	cP, P	Centipoise, poise
Energy	kWh, MWh, GWh	Kilowatt hour, megawatt hour, gigawatt hour
	kJ, MJ, GJ	Kilojoule, megajoule, gigajoule
	kcal, Mcal, Gcal	Kilocalories, megacalories, gigacalories
Energy flow	kW, MW, GW	Kilowatt, megawatt
	kJ/s, kJ/min, kJ/h, kJ/d	Kilojoule/time unit
	MJ/s, MJ/min, MJ/h, MJ/d	Megajoule/time unit
	GJ/s, GJ/min, GJ/h, GJ/d	Gigajoule/time unit
	kcal/s, kcal/min, kcal/h, kcal/d	Kilocalories/time unit
	Mcal/s, Mcal/min, Mcal/h, Mcal/d	Megacalories/time unit
	Gcal/s, Gcal/min, Gcal/h, Gcal/d	Gigacalories/time unit
Velocity	m/s	Meter/time unit
Length	mm, m	Millimeter, meter
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Corrected volume	Nl, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Corrected volume flow	Nl/s, Nl/min, Nl/h, Nl/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit

Process variable	Units	Explanation
Specific heat capacity	kJ/(kgK), MJ/(kgK)	Kilojoule, megajoule/kilogram Kelvin
	kWh/(kgK)	Kilowatt hour/kilogram Kelvin
	kcal/(kgK)	Kilocalories/kilogram Kelvin
Temperature	°C , K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l	Milliliter, liter
Volume flow	cm ³ /s , cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
Time	m, h, d, y	Minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Calorific value (mass)	kWh/lb, MWh/lb, kJ/lb, MJ/lb	Kilowatt hour, kilojoule, British thermal unit, thousand British thermal units/pound
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Pressure	psi a	Psi absolute
Velocity	ft/s	Foot/time unit
Length	in, ft	Inch, foot
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Corrected volume	Sft ³	Standard cubic foot
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit

Process variable	Units	Explanation
	kgal/s (us), kgal/min (us), kgal/h (us,) kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel /time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Calorific value (volume)	Btu/Sm ³ , MBtu/Sm ³	British thermal unit, thousand British thermal units/standard cubic meter
	Btu/Sft ³ , MBtu/Sft ³	British thermal unit, thousand British thermal units/standard cubic foot
Calorific value (mass)	Btu/lb, MBtu/lb	British thermal unit, thousand British thermal units/pound
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Energy	Btu, MBtu, MMBtu	British thermal unit, thousand British thermal units, million British thermal units
Energy flow	Btu/s, Btu/min, Btu/h, Btu/day	British thermal unit/time unit
	MBtu/s, MBtu/min, MBtu/h, MBtu/d	Thousand British thermal units/time unit
	MMBtu/s, MMBtu/min, MMBtu/h, MMBtu/d	Million British thermal units/time unit
Specific heat capacity	Btu/(lb °R)	British thermal unit/pound degree Rankine
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	m, h, d, y	Minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.4 Other units

Process variable	Units	Explanation
Pressure	mmH ₂ O (4°C)	Millimeter of water column (4 °C)
	mmH ₂ O (68°F)	Millimeter of water column (68 °F)
	mmHg (0°C)	Millimeter of mercury column (0 °C)
	inH ₂ O (4°C)	Inch of water column (4 °C)
	inH ₂ O (68°F)	Inch of water column (68 °F)
	ftH ₂ O (68°F)	Foot of water column (68 °F)
Specific volume	m ³ /kg	Cubic meter/kilogram
	ft ³ /lb	Cubic foot/pound

Index

0 ... 9

- 0% bargraph value 1 (Parameter) 18
0% bargraph value 3 (Parameter) 21
2nd temperature delta heat (Parameter) 115
100% bargraph value 1 (Parameter) 19
100% bargraph value 3 (Parameter) 22

A

- Access status display (Parameter) 12, 26
Access status tooling (Parameter) 13
Acknowledge Option (Parameter) 158, 200, 233
Activate sensor emergency mode (Parameter) 54
Activate SW option (Parameter) 53
Actual diagnostics (Parameter) 262
Actual mode (Parameter) 143, 163, 213, 241, 250
Administration (Submenu) 50
Alarm delay (Parameter) 31
Alarm Hysteresis (Parameter) 201
Alarm State (Parameter) 155, 159, 198, 204, 206,
207, 209, 235, 236
Alert Key (Parameter) 141, 163, 212, 240, 249
Analog input 1 to 4 (Submenu) 161
Analog inputs (Submenu) 161
Analog outputs (Submenu) 239
Application (Submenu) 256
Assign behavior of diagnostic no. 022 (Parameter) 34
Assign behavior of diagnostic no. 122 (Parameter) 35
Assign behavior of diagnostic no. 350 (Parameter) 35
Assign behavior of diagnostic no. 371 (Parameter) 36
Assign behavior of diagnostic no. 442 (Parameter) 36
Assign behavior of diagnostic no. 443 (Parameter) 36
Assign behavior of diagnostic no. 828 (Parameter) 37
Assign behavior of diagnostic no. 829 (Parameter) 37
Assign behavior of diagnostic no. 832 (Parameter) 37
Assign behavior of diagnostic no. 833 (Parameter) 38
Assign behavior of diagnostic no. 834 (Parameter) 38
Assign behavior of diagnostic no. 835 (Parameter) 39
Assign behavior of diagnostic no. 841 (Parameter) 39
Assign behavior of diagnostic no. 844 (Parameter) 39
Assign behavior of diagnostic no. 870 (Parameter) 40
Assign behavior of diagnostic no. 871 (Parameter) 40
Assign behavior of diagnostic no. 872 (Parameter) 40
Assign behavior of diagnostic no. 873 (Parameter) 41
Assign behavior of diagnostic no. 945 (Parameter) 41
Assign behavior of diagnostic no. 947 (Parameter) 42
Assign channel 1 (Parameter) 276
Assign channel 2 (Parameter) 277
Assign channel 3 (Parameter) 277
Assign channel 4 (Parameter) 278
Assign diagnostic behavior (Parameter) 133
Assign flow direction check (Parameter) 136
Assign frequency output (Parameter) 127
Assign limit (Parameter) 134
Assign process variable (Parameter) 83, 257
Assign pulse output (Parameter) 123
Assign simulation process variable (Parameter) 288

- Assign status (Parameter) 137
Assign status of diagnostic number 022 (Parameter) 42
Assign status of diagnostic number 122 (Parameter) 42
Assign status of diagnostic number 350 (Parameter) 43
Assign status of diagnostic number 371 (Parameter) 43
Assign status of diagnostic number 828 (Parameter) 43
Assign status of diagnostic number 829 (Parameter) 44
Assign status of diagnostic number 832 (Parameter) 44
Assign status of diagnostic number 833 (Parameter) 44
Assign status of diagnostic number 834 (Parameter) 45
Assign status of diagnostic number 835 (Parameter) 45
Assign status of diagnostic number 841 (Parameter) 45
Assign status of diagnostic number 844 (Parameter) 46
Assign status of diagnostic number 870 (Parameter) 46
Assign status of diagnostic number 871 (Parameter) 46
Assign status of diagnostic number 872 (Parameter) 47
Assign status of diagnostic number 873 (Parameter) 47
Assign status of diagnostic number 945 (Parameter) 47
Assign status of diagnostic number 947 (Parameter) 48
Atmospheric pressure (Parameter) 113
Average value (Parameter) 283, 284

B

- Backlight (Parameter) 26
Backup state (Parameter) 29
Block Error (Parameter) 144, 165, 214, 243, 252
Block tag (Parameter) 140, 162, 211, 239, 248

C

- Calculated saturated steam pressure (Parameter) 60
Calibration (Submenu) 119
Calibration factor (Parameter) 119
Calorific value (Parameter) 92
Calorific value type (Parameter) 90
Calorific value unit (Parameter) 77, 78
Channel (Parameter) 190, 228, 243, 252
Clear Fault State (Parameter) 151
Clear logging data (Parameter) 279
Communication (Submenu) 139
Comparison result (Parameter) 29
Compressibility factor (Parameter) 64
Condensate mass flow (Parameter) 61
Configuration backup display (Submenu) 27
Configuration management (Parameter) 28
Confirm access code (Parameter) 51
Confirm Time (Parameter) 151
Contrast display (Parameter) 26
Control Totalizer 1 to 3 (Parameter) 260
Corrected volume flow (Parameter) 57
Corrected volume flow unit (Parameter) 73
Corrected volume unit (Parameter) 74
Current (Parameter) 157, 199, 233
Cycle Selection (Parameter) 149
Cycle Type (Parameter) 149

D

- Damping output (Parameter) 130

Data logging (Submenu)	275	Analog input 1 to 4 (6927-1 to 4)	206
Date/time format (Parameter)	81	Analog input 1 to 4 (6932-1 to 4)	204
DD Resource (Parameter)	146	Analog input 1 to 4 (6942-1 to 4)	207
DD Revision (Parameter)	147, 272	Analog input 1 to 4 (6948-1 to 4)	209
Decimal (Parameter)	179, 189	Discrete input 1 to 2 (6847-1 to 2)	235
Decimal places 1 (Parameter)	19	Discrete input 1 to 2 (6858-1 to 2)	236
Decimal places 2 (Parameter)	20	Alarm State (10697)	155
Decimal places 3 (Parameter)	22	Alarm State (10742)	159
Decimal places 4 (Parameter)	23	Alert Key	
Define access code (Parameter)	50, 51	Analog input 1 to 4 (6916-1 to 4)	163
Define access code (Wizard)	50	Discrete input 1 to 2 (6846-1 to 2)	212
Degrees of superheat limit (Parameter)	49	Alert Key (10696)	141
Delta heat calculation (Parameter)	114	Alert Key (11251)	249
Density (Parameter)	62	Alert Key (11365)	240
Density calculation (Parameter)	88	Assign behavior of diagnostic no. 022 (0751)	34
Density unit (Parameter)	79	Assign behavior of diagnostic no. 122 (0752)	35
Deny (Parameter)	147, 189, 227	Assign behavior of diagnostic no. 350 (0756)	35
Device address (Parameter)	139	Assign behavior of diagnostic no. 371 (0757)	36
Device information (Submenu)	271	Assign behavior of diagnostic no. 442 (0658)	36
Device Revision (Parameter)	147, 272	Assign behavior of diagnostic no. 443 (0659)	36
Device tag (Parameter)	271	Assign behavior of diagnostic no. 828 (0755)	37
Device type (Parameter)	146, 272	Assign behavior of diagnostic no. 829 (0754)	37
Diagnostic behavior (Submenu)	32	Assign behavior of diagnostic no. 832 (0675)	37
Diagnostic event category (Parameter)	293	Assign behavior of diagnostic no. 833 (0676)	38
Diagnostic handling (Submenu)	30	Assign behavior of diagnostic no. 834 (0677)	38
Diagnostic limits (Submenu)	48	Assign behavior of diagnostic no. 835 (0678)	39
Diagnostic list (Submenu)	265	Assign behavior of diagnostic no. 841 (0729)	39
Diagnostics (Submenu)	262	Assign behavior of diagnostic no. 844 (0747)	39
Diagnostics 1 (Parameter)	265	Assign behavior of diagnostic no. 870 (0726)	40
Diagnostics 2 (Parameter)	266	Assign behavior of diagnostic no. 871 (0748)	40
Diagnostics 3 (Parameter)	266	Assign behavior of diagnostic no. 872 (0746)	40
Diagnostics 4 (Parameter)	267	Assign behavior of diagnostic no. 873 (0749)	41
Diagnostics 5 (Parameter)	268	Assign behavior of diagnostic no. 945 (0750)	41
Direct access		Assign behavior of diagnostic no. 947 (0753)	42
0% bargraph value 1 (0123)	18	Assign channel 1 (0851)	276
0% bargraph value 3 (0124)	21	Assign channel 2 (0852)	277
2nd temperature delta heat (7625)	115	Assign channel 3 (0853)	277
100% bargraph value 1 (0125)	19	Assign channel 4 (0854)	278
100% bargraph value 3 (0126)	22	Assign diagnostic behavior (0482)	133
Access status display (0091)	12, 26	Assign flow direction check (0484)	136
Access status tooling (0005)	13	Assign frequency output (0478)	127
Acknowledge Option		Assign limit (0483)	134
Analog input 1 to 4 (6910-1 to 4)	200	Assign process variable	
Discrete input 1 to 2 (6841-1 to 2)	233	Totalizer 1 to 3 (0914-1 to 3)	257
Acknowledge Option (10691)	158	Assign process variable (1837)	83
Activate sensor emergency mode (7712)	54	Assign pulse output (0460)	123
Activate SW option (0029)	53	Assign simulation process variable (1810)	288
Actual diagnostics (0691)	262	Assign status (0485)	137
Actual mode		Assign status of diagnostic number 022 (11041)	42
Analog input 1 to 4 (6957-1 to 4)	163	Assign status of diagnostic number 122 (11042)	42
Discrete input 1 to 2 (6870-1 to 2)	213	Assign status of diagnostic number 350 (11000)	43
Actual mode (10725)	143	Assign status of diagnostic number 371 (11014)	43
Actual mode (11264)	250	Assign status of diagnostic number 828 (11015)	43
Actual mode (11366)	241	Assign status of diagnostic number 829 (11001)	44
Alarm delay (0651)	31	Assign status of diagnostic number 832 (11002)	44
Alarm Hysteresis		Assign status of diagnostic number 833 (11003)	44
Analog input 1 to 4 (6911-1 to 4)	201	Assign status of diagnostic number 834 (11004)	45
Alarm State		Assign status of diagnostic number 835 (11005)	45
Analog input 1 to 4 (6917-1 to 4)	198	Assign status of diagnostic number 841 (11006)	45

Assign status of diagnostic number 844 (11007)	46
Assign status of diagnostic number 870 (11008)	46
Assign status of diagnostic number 871 (11009)	46
Assign status of diagnostic number 872 (11010)	47
Assign status of diagnostic number 873 (11011)	47
Assign status of diagnostic number 945 (11012)	47
Assign status of diagnostic number 947 (11013)	48
Atmospheric pressure (7601)	113
Average value (0697)	284
Average value (0698)	283
Backlight (0111)	26
Backup state (0121)	29
Block Error	
Analog input 1 to 4 (6922–1 to 4)	165
Discrete input 1 to 2 (6857–1 to 2)	214
Block Error (10703)	144
Block Error (11272)	252
Block Error (11364)	243
Block tag	
Analog input 1 to 4 (6901–1 to 4)	162
Discrete input 1 to 2 (6851–1 to 2)	211
Block tag (10702)	140
Block tag (11252)	248
Block tag (11351)	239
Calculated saturated steam pressure (1852)	60
Calibration factor (7604)	119
Calorific value (7626)	92
Calorific value type (7698)	90
Calorific value unit (0552)	77
Calorific value unit (0606)	78
Channel	
Analog input 1 to 4 (6902–1 to 4)	190
Discrete input 1 to 2 (6852–1 to 2)	228
Channel (11253)	252
Channel (11352)	243
Clear Fault State (10704)	151
Clear logging data (0855)	279
Comparison result (0103)	29
Compressibility factor (7729)	64
Condensate mass flow (1857)	61
Configuration management (0100)	28
Confirm Time (10705)	151
Contrast display (0105)	26
Control Totalizer 1 to 3 (0912–1 to 3)	260
Corrected volume flow (1850)	57
Corrected volume flow unit (0558)	73
Corrected volume unit (0575)	74
Current	
Analog input 1 to 4 (6912–1 to 4)	199
Discrete input 1 to 2 (6842–1 to 2)	233
Current (10692)	157
Cycle Selection (10706)	149
Cycle Type (10707)	149
Damping output (0477)	130
Date/time format (2812)	81
DD Resource (10708)	146
DD Revision (10709)	147, 272
Decimal	
Analog input 1 to 4 (6961–1 to 4)	189
Analog input 1 to 4 (6980–1 to 4)	179
Decimal places 1 (0095)	19
Decimal places 2 (0117)	20
Decimal places 3 (0118)	22
Decimal places 4 (0119)	23
Define access code (0093)	51
Degrees of superheat limit (7737)	49
Delta heat calculation (7736)	114
Density (7607)	62
Density calculation (7608)	88
Density unit (0555)	79
Deny	
Analog input 1 to 4 (6925–1 to 4)	189
Discrete input 1 to 2 (6867–1 to 2)	227
Deny (10717)	147
Device address (11061)	139
Device Revision (10710)	147, 272
Device tag (10799)	271
Device type (10711)	146, 272
Diagnostic event category (0738)	293
Diagnostics 1 (0692)	265
Diagnostics 2 (0693)	266
Diagnostics 3 (0694)	266
Diagnostics 4 (0695)	267
Diagnostics 5 (0696)	268
Direct access (0106)	11
Disabled	
Analog input 1 to 4 (6913–1 to 4)	200
Discrete input 1 to 2 (6843–1 to 2)	234
Disabled (10693)	157
Discrete Limit	
Discrete input 1 to 2 (6863–1 to 2)	238
Discrete Priority	
Discrete input 1 to 2 (6864–1 to 2)	238
Discrete Value	
Discrete input 1 to 2 (6862–1 to 2)	238
Discrete Value (10746)	160
Display damping (0094)	24
Display interval (0096)	23
DSC sensor serial number (7728)	275
Dynamic viscosity (7732)	93
Dynamic viscosity (7733)	92
Dynamic viscosity unit (0577)	80
Energy flow (1872)	61
Energy flow unit (0565)	76
Energy unit (0559)	77
ENP version (10791)	275
Enter access code (0003)	14
Enter access code (0092)	14
Enthalpy calculation (7619)	88
Enthalpy type (7620)	90
EU at 0%	
Analog input 1 to 4 (6962–1 to 4)	180
Analog input 1 to 4 (6981–1 to 4)	176
EU at 100%	
Analog input 1 to 4 (6963–1 to 4)	180
Analog input 1 to 4 (6982–1 to 4)	176
Extended order code (10795)	273
Extended order code 1 (10796)	274

Extended order code 2 (10797)	274	Header text (0112)	25
External value (7622)	113	Heat flow difference (1863)	61
Failure frequency (0474)	132	High High Limit Analog input 1 to 4 (6937-1 to 4)	201
Failure mode Totalizer 1 to 3 (0901-1 to 3)	261	High High Priority Analog input 1 to 4 (6938-1 to 4)	201
Failure mode (0451)	131	High Limit Analog input 1 to 4 (6939-1 to 4)	202
Failure mode (0480)	125	High Priority Analog input 1 to 4 (6940-1 to 4)	202
Failure mode (0486)	138	I/O Options Analog input 1 to 4 (6941-1 to 4)	189
Fault State (10712)	151	Discrete input 1 to 2 (6869-1 to 2)	227
Fault State Status (11254)	256	Inlet configuration (7641)	117
Fault State Status (11353)	247	Inlet run (7642)	117
Fault State Time (11255)	253	Installation factor (7616)	119
Fault State Time (11354)	244	Invert output signal (0470)	138
Fault State Val 1 (11355)	244	ITK Version (10794)	161, 273
Fault State Val 2 (11356)	245	Language (0104)	15
Fault State Val 3 (11357)	245	Last backup (0102)	28
Fault State Val 4 (11358)	245	Length unit (0551)	81
Fault State Val 5 (11359)	246	Limit Notify (10720)	152
Fault State Val 6 (11360)	246	Linear expansion coefficient (7621)	91
Fault State Val 7 (11361)	246	Linearization Type Analog input 1 to 4 (6905-1 to 4)	191
Fault State Val 8 (11362)	247	Locking status (0004)	12
Fault State Value Discrete 1 (11256)	253	Logging interval (0856)	278
Fault State Value Discrete 2 (11257)	254	Low Cutoff Analog input 1 to 4 (6956-1 to 4)	193
Fault State Value Discrete 3 (11258)	254	Low Limit Analog input 1 to 4 (6947-1 to 4)	203
Fault State Value Discrete 4 (11259)	254	Low Low Limit Analog input 1 to 4 (6953-1 to 4)	203
Fault State Value Discrete 5 (11260)	255	Low Low Priority Analog input 1 to 4 (6954-1 to 4)	203
Fault State Value Discrete 6 (11261)	255	Low Priority Analog input 1 to 4 (6955-1 to 4)	202
Fault State Value Discrete 7 (11262)	255	Manufacturer Id (10721)	146
Fault State Value Discrete 8 (11263)	256	Mass flow (1847)	58
Feature Selection (10714)	149	Mass flow unit (0554)	72
Features (10713)	148	Mass unit (0574)	73
Filter options (0656)	269	Mating pipe diameter (7648)	118
Filter options (0705)	269	Max Notify (10722)	152
Firmware version (10792)	273	Maximum frequency value (0454)	128
Fixed density (7627)	114	Maximum value (0663)	283
Fixed process pressure (7629)	115	Maximum value (0665)	284
Fixed temperature (7628)	114	Maximum value (7623)	287
Float Value Analog input 1 to 4 (6931-1 to 4)	207	Maximum value (7633)	287
Analog input 1 to 4 (6936-1 to 4)	205	Maximum value (7654)	286
Analog input 1 to 4 (6946-1 to 4)	208	Maximum value (7723)	285
Analog input 1 to 4 (6952-1 to 4)	210	Measuring value at maximum frequency (0475)	129
Flow damping (1802)	83	Measuring value at minimum frequency (0476)	128
Flow override (1839)	82	Memory Size (10723)	150
Flow velocity (1865)	59	Meter body properties (7658)	120
Format display (0098)	16	Minimum frequency value (0453)	127
Free Space (10715)	150	Minimum value (0688)	284
Free Time (10716)	150	Minimum value (0689)	283
Frequency simulation (0472)	290	Minimum value (7655)	286
Frequency value (0473)	290	Minimum value (7724)	285
Gas mixture (7640)	99		
Gas type (7714)	99		
Grant Analog input 1 to 4 (6926-1 to 4)	189		
Discrete input 1 to 2 (6868-1 to 2)	227		
Grant (10718)	147		
Hard Types (10719)	148		
Hardware revision (10793)	273		
Header (0097)	24		

Minimum Cycle Time (10724)	150	Discrete input 1 to 2 (6855–1 to 2)	228
Mol% Ar (7663)	100	Pulse output (0456)	68, 126
Mol% C2H3Cl (7664)	100	Pulse simulation (0458)	290
Mol% C2H4 (7665)	101	Pulse value (0459)	291
Mol% C2H6 (7666)	101	Pulse width (0452)	124
Mol% C3H8 (7667)	102	Reference combustion temperature (7699)	94
Mol% CH4 (7668)	102	Reference density (7700)	94
Mol% Cl2 (7707)	102	Reference gross calorific value (7701)	95
Mol% CO (7669)	103	Reference pressure (7702)	95
Mol% CO2 (7670)	103	Reference temperature (7703)	96
Mol% H2 (7671)	104	Reference Z-factor (7704)	96
Mol% H2O (7672)	104	Relative density (7705)	96
Mol% H2S (7673)	104	Relative humidity (7731)	112
Mol% HCl (7674)	105	Relative Index	
Mol% He (7675)	105	Analog input 1 to 4 (6975–1 to 4)	197
Mol% i-C4H10 (7676)	106	Discrete input 1 to 2 (6886–1 to 2)	233
Mol% i-C5H12 (7677)	106	Relative Index (10737)	154
Mol% Kr (7678)	106	Reset all totalizers (2806)	257
Mol% n-C4H10 (7681)	108	Reset min/max values (7706)	282
Mol% n-C5H12 (7682)	108	Resource State (10730)	145
Mol% n-C6H14 (7683)	108	Response time (0491)	130
Mol% n-C7H16 (7684)	109	Restart (10800)	52, 148
Mol% n-C8H18 (7685)	109	Reynolds number (1864)	62
Mol% n-C9H20 (7686)	109	Reynolds number limit (7646)	48
Mol% n-C10H22 (7680)	107	Saturated steam calculation mode (7708)	89
Mol% N2 (7679)	107	Saturation temperature (7709)	63
Mol% Ne (7687)	110	Select gas type (7635)	86
Mol% NH3 (7688)	110	Select liquid type (7636)	87
Mol% O2 (7689)	111	Select medium (7653)	85
Mol% other gas (7690)	112	Select steam type (7637)	87
Mol% SO2 (7691)	111	Separator (0101)	25
Mol% Xe (7692)	111	Serial number (10798)	272
Nonvolatile Cycle Time (10729)	150	Set Fault State (10731)	152
Normal mode		Shed Remote Cascade (10732)	152
Analog input 1 to 4 (6958–1 to 4)	164	Shed Remote Out (10733)	153
Discrete input 1 to 2 (6871–1 to 2)	214	Simulate En/Disable	
Normal mode (10726)	144	Analog input 1 to 4 (6966–1 to 4)	176
Normal mode (11265)	251	Discrete input 1 to 2 (6877–1 to 2)	226
Normal mode (11367)	242	Simulate Status	
Off value low flow cutoff (1804)	84	Analog input 1 to 4 (6967–1 to 4)	170
On value low flow cutoff (1805)	84	Discrete input 1 to 2 (6878–1 to 2)	220
Operating mode (0469)	121	Simulate Value	
Operating time (0652)	27, 264	Analog input 1 to 4 (6968–1 to 4)	173
Operating time from restart (0653)	264	Discrete input 1 to 2 (6879–1 to 2)	222
Output frequency (0471)	69, 132	Simulation device alarm (0654)	292
Output State		Simulation diagnostic event (0737)	293
Discrete input 1 to 2 (6874–1 to 2)	226	Software option overview (0015)	54
Permitted mode		Specific heat capacity (7716)	97
Analog input 1 to 4 (6959–1 to 4)	164	Specific heat capacity unit (0604)	80
Discrete input 1 to 2 (6872–1 to 2)	213	Static revision	
Permitted mode (10727)	143	Analog input 1 to 4 (6976–1 to 4)	197
Permitted mode (11266)	251	Discrete input 1 to 2 (6887–1 to 2)	233
Permitted mode (11368)	242	Static Revision	
Preset value 1 to 3 (0913–1 to 3)	260	Analog input 1 to 4 (6973–1 to 4)	162
Pressure (7696)	63	Discrete input 1 to 2 (6884–1 to 2)	211
Pressure unit (0564)	74	Static Revision (10735)	140
Previous diagnostics (0690)	263	Static revision (10738)	154
Process Value Filter Time		Static Revision (11270)	249
Analog input 1 to 4 (6909–1 to 4)	196	Static Revision (11371)	240

Status	
Analog input 1 to 4 (6906-1 to 4)	168
Analog input 1 to 4 (6923-1 to 4)	193
Analog input 1 to 4 (6964-1 to 4)	165
Discrete input 1 to 2 (6853-1 to 2)	217
Discrete input 1 to 2 (6865-1 to 2)	229
Discrete input 1 to 2 (6875-1 to 2)	215
Status Options	
Analog input 1 to 4 (6971-1 to 4)	190
Discrete input 1 to 2 (6882-1 to 2)	228
Status Options (11268)	252
Status Options (11363)	243
Steam quality (1853)	60
Steam quality (7605)	116
Steam quality limit (7717)	49
Steam quality value (7630)	116
Strategy	
Analog input 1 to 4 (6972-1 to 4)	162
Discrete input 1 to 2 (6883-1 to 2)	212
Strategy (10734)	141
Strategy (11269)	249
Strategy (11370)	240
Subcode	
Analog input 1 to 4 (6918-1 to 4)	199
Analog input 1 to 4 (6928-1 to 4)	206
Analog input 1 to 4 (6933-1 to 4)	204
Analog input 1 to 4 (6943-1 to 4)	208
Analog input 1 to 4 (6949-1 to 4)	210
Discrete input 1 to 2 (6848-1 to 2)	235
Discrete input 1 to 2 (6859-1 to 2)	236
Subcode (10698)	156
Subcode (10743)	160
Switch output function (0481)	132
Switch output simulation (0462)	291
Switch status (0461)	69, 138
Switch status (0463)	292
Switch-off delay (0465)	137
Switch-off value (0464)	136
Switch-on delay (0467)	137
Switch-on value (0466)	135
Tag Description	
Analog input 1 to 4 (6974-1 to 4)	162
Discrete input 1 to 2 (6885-1 to 2)	212
Tag Description (10736)	141
Tag Description (11271)	249
Tag Description (11372)	240
Target mode	
Analog input 1 to 4 (6960-1 to 4)	163
Discrete input 1 to 2 (6873-1 to 2)	212
Target mode (10728)	141
Target mode (11267)	250
Target mode (11369)	241
Temperature (1851)	59
Temperature unit (0557)	75
Terminal voltage 1 (0662)	68
Time Stamp	
Analog input 1 to 4 (6919-1 to 4)	198
Analog input 1 to 4 (6929-1 to 4)	206
Analog input 1 to 4 (6934-1 to 4)	204
Analog input 1 to 4 (6944-1 to 4)	208
Analog input 1 to 4 (6950-1 to 4)	209
Analog input 1 to 4 (6977-1 to 4)	197
Discrete input 1 to 2 (6849-1 to 2)	235
Discrete input 1 to 2 (6860-1 to 2)	237
Discrete input 1 to 2 (6888-1 to 2)	232
Time Stamp (10699)	156
Time Stamp (10739)	154
Time Stamp (10744)	159
Timestamp (0667)	263
Timestamp (0672)	264
Timestamp (0683)	265
Timestamp (0684)	266
Timestamp (0685)	267
Timestamp (0686)	267
Timestamp (0687)	268
Total mass flow (1854)	60
Totalizer overflow 1 to 3 (0910-1 to 3)	67
Totalizer value 1 to 3 (0911-1 to 3)	66
Transducer State	
Discrete input 1 to 2 (6891-1 to 2)	226
Transducer Status	
Analog input 1 to 4 (6969-1 to 4)	173
Discrete input 1 to 2 (6880-1 to 2)	223
Transducer Value	
Analog input 1 to 4 (6970-1 to 4)	175
Discrete input 1 to 2 (6881-1 to 2)	225
Unacknowledged	
Analog input 1 to 4 (6914-1 to 4)	200
Analog input 1 to 4 (6920-1 to 4)	198
Analog input 1 to 4 (6930-1 to 4)	205
Analog input 1 to 4 (6935-1 to 4)	203
Analog input 1 to 4 (6945-1 to 4)	207
Analog input 1 to 4 (6951-1 to 4)	209
Analog input 1 to 4 (6978-1 to 4)	196
Discrete input 1 to 2 (6844-1 to 2)	234
Discrete input 1 to 2 (6850-1 to 2)	236
Discrete input 1 to 2 (6861-1 to 2)	237
Discrete input 1 to 2 (6889-1 to 2)	232
Unacknowledged (10694)	157
Unacknowledged (10700)	155
Unacknowledged (10740)	153
Unacknowledged (10745)	159
Unit totalizer	
Totalizer 1 to 3 (0915-1 to 3)	258
Units index	
Analog input 1 to 4 (6908-1 to 4)	180
Analog input 1 to 4 (6983-1 to 4)	176
Unreported	
Analog input 1 to 4 (6915-1 to 4)	200
Discrete input 1 to 2 (6845-1 to 2)	234
Unreported (10695)	157
Update State	
Analog input 1 to 4 (6979-1 to 4)	197
Discrete input 1 to 2 (6890-1 to 2)	232
Update State (10741)	153
Value	
Analog input 1 to 4 (6907-1 to 4)	170
Analog input 1 to 4 (6921-1 to 4)	199

Analog input 1 to 4 (6924-1 to 4)	196
Analog input 1 to 4 (6965-1 to 4)	167
Discrete input 1 to 2 (6854-1 to 2)	220
Discrete input 1 to 2 (6856-1 to 2)	236
Discrete input 1 to 2 (6866-1 to 2)	231
Discrete input 1 to 2 (6876-1 to 2)	217
Value (10701)	156
Value 1 display (0107)	18
Value 2 display (0108)	20
Value 3 display (0110)	21
Value 4 display (0109)	22
Value per pulse (0455)	124
Value process variable (1811)	289
Velocity unit (0566)	79
Volume flow (1838)	57
Volume flow unit (0553)	70
Volume unit (0563)	72
Vortex frequency (7722)	64
Write Lock (10747)	154
Write Priority (10748)	158
Z-factor (7631)	94
Direct access (Parameter)	11
Disabled (Parameter)	157, 200, 234
Discrete input 1 to 2 (Submenu)	211
Discrete inputs (Submenu)	210
Discrete Limit (Parameter)	238
Discrete outputs (Submenu)	247
Discrete Priority (Parameter)	238
Discrete Value (Parameter)	160, 238
Display (Submenu)	14
Display channel 1 (Submenu)	279
Display channel 2 (Submenu)	280
Display channel 3 (Submenu)	281
Display channel 4 (Submenu)	281
Display damping (Parameter)	24
Display interval (Parameter)	23
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4
Document function	4
DSC sensor serial number (Parameter)	275
Dynamic viscosity (Parameter)	92, 93
Dynamic viscosity unit (Parameter)	80

E

Energy flow (Parameter)	61
Energy flow unit (Parameter)	76
Energy unit (Parameter)	77
ENP version (Parameter)	275
Enter access code (Parameter)	14
Enthalpy calculation (Parameter)	88
Enthalpy type (Parameter)	90
EU at 0% (Parameter)	176, 180
EU at 100% (Parameter)	176, 180

Event list (Submenu)	270
Event logbook (Submenu)	268
Extended order code (Parameter)	273
Extended order code 1 (Parameter)	274
Extended order code 2 (Parameter)	274
External compensation (Submenu)	112
External pressure (Submenu)	287
External value (Parameter)	113

F

Factory settings	294
SI units	294
US units	296
Failure frequency (Parameter)	132
Failure mode (Parameter)	125, 131, 138, 261
Fault State (Parameter)	151
Fault State Status (Parameter)	247, 256
Fault State Time (Parameter)	244, 253
Fault State Val 1 (Parameter)	244
Fault State Val 2 (Parameter)	245
Fault State Val 3 (Parameter)	245
Fault State Val 4 (Parameter)	245
Fault State Val 5 (Parameter)	246
Fault State Val 6 (Parameter)	246
Fault State Val 7 (Parameter)	246
Fault State Val 8 (Parameter)	247
Fault State Value Discrete 1 (Parameter)	253
Fault State Value Discrete 2 (Parameter)	254
Fault State Value Discrete 3 (Parameter)	254
Fault State Value Discrete 4 (Parameter)	254
Fault State Value Discrete 5 (Parameter)	255
Fault State Value Discrete 6 (Parameter)	255
Fault State Value Discrete 7 (Parameter)	255
Fault State Value Discrete 8 (Parameter)	256
Feature Selection (Parameter)	149
Features (Parameter)	148
Filter options (Parameter)	269
Firmware version (Parameter)	273
Fixed density (Parameter)	114
Fixed process pressure (Parameter)	115
Fixed temperature (Parameter)	114
Float Value (Parameter)	205, 207, 208, 210
Flow damping (Parameter)	83
Flow override (Parameter)	82
Flow velocity (Parameter)	59
Flow velocity (Submenu)	286
Format display (Parameter)	16
Free Space (Parameter)	150
Free Time (Parameter)	150
Frequency simulation (Parameter)	290
Frequency value (Parameter)	290
Function	
see Parameter	

G

Gas composition (Submenu)	97
Gas mixture (Parameter)	99
Gas type (Parameter)	99
Grant (Parameter)	147, 189, 227

H

Hard Types (Parameter)	148
Hardware revision (Parameter)	273
Header (Parameter)	24
Header text (Parameter)	25
Heartbeat (Submenu)	287
Heat flow difference (Parameter)	61
High High Limit (Parameter)	201
High High Priority (Parameter)	201
High Limit (Parameter)	202
High Priority (Parameter)	202

I

I/O Options (Parameter)	189, 227
Inlet configuration (Parameter)	117
Inlet run (Parameter)	117
Installation factor (Parameter)	119
Invert output signal (Parameter)	138
IO module temperature (Submenu)	283
ITK Version (Parameter)	161, 273

L

Language (Parameter)	15
Last backup (Parameter)	28
Length unit (Parameter)	81
Limit Notify (Parameter)	152
Linear expansion coefficient (Parameter)	91
Linearization Type (Parameter)	191
Locking status (Parameter)	12
Logging interval (Parameter)	278
Low Cutoff (Parameter)	193
Low flow cut off (Submenu)	83
Low Limit (Parameter)	203
Low Low Limit (Parameter)	203
Low Low Priority (Parameter)	203
Low Priority (Parameter)	202

M

Manufacturer Id (Parameter)	146
Mass flow (Parameter)	58
Mass flow unit (Parameter)	72
Mass unit (Parameter)	73
Mating pipe diameter (Parameter)	118
Max Notify (Parameter)	152
Maximum frequency value (Parameter)	128
Maximum value (Parameter)	283, 284, 285, 286, 287
Measured values (Submenu)	56
Measurement mode (Submenu)	85
Measuring value at maximum frequency (Parameter)	129
Measuring value at minimum frequency (Parameter)	128
Medium properties (Submenu)	89
Medium temperature (Submenu)	286
Memory Size (Parameter)	150
Meter body properties (Parameter)	120
Min/max values (Submenu)	281
Minimum frequency value (Parameter)	127
Minimum value (Parameter)	283, 284, 285, 286

Minimum Cycle Time (Parameter)	150
Mol% Ar (Parameter)	100
Mol% C2H3Cl (Parameter)	100
Mol% C2H4 (Parameter)	101
Mol% C2H6 (Parameter)	101
Mol% C3H8 (Parameter)	102
Mol% CH4 (Parameter)	102
Mol% Cl2 (Parameter)	102
Mol% CO (Parameter)	103
Mol% CO2 (Parameter)	103
Mol% H2 (Parameter)	104
Mol% H2O (Parameter)	104
Mol% H2S (Parameter)	104
Mol% HCl (Parameter)	105
Mol% He (Parameter)	105
Mol% i-C4H10 (Parameter)	106
Mol% i-C5H12 (Parameter)	106
Mol% Kr (Parameter)	106
Mol% n-C4H10 (Parameter)	108
Mol% n-C5H12 (Parameter)	108
Mol% n-C6H14 (Parameter)	108
Mol% n-C7H16 (Parameter)	109
Mol% n-C8H18 (Parameter)	109
Mol% n-C9H20 (Parameter)	109
Mol% n-C10H22 (Parameter)	107
Mol% N2 (Parameter)	107
Mol% Ne (Parameter)	110
Mol% NH3 (Parameter)	110
Mol% O2 (Parameter)	111
Mol% other gas (Parameter)	112
Mol% SO2 (Parameter)	111
Mol% Xe (Parameter)	111
Multiple analog output (Submenu)	239
Multiple discrete output (Submenu)	248

N

Nonvolatile Cycle Time (Parameter)	150
Normal mode (Parameter)	144, 164, 214, 242, 251

O

Off value low flow cutoff (Parameter)	84
On value low flow cutoff (Parameter)	84
Operating mode (Parameter)	121
Operating time (Parameter)	27, 264
Operating time from restart (Parameter)	264
Output (Submenu)	120
Output frequency (Parameter)	69, 132
Output State (Parameter)	226
Output values (Submenu)	67

P

Parameter

Structure of a parameter description	6
Permitted mode (Parameter)	143, 164, 213, 242, 251
Pre-amplifier temperature (Submenu)	285
Preset value 1 to 3 (Parameter)	260
Pressure (Parameter)	63
Pressure unit (Parameter)	74
Previous diagnostics (Parameter)	263

Process parameters (Submenu)	82
Process Value Filter Time (Parameter)	196, 228
Process variables (Submenu)	56
Pulse output (Parameter)	68, 126
Pulse simulation (Parameter)	290
Pulse value (Parameter)	291
Pulse width (Parameter)	124
Pulse/frequency/switch output (Submenu)	120

R

Reference combustion temperature (Parameter)	94
Reference density (Parameter)	94
Reference gross calorific value (Parameter)	95
Reference pressure (Parameter)	95
Reference temperature (Parameter)	96
Reference Z-factor (Parameter)	96
Relative density (Parameter)	96
Relative humidity (Parameter)	112
Relative Index (Parameter)	154, 197, 233
Reset all totalizers (Parameter)	257
Reset min/max values (Parameter)	282
Resource block (Submenu)	140
Resource State (Parameter)	145
Response time (Parameter)	130
Restart (Parameter)	52, 148
Reynolds number (Parameter)	62
Reynolds number limit (Parameter)	48

S

Saturated steam calculation mode (Parameter)	89
Saturation temperature (Parameter)	63
Select gas type (Parameter)	86
Select liquid type (Parameter)	87
Select medium (Parameter)	85
Select steam type (Parameter)	87
Sensor (Submenu)	55
Sensor adjustment (Submenu)	117
Sensor information (Submenu)	275
Separator (Parameter)	25
Serial number (Parameter)	272
Set Fault State (Parameter)	152
Shed Remote Cascade (Parameter)	152
Shed Remote Out (Parameter)	153
Simulate En/Disable (Parameter)	176, 226
Simulate Status (Parameter)	170, 220
Simulate Value (Parameter)	173, 222
Simulation (Submenu)	288
Simulation device alarm (Parameter)	292
Simulation diagnostic event (Parameter)	293
Software option overview (Parameter)	54
Specific heat capacity (Parameter)	97
Specific heat capacity unit (Parameter)	80
Static revision (Parameter)	154, 197, 233
Static Revision (Parameter)	140, 162, 211, 240, 249
Status (Parameter)	165, 168, 193, 215, 217, 229
Status Options (Parameter)	190, 228, 243, 252
Steam quality (Parameter)	60, 116
Steam quality limit (Parameter)	49
Steam quality value (Parameter)	116

Strategy (Parameter)	141, 162, 212, 240, 249
Subcode (Parameter)	156, 160, 199, 204, 206, 208, 210, 235, 236
Submenu	
Administration	50
Analog input 1 to 4	161
Analog inputs	161
Analog outputs	239
Application	256
Calibration	119
Communication	139
Configuration backup display	27
Data logging	275
Device information	271
Diagnostic behavior	32
Diagnostic handling	30
Diagnostic limits	48
Diagnostic list	265
Diagnostics	262
Discrete input 1 to 2	211
Discrete inputs	210
Discrete outputs	247
Display	14
Display channel 1	279
Display channel 2	280
Display channel 3	281
Display channel 4	281
Event list	270
Event logbook	268
External compensation	112
External pressure	287
Flow velocity	286
Gas composition	97
Heartbeat	287
IO module temperature	283
Low flow cut off	83
Measured values	56
Measurement mode	85
Medium properties	89
Medium temperature	286
Min/max values	281
Multiple analog output	239
Multiple discrete output	248
Output	120
Output values	67
Pre-amplifier temperature	285
Process parameters	82
Process variables	56
Pulse/frequency/switch output	120
Resource block	140
Sensor	55
Sensor adjustment	117
Sensor information	275
Simulation	288
System	14
System units	69
Terminal voltage	282
Totalizer	66
Totalizer 1 to 3	257

Switch output function (Parameter)	132	Z Z-factor (Parameter) 94
Switch output simulation (Parameter)	291	
Switch status (Parameter)	69, 138, 292	
Switch-off delay (Parameter)	137	
Switch-off value (Parameter)	136	
Switch-on delay (Parameter)	137	
Switch-on value (Parameter)	135	
System (Submenu)	14	
System units (Submenu)	69	
T		
Tag Description (Parameter)	141, 162, 212, 240, 249	
Target group	4	
Target mode (Parameter)	141, 163, 212, 241, 250	
Temperature (Parameter)	59	
Temperature unit (Parameter)	75	
Terminal voltage (Submenu)	282	
Terminal voltage 1 (Parameter)	68	
Time Stamp (Parameter)	154, 156, 159, 197, 198, 204, 206, 208, 209, 232, 235, 237	
Timestamp (Parameter)	263, 264, 265, 266, 267, 268	
Total mass flow (Parameter)	60	
Totalizer (Submenu)	66	
Totalizer 1 to 3 (Submenu)	257	
Totalizer overflow 1 to 3 (Parameter)	67	
Totalizer value 1 to 3 (Parameter)	66	
Transducer State (Parameter)	226	
Transducer Status (Parameter)	173, 223	
Transducer Value (Parameter)	175, 225	
U		
Unacknowledged (Parameter)	153, 155, 157, 159, 196, 198, 200, 203, 205, 207, 209, 232, 234, 236, 237	
Unit totalizer (Parameter)	258	
Units index (Parameter)	176, 180	
Unreported (Parameter)	157, 200, 234	
Update State (Parameter)	153, 197, 232	
V		
Value (Parameter)	156, 167, 170, 196, 199, 217, 220, 231, 236	
Value 1 display (Parameter)	18	
Value 2 display (Parameter)	20	
Value 3 display (Parameter)	21	
Value 4 display (Parameter)	22	
Value per pulse (Parameter)	124	
Value process variable (Parameter)	289	
Velocity unit (Parameter)	79	
Volume flow (Parameter)	57	
Volume flow unit (Parameter)	70	
Volume unit (Parameter)	72	
Vortex frequency (Parameter)	64	
W		
Wizard		
Define access code	50	
Write Lock (Parameter)	154	
Write Priority (Parameter)	158	

www.addresses.endress.com
