

Description of Device Parameters

Proline t-mass A, B 150

HART

Thermal Mass Flowmeter




Table of contents

1 Document information	4	
1.1 Document function	4	
1.2 Target group	4	
1.3 Using this document	4	
1.3.1 Information on the document structure	4	
1.3.2 Structure of a parameter description	6	
1.4 Symbols used	6	
1.4.1 Symbols for certain types of information	6	
1.4.2 Symbols in graphics	7	
2 Overview of the Expert operating menu	8	
3 Description of device parameters ...	10	
3.1 "System" submenu	13	
3.1.1 "Display" submenu	14	
3.1.2 "Configuration backup display" submenu	27	
3.1.3 "Diagnostic handling" submenu	30	
3.1.4 "Management" submenu	35	
3.2 "Sensor" submenu	37	
3.2.1 "Measured values" submenu	37	
3.2.2 "System units" submenu	43	
3.2.3 "Process parameters" submenu	52	
3.2.4 "Measurement mode" submenu	55	
3.2.5 "Calculated values" submenu	56	
3.2.6 "Sensor adjustment" submenu	59	
3.2.7 "Calibration" submenu	76	
3.3 "Output" submenu	77	
3.3.1 "Current output 1" submenu	77	
3.3.2 "Pulse-Frequency-Switch output" submenu	85	
3.4 "Communication" submenu	102	
3.4.1 "HART output" submenu	102	
3.5 "Application" submenu	111	
3.5.1 "Totalizer" submenu	112	
3.6 "Diagnostics" submenu	115	
3.6.1 "Diagnostic list" submenu	118	
3.6.2 "Event logbook" submenu	122	
3.6.3 "Device information" submenu	125	
3.6.4 "Data logging" submenu	128	
3.6.5 "Min/max values" submenu	134	
3.6.6 "Simulation" submenu	136	
4 Country-specific factory settings ..	142	
4.1 SI units	142	
4.1.1 System units	142	
4.1.2 Full scale values	142	
4.1.3 Output current span	142	
4.1.4 Pulse value	143	
4.1.5 On value low flow cut off	143	
US units	143	
4.2.1 System units	143	
4.2.2 Full scale values	144	
4.2.3 Output current span	144	
4.2.4 Pulse value	144	
4.2.5 On value low flow cut off	144	
5 Explanation of abbreviated units ..	146	
5.1 SI units	146	
5.2 US units	146	
5.3 Imperial units	147	
Index	148	

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document


1.3.1 Information on the document structure

This document lists the submenus and their parameters according to the structure of the **Expert** menu (→ 8) that are available once the "**Operator**" user role or the "**Maintenance**" user role is enabled.



1 Sample graphic

For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→ 115), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code)  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
Access status display (0091)	→ 11
Enter access code (0092)	→ 12
System	→ 13
Define access code (0093)	→ 13
▶ Display	→ 14
▶ Configuration backup display	→ 27
▶ Diagnostic handling	→ 30
▶ Management	→ 35
Sensor	→ 37
▶ Measured values	→ 37
▶ System units	→ 43
▶ Process parameters	→ 52
▶ Measurement mode	→ 55
▶ Calculated values	→ 56
▶ Sensor adjustment	→ 59
▶ Calibration	→ 76
Output	→ 77
▶ Current output 1	→ 77
▶ Pulse-Frequency-Switch output 1	→ 85

▶ Communication	→ 102
▶ HART output	→ 102
▶ Application	→ 111
Reset all totalizers (2806)	→ 112
▶ Totalizer	→ 112
▶ Diagnostics	→ 115
Actual diagnostics (0691)	→ 116
Previous diagnostics (0690)	→ 117
Operating time from restart (0653)	→ 118
Operating time (0652)	→ 118
▶ Diagnostic list	→ 118
▶ Event logbook	→ 122
▶ Device information	→ 125
▶ Data logging	→ 128
▶ Min/max values	→ 134
▶ Simulation	→ 136

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

Expert	
Direct access (0106)	→ 10
Locking status (0004)	→ 11
Access status display (0091)	→ 11
Enter access code (0092)	→ 12
▶ System	→ 13
▶ Sensor	→ 37
▶ Output	→ 77
▶ Communication	→ 102
▶ Application	→ 111
▶ Diagnostics	→ 115

Direct access



Navigation

Expert → Direct access (0106)

Description

Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears in the navigation view on the right in the header of the selected parameter.

User entry

0 to 65 535

Additional information

User entry

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1



- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Enter 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Enter 0914-3 → **Assign process variable** parameter

Locking status

Navigation	 Expert → Locking status (0004)
Description	Use this function to view the active write protection.
User interface	<ul style="list-style-type: none">■ Hardware locked■ Temporarily locked
Additional information	<p><i>User interface</i></p> <p>If two or more types of write protection are active, the write protection with the highest priority is shown on the local display.</p> <p>In the operating tool all active types of write protection are selected.</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p> <p><i>"Hardware locked" option (priority 1)</i></p> <p>The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).</p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p> <p><i>"Temporarily locked" option (priority 2)</i></p> <p>Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.</p>

Access status display

Navigation	 Expert → Access stat.disp (0091)
Prerequisite	A local display is provided.
Description	Use this function to view the access authorization to the parameters via the local display.
User interface	<ul style="list-style-type: none">■ Operator■ Maintenance
Factory setting	Operator

Additional information*Description*

If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.

 The access authorization can be modified via the **Enter access code** parameter (→  12).

 For information on the **Enter access code** parameter (→  12), see the "Disabling write protection via access code" section of the Operating Instructions for the device

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→  11).

User interface

 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Access status tooling**Navigation**

 Expert → Access stat.tool (0005)

Description

Use this function to view the access authorization to the parameters via the operating tool.

User interface

- Operator
- Maintenance

Factory setting

Maintenance

Additional information*Description*

 The access authorization can be modified via the **Enter access code** parameter (→  12).

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→  11).

Display

 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Enter access code**Navigation**

 Expert → Ent. access code (0092)

Description

Use this function to enter the user-specific release code to remove parameter write protection on the local display.

User entry


0 to 9 999

Enter access code

Navigation	Expert → Ent. access code (0003)
Description	Use this function to enter the user-specific release code to remove parameter write protection in the operating tool.
User entry	0 to 9 999

3.1 "System" submenu

Navigation Expert → System

**Define access code**

Navigation	Expert → System → Def. access code (0093)
Description	Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.
User entry	0 to 9 999
Factory setting	0

Additional information**Description**

The write protection affects all parameters in the document marked with the  symbol.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→  12).

 If you lose the access code, please contact your Endress+Hauser Sales Center.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

3.1.1 "Display" submenu

Navigation  Expert → System → Display

 Display	
Language (0104)	→  15
Format display (0098)	→  16
Value 1 display (0107)	→  18
0% bargraph value 1 (0123)	→  18
100% bargraph value 1 (0125)	→  19
Decimal places 1 (0095)	→  19
Value 2 display (0108)	→  19
Decimal places 2 (0117)	→  20
Value 3 display (0110)	→  20
0% bargraph value 3 (0124)	→  21
100% bargraph value 3 (0126)	→  21
Decimal places 3 (0118)	→  22
Value 4 display (0109)	→  22

Decimal places 4 (0119)	→ 23
Display interval (0096)	→ 23
Display damping (0094)	→ 24
Header (0097)	→ 24
Header text (0112)	→ 25
Separator (0101)	→ 25
Contrast display (0105)	→ 26
Backlight (0111)	→ 26
Access status display (0091)	→ 26

Language

Navigation

Expert → System → Display → Language (0104)

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English *
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech) *

Factory setting

English (alternatively, the ordered language is preset in the device)

* Visibility depends on order options or device settings

Format display

Navigation

 Expert → System → Display → Format display (0098)

Prerequisite

A local display is provided.

Description

Use this function to select how the measured value is shown on the local display.

Selection

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

Factory setting

1 value, max. size

Additional information*Description*


The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.




- The **Value 1 display** parameter (→  18) to **Value 4 display** parameter (→  22) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→  23).

Possible measured values shown on the local display:


"1 value, max. size" option



"1 bargraph + 1 value" option




"2 values" option




3

"1 value large + 2 values" option



"4 values" option



Value 1 display



Navigation

Expert → System → Display → Value 1 display (0107)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer
- Current output

Factory setting

Mass flow

Additional information

Description

If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

0% bargraph value 1



Navigation

Expert → System → Display → 0% bargraph 1 (0123)

Prerequisite

A local display is provided.

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information

Description

i The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

i The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

100% bargraph value 1

Navigation	Expert → System → Display → 100% bargraph 1 (0125)
Prerequisite	A local display is provided.
Description	Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 142
Additional information	<p><i>Description</i></p> <p> The Format display parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 43).</p>

Decimal places 1

Navigation	Expert → System → Display → Decimal places 1 (0095)
Prerequisite	A measured value is specified in the Value 1 display parameter (→ 18).
Description	Use this function to select the number of decimal places for measured value 1.
Selection	<ul style="list-style-type: none"> <input type="checkbox"/> X <input type="checkbox"/> X.X <input type="checkbox"/> X.XX <input type="checkbox"/> X.XXX <input type="checkbox"/> X.XXXX
Factory setting	X.XX
Additional information	<p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p>

Value 2 display

Navigation	Expert → System → Display → Value 2 display (0108)
Prerequisite	A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection For the picklist, see the **Value 1 display** parameter (→ 18)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Decimal places 2



Navigation Expert → System → Display → Decimal places 2 (0117)

Prerequisite A measured value is specified in the **Value 2 display** parameter (→ 19).

Description Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display



Navigation Expert → System → Display → Value 3 display (0110)

Prerequisite A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection Picklist, see **Value 1 display** parameter (→ 18)

Factory setting None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

0% bargraph value 3**Navigation**

Expert → System → Display → 0% bargraph 3 (0124)

Prerequisite

A selection has been made in the **Value 3 display** parameter (→ 20).

Description

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

Country-specific:

- 0 kg/h
- 0 lb/min

Additional information*Description*

The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

100% bargraph value 3**Navigation**

Expert → System → Display → 100% bargraph 3 (0126)

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 20).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

 The **Format display** parameter (→ 16) is used to specify that the measured value is to be displayed as a bar graph.

User entry

 The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Decimal places 3**Navigation**

  Expert → System → Display → Decimal places 3 (0118)

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

x.xx

Additional information*Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display**Navigation**

  Expert → System → Display → Value 4 display (0109)

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

Picklist, see **Value 1 display** parameter (→ 18)

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ 16) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Decimal places 4**Navigation**

Expert → System → Display → Decimal places 4 (0119)

Prerequisite

A measured value is specified in the **Value 4 display** parameter (→ 22).

Description

Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device.

The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval**Navigation**

Expert → System → Display → Display interval (0096)

Prerequisite

A local display is provided.

Description

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry

1 to 10 s

Factory setting

5 s

Additional information*Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 18) to **Value 4 display** parameter (→ 22) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 16).

Display damping**Navigation**

Expert → System → Display → Display damping (0094)

Prerequisite

A local display is provided.

Description

Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry

0.0 to 999.9 s

Factory setting

0.0 s

Additional information*User entry*

A time constant is entered:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

Header**Navigation**

Expert → System → Display → Header (0097)

Prerequisite

A local display is provided.

Description

Use this function to select the contents of the header of the local display.

Selection


- Device tag
- Free text

Factory setting

Device tag

Additional information*Description*

The header text only appears during normal operation.



1 Position of the header text on the display

Selection

- Device tag
Is defined in the **Device tag** parameter (→ 125).
- Free text
Is defined in the **Header text** parameter (→ 25).

Header text



Navigation

Expert → System → Display → Header text (0112)

Prerequisite

The **Free text** option is selected in the **Header** parameter (→ 24).

Description

Use this function to enter a customer-specific text for the header of the local display.

User entry


Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information

Description

The header text only appears during normal operation.



1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator



Navigation

Expert → System → Display → Separator (0101)

Prerequisite

A local display is provided.

Description Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting . (point)

Contrast display

Navigation  Expert → System → Display → Contrast display (0105)

Prerequisite A local display is provided.

Description Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry 20 to 50 %

Factory setting Depends on the display

Additional information Set the contrast via the push-buttons:

- Brighter: Press and hold down the   keys simultaneously.
- Darker: Press and hold down the   keys simultaneously.

Backlight

Navigation  Expert → System → Display → Backlight (0111)

Prerequisite Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"

Description Use this function to switch the backlight of the local display on and off.

Selection

- Disabled
- Enabled

Factory setting Disabled

Access status display

Navigation  Expert → System → Display → Access stat.disp (0091)

Prerequisite A local display is provided.

Description Displays the access authorization to the parameters via the local display.

User interface	■ Operator ■ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <ul style="list-style-type: none">  The access authorization can be modified via the Enter access code parameter (→  12).  For information on the Enter access code parameter (→  12), see the "Disabling write protection via access code" section of the Operating Instructions for the device  If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11). <p><i>Display</i></p> <ul style="list-style-type: none">  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1.2 "Configuration backup display" submenu

Navigation

  Expert → System → Conf.backup disp

► Configuration backup display	
Operating time (0652)	→  27
Last backup (0102)	→  28
Configuration management (0100)	→  28
Comparison result (0103)	→  29

Operating time

Navigation

  Expert → System → Conf.backup disp → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

User interface

The maximum number of days is 9999, which is equivalent to 27 years.

Last backup

Navigation	  Expert → System → Conf.backup disp → Last backup (0102)
Prerequisite	A local display is provided.
Description	Use this function to display the time since a backup copy of the data was last saved to the display module.
User interface	Days (d), hours (h), minutes (m) and seconds (s)

Configuration management



Navigation	  Expert → System → Conf.backup disp → Config. managem. (0100)
Prerequisite	A local display is provided.
Description	Use this function to select an action to save the data to the display module.
Selection	<ul style="list-style-type: none">■ Cancel■ Execute backup■ Restore■ Duplicate■ Compare■ Clear backup data
Factory setting	Cancel
Additional information	<p><i>Description</i></p> <p>Configuration via the local display is disabled while the action is performed.</p> <p> For information on the status message in the operating tool, see: Backup state parameter (→  29)</p> <p><i>Selection</i></p> <ul style="list-style-type: none">■ Cancel<ul style="list-style-type: none">No action is executed and the user exits the parameter.■ Execute backup<ul style="list-style-type: none">- A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.- The following message appears on local display: Backup active, please wait!■ Restore<ul style="list-style-type: none">- The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device.- The following message appears on local display: Restore active! Do not interrupt power supply!

- Duplicate
 - The transmitter configuration from another device is duplicated to the device using the display module.
 - The following message appears on local display: Copy active! Do not interrupt power supply!
- Compare
 - The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
 - The following message appears on local display: Comparing files
 - The result can be viewed in **Comparison result** parameter (→ 29).
- Clear backup data
 - The backup copy of the device configuration is deleted from the display module of the device.
 - The following message appears on local display: Deleting file

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

Backup state

Navigation	 Expert → System → Conf.backup disp → Backup state (0121)
Prerequisite	A local display is provided.
Description	Use this function to view the status of the data backup process.
User interface	<ul style="list-style-type: none"> ■ None ■ Store in progress ■ Restore in progress ■ Import in progress ■ Delete in progress ■ Compare in progress
Factory setting	None

Comparison result

Navigation	  Expert → System → Conf.backup disp → Compar. result (0103)
Prerequisite	A local display is provided.
Description	Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.
User interface	<ul style="list-style-type: none"> ■ Settings identical ■ Settings not identical ■ No backup available ■ Backup settings corrupt ■ Check not done ■ Dataset incompatible

Factory setting	Check not done
Additional information	<p><i>Description</i></p> <p>i The comparison is started via the Compare option in the Configuration management parameter (→ 28).</p> <p><i>Selection</i></p> <ul style="list-style-type: none">■ Settings identical<ul style="list-style-type: none">- The current device configuration of the HistoROM is identical to the backup copy in the display module.- If the transmitter configuration of another device has been copied to the device via the display module and the Duplicate option in the Configuration management parameter (→ 28), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical.■ Settings not identical<ul style="list-style-type: none">The current device configuration of the HistoROM is not identical to the backup copy in the display module.■ No backup available<ul style="list-style-type: none">There is no backup copy of the device configuration of the HistoROM in the display module.■ Backup settings corrupt<ul style="list-style-type: none">The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.■ Check not done<ul style="list-style-type: none">The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.■ Dataset incompatible<ul style="list-style-type: none">The backup copy in the display module is not compatible with the device.


HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.1.3 "Diagnostic handling" submenu

Navigation

Expert → System → Diagn. handling



Alarm delay**Navigation**

Expert → System → Diagn. handling → Alarm delay (0651)

Description

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

User entry 0 to 60 s

Factory setting 0 s

Additional information**"Diagnostic behavior" submenu**

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 31).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Options	Description
Alarm	The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 122) (Event list submenu (→ 124)) and is not displayed in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.

For a list of all the diagnostic events, see the Operating Instructions for the device.

Navigation

Expert → System → Diagn. handling → Diagn. behavior

► Diagnostic behavior

Assign behavior of diagnostic no. 441
(0657)

→ 32

Assign behavior of diagnostic no. 442
(0658)

→ 32

Assign behavior of diagnostic no. 443
(0659)

→ 33

Assign behavior of diagnostic no. 801 (0660)	→ 33
Assign behavior of diagnostic no. 832 (0675)	→ 33
Assign behavior of diagnostic no. 833 (0676)	→ 34
Assign behavior of diagnostic no. 834 (0677)	→ 34
Assign behavior of diagnostic no. 835 (0678)	→ 35

Assign behavior of diagnostic no. 441 (Current output 1)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)

Description

Option for changing the diagnostic behavior of the diagnostic message **441 Current output 1**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → 31

Assign behavior of diagnostic no. 442 (Frequency output)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)

Prerequisite

The measuring device has a pulse/frequency/switch output.

Description

Option for changing the diagnostic behavior of the diagnostic message **442 Frequency output**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional informationFor a detailed description of the options available, see → [31](#)**Assign behavior of diagnostic no. 443 (Pulse output)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

Prerequisite

The measuring device has a pulse/frequency/switch output.

DescriptionOption for changing the diagnostic behavior of the diagnostic message **443 Pulse output**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional informationFor a detailed description of the options available, see → [31](#)**Assign behavior of diagnostic no. 801 (Supply voltage too low)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 801 (0660)

DescriptionOption for changing the diagnostic behavior of the diagnostic message **801 Supply voltage too low**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional informationFor a detailed description of the options available, see → [31](#)**Assign behavior of diagnostic no. 832 (Electronic temperature too high)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

DescriptionOption for changing the diagnostic behavior of the diagnostic message **832 Electronic temperature too high**.

Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available, see → 31

Assign behavior of diagnostic no. 833 (Electronic temperature too low)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)
Description	Option for changing the diagnostic behavior of the diagnostic message 833 Electronic temperature too low .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available, see → 31

Assign behavior of diagnostic no. 834 (Process temperature too high)

Navigation	 Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677)
Description	Option for changing the diagnostic behavior of the diagnostic message 834 Process temperature too high .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	 For a detailed description of the options available, see → 31

Assign behavior of diagnostic no. 835 (Process temperature too low)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678)

Description

Option for changing the diagnostic behavior of the diagnostic message **835 Process temperature too low**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting


Warning

Additional information

For a detailed description of the options available, see → [31](#)

3.1.4 "Management" submenu**Navigation**

Expert → System → Management

**Device reset****Navigation**

Expert → System → Management → Device reset (0000)

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To factory defaults
- To delivery settings
- Restart device

Factory setting

Cancel

Additional information*"Cancel" option*

No action is executed and the user exits the parameter.

"To factory defaults" option

Every parameter is reset to its factory setting.

"To delivery settings" option

Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.

 This option is not visible if no customer-specific settings have been ordered.

"Restart device" option

The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Activate SW option**Navigation**

  Expert → System → Management → Activate SW opt. (0029)

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

Depends on the software option ordered

Additional information*Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

User entry

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

NOTE!

The activation code is linked to the serial number of the measuring device and varies according to the device and software option.

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- If the code entered is incorrect or invalid, enter the old activation code .
- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

Example for a software option

Order code for "Application package", option EA "Extended HistoROM"

Reset write protection**Navigation**

Expert → System → Management → Res. write prot. (0019)

Description

The functionality of this parameter is not available for the t-mass 150 measuring device.

3.2 "Sensor" submenu

Navigation

Expert → Sensor

► Sensor	
► Measured values	→ 37
► System units	→ 43
► Process parameters	→ 52
► Measurement mode	→ 55
► Calculated values	→ 56
► Sensor adjustment	→ 59
► Calibration	→ 76

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

► Measured values	
► Process variables	→ 38
► Totalizer	→ 40
► Output values	→ 41

"Process variables" submenu**Navigation** Expert → Sensor → Measured val. → Process variab.

▶ Process variables	
Mass flow (1838)	→  38
Corrected volume flow (1847)	→  38
FAD volume flow (1851)	→  39
Temperature (1853)	→  39

Mass flow**Navigation** Expert → Sensor → Measured val. → Process variab. → Mass flow (1838)**Prerequisite**

The following conditions are met:

- The **Enabled** option is selected in the **Operating mode** parameter (→  64).
- The **Mass flow** option is selected in the **Flow reference in use** parameter (→  65).

Description

Displays the mass flow that is currently measured.

User interface

Signed floating-point number

Additional information

Dependency

 The unit is taken from the **Mass flow unit** parameter (→  44)

Corrected volume flow**Navigation** Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow (1847)**Prerequisite**

The following conditions are met:

- The **Enabled** option is selected in the **Operating mode** parameter (→  64).
- The **Corrected volume flow** option is selected in the **Flow reference in use** parameter (→  65).

Description

Displays the corrected volume flow currently calculated.

User interface

Signed floating-point number

Additional information*Description*

The corrected volume flow is derived from the measured volume flow corrected to the selected reference conditions.

Dependency

 The unit is taken from the **Corrected volume flow unit** parameter (→ [45](#))

FAD volume flow

Navigation

  Expert → Sensor → Measured val. → Process variab. → FAD volume flow (1851)

Prerequisite

The following conditions are met:

- The **Enabled** option is selected in the **Operating mode** parameter (→ [64](#)).
- The **FAD volume flow** option is selected in the **Flow reference in use** parameter (→ [65](#)).

Description

Displays the FAD¹⁾ volume flow that is currently measured.

User interface

Signed floating-point number

Additional information*Dependency*

 The unit is taken from the **FAD volume flow unit** parameter (→ [47](#)).

Temperature

Navigation

  Expert → Sensor → Measured val. → Process variab. → Temperature (1853)

Description

Displays the temperature currently measured.


User interface

Signed floating-point number

Additional information*Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [48](#))

1) Free Air Delivery

"Totalizer" submenu*Navigation* Expert → Sensor → Measured val. → Totalizer**Totalizer value****Navigation** Expert → Sensor → Measured val. → Totalizer → Totalizer val. (0911)**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ [40](#)) of the **Totalizer** submenu:

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Displays the current totalizer reading.

User interface

Signed floating-point number

Additional information*Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow** parameter (→ [41](#)) if the display range is exceeded.

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ [115](#)).

User interface

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [113](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: $1968\,457 \text{ m}^3$
- Value in the **Totalizer overflow 1** parameter: $1 \cdot 10^7$ (1 overflow) = $10\,000\,000 \text{ [m}^3]$
- Current totalizer reading: $11\,968\,457 \text{ m}^3$

Totalizer overflow**Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow (0910)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ [112](#)) of the **Totalizer** submenu:

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Displays the current totalizer overflow.

User interface

Integer with sign

Additional information*Description*

If the current totalizer reading has more than 7 digits, which is the maximum value range of the operating tool that can be displayed, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value** parameter (→ [40](#))

Display

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [113](#)).

Example

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m³
- Value in the **Totalizer overflow 1** parameter: 2 · 10⁷ (2 overflows) = 20 000 000 [m³]
- Current totalizer reading: 21 968 457 m³

"Output values" submenu**Navigation**

Expert → Sensor → Measured val. → Output values

► Output values

Output current (0361)

→ [42](#)

Pulse output (0456)

→ [42](#)

Output frequency (0471)

→ [43](#)

Switch status (0461)

→ [43](#)

Output current

Navigation  Expert → Sensor → Measured val. → Output values → Output curr. (0361)

Description Displays the actual calculated value of the output current.

User interface 3.59 to 22.5 mA

Pulse output

Navigation  Expert → Sensor → Measured val. → Output values → Pulse output (0456)


Prerequisite In the **Operating mode** parameter (→ [86](#)), the **Pulse** option is selected.

Description Displays the pulse frequency currently output.

User interface Positive floating-point number

Additional information *Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ [88](#)) and **Pulse width** parameter (→ [88](#)) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



0 Non-conductive

1 Conductive

NC Normally closed

NO Normally opened

The output behavior can be reversed via the **Invert output signal** parameter (→ [101](#)) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ [89](#))) can be configured.

Output frequency

Navigation	Expert → Sensor → Measured val. → Output values → Out frequency (0471)
Prerequisite	In the Operating mode parameter (→ 86), the Frequency option is selected.
Description	Displays the actual value of the output frequency which is currently measured.
User interface	0.0 to 1250.0 Hz

Switch status

Navigation	Expert → Sensor → Measured val. → Output values → Switch status (0461)
Prerequisite	In the Operating mode parameter (→ 86), the Switch option is selected.
Description	Displays the current switch status of the status output.
User interface	<ul style="list-style-type: none"> ▪ Open ▪ Closed
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Open The switch output is not conductive. ▪ Closed The switch output is conductive.

3.2.2 "System units" submenu

Navigation

Expert → Sensor → System units

► System units	
Mass flow unit (0554)	→ 44
Mass unit (0574)	→ 45
Corrected volume flow unit (0558)	→ 45
Corrected volume unit (0575)	→ 46
FAD volume flow unit (0601)	→ 47
FAD volume unit (0591)	→ 47

Density unit (0555)	→ 48
Temperature unit (0557)	→ 48
Length unit (0551)	→ 49
Pressure unit (0564)	→ 49
Date/time format (2812)	→ 50
► User specific units	→ 50

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

Description

Use this function to select the unit for the mass flow.

Selection*SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

US units

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

Imperial units

- LTon/s
- LTon/min
- LTon/h
- LTon/d

Custom-specific units

- User mass/s
- User mass/min
- User mass/h
- User mass/d

Factory setting

Country-specific:

- kg/h
- lb/h

Additional information*Result*

The selected unit applies for:

Mass flow parameter (→ 38)

Selection

 For an explanation of the abbreviated units: → 146

Customer-specific units

 The unit for the customer-specific mass is specified in the **User mass text** parameter (→ 51).

Mass unit**Navigation**

Expert → Sensor → System units → Mass unit (0574)

Description

Use this function to select the unit for the mass.

Selection*SI units*

- g
- kg
- t

US units

- oz
- lb
- STon

Imperial units

LTon

Custom-specific units

User mass

Factory setting

Country-specific:

- kg
- lb

Additional information*Selection*

 For an explanation of the abbreviated units: → 146

Customer-specific units

 The unit for the customer-specific mass is specified in the **User mass text** parameter (→ 51).

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit (0558)

Description

Use this function to select the unit for the corrected volume flow.

Selection	<i>SI units</i>	<i>US units</i>
	▪ Nl/s	▪ Sft ³ /s
	▪ Nl/min	▪ Sft ³ /min
	▪ Nl/h	▪ Sft ³ /h
	▪ Nl/d	▪ Sft ³ /d
	▪ Nm ³ /s	
	▪ Nm ³ /min	
	▪ Nm ³ /h	
	▪ Nm ³ /d	
	▪ Sl/s	
	▪ Sl/min	
	▪ Sl/h	
	▪ Sl/d	
	▪ Sm ³ /s	
	▪ Sm ³ /min	
	▪ Sm ³ /h	
	▪ Sm ³ /d	
Factory setting	Country-specific:	
	▪ Nm ³ /h	
	▪ Sft ³ /min	
Additional information	<i>Result</i>	
	The selected unit applies for:	
	Corrected volume flow parameter (→  38)	
	<i>Selection</i>	
	 For an explanation of the abbreviated units: →  146	

Corrected volume unit	
Navigation	  Expert → Sensor → System units → Corr. vol. unit (0575)
Description	Use this function to select the unit for the corrected volume.
Selection	<i>SI units</i>
	▪ Nl
	▪ Nm ³
	▪ Sl
	▪ Sm ³
<i>US units</i>	
	Sft ³
Factory setting	Country-specific:
	▪ Nm ³
	▪ Sft ³
Additional information	<i>Selection</i>
	 For an explanation of the abbreviated units: →  146

FAD volume flow unit**Navigation**

Expert → Sensor → System units → FAD vol.fl. unit (0601)

Description

Use this function to select the unit for the FAD²⁾ volume flow.

Selection*SI units*

- 1 FAD/s
- 1 FAD/min
- 1 FAD/h
- 1 FAD/d
- m³ FAD/s
- m³ FAD/min
- m³ FAD/h
- m³ FAD/d

US units

- cf FAD/s
- cf FAD/min
- cf FAD/h
- cf FAD/d

Factory setting

Country-specific:

- m³ FAD/h
- cf FAD/min

Additional information*Effect*

The selected unit applies to:

FAD volume flow parameter (→ 39)

Selection

For an explanation of the abbreviated units: → 146

FAD volume unit**Navigation**

Expert → Sensor → System units → FAD volume unit (0591)

Description

Use this function to select the unit for the FAD³⁾ volume.

Selection*SI units*

- 1 FAD
- m³ FAD

US units

- cf FAD

Factory setting

Country-specific:

- m³ FAD
- cf FAD

Additional information*Selection*

For an explanation of the abbreviated units: → 146

2) Free air delivery
3) Free air delivery

Density unit**Navigation**

Expert → Sensor → System units → Density unit (0555)

Description

Use this function to select the unit for the density.

Selection

<i>SI units</i>	<i>US units</i>
■ g/cm ³	lb/ft ³
■ kg/dm ³	
■ kg/l	
■ kg/m ³	

Factory setting

Country-specific:

- kg/m³
- lb/ft³

Additional information*Result*

The selected unit applies for:

FAD density parameter (→ 59)

Selection

For an explanation of the abbreviated units: → 146

Temperature unit**Navigation**

Expert → Sensor → System units → Temperature unit (0557)

Description

Use this function to select the unit for the temperature.

Selection

<i>SI units</i>	<i>US units</i>
■ °C	■ °F
■ K	■ °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Result*

The selected unit applies for:

- **Temperature** parameter (→ 39)
- **FAD temperature** parameter (→ 59)
- **Reference combustion temperature** parameter
- **Reference temperature** parameter (→ 57)
- **Maximum value** parameter (→ 134)

- **Minimum value** parameter (→ 134)
- **Maximum value** parameter (→ 135)
- **Minimum value** parameter (→ 135)

Selection

 For an explanation of the abbreviated units: → 146

Length unit**Navigation**

  Expert → Sensor → System units → Length unit (0551)

Description

Use this function to select the unit of length.

Selection*SI units*

- mm
- m

US units

- in
- ft

Factory setting

Country-specific:

- mm
- in

Additional information*Effect*

The selected unit applies for:

- **Duct internal height** parameter (→ 61)
- **Insertion depth** parameter (→ 63)
- **Pipe inner diameter** parameter (→ 61)
- **Mounting set height** parameter (→ 62)
- **Pipe wall thickness** parameter (→ 62)
- **Duct internal width** parameter (→ 61)

Selection

 For an explanation of the abbreviated units: → 146

Pressure unit**Navigation**

  Expert → Sensor → System units → Pressure unit (0564)

Description

Use this function to select the unit for the pipe pressure.

Selection*SI units*

- kPa a
- MPa a
- bar
- mbar a

US units

psi a

Factory setting	Country-specific: <ul style="list-style-type: none">▪ bar a▪ psi a
Additional information	<p><i>Result</i></p> <p>The unit is taken from:</p> <ul style="list-style-type: none">▪ FAD pressure parameter (→ 58)▪ Reference pressure parameter (→ 57) <p><i>Selection</i></p> <p> For an explanation of the abbreviated units: → 146</p>

Date/time format	
Navigation	 Expert → Sensor → System units → Date/time format (2812)
Description	Use this function to select the desired time format for calibration history.
Selection	<ul style="list-style-type: none">▪ dd.mm.yy hh:mm▪ dd.mm.yy hh:mm am/pm▪ mm/dd/yy hh:mm▪ mm/dd/yy hh:mm am/pm
Factory setting	dd.mm.yy hh:mm
Additional information	<p><i>Selection</i></p> <p> For an explanation of the abbreviated units: → 146</p>

"User specific units" submenu

Navigation  Expert → Sensor → System units → User spec. units

 User specific units	
User mass text (0560)	→ 51
User mass offset (0562)	→ 51
User mass factor (0561)	→ 51

User mass text

Navigation Expert → Sensor → System units → User spec. units → User mass text (0560)

Description Use this function to enter a text for the user-specific unit of mass and mass flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.

User entry Max. 10 characters such as letters, numbers or special characters (@, %, /)

Factory setting User mass

Additional information *Result*

- The defined unit is shown as an option in the choose list of the following parameters:
- **Mass flow unit** parameter (→ 44)
 - **Mass unit** parameter (→ 45)

Example

If the text GLAS is entered, the following options are displayed in the picklist for the **Mass flow unit** parameter (→ 44):

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

User mass offset

Navigation Expert → Sensor → System units → User spec. units → User mass offset (0562)

Description Use this function to enter the offset for adapting the user-specific mass unit and mass flow unit (without time).

User entry Signed floating-point number

Factory setting 0

Additional information *Description*

- Value in user-specific unit = (factor × value in base unit) + offset

User mass factor

Navigation Expert → Sensor → System units → User spec. units → User mass factor (0561)


Description Use this function to enter a quantity factor (without time) for the user-specific mass and mass flow unit.

User entry Signed floating-point number

Factory setting 1.0

3.2.3 "Process parameters" submenu

Navigation Expert → Sensor → Process param.



Flow override



Navigation Expert → Sensor → Process param. → Flow override (1839)

Description Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting Off

Additional information *Result*

This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized

Flow damping



Navigation Expert → Sensor → Process param. → Flow damping (1802)

Description Use this function to enter a time constant for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the

flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry 0 to 999.9 s

Factory setting 0 s

Additional information

User entry

- Value = 0: no damping
- Value > 0: damping is increased

Result

 The damping affects the following variables of the device:

- Outputs → [77](#)
- Low flow cut off → [53](#)
- Totalizers → [112](#)

"Low flow cut off" submenu

Navigation

 Expert → Sensor → Process param. → Low flow cut off

► Low flow cut off

Assign process variable (1837)	→ 53
On value low flow cutoff (1805)	→ 54
Off value low flow cutoff (1804)	→ 54

Assign process variable



Navigation  Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

Description Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow

Factory setting Mass flow

On value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → On value (1805)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter
(→ [53](#)):
■ Mass flow
■ Corrected volume flow
■ FAD volume flow

Description

Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → [54](#).

User entry

Positive floating-point number

Factory setting

Depends on country and nominal diameter → [143](#)

Additional information

Dependency

The unit depends on the process variable selected in the **Assign process variable** parameter (→ [53](#)).

Off value low flow cutoff**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter
(→ [53](#)):
■ Mass flow
■ Corrected volume flow
■ FAD volume flow

Description


Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → [54](#).

User entry

0 to 100.0 %

Factory setting

50 %


Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

3.2.4 "Measurement mode" submenu

Navigation

Expert → Sensor → Measurement mode

**Select gas type****Navigation**

Expert → Sensor → Measurement mode → Select gas type (3381)

PrerequisiteThe **Disabled** option is selected in the **Operating mode** parameter (→ 64) parameter.**Description**

Use this function to select the type of gas for the measuring application.

Selection

- Air
- Argon Ar
- Carbon dioxide CO₂
- Nitrogen N₂


Factory setting

Air

3.2.5 "Calculated values" submenu

Navigation


Expert → Sensor → Calculated value



"Reference values" submenu

Navigation

Expert → Sensor → Calculated value → Reference values



Reference conditions



Navigation

Expert → Sensor → Calculated value → Reference values → Ref. conditions (3439)

Description

Use this function to select the reference conditions for calculating the reference density.

Selection

- 1013.25mbara, 0°C
- 1013.25mbara, 15°C
- 1013.25mbara, 20°C
- 1013.25mbara, 25°C
- 1000mbara, 0°C
- 1000mbara, 15°C
- 1000mbara, 20°C
- 1000mbara, 25°C
- 14.696Psia, 59°F
- 14.696Psia, 60°F
- 14.730Psia, 60°F
- User defined

Factory setting 1013.25mbara, 0°C

Reference pressure



Navigation Expert → Sensor → Calculated value → Reference values → Ref. pressure (3378)

Prerequisite The **User defined** option is selected in the **Reference conditions** parameter (→ 56) parameter.

Description Use this function to enter the reference pressure for calculating the reference density.

User entry 0.1 to 99 bar

Factory setting 1.01325 bar

Additional information *Dependency*



The unit is taken from the **Pressure unit** parameter (→ 49)

Reference temperature



Navigation Expert → Sensor → Calculated value → Reference values → Ref. temperature (3379)

Prerequisite The **User defined** option is selected in the **Reference conditions** parameter (→ 56) parameter.

Description Use this function to enter the reference temperature for calculating the reference density.

User entry -50 to 150 °C

Factory setting 0 °C

Additional information *Dependency*



The unit is taken from the **Temperature unit** parameter (→ 48)

Reference density

Navigation Expert → Sensor → Calculated value → Reference values → Ref.density (3377)

Description Displays the calculated reference density.

User interface 0 to $9.9 \cdot 10^5$ kg/m³

Additional information*Dependency*

The unit is taken from the **Density unit** parameter (→ [48](#))

FAD conditions**Navigation**

Expert → Sensor → Calculated value → Reference values → FAD conditions (3438)

Prerequisite

The **Air** option is selected in the **Select gas type** parameter (→ [55](#)) parameter.

Description

Use this function to select the reference conditions for calculating the FAD⁴⁾ density.

Selection

- 1000mbara, 20°C
- 14.504Psia, 68°F
- User defined

Factory setting

1000mbara, 20°C

FAD pressure**Navigation**

Expert → Sensor → Calculated value → Reference values → FAD pressure (3373)

Prerequisite

The following conditions are met:

- The **Air** option is selected in the **Select gas type** parameter (→ [55](#)) parameter.
- The **User defined** option is selected in the **FAD conditions** parameter (→ [58](#)) parameter.

Description

Use this function to enter the reference pressure for calculating the FAD⁵⁾ density.

User entry

0.1 to 99 bar

Factory setting

1 bar

Additional information*Dependency*

The unit is taken from the **Pressure unit** parameter (→ [49](#))

4) Free air delivery

5) Free air delivery

FAD temperature


Navigation	Expert → Sensor → Calculated value → Reference values → FAD temperature (3374)
Prerequisite	The following conditions are met: ■ The Air option is selected in the Select gas type parameter (→ 55) parameter. ■ The User defined option is selected in the FAD conditions parameter (→ 58) parameter.
Description	Use this function to enter the reference temperature for calculating the FAD ⁶⁾ density.
User entry	-50 to 150 °C
Factory setting	20 °C
Additional information	<i>Dependency</i> The unit is taken from the Temperature unit parameter (→ 48)

FAD density

Navigation	Expert → Sensor → Calculated value → Reference values → FAD density (3372)
Prerequisite	The Air option is selected in the Select gas type parameter (→ 55) parameter.
Description	Displays the calculated FAD ⁷⁾ density.
User interface	0 to $9.9 \cdot 10^5$ kg/m ³
Additional information	<i>Dependency</i> The unit is taken from the Density unit parameter (→ 48)

3.2.6 "Sensor adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm.



6) Free air delivery
 7) Free air delivery

"Installation settings" submenu**Navigation**
 Expert → Sensor → Sensor adjustm. → Install.settings

 Installation settings	
Installation factor (3470)	→  60
Pipe shape (3441)	→  60
Pipe inner diameter (3476)	→  61
Duct internal height (3405)	→  61
Duct internal width (3411)	→  61
Orientation (3437)	→  62
Pipe wall thickness (3409)	→  62
Mounting set height (3435)	→  62
Insertion depth (3406)	→  63

Installation factor**Navigation**
 Expert → Sensor → Sensor adjustm. → Install.settings → Install. factor (3470)
Prerequisite

The **Disabled** option is selected in the **Operating mode** parameter (→  64) parameter.

Description

Use this function to enter the installation factor.

User entry

0 to 9 999

Factory setting

1

Pipe shape**Navigation**
 Expert → Sensor → Sensor adjustm. → Install.settings → Pipe shape (3441)
Prerequisite

The sensor is an insert version.

Description

Use this function to select the shape of the pipe.

Selection

- Circular
- Rectangular

Factory setting	Circular
-----------------	----------

Pipe inner diameter

[Edit]

Navigation	  Expert → Sensor → Sensor adjustm. → Install.settings → Pipe inner diam. (3476)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ The sensor is an insert version.■ The Circular option is selected in the Pipe shape parameter (→  60) parameter.
Description	Enter the inner diameter of the pipe.
User entry	45 to 99 999 mm
Factory setting	50 mm
Additional information	<i>Dependency</i>  The unit is taken from the Length unit parameter (→  49)

Duct internal height

[Edit]

Navigation	  Expert → Sensor → Sensor adjustm. → Install.settings → Duct int. height (3405)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ The sensor is an insert version.■ The Rectangular option is selected in the Pipe shape parameter (→  60) parameter.
Description	Use this function to enter the height of the rectangular pipe.
User entry	45 to 99 999 mm
Factory setting	50 mm
Additional information	<i>Dependency</i>  The unit is taken from the Length unit parameter (→  49)

Duct internal width

[Edit]

Navigation	  Expert → Sensor → Sensor adjustm. → Install.settings → Duct int. width (3411)
Prerequisite	The following conditions are met: <ul style="list-style-type: none">■ The sensor is an insert version.■ The Rectangular option is selected in the Pipe shape parameter (→  60) parameter.

Description Use this function to enter the width of the rectangular pipe.

User entry 45 to 99 999 mm

Factory setting 50 mm

Additional information *Dependency*

 The unit is taken from the **Length unit** parameter (→  49)

Orientation



Navigation  Expert → Sensor → Sensor adjustm. → Install.settings → Orientation (3437)

Prerequisite The following conditions are met:

- The sensor is an insert version.
- The **Rectangular** option is selected in the **Pipe shape** parameter (→  60) parameter.

Description Use this function to select the orientation of the sensor.

Selection
▪ Vertical
▪ Horizontal

Factory setting Vertical

Pipe wall thickness



Navigation  Expert → Sensor → Sensor adjustm. → Install.settings → Wall thickness (3409)

Prerequisite The sensor is an insert version.

Description Use this function to enter the pipe wall thickness.

User entry 2 to 999.9 mm

Factory setting 4.5 mm

Additional information *Dependency*

 The unit is taken from the **Length unit** parameter (→  49)

Mounting set height



Navigation  Expert → Sensor → Sensor adjustm. → Install.settings → Mounting set ht. (3435)


Prerequisite The sensor is an insert version.

Description Use this function to enter the mounting set height.

User entry 0 to 999 mm

Factory setting 106 mm

Additional information *Description*



A0028527

4 Mounting set height: $C1 + C2$

$C1$ Length of mounting set

$C2$ Length of sensor compression fitting

For more detailed information on determining the mounting set height, please see the Operating Instructions for the device, section "Insertion depth"

Dependency

The unit is taken from the **Length unit** parameter (→ 49)

Insertion depth

Navigation Expert → Sensor → Sensor adjustm. → Install.settings → Insertion depth (3406)

Prerequisite The sensor is an insert version.

Description Displays the calculated insertion depth of the sensor.

User interface 0 to 999 000 mm

Factory setting 50 mm

Additional information *Description*

The insertion depth depends on the internal diameter of the pipe.

$$(0.3 \cdot A) + B + (C1 + C2)$$

A: Internal pipe diameter DN (circular pipe) or internal dimension (rectangular duct)

B: Thickness of pipe wall or of duct wall

C1: Length of mounting set

C2: Length of sensor compression fitting



For more detailed information on determining the insertion depth, please see the Operating Instructions for the device, section "Insertion depth"

Dependency




The unit is taken from the **Length unit** parameter (→ [49](#))

"In-situ adjustment" submenu

Navigation

Expert → Sensor → Sensor adjustm. → In-situ adjust.



Operating mode



Navigation

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Operating mode (3400)

Description

Use this function to activate/deactivate in-situ adjustment.

Selection

- Disabled
- Enabled

Factory setting

Disabled

*"Adjustment values in use" submenu**Navigation*

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use

► Adjustment values in use	
Flow reference in use	→ 65
Flow reference value 1	→ 66
Power coefficient 1	→ 66
Flow reference value 2	→ 66
Power coefficient 2	→ 66
Flow reference value 3	→ 67
Power coefficient 3	→ 67
Flow reference value 4	→ 67
Power coefficient 4	→ 67
Flow reference value 5	→ 67
Power coefficient 5	→ 68
Flow reference value 6	→ 68
Power coefficient 6	→ 68
Flow reference value 7	→ 68
Power coefficient 7	→ 69
Flow reference value 8	→ 69
Power coefficient 8	→ 69

Flow reference in use**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. in use (3440)

Description

Use this function to select the flow reference value used.

User interface	<ul style="list-style-type: none">■ Mass flow■ Corrected volume flow■ FAD volume flow
-----------------------	---

Factory setting	Mass flow
------------------------	-----------

Flow reference value 1

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 1 (3401)
Description	Displays the Flow reference value 1 (→ 66) defined for the adjustment.
User interface	Signed floating-point number

Power coefficient 1

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 1 (3425)
Description	Displays the Power coefficient 1 defined for the adjustment.
User interface	Positive floating-point number

Flow reference value 2

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 2 (3418)
Description	Displays the Flow reference value 2 defined for the adjustment.
User interface	Signed floating-point number

Power coefficient 2

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 2 (3426)
Description	Displays the Power coefficient 2 defined for the adjustment.
User interface	Positive floating-point number

Flow reference value 3

Navigation	 Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 3 (3419)
Description	Displays the Flow reference value 3 defined for the adjustment.
User interface	Signed floating-point number

Power coefficient 3

Navigation	 Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 3 (3427)
Description	Displays the Power coefficient 3 defined for the adjustment.
User interface	Positive floating-point number

Flow reference value 4

Navigation	 Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 4 (3420)
Description	Displays the Flow reference value 4 defined for the adjustment.
User interface	Signed floating-point number

Power coefficient 4

Navigation	 Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 4 (3428)
Description	Displays the Power coefficient 4 defined for the adjustment.
User interface	Positive floating-point number

Flow reference value 5

Navigation	 Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 5 (3421)
Description	Displays the Flow reference value 5 defined for the adjustment.

User interface	Signed floating-point number
-----------------------	------------------------------

Power coefficient 5

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 5 (3429)
-------------------	---

Description	Displays the Power coefficient 5 defined for the adjustment.
--------------------	--

User interface	Positive floating-point number
-----------------------	--------------------------------

Flow reference value 6

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 6 (3422)
-------------------	---

Description	Displays the Flow reference value 6 defined for the adjustment.
--------------------	---

User interface	Signed floating-point number
-----------------------	------------------------------

Power coefficient 6

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 6 (3430)
-------------------	---

Description	Displays the Power coefficient 6 defined for the adjustment.
--------------------	--

User interface	Positive floating-point number
-----------------------	--------------------------------

Flow reference value 7

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 7 (3423)
-------------------	---

Description	Displays the Flow reference value 7 defined for the adjustment.
--------------------	---

User interface	Signed floating-point number
-----------------------	------------------------------

Power coefficient 7

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 7 (3431)

Description Displays the Power coefficient 7 defined for the adjustment.

User interface Positive floating-point number

Flow reference value 8

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 8 (3424)

Description Displays the Flow reference value 8 defined for the adjustment.

User interface Signed floating-point number

Power coefficient 8


Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 8 (3432)

Description Displays the Power coefficient 8 defined for the adjustment.

User interface Positive floating-point number

"New adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment



Select flow reference

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Select flow ref. (3382)

Description Use this function to select the process variable used as flow reference value for the adjustment.

Selection

- Mass flow
- Corrected volume flow
- FAD volume flow

Factory setting Mass flow

"Perform adjustment" submenu

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust.

► Perform adjustment	
Clear values (3529)	→ 71
Flow reference value 1 (3384)	→ 71
Power coefficient 1 (3392)	→ 71
Flow reference value 2 (3385)	→ 72
Power coefficient 2 (3393)	→ 72
Flow reference value 3 (3386)	→ 72
Power coefficient 3 (3394)	→ 72
Flow reference value 4 (3387)	→ 73
Power coefficient 4 (3395)	→ 73
Flow reference value 5 (3388)	→ 73
Power coefficient 5 (3396)	→ 73
Flow reference value 6 (3389)	→ 74
Power coefficient 6 (3397)	→ 74

Flow reference value 7 (3390)	→ 74
Power coefficient 7 (3398)	→ 74
Flow reference value 8 (3391)	→ 75
Power coefficient 8 (3399)	→ 75

Clear values

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Clear values (3529)

Description Use this function to delete the existing adjustment values.

Selection

- Cancel
- Clear values

Factory setting Cancel

Flow reference value 1

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 1 (3384)

Description Use this function to enter a flow rate used as reference for flow point 1.

User entry Signed floating-point number

Factory setting 0 kg/h

Power coefficient 1

Navigation Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 1 (3392)

Description Displays the automatically assigned power coefficient 1 which is directly proportional to the flow: heater power/measured temperature difference.

User interface Positive floating-point number

Flow reference value 2**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 2 (3385)

Description

Use this function to enter a flow rate used as reference for flow point 2.

User entry

Signed floating-point number

Factory setting

0 kg/h

Power coefficient 2**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 2 (3393)

Description

Displays the automatically assigned power coefficient 2 which is directly proportional to the flow: heater power/measured temperature difference.

User interface

Positive floating-point number

Flow reference value 3**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 3 (3386)

Description

Use this function to enter a flow rate used as reference for flow point 3.

User entry

Signed floating-point number

Factory setting

0 kg/h

Power coefficient 3**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 3 (3394)

Description

Displays the automatically assigned power coefficient 3 which is directly proportional to the flow: heater power/measured temperature difference.

User interface

Positive floating-point number

Flow reference value 4

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 4 (3387)
Description	Use this function to enter a flow rate used as reference for flow point 4.
User entry	Signed floating-point number
Factory setting	0 kg/h

Power coefficient 4

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 4 (3395)
Description	Displays the automatically assigned power coefficient 4 which is directly proportional to the flow: heater power/measured temperature difference.
User interface	Positive floating-point number

Flow reference value 5

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 5 (3388)
Description	Use this function to enter a flow rate used as reference for flow point 5.
User entry	Signed floating-point number
Factory setting	0 kg/h

Power coefficient 5

Navigation	  Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 5 (3396)
Description	Displays the automatically assigned power coefficient 5 which is directly proportional to the flow: heater power/measured temperature difference.
User interface	Positive floating-point number

Flow reference value 6**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 6 (3389)

Description

Use this function to enter a flow rate used as reference for flow point 6.

User entry

Signed floating-point number

Factory setting

0 kg/h

Power coefficient 6**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 6 (3397)

Description

Displays the automatically assigned power coefficient 6 which is directly proportional to the flow: heater power/measured temperature difference.

User interface

Positive floating-point number

Flow reference value 7**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 7 (3390)

Description

Use this function to enter a flow rate used as reference for flow point 7.

User entry

Signed floating-point number

Factory setting

0 kg/h

Power coefficient 7**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 7 (3398)

Description

Displays the automatically assigned power coefficient 7 which is directly proportional to the flow: heater power/measured temperature difference.

User interface

Positive floating-point number

Flow reference value 8


Navigation	█ █ Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 8 (3391)
Description	Use this function to enter a flow rate used as reference for flow point 8.
User entry	Signed floating-point number
Factory setting	0 kg/h

Power coefficient 8

Navigation	█ █ Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 8 (3399)
Description	Displays the automatically assigned power coefficient 8 which is directly proportional to the flow: heater power/measured temperature difference.
User interface	Positive floating-point number

"Use adjustment" submenu

Navigation █ █ Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment

**Data validity**

Navigation	█ █ Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment → Data validity (3434)
Description	Displays whether the performed adjustment is usable.
User interface	<ul style="list-style-type: none"> ■ Ok ■ Too few points ■ Invalid pair of values ■ Values too close ■ Out of range

Apply

Navigation  Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment → Apply (3528)

Prerequisite In the **Data validity** parameter (→ [75](#)) the **Ok** option is displayed.

Description Use this function to select whether the new adjustment values are to be used.


Selection

- Cancel
- Ok

Factory setting Cancel

3.2.7 "Calibration" submenu

Navigation  Expert → Sensor → Calibration



Flow conditioner

Navigation  Expert → Sensor → Calibration → Flow conditioner (3404)

Description Displays whether the measuring device was calibrated with or without a flow conditioner.

User interface

- No
- Yes

Calibration date/time

Navigation  Expert → Sensor → Calibration → Cal date/time (3436)

Description Displays the date of the last factory calibration of the measuring device.

User interface Format: dd.mm.yyyy


Additional information*Description*

The date remains unchanged in the case of onsite calibration.

3.3 "Output" submenu

Navigation


Expert → Output



3.3.1 "Current output 1" submenu

Navigation

Expert → Output → Curr.output 1



Assign current output



Navigation Expert → Output → Curr.output 1 → Assign curr. (0359-1)

Description Use this function to select a process variable for the current output.

Selection

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Factory setting Mass flow

Current span



Navigation Expert → Output → Curr.output 1 → Current span (0353-1)

Description Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

Selection

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- Fixed current

Factory setting Country-specific:
▪ 4...20 mA NAMUR
▪ 4...20 mA US

Additional information *Description*




- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 82).
- If the measured value is outside the measuring range, the diagnostic message **△S441 Current output 1** is displayed.
- The measuring range is specified via the **4 mA value** parameter (→ 79) and **20 mA value** parameter (→ 80).

"Fixed current" option

The current value is set via the **Fixed current** parameter (→ 79).

Example

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:



- I* Current
 1 Current span for process value
 2 Lower level for signal on alarm
 3 Upper level for signal on alarm

Selection

Selection	1	2	3
4...20 mA NAMUR	3.8 to 20.5 mA	< 3.6 mA	> 21.95 mA
4...20 mA US	3.9 to 20.8 mA US	< 3.6 mA	> 21.95 mA
4...20 mA	4 to 20.5 mA	< 3.6 mA	> 21.95 mA

i If the flow exceeds or falls below the upper or lower signal on alarm level, the diagnostic message **△S441 Current output 1** is displayed.

Fixed current



Navigation

Expert → Output → Curr.output 1 → Fixed current (0365-1)

Prerequisite

In the **Current span** parameter (→ 78), the **Fixed current** option is selected.

Description

Use this function to enter a constant current value for the current output.

User entry

3.59 to 22.5 mA

Factory setting

4 mA

Additional information

Example

This setting can be used for HART multidrop, for example.

4 mA value



Navigation

Expert → Output → Curr.output 1 → 4 mA value (0367-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 78):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description

Use this function to enter a value for the 4 mA current.

User entry

Signed floating-point number

Factory setting 0 kg/h

Additional information *Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 78). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 80).

Dependency

i The unit depends on the process variable selected in the **Assign current output** parameter (→ 78).

Current output behavior

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 78)
- Failure mode (→ 82)


Configuration examples

A configuration example and its effect on the current output is explained in the following section.

Configuration example

In Forward flow

- **4 mA value** parameter (→ 79) = not equal to zero flow (e.g. -250 m³/h)
- **20 mA value** parameter (→ 80) = not equal to zero flow (e.g. +750 m³/h)
- Calculated current value = 8 mA at zero flow



Q Flow
 I Current
 1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **4 mA value** parameter (→ 79) and **20 mA value** parameter (→ 80). If the effective flow exceeds or falls below this operational range, the diagnostic message **△S441 Current output 1** is displayed.

20 mA value



Navigation

Expert → Output → Curr.output 1 → 20 mA value (0372-1)

Prerequisite

One of the following options is selected in the **Current span** parameter (→ 78):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description	Use this function to enter a value for the 20 mA current.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter → 142
Additional information	<p><i>Description</i></p> <p>Positive and negative values are permitted depending on the process variable assigned in the Assign current output parameter (→ 78). In addition, the value can be greater than or smaller than the value assigned for the 4 mA current in the 4 mA value parameter (→ 79).</p> <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the Assign current output parameter (→ 78).</p> <p><i>Example</i></p> <ul style="list-style-type: none"> ■ Value assigned to 4 mA = -250 m³/h ■ Value assigned to 20 mA = +750 m³/h ■ Calculated current value = 8 mA (at zero flow) <p><i>Configuration examples</i></p> <p> Pay attention to the configuration examples for 4 mA value parameter (→ 79).</p>

Damping



Navigation	 Expert → Output → Curr.output 1 → Damping (0363-1)
Prerequisite	<p>One of the following options is selected in the Assign current output parameter (→ 78):</p> <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature <p>One of the following options is selected in the Current span parameter (→ 78):</p> <ul style="list-style-type: none"> ■ 4...20 mA NAMUR ■ 4...20 mA US ■ 4...20 mA
Description	Use this function to enter the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.
User entry	0.0 to 999.9 s
Factory setting	1.0 s

Additional information*User entry*

Use this function to enter a time constant:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

Response time**Navigation**

Diagram: Expert → Output → Curr.output 1 → Response time (0378-1)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ [78](#)):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

One of the following options is selected in the **Current span** parameter (→ [78](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description

Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.

User interface

Positive floating-point number

Additional information*Description*

 The response time is made up of the time specified for the following dampings:

- Current output damping → [81](#)
and
- Depending on the measured variable assigned to the output.
Flow damping

Failure mode**Navigation**

Diagram: Expert → Output → Curr.output 1 → Failure mode (0364-1)

Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ [78](#)):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

One of the following options is selected in the **Current span** parameter (→ [78](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description	Use this function to select the value of the current output in the event of a device alarm.
Selection	<ul style="list-style-type: none"> ■ Min. ■ Max. ■ Last valid value ■ Actual value ■ Defined value
Factory setting	Max.
Additional information	<p><i>Description</i></p> <p> This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.</p> <p><i>"Min." option</i></p> <p>The current output adopts the value of the lower level for signal on alarm.</p> <p> The signal on alarm level is defined via the Current span parameter (→ 78).</p> <p><i>"Max." option</i></p> <p>The current output adopts the value of the upper level for signal on alarm.</p> <p> The signal on alarm level is defined via the Current span parameter (→ 78).</p> <p><i>"Last valid value" option</i></p> <p>The current output adopts the last measured value that was valid before the device alarm occurred.</p> <p><i>"Actual value" option</i></p> <p>The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.</p> <p><i>"Defined value" option</i></p> <p>The current output adopts a defined measured value.</p> <p> The measured value is defined via the Failure current parameter (→ 83).</p>

Failure current



Navigation	 Expert → Output → Curr.output 1 → Failure current (0352-1)
Prerequisite	In the Failure mode parameter (→ 82), the Defined value option is selected.
Description	Use this function to enter a fixed value that the current output adopts in the event of a device alarm.
User entry	3.59 to 22.5 mA
Factory setting	22.5 mA

Output current 1

Navigation   Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)

Description Displays the current value currently calculated for the current output.

User interface 3.59 to 22.5 mA

Start-up mode



Navigation   Expert → Output → Curr.output 1 → Start-up mode (0368-1)

Prerequisite In the **Current span** parameter (→  78), one of the following options is selected:

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

Description Use this function to select the current value that the current output adopts during the device start-up phase as long as no measured value is present.

Selection

- Min.
- Max.
- Defined value

Factory setting Min.

Additional information "Min." option

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  78).

"Max." option

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→  78).

"Defined value" option

The current output outputs a defined current value.

 The current value is defined via the **Start-up current** parameter (→  84).

Start-up current



Navigation   Expert → Output → Curr.output 1 → Start-up current (0369-1)

Prerequisite The **Defined value** option is selected in the **Start-up mode** parameter (→  84).

Description	Use this function to enter a fixed current value that the current output adopts during the device start-up phase as long as no measured value is present.
User entry	3.59 to 22.5 mA
Factory setting	3.59 mA

3.3.2 "Pulse-Frequency-Switch output" submenu

Navigation

Expert → Output → PFS-output

► Pulse-Frequency-Switch output 1	
Operating mode (0469-1)	→ 86
Assign pulse output (0460-1)	→ 88
Value per pulse (0455-1)	→ 88
Pulse width (0452-1)	→ 88
Failure mode (0480-1)	→ 89
Pulse output (0456-1)	→ 90
Assign frequency output (0478-1)	→ 91
Minimum frequency value (0453-1)	→ 91
Maximum frequency value (0454-1)	→ 92
Measuring value at minimum frequency (0476-1)	→ 92
Measuring value at maximum frequency (0475-1)	→ 92
Damping output (0477-1)	→ 93
Response time (0491-1)	→ 93
Failure mode (0451-1)	→ 94
Failure frequency (0474-1)	→ 95
Output frequency (0471-1)	→ 95
Switch output function (0481-1)	→ 95

Assign diagnostic behavior (0482-1)	→ 96
Assign limit (0483-1)	→ 97
Switch-on value (0466-1)	→ 98
Switch-off value (0464-1)	→ 99
Assign status (0485-1)	→ 99
Switch-on delay (0467-1)	→ 100
Switch-off delay (0465-1)	→ 100
Failure mode (0486-1)	→ 100
Switch status (0461-1)	→ 101
Invert output signal (0470-1)	→ 101

Operating mode**Navigation**

Expert → Output → PFS-output 1 → Operating mode (0469-1)

Description

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

Selection

- Pulse
- Frequency
- Switch

Factory setting

Pulse

Additional information

"Pulse" option

Quantity-dependent pulse with configurable pulse width

- Whenever a specific mass, corrected volume or FAD volume is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

Example

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s




Fig. 5 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses

"Frequency" option

Example

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1000 g/s
- Output frequency approx. 1000 Hz




Fig. 6 Flow-proportional frequency output

"Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

Example

Alarm response without alarm




Fig. 7 No alarm, high level

Example

Alarm response in case of alarm




Fig. 8 Alarm, low level

Assign pulse output



Navigation

Expert → Output → PFS-output 1 → Assign pulse (0460-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 86) parameter.

Description

Use this function to select the process variable for the pulse output.

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow

Factory setting

Off

Value per pulse



Navigation

Expert → Output → PFS-output 1 → Value per pulse (0455-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign pulse output** parameter (→ 88):

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Use this function to enter the value for the measured value that a pulse is equivalent to.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → 143

Additional information

User entry

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

Pulse width



Navigation

Expert → Output → PFS-output 1 → Pulse width (0452-1)

Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign pulse output** parameter (→ 88):

- Mass flow
- Corrected volume flow
- FAD volume flow

Description


Use this function to enter the duration of the output pulse.

User entry 0.5 to 2 000 ms

Factory setting 100 ms

Additional information *Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by $f_{\max} = 1 / (2 \times \text{pulse width})$.
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by $Q_{\max} = f_{\max} \times \text{pulse value}$.
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to n**.



B Pulse width entered
P Pauses between the individual pulses

Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

Failure mode



Navigation Expert → Output → PFS-output 1 → Failure mode (0480-1)

Prerequisite The **Pulse** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign pulse output** parameter (→ 88):

- Mass flow
- Corrected volume flow
- FAD volume flow

Description Use this function to select the failure mode of the pulse output in the event of a device alarm.

Selection

- Actual value
- No pulses

Factory setting No pulses

Additional information*Description*

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

*Selection***■ Actual value**

In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.

■ No pulses

In the event of a device alarm, the pulse output is "switched off".

NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

Pulse output**Navigation**

Expert → Output → PFS-output 1 → Pulse output (0456-1)

Prerequisite

In the **Operating mode** parameter (→ 86), the **Pulse** option is selected.

Description


Displays the pulse frequency currently output.

User interface

Positive floating-point number

Additional information*Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 88) and **Pulse width** parameter (→ 88) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 101) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 89)) can be configured.

Assign frequency output

**Navigation**

Expert → Output → PFS-output 1 → Assign freq. (0478-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) parameter.

Description

Use this function to select the process variable for the frequency output.

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Factory setting

Off

Minimum frequency value

**Navigation**

Expert → Output → PFS-output 1 → Min. freq. value (0453-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign frequency output** parameter (→ 91):
▪ Mass flow
▪ Corrected volume flow
▪ FAD volume flow
▪ Temperature

Description

Use this function to enter the start value frequency.

User entry

0.0 to 1000.0 Hz

Factory setting

0.0 Hz

Maximum frequency value

**Navigation**

Expert → Output → PFS-output 1 → Max. freq. value (0454-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign frequency output** parameter (→ 91):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Description

Use this function to enter the end value frequency.

User entry

0.0 to 1000.0 Hz

Factory setting

1 000.0 Hz

Measuring value at minimum frequency

**Navigation**

Expert → Output → PFS-output 1 → Val. at min.freq (0476-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign frequency output** parameter (→ 91):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Description

Use this function to enter the measured value for the start value frequency.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter

Additional information

Dependency

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 91).

Measuring value at maximum frequency

**Navigation**

Expert → Output → PFS-output 1 → Val. at max.freq (0475-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign frequency output** parameter (→ 91):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Description	Use this function to enter the measured value for the end value frequency.
User entry	Signed floating-point number
Factory setting	Depends on country and nominal diameter
Additional information	<p><i>Description</i></p> <p>Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.</p> <p><i>Dependency</i></p> <p> The entry depends on the process variable selected in the Assign frequency output parameter (→ 91).</p>

Damping output



Navigation	  Expert → Output → PFS-output 1 → Damping out. (0477-1)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 86) and one of the following options is selected in the Assign frequency output parameter (→ 91): <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature
Description	Use this function to enter the reaction time of the output signal to fluctuations in the measured value.
User entry	0 to 999.9 s
Factory setting	0.0 s
Additional information	<p><i>Description</i></p> <p>Use this function to enter a time constant (PT1 element) for frequency output damping. The frequency output is subject to separate damping that is independent of all preceding time constants.</p>

Response time



Navigation	  Expert → Output → PFS-output 1 → Response time (0491-1)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 86) and one of the following options is selected in the Assign frequency output parameter (→ 91): <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow ■ Temperature

Description	Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.
User interface	Positive floating-point number
Additional information	<i>Description</i> i The response time is made up of the time specified for the following dampings: <ul style="list-style-type: none">▪ Damping of pulse/frequency/switch output → 81and▪ Depending on the measured variable assigned to the output. Flow damping

Failure mode

Navigation	Expert → Output → PFS-output 1 → Failure mode (0451-1)
Prerequisite	The Frequency option is selected in the Operating mode parameter (→ 86) and one of the following options is selected in the Assign frequency output parameter (→ 91): <ul style="list-style-type: none">▪ Mass flow▪ Corrected volume flow▪ FAD volume flow▪ Temperature
Description	Use this function to select the failure mode of the frequency output in the event of a device alarm.
Selection	<ul style="list-style-type: none">▪ Actual value▪ Defined value▪ 0 Hz
Factory setting	0 Hz
Additional information	<i>Selection</i> <ul style="list-style-type: none">▪ Actual value In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.▪ Defined value In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→ 95) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.▪ 0 Hz In the event of a device alarm, the frequency output is "switched off". <p>NOTICE! A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The Actual value option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.</p>

Failure frequency**Navigation**

Expert → Output → PFS-output 1 → Failure freq. (0474-1)

Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 86) and one of the following options is selected in the **Assign frequency output** parameter (→ 91):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Description

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

User entry

0.0 to 1250.0 Hz

Factory setting

0.0 Hz

Output frequency**Navigation**

Expert → Output → PFS-output 1 → Out frequency (0471-1)

Prerequisite

In the **Operating mode** parameter (→ 86), the **Frequency** option is selected.

Description

Displays the actual value of the output frequency which is currently measured.

User interface

0.0 to 1250.0 Hz

Switch output function**Navigation**

Expert → Output → PFS-output 1 → Switch out funct (0481-1)

Prerequisite

In the **Operating mode** parameter (→ 86) the **Switch** option is selected.

Description

Use this function to select a function for the switch output.

Selection

- Off
- On
- Diagnostic behavior
- Limit
- Status

Factory setting

Off

Additional information*Selection*

- Off
The switch output is permanently switched off (open, non-conductive).
- On
The switch output is permanently switched on (closed, conductive).
- Diagnostic behavior
Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.
- Limit
Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.
- Status
Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.

Assign diagnostic behavior**Navigation** Expert → Output → PFS-output 1 → Assign diag. beh (0482-1)**Prerequisite**

- The **Switch** option is selected in the **Operating mode** parameter (→ 86).
- The **Diagnostic behavior** option is selected in the **Switch output function** parameter (→ 95).

Description

Use this function to select the diagnostic event category that is displayed for the switch output.

Selection

- Alarm
- Alarm or warning
- Warning

Factory setting

Alarm

Additional information*Description*

 If no diagnostic event is pending, the switch output is closed and conductive.

Options

- Alarm
The switch output signals only diagnostic events in the alarm category.
- Alarm or warning
The switch output signals diagnostic events in the alarm and warning category.
- Warning
The switch output signals only diagnostic events in the warning category.

Assign limit**Navigation**

Expert → Output → PFS-output 1 → Assign limit (0483-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 86) parameter.
- The **Limit** option is selected in the **Switch output function** parameter (→ 95) parameter.

Description

Use this function to select a process variable for the limit function.

Selection

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer 1


Factory setting

Mass flow

Additional information*Description*

Behavior of status output when Switch-on value > Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive




A0026891

- | | |
|---|------------------|
| 1 | Switch-on value |
| 2 | Switch-off value |
| 3 | Conductive |
| 4 | Non-conductive |
| A | Process variable |
| B | Status output |

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is conductive
- Process variable > Switch-off value: transistor is non-conductive




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



A0026893

- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

Switch-on value



Navigation

Expert → Output → PFS-output 1 → Switch-on value (0466-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 86).
- The **Limit** option is selected in the **Switch output function** parameter (→ 95).

Description

Use this function to enter the measured value for the switch-on point.

User entry

Signed floating-point number

Factory setting

0 kg/h

Additional information*Description*

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 97).

Switch-off value**Navigation**

Expert → Output → PFS-output 1 → Switch-off value (0464-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 86).
- The **Limit** option is selected in the **Switch output function** parameter (→ 95).

Description

Use this function to enter the measured value for the switch-off point.

User entry

Signed floating-point number

Factory setting

0 kg/h

Additional information*Description*

Use this function to enter the limit value for the switch-off value (process variable < switch-off value = open, non-conductive).



When using a hysteresis: Switch-on value > Switch-off value.

Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ 97).

Assign status**Navigation**

Expert → Output → PFS-output 1 → Assign status (0485-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ 86).
- The **Status** option is selected in the **Switch output function** parameter (→ 95).

Description

Use this function to select a device status for the switch output.

Selection

Low flow cut off

Factory setting

Low flow cut off

Additional information*Options*

If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.

Switch-on delay**Navigation**

Expert → Output → PFS-output 1 → Switch-on delay (0467-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [86](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [95](#)).

Description

Use this function to enter a delay time for switching on the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Switch-off delay**Navigation**

Expert → Output → PFS-output 1 → Switch-off delay (0465-1)

Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [86](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [95](#)).

Description

Use this function to enter a delay time for switching off the switch output.

User entry

0.0 to 100.0 s

Factory setting

0.0 s

Failure mode**Navigation**

Expert → Output → PFS-output 1 → Failure mode (0486-1)

Description

Use this function to select a failsafe mode for the switch output in the event of a device alarm.

Selection

- Actual status
- Open
- Closed

Factory setting

Open

Additional information*Options*

■ Actual status

In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.

■ Open

In the event of a device alarm, the switch output's transistor is set to **non-conductive**.

■ Closed

In the event of a device alarm, the switch output's transistor is set to **conductive**.

Switch status**Navigation**
 Expert → Output → PFS-output 1 → Switch status (0461-1)
Prerequisite

The **Switch** option is selected in the **Operating mode** parameter (→ 86).

Description

Displays the current switch status of the status output.

User interface

- Open
- Closed

Additional information*User interface*

■ Open

The switch output is not conductive.

■ Closed

The switch output is conductive.

Invert output signal**Navigation**
 Expert → Output → PFS-output 1 → Invert outp.sig. (0470-1)
Description

Use this function to select whether to invert the output signal.

Selection


- No
- Yes

Factory setting

No


Additional information*Selection*

No option (passive - negative)



A0026693


Yes option (passive - positive)



3.4 "Communication" submenu

Navigation


Expert → Communication



3.4.1 "HART output" submenu

Navigation


Expert → Communication → HART output



"Configuration" submenu

Navigation

Expert → Communication → HART output → Configuration



Burst mode

Navigation	Expert → Communication → HART output → Configuration → Burst mode (0208)
Description	Use this function to select whether to activate or deactivate the HART burst mode for burst message X.
Selection	<ul style="list-style-type: none"> ▪ Off ▪ On
Factory setting	Off
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Off The measuring device transmits data only when requested by the HART master. ▪ On The measuring device transmits data regularly without being requested.

Burst command

Navigation	Expert → Communication → HART output → Configuration → Burst command (0207)
Description	Use this function to select the HART command that is sent to the HART master.
Selection	<ul style="list-style-type: none"> ▪ Command 1 ▪ Command 2 ▪ Command 3 ▪ Command 9 ▪ Command 33
Factory setting	Command 2
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ▪ Command 1 Read out the primary variable. ▪ Command 2 Read out the current and the main measured value as a percentage. ▪ Command 3 Read out the dynamic HART variables and the current. ▪ Command 9 Read out the dynamic HART variables including the related status. ▪ Command 33 Command 33: Read out the dynamic HART variables including the related unit.

HART address

Navigation	Expert → Communication → HART output → Configuration → HART address (0219)
Description	Use this function to enter the address via which the data exchange takes place via HART protocol.
User entry	0 to 63
Factory setting	0

No. of preambles

Navigation	Expert → Communication → HART output → Configuration → No. of preambles (0217)
Description	Use this function to enter the number of preambles in the HART protocol.
User entry	2 to 20
Factory setting	5
Additional information	<i>User entry</i> As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.

HART short tag

Navigation	Expert → Communication → HART output → Configuration → HART short tag (0220)
Description	Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.
User entry	Max. 8 characters: A-Z, 0-9 and certain special characters (e.g. punctuation marks, @, %).
Factory setting	T-MASS

"Information" submenu*Navigation*
 Expert → Communication → HART output → Information

► Information	
Device revision (0204)	→  105
Device ID (0221)	→  106
Device type (0222)	→  106
Manufacturer ID (0223)	→  106
HART revision (0205)	→  106
HART descriptor (0212)	→  107
HART message (0216)	→  107
HART date code (0202)	→  107
Hardware revision (0206)	→  108
Software revision (0224)	→  108

Device revision**Navigation**
 Expert → Communication → HART output → Information → Device revision (0204)
Description

Use this function to view the device revision with which the device is registered with the HART Communication Foundation.

User interface

2-digit hexadecimal number

Factory setting

0x02

Additional information*Description*

 The device revision is needed to assign the appropriate device description file (DD) to the device.

Device ID

Navigation   Expert → Communication → HART output → Information → Device ID (0221)

Description Use this function to view the device ID for identifying the measuring device in a HART network.

User interface 6-digit hexadecimal number

Additional information *Description*

 In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID.

Device type

Navigation   Expert → Communication → HART output → Information → Device type (0222)

Description Displays the device type with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x66 (for t-mass A, B 150)

Additional information *Description*

 The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

Manufacturer ID

Navigation   Expert → Communication → HART output → Information → Manufacturer ID (0223)

Description Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

User interface 2-digit hexadecimal number

Factory setting 0x11 (for Endress+Hauser)

HART revision

Navigation   Expert → Communication → HART output → Information → HART revision (0205)

Description Use this function to display the HART protocol revision of the measuring device.

User interface 5 to 7

Factory setting 6

HART descriptor



Navigation Expert → Communication → HART output → Information → HART descriptor (0212)

Description Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

User entry Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting t-mass 150

HART message



Navigation Expert → Communication → HART output → Information → HART message (0216)

Description Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting t-mass 150

HART date code



Navigation Expert → Communication → HART output → Information → HART date code (0202)

Description Use this function to enter the date information for individual use.

User entry Date entry format: yyyy-mm-dd

Factory setting 2009-07-20

Additional information *Example*

Device installation date

Hardware revision


Navigation	  Expert → Communication → HART output → Information → Hardware rev. (0206)
Description	Displays the hardware revision of the measuring device.
User interface	0 to 255
Factory setting	1

Software revision

Navigation	  Expert → Communication → HART output → Information → Software rev. (0224)
Description	Displays the software revision of the measuring device.
User interface	0 to 255
Factory setting	0

"Output" submenu

Navigation   Expert → Communication → HART output → Output



Assign PV**Navigation**

Expert → Communication → HART output → Output → Assign PV (0234)

Description

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

Selection

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Factory setting

Mass flow

Primary variable (PV)**Navigation**

Expert → Communication → HART output → Output → Primary var (PV) (0201)

Description

Displays the current measured value of the primary dynamic variable (PV).

User interface

Signed floating-point number

Additional information

User interface

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→ 109).

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

Assign SV**Navigation**

Expert → Communication → HART output → Output → Assign SV (0235)

Description

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

Selection

- None
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer

Factory setting

Totalizer

Secondary variable (SV)

Navigation  Expert → Communication → HART output → Output → Second.var(SV) (0226)

Description Displays the current measured value of the secondary dynamic variable (SV).

User interface Signed floating-point number

Additional information *User interface*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (→  109).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  43).

Assign TV



Navigation  Expert → Communication → HART output → Output → Assign TV (0236)

Description Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

Selection

- None
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer

Factory setting None

Tertiary variable (TV)

Navigation  Expert → Communication → HART output → Output → Tertiary var(TV) (0228)

Description Displays the current measured value of the tertiary dynamic variable (TV).

User interface Signed floating-point number

Additional information *User interface*

The measured value displayed depends on the process variable selected in the **Assign TV** parameter (→  110).

Dependency

 The unit of the displayed measured value is taken from the **System units** submenu (→  43).

Assign QV**Navigation**

Expert → Communication → HART output → Output → Assign QV (0237)

Description

Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).

Selection

- None
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Totalizer

Factory setting

None

Quaternary variable (QV)**Navigation**

Expert → Communication → HART output → Output → Quaterna.var(QV) (0203)

Description

Displays the current measured value of the quaternary dynamic variable (QV).

User interface

Signed floating-point number

Additional information*User interface*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→ 111).

Dependency

The unit of the displayed measured value is taken from the **System units** submenu (→ 43).

3.5 "Application" submenu

Navigation

Expert → Application

► Application

Reset all totalizers
→ 112

► Totalizer

→ 112

Reset all totalizers

Navigation
 Expert → Application → Reset all tot. (2806)
Description

Use this function to reset all totalizers to the value **0** and restart the totaling process. This deletes all the flow values previously totalized.

Selection

- Cancel
- Reset + totalize

Factory setting


Cancel

Additional information

Selection

- Cancel
No action is executed and the user exits the parameter.
- Reset + totalize
All totalizers are reset to 0 and the totaling process is restarted.

3.5.1 "Totalizer" submenu

Navigation
 Expert → Application → Totalizer


Assign process variable


Navigation
 Expert → Application → Totalizer → Assign variable (0914)
Description

Use this function to select a process variable for the Totalizer .

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow

Factory setting	Mass flow
Additional information	<p><i>Description</i></p> <p> If the option selected is changed, the device resets the totalizer to 0.</p>
	<p><i>Selection</i></p> <p>If the Off option is selected, only Assign process variable parameter (→ 112) is still displayed in the Totalizer submenu. All other parameters in the submenu are hidden.</p>

Unit

Navigation	 Expert → Application → Totalizer → Unit (0915)
Prerequisite	<p>One of the following options is selected in the Assign process variable parameter (→ 112)Totalizer submenu:</p> <ul style="list-style-type: none"> ■ Mass flow ■ Corrected volume flow ■ FAD volume flow
Description	Use this function to select the unit for the process variable for Totalizer (→ 40).
Selection	<ul style="list-style-type: none"> ■ g ■ kg ■ t ■ oz ■ lb ■ STon ■ LTon ■ User mass ■ Nl ■ Nm³ ■ Sl ■ Sm³ ■ Sft³ ■ cf FAD ■ m³ FAD ■ l FAD
Factory setting	<p>Country-specific:</p> <ul style="list-style-type: none"> ■ kg ■ lb
Additional information	<p><i>Selection</i></p> <p>The selection is independent of the process variable selected in the Assign process variable parameter (→ 112).</p>

Control Totalizer

Navigation

  Expert → Application → Totalizer → Control Tot. (0912)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 112) of the **Totalizer** submenu:

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Use this function to select the control of the totalizer value.

Selection

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize

Factory setting

Totalize

Additional information*Selection*

- Totalize
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter (→ 114).
- Reset + totalize
The totalizer is reset to 0 and the totaling process is restarted.
- Preset + totalize
The totalizer is set to the defined start value from the **Preset value** parameter (→ 114) and the totaling process is restarted.

Preset value

Navigation

  Expert → Application → Totalizer → Preset value (0913)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 112) of the **Totalizer** submenu:

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Use this function to enter a start value for the Totalizer .

User entry

Signed floating-point number

Factory setting

0 kg

Additional information*User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 113).

Example

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

Failure mode**Navigation**

 Expert → Application → Totalizer → Failure mode (0901)

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 112) of the **Totalizer** submenu:

- Mass flow
- Corrected volume flow
- FAD volume flow

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Stop

Additional information*Description*

 This setting does not affect the failsafe mode of the outputs. This is specified in separate parameters.


Selection

- Stop
Totalizing is stopped when a device alarm occurs.
- Actual value
The totalizer continues to count based on the actual measured value; the device alarm is ignored.
- Last valid value
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

3.6 "Diagnostics" submenu

Navigation

 Expert → Diagnostics



Previous diagnostics (0690)	→ 117
Operating time from restart (0653)	→ 118
Operating time (0652)	→ 118
► Diagnostic list	→ 118
► Event logbook	→ 122
► Device information	→ 125
► Data logging	→ 128
► Min/max values	→ 134
► Simulation	→ 136

Actual diagnostics

Navigation

Expert → Diagnostics → Actual diagnos. (0691)

Prerequisite

A diagnostic event has occurred.

Description

Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 118).

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Example

For the display format:

F271 Main electronic failure

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the current diagnostic message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Actual diagnostics** parameter
(→ 116).

Example

For the display format:

24d12h13m00s

Previous diagnostics

Navigation

Expert → Diagnostics → Prev.diagnostics (0690)

Prerequisite

Two diagnostic events have already occurred.

Description

Displays the diagnostic message that occurred before the current message.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the **✉** key.

Example

For the display format:

☒F271 Main electronic failure

Timestamp

Navigation

Expert → Diagnostics → Timestamp

Description

Displays the operating time when the last diagnostic message before the current message occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Previous diagnostics** parameter
(→ 117).

Example

For the display format:

24d12h13m00s

Operating time from restart

Navigation  Expert → Diagnostics → Time fr. restart (0653)

Description Use this function to display the time the device has been in operation since the last device restart.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation  Expert → Diagnostics → Operating time (0652)

Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.6.1 "Diagnostic list" submenu

Navigation  Expert → Diagnostics → Diagnostic list

 Diagnostic list	
Diagnostics 1 (0692)	→  118
Diagnostics 2 (0693)	→  119
Diagnostics 3 (0694)	→  120
Diagnostics 4 (0695)	→  121
Diagnostics 5 (0696)	→  122

Diagnostics 1

Navigation  Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

Description Displays the current diagnostics message with the highest priority.

User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: ■ \triangle S442 Frequency output ■ \times F276 I/O module failure

Timestamp

Navigation	 Expert → Diagnostics → Diagnostic list → Timestamp
Description	Displays the operating time when the diagnostic message with the highest priority occurred.
User interface	Days (d), hours (h), minutes (m) and seconds (s)
Additional information	<i>Display</i>  The diagnostic message can be viewed via the Diagnostics 1 parameter (→  118).
	<i>Example</i> For the display format: 24d12h13m00s

Diagnostics 2

Navigation	  Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)
Description	Displays the current diagnostics message with the second-highest priority.
User interface	Symbol for diagnostic behavior, diagnostic code and short message.
Additional information	<i>Display</i>  Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.
	<i>Examples</i> For the display format: ■ \triangle S442 Frequency output ■ \times F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

 The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 119).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:
▪  S442 Frequency output
▪  F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 3** parameter (→ 120).

Example

For the display format:

24d12h13m00s

Diagnostics 4

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695)

Description

Displays the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

Examples

For the display format:

- S442 Frequency output
- F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 121).

Example

For the display format:

24d12h13m00s

Diagnostics 5

Navigation

  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information

Display

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

Examples

For the display format:

-  AS442 Frequency output
-  F276 I/O module failure

Timestamp

Navigation

 Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

Display

 The diagnostic message can be viewed via the **Diagnostics 5** parameter (→  122).

Example


For the display format:

24d12h13m00s

3.6.2 "Event logbook" submenu

Navigation

 Expert → Diagnostics → Event logbook



Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options (0705)

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information*Description*

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

Filter options**Navigation**

Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information*Description*

- The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required


"Event list" submenu

i The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

Navigation

Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→ 123).

User interface

- For a "Category I" event message

Information event, short message, symbol for event recording and operating time when error occurred

- For a "Category F, C, S, M" event message (status signal)

Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information

Description

A maximum of 20 event messages are displayed in chronological order.

If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ΔS442 Frequency output
⊖ 01d04h12min30s

i Additional information, such as remedial measures, can be retrieved via the key.

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

To order the **HistoROM advanced capabilities** application package, see the "Accessories" section of the "Technical Information" document.

3.6.3 "Device information" submenu

Navigation

Expert → Diagnostics → Device info

► Device information	
Device tag (0011)	→ 125
Serial number (0009)	→ 126
Firmware version (0010)	→ 126
Device name (0013)	→ 126
Order code (0008)	→ 126
Extended order code 1 (0023)	→ 127
Extended order code 2 (0021)	→ 127
Extended order code 3 (0022)	→ 127
ENP version (0012)	→ 128
Configuration counter (0233)	→ 128

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag (0011)

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

User interface


Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

t-mass

Additional information

User interface



A0013375

9 Header text

The number of characters displayed depends on the characters used.

Serial number

Navigation   Expert → Diagnostics → Device info → Serial number (0009)

Description Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface A maximum of 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation   Expert → Diagnostics → Device info → Firmware version (0010)

Description Displays the device firmware version installed.

User interface Character string in the format xx.yy.zz

Additional information *Display*

 The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name

Navigation   Expert → Diagnostics → Device info → Device name (0013)

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface t-mass 150

Order code



Navigation   Expert → Diagnostics → Device info → Order code (0008)

Description Displays the device order code.

User interface Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

 The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

 **Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

 The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

Description

For displaying the second part of the extended order code.

User interface

Character string

Additional information

For additional information, see **Extended order code 1** parameter (→  127)

Extended order code 3**Navigation**

  Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

Description

For displaying the third part of the extended order code.

User interface

Character string

Additional information For additional information, see **Extended order code 1** parameter (→ 127)

ENP version

Navigation  Expert → Diagnostics → Device info → ENP version (0012)

Description Displays the version of the electronic nameplate.

User interface Character string

Factory setting 2.02.00

Additional information *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

Configuration counter


Navigation  Expert → Diagnostics → Device info → Config. counter (0233)

Description Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

User interface 0 to 65 535

3.6.4 "Data logging" submenu

Navigation  Expert → Diagnostics → Data logging



▶ Display channel 1	→ 132
▶ Display channel 2	→ 132
▶ Display channel 3	→ 133
▶ Display channel 4	→ 133

Assign channel 1



Navigation Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter.

Description Use this function to select a process variable for the data logging channel.

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Current output

Factory setting Off

Additional information *Description*

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The log contents are cleared if the option selected is changed.

Assign channel 2



Navigation Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

Prerequisite The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter.

Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→ 129)
Factory setting	Off

Assign channel 3



Navigation	Expert → Diagnostics → Data logging → Assign chan. 3 (0853)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→ 129)
Factory setting	Off

Assign channel 4



Navigation	Expert → Diagnostics → Data logging → Assign chan. 4 (0854)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.
Description	Options for the assignment of a process variable to the data logging channel.
Selection	Picklist, see Assign channel 1 parameter (→ 129)
Factory setting	Off

Logging interval



Navigation	Expert → Diagnostics → Data logging → Logging interval (0856)
Prerequisite	The Extended HistoROM application package is available. The software options currently enabled are displayed in the Software option overview parameter.
Description	Use this function to enter the logging interval t_{log} for data logging.
User entry	1.0 to 3 600.0 s

Factory setting 10.0 s

Additional information *Description*

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time T_{\log} :

- If 1 logging channel is used: $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used: $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used: $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used: $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of T_{\log} always remains in the memory (ring memory principle).

 The log contents are cleared if the length of the logging interval is changed.

Example

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

Clear logging data



Navigation

 Expert → Diagnostics → Data logging → Clear logging (0855)

Prerequisite

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter.

Description

Option to clear the entire logging data.

Selection

- Cancel
- Clear data

Factory setting

Cancel


Additional information

Selection

- Cancel
The data is not cleared. All the data is retained.
- Clear data
The logging data is cleared. The logging process starts from the beginning.

"Display channel 1" submenu**Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

**Display channel 1****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

Prerequisite

The **Extended HistoROM** application package is available.


The software options currently enabled are displayed in the **Software option overview** parameter.

One of the following options is selected in the **Assign channel 1** parameter (→ 129):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature
- Current output

Description

Displays the measured value trend for the logging channel in the form of a chart.

Additional information*Description*

- x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.
- y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.

"Display channel 2" submenu**Navigation**

Expert → Diagnostics → Data logging → Displ.channel 2



Display channel 2

Navigation  Expert → Diagnostics → Data logging → Displ.channel 2

Prerequisite A process variable is defined in the **Assign channel 2** parameter.

Description See the **Display channel 1** parameter →  132

"Display channel 3" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3



Display channel 3

Navigation  Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite A process variable is defined in the **Assign channel 3** parameter.

Description See the **Display channel 1** parameter →  132

"Display channel 4" submenu

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4



Display channel 4

Navigation  Expert → Diagnostics → Data logging → Displ.channel 4


Prerequisite A process variable is defined in the **Assign channel 4** parameter.

Description	See the Display channel 1 parameter → 132
-------------	--

3.6.5 "Min/max values" submenu

Navigation


Expert → Diagnostics → Min/max val.



"Electronic temperature" submenu

Navigation

Expert → Diagnostics → Min/max val. → Electronic temp.



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Electronic temp. → Minimum value (3445)

Description

Displays the lowest previously measured temperature value of the main electronics module.

User interface

-273.15 to 726.75 °C

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ [48](#))

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Electronic temp. → Maximum value (3444)

Description

Displays the highest previously measured temperature value of the main electronics module.

User interface -273.15 to 726.75 °C


Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [48](#))

"Process temperature" submenu

Navigation

  Expert → Diagnostics → Min/max val. → Process temp.



Minimum value

Navigation   Expert → Diagnostics → Min/max val. → Process temp. → Minimum value (3447)

Description Displays the lowest previously measured process temperature.

User interface -273.15 to 726.75 °C

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [48](#))

Maximum value

Navigation   Expert → Diagnostics → Min/max val. → Process temp. → Maximum value (3446)

Description Displays the highest previously measured process temperature.

User interface -273.15 to 726.75 °C

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [48](#))

3.6.6 "Simulation" submenu

Navigation

 Expert → Diagnostics → Simulation

▶ Simulation	
Assign simulation process variable (1810)	→  136
Value process variable (1811)	→  137
Simulation current output 1 (0354-1)	→  137
Value current output 1 (0355-1)	→  138
Frequency simulation (0472)	→  138
Frequency value (0473)	→  138
Pulse simulation (0458)	→  139
Pulse value (0459)	→  139
Switch output simulation (0462)	→  140
Switch status (0463)	→  140
Simulation device alarm (0654)	→  141

Assign simulation process variable



Navigation

 Expert → Diagnostics → Simulation → Assign proc.var. (1810)

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Factory setting

Off

Additional information

Description

 The simulation value of the process variable selected is defined in the **Value process variable** parameter (→  137).

Value process variable**Navigation**

Expert → Diagnostics → Simulation → Value proc. var. (1811)

Prerequisite

One of the following options is selected in the **Assign simulation process variable** parameter (→ [136](#)):

- Mass flow
- Corrected volume flow
- FAD volume flow
- Temperature

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ [43](#)).

Simulation current output 1**Navigation**

Expert → Diagnostics → Simulation → Sim.curr.out. 1 (0354-1)

Description

Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is specified in the **Value current output 1** parameter (→ [138](#)).

Selection

- Off
Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Current simulation is active.

Value current output 1



Navigation

Expert → Diagnostics → Simulation → Value curr.out 1 (0355-1)

Prerequisite

In the **Simulation current output 1** parameter, the **On** option is selected.

Description

Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units.

User entry

3.59 to 22.5 mA

Frequency simulation



Navigation

Expert → Diagnostics → Simulation → Frequency sim. (0472)

Prerequisite

In the **Operating mode** parameter (→ 86), the **Frequency** option is selected.

Description

Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Frequency value** parameter (→ 138).

Selection

- Off
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Frequency simulation is active.

Frequency value



Navigation

Expert → Diagnostics → Simulation → Freq. value (0473)

Prerequisite

In the **Frequency simulation** parameter (→ 138), the **On** option is selected.

Description

Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

User entry 0.0 to 1250 Hz

Factory setting 0.0 Hz

Pulse simulation



Navigation Expert → Diagnostics → Simulation → Pulse sim. (0458)

Prerequisite In the **Operating mode** parameter (→ 86), the **Pulse** option is selected.

Description Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Fixed value
- Down-counting value

Factory setting Off

Additional information *Description*

The desired simulation value is defined in the **Pulse value** parameter (→ 139).

Selection

- Off
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 88).
- Down-counting value
The pulses specified in the **Pulse value** parameter (→ 139) are output.

Pulse value



Navigation Expert → Diagnostics → Simulation → Pulse value (0459)

Prerequisite In the **Pulse simulation** parameter (→ 139), the **Down-counting value** option is selected.

Description Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

User entry 0 to 65 535

Switch output simulation



Navigation

Expert → Diagnostics → Simulation → Switch sim. (0462)

Prerequisite

In the **Operating mode** parameter (→ 86), the **Switch** option is selected.

Description

Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- On

Factory setting

Off

Additional information

Description

The desired simulation value is defined in the **Switch status** parameter (→ 140).

Selection

- Off
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On
Switch simulation is active.

Switch status



Navigation

Expert → Diagnostics → Simulation → Switch status (0463)

Prerequisite

In the **Switch output simulation** parameter (→ 140), the **On** option is selected.

Description

Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.

Selection

- Open
- Closed

Factory setting

Open

Additional information

Selection

- Open
Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Closed
Switch simulation is active.

Simulation device alarm

Navigation	Expert → Diagnostics → Simulation → Sim. alarm (0654)
Description	Use this function to switch the device alarm on and off.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<i>Description</i> The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Diagnostic event category

Navigation	Expert → Diagnostics → Simulation → Event category (0738)
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Simulation diagnostic event parameter (→ 141).
Selection	<ul style="list-style-type: none">▪ Sensor▪ Electronics▪ Configuration▪ Process
Factory setting	Sensor

Simulation diagnostic event

Navigation	Expert → Diagnostics → Simulation → Sim. diag. event (0737)
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	<ul style="list-style-type: none">▪ Off▪ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<i>Description</i> For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 141).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Mass flow	kg/h
Mass	kg
Corrected volume flow	Nm ³ /h
Corrected volume	Nm ³
FAD volume flow	m ³ FAD/h
FAD volume	m ³ FAD
Density	kg/m ³
Reference density	kg/Nm ³
Temperature	°C
Length	mm
Pressure	bar a

4.1.2 Full scale values

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

t-mass A

DN [mm]	[kg/h]
15	53
25	200
40	555
50	910

t-mass B

DN [mm]	[kg/h]
175	7 500

4.1.3 Output current span

Current output 1	4 to 20 mA NAMUR
------------------	------------------

4.1.4 Pulse value

t-mass A

Nominal diameter [mm]	[kg]
15	0.1
25	1
40	1
50	10

t-mass B

Nominal diameter [mm]	[kg]
175	100

4.1.5 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

t-mass A

Nominal diameter [mm]	[kg/h]
15	0.53
25	2
40	5.55
50	9.1

t-mass B

Nominal diameter [mm]	[kg/h]
175	75

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Mass flow	lb/h
Mass flow	lb/min
Mass	lb
Corrected volume flow	Sft ³ /min
Corrected volume	Sft ³
FAD volume flow	cf FAD/min
FAD volume	cf FAD
Density	lb/ft ³

Reference density	lb/Sft ³
Temperature	°F
Length	in
Pressure	psi a

4.2.2 Full scale values

- i** The factory settings apply to the following parameters:
- 20 mA value (full scale value of the current output)
 - 100% bar graph value 1

t-mass A

DN [in]	[lb/h]
½	116
1	440
1½	1220
2	2002

t-mass B

DN [in]	[lb/h]
7	16 500

4.2.3 Output current span

Current output 1	4 to 20 mA US
------------------	---------------

4.2.4 Pulse value

t-mass A

Nominal diameter [in]	[lb]
½	0.2
1	2
1½	2
2	20

t-mass B

Nominal diameter [in]	[lb]
7	200

4.2.5 On value low flow cut off

- i** The switch-on point depends on the type of medium and the nominal diameter.

t-mass A

Nominal diameter [in]	[lb/h]
½	1.16
1	4.4
1½	12.2
2	20.02

t-mass B

Nominal diameter [in]	[lb/h]
7	165

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³	Gram/volume unit
	kg/l, kg/dm ³ , kg/m ³	Kilogram/volume unit
Pressure	kPa a, MPa a	Kilopascal, megapascal (absolute)
	bar	Bar
	mbar a	Millibar (absolute)
FAD volume	l FAD, m ³ FAD	FAD liter, FAD cubic meter
FAD volume flow	l FAD/s, l FAD/min, l FAD/h, l FAD/d	FAD liter/time unit
	m ³ FAD/s, m ³ FAD/min, m ³ FAD/h, m ³ FAD/d	FAD cubic meter/time unit
Length	mm, m	Millimeter, meter
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Corrected volume	NI, Nm ³ , Sl, Sm ³	Normal liter, normal cubic meter, standard liter, standard cubic meter
Corrected volume flow	NI/s, NI/min, NI/h, NI/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sl/s, Sl/min, Sl/h, Sl/d	Standard liter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Temperature	°C, K	Celsius, Kelvin
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³	Pound/cubic foot
Pressure	psi a	Psi absolute
FAD volume	cf FAD	FAD cubic foot
FAD volume flow	cf FAD/s, cf FAD/min, cf FAD/h, cf FAD/d	FAD cubic foot/time unit
Length	in, ft	Inch, foot
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Corrected volume	Sft ³	Standard cubic foot

Process variable	Units	Explanation
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
Temperature	°F, °R	Fahrenheit, Rankine
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Mass	LTon	Long ton
Mass flow	LTon/s, LTon/min, LTon/h, LTon/d	Long ton/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0% bargraph value 1 (Parameter)	18
0% bargraph value 3 (Parameter)	21
4 mA value (Parameter)	79
20 mA value (Parameter)	80
100% bargraph value 1 (Parameter)	19
100% bargraph value 3 (Parameter)	21

A

Access status display (Parameter)	11, 26
Access status tooling (Parameter)	12
Activate SW option (Parameter)	36
Actual diagnostics (Parameter)	116
Adjustment values in use (Submenu)	65
Alarm delay (Parameter)	31
Application (Submenu)	111
Apply (Parameter)	76
Assign behavior of diagnostic no. 441 (Parameter)	32
Assign behavior of diagnostic no. 442 (Parameter)	32
Assign behavior of diagnostic no. 443 (Parameter)	33
Assign behavior of diagnostic no. 801 (Parameter)	33
Assign behavior of diagnostic no. 832 (Parameter)	33
Assign behavior of diagnostic no. 833 (Parameter)	34
Assign behavior of diagnostic no. 834 (Parameter)	34
Assign behavior of diagnostic no. 835 (Parameter)	35
Assign channel 1 (Parameter)	129
Assign channel 2 (Parameter)	129
Assign channel 3 (Parameter)	130
Assign channel 4 (Parameter)	130
Assign current output (Parameter)	78
Assign diagnostic behavior (Parameter)	96
Assign frequency output (Parameter)	91
Assign limit (Parameter)	97
Assign process variable (Parameter)	53, 112
Assign pulse output (Parameter)	88
Assign PV (Parameter)	109
Assign QV (Parameter)	111
Assign simulation process variable (Parameter)	136
Assign status (Parameter)	99
Assign SV (Parameter)	109
Assign TV (Parameter)	110

B

Backlight (Parameter)	26
Backup state (Parameter)	29
Burst command (Parameter)	103
Burst mode (Parameter)	103

C

Calculated values (Submenu)	56
Calibration (Submenu)	76
Calibration date/time (Parameter)	76
Clear logging data (Parameter)	131
Clear values (Parameter)	71
Communication (Submenu)	102
Comparison result (Parameter)	29

Configuration (Submenu)	102
Configuration backup display (Submenu)	27
Configuration counter (Parameter)	128
Configuration management (Parameter)	28
Contrast display (Parameter)	26
Control Totalizer (Parameter)	114
Corrected volume flow (Parameter)	38
Corrected volume flow unit (Parameter)	45
Corrected volume unit (Parameter)	46
Current output 1 (Submenu)	77
Current span (Parameter)	78

D

Damping (Parameter)	81
Damping output (Parameter)	93
Data logging (Submenu)	128
Data validity (Parameter)	75
Date/time format (Parameter)	50
Decimal places 1 (Parameter)	19
Decimal places 2 (Parameter)	20
Decimal places 3 (Parameter)	22
Decimal places 4 (Parameter)	23
Define access code (Parameter)	13
Density unit (Parameter)	48
Device ID (Parameter)	106
Device information (Submenu)	125
Device name (Parameter)	126
Device reset (Parameter)	35
Device revision (Parameter)	105
Device tag (Parameter)	125
Device type (Parameter)	106
Diagnostic behavior (Submenu)	31
Diagnostic event category (Parameter)	141
Diagnostic handling (Submenu)	30
Diagnostic list (Submenu)	118
Diagnostics (Submenu)	115
Diagnostics 1 (Parameter)	118
Diagnostics 2 (Parameter)	119
Diagnostics 3 (Parameter)	120
Diagnostics 4 (Parameter)	121
Diagnostics 5 (Parameter)	122

Direct access

0% bargraph value 1 (0123)	18
0% bargraph value 3 (0124)	21
4 mA value	
Current output 1 (0367-1)	79
20 mA value	
Current output 1 (0372-1)	80
100% bargraph value 1 (0125)	19
100% bargraph value 3 (0126)	21
Access status display (0091)	11, 26
Access status tooling (0005)	12
Activate SW option (0029)	36
Actual diagnostics (0691)	116
Alarm delay (0651)	31
Apply (3528)	76

Assign behavior of diagnostic no. 441 (0657)	32
Assign behavior of diagnostic no. 442 (0658)	32
Assign behavior of diagnostic no. 443 (0659)	33
Assign behavior of diagnostic no. 801 (0660)	33
Assign behavior of diagnostic no. 832 (0675)	33
Assign behavior of diagnostic no. 833 (0676)	34
Assign behavior of diagnostic no. 834 (0677)	34
Assign behavior of diagnostic no. 835 (0678)	35
Assign channel 1 (0851)	129
Assign channel 2 (0852)	129
Assign channel 3 (0853)	130
Assign channel 4 (0854)	130
Assign current output	
Current output 1 (0359-1)	78
Assign diagnostic behavior	
Pulse-Frequency-Switch output 1 (0482-1)	96
Assign frequency output	
Pulse-Frequency-Switch output 1 (0478-1)	91
Assign limit	
Pulse-Frequency-Switch output 1 (0483-1)	97
Assign process variable (0914)	112
Assign process variable (1837)	53
Assign pulse output	
Pulse-Frequency-Switch output 1 (0460-1)	88
Assign PV (0234)	109
Assign QV (0237)	111
Assign simulation process variable (1810)	136
Assign status	
Pulse-Frequency-Switch output 1 (0485-1)	99
Assign SV (0235)	109
Assign TV (0236)	110
Backlight (0111)	26
Backup state (0121)	29
Burst command (0207)	103
Burst mode (0208)	103
Calibration date/time (3436)	76
Clear logging data (0855)	131
Clear values (3529)	71
Comparison result (0103)	29
Configuration counter (0233)	128
Configuration management (0100)	28
Contrast display (0105)	26
Control Totalizer (0912)	114
Corrected volume flow (1847)	38
Corrected volume flow unit (0558)	45
Corrected volume unit (0575)	46
Current span	
Current output 1 (0353-1)	78
Damping	
Current output 1 (0363-1)	81
Damping output	
Pulse-Frequency-Switch output 1 (0477-1)	93
Data validity (3434)	75
Date/time format (2812)	50
Decimal places 1 (0095)	19
Decimal places 2 (0117)	20
Decimal places 3 (0118)	22
Decimal places 4 (0119)	23
Define access code (0093)	13
Density unit (0555)	48
Device ID (0221)	106
Device name (0013)	126
Device reset (0000)	35
Device revision (0204)	105
Device tag (0011)	125
Device type (0222)	106
Diagnostic event category (0738)	141
Diagnostics 1 (0692)	118
Diagnostics 2 (0693)	119
Diagnostics 3 (0694)	120
Diagnostics 4 (0695)	121
Diagnostics 5 (0696)	122
Direct access (0106)	10
Display damping (0094)	24
Display interval (0096)	23
Duct internal height (3405)	61
Duct internal width (3411)	61
ENP version (0012)	128
Enter access code (0003)	13
Enter access code (0092)	12
Extended order code 1 (0023)	127
Extended order code 2 (0021)	127
Extended order code 3 (0022)	127
FAD conditions (3438)	58
FAD density (3372)	59
FAD pressure (3373)	58
FAD temperature (3374)	59
FAD volume flow (1851)	39
FAD volume flow unit (0601)	47
FAD volume unit (0591)	47
Failure current	
Current output 1 (0352-1)	83
Failure frequency	
Pulse-Frequency-Switch output 1 (0474-1)	95
Failure mode	
Current output 1 (0364-1)	82
Pulse-Frequency-Switch output 1 (0451-1)	94
Pulse-Frequency-Switch output 1 (0480-1)	89
Pulse-Frequency-Switch output 1 (0486-1)	100
Failure mode (0901)	115
Filter options	123
Filter options (0705)	123
Firmware version (0010)	126
Fixed current	
Current output 1 (0365-1)	79
Flow conditioner (3404)	76
Flow damping (1802)	52
Flow override (1839)	52
Flow reference in use (3440)	65
Flow reference value 1 (3384)	71
Flow reference value 1 (3401)	66
Flow reference value 2 (3385)	72
Flow reference value 2 (3418)	66
Flow reference value 3 (3386)	72
Flow reference value 3 (3419)	67
Flow reference value 4 (3387)	73
Flow reference value 4 (3420)	67
Flow reference value 5 (3388)	73

Flow reference value 5 (3421)	67	Output frequency (0471)	43
Flow reference value 6 (3389)	74	Pipe inner diameter (3476)	61
Flow reference value 6 (3422)	68	Pipe shape (3441)	60
Flow reference value 7 (3390)	74	Pipe wall thickness (3409)	62
Flow reference value 7 (3423)	68	Power coefficient 1 (3392)	71
Flow reference value 8 (3391)	75	Power coefficient 1 (3425)	66
Flow reference value 8 (3424)	69	Power coefficient 2 (3393)	72
Format display (0098)	16	Power coefficient 2 (3426)	66
Frequency simulation (0472)	138	Power coefficient 3 (3394)	72
Frequency value (0473)	138	Power coefficient 3 (3427)	67
Hardware revision (0206)	108	Power coefficient 4 (3395)	73
HART address (0219)	104	Power coefficient 4 (3428)	67
HART date code (0202)	107	Power coefficient 5 (3396)	73
HART descriptor (0212)	107	Power coefficient 5 (3429)	68
HART message (0216)	107	Power coefficient 6 (3397)	74
HART revision (0205)	106	Power coefficient 6 (3430)	68
HART short tag (0220)	104	Power coefficient 7 (3398)	74
Header (0097)	24	Power coefficient 7 (3431)	69
Header text (0112)	25	Power coefficient 8 (3399)	75
Insertion depth (3406)	63	Power coefficient 8 (3432)	69
Installation factor (3470)	60	Preset value (0913)	114
Invert output signal		Pressure unit (0564)	49
Pulse-Frequency-Switch output 1 (0470-1)	101	Previous diagnostics (0690)	117
Language (0104)	15	Primary variable (PV) (0201)	109
Last backup (0102)	28	Pulse output	
Length unit (0551)	49	Pulse-Frequency-Switch output 1 (0456-1)	90
Locking status (0004)	11	Pulse output (0456)	42
Logging interval (0856)	130	Pulse simulation (0458)	139
Manufacturer ID (0223)	106	Pulse value (0459)	139
Mass flow (1838)	38	Pulse width	
Mass flow unit (0554)	44	Pulse-Frequency-Switch output 1 (0452-1)	88
Mass unit (0574)	45	Quaternary variable (QV) (0203)	111
Maximum frequency value		Reference conditions (3439)	56
Pulse-Frequency-Switch output 1 (0454-1)	92	Reference density (3377)	57
Maximum value (3444)	134	Reference pressure (3378)	57
Maximum value (3446)	135	Reference temperature (3379)	57
Measuring value at maximum frequency		Reset all totalizers (2806)	112
Pulse-Frequency-Switch output 1 (0475-1)	92	Reset write protection (0019)	37
Measuring value at minimum frequency		Response time	
Pulse-Frequency-Switch output 1 (0476-1)	92	Current output 1 (0378-1)	82
Minimum frequency value		Pulse-Frequency-Switch output 1 (0491-1)	93
Pulse-Frequency-Switch output 1 (0453-1)	91	Secondary variable (SV) (0226)	110
Minimum value (3445)	134	Select flow reference (3382)	70
Minimum value (3447)	135	Select gas type (3381)	55
Mounting set height (3435)	62	Separator (0101)	25
No. of preambles (0217)	104	Serial number (0009)	126
Off value low flow cutoff (1804)	54	Simulation current output 1 (0354-1)	137
On value low flow cutoff (1805)	54	Simulation device alarm (0654)	141
Operating mode		Simulation diagnostic event (0737)	141
Pulse-Frequency-Switch output 1 (0469-1)	86	Software revision (0224)	108
Operating mode (3400)	64	Start-up current	
Operating time (0652)	27, 118	Current output 1 (0369-1)	84
Operating time from restart (0653)	118	Start-up mode	
Order code (0008)	126	Current output 1 (0368-1)	84
Orientation (3437)	62	Switch output function	
Output current (0361)	42	Pulse-Frequency-Switch output 1 (0481-1)	95
Output current 1 (0361-1)	84	Switch output simulation (0462)	140
Output frequency		Pulse-Frequency-Switch output 1 (0461-1)	101
Pulse-Frequency-Switch output 1 (0471-1)	95		

Switch status (0461)	43
Switch status (0463)	140
Switch-off delay	
Pulse-Frequency-Switch output 1 (0465-1) . .	100
Switch-off value	
Pulse-Frequency-Switch output 1 (0464-1) . .	99
Switch-on delay	
Pulse-Frequency-Switch output 1 (0467-1) . .	100
Switch-on value	
Pulse-Frequency-Switch output 1 (0466-1) . .	98
Temperature (1853)	39
Temperature unit (0557)	48
Tertiary variable (TV) (0228)	110
Timestamp	116, 117, 119, 120, 121, 122
Totalizer overflow (0910)	41
Totalizer value (0911)	40
Unit (0915)	113
User mass factor (0561)	51
User mass offset (0562)	51
User mass text (0560)	51
Value 1 display (0107)	18
Value 2 display (0108)	19
Value 3 display (0110)	20
Value 4 display (0109)	22
Value current output 1 (0355-1)	138
Value per pulse	
Pulse-Frequency-Switch output 1 (0455-1) . .	88
Value process variable (1811)	137
Direct access (Parameter)	10
Display (Submenu)	14
Display channel 1 (Submenu)	132
Display channel 2 (Submenu)	132
Display channel 3 (Submenu)	133
Display channel 4 (Submenu)	133
Display damping (Parameter)	24
Display interval (Parameter)	23
Document	
Explanation of the structure of a parameter	
description	6
Function	4
Structure	4
Symbols used	6
Target group	4
Using the document	4
Document function	4
Duct internal height (Parameter)	61
Duct internal width (Parameter)	61
E	
Electronic temperature (Submenu)	134
ENP version (Parameter)	128
Enter access code (Parameter)	12, 13
Event list (Submenu)	124
Event logbook (Submenu)	122
Extended order code 1 (Parameter)	127
Extended order code 2 (Parameter)	127
Extended order code 3 (Parameter)	127
F	
Factory settings	142
SI units	142
US units	143
FAD conditions (Parameter)	58
FAD density (Parameter)	59
FAD pressure (Parameter)	58
FAD temperature (Parameter)	59
FAD volume flow (Parameter)	39
FAD volume flow unit (Parameter)	47
FAD volume unit (Parameter)	47
Failure current (Parameter)	83
Failure frequency (Parameter)	95
Failure mode (Parameter)	82, 89, 94, 100, 115
Filter options (Parameter)	123
Firmware version (Parameter)	126
Fixed current (Parameter)	79
Flow conditioner (Parameter)	76
Flow damping (Parameter)	52
Flow override (Parameter)	52
Flow reference in use (Parameter)	65
Flow reference value 1 (Parameter)	66, 71
Flow reference value 2 (Parameter)	66, 72
Flow reference value 3 (Parameter)	67, 72
Flow reference value 4 (Parameter)	67, 73
Flow reference value 5 (Parameter)	67, 73
Flow reference value 6 (Parameter)	68, 74
Flow reference value 7 (Parameter)	68, 74
Flow reference value 8 (Parameter)	69, 75
Format display (Parameter)	16
Frequency simulation (Parameter)	138
Frequency value (Parameter)	138
Function	
see Parameter	
H	
Hardware revision (Parameter)	108
HART address (Parameter)	104
HART date code (Parameter)	107
HART descriptor (Parameter)	107
HART message (Parameter)	107
HART output (Submenu)	102
HART revision (Parameter)	106
HART short tag (Parameter)	104
Header (Parameter)	24
Header text (Parameter)	25
I	
In-situ adjustment (Submenu)	64
Information (Submenu)	105
Insertion depth (Parameter)	63
Installation factor (Parameter)	60
Installation settings (Submenu)	60
Invert output signal (Parameter)	101
L	
Language (Parameter)	15
Last backup (Parameter)	28
Length unit (Parameter)	49

Locking status (Parameter) 11
 Logging interval (Parameter) 130
 Low flow cut off (Submenu) 53

M

Management (Submenu) 35
 Manufacturer ID (Parameter) 106
 Mass flow (Parameter) 38
 Mass flow unit (Parameter) 44
 Mass unit (Parameter) 45
 Maximum frequency value (Parameter) 92
 Maximum value (Parameter) 134, 135
 Measured values (Submenu) 37
 Measurement mode (Submenu) 55
 Measuring value at maximum frequency (Parameter) 92
 Measuring value at minimum frequency (Parameter) 92
 Min/max values (Submenu) 134
 Minimum frequency value (Parameter) 91
 Minimum value (Parameter) 134, 135
 Mounting set height (Parameter) 62

N

New adjustment (Submenu) 69
 No. of preambles (Parameter) 104

O

Off value low flow cutoff (Parameter) 54
 On value low flow cutoff (Parameter) 54
 Operating mode (Parameter) 64, 86
 Operating time (Parameter) 27, 118
 Operating time from restart (Parameter) 118
 Order code (Parameter) 126
 Orientation (Parameter) 62
 Output (Submenu) 77, 108
 Output current (Parameter) 42
 Output current 1 (Parameter) 84
 Output frequency (Parameter) 43, 95
 Output values (Submenu) 41

P

Parameter
 Structure of a parameter description 6
 Perform adjustment (Submenu) 70
 Pipe inner diameter (Parameter) 61
 Pipe shape (Parameter) 60
 Pipe wall thickness (Parameter) 62
 Power coefficient 1 (Parameter) 66, 71
 Power coefficient 2 (Parameter) 66, 72
 Power coefficient 3 (Parameter) 67, 72
 Power coefficient 4 (Parameter) 67, 73
 Power coefficient 5 (Parameter) 68, 73
 Power coefficient 6 (Parameter) 68, 74
 Power coefficient 7 (Parameter) 69, 74
 Power coefficient 8 (Parameter) 69, 75
 Preset value (Parameter) 114
 Pressure unit (Parameter) 49
 Previous diagnostics (Parameter) 117
 Primary variable (PV) (Parameter) 109
 Process parameters (Submenu) 52
 Process temperature (Submenu) 135

Process variables (Submenu) 38
 Pulse output (Parameter) 42, 90
 Pulse simulation (Parameter) 139
 Pulse value (Parameter) 139
 Pulse width (Parameter) 88
 Pulse-Frequency-Switch output (Submenu) 85

Q

Quaternary variable (QV) (Parameter) 111

R

Reference conditions (Parameter) 56
 Reference density (Parameter) 57
 Reference pressure (Parameter) 57
 Reference temperature (Parameter) 57
 Reference values (Submenu) 56
 Reset all totalizers (Parameter) 112
 Reset write protection (Parameter) 37
 Response time (Parameter) 82, 93

S

Secondary variable (SV) (Parameter) 110
 Select flow reference (Parameter) 70
 Select gas type (Parameter) 55
 Sensor (Submenu) 37
 Sensor adjustment (Submenu) 59
 Separator (Parameter) 25
 Serial number (Parameter) 126
 Simulation (Submenu) 136
 Simulation current output 1 (Parameter) 137
 Simulation device alarm (Parameter) 141
 Simulation diagnostic event (Parameter) 141
 Software revision (Parameter) 108
 Start-up current (Parameter) 84
 Start-up mode (Parameter) 84
 Submenu

 Adjustment values in use 65
 Application 111
 Calculated values 56
 Calibration 76
 Communication 102
 Configuration 102
 Configuration backup display 27
 Current output 1 77
 Data logging 128
 Device information 125
 Diagnostic behavior 31
 Diagnostic handling 30
 Diagnostic list 118
 Diagnostics 115
 Display 14
 Display channel 1 132
 Display channel 2 132
 Display channel 3 133
 Display channel 4 133
 Electronic temperature 134
 Event list 124
 Event logbook 122
 HART output 102

In-situ adjustment	64	Value per pulse (Parameter)	88
Information	105	Value process variable (Parameter)	137
Installation settings	60		
Low flow cut off	53		
Management	35		
Measured values	37		
Measurement mode	55		
Min/max values	134		
New adjustment	69		
Output	77, 108		
Output values	41		
Perform adjustment	70		
Process parameters	52		
Process temperature	135		
Process variables	38		
Pulse-Frequency-Switch output	85		
Reference values	56		
Sensor	37		
Sensor adjustment	59		
Simulation	136		
System	13		
System units	43		
Totalizer	40, 112		
Use adjustment	75		
User specific units	50		
Switch output function (Parameter)	95		
Switch output simulation (Parameter)	140		
Switch status (Parameter)	43, 101, 140		
Switch-off delay (Parameter)	100		
Switch-off value (Parameter)	99		
Switch-on delay (Parameter)	100		
Switch-on value (Parameter)	98		
System (Submenu)	13		
System units (Submenu)	43		
T			
Target group	4		
Temperature (Parameter)	39		
Temperature unit (Parameter)	48		
Tertiary variable (TV) (Parameter)	110		
Timestamp (Parameter)	116, 117, 119, 120, 121, 122		
Totalizer (Submenu)	40, 112		
Totalizer overflow (Parameter)	41		
Totalizer value (Parameter)	40		
U			
Unit (Parameter)	113		
Use adjustment (Submenu)	75		
User mass factor (Parameter)	51		
User mass offset (Parameter)	51		
User mass text (Parameter)	51		
User specific units (Submenu)	50		
V			
Value 1 display (Parameter)	18		
Value 2 display (Parameter)	19		
Value 3 display (Parameter)	20		
Value 4 display (Parameter)	22		
Value current output 1 (Parameter)	138		

www.addresses.endress.com
