


# Description of Device Parameters

## Proline t-mass T 150

## HART

Thermal Mass Flowmeter





# Table of contents

|  |            |  |            |
|--|------------|--|------------|
| <b>1 Document information .....</b>                      | <b>4</b>   |  |            |
| 1.1 Document function .....                              | 4          | 4.1.4 Pulse value .....                      | 140        |
| 1.2 Target group .....                                   | 4          | 4.1.5 On value low flow cut off .....        | 140        |
| 1.3 Using this document .....                            | 4          | 4.2 US units .....                           | 141        |
| 1.3.1 Information on the document<br>structure .....     | 4          | 4.2.1 System units .....                     | 141        |
| 1.3.2 Structure of a parameter<br>description .....      | 6          | 4.2.2 Full scale values .....                | 141        |
| 1.4 Symbols used .....                                   | 6          | 4.2.3 Output current span .....              | 141        |
| 1.4.1 Symbols for certain types of<br>information .....  | 6          | 4.2.4 Pulse value .....                      | 141        |
| 1.4.2 Symbols in graphics .....                          | 7          | 4.2.5 On value low flow cut off .....        | 141        |
| <b>2 Overview of the Expert operating<br/>menu .....</b> | <b>8</b>   |  |            |
| <b>3 Description of device parameters ...</b>            | <b>10</b>  |  |            |
| 3.1 "System" submenu .....                               | 13         | <b>5 Explanation of abbreviated units ..</b> | <b>143</b> |
| 3.1.1 "Display" submenu .....                            | 13         | 5.1 SI units .....                           | 143        |
| 3.1.2 "Configuration backup display"<br>submenu .....    | 26         | 5.2 US units .....                           | 143        |
| 3.1.3 "Diagnostic handling" submenu .....                | 29         | 5.3 Imperial units .....                     | 144        |
| 3.1.4 "Administration" submenu .....                     | 34         |  |            |
| 3.2 "Sensor" submenu .....                               | 39         | <b>Index .....</b>                           | <b>145</b> |
| 3.2.1 "Measured values" submenu .....                    | 39         |  |            |
| 3.2.2 "System units" submenu .....                       | 45         |  |            |
| 3.2.3 "Process parameters" submenu .....                 | 54         |  |            |
| 3.2.4 "Sensor adjustment" submenu .....                  | 57         |  |            |
| 3.2.5 "Calibration" submenu .....                        | 71         |  |            |
| 3.3 "Input" submenu .....                                | 71         |  |            |
| 3.3.1 "Status input" submenu .....                       | 72         |  |            |
| 3.4 "Output" submenu .....                               | 73         |  |            |
| 3.4.1 "Current output 1" submenu .....                   | 73         |  |            |
| 3.4.2 "Pulse/frequency/switch output"<br>submenu .....   | 81         |  |            |
| 3.5 "Communication" submenu .....                        | 98         |  |            |
| 3.5.1 "HART output" submenu .....                        | 99         |  |            |
| 3.6 "Application" submenu .....                          | 108        |  |            |
| 3.6.1 "Totalizer" submenu .....                          | 108        |  |            |
| 3.6.2 "CIP/SIP" submenu .....                            | 111        |  |            |
| 3.7 "Diagnostics" submenu .....                          | 112        |  |            |
| 3.7.1 "Diagnostic list" submenu .....                    | 115        |  |            |
| 3.7.2 "Event logbook" submenu .....                      | 119        |  |            |
| 3.7.3 "Device information" submenu .....                 | 121        |  |            |
| 3.7.4 "Data logging" submenu .....                       | 125        |  |            |
| 3.7.5 "Min/max values" submenu .....                     | 131        |  |            |
| 3.7.6 "Simulation" submenu .....                         | 133        |  |            |
| <b>4 Country-specific factory settings ..</b>            | <b>140</b> |  |            |
| 4.1 SI units .....                                       | 140        |  |            |
| 4.1.1 System units .....                                 | 140        |  |            |
| 4.1.2 Full scale values .....                            | 140        |  |            |
| 4.1.3 Output current span .....                          | 140        |  |            |

# 1 Document information

## 1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


## 1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

## 1.3 Using this document

### 1.3.1 Information on the document structure


This document lists the submenus and their parameters according to the structure of the **Expert** menu (→ 8) menu that are available once the "**Operator**" user role or the "**Maintenance**" user role is enabled.



A0022576-EN

1 *Sample graphic*

For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→ 112), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

### 1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

| Complete parameter name       | Write-protected parameter =   |
|-------------------------------|--|
| <b>Navigation</b>             |  Navigation path to the parameter via the local display (direct access code)<br> Navigation path to the parameter via the operating tool<br>The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool. |
| <b>Prerequisite</b>           | The parameter is only available under these specific conditions  |
| <b>Description</b>            | Description of the parameter function  |
| <b>Selection</b>              | List of the individual options for the parameter <ul style="list-style-type: none"> <li>▪ Option 1</li> <li>▪ Option 2</li> </ul>  |
| <b>User entry</b>             | Input range for the parameter  |
| <b>User interface</b>         | Display value/data for the parameter   |
| <b>Factory setting</b>        | Default setting ex works   |
| <b>Additional information</b> | Additional explanations (e.g. in examples): <ul style="list-style-type: none"> <li>▪ On individual options</li> <li>▪ On display values/data</li> <li>▪ On the input range</li> <li>▪ On the factory setting</li> <li>▪ On the parameter function</li> </ul>   |

## 1.4 Symbols used

### 1.4.1 Symbols for certain types of information

| Symbol  | Meaning   |
|---|---|
|  | <b>Tip</b><br>Indicates additional information. |
|  | Reference to documentation                      |
|  | Reference to page                               |
|  | Reference to graphic                            |
|  | Operation via local display                     |
|  | Operation via operating tool                    |
|  | Write-protected parameter                       |

### 1.4.2 Symbols in graphics

| Symbol             | Meaning      | Symbol       | Meaning |
|--------------------|--------------|--------------|---------|
| 1, 2, 3 ...        | Item numbers | A, B, C, ... | Views   |
| A-A, B-B, C-C, ... | Sections     |              |         |

## 2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

|                                 |                      |
|---------------------------------|----------------------|
| » Expert                        |                      |
| Direct access (0106)            | → <a href="#">10</a> |
| Locking status (0004)           | → <a href="#">11</a> |
| Access status display (0091)    | → <a href="#">11</a> |
| Enter access code (0092)        | → <a href="#">13</a> |
| ▶ System                        | → <a href="#">13</a> |
| ▶ Display                       | → <a href="#">13</a> |
| ▶ Configuration backup display  | → <a href="#">26</a> |
| ▶ Diagnostic handling           | → <a href="#">29</a> |
| ▶ Administration                | → <a href="#">34</a> |
| ▶ Sensor                        | → <a href="#">39</a> |
| ▶ Measured values               | → <a href="#">39</a> |
| ▶ System units                  | → <a href="#">45</a> |
| ▶ Process parameters            | → <a href="#">54</a> |
| ▶ Sensor adjustment             | → <a href="#">57</a> |
| ▶ Calibration                   | → <a href="#">71</a> |
| ▶ Input                         | → <a href="#">71</a> |
| ▶ Status input                  | → <a href="#">72</a> |
| ▶ Output                        | → <a href="#">73</a> |
| ▶ Current output                | → <a href="#">73</a> |
| ▶ Pulse/frequency/switch output | → <a href="#">81</a> |

|                                    |       |
|------------------------------------|-------|
| ▶ Communication                    | → 98  |
| ▶ HART output                      | → 99  |
| ▶ Application                      | → 108 |
| ▶ Totalizer                        | → 108 |
| ▶ CIP/SIP                          | → 111 |
| ▶ Diagnostics                      | → 112 |
| Actual diagnostics (0691)          | → 112 |
| Previous diagnostics (0690)        | → 113 |
| Operating time from restart (0653) | → 114 |
| Operating time (0652)              | → 114 |
| ▶ Diagnostic list                  | → 115 |
| ▶ Event logbook                    | → 119 |
| ▶ Device information               | → 121 |
| ▶ Data logging                     | → 125 |
| ▶ Min/max values                   | → 131 |
| ▶ Simulation                       | → 133 |

### 3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

|                              |        |
|------------------------------|--------|
| <b>Expert</b>                |        |
| Direct access (0106)         | →  10  |
| Locking status (0004)        | →  11  |
| Access status display (0091) | →  11  |
| Enter access code (0092)     | →  13  |
| ▶ System                     | →  13  |
| ▶ Sensor                     | →  39  |
| ▶ Input                      | →  71  |
| ▶ Output                     | →  73  |
| ▶ Communication              | →  98  |
| ▶ Application                | →  108 |
| ▶ Diagnostics                | →  112 |

---

#### Direct access



##### Navigation

Expert → Direct access (0106)

##### Description

Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears in the navigation view on the right in the header of the selected parameter.

##### User entry

0 to 65 535

**Additional information***User entry*

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1



- The leading zeros in the direct access code do not have to be entered.  
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.  
Example: Enter 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.  
Example: Enter 0914-3 → **Assign process variable** parameter

**Locking status****Navigation**

Expert → Locking status (0004)

**Description**

Use this function to view the active write protection.

**User interface**

- Hardware locked
- Temporarily locked

**Additional information***User interface*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display.

In the operating tool all active types of write protection are selected.



If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→ 11).

*"Hardware locked" option (priority 1)*

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).



Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

*"Temporarily locked" option (priority 2)*

Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

**Access status display****Navigation**

Expert → Access stat.disp (0091)

**Prerequisite**

A local display is provided.

**Description**

Use this function to view the access authorization to the parameters via the local display.

|                        |   |
|------------------------|---|
| User interface         | <ul style="list-style-type: none"><li>▪ Operator</li><li>▪ Maintenance</li></ul>  |
| Factory setting        | Operator  |
| Additional information | <p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the <b>Enter access code</b> parameter (→  13).</p> <p> For information on the <b>Enter access code</b> parameter (→  13), see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the <b>Locking status</b> parameter (→  11).</p> |

---

## Access status tooling

---

|                 |  |
|-----------------|--|
| Navigation      |  Expert → Access stat.tool (0005) |
| Description     | Use this function to view the access authorization to the parameters via the operating tool.                         |
| User interface  | <ul style="list-style-type: none"><li>▪ Operator</li><li>▪ Maintenance</li></ul>                                     |
| Factory setting | Maintenance  |

**Additional information**

*Description*

 The access authorization can be modified via the **Enter access code** parameter (→  13).

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→  11).

*Display*

 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

**Enter access code**


|                    |  |
|--------------------|--|
| <b>Navigation</b>  | Expert → Ent. access code (0092)   |
| <b>Description</b> | Use this function to enter the user-specific release code to remove parameter write protection on the local display. |
| <b>User entry</b>  | 0 to 9 999   |

**Enter access code**

|                    |   |
|--------------------|---|
| <b>Navigation</b>  | Expert → Ent. access code (0003)  |
| <b>Description</b> | Use this function to enter the user-specific release code to remove parameter write protection in the operating tool. |
| <b>User entry</b>  | 0 to 9 999  |


### 3.1 "System" submenu

*Navigation* Expert → System



#### 3.1.1 "Display" submenu

*Navigation* Expert → System → Display



|                              |       |
|------------------------------|-------|
| 0% bargraph value 1 (0123)   | →  17 |
| 100% bargraph value 1 (0125) | →  18 |
| Decimal places 1 (0095)      | →  18 |
| Value 2 display (0108)       | →  18 |
| Decimal places 2 (0117)      | →  19 |
| Value 3 display (0110)       | →  19 |
| 0% bargraph value 3 (0124)   | →  20 |
| 100% bargraph value 3 (0126) | →  20 |
| Decimal places 3 (0118)      | →  21 |
| Value 4 display (0109)       | →  21 |
| Decimal places 4 (0119)      | →  22 |
| Display interval (0096)      | →  22 |
| Display damping (0094)       | →  23 |
| Header (0097)                | →  23 |
| Header text (0112)           | →  24 |
| Separator (0101)             | →  24 |
| Contrast display (0105)      | →  25 |
| Backlight (0111)             | →  25 |
| Access status display (0091) | →  25 |

---

## Language

---

**Navigation**

Expert → System → Display → Language (0104)

**Prerequisite**

A local display is provided.

**Description**

Use this function to select the configured language on the local display.

**Selection**

- English \*
- Deutsch \*
- Français \*
- Español \*
- Italiano
- Nederlands \*
- Portuguesa \*
- Polski \*
- русский язык (Russian) \*
- Svenska \*
- Türkçe \*
- 中文 (Chinese) \*
- 日本語 (Japanese) \*
- 한국어 (Korean) \*
- العربية (Arabic) \*
- Bahasa Indonesia \*
- ภาษาไทย (Thai) \*
- tiếng Việt (Vietnamese) \*
- čeština (Czech) \*

**Factory setting**

English (alternatively, the ordered language is preset in the device)

**Format display****Navigation**

 Expert → System → Display → Format display (0098)

**Prerequisite**

A local display is provided.

**Description**

Use this function to select how the measured value is shown on the local display.

**Selection**

- 1 value, max. size
- 1 bargraph + 1 value
- 2 values
- 1 value large + 2 values
- 4 values

**Factory setting**

1 value, max. size

**Additional information***Description*

The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.



- The **Value 1 display** parameter (→  17) to **Value 4 display** parameter (→  21) are used to specify which measured values are shown on the local display and in what order.
- If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the **Display interval** parameter (→  22).

\* Visibility depends on order options or device settings


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option



A0016530


"2 values" option



A0016531


3

"1 value large + 2 values" option



A0016532

"4 values" option



A0016533

---

**Value 1 display**

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             | Expert → System → Display → Value 1 display (0107)  |
| <b>Prerequisite</b>           | A local display is provided.  |
| <b>Description</b>            | Use this function to select one of the measured values to be shown on the local display.  |
| <b>Selection</b>              | <ul style="list-style-type: none"><li>■ Volume flow</li><li>■ Mass flow</li><li>■ Temperature</li><li>■ Totalizer 1</li><li>■ Current output</li></ul>  |
| <b>Factory setting</b>        | Volume flow   |
| <b>Additional information</b> | <p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The <b>Format display</b> parameter (→  15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the <b>System units</b> submenu (→  45).</p> |

---

**0% bargraph value 1**

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             | Expert → System → Display → 0% bargraph 1 (0123)   |
| <b>Prerequisite</b>           | A local display is provided.   |
| <b>Description</b>            | Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.   |
| <b>User entry</b>             | Signed floating-point number   |
| <b>Factory setting</b>        | Country-specific: <ul style="list-style-type: none"><li>■ 0 l/h</li><li>■ 0 gal/min (us)</li></ul>   |
| <b>Additional information</b> | <p><i>Description</i></p> <p> The <b>Format display</b> parameter (→  15) is used to specify that the measured value is to be displayed as a bar graph.</p> <p><i>User entry</i></p> <p> The unit of the displayed measured value is taken from the <b>System units</b> submenu (→  45).</p> |

## 100% bargraph value 1



### Navigation

Expert → System → Display → 100% bargraph 1 (0125)

### Prerequisite

A local display is provided.

### Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

### User entry

Signed floating-point number

### Factory setting

Depends on country and nominal diameter → 140

### Additional information

#### Description

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

#### User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

## Decimal places 1



### Navigation

Expert → System → Display → Decimal places 1 (0095)

### Prerequisite

A measured value is specified in the **Value 1 display** parameter (→ 17).

### Description

Use this function to select the number of decimal places for measured value 1.

### Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

### Factory setting

X.XX

### Additional information

#### Description

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

## Value 2 display



### Navigation

Expert → System → Display → Value 2 display (0108)

### Prerequisite

A local display is provided.

|                               |  |
|-------------------------------|--|
| <b>Description</b>            | Use this function to select one of the measured values to be shown on the local display.   |
| <b>Selection</b>              | For the picklist, see the <b>Value 1 display</b> parameter (→ 17)  |
| <b>Factory setting</b>        | None   |
| <b>Additional information</b> | <p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.</p> <p> The <b>Format display</b> parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the <b>System units</b> submenu (→ 45).</p> |

## Decimal places 2



|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |  Expert → System → Display → Decimal places 2 (0117)   |
| <b>Prerequisite</b>           | A measured value is specified in the <b>Value 2 display</b> parameter (→ 18).   |
| <b>Description</b>            | Use this function to select the number of decimal places for measured value 2.  |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li><input type="checkbox"/> X</li> <li><input type="checkbox"/> X.X</li> <li><input type="checkbox"/> X.XX</li> <li><input type="checkbox"/> X.XXX</li> <li><input type="checkbox"/> X.XXXX</li> </ul>  |
| <b>Factory setting</b>        | x.xx  |
| <b>Additional information</b> | <p><i>Description</i></p> <p> This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.</p> |

## Value 3 display



|                        |  |
|------------------------|--|
| <b>Navigation</b>      |  Expert → System → Display → Value 3 display (0110) |
| <b>Prerequisite</b>    | A local display is provided.   |
| <b>Description</b>     | Use this function to select one of the measured values to be shown on the local display.   |
| <b>Selection</b>       | Picklist, see <b>Value 1 display</b> parameter (→ 17)  |
| <b>Factory setting</b> | None   |

**Additional information***Description*

If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

*Selection*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

**0% bargraph value 3****Navigation**

  Expert → System → Display → 0% bargraph 3 (0124)

**Prerequisite**

A selection has been made in the **Value 3 display** parameter (→ 19).

**Description**

Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.

**User entry**

Signed floating-point number

**Factory setting**

Country-specific:

- 0 l/h
- 0 gal/min (us)

**Additional information***Description*

 The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

*User entry*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

**100% bargraph value 3****Navigation**

  Expert → System → Display → 100% bargraph 3 (0126)

**Prerequisite**

A selection was made in the **Value 3 display** parameter (→ 19).

**Description**

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

**User entry**

Signed floating-point number

**Factory setting**

0

**Additional information***Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

---

**Decimal places 3****Navigation**

Expert → System → Display → Decimal places 3 (0118)

**Prerequisite**

A measured value is specified in the **Value 3 display** parameter (→ 19).

**Description**

Use this function to select the number of decimal places for measured value 3.

**Selection**

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

**Factory setting**

X.XX

**Additional information***Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

---

**Value 4 display****Navigation**

Expert → System → Display → Value 4 display (0109)

**Prerequisite**

A local display is provided.

**Description**

Use this function to select one of the measured values to be shown on the local display.

**Selection**

Picklist, see **Value 1 display** parameter (→ 17)

**Factory setting**

None

**Additional information***Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

 The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

*Selection*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

---

**Decimal places 4****Navigation**

 Expert → System → Display → Decimal places 4 (0119)

**Prerequisite**

A measured value is specified in the **Value 4 display** parameter (→ 21).

**Description**

Use this function to select the number of decimal places for measured value 4.

**Selection**

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

**Factory setting**

X.XX

**Additional information***Description*

 This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

---

**Display interval****Navigation**

 Expert → System → Display → Display interval (0096)

**Prerequisite**

A local display is provided.

**Description**

Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

**User entry**

1 to 10 s

**Factory setting**

5 s

**Additional information***Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.



- The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display.
- The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

**Display damping****Navigation**

Expert → System → Display → Display damping (0094)

**Prerequisite**

A local display is provided.

**Description**

Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.

**User entry**

0.0 to 999.9 s

**Factory setting**

0.0 s

**Additional information***User entry*

A time constant is entered:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

**Header****Navigation**

Expert → System → Display → Header (0097)

**Prerequisite**

A local display is provided.

**Description**

Use this function to select the contents of the header of the local display.

**Selection**


- Device tag
- Free text

**Factory setting**

Device tag

**Additional information***Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

#### Selection

- Device tag  
Is defined in the **Device tag** parameter (→ 122).
- Free text  
Is defined in the **Header text** parameter (→ 24).

## Header text



### Navigation

Expert → System → Display → Header text (0112)

### Prerequisite

The **Free text** option is selected in the **Header** parameter (→ 23).

### Description

Use this function to enter a customer-specific text for the header of the local display.

### User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)


### Factory setting

-----

### Additional information

#### Description

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

#### User entry

The number of characters displayed depends on the characters used.

## Separator



### Navigation

Expert → System → Display → Separator (0101)

### Prerequisite

A local display is provided.

**Description** Use this function to select the decimal separator.

**Selection**

- . (point)
- , (comma)

**Factory setting** . (point)

## Contrast display

**Navigation**  Expert → System → Display → Contrast display (0105)

**Prerequisite** A local display is provided.

**Description** Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

**User entry** 20 to 50 %

**Factory setting** Depends on the display

**Additional information** Set the contrast via the push-buttons:

- Brighter: Press and hold down the   keys simultaneously.
- Darker: Press and hold down the   keys simultaneously.

## Backlight

**Navigation**  Expert → System → Display → Backlight (0111)

**Prerequisite** Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"

**Description** Use this function to switch the backlight of the local display on and off.

**Selection**

- Disabled
- Enabled

**Factory setting** Disabled

## Access status display

**Navigation**  Expert → System → Display → Access stat.disp (0091)

**Prerequisite** A local display is provided.

**Description** Displays the access authorization to the parameters via the local display.

|                        |  |
|------------------------|--|
| User interface         | <ul style="list-style-type: none"> <li>▪ Operator</li> <li>▪ Maintenance</li> </ul>  |
| Factory setting        | Operator   |
| Additional information | <p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> The access authorization can be modified via the <b>Enter access code</b> parameter (→ <a href="#">13</a>).</p> <p> For information on the <b>Enter access code</b> parameter (→ <a href="#">13</a>), see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the <b>Locking status</b> parameter (→ <a href="#">11</a>).</p> <p><i>Display</i></p> <p> Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.</p> |

### 3.1.2 "Configuration backup display" submenu

Navigation

 Expert → System → Conf.backup disp

|  Configuration backup display |                      |
|--|----------------------|
| Operating time (0652)  | → <a href="#">26</a> |
| Last backup (0102)   | → <a href="#">27</a> |
| Configuration management (0100)  | → <a href="#">27</a> |
| Comparison result (0103)   | → <a href="#">28</a> |

---

#### Operating time

---

Navigation

 Expert → System → Conf.backup disp → Operating time (0652)

Description

Use this function to display the length of time the device has been in operation.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information

*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

**Last backup**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |  Expert → System → Conf.backup disp → Last backup (0102) |
| <b>Prerequisite</b>   | A local display is provided.  |
| <b>Description</b>    | Use this function to display the time since a backup copy of the data was last saved to the display module.                               |
| <b>User interface</b> | Days (d), hours (h), minutes (m) and seconds (s)  |

**Configuration management**

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |  Expert → System → Conf.backup disp → Config. managem. (0100)  |
| <b>Prerequisite</b>           | A local display is provided.  |
| <b>Description</b>            | Use this function to select an action to save the data to the display module.   |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li>■ Cancel</li> <li>■ Execute backup</li> <li>■ Restore</li> <li>■ Duplicate</li> <li>■ Compare</li> <li>■ Clear backup data</li> </ul>  |
| <b>Factory setting</b>        | Cancel  |
| <b>Additional information</b> | <p><i>Description</i></p> <p>Configuration via the local display is disabled while the action is performed.</p> <p> For information on the status message in the operating tool, see: <b>Backup state</b> parameter (→  28)</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> <li>■ Cancel           <p>No action is executed and the user exits the parameter.</p> </li> <li>■ Execute backup           <ul style="list-style-type: none"> <li>– A backup copy of the current device configuration in the HistoROM is saved to the display module of the device. The backup copy includes the transmitter data of the device.</li> <li>– The following message appears on local display: Backup active, please wait!</li> </ul> </li> <li>■ Restore           <ul style="list-style-type: none"> <li>– The last backup copy of the device configuration is copied from the display module to the HistoROM of the device. The backup copy comprises the transmitter data of the device.</li> <li>– The following message appears on local display: Restore active! Do not interrupt power supply!</li> </ul> </li> </ul> |

- Duplicate
  - The transmitter configuration from another device is duplicated to the device using the display module.
  - The following message appears on local display: Copy active! Do not interrupt power supply!
- Compare
  - The device configuration saved in the display module is compared to the current device configuration of the HistoROM.
  - The following message appears on local display: Comparing files
  - The result can be viewed in **Comparison result** parameter (→ 28).
- Clear backup data
  - The backup copy of the device configuration is deleted from the display module of the device.
  - The following message appears on local display: Deleting file

#### *HistoROM*

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

---

### **Backup state**

---

|                        |  |
|------------------------|--|
| <b>Navigation</b>      |  Expert → System → Conf.backup disp → Backup state (0121)  |
| <b>Prerequisite</b>    | A local display is provided.   |
| <b>Description</b>     | Use this function to view the status of the data backup process.   |
| <b>User interface</b>  | <ul style="list-style-type: none"><li>■ None</li><li>■ Store in progress</li><li>■ Restore in progress</li><li>■ Import in progress</li><li>■ Delete in progress</li><li>■ Compare in progress</li></ul> |
| <b>Factory setting</b> | None   |

---

### **Comparison result**

---

|                       |  |
|-----------------------|--|
| <b>Navigation</b>     |   Expert → System → Conf.backup disp → Compar. result (0103) |
| <b>Prerequisite</b>   | A local display is provided.   |
| <b>Description</b>    | Use this function to view the last result of comparing the current device configuration to the backup copy in the display module.  |
| <b>User interface</b> | <ul style="list-style-type: none"><li>■ Settings identical</li><li>■ Settings not identical</li><li>■ No backup available</li><li>■ Backup settings corrupt</li><li>■ Check not done</li><li>■ Dataset incompatible</li></ul>      |

**Factory setting** Check not done

**Additional information** *Description*

 The comparison is started via the **Compare** option in the **Configuration management** parameter (→ 27).

*Selection*

- Settings identical
  - The current device configuration of the HistoROM is identical to the backup copy in the display module.
  - If the transmitter configuration of another device has been copied to the device via the display module and the **Duplicate** option in the **Configuration management** parameter (→ 27), the current device configuration of the HistoROM only partly matches the backup copy in the display module: The settings for the transmitter are not identical.
- Settings not identical
 

The current device configuration of the HistoROM is not identical to the backup copy in the display module.
- No backup available
 

There is no backup copy of the device configuration of the HistoROM in the display module.
- Backup settings corrupt
 

The current device configuration of the HistoROM is corrupt or not compatible with the backup copy in the display module.
- Check not done
 

The device configuration of the HistoROM has not yet been compared to the backup copy in the display module.
- Dataset incompatible
 

The backup copy in the display module is not compatible with the device.

*HistoROM*

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

### 3.1.3 "Diagnostic handling" submenu

*Navigation*

 Expert → System → Diagn. handling

|   |      |                    |      |                              |      |
|---|------|--------------------|------|------------------------------|------|
| <b>► Diagnostic handling</b>  |      |                    |      |                              |      |
| <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 5px; width: 80%;">Alarm delay (0651)</td> <td style="width: 20%; text-align: right; padding: 5px;">→ 30</td> </tr> <tr> <td style="padding: 5px;"><b>► Diagnostic behavior</b></td> <td style="text-align: right; padding: 5px;">→ 30</td> </tr> </table> |      | Alarm delay (0651) | → 30 | <b>► Diagnostic behavior</b> | → 30 |
| Alarm delay (0651)  | → 30 |                    |      |                              |      |
| <b>► Diagnostic behavior</b>  | → 30 |                    |      |                              |      |

**Alarm delay****Navigation**

Expert → System → Diagn. handling → Alarm delay (0651)

**Description**

Use this function to enter the time interval until the device generates a diagnostic message.

The diagnostic message is reset without a time delay.

**User entry**

0 to 60 s

**Factory setting**

0 s

**Additional information****"Diagnostic behavior" submenu**

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ [30](#)).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

| Options            | Description  |
|--------------------|--|
| Alarm              | The device stops measurement. The signal outputs and totalizers assume the defined alarm condition. A diagnostic message is generated.   |
| Warning            | The device continues to measure. The signal outputs and totalizers are not affected. A diagnostic message is generated.  |
| Logbook entry only | The device continues to measure. The diagnostic message is displayed only in the <b>Event logbook</b> submenu (→ <a href="#">119</a> ) ( <b>Event list</b> submenu (→ <a href="#">120</a> )) and is not displayed in alternation with the operational display. |
| Off                | The diagnostic event is ignored, and no diagnostic message is generated or entered.  |



For a list of all the diagnostic events, see the Operating Instructions for the device.

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior

**Diagnostic behavior**

|   |                      |
|---|----------------------|
| Assign behavior of diagnostic no. 441<br>(0657) | → <a href="#">31</a> |
| Assign behavior of diagnostic no. 442<br>(0658) | → <a href="#">31</a> |
| Assign behavior of diagnostic no. 443<br>(0659) | → <a href="#">32</a> |

|   |       |
|---|-------|
| Assign behavior of diagnostic no. 832<br>(0675) | →  32 |
| Assign behavior of diagnostic no. 833<br>(0676) | →  32 |
| Assign behavior of diagnostic no. 834<br>(0677) | →  33 |
| Assign behavior of diagnostic no. 835<br>(0678) | →  33 |
| Assign behavior of diagnostic no. 862<br>(0679) | →  34 |

**Assign behavior of diagnostic no. 441 (Current output 1)**

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 441 (0657)   |
| <b>Description</b>            | Option for changing the diagnostic behavior of the diagnostic message <b>441 Current output 1</b> .                       |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li>■ Off</li> <li>■ Alarm</li> <li>■ Warning</li> <li>■ Logbook entry only</li> </ul> |
| <b>Factory setting</b>        | Warning   |
| <b>Additional information</b> | For a detailed description of the options available, see →  30  |

**Assign behavior of diagnostic no. 442 (Frequency output)**

|                        |   |
|------------------------|---|
| <b>Navigation</b>      | Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 442 (0658)   |
| <b>Prerequisite</b>    | The measuring device has a pulse/frequency/switch output.   |
| <b>Description</b>     | Option for changing the diagnostic behavior of the diagnostic message <b>442 Frequency output</b> .                       |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>■ Off</li> <li>■ Alarm</li> <li>■ Warning</li> <li>■ Logbook entry only</li> </ul> |
| <b>Factory setting</b> | Warning   |

**Additional information**

For a detailed description of the options available, see → 30

**Assign behavior of diagnostic no. 443 (Pulse output)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 443 (0659)

**Prerequisite**

The measuring device has a pulse/frequency/switch output.

**Description**Option for changing the diagnostic behavior of the diagnostic message **443 Pulse output**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

**Factory setting**

Warning

**Additional information**

For a detailed description of the options available, see → 30

**Assign behavior of diagnostic no. 832 (Electronic temperature too high)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832 (0675)

**Description**Option for changing the diagnostic behavior of the diagnostic message **832 Electronic temperature too high**.**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

**Factory setting**

Warning

**Additional information**

For a detailed description of the options available, see → 30

**Assign behavior of diagnostic no. 833 (Electronic temperature too low)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833 (0676)

**Description**Option for changing the diagnostic behavior of the diagnostic message **833 Electronic temperature too low**.

|                  |  |
|------------------|--|
| <b>Selection</b> | <ul style="list-style-type: none"><li>■ Off</li><li>■ Alarm</li><li>■ Warning</li><li>■ Logbook entry only</li></ul> |
|------------------|--|

|                        |         |
|------------------------|---------|
| <b>Factory setting</b> | Warning |
|------------------------|---------|

|                               |   |
|-------------------------------|---|
| <b>Additional information</b> |  For a detailed description of the options available, see → <a href="#">30</a> |
|-------------------------------|---|

---

#### Assign behavior of diagnostic no. 834 (Process temperature too high)



|                   |   |
|-------------------|---|
| <b>Navigation</b> |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834 (0677) |
|-------------------|---|

|                    |   |
|--------------------|---|
| <b>Description</b> | Option for changing the diagnostic behavior of the diagnostic message <b>834 Process temperature too high</b> . |
|--------------------|---|

|                  |  |
|------------------|--|
| <b>Selection</b> | <ul style="list-style-type: none"><li>■ Off</li><li>■ Alarm</li><li>■ Warning</li><li>■ Logbook entry only</li></ul> |
|------------------|--|

|                        |         |
|------------------------|---------|
| <b>Factory setting</b> | Warning |
|------------------------|---------|

|                               |   |
|-------------------------------|---|
| <b>Additional information</b> |  For a detailed description of the options available, see → <a href="#">30</a> |
|-------------------------------|---|

---

#### Assign behavior of diagnostic no. 835 (Process temperature too low)



|                   |   |
|-------------------|---|
| <b>Navigation</b> |   Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835 (0678) |
|-------------------|---|

|                    |  |
|--------------------|--|
| <b>Description</b> | Option for changing the diagnostic behavior of the diagnostic message <b>835 Process temperature too low</b> . |
|--------------------|--|

|                  |  |
|------------------|--|
| <b>Selection</b> | <ul style="list-style-type: none"><li>■ Off</li><li>■ Alarm</li><li>■ Warning</li><li>■ Logbook entry only</li></ul> |
|------------------|--|

|                        |         |
|------------------------|---------|
| <b>Factory setting</b> | Warning |
|------------------------|---------|

|                               |   |
|-------------------------------|---|
| <b>Additional information</b> |  For a detailed description of the options available, see → <a href="#">30</a> |
|-------------------------------|---|

**Assign behavior of diagnostic no. 862 (Empty pipe)****Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 862 (0679)

**Description**

Use this function to change the diagnostic behavior of the diagnostic message **862 Empty pipe**.

**Selection**

- Off
- Alarm
- Warning
- Logbook entry only

**Factory setting**

Off


**Additional information**

For a detailed description of the options available, see → [30](#)

### 3.1.4 "Administration" submenu

**Navigation**

Expert → System → Administration

**"Define access code" wizard**

The **Define access code** wizard (→ [34](#)) is only available when operating via the local display.

If operating via the operating tool, the **Define access code** parameter (→ [36](#)) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

**Navigation**

Expert → System → Administration → Def. access code

**► Define access code**

Define access code

→ 35

Confirm access code

→ 35

**Define access code****Navigation**

Expert → System → Administration → Def. access code → Def. access code

**Description**

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display.

**User entry** 0 to 9 999

**Factory setting** 0

**Additional information***Description*

The write protection affects all parameters in the document marked with the symbol.

On the local display, the symbol in front of a parameter indicates that the parameter is write-protected.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).

If you lose the access code, please contact your Endress+Hauser sales organization.

*User entry*

A message is displayed if the access code is not in the input range.

*Factory setting*

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

**Confirm access code****Navigation**

Expert → System → Administration → Def. access code → Confirm code

**Description**

Enter the defined release code a second time to confirm the release code.

**User entry** 0 to 9 999

---

|                 |   |
|-----------------|---|
| Factory setting | 0 |
|-----------------|---|

### Additional parameters in the "Administration" submenu

---

## Define access code



**Navigation** Expert → System → Administration → Def. access code

**Description** Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.

**User entry** 0 to 9 999

**Factory setting** 0

**Additional information** *Description*

The write protection affects all parameters in the document marked with the symbol.

Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).

If you lose the access code, please contact your Endress+Hauser sales organization.

*User entry*

A message is displayed if the access code is not in the input range.

*Factory setting*

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

---

## Device reset



**Navigation** Expert → System → Administration → Device reset (0000)

**Description** Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

**Selection**

- Cancel
- To factory defaults
- To delivery settings
- Restart device

**Factory setting** Cancel

**Additional information***"Cancel" option*

No action is executed and the user exits the parameter.

*"To factory defaults" option*

Every parameter is reset to its factory setting.

*"To delivery settings" option*

Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.

 This option is not visible if no customer-specific settings have been ordered.

*"Restart device" option*

The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

**Activate SW option****Navigation**

 Expert → System → Administration → Activate SW opt. (0029)

**Description**

Use this function to enter an activation code to enable an additional, ordered software option.

**User entry**

Max. 10-digit string consisting of numbers.

**Factory setting**

Depends on the software option ordered

**Additional information***Description*

If a measuring device was ordered with an additional software option, the activation code is programmed in the device at the factory.

*User entry*

 To activate a software option subsequently, please contact your Endress+Hauser sales organization.

**NOTE!**

**The activation code is linked to the serial number of the measuring device and varies according to the device and software option.**

If an incorrect or invalid code is entered, this results in the loss of software options that have already been activated.

- Before you enter a new activation code, make a note of the current activation code .
- Enter the new activation code provided by Endress+Hauser when the new software option was ordered.
- Once the activation code has been entered, check if the new software option is displayed in the **Software option overview** parameter (→  38).
- ↳ The new software option is active if it is displayed.
- ↳ If the new software option is not displayed or all software options have been deleted, the code entered was either incorrect or invalid.
- If the code entered is incorrect or invalid, enter the old activation code .

- Have your Endress+Hauser sales organization check the new activation code remembering to specify the serial number or ask for the code again.

*Example for a software option*

Order code for "Application package", option EA "Extended HistoROM"

 The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

---

## Software option overview

---

**Navigation**  Expert → System → Administration → SW option overv. (0015)

**Description** Displays all the software options that are enabled in the device.

**User interface**

- Extended HistoROM
- 4-20 mA HART output
- Pulse/frequency/switch output
- Status input

**Additional information** *Description*  
Displays all the options that are available if ordered by the customer.

*"Extended HistoROM" option*

Order code for "Application package", option EA "Extended HistoROM"

*"4-20 mA HART output" option*

Order code for "Output; input"

- Option A "4-20mA HART"
- Option B "4-20mA HART, pul./freq./switch output"
- Option Q "4-20mA HART, pul./freq./switch; status input"

*"Pulse/frequency/switch output" option*

Order code for "Output; input"

- Option B "4-20mA HART, pul./freq./switch output"
- Option K "Pulse/freq./switch output"
- Option Q "4-20mA HART, pul./freq./switch; status input"

*"Status input" option*

Order code for "Output; input", option Q "4-20mA HART, pul./freq./switch; status input"

---

## Reset write protection

---




**Navigation**  Expert → System → Administration → Res. write prot. (0019)

**Description** The functionality of this parameter is not available for the t-mass 150 measuring device.

## 3.2 "Sensor" submenu

*Navigation*


Expert → Sensor



### 3.2.1 "Measured values" submenu

*Navigation*


Expert → Sensor → Measured val.



#### "Process variables" submenu

*Navigation*

Expert → Sensor → Measured val. → Process variab.



---

## Volume flow

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Sensor → Measured val. → Process variab. → Volume flow (1850)   |
| <b>Prerequisite</b>           | The following conditions are met: <ul style="list-style-type: none"><li>▪ The <b>Enabled</b> option is selected in the <b>Operating mode</b> parameter (→ <a href="#">59</a>).</li><li>▪ The <b>Volume flow</b> option is selected in the <b>Flow reference in use</b> parameter (→ <a href="#">60</a>).</li></ul> |
| <b>Description</b>            | Displays the volume flow that is currently measured.   |
| <b>User interface</b>         | Signed floating-point number   |
| <b>Additional information</b> | <i>Dependency</i><br> The unit is taken from the <b>Volume flow unit</b> parameter (→ <a href="#">45</a> )  |

---

## Mass flow

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Sensor → Measured val. → Process variab. → Mass flow (1838)   |
| <b>Prerequisite</b>           | The following conditions are met: <ul style="list-style-type: none"><li>▪ The <b>Enabled</b> option is selected in the <b>Operating mode</b> parameter (→ <a href="#">59</a>).</li><li>▪ The <b>Mass flow</b> option is selected in the <b>Flow reference in use</b> parameter (→ <a href="#">60</a>).</li></ul> |
| <b>Description</b>            | Displays the mass flow that is currently measured.   |
| <b>User interface</b>         | Signed floating-point number   |
| <b>Additional information</b> | <i>Dependency</i><br> The unit is taken from the <b>Mass flow unit</b> parameter (→ <a href="#">48</a> )  |

---


## Temperature

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Sensor → Measured val. → Process variab. → Temperature (1853) |
| <b>Description</b>            | Displays the temperature currently measured.   |
| <b>User interface</b>         | Signed floating-point number   |
| <b>Additional information</b> | <i>Dependency</i><br> The unit is taken from the <b>Temperature unit</b> parameter (→ <a href="#">49</a> )  |

**"Totalizer" submenu***Navigation*

Expert → Sensor → Measured val. → Totalizer

**Totalizer value****Navigation**

Expert → Sensor → Measured val. → Totalizer → Totalizer val. (0911)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ [41 108](#)) of the **Totalizer** submenu:

- Volume flow
- Mass flow

**Description**

Displays the current totalizer reading.

**User interface**

Signed floating-point number

**Additional information***Description*

As it is only possible to display a maximum of 7 digits in the operating tool, the current counter value is the sum of the totalizer value and the overflow value from the **Totalizer overflow** parameter (→ [41 42](#)) if the display range is exceeded.

In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ [41 111](#)).

*User interface*

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [41 109](#)).

*Example*

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter:  $1968\,457 \text{ m}^3$
- Value in the **Totalizer overflow 1** parameter:  $1 \cdot 10^7$  (1 overflow) =  $10\,000\,000 \text{ [m}^3]$
- Current totalizer reading:  $11\,968\,457 \text{ m}^3$

**Totalizer overflow****Navigation**

Expert → Sensor → Measured val. → Totalizer → Tot. overflow (0910)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ 108) of the **Totalizer** submenu:

- Volume flow
- Mass flow

**Description**

Displays the current totalizer overflow.

**User interface**

Integer with sign

**Additional information***Description*

If the current totalizer reading has more than 7 digits, which is the maximum value range of the operating tool that can be displayed, the value above this range is output as an overflow. The current totalizer value is therefore the sum of the overflow value and the totalizer value from the **Totalizer value** parameter (→ 41)

*Display*

**i** The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 109).


*Example*

Calculation of the current totalizer reading when the value exceeds the 7-digit display range of the operating tool:

- Value in the **Totalizer value 1** parameter: 1968457 m<sup>3</sup>
- Value in the **Totalizer overflow 1** parameter: 2 · 10<sup>7</sup> (2 overflows) = 20 000 000 [m<sup>3</sup>]
- Current totalizer reading: 21 968 457 m<sup>3</sup>

**"Input values" submenu****Navigation**

Expert → Sensor → Measured val. → Input values

**Value status input****Navigation**

Expert → Sensor → Measured val. → Input values → Val. status inp. (1353)

**Prerequisite**

For the following order code:  
"Output; input", option Q "4-20mA HART, pul./freq./switch; status input"

**Description**

Displays the current input signal level.

**User interface**

- High
- Low

**"Output values" submenu***Navigation*

Diagram Expert → Sensor → Measured val. → Output values

| ► Output values         |                      |
|-------------------------|----------------------|
| Output current (0361)   | → <a href="#">43</a> |
| Pulse output (0456)     | → <a href="#">43</a> |
| Output frequency (0471) | → <a href="#">44</a> |
| Switch status (0461)    | → <a href="#">44</a> |

**Output current****Navigation**

Diagram Expert → Sensor → Measured val. → Output values → Output curr. (0361)

**Description**

Displays the actual calculated value of the output current.

**User interface**

3.59 to 22.5 mA

**Pulse output****Navigation**

Diagram Expert → Sensor → Measured val. → Output values → Pulse output (0456)

**Prerequisite**In the **Operating mode** parameter (→ [83](#)), the **Pulse** option is selected.**Description**


Displays the pulse frequency currently output.

**User interface**

Positive floating-point number

**Additional information***Description*

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ [85](#)) and **Pulse width** parameter (→ [85](#)) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

- 0 Non-conductive
- 1 Conductive
- NC Normally closed
- NO Normally opened

The output behavior can be reversed via the **Invert output signal** parameter (→ 98) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 86)) can be configured.

## Output frequency

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Measured val. → Output values → Output freq. (0471)                   |
| <b>Prerequisite</b>   | In the <b>Operating mode</b> parameter (→ 83), the <b>Frequency</b> option is selected. |
| <b>Description</b>    | Displays the actual value of the output frequency which is currently measured.          |
| <b>User interface</b> | 0.0 to 1 250.0 Hz   |

## Switch status

|                       |  |
|-----------------------|--|
| <b>Navigation</b>     | Expert → Sensor → Measured val. → Output values → Switch status (0461)               |
| <b>Prerequisite</b>   | In the <b>Operating mode</b> parameter (→ 83), the <b>Switch</b> option is selected. |
| <b>Description</b>    | Displays the current switch status of the status output.                             |
| <b>User interface</b> | <ul style="list-style-type: none"> <li>■ Open</li> <li>■ Closed</li> </ul>           |

**Additional information***Selection*

- Open  
The switch output is not conductive.
- Closed  
The switch output is conductive.

### 3.2.2 "System units" submenu

*Navigation* Expert → Sensor → System units

|                              |  |
|------------------------------|--|
| <b>► System units</b>        |  |
| Volume flow unit (0553)      | →  45   |
| Volume unit (0563)           | →  47   |
| Mass flow unit (0554)        | →  48   |
| Mass unit (0574)             | →  48  |
| Density unit (0555)          | →  49 |
| Temperature unit (0557)      | →  49 |
| Length unit (0551)           | →  50 |
| <b>► User-specific units</b> | →  51 |

---

**Volume flow unit***Navigation* Expert → Sensor → System units → Volume flow unit (0553)**Description**

Use this function to select the unit for the volume flow.

**Selection**

- | <i>SI units</i>        | <i>US units</i>        | <i>Imperial units</i> |
|------------------------|------------------------|-----------------------|
| ■ dm <sup>3</sup> /s   | ■ ft <sup>3</sup> /s   | ■ gal/s (imp)         |
| ■ dm <sup>3</sup> /min | ■ ft <sup>3</sup> /min | ■ gal/min (imp)       |
| ■ dm <sup>3</sup> /h   | ■ ft <sup>3</sup> /h   | ■ gal/h (imp)         |
| ■ dm <sup>3</sup> /d   | ■ ft <sup>3</sup> /d   | ■ gal/d (imp)         |
| ■ m <sup>3</sup> /s    | ■ gal/s (us)           | ■ Mgal/s (imp)        |
| ■ m <sup>3</sup> /min  | ■ gal/min (us)         | ■ Mgal/min (imp)      |
| ■ m <sup>3</sup> /h    | ■ gal/h (us)           | ■ Mgal/h (imp)        |
| ■ m <sup>3</sup> /d    | ■ gal/d (us)           | ■ Mgal/d (imp)        |
| ■ l/s                  | ■ fl oz/s (us)         | ■ bbl/s (imp;oil)     |
| ■ l/min                | ■ fl oz/min (us)       | ■ bbl/min (imp;oil)   |
| ■ l/h                  | ■ fl oz/h (us)         | ■ bbl/h (imp;oil)     |
| ■ l/d                  | ■ fl oz/d (us)         | ■ bbl/d (imp;oil)     |
| ■ hl/s                 | ■ af/s                 |                       |
| ■ hl/min               | ■ af/min               |                       |
| ■ hl/h                 | ■ af/h                 |                       |
| ■ hl/d                 | ■ af/d                 |                       |
| ■ cm <sup>3</sup> /s   | ■ kgal/s (us)          |                       |
| ■ cm <sup>3</sup> /min | ■ kgal/min (us)        |                       |
| ■ cm <sup>3</sup> /h   | ■ kgal/h (us)          |                       |
| ■ cm <sup>3</sup> /d   | ■ kgal/d (us)          |                       |
| ■ ml/s                 | ■ Mgal/s (us)          |                       |
| ■ ml/min               | ■ Mgal/min (us)        |                       |
| ■ ml/h                 | ■ Mgal/h (us)          |                       |
| ■ ml/d                 | ■ Mgal/d (us)          |                       |
| ■ Ml/s                 | ■ bbl/s (us;liq.)      |                       |
| ■ Ml/min               | ■ bbl/min (us;liq.)    |                       |
| ■ Ml/h                 | ■ bbl/h (us;liq.)      |                       |
| ■ Ml/d                 | ■ bbl/d (us;liq.)      |                       |
|                        | ■ bbl/s (us;beer)      |                       |
|                        | ■ bbl/min (us;beer)    |                       |
|                        | ■ bbl/h (us;beer)      |                       |
|                        | ■ bbl/d (us;beer)      |                       |
|                        | ■ bbl/s (us;tank)      |                       |
|                        | ■ bbl/min (us;tank)    |                       |
|                        | ■ bbl/h (us;tank)      |                       |
|                        | ■ bbl/d (us;tank)      |                       |
|                        | ■ bbl/s (us;oil)       |                       |
|                        | ■ bbl/min (us;oil)     |                       |
|                        | ■ bbl/h (us;oil)       |                       |
|                        | ■ bbl/d (us;oil)       |                       |

*Custom-specific units*

- User vol./s
- User vol./min
- User vol./h
- User vol./d

**Factory setting**

Country-specific:

- l/h
- gal/min (us)

**Additional information***Result*

The selected unit applies for:

- **Volume flow parameter**
- **Volume flow parameter** (→ 40)

*Selection*

For an explanation of the abbreviated units: → 143

*Customer-specific units*

The unit for the customer-specific volume is specified in the **User volume text** parameter (→ 51).

**Volume unit****Navigation**

Expert → Sensor → System units → Volume unit (0563)

**Description**

Use this function to select the unit for the volume.

**Selection***SI units*

- dm<sup>3</sup>
- m<sup>3</sup>
- l
- hl
- cm<sup>3</sup>
- ml
- Ml Mega

*US units*

- ft<sup>3</sup>
- gal (us)
- fl oz (us)
- af
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)
- bbl (us;oil)

*Imperial units*

- gal (imp)
- Mgal (imp)
- bbl (imp;oil)

*Custom-specific units*

User vol.

**Factory setting**

Country-specific:

- l
- gal (us)

**Additional information***Selection*

For an explanation of the abbreviated units: → 143

*Customer-specific units*

The unit for the customer-specific volume is specified in the **User volume text** parameter (→ 51).

**Mass flow unit****Navigation**

Expert → Sensor → System units → Mass flow unit (0554)

**Description**

Use this function to select the unit for the mass flow.

**Selection***SI units*

- g/s
- g/min
- g/h
- g/d
- kg/s
- kg/min
- kg/h
- kg/d
- t/s
- t/min
- t/h
- t/d

*US units*

- oz/s
- oz/min
- oz/h
- oz/d
- lb/s
- lb/min
- lb/h
- lb/d
- STon/s
- STon/min
- STon/h
- STon/d

*Imperial units*

- LTon/s
- LTon/min
- LTon/h
- LTon/d

*Custom-specific units*

- User mass/s
- User mass/min
- User mass/h
- User mass/d

**Factory setting**

Country-specific:

- kg/h
- lb/min

**Additional information***Result*

The selected unit applies for:

**Mass flow** parameter (→ 40)

*Selection*

For an explanation of the abbreviated units: → 143

*Customer-specific units*

The unit for the customer-specific mass is specified in the **User mass text** parameter (→ 52).

**Mass unit****Navigation**

Expert → Sensor → System units → Mass unit (0574)

**Description**

Use this function to select the unit for the mass.

| Selection                     | <i>SI units</i>   | <i>US units</i> | <i>Imperial units</i> |
|-------------------------------|---|-----------------|-----------------------|
|                               | ■ g   | ■ oz            | LTon                  |
|                               | ■ kg  | ■ lb            |                       |
|                               | ■ t   | ■ STon          |                       |
|                               |   |                 |                       |
|                               | <i>Custom-specific units</i>  |                 |                       |
|                               | User mass   |                 |                       |
| <b>Factory setting</b>        | Country-specific:   |                 |                       |
|                               | ■ kg  |                 |                       |
|                               | ■ lb  |                 |                       |
| <b>Additional information</b> | <i>Selection</i>  |                 |                       |
|                               |  For an explanation of the abbreviated units: → <a href="#">143</a>  |                 |                       |
|                               |   |                 |                       |
|                               | <i>Customer-specific units</i>  |                 |                       |
|                               |  The unit for the customer-specific mass is specified in the <b>User mass text</b> parameter<br>(→ <a href="#">52</a> ). |                 |                       |

---

## Density unit



**Navigation**  Expert → Sensor → System units → Density unit (0555)

**Description** Use this function to select the unit for the density.

| Selection | <i>SI units</i>      | <i>US units</i>    |
|-----------|----------------------|--------------------|
|           | ■ g/cm <sup>3</sup>  | lb/ft <sup>3</sup> |
|           | ■ kg/dm <sup>3</sup> |                    |
|           | ■ kg/l               |                    |
|           | ■ kg/m <sup>3</sup>  |                    |

| Factory setting | Country-specific:    |
|-----------------|----------------------|
|                 | ■ kg/m <sup>3</sup>  |
|                 | ■ lb/ft <sup>3</sup> |

**Additional information** *Selection*

 For an explanation of the abbreviated units: → [143](#)

---

## Temperature unit



**Navigation**  Expert → Sensor → System units → Temperature unit (0557)

**Description** Use this function to select the unit for the temperature.

| Selection | <i>SI units</i> | <i>US units</i> |
|-----------|-----------------|-----------------|
|           | ■ °C            | ■ °F            |
|           | ■ K             | ■ °R            |

|                               |  |
|-------------------------------|--|
| <b>Factory setting</b>        | Country-specific:<br>■ °C<br>■ °F  |
| <b>Additional information</b> | <i>Result</i><br><br>The selected unit applies for:<br>■ <b>Temperature</b> parameter (→ 40)<br>■ <b>Maximum value</b> parameter (→ 131)<br>■ <b>Minimum value</b> parameter (→ 131)<br>■ <b>Maximum value</b> parameter (→ 132)<br>■ <b>Minimum value</b> parameter (→ 132)<br><br><i>Selection</i><br> For an explanation of the abbreviated units: → 143 |

|                    |   |
|--------------------|---|
| <b>Length unit</b> |  |
|--------------------|---|

|                               |  |                 |                 |      |      |     |      |
|-------------------------------|--|-----------------|-----------------|------|------|-----|------|
| <b>Navigation</b>             |  Expert → Sensor → System units → Length unit (0551)  |                 |                 |      |      |     |      |
| <b>Description</b>            | Use this function to select the unit of length.  |                 |                 |      |      |     |      |
| <b>Selection</b>              | <table><tr><td><i>SI units</i></td><td><i>US units</i></td></tr><tr><td>■ mm</td><td>■ in</td></tr><tr><td>■ m</td><td>■ ft</td></tr></table>  | <i>SI units</i> | <i>US units</i> | ■ mm | ■ in | ■ m | ■ ft |
| <i>SI units</i>               | <i>US units</i>  |                 |                 |      |      |     |      |
| ■ mm                          | ■ in   |                 |                 |      |      |     |      |
| ■ m                           | ■ ft   |                 |                 |      |      |     |      |
| <b>Factory setting</b>        | Country-specific:<br>■ mm<br>■ in  |                 |                 |      |      |     |      |
| <b>Additional information</b> | <i>Effect</i><br><br>The selected unit applies for:<br>■ <b>Insertion depth</b> parameter (→ 58)<br>■ <b>Pipe inner diameter</b> parameter<br>■ <b>Mounting set height</b> parameter (→ 58)<br>■ <b>Pipe wall thickness</b> parameter (→ 57)<br><br><i>Selection</i><br> For an explanation of the abbreviated units: → 143 |                 |                 |      |      |     |      |

|                         |   |
|-------------------------|---|
| <b>Date/time format</b> |  |
|-------------------------|---|

|                    |  |
|--------------------|--|
| <b>Navigation</b>  |  Expert → Sensor → System units → Date/time format (2812) |
| <b>Description</b> | Use this function to select the desired time format for calibration history.   |

|                  |  |
|------------------|--|
| <b>Selection</b> | <ul style="list-style-type: none"> <li>■ dd.mm.yy hh:mm</li> <li>■ dd.mm.yy hh:mm am/pm</li> <li>■ mm/dd/yy hh:mm</li> <li>■ mm/dd/yy hh:mm am/pm</li> </ul> |
|------------------|--|

|                        |                |
|------------------------|----------------|
| <b>Factory setting</b> | dd.mm.yy hh:mm |
|------------------------|----------------|

|                               |                  |
|-------------------------------|------------------|
| <b>Additional information</b> | <i>Selection</i> |
|-------------------------------|------------------|

 For an explanation of the abbreviated units: → [143](#)

### "User-specific units" submenu

#### *Navigation*

 Expert → Sensor → System units → User-spec. units

|  User-specific units |                      |
|---|----------------------|
| User volume text (0567)   | → <a href="#">51</a> |
| User volume offset (0569)   | → <a href="#">52</a> |
| User volume factor (0568)   | → <a href="#">52</a> |
| User mass text (0560)   | → <a href="#">52</a> |
| User mass offset (0562)   | → <a href="#">53</a> |
| User mass factor (0561)   | → <a href="#">53</a> |

---

## User volume text



#### *Navigation*

 Expert → Sensor → System units → User-spec. units → Volume text (0567)

#### **Description**

Use this function to enter a text for the user-specific unit of volume and volume flow. The corresponding time units (s, min, h, d) for volume flow are generated automatically.

#### **User entry**

Max. 10 characters such as letters, numbers or special characters (@, %, /)

#### **Factory setting**

User vol.

**Additional information***Result*

The defined unit is shown as an option in the choose list of the following parameters:

- **Volume flow unit** parameter (→ 45)
- **Volume unit** parameter (→ 47)

*Example*

If the text GLAS is entered, the choose list of the **Volume flow unit** parameter (→ 45) shows the following options:

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

---

**User volume offset****Navigation**

Expert → Sensor → System units → User-spec. units → Volume offset (0569)

**Description**

Use this function to enter the offset for adapting the user-specific volume unit and volume flow unit (without time).

**User entry**

Signed floating-point number

**Factory setting**

0

**Additional information***Description*

Value in user-specific unit = (factor × value in base unit) + offset

---

**User volume factor****Navigation**

Expert → Sensor → System units → User-spec. units → Volume factor (0568)

**Description**

Use this function to enter a quantity factor (without time) for the user-specific volume and volume flow unit.

**User entry**

Signed floating-point number

**Factory setting**

1.0

---

**User mass text****Navigation**

Expert → Sensor → System units → User-spec. units → Mass text (0560)

**Description**

Use this function to enter a text for the user-specific unit of mass and mass flow. The corresponding time units (s, min, h, d) for mass flow are generated automatically.

**User entry** Max. 10 characters such as letters, numbers or special characters (@, %, /)

**Factory setting** User mass

**Additional information** *Result*

 The defined unit is shown as an option in the choose list of the following parameters:

- **Mass flow unit** parameter (→  48)
- **Mass unit** parameter (→  48)

*Example*

If the text GLAS is entered, the following options are displayed in the picklist for the **Mass flow unit** parameter (→  48):

- GLAS/s
- GLAS/min
- GLAS/h
- GLAS/d

## User mass offset



**Navigation**  Expert → Sensor → System units → User-spec. units → Mass offset (0562)

**Description** Use this function to enter the offset for adapting the user-specific mass unit and mass flow unit (without time).

**User entry** Signed floating-point number

**Factory setting** 0

**Additional information** *Description*

 Value in user-specific unit = (factor × value in base unit) + offset

## User mass factor



**Navigation**  Expert → Sensor → System units → User-spec. units → Mass factor (0561)

**Description** Use this function to enter a quantity factor (without time) for the user-specific mass and mass flow unit.


**User entry** Signed floating-point number

**Factory setting** 1.0

### 3.2.3 "Process parameters" submenu

#### Navigation

Expert → Sensor → Process param.



#### Flow override



##### Navigation

Expert → Sensor → Process param. → Flow override (1839)

##### Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

##### Selection

- Off
- On

##### Factory setting

Off

##### Additional information

###### Result

This setting affects all the functions and outputs of the measuring device.

###### Description

###### Flow override is active

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
  - Output: Value at zero flow
  - Temperature: proceeding output
  - Totalizers 1-3: Stop being totalized

#### Flow damping



##### Navigation

Expert → Sensor → Process param. → Flow damping (1802)

##### Description

Use this function to enter a time constant for flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

##### User entry

0 to 999.9 s

##### Factory setting

0 s

**Additional information***User entry*

- Value = 0: no damping
- Value > 0: damping is increased


*Result*

The damping affects the following variables of the device:

- Outputs → [73](#)
- Low flow cut off → [55](#)
- Totalizers → [108](#)

**"Low flow cut off" submenu***Navigation*

Expert → Sensor → Process param. → Low flow cut off

**Assign process variable****Navigation**

Expert → Sensor → Process param. → Low flow cut off → Assign variable (1837)

**Description**

Use this function to select the process variable for low flow cutoff detection.

**Selection**

- Off
- Volume flow
- Mass flow

**Factory setting**

Volume flow

**On value low flow cutoff****Navigation**

Expert → Sensor → Process param. → Low flow cut off → On value (1805)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter  
(→ [55](#)):

- Volume flow
- Mass flow

**Description** Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → 56.

**User entry** Signed floating-point number

**Factory setting** Depends on country and nominal diameter → 140

**Additional information** Dependency

**i** The unit depends on the process variable selected in the **Assign process variable** parameter (→ 55).

## Off value low flow cutoff



**Navigation** Expert → Sensor → Process param. → Low flow cut off → Off value (1804)

**Prerequisite** One of the following options is selected in the **Assign process variable** parameter (→ 55):  


- Volume flow
- Mass flow

**Description** Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → 55.

**User entry** 0 to 100.0 %

**Factory setting** 50 %

**Additional information** Example




A0012887

- |   |                                 |
|---|---------------------------------|
| Q | Flow                            |
| t | Time                            |
| H | Hysteresis                      |
| A | Low flow cut off active         |
| 1 | Low flow cut off is activated   |
| 2 | Low flow cut off is deactivated |
| 3 | On value entered                |
| 4 | Off value entered               |

### 3.2.4 "Sensor adjustment" submenu

*Navigation*


Expert → Sensor → Sensor adjustm.



#### "Installation settings" submenu

*Navigation*

Expert → Sensor → Sensor adjustm. → Install.settings




---

#### Installation factor



**Navigation**

Expert → Sensor → Sensor adjustm. → Install.settings → Install. factor (3470)

**Prerequisite**

The **Disabled** option is selected in the **Operating mode** parameter (→ 59) parameter.

**Description**

Use this function to enter the installation factor.

**User entry**

0 to 9 999

**Factory setting**

1

---

#### Pipe wall thickness



**Navigation**

Expert → Sensor → Sensor adjustm. → Install.settings → Wall thickness (3409)

**Prerequisite**

The sensor is an insert version.

**Description**

Use this function to enter the pipe wall thickness.

**User entry**

2 to 999.9 mm

**Factory setting** 4.5 mm

**Additional information** *Dependency*

 The unit is taken from the **Length unit** parameter (→ 50)

## Mounting set height



**Navigation**  Expert → Sensor → Sensor adjustm. → Install.settings → Mounting set ht. (3435)


**Prerequisite** The sensor is an insert version.

**Description** Use this function to enter the mounting set height.

**User entry** 0 to 999 mm

**Factory setting** 106 mm

**Additional information** *Description*



 For more detailed information on determining the mounting set height, please see the Operating Instructions for the device, section "Insertion depth"

*Dependency*

 The unit is taken from the **Length unit** parameter (→ 50)

## Insertion depth


**Navigation**  Expert → Sensor → Sensor adjustm. → Install.settings → Insertion depth (3406)

**Prerequisite** The sensor is an insert version.

|                               |   |
|-------------------------------|---|
| <b>Description</b>            | Displays the calculated insertion depth of the sensor.  |
| <b>User interface</b>         | 0 to 999 000 mm   |
| <b>Factory setting</b>        | 50 mm   |
| <b>Additional information</b> | <p><i>Description</i></p> <p>Fixed insertion depth 8 mm (0.31 in) ±2 mm (0.08 in)</p> <p> For more detailed information on determining the insertion depth, please see the Operating Instructions for the device, section "Insertion depth"</p> <p><i>Dependency</i></p> <p> The unit is taken from the <b>Length unit</b> parameter (→ 50)</p> |

### "In-situ adjustment" submenu

*Navigation*       Expert → Sensor → Sensor adjustm. → In-situ adjust.




---

## Operating mode



|                        |   |
|------------------------|---|
| <b>Navigation</b>      |  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Operating mode (3400) |
| <b>Description</b>     | Use this function to activate/deactivate in-situ adjustment.  |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>▪ Disabled</li> <li>▪ Enabled</li> </ul>   |
| <b>Factory setting</b> | Disabled  |

*"Adjustment values in use" submenu**Navigation*

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use

| ► Adjustment values in use |       |
|----------------------------|-------|
| Flow reference in use      | →  60 |
| Flow reference value 1     | →  61 |
| Power coefficient 1        | →  61 |
| Flow reference value 2     | →  61 |
| Power coefficient 2        | →  61 |
| Flow reference value 3     | →  62 |
| Power coefficient 3        | →  62 |
| Flow reference value 4     | →  62 |
| Power coefficient 4        | →  62 |
| Flow reference value 5     | →  62 |
| Power coefficient 5        | →  63 |
| Flow reference value 6     | →  63 |
| Power coefficient 6        | →  63 |
| Flow reference value 7     | →  63 |
| Power coefficient 7        | →  64 |
| Flow reference value 8     | →  64 |
| Power coefficient 8        | →  64 |

---

**Flow reference in use**

---

**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. in use (3440)

**Description**

Use this function to select the flow reference value used.

**User interface** ■ Volume flow  
■ Mass flow

**Factory setting** Volume flow

---

### Flow reference value 1

---

**Navigation** ☐ ☐ Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 1 (3401)

**Description** Displays the Flow reference value 1 (→ 61) defined for the adjustment.

**User interface** Signed floating-point number

---

### Power coefficient 1

---

**Navigation** ☐ ☐ Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 1 (3425)

**Description** Displays the Power coefficient 1 defined for the adjustment.

**User interface** Positive floating-point number

---

### Flow reference value 2

---

**Navigation** ☐ ☐ Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 2 (3418)

**Description** Displays the Flow reference value 2 defined for the adjustment.

**User interface** Signed floating-point number

---

### Power coefficient 2

---

**Navigation** ☐ ☐ Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 2 (3426)

**Description** Displays the Power coefficient 2 defined for the adjustment.

**User interface** Positive floating-point number

**Flow reference value 3**

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 3 (3419) |
| <b>Description</b>    | Displays the Flow reference value 3 defined for the adjustment.   |
| <b>User interface</b> | Signed floating-point number  |

---

**Power coefficient 3**

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 3 (3427) |
| <b>Description</b>    | Displays the Power coefficient 3 defined for the adjustment.  |
| <b>User interface</b> | Positive floating-point number  |

---

**Flow reference value 4**

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 4 (3420) |
| <b>Description</b>    | Displays the Flow reference value 4 defined for the adjustment.   |
| <b>User interface</b> | Signed floating-point number  |

---

**Power coefficient 4**

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 4 (3428) |
| <b>Description</b>    | Displays the Power coefficient 4 defined for the adjustment.  |
| <b>User interface</b> | Positive floating-point number  |

---

**Flow reference value 5**

---

|                    |   |
|--------------------|---|
| <b>Navigation</b>  |   Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 5 (3421) |
| <b>Description</b> | Displays the Flow reference value 5 defined for the adjustment.   |

---

|                |                              |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

---

### Power coefficient 5

---

|            |   |
|------------|---|
| Navigation |  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 5 (3429) |
|------------|---|

|             |  |
|-------------|--|
| Description | Displays the Power coefficient 5 defined for the adjustment. |
|-------------|--|

|                |                                |
|----------------|--------------------------------|
| User interface | Positive floating-point number |
|----------------|--------------------------------|

---

### Flow reference value 6

---

|            |   |
|------------|---|
| Navigation |  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 6 (3422) |
|------------|---|

|             |   |
|-------------|---|
| Description | Displays the Flow reference value 6 defined for the adjustment. |
|-------------|---|

|                |                              |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

---

### Power coefficient 6

---

|            |   |
|------------|---|
| Navigation |  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 6 (3430) |
|------------|---|

|             |  |
|-------------|--|
| Description | Displays the Power coefficient 6 defined for the adjustment. |
|-------------|--|

|                |                                |
|----------------|--------------------------------|
| User interface | Positive floating-point number |
|----------------|--------------------------------|

---

### Flow reference value 7

---

|            |   |
|------------|---|
| Navigation |  Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 7 (3423) |
|------------|---|

|             |   |
|-------------|---|
| Description | Displays the Flow reference value 7 defined for the adjustment. |
|-------------|---|

|                |                              |
|----------------|------------------------------|
| User interface | Signed floating-point number |
|----------------|------------------------------|

---

## Power coefficient 7

---

**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 7 (3431)

**Description**

Displays the Power coefficient 7 defined for the adjustment.

**User interface**

Positive floating-point number

---

## Flow reference value 8

---

**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Flow ref. val. 8 (3424)

**Description**

Displays the Flow reference value 8 defined for the adjustment.

**User interface**

Signed floating-point number

---

## Power coefficient 8

---

**Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → Values in use → Power coeff. 8 (3432)

**Description**


Displays the Power coefficient 8 defined for the adjustment.

**User interface**

Positive floating-point number

*"New adjustment" submenu*

**Navigation**      Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment



**Select flow reference**

|                        |   |
|------------------------|---|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Select flow ref. (3382)    |
| <b>Description</b>     | Use this function to select the process variable used as flow reference value for the adjustment. |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> </ul>              |
| <b>Factory setting</b> | Volume flow   |

*"Perform adjustment" submenu*

*Navigation*      Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust.

| <b>► Perform adjustment</b>   |       |
|-------------------------------|-------|
| Clear values (3529)           | →  66 |
| Flow reference value 1 (3384) | →  66 |
| Power coefficient 1 (3392)    | →  66 |
| Flow reference value 2 (3385) | →  67 |
| Power coefficient 2 (3393)    | →  67 |
| Flow reference value 3 (3386) | →  67 |
| Power coefficient 3 (3394)    | →  67 |
| Flow reference value 4 (3387) | →  68 |
| Power coefficient 4 (3395)    | →  68 |
| Flow reference value 5 (3388) | →  68 |
| Power coefficient 5 (3396)    | →  68 |
| Flow reference value 6 (3389) | →  69 |
| Power coefficient 6 (3397)    | →  69 |
| Flow reference value 7 (3390) | →  69 |

|                               |       |
|-------------------------------|-------|
| Power coefficient 7 (3398)    | →  69 |
| Flow reference value 8 (3391) | →  70 |
| Power coefficient 8 (3399)    | →  70 |

---

**Clear values**

**Navigation** Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Clear values (3529)

**Description** Use this function to delete the existing adjustment values.

**Selection**

- Cancel
- Clear values

**Factory setting** Cancel

---

**Flow reference value 1**

**Navigation** Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 1 (3384)

**Description** Use this function to enter a flow rate used as reference for flow point 1.

**User entry** Signed floating-point number

**Factory setting** 0 l/h

---

**Power coefficient 1**

**Navigation** Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 1 (3392)

**Description** Displays the automatically assigned power coefficient 1 which is directly proportional to the flow: heater power/measured temperature difference.

**User interface** Positive floating-point number

---

**Flow reference value 2**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 2 (3385) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 2.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

---

**Power coefficient 2**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 2 (3393)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 2 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

---

**Flow reference value 3**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 3 (3386) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 3.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

---

**Power coefficient 3**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 3 (3394)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 3 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

**Flow reference value 4**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 4 (3387) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 4.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

**Power coefficient 4**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 4 (3395)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 4 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

**Flow reference value 5**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 5 (3388) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 5.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

**Power coefficient 5**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 5 (3396)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 5 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

**Flow reference value 6**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 6 (3389) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 6.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

**Power coefficient 6**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 6 (3397)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 6 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

**Flow reference value 7**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 7 (3390) |
| <b>Description</b>     | Use this function to enter a flow rate used as reference for flow point 7.                                       |
| <b>User entry</b>      | Signed floating-point number   |
| <b>Factory setting</b> | 0 l/h  |

**Power coefficient 7**

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     | Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 7 (3398)                                    |
| <b>Description</b>    | Displays the automatically assigned power coefficient 7 which is directly proportional to the flow: heater power/measured temperature difference. |
| <b>User interface</b> | Positive floating-point number  |

**Flow reference value 8****Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Flow ref. val. 8 (3391)

**Description**

Use this function to enter a flow rate used as reference for flow point 8.

**User entry**

Signed floating-point number

**Factory setting**

0 l/h

**Power coefficient 8****Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Perform adjust. → Power coeff. 8 (3399)

**Description**

Displays the automatically assigned power coefficient 8 which is directly proportional to the flow: heater power/measured temperature difference.


**User interface**

Positive floating-point number

*"Use adjustment" submenu*

*Navigation*

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment

**Data validity****Navigation**

Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment → Data validity (3434)

**Description**

Displays whether the performed adjustment is usable.

**User interface**

- Ok
- Too few points
- Invalid pair of values
- Values too close
- Out of range

**Apply**

**Navigation**      Expert → Sensor → Sensor adjustm. → In-situ adjust. → New adjustment → Use adjustment → Apply (3528)

**Prerequisite**      In the **Data validity** parameter (→ 70) the **Ok** option is displayed.

**Description**      Use this function to select whether the new adjustment values are to be used.

**Selection**

- Cancel
- Ok

**Factory setting**      Cancel

### 3.2.5 "Calibration" submenu

*Navigation*

Expert → Sensor → Calibration

► Calibration

Calibration date/time (3436)

→ 71

---

**Calibration date/time**

**Navigation**      Expert → Sensor → Calibration → Cal date/time (3436)

**Description**      Displays the date of the last factory calibration of the measuring device.

**User interface**      Format: dd.mm.yyyy

**Additional information**      *Description*



The date remains unchanged in the case of onsite calibration.

### 3.3 "Input" submenu

*Navigation*

Expert → Input

► Input


► Status input

→ 72

### 3.3.1 "Status input" submenu

Navigation

Expert → Input → Status input



#### Assign status input



Navigation

Expert → Input → Status input → Assign stat.inp. (1352)

Description

Use this function to select the function for the status input.

Selection

- Off
- Reset totalizer 1
- Flow override
- CIP/SIP mode

Factory setting

Off

#### Value status input

Navigation

Expert → Input → Status input → Val. status inp. (1353)

Prerequisite

For the following order code:  
"Output; input", option Q "4-20mA HART, pul./freq./switch; status input"

Description

Displays the current input signal level.

User interface

- High
- Low

**Active level****Navigation**

Expert → Input → Status input → Active level (1351)

**Description**

Use this function to determine the input signal level at which the assigned function is activated.

**Selection**

- High
- Low

**Factory setting**

High

**Response time status input****Navigation**

Expert → Input → Status input → Response time (1354)

**Description**

Use this function to enter the minimum time period for which the input signal level must be present before the selected function is activated.

**User entry**

5 to 200 ms


**Factory setting**

50 ms

## 3.4 "Output" submenu

*Navigation*


Expert → Output



### 3.4.1 "Current output 1" submenu

*Navigation*

Expert → Output → Curr.output 1



|                         |       |
|-------------------------|-------|
| 4 mA value (0367)       | →  76 |
| 20 mA value (0372)      | →  77 |
| Damping output (0363)   | →  77 |
| Response time (0378)    | →  78 |
| Failure mode (0364)     | →  79 |
| Failure current (0352)  | →  80 |
| Output current (0361)   | →  80 |
| Start-up mode (0368)    | →  80 |
| Start-up current (0369) | →  81 |

**Assign current output****Navigation**

Expert → Output → Curr.output → Assign curr. (0359)

**Description**

Use this function to select a process variable for the current output.

**Selection**

- Volume flow
- Mass flow
- Temperature

**Factory setting**

Volume flow

**Current span****Navigation**

Expert → Output → Curr.output → Current span (0353)

**Description**

Use this function to select the current range for the process value output and the upper and lower level for signal on alarm.

**Selection**

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA
- Fixed current

**Factory setting**

Country-specific:

- 4...20 mA NAMUR
- 4...20 mA US

**Additional information***Description*


- In the event of a device alarm, the current output adopts the value specified in the **Failure mode** parameter (→ 79).
- If the measured value is outside the measuring range, the diagnostic message **△S441 Current output 1** is displayed.
- The measuring range is specified via the **4 mA value** parameter (→ 76) and **20 mA value** parameter (→ 77).

*"Fixed current" option*

The current value is set via the **Fixed current** parameter (→ 75).

*Example*

Shows the relationship between the current span for the output of the process variable and the lower and upper alarm levels:



A0013316

*I Current*

*1 Current span for process value*

*2 Lower level for signal on alarm*

*3 Upper level for signal on alarm*

*Selection*

| Selection       | 1                 | 2        | 3          |
|-----------------|-------------------|----------|------------|
| 4...20 mA NAMUR | 3.8 to 20.5 mA    | < 3.6 mA | > 21.95 mA |
| 4...20 mA US    | 3.9 to 20.8 mA US | < 3.6 mA | > 21.95 mA |
| 4...20 mA       | 4 to 20.5 mA      | < 3.6 mA | > 21.95 mA |



If the flow exceeds or falls below the upper or lower signal on alarm level, the diagnostic message **△S441 Current output 1** is displayed.

**Fixed current****Navigation**

Expert → Output → Curr.output → Fixed current (0365)

**Prerequisite**

In the **Current span** parameter (→ 74), the **Fixed current** option is selected.

**Description**

Use this function to enter a constant current value for the current output.

**User entry**

3.59 to 22.5 mA

**Factory setting**

4 mA

**Additional information***Example*

This setting can be used for HART multidrop, for example.

**4 mA value****Navigation**

Expert → Output → Curr.output → 4 mA value (0367)

**Prerequisite**

One of the following options is selected in the **Current span** parameter (→ 74):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

**Description**

Use this function to enter a value for the 4 mA current.

**User entry**

Signed floating-point number

**Factory setting**

0 1/h

**Additional information***Description*

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 74). In addition, the value can be greater than or smaller than the value assigned for the 20 mA current in the **20 mA value** parameter (→ 77).

*Dependency*

The unit depends on the process variable selected in the **Assign current output** parameter (→ 74).

*Current output behavior*

The current output behaves differently depending on the settings configured in the following parameters:

- Current span (→ 74)
- Failure mode (→ 79)


*Configuration examples*

A configuration example and its effect on the current output is explained in the following section.

**Configuration example**

In Forward flow

- **4 mA value** parameter (→ 76) = not equal to zero flow (e.g. -250 m<sup>3</sup>/h)
- **20 mA value** parameter (→ 77) = not equal to zero flow (e.g. +750 m<sup>3</sup>/h)
- Calculated current value = 8 mA at zero flow



A0013757

Q Flow

I Current

1 Measuring range is exceeded or undershot

The operational range of the measuring device is defined by the values entered for the **4 mA value** parameter (→ 76) and **20 mA value** parameter (→ 77). If the effective

flow exceeds or falls below this operational range, the diagnostic message **△S441 Current output 1** is displayed.

## 20 mA value



### Navigation

Expert → Output → Curr.output → 20 mA value (0372)

### Prerequisite

One of the following options is selected in the **Current span** parameter (→ 74):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

### Description

Use this function to enter a value for the 20 mA current.

### User entry

Signed floating-point number

### Factory setting

Depends on country and nominal diameter → 140

### Additional information

#### Description

Positive and negative values are permitted depending on the process variable assigned in the **Assign current output** parameter (→ 74). In addition, the value can be greater than or smaller than the value assigned for the 4 mA current in the **4 mA value** parameter (→ 76).

#### Dependency

The unit depends on the process variable selected in the **Assign current output** parameter (→ 74).

#### Example

- Value assigned to 4 mA = -250 m<sup>3</sup>/h
- Value assigned to 20 mA = +750 m<sup>3</sup>/h
- Calculated current value = 8 mA (at zero flow)

#### Configuration examples

Pay attention to the configuration examples for **4 mA value** parameter (→ 76).

## Damping output



### Navigation

Expert → Output → Curr.output → Damping out. (0363)

### Prerequisite

One of the following options is selected in the **Assign current output** parameter (→ 74):

- Volume flow
- Mass flow
- Temperature

One of the following options is selected in the **Current span** parameter (→ [74](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

**Description**

Use this function to enter the reaction time of the current output signal to fluctuations in the measured value caused by process conditions.

**User entry**

0.0 to 999.9 s

**Factory setting**

1.0 s

**Additional information**

*User entry*

Use this function to enter a time constant:

- If a low time constant is entered, the current output reacts particularly quickly to fluctuating measured variables.
- On the other hand, the current output reacts more slowly if a high time constant is entered.

---

**Response time**

---

**Navigation**

 Expert → Output → Curr.output → Response time (0378)

**Prerequisite**

One of the following options is selected in the **Assign current output** parameter (→ [74](#)):

- Volume flow
- Mass flow
- Temperature

One of the following options is selected in the **Current span** parameter (→ [74](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

**Description**

Displays the response time. This specifies how quickly the current output reaches the measured value change of 63 % of 100 % of the measured value change.

**User interface**

Positive floating-point number

**Additional information**

*Description*

 The response time is made up of the time specified for the following dampings:

- Current output damping → [77](#)  
and
- Depending on the measured variable assigned to the output.  
Flow damping

**Failure mode****Navigation**

Expert → Output → Curr.output → Failure mode (0364)

**Prerequisite**

One of the following options is selected in the **Assign current output** parameter (→ [74](#)):

- Volume flow
- Mass flow
- Temperature

One of the following options is selected in the **Current span** parameter (→ [74](#)):

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

**Description**

Use this function to select the value of the current output in the event of a device alarm.

**Selection**

- Min.
- Max.
- Last valid value
- Actual value
- Defined value

**Factory setting**

Max.

**Additional information***Description*

This setting does not affect the failsafe mode of other outputs and totalizers. This is specified in separate parameters.

*"Min." option*

The current output adopts the value of the lower level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ [74](#)).

*"Max." option*

The current output adopts the value of the upper level for signal on alarm.

The signal on alarm level is defined via the **Current span** parameter (→ [74](#)).

*"Last valid value" option*

The current output adopts the last measured value that was valid before the device alarm occurred.

*"Actual value" option*

The current output adopts the measured value on the basis of the current flow measurement; the device alarm is ignored.

*"Defined value" option*

The current output adopts a defined measured value.

The measured value is defined via the **Failure current** parameter (→ [80](#)).

**Failure current****Navigation**

Expert → Output → Curr.output → Failure current (0352)

**Prerequisite**

In the **Failure mode** parameter (→ 79), the **Defined value** option is selected.

**Description**

Use this function to enter a fixed value that the current output adopts in the event of a device alarm.

**User entry**

3.59 to 22.5 mA

**Factory setting**

22.5 mA

---

**Output current 1****Navigation**

Expert → Output → Curr.output 1 → Output curr. 1 (0361-1)

**Description**

Displays the current value currently calculated for the current output.

**User interface**

3.59 to 22.5 mA

---

**Start-up mode****Navigation**

Expert → Output → Curr.output → Start-up mode (0368)

**Prerequisite**

In the **Current span** parameter (→ 74), one of the following options is selected:

- 4...20 mA NAMUR
- 4...20 mA US
- 4...20 mA

**Description**

Use this function to select the current value that the current output adopts during the device start-up phase as long as no measured value is present.

**Selection**

- Min.
- Max.
- Defined value

**Factory setting**

Min.

**Additional information***"Min." option*

The current output adopts the value of the lower level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→ [74](#)).

*"Max." option*

The current output adopts the value of the upper level for signal on alarm.

 The signal on alarm level is defined via the **Current span** parameter (→ [74](#)).

*"Defined value" option*

The current output outputs a defined current value.

 The current value is defined via the **Start-up current** parameter (→ [81](#)).

**Start-up current****Navigation**

 Expert → Output → Curr.output → Start-up current (0369)

**Prerequisite**

The **Defined value** option is selected in the **Start-up mode** parameter (→ [80](#)).

**Description**

Use this function to enter a fixed current value that the current output adopts during the device start-up phase as long as no measured value is present.

**User entry**

3.59 to 22.5 mA

**Factory setting**

3.6 mA

**3.4.2 "Pulse/frequency/switch output" submenu***Navigation*

 Expert → Output → PFS output

|  Pulse/frequency/switch output |                      |
|---|----------------------|
| Operating mode (0469)   | → <a href="#">83</a> |
| Assign pulse output (0460)  | → <a href="#">84</a> |
| Value per pulse (0455)  | → <a href="#">85</a> |
| Pulse width (0452)  | → <a href="#">85</a> |
| Failure mode (0480)   | → <a href="#">86</a> |
| Pulse output (0456)   | → <a href="#">87</a> |

|   |       |
|---|-------|
| Assign frequency output (0478)              | →  87 |
| Minimum frequency value (0453)              | →  88 |
| Maximum frequency value (0454)              | →  88 |
| Measuring value at minimum frequency (0476) | →  89 |
| Measuring value at maximum frequency (0475) | →  89 |
| Damping output (0477)                       | →  90 |
| Response time (0491)                        | →  90 |
| Failure mode (0451)                         | →  91 |
| Failure frequency (0474)                    | →  91 |
| Output frequency (0471)                     | →  92 |
| Switch output function (0481)               | →  92 |
| Assign diagnostic behavior (0482)           | →  92 |
| Assign limit (0483)                         | →  93 |
| Switch-on value (0466)                      | →  95 |
| Switch-off value (0464)                     | →  95 |
| Assign status (0485)                        | →  96 |
| Switch-on delay (0467)                      | →  96 |
| Switch-off delay (0465)                     | →  97 |
| Failure mode (0486)                         | →  97 |
| Switch status (0461)                        | →  97 |
| Invert output signal (0470)                 | →  98 |

**Operating mode****Navigation**

Expert → Output → PFS output → Operating mode (0469)

**Description**

Use this function to select the operating mode of the output as a pulse, frequency or switch output.

**Selection**

- Pulse
- Frequency
- Switch

**Factory setting**

Pulse


**Additional information***"Pulse" option*

Quantity-dependent pulse with configurable pulse width

- Whenever a specific volume or mass is reached (pulse value), a pulse is output, the duration of which was set previously (pulse width).
- The pulses are never shorter than the set duration.

**Example**

- Flow rate approx. 100 g/s
- Pulse value 0.1 g
- Pulse width 0.05 ms
- Pulse rate 1 000 Impuls/s




4 Quantity-proportional pulse (pulse value) with pulse width to be configured

B Pulse width entered

P Pauses between the individual pulses

*"Frequency" option***Example**

- Flow rate approx. 100 g/s
- Max. frequency 10 kHz
- Flow rate at max. frequency 1 000 g/s
- Output frequency approx. 1 000 Hz




5 Flow-proportional frequency output

#### "Switch" option

Contact for displaying a condition (e.g. alarm or warning if a limit value is reached)

##### Example


Alarm response without alarm



6 No alarm, high level

##### Example

Alarm response in case of alarm



7 Alarm, low level

---

## Assign pulse output



### Navigation

Expert → Output → PFS output → Assign pulse (0460)

### Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 83) parameter.

### Description

Use this function to select the process variable for the pulse output.

### Selection

- Off
- Volume flow
- Mass flow

### Factory setting

Off

---

**Value per pulse**

---

**Navigation**

Expert → Output → PFS output → Value per pulse (0455)

**Prerequisite**

The **Pulse** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign pulse output** parameter (→ 84):

- Volume flow
- Mass flow

**Description**

Use this function to enter the value for the measured value that a pulse is equivalent to.

**User entry**

Signed floating-point number

**Factory setting**

Depends on country and nominal diameter → 140

**Additional information**

*User entry*

Weighting of the pulse output with a quantity.

The lower the pulse value, the

- better the resolution.
- the higher the frequency of the pulse response.

---

**Pulse width**

---

**Navigation**

Expert → Output → PFS output → Pulse width (0452)

**Prerequisite**

The **Pulse** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign pulse output** parameter (→ 84):

- Volume flow
- Mass flow

**Description**

Use this function to enter the duration of the output pulse.

**User entry**

0.5 to 2 000 ms


**Factory setting**

100 ms

**Additional information**

*Description*

- Define how long a pulse is (duration).
- The maximum pulse rate is defined by  $f_{\max} = 1 / (2 \times \text{pulse width})$ .
- The interval between two pulses lasts at least as long as the set pulse width.
- The maximum flow is defined by  $Q_{\max} = f_{\max} \times \text{pulse value}$ .
- If the flow exceeds these limit values, the measuring device displays the diagnostic message **△S443 Pulse output 1 to n**.



*B* Pulse width entered  
*P* Pauses between the individual pulses

### Example

- Pulse value: 0.1 g
- Pulse width: 0.1 ms
- $f_{\max}: 1 / (2 \times 0.1 \text{ ms}) = 5 \text{ kHz}$
- $Q_{\max}: 5 \text{ kHz} \times 0.1 \text{ g} = 0.5 \text{ kg/s}$

## Failure mode



### Navigation

Expert → Output → PFS output → Failure mode (0480)

### Prerequisite

The **Pulse** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign pulse output** parameter (→ 84):

- Volume flow
- Mass flow

### Description

Use this function to select the failure mode of the pulse output in the event of a device alarm.

### Selection

- Actual value
- No pulses

### Factory setting

No pulses

### Additional information

#### Description

The dictates of safety render it advisable to ensure that the pulse output shows a predefined behavior in the event of a device alarm.

#### Selection

- Actual value  
In the event of a device alarm, the pulse output continues on the basis of the current flow measurement. The fault is ignored.
- No pulses  
In the event of a device alarm, the pulse output is "switched off".

**NOTICE!** A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

## Pulse output

### Navigation

Expert → Output → PFS output → Pulse output (0456)

### Prerequisite

In the **Operating mode** parameter (→ 83), the **Pulse** option is selected.

### Description

Displays the pulse frequency currently output.


### User interface

Positive floating-point number

### Additional information

#### Description

- The pulse output is an open collector output.
- This is configured at the factory in such a way that the transistor is conductive for the duration of the pulse (NO contact) and is safety-oriented.
- The **Value per pulse** parameter (→ 85) and **Pulse width** parameter (→ 85) can be used to define the value (i.e. the measured value amount that corresponds to a pulse) and the duration of the pulse.



A0025816-EN

0 Non-conductive

1 Conductive

NC NC contact (normally closed)

NO NO contact (normally open)

The output behavior can be reversed via the **Invert output signal** parameter (→ 98) i.e. the transistor does not conduct for the duration of the pulse.

In addition, the behavior of the output in the event of a device alarm (**Failure mode** parameter (→ 86)) can be configured.

## Assign frequency output

### Navigation

Expert → Output → PFS output → Assign freq. (0478)

### Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) parameter.

### Description

Use this function to select the process variable for the frequency output.

|                  |   |
|------------------|---|
| <b>Selection</b> | <ul style="list-style-type: none"><li>■ Off</li><li>■ Volume flow</li><li>■ Mass flow</li><li>■ Temperature</li></ul> |
|------------------|---|

|                        |     |
|------------------------|-----|
| <b>Factory setting</b> | Off |
|------------------------|-----|

---

### Minimum frequency value



|                   |  |
|-------------------|--|
| <b>Navigation</b> | Expert → Output → PFS output → Min. freq. value (0453) |
|-------------------|--|

|                     |  |
|---------------------|--|
| <b>Prerequisite</b> | The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 83) and one of the following options is selected in the <b>Assign frequency output</b> parameter (→ 87): <ul style="list-style-type: none"><li>■ Volume flow</li><li>■ Mass flow</li><li>■ Temperature</li></ul> |
|---------------------|--|

|                    |   |
|--------------------|---|
| <b>Description</b> | Use this function to enter the start value frequency. |
|--------------------|---|

|                   |                  |
|-------------------|------------------|
| <b>User entry</b> | 0.0 to 1000.0 Hz |
|-------------------|------------------|

|                        |        |
|------------------------|--------|
| <b>Factory setting</b> | 0.0 Hz |
|------------------------|--------|

---

### Maximum frequency value



|                   |  |
|-------------------|--|
| <b>Navigation</b> | Expert → Output → PFS output → Max. freq. value (0454) |
|-------------------|--|

|                     |  |
|---------------------|--|
| <b>Prerequisite</b> | The <b>Frequency</b> option is selected in the <b>Operating mode</b> parameter (→ 83) and one of the following options is selected in the <b>Assign frequency output</b> parameter (→ 87): <ul style="list-style-type: none"><li>■ Volume flow</li><li>■ Mass flow</li><li>■ Temperature</li></ul> |
|---------------------|--|

|                    |   |
|--------------------|---|
| <b>Description</b> | Use this function to enter the end value frequency. |
|--------------------|---|

|                   |                  |
|-------------------|------------------|
| <b>User entry</b> | 0.0 to 1000.0 Hz |
|-------------------|------------------|

|                        |           |
|------------------------|-----------|
| <b>Factory setting</b> | 1000.0 Hz |
|------------------------|-----------|

---

**Measuring value at minimum frequency**

---

**Navigation**

Expert → Output → PFS output → Val. at min.freq (0476)

**Prerequisite**

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

**Description**

Use this function to enter the measured value for the start value frequency.

**User entry**

Signed floating-point number

**Factory setting**

Depends on country and nominal diameter

**Additional information***Dependency*

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 87).

---

**Measuring value at maximum frequency**

---

**Navigation**

Expert → Output → PFS output → Val. at max.freq (0475)

**Prerequisite**

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

**Description**

Use this function to enter the measured value for the end value frequency.

**User entry**

Signed floating-point number

**Factory setting**

Depends on country and nominal diameter

**Additional information***Description*

Use this function to enter the maximum measured value at the maximum frequency. The selected process variable is output as a proportional frequency.

*Dependency*

The entry depends on the process variable selected in the **Assign frequency output** parameter (→ 87).

## Damping output



### Navigation

Expert → Output → PFS output → Damping out. (0477)

### Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

### Description

Use this function to enter the reaction time of the output signal to fluctuations in the measured value.

### User entry

0 to 999.9 s

### Factory setting

0.0 s

### Additional information

#### Description

Use this function to enter a time constant (PT1 element) for frequency output damping. The frequency output is subject to separate damping that is independent of all preceding time constants.

## Response time

### Navigation

Expert → Output → PFS output → Response time (0491)

### Prerequisite

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

### Description

Displays the response time. This specifies how quickly the pulse/frequency/switch output reaches the measured value change of 63 % of 100 % of the measured value change.

### User interface

Positive floating-point number

### Additional information

#### Description

The response time is made up of the time specified for the following dampings:

- Damping of pulse/frequency/switch output → 77  
and
- Depending on the measured variable assigned to the output.  
Flow damping

**Failure mode****Navigation**

Expert → Output → PFS output → Failure mode (0451)

**Prerequisite**

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

**Description**

Use this function to select the failure mode of the frequency output in the event of a device alarm.

**Selection**

- Actual value
- Defined value
- 0 Hz

**Factory setting**

0 Hz

**Additional information***Selection***Actual value**

In the event of a device alarm, the frequency output continues on the basis of the current flow measurement. The device alarm is ignored.

**Defined value**

In the event of a device alarm, the frequency output continues on the basis of a predefined value. The Failure frequency (→ 91) replaces the current measured value, making it possible to bypass the device alarm. The actual measurement is switched off for the duration of the device alarm.

**0 Hz**

In the event of a device alarm, the frequency output is "switched off".

**NOTICE!** A device alarm is a measuring device error that must be taken seriously. It can affect the measurement quality such that the quality can no longer be guaranteed. The **Actual value** option is only recommended if it can be guaranteed that all possible alarm conditions will not affect the measurement quality.

**Failure frequency****Navigation**

Expert → Output → PFS output → Failure freq. (0474)

**Prerequisite**

The **Frequency** option is selected in the **Operating mode** parameter (→ 83) and one of the following options is selected in the **Assign frequency output** parameter (→ 87):

- Volume flow
- Mass flow
- Temperature

**Description**

Use this function to enter the value for the frequency output in the event of a device alarm in order to bypass the alarm.

**User entry**

0.0 to 1250.0 Hz

**Factory setting**

0.0 Hz

## Output frequency

|                       |  |
|-----------------------|--|
| <b>Navigation</b>     |   Expert → Output → PFS output → Output freq. (0471) |
| <b>Prerequisite</b>   | In the <b>Operating mode</b> parameter (→ 83), the <b>Frequency</b> option is selected.  |
| <b>Description</b>    | Displays the actual value of the output frequency which is currently measured.   |
| <b>User interface</b> | 0.0 to 1 250.0 Hz  |

## Switch output function



|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |   Expert → Output → PFS output → Switch out funct (0481)  |
| <b>Prerequisite</b>           | In the <b>Operating mode</b> parameter (→ 83) the <b>Switch</b> option is selected.   |
| <b>Description</b>            | Use this function to select a function for the switch output.   |
| <b>Selection</b>              | <ul style="list-style-type: none"><li>▪ Off</li><li>▪ On</li><li>▪ Diagnostic behavior</li><li>▪ Limit</li><li>▪ Status</li></ul>   |
| <b>Factory setting</b>        | Off   |
| <b>Additional information</b> | <i>Selection</i> <ul style="list-style-type: none"><li>▪ Off<br/>The switch output is permanently switched off (open, non-conductive).</li><li>▪ On<br/>The switch output is permanently switched on (closed, conductive).</li><li>▪ Diagnostic behavior<br/>Indicates if the diagnostic event is present or not. Is used to output diagnostic information and to react to it appropriately at the system level.</li><li>▪ Limit<br/>Indicates if a specified limit value has been reached for the process variable. Is used to output diagnostic information relating to the process and to react to it appropriately at the system level.</li><li>▪ Status<br/>Indicates the device status depending on whether empty pipe detection or low flow cut off is selected.</li></ul> |


## Assign diagnostic behavior



|                     |  |
|---------------------|--|
| <b>Navigation</b>   |   Expert → Output → PFS output → Assign diag. beh (0482)                           |
| <b>Prerequisite</b> | <ul style="list-style-type: none"><li>▪ The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter (→ 83).</li><li>▪ The <b>Diagnostic behavior</b> option is selected in the <b>Switch output function</b> parameter (→ 92).</li></ul> |

|                               |   |
|-------------------------------|---|
| <b>Description</b>            | Use this function to select the diagnostic event category that is displayed for the switch output.  |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li>▪ Alarm</li> <li>▪ Alarm or warning</li> <li>▪ Warning</li> </ul>  |
| <b>Factory setting</b>        | Alarm   |
| <b>Additional information</b> | <p><i>Description</i></p> <p> If no diagnostic event is pending, the switch output is closed and conductive.</p> <p><i>Options</i></p> <ul style="list-style-type: none"> <li>▪ Alarm<br/>The switch output signals only diagnostic events in the alarm category.</li> <li>▪ Alarm or warning<br/>The switch output signals diagnostic events in the alarm and warning category.</li> <li>▪ Warning<br/>The switch output signals only diagnostic events in the warning category.</li> </ul> |

|                               |  |
|-------------------------------|--|
| <b>Assign limit</b>           |  |
| <b>Navigation</b>             |  Expert → Output → PFS output → Assign limit (0483)   |
| <b>Prerequisite</b>           | <ul style="list-style-type: none"> <li>▪ The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter (→ 83) parameter.</li> <li>▪ The <b>Limit</b> option is selected in the <b>Switch output function</b> parameter (→ 92) parameter.</li> </ul>  |
| <b>Description</b>            | Use this function to select a process variable for the limit function.   |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li>▪ Volume flow</li> <li>▪ Mass flow</li> <li>▪ Temperature</li> <li>▪ Totalizer 1</li> </ul>   |
| <b>Factory setting</b>        | Volume flow  |
| <b>Additional information</b> | <p><i>Description</i></p> <p>Behavior of status output when Switch-on value &gt; Switch-off value:</p> <ul style="list-style-type: none"> <li>▪ Process variable &gt; Switch-on value: transistor is conductive</li> <li>▪ Process variable &lt; Switch-off value: transistor is non-conductive</li> </ul> |




A0026891

- 1 Switch-on value
- 2 Switch-off value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value < Switch-off value:

- Process variable < Switch-on value: transistor is non-conductive
- Process variable > Switch-off value: transistor is conductive




A0026892

- 1 Switch-off value
- 2 Switch-on value
- 3 Conductive
- 4 Non-conductive
- A Process variable
- B Status output

Behavior of status output when Switch-on value = Switch-off value:

- Process variable > Switch-on value: transistor is conductive
- Process variable < Switch-off value: transistor is non-conductive



- 1 Switch-on value = Switch-off value
- 2 Conductive
- 3 Non-conductive
- A Process variable
- B Status output

## Switch-on value



### Navigation

Expert → Output → PFS output → Switch-on value (0466)

### Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [83](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [92](#)).

### Description

Use this function to enter the measured value for the switch-on point.

### User entry

Signed floating-point number

### Factory setting

0 l/h

### Additional information

#### Description

Use this function to enter the limit value for the switch-on value (process variable > switch-on value = closed, conductive).

When using a hysteresis: Switch-on value > Switch-off value.

#### Dependency

The unit depends on the process variable selected in the **Assign limit** parameter (→ [93](#)).

## Switch-off value



### Navigation

Expert → Output → PFS output → Switch-off value (0464)

### Prerequisite

- The **Switch** option is selected in the **Operating mode** parameter (→ [83](#)).
- The **Limit** option is selected in the **Switch output function** parameter (→ [92](#)).

### Description

Use this function to enter the measured value for the switch-off point.

|                        |  |
|------------------------|--|
| User entry             | Signed floating-point number   |
| Factory setting        | 0 l/h  |
| Additional information | <p><i>Description</i></p> <p>Use this function to enter the limit value for the switch-off value (process variable &lt; switch-off value = open, non-conductive).</p> <p> When using a hysteresis: Switch-on value &gt; Switch-off value.</p> |
|                        | <p><i>Dependency</i></p> <p> The unit depends on the process variable selected in the <b>Assign limit</b> parameter (→ 93).</p>   |

| Assign status          |   |
|------------------------|---|
| Navigation             |  Expert → Output → PFS output → Assign status (0485)   |
| Prerequisite           | <ul style="list-style-type: none"><li>■ The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter (→ 83).</li><li>■ The <b>Status</b> option is selected in the <b>Switch output function</b> parameter (→ 92).</li></ul> |
| Description            | Use this function to select a device status for the switch output.  |
| Selection              | <ul style="list-style-type: none"><li>■ Partially filled pipe detection</li><li>■ Low flow cut off</li></ul>  |
| Factory setting        | Low flow cut off  |
| Additional information | <p><i>Options</i></p> <p>If empty pipe detection or low flow cut off are enabled, the output is conductive. Otherwise, the switch output is non-conductive.</p>   |

| Switch-on delay |  |
|-----------------|--|
| Navigation      |  Expert → Output → PFS output → Switch-on delay (0467)  |
| Prerequisite    | <ul style="list-style-type: none"><li>■ The <b>Switch</b> option is selected in the <b>Operating mode</b> parameter (→ 83).</li><li>■ The <b>Limit</b> option is selected in the <b>Switch output function</b> parameter (→ 92).</li></ul> |
| Description     | Use this function to enter a delay time for switching on the switch output.  |
| User entry      | 0.0 to 100.0 s   |
| Factory setting | 0.0 s  |

**Switch-off delay**

**Navigation** Expert → Output → PFS output → Switch-off delay (0465)

**Prerequisite**

- The **Switch** option is selected in the **Operating mode** parameter (→ 83).
- The **Limit** option is selected in the **Switch output function** parameter (→ 92).

**Description** Use this function to enter a delay time for switching off the switch output.

**User entry** 0.0 to 100.0 s

**Factory setting** 0.0 s

**Failure mode**

**Navigation** Expert → Output → PFS output → Failure mode (0486)

**Description** Use this function to select a failsafe mode for the switch output in the event of a device alarm.

**Selection**

- Actual status
- Open
- Closed

**Factory setting** Open

**Additional information** *Options*

- Actual status  
In the event of a device alarm, faults are ignored and the current behavior of the input value is output by the switch output. The **Actual status** option behaves in the same way as the current input value.
- Open  
In the event of a device alarm, the switch output's transistor is set to **non-conductive**.
- Closed  
In the event of a device alarm, the switch output's transistor is set to **conductive**.

**Switch status**

**Navigation** Expert → Output → PFS output → Switch status (0461)

**Prerequisite** The **Switch** option is selected in the **Operating mode** parameter (→ 83).

**Description** Displays the current switch status of the status output.

**User interface**

- Open
- Closed

**Additional information***User interface*

- Open  
The switch output is not conductive.
- Closed  
The switch output is conductive.

**Invert output signal****Navigation**

Expert → Output → PFS output → Invert outp.sig. (0470)

**Description**

Use this function to select whether to invert the output signal.

**Selection**


- No
- Yes

**Factory setting**


No

**Additional information***Selection*

**No** option (passive - negative)




**Yes** option (passive - positive)



### 3.5 "Communication" submenu

**Navigation**


Expert → Communication



### 3.5.1 "HART output" submenu

*Navigation*


Expert → Communication → HART output



#### "Configuration" submenu

*Navigation*

Expert → Communication → HART output → Configuration




---

## Burst mode



**Navigation**

Expert → Communication → HART output → Configuration → Burst mode (0208)

**Description**

Use this function to select whether to activate or deactivate the HART burst mode for burst message X.

**Selection**

- Off
- On

**Factory setting**

Off

**Additional information**

*Selection*

- Off  
The measuring device transmits data only when requested by the HART master.
- On  
The measuring device transmits data regularly without being requested.

**Burst command**

**Navigation** Expert → Communication → HART output → Configuration → Burst command (0207)

**Description** Use this function to select the HART command that is sent to the HART master.

**Selection**

- Command 1
- Command 2
- Command 3
- Command 9
- Command 33
- Command 48

**Factory setting** Command 2

**Additional information**

*Selection*

- Command 1  
Read out the primary variable.
- Command 2  
Read out the current and the main measured value as a percentage.
- Command 3  
Read out the dynamic HART variables and the current.
- Command 9  
Read out the dynamic HART variables including the related status.
- Command 33  
Command 33: Read out the dynamic HART variables including the related unit.

**HART short tag**

**Navigation** Expert → Communication → HART output → Configuration → HART short tag (0220)

**Description** Use this function to enter a brief description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

**User entry** Max. 8 characters: A-Z, 0-9 and certain special characters (e.g. punctuation marks, @, %).

**Factory setting** T-MASS

**Device tag**

**Navigation** Expert → Communication → HART output → Configuration → Device tag (0215)

**Description** Use this function to enter the name for the measuring point.

**User entry** Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

**Factory setting** t-mass

**HART address**

|                        |   |
|------------------------|---|
| <b>Navigation</b>      | Diagram: Expert → Communication → HART output → Configuration → HART address (0219)               |
| <b>Description</b>     | Use this function to enter the address via which the data exchange takes place via HART protocol. |
| <b>User entry</b>      | 0 to 63   |
| <b>Factory setting</b> | 0   |

**No. of preambles**

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             | Diagram: Expert → Communication → HART output → Configuration → No. of preambles (0217)                                   |
| <b>Description</b>            | Use this function to enter the number of preambles in the HART protocol.  |
| <b>User entry</b>             | 2 to 20   |
| <b>Factory setting</b>        | 5   |
| <b>Additional information</b> | <p><i>User entry</i></p> <p>As every modem component can "swallow" a byte, 2-byte preambles at least must be defined.</p> |

**"Information" submenu***Navigation*

Diagram: Expert → Communication → HART output → Information

| ► Information          |        |
|------------------------|--------|
| Device revision (0204) | →  102 |
| Device ID (0221)       | →  102 |
| Device type (0222)     | →  102 |
| Manufacturer ID (0223) | →  103 |
| HART revision (0205)   | →  103 |
| HART descriptor (0212) | →  103 |
| HART message (0216)    | →  103 |

|                          |        |
|--------------------------|--------|
| Hardware revision (0206) | →  104 |
| Software revision (0224) | →  104 |
| HART date code (0202)    | →  104 |

---

## Device revision

---

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             | Expert → Communication → HART output → Information → Device revision (0204)   |
| <b>Description</b>            | Use this function to view the device revision with which the device is registered with the HART Communication Foundation. |
| <b>User interface</b>         | 2-digit hexadecimal number  |
| <b>Factory setting</b>        | 0x01  |
| <b>Additional information</b> | <i>Description</i><br>The device revision is needed to assign the appropriate device description file (DD) to the device. |

---

## Device ID

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             | Expert → Communication → HART output → Information → Device ID (0221)  |
| <b>Description</b>            | Use this function to view the device ID for identifying the measuring device in a HART network.  |
| <b>User interface</b>         | 6-digit hexadecimal number   |
| <b>Additional information</b> | <i>Description</i><br>In addition to the device type and manufacturer ID, the device ID is part of the unique ID. Each HART device is uniquely identified by the unique device ID. |

---

## Device type

---

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Communication → HART output → Information → Device type (0222)  |
| <b>Description</b>     | Displays the device type with which the measuring device is registered with the HART Communication Foundation. |
| <b>User interface</b>  | 2-digit hexadecimal number   |
| <b>Factory setting</b> | 0x68 (for t-mass T 150)  |

**Additional information***Description*

The device type is specified by the manufacturer. It is needed to assign the appropriate device description file (DD) to the device.

**Manufacturer ID****Navigation**

Expert → Communication → HART output → Information → Manufacturer ID (0223)

**Description**

Use this function to view the manufacturer ID with which the measuring device is registered with the HART Communication Foundation.

**User interface**

2-digit hexadecimal number

**Factory setting**

0x11 (for Endress+Hauser)

**HART revision****Navigation**

Expert → Communication → HART output → Information → HART revision (0205)

**Description**

Use this function to display the HART protocol revision of the measuring device.

**User interface**

5 to 7

**Factory setting**

6

**HART descriptor****Navigation**

Expert → Communication → HART output → Information → HART descriptor (0212)

**Description**

Use this function to enter a description for the measuring point. This can be edited and displayed via HART protocol or using the local display.

**User entry**

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /)

**Factory setting**

t-mass L T 150

**HART message****Navigation**

Expert → Communication → HART output → Information → HART message (0216)

**Description**

Use this function to enter a HART message which is sent via the HART protocol when requested by the master.

**User entry** Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

**Factory setting** t-mass L T 150

---

#### Hardware revision

---

**Navigation**  Expert → Communication → HART output → Information → Hardware rev. (0206)

**Description** Displays the hardware revision of the measuring device.

**User interface** 0 to 255

**Factory setting** 1

---

#### Software revision

---

**Navigation**  Expert → Communication → HART output → Information → Software rev. (0224)

**Description** Displays the software revision of the measuring device.

**User interface** 0 to 255

**Factory setting** 1

---

#### HART date code

---



**Navigation**  Expert → Communication → HART output → Information → HART date code (0202)

**Description** Use this function to enter the date information for individual use.

**User entry** Date entry format: yyyy-mm-dd

**Factory setting** 2009-07-20

**Additional information** *Example*

Device installation date

**"Output" submenu***Navigation*

Expert → Communication → HART output → Output

| ▶ Output                        |        |
|---------------------------------|--------|
| Assign PV (0234)                | →  105 |
| Primary variable (PV) (0201)    | →  105 |
| Assign SV (0235)                | →  106 |
| Secondary variable (SV) (0226)  | →  106 |
| Assign TV (0236)                | →  106 |
| Tertiary variable (TV) (0228)   | →  107 |
| Assign QV (0237)                | →  107 |
| Quaternary variable (QV) (0203) | →  107 |

**Assign PV****Navigation**

Expert → Communication → HART output → Output → Assign PV (0234)

**Description**

Use this function to select a measured variable (HART device variable) for the primary dynamic variable (PV).

**Selection**

- Volume flow
- Mass flow
- Temperature

**Factory setting**

Volume flow

**Primary variable (PV)****Navigation**

Expert → Communication → HART output → Output → Primary var (PV) (0201)

**Description**

Displays the current measured value of the primary dynamic variable (PV).

**User interface**

Signed floating-point number

**Additional information***User interface*

The measured value displayed depends on the process variable selected in the **Assign PV** parameter (→ 105).

*Dependency*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

---

**Assign SV****Navigation**

  Expert → Communication → HART output → Output → Assign SV (0235)

**Description**

Use this function to select a measured variable (HART device variable) for the secondary dynamic variable (SV).

**Selection**

- Volume flow
- Mass flow
- Temperature
- Totalizer

**Factory setting**

Totalizer

---

**Secondary variable (SV)****Navigation**

  Expert → Communication → HART output → Output → Second.var(SV) (0226)

**Description**

Displays the current measured value of the secondary dynamic variable (SV).

**User interface**

Signed floating-point number

**Additional information***User interface*

The measured value displayed depends on the process variable selected in the **Assign SV** parameter (→ 106).

*Dependency*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

---

**Assign TV****Navigation**

  Expert → Communication → HART output → Output → Assign TV (0236)

**Description**

Use this function to select a measured variable (HART device variable) for the tertiary (third) dynamic variable (TV).

---

|                  |  |
|------------------|--|
| <b>Selection</b> | <ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Temperature</li> <li>■ Totalizer</li> </ul> |
|------------------|--|

|                        |             |
|------------------------|-------------|
| <b>Factory setting</b> | Temperature |
|------------------------|-------------|

---

### Tertiary variable (TV)

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Communication → HART output → Output → Tertiary var(TV) (0228)  |
| <b>Description</b>            | Displays the current measured value of the tertiary dynamic variable (TV).   |
| <b>User interface</b>         | 0 to 99 999.9999 °C  |
| <b>Additional information</b> | <p><i>User interface</i></p> <p>The measured value displayed depends on the process variable selected in the <b>Assign TV</b> parameter (→  106).</p> <p><i>Dependency</i></p> <p> The unit of the displayed measured value is taken from the <b>System units</b> submenu (→  45).</p> |

---

### Assign QV

---



|                        |  |
|------------------------|--|
| <b>Navigation</b>      |   Expert → Communication → HART output → Output → Assign QV (0237) |
| <b>Description</b>     | Use this function to select a measured variable (HART device variable) for the quaternary (fourth) dynamic variable (QV).  |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>■ Volume flow</li> <li>■ Mass flow</li> <li>■ Temperature</li> <li>■ Totalizer</li> </ul>   |
| <b>Factory setting</b> | Totalizer  |

---

### Quaternary variable (QV)

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Communication → HART output → Output → Quaterna.var(QV) (0203) |
| <b>Description</b>    | Displays the current measured value of the quaternary dynamic variable (QV).  |
| <b>User interface</b> | Signed floating-point number  |


**Additional information***User interface*

The measured value displayed depends on the process variable selected in the **Assign QV** parameter (→ [107](#)).


*Dependency*

 The unit of the displayed measured value is taken from the **System units** submenu (→ [45](#)).

## 3.6 "Application" submenu

*Navigation*
 Expert → Application


### 3.6.1 "Totalizer" submenu

*Navigation*
 Expert → Application → Totalizer


#### Assign process variable

*Navigation*
 Expert → Application → Totalizer → Assign variable (0914)
*Description*

Use this function to select a process variable for the Totalizer .

*Selection*

- Off
- Volume flow
- Mass flow

**Factory setting** Volume flow

**Additional information** *Description*



If the option selected is changed, the device resets the totalizer to 0.

*Selection*

If the **Off** option is selected, only **Assign process variable** parameter (→ 108) is still displayed in the **Totalizer** submenu. All other parameters in the submenu are hidden.

## Unit totalizer



**Navigation** Expert → Application → Totalizer → Unit totalizer (0915)

**Prerequisite** One of the following options is selected in the **Assign process variable** parameter (→ 108)**Totalizer** submenu:

- Volume flow
- Mass flow

**Description** Use this function to select the unit for the process variable for Totalizer (→ 41).

**Selection**

*SI units*

- g
- kg
- t

*US units*

- oz
- lb
- STon

*Imperial units*

LTon

*Custom-specific units*

User mass

or

*SI units*

- cm<sup>3</sup>
- dm<sup>3</sup>
- m<sup>3</sup>
- ml
- l
- hl
- Ml Mega

*US units*

- af
- ft<sup>3</sup>
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;oil)
- bbl (us;tank)

*Imperial units*

- gal (imp)
- Mgal (imp)
- bbl (imp;oil)

*Custom-specific units*

User vol.

**Factory setting**

Country-specific:

- m<sup>3</sup>
- ft<sup>3</sup>

**Additional information**

*Selection*

The selection is independent of the process variable selected in the **Assign process variable** parameter (→ 108).

---

## Control Totalizer

---

**Navigation**

  Expert → Application → Totalizer → Control Tot. (0912)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ [108](#)) of the **Totalizer** submenu:

- Volume flow
- Mass flow

**Description**

Use this function to select the control of the totalizer value.

**Selection**

- Totalize
- Reset + hold
- Preset + hold
- Reset + totalize
- Preset + totalize

**Factory setting**

Totalize

**Additional information***Selection*

- Totalize  
The totalizer is started or continues totalizing with the current counter reading.
- Reset + hold  
The totaling process is stopped and the totalizer is reset to 0.
- Preset + hold  
The totaling process is stopped and the totalizer is set to its defined start value from the **Preset value** parameter (→ [110](#)).
- Reset + totalize  
The totalizer is reset to 0 and the totaling process is restarted.
- Preset + totalize  
The totalizer is set to the defined start value from the **Preset value** parameter (→ [110](#)) and the totaling process is restarted.

---

## Preset value

---

**Navigation**

  Expert → Application → Totalizer → Preset value (0913)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ [108](#)) of the **Totalizer** submenu:

- Volume flow
- Mass flow

**Description**

Use this function to enter a start value for the Totalizer .

**User entry**

Signed floating-point number

**Factory setting**

0 m<sup>3</sup>

**Additional information***User entry*

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 109).

*Example*

This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.

**Failure mode****Navigation**

 Expert → Application → Totalizer → Failure mode (0901)

**Prerequisite**

One of the following options is selected in the **Assign process variable** parameter (→ 108) of the **Totalizer** submenu:

- Volume flow
- Mass flow

**Description**

Use this function to select how a totalizer behaves in the event of a device alarm.

**Selection**

- Stop
- Actual value
- Last valid value

**Factory setting**

Stop

**Additional information***Description*


 This setting does not affect the failsafe mode of the outputs. This is specified in separate parameters.

*Selection*

- Stop  
Totalizing is stopped when a device alarm occurs.
- Actual value  
The totalizer continues to count based on the actual measured value; the device alarm is ignored.
- Last valid value  
The totalizer continues to count based on the last valid measured value before the device alarm occurred.

**3.6.2 "CIP/SIP" submenu***Navigation*

 Expert → Application → CIP/SIP



**CIP/SIP mode**

**Navigation**  Expert → Application → CIP/SIP → CIP/SIP mode (3536)

**Description** Use this function to activate and deactivate CIP/SIP mode.

**Selection**

- Off
- On

**Factory setting** Off

**Additional information**  SIP process: max. +130 °C (+266 °F) for one hour max.

## 3.7 "Diagnostics" submenu

*Navigation*  Expert → Diagnostics

|   |   |
|---|---|
|  <b>Diagnostics</b> |   |
| Actual diagnostics (0691)   | →  112 |
| Previous diagnostics (0690)   | →  113 |
| Operating time from restart (0653)  | →  114 |
| Operating time (0652)   | →  114 |
| ► Diagnostic list   | →  115 |
| ► Event logbook   | →  119 |
| ► Device information  | →  121 |
| ► Data logging  | →  125 |
| ► Min/max values  | →  131 |
| ► Simulation  | →  133 |

---

### Actual diagnostics

---

**Navigation**  Expert → Diagnostics → Actual diagnos. (0691)

**Prerequisite** A diagnostic event has occurred.

---

|                               |   |
|-------------------------------|---|
| <b>Description</b>            | Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.   |
| <b>User interface</b>         | Symbol for diagnostic behavior, diagnostic code and short message.  |
| <b>Additional information</b> | <p><i>Display</i></p> <p> Additional pending diagnostic messages can be viewed in the <b>Diagnostic list</b> submenu (→ 115).</p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> |
|                               | <p><i>Example</i></p> <p>For the display format:<br/>F271 Main electronic failure</p>   |

---

## Timestamp

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |  Expert → Diagnostics → Timestamp   |
| <b>Description</b>            | Displays the operating time when the current diagnostic message occurred.  |
| <b>User interface</b>         | Days (d), hours (h), minutes (m) and seconds (s)   |
| <b>Additional information</b> | <p><i>Display</i></p> <p> The diagnostic message can be viewed via the <b>Actual diagnostics</b> parameter (→ 112).</p> |
|                               | <p><i>Example</i></p> <p>For the display format:<br/>24d12h13m00s</p>  |

---

## Previous diagnostics

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Diagnostics → Prev.diagnostics (0690)   |
| <b>Prerequisite</b>           | Two diagnostic events have already occurred.   |
| <b>Description</b>            | Displays the diagnostic message that occurred before the current message.  |
| <b>User interface</b>         | Symbol for diagnostic behavior, diagnostic code and short message.   |
| <b>Additional information</b> | <p><i>Display</i></p> <p> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.</p> |
|                               | <p><i>Example</i></p> <p>For the display format:<br/>F271 Main electronic failure</p>  |

---

**Timestamp**

---

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |  Expert → Diagnostics → Timestamp  |
| <b>Description</b>            | Displays the operating time when the last diagnostic message before the current message occurred.   |
| <b>User interface</b>         | Days (d), hours (h), minutes (m) and seconds (s)  |
| <b>Additional information</b> | <i>Display</i><br> The diagnostic message can be viewed via the <b>Previous diagnostics</b> parameter (→  113). |
|                               | <i>Example</i><br>For the display format:<br>24d12h13m00s   |

---

**Operating time from restart**

---

|                       |  |
|-----------------------|--|
| <b>Navigation</b>     |   Expert → Diagnostics → Time fr. restart (0653) |
| <b>Description</b>    | Use this function to display the time the device has been in operation since the last device restart.  |
| <b>User interface</b> | Days (d), hours (h), minutes (m) and seconds (s)   |

---

**Operating time**


---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |   Expert → Diagnostics → Operating time (0652) |
| <b>Description</b>            | Use this function to display the length of time the device has been in operation.  |
| <b>User interface</b>         | Days (d), hours (h), minutes (m) and seconds (s)   |
| <b>Additional information</b> | <i>User interface</i><br>The maximum number of days is 9999, which is equivalent to 27 years.  |

### 3.7.1 "Diagnostic list" submenu

#### *Navigation*

Expert → Diagnostics → Diagnostic list



## Diagnostics 1

#### **Navigation**

Expert → Diagnostics → Diagnostic list → Diagnostics 1 (0692)

#### **Description**

Displays the current diagnostics message with the highest priority.

#### **User interface**

Symbol for diagnostic behavior, diagnostic code and short message.

#### **Additional information**

##### *Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

#### *Examples*

For the display format:

- S442 Frequency output
- F276 I/O module failure

## Timestamp

#### **Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

#### **Description**

Displays the operating time when the diagnostic message with the highest priority occurred.

#### **User interface**

Days (d), hours (h), minutes (m) and seconds (s)

**Additional information***Display*

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 115).

*Example*

For the display format:  
24d12h13m00s

---

**Diagnostics 2**

---

**Navigation**

Expert → Diagnostics → Diagnostic list → Diagnostics 2 (0693)

**Description**

Displays the current diagnostics message with the second-highest priority.

**User interface**

Symbol for diagnostic behavior, diagnostic code and short message.

**Additional information***Display*

Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the key.

*Examples*

For the display format:  
■ S442 Frequency output  
■ F276 I/O module failure

---

**Timestamp**

---

**Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

**Description**

Displays the operating time when the diagnostic message with the second-highest priority occurred.

**User interface**

Days (d), hours (h), minutes (m) and seconds (s)

**Additional information***Display*

The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 116).

*Example*

For the display format:  
24d12h13m00s

---

## Diagnostics 3

---

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |   Expert → Diagnostics → Diagnostic list → Diagnostics 3 (0694)   |
| <b>Description</b>            | Displays the current diagnostics message with the third-highest priority.   |
| <b>User interface</b>         | Symbol for diagnostic behavior, diagnostic code and short message.  |
| <b>Additional information</b> | <i>Display</i><br> Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key. |
|                               | <i>Examples</i><br>For the display format:<br>■  AS442 Frequency output<br>■  F276 I/O module failure   |

---

## Timestamp

---

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |  Expert → Diagnostics → Diagnostic list → Timestamp   |
| <b>Description</b>            | Displays the operating time when the diagnostic message with the third-highest priority occurred.  |
| <b>User interface</b>         | Days (d), hours (h), minutes (m) and seconds (s)   |
| <b>Additional information</b> | <i>Display</i><br> The diagnostic message can be viewed via the <b>Diagnostics 3</b> parameter (→  117). |
|                               | <i>Example</i><br>For the display format:<br>24d12h13m00s  |

---

## Diagnostics 4

---

|                       |   |
|-----------------------|---|
| <b>Navigation</b>     |   Expert → Diagnostics → Diagnostic list → Diagnostics 4 (0695) |
| <b>Description</b>    | Displays the current diagnostics message with the fourth-highest priority.  |
| <b>User interface</b> | Symbol for diagnostic behavior, diagnostic code and short message.  |

**Additional information***Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

*Examples*

For the display format:

-  S442 Frequency output
-  F276 I/O module failure

---

**Timestamp**

---

**Navigation**

 Expert → Diagnostics → Diagnostic list → Timestamp

**Description**

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

**User interface**

Days (d), hours (h), minutes (m) and seconds (s)

**Additional information***Display*

 The diagnostic message can be viewed via the **Diagnostics 4** parameter (→  117).

*Example*

For the display format:

24d12h13m00s

---

**Diagnostics 5**

---

**Navigation**

  Expert → Diagnostics → Diagnostic list → Diagnostics 5 (0696)

**Description**

Displays the current diagnostics message with the fifth-highest priority.

**User interface**

Symbol for diagnostic behavior, diagnostic code and short message.

**Additional information***Display*

 Via the local display: the time stamp and corrective measures referring to the cause of the diagnostic message can be accessed via the  key.

*Examples*

For the display format:


-  S442 Frequency output
-  F276 I/O module failure

**Timestamp**

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             |  Expert → Diagnostics → Diagnostic list → Timestamp   |
| <b>Description</b>            | Displays the operating time when the diagnostic message with the fifth-highest priority occurred.  |
| <b>User interface</b>         | Days (d), hours (h), minutes (m) and seconds (s)   |
| <b>Additional information</b> | <p><i>Display</i></p>  The diagnostic message can be viewed via the <b>Diagnostics 5</b> parameter (→  118). |
|                               | <p><i>Example</i></p> <p>For the display format:<br/>24d12h13m00s</p>  |

**3.7.2 "Event logbook" submenu**

*Navigation*  Expert → Diagnostics → Event logbook

**Filter options**

|                        |   |
|------------------------|---|
| <b>Navigation</b>      |  Expert → Diagnostics → Event logbook → Filter options (0705)  |
| <b>Description</b>     | Use this function to select the category whose event messages are displayed in the event list of the local display.   |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>■ All</li> <li>■ Failure (F)</li> <li>■ Function check (C)</li> <li>■ Out of specification (S)</li> <li>■ Maintenance required (M)</li> <li>■ Information (I)</li> </ul> |
| <b>Factory setting</b> | All   |

**Additional information***Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

**Filter options****Navigation**

Expert → Diagnostics → Event logbook → Filter options

**Description**

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

**Selection**

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

**Factory setting**

All

**Additional information***Description*

The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required


**"Event list" submenu**

The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

**Navigation**

Expert → Diagnostics → Event logbook → Event list



**Event list**

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |  Expert → Diagnostics → Event logbook → Event list   |
| <b>Description</b>            | Displays the history of event messages of the category selected in the <b>Filter options</b> parameter (→  119).   |
| <b>User interface</b>         | <ul style="list-style-type: none"> <li>■ For a "Category I" event message<br/>Information event, short message, symbol for event recording and operating time when error occurred</li> <li>■ For a "Category F, C, S, M" event message (status signal)<br/>Diagnostics code, short message, symbol for event recording and operating time when error occurred</li> </ul>  |
| <b>Additional information</b> | <p><i>Description</i></p> <p>A maximum of 20 event messages are displayed in chronological order.</p> <p>If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.</p> <p>The following symbols indicate whether an event has occurred or has ended:</p> <ul style="list-style-type: none"> <li>■  Occurrence of the event</li> <li>■  End of the event</li> </ul> <p><i>Examples</i></p> <p>For the display format:</p> <ul style="list-style-type: none"> <li>■ I1091 Configuration modified<br/> 24d12h13m00s</li> <li>■  Frequency output<br/> 01d04h12min30s</li> </ul> <p> Additional information, such as remedial measures, can be retrieved via the  key.</p> |
| <i>HistoROM</i>               |   |
|                               | A HistoROM is a "non-volatile" device memory in the form of an EEPROM.  |
|                               |  To order the <b>HistoROM advanced capabilities</b> application package, see the "Accessories" section of the "Technical Information" document.  |

**3.7.3 "Device information" submenu***Navigation*  Expert → Diagnostics → Device info

|  Device information |   |
|--|---|
| Device tag (0011)  | →  122 |
| Serial number (0009)   | →  122 |
| Firmware version (0010)  | →  123 |

|                              |        |
|------------------------------|--------|
| Device name (0013)           | →  123 |
| Order code (0008)            | →  123 |
| Extended order code 1 (0023) | →  124 |
| Extended order code 2 (0021) | →  124 |
| Extended order code 3 (0022) | →  124 |
| ENP version (0012)           | →  124 |
| Configuration counter (0233) | →  125 |

## Device tag

### Navigation

Expert → Diagnostics → Device info → Device tag (0011)

### Description

Displays a unique name for the measuring point so it can be identified quickly within the plant. The name is displayed in the header.

### User interface


Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

### Factory setting

t-mass L T 150

### Additional information

*User interface*



8 Header text

The number of characters displayed depends on the characters used.

## Serial number

### Navigation

Expert → Diagnostics → Device info → Serial number (0009)

### Description

Displays the serial number of the measuring device.

The number can be found on the nameplate of the sensor and transmitter.

### User interface

A maximum of 11-digit character string comprising letters and numbers.

**Additional information***Description***Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:  
[www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)

---

**Firmware version**

---

**Navigation**

Expert → Diagnostics → Device info → Firmware version (0010)

**Description**

Displays the device firmware version installed.

**User interface**

Character string in the format xx.yy.zz

**Additional information***Display*

The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

---

**Device name**

---

**Navigation**

Expert → Diagnostics → Device info → Device name (0013)

**Description**

Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

**User interface**

t-mass T 150

---

**Order code**

---

**Navigation**

Expert → Diagnostics → Device info → Order code (0008)

**Description**

Displays the device order code.

**User interface**

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

**Additional information***Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

**Uses of the order code**

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

---

**Extended order code 1****Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1 (0023)

**Description**

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

**User interface**

Character string

**Additional information****Description**

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

---

**Extended order code 2****Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2 (0021)

**Description**

For displaying the second part of the extended order code.

**User interface**

Character string

**Additional information**

For additional information, see **Extended order code 1** parameter (→ 124)

---

**Extended order code 3****Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 3 (0022)

**Description**

For displaying the third part of the extended order code.

**User interface**

Character string

**Additional information**

For additional information, see **Extended order code 1** parameter (→ 124)

---

**ENP version****Navigation**

Expert → Diagnostics → Device info → ENP version (0012)

**Description**

Displays the version of the electronic nameplate.

**User interface**

Character string

**Factory setting** 2.02.00

**Additional information** *Description*

This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.

---

### Configuration counter

---

**Navigation**  Expert → Diagnostics → Device info → Config. counter (0233)

**Description** Displays the number of parameter modifications for the device. When the user changes a parameter setting, this counter is incremented.

**User interface** 0 to 65 535

### 3.7.4 "Data logging" submenu

*Navigation*  Expert → Diagnostics → Data logging

|  <b>Data logging</b>      |   |
|--|---|
| Assign channel 1 (0851)  | →  126 |
| Assign channel 2 (0852)  | →  126 |
| Assign channel 3 (0853)  | →  127 |
| Assign channel 4 (0854)  | →  127 |
| Logging interval (0856)  | →  127 |
| Clear logging data (0855)  | →  128 |
|  <b>Display channel 1</b> |   |
| Display channel 2  | →  129 |
| Display channel 3  | →  130 |
| Display channel 4  | →  130 |

## Assign channel 1



### Navigation

Expert → Diagnostics → Data logging → Assign chan. 1 (0851)

### Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

### Description

Use this function to select a process variable for the data logging channel.

### Selection

- Off
- Volume flow
- Mass flow
- Temperature
- Current output

### Factory setting

Off

### Additional information

#### Description

A total of 1000 measured values can be logged. This means:

- 1000 data points if 1 logging channel is used
- 500 data points if 2 logging channels are used
- 333 data points if 3 logging channels are used
- 250 data points if 4 logging channels are used

Once the maximum number of data points is reached, the oldest data points in the data log are cyclically overwritten in such a way that the last 1000, 500, 333 or 250 measured values are always in the log (ring memory principle).

The log contents are cleared if the option selected is changed.

## Assign channel 2



### Navigation

Expert → Diagnostics → Data logging → Assign chan. 2 (0852)

### Prerequisite

The **Extended HistoROM** application package is available.

The software options currently enabled are displayed in the **Software option overview** parameter (→ 38).

### Description

Options for the assignment of a process variable to the data logging channel.

### Selection

Picklist, see **Assign channel 1** parameter (→ 126)

### Factory setting

Off

---

**Assign channel 3**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Diagnostics → Data logging → Assign chan. 3 (0853)  |
| <b>Prerequisite</b>    | The <b>Extended HistoROM</b> application package is available.<br>The software options currently enabled are displayed in the <b>Software option overview</b> parameter (→  38). |
| <b>Description</b>     | Options for the assignment of a process variable to the data logging channel.  |
| <b>Selection</b>       | Picklist, see <b>Assign channel 1</b> parameter (→  126)   |
| <b>Factory setting</b> | Off  |

---

**Assign channel 4**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Diagnostics → Data logging → Assign chan. 4 (0854)  |
| <b>Prerequisite</b>    | The <b>Extended HistoROM</b> application package is available.<br>The software options currently enabled are displayed in the <b>Software option overview</b> parameter (→  38). |
| <b>Description</b>     | Options for the assignment of a process variable to the data logging channel.  |
| <b>Selection</b>       | Picklist, see <b>Assign channel 1</b> parameter (→  126)   |
| <b>Factory setting</b> | Off  |

---

**Logging interval**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Diagnostics → Data logging → Logging interval (0856)  |
| <b>Prerequisite</b>    | The <b>Extended HistoROM</b> application package is available.<br>The software options currently enabled are displayed in the <b>Software option overview</b> parameter (→  38). |
| <b>Description</b>     | Use this function to enter the logging interval $t_{log}$ for data logging.  |
| <b>User entry</b>      | 1.0 to 3 600.0 s   |
| <b>Factory setting</b> | 10.0 s   |

**Additional information****Description**

This defines the interval between the individual data points in the data log, and thus the maximum loggable process time  $T_{\log}$ :

- If 1 logging channel is used:  $T_{\log} = 1000 \times t_{\log}$
- If 2 logging channels are used:  $T_{\log} = 500 \times t_{\log}$
- If 3 logging channels are used:  $T_{\log} = 333 \times t_{\log}$
- If 4 logging channels are used:  $T_{\log} = 250 \times t_{\log}$

Once this time elapses, the oldest data points in the data log are cyclically overwritten such that a time of  $T_{\log}$  always remains in the memory (ring memory principle).

 The log contents are cleared if the length of the logging interval is changed.

**Example**

If 1 logging channel is used:

- $T_{\log} = 1000 \times 1 \text{ s} = 1000 \text{ s} \approx 15 \text{ min}$
- $T_{\log} = 1000 \times 10 \text{ s} = 10000 \text{ s} \approx 3 \text{ h}$
- $T_{\log} = 1000 \times 80 \text{ s} = 80000 \text{ s} \approx 1 \text{ d}$
- $T_{\log} = 1000 \times 3600 \text{ s} = 3600000 \text{ s} \approx 41 \text{ d}$

**Clear logging data****Navigation**

 Expert → Diagnostics → Data logging → Clear logging (0855)

**Prerequisite**

The **Extended HistoROM** application package is available.

 The software options currently enabled are displayed in the **Software option overview** parameter (→  38).

**Description**

Option to clear the entire logging data.

**Selection**

- Cancel
- Clear data

**Factory setting**

Cancel

**Additional information****Selection**

- Cancel  
The data is not cleared. All the data is retained.
- Clear data  
The logging data is cleared. The logging process starts from the beginning.


**"Display channel 1" submenu****Navigation**

Expert → Diagnostics → Data logging → Displ.channel 1

▶ Display channel 1

Display channel 1
→  129

## Display channel 1

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             | ④ Expert → Diagnostics → Data logging → Displ.channel 1  |
| <b>Prerequisite</b>           | The <b>Extended HistoROM</b> application package is available.<br>④ The software options currently enabled are displayed in the <b>Software option overview</b> parameter (→ ④ 38).<br>One of the following options is selected in the <b>Assign channel 1</b> parameter (→ ④ 126): <ul style="list-style-type: none"><li>■ Volume flow</li><li>■ Mass flow</li><li>■ Temperature</li><li>■ Current output</li></ul> |
| <b>Description</b>            | Displays the measured value trend for the logging channel in the form of a chart.  |
| <b>Additional information</b> | <i>Description</i>   |
|                               |  <p>A0016222</p> <ul style="list-style-type: none"><li>■ x-axis: depending on the number of channels selected displays 250 to 1000 measured values of a process variable.</li><li>■ y-axis: displays the approximate measured value span and constantly adapts this to the ongoing measurement.</li></ul>                          |

## "Display channel 2" submenu

|                     |  |                     |                           |
|---------------------|--|---------------------|---------------------------|
| <i>Navigation</i>   | ④ Expert → Diagnostics → Data logging → Displ.channel 2  |                     |                           |
|                     | <table border="1" style="width: 100%;"><tr><td style="padding: 5px;">▶ Display channel 2</td><td style="padding: 5px;">Display channel 2 → ④ 129</td></tr></table> | ▶ Display channel 2 | Display channel 2 → ④ 129 |
| ▶ Display channel 2 | Display channel 2 → ④ 129  |                     |                           |

## Display channel 2


|                     |   |
|---------------------|---|
| <b>Navigation</b>   | ④ Expert → Diagnostics → Data logging → Displ.channel 2                 |
| <b>Prerequisite</b> | A process variable is defined in the <b>Assign channel 2</b> parameter. |
| <b>Description</b>  | See the <b>Display channel 1</b> parameter → ④ 129                      |

### "Display channel 3" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3



---

## Display channel 3

---

Navigation



Expert → Diagnostics → Data logging → Displ.channel 3

Prerequisite

A process variable is defined in the **Assign channel 3** parameter.

Description

See the **Display channel 1** parameter → 129

### "Display channel 4" submenu

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4



---

## Display channel 4

---

Navigation



Expert → Diagnostics → Data logging → Displ.channel 4

Prerequisite

A process variable is defined in the **Assign channel 4** parameter.


Description

See the **Display channel 1** parameter → 129

### 3.7.5 "Min/max values" submenu

*Navigation*


Expert → Diagnostics → Min/max val.



#### "Electronic temperature" submenu

*Navigation*

Expert → Diagnostics → Min/max val. → Electronic temp.




---

#### Minimum value

---

**Navigation**

Expert → Diagnostics → Min/max val. → Electronic temp. → Minimum value (3445)

**Description**

Displays the lowest previously measured temperature value of the main electronics module.

**User interface**

-273.15 to 726.75 °C

**Additional information**

*Dependency*

The unit is taken from the **Temperature unit** parameter (→ 49)

---

#### Maximum value

---

**Navigation**

Expert → Diagnostics → Min/max val. → Electronic temp. → Maximum value (3444)

**Description**

Displays the highest previously measured temperature value of the main electronics module.

**User interface**


-273.15 to 726.75 °C

**Additional information***Dependency*

The unit is taken from the **Temperature unit** parameter (→ [49](#))

**"Process temperature" submenu****Navigation**

Expert → Diagnostics → Min/max val. → Process temp.



---

**Minimum value**

---

**Navigation**

Expert → Diagnostics → Min/max val. → Process temp. → Minimum value (3447)

**Description**

Displays the lowest previously measured process temperature.

**User interface**

-273.15 to 726.75 °C

**Additional information***Dependency*

The unit is taken from the **Temperature unit** parameter (→ [49](#))

---

**Maximum value**

---

**Navigation**

Expert → Diagnostics → Min/max val. → Process temp. → Maximum value (3446)

**Description**

Displays the highest previously measured process temperature.

**User interface**

-273.15 to 726.75 °C

**Additional information***Dependency*

The unit is taken from the **Temperature unit** parameter (→ [49](#))

### 3.7.6 "Simulation" submenu

*Navigation*

Expert → Diagnostics → Simulation

| ▶ Simulation                              |       |
|---|-------|
| Assign simulation process variable (1810) | → 133 |
| Value process variable (1811)             | → 134 |
| Simulation status input (1355)            | → 134 |
| Input signal level (1356)                 | → 135 |
| Simulation current output 1 (0354-1)      | → 135 |
| Value current output 1 (0355-1)           | → 135 |
| Frequency simulation (0472)               | → 136 |
| Frequency value (0473)                    | → 136 |
| Pulse simulation (0458)                   | → 137 |
| Pulse value (0459)                        | → 137 |
| Switch output simulation (0462)           | → 137 |
| Switch status (0463)                      | → 138 |
| Simulation device alarm (0654)            | → 138 |
| Diagnostic event category (0738)          | → 139 |
| Simulation diagnostic event (0737)        | → 139 |

#### Assign simulation process variable



**Navigation**

Expert → Diagnostics → Simulation → Assign proc.var. (1810)

**Description**

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

**Selection**

- Off
- Volume flow
- Mass flow
- Temperature

**Factory setting** Off

**Additional information** *Description*

 The simulation value of the process variable selected is defined in the **Value process variable** parameter (→ 134).

## Value process variable



**Navigation**  Expert → Diagnostics → Simulation → Value proc. var. (1811)

**Description** Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

**User entry** Depends on the process variable selected

**Factory setting** 0

**Additional information** *User entry*

 The unit of the displayed measured value is taken from the **System units** submenu (→ 45).

## Simulation status input



**Navigation**  Expert → Diagnostics → Simulation → Sim. status inp. (1355)

**Prerequisite** For the following order code:  
"Output; input", option Q "4-20mA HART, pul./freq./switch; status input"

**Description** Use this function to switch simulation of the status input on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

**Selection**

- Off
- On

**Factory setting** Off

**Additional information** *Description*

 The desired simulation value is defined in the **Input signal level** parameter (→ 135).

*Selection*

- Off  
Simulation for the status input is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On  
Simulation for the status input is active.

**Input signal level**

|                        |  |
|------------------------|--|
| <b>Navigation</b>      | Expert → Diagnostics → Simulation → Signal level (1356)  |
| <b>Prerequisite</b>    | In the <b>Simulation status input</b> parameter (→ 134), the <b>On</b> option is selected.   |
| <b>Description</b>     | Use this function to select the signal level for the simulation of the status input. In this way, users can verify the correct configuration of the status input and the correct function of upstream feed-in units. |
| <b>Selection</b>       | <ul style="list-style-type: none"> <li>▪ High</li> <li>▪ Low</li> </ul>  |
| <b>Factory setting</b> | High   |

**Simulation current output 1**

|                               |  |
|-------------------------------|--|
| <b>Navigation</b>             | Expert → Diagnostics → Simulation → Sim.curr.out. 1 (0354-1)   |
| <b>Description</b>            | Use this function to switch simulation of the current output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.  |
| <b>Selection</b>              | <ul style="list-style-type: none"> <li>▪ Off</li> <li>▪ On</li> </ul>  |
| <b>Factory setting</b>        | Off  |
| <b>Additional information</b> | <p><i>Description</i></p> <p> The desired simulation value is specified in the <b>Value current output 1</b> parameter (→ 135).</p> <p><i>Selection</i></p> <ul style="list-style-type: none"> <li>▪ Off<br/>Current simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.</li> <li>▪ On<br/>Current simulation is active.</li> </ul> |

**Value current output 1**

|                     |   |
|---------------------|---|
| <b>Navigation</b>   | Expert → Diagnostics → Simulation → Value curr.out 1 (0355-1)   |
| <b>Prerequisite</b> | In the <b>Simulation current output 1</b> parameter, the <b>On</b> option is selected.  |
| <b>Description</b>  | Use this function to enter a current value for the simulation. In this way, users can verify the correct adjustment of the current output and the correct function of downstream switching units. |

---

|            |                 |
|------------|-----------------|
| User entry | 3.59 to 22.5 mA |
|------------|-----------------|

---

## Frequency simulation



**Navigation** Expert → Diagnostics → Simulation → Frequency sim. (0472)

**Prerequisite** In the **Operating mode** parameter (→ 83), the **Frequency** option is selected.

**Description** Use this function to switch simulation of the frequency output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

- Selection**
- Off
  - On

**Factory setting** Off

**Additional information** *Description*

The desired simulation value is defined in the **Frequency value** parameter (→ 136).

*Selection*

- Off  
Frequency simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- On  
Frequency simulation is active.

---

## Frequency value



**Navigation** Expert → Diagnostics → Simulation → Freq. value (0473)

**Prerequisite** In the **Frequency simulation** parameter (→ 136), the **On** option is selected.

**Description** Use this function to enter a frequency value for the simulation. In this way, users can verify the correct adjustment of the frequency output and the correct function of downstream switching units.

**User entry** 0.0 to 1250.0 Hz

**Factory setting** 0.0 Hz

---

**Pulse simulation****Navigation**

Expert → Diagnostics → Simulation → Pulse sim. (0458)

**Prerequisite**In the **Operating mode** parameter (→ 83), the **Pulse** option is selected.**Description**

Use this function to switch simulation of the pulse output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

**Selection**

- Off
- Fixed value
- Down-counting value

**Factory setting** Off**Additional information***Description* The desired simulation value is defined in the **Pulse value** parameter (→ 137).*Selection*

- Off  
Pulse simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.
- Fixed value  
Pulses are continuously output with the pulse width specified in the **Pulse width** parameter (→ 85).
- Down-counting value  
The pulses specified in the **Pulse value** parameter (→ 137) are output.

---

**Pulse value****Navigation**

Expert → Diagnostics → Simulation → Pulse value (0459)

**Prerequisite**In the **Pulse simulation** parameter (→ 137), the **Down-counting value** option is selected.**Description**

Use this function to enter a pulse value for the simulation. In this way, users can verify the correct adjustment of the pulse output and the correct function of downstream switching units.

**User entry**

0 to 65 535

---

**Switch output simulation****Navigation**

Expert → Diagnostics → Simulation → Switch sim. (0462)

**Prerequisite**In the **Operating mode** parameter (→ 83), the **Switch** option is selected.

---

|                               |   |
|-------------------------------|---|
| <b>Description</b>            | Use this function to switch simulation of the switch output on and off. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.                                  |
| <b>Selection</b>              | <ul style="list-style-type: none"><li>▪ Off</li><li>▪ On</li></ul>  |
| <b>Factory setting</b>        | Off   |
| <b>Additional information</b> | <p><i>Description</i></p> <p> The desired simulation value is defined in the <b>Switch status</b> parameter (→ 138).</p>   |
|                               | <p><i>Selection</i></p> <ul style="list-style-type: none"><li>▪ Off<br/>Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.</li><li>▪ On<br/>Switch simulation is active.</li></ul> |

---

|                               |  |
|-------------------------------|--|
| <b>Switch status</b>          |   |
| <b>Navigation</b>             |  Expert → Diagnostics → Simulation → Switch status (0463)   |
| <b>Prerequisite</b>           | In the <b>Switch output simulation</b> parameter (→ 137), the <b>On</b> option is selected.  |
| <b>Description</b>            | Use this function to select a switch value for the simulation. In this way, users can verify the correct adjustment of the switch output and the correct function of downstream switching units.   |
| <b>Selection</b>              | <ul style="list-style-type: none"><li>▪ Open</li><li>▪ Closed</li></ul>  |
| <b>Factory setting</b>        | Open   |
| <b>Additional information</b> | <p><i>Selection</i></p> <ul style="list-style-type: none"><li>▪ Open<br/>Switch simulation is switched off. The device is in normal measuring mode or another process variable is being simulated.</li><li>▪ Closed<br/>Switch simulation is active.</li></ul> |

---

|                                |   |
|--------------------------------|---|
| <b>Simulation device alarm</b> |    |
| <b>Navigation</b>              |  Expert → Diagnostics → Simulation → Sim. alarm (0654) |
| <b>Description</b>             | Use this function to switch the device alarm on and off.  |

|                               |  |
|-------------------------------|--|
| <b>Selection</b>              | <ul style="list-style-type: none"><li>■ Off</li><li>■ On</li></ul>   |
| <b>Factory setting</b>        | Off  |
| <b>Additional information</b> | <i>Description</i><br>The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress. |

---

### Diagnostic event category

---

|                        |  |
|------------------------|--|
| <b>Navigation</b>      |  Expert → Diagnostics → Simulation → Event category (0738)                          |
| <b>Description</b>     | Use this function to select the category of the diagnostic events that are displayed for the simulation in the <b>Simulation diagnostic event</b> parameter (→ 139). |
| <b>Selection</b>       | <ul style="list-style-type: none"><li>■ Sensor</li><li>■ Electronics</li><li>■ Configuration</li><li>■ Process</li></ul>   |
| <b>Factory setting</b> | Sensor   |

---

### Simulation diagnostic event

---

|                               |   |
|-------------------------------|---|
| <b>Navigation</b>             |  Expert → Diagnostics → Simulation → Sim. diag. event (0737)   |
| <b>Description</b>            | Use this function to select a diagnostic event for the simulation process that is activated.  |
| <b>Selection</b>              | <ul style="list-style-type: none"><li>■ Off</li><li>■ Diagnostic event picklist (depends on the category selected)</li></ul>  |
| <b>Factory setting</b>        | Off   |
| <b>Additional information</b> | <i>Description</i><br> For the simulation, you can choose from the diagnostic events of the category selected in the <b>Diagnostic event category</b> parameter (→ 139). |

## 4 Country-specific factory settings

### 4.1 SI units

**i** Not valid for USA and Canada.

#### 4.1.1 System units

|             |                   |
|-------------|-------------------|
| Volume flow | l/h               |
| Volume      | l                 |
| Mass flow   | kg/h              |
| Mass        | kg                |
| Density     | kg/m <sup>3</sup> |
| Temperature | °C                |
| Length      | mm                |

#### 4.1.2 Full scale values

**i** The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

*t-mass T*

| DN<br>[mm] | [l/h]  |
|------------|--------|
| 50         | 35200  |
| 150        | 317000 |

#### 4.1.3 Output current span

|                  |                  |
|------------------|------------------|
| Current output 1 | 4 to 20 mA NAMUR |
|------------------|------------------|

#### 4.1.4 Pulse value

*t-mass T*

| Nominal diameter<br>[mm] | [l] |
|--------------------------|-----|
| 50                       | 1   |
| 150                      | 100 |

#### 4.1.5 On value low flow cut off

**i** The switch-on point depends on the type of medium and the nominal diameter.

*t-mass T*

| Nominal diameter<br>[mm] | [l/h] |
|--------------------------|-------|
| 50                       | 352   |
| 150                      | 3170  |

**4.2 US units**

 Only valid for USA and Canada.

**4.2.1 System units**

|             |                    |
|-------------|--------------------|
| Volume flow | gal/min (us)       |
| Volume      | gal (us)           |
| Mass flow   | lb/min             |
| Mass        | lb                 |
| Density     | lb/ft <sup>3</sup> |
| Temperature | °F                 |
| Length      | in                 |

**4.2.2 Full scale values**

 The factory settings apply to the following parameters:

- 20 mA value (full scale value of the current output)
- 100% bar graph value 1

*t-mass T*

| DN<br>[in] | [gal(us)/h] |
|------------|-------------|
| 2          | 9300        |
| 6          | 84000       |

**4.2.3 Output current span**

|                  |               |
|------------------|---------------|
| Current output 1 | 4 to 20 mA US |
|------------------|---------------|

**4.2.4 Pulse value***t-mass T*

| Nominal diameter<br>[in] | [gal(us)] |
|--------------------------|-----------|
| 2                        | 5         |
| 6                        | 50        |

**4.2.5 On value low flow cut off**

 The switch-on point depends on the type of medium and the nominal diameter.

*t-mass T*

| Nominal diameter<br>[in] | [gal(us)/h] |
|--------------------------|-------------|
| 2                        | 93          |
| 6                        | 840         |

## 5 Explanation of abbreviated units

### 5.1 SI units

| Process variable | Units  | Explanation                                    |
|------------------|--|--|
| Density          | g/cm <sup>3</sup>  | Gram/volume unit                               |
|                  | kg/l, kg/dm <sup>3</sup> , kg/m <sup>3</sup>                                     | Kilogram/volume unit                           |
| Length           | mm, m  | Millimeter, meter                              |
| Mass             | g, kg, t   | Gram, kilogram, metric ton                     |
| Mass flow        | g/s, g/min, g/h, g/d   | Gram/time unit                                 |
|                  | kg/s, kg/min, kg/h, kg/d   | Kilogram/time unit                             |
|                  | t/s, t/min, t/h, t/d   | Metric ton/time unit                           |
| Temperature      | °C, K  | Celsius, Kelvin                                |
| Volume           | cm <sup>3</sup> , dm <sup>3</sup> , m <sup>3</sup>                               | Cubic centimeter, cubic decimeter, cubic meter |
|                  | ml, l, hl, Ml Mega   | Milliliter, liter, hectoliter, megaliter       |
| Volume flow      | cm <sup>3</sup> /s, cm <sup>3</sup> /min, cm <sup>3</sup> /h, cm <sup>3</sup> /d | Cubic centimeter/time unit                     |
|                  | dm <sup>3</sup> /s, dm <sup>3</sup> /min, dm <sup>3</sup> /h, dm <sup>3</sup> /d | Cubic decimeter/time unit                      |
|                  | m <sup>3</sup> /s, m <sup>3</sup> /min, m <sup>3</sup> /h, m <sup>3</sup> /d     | Cubic meter/time unit                          |
|                  | ml/s, ml/min, ml/h, ml/d   | Milliliter/time unit                           |
|                  | l/s, l/min, l/h, l/d   | Liter/time unit                                |
|                  | hl/s, hl/min, hl/h, hl/d   | Hectoliter/time unit                           |
|                  | Ml/s, Ml/min, Ml/h, Ml/d   | Megaliter/time unit                            |
| Time             | s, m, h, d, y  | Second, minute, hour, day, year                |

### 5.2 US units

| Process variable | Units  | Explanation   |
|------------------|--|---|
| Density          | lb/ft <sup>3</sup>   | Pound/cubic foot  |
| Length           | in, ft   | Inch, foot  |
| Mass             | oz, lb, STon   | Ounce, pound, standard ton  |
| Mass flow        | oz/s, oz/min, oz/h, oz/d   | Ounce/time unit   |
|                  | lb/s, lb/min, lb/h, lb/d   | Pound/time unit   |
|                  | STon/s, STon/min, STon/h, STon/d   | Standard ton/time unit  |
| Temperature      | °F, °R   | Fahrenheit, Rankine   |
| Volume           | af   | Acre foot   |
|                  | ft <sup>3</sup>  | Cubic foot  |
|                  | fl oz (us), gal (us), kgal (us), Mgal (us)                                       | Fluid ounce, gallon, kilogallon, million gallon   |
|                  | bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)                        | Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks) |
| Volume flow      | af/s, af/min, af/h, af/d   | Acre foot/time unit   |
|                  | ft <sup>3</sup> /s, ft <sup>3</sup> /min, ft <sup>3</sup> /h, ft <sup>3</sup> /d | Cubic foot/time unit  |
|                  | fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)                         | Fluid ounce/time unit   |

| Process variable | Units  | Explanation   |
|------------------|--|---|
|                  | gal/s (us), gal/min (us), gal/h (us), gal/d (us)                     | Gallon/time unit  |
|                  | kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)                 | Kilogallon/time unit  |
|                  | Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)                 | Million gallon/time unit  |
|                  | bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.) | Barrel/time unit (normal liquids)<br>Normal liquids: 31.5 gal/bbl |
|                  | bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer) | Barrel /time unit (beer)<br>Beer: 31.0 gal/bbl                    |
|                  | bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)     | Barrel/time unit (petrochemicals)<br>Petrochemicals: 42.0 gal/bbl |
|                  | bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank) | Barrel/time unit (filling tank)<br>Filling tanks: 55.0 gal/bbl    |
| Time             | s, m, h, d, y  | Second, minute, hour, day, year                                   |
|                  | am, pm   | Ante meridiem ( before midday), post meridiem (after midday)      |

### 5.3 Imperial units

| Process variable | Units  | Explanation  |
|------------------|--|--|
| Mass             | LTon   | Long ton   |
| Mass flow        | LTon/s, LTon/min, LTon/h, LTon/d                                     | Long ton/time unit   |
| Volume           | gal (imp), Mgal (imp)  | Gallon, mega gallon  |
|                  | bbl (imp;oil)  | Barrel (petrochemicals)  |
| Volume flow      | gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)                 | Gallon/time unit   |
|                  | Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)             | Mega gallon/time unit  |
|                  | bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil) | Barrel/time unit (petrochemicals)<br>Petrochemicals: 34.97 gal/bbl |
| Time             | s, m, h, d, y  | Second, minute, hour, day, year                                    |
|                  | am, pm   | Ante meridiem (before midday), post meridiem (after midday)        |

# Index

## 0 ... 9

|   |    |
|---|----|
| 0% bargraph value 1 (Parameter) . . . . .   | 17 |
| 0% bargraph value 3 (Parameter) . . . . .   | 20 |
| 4 mA value (Parameter) . . . . .            | 76 |
| 20 mA value (Parameter) . . . . .           | 77 |
| 100% bargraph value 1 (Parameter) . . . . . | 18 |
| 100% bargraph value 3 (Parameter) . . . . . | 20 |

## A

|   |         |
|---|---------|
| Access status display (Parameter) . . . . .                 | 11, 25  |
| Access status tooling (Parameter) . . . . .                 | 12      |
| Activate SW option (Parameter) . . . . .                    | 37      |
| Active level (Parameter) . . . . .                          | 73      |
| Actual diagnostics (Parameter) . . . . .                    | 112     |
| Adjustment values in use (Submenu) . . . . .                | 60      |
| Administration (Submenu) . . . . .                          | 34      |
| Alarm delay (Parameter) . . . . .                           | 30      |
| Application (Submenu) . . . . .                             | 108     |
| Apply (Parameter) . . . . .                                 | 71      |
| Assign behavior of diagnostic no. 441 (Parameter) . . . . . | 31      |
| Assign behavior of diagnostic no. 442 (Parameter) . . . . . | 31      |
| Assign behavior of diagnostic no. 443 (Parameter) . . . . . | 32      |
| Assign behavior of diagnostic no. 832 (Parameter) . . . . . | 32      |
| Assign behavior of diagnostic no. 833 (Parameter) . . . . . | 32      |
| Assign behavior of diagnostic no. 834 (Parameter) . . . . . | 33      |
| Assign behavior of diagnostic no. 835 (Parameter) . . . . . | 33      |
| Assign behavior of diagnostic no. 862 (Parameter) . . . . . | 34      |
| Assign channel 1 (Parameter) . . . . .                      | 126     |
| Assign channel 2 (Parameter) . . . . .                      | 126     |
| Assign channel 3 (Parameter) . . . . .                      | 127     |
| Assign channel 4 (Parameter) . . . . .                      | 127     |
| Assign current output (Parameter) . . . . .                 | 74      |
| Assign diagnostic behavior (Parameter) . . . . .            | 92      |
| Assign frequency output (Parameter) . . . . .               | 87      |
| Assign limit (Parameter) . . . . .                          | 93      |
| Assign process variable (Parameter) . . . . .               | 55, 108 |
| Assign pulse output (Parameter) . . . . .                   | 84      |
| Assign PV (Parameter) . . . . .                             | 105     |
| Assign QV (Parameter) . . . . .                             | 107     |
| Assign simulation process variable (Parameter) . . . . .    | 133     |
| Assign status (Parameter) . . . . .                         | 96      |
| Assign status input (Parameter) . . . . .                   | 72      |
| Assign SV (Parameter) . . . . .                             | 106     |
| Assign TV (Parameter) . . . . .                             | 106     |

## B

|                                     |     |
|-------------------------------------|-----|
| Backlight (Parameter) . . . . .     | 25  |
| Backup state (Parameter) . . . . .  | 28  |
| Burst command (Parameter) . . . . . | 100 |
| Burst mode (Parameter) . . . . .    | 99  |

## C

|   |     |
|---|-----|
| Calibration (Submenu) . . . . .             | 71  |
| Calibration date/time (Parameter) . . . . . | 71  |
| CIP/SIP (Submenu) . . . . .                 | 111 |
| CIP/SIP mode (Parameter) . . . . .          | 112 |

|  |     |
|--|-----|
| Clear logging data (Parameter) . . . . .         | 128 |
| Clear values (Parameter) . . . . .               | 66  |
| Communication (Submenu) . . . . .                | 98  |
| Comparison result (Parameter) . . . . .          | 28  |
| Configuration (Submenu) . . . . .                | 99  |
| Configuration backup display (Submenu) . . . . . | 26  |
| Configuration counter (Parameter) . . . . .      | 125 |
| Configuration management (Parameter) . . . . .   | 27  |
| Confirm access code (Parameter) . . . . .        | 35  |
| Contrast display (Parameter) . . . . .           | 25  |
| Control Totalizer (Parameter) . . . . .          | 110 |
| Current output 1 (Submenu) . . . . .             | 73  |
| Current span (Parameter) . . . . .               | 74  |

## D

|   |          |
|---|----------|
| Damping output (Parameter) . . . . .            | 77, 90   |
| Data logging (Submenu) . . . . .                | 125      |
| Data validity (Parameter) . . . . .             | 70       |
| Date/time format (Parameter) . . . . .          | 50       |
| Decimal places 1 (Parameter) . . . . .          | 18       |
| Decimal places 2 (Parameter) . . . . .          | 19       |
| Decimal places 3 (Parameter) . . . . .          | 21       |
| Decimal places 4 (Parameter) . . . . .          | 22       |
| Define access code (Parameter) . . . . .        | 35, 36   |
| Define access code (Wizard) . . . . .           | 34       |
| Density unit (Parameter) . . . . .              | 49       |
| Device ID (Parameter) . . . . .                 | 102      |
| Device information (Submenu) . . . . .          | 121      |
| Device name (Parameter) . . . . .               | 123      |
| Device reset (Parameter) . . . . .              | 36       |
| Device revision (Parameter) . . . . .           | 102      |
| Device tag (Parameter) . . . . .                | 100, 122 |
| Device type (Parameter) . . . . .               | 102      |
| Diagnostic behavior (Submenu) . . . . .         | 30       |
| Diagnostic event category (Parameter) . . . . . | 139      |
| Diagnostic handling (Submenu) . . . . .         | 29       |
| Diagnostic list (Submenu) . . . . .             | 115      |
| Diagnostics (Submenu) . . . . .                 | 112      |
| Diagnostics 1 (Parameter) . . . . .             | 115      |
| Diagnostics 2 (Parameter) . . . . .             | 116      |
| Diagnostics 3 (Parameter) . . . . .             | 117      |
| Diagnostics 4 (Parameter) . . . . .             | 117      |
| Diagnostics 5 (Parameter) . . . . .             | 118      |

## Direct access

|  |        |
|--|--------|
| 0% bargraph value 1 (0123) . . . . .   | 17     |
| 0% bargraph value 3 (0124) . . . . .   | 20     |
| 4 mA value (0367) . . . . .            | 76     |
| 20 mA value (0372) . . . . .           | 77     |
| 100% bargraph value 1 (0125) . . . . . | 18     |
| 100% bargraph value 3 (0126) . . . . . | 20     |
| Access status display (0091) . . . . . | 11, 25 |
| Access status tooling (0005) . . . . . | 12     |
| Activate SW option (0029) . . . . .    | 37     |
| Active level (1351) . . . . .          | 73     |
| Actual diagnostics (0691) . . . . .    | 112    |
| Alarm delay (0651) . . . . .           | 30     |

|  |     |
|--|-----|
| Apply (3528) . . . . .                                 | 71  |
| Assign behavior of diagnostic no. 441 (0657) . . . . . | 31  |
| Assign behavior of diagnostic no. 442 (0658) . . . . . | 31  |
| Assign behavior of diagnostic no. 443 (0659) . . . . . | 32  |
| Assign behavior of diagnostic no. 832 (0675) . . . . . | 32  |
| Assign behavior of diagnostic no. 833 (0676) . . . . . | 32  |
| Assign behavior of diagnostic no. 834 (0677) . . . . . | 33  |
| Assign behavior of diagnostic no. 835 (0678) . . . . . | 33  |
| Assign behavior of diagnostic no. 862 (0679) . . . . . | 34  |
| Assign channel 1 (0851) . . . . .                      | 126 |
| Assign channel 2 (0852) . . . . .                      | 126 |
| Assign channel 3 (0853) . . . . .                      | 127 |
| Assign channel 4 (0854) . . . . .                      | 127 |
| Assign current output (0359) . . . . .                 | 74  |
| Assign diagnostic behavior (0482) . . . . .            | 92  |
| Assign frequency output (0478) . . . . .               | 87  |
| Assign limit (0483) . . . . .                          | 93  |
| Assign process variable (0914) . . . . .               | 108 |
| Assign process variable (1837) . . . . .               | 55  |
| Assign pulse output (0460) . . . . .                   | 84  |
| Assign PV (0234) . . . . .                             | 105 |
| Assign QV (0237) . . . . .                             | 107 |
| Assign simulation process variable (1810) . . . . .    | 133 |
| Assign status (0485) . . . . .                         | 96  |
| Assign status input (1352) . . . . .                   | 72  |
| Assign SV (0235) . . . . .                             | 106 |
| Assign TV (0236) . . . . .                             | 106 |
| Backlight (0111) . . . . .                             | 25  |
| Backup state (0121) . . . . .                          | 28  |
| Burst command (0207) . . . . .                         | 100 |
| Burst mode (0208) . . . . .                            | 99  |
| Calibration date/time (3436) . . . . .                 | 71  |
| CIP/SIP mode (3536) . . . . .                          | 112 |
| Clear logging data (0855) . . . . .                    | 128 |
| Clear values (3529) . . . . .                          | 66  |
| Comparison result (0103) . . . . .                     | 28  |
| Configuration counter (0233) . . . . .                 | 125 |
| Configuration management (0100) . . . . .              | 27  |
| Contrast display (0105) . . . . .                      | 25  |
| Control Totalizer (0912) . . . . .                     | 110 |
| Current span (0353) . . . . .                          | 74  |
| Damping output (0363) . . . . .                        | 77  |
| Damping output (0477) . . . . .                        | 90  |
| Data validity (3434) . . . . .                         | 70  |
| Date/time format (2812) . . . . .                      | 50  |
| Decimal places 1 (0095) . . . . .                      | 18  |
| Decimal places 2 (0117) . . . . .                      | 19  |
| Decimal places 3 (0118) . . . . .                      | 21  |
| Decimal places 4 (0119) . . . . .                      | 22  |
| Define access code . . . . .                           | 36  |
| Density unit (0555) . . . . .                          | 49  |
| Device ID (0221) . . . . .                             | 102 |
| Device name (0013) . . . . .                           | 123 |
| Device reset (0000) . . . . .                          | 36  |
| Device revision (0204) . . . . .                       | 102 |
| Device tag (0011) . . . . .                            | 122 |
| Device tag (0215) . . . . .                            | 100 |
| Device type (0222) . . . . .                           | 102 |
| Diagnostic event category (0738) . . . . .             | 139 |
| Diagnostics 1 (0692) . . . . .                         | 115 |
| Diagnostics 2 (0693) . . . . .                         | 116 |
| Diagnostics 3 (0694) . . . . .                         | 117 |
| Diagnostics 4 (0695) . . . . .                         | 117 |
| Diagnostics 5 (0696) . . . . .                         | 118 |
| Direct access (0106) . . . . .                         | 10  |
| Display damping (0094) . . . . .                       | 23  |
| Display interval (0096) . . . . .                      | 22  |
| ENP version (0012) . . . . .                           | 124 |
| Enter access code (0003) . . . . .                     | 13  |
| Enter access code (0092) . . . . .                     | 13  |
| Extended order code 1 (0023) . . . . .                 | 124 |
| Extended order code 2 (0021) . . . . .                 | 124 |
| Extended order code 3 (0022) . . . . .                 | 124 |
| Failure current (0352) . . . . .                       | 80  |
| Failure frequency (0474) . . . . .                     | 91  |
| Failure mode (0364) . . . . .                          | 79  |
| Failure mode (0451) . . . . .                          | 91  |
| Failure mode (0480) . . . . .                          | 86  |
| Failure mode (0486) . . . . .                          | 97  |
| Failure mode (0901) . . . . .                          | 111 |
| Filter options . . . . .                               | 120 |
| Filter options (0705) . . . . .                        | 119 |
| Firmware version (0010) . . . . .                      | 123 |
| Fixed current (0365) . . . . .                         | 75  |
| Flow damping (1802) . . . . .                          | 54  |
| Flow override (1839) . . . . .                         | 54  |
| Flow reference in use (3440) . . . . .                 | 60  |
| Flow reference value 1 (3384) . . . . .                | 66  |
| Flow reference value 1 (3401) . . . . .                | 61  |
| Flow reference value 2 (3385) . . . . .                | 67  |
| Flow reference value 2 (3418) . . . . .                | 61  |
| Flow reference value 3 (3386) . . . . .                | 67  |
| Flow reference value 3 (3419) . . . . .                | 62  |
| Flow reference value 4 (3387) . . . . .                | 68  |
| Flow reference value 4 (3420) . . . . .                | 62  |
| Flow reference value 5 (3388) . . . . .                | 68  |
| Flow reference value 5 (3421) . . . . .                | 62  |
| Flow reference value 6 (3389) . . . . .                | 69  |
| Flow reference value 6 (3422) . . . . .                | 63  |
| Flow reference value 7 (3390) . . . . .                | 69  |
| Flow reference value 7 (3423) . . . . .                | 63  |
| Flow reference value 8 (3391) . . . . .                | 70  |
| Flow reference value 8 (3424) . . . . .                | 64  |
| Format display (0098) . . . . .                        | 15  |
| Frequency simulation (0472) . . . . .                  | 136 |
| Frequency value (0473) . . . . .                       | 136 |
| Hardware revision (0206) . . . . .                     | 104 |
| HART address (0219) . . . . .                          | 101 |
| HART date code (0202) . . . . .                        | 104 |
| HART descriptor (0212) . . . . .                       | 103 |
| HART message (0216) . . . . .                          | 103 |
| HART revision (0205) . . . . .                         | 103 |
| HART short tag (0220) . . . . .                        | 100 |
| Header (0097) . . . . .                                | 23  |
| Header text (0112) . . . . .                           | 24  |
| Input signal level (1356) . . . . .                    | 135 |
| Insertion depth (3406) . . . . .                       | 58  |
| Installation factor (3470) . . . . .                   | 57  |

|   |         |  |                                   |
|---|---------|--|-----------------------------------|
| Invert output signal (0470) . . . . .                 | 98      | Secondary variable (SV) (0226) . . . . .       | 106                               |
| Language (0104) . . . . .                             | 14      | Select flow reference (3382) . . . . .         | 65                                |
| Last backup (0102) . . . . .                          | 27      | Separator (0101) . . . . .                     | 24                                |
| Length unit (0551) . . . . .                          | 50      | Serial number (0009) . . . . .                 | 122                               |
| Locking status (0004) . . . . .                       | 11      | Simulation current output 1 (0354-1) . . . . . | 135                               |
| Logging interval (0856) . . . . .                     | 127     | Simulation device alarm (0654) . . . . .       | 138                               |
| Manufacturer ID (0223) . . . . .                      | 103     | Simulation diagnostic event (0737) . . . . .   | 139                               |
| Mass flow (1838) . . . . .                            | 40      | Simulation status input (1355) . . . . .       | 134                               |
| Mass flow unit (0554) . . . . .                       | 48      | Software option overview (0015) . . . . .      | 38                                |
| Mass unit (0574) . . . . .                            | 48      | Software revision (0224) . . . . .             | 104                               |
| Maximum frequency value (0454) . . . . .              | 88      | Start-up current (0369) . . . . .              | 81                                |
| Maximum value (3444) . . . . .                        | 131     | Start-up mode (0368) . . . . .                 | 80                                |
| Maximum value (3446) . . . . .                        | 132     | Switch output function (0481) . . . . .        | 92                                |
| Measuring value at maximum frequency (0475) . . . . . | 89      | Switch output simulation (0462) . . . . .      | 137                               |
| Measuring value at minimum frequency (0476) . . . . . | 89      | Switch status (0461) . . . . .                 | 44, 97                            |
| Minimum frequency value (0453) . . . . .              | 88      | Switch status (0463) . . . . .                 | 138                               |
| Minimum value (3445) . . . . .                        | 131     | Switch-off delay (0465) . . . . .              | 97                                |
| Minimum value (3447) . . . . .                        | 132     | Switch-off value (0464) . . . . .              | 95                                |
| Mounting set height (3435) . . . . .                  | 58      | Switch-on delay (0467) . . . . .               | 96                                |
| No. of preambles (0217) . . . . .                     | 101     | Switch-on value (0466) . . . . .               | 95                                |
| Off value low flow cutoff (1804) . . . . .            | 56      | Temperature (1853) . . . . .                   | 40                                |
| On value low flow cutoff (1805) . . . . .             | 55      | Temperature unit (0557) . . . . .              | 49                                |
| Operating mode (0469) . . . . .                       | 83      | Tertiary variable (TV) (0228) . . . . .        | 107                               |
| Operating mode (3400) . . . . .                       | 59      | Timestamp . . . . .                            | 113, 114, 115, 116, 117, 118, 119 |
| Operating time (0652) . . . . .                       | 26, 114 | Totalizer overflow (0910) . . . . .            | 42                                |
| Operating time from restart (0653) . . . . .          | 114     | Totalizer value (0911) . . . . .               | 41                                |
| Order code (0008) . . . . .                           | 123     | Unit totalizer (0915) . . . . .                | 109                               |
| Output current (0361) . . . . .                       | 43      | User mass factor (0561) . . . . .              | 53                                |
| Output current 1 (0361-1) . . . . .                   | 80      | User mass offset (0562) . . . . .              | 53                                |
| Output frequency (0471) . . . . .                     | 44, 92  | User mass text (0560) . . . . .                | 52                                |
| Pipe wall thickness (3409) . . . . .                  | 57      | User volume factor (0568) . . . . .            | 52                                |
| Power coefficient 1 (3392) . . . . .                  | 66      | User volume offset (0569) . . . . .            | 52                                |
| Power coefficient 1 (3425) . . . . .                  | 61      | User volume text (0567) . . . . .              | 51                                |
| Power coefficient 2 (3393) . . . . .                  | 67      | Value 1 display (0107) . . . . .               | 17                                |
| Power coefficient 2 (3426) . . . . .                  | 61      | Value 2 display (0108) . . . . .               | 18                                |
| Power coefficient 3 (3394) . . . . .                  | 67      | Value 3 display (0110) . . . . .               | 19                                |
| Power coefficient 3 (3427) . . . . .                  | 62      | Value 4 display (0109) . . . . .               | 21                                |
| Power coefficient 4 (3395) . . . . .                  | 68      | Value current output 1 (0355-1) . . . . .      | 135                               |
| Power coefficient 4 (3428) . . . . .                  | 62      | Value per pulse (0455) . . . . .               | 85                                |
| Power coefficient 5 (3396) . . . . .                  | 68      | Value process variable (1811) . . . . .        | 134                               |
| Power coefficient 5 (3429) . . . . .                  | 63      | Value status input (1353) . . . . .            | 42, 72                            |
| Power coefficient 6 (3397) . . . . .                  | 69      | Volume flow (1850) . . . . .                   | 40                                |
| Power coefficient 6 (3430) . . . . .                  | 63      | Volume flow unit (0553) . . . . .              | 45                                |
| Power coefficient 7 (3398) . . . . .                  | 69      | Volume unit (0563) . . . . .                   | 47                                |
| Power coefficient 7 (3431) . . . . .                  | 64      | Direct access (Parameter) . . . . .            | 10                                |
| Power coefficient 8 (3399) . . . . .                  | 70      | Display (Submenu) . . . . .                    | 13                                |
| Power coefficient 8 (3432) . . . . .                  | 64      | Display channel 1 (Submenu) . . . . .          | 128                               |
| Preset value (0913) . . . . .                         | 110     | Display channel 2 (Submenu) . . . . .          | 129                               |
| Previous diagnostics (0690) . . . . .                 | 113     | Display channel 3 (Submenu) . . . . .          | 130                               |
| Primary variable (PV) (0201) . . . . .                | 105     | Display channel 4 (Submenu) . . . . .          | 130                               |
| Pulse output (0456) . . . . .                         | 43, 87  | Display damping (Parameter) . . . . .          | 23                                |
| Pulse simulation (0458) . . . . .                     | 137     | Display interval (Parameter) . . . . .         | 22                                |
| Pulse value (0459) . . . . .                          | 137     | Document                                       |                                   |
| Pulse width (0452) . . . . .                          | 85      | Explanation of the structure of a parameter    |                                   |
| Quaternary variable (QV) (0203) . . . . .             | 107     | description . . . . .                          | 6                                 |
| Reset write protection (0019) . . . . .               | 38      | Function . . . . .                             | 4                                 |
| Response time (0378) . . . . .                        | 78      | Structure . . . . .                            | 4                                 |
| Response time (0491) . . . . .                        | 90      | Symbols used . . . . .                         | 6                                 |
| Response time status input (1354) . . . . .           | 73      | Target group . . . . .                         | 4                                 |

|  |                     |  |          |  |
|--|---------------------|--|----------|--|
| Using the document . . . . .                               | 4                   | Installation settings (Submenu) . . . . .                  | 57       |  |
| Document function . . . . .                                | 4                   | Invert output signal (Parameter) . . . . .                 | 98       |  |
| <b>E</b>   |                     |  |          |  |
| Electronic temperature (Submenu) . . . . .                 | 131                 | Language (Parameter) . . . . .                             | 14       |  |
| ENP version (Parameter) . . . . .                          | 124                 | Last backup (Parameter) . . . . .                          | 27       |  |
| Enter access code (Parameter) . . . . .                    | 13                  | Length unit (Parameter) . . . . .                          | 50       |  |
| Event list (Submenu) . . . . .                             | 120                 | Locking status (Parameter) . . . . .                       | 11       |  |
| Event logbook (Submenu) . . . . .                          | 119                 | Logging interval (Parameter) . . . . .                     | 127      |  |
| Extended order code 1 (Parameter) . . . . .                | 124                 | Low flow cut off (Submenu) . . . . .                       | 55       |  |
| Extended order code 2 (Parameter) . . . . .                | 124                 |  |          |  |
| Extended order code 3 (Parameter) . . . . .                | 124                 |  |          |  |
| <b>F</b>   |                     |  |          |  |
| Factory settings . . . . .                                 | 140                 | Manufacturer ID (Parameter) . . . . .                      | 103      |  |
| SI units . . . . .   | 140                 | Mass flow (Parameter) . . . . .                            | 40       |  |
| US units . . . . .   | 141                 | Mass flow unit (Parameter) . . . . .                       | 48       |  |
| Failure current (Parameter) . . . . .                      | 80                  | Mass unit (Parameter) . . . . .                            | 48       |  |
| Failure frequency (Parameter) . . . . .                    | 91                  | Maximum frequency value (Parameter) . . . . .              | 88       |  |
| Failure mode (Parameter) . . . . .                         | 79, 86, 91, 97, 111 | Maximum value (Parameter) . . . . .                        | 131, 132 |  |
| Filter options (Parameter) . . . . .                       | 119, 120            | Measured values (Submenu) . . . . .                        | 39       |  |
| Firmware version (Parameter) . . . . .                     | 123                 | Measuring value at maximum frequency (Parameter) . . . . . | 89       |  |
| Fixed current (Parameter) . . . . .                        | 75                  | Measuring value at minimum frequency (Parameter) . . . . . | 89       |  |
| Flow damping (Parameter) . . . . .                         | 54                  | Min/max values (Submenu) . . . . .                         | 131      |  |
| Flow override (Parameter) . . . . .                        | 54                  | Minimum frequency value (Parameter) . . . . .              | 88       |  |
| Flow reference in use (Parameter) . . . . .                | 60                  | Minimum value (Parameter) . . . . .                        | 131, 132 |  |
| Flow reference value 1 (Parameter) . . . . .               | 61, 66              | Mounting set height (Parameter) . . . . .                  | 58       |  |
| Flow reference value 2 (Parameter) . . . . .               | 61, 67              |  |          |  |
| Flow reference value 3 (Parameter) . . . . .               | 62, 67              |  |          |  |
| Flow reference value 4 (Parameter) . . . . .               | 62, 68              |  |          |  |
| Flow reference value 5 (Parameter) . . . . .               | 62, 68              |  |          |  |
| Flow reference value 6 (Parameter) . . . . .               | 63, 69              |  |          |  |
| Flow reference value 7 (Parameter) . . . . .               | 63, 69              |  |          |  |
| Flow reference value 8 (Parameter) . . . . .               | 64, 70              |  |          |  |
| Format display (Parameter) . . . . .                       | 15                  |  |          |  |
| Frequency simulation (Parameter) . . . . .                 | 136                 |  |          |  |
| Frequency value (Parameter) . . . . .                      | 136                 |  |          |  |
| Function   |                     |  |          |  |
| see Parameter  |                     |  |          |  |
| <b>H</b>   |                     |  |          |  |
| Hardware revision (Parameter) . . . . .                    | 104                 | Off value low flow cutoff (Parameter) . . . . .            | 56       |  |
| HART address (Parameter) . . . . .                         | 101                 | On value low flow cutoff (Parameter) . . . . .             | 55       |  |
| HART date code (Parameter) . . . . .                       | 104                 | Operating mode (Parameter) . . . . .                       | 59, 83   |  |
| HART descriptor (Parameter) . . . . .                      | 103                 | Operating time (Parameter) . . . . .                       | 26, 114  |  |
| HART message (Parameter) . . . . .                         | 103                 | Operating time from restart (Parameter) . . . . .          | 114      |  |
| HART output (Submenu) . . . . .                            | 99                  | Order code (Parameter) . . . . .                           | 123      |  |
| HART revision (Parameter) . . . . .                        | 103                 | Output (Submenu) . . . . .                                 | 73, 105  |  |
| HART short tag (Parameter) . . . . .                       | 100                 | Output current (Parameter) . . . . .                       | 43       |  |
| Header (Parameter) . . . . .                               | 23                  | Output current 1 (Parameter) . . . . .                     | 80       |  |
| Header text (Parameter) . . . . .                          | 24                  | Output frequency (Parameter) . . . . .                     | 44, 92   |  |
| <b>I</b>   |                     |  |          |  |
| In-situ adjustment (Submenu) . . . . .                     | 59                  | Output values (Submenu) . . . . .                          | 43       |  |
| Information (Submenu) . . . . .                            | 101                 |  |          |  |
| Input (Submenu) . . . . .                                  | 71                  |  |          |  |
| Input signal level (Parameter) . . . . .                   | 135                 |  |          |  |
| Input values (Submenu) . . . . .                           | 42                  |  |          |  |
| Insertion depth (Parameter) . . . . .                      | 58                  |  |          |  |
| Installation factor (Parameter) . . . . .                  | 57                  |  |          |  |
| <b>L</b>   |                     |  |          |  |
| Language (Parameter) . . . . .                             | 14                  |  |          |  |
| Last backup (Parameter) . . . . .                          | 27                  |  |          |  |
| Length unit (Parameter) . . . . .                          | 50                  |  |          |  |
| Locking status (Parameter) . . . . .                       | 11                  |  |          |  |
| Logging interval (Parameter) . . . . .                     | 127                 |  |          |  |
| Low flow cut off (Submenu) . . . . .                       | 55                  |  |          |  |
| <b>M</b>   |                     |  |          |  |
| Manufacturer ID (Parameter) . . . . .                      | 103                 |  |          |  |
| Mass flow (Parameter) . . . . .                            | 40                  |  |          |  |
| Mass flow unit (Parameter) . . . . .                       | 48                  |  |          |  |
| Mass unit (Parameter) . . . . .                            | 48                  |  |          |  |
| Maximum frequency value (Parameter) . . . . .              | 88                  |  |          |  |
| Maximum value (Parameter) . . . . .                        | 131, 132            |  |          |  |
| Measured values (Submenu) . . . . .                        | 39                  |  |          |  |
| Measuring value at maximum frequency (Parameter) . . . . . | 89                  |  |          |  |
| Measuring value at minimum frequency (Parameter) . . . . . | 89                  |  |          |  |
| Min/max values (Submenu) . . . . .                         | 131                 |  |          |  |
| Minimum frequency value (Parameter) . . . . .              | 88                  |  |          |  |
| Minimum value (Parameter) . . . . .                        | 131, 132            |  |          |  |
| Mounting set height (Parameter) . . . . .                  | 58                  |  |          |  |
| <b>N</b>   |                     |  |          |  |
| New adjustment (Submenu) . . . . .                         | 64                  |  |          |  |
| No. of preambles (Parameter) . . . . .                     | 101                 |  |          |  |
| <b>O</b>   |                     |  |          |  |
| Off value low flow cutoff (Parameter) . . . . .            | 56                  |  |          |  |
| On value low flow cutoff (Parameter) . . . . .             | 55                  |  |          |  |
| Operating mode (Parameter) . . . . .                       | 59, 83              |  |          |  |
| Operating time (Parameter) . . . . .                       | 26, 114             |  |          |  |
| Operating time from restart (Parameter) . . . . .          | 114                 |  |          |  |
| Order code (Parameter) . . . . .                           | 123                 |  |          |  |
| Output (Submenu) . . . . .                                 | 73, 105             |  |          |  |
| Output current (Parameter) . . . . .                       | 43                  |  |          |  |
| Output current 1 (Parameter) . . . . .                     | 80                  |  |          |  |
| Output frequency (Parameter) . . . . .                     | 44, 92              |  |          |  |
| Output values (Submenu) . . . . .                          | 43                  |  |          |  |
| <b>P</b>   |                     |  |          |  |
| Parameter  |                     |  |          |  |
| Structure of a parameter description . . . . .             | 6                   |  |          |  |
| Perform adjustment (Submenu) . . . . .                     | 65                  |  |          |  |
| Pipe wall thickness (Parameter) . . . . .                  | 57                  |  |          |  |
| Power coefficient 1 (Parameter) . . . . .                  | 61, 66              |  |          |  |
| Power coefficient 2 (Parameter) . . . . .                  | 61, 67              |  |          |  |
| Power coefficient 3 (Parameter) . . . . .                  | 62, 67              |  |          |  |
| Power coefficient 4 (Parameter) . . . . .                  | 62, 68              |  |          |  |
| Power coefficient 5 (Parameter) . . . . .                  | 63, 68              |  |          |  |
| Power coefficient 6 (Parameter) . . . . .                  | 63, 69              |  |          |  |
| Power coefficient 7 (Parameter) . . . . .                  | 64, 69              |  |          |  |
| Power coefficient 8 (Parameter) . . . . .                  | 64, 70              |  |          |  |
| Preset value (Parameter) . . . . .                         | 110                 |  |          |  |
| Previous diagnostics (Parameter) . . . . .                 | 113                 |  |          |  |
| Primary variable (PV) (Parameter) . . . . .                | 105                 |  |          |  |
| Process parameters (Submenu) . . . . .                     | 54                  |  |          |  |

|   |        |  |                                      |
|---|--------|--|--------------------------------------|
| Process temperature (Submenu) . . . . .           | 132    | Information . . . . .                          | 101                                  |
| Process variables (Submenu) . . . . .             | 39     | Input . . . . .                                | 71                                   |
| Pulse output (Parameter) . . . . .                | 43, 87 | Input values . . . . .                         | 42                                   |
| Pulse simulation (Parameter) . . . . .            | 137    | Installation settings . . . . .                | 57                                   |
| Pulse value (Parameter) . . . . .                 | 137    | Low flow cut off . . . . .                     | 55                                   |
| Pulse width (Parameter) . . . . .                 | 85     | Measured values . . . . .                      | 39                                   |
| Pulse/frequency/switch output (Submenu) . . . . . | 81     | Min/max values . . . . .                       | 131                                  |
| <b>Q</b>  |        | New adjustment . . . . .                       | 64                                   |
| Quaternary variable (QV) (Parameter) . . . . .    | 107    | Output . . . . .                               | 73, 105                              |
| <b>R</b>  |        | Output values . . . . .                        | 43                                   |
| Reset write protection (Parameter) . . . . .      | 38     | Perform adjustment . . . . .                   | 65                                   |
| Response time (Parameter) . . . . .               | 78, 90 | Process parameters . . . . .                   | 54                                   |
| Response time status input (Parameter) . . . . .  | 73     | Process temperature . . . . .                  | 132                                  |
| <b>S</b>  |        | Process variables . . . . .                    | 39                                   |
| Secondary variable (SV) (Parameter) . . . . .     | 106    | Pulse/frequency/switch output . . . . .        | 81                                   |
| Select flow reference (Parameter) . . . . .       | 65     | Sensor . . . . .                               | 39                                   |
| Sensor (Submenu) . . . . .                        | 39     | Sensor adjustment . . . . .                    | 57                                   |
| Sensor adjustment (Submenu) . . . . .             | 57     | Simulation . . . . .                           | 133                                  |
| Separator (Parameter) . . . . .                   | 24     | Status input . . . . .                         | 72                                   |
| Serial number (Parameter) . . . . .               | 122    | System . . . . .                               | 13                                   |
| Simulation (Submenu) . . . . .                    | 133    | System units . . . . .                         | 45                                   |
| Simulation current output 1 (Parameter) . . . . . | 135    | Totalizer . . . . .                            | 41, 108                              |
| Simulation device alarm (Parameter) . . . . .     | 138    | Use adjustment . . . . .                       | 70                                   |
| Simulation diagnostic event (Parameter) . . . . . | 139    | User-specific units . . . . .                  | 51                                   |
| Simulation status input (Parameter) . . . . .     | 134    | Switch output function (Parameter) . . . . .   | 92                                   |
| Software option overview (Parameter) . . . . .    | 38     | Switch output simulation (Parameter) . . . . . | 137                                  |
| Software revision (Parameter) . . . . .           | 104    | Switch status (Parameter) . . . . .            | 44, 97, 138                          |
| Start-up current (Parameter) . . . . .            | 81     | Switch-off delay (Parameter) . . . . .         | 97                                   |
| Start-up mode (Parameter) . . . . .               | 80     | Switch-off value (Parameter) . . . . .         | 95                                   |
| Status input (Submenu) . . . . .                  | 72     | Switch-on delay (Parameter) . . . . .          | 96                                   |
| Submenu   |        | Switch-on value (Parameter) . . . . .          | 95                                   |
| Adjustment values in use . . . . .                | 60     | System (Submenu) . . . . .                     | 13                                   |
| Administration . . . . .                          | 34     | System units (Submenu) . . . . .               | 45                                   |
| Application . . . . .                             | 108    |  |                                      |
| Calibration . . . . .                             | 71     | <b>T</b>                                       |                                      |
| CIP/SIP . . . . .                                 | 111    | Target group . . . . .                         | 4                                    |
| Communication . . . . .                           | 98     | Temperature (Parameter) . . . . .              | 40                                   |
| Configuration . . . . .                           | 99     | Temperature unit (Parameter) . . . . .         | 49                                   |
| Configuration backup display . . . . .            | 26     | Tertiary variable (TV) (Parameter) . . . . .   | 107                                  |
| Current output 1 . . . . .                        | 73     | Timestamp (Parameter) . . . . .                | 113, 114, 115, 116, 117,<br>118, 119 |
| Data logging . . . . .                            | 125    | Totalizer (Submenu) . . . . .                  | 41, 108                              |
| Device information . . . . .                      | 121    | Totalizer overflow (Parameter) . . . . .       | 42                                   |
| Diagnostic behavior . . . . .                     | 30     | Totalizer value (Parameter) . . . . .          | 41                                   |
| Diagnostic handling . . . . .                     | 29     |  |                                      |
| Diagnostic list . . . . .                         | 115    | <b>U</b>                                       |                                      |
| Diagnostics . . . . .                             | 112    | Unit totalizer (Parameter) . . . . .           | 109                                  |
| Display . . . . .                                 | 13     | Use adjustment (Submenu) . . . . .             | 70                                   |
| Display channel 1 . . . . .                       | 128    | User mass factor (Parameter) . . . . .         | 53                                   |
| Display channel 2 . . . . .                       | 129    | User mass offset (Parameter) . . . . .         | 53                                   |
| Display channel 3 . . . . .                       | 130    | User mass text (Parameter) . . . . .           | 52                                   |
| Display channel 4 . . . . .                       | 130    | User volume factor (Parameter) . . . . .       | 52                                   |
| Electronic temperature . . . . .                  | 131    | User volume offset (Parameter) . . . . .       | 52                                   |
| Event list . . . . .                              | 120    | User volume text (Parameter) . . . . .         | 51                                   |
| Event logbook . . . . .                           | 119    | User-specific units (Submenu) . . . . .        | 51                                   |
| HART output . . . . .                             | 99     |  |                                      |
| In-situ adjustment . . . . .                      | 59     |  |                                      |

|  |        |
|--|--------|
| Value 3 display (Parameter) . . . . .        | 19     |
| Value 4 display (Parameter) . . . . .        | 21     |
| Value current output 1 (Parameter) . . . . . | 135    |
| Value per pulse (Parameter) . . . . .        | 85     |
| Value process variable (Parameter) . . . . . | 134    |
| Value status input (Parameter) . . . . .     | 42, 72 |
| Volume flow (Parameter) . . . . .            | 40     |
| Volume flow unit (Parameter) . . . . .       | 45     |
| Volume unit (Parameter) . . . . .            | 47     |

## W

### Wizard

|                              |    |
|------------------------------|----|
| Define access code . . . . . | 34 |
|------------------------------|----|



[www.addresses.endress.com](http://www.addresses.endress.com)

---