

Description of Device Parameters

Proline Promag 100

PROFIBUS DP

Electromagnetic flowmeter




Table of contents

1 Document information	4	4 Country-specific factory settings ..	158
1.1 Document function	4	4.1 SI units	158
1.2 Target group	4	4.1.1 System units	158
1.3 Using this document	4	4.1.2 Full scale values	158
1.3.1 Information on the document structure	4	4.1.3 On value low flow cut off	159
1.3.2 Structure of a parameter description	6	4.2 US units	159
1.4 Symbols used	6	4.2.1 System units	159
1.4.1 Symbols for certain types of information	6	4.2.2 Full scale values	160
1.4.2 Symbols in graphics	7	4.2.3 On value low flow cut off	160
2 Overview of the Expert operating menu	8	5 Explanation of abbreviated units ..	162
3 Description of device parameters ..	10	5.1 SI units	162
3.1 "System" submenu	13	5.2 US units	162
3.1.1 "Display" submenu	13	5.3 Imperial units	163
3.1.2 "Diagnostic handling" submenu	26		
3.1.3 "Administration" submenu	30		
3.2 "Sensor" submenu	34		
3.2.1 "Measured values" submenu	35		
3.2.2 "System units" submenu	38		
3.2.3 "Process parameters" submenu	46		
3.2.4 "External compensation" submenu	58		
3.2.5 "Sensor adjustment" submenu	60		
3.2.6 "Calibration" submenu	65		
3.3 "Communication" submenu	67		
3.3.1 "PROFIBUS DP configuration" submenu	67		
3.3.2 "PROFIBUS DP info" submenu	69		
3.3.3 "Physical block" submenu	71		
3.3.4 "Web server" submenu	80		
3.4 "Analog inputs" submenu	83		
3.4.1 "Analog input 1 to 4" submenu	83		
3.5 "Discrete inputs" submenu	97		
3.5.1 "Discrete input 1 to 2" submenu	97		
3.6 "Analog outputs" submenu	104		
3.6.1 "Analog output 1 to 2" submenu	104		
3.7 "Discrete outputs" submenu	116		
3.7.1 "Discrete output 1 to 2" submenu	116		
3.8 "Application" submenu	126		
3.8.1 "Totalizer 1 to 3" submenu	126		
3.9 "Diagnostics" submenu	140		
3.9.1 "Diagnostic list" submenu	143		
3.9.2 "Event logbook" submenu	147		
3.9.3 "Device information" submenu	149		
3.9.4 "Min/max values" submenu	152		
3.9.5 "Heartbeat" submenu	154		
3.9.6 "Simulation" submenu	155		
		Index	165

1 Document information

1.1 Document function

The document is part of the Operating Instructions and serves as a reference for parameters, providing a detailed explanation of each individual parameter of the Expert operating menu.


1.2 Target group

The document is aimed at specialists who work with the device over the entire life cycle and perform specific configurations.

1.3 Using this document


1.3.1 Information on the document structure

This document lists the submenus and their parameters according to the structure of the **Expert** menu (→ 8) menu that are available once the "**Operator**" user role or the "**Maintenance**" user role is enabled.



1 *Sample graphic*

For information on the arrangement of the parameters according to the structure of the **Operation** menu, **Setup** menu, **Diagnostics** menu (→ 140), along with a brief description, see the Operating Instructions for the device.



2 Sample graphic

 For information about the operating philosophy, see the "Operating philosophy" chapter in the device's Operating Instructions

1.3.2 Structure of a parameter description

The individual parts of a parameter description are described in the following section:

Complete parameter name	Write-protected parameter = 
Navigation	 Navigation path to the parameter via the local display (direct access code) or Web browser  Navigation path to the parameter via the operating tool The names of the menus, submenus and parameters are abbreviated to the form in which they appear on the display and in the operating tool.
Prerequisite	The parameter is only available under these specific conditions
Description	Description of the parameter function
Selection	List of the individual options for the parameter <ul style="list-style-type: none"> ▪ Option 1 ▪ Option 2
User entry	Input range for the parameter
User interface	Display value/data for the parameter
Factory setting	Default setting ex works
Additional information	Additional explanations (e.g. in examples): <ul style="list-style-type: none"> ▪ On individual options ▪ On display values/data ▪ On the input range ▪ On the factory setting ▪ On the parameter function

1.4 Symbols used

1.4.1 Symbols for certain types of information

Symbol	Meaning
	Tip Indicates additional information.
	Reference to documentation
	Reference to page
	Reference to graphic
	Operation via local display
	Operation via operating tool
	Write-protected parameter

1.4.2 Symbols in graphics

Symbol	Meaning	Symbol	Meaning
1, 2, 3 ...	Item numbers	A, B, C, ...	Views
A-A, B-B, C-C, ...	Sections		

2 Overview of the Expert operating menu

The following table provides an overview of the menu structure of the expert operating menu and its parameters. The page reference indicates where the associated description of the submenu or parameter can be found.

Expert	
Direct access	→ 10
Locking status	→ 11
Access status display	→ 11
Access status tooling	→ 12
Enter access code	→ 13
System	→ 13
▶ Display	→ 13
▶ Diagnostic handling	→ 26
▶ Administration	→ 30
Sensor	→ 34
▶ Measured values	→ 35
▶ System units	→ 38
▶ Process parameters	→ 46
▶ External compensation	→ 58
▶ Sensor adjustment	→ 60
▶ Calibration	→ 65
Communication	→ 67
▶ PROFIBUS DP configuration	→ 67
▶ PROFIBUS DP info	→ 69
▶ Physical block	→ 71
▶ Web server	→ 80

▶ Analog inputs	→ 83
▶ Analog input 1 to 4	→ 83
▶ Discrete inputs	→ 97
▶ Discrete input 1 to 2	→ 97
▶ Analog outputs	→ 104
▶ Analog output 1 to 2	→ 104
▶ Discrete outputs	→ 116
▶ Discrete output 1 to 2	→ 116
▶ Application	→ 126
▶ Totalizer 1 to 3	→ 126
▶ Diagnostics	→ 140
Actual diagnostics	→ 141
Previous diagnostics	→ 141
Operating time from restart	→ 142
Operating time	→ 142
▶ Diagnostic list	→ 143
▶ Event logbook	→ 147
▶ Device information	→ 149
▶ Min/max values	→ 152
▶ Heartbeat	→ 154
▶ Simulation	→ 155

3 Description of device parameters

In the following section, the parameters are listed according to the menu structure of the local display. Specific parameters for the operating tools are included at the appropriate points in the menu structure.

⚡ Expert	
Direct access	→ 10
Locking status	→ 11
Access status display	→ 11
Access status tooling	→ 12
Enter access code	→ 13
▶ System	→ 13
▶ Sensor	→ 34
▶ Communication	→ 67
▶ Analog inputs	→ 83
▶ Discrete inputs	→ 97
▶ Analog outputs	→ 104
▶ Discrete outputs	→ 116
▶ Application	→ 126
▶ Diagnostics	→ 140

Direct access



Navigation

⌚ Expert → Direct access

Prerequisite

There is a local display with operating elements.

Description

Input of the access code to enable direct access to the desired parameter via the local display. For this reason, each parameter is assigned a parameter number that appears in the navigation view on the right in the header of the selected parameter.

User entry

0 to 65 535

Additional information*User entry*

The direct access code consists of a 4-digit number and the channel number, which identifies the channel of a process variable: e.g. 0914-1



- The leading zeros in the direct access code do not have to be entered.
Example: Input of "914" instead of "0914"
- If no channel number is entered, channel 1 is jumped to automatically.
Example: Enter 0914 → **Assign process variable** parameter
- If a different channel is jumped to: Enter the direct access code with the corresponding channel number.
Example: Enter 0914-3 → **Assign process variable** parameter

Locking status**Navigation**

Expert → Locking status

Description

Displays the active write protection.

User interface

- Hardware locked
- Temporarily locked

Additional information*Display*

If two or more types of write protection are active, the write protection with the highest priority is shown on the local display. In the operating tool all active types of write protection are displayed.



If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→ 11).

"Hardware locked" option (priority 1)

The DIP switch for hardware locking is activated on the main electronics module. This locks write access to the parameters (e.g. via local display or operating tool).



Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

"Temporarily locked" option (priority 2)

Write access to the parameters is temporarily locked on account of internal processes running in the device (e.g. data upload/download, reset etc.). Once the internal processing has been completed, the parameters can be changed once again.

Access status display**Navigation**

Expert → Access stat.disp

Prerequisite

A local display is provided.

Description

Displays the access authorization to the parameters via the local display.

User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Operator
Additional information	<p><i>Description</i></p> <p>If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.</p> <p> Access authorization can be modified via the Enter access code parameter (→  13).</p> <p> For information on the Enter access code parameter, see the "Disabling write protection via access code" section of the Operating Instructions for the device</p> <p> If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the Locking status parameter (→  11).</p>

Display

-  Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Access status tooling

Navigation	  Expert → Access stat.tool
Description	Displays the access authorization to the parameters via the operating tool or Web browser.
User interface	<ul style="list-style-type: none">▪ Operator▪ Maintenance
Factory setting	Maintenance

Additional information

Description

 Access authorization can be modified via the **Enter access code** parameter (→  13).

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→  11).

Display

 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

Enter access code**Navigation**
 Expert → Ent. access code
Description

Use this function to enter the user-specific release code to remove parameter write protection.

User entry

0 to 9 999

3.1 "System" submenu*Navigation*
 Expert → System

► System	
► Display	→  13
► Diagnostic handling	→  26
► Administration	→  30

3.1.1 "Display" submenu*Navigation*
 Expert → System → Display

► Display	
Display language	→  14
Format display	→  15
Value 1 display	→  17
0% bargraph value 1	→  17
100% bargraph value 1	→  18
Decimal places 1	→  18
Value 2 display	→  19
Decimal places 2	→  19
Value 3 display	→  20

0% bargraph value 3	→ 20
100% bargraph value 3	→ 21
Decimal places 3	→ 21
Value 4 display	→ 21
Decimal places 4	→ 22
Display interval	→ 22
Display damping	→ 23
Header	→ 23
Header text	→ 24
Separator	→ 24
Contrast display	→ 25
Backlight	→ 25
Access status display	→ 25

Display language

Navigation

Expert → System → Display → Display language

Prerequisite

A local display is provided.

Description

Use this function to select the configured language on the local display.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *

* Visibility depends on order options or device settings

- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech)

Factory setting English (alternatively, the ordered language is preset in the device)

Format display

Navigation	 Expert → System → Display → Format display
Prerequisite	A local display is provided.
Description	Use this function to select how the measured value is shown on the local display.
Selection	<ul style="list-style-type: none"> ■ 1 value, max. size ■ 1 bargraph + 1 value ■ 2 values ■ 1 value large + 2 values ■ 4 values
Factory setting	1 value, max. size
Additional information	<p><i>Description</i></p> <p>The display format (size, bar graph etc.) and number of measured values displayed simultaneously (1 to 4) can be configured. This setting only applies to normal operation.</p> <p> ■ The Value 1 display parameter (→ 17) to Value 4 display parameter (→ 21) are used to specify which measured values are shown on the local display and in what order.</p> <p>■ If more measured values are specified than the display mode selected permits, then the values alternate on the device display. The display time until the next change is configured via the Display interval parameter (→ 22).</p>

* Visibility depends on order options or device settings


Possible measured values shown on the local display:

"1 value, max. size" option




A0016529

"1 bargraph + 1 value" option



A0016530


"2 values" option



A0016531


3

"1 value large + 2 values" option



A0016532

"4 values" option



A0016533

Value 1 display

Navigation	Expert → System → Display → Value 1 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	<ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow ■ Flow velocity* ■ Conductivity* ■ Corrected conductivity* ■ None ■ Totalizer 1 ■ Totalizer 2 ■ Totalizer 3 ■ Temperature* ■ Electronic temperature
Factory setting	Volume flow
Additional information	<p><i>Description</i></p> <p>If several measured values are displayed at once, the measured value selected here will be the first value to be displayed. The value is only displayed during normal operation.</p> <p> The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.</p> <p><i>Selection</i></p> <p> The unit of the displayed measured value is taken from the System units submenu (→ 38).</p>

0% bargraph value 1

Navigation	Expert → System → Display → 0% bargraph 1
Prerequisite	A local display is provided.
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 1.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ 0 l/h ■ 0 gal/min (us)

* Visibility depends on order options or device settings

Additional information*Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 38).

100% bargraph value 1**Navigation**

Expert → System → Display → 100% bargraph 1

Prerequisite

A local display is provided.

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 1.

User entry

Signed floating-point number

Factory setting

Depends on country and nominal diameter → 158

Additional information*Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 38).

Decimal places 1**Navigation**

Expert → System → Display → Decimal places 1

Prerequisite

A measured value is specified in the **Value 1 display** parameter (→ 17).

Description

Use this function to select the number of decimal places for measured value 1.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 2 display**Navigation**

Expert → System → Display → Value 2 display

Prerequisite

A local display is provided.

Description

Use this function to select one of the measured values to be shown on the local display.

Selection

For the picklist, see the **Value 1 display** parameter (→ [17](#))

Factory setting

None

Additional information*Description*

If several measured values are displayed at once, the measured value selected here will be the second value to be displayed. The value is only displayed during normal operation.



The **Format display** parameter (→ [15](#)) is used to specify how many measured values are displayed simultaneously and how.

Selection

The unit of the displayed measured value is taken from the **System units** submenu (→ [38](#)).

Decimal places 2**Navigation**

Expert → System → Display → Decimal places 2

Prerequisite

A measured value is specified in the **Value 2 display** parameter (→ [19](#)).

Description

Use this function to select the number of decimal places for measured value 2.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 3 display

Navigation	Expert → System → Display → Value 3 display
Prerequisite	A local display is provided.
Description	Use this function to select one of the measured values to be shown on the local display.
Selection	Picklist, see Value 1 display parameter (→ 17)
Factory setting	None
Additional information	<i>Description</i> If several measured values are displayed at once, the measured value selected here will be the third value to be displayed. The value is only displayed during normal operation. The Format display parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how. <i>Selection</i> The unit of the displayed measured value is taken from the System units submenu (→ 38).

0% bargraph value 3

Navigation	Expert → System → Display → 0% bargraph 3
Prerequisite	A selection has been made in the Value 3 display parameter (→ 20).
Description	Use this function to enter the 0% bar graph value to be shown on the display for the measured value 3.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none">▪ 0 l/h▪ 0 gal/min (us)
Additional information	<i>Description</i> The Format display parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph. <i>User entry</i> The unit of the displayed measured value is taken from the System units submenu (→ 38).

100% bargraph value 3

**Navigation**

Expert → System → Display → 100% bargraph 3

Prerequisite

A selection was made in the **Value 3 display** parameter (→ 20).

Description

Use this function to enter the 100% bar graph value to be shown on the display for the measured value 3.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The **Format display** parameter (→ 15) is used to specify that the measured value is to be displayed as a bar graph.

User entry

The unit of the displayed measured value is taken from the **System units** submenu (→ 38).

Decimal places 3

**Navigation**

Expert → System → Display → Decimal places 3

Prerequisite

A measured value is specified in the **Value 3 display** parameter (→ 20).

Description

Use this function to select the number of decimal places for measured value 3.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting

X.XX

Additional information*Description*

This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Value 4 display

**Navigation**

Expert → System → Display → Value 4 display

Prerequisite

A local display is provided.

Description Use this function to select one of the measured values to be shown on the local display.

Selection Picklist, see **Value 1 display** parameter (→ 17)

Factory setting None

Additional information *Description*

If several measured values are displayed at once, the measured value selected here will be the fourth value to be displayed. The value is only displayed during normal operation.

i The **Format display** parameter (→ 15) is used to specify how many measured values are displayed simultaneously and how.

Selection

i The unit of the displayed measured value is taken from the **System units** submenu (→ 38).

Decimal places 4



Navigation Expert → System → Display → Decimal places 4

Prerequisite A measured value is specified in the **Value 4 display** parameter (→ 21).

Description Use this function to select the number of decimal places for measured value 4.

Selection

- X
- X.X
- X.XX
- X.XXX
- X.XXXX

Factory setting X.XX

Additional information *Description*

i This setting does not affect the measuring or computational accuracy of the device. The arrow displayed between the measured value and the unit indicates that the device computes with more digits than are shown on the local display.

Display interval

Navigation Expert → System → Display → Display interval

Prerequisite A local display is provided.

Description Use this function to enter the length of time the measured values are displayed if the values alternate on the display.

User entry 1 to 10 s

Factory setting 5 s

Additional information *Description*

This type of alternating display only occurs automatically if the number of measured values defined exceeds the number of values the selected display format can display simultaneously.

-  ■ The **Value 1 display** parameter (→ 17) to **Value 4 display** parameter (→ 21) are used to specify which measured values are shown on the local display.
■ The display format of the displayed measured values is specified using the **Format display** parameter (→ 15).

Display damping



Navigation  Expert → System → Display → Display damping

Prerequisite A local display is provided.

Description Use this function to enter the reaction time of the local display to fluctuations in the measured value caused by process conditions.

User entry 0.0 to 999.9 s

Factory setting 0.0 s

Additional information *User entry*

A time constant is entered:

- If a low time constant is entered, the display reacts particularly quickly to fluctuating measured variables.
- On the other hand, the display reacts more slowly if a high time constant is entered.

Header



Navigation  Expert → System → Display → Header

Prerequisite A local display is provided.

Description Use this function to select the contents of the header of the local display.


Selection

- Device tag
- Free text

Factory setting Device tag

Additional information *Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

Selection

Free text

Is defined in the **Header text** parameter (→ 24).**Header text****Navigation**

Expert → System → Display → Header text

PrerequisiteThe **Free text** option is selected in the **Header** parameter (→ 23).**Description**

Use this function to enter a customer-specific text for the header of the local display.


User entry

Max. 12 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting

Additional information*Description*

The header text only appears during normal operation.



A0013375

1 Position of the header text on the display

User entry

The number of characters displayed depends on the characters used.

Separator**Navigation**

Expert → System → Display → Separator

Prerequisite

A local display is provided.

Description

Use this function to select the decimal separator.

Selection

- . (point)
- , (comma)

Factory setting

. (point)

Contrast display

Navigation

Expert → System → Display → Contrast display

Prerequisite

A local display is provided.

Description

Use this function to enter a value to adapt the display contrast to the ambient conditions (e.g. the lighting or viewing angle).

User entry

20 to 80 %

Factory setting

Depends on the display

Backlight

Navigation

Expert → System → Display → Backlight

Prerequisite

Order code for "Display; operation", option E "SD03 4-line, illum.; touch control + data backup function"

Description

Use this function to switch the backlight of the local display on and off.

Selection

- Disable
- Enable

Factory setting

Enable

Access status display

Navigation

Expert → System → Display → Access stat.disp

Prerequisite

A local display is provided.

Description

Displays the access authorization to the parameters via the local display.

User interface

- Operator
- Maintenance

Factory setting

Operator

Additional information*Description*

If the -symbol appears in front of a parameter, it cannot be modified via the local display with the current access authorization.

 Access authorization can be modified via the **Enter access code** parameter (→ [13](#)).

 For information on the **Enter access code** parameter, see the "Disabling write protection via access code" section of the Operating Instructions for the device

 If additional write protection is active, this restricts the current access authorization even further. The write protection status can be viewed via the **Locking status** parameter (→ [11](#)).


Display

 Information on access authorization is provided in the "User roles and associated access authorization" and "Operating concept" sections of the Operations Instructions for the device.

3.1.2 "Diagnostic handling" submenu

Navigation

  Expert → System → Diagn. handling



Alarm delay

*Navigation*

  Expert → System → Diagn. handling → Alarm delay

Description

Use this function to enter the time interval until the device generates a diagnostic message.

 The diagnostic message is reset without a time delay.

User entry

0 to 60 s

Factory setting

0 s

*Additional information**Effect*

This setting affects the following diagnostic messages:

- 190 Special event 1
- 191 Special event 5
- 832 Electronic temperature too high
- 833 Electronic temperature too low
- 834 Process temperature too high

- 835 Process temperature too low
- 862 Partly filled pipe
- 990 Special event 4
- 991 Special event 8

"Diagnostic behavior" submenu

Each item of diagnostic information is assigned a specific diagnostic behavior at the factory. The user can change this assignment for specific diagnostic information in the **Diagnostic behavior** submenu (→ 27).

The following options are available in the **Assign behavior of diagnostic no. xxx** parameters:

Diagnostic behavior	Description
Alarm	The device stops measurement. The totalizers assume the defined alarm condition. A diagnostic message is generated.
Warning	The device continues to measure. The measured value output via PROFIBUS and the totalizers are not affected. A diagnostic message is generated.
Logbook entry only	The device continues to measure. The diagnostic message is displayed only in the Event logbook submenu (→ 147) (Event list submenu (→ 148)) and not in alternation with the operational display.
Off	The diagnostic event is ignored, and no diagnostic message is generated or entered.



For a list of all the diagnostic events, see the Operating Instructions for the device.

Navigation



Expert → System → Diagn. handling → Diagn. behavior

► **Diagnostic behavior**

Assign behavior of diagnostic no. 531	→ 28
Assign behavior of diagnostic no. 832	→ 28
Assign behavior of diagnostic no. 833	→ 28
Assign behavior of diagnostic no. 834	→ 29
Assign behavior of diagnostic no. 835	→ 29
Assign behavior of diagnostic no. 862	→ 29
Assign behavior of diagnostic no. 937	→ 30
Assign behavior of diagnostic no. 302	→ 30

Assign behavior of diagnostic no. 531 (Empty pipe detection)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 531

Description

Use this function to change the diagnostic behavior of the diagnostic message **531 Empty pipe detection**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [27](#)

Assign behavior of diagnostic no. 832 (Electronic temperature too high)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 832

Description

Use this function to change the diagnostic behavior of the diagnostic message **832 Electronic temperature too high**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [27](#)

Assign behavior of diagnostic no. 833 (Electronic temperature too low)

**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 833

Description

Use this function to change the diagnostic behavior of the diagnostic message **833 Electronic temperature too low**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [27](#)

Assign behavior of diagnostic no. 834 (Process temperature too high)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 834
Description	Use this function to change the diagnostic behavior of the diagnostic message 834 Process temperature too high .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 27

Assign behavior of diagnostic no. 835 (Process temperature too low)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 835
Description	Use this function to change the diagnostic behavior of the diagnostic message 835 Process temperature too low .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 27

Assign behavior of diagnostic no. 862 (Empty pipe)



Navigation	Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 862
Description	Use this function to change the diagnostic behavior of the diagnostic message 862 Empty pipe .
Selection	<ul style="list-style-type: none">▪ Off▪ Alarm▪ Warning▪ Logbook entry only
Factory setting	Warning
Additional information	For a detailed description of the options available, see → 27

Assign behavior of diagnostic no. 937 (EMC interference)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 937

Description

Use this function to change the diagnostic behavior of the diagnostic message **937 EMC interference**.

Selection

- Off
- Alarm
- Warning
- Logbook entry only

Factory setting

Warning

Additional information

For a detailed description of the options available, see → [27](#)

Assign behavior of diagnostic no. 302 (Device verification active)**Navigation**

Expert → System → Diagn. handling → Diagn. behavior → Diagnostic no. 302

Description

Use this function to change the diagnostic behavior of the diagnostic message **302 Device verification active**.

Selection

- Alarm
- Warning

Factory setting

Warning


Additional information

For a detailed description of the options available, see → [27](#)

3.1.3 "Administration" submenu

Navigation

Expert → System → Administration



"Define access code" wizard


 The **Define access code** wizard (→ 31) is only available when operating via the local display or Web browser.

If operating via the operating tool, the **Define access code** parameter (→ 32) can be found directly in the **Administration** submenu. There is no **Confirm access code** parameter if the device is operated via the operating tool.

Navigation



Expert → System → Administration → Def. access code



Define access code



Navigation



Expert → System → Administration → Def. access code → Def. access code

Description

Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the local display or Web browser.

User entry

0 to 9 999

Factory setting

0

Additional information

Description

The write protection affects all parameters in the document marked with the  symbol.

On the local display, the  symbol in front of a parameter indicates that the parameter is write-protected.

The parameters that cannot be write-accessed are grayed out in the Web browser.

 Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the **Enter access code** parameter (→ 13).

 If you lose the access code, please contact your Endress+Hauser Sales Center.

User entry

A message is displayed if the access code is not in the input range.

Factory setting

If the factory setting is not changed or **0** is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the "**Maintenance**" role.

Confirm access code

Navigation	Expert → System → Administration → Def. access code → Confirm code
Description	Enter the defined release code a second time to confirm the release code.
User entry	0 to 9 999
Factory setting	0

Additional parameters in the "Administration" submenu**Define access code**

Navigation	Expert → System → Administration → Def. access code
Description	Use this function to enter a user-specific release code to restrict write-access to the parameters. This protects the configuration of the device against any inadvertent changes via the operating tool.
User entry	0 to 9 999
Factory setting	0
Additional information	<i>Description</i> The write protection affects all parameters in the document marked with the symbol. Once the access code has been defined, write-protected parameters can only be modified if the access code is entered in the Enter access code parameter (→ 13). If you lose the access code, please contact your Endress+Hauser Sales Center. <i>User entry</i> A message is displayed if the access code is not in the input range. <i>Factory setting</i> If the factory setting is not changed or 0 is defined as the access code, the parameters are not write-protected and the device configuration data can be modified. The user is logged on in the " Maintenance " role.

Device reset**Navigation**

Expert → System → Administration → Device reset

Description

Use this function to choose whether to reset the device configuration - either entirely or in part - to a defined state.

Selection

- Cancel
- To delivery settings
- Restart device

Factory setting

Cancel

Additional information*"Cancel" option*

No action is executed and the user exits the parameter.

"To delivery settings" option

Every parameter for which a customer-specific default setting was ordered is reset to this customer-specific value. All other parameters are reset to the factory setting.



This option is not visible if no customer-specific settings have been ordered.

"Restart device" option

The restart resets every parameter whose data are in the volatile memory (RAM) to the factory setting (e.g. measured value data). The device configuration remains unchanged.

Activate SW option**Navigation**

Expert → System → Administration → Activate SW opt.

Description

Use this function to enter an activation code to enable an additional, ordered software option.

User entry

Max. 10-digit string consisting of numbers.

Factory setting

0

Additional information*User entry*

Endress+Hauser provides the corresponding activation code for the software option with the order.

NOTICE! This activation code varies depending on the measuring device and the software option. If an incorrect or invalid code is entered, this can result in the loss of software options that are already been activated. After commissioning the measuring device: in this parameter only enter activation codes which Endress+Hauser has provided (e.g. when a new software option was ordered). If an incorrect or invalid activation code is entered,

enter the activation code from the parameter protocol again and contact your Endress+Hauser sales organization, quoting the serial number of your device.

Example for a software option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

Web browser

 Once a software option has been activated, the page must be loaded again in the Web browser.

Software option overview

Navigation

  Expert → System → Administration → SW option overv.

Description

Displays all the software options that are enabled in the device.

User interface

- Electrode cleaning circuit
- Heartbeat Verification
- Heartbeat Monitoring

Additional information

Description

Displays all the options that are available if ordered by the customer.

"Electrode cleaning circuit" option

Order code for "Application package", option EC "ECC electrode cleaning"

"Heartbeat Verification" option and "Heartbeat Monitoring" option

Order code for "Application package", option EB "Heartbeat Verification + Monitoring"

3.2 "Sensor" submenu

Navigation

  Expert → Sensor

 Sensor	
 Measured values	→  35
 System units	→  38
 Process parameters	→  46
 External compensation	→  58

► Sensor adjustment

→ 60

► Calibration

→ 65

3.2.1 "Measured values" submenu

Navigation

Expert → Sensor → Measured val.

► Measured values

► Process variables

→ 35

► Totalizer

→ 37

"Process variables" submenu

Navigation

Expert → Sensor → Measured val. → Process variab.

► Process variables

Volume flow

→ 35

Mass flow

→ 36

Conductivity

→ 36

Corrected volume flow

→ 36

Temperature

→ 36

Corrected conductivity

→ 37

Volume flow

Navigation

Expert → Sensor → Measured val. → Process variab. → Volume flow

Description

Displays the volume flow currently measured.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Volume flow unit** parameter (→ 39)

Mass flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Mass flow
Description	Displays the mass flow currently calculated.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	 The unit is taken from the Mass flow unit parameter (→  42)

Conductivity

Navigation	 Expert → Sensor → Measured val. → Process variab. → Conductivity
Prerequisite	In the Conductivity measurement parameter (→  49), the On option is selected.
Description	Displays the conductivity currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	 The unit is taken from the Conductivity unit parameter (→  41)

Corrected volume flow

Navigation	 Expert → Sensor → Measured val. → Process variab. → Correct.vol.flow
Description	Displays the corrected volume flow currently measured.
User interface	Signed floating-point number
Additional information	<i>Dependency</i>
	 The unit is taken from the Corrected volume flow unit parameter (→  44)

Temperature

Navigation	 Expert → Sensor → Measured val. → Process variab. → Temperature
Prerequisite	For the following order code: "Sensor Option", option CI "Fluid temperature probe"

Description Displays the temperature currently calculated.

User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Temperature unit** parameter (→ [42](#))

Corrected conductivity

Navigation  Expert → Sensor → Measured val. → Process variab. → CorrConductivity

Prerequisite One of the following conditions is satisfied:

- Order code for "Sensor Option", option CI "Fluid temperature probe"
or
- The temperature is read into the flowmeter from an external device.

Description Displays the conductivity currently corrected.


User interface Positive floating-point number

Additional information *Dependency*

 The unit is taken from the **Conductivity unit** parameter (→ [41](#))

"Totalizer" submenu

Navigation  Expert → Sensor → Measured val. → Totalizer



Totalizer value 1 to 3

Navigation  Expert → Sensor → Measured val. → Totalizer → Totalizer val. 1 to 3

Prerequisite In the **Target mode** parameter (→ [133](#)), the **Auto** option is selected.

Description Displays the current reading for totalizer 1-3.

User interface Signed floating-point number

Additional information *Description*

i In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 130).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 130).

Dependency

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Totalizer status (Hex) 1 to 3

Navigation Expert → Sensor → Measured val. → Totalizer → Status (Hex) 1 to 3

Prerequisite In **Target mode** parameter (→ 133), the **Auto** option is selected.

Description Displays the status value (hex) of the particular totalizer.

User interface 0 to 0xFF

Totalizer status 1 to 3

Navigation Expert → Sensor → Measured val. → Totalizer → Tot. status 1 to 3


Description Displays the status of the particular totalizer.

User interface

- Good
- Uncertain
- Bad

3.2.2 "System units" submenu

Navigation Expert → Sensor → System units



Conductivity unit	→ 41
Temperature unit	→ 42
Mass flow unit	→ 42
Mass unit	→ 43
Density unit	→ 44
Corrected volume flow unit	→ 44
Corrected volume unit	→ 45
Date/time format	→ 46

Volume flow unit



Navigation

Expert → Sensor → System units → Volume flow unit

Description

Use this function to select the unit for the volume flow.

Selection

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³ /s	■ af/s	■ gal/s (imp)
■ cm ³ /min	■ af/min	■ gal/min (imp)
■ cm ³ /h	■ af/h	■ gal/h (imp)
■ cm ³ /d	■ af/d	■ gal/d (imp)
■ dm ³ /s	■ ft ³ /s	■ Mgal/s (imp)
■ dm ³ /min	■ ft ³ /min	■ Mgal/min (imp)
■ dm ³ /h	■ ft ³ /h	■ Mgal/h (imp)
■ dm ³ /d	■ ft ³ /d	■ Mgal/d (imp)
■ m ³ /s	■ fl oz/s (us)	■ bbl/s (imp;beer)
■ m ³ /min	■ fl oz/min (us)	■ bbl/min (imp;beer)
■ m ³ /h	■ fl oz/h (us)	■ bbl/h (imp;beer)
■ m ³ /d	■ fl oz/d (us)	■ bbl/d (imp;beer)
■ ml/s	■ gal/s (us)	■ bbl/s (imp;oil)
■ ml/min	■ gal/min (us)	■ bbl/min (imp;oil)
■ ml/h	■ gal/h (us)	■ bbl/h (imp;oil)
■ ml/d	■ gal/d (us)	■ bbl/d (imp;oil)
■ l/s	■ kgal/s (us)	
■ l/min	■ kgal/min (us)	
■ l/h	■ kgal/h (us)	
■ l/d	■ kgal/d (us)	
■ hl/s	■ Mgal/s (us)	
■ hl/min	■ Mgal/min (us)	
■ hl/h	■ Mgal/h (us)	
■ hl/d	■ Mgal/d (us)	
■ Ml/s	■ bbl/s (us;liq.)	
■ Ml/min	■ bbl/min (us;liq.)	
■ Ml/h	■ bbl/h (us;liq.)	
■ Ml/d	■ bbl/d (us;liq.)	
	■ bbl/s (us;beer)	
	■ bbl/min (us;beer)	
	■ bbl/h (us;beer)	
	■ bbl/d (us;beer)	
	■ bbl/s (us;oil)	
	■ bbl/min (us;oil)	
	■ bbl/h (us;oil)	
	■ bbl/d (us;oil)	
	■ bbl/s (us;tank)	
	■ bbl/min (us;tank)	
	■ bbl/h (us;tank)	
	■ bbl/d (us;tank)	

Factory setting

Country-specific:

- l/h
- gal/min (us)

Additional information*Result*

The selected unit applies for:

Volume flow parameter (→  35)*Selection*
 For an explanation of the abbreviated units: →  162

Volume unit**Navigation**

Expert → Sensor → System units → Volume unit

Description

Use this function to select the unit for the volume.

Selection*SI units*

- cm³
- dm³
- m³
- ml
- l
- hl
- Ml Mega

US units

- af
- ft³
- fl oz (us)
- gal (us)
- kgal (us)
- Mgal (us)
- bbl (us;oil)
- bbl (us;liq.)
- bbl (us;beer)
- bbl (us;tank)

Imperial units

- gal (imp)
- Mgal (imp)
- bbl (imp;beer)
- bbl (imp;oil)

Factory setting

Country-specific:

- m³
- gal (us)

Additional information*Selection*

For an explanation of the abbreviated units: → [162](#)

Conductivity unit**Navigation**

Expert → Sensor → System units → Conductiv. unit

Prerequisite

In the **Conductivity measurement** parameter (→ [49](#)), the **On** option is selected.

Description

Use this function to select the unit for the conductivity.

Selection*SI units*

- nS/cm
- µS/cm
- µS/m
- µS/mm
- mS/m
- mS/cm
- S/cm
- S/m
- kS/m
- MS/m

Factory setting

µS/cm

Additional information*Result*

The selected unit applies for:

- **Conductivity** parameter (→ 36)
- **Corrected conductivity** parameter (→ 37)

Selection

 For an explanation of the abbreviated units: → 162

Temperature unit**Navigation**

Expert → Sensor → System units → Temperature unit

Description

Use this function to select the unit for the temperature.

Selection*SI units*

- °C
- K

US units

- °F
- °R

Factory setting

Country-specific:

- °C
- °F

Additional information*Result*

The selected unit applies for:

- **Temperature** parameter (→ 36)
- **Maximum value** parameter (→ 153)
- **Minimum value** parameter (→ 153)
- **External temperature** parameter (→ 59)
- **Maximum value** parameter (→ 154)
- **Minimum value** parameter (→ 154)

Selection

 For an explanation of the abbreviated units: → 162

Mass flow unit**Navigation**

Expert → Sensor → System units → Mass flow unit

Description

Use this function to select the unit for the mass flow.

Selection	<i>SI units</i>	<i>US units</i>
■ g/s	■ oz/s	
■ g/min	■ oz/min	
■ g/h	■ oz/h	
■ g/d	■ oz/d	
■ kg/s	■ lb/s	
■ kg/min	■ lb/min	
■ kg/h	■ lb/h	
■ kg/d	■ lb/d	
■ t/s	■ STon/s	
■ t/min	■ STon/min	
■ t/h	■ STon/h	
■ t/d	■ STon/d	

Factory setting	Country-specific: ■ kg/h ■ lb/min
-----------------	---

Additional information	<i>Result</i> The selected unit applies for: Mass flow parameter (→ 36)
------------------------	--

Selection

 For an explanation of the abbreviated units: → 162

Mass unit

Navigation	 Expert → Sensor → System units → Mass unit
------------	--

Description	Use this function to select the unit for the mass.
-------------	--

Selection	<i>SI units</i>	<i>US units</i>
■ g	■ oz	
■ kg	■ lb	
■ t	■ STon	

Factory setting	Country-specific: ■ kg ■ lb
-----------------	-----------------------------------

Additional information	<i>Selection</i>  For an explanation of the abbreviated units: → 162
------------------------	--

Density unit**Navigation**

Expert → Sensor → System units → Density unit

Description

Use this function to select the unit for the density.

Selection*SI units*

- g/cm³
- g/m³
- kg/dm³
- kg/l
- kg/m³
- SD4°C
- SD15°C
- SD20°C
- SG4°C
- SG15°C
- SG20°C

US units

- lb/ft³
- lb/gal (us)
- lb/bbl (us;liq.)
- lb/bbl (us;beer)
- lb/bbl (us;oil)
- lb/bbl (us;tank)

Imperial units

- lb/gal (imp)
- lb/bbl (imp;beer)
- lb/bbl (imp;oil)

Factory setting

Country-specific:

- kg/l
- lb/ft³

Additional information*Result*

The selected unit applies for:

- **External density** parameter (→ 59)
- **Fixed density** parameter (→ 59)

Selection

- SD = specific density

The specific density is the ratio of the density of the fluid to the density of water at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

- SG = specific gravity

The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of +4 °C (+39 °F), +15 °C (+59 °F), +20 °C (+68 °F).

For an explanation of the abbreviated units: → 162

Corrected volume flow unit**Navigation**

Expert → Sensor → System units → Cor.volflow unit

Description

Use this function to select the unit for the corrected volume flow.

Selection	<i>SI units</i>	<i>US units</i>
	■ Nl/s	■ Sft ³ /s
	■ Nl/min	■ Sft ³ /min
	■ Nl/h	■ Sft ³ /h
	■ Nl/d	■ Sft ³ /d
	■ Nm ³ /s	■ Sgal/s (us)
	■ Nm ³ /min	■ Sgal/min (us)
	■ Nm ³ /h	■ Sgal/h (us)
	■ Nm ³ /d	■ Sgal/d (us)
	■ Sm ³ /s	■ Sbbl/s (us;liq.)
	■ Sm ³ /min	■ Sbbl/min (us;liq.)
	■ Sm ³ /h	■ Sbbl/h (us;liq.)
	■ Sm ³ /d	■ Sbbl/d (us;liq.)
		■ Sgal/s (imp)
		■ Sgal/min (imp)
		■ Sgal/h (imp)
		■ Sgal/d (imp)
Factory setting	Country-specific:	
	■ Nl/h	
	■ Sft ³ /h	
Additional information	<i>Result</i>	
	The selected unit applies for: Corrected volume flow parameter (→  36)	
	<i>Selection</i>	
	 For an explanation of the abbreviated units: →  162	

Corrected volume unit



Navigation  Expert → Sensor → System units → Corr. vol. unit

Description Use this function to select the unit for the corrected volume.

Selection	<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
	■ Nl	■ Sft ³	Sgal (imp)
	■ Nm ³	■ Sgal (us)	
	■ Sm ³	■ Sbbl (us;liq.)	

Factory setting Country-specific:
■ Nm³
■ Sft³

Additional information *Selection*

 For an explanation of the abbreviated units: →  162

Date/time format**Navigation**

Expert → Sensor → System units → Date/time format

Description

Use this function to select the desired time format for calibration history.

Selection

- dd.mm.yy hh:mm
- dd.mm.yy hh:mm am/pm
- mm/dd/yy hh:mm
- mm/dd/yy hh:mm am/pm

Factory setting

dd.mm.yy hh:mm

Additional information*Selection*

For an explanation of the abbreviated units: → 162

3.2.3 "Process parameters" submenu

Navigation

Expert → Sensor → Process param.

► Process parameters	
Filter options	→ 47
Flow damping	→ 48
Flow override	→ 48
Conductivity damping	→ 49
Temperature damping	→ 49
Conductivity measurement	→ 49
► Low flow cut off	→ 50
► Empty pipe detection	→ 53
► Electrode cleaning circuit	→ 56

Filter options**Navigation**

Expert → Sensor → Process param. → Filter options

Description

Use this function to select a filter option.

Selection

- Standard CIP off
- Standard CIP on
- Dynamic CIP off
- Dynamic CIP on
- Binomial filter

Factory setting

Standard CIP off

Additional information*Description*

The user can choose from a range of filter combinations which can optimize the measurement result depending on the application. Each change in the filter setting affects the output signal of the measuring device. The response time of the output signal increases as the filter depth increases.

*Selection***▪ Standard**

- Strong flow damping with a short output signal response time.
- Some time is needed before a stable output signal can be generated.
- Not suitable for pulsating flow as the average flow can be different here.

▪ Dynamic

- Average flow damping with a delayed output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

▪ Binomial

- Weak flow damping with a short output signal response time.
- The average flow is displayed correctly over a measuring interval determined over a long period.

▪ CIP

- This filter is also available for the **Standard** and **Dynamic** filter options.
- If the CIP filter has detected a change in the medium (abrupt increase in the noise level, e.g. quickly changing medium conductivity values during CIP cleaning), flow damping is greatly increased and the raw value (before flow damping) is limited by the mean value (delimiter). This eliminates extremely high measured errors (up to several 100 m/s).
- If the CIP filter is enabled, the response time of the entire measuring system increases and the output signal is delayed accordingly.

*Examples**Possible applications for the filters*

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Pulsating flow (flow is negative intermittently)	----	---	++	--	++
Flow changes frequently (flow is dynamic)	-	--	++	-	++
Clear signal, quick control loop (< 1 s)	--	--	+ ¹⁾		++
Poor signal, slow control loop (response time of a few seconds)	++	-	--	---	---
Permanently bad signal	++	--	-	---	-

Application	Standard	Standard CIP	Dynamic	Dynamic CIP	Binomial
Short and severe signal distortion after a while	++			++	
Promag 50/53 replacement: Promag 100 system damping = 0.5 * Promag 50/53					+++
Promag 10 replacement: Promag 100 system damping = Promag 10 + 2			+++		
For a stable flow signal (no other requirements)	+++				

1) Flow damping value < 6

Flow damping



Navigation

Expert → Sensor → Process param. → Flow damping

Description

Use this function to enter flow damping. Reduction of the variability of the flow measured value (in relation to interference). For this purpose, the depth of the flow filter is adjusted: when the filter setting increases, the reaction time of the device also increases.

User entry

0 to 15

Factory setting

7

Additional information

User entry

- Value = 0: no damping
- Value > 0: damping is increased



- 0 is a weak damping and 15 a strong one.
- A damping of 0 is not recommended, as the measuring signal is then so noisy that it is almost impossible to carry out a measurement.
- The damping depends on the measuring period and the filter type selected.
- An increase or decrease in the damping depends on the application.

Effect



The damping affects the following variables of the device:

- Outputs
- Low flow cut off → 50
- Totalizers → 126

Flow override



Navigation

Expert → Sensor → Process param. → Flow override

Description

Use this function to select whether to interrupt the evaluation of measured values. This is useful for the cleaning processes of a pipeline, for example.

Selection

- Off
- On

Factory setting Off

Additional information *Result*



This setting affects all the functions and outputs of the measuring device.

Description

Flow override is active

- The diagnostic message diagnostic message **△C453 Flow override** is displayed.
- Output values
 - Output: Value at zero flow
 - Temperature: proceeding output
 - Totalizers 1-3: Stop being totalized

Conductivity damping



Navigation Expert → Sensor → Process param. → Conduct. damping

Prerequisite In the **Conductivity measurement** parameter (→ 49), the **On** option is selected.

Description Use this function to enter the time constant for conductivity damping.

User entry 0 to 999.9 s

Factory setting 0 s

Temperature damping



Navigation Expert → Sensor → Process param. → Temp. damping

Prerequisite For the following order code:
"Sensor Option", option CI "Fluid temperature probe"

Description Use this function to enter the time constant for temperature damping.

User entry 0 to 999.9 s

Factory setting 0 s

Conductivity measurement



Navigation Expert → Sensor → Process param. → Conduct. measur.


Description Use this function to enable and disable conductivity measurement.

Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off
Additional information	<p><i>Description</i></p> <p>i For conductivity measurement to work, the medium must have a minimum conductivity of 5 µS/cm.</p>

"Low flow cut off" submenu

Navigation

Expert → Sensor → Process param. → Low flow cut off



Assign process variable



Navigation

Expert → Sensor → Process param. → Low flow cut off → Assign variable

Description

Use this function to select the process variable for low flow cutoff detection.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow

Factory setting

Volume flow

On value low flow cutoff

Navigation Expert → Sensor → Process param. → Low flow cut off → On value

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ [50](#)):
■ Volume flow
■ Mass flow
■ Corrected volume flow

Description Use this function to enter a switch-on value for low flow cut off. Low flow cut off is activated if the value entered is not equal to 0 → [51](#).

User entry Signed floating-point number

Factory setting Depends on country and nominal diameter → [159](#)

Additional information *Dependency*

The unit depends on the process variable selected in the **Assign process variable** parameter (→ [50](#)).

Off value low flow cutoff


Navigation Expert → Sensor → Process param. → Low flow cut off → Off value

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ [50](#)):
■ Volume flow
■ Mass flow
■ Corrected volume flow

Description Use this function to enter a switch-off value for low flow cut off. The off value is entered as a positive hysteresis from the on value → [51](#).

User entry 0 to 100.0 %

Factory setting 50 %

Additional information*Example*

- Q* Flow
- t* Time
- H* Hysteresis
- A* Low flow cut off active
- 1 Low flow cut off is activated
- 2 Low flow cut off is deactivated
- 3 On value entered
- 4 Off value entered

Pressure shock suppression**Navigation**

Expert → Sensor → Process param. → Low flow cut off → Pres. shock sup.

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 50):

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to enter the time interval for signal suppression (= active pressure shock suppression).

User entry

0 to 100 s

Factory setting

0 s

Additional information*Description***Pressure shock suppression is enabled**


- Prerequisite:
Flow rate < on-value of low flow cut off
- Output values
 - Flow displayed: 0
 - Totalizer: the totalizers are pegged at the last correct value

Pressure shock suppression is disabled

- Prerequisite: the time interval set in this function has elapsed.
- If the flow also exceeds the switch-off value for low flow cut off, the device starts processing the current flow value again and displays it.

Example

When closing a valve, momentarily strong fluid movements may occur in the pipeline, which are registered by the measuring system. These totalized flow values lead to a false totalizer status, particularly during batching processes.



- Q Flow
 t Time
 A Drip
 B Pressure shock
 C Pressure shock suppression active as specified by the time entered
 D Pressure shock suppression inactive
 1 Valve closes
 2 Flow falls below the on-value of the low flow cut off: pressure shock suppression is activated
 3 The time entered has elapsed: pressure shock suppression is deactivated
 4 The actual flow value is now displayed and output
 5 On value for low flow cut off
 6 Off value for low flow cut off

"Empty pipe detection" submenu

Navigation

Diagram Expert → Sensor → Process param. → Empty pipe det.

► Empty pipe detection	
Empty pipe detection	→ 54
Switch point empty pipe detection	→ 54
Response time empty pipe detection	→ 54
Empty pipe adjust value	→ 55
Full pipe adjust value	→ 55
Measured value EPD	→ 56
► Empty pipe adjust	

Empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Empty pipe det.
Description	Use this function to switch empty pipe detection on and off.
Selection	<ul style="list-style-type: none">▪ Off▪ On
Factory setting	Off

Switch point empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Switch point EPD
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 54).
Description	Use this function to enter the percentage threshold value of the resistance in relation to the adjustment values.
User entry	0 to 100 %
Factory setting	10 %

Response time empty pipe detection



Navigation	Expert → Sensor → Process param. → Empty pipe det. → Response time
Prerequisite	In the Empty pipe detection parameter (→ 54), the On option is selected.
Description	Enter the minimum length of time (debouncing time) the signal must be present for the diagnostic message △S862 Empty pipe to be triggered if the measuring pipe is empty or partially full.
User entry	0 to 100 s
Factory setting	1 s

New adjustment



Navigation	Expert → Sensor → Process param. → Empty pipe det. → New adjustment
Prerequisite	The On option is selected in the Empty pipe detection parameter (→ 54).
Description	For selecting whether to perform an empty pipe or full pipe adjustment.

Selection	<ul style="list-style-type: none">■ Cancel■ Empty pipe adjust■ Full pipe adjust
------------------	---

Factory setting	Cancel
------------------------	--------

Progress

Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Progress
-------------------	---

Prerequisite The **On** option is selected in the **Empty pipe detection** parameter (→ [54](#)).

Description Use this function to view the progress.

User interface	<ul style="list-style-type: none">■ Ok■ Busy■ Not ok
-----------------------	--

Empty pipe adjust value



Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Empty pipe value
-------------------	---

Prerequisite ■ In the **Empty pipe detection** parameter (→ [54](#)), the **On** option is selected.
■ Adjustment value > full pipe value.

Description Displays the adjustment value when the measuring pipe is empty.

User interface Positive floating-point number

Full pipe adjust value



Navigation	  Expert → Sensor → Process param. → Empty pipe det. → Full pipe value
-------------------	--

Prerequisite ■ In the **Empty pipe detection** parameter (→ [54](#)), the **On** option is selected.
■ Adjustment value < empty pipe value.

Description Displays the adjustment value when the measuring pipe is full.


User interface Positive floating-point number

Measured value EPD

Navigation	Expert → Sensor → Process param. → Empty pipe det. → Meas. value EPD
Prerequisite	In the Empty pipe detection parameter (→ 54), the On option is selected.
Description	Displays the current measured value.
User interface	Positive floating-point number

"Electrode cleaning circuit" submenu

Navigation Expert → Sensor → Process param. → ECC



Electrode cleaning circuit



Navigation Expert → Sensor → Process param. → ECC → ECC

Prerequisite For the following order code:
"Application package", option EC "ECC electrode cleaning"

Description Use this function to enable and disable cyclic electrode cleaning.

Selection

- Off
- On

Factory setting Off

ECC duration

Navigation Expert → Sensor → Process param. → ECC → ECC duration

Prerequisite For the following order code:
"Application package", option EC "ECC electrode cleaning"

Description Use this function to enter the duration of electrode cleaning in seconds.

User entry 0.01 to 30 s

Factory setting 2 s

ECC recovery time

Navigation Expert → Sensor → Process param. → ECC → ECC recov. time

Prerequisite For the following order code:
"Application package", option EC "ECC electrode cleaning"

Description Use this function to enter the recovery time after electrode cleaning to prevent signal output interference. The current output values are frozen in the meanwhile.

User entry Positive floating-point number

Factory setting 60 s

ECC cleaning cycle

Navigation Expert → Sensor → Process param. → ECC → ECC clean. cycle

Prerequisite For the following order code:
"Application package", option EC "ECC electrode cleaning"

Description Use this function to enter the pause duration until the next electrode cleaning.

User entry 0.5 to 168 h

Factory setting 0.5 h

ECC Polarity**Navigation**

Expert → Sensor → Process param. → ECC → ECC Polarity

Prerequisite

For the following order code:
"Application package", option EC "ECC electrode cleaning"

Description

Displays the polarity of the electrode cleaning circuit.

User interface

- Positive
- Negative

Factory setting

Depends on the electrode material:

- Platinum: **Negative** option
- Tantalum, Alloy C22, stainless steel: **Positive** option

3.2.4 "External compensation" submenu**Navigation**

Expert → Sensor → External comp.

► External compensation	
Temperature source	→ 58
External temperature	→ 59
Density source	→ 59
External density	→ 59
Fixed density	→ 59
Reference density	→ 60

Temperature source**Navigation**

Expert → Sensor → External comp. → Temp. source

Description

Use this function to select the temperature source.

Selection

- Internal temperature sensor
- External value

Factory setting

External value

External temperature

Navigation	 Expert → Sensor → External comp. → External temp.
Prerequisite	The External value option is selected in the Temperature source parameter (→  58).
Description	Displays the temperature read in by the external device.
User interface	Floating point number with sign
Additional information	<i>Dependency</i>  The unit is taken from the Temperature unit parameter (→  42)

Density source

Navigation	 Expert → Sensor → External comp. → Density source
Description	Use this function to select the density source.
Selection	<ul style="list-style-type: none">■ Fixed density■ External density
Factory setting	Fixed density

External density

Navigation	 Expert → Sensor → External comp. → External density
Prerequisite	In the Density source parameter (→  59), the External density option is selected.
Description	Displays the density read in from the external device.
User interface	Positive floating-point number
Additional information	<i>Dependency</i>  The unit is taken from the Density unit parameter (→  44)

Fixed density

Navigation	 Expert → Sensor → External comp. → Fixed density
Description	Use this function to enter a fixed value for the density.

User entry Positive floating-point number

Factory setting Country-specific:
■ 1 000 kg/l
■ 1 000 lb/ft³

Additional information *Dependency*
 The unit is taken from the **Density unit** parameter (→ 44)

Reference density



Navigation  Expert → Sensor → External comp. → Ref.density

Description Use this function to enter a fixed value for the reference density.


User entry Positive floating-point number

Factory setting Country-specific:
■ 1 kg/l
■ 1 lb/ft³

Additional information *Dependency*
 The unit is taken from the **Density unit** parameter (→ 44)

3.2.5 "Sensor adjustment" submenu

Navigation  Expert → Sensor → Sensor adjustm.



Installation direction**Navigation**

Expert → Sensor → Sensor adjustm. → Install. direct.

Description

Use this function to change the sign of the medium flow direction.

Selection

- Flow in arrow direction
- Flow against arrow direction

Factory setting

Flow in arrow direction

Additional information*Description*

Before changing the sign: ascertain the actual direction of fluid flow with reference to the direction indicated by the arrow on the sensor nameplate.

Integration time**Navigation**

Expert → Sensor → Sensor adjustm. → Integration time

Description

Display the duration of an integration cycle.

User interface

1 to 65 ms

Measuring period**Navigation**

Expert → Sensor → Sensor adjustm. → Measuring period

Description

Display the time of a full measuring period.

User interface

50 to 1 000 ms

"Process variable adjustment" submenu*Navigation*

Expert → Sensor → Sensor adjustm. → Variable adjust

▶ Process variable adjustment	
Volume flow offset	→ 62
Volume flow factor	→ 62
Mass flow offset	→ 63

Mass flow factor	→ 63
Conductivity offset	→ 63
Conductivity factor	→ 64
Corrected volume flow offset	→ 64
Corrected volume flow factor	→ 64
Temperature offset	→ 65
Temperature factor	→ 65

Volume flow offset**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow offset

Description

Use this function to enter the zero point shift for the volume flow trim. The volume flow unit on which the shift is based is m³/s.

User entry

Signed floating-point number

Factory setting

0 m³/s

Additional information*Description*

Corrected value = (factor × value) + offset

Volume flow factor**Navigation**

Expert → Sensor → Sensor adjustm. → Variable adjust → Vol. flow factor

Description

Use this function to enter a quantity factor (without time) for the volume flow. This multiplication factor is applied over the volume flow range.

User entry

Positive floating-point number

Factory setting

1

Additional information*Description*

Corrected value = (factor × value) + offset

Mass flow offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow offset

Description Use this function to enter the zero point shift for the mass flow trim. The mass flow unit on which the shift is based is kg/s.

User entry Signed floating-point number

Factory setting 0 kg/s

Additional information *Description*

Corrected value = (factor × value) + offset

Mass flow factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Mass flow factor

Description Use this function to enter a quantity factor (without time) for the mass flow. This multiplication factor is applied over the mass flow range.

User entry Positive floating-point number

Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

Conductivity offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. offset

Prerequisite In the **Conductivity measurement** parameter (→ 49), the **On** option is selected.

Description Use this function to enter the zero point shift for the conductivity trim. The conductivity unit on which the shift is based is S/m

User entry Signed floating-point number

Factory setting 0 S/m

Additional information *Description*

Corrected value = (factor × value) + offset

Conductivity factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Conduct. factor
Prerequisite	In the Conductivity measurement parameter (→ 49), the On option is selected.
Description	Use this function to enter a quantity factor for the conductivity. This multiplication factor is applied over the conductivity range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected volume flow offset



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol offset
Description	Use this function to enter the zero point shift for the corrected volume flow trim. The corrected volume flow unit on which the shift is based is 1 Nm ³ /s.
User entry	Signed floating-point number
Factory setting	0 Nm ³ /s
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Corrected volume flow factor



Navigation	Expert → Sensor → Sensor adjustm. → Variable adjust → Corr. vol factor
Description	Use this function to enter a quantity factor (without time) for the corrected volume flow. This multiplication factor is applied over the corrected volume flow range.
User entry	Positive floating-point number
Factory setting	1
Additional information	<i>Description</i> Corrected value = (factor × value) + offset

Temperature offset

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. offset

Prerequisite For the following order code:
"Sensor Option", option CI "Fluid temperature probe"

Description Use this function to enter the zero point shift for the temperature trim. The temperature unit on which the shift is based is 1 K.

User entry Signed floating-point number

Factory setting 0 K

Additional information *Description*

Corrected value = (factor × value) + offset

Temperature factor

Navigation Expert → Sensor → Sensor adjustm. → Variable adjust → Temp. factor

Prerequisite For the following order code:
"Sensor Option", option CI "Fluid temperature probe"

Description Use this function to enter a quantity factor (without time) for the temperature. This multiplication factor is applied over the temperature range.

User entry Positive floating-point number


Factory setting 1

Additional information *Description*

Corrected value = (factor × value) + offset

3.2.6 "Calibration" submenu

Navigation Expert → Sensor → Calibration



Zero point	→ 66
Conductivity calibration factor	→ 67

Nominal diameter

Navigation Expert → Sensor → Calibration → Nominal diameter

Description Displays the nominal diameter of the sensor.

User interface DNxx / x"

Factory setting Depends on the size of the sensor

Additional information *Description*

The value is also specified on the sensor nameplate.

Calibration factor

Navigation Expert → Sensor → Calibration → Cal. factor

Description Displays the current calibration factor for the sensor.

User interface Positive floating-point number

Factory setting Depends on nominal diameter and calibration.

Zero point



Navigation Expert → Sensor → Calibration → Zero point

Description This function shows the zero point correction value for the sensor.

User interface Signed floating-point number

Factory setting Depends on nominal diameter and calibration

Conductivity calibration factor**Navigation**

Expert → Sensor → Calibration → Cond. cal. fact.

Prerequisite

In the **Conductivity measurement** parameter (→ 49), the **On** option is selected.

Description

Displays the calibration factor for the conductivity measurement.


User interface

0 to 10 000

3.3 "Communication" submenu

Navigation


Expert → Communication



3.3.1 "PROFIBUS DP configuration" submenu

Navigation

Expert → Communication → PROFIBUS DP conf



Address mode**Navigation**

Expert → Communication → PROFIBUS DP conf → Address mode

Description

Displays the configured address mode.

User interface	<ul style="list-style-type: none">▪ Hardware▪ Software
Factory setting	Software
Additional information	<i>Description</i>  For detailed information, see the "Setting the device address" section of the Operating Instructions.

Device address	
Navigation	 Expert → Communication → PROFIBUS DP conf → Device address
Description	Use this function to enter the device address.
User entry	0 to 126
Factory setting	126
Additional information	<i>Description</i> The address must always be configured for a PROFIBUS device. The valid address range is between 1 and 126. In a PROFIBUS network, each address can only be assigned once. If an address is not configured correctly, the device is not recognized by the master. All measuring devices are delivered from the factory with the device address 126 and with the software addressing method.  Displays the configured address mode: Address mode parameter (→ 67)


Ident number selector	
Navigation	 Expert → Communication → PROFIBUS DP conf → Ident num select
Description	Use this function to select the device master file (GSD).
Selection	<ul style="list-style-type: none">▪ Automatic mode▪ Manufacturer▪ Profile▪ 2 AI, 1 Totalizer (0x9741)▪ 3 AI, 1 Totalizer (0x9742)
Factory setting	Automatic mode
Additional information	<i>Description</i> In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file

(GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

3.3.2 "PROFIBUS DP info" submenu

Navigation

Expert → Communication → PROFIBUS DP info



Status PROFIBUS Master Config

Navigation

Expert → Communication → PROFIBUS DP info → Stat Master Conf

Description

For displaying the status of the PROFIBUS Master configuration.

User interface

- Active
- Not active

Factory setting

Not active

PROFIBUS ident number

Navigation

Expert → Communication → PROFIBUS DP info → Ident number

Description

For displaying the PROFIBUS identification number.

User interface

0 to FFFF

Factory setting

0x1560

Profile version

Navigation   Expert → Communication → PROFIBUS DP info → Profile version

Description Displays the profile version.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting 3.02

Base current

Navigation   Expert → Communication → PROFIBUS DP info → Base current

Description Displays the basic current: Every PA measuring device taps a constant basic current from the MBP cable. This base current must be at least 10 mA. The base current enables power to be supplied to the measuring device.

User interface 16 mA

Baudrate

Navigation   Expert → Communication → PROFIBUS DP info → Baudrate

Description Displays the transmission rate.

User interface

- Not available
- 9.6 kBaud
- 19.2 kBaud
- 31.25 kBaud
- 45.45 kBaud
- 93.75 kBaud
- 187.5 kBaud
- 500 kBaud
- 1.5 MBaud
- 3 MBaud
- 6 MBaud
- 12 MBaud

Factory setting 9.6 kBaud

Master availability

Navigation   Expert → Communication → PROFIBUS DP info → Master avail.

Description Displays whether or not a PROFIBUS master is present in the network.

User interface ■ No
 ■ Yes

Factory setting No

3.3.3 "Physical block" submenu

Navigation

Expert → Communication → Physical block

► Physical block	
Device tag	→ 72
Static revision	→ 72
Strategy	→ 73
Alert key	→ 73
Target mode	→ 73
Mode block actual	→ 73
Mode block permitted	→ 74
Mode block normal	→ 74
Alarm summary	→ 74
Software revision	→ 75
Hardware revision	→ 75
Manufacturer ID	→ 75
Device ID	→ 76
Serial number	→ 76
Diagnostics	→ 76
Diagnostics mask	→ 77
Device certification	→ 77
Factory reset	→ 78

Descriptor	→ 78
Device message	→ 78
Device install date	→ 78
Ident number selector	→ 79
Hardware lock	→ 79
Feature supported	→ 79
Feature enabled	→ 80
Condensed status diagnostic	→ 80

Device tag



Navigation

Expert → Communication → Physical block → Device tag

Description

Use this function to enter the name for the measuring point.

User entry

Max. 32 characters, such as letters, numbers or special characters (e.g. @, %, /).

Factory setting

Promag 100 DP

Static revision

Navigation

Expert → Communication → Physical block → Static revision

Description

Displays the event counter: every write access to a static block parameter is counted.

User interface

0 to FFFF

Additional information

Description

Static parameters are parameters that are not changed by the process.

Strategy**Navigation**

Expert → Communication → Physical block → Strategy

Description

Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry

0 to FFFF

Factory setting

0

Alert key**Navigation**

Expert → Communication → Physical block → Alert key

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

Expert → Communication → Physical block → Target mode

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Out of service

Mode block actual**Navigation**

Expert → Communication → Physical block → Mode block act

Description

Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 73).

User interface

- Auto
- Out of service

Additional information*Description*

A comparison of the current mode with the target mode (**Target mode** parameter (→ 73)) indicates whether it was possible to reach the target mode.

Mode block permitted**Navigation**

Expert → Communication → Physical block → Mode block perm

Description

Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 73) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface

0 to 255

Mode block normal**Navigation**

Expert → Communication → Physical block → Mode blk norm

Description

Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Out of service

Alarm summary**Navigation**

Expert → Communication → Physical block → Alarm summary

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information*Description*

Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Physical Block function block.

User interface

- Discrete alarm
Alarm or warning message with a discrete value.
- Alarm state HiHi limit
Upper alarm limit
- Alarm state Hi limit
Upper warning limit
- Alarm state LoLo limit
Lower alarm limit
- Alarm state Lo limit
Lower warning limit
- Update Event

This option constitutes a special alarm that is triggered if a static parameter is changed. If such a parameter is modified, the associated bit is set in the **Alarm summary** parameter (→ 74), the output of the block switches to "GOOD (NC) Active Update Event" (if the current status has a lower priority than this), and the block remains in this state for a duration of 10 s. The block then reverts to the normal state (the output has the last status and the **Update Event** option bit in the **Alarm summary** parameter (→ 74) is deleted again).

Software revision**Navigation**

Expert → Communication → Physical block → Software rev.

Description

Displays the firmware version of the measuring device.

User interface

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Hardware revision**Navigation**

Expert → Communication → Physical block → Hardware rev.

Description

Displays the hardware revision of the measuring device.

User interface

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Manufacturer ID**Navigation**

Expert → Communication → Physical block → Manufacturer ID

Description

Displays the manufacturer ID with which the measuring device has been registered with the PNO (PROFIBUS User Organization).

User interface 0 to FFFF

Factory setting 0x11

Device ID

Navigation  Expert → Communication → Physical block → Device ID

Description Displays the device ID for identifying the measuring device in a PROFIBUS network.

User interface Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory setting Promag 100 DP

Serial number

Navigation  Expert → Communication → Physical block → Serial number

Description Displays the serial number of the measuring device. It can also be found on the nameplate of the sensor and transmitter.

User interface Max. 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Diagnostics

Navigation  Expert → Communication → Physical block → Diagnostics

Description Displays the diagnostic messages.

User interface

- Hardware failure electronics
- Hardware failure mechanics
- Temperature motor
- Electronic temperature
- Memory checksum error
- Measurement error
- Device not initialized
- Initialization error
- Zero point error
- Power supply
- Configuration invalid
- On warmstart

- On coldstart
- Maintenance required
- Characterization invalid
- Ident number violation
- More information available
- Maintenance alarm
- Maintenance demanded
- Function check or simulation
- Invalid process condition

Diagnostics mask

Navigation  Expert → Communication → Physical block → Diagnostics mask

Description Displays the diagnostic messages supported by the measuring device.

User interface

- Hardware failure electronics
- Hardware failure mechanics
- Temperature motor
- Electronic temperature
- Memory checksum error
- Measurement error
- Device not initialized
- Initialization error
- Zero point error
- Power supply
- Configuration invalid
- On warmstart
- On coldstart
- Maintenance required
- Characterization invalid
- Ident number violation
- More information available
- Maintenance alarm
- Maintenance demanded
- Function check or simulation
- Invalid process condition

Device certification

Navigation  Expert → Communication → Physical block → Dev certificate

Description Displays certificates of the measuring device, e.g. Ex certificate.

User interface Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Factory reset

Navigation Expert → Communication → Physical block → Factory reset

Description Use this function to reset a certain set of parameters in a block.

Selection

- to defaults
- warmstart device
- reset bus address
- Cancel

Factory setting Cancel

Descriptor

Navigation Expert → Communication → Physical block → Descriptor

Description Use this function to enter a user-specific string to describe the device within the application.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Device message

Navigation Expert → Communication → Physical block → Device message

Description Use this function to enter a user-definable message (a string) to describe the device within the application or in the plant.

User entry Max. 32 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Device install date

Navigation Expert → Communication → Physical block → Device inst.date

Description Use this function to enter the date of installation of the device.

User entry Max. 16 Zeichen wie Buchstaben, Zahlen oder Sonderzeichen (z.B. @, %, /).

Ident number selector

Navigation Expert → Communication → Physical block → Ident num select

Description Use this function to select the device master file (GSD).

Selection

- Automatic mode
- Manufacturer
- Profile
- 2 AI, 1 Totalizer (0x9741)
- 3 AI, 1 Totalizer (0x9742)

Factory setting Automatic mode

Additional information *Description*

In order to integrate the field devices into the bus system, the PROFIBUS system needs a description of the device parameters, such as output data, input data, data format, data volume and supported transmission rate. These data are available in the device master file (GSD) which is provided to the PROFIBUS Master when the communication system is commissioned.

Hardware lock

Navigation Expert → Communication → Physical block → Hardware lock

Description Displays the hardware write protection.

User interface

- Unprotected
- Protected

Additional information *Description*

Indicates whether it is possible to write-access the measuring device via PROFIBUS (acyclic data transmission, e.g. via the "FieldCare" operating program).

For detailed information on hardware write protection, see the "Write protection via write protection switch" section of the Operating Instructions.

User interface

- Unprotected
Write access via PROFIBUS is possible (acyclic data transmission).
- Protected
Write access via PROFIBUS is locked (acyclic data transmission).

Feature supported

Navigation Expert → Communication → Physical block → Feature support

Description Displays the PROFIBUS features that are supported by the measuring device.

User interface

- Condensed status
- Classic status diagnosis
- Data exchange broadcast
- MS1 application relationship
- PROFIsafe communication

Feature enabled**Navigation** Expert → Communication → Physical block → Feature enabled**Description**

Displays the PROFIBUS features that are enabled in the measuring device.

User interface

- Condensed status
- Classic status diagnosis
- Data exchange broadcast
- MS1 application relationship
- PROFIsafe communication

Condensed status diagnostic**Navigation** Expert → Communication → Physical block → Condensed status**Description**

Use this function to switch the condensed status diagnostic on and off.


Selection


- Off
- On

Factory setting

On

3.3.4 "Web server" submenu

Navigation Expert → Communication → Web server



Web server language

Navigation

Expert → Communication → Web server → Webserv.language

Description

Use this function to select the web server language setting.

Selection

- English
- Deutsch *
- Français *
- Español *
- Italiano *
- Nederlands *
- Portuguesa *
- Polski *
- русский язык (Russian) *
- Svenska *
- Türkçe *
- 中文 (Chinese) *
- 日本語 (Japanese) *
- 한국어 (Korean) *
- العربية (Arabic) *
- Bahasa Indonesia *
- ภาษาไทย (Thai) *
- tiếng Việt (Vietnamese) *
- čeština (Czech)

Factory setting

English

MAC address

Navigation

Expert → Communication → Web server → MAC Address

Description

Displays the MAC¹⁾ address of the measuring device.

User interface

Unique 12-digit character string comprising letters and numbers

Factory setting

Each measuring device is given an individual address.

Additional information

Example

For the display format
00:07:05:10:01:5F

* Visibility depends on order options or device settings

1) Media Access Control

IP address**Navigation**

Expert → Communication → Web server → IP address

Description

Displays the IP address of the device's web server.

User interface

4 octet: 0 to 255 (in the particular octet)

Factory setting

192.168.1.212

Subnet mask**Navigation**

Expert → Communication → Web server → Subnet mask

Description

Displays the subnet mask.

User interface

4 octet: 0 to 255 (in the particular octet)

Factory setting

255.255.255.0

Default gateway**Navigation**

Expert → Communication → Web server → Default gateway

Description

Displays the default gateway.

User interface

4 octet: 0 to 255 (in the particular octet)

Factory setting

0.0.0.0

Web server functionality**Navigation**

Expert → Communication → Web server → Webserver funct.

Description

Use this function to switch the Web server on and off.

Selection

- Off
- On

Factory setting

On

Additional information*Description*

Once disabled, the Web server functionality can be re-enabled only via the local display or the FieldCare operating tool.


Selection

- Off
 - The web server is completely disabled.
 - Port 80 is locked.
- On
 - The complete functionality of the web server is available.
 - JavaScript is used.
 - The password is transferred in an encrypted state.
 - Any change to the password is also transferred in an encrypted state.

3.4 "Analog inputs" submenu

Navigation


Expert → Analog inputs



3.4.1 "Analog input 1 to 4" submenu

Navigation

Expert → Analog inputs → Analog input 1 to 4



Channel**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Channel

Description

For selecting the process variable.

Selection

- Volume flow
- Mass flow
- Corrected volume flow
- Flow velocity
- Conductivity *
- Corrected conductivity *
- Temperature *
- Electronic temperature

Factory setting

Volume flow

PV filter time**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → PV filter time

Description

Use this function to enter a time to suppress signal peaks. During the specified time the Analog input does not respond to an erratic increase in the process variable.

User entry

Positive floating-point number

Factory setting

0

Fail safe type**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Fail safe type

Description

Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value

A substitute value is used. This is specified in the **Fail safe value** parameter (→ 85).

- Fallback value

If the value was good at one point, then this last valid value is used.

- Off

The system continues to use the bad value.

Fail safe value**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Fail safe value

Prerequisite

In **Fail safe type** parameter (→ 84), the **Fail safe value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 85)) in the event of an error.

User entry

Signed floating-point number

Factory setting

0

Out value**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Out value

Prerequisite

In **Target mode** parameter (→ 87), the **Auto** option is selected.

Description

Displays the analog value which is calculated when the function is executed.

User interface

Signed floating-point number

Out status**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Out status

Description

Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Out status

Prerequisite In **Target mode** parameter (→ 87), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Analog inputs → Analog input 1 to 4 → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Analog inputs → Analog input 1 to 4 → Strategy

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key

Navigation Expert → Analog inputs → Analog input 1 to 4 → Alert key

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Analog inputs → Analog input 1 to 4 → Target mode

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block actual

Navigation Expert → Analog inputs → Analog input 1 to 4 → Mode block act

Description Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 87).

User interface

- Auto
- Man
- Out of service

Additional information *Description*



A comparison of the current mode with the target mode (**Target mode** parameter (→ 87)) indicates whether it was possible to reach the target mode.

Mode block permitted

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Mode block perm
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 87) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Mode blk norm
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service

Alarm summary

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Alarm summary
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alarm state HiHi limit■ Alarm state Hi limit■ Alarm state LoLo limit■ Alarm state Lo limit■ Update Event
Additional information	<i>Description</i>  Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Inputs function block.

Batch ID

Navigation Expert → Analog inputs → Analog input 1 to 4 → Batch ID

Description Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry Positive integer

Batch operation

Navigation Expert → Analog inputs → Analog input 1 to 4 → Batch operation

Description Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch phase

Navigation Expert → Analog inputs → Analog input 1 to 4 → Batch phase

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe Unit Procedure

Navigation Expert → Analog inputs → Analog input 1 to 4 → Batch Recipe

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information	Description
	 The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PV scale lower range 

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → PVscale lo range
Description	Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.
User entry	Signed floating-point number
Factory setting	0

PV scale upper range 

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → PVscale up range
Description	Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.
User entry	Signed floating-point number
Factory setting	100.0

Out scale lower range 

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Out scale low
Description	Use this function to enter the lower value range for the output value in system units.
User entry	Signed floating-point number
Factory setting	0

Out scale upper range 

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Out scale up
Description	Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number

Factory setting 100.0

Lin type 

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Lin type

Description Use this function to switch off the linearization type for the input value.

Selection Off

Factory setting Off

Out unit 

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Out unit

Description Use this function to enter a numerical code (hex) for the system unit.

User entry 0 to 65 535

Factory setting 1997

Out decimal point 

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Out dec_point

Description Use this function to enter the maximum number of decimal places that are displayed for the output value.

User entry 0 to 7

Factory setting 0

Alarm hysteresis 

Navigation  Expert → Analog inputs → Analog input 1 to 4 → Alarm hysteresis

Description Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry Signed floating-point number

Factory setting	0
-----------------	---

Hi Hi Lim



Navigation Expert → Analog inputs → Analog input 1 to 4 → Hi Hi Lim

Description Use this function to enter the value for the upper alarm limit (**Hi Hi alarm value** parameter (→ [93](#))).

User entry Signed floating-point number

Factory setting Positive floating-point number

Additional information *Description*

If the output value Out value (→ [85](#)) exceeds this limit value, the **Hi Hi alarm state** parameter (→ [94](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [91](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [90](#)) and **Out scale upper range** parameter (→ [90](#)).

Hi Lim



Navigation Expert → Analog inputs → Analog input 1 to 4 → Hi Lim

Description Use this function to enter the value for the upper warning limit (**Hi alarm value** parameter (→ [94](#))).

User entry Signed floating-point number

Factory setting Positive floating-point number

Additional information *Description*

If the output value Out value (→ [85](#)) exceeds this limit value, the **Hi alarm state** parameter (→ [94](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [91](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [90](#)) and **Out scale upper range** parameter (→ [90](#)).

Lo Lim**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Lo Lim

Description

Use this function to enter the value for the lower warning limit (**Lo alarm value** parameter (→ [94](#))).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ [85](#)) exceeds this limit value, the **Lo alarm state** parameter (→ [95](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [91](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [90](#)) and **Out scale upper range** parameter (→ [90](#)).

Lo Lo Lim**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → Lo Lo Lim

Description

Use this function to enter the value for the lower alarm limit (**Lo Lo alarm value** parameter (→ [95](#))).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ [85](#)) exceeds this limit value, the **Lo Lo alarm state** parameter (→ [95](#)) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ [91](#))) and must be in the range defined in the **Out scale lower range** parameter (→ [90](#)) and **Out scale upper range** parameter (→ [90](#)).

Hi Hi alarm value**Navigation**

Expert → Analog inputs → Analog input 1 to 4 → HiHi alarm value

Description

Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ [92](#))).

User interface

Signed floating-point number

Hi Hi alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → HiHi alarm state
Description	Displays the status for the upper alarm limit value (Hi Hi Lim parameter (→ 92)).
User interface	<ul style="list-style-type: none">▪ No alarm▪ Alarm state HiHi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Hi alarm value
Description	Displays the alarm value for the upper warning limit value (Hi Lim parameter (→ 92)).
User interface	Signed floating-point number

Hi alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Hi alarm state
Description	Displays the status for the upper warning limit value (Hi Lim parameter (→ 92)).
User interface	<ul style="list-style-type: none">▪ No warning▪ Alarm state Hi limit
Additional information	<i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Lo alarm value
Description	Displays the alarm value for the lower warning limit value (Lo Lim parameter (→ 93)).
User interface	Signed floating-point number

Lo alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Lo alarm state
Description	Displays the status for the lower warning limit value (Lo Lim parameter (→ 93)).
User interface	<ul style="list-style-type: none">▪ No warning▪ Alarm state Lo limit
Additional information	<i>User interface</i>  The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo Lo alarm value

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → LoLo alarm value
Description	Displays the alarm value for the lower alarm limit value (Lo Lo Lim parameter (→ 93)).
User interface	Signed floating-point number

Lo Lo alarm state

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → LoLo alarm state
Description	Displays the status for the lower alarm limit value (Lo Lo Lim parameter (→ 93)).
User interface	<ul style="list-style-type: none">▪ No alarm▪ Alarm state LoLo limit
Additional information	<i>User interface</i>  The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Simulate enabled

Navigation	 Expert → Analog inputs → Analog input 1 to 4 → Simulate enabled
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">▪ Disable▪ Enable
Factory setting	Disable

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value**Navigation**

█ Expert → Analog inputs → Analog input 1 to 4 → Simulate value

Description

Use this function to enter a simulation value for the block.

User entry

Signed floating-point number

Factory setting

0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status**Navigation**

█ Expert → Analog inputs → Analog input 1 to 4 → Simulate status

Description

Use this function to enter a simulation status for the block.

User entry

0 to 255

Factory setting

0

Additional information*Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Out unit text**Navigation**

█ Expert → Analog inputs → Analog input 1 to 4 → Out unit text

Description

Use this function to enter the out unit text: if a specific out unit does not appear in the code list, the user can enter the specific text. The unit code is then equivalent to the definition provided here.

User entry

Max. 16 characters such as letters, numbers or special characters (e.g. @, %, /).


Factory setting

NoUnit

3.5 "Discrete inputs" submenu

Navigation


Expert → Discrete inputs



3.5.1 "Discrete input 1 to 2" submenu

Navigation

Expert → Discrete inputs → Discrete input 1 to 2



Channel



Navigation

Expert → Discrete inputs → Discrete input 1 to 2 → Channel

Description

Use this function to assign a measured variable to the particular function block.

Selection

- Empty pipe detection
- Low flow cut off
- Verification status *

Factory setting

Empty pipe detection

* Visibility depends on order options or device settings

Invert 

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → Invert

Description Use this function to invert the input signal.

Selection

- Off
- On

Factory setting Off

Fail safe type 

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → Fail safe type

Description Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting Off

Additional information *Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 98).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value 

Navigation   Expert → Discrete inputs → Discrete input 1 to 2 → Fail safe value

Prerequisite In **Fail safe type** parameter (→ 98), the **Fail safe value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 99)) in the event of an error.

User entry 0 to 255

Factory setting 0

Out value

Navigation

  Expert → Discrete inputs → Discrete input 1 to 2 → Out value

Prerequisite

In **Target mode** parameter (→  100), the **Auto** option is selected.

Description

Displays the analog value which is calculated when the function is executed.

User interface

0 to 255

Out status

Navigation

  Expert → Discrete inputs → Discrete input 1 to 2 → Out status

Description

Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation

  Expert → Discrete inputs → Discrete input 1 to 2 → Out status

Prerequisite

In **Target mode** parameter (→  100), the **Auto** option is selected.

Description

Displays the current output status (hex value).

User interface

0 to 0xFF

Tag description

**Navigation**

 Expert → Discrete inputs → Discrete input 1 to 2 → Tag description

Description

Use this function to enter a string to identify the block.

User entry

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*

 Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Strategy

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key



Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Alert key

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode



Navigation  Expert → Discrete inputs → Discrete input 1 to 2 → Target mode

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block actual

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Mode block act
Description	Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→  100).
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service
Additional information	<p><i>Description</i></p> <p> A comparison of the current mode with the target mode (Target mode parameter (→  100)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Mode block perm
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→  100) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Mode blk norm
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none">■ Auto■ Man■ Out of service

Alarm summary

Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Alarm summary
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface	<ul style="list-style-type: none">■ Discrete alarm■ Alarm state HiHi limit■ Alarm state Hi limit■ Alarm state LoLo limit■ Alarm state Lo limit■ Update Event
Additional information	<p><i>Description</i></p> <p> Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Inputs function block.</p>

Batch ID	
Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Batch ID
Description	Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.
User entry	Positive integer

Batch operation	
Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Batch operation
Description	Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch phase	
Navigation	 Expert → Discrete inputs → Discrete input 1 to 2 → Batch phase
Description	Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch Recipe Unit Procedure

Navigation	Expert → Discrete inputs → Discrete input 1 to 2 → Batch Recipe
Description	Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).
User entry	0 to 65 535
Factory setting	0
Additional information	<i>Description</i> The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Simulate enabled

Navigation	Expert → Discrete inputs → Discrete input 1 to 2 → Simulate enabled
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">■ Disable■ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate status

Navigation	Expert → Discrete inputs → Discrete input 1 to 2 → Simulate status
Description	Use this function to enter a simulation status for the block.
User entry	0 to 255
Factory setting	0
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Simulate value

Navigation Expert → Discrete inputs → Discrete input 1 to 2 → Simulate value

Description Use this function to enter a simulation value for the block.

User entry 0 to 255


Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.


3.6 "Analog outputs" submenu

Navigation Expert → Analog outputs



3.6.1 "Analog output 1 to 2" submenu

Navigation Expert → Analog outputs → Analog output 1 to 2



Set point value

Navigation Expert → Analog outputs → Analog output 1 to 2 → Set point val

Description Use this function to enter an analog set point.

User entry Signed floating-point number

Factory setting 0

Set point status

Navigation Expert → Analog outputs → Analog output 1 to 2 → Set point status

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Fail safe time

Navigation Expert → Analog outputs → Analog output 1 to 2 → Fail safe time

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry 0 to 999.0

Factory setting 0

Additional information *User entry*

NOTE!

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- ▶ Check in advance to ensure that the safety-specific requirements of the process would permit this.
- ▶ If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type



Navigation Expert → Analog outputs → Analog output 1 to 2 → Fail safe type

Description Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting Fallback value

Additional information *Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
A substitute value is used. This is specified in the **Fail safe value** parameter (→ 106).
- Fallback value
If the value was good at one point, then this last valid value is used.
- Off
The system continues to use the bad value.

Fail safe value



Navigation Expert → Analog outputs → Analog output 1 to 2 → Fail safe value

Prerequisite In **Fail safe type** parameter (→ 106), the **Fallback value** option is selected.

Description Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 106)) in the event of an error.

User entry Signed floating-point number

Factory setting 0

Out value

Navigation Expert → Analog outputs → Analog output 1 to 2 → Out value

Prerequisite In **Target mode** parameter (→ 108), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface Signed floating-point number

Out status

Navigation	  Expert → Analog outputs → Analog output 1 to 2 → Out status
Description	Displays the current output status (Good, Bad, Uncertain).
User interface	<ul style="list-style-type: none">■ Good■ Uncertain■ Bad

Out status

Navigation	  Expert → Analog outputs → Analog output 1 to 2 → Out status
Prerequisite	In Target mode parameter (→ 108), the Auto option is selected.
Description	Displays the current output status (hex value).
User interface	0 to 0xFF

Tag description

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Tag description
Description	Use this function to enter a string to identify the block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Static revision
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>  Static parameters are parameters that are not changed by the process.

Strategy**Navigation**

█ Expert → Analog outputs → Analog output 1 to 2 → Strategy

Description

Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry

0 to FFFF

Factory setting

0

Alert key**Navigation**

█ Expert → Analog outputs → Analog output 1 to 2 → Alert key

Description

Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry

0 to 0xFF

Factory setting

0

Target mode**Navigation**

█ Expert → Analog outputs → Analog output 1 to 2 → Target mode

Description

Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Local override
- Man
- Out of service
- Remote Cascaded

Mode block actual**Navigation**

█ Expert → Analog outputs → Analog output 1 to 2 → Mode block act

Description

Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 108).

User interface	<ul style="list-style-type: none"> ■ Auto ■ Local override ■ Man ■ Out of service ■ Remote Cascaded
Additional information	<p><i>Description</i></p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 108)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Mode block perm
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 108) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Mode blk norm
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.
User interface	<ul style="list-style-type: none"> ■ Auto ■ Local override ■ Man ■ Out of service ■ Remote Cascaded

Alarm summary

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Alarm summary
Description	Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.
User interface	<ul style="list-style-type: none"> ■ Discrete alarm ■ Alarm state HiHi limit ■ Alarm state Hi limit ■ Alarm state LoLo limit ■ Alarm state Lo limit ■ Update Event

Additional information	Description
	 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Analog Outputs function block.

Batch ID

Navigation  Expert → Analog outputs → Analog output 1 to 2 → Batch ID

Description Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry Positive integer

Batch operation

Navigation  Expert → Analog outputs → Analog output 1 to 2 → Batch operation

Description Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch phase

Navigation  Expert → Analog outputs → Analog output 1 to 2 → Batch phase

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe Unit Procedure

Navigation  Expert → Analog outputs → Analog output 1 to 2 → Batch Recipe

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information *Description*



The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

PV scale lower range



Navigation ☐ Expert → Analog outputs → Analog output 1 to 2 → PVscale lo range

Description Use this function to enter the lower value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 0

PV scale upper range



Navigation ☐ Expert → Analog outputs → Analog output 1 to 2 → PVscale up range

Description Use this function to enter the upper value range for the input value (Process Value Scale) in system units. The process value scale normalizes the input value to a user-specific range.

User entry Signed floating-point number

Factory setting 100.0

Readback value

Navigation ☐ Expert → Analog outputs → Analog output 1 to 2 → Readback value

Description Displays the readback value. The readback value indicates the current position of the control element within the travel range (between the open and close position) in PV scale units.

User interface Signed floating-point number

Readback status

Navigation	Expert → Analog outputs → Analog output 1 to 2 → Readback status
Description	Displays the readback status. The readback status contains the status information of the slave.
User interface	0 to 255

RCAS in value



Navigation	Expert → Analog outputs → Analog output 1 to 2 → RCAS in value
Description	Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade RCAS in value parameter (→ 112). The normal algorithm calculates the output value of the block on the basis of this set point.
User entry	Signed floating-point number
Factory setting	0

RCAS in status



Navigation	Expert → Analog outputs → Analog output 1 to 2 → RCAS in status
Description	Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→ 112).
User entry	0 to 255
Factory setting	0

Input channel



Navigation	Expert → Analog outputs → Analog output 1 to 2 → Input channel
Description	Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.
Selection	None
Factory setting	None

Output channel

Navigation Expert → Analog outputs → Analog output 1 to 2 → Output channel

Description Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.

Selection

- External temperature
- External density

Factory setting External temperature

RCAS out value

Navigation Expert → Analog outputs → Analog output 1 to 2 → RCAS out value

Description Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.

User interface Signed floating-point number

RCAS out status

Navigation Expert → Analog outputs → Analog output 1 to 2 → RCAS out status

Description Displays the RCAS out status. Displays the status of the set point.

User interface 0 to 0xFF

Position value

Navigation Expert → Analog outputs → Analog output 1 to 2 → Pos value

Description Displays the current value of the positioner.

User interface 0 to 255

Position status

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Position status
Description	Displays the current status of the positioner.
User interface	0 to 255

Setpoint deviation

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Setp. deviation
Description	Displays the deviation between the set point (Set point value parameter (→  105)) and the actual value (Readback value parameter (→  111)).
User interface	Signed floating-point number

Simulate enabled

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Simulate enabled
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">▪ Disable▪ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value

Navigation	 Expert → Analog outputs → Analog output 1 to 2 → Simulate value
Description	Use this function to enter a simulation value.
User entry	Signed floating-point number
Factory setting	0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status

Navigation Expert → Analog outputs → Analog output 1 to 2 → Simulate status

Description Use this function to enter a simulation status for the block.

User entry 0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.

Increase close

Navigation Expert → Analog outputs → Analog output 1 to 2 → Increase close

Description Use this function to enter the effective direction of the positioner in automatic mode.

User entry 0 to 255

Factory setting 0

Out scale upper range

Navigation Expert → Analog outputs → Analog output 1 to 2 → Out scale up

Description Use this function to enter the upper value range for the output value in system units.

User entry Signed floating-point number

Factory setting 100.0

Out scale lower range

Navigation Expert → Analog outputs → Analog output 1 to 2 → Out scale low


Description Use this function to enter the lower value range for the output value in system units.

User entry Signed floating-point number

Factory setting 0


3.7 "Discrete outputs" submenu

Navigation Expert → Discrete outputs



3.7.1 "Discrete output 1 to 2" submenu

Navigation Expert → Discrete outputs → Discr. out. 1 to 2



Set point value

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Set point val

Description Use this function to enter an analog set point.

User entry 0 to 255

Factory setting 0

Set point status

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Set point status

Description Use this function to enter a status for the analog set point.

User entry 0 to 255

Factory setting 0

Invert

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Invert

Description Use this function to switch inversion on and off. Specifies whether the set point should be inverted before the value is set as the output value or the RCAS value (in the automatic mode).

Selection
■ Off
■ On

Factory setting Off

Fail safe time

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Fail safe time

Description Use this function to enter a time span within which the criteria for an error must be met continuously before an error message or notice message is generated.

User entry Signed floating-point number

Factory setting 0

Additional information*User entry***NOTE!**

If this parameter is used, error messages and notice messages are delayed by the set time before being relayed to the higher-level controller (DCS, etc.).

- Check in advance to ensure that the safety-specific requirements of the process would permit this.
- If the error and notice messages may not be suppressed, a value of 0 seconds must be configured here.

Fail safe type**Navigation**

Expert → Discrete outputs → Discr. out. 1 to 2 → Fail safe type

Description

Use this function to select the failure mode.

Selection

- Fail safe value
- Fallback value
- Off

Factory setting

Fallback value

Additional information*Selection*

If an input or simulation value has the status BAD, the function block uses this predefined failure value:

- Fail safe value
 - A substitute value is used. This is specified in the **Fail safe value** parameter (→ 118).
- Fallback value
 - If the value was good at one point, then this last valid value is used.
- Off
 - The system continues to use the bad value.

Fail safe value**Navigation**

Expert → Discrete outputs → Discr. out. 1 to 2 → Fail safe value

Prerequisite

In **Fail safe type** parameter (→ 118), the **Fail safe value** option is selected.

Description

Use this function to enter a failure value. The value entered is displayed as the output value (**Out value** parameter (→ 119)) in the event of an error.

User entry

0 to 255

Factory setting

0

Out value

Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Out value

Prerequisite In **Target mode** parameter (→ 120), the **Auto** option is selected.

Description Displays the analog value which is calculated when the function is executed.

User interface 0 to 255

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Out status

Description Displays the current output status (Good, Bad, Uncertain).

User interface

- Good
- Uncertain
- Bad

Out status

Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Out status

Prerequisite In **Target mode** parameter (→ 120), the **Auto** option is selected.

Description Displays the current output status (hex value).

User interface 0 to 0xFF

Tag description



Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Tag description

Description Use this function to enter a string to identify the block.

User entry Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Static revision

Description Displays the event counter: every write access to a static block parameter is counted.

User interface 0 to FFFF

Additional information *Description*



Static parameters are parameters that are not changed by the process.

Strategy



Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Strategy

Description Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.

User entry 0 to FFFF

Factory setting 0

Alert key



Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Alert key

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode



Navigation  Expert → Discrete outputs → Discr. out. 1 to 2 → Target mode

Description Displays the Target mode: The target mode specifies which mode of operation is used for this function block. This mode is generally set by a control application.

User interface	<ul style="list-style-type: none"> ■ Local override ■ Remote Cascaded ■ Man ■ Out of service ■ Auto
-----------------------	--

Mode block actual

Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → Mode block act
Description	Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 120).
User interface	<ul style="list-style-type: none"> ■ Local override ■ Remote Cascaded ■ Man ■ Out of service ■ Auto
Additional information	<p>Description</p> <p> A comparison of the current mode with the target mode (Target mode parameter (→ 120)) indicates whether it was possible to reach the target mode.</p>

Mode block permitted

Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → Mode block perm
Description	Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 120) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.
User interface	0 to 255

Mode block normal

Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → Mode blk norm
Description	Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Local override
- Remote Cascaded
- Man
- Out of service
- Auto

Alarm summary

Navigation

█ Expert → Discrete outputs → Discr. out. 1 to 2 → Alarm summary

Description

Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information*Description*

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Discrete Outputs function block.

Batch ID

**Navigation**

█ Expert → Discrete outputs → Discr. out. 1 to 2 → Batch ID

Description

Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry

Positive integer

Batch operation

**Navigation**

█ Expert → Discrete outputs → Discr. out. 1 to 2 → Batch operation

Description

Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry

0 to 65 535

Factory setting

0

Batch phase

Navigation	Expert → Discrete outputs → Discr. out. 1 to 2 → Batch phase
Description	Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.
User entry	0 to 65 535
Factory setting	0

Batch Recipe Unit Procedure

Navigation	Expert → Discrete outputs → Discr. out. 1 to 2 → Batch Recipe
Description	Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).
User entry	0 to 65 535
Factory setting	0
Additional information	<i>Description</i> The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Readback value

Navigation	Expert → Discrete outputs → Discr. out. 1 to 2 → Readback value
Description	Displays the readback value. The readback value indicates the current position of the control element and the element's sensors.
User interface	0 to 255

Readback status

Navigation	Expert → Discrete outputs → Discr. out. 1 to 2 → Readback status
Description	Displays the readback status. Displays the status of the readback value.
User interface	0 to 255

RCAS in value

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → RCAS in value

Description Use this function to enter the RCAS (Remote Cascade) in value. The block set point is set by a control application via the remote cascade **RCAS in value** parameter (→ 124). The normal algorithm calculates the output value of the block on the basis of this set point.

User entry 0 to 255

Factory setting 0

RCAS in status

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → RCAS in status

Description Use this function to enter the RCAS (Remote Cascade) in status. Defines the status for the RCAS in value (→ 124).

User entry 0 to 255

Factory setting 0

Input channel

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Input channel

Description Use this function to select the input channel. The number of logical hardware channels from the converter that is connected to this I/O block.

Selection None

Factory setting None

Output channel

Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Output channel

Description Use this function to select the output channel. The number of logical hardware channels to the converter that is connected to this I/O block.

Selection

- Flow override
- Start verification *

* Visibility depends on order options or device settings

Factory setting	Flow override
------------------------	---------------

RCAS out value

Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → RCAS out value
Description	Displays the RCAS out value. Displays the set point of the block which is made available to the higher-level host for monitoring/back calculation and which makes it possible to take action under certain conditions or in a different mode.
User interface	0 to 255

RCAS out status

Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → RCAS out status
Description	Displays the RCAS out status. Displays the status of the set point.
User interface	0 to 255

Simulate enabled



Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → Simulate enabled
Description	Use this function to enable or disable block simulation.
Selection	<ul style="list-style-type: none">▪ Disable▪ Enable
Factory setting	Disable
Additional information	<i>Description</i> The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated discrete I/O channel during operation.

Simulate value



Navigation	 Expert → Discrete outputs → Discr. out. 1 to 2 → Simulate value
Description	Use this function to enter a simulation value.
User entry	0 to 255

Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated value during operation.

Simulate status



Navigation Expert → Discrete outputs → Discr. out. 1 to 2 → Simulate status

Description Use this function to enter a simulation status for the block.

User entry 0 to 255


Factory setting 0

Additional information *Description*

The simulation is used to bypass the physical I/O channel. In this way, the block remains in the normal mode and uses the simulated status during operation.


3.8 "Application" submenu

Navigation Expert → Application



3.8.1 "Totalizer 1 to 3" submenu

Navigation Expert → Application → Totalizer 1 to 3



Failure mode	→ 130
Totalizer value 1 to 3	→ 131
Totalizer status 1 to 3	→ 131
Totalizer status (Hex) 1 to 3	→ 132

Assign process variable



Navigation Expert → Application → Totalizer 1 to 3 → Assign variable

Description Use this function to select a process variable for the Totalizer 1 to 3.

Selection

- Volume flow
- Mass flow
- Corrected volume flow

Factory setting Volume flow

Additional information *Description*

If the option selected is changed, the device resets the totalizer to 0.

Unit totalizer

Navigation Expert → Application → Totalizer 1 to 3 → Unit totalizer

Prerequisite One of the following options is selected in the **Assign process variable** parameter (→ [127](#)):

- Volume flow
- Mass flow
- Corrected volume flow

Description Use this function to select the process variable of a totalizer.

The unit is selected separately for each totalizer. It is independent of the selection made in the **System units** submenu (→ [38](#)).

Selection	SI units	US units
	<ul style="list-style-type: none"> ▪ g ▪ kg ▪ t 	<ul style="list-style-type: none"> ▪ oz ▪ lb ▪ STon

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ cm ³	■ af	■ gal (imp)
■ dm ³	■ ft ³	■ Mgal (imp)
■ m ³	■ fl oz (us)	■ bbl (imp;beer)
■ ml	■ gal (us)	■ bbl (imp;oil)
■ l	■ kgal (us)	
■ hl	■ Mgal (us)	
■ Ml Mega	■ bbl (us;liq.)	
	■ bbl (us;beer)	
	■ bbl (us;oil)	
	■ bbl (us;tank)	

or

<i>SI units</i>	<i>US units</i>	<i>Imperial units</i>
■ NI	■ Sft ³	Sgal (imp)
■ Nm ³	■ Sgal (us)	
■ SI	■ Sbbl (us;liq.)	
■ Sm ³		

Factory setting

Country-specific:

- m³
- ft³

Additional information*Selection*

The selection is independent of the process variable selected in the **Assign process variable** parameter (→ 127).

Dependency

The following parameters depend on the option selected:

- **Alarm hysteresis** parameter (→ 136)
- **Hi Hi Lim** parameter (→ 136)
- **Hi Lim** parameter (→ 137)
- **Lo Lim** parameter (→ 137)
- **Lo Lo Lim** parameter (→ 138)
- **Totalizer value** parameter (→ 37)
- **Preset value** parameter (→ 129)

Control Totalizer 1 to 3**Navigation**
 Expert → Application → Totalizer 1 to 3 → Control Tot. 1 to 3
Prerequisite

In the **Assign process variable** parameter (→ 127), one of the following options is selected:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to select the control of totalizer value 1-3.

Selection	<ul style="list-style-type: none"> ■ Totalize ■ Reset + hold ■ Preset + hold
Factory setting	Totalize
Additional information	<p><i>Selection</i></p> <ul style="list-style-type: none"> ■ Totalize The totalizer is started or continues totalizing with the current counter reading. ■ Reset + hold The totaling process is stopped and the totalizer is reset to 0. ■ Preset + hold The totaling process is stopped and the totalizer is set to its defined start value from the Preset value parameter.

Preset value 1 to 3

Navigation	 Expert → Application → Totalizer 1 to 3 → Preset value 1 to 3
Prerequisite	One of the following options is selected in the Assign process variable parameter (→ 127): <ul style="list-style-type: none"> ■ Volume flow ■ Mass flow ■ Corrected volume flow
Description	Use this function to enter an initial value for the specific totalizer.
User entry	Signed floating-point number
Factory setting	Country-specific: <ul style="list-style-type: none"> ■ m³ ■ ft³
Additional information	<p><i>User entry</i></p> <p> The unit of the selected process variable is specified for the totalizer in the Unit totalizer parameter (→ 127).</p> <p><i>Example</i></p> <p>This configuration is suitable for applications such as iterative filling processes with a fixed batch quantity.</p>

Totalizer operation mode



Navigation

Expert → Application → Totalizer 1 to 3 → Operation mode

Prerequisite

In the **Assign process variable** parameter (→ 127), one of the following options is selected:

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to select how the totalizer summates the flow.

Selection

- Net flow total
- Forward flow total
- Reverse flow total
- Last valid value

Factory setting

Net flow total

Additional information

Selection

- Net flow total
Positive and negative flow values are totalized and balanced against one another. Net flow is registered in the flow direction.
- Forward flow total
Only the flow in the forward flow direction is totalized.
- Reverse flow total
Only the flow against the forward flow direction is totalized (= reverse flow total).
- Last valid value
The value is frozen. Totaling is stopped.

Failure mode



Navigation

Expert → Application → Totalizer 1 to 3 → Failure mode

Prerequisite

One of the following options is selected in the **Assign process variable** parameter (→ 127):

- Volume flow
- Mass flow
- Corrected volume flow

Description

Use this function to select how a totalizer behaves in the event of a device alarm.

Selection

- Stop
- Actual value
- Last valid value

Factory setting

Actual value

Additional information*Description*

 This setting does not affect the failsafe mode of other totalizers and the outputs. This is specified in separate parameters.

Selection

■ Stop

Totalizing is stopped when a device alarm occurs.

■ Actual value

The totalizer continues to count based on the current measured value; the device alarm is ignored.

■ Last valid value

The totalizer continues to count based on the last valid measured value before the device alarm occurred.

Totalizer value 1 to 3**Navigation**

  Expert → Application → Totalizer 1 to 3 → Totalizer val. 1 to 3

Prerequisite

In the **Target mode** parameter (→ 133), the **Auto** option is selected.

Description

Displays the current reading for totalizer 1-3.

User interface

Signed floating-point number

Additional information*Description*

 In the event of an error, the totalizer adopts the mode defined in the **Failure mode** parameter (→ 130).

User interface

The value of the process variable totalized since measuring began can be positive or negative. This depends on the settings in the **Totalizer operation mode** parameter (→ 130).

Dependency

 The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Totalizer status 1 to 3**Navigation**

  Expert → Application → Totalizer 1 to 3 → Tot. status 1 to 3

Description

Displays the status of the particular totalizer.

User interface

- Good
- Uncertain
- Bad

Totalizer status (Hex) 1 to 3

Navigation	Expert → Application → Totalizer 1 to 3 → Status (Hex) 1 to 3
Prerequisite	In Target mode parameter (→ 133), the Auto option is selected.
Description	Displays the status value (hex) of the particular totalizer.
User interface	0 to 0xFF

Tag description



Navigation	Expert → Application → Totalizer 1 to 3 → Tag description
Description	Use this function to enter a string to identify the block.
User entry	Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /).

Static revision

Navigation	Expert → Application → Totalizer 1 to 3 → Static revision
Description	Displays the event counter: every write access to a static block parameter is counted.
User interface	0 to FFFF
Additional information	<i>Description</i>
	Static parameters are parameters that are not changed by the process.

Strategy



Navigation	Expert → Application → Totalizer 1 to 3 → Strategy
Description	Use this function to enter the strategy: makes it possible to group blocks by entering identical numbers.
User entry	0 to FFFF
Factory setting	0

Alert key

Navigation Expert → Application → Totalizer 1 to 3 → Alert key

Description Use this function to enter the alert key: identifies the section of the plant where the transmitter is located. This helps in pinpointing events.

User entry 0 to 0xFF

Factory setting 0

Target mode

Navigation Expert → Application → Totalizer 1 to 3 → Target mode

Description Displays the Target mode: The target mode indicates which mode of operation is used for this function block. This mode is generally set by a control application.

User interface

- Auto
- Man
- Out of service

Mode block actual

Navigation Expert → Application → Totalizer 1 to 3 → Mode block act

Description Displays the Mode block actual: Under certain conditions, it is possible that a function block will not operate in the required mode. In this case, the Mode block actual shows the actual mode in which the function block is currently operating. A comparison of the Mode block actual with the Target mode indicates whether it was possible to reach the Target mode (→ 133).

User interface

- Auto
- Man
- Out of service

Additional information *Description*



A comparison of the current mode with the target mode (**Target mode** parameter (→ 133)) indicates whether it was possible to reach the target mode.

Mode block permitted

Navigation  Expert → Application → Totalizer 1 to 3 → Mode block perm

Description Displays the Mode block permitted: This defines which modes of operation in the Target mode (→ 133) are available for the function block. The operating modes that are supported vary depending on the type and function of the block.

User interface 0 to 255

Mode block normal

Navigation  Expert → Application → Totalizer 1 to 3 → Mode blk norm

Description Displays the Mode block normal: This is available to allow the operator to select the Mode block normal from the available modes of operation. This can be set using an operating tool in order to help the user configure the operating mode of a function block.

User interface

- Auto
- Man
- Out of service

Alarm summary

Navigation  Expert → Application → Totalizer 1 to 3 → Alarm summary

Description Displays the alarm summary: the current status of the block alarms is displayed. A summary of up to 16 statuses can be displayed.

User interface

- Discrete alarm
- Alarm state HiHi limit
- Alarm state Hi limit
- Alarm state LoLo limit
- Alarm state Lo limit
- Update Event

Additional information *Description*

 Currently, the system only displays a change in a static parameter for 10 seconds, and violations of the early warning and alarm limits in the Totalizer function block.

Batch ID

Navigation Expert → Application → Totalizer 1 to 3 → Batch ID

Description Use this function to enter the batch ID: identification of a specific batch to make it possible to assign device-specific information (e.g. errors, alarm conditions etc.) to the batching process.

User entry Positive integer

Factory setting 0

Batch operation

Navigation Expert → Application → Totalizer 1 to 3 → Batch operation

Description Use this function to enter the batch operation: control recipe operation number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch phase

Navigation Expert → Application → Totalizer 1 to 3 → Batch phase

Description Use this function to enter the batch phase: control recipe phase number to identify the active control recipe operation.

User entry 0 to 65 535

Factory setting 0

Batch Recipe Unit Procedure

Navigation Expert → Application → Totalizer 1 to 3 → Batch Recipe

Description Use this function to enter the batch recipe unit procedure (RUP): identification of the active control recipe unit procedure or the associated unit (e.g. inductor, centrifuge, drying agent).

User entry 0 to 65 535

Factory setting 0

Additional information*Description*

The unit is defined in IEC61512 Part1/ISA S88 but its meaning is different to that of the parameter unit, such as system units.

Alarm hysteresis**Navigation**

Expert → Application → Totalizer 1 to 3 → Alarm hysteresis

Description

Use this function to enter the hysteresis value for the upper and lower warning or alarm limit values.

User entry

Signed floating-point number

Factory setting

0 m³

Additional information*User entry*

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Hi Hi Lim**Navigation**

Expert → Application → Totalizer 1 to 3 → Hi Hi Lim

Description

Use this function to enter the value for the upper alarm limit of the totalizer (**Hi Hi alarm value** parameter (→ 138)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

If the output value Out value (→ 85) exceeds this limit value, the **Hi Hi alarm state** parameter (→ 138) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 91)) and must be in the range defined in the **Out scale lower range** parameter (→ 90) and **Out scale upper range** parameter (→ 90).



The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Hi Lim**Navigation**

Expert → Application → Totalizer 1 to 3 → Hi Lim

Description

Use this function to enter the value for the upper warning limit of the totalizer (**Hi alarm value** parameter (→ 139)).

User entry

Signed floating-point number

Factory setting

Positive floating-point number

Additional information*Description*

If the output value Out value (→ 85) exceeds this limit value, the **Hi alarm state** parameter (→ 139) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 91)) and must be in the range defined in the **Out scale lower range** parameter (→ 90) and **Out scale upper range** parameter (→ 90).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Lo Lim**Navigation**

Expert → Application → Totalizer 1 to 3 → Lo Lim

Description

Use this function to enter the value for the lower warning limit of the totalizer (**Lo alarm value** parameter (→ 139)).

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information*Description*

If the output value Out value (→ 85) exceeds this limit value, the **Lo alarm state** parameter (→ 139) is output.

User entry

The value is entered in the defined units (**Out unit** parameter (→ 91)) and must be in the range defined in the **Out scale lower range** parameter (→ 90) and **Out scale upper range** parameter (→ 90).

The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ 127).

Lo Lo Lim**Navigation**

█ Expert → Application → Totalizer 1 to 3 → Lo Lo Lim

Description

Use this function to enter the value for the lower alarm limit of the totalizer (**Lo Lo alarm value** parameter (→ [140\)\)\).](#)

User entry

Signed floating-point number

Factory setting

Negative floating-point number

Additional information**Description**

i If the output value Out value (→ [85\) exceeds this limit value, the **Lo Lo alarm state** parameter \(→ \[140\\)\\) is output.\]\(#\)](#)

User entry

i The value is entered in the defined units (**Out unit** parameter (→ [91\)\) and must be in the range defined in the **Out scale lower range** parameter \(→ \[90\\) and **Out scale upper range** parameter \\(→ \\[90\\\).\\]\\(#\\)\]\(#\)](#)

i The unit of the selected process variable is specified for the totalizer in the **Unit totalizer** parameter (→ [127\).](#)

Hi Hi alarm value**Navigation**

█ Expert → Application → Totalizer 1 to 3 → HiHi alarm value

Description

Displays the alarm value for the upper alarm limit value (**Hi Hi Lim** parameter (→ [136\)\).](#)

User interface

Signed floating-point number

Hi Hi alarm state**Navigation**

█ Expert → Application → Totalizer 1 to 3 → HiHi alarm state

Description

Displays the status for the upper alarm limit value (**Hi Hi Lim** parameter (→ [136\)\).](#)

User interface

- No alarm
- Alarm state HiHi limit

Additional information**User interface**

i The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

Hi alarm value

Navigation  Expert → Application → Totalizer 1 to 3 → Hi alarm value

Description Displays the warning value for the upper warning limit value (**Hi Lim** parameter (→ [137](#))).

User interface Signed floating-point number

Hi alarm state

Navigation  Expert → Application → Totalizer 1 to 3 → Hi alarm state

Description Displays the status for the upper warning limit value (**Hi Lim** parameter (→ [137](#))).

User interface

- No warning
- Alarm state Hi limit

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo alarm value

Navigation  Expert → Application → Totalizer 1 to 3 → Lo alarm value

Description Displays the warning value for the lower warning limit value (**Lo Lim** parameter (→ [137](#))).

User interface Signed floating-point number

Lo alarm state

Navigation  Expert → Application → Totalizer 1 to 3 → Lo alarm state

Description Displays the status for the lower warning limit value (**Lo Lim** parameter (→ [137](#))).

User interface

- No warning
- Alarm state Lo limit

Additional information *User interface*

 The display contains information such as the time of the warning (date and time) and the value that triggered the alarm.

Lo Lo alarm value

Navigation  Expert → Application → Totalizer 1 to 3 → LoLo alarm value

Description Displays the alarm value for the lower alarm limit value (**Lo Lo Lim** parameter (→ [138](#))).

User interface Signed floating-point number

Lo Lo alarm state

Navigation  Expert → Application → Totalizer 1 to 3 → LoLo alarm state

Description Displays the status for the lower alarm limit value (**Lo Lo Lim** parameter (→ [138](#))).

User interface

- No alarm
- Alarm state LoLo limit

Additional information *User interface*

 The display contains information such as the time of the alarm (date and time) and the value that triggered the alarm.

3.9 "Diagnostics" submenu

Navigation

  Expert → Diagnostics

 Diagnostics	
Actual diagnostics	→ 141
Previous diagnostics	→ 141
Operating time from restart	→ 142
Operating time	→ 142
 Diagnostic list	→ 143
 Event logbook	→ 147
 Device information	→ 149
 Min/max values	→ 152

► Heartbeat	→ 154
► Simulation	→ 155

Actual diagnostics

Navigation Expert → Diagnostics → Actual diagnos.

Prerequisite A diagnostic event has occurred.

Description Displays the current diagnostic message. If two or more messages occur simultaneously, the message with the highest priority is shown on the display.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Display*

Additional pending diagnostic messages can be viewed in the **Diagnostic list** submenu (→ 143).

Example

For the display format:
☒F271 Main electronic failure

Timestamp

Navigation Expert → Diagnostics → Timestamp

Description Displays the operating time when the current diagnostic message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

The diagnostic message can be viewed via the **Actual diagnostics** parameter (→ 141).

Example

For the display format:
24d12h13m00s

Previous diagnostics

Navigation Expert → Diagnostics → Prev.diagnostics

Prerequisite Two diagnostic events have already occurred.

Description Displays the diagnostic message that occurred before the current message.

User interface Symbol for diagnostic behavior, diagnostic code and short message.

Additional information *Example*

For the display format:

 F271 Main electronic failure

Timestamp

Navigation  Expert → Diagnostics → Timestamp

Description Displays the operating time when the last diagnostic message before the current message occurred.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information *Display*

 The diagnostic message can be viewed via the **Previous diagnostics** parameter
(→  141).

Example

For the display format:
24d12h13m00s

Operating time from restart

Navigation   Expert → Diagnostics → Time fr. restart

Description Use this function to display the time the device has been in operation since the last device restart.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Operating time

Navigation   Expert → Diagnostics → Operating time


Description Use this function to display the length of time the device has been in operation.

User interface Days (d), hours (h), minutes (m) and seconds (s)

Additional information*User interface*

The maximum number of days is 9999, which is equivalent to 27 years.

3.9.1 "Diagnostic list" submenu

Navigation
 Expert → Diagnostics → Diagnostic list


Diagnostics 1

Navigation
 Expert → Diagnostics → Diagnostic list → Diagnostics 1
Description

Displays the current diagnostics message with the highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

-  F271 Main electronic failure
-  F276 I/O module failure

Timestamp

Navigation
 Expert → Diagnostics → Diagnostic list → Timestamp
Description

Displays the operating time when the diagnostic message with the highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 1** parameter (→ 143).

Example

For the display format:
24d12h13m00s

Diagnostics 2

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 2

Description

Displays the current diagnostics message with the second-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic failure
- F276 I/O module failure

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the second-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 2** parameter (→ 144).

Example

For the display format:
24d12h13m00s

Diagnostics 3

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 3

Description

Displays the current diagnostics message with the third-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic failure
- F276 I/O module failure

Timestamp**Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the third-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 3** parameter (→ 144).

Example

For the display format:

24d12h13m00s

Diagnostics 4**Navigation**

Expert → Diagnostics → Diagnostic list → Diagnostics 4

Description

Displays the current diagnostics message with the fourth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic failure
- F276 I/O module failure

Timestamp**Navigation**

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fourth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 4** parameter (→ 145).

Example

For the display format:
24d12h13m00s

Diagnostics 5

Navigation

Expert → Diagnostics → Diagnostic list → Diagnostics 5

Description

Displays the current diagnostics message with the fifth-highest priority.

User interface

Symbol for diagnostic behavior, diagnostic code and short message.

Additional information*Examples*

For the display format:

- F271 Main electronic failure
 - F276 I/O module failure
-

Timestamp

Navigation

Expert → Diagnostics → Diagnostic list → Timestamp

Description

Displays the operating time when the diagnostic message with the fifth-highest priority occurred.

User interface

Days (d), hours (h), minutes (m) and seconds (s)

Additional information*Display*

The diagnostic message can be viewed via the **Diagnostics 5** parameter (→ 146).

Example


For the display format:
24d12h13m00s

3.9.2 "Event logbook" submenu

Navigation



Expert → Diagnostics → Event logbook



Filter options



Navigation



Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the local display.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting

All

Additional information

Description



The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:

- F = Failure
- C = Function Check
- S = Out of Specification
- M = Maintenance Required

Filter options



Navigation



Expert → Diagnostics → Event logbook → Filter options

Description

Use this function to select the category whose event messages are displayed in the event list of the operating tool.

Selection

- All
- Failure (F)
- Function check (C)
- Out of specification (S)
- Maintenance required (M)
- Information (I)

Factory setting All

Additional information *Description*

- i** The status signals are categorized in accordance with VDI/VDE 2650 and NAMUR Recommendation NE 107:
- F = Failure
 - C = Function Check
 - S = Out of Specification
 - M = Maintenance Required

"Event list" submenu

i The **Event list** submenu is only displayed if operating via the local display.

If operating via the FieldCare operating tool, the event list can be read out with a separate FieldCare module.

If operating via the Web browser, the event messages can be found directly in the **Event logbook** submenu.

Navigation  Expert → Diagnostics → Event logbook → Event list



Event list

Navigation

 Expert → Diagnostics → Event logbook → Event list

Description

Displays the history of event messages of the category selected in the **Filter options** parameter (→  147).

User interface

- For a "Category I" event message
Information event, short message, symbol for event recording and operating time when error occurred
- For a "Category F, C, S, M" event message (status signal)
Diagnostics code, short message, symbol for event recording and operating time when error occurred

Additional information

Description

A maximum of 20 event messages are displayed in chronological order.

If the advanced HistoROM function is enabled in the device, the event list can contain up to 100 entries.

The following symbols indicate whether an event has occurred or has ended:

- ⊖: Occurrence of the event
- ⊕: End of the event

Examples

For the display format:

- I1091 Configuration modified
⊖ 24d12h13m00s
- ✗ F271 Main electronic failure
⊖ 01d04h12min30s

HistoROM

A HistoROM is a "non-volatile" device memory in the form of an EEPROM.

3.9.3 "Device information" submenu

Navigation

Expert → Diagnostics → Device info

► Device information	
Device tag	→ 149
Serial number	→ 150
Firmware version	→ 150
Device name	→ 150
Order code	→ 151
Extended order code 1	→ 151
Extended order code 2	→ 151
Extended order code 3	→ 152
ENP version	→ 152

Device tag

Navigation

Expert → Diagnostics → Device info → Device tag

Description

Displays a unique name for the measuring point so it can be identified quickly within the plant.

User interface

Max. 32 characters such as letters, numbers or special characters (e.g. @, %, /)

Factory setting Promag 100 DP

Serial number

Navigation   Expert → Diagnostics → Device info → Serial number

Description Displays the serial number of the measuring device.

 The number can be found on the nameplate of the sensor and transmitter.

User interface A maximum of 11-digit character string comprising letters and numbers.

Additional information *Description*

 **Uses of the serial number**

- To identify the measuring device quickly, e.g. when contacting Endress+Hauser.
- To obtain specific information on the measuring device using the Device Viewer:
www.endress.com/deviceviewer

Firmware version

Navigation   Expert → Diagnostics → Device info → Firmware version

Description Displays the device firmware version installed.

User interface Character string in the format xx.yy.zz

Additional information *Display*

 The Firmware version is also located:

- On the title page of the Operating instructions
- On the transmitter nameplate

Device name

Navigation   Expert → Diagnostics → Device info → Device name

Description Displays the name of the transmitter. It can also be found on the nameplate of the transmitter.

User interface Promag 100

Order code**Navigation**

Expert → Diagnostics → Device info → Order code

Description

Displays the device order code.

User interface

Character string composed of letters, numbers and certain punctuation marks (e.g. /).

Additional information*Description*

The order code can be found on the nameplate of the sensor and transmitter in the "Order code" field.

The order code is generated from the extended order code through a process of reversible transformation. The extended order code indicates the attributes for all the device features in the product structure. The device features are not directly readable from the order code.

Uses of the order code

- To order an identical spare device.
- To identify the device quickly and easily, e.g. when contacting Endress+Hauser.

Extended order code 1**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 1

Description

Displays the first part of the extended order code.

On account of length restrictions, the extended order code is split into a maximum of 3 parameters.

User interface

Character string

Additional information*Description*

The extended order code indicates the version of all the features of the product structure for the measuring device and thus uniquely identifies the measuring device.

The extended order code can also be found on the nameplate of the sensor and transmitter in the "Ext. ord. cd." field.

Extended order code 2**Navigation**

Expert → Diagnostics → Device info → Ext. order cd. 2

Description

For displaying the second part of the extended order code.

User interface

Character string

Additional informationFor additional information, see **Extended order code 1** parameter (→ 151)

Extended order code 3


Navigation	Expert → Diagnostics → Device info → Ext. order cd. 3
Description	For displaying the third part of the extended order code.
User interface	Character string
Additional information	For additional information, see Extended order code 1 parameter (→ 151)

ENP version

Navigation	Expert → Diagnostics → Device info → ENP version
Description	Displays the version of the electronic nameplate.
User interface	Character string
Factory setting	2.02.00
Additional information	<i>Description</i> This electronic nameplate stores a data record for device identification that includes more data than the nameplates attached to the outside of the device.


3.9.4 "Min/max values" submenu

Navigation Expert → Diagnostics → Min/max val.



Reset min/max values


Navigation	Expert → Diagnostics → Min/max val. → Reset min/max
Description	Use this function to select measured variables whose minimum, maximum and average measured values are to be reset.

Selection Cancel**Factory setting** Cancel**"Main electronic temperature" submenu***Navigation*  Expert → Diagnostics → Min/max val. → Main elect.temp.**Minimum value****Navigation**  Expert → Diagnostics → Min/max val. → Main elect.temp. → Minimum value**Description** Displays the lowest previously measured temperature value of the main electronics module.**User interface** Signed floating-point number**Additional information** *Dependency* The unit is taken from the **Temperature unit** parameter (→ 42)**Maximum value****Navigation**  Expert → Diagnostics → Min/max val. → Main elect.temp. → Maximum value**Description** Displays the highest previously measured temperature value of the main electronics module.**User interface** Signed floating-point number**Additional information** *Dependency* The unit is taken from the **Temperature unit** parameter (→ 42)

"Temperature" submenu

Navigation

Expert → Diagnostics → Min/max val. → Temperature



Minimum value

Navigation

Expert → Diagnostics → Min/max val. → Temperature → Minimum value

Prerequisite

For the following order code:
"Sensor Option", option CI "Fluid temperature probe"

Description

Displays the lowest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information

Dependency

The unit is taken from the **Temperature unit** parameter (→ 42)

Maximum value

Navigation

Expert → Diagnostics → Min/max val. → Temperature → Maximum value

Prerequisite

For the following order code:
"Sensor Option", option CI "Fluid temperature probe"

Description

Displays the highest previously measured medium temperature value.

User interface

Signed floating-point number

Additional information

Dependency


The unit is taken from the **Temperature unit** parameter (→ 42)

3.9.5 "Heartbeat" submenu

For detailed information on the parameter descriptions of the **Heartbeat Verification** application package, see the Special Documentation for the device

Navigation


Expert → Diagnostics → Heartbeat



3.9.6 "Simulation" submenu

Navigation

Expert → Diagnostics → Simulation



Assign simulation process variable



Navigation

Expert → Diagnostics → Simulation → Assign proc.var.

Description

Use this function to select a process variable for the simulation process that is activated. The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

Selection

- Off
- Volume flow
- Mass flow
- Corrected volume flow
- Conductivity*
- Corrected conductivity*
- Temperature

Factory setting

Off

* Visibility depends on order options or device settings

Additional information*Description*

The simulation value of the process variable selected is defined in the **Value process variable** parameter (→ 156).

Value process variable**Navigation**

Expert → Diagnostics → Simulation → Value proc. var.

Prerequisite

One of the following options is selected in the **Assign simulation process variable** parameter (→ 155):

- Volume flow
- Mass flow
- Corrected volume flow
- Conductivity *
- Corrected conductivity *
- Temperature *

Description

Use this function to enter a simulation value for the selected process variable. Subsequent measured value processing and the signal output use this simulation value. In this way, users can verify whether the measuring device has been configured correctly.

User entry

Depends on the process variable selected

Factory setting

0

Additional information*User entry*

The unit of the displayed measured value is taken from the **System units** submenu (→ 38).

Simulation device alarm**Navigation**

Expert → Diagnostics → Simulation → Sim. alarm

Description

Use this function to switch the device alarm on and off.

Selection

- Off
- On

Factory setting

Off

Additional information*Description*

The display alternates between the measured value and a diagnostic message of the "Function check" category (C) while simulation is in progress.

* Visibility depends on order options or device settings

Diagnostic event category

Navigation	 Expert → Diagnostics → Simulation → Event category
Description	Use this function to select the category of the diagnostic events that are displayed for the simulation in the Simulation diagnostic event parameter (→ 157).
Selection	<ul style="list-style-type: none">■ Sensor■ Electronics■ Configuration■ Process
Factory setting	Process

Simulation diagnostic event

Navigation	  Expert → Diagnostics → Simulation → Sim. diag. event
Description	Use this function to select a diagnostic event for the simulation process that is activated.
Selection	<ul style="list-style-type: none">■ Off■ Diagnostic event picklist (depends on the category selected)
Factory setting	Off
Additional information	<i>Description</i>  For the simulation, you can choose from the diagnostic events of the category selected in the Diagnostic event category parameter (→ 157).

4 Country-specific factory settings

4.1 SI units

 Not valid for USA and Canada.

4.1.1 System units

Volume flow	l/h
Volume	m ³
Conductivity	µS/cm
Temperature	°C
Mass flow	kg/h
Mass	kg
Density	kg/l
Corrected volume flow	Nl/h
Corrected volume	Nm ³

4.1.2 Full scale values

 The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
2	0.5
4	2
8	8
15	25
25	75
32	125
40	200
50	300
65	500
80	750
100	1200
125	1850
150	150 m ³ /h
200	300 m ³ /h
250	500 m ³ /h
300	750 m ³ /h
350	1000 m ³ /h
400	1200 m ³ /h
450	1500 m ³ /h

Nominal diameter [mm]	(v ~ 2.5 m/s) [dm ³ /min]
500	2000 m ³ /h
600	2500 m ³ /h

4.1.3 On value low flow cut off

 The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [mm]	(v ~ 0.04 m/s) [m ³ /h]
2	0.01
4	0.05
8	0.1
15	0.5
25	1
32	2
40	3
50	5
65	8
80	12
100	20
125	30
150	2.5
200	5
250	7.5
300	10
350	15
400	20
450	25
500	30
600	40

4.2 US units

 Only valid for USA and Canada.

4.2.1 System units

Volume flow	gal/min (us)
Volume	gal (us)
Temperature	°F
Mass flow	lb/min
Mass	lb
Density	lb/ft ³

Corrected volume flow	Sft ³ /h
Corrected volume	Sft ³

4.2.2 Full scale values

i The factory settings apply to the following parameters:
100% bar graph value 1

Nominal diameter [in]	(v ~ 2.5 m/s) [gal/min]
1/12	0.1
1/8	0.5
3/8	2
1/2	6
1	18
1½	50
2	75
3	200
4	300
5	450
6	600
8	1200
10	1500
12	2400
14	3600
16	4800
18	6000
20	7500
24	10500

4.2.3 On value low flow cut off

i The switch-on point depends on the type of medium and the nominal diameter.

Nominal diameter [in]	(v ~ 0.04 m/s) [gal/min]
1/12	0.002
1/8	0.008
3/8	0.025
1/2	0.15
1	0.25
1½	0.75
2	1.25
3	2.5
4	4
5	7

Nominal diameter [in]	{v ~ 0.04 m/s) [gal/min]}
6	12
8	15
10	30
12	45
14	60
16	60
18	90
20	120
24	180

5 Explanation of abbreviated units

5.1 SI units

Process variable	Units	Explanation
Density	g/cm ³ , g/m ³	Gram/volume unit
	kg/dm ³ , kg/l, kg/m ³	Kilogram/volume unit
	SD4°C, SD15°C, SD20°C	Specific density: The specific density is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
	SG4°C, SG15°C, SG20°C	Specific gravity: The specific gravity is the ratio of the density of the fluid to the density of water at a water temperature of 4 °C (39 °F), 15 °C (59 °F), 20 °C (68 °F).
Conductivity	µS/mm	Microsiemens/length unit
	nS/cm, µS/cm, mS/cm, S/cm	Nano- Micro- , Milli- , Siemens/length unit
	µS/m, mS/m, S/m, kS/m, MS/m	Micro- , Milli- , Siemens, Kilo-, Megasiemens/length unit
Mass	g, kg, t	Gram, kilogram, metric ton
Mass flow	g/s, g/min, g/h, g/d	Gram/time unit
	kg/s, kg/min, kg/h, kg/d	Kilogram/time unit
	t/s, t/min, t/h, t/d	Metric ton/time unit
Corrected volume	NI, Nm ³ , Sm ³	Normal liter, normal cubic meter, standard cubic meter
Corrected volume flow	NI/s, NI/min, NI/h, NI/d	Normal liter/time unit
	Nm ³ /s, Nm ³ /min, Nm ³ /h, Nm ³ /d	Normal cubic meter/time unit
	Sm ³ /s, Sm ³ /min, Sm ³ /h, Sm ³ /d	Standard cubic meter/time unit
Temperature	°C, K	Celsius, Kelvin
Volume	cm ³ , dm ³ , m ³	Cubic centimeter, cubic decimeter, cubic meter
	ml, l, hl, Ml Mega	Milliliter, liter, hectoliter, megaliter
Volume flow	cm ³ /s, cm ³ /min, cm ³ /h, cm ³ /d	Cubic centimeter/time unit
	dm ³ /s, dm ³ /min, dm ³ /h, dm ³ /d	Cubic decimeter/time unit
	m ³ /s, m ³ /min, m ³ /h, m ³ /d	Cubic meter/time unit
	ml/s, ml/min, ml/h, ml/d	Milliliter/time unit
	l/s, l/min, l/h, l/d	Liter/time unit
	hl/s, hl/min, hl/h, hl/d	Hectoliter/time unit
	Ml/s, Ml/min, Ml/h, Ml/d	Megaliter/time unit
Time	s, m, h, d, y	Second, minute, hour, day, year

5.2 US units

Process variable	Units	Explanation
Density	lb/ft ³ , lb/gal (us)	Pound/cubic foot, pound/gallon
	lb/bbl (us;liq.), lb/bbl (us;beer), lb/bbl (us;oil), lb/bbl (us;tank)	Pound/volume unit
Mass	oz, lb, STon	Ounce, pound, standard ton
Mass flow	oz/s, oz/min, oz/h, oz/d	Ounce/time unit

Process variable	Units	Explanation
	lb/s, lb/min, lb/h, lb/d	Pound/time unit
	STon/s, STon/min, STon/h, STon/d	Standard ton/time unit
Corrected volume	Sft ³ , Sgal (us), Sbbl (us;liq.)	Standard cubic foot, standard gallon, standard barrel
Corrected volume flow	Sft ³ /s, Sft ³ /min, Sft ³ /h, Sft ³ /d	Standard cubic foot/time unit
	Sgal/s (us), Sgal/min (us), Sgal/h (us), Sgal/d (us)	Standard gallon/time unit
	Sbbl/s (us;liq.), Sbbl/min (us;liq.), Sbbl/h (us;liq.), Sbbl/d (us;liq.)	Barrel/time unit (normal liquids)
Temperature	°F, °R	Fahrenheit, Rankine
Volume	af	Acre foot
	ft ³	Cubic foot
	fl oz (us), gal (us), kgal (us), Mgal (us)	Fluid ounce, gallon, kilogallon, million gallon
	bbl (us;liq.), bbl (us;beer), bbl (us;oil), bbl (us;tank)	Barrel (normal liquids), barrel (beer), barrel (petrochemicals), barrel (filling tanks)
Volume flow	af/s, af/min, af/h, af/d	Acre foot/time unit
	ft ³ /s, ft ³ /min, ft ³ /h, ft ³ /d	Cubic foot/time unit
	fl oz/s (us), fl oz/min (us), fl oz/h (us), fl oz/d (us)	Fluid ounce/time unit
	gal/s (us), gal/min (us), gal/h (us), gal/d (us)	Gallon/time unit
	kgal/s (us), kgal/min (us), kgal/h (us), kgal/d (us)	Kilogallon/time unit
	Mgal/s (us), Mgal/min (us), Mgal/h (us), Mgal/d (us)	Million gallon/time unit
	bbl/s (us;liq.), bbl/min (us;liq.), bbl/h (us;liq.), bbl/d (us;liq.)	Barrel/time unit (normal liquids) Normal liquids: 31.5 gal/bbl
	bbl/s (us;beer), bbl/min (us;beer), bbl/h (us;beer), bbl/d (us;beer)	Barrel/time unit (beer) Beer: 31.0 gal/bbl
	bbl/s (us;oil), bbl/min (us;oil), bbl/h (us;oil), bbl/d (us;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 42.0 gal/bbl
Time	bbl/s (us;tank), bbl/min (us;tank), bbl/h (us;tank), bbl/d (us;tank)	Barrel/time unit (filling tank) Filling tanks: 55.0 gal/bbl
	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

5.3 Imperial units

Process variable	Units	Explanation
Density	lb/gal (imp), lb/bbl (imp;beer), lb/bbl (imp;oil)	Pound/volume unit
Corrected volume	Sgal (imp)	Standard gallon
Corrected volume flow	Sgal/s (imp), Sgal/min (imp), Sgal/h (imp), Sgal/d (imp)	Standard gallon/time unit
Volume	gal (imp), Mgal (imp)	Gallon, mega gallon
	bbl (imp;beer), bbl (imp;oil)	Barrel (beer), barrel (petrochemicals)

Process variable	Units	Explanation
Volume flow	gal/s (imp), gal/min (imp), gal/h (imp), gal/d (imp)	Gallon/time unit
	Mgal/s (imp), Mgal/min (imp), Mgal/h (imp), Mgal/d (imp)	Mega gallon/time unit
	bbl/s (imp;beer), bbl/min (imp;beer), bbl/h (imp;beer), bbl/d (imp;beer)	Barrel /time unit (beer) Beer: 36.0 gal/bbl
	bbl/s (imp;oil), bbl/min (imp;oil), bbl/h (imp;oil), bbl/d (imp;oil)	Barrel/time unit (petrochemicals) Petrochemicals: 34.97 gal/bbl
Time	s, m, h, d, y	Second, minute, hour, day, year
	am, pm	Ante meridiem (before midday), post meridiem (after midday)

Index

0 ... 9

0% bargraph value 1 (Parameter)	17
0% bargraph value 3 (Parameter)	20
100% bargraph value 1 (Parameter)	18
100% bargraph value 3 (Parameter)	21

A

Access status display (Parameter)	11, 25
Access status tooling (Parameter)	12
Activate SW option (Parameter)	33
Actual diagnostics (Parameter)	141
Address mode (Parameter)	67
Administration (Submenu)	30
Alarm delay (Parameter)	26
Alarm hysteresis (Parameter)	91, 136
Alarm summary (Parameter)	74, 88, 101, 109, 122, 134
Alert key (Parameter)	73, 87, 100, 108, 120, 133
Analog input 1 to 4 (Submenu)	83
Analog inputs (Submenu)	83
Analog output 1 to 2 (Submenu)	104
Analog outputs (Submenu)	104
Application (Submenu)	126
Assign behavior of diagnostic no. 302 (Parameter)	30
Assign behavior of diagnostic no. 531 (Parameter)	28
Assign behavior of diagnostic no. 832 (Parameter)	28
Assign behavior of diagnostic no. 833 (Parameter)	28
Assign behavior of diagnostic no. 834 (Parameter)	29
Assign behavior of diagnostic no. 835 (Parameter)	29
Assign behavior of diagnostic no. 862 (Parameter)	29
Assign behavior of diagnostic no. 937 (Parameter)	30
Assign process variable (Parameter)	50, 127
Assign simulation process variable (Parameter)	155

B

Backlight (Parameter)	25
Base current (Parameter)	70
Batch ID (Parameter)	89, 102, 110, 122, 135
Batch operation (Parameter)	89, 102, 110, 122, 135
Batch phase (Parameter)	89, 102, 110, 123, 135
Batch Recipe Unit Procedure (Parameter)	89, 103, 110, 123, 135
Baudrate (Parameter)	70

C

Calibration (Submenu)	65
Calibration factor (Parameter)	66
Channel (Parameter)	84, 97
Communication (Submenu)	67
Condensed status diagnostic (Parameter)	80
Conductivity (Parameter)	36
Conductivity calibration factor (Parameter)	67
Conductivity damping (Parameter)	49
Conductivity factor (Parameter)	64
Conductivity measurement (Parameter)	49
Conductivity offset (Parameter)	63
Conductivity unit (Parameter)	41

Confirm access code (Parameter)	32
Contrast display (Parameter)	25
Control Totalizer 1 to 3 (Parameter)	128
Corrected conductivity (Parameter)	37
Corrected volume flow (Parameter)	36
Corrected volume flow factor (Parameter)	64
Corrected volume flow offset (Parameter)	64
Corrected volume flow unit (Parameter)	44
Corrected volume unit (Parameter)	45

D

Date/time format (Parameter)	46
Decimal places 1 (Parameter)	18
Decimal places 2 (Parameter)	19
Decimal places 3 (Parameter)	21
Decimal places 4 (Parameter)	22
Default gateway (Parameter)	82
Define access code (Parameter)	31, 32
Define access code (Wizard)	31
Density source (Parameter)	59
Density unit (Parameter)	44
Descriptor (Parameter)	78
Device address (Parameter)	68
Device certification (Parameter)	77
Device ID (Parameter)	76
Device information (Submenu)	149
Device install date (Parameter)	78
Device message (Parameter)	78
Device name (Parameter)	150
Device reset (Parameter)	33
Device tag (Parameter)	72, 149
Diagnostic behavior (Submenu)	27
Diagnostic event category (Parameter)	157
Diagnostic handling (Submenu)	26
Diagnostic list (Submenu)	143
Diagnostics (Parameter)	76
Diagnostics (Submenu)	140
Diagnostics 1 (Parameter)	143
Diagnostics 2 (Parameter)	144
Diagnostics 3 (Parameter)	144
Diagnostics 4 (Parameter)	145
Diagnostics 5 (Parameter)	146
Diagnostics mask (Parameter)	77

Direct access

0% bargraph value 1	17
0% bargraph value 3	20
100% bargraph value 1	18
100% bargraph value 3	21
Access status display	11, 25
Access status tooling	12
Activate SW option	33
Actual diagnostics	141
Address mode	67
Alarm delay	26
Alarm hysteresis	
Analog input 1 to 4	91

Totalizer 1 to 3	136	Conductivity factor	64
Alarm summary	74	Conductivity measurement	49
Analog input 1 to 4	88	Conductivity offset	63
Analog output 1 to 2	109	Conductivity unit	41
Discrete input 1 to 2	101	Contrast display	25
Discrete output 1 to 2	122	Control Totalizer 1 to 3	128
Totalizer 1 to 3	134	Corrected conductivity	37
Alert key	73	Corrected volume flow	36
Analog input 1 to 4	87	Corrected volume flow factor	64
Analog output 1 to 2	108	Corrected volume flow offset	64
Discrete input 1 to 2	100	Corrected volume flow unit	44
Discrete output 1 to 2	120	Corrected volume unit	45
Totalizer 1 to 3	133	Date/time format	46
Assign behavior of diagnostic no. 302	30	Decimal places 1	18
Assign behavior of diagnostic no. 531	28	Decimal places 2	19
Assign behavior of diagnostic no. 832	28	Decimal places 3	21
Assign behavior of diagnostic no. 833	28	Decimal places 4	22
Assign behavior of diagnostic no. 834	29	Default gateway	82
Assign behavior of diagnostic no. 835	29	Define access code	32
Assign behavior of diagnostic no. 862	29	Density source	59
Assign behavior of diagnostic no. 937	30	Density unit	44
Assign process variable	50	Descriptor	78
Totalizer 1 to 3	127	Device address	68
Assign simulation process variable	155	Device certification	77
Backlight	25	Device ID	76
Base current	70	Device install date	78
Batch ID		Device message	78
Analog input 1 to 4	89	Device name	150
Analog output 1 to 2	110	Device reset	33
Discrete input 1 to 2	102	Device tag	72, 149
Discrete output 1 to 2	122	Diagnostic event category	157
Totalizer 1 to 3	135	Diagnostics	76
Batch operation		Diagnostics 1	143
Analog input 1 to 4	89	Diagnostics 2	144
Analog output 1 to 2	110	Diagnostics 3	144
Discrete input 1 to 2	102	Diagnostics 4	145
Discrete output 1 to 2	122	Diagnostics 5	146
Totalizer 1 to 3	135	Diagnostics mask	77
Batch phase		Direct access	10
Analog input 1 to 4	89	Display damping	23
Analog output 1 to 2	110	Display interval	22
Discrete input 1 to 2	102	Display language	14
Discrete output 1 to 2	123	ECC cleaning cycle	57
Totalizer 1 to 3	135	ECC duration	57
Batch Recipe Unit Procedure		ECC Polarity	58
Analog input 1 to 4	89	ECC recovery time	57
Analog output 1 to 2	110	Electrode cleaning circuit	56
Discrete input 1 to 2	103	Empty pipe adjust value	55
Discrete output 1 to 2	123	Empty pipe detection	54
Totalizer 1 to 3	135	ENP version	152
Baudrate	70	Enter access code	13
Calibration factor	66	Extended order code 1	151
Channel		Extended order code 2	151
Analog input 1 to 4	84	Extended order code 3	152
Discrete input 1 to 2	97	External density	59
Condensed status diagnostic	80	External temperature	59
Conductivity	36	Factory reset	78
Conductivity calibration factor	67	Fail safe time	
Conductivity damping	49	Analog output 1 to 2	105

Discrete output 1 to 2	117
Fail safe type	
Analog input 1 to 4	84
Analog output 1 to 2	106
Discrete input 1 to 2	98
Discrete output 1 to 2	118
Fail safe value	
Analog input 1 to 4	85
Analog output 1 to 2	106
Discrete input 1 to 2	98
Discrete output 1 to 2	118
Failure mode	
Totalizer 1 to 3	130
Feature enabled	80
Feature supported	79
Filter options	47, 147
Firmware version	150
Fixed density	59
Flow damping	48
Flow override	48
Format display	15
Full pipe adjust value	55
Hardware lock	79
Hardware revision	75
Header	23
Header text	24
Hi alarm state	
Analog input 1 to 4	94
Totalizer 1 to 3	139
Hi alarm value	
Analog input 1 to 4	94
Totalizer 1 to 3	139
Hi Hi alarm state	
Analog input 1 to 4	94
Totalizer 1 to 3	138
Hi Hi alarm value	
Analog input 1 to 4	93
Totalizer 1 to 3	138
Hi Hi Lim	
Analog input 1 to 4	92
Totalizer 1 to 3	136
Hi Lim	
Analog input 1 to 4	92
Totalizer 1 to 3	137
Ident number selector	68, 79
Increase close	
Analog output 1 to 2	115
Input channel	
Analog output 1 to 2	112
Discrete output 1 to 2	124
Installation direction	61
Integration time	61
Invert	
Discrete input 1 to 2	98
Discrete output 1 to 2	117
IP address	82
Lin type	
Analog input 1 to 4	91
Lo alarm state	
Analog input 1 to 4	95
Totalizer 1 to 3	139
Lo alarm value	
Analog input 1 to 4	94
Totalizer 1 to 3	139
Lo Lim	
Analog input 1 to 4	93
Totalizer 1 to 3	137
Lo Lo alarm state	
Analog input 1 to 4	95
Totalizer 1 to 3	140
Lo Lo alarm value	
Analog input 1 to 4	95
Totalizer 1 to 3	140
Lo Lo Lim	
Analog input 1 to 4	93
Totalizer 1 to 3	138
Locking status	11
MAC address	81
Manufacturer ID	75
Mass flow	36
Mass flow factor	63
Mass flow offset	63
Mass flow unit	42
Mass unit	43
Master availability	70
Maximum value	153, 154
Measured value EPD	56
Measuring period	61
Minimum value	153, 154
Mode block actual	73
Analog input 1 to 4	87
Analog output 1 to 2	108
Discrete input 1 to 2	101
Discrete output 1 to 2	121
Totalizer 1 to 3	133
Mode block normal	74
Analog input 1 to 4	88
Analog output 1 to 2	109
Discrete input 1 to 2	101
Discrete output 1 to 2	121
Totalizer 1 to 3	134
Mode block permitted	74
Analog input 1 to 4	88
Analog output 1 to 2	109
Discrete input 1 to 2	101
Discrete output 1 to 2	121
Totalizer 1 to 3	134
New adjustment	54
Nominal diameter	66
Off value low flow cutoff	51
On value low flow cutoff	51
Operating time	142
Operating time from restart	142
Order code	151
Out decimal point	
Analog input 1 to 4	91

Out scale lower range	60
Analog input 1 to 4	90
Analog output 1 to 2	116
Out scale upper range	54
Analog input 1 to 4	90
Analog output 1 to 2	115
Out status	24
Analog input 1 to 4	85, 86
Analog output 1 to 2	107
Discrete input 1 to 2	99
Discrete output 1 to 2	119
Out unit	117
Analog input 1 to 4	91
Out unit text	105
Analog input 1 to 4	96
Out value	117
Analog input 1 to 4	85
Analog output 1 to 2	106
Discrete input 1 to 2	99
Discrete output 1 to 2	119
Output channel	114
Analog output 1 to 2	113
Discrete output 1 to 2	124
Position status	114
Analog output 1 to 2	114
Position value	96
Analog output 1 to 2	113
Preset value 1 to 3	129
Pressure shock suppression	52
Previous diagnostics	141
PROFIBUS ident number	69
Profile version	70
Progress	55
PV filter time	86
Analog input 1 to 4	84
PV scale lower range	107
Analog input 1 to 4	90
Analog output 1 to 2	111
PV scale upper range	100
Analog input 1 to 4	90
Analog output 1 to 2	111
RCAS in status	100
Analog output 1 to 2	112
Discrete output 1 to 2	124
RCAS in value	120
Analog output 1 to 2	112
Discrete output 1 to 2	124
RCAS out status	132
Analog output 1 to 2	113
Discrete output 1 to 2	125
RCAS out value	132
Analog output 1 to 2	113
Discrete output 1 to 2	125
Readback status	133
Analog output 1 to 2	112
Discrete output 1 to 2	123
Readback value	100
Analog output 1 to 2	111
Discrete output 1 to 2	123
Reference density	152
Reset min/max values	54
Response time empty pipe detection	76, 150
Separator	24
Set point status	105
Analog output 1 to 2	105
Discrete output 1 to 2	117
Set point value	105
Analog output 1 to 2	105
Discrete output 1 to 2	117
Setpoint deviation	114
Analog output 1 to 2	114
Simulate enabled	95
Analog input 1 to 4	95
Analog output 1 to 2	114
Discrete input 1 to 2	103
Discrete output 1 to 2	125
Simulate status	126
Analog input 1 to 4	96
Analog output 1 to 2	115
Discrete input 1 to 2	103
Discrete output 1 to 2	126
Simulate value	96
Analog input 1 to 4	96
Analog output 1 to 2	114
Discrete input 1 to 2	104
Discrete output 1 to 2	125
Simulation device alarm	156
Simulation diagnostic event	157
Software option overview	34
Software revision	75
Static revision	72
Analog input 1 to 4	86
Analog output 1 to 2	107
Discrete input 1 to 2	100
Discrete output 1 to 2	120
Totalizer 1 to 3	132
Status PROFIBUS Master Config	69
Strategy	73
Analog input 1 to 4	86
Analog output 1 to 2	108
Discrete input 1 to 2	100
Discrete output 1 to 2	120
Totalizer 1 to 3	132
Subnet mask	82
Switch point empty pipe detection	54
Tag description	86
Analog input 1 to 4	86
Analog output 1 to 2	107
Discrete input 1 to 2	99
Discrete output 1 to 2	119
Totalizer 1 to 3	132
Target mode	73
Analog input 1 to 4	87
Analog output 1 to 2	108
Discrete input 1 to 2	100
Discrete output 1 to 2	120
Totalizer 1 to 3	133

Temperature	36		Event logbook (Submenu)	147
Temperature damping	49		Extended order code 1 (Parameter)	151
Temperature factor	65		Extended order code 2 (Parameter)	151
Temperature offset	65		Extended order code 3 (Parameter)	152
Temperature source	58		External compensation (Submenu)	58
Temperature unit	42		External density (Parameter)	59
Timestamp	141, 142, 143, 144, 145, 146		External temperature (Parameter)	59
Totalizer operation mode				
Totalizer 1 to 3	130			
Totalizer status (Hex) 1 to 3	38, 132			
Totalizer status 1 to 3	38, 131			
Totalizer value 1 to 3	37, 131			
Unit totalizer				
Totalizer 1 to 3	127			
Value 1 display	17			
Value 2 display	19			
Value 3 display	20			
Value 4 display	21			
Value process variable	156			
Volume flow	35			
Volume flow factor	62			
Volume flow offset	62			
Volume flow unit	39			
Volume unit	41			
Web server functionality	82			
Web server language	81			
Zero point	66			
Direct access (Parameter)	10			
Discrete input 1 to 2 (Submenu)	97			
Discrete inputs (Submenu)	97			
Discrete output 1 to 2 (Submenu)	116			
Discrete outputs (Submenu)	116			
Display (Submenu)	13			
Display damping (Parameter)	23			
Display interval (Parameter)	22			
Display language (Parameter)	14			
Document				
Explanation of the structure of a parameter				
description	6			
Function	4			
Structure	4			
Symbols used	6			
Target group	4			
Using the document	4			
Document function	4			
E				
ECC cleaning cycle (Parameter)	57			
ECC duration (Parameter)	57			
ECC Polarity (Parameter)	58			
ECC recovery time (Parameter)	57			
Electrode cleaning circuit (Parameter)	56			
Electrode cleaning circuit (Submenu)	56			
Empty pipe adjust value (Parameter)	55			
Empty pipe detection (Parameter)	54			
Empty pipe detection (Submenu)	53			
ENP version (Parameter)	152			
Enter access code (Parameter)	13			
Event list (Submenu)	148			
F				
Factory reset (Parameter)	78			
Factory settings	158			
SI units	158			
US units	159			
Fail safe time (Parameter)	105, 117			
Fail safe type (Parameter)	84, 98, 106, 118			
Fail safe value (Parameter)	85, 98, 106, 118			
Failure mode (Parameter)	130			
Feature enabled (Parameter)	80			
Feature supported (Parameter)	79			
Filter options (Parameter)	47, 147			
Firmware version (Parameter)	150			
Fixed density (Parameter)	59			
Flow damping (Parameter)	48			
Flow override (Parameter)	48			
Format display (Parameter)	15			
Full pipe adjust value (Parameter)	55			
Function				
see Parameter				
H				
Hardware lock (Parameter)	79			
Hardware revision (Parameter)	75			
Header (Parameter)	23			
Header text (Parameter)	24			
Heartbeat (Submenu)	154			
Hi alarm state (Parameter)	94, 139			
Hi alarm value (Parameter)	94, 139			
Hi Hi alarm state (Parameter)	94, 138			
Hi Hi alarm value (Parameter)	93, 138			
Hi Hi Lim (Parameter)	92, 136			
Hi Lim (Parameter)	92, 137			
I				
Ident number selector (Parameter)	68, 79			
Increase close (Parameter)	115			
Input channel (Parameter)	112, 124			
Installation direction (Parameter)	61			
Integration time (Parameter)	61			
Invert (Parameter)	98, 117			
IP address (Parameter)	82			
L				
Lin type (Parameter)	91			
Lo alarm state (Parameter)	95, 139			
Lo alarm value (Parameter)	94, 139			
Lo Lim (Parameter)	93, 137			
Lo Lo alarm state (Parameter)	95, 140			
Lo Lo alarm value (Parameter)	95, 140			
Lo Lo Lim (Parameter)	93, 138			
Locking status (Parameter)	11			

Low flow cut off (Submenu)	50	Progress (Parameter)	55
M		PV filter time (Parameter)	84
MAC address (Parameter)	81	PV scale lower range (Parameter)	90, 111
Main electronic temperature (Submenu)	153	PV scale upper range (Parameter)	90, 111
Manufacturer ID (Parameter)	75		
Mass flow (Parameter)	36	R	
Mass flow factor (Parameter)	63	RCAS in status (Parameter)	112, 124
Mass flow offset (Parameter)	63	RCAS in value (Parameter)	112, 124
Mass flow unit (Parameter)	42	RCAS out status (Parameter)	113, 125
Mass unit (Parameter)	43	RCAS out value (Parameter)	113, 125
Master availability (Parameter)	70	Readback status (Parameter)	112, 123
Maximum value (Parameter)	153, 154	Readback value (Parameter)	111, 123
Measured value EPD (Parameter)	56	Reference density (Parameter)	60
Measured values (Submenu)	35	Reset min/max values (Parameter)	152
Measuring period (Parameter)	61	Response time empty pipe detection (Parameter)	54
Min/max values (Submenu)	152		
Minimum value (Parameter)	153, 154	S	
Mode block actual (Parameter)	73, 87, 101, 108, 121,	Sensor (Submenu)	34
Mode block normal (Parameter)	74, 88, 101, 109, 121,	Sensor adjustment (Submenu)	60
Mode block permitted (Parameter)	74, 88, 101, 109, 121,	Separator (Parameter)	24
N		Serial number (Parameter)	76, 150
New adjustment (Parameter)	54	Set point status (Parameter)	105, 117
Nominal diameter (Parameter)	66	Set point value (Parameter)	105, 117
O		Setpoint deviation (Parameter)	114
Off value low flow cutoff (Parameter)	51	Simulate enabled (Parameter)	95, 103, 114, 125
On value low flow cutoff (Parameter)	51	Simulate status (Parameter)	96, 103, 115, 126
Operating time (Parameter)	142	Simulation (Submenu)	155
Operating time from restart (Parameter)	142	Simulation device alarm (Parameter)	156
Order code (Parameter)	151	Simulation diagnostic event (Parameter)	157
Out decimal point (Parameter)	91	Software option overview (Parameter)	34
Out scale lower range (Parameter)	90, 116	Software revision (Parameter)	75
Out scale upper range (Parameter)	90, 115	Static revision (Parameter)	72, 86, 100, 107, 120, 132
Out status (Parameter)	85, 86, 99, 107, 119	Status PROFIBUS Master Config (Parameter)	69
Out unit (Parameter)	91	Strategy (Parameter)	73, 86, 100, 108, 120, 132
Out unit text (Parameter)	96		
Out value (Parameter)	85, 99, 106, 119	Submenu	
Output channel (Parameter)	113, 124	Administration	30
P		Analog input 1 to 4	83
Parameter		Analog inputs	83
Structure of a parameter description	6	Analog output 1 to 2	104
Physical block (Submenu)	71	Analog outputs	104
Position status (Parameter)	114	Application	126
Position value (Parameter)	113	Calibration	65
Preset value 1 to 3 (Parameter)	129	Communication	67
Pressure shock suppression (Parameter)	52	Device information	149
Previous diagnostics (Parameter)	141	Diagnostic behavior	27
Process parameters (Submenu)	46	Diagnostic handling	26
Process variable adjustment (Submenu)	61	Diagnostic list	143
Process variables (Submenu)	35	Diagnostics	140
PROFIBUS DP configuration (Submenu)	67	Discrete input 1 to 2	97
PROFIBUS DP info (Submenu)	69	Discrete inputs	97
PROFIBUS ident number (Parameter)	69	Discrete output 1 to 2	116
Profile version (Parameter)	70	Discrete outputs	116
		Display	13
		Electrode cleaning circuit	56
		Empty pipe detection	53
		Event list	148
		Event logbook	147
		External compensation	58

Heartbeat	154	W	
Low flow cut off	50	Web server (Submenu)	80
Main electronic temperature	153	Web server functionality (Parameter)	82
Measured values	35	Web server language (Parameter)	81
Min/max values	152	Wizard	
Physical block	71	Define access code	31
Process parameters	46	Z	
Process variable adjustment	61	Zero point (Parameter)	66
Process variables	35		
PROFIBUS DP configuration	67		
PROFIBUS DP info	69		
Sensor	34		
Sensor adjustment	60		
Simulation	155		
System	13		
System units	38		
Temperature	154		
Totalizer	37		
Totalizer 1 to 3	126		
Web server	80		
Subnet mask (Parameter)	82		
Switch point empty pipe detection (Parameter)	54		
System (Submenu)	13		
System units (Submenu)	38		
T			
Tag description (Parameter)	86, 99, 107, 119, 132		
Target group	4		
Target mode (Parameter)	73, 87, 100, 108, 120, 133		
Temperature (Parameter)	36		
Temperature (Submenu)	154		
Temperature damping (Parameter)	49		
Temperature factor (Parameter)	65		
Temperature offset (Parameter)	65		
Temperature source (Parameter)	58		
Temperature unit (Parameter)	42		
Timestamp (Parameter)	141, 142, 143, 144, 145, 146		
Totalizer (Submenu)	37		
Totalizer 1 to 3 (Submenu)	126		
Totalizer operation mode (Parameter)	130		
Totalizer status (Hex) 1 to 3 (Parameter)	38, 132		
Totalizer status 1 to 3 (Parameter)	38, 131		
Totalizer value 1 to 3 (Parameter)	37, 131		
U			
Unit totalizer (Parameter)	127		
V			
Value 1 display (Parameter)	17		
Value 2 display (Parameter)	19		
Value 3 display (Parameter)	20		
Value 4 display (Parameter)	21		
Value process variable (Parameter)	156		
Volume flow (Parameter)	35		
Volume flow factor (Parameter)	62		
Volume flow offset (Parameter)	62		
Volume flow unit (Parameter)	39		
Volume unit (Parameter)	41		

www.addresses.endress.com
