


Bestellung von neuen Typenschilder oder Nachdruck eines Typenschilds

Nach einem Umbau, z.B. Austausch einem Anschlußkopf, einer Messbereichsänderung, Austausch des Kopftransmitters, usw. wird empfohlen das Typenschild zu erneuern

Zu verwenden ist der Bestellcode DIENST-T



Geben Sie den Bestellcode DIENST-T als Bestellnummer und pro Position ist nur 1 Schild möglich



Der E+H Konfigurator wird geöffnet, hier werde die detaillierte Information des Gerätes editiert

Alter Bestellcode/Ident	
Neuer Bestellcode/Ident	
Seriennummer	
Kundeninformation	
z.B. neuer Messbereich/neue	er Kopftransmitter/
Nachdruck	

Pro Position kann immer nur eine Seriennummer eingegeben werden.


Order of a new nameplate or replacement

After a modification, e.g. change of housing / measuring range change / transmitter exchange / is a type plate replacement is recommended.

Enter the code DIENST-T



Enter the code DIENST-T as order code and the number of pieces with 1 piece



The Configurator field will be opened. Here you have to edit a text with detailed information.

Enter the following information in the opened window:

old order code/Ident	
new order code/Ident	
serial no	
customer text	
For information, e.g. for a measuring range change	

, 3

Only one serial number can be entered per position.

People for Process Automation

