Promass 200/TB2

**EN** Installation Instructions: EA00106D → 🖺 3

**DE** Einbauanleitung: EA00106D → 🖺 11



# Sensor replacement

Promass 200/TB2

#### Table of contents

1	Overview of spare part sets	4
2	Designated use	, 4
3	Personnel authorized to carry out repairs	5
4	Safety instructions	5
5	Symbols used	6
6	Tools list	. 7
7	Sensor replacement	7

## 1 Overview of spare part sets

The Installation Instructions apply to the following replacement sensors:

Order structure	Contents
8E2B**-	1 × sensor Promass E 200/TB2
8F2B**-	1 × sensor Promass F 200/TB2


## 2 Designated use

The spare part sets and Installation Instructions are used to replace a faulty unit with a functioning unit of the same type. Only original parts from Endress+Hauser may be used. Only spare parts kits designed by Endress+Hauser for the measuring device can be used at any time.

Inspection is performed using the W@M Device Viewer. The procedure involved is described as follows.

i

A spare parts overview is located in the interior of some measuring devices. If the spare parts kit is specified on this list, no inspection is required.



- 1. www.endress.com/deviceviewer
- 2. Enter serial number (ser. no.), search for product data and click Spare Parts.
- All spare parts for the measuring device are displayed.
- 4. Determine the order number of the spare parts kit.
- The spare parts kit may be used only if the order number of the spare parts kit corresponds to an order number on the spare parts list.

## 3 Personnel authorized to carry out repairs

Authorization to carry out repairs depends on the measuring device's approval type. The table below shows the authorized group of people in each case.



Whoever carries out the repairs has full responsibility to ensure that work is carried out safely and to the required quality standard. He/she must also guarantee the safety of the device following repair.


Measuring device approval	Personnel authorized to perform repairs <sup>1)</sup>
Without approval	2, 3
With approval (e.g. IECEx)	2, 3
For custody transfer	4

- 1) 1 = Qualified specialist on customer side, 2 = Service technician authorized by Endress+Hauser,
  - 3 = Endress+Hauser (return measuring device to manufacturer)
  - 4 = Check with local approval center if installation/modification must be performed under supervision.

## 4 Safety instructions

- Check whether the spare part matches the labeling on the measuring device as described on the cover page.
- The spare part sets and Installation Instructions are used to replace a faulty unit with a functioning unit of the same type.
  - Only use original parts from Endress+Hauser.
- Comply with national regulations governing mounting, electrical installation, commissioning, maintenance and repair procedures.
- The following requirements must be met with regard to specialized technical staff for the mounting, electrical installation, commissioning, maintenance and repair of the measuring devices:
  - Specialized technical staff must be trained in instrument safety.
  - They must be familiar with the individual operating conditions of the devices.
  - In the case of Ex-certified measuring devices, they must also be trained in explosion protection.
- The measuring device is energized! Risk of fatal injury from electric shock. Open the measuring device only when the device is de-energized.
- When using Ex-certified measuring devices: Open device only when in a de-energized state (allow 10 minutes to elapse after switching off the power supply) or in environments which do not have a potentially explosive atmosphere.
- In the case of measuring devices in safety-related applications in accordance with IEC 61508 or IEC 61511: Commission in accordance with Operating Instructions after repair. Document the repair procedure.
- Before removing the device: set the process to a safe state and purge the pipe of dangerous process substances.
- Hot surfaces! Risk of injury! Before commencing work: allow the system and measuring device to cool down to a touchable temperature.

- In the case of devices in custody transfer, the custody transfer status no longer applies once the seal has been removed.
- The Operating Instructions for the device must be followed.
- Risk of damaging the electronic components! Ensure you have a working environment protected from electrostatic discharge.
- After removing the electronics compartment cover: risk of electrical shock due to missing touch protection!
  - Turn the measuring device off before removing internal covers.
- Modifications to the measuring device are not permitted.
- Only open the housing for a brief period. Avoid the penetration of foreign bodies, moisture
  or contaminants.
- Replace defective seals only with original seals from Endress+Hauser.
- If threads are damaged or defective, the measuring device must be repaired.
- Threads (e.g. of the electronics compartment cover and connection compartment cover) must be lubricated if an abrasion-proof dry lubricant is not available. Use acid-free, non-hardening lubricant.
- If spacing is reduced or the dielectric strength of the measuring device cannot be guaranteed during repair work, perform a test on completion of the work (e.g. high-voltage test in accordance with the manufacturer's instructions).
- Service plug:
  - Do not connect in explosive atmospheres.
  - Only connect to Endress+Hauser service devices.
- Observe the instructions for transporting and returning the device outlined in the Operating Instructions



## 5 Symbols used

#### 5.1 Safety symbols

Symbol	Meaning	
<b>⚠</b> DANGER	DANGER! This symbol alerts you to a dangerous situation. Failure to avoid this situation will result in serious or fatal injury.	
<b>▲</b> WARNING	<b>WARNING!</b> This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in serious or fatal injury.	
<b>A</b> CAUTION	CAUTION! This symbol alerts you to a dangerous situation. Failure to avoid this situation can result in minor or medium injury.	
NOTICE	NOTE! This symbol contains information on procedures and other facts which do not result in personal injury.	

## 5.2 Symbols for certain types of information

Symbol	Meaning	
	Permitted Procedures, processes or actions that are permitted.	
X	Forbidden Procedures, processes or actions that are forbidden.	
i	Tip Indicates additional information.	
1., 2., 3	Series of steps	

#### 6 Tools list



## 7 Sensor replacement


## 7.1 Removing the transmitter


#### **A** CAUTION


#### The measuring device is energized!


Risk of fatal injury from electric shock.


▶ Open the measuring device only when the device is deenergized.




























#### 7.1.1 Replacing the sensor E (Fig. 1) and sensor F (Fig. 2)

Proceed as described in Section 7.1.  $\rightarrow$   $\blacksquare$  7 and in Figure 1 or 2.







#### 7.1.2 Reassembling the sensor and transmitter

Reassembly is carried out in reverse order.


Note the following:





 Check the male pin header strip of the electronics module before installation. The pins must not be bent.



► When installing, slide the electronics module along the mounting guide rail (A) in the transmitter housing.










► Tighten the screws of the electronics module.



#### Check the position of the write protection switch







## Austausch Messaufnehmer

#### Promass 200/TB2

#### Inhaltsverzeichnis

1	Übersicht Ersatzteilsets	12
2	Bestimmungsgemäße Verwendung	12
3	Reparaturberechtigte Personen	13
4	Sicherheitshinweise	13
5	Verwendete Symbole	14
6	Werkzeugliste	15
7	Austausch Messaufnehmer	15

#### 1 Übersicht Ersatzteilsets

Die Einbauanleitung ist für folgende Ersatzmessaufnehmer gültig:


Bestellstruktur	Inhalt
8E2B**-	1 × Messaufnehmer Promass E 200/TB2
8F2B**-	1 × Messaufnehmer Promass F 200/TB2

## 2 Bestimmungsgemäße Verwendung

Ersatzteilset und Einbauanleitung dienen dazu, eine defekte Einheit gegen eine funktionierende Einheit des gleichen Typs zu ersetzen. Es dürfen nur Originalteile von Endress+Hauser verwendet werden. Grundsätzlich dürfen nur Ersatzteilsets verwendet werden, die von Endress+Hauser für das Messgerät vorgesehen sind.

Die Überprüfung ist via W@M Device Viewer durchzuführen, die Vorgehensweise dazu ist nachfolgend beschrieben.

Bei einigen Messgeräten befindet sich im Inneren des Gerätes eine Ersatzteilübersicht. Ist das Ersatzteilset dort aufgelistet, entfällt die Überprüfung.



- 1. www.endress.com/deviceviewer
- 2. Seriennummer (Ser. No.) eingeben, Produktdaten suchen und auf Ersatzteile klicken.
- Anzeige aller Ersatzteile zum Messgerät.
  - Die Bestellnummer des Ersatzteilsets ermitteln.
- Nur wenn die Bestellnummer des Ersatzteilsets mit einer Bestellnummer in der Ersatzteilliste übereinstimmt, darf das Ersatzteilset verwendet werden.

## 3 Reparaturberechtigte Personen

Die Berechtigung zur Durchführung einer Reparatur ist von der Zulassung des Messgeräts abhängig. Die Tabelle zeigt den jeweils berechtigten Personenkreis.



Die Person, die eine Reparatur vornimmt, übernimmt die Verantwortung für die Sicherheit während der Arbeiten, die Qualität der Ausführung und die Sicherheit des Geräts nach der Reparatur.


Zulassung des Messgeräts	Reparaturberechtigter Personenkreis <sup>1)</sup>
Ohne Zulassung	2, 3
Mit Zulassung (z.B. IECEx)	2, 3
Bei eichfähigem Verkehr	4

- 1) 1 = Ausgebildete Fachkraft des Kunden, 2 = Von Endress+Hauser autorisierter Servicetechniker,
  - 3 = Endress+Hauser (Messgerät an Hersteller zurücksenden)
  - 4 = Mit der lokalen Zulassungsstelle prüfen, ob ein Ein-/Umbau unter Aufsicht erfolgen muss.

#### 4 Sicherheitshinweise

- Prüfen, ob das vorliegende Ersatzteil zur Kennzeichnung auf dem Messgerät passt, wie auf der Titelseite beschrieben.
- Ersatzteilset und Einbauanleitung dienen dazu, eine defekte Einheit gegen eine funktionierende Einheit des gleichen Typs zu ersetzen.
  - Nur Originalteile von Endress+Hauser verwenden.
- Nationale Vorschriften bezüglich der Montage, elektrischen Installation, Inbetriebnahme, Wartung und Reparatur einhalten.
- Folgende Anforderungen an das Fachpersonal für Montage, elektrische Installation, Inbetriebnahme, Wartung und Reparatur der Messgeräte müssen erfüllt sein:
  - In Gerätesicherheit ausgebildet.
  - Mit den jeweiligen Einsatzbedingungen der Geräte vertraut.
  - Bei Ex-zertifizierten Messgeräten: zusätzlich im Explosionsschutz ausgebildet.
- Messgerät unter Spannung! Lebensgefahr durch Stromschlag. Messgerät nur im spannungslosen Zustand öffnen.
- Bei Ex-zertifizierten Messgeräten: Nur in spannungslosem Zustand (nach Berücksichtigung einer Wartezeit von 10 Minuten nach Abschalten der Energiezufuhr) oder in Umgebungen öffnen, die keine explosionsfähige Atmosphäre enthalten.
- Bei Messgeräten in sicherheitstechnischen Applikationen gemäß IEC 61508 bzw.
   IEC 61511: Nach Reparatur Neuinbetriebnahme gemäß Betriebsanleitung durchführen.
   Reparatur dokumentieren.
- Vor einem Geräteausbau: Prozess in sicheren Zustand bringen und Leitung von gefährlichen Prozessstoffen befreien.
- Verbrennungsgefahr durch heiße Oberflächen! Vor Arbeitsbeginn: Anlage und Messgerät auf berührungssichere Temperatur abkühlen.
- Bei Messgeräten im abrechnungspflichtigen Verkehr: Nach Entfernen der Plombe ist der geeichte Zustand aufgehoben.

- Die Betriebsanleitung zum Messgerät ist zu beachten.
- Beschädigungsgefahr elektronischer Bauteile! Eine ESD-geschützte Arbeitsumgebung herstellen.
- Nach Entfernen der Elektronikabdeckung: Stromschlaggefahr durch aufgehobenen Berührungsschutz!
  - Messgerät ausschalten, bevor interne Abdeckungen entfernt werden.
- Änderungen am Messgerät sind nicht zulässig.
- Gehäuse nur kurzzeitig öffnen. Eindringen von Fremdkörpern, Feuchtigkeit oder Verunreinigung vermeiden.
- Defekte Dichtungen nur durch Original-Dichtungen von Endress+Hauser ersetzen.
- Defekte Gewinde erfordern eine Instandsetzung des Messgeräts.
- Gewinde (z.B. von Elektronikraum- und Anschlussraumdeckel) müssen geschmiert sein, sofern keine abriebfeste Trockenschmierung vorhanden ist. Säurefreies, nicht härtendes Fett verwenden.
- Wenn bei den Reparaturarbeiten Abstände reduziert oder die Spannungsfestigkeit des Messgeräts nicht sichergestellt werden kann: Prüfung nach Abschluss der Arbeiten durchführen (z.B. Hochspannungstest gemäß Herstellerangaben).
- Servicestecker:
  - Nicht in explosionsfähiger Atmosphäre anschließen.
  - Nur an Servicegeräte von Endress+Hauser anschließen.
- Die in der Betriebsanleitung aufgeführten Hinweise zum Transport und zur Rücksendung beachten.



## 5 Verwendete Symbole

#### 5.1 Warnhinweissymbole

Symbol	Bedeutung
<b>▲</b> GEFAHR	<b>GEFAHR!</b> Dieser Hinweis macht auf eine gefährliche Situation aufmerksam, die, wenn sie nicht vermieden wird, zu Tod oder schwerer Körperverletzung führen wird.
<b>▲</b> WARNUNG	WARNUNG! Dieser Hinweis macht auf eine gefährliche Situation aufmerksam, die, wenn sie nicht vermieden wird, zu Tod oder schwerer Körperverletzung führen kann.
<b>▲</b> VORSICHT	VORSICHT!  Dieser Hinweis macht auf eine gefährliche Situation aufmerksam, die, wenn sie nicht vermieden wird, zu leichter oder mittelschwerer Körperverletzung führen kann.
HINWEIS	<b>HINWEIS!</b> Dieser Hinweis enthält Informationen zu Vorgehensweisen und weiterführenden Sachverhalten, die keine Körperverletzung nach sich ziehen.

## 5.2 Symbole für Informationstypen

Symbol	Bedeutung	
$\checkmark$	<b>Erlaubt</b> Abläufe, Prozesse oder Handlungen, die erlaubt sind.	
X	Verboten Abläufe, Prozesse oder Handlungen, die verboten sind.	
i	Tipp Kennzeichnet zusätzliche Informationen.	
1., 2., 3	Handlungsschritte	

## 6 Werkzeugliste



### 7 Austausch Messaufnehmer


#### 7.1 Ausbau Messumformer


#### **▲** VORSICHT


#### Messgerät unter Spannung!


Lebensgefahr durch Stromschlag.


► Messgerät nur im spannungslosen Zustand öffnen.




























#### 7.1.1 Austausch Messaufnehmer E (Bild 1) und Messaufnehmer F (Bild 2)

Vorgehen wie in Kapitel 7.1.  $\rightarrow$   $\blacksquare$  15 und wie im Bild 1 oder 2.







#### 7.1.2 Zusammenbau Messaufnehmer und Messumformer

Der Zusammenbau erfolgt in umgekehrter Reihenfolge.


Folgendes ist zu beachten:





► Vor dem Einbau die Stiftleiste des Elektronikmoduls überprüfen. Die Pins dürfen nicht verbogen sein.



 Das Elektronikmodul beim Einbau entlang der Führungsschiene (A) im Messumformergehäuse einschieben.








· Schrauben des Elektronikmoduls festziehen.



#### Position des Schreibschutz-Verriegelungsschalters kontrollieren



Detaillierte Angaben zum elektrischen Anschluss: Kapitel "Elektrischer Anschluss", Betriebsanleitung zum Gerät.

Detaillierte Angaben zur Inbetriebnahme: Kapitel "Inbetriebnahme", Betriebsanleitung zum Gerät.





www.addresses.endress.com