



Herstellerinformation

für Anwender betreffend Softwareänderungen
(in Anlehnung an NAMUR-Empfehlung 53)

Field Xpert - Device Xpert - SFX100

Freigabe der Software Device Xpert HART 1.6.2

1 Produkt

- ☐ Feldgerät / signalverarbeitendes Gerät
- ☒ Softwareanwendung zur Gerätekonfiguration / Handkommunikator / Gerätetreiber o.ä.
- ☐ Modem / Schnittstelle

Hersteller : Endress+Hauser Process Solutions AG
Produkt : Field Xpert - Device Xpert HART
Teilenummer : SFX100

2 Software

Bisherige Softwareversion : **Device Xpert HART 1.6.1 Software**
Neue Softwareversion : **Device Xpert HART 1.6.2 Software**
Wie kann die bisherige Software-Versionsnummer ermittelt werden? : Ermittlung der aktuellen Software Version über den Device Xpert Software Menüpunkt "Hilfe -> Über Device Xpert"
Beschreibung der Änderungen gegenüber der Vorgängerversion: : Die neue Software ist sowohl als Download von der Produkt-Website: <http://www.produkte.endress.com/sfx100> Register "Dokumente/Software" als auch auf der Produkt CD des Field Xpert - Device Xpert Package V1.02.02 verfügbar

3 Kompatibilität

Ist die neue Softwareversion kompatibel mit der Vorgängerversion, installierten Gerätesoftwaretreibern und Bedientools?

- ☒ Ja
- ☐ Nein, Begründung:

Ist ein Update der Software generell empfehlenswert?

- ☒ Ja, Begründung:

In der neuen Softwareversion sind verschiedene kleine Verbesserungen für eine schnellere und bessere Benutzung integriert und einige Programmfehler (Bugs) sind behoben (siehe Release Notes/Freigabehinweise im Anhang).

Herstellerinformation

für Anwender betreffend Softwareänderungen
(in Anlehnung an NAMUR-Empfehlung 53)

☐ Nein, Begründung:

4 Bedienungsanleitung

Wird eine neue Betriebsanleitung aufgrund der Modifikationen benötigt?

- ☐ Ja
☒ Nein

Welche Betriebsanleitung passt zur aktuellen Softwareversion:

Produkt	Kommunikation	Anleitung	Bezeichnung
Field Xpert	HART	Betriebsanleitung Field Xpert Gerätekonfigurator	BA060S/04/de/03.10

Die Betriebsanleitungen können im Internet bezogen werden:

<http://www.produkte.endress.com/sfx100>

- Register „Software/Dokumente“

5 Preis

Ändert sich der Preis im Vergleich mit der Vorgängerversion?

- ☐ Ja, neue Preise und Updatekosten (ohne Installation) liegen als Anlage bei
☒ Nein

Release Notes Device Xpert configuration software

Device Xpert configuration software from Endress+Hauser makes Field Xpert the complete HART® communicator for industrial applications.

Please read this document to ensure successful installation of the latest Device Xpert Software on your Field Xpert.

Software version: Device Xpert HART 1.6.2

1. Improvements/Changes:

- Optimized some issues regarding communication infrastructure
- Implemented new style sheets (XSL) for English and German device reports
- Implemented communications failure popup window with hints to solve the problem, when an error like 4...20mA loop open occurs
- Image tab can now directly be closed from tab submenu
- Changed default proxy from 80 to 8080 (common used)
- Envelope curve automatically is loaded in the device menu when a time of flight device is recognized
- Bluetooth modem is now the default connection
- If only 1 device is scanned (addr. range) then Device Xpert opens the device configuration view automatically
- New constants.xml file for new device DD integration
- Used 'Compare' instead of 'Verify' as this reflects better the functionality
- Changed software name to Device Xpert HART to differentiate Device Xpert HART and Device Xpert FF (also splash screen)
- many new DDs can easily be downloaded via Internet from the Endress+Hauser DD Update server (round 1000 DDs) (needs DD update contract)
- 'Poll all dynamic every' is per default checked and set to 10s (View -> Settings -> Options) -> automatic. update of parameters
- New Today Splash Screen (TSK-File)

2. Bug Fixes:

- fixed a Generic DD problem during opening of the DD and in application installer (now correct Generic DD is used)
- fixed application hang when exiting with envelope graph open
- removed DD library flattening check
- Improved and fixed some text strings and translations in German and English help file
- fixed Liquline scaling and constant unit issue
- Header polling is now configurable
- Header Units now read from HART Command 3 on each refresh
- Fixed the cleanup of menu items in the tree control
- Fixed Device View menu generation in certain logging levels
- Fixed usage of ABB TH02 method
- Fixed 'Poll Header Bar' - Values cannot be set to values <2
- Fixed the month displayed in the header of a device image
- Some other minor bug fixes

3. Known Issues:

- sometimes it is not possible to 'Retry' after a communication error has occurred. Then please choose 'no' if you are asked in the pop-up window. Device Xpert disconnects then the device. Connect it again.

4. Important to know:

- Ensure Device Xpert English version is installed on English OS (Windows mobile English).

5. Before you install:

- Please ensure Active Sync Connection during installation.
- Following the installation procedure correctly would ensure upgrade in functionality of software, but for some reason if installation fails we recommend to 'Clean Reset' of your Field Xpert (refer to Operating Manual for clean reset procedure) and then install the Device Xpert software.
After installation you need to reactivate the license with Endress+Hauser Process Solutions AG (refer to operating manual).

5. Recommendations:

- to work with Device Xpert - field device images and reports, please use folders on the root of the SD-Card and name them Reports and Images

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
ABB Automation	0x00001A	KSX	0x0001	5	2
ABB Automation	0x00001A	600T	0x0002	1	2
ABB Automation	0x00001A	600T	0x0002	2	3
ABB Automation	0x00001A	600T	0x0002	3	4
ABB Automation	0x00001A	2600T-268	0x0003	1	1
ABB Automation	0x00001A	2600T-268	0x0003	3	1
ABB Automation	0x00001A	2600T-262/264	0x0004	1	1
ABB Automation	0x00001A	2600T-262/264	0x0004	2	2
ABB Automation	0x000016	TEU 211	0x0005	1	2
ABB Automation	0x00001A	2600T-364	0x0005	1	2
ABB Automation	0x000016	TEU 211	0x0005	2	2
ABB Automation	0x000016	TEU 211	0x0005	3	2
ABB Automation	0x000016	TS 11	0x0006	1	2
ABB Automation	0x000016	TS 11	0x0006	2	2
ABB Automation	0x000016	TS 11	0x0006	3	2
ABB Automation	0x000016	TH 02	0x0008	1	1
ABB Automation	0x00001A	KST	0x0008	1	2
ABB Automation	0x00001A	658T	0x000A	1	2
ABB Automation	0x00001A	652/653S	0x000C	1	2
ABB Automation	0x00001A	FVS4000	0x001A	0	11
ABB Automation	0x00001A	FSM4000	0x001D	0	0
ABB Automation	0x00001A	TB82PH-Combined	0x0023	1	1
ABB Automation	0x00001A	TB82EC-Combined	0x0024	1	1
ABB Automation	0x00001A	TB82TE-Combined	0x0025	1	1
ABB Automation	0x00001A	TB82TC-Combined	0x0026	1	1
ABB Automation	0x000016	TZID	0x0040	1	1
ABB Automation	0x000016	TZIDC	0x0041	1	1
ABB Automation	0x000016	AS800	0x0085	2	2
ABB Automation	0x000016	Contrac	0x0087	1	1
ABB Automation	0x00001A	263/265, 2000T	0x0089	2	2
ABB Automation	0x00001A	263/265, 2000T	0x0089	2	3
ABB Automation	0x00001A	261	0x008C	1	1
ACCUTECH	0x00005E	VR1500XX	0x00EE	1	1
ACCUTECH	0x00005E	AI1500	0x00EF	1	1
Action Instruments	0x000089	T798	0x00EF	1	1
American Level Instruments	0x0000B2	Model 32E	0x007F	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	1	1
Ametek	0x000003	NEWTHERMOX	0x0004	2	1
Ametek	0x000003	NEWTHERMOX	0x0004	3	1
Analytical Technology Inc.	0x00009F	D12	0x007F	2	0
Anderson Instrument Company	0x00005A	ANDRSN1	0x00C8	1	3
Apparatebau Hundsbach	0x000071	MT115	0x00EE	1	1
Badgermeter	0x0000BD	Primo Advanced	0x0001	1	1
BERTHOLD	0x0000A1	LB491	0x007D	1	2
BERTHOLD	0x0000A1	LB491	0x007D	2	3
BERTHOLD	0x0000A1	LB491	0x007D	2	4
BERTHOLD	0x0000A1	LB460	0x007E	1	1
BERTHOLD	0x0000A1	LB490	0x007F	1	1
BERTHOLD	0x0000A1	LB490	0x007F	2	2
BERTHOLD	0x0000A1	LB490	0x007F	3	3
BERTHOLD	0x0000A1	LB490	0x007F	3	4
BESTA	0x000066	CLS 4-20	0x00EF	1	1
Bopp & Reuther Heinrichs	0x00006C	UMC2	0x00EB	3	1
Bopp & Reuther Heinrichs	0x00006C	ES	0x00EC	2	1
Bopp & Reuther Heinrichs	0x00006C	VTX	0x00ED	7	1
Bopp & Reuther Heinrichs	0x00006C	DIMF	0x00EE	7	1
Bopp & Reuther Heinrichs	0x00006C	UST 1	0x00EF	1	2
Bopp & Reuther Heinrichs	0x00006C	UST 1	0x00EF	7	1
Brooks Instrument	0x00000A	TRI20	0x0001	1	1
Brooks Instrument	0x00000A	38XXVA	0x0002	1	1
Brooks Instrument	0x00000A	QUANTIM	0x0004	1	1
Danfoss	0x000080	MAGFLO	0x0003	1	1
Det-Tronics	0x00008F	X2200	0x0076	1	1
Det-Tronics	0x00008F	X5200	0x0077	1	1
Det-Tronics	0x00008F	X9800	0x0078	1	1
Det-Tronics	0x00008F	X3302	0x0079	1	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Det-Tronics	0x00008F	GT3000	0x007B	1	1
Det-Tronics	0x00008F	X3301	0x007C	1	1
Det-Tronics	0x00008F	OPECL_RX	0x007E	1	1
Det-Tronics	0x00008F	OPECL_RX	0x007E	1	2
Det-Tronics	0x00008F	Eclipse	0x007F	1	1
DeZURIK	0x000091	Positioner	0x00EF	1	4
Direct Measurement	0x000074	DMC R-1A	0x00EF	1	1
Draeger	0x000052	Polytron 7000	0x00EB	1	1
Draeger	0x000052	POLYTRON2 IR	0x00ED	0	5
Draeger	0x000052	POLYTRON2 IR	0x00ED	1	1
Draeger	0x000052	Polytron2	0x00F7	1	1
Draeger	0x000052	Polytron2	0x00F7	1	2
Draeger	0x000052	Polytron2	0x00F7	3	1
Draeger	0x000052	Polytron2	0x00F7	3	2
Drexelbrook	0x00004E	UNIVERSAL III	0x0002	5	3
Drexelbrook	0x00004E	USonic	0x00EB	2	2
Dynisco	0x000072	SPX	0x00DE	16	2
Dynisco	0x000072	IPXII	0x00DF	1	1
Dynisco	0x000072	IPX	0x00E0	1	3
Elsag Bailey	0x000012	50XM2000	0x0007	0	5
Elsag Bailey	0x000012	50XE4000	0x0008	0	6
Elsag Bailey	0x000012	50VT1000	0x000E	0	5
Elsag Bailey	0x000012	50VM1000	0x000F	0	4
Elsag Bailey	0x000012	50XM1000	0x0019	4	2
Elsag Bailey	0x000012	50SM1000	0x001A	4	1
Elsag Bailey	0x000012	PTH	0x0042	1	1
Elsag Bailey	0x000012	TB82PH pH	0x0050	1	1
Elsag Bailey	0x000012	TB82PH ORP	0x0051	1	1
Elsag Bailey	0x000012	TB82PH pION	0x0052	1	1
Elsag Bailey	0x000012	TB82PH IConc	0x0053	1	1
Elsag Bailey	0x000012	TB82EC COND	0x0054	1	1
Elsag Bailey	0x000012	TB82EC CONC	0x0055	1	1
Elsag Bailey	0x000012	TB82TE COND	0x0056	1	1
Elsag Bailey	0x000012	TB82TE CONC	0x0057	1	1
Elsag Bailey	0x000012	TB82TC COND	0x0058	1	1
Elsag Bailey	0x000012	TB82TC CONC	0x0059	1	1
Endress + Hauser	0x000011	FMU860	0x0003	1	2
Endress + Hauser	0x000011	FMU860	0x0003	2	3
Endress + Hauser	0x000011	FMU860	0x0003	3	1
Endress + Hauser	0x000011	FMU861	0x0004	1	1
Endress + Hauser	0x000011	FMU861	0x0004	2	2
Endress + Hauser	0x000011	FMU861	0x0004	3	1
Endress + Hauser	0x000011	FMU862	0x0005	1	1
Endress + Hauser	0x000011	FMU862	0x0005	2	2
Endress + Hauser	0x000011	FMU862	0x0005	3	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	1	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	2	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	3	1
Endress + Hauser	0x000011	FMR130/Micropilot	0x0006	4	1
Endress + Hauser	0x000011	Cerabar S	0x0007	1	1
Endress + Hauser	0x000011	Cerabar S	0x0007	2	2
Endress + Hauser	0x000011	Cerabar S	0x0007	3	2
Endress + Hauser	0x000011	Cerabar S	0x0007	4	1
Endress + Hauser	0x000011	Cerabar S	0x0007	5	1
Endress + Hauser	0x000011	Cerabar S	0x0007	6	1
Endress + Hauser	0x000011	Cerabar S	0x0007	7	1
Endress + Hauser	0x000011	Cerabar S	0x0007	7	2
Endress + Hauser	0x000011	Cerabar S	0x0007	7	3
Endress + Hauser	0x000011	FEC12	0x0008	1	2
Endress + Hauser	0x000011	Deltabar S	0x0009	1	2
Endress + Hauser	0x000011	Deltabar S	0x0009	2	2
Endress + Hauser	0x000011	Deltabar S	0x0009	3	1
Endress + Hauser	0x000011	Deltabar S	0x0009	5	1
Endress + Hauser	0x000011	Deltabar S	0x0009	6	1
Endress + Hauser	0x000011	Deltabar S	0x0009	7	1
Endress + Hauser	0x000011	Deltabar S	0x0009	7	2

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	Deltabar S	0x0009	7	3
Endress + Hauser	0x000011	FMU231/FMU13x	0x000A	1	2
Endress + Hauser	0x000011	FMU231/FMU13x	0x000A	2	2
Endress + Hauser	0x000011	Deltapilot	0x000B	1	2
Endress + Hauser	0x000011	Deltapilot	0x000B	2	2
Endress + Hauser	0x000011	FMR23x	0x000C	1	1
Endress + Hauser	0x000011	FMR23x	0x000C	2	1
Endress + Hauser	0x000011	FMP200	0x000D	1	1
Endress + Hauser	0x000011	FMP200	0x000D	2	1
Endress + Hauser	0x000011	Cerabar M	0x000E	1	1
Endress + Hauser	0x000011	FMR2xx	0x000F	1	2
Endress + Hauser	0x000011	FMR2xx	0x000F	2	1
Endress + Hauser	0x000011	FMR2xx	0x000F	4	1
Endress + Hauser	0x000011	FMR53x	0x0010	1	2
Endress + Hauser	0x000011	FMR53x	0x0010	2	1
Endress + Hauser	0x000011	FMR53x	0x0010	3	1
Endress + Hauser	0x000011	FMU4x	0x0011	2	2
Endress + Hauser	0x000011	FMU4x	0x0011	4	1
Endress + Hauser	0x000011	FMP4x	0x0012	2	1
Endress + Hauser	0x000011	FMP4x	0x0012	4	1
Endress + Hauser	0x000011	FMG60	0x0013	1	1
Endress + Hauser	0x000011	FMG60	0x0013	2	1
Endress + Hauser	0x000011	FMG60	0x0013	2	2
Endress + Hauser	0x000011	DeltabarS	0x0017	10	1
Endress + Hauser	0x000011	DeltabarS	0x0017	20	1
Endress + Hauser	0x000011	DeltabarS	0x0017	21	1
Endress + Hauser	0x000011	DeltabarS	0x0017	21	2
Endress + Hauser	0x000011	CerabarS	0x0018	10	1
Endress + Hauser	0x000011	CerabarS	0x0018	20	1
Endress + Hauser	0x000011	CerabarS	0x0018	21	1
Endress + Hauser	0x000011	CerabarS	0x0018	21	2
Endress + Hauser	0x000011	Cerabar M 5x	0x0019	1	1
Endress + Hauser	0x000011	DeltapilotS	0x001A	21	1
Endress + Hauser	0x000011	DeltapilotS	0x001A	21	2
Endress + Hauser	0x000011	FMU9x	0x001B	1	1
Endress + Hauser	0x000011	FMU9x	0x001B	2	1
Endress + Hauser	0x000011	FMU9x	0x001B	3	1
Endress + Hauser	0x000011	FMI5x	0x001D	3	1
Endress + Hauser	0x000011	FMR25x	0x001E	1	1
Endress + Hauser	0x000011	FMR25x	0x001E	4	1
Endress + Hauser	0x000011	FMR25x	0x001E	5	1
Endress + Hauser	0x000011	FMR54x	0x001F	1	1
Endress + Hauser	0x000011	FMR54x	0x001F	1	2
Endress + Hauser	0x000011	FMP4x I	0x0020	8	1
Endress + Hauser	0x000011	Deltabar M 5x	0x0021	1	1
Endress + Hauser	0x000011	Deltapilot M 5x	0x0023	1	1
Endress + Hauser	0x000011	Waterpilot 2x	0x0024	1	1
Endress + Hauser	0x000011	PROMAG 33	0x0032	1	2
Endress + Hauser	0x000011	PROMAG 33	0x0032	2	1
Endress + Hauser	0x000011	PROWIRL 70	0x0033	1	2
Endress + Hauser	0x000011	PROMASS 63	0x0034	1	3
Endress + Hauser	0x000011	PROMASS 63	0x0034	2	1
Endress + Hauser	0x000011	PROMASS 63	0x0034	3	3
Endress + Hauser	0x000011	PROMASS 63	0x0034	4	1
Endress + Hauser	0x000011	PROMAG 39	0x0035	1	1
Endress + Hauser	0x000011	PROMAG 35S	0x0036	1	1
Endress + Hauser	0x000011	PROWIRL 77	0x0037	1	2
Endress + Hauser	0x000011	PROMASS 60	0x0039	1	1
Endress + Hauser	0x000011	PROMASS 60	0x0039	2	2
Endress + Hauser	0x000011	PROMASS 60	0x0039	3	1
Endress + Hauser	0x000011	PROSONIC FLOW	0x0040	1	1
Endress + Hauser	0x000011	PROSONIC FLOW	0x0040	2	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	1	2
Endress + Hauser	0x000011	PROMAG 50	0x0041	2	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	3	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	4	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	PROMAG 50	0x0041	5	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	6	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	7	1
Endress + Hauser	0x000011	PROMAG 50	0x0041	8	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	1	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	2	2
Endress + Hauser	0x000011	PROMAG 53	0x0042	3	2
Endress + Hauser	0x000011	PROMAG 53	0x0042	4	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	5	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	6	1
Endress + Hauser	0x000011	PROMAG 53	0x0042	7	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	2	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	3	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	4	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	5	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	6	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	7	1
Endress + Hauser	0x000011	PROMAG 51	0x0043	8	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	1	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	2	1
Endress + Hauser	0x000011	PROMAG 55	0x0044	3	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	1	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	2	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	3	1
Endress + Hauser	0x000011	PROMAG 10	0x0045	4	1
Endress + Hauser	0x000011	PROMAG 23	0x0046	1	1
Endress + Hauser	0x000011	PROMAG 23	0x0046	2	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	1	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	2	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	3	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	4	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	5	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	6	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	7	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	8	1
Endress + Hauser	0x000011	PROMASS 80	0x0050	9	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	1	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	2	3
Endress + Hauser	0x000011	PROMASS 83	0x0051	3	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	4	2
Endress + Hauser	0x000011	PROMASS 83	0x0051	5	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	6	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	7	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	8	1
Endress + Hauser	0x000011	PROMASS 83	0x0051	9	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	6	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	7	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	8	1
Endress + Hauser	0x000011	PROMASS 84	0x0052	9	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	1	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	2	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	3	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	4	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	5	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	6	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	7	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	8	1
Endress + Hauser	0x000011	PROMASS 40	0x0053	9	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	1	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	2	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	3	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	4	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	5	1
Endress + Hauser	0x000011	PROWIRL 72	0x0056	6	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	1	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	2	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Endress + Hauser	0x000011	PROWIRL 73	0x0057	3	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	4	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	5	1
Endress + Hauser	0x000011	PROWIRL 73	0x0057	6	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	1	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	2	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	3	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	4	1
Endress + Hauser	0x000011	PROSONIC FLOW 90	0x0058	5	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	1	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	2	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	3	2
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	4	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	5	1
Endress + Hauser	0x000011	PROSONIC FLOW 93	0x0059	6	1
Endress + Hauser	0x000011	PROSON_F92	0x0061	1	1
Endress + Hauser	0x000011	PROSON_F91	0x0062	1	1
Endress + Hauser	0x000011	PROSON_F91	0x0062	2	1
Endress + Hauser	0x000011	AT70	0x0064	2	2
Endress + Hauser	0x000011	AT70	0x0064	3	1
Endress + Hauser	0x000011	AT70	0x0064	4	1
Endress + Hauser	0x000011	T-MASS65	0x0065	1	1
Endress + Hauser	0x000011	TMD832	0x0078	1	1
Endress + Hauser	0x000011	TMD832	0x0078	2	1
Endress + Hauser	0x000011	TMD833	0x0079	1	1
Endress + Hauser	0x000011	TMD842	0x007C	1	1
Endress + Hauser	0x000011	MyPro pH	0x008C	1	2
Endress + Hauser	0x000011	MyPro pH	0x008C	2	1
Endress + Hauser	0x000011	MyPro LFC	0x008D	1	2
Endress + Hauser	0x000011	MyPro LFC	0x008D	2	1
Endress + Hauser	0x000011	MyPro LFI	0x008E	2	1
Endress + Hauser	0x000011	CPM2x3	0x0091	1	5
Endress + Hauser	0x000011	CLi2x3	0x0092	1	3
Endress + Hauser	0x000011	CLC2x3	0x0093	1	3
Endress + Hauser	0x000011	COM2x3	0x0094	1	4
Endress + Hauser	0x000011	CUM2x3	0x0095	1	4
Endress + Hauser	0x000011	CCM2x3	0x0096	1	3
Endress + Hauser	0x000011	CLD132	0x0097	1	1
Endress + Hauser	0x000011	Mycom LFC	0x0099	1	1
Endress + Hauser	0x000011	NMT530	0x00B5	4	1
Endress + Hauser	0x000011	NMS530	0x00B6	2	1
Endress + Hauser	0x000011	TMT182	0x00C8	1	2
Endress + Hauser	0x000011	TMT182	0x00C8	2	1
Endress + Hauser	0x000011	TMT122	0x00C9	2	1
Endress + Hauser	0x000011	TMT122	0x00C9	2	2
Endress + Hauser	0x000011	TMT162	0x00CA	1	1
Endress + Hauser	0x000011	TMT162	0x00CA	2	1
Endress + Hauser	0x000011	TMT162	0x00CA	2	2
Endress + Hauser	0x000011	TMT142	0x00CB	2	2
Fieldbus International	0x0000A0	PIR 2000	0x0002	1	1
Fieldbus International	0x0000A0	OXI5000	0x00ED	1	1
Flowserve	0x000030	Logix 12xx	0x0001	1	4
Flowserve	0x000030	Logix 12xx	0x0001	1	5
Flowserve	0x000030	Logix 12xx	0x0001	2	5
Flowserve	0x000030	Logix 12xx	0x0001	2	6
Flowserve	0x000030	Logix 12xx	0x0001	3	1
Flowserve	0x000030	Logix 12xx	0x0001	3	2
Flowserve	0x000030	Logix 12xx	0x0001	3	3
Flowserve	0x000030	Kammer C2100	0x0002	1	1
Flowserve	0x000030	Logix 520	0x0003	1	1
Flowserve	0x000030	Logix 520	0x0003	1	2
Flowserve	0x000030	Logix 520	0x0003	2	1
Flowserve	0x000030	Logix 520	0x0003	2	2
Flowserve	0x000030	Logix3200-IQ	0x0004	1	2
Flowserve	0x000030	Logix3200-IQ	0x0004	2	1
Flowserve	0x000030	Logix3200-IQ	0x0004	2	2

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Fluid Componets Intl	0x0000A6	ST98	0x0078	1	2
Foxboro	0x000014	MAG2	0x0001	2	2
Foxboro	0x000014	IASPT Premium 2	0x0002	1	1
Foxboro	0x000014	RTT30	0x0007	2	1
Foxboro	0x000014	IMV31	0x001D	2	1
Foxboro	0x000014	Vortex 84	0x001E	1	3
Foxboro	0x000014	IMT96	0x0028	1	1
Foxboro	0x000014	IMT25	0x0029	1	2
Foxboro	0x000014	I/A Pressure	0x002E	1	2
Foxboro	0x000014	I/A Pressure	0x002E	1	3
Foxboro	0x000014	I/A Pressure	0x002E	1	4
Foxboro	0x000014	I/A Pressure	0x002E	2	1
Foxboro	0x000014	I/A Pressure	0x002E	2	2
Foxboro	0x000014	I/A Pressure	0x002E	3	2
Foxboro	0x000014	IMV 25/30	0x002F	1	1
Foxboro	0x000014	IMV 25/30	0x002F	2	1
Foxboro	0x000014	IMV 25/30	0x002F	2	2
Foxboro	0x000014	875PH	0x0030	2	1
Foxboro	0x000014	875PH	0x0030	2	2
Foxboro	0x000014	875PH	0x0030	2	3
Foxboro	0x000014	875PH	0x0030	3	1
Foxboro	0x000014	ITVORTEX	0x0033	1	2
Foxboro	0x000014	ITVORTEX	0x0033	1	3
Foxboro	0x000014	CFT50	0x0034	2	1
Foxboro	0x000014	875CR	0x0035	2	2
Foxboro	0x000014	875CR	0x0035	2	3
Foxboro	0x000014	875CR	0x0035	2	4
Foxboro	0x000014	875CR	0x0035	3	1
Foxboro	0x000014	875EC	0x0036	2	2
Foxboro	0x000014	875EC	0x0036	2	3
Foxboro	0x000014	875EC	0x0036	3	1
Foxboro	0x000014	RTT15	0x0038	1	1
Foxboro	0x000014	RTT15	0x0038	1	2
Foxboro	0x000014	CFT 30 x	0x007D	3	1
Foxboro Eckardt	0x00003F	TSV175	0x0001	1	1
Foxboro Eckardt	0x00003F	DMU130	0x0002	1	2
Foxboro Eckardt	0x00003F	TI/RTT20	0x0003	1	2
Foxboro Eckardt	0x00003F	SRD991	0x0004	1	2
Foxboro Eckardt	0x00003F	DMU140	0x0005	1	2
Foxboro Eckardt	0x00003F	SRD960	0x0006	1	1
Fuji	0x000015	FCX-A/C	0x0001	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	1	1
Fuji	0x000015	FCX-A2/C2	0x0002	2	2
Fuji	0x000015	FCX-A2/C2	0x0002	2	3
Fuji	0x000015	FCX-A2/C2	0x0002	3	1
Fuji	0x000015	FRC	0x0081	1	1
Hengesbach	0x0000C2	TE 52	0x0021	2	1
Honeywell	0x000017	ST3000	0x0001	1	2
Honeywell	0x000017	ST3000	0x0001	2	1
Honeywell	0x000017	ST3000	0x0001	4	1
Honeywell	0x000017	ST3000	0x0001	4	2
Honeywell	0x000017	ST3000	0x0001	5	1
Honeywell	0x000017	STT25T	0x0002	1	1
Honeywell	0x000017	HWFLOW/Mage W Plus	0x0003	1	1
Honeywell	0x000017	STT25H	0x0004	1	5
Honeywell	0x000017	STT25H	0x0004	2	6
Honeywell	0x000017	STT25H	0x0004	2	7
Honeywell	0x000017	HERCULINE	0x0005	1	2
Honeywell	0x000017	HERCULINE	0x0005	1	3
Honeywell	0x000017	HERCULINE	0x0005	3	1
Honeywell	0x000017	SmartCET	0x0006	1	1
Honeywell	0x000017	STT17H	0x0007	1	1
Honeywell	0x000017	STT25S	0x0009	1	1
Honeywell	0x000017	TWM9000	0x0050	2	2
Huakong	0x000085	HK TT01	0x007F	5	1
INOR	0x00005B	MESO	0x00EF	1	4

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
InterCorr	0x0000A2	SMARTCET 18C	0x00EF	1	1
Invensys	0x0000A9	IA PRESSURE	0x002E	1	2
ISE-Magtech	0x00008C	LTM-100	0x0088	1	1
ISE-Magtech	0x00008C	LTM-300	0x0089	2	1
ISE-Magtech	0x00008C	LTM-300	0x0089	3	1
J Tec	0x0000AD	SERIES_0	0x0000	1	1
KAMSTRUP	0x000060	FLEXBAR 3501	0x00ED	1	3
KAMSTRUP	0x000060	FLEXBAR HRT	0x00EE	1	4
KAMSTRUP	0x000060	FLEXTOP HRT	0x00EF	1	1
KAMSTRUP	0x000060	FLEXTOP HRT	0x00EF	2	1
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	1	3
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	2	3
Kay Ray/Sensall	0x000019	3680 Dens	0x0009	2	4
Kay Ray/Sensall	0x000019	4790	0x000A	1	1
Kay Ray/Sensall	0x000019	4790	0x000A	2	2
Kay Ray/Sensall	0x000019	Accu-Pulse PRO	0x000B	1	1
Klay Instruments	0x000075	Klay 2000 Pressure/Level	0x00EF	1	1
Knick	0x000061	2211 CondI	0x00E8	1	1
Knick	0x000061	2211 CondI	0x00E8	2	1
Knick	0x000061	2211 Oxy	0x00E9	1	1
Knick	0x000061	2211 Cond	0x00EA	1	1
Knick	0x000061	2211 Cond	0x00EA	2	1
Knick	0x000061	2211 pH	0x00EB	1	1
Knick	0x000061	2211 pH	0x00EB	2	1
Kongsberg Maritime	0x0000C0	GT400	0x00EF	1	1
KPM	0x0000C5	KC/3	0x0080	1	1
KPM	0x0000C5	KC/5	0x0081	1	1
Krohne	0x000045	IFC 100	0x00D9	2	1
Krohne	0x000045	TT50C/R	0x00DB	1	4
Krohne	0x000045	MFC 300	0x00DD	2	1
Krohne	0x000045	ESK2A	0x00E2	1	1
Krohne	0x000045	IFC 300	0x00E3	1	2
Krohne	0x000045	IFC 300	0x00E3	2	1
Krohne	0x000045	Optiwave 7300C	0x00E5	1	2
Krohne	0x000045	M8E	0x00E6	1	1
Krohne	0x000045	UFC030	0x00E7	2	1
Krohne	0x000045	UFC030	0x00E7	2	2
Krohne	0x000045	MFC05x	0x00E8	1	1
Krohne	0x000045	IFC040	0x00E9	2	1
Krohne	0x000045	M10	0x00EA	2	1
Krohne	0x000045	BM102	0x00EC	1	1
Krohne	0x000045	VFM31	0x00ED	1	2
Krohne	0x000045	BM100	0x00EE	1	4
Krohne	0x000045	BM100	0x00EE	1	5
Krohne	0x000045	ESKII	0x00F2	1	1
Krohne	0x000045	IFC110	0x00F3	1	2
Krohne	0x000045	IFC110	0x00F3	2	1
Krohne	0x000045	IFC090	0x00F4	1	2
Krohne	0x000045	IFC090	0x00F4	2	1
Krohne	0x000045	UFC500	0x00F5	1	2
Krohne	0x000045	MFC08x	0x00F7	2	3
Krohne	0x000045	MFC08x	0x00F7	3	1
Krohne	0x000045	IFC080	0x00F8	1	1
Krohne	0x000045	IFC080	0x00F8	2	3
Krohne	0x000045	BM70	0x00F9	1	1
Krohne	0x000045	BM70	0x00F9	11	2
LABOM	0x00007F	PASCAL CI	0x003C	1	2
LABOM	0x00007F	IPX	0x00E0	1	2
Lanlian Instruments	0x0000C3	LSIII Pressure	0x0074	1	1
Magnetrik	0x000056	Model 705 3.x	0x00E5	1	1
Magnetrik	0x000056	Model 705 3.x	0x00E5	1	2
Magnetrik	0x000056	Model RX5	0x00E6	2	1
Magnetrik	0x000056	Model RX5	0x00E6	4	1
Magnetrik	0x000056	Model 704	0x00E7	1	1
Magnetrik	0x000056	Jupiter	0x00E8	2	1
Magnetrik	0x000056	Jupiter	0x00E8	3	2

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Magnetrik	0x000056	Model TA2	0x00E9	1	2
Magnetrik	0x000056	Model TA2	0x00E9	2	1
Magnetrik	0x000056	Model 707	0x00EA	2	1
Magnetrik	0x000056	Model 707	0x00EA	3	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	1	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	2	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	3	1
Magnetrik	0x000056	Model 705 2.x	0x00EB	4	1
Magnetrik	0x000056	Model 708	0x00EC	1	1
Magnetrik	0x000056	Model 708	0x00EC	2	1
Magnetrik	0x000056	Model 708	0x00EC	3	1
Magnetrik	0x000056	Model 708	0x00EC	4	1
Magnetrik	0x000056	Model 805	0x00ED	1	2
Magnetrik	0x000056	Model 705	0x00EE	1	2
Magnetrik	0x000056	Model 705	0x00EE	3	1
Magnetrik	0x000056	Model 705	0x00EE	4	1
Magnetrik	0x000056	SMARTEZ	0x00EF	1	2
Magnetrik	0x000056	SMARTEZ	0x00EF	2	1
Masoneilan-Dresser	0x000065	HDLT	0x0064	1	2
Masoneilan-Dresser	0x000065	SVI	0x00C8	2	2
Masoneilan-Dresser	0x000065	SVI2	0x00C9	2	1
Masoneilan-Dresser	0x000065	SVI2	0x00C9	2	2
Masoneilan-Dresser	0x000065	SVI II AP	0x00CA	1	2
Meggitt Mobrey	0x00003B	4301	0x0013	3	3
Meggitt Mobrey	0x00003B	4301	0x0013	3	4
Meggitt Mobrey	0x00003B	MSP100	0x0015	2	2
Meggitt Mobrey	0x00003B	MSP100	0x0015	2	3
Meggitt Mobrey	0x00003B	GWR3300	0x0021	2	1
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	1
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	2
Meggitt Mobrey	0x00003B	MLT100	0x0029	1	3
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	3	1
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	4	1
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	5	5
Meggitt Mobrey	0x00003B	MSP900/400	0x002E	5	6
Meggitt Mobrey	0x00003B	MRL700	0x002F	1	1
Meggitt Mobrey	0x00003B	MRL700	0x002F	1	2
Metso Automation	0x00002F	PSMART	0x0001	2	1
Metso Automation	0x00002F	SMARTPULP	0x003C	2	2
Metso Automation	0x00002F	SMARTPULP	0x003C	3	1
Metso Automation	0x00002F	SMARTLX	0x003D	3	1
Metso Automation	0x00002F	MCAi	0x003E	1	1
Metso Automation	0x00002F	SMARTLC	0x003F	1	1
Metso Automation	0x00002F	MCA	0x0040	1	2
Metso Automation	0x000057	ND9100HT	0x00E4	1	1
Metso Automation	0x000057	ND9100HT	0x00E4	2	1
Metso Automation	0x000057	ND9100HT	0x00E4	2	2
Metso Automation	0x000057	ND9100H	0x00E5	1	1
Metso Automation	0x000057	ND9100H	0x00E5	2	1
Metso Automation	0x000057	ND9100H	0x00E5	2	2
Metso Automation	0x000057	ND9100H	0x00E5	3	2
Metso Automation	0x000057	ValvGuard	0x00EB	2	1
Metso Automation	0x000057	ValvGuard	0x00EB	6	1
Metso Automation	0x000057	ND820/T	0x00EE	1	3
Metso Automation	0x000057	ND820/T	0x00EE	2	3
Metso Automation	0x000057	ND820/T	0x00EE	3	3
Metso Automation	0x000057	ND820/T	0x00EE	4	2
Metso Automation	0x000057	ND820/T	0x00EE	5	1
Metso Automation	0x000057	ND820/T	0x00EE	6	1
Metso Automation	0x000057	ND820/T	0x00EE	7	1
Metso Automation	0x000057	ND820	0x00EF	1	3
Metso Automation	0x000057	ND820	0x00EF	2	3
Metso Automation	0x000057	ND820	0x00EF	3	3
Metso Automation	0x000057	ND820	0x00EF	4	2
Metso Automation	0x000057	ND820	0x00EF	5	1
Metso Automation	0x000057	ND820	0x00EF	6	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Metso Automation	0x000057	ND820	0x00EF	7	1
Mettler Toledo	0x00008E	CondI7100	0x0078	1	1
Mettler Toledo	0x00008E	CondI7100	0x0078	2	1
Mettler Toledo	0x00008E	O2 4100e	0x0079	1	1
Mettler Toledo	0x00008E	Cond7100	0x007A	1	1
Mettler Toledo	0x00008E	Cond7100	0x007A	2	1
Mettler Toledo	0x00008E	pH 2100	0x007B	1	1
Mettler Toledo	0x00008E	pH 2100	0x007B	2	1
Micro Motion	0x00001F	9712 Mass flo	0x0007	2	6
Micro Motion	0x00001F	9739 Mass flo	0x0015	1	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	2	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	3	5
Micro Motion	0x00001F	9739 Mass flo	0x0015	4	1
Micro Motion	0x00001F	9739 Mass flo	0x0015	4	2
Micro Motion	0x00001F	9701	0x001E	1	3
Micro Motion	0x00001F	9701	0x001E	1	4
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	3	1
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	3	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	4	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	5	2
Micro Motion	0x00001F	MVD Series 2000 Config I/O	0x0024	5	4
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	4	1
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	5	2
Micro Motion	0x00001F	MVD Series 1000 Config I/O	0x0025	5	4
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	2	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	2	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	3	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	3	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	4	1
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	5	2
Micro Motion	0x00001F	MVD Series 2000 IS Output	0x0026	5	4
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	2	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	3	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	3	2
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	4	1
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	5	2
Micro Motion	0x00001F	MVD Series 1000 IS Output	0x0027	5	4
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	2	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	3	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	3	2
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	4	1
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	5	2
Micro Motion	0x00001F	MVD Series 1000 Analog Output	0x0029	5	4
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	1	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	2	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	2	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	3	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	3	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	4	1
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	5	2
Micro Motion	0x00001F	MVD Series 2000 Analog Output	0x002A	5	4
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	1
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	2
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	3
Micro Motion	0x00001F	2400S Mass flo	0x0034	1	4
Micro Motion	0x00001F	2400S Mass flo	0x0034	2	2
Micro Motion	0x00001F	2400S Mass flo	0x0034	2	3
Micro Motion	0x00001F	2400S Mass flo	0x0034	3	1
Micro Motion	0x00001F	2200S Analog	0x003A	1	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	6	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	6	2
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	1
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	3
Micro Motion	0x00001F	MVD Series 3000	0x0041	7	4
Milltronics	0x000058	86x PROBE	0x00C8	1	2
Milltronics	0x000058	SITRANS LR300	0x00C9	1	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Milltronics	0x000058	LR 200	0x00CA	1	1
Milltronics	0x000058	LR 200	0x00CA	2	2
Milltronics	0x000058	SITRANS LR400	0x00CC	1	1
Milltronics	0x000058	Sitrans Probe LU 6m	0x00CD	1	1
Milltronics	0x000058	Sitrans Probe LU 12m	0x00CE	1	1
Milltronics	0x000058	Probe LR	0x00CF	2	2
Moore Industries	0x000020	TRZ	0x0001	1	1
Moore Industries	0x000020	TRZ	0x0001	2	1
Moore Industries	0x000020	TRZ	0x0001	3	1
Moore Industries	0x000020	THZ	0x0003	1	1
Moore Industries	0x000020	THZ2	0x0004	1	1
Moore Industries	0x000020	HTZ	0x0005	1	1
Moore Industries	0x000020	TCM	0x0006	1	1
Moore Industries	0x000020	Unknown Device (0x2007)	0x0007	1	1
M-System Co.	0x00001D	B6U	0x0001	1	1
M-System Co.	0x00001D	B3HU	0x0002	1	1
M-System Co.	0x00001D	27HU	0x0003	1	1
MTS Systems Corp.	0x000063	M-Series	0x00ED	0	1
Ohmart	0x000067	DSTH/LSTH	0x00E0	1	4
Ohmart	0x000067	DSTH/LSTH Comp	0x00E1	1	1
Open Field Communications	0x0000DD	Unknown Device (0xdd00)	0x0000	1	1
Open Field Communications	0x0000DD	FMU4x Envelope	0x0001	1	1
Open Field Communications	0x0000DD	FMR2xx Envelope	0x0002	1	1
Open Field Communications	0x0000DD	FMP4x Envelope	0x0003	1	1
Oval	0x000064	ULTRA OVAL	0x0064	2	1
Oval	0x000064	ExDelta	0x0065	1	1
Oval	0x000064	9401 Mass flo	0x006E	2	1
Oval	0x000064	9801 Mass flo	0x006F	2	1
Oval	0x000064	9201 Mass flo	0x0070	2	1
Oval	0x000064	9431 Mass flo	0x007B	2	1
Panametrics	0x00009D	x868	0x0070	1	1
Paper Machine Components	0x00007E	SMT-EL	0x00E0	1	1
Peek Measurment	0x000027	900 Densitometer	0x0000	0	1
Peek Measurment	0x000027	900 Densitometer	0x0000	1	1
PEPPERL+FUCHS	0x00005D	Barcon	0x000E	1	1
PEPPERL+FUCHS	0x00005D	Unknown Device (0x5d11)	0x0011	2	2
PEPPERL+FUCHS	0x00005D	Pulscon	0x0012	2	1
Phoenix Contact	0x0000B0	MCR-TS-LP	0x0001	2	2
Phoenix Contact	0x0000B0	MCR-HT-TS	0x0002	2	2
PMV	0x00009B	D3	0x00D3	1	2
PMV	0x00009B	D3	0x00D3	1	3
PR Electronics	0x00006D	T55	0x00DF	1	1
PR Electronics	0x00006D	PRetrans 6335	0x00EE	1	1
PR Electronics	0x00006D	Pretop 5335	0x00EF	1	1
Pyromation Inc	0x0000B5	Series442	0x007F	2	1
Pyromation Inc	0x0000B5	Series642	0x0080	2	2
Pyromation Inc	0x0000B5	Series642	0x0080	2	3
ROBERTSHAW	0x00005C	Excalibur 7000	0x00C8	1	2
Rosemount	0x000026	3044 Temp	0x0002	3	3
Rosemount	0x000026	1151s	0x0003	1	1
Rosemount	0x000026	1151s	0x0003	2	1
Rosemount	0x000026	1151s	0x0003	3	1
Rosemount	0x000026	1151s	0x0003	4	2
Rosemount	0x000026	1151s	0x0003	5	4
Rosemount	0x000026	1151s	0x0003	6	1
Rosemount	0x000026	Magmeter	0x0004	3	3
Rosemount	0x000026	Magmeter	0x0004	4	3
Rosemount	0x000026	Magmeter	0x0004	5	3
Rosemount	0x000026	Magmeter	0x0004	6	1
Rosemount	0x000026	Magmeter	0x0004	7	5
Rosemount	0x000026	Magmeter	0x0004	7	6
Rosemount	0x000026	Magmeter	0x0004	8	3
Rosemount	0x000026	Magmeter	0x0004	9	3
Rosemount	0x000026	Magmeter	0x0004	10	1
Rosemount	0x000026	3051C	0x0006	1	2
Rosemount	0x000026	3051C	0x0006	2	6

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Rosemount	0x000026	3051C	0x0006	3	2
Rosemount	0x000026	3051C	0x0006	3	6
Rosemount	0x000026	3051C	0x0006	6	3
Rosemount	0x000026	3051C	0x0006	6	4
Rosemount	0x000026	3051C	0x0006	7	5
Rosemount	0x000026	3051C	0x0006	7	7
Rosemount	0x000026	Mag HS	0x000C	1	5
Rosemount	0x000026	Mag HS	0x000C	1	6
Rosemount	0x000026	3044C Temp	0x000D	1	3
Rosemount	0x000026	3044C Temp	0x000D	2	3
Rosemount	0x000026	3001C HTG	0x000E	1	2
Rosemount	0x000026	3001C HTG	0x000E	2	1
Rosemount	0x000026	3001C HTG	0x000E	3	1
Rosemount	0x000026	3051C LP	0x000F	1	1
Rosemount	0x000026	Vortex	0x0010	1	3
Rosemount	0x000026	Vortex	0x0010	2	1
Rosemount	0x000026	Vortex	0x0010	3	1
Rosemount	0x000026	3201 SAM	0x0011	1	2
Rosemount	0x000026	3201 SAM	0x0011	1	3
Rosemount	0x000026	3202 SAM	0x0013	1	3
Rosemount	0x000026	3001S HTG	0x0014	2	1
Rosemount	0x000026	3095MV	0x0016	1	8
Rosemount	0x000026	3095MV	0x0016	2	2
Rosemount	0x000026	3095MV	0x0016	2	3
Rosemount	0x000026	644 Temp	0x0018	3	1
Rosemount	0x000026	644 Temp	0x0018	4	1
Rosemount	0x000026	644 Temp	0x0018	5	4
Rosemount	0x000026	644 Temp	0x0018	6	2
Rosemount	0x000026	644 Temp	0x0018	7	1
Rosemount	0x000026	3144 Temp	0x0019	1	8
Rosemount	0x000026	3144 Temp	0x0019	2	1
Rosemount	0x000026	3144 Temp	0x0019	3	2
Rosemount	0x000026	3144 Temp	0x0019	3	3
Rosemount	0x000026	3144 Temp	0x0019	3	7
Rosemount	0x000026	3144 Temp	0x0019	4	1
Rosemount	0x000026	3244 Temp	0x001A	1	8
Rosemount	0x000026	3244 Temp	0x001A	2	1
Rosemount	0x000026	3750	0x001C	1	2
Rosemount	0x000026	3750	0x001C	2	2
Rosemount	0x000026	Tri-Loop	0x001D	1	2
Rosemount	0x000026	3095C	0x001E	5	3
Rosemount	0x000026	3300	0x0021	1	1
Rosemount	0x000026	3300	0x0021	2	1
Rosemount	0x000026	3300	0x0021	3	2
Rosemount	0x000026	2088 Smart	0x0023	3	2
Rosemount	0x000026	ProBar	0x0024	2	2
Rosemount	0x000026	ProBar	0x0024	3	1
Rosemount	0x000026	ProBar	0x0024	4	1
Rosemount	0x000026	2090 Smart	0x0027	3	1
Rosemount	0x000026	ProBar UC	0x0028	3	1
Rosemount	0x000026	ProBar UC	0x0028	4	1
Rosemount	0x000026	ProPlate UC	0x002F	3	1
Rosemount	0x000026	1810	0x0036	3	1
Rosemount	0x000026	8712D	0x0037	1	2
Rosemount	0x000026	8712D	0x0037	2	1
Rosemount	0x000026	4600	0x0038	1	2
Rosemount	0x000026	8800D	0x003A	1	1
Rosemount	0x000026	8800D	0x003A	1	2
Rosemount	0x000026	8800D	0x003A	2	1
Rosemount	0x000026	248 Temperature	0x003B	1	1
Rosemount	0x000026	248 Temperature	0x003B	2	1
Rosemount	0x000026	8732D	0x003C	1	1
Rosemount	0x000026	8732D	0x003C	2	1
Rosemount	0x000026	8732D	0x003C	3	1
Rosemount	0x000026	2088LP	0x0040	1	1
Rosemount	0x000026	951	0x0042	6	3

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Rosemount	0x000026	951	0x0042	7	5
Rosemount	0x000026	5400	0x0043	1	1
Rosemount	0x000026	3051S SIS	0x0044	1	1
Rosemount	0x000026	3051S SIS	0x0044	1	2
Rosemount	0x000026	3144P SIS	0x0045	1	1
Rosemount	0x000026	3144P SIS	0x0045	2	1
Rosemount	0x000026	4500	0x0047	7	1
Rosemount	0x000026	3051S Diag	0x004A	1	2
Rosemount	0x000026	3051S Diag	0x004A	2	1
Rosemount	0x000026	3100	0x0050	5	5
Rosemount	0x000026	3100	0x0050	5	6
Rosemount	0x000026	2051	0x0055	3	1
Rosemount	0x000026	8712E	0x0057	1	1
Rosemount	0x000026	8712E	0x0057	3	1
Rosemount	0x000026	8712E	0x0057	3	2
Rosemount	0x000026	Metran-150	0x0062	3	1
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	3	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	3	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	4	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	4	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	5	4
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	5	5
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	6	2
Rosemount	0x000026	UNIVERSAL_XMTR	0x0080	7	2
Rosemount Analytic	0x00002E	2081 pH	0x0006	1	1
Rosemount Analytic	0x00002E	2081 Cond	0x0007	1	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	1	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	2	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	3	1
Rosemount Analytic	0x00002E	Oxymitter 4000	0x000C	4	1
Rosemount Analytic	0x00002E	WC_3000	0x000D	1	1
Rosemount Analytic	0x00002E	3081FG	0x000E	1	1
Rosemount Analytic	0x00002E	OPM-2000R	0x000F	1	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	1	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	2	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	3	1
Rosemount Analytic	0x00002E	OCX-4000	0x0010	4	1
Rosemount Analytic	0x00002E	3081pH	0x0014	1	1
Rosemount Analytic	0x00002E	3081pH	0x0014	1	2
Rosemount Analytic	0x00002E	3081C	0x0015	1	1
Rosemount Analytic	0x00002E	3081-81con	0x0016	1	1
Rosemount Analytic	0x00002E	3081-81con	0x0016	2	1
Rosemount Analytic	0x00002E	3081-81T	0x0017	1	1
Rosemount Analytic	0x00002E	5081A	0x0018	1	1
Rosemount Analytic	0x00002E	5081A	0x0018	2	1
Rosemount Analytic	0x00002E	5081C/T	0x0019	1	1
Rosemount Analytic	0x00002E	5081pH	0x001A	1	1
Rosemount Analytic	0x00002E	5081pH	0x001A	2	1
Rosemount Analytic	0x00002E	Xmt A	0x001B	1	1
Rosemount Analytic	0x00002E	Xmt C/T	0x001C	1	1
Rosemount Analytic	0x00002E	Xmt pH	0x001D	1	1
Rosemount Analytic	0x00002E	5081FG	0x001E	1	1
Rosemount Analytic	0x00002E	XS-O2	0x002B	1	1
Rosemount Analytic	0x00002E	54pH/ORP	0x0050	1	2
Rosemount Analytic	0x00002E	54eC	0x0051	1	2
Rosemount Analytic	0x00002E	54eC	0x0051	2	1
Rosemount Analytic	0x00002E	52epH/ORP	0x0052	1	1
Rosemount Analytic	0x00002E	52epH/ORP	0x0052	2	1
Rosemount Analytic	0x00002E	54eA	0x0053	1	1
Rosemount Analytic	0x00002E	54eA	0x0053	2	1
Rueger	0x00008D	S95 HRT	0x0001	1	1
Rueger	0x00008D	S95.3U_2	0x007F	1	1
Saab Tank Control	0x00004F	5600	0x00ED	6	1
Saab Tank Control	0x00004F	5600	0x00ED	7	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	2	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	3	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	5	1
Saab Tank Control	0x00004F	TankRadarPro	0x00EF	6	1
Samson	0x000042	373X-3	0x00EF	2	1
Samson	0x000042	373X-3	0x00EF	4	2
Samson	0x000042	3780	0x00F9	1	1
Samson	0x000042	3780	0x00F9	2	1
Schlumberger	0x000028	NEXGEN	0x0001	1	1
Schlumberger	0x000028	NEXGEN	0x0001	1	2
Siemens	0x00002A	SITRANS FUS	0x0004	1	1
Siemens	0x00002A	SITRANS LR	0x0007	1	1
Siemens	0x00002A	SITRANS P HS	0x000A	1	1
Siemens	0x00002A	SITRANS P DS	0x000B	1	2
Siemens	0x00002A	SITRANS P DS	0x000B	2	1
Siemens	0x00002A	SITRANS P DS	0x000B	3	1
Siemens	0x00002A	SITRANS P DS	0x000B	3	2
Siemens	0x00002A	SITRANS P ES	0x000C	1	1
Siemens	0x00002A	SITRANS P MS	0x000D	1	1
Siemens	0x00002A	SITRANS TW	0x0010	1	1
Siemens	0x00002A	SITRANS TK H	0x0012	1	1
Siemens	0x00002A	SITRANS TK H	0x0012	2	1
Siemens	0x00002A	SITRANS TH300	0x0013	1	1
Siemens	0x00002A	SITRANS TH300	0x0013	1	2
Siemens	0x00002A	SIPART PS2	0x0015	1	1
Siemens	0x00002A	SIPART PS2	0x0015	2	1
Siemens	0x00002A	SIPART PS2	0x0015	3	1
Siemens	0x00002A	SIPART PS2	0x0015	3	2
Siemens	0x00002A	SITRANS FM	0x0016	1	1
Siemens	0x00002A	SITRANS FM MAGFLO	0x0018	1	1
Siemens	0x00002A	SITRANS FM MAGFLO	0x0018	2	1
Siemens	0x00002A	SITRANS FC MASSFLO	0x0019	2	1
Siemens	0x00002A	SITRANS FM IT2 / TM2	0x001A	1	1
Siemens	0x00002A	SITRANS P300	0x001D	1	1
Siemens	0x00002A	SITRANS P300	0x001D	2	1
Siemens	0x00002A	SITRANS P300	0x001D	3	1
Siemens	0x00002A	SITRANS P300	0x001D	3	2
Siemens	0x00002A	SITRANS TR300	0x001F	1	1
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	0	1
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	0	2
Siemens Milltronics PI	0x000054	MSP2002	0x00F8	1	1
Siemens Milltronics PI	0x000054	MST9500	0x00F9	0	1
Siemens Milltronics PI	0x000054	MST9500	0x00F9	1	2
Siemens Milltronics PI	0x000054	MST9500	0x00F9	2	3
Siemens Milltronics PI	0x000054	MST9500	0x00F9	3	4
Smar	0x00003E	LD301	0x0001	3	5
Smar	0x00003E	LD301	0x0001	3	6
Smar	0x00003E	LD301	0x0001	4	2
Smar	0x00003E	TT301	0x0002	2	2
Smar	0x00003E	TT301	0x0002	3	1
Smar	0x00003E	FY301	0x0003	1	2
Smar	0x00003E	FY301	0x0003	2	1
Smar	0x00003E	LD291	0x0004	3	1
Smar	0x00003E	LD291	0x0004	4	1
Smar	0x00003E	TP301	0x0005	1	1
Smar	0x00003E	DT301	0x0006	3	2
Smar	0x00003E	LD400	0x000A	1	1
SMC	0x000083	IP8101	0x007E	1	1
SMC	0x000083	F793-E701	0x00EF	1	2
Sparling Instruments	0x000043	FM6XX	0x00EE	1	1
Status Instruments	0x000084	SEM 300	0x00EF	0	0
Status Instruments	0x000084	SEM 300	0x00EF	1	1
TN Technologies	0x000090	NDMi	0x007D	1	3
TN Technologies	0x000090	Accu-Wave	0x007E	1	4
TN Technologies	0x000090	NCMi	0x007F	2	2
TN Technologies	0x000090	NCMi	0x007F	3	1
Toshiba	0x00002C	AP3100	0x0002	4	2
Toshiba	0x00002C	LF220	0x000A	5	3

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Toshiba	0x00002C	LF220	0x000A	6	1
Toshiba	0x00002C	LF220	0x000A	8	1
Toshiba	0x00002C	LF220	0x000A	8	2
Turbo	0x000081	Intermag-Transmag	0x007F	2	3
Turbo	0x000081	Intermag-Transmag	0x007F	3	4
Turck	0x00009C	KMU-HLI	0x0001	1	1
Tyco Valve Controls	0x0000AB	SmartCal	0x0001	1	1
Tyco Valve Controls	0x0000AB	Unknown Device (0xab02)	0x0002	1	1
Unknown Manufacturer (0xef)	0x0000EF	Unknown Device (0xef83)	0x0083	1	0
Unknown Manufacturer (0xef)	0x0000EF	Unknown Device (0xef83)	0x0083	1	1
Viatran	0x000032	970	0x0001	1	2
Viatran	0x000032	970	0x0001	2	3
Viatran	0x000032	I/A Pressure	0x002E	1	3
Vortek Instruments, LLC	0x000087	Innova-Mass	0x0001	5	1
Welltech Shanghai	0x000093	WT2000	0x007C	5	1
Westlock Controls	0x00004D	ICOT	0x0001	4	1
Westlock Controls	0x00004D	ICOT	0x0001	5	2
Westlock Controls	0x00004D	SmartCal	0x0002	5	2
Westlock Controls	0x00004D	D-EPIC	0x0003	1	1
Westlock Controls	0x00004D	D-EPIC ESD	0x0004	1	1
WIKA	0x00006B	UniTrans	0x00EE	5	1
WIKA	0x00006B	T32	0x00EF	0	2
WIKA	0x00006B	T32	0x00EF	1	1
WIKA	0x00006B	T32	0x00EF	2	1
Yamatake	0x000036	MagneW	0x0001	1	2
Yamatake	0x000036	ST3000	0x0002	1	2
Yamatake	0x000036	ST3000	0x0002	2	1
Yamatake	0x000036	SVP	0x0003	1	1
Yamatake	0x000036	SVP	0x0003	2	1
Yamatake	0x000036	ThermoPlus ATT	0x0004	1	2
Yamatake	0x000036	PTG	0x0005	1	1
Yamatake	0x000036	MagneW 2W	0x0008	1	1
Yamatake	0x000036	MagneW 2W	0x0008	2	1
Yamatake	0x000036	MagneW 2W	0x0008	2	2
Yamatake	0x000036	MAGNEW4W	0x000C	1	1
Yokogawa	0x000037	YEWFO	0x0001	1	4
Yokogawa	0x000037	YEWFO	0x0001	2	2
Yokogawa	0x000037	YT200	0x0002	1	1
Yokogawa	0x000037	UNICOM	0x0003	1	1
Yokogawa	0x000037	EJA	0x0004	1	2
Yokogawa	0x000037	EJA	0x0004	2	1
Yokogawa	0x000037	EJA	0x0004	3	1
Yokogawa	0x000037	ADMAG AE	0x0005	1	1
Yokogawa	0x000037	ADMAG AE	0x0005	2	1
Yokogawa	0x000037	AM11	0x0006	1	1
Yokogawa	0x000037	ADMAG SE	0x0008	1	1
Yokogawa	0x000037	ADMAG SE	0x0008	2	1
Yokogawa	0x000037	YTA	0x0009	1	2
Yokogawa	0x000037	YTA	0x0009	2	1
Yokogawa	0x000037	YTA	0x0009	3	1
Yokogawa	0x000037	YTA70E	0x000A	1	1
Yokogawa	0x000037	DYF	0x000B	1	1
Yokogawa	0x000037	DYF	0x000B	2	1
Yokogawa	0x000037	DYF	0x000B	3	1
Yokogawa	0x000037	DYF	0x000B	3	2
Yokogawa	0x000037	ZR202	0x000C	1	1
Yokogawa	0x000037	ZR402	0x000D	1	1
Yokogawa	0x000037	ISC202	0x0014	1	2
Yokogawa	0x000037	PH202	0x0015	1	3
Yokogawa	0x000037	SC202	0x0016	1	2
Yokogawa	0x000037	DO202	0x0018	1	1
Yokogawa	0x000037	PH150	0x0027	1	1
Yokogawa	0x000037	PH150	0x0027	2	1
Yokogawa	0x000037	SC150	0x0028	1	1
Yokogawa	0x000037	SC150	0x0028	2	1
Yokogawa	0x000037	PH450	0x002B	1	1

Device Xpert V1.6.2 - DD Library List

Status dated 2011.02.04

R05

DDs for Language:

en

Manufacturer Name	Manufacturer ID	Device Type/Model	Device ID	Dev Revision	DD Revision
Yokogawa	0x000037	PH450	0x002B	2	1
Yokogawa	0x000037	SC450	0x002C	1	1
Yokogawa	0x000037	SC450	0x002C	2	1
Yokogawa	0x000037	ISC450	0x002D	1	1
Yokogawa	0x000037	ISC450	0x002D	2	1
Yokogawa	0x000037	ROTAMASS	0x0040	1	2
Yokogawa	0x000037	RAMC	0x0041	1	2
Yokogawa	0x000037	RCCT_F3	0x0042	1	1
Yokogawa	0x000037	RCCT_F3	0x0042	1	3
Yokogawa	0x000037	RCCT_F3	0x0042	2	1
Yokogawa	0x000037	RCCT_F3	0x0042	3	1
Yokogawa	0x000037	AXFA11	0x0050	1	1
Yokogawa	0x000037	AXFA11	0x0050	1	2
Yokogawa	0x000037	EJX	0x0051	1	1
Yokogawa	0x000037	EJX	0x0051	1	2
Yokogawa	0x000037	AXFA14	0x0052	1	1