Safety Instructions **Liquiphant FTL51B**

4-20 mA HART

II 1 G Ex ia IIC T6...T1 Ga









Liquiphant FTL51B

4-20 mA HART

Table of contents

Associated documentation	4
Supplementary documentation	4
Manufacturer's certificates	4
Manufacturer address	4
Other standards	4
Extended order code	5
Safety instructions: General	7
Safety instructions: Special conditions	8
Safety instructions: Installation	9
Temperature tables	10
Connection data	11

XA03002F-A Liquiphant FTL51B

Associated documentation

This document is an integral part of the following Operating Instructions:

BA02213F

Supplementary documentation

Explosion protection brochure: CP00021Z

The Explosion-protection brochure is available:

 In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Brochures and Catalogs -> Text Search: CP000217.

• On the CD for devices with CD-based documentation

Manufacturer's certificates

UK Declaration of Conformity

Declaration Number: UK 00529

The UK Declaration of Conformity is available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Declaration -> Type: UKCA Declaration -> Product Code: ...

UKCA type-examination certificate

Certificate number: CML 22UKEX1611X

List of applied standards: See UK Declaration of Conformity.

Manufacturer address

Endress+Hauser SE+Co. KG Hauptstraße 1

79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

Other standards

Among other things, the following standards shall be observed in their current version for proper installation:

- IEC/EN 60079-14: "Explosive atmospheres Part 14: Electrical installations design, selection and erection"
- EN 1127-1: "Explosive atmospheres Explosion prevention and protection - Part 1: Basic concepts and methodology"

Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

Structure of the extended order code

FTL51B	-	********	+	A*B*C*D*E*F*G*
(Device		(Basic		(Optional
type)		specifications)		specifications)

* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Extended order code: Liquiphant



The following specifications reproduce an extract from the product structure and are used to assign:

- This documentation to the device (using the extended order code on the nameplate).
- The device options cited in the document.

Device type

FTL51B

XA03002F-A Liquiphant FTL51B

Basic specifications

Position 1, 2 (Approval)			
Selected option Descr		Description	
FTL51B UA		UK Ex II 1 G Ex ia IIC T6T1 Ga	

Position 3, 4 (Output)			
Selected option		Description	
FTL51B BA		FEL60H, 2-wire 420 mA HART+test button	

Position 5 (Display, Operation)			
Selected option Description		Description	
FTL51B	Α	W/o; switch	
	Е	Graphic display with touch control	
	F	Graphic display with touch control+Bluetooth	

Position 6 (Housing, Material)			
Selected option		Description	
FTL51B	В	Single compartment; Alu, coated	
	M	Dual compartment L-shape; Alu, coated	
	N	Dual compartment L-shape; 316L	

Optional specifications

ID Jx, Kx (Test, Certificate, Declaration)		
Selected option Description		Description
FTL51B	JL	Ambient temperature -50°C/-58°F
JN Ambient temperature -52°C/-62°F		

ID Mx (Sensor Design)			
Selected option		Description	
FTL51B	MR	Temperature separator	
	MS	Pressure tight feed through (Second line of defence)	

ID Nx, Ox (Accessory Mounted)			
Selected option		Description	
FTL51B	NA 1)	Overvoltage protection	

1) Only in connection with Position 6 = M, N

ID Px, Rx (Accessory Enclosed)			
Selected option		Description	
FTL51B	PA 1)	Weather protection cover, 316L	
	PB 2)	Weather protection cover, plastic	

- 1) Only in connection with Position 6 = M, N
- 2) Only in connection with Position 6 = B

Safety instructions: General

- The device is intended to be used in explosive atmospheres as defined in the scope of EN IEC 60079-0 or equivalent national standards. If no potentially explosive atmospheres are present or if additional protective measures have been taken: The device may be operated according to the manufacturer's specifications.
- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations
- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and national regulations.
- Do not operate the device outside the specified electrical, thermal and mechanical parameters.
- Only use the device in media to which the wetted materials have sufficient durability.
- Avoid electrostatic charging:
 - Of plastic surfaces (e.g. enclosure, sensor element, special varnishing, attached additional plates, ..)
 - Of isolated capacities (e.g. isolated metallic plates)
- Refer to the temperature tables for the relationship between the permitted ambient temperature for the sensor and/or transmitter, depending on the range of application and the temperature class.
- Alterations to the device can affect the explosion protection and must be carried out by staff authorized to perform such work by Endress+Hauser

XA03002F-A Liquiphant FTL51B

Safety instructions: Special conditions


Permitted ambient temperature range at the electronics enclosure: $-40\,^{\circ}\text{C} \le T_a \le +70\,^{\circ}\text{C}$

- Limitations of the maximum ambient temperature at the electronics enclosure may be required dependent on device configuration, process temperatures and temperature classification.
- Details of limitations: $\rightarrow \blacksquare 10$, "Temperature tables".
- To avoid electrostatic charging: Do not rub surfaces with a dry cloth.
- In the event of additional or alternative special varnishing on the enclosure or other metal parts or for adhesive plates:
 - Observe the danger of electrostatic charging and discharge.
 - Do not install in the vicinity of processes (≤ 0.5 m) generating strong electrostatic charges.
- Avoid sparks caused by impact and friction.

Optional specification, ID Px, Rx = PAConnect the weather protection cover to the local potential equalization.

Optional specification, ID Px, Rx = PBAvoid electrostatic charging of the weather protection cover (e.g. friction, cleaning, maintenance, strong medium flow).

Safety instructions: Installation



■ 1

- Α Zone 0
- 1 Tank: Zone 0
- 2 Electronic insert
- 3 Enclosure
- Associated intrinsically safe power supply units
- Potential equalization line 5
- Local potential equalization
- After aligning (rotating) the enclosure, retighten the fixing screw.
- Continuous service temperature of the connecting cable: $\geq T_a + 20 \text{ K}$.
- Observe the pertinent quidelines when interconnecting intrinsically safe circuits.
- Observe the maximum process conditions according to the manufacturer's Operating Instructions.
- At high medium temperatures, note flange pressure load capacity as a factor of temperature.
- Install the device to exclude any mechanical damage or friction during the application. Pay particular attention to flow conditions and tank fittings.
- Support extension tube of the device if a dynamic load is expected.
- Only use genuine spare parts from Endress+Hauser which are specified for the device.

Accessory: Sliding sleeve

The sliding sleeve can be used for a continuous setting of the switch point (see Operating Instructions).

XA03002F-A Liguiphant FTL51B

Intrinsic safety

- The device is only suitable for connection to certified, intrinsically safe equipment with explosion protection Ex ia.
- The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 500 V_{rms} .

Optional specification, ID Nx, Ox = NA

The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 290 V_{rms} .

Potential equalization

Integrate the device into the local potential equalization.

Optional specification, ID Px, Rx= PA

Connect the weather protection cover to the local potential equalization.

Temperature tables



- The specified ambient and process temperature ranges exclusively refer to the explosion protection and must not be exceeded. Operationally permitted ambient temperature ranges can be restricted depending on the version: See Operating Instructions.
- Do not exceed the max. ambient temperature at the enclosure.

Optional specification, ID Jx, Kx = JL

Lower limit of the ambient temperature for explosion protection changes to -50 °C.

Optional specification, ID Jx, Kx = JN

Lower limit of the ambient temperature for explosion protection changes to −52 °C.

Optional specification, ID Px, Rx = PB

When using the weather protection cover: Reduce the admissible ambient temperature by 10 K.

Basic specification, Position 5 = A

Temperature class	Process temperature range	Ambient temperature range
Т6	$-40 ^{\circ}\text{C} \le \text{T}_{\text{p}} \le +75 ^{\circ}\text{C}$ $-40 ^{\circ}\text{C} \le \text{T}_{\text{p}} \le +60 ^{\circ}\text{C}$	$-40 ^{\circ}\text{C} \le \text{T}_{\text{a}} \le +50 ^{\circ}\text{C}$ $-40 ^{\circ}\text{C} \le \text{T}_{\text{a}} \le +55 ^{\circ}\text{C}$
T5	-40 °C ≤ T _p ≤ +90 °C	-40 °C ≤ T _a ≤ +55 °C
T4T1	-40 °C ≤ T _p ≤ +120 °C	-40 °C ≤ T _a ≤ +50 °C

with Optional specification, ID Mx = MR, MS

Temperature class	Process temperature range	Ambient temperature range	
Т6	-40 °C ≤ T _p ≤ +75 °C	$-40 ^{\circ}\text{C} \le T_a \le +60 ^{\circ}\text{C}$	
T5	-40 °C ≤ T _p ≤ +90 °C	-40 °C ≤ T _a ≤ +65 °C	
T4	-40 °C ≤ T _p ≤ +125 °C	-40 °C ≤ T _a ≤ +65 °C	
T3T1	-40 °C ≤ T _p ≤ +150 °C	-40 °C ≤ T _a ≤ +65 °C	

Basic specification, Position 5 = E, F

Temperature class	Process temperature range	Ambient temperature range	
Т6	$-40 ^{\circ}\text{C} \le \text{T}_{\text{p}} \le +75 ^{\circ}\text{C}$ $-40 ^{\circ}\text{C} \le \text{T}_{\text{p}} \le +60 ^{\circ}\text{C}$	$-40 ^{\circ}\text{C} \le \text{T}_{\text{a}} \le +45 ^{\circ}\text{C}$ $-40 ^{\circ}\text{C} \le \text{T}_{\text{a}} \le +50 ^{\circ}\text{C}$	
T5	-40 °C ≤ T _p ≤ +90 °C	-40 °C ≤ T _a ≤ +50 °C	
T4T1	-40 °C ≤ T _p ≤ +120 °C	-40 °C ≤ T _a ≤ +45 °C	

with Optional specification, ID Mx = MR, MS

Temperature class	Process temperature range	Ambient temperature range	
Т6	-40 °C ≤ T _p ≤ +75 °C	-40 °C ≤ T _a ≤ +55 °C	
T5	-40 °C ≤ T _p ≤ +90 °C	-40 °C ≤ T _a ≤ +60 °C	
T4	-40 °C ≤ T _p ≤ +125 °C	-40 °C ≤ T _a ≤ +55 °C	
T3T1	-40 °C ≤ T _p ≤ +150 °C	-40 °C ≤ T _a ≤ +55 °C	

Connection data

Power supply		
$U_i \le 30 V_{DC}$		
I _i ≤ 300 mA		
$P_i \le 1 W$		
C _i ≤ 10 nF		
$L_i = 0$		



www.addresses.endress.com