

Installation Instructions

Detector unit, Servo


Proservo NMS8x



1 Intended use

- A defective unit can only be replaced with a functioning unit of the same type.
- Use only original parts from Endress+Hauser.
- In the W@M Device Viewer, check if the spare part is suitable for the existing device.

 In some devices, an overview of spare parts is provided inside the device. If the spare part set is listed in the overview, it is not necessary to check the Device Viewer.



2 Personnel authorized to carry out repairs

Technical staff must comply with the following requirements for repair, mounting, electrical installation and commissioning of the devices:

- Be trained in instrument safety.
- Be familiar with the individual operating conditions of the devices.
- In the case of Ex-certified devices, they must also be trained in explosion protection.

 Technical staff carrying out work are responsible for ensuring that the work is carried out safely and to the required quality standard. They must also guarantee the safety of the device following repair.

3 Safety instructions






- Observe the Operating Instructions for the device.
- Comply with national regulations regarding mounting, electrical installation, commissioning, maintenance and repair.
- Device is live! Risk of fatal injury from electric shock. Open the device only when the device is deenergized.
- For devices intended for use in hazardous locations, please observe the instructions in the Ex documentation (XA).
- In the case of devices in safety-related applications in accordance with IEC 61508 or IEC 61511: Commission in accordance with Operating Instructions after repair.

- Before removing the device: set the process to a safe state and purge the pipe of dangerous process substances.
- Risk of burns from hot surfaces! Before commencing work: allow the system and device to cool down to a touchable temperature.
- In the case of devices in custody transfer, the custody transfer status no longer applies once the seal has been removed.
- Risk of damaging electronic components! Ensure that the working environment is protected against electrostatic discharge.
- After removing the electronics compartment cover: risk of electric shock due to removal of contact protection! Switch the device off before removing internal covers.
- Modifications to the device are not permitted.
- Only open the housing for a short period. Avoid ingress of foreign bodies, moisture or contaminants.
- Replace defective seals only with original seals from Endress+Hauser.
- If threads are damaged or defective, the device must be repaired.
- Do not lubricate threads (e.g. of electronics compartment cover and connection compartment cover).
- If spacing is reduced or the dielectric strength of the device cannot be guaranteed during repair work: Perform a test on completion of the work (e.g. high-voltage test in accordance with the manufacturer's specifications).
- Service connector:
 - Do not connect in potentially explosive atmospheres.
 - Only connect to Endress+Hauser service devices.
- Observe the instructions for transporting and returning the device outlined in the Operating Instructions.



For information on service and spare parts, contact your Endress+Hauser sales center.

4 Tool list




5 Spare parts list

This installation instruction is valid for the following spare part sets.


Wire drum with measuring wire

Order number	Original spare part set	Usage
71273681	Detector Unit, Servo, SW 01.05 and below	NMS80/81/83
71726277	Detector Unit, Servo, SW 01.06 and above	NMS80/81/83


6 Loosen seal (for Weight + Measure approval applications only)



7 Remove the drum housing cover









8 Attach the fixing screw to the wire drum hole to secure it.





i The fixing screw (26 mm (1.02 in)) (M3) is supplied in the kit.


9 Remove the front cover



10 Remove the electronic box




11 Exchange electric assembly



- Do not pull out the electronic assembly by excessive force. The electronic includes the flat cable between platform and sensor assembly.
- After installing the assembly, reference, sensor, and drum calibrations must be required.

Assembly has to be done in reverse order.

12 Seal device (for Weight + Measure approval applications only)





71749032

www.addresses.endress.com
