

# Special Documentation **Tegwave FIH**

Download Software and Documentation





**Table of contents**

**1     Download the Teqwave Viewer  
operating tool ..... 4**

**2     Download Firmware ..... 4**

**3     Download Documentation ..... 4**

**4     Download Fluid Profile ..... 4**

## 1 Download the Teqwave Viewer operating tool

The Teqwave Viewer operating tool is available for download at [www.software-products.endress.com](http://www.software-products.endress.com). To download it, you must register on the Endress+Hauser software portal. Once you have logged in, the software is available under **Download** in the **Device Configuration Software & Device Drivers** section.

## 2 Download Firmware

The firmware must be updated using the Viewer. The firmware is available in the Download section of the Endress+Hauser website [www.endress.com](http://www.endress.com).

To search, enter the following details:

1. Search category: **Device drivers and firmware**
2. Type: **Firmware Flash File**
3. Product root: –
4. Text search: Teqwave

 The procedure for updating the firmware is described in detail in the user manual for the respective product.

## 3 Download Documentation

 For an overview of the scope of the associated Technical Documentation, refer to the following:

- *Device Viewer* ([www.endress.com/deviceviewer](http://www.endress.com/deviceviewer)): Enter the serial number from the nameplate
- *Endress+Hauser Operations App*: Enter the serial number from the nameplate or scan the matrix code/QR code on the nameplate

 This Special Documentation and other documentation are available:


In the Download Area of the Endress+Hauser website: [www.endress.com](http://www.endress.com) → Downloads

## 4 Download Fluid Profile

When ordering individual fluid profiles, they are preinstalled on the transmitter and can be used immediately.


When ordering an application range, only common fluid profiles are initially available on the transmitter. All fluid profiles available for a system can be downloaded at any time from the Netilion Library (<https://netilion.endress.com>).

To access the library, you must register at [www.endress.com](http://www.endress.com). After logging in to Netilion, you must first add a device using its serial number in the **Library** section (1. → 2. → 3.):



1 Netilion Library

After activation (4.), all fluid profiles, documents and files associated with the system can be downloaded:



A0062851

2 Netilion Library Device





71784804

[www.addresses.endress.com](http://www.addresses.endress.com)

---