



71782825

Brief Operating Instructions RLN42

NAMUR isolating amplifier, 2-channel with 24 to 230 V_{AC/DC} and NAMUR or switching contact input as well as relay output, optionally with SIL and Ex

These Brief Operating Instructions are not a substitute for the Operating Instructions. For further information on the product, see:

- www.endress.com/deviceviewer
- Smartphone/tablet: Endress+Hauser Operations app



Manufacturer: Endress+Hauser Wetzlar GmbH + Co. KG, Obere Wank 1, D-87484 Nesselwang or www.endress.com

Basic safety instructions

Requirements for the personnel

The operating personnel must fulfill the following requirements:

- ▶ They must be trained, qualified specialists
- ▶ Before starting work, they must have read and understood the information in the Operating Instructions and certificates.

Intended use

The NAMUR isolating amplifier is designed for the operation of proximity switches, floating contacts and contacts with a resistive circuit. A relay is available per channel as the signal output. The device is designed for installation on DIN rails in accordance with IEC 60715.

Product liability

The manufacturer does not accept any responsibility for damage that results from non-designated use and from failure to comply with the instructions in this manual.

Operational safety

NOTICE

Damage to the device!

- ▶ Operate the device only if it is in proper technical condition, free from errors and faults.
- ▶ The operator is responsible for interference-free operation of the device.

Product safety

This state-of-the-art device is designed and tested in accordance with good engineering practice to meet operational safety standards. It left the factory in a condition in which it is safe to operate.

It meets general safety standards and legal requirements. It also complies with the EU directives listed in the device-specific EU declaration of conformity. The manufacturer confirms this by affixing the CE mark.

Installation

Installation requirements

Dimensions

Width (B) x length (L) x height (H) (with terminals): 17.5 mm (0.69 in) x 116 mm (4.57 in) x 107.5 mm (4.23 in)

Mounting location

The device is designed for installation on 35 mm (1.38 in) DIN rails in accordance with IEC 60715 (TH35).

Installation instructions

- The device's IP20 degree of protection is intended for a clean and dry environment.
- Do not expose the device to mechanical and/or thermal stress that exceeds the specified limits.
- The device is intended for installation in a cabinet or similar housing. The device may only be operated as an installed device.
The cabinet must meet the fire protection housing requirements according to safety standard UL/IEC 61010-1 and provide adequate protection against electric shock or burns.
- To protect against mechanical or electrical damage, the device must be installed in an appropriate housing with a suitable protection rating in accordance with IEC 60529.
- The device fulfills the EMC regulations for the industrial sector (EMC Class A). It can cause electrical interference if used in residential environments.
- During installation, repair and maintenance work, the device must be disconnected from all effective power sources if the power sources are not SELV or PELV circuits.
- Only use copper cables with a permitted temperature range (60 °C / 75 °C) as the connection cable.

Functional safety

A SIL version of the device is optionally available. It can be used in safety equipment in accordance with IEC 61508 up to SIL 2 (SC 3).



Please refer to Safety Manual FY01035K for the use of the device in safety instrumented systems according to IEC 61508.



Protection against modifications:

As it is not possible to disengage the operating elements (DIP switches), a lockable control cabinet is required for use in SIL applications. The cabinet must be locked by key. A normal electrical cabinet key does not suffice for this purpose.

The device's housing provides basic insulation from neighboring devices for 300 Veff. If several devices are installed side by side, this must be taken into consideration and additional insulation must be provided if necessary. If the adjacent device also offers basic insulation, no additional insulation is required.

NOTICE

- ▶ When using in hazardous areas, the limit values of the certificates and approvals must be observed.


Important ambient conditions

Ambient temperature range	−40 to 60 °C (−40 to 140 °F)	Storage temperature	−40 to 80 °C (−40 to 176 °F)
Degree of protection	IP 20	Overvoltage category	III
Pollution degree	2	Humidity	10 to 95 % No condensation

Electrical connection

Connecting requirements

A flat-blade screwdriver is required to establish an electrical connection to screw or push-in terminals.



1 Electrical connection using screw terminals (left) and push-in terminals (right)

CAUTION

Destruction of parts of the electronics

- Switch off the power supply before installing or connecting the device.

NOTICE

Destruction or malfunction of parts of the electronics

- ESD - Electrostatic discharge. Protect the terminals from electrostatic discharge.

Special connection instructions

- Disconnecting units and auxiliary circuit protective systems with suitable AC or DC values must be provided in the building installation.
- A switch/power circuit breaker must be provided close to the device and clearly marked as a disconnecting unit for this device.
- An overcurrent protection unit ($I \leq 16$ A) must be provided in the installation.
- The voltages applied at the input are extra-low voltages (ELV). Depending on the application, the supply and switching voltage at the relay output can be a dangerous voltage (> 30 V). Safe galvanic isolation to the other connections is provided for this scenario.

Important connection data


Power supply

Supply voltage	24 to 230 V _{AC/DC} (−20% / +10%, 0/50/60 Hz)	Maximum current consumption	<80 mA; <42 mA (24 V _{DC})
Power dissipation	≤1.3 W	Power consumption	≤1 W

Input data (floating switch contacts with resistive coupling elements to connect NAMUR proximity switches (IEC/EN 60947-5-6))

Switch points	Blocking: < 1.2 mA Conducting: > 2.1 mA	Line fault detection	Open circuit: $I_{IN} < 0.05$ to 0.35 mA Short-circuit: $100 \Omega < R_{\text{sensor}} < 360 \Omega$
Short-circuit current	~ 8 mA	Open-circuit voltage	~ 8 V _{DC}
Switching hysteresis	< 0.2 mA		

Display and operating elements



Altitude	≤ 2 000 m (6 562 ft)		
----------	----------------------	--	--

Installing a DIN rail device

The device can be installed in any position (horizontal or vertical) on the DIN rail without lateral clearance from neighboring devices. No tools are required for installation. The use of end brackets (type WEW "35/1" or similar) on the DIN rail is recommended as an end support for the device.


Relay output data

Contact type	1 changeover per channel	Mechanical operating life	10 ⁷ switching cycles
Maximum switching voltage	250 V _{AC} (2 A) / 120 V _{DC} (0.2 A) / 30 V _{DC} (2 A)	Recommended minimum load	5 V / 10 mA
Maximum switching capacity	500 VA	Switching frequency (no load)	≤ 20 Hz



For detailed technical data, see the Operating Instructions

Quick wiring guide



2 Terminal assignment RLN42

Supply voltage

The modules are supplied with 24 to 230 V_{AC/DC} via terminals 1.1 and 1.2.

Local operation

Hardware settings / configuration



Any device settings using the DIP switch must be made when the device is de-energized.



For details refer to the Operating Instructions

Direction of action

At the device, the direction of action (operating or closed circuit current behavior) can be selected and line fault detection can be enabled or disabled via DIP switches.

DIP switch 1 = channel 1; DIP switch 3 = channel 2

All DIP switches are set to the "I" position when the device is delivered from the factory:

- I = normal phase (operating current behavior)
- II = inverse phase (closed circuit current behavior)

Maintenance

Maintenance work

The device does not require specific maintenance work.

Cleaning of surfaces not in contact with the medium

- Recommendation: Use a lint-free cloth that is either dry or slightly dampened using water.

Line fault detection

DIP switch 2 = channel 1; DIP switch 4 = channel 2

I = line fault detection switched off - **not permitted for safety-oriented applications!**

II = line fault detection switched on

If a line fault occurs, the relay is de-energized and the red LED "LF" flashes (NE 44).

NOTICE

Error detection malfunctions

- ▶ For switch contacts with an open circuit, line fault detection (LF) must be disabled or the corresponding resistance circuit (1 kΩ/10 kΩ) must be provided directly at the contact. (See the "Quick wiring guide" and "Accessories" sections of the Operating Instructions)

- Do not use any sharp objects or aggressive cleaning agents that corrode the surfaces (e.g. displays, housing) and seals.
- Do not use high-pressure steam.
- Observe the degree of protection of the device.



The cleaning agent used must be compatible with the materials of the device configuration. Do not use cleaning agents with concentrated mineral acids, bases or organic solvents.
