# Safety Instructions **Deltabar M PMD55**

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

Ga/Gb Ex ia IIC T6...T4 1Ex ia IIC T6...T4 Gb



Document: XA01398P-C

Safety instructions for electrical apparatus for explosion-hazardous areas  $\rightarrow \square 3$ 



Deltabar M PMD55 XA01398P-C

# Deltabar M PMD55

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

# Table of contents

Associated documentation	4
Supplementary documentation	4
Manufacturer's certificates	4
Manufacturer address	4
Extended order code	4
Safety instructions: General	5
Safety instructions: Special conditions	5
Safety instructions: Installation	6
Safety instructions: Zone 0	6
Temperature tables	6
Connection data	7

XA01398P-C Deltabar M PMD55

#### Associated documentation

This document is an integral part of the following Operating Instructions:

**HART** 

BA00382P/00 PROFIBUS PA BA00383P/00

FOUNDATION Fieldbus

BA00384P/00

# **Supplementary** documentation

Explosion-protection brochure: CP00021Z/11

The Explosion-protection brochure is available:

- In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Media Type: Documentation -> Documentation Type: Brochures and catalogs -> Text Search: CP00021Z
- On the CD for devices with CD-based documentation

#### Manufacturer's certificates

## Certificate of Conformity TP TC 012/2011

Inspection authority:

LLC NANIO CCVE (ООО «НАНИО ЦСВЭ»)

Certificate number:

EA9C RU C-DE.AA87.B.00320/20

Affixing the certificate number certifies conformity with the following standards (depending on the device version):

- GOST 31610.0-2014 (IEC 60079-0:2011)
- GOST 31610.11-2014 (IEC 60079-11:2011)
- FOCT 31610.26-2012 / IEC 60079-26:2006

#### Manufacturer address

Endress+Hauser SE+Co. KG

Hauptstraße 1

79689 Maulburg, Germany

Address of the manufacturing plant: See nameplate.

# Extended order code

The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.

#### Structure of the extended order code

PMD55	_	******	+	A*B*C*D*E*F*G*
(Device type)		(Basic specifications)		(Optional specifications)

\* = Placeholder

At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.

# Basic specifications

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Deltabar M PMD55 XA01398P-C

## Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

#### Extended order code: Deltabar M

Device type

PMD55

Basic specifications

Position 1, 2 (Approval)		
Selected optio	n	Description
PMD55	GA	EAC Ga/Gb Ex ia IIC T6T4 EAC 1Ex ia IIC T6T4 Gb

Position 3 (Output)		
Selected option		Description
PMD55	2	4-20 mA HART
	3	PROFIBUS PA
	4	FOUNDATION Fieldbus

# Optional specifications

No options specific to hazardous locations are available.

#### Safety instructions: General


- Comply with the installation and safety instructions in the Operating Instructions.
- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
  - Be suitably qualified for their role and the tasks they perform
  - Be trained in explosion protection
  - Be familiar with national regulations
- Install the device according to the manufacturer's instructions and national regulations.
- Only use the device in media to which the wetted materials have sufficient durability.
- Avoid electrostatic charging:
  - Of plastic surfaces (e.g. housing, sensor element, special varnishing, attached additional plates, ..)
  - Of isolated capacities (e.g. isolated metallic plates)

## Safety instructions: Special conditions

- In the case of process connections made of polymeric material or with polymeric coatings, avoid electrostatic charging of the plastic surfaces.
- For light metal flanges or flange faces (e.g. titanium, zirconium), avoid sparks caused by impact and friction.
- $\blacksquare$  In the event of additional or alternative special varnishing on the housing or other metal parts:
  - Observe the danger of electrostatic charging and discharge.
  - Do not rub surfaces with a dry cloth.

XA01398P-C Deltabar M PMD55

# Safety instructions: Installation



A0028184

- A Zone 1, Electronic
- B Ga/Gb: Zone 0, Process; Gb: Zone 1, Process
- 1 Certified associated apparatus
- 2 PMD55

#### Intrinsic safety

- When the device is connected to an intrinsically safe circuit Ex ib, the type of protection changes to Ex ib. Do not operate intrinsically safe circuits Ex ib in Zone 0.
- When the device is connected to an intrinsically safe circuit Ex ic, the type of protection changes to Ex ic. Do not operate intrinsically safe circuits Ex ic in Zone 0 or Zone 1.
- $\bullet$  The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 500  $V_{\rm rms}.$

#### Service connection

Basic specification, Position 3 (Output) = 2

- For service operations: connect the Commubox FXA195 (from Endress+Hauser) to the display socket.
- Observe the safety instructions of the Commubox.

## Safety instructions: Zone 0

- In the event of potentially explosive vapor/air mixtures, only operate the device under atmospheric conditions.
  - Temperature: -20 to +60 °C
  - Pressure: 80 to 110 kPa (0.8 to 1.1 bar)
  - Air with normal oxygen content, usually 21 % (V/V)
- If no potentially explosive mixtures are present, or if additional protective measures have been taken, the device may also be operated under non-atmospheric conditions in accordance with the manufacturer's specifications.
- Associated devices with galvanic isolation between the intrinsically safe and non-intrinsically safe circuits are preferred.

# Temperature tables

Type of protection	Temperature class	Process temperature T <sub>p</sub> (process)	Ambient temperature T <sub>a</sub> (ambient): housing
Ga/Gb Ex ia IIC T6T4 1Ex ia IIC T6T4 Gb	Т6	≤ 80 °C	$-40 ^{\circ}\text{C} \le T_a \le +40 ^{\circ}\text{C}$
	T4	≤ 120 °C	$-40 ^{\circ}\text{C} \le \text{T}_{\text{a}} \le +70 ^{\circ}\text{C}$

- i
- The process temperatures refer to the temperature at the separation membrane.
- Do not exceed the max. ambient temperature at the housing.

Deltabar M PMD55 XA01398P-C

# Connection data

*Basic specification, Position 3 (Output) = 2* 

Power supply	
$\begin{aligned} &U_i \leq 30 \ V_{DC} \\ &I_i \leq 300 \ mA \\ &P_i \leq 1 \ W \\ &C_i \leq 10 \ nF \end{aligned}$	
$C_i \le 10 \text{ nF}$ $C_i = 0$	

Basic specification, Position 3 (Output) = 3, 4

Power supply	
FISCO	Entity
$\begin{split} &U_i \leq 17.5 \ V_{DC} \\ &I_i \leq 500 \ mA \\ &P_i \leq 5.5 \ W \\ &C_i \leq 5 \ nF \\ &L_i \leq 10 \ \mu H \end{split}$	$\begin{split} &U_i \leq 24 \ V_{DC} \\ &I_i \leq 250 \ mA \\ &P_i \leq 1.2 \ W \\ &C_i \leq 5 \ nF \\ &L_i \leq 10 \ \mu H \end{split}$



www.addresses.endress.com