Safety Instructions Deltapilot M FMB50, FMB51, FMB52, FMB53

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

2Ex ic IIC T6...T4 Gc



Document: XA01951P-A Safety instructions for electrical apparatus for explosion-hazardous areas $\rightarrow \cong$ 3



Deltapilot M FMB50, FMB51, FMB52, FMB53

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

Table of contents

Associated documentation	4
Supplementary documentation	4
Manufacturer's certificates	4
Manufacturer address	4
Extended order code	4
Safety instructions: General	5
Safety instructions: Special conditions	6
Safety instructions: Installation	6
Temperature tables	6
Connection data	7

Associated documentation	This document is an integral part of the following Operating Instructions:			
	HART BA00382P/00			
	PROFIBUS PA			
	BA00383P/00			
	FOUNDATION Fieldbus BA00384P/00			
Supplementary	Explosion-protection brochure: CP00021Z/11			
documentation	 The Explosion-protection brochure is available: In the download area of the Endress+Hauser website: www.endress.com -> Downloads -> Media Type: Documentation -> Documentation Type: Brochures and catalogs -> Text Search: CP00021Z On the CD for devices with CD-based documentation 			
Manufacturer's certificates	Certificate of Conformity TP TC 012/2011			
	Inspection authority: LLC NANIO CCVE (ООО «НАНИО ЦСВЭ»)			
	Certificate number: EAƏC RU C-DE.AA87.B.00321/20			
	Affixing the certificate number certifies conformity with the following standards (depending on the device version):			
	 GOST 31610.0-2014 (IEC 60079-0:2011) GOST 31610.11-2014 (IEC 60079-11:2011) 			
Manufacturer address	Endress+Hauser SE+Co. KG Hauptstraße 1 79689 Maulburg, Germany			
	Address of the manufacturing plant: See nameplate.			
Extended order code	The extended order code is indicated on the nameplate, which is affixed to the device in such a way that it is clearly visible. Additional information about the nameplate is provided in the associated Operating Instructions.			
	Structure of the extended order code			
	FMB5x – ******** + A*B*C*D*E*F*G*			
	(Device type) (Basic specifications) (Optional specifications)			
	* = Placeholder At this position, an option (number or letter) selected from the specification is displayed instead of the placeholders.			
	Basic specifications			

The features that are absolutely essential for the device (mandatory features) are specified in the basic specifications. The number of positions depends on the number of features available. The selected option of a feature can consist of several positions.

Optional specifications

The optional specifications describe additional features for the device (optional features). The number of positions depends on the number of features available. The features have a 2-digit structure to aid identification (e.g. JA). The first digit (ID) stands for the feature group and consists of a number or a letter (e.g. J = Test, Certificate). The second digit constitutes the value that stands for the feature within the group (e.g. A = 3.1 material (wetted parts), inspection certificate).

More detailed information about the device is provided in the following tables. These tables describe the individual positions and IDs in the extended order code which are relevant to hazardous locations.

Extended order code: Deltapilot M

The following specifications reproduce an extract from the product structure and are used to assign:

- This documentation to the device (using the extended order code on the nameplate).
- The device options cited in the document.

Device type

FMB50, FMB51, FMB52, FMB53

Basic specifications

Position 1,	2 (Approval)		
Selected option		Description	
FMB5x	GG	EAC 2Ex ic IIC T6T4 Gc	

Position 3 (Output)		
Selected option Description		Description
FMB5x	2	4-20 mA HART
	3	PROFIBUS PA
	4	FOUNDATION Fieldbus

Optional specifications


No options specific to hazardous locations are available.


Safety instructions: General • Comply with the installation and safety instructions in the Operating Instructions.

- Staff must meet the following conditions for mounting, electrical installation, commissioning and maintenance of the device:
 - Be suitably qualified for their role and the tasks they perform
 - Be trained in explosion protection
 - Be familiar with national regulations
 - Install the device according to the manufacturer's instructions and national regulations.
 - Only use the device in media to which the wetted materials have sufficient durability.
 - Avoid electrostatic charging:
 - Of plastic surfaces (e.g. housing, sensor element, special varnishing, attached additional plates, ..)
 - Of isolated capacities (e.g. isolated metallic plates)

Safety instructions: Special conditions

- In the case of process connections made of polymeric material or with polymeric coatings, avoid electrostatic charging of the plastic surfaces.
- For light metal flanges or flange faces (e.g. titanium, zirconium), avoid sparks caused by impact and friction.
- In the event of additional or alternative special varnishing on the housing or other metal parts:
 Observe the danger of electrostatic charging and discharge.
 - Do not rub surfaces with a dry cloth.





- A Zone 2, Electronic
- B Zone 2, Process
- 1 Certified associated apparatus
- 2 FMB50, FMB51, FMB52, FMB53
- 3 Option: Separate housing

Device type FMB51

Mechanically fix probes which are more than 3 m (e.g. using guy ropes).

Device type FMB52, FMB53

- Avoid electrostatic charging of the cable.
- Secure probes against swinging.

Intrinsic safety

The intrinsically safe input power circuit of the device is isolated from ground. The dielectric strength is at least 500 $V_{\rm rms}$.

Service connection

Basic specification, Position 3 (Output) = 2

- For service operations: connect the Commubox FXA195 (from Endress+Hauser) to the display socket.
- Observe the safety instructions of the Commubox.

Temperature tables

Device type FMB50

Type of protection	Temperature class	Process temperature T _p (process)	Ambient temperature T _a (ambient): housing
2Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	$-40 \degree C \le T_a \le +40 \degree C$
	T4	≤ 100 °C	$-40 ^{\circ}\text{C} \le \text{T}_{a} \le +70 ^{\circ}\text{C}$

Device type FMB51

Type of protection	Temperature class	Process temperature T _p (process)	Ambient temperature T _a (ambient): housing
2Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	$-40 \degree C \le T_a \le +40 \degree C$
	T4	≤ 85 °C	$-40 \text{ °C} \le T_a \le +70 \text{ °C}$

Device type FMB52, FMB53

Type of protection	Temperature class	Process temperature T _p (process)	Ambient temperature T _a (ambient): housing
2Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	$-40 \text{ °C} \le T_a \le +40 \text{ °C}$
	T4	≤ 80 °C	$-40 \degree C \le T_a \le +70 \degree C$



P Do not exceed the max. ambient temperature at the housing.

Device type FMB50

The process temperatures refer to the temperature at the separation membrane.

Device type FMB51

The process temperatures refer to the temperature at the rod.

Device type FMB52, FMB53

The process temperatures refer to the temperature at the cable.

Connection data

Basic specification, Position 3 (Output) = 2

Power supply	
$U_i \le 45 V_{DC}$	
$I_i \le 300 \text{ mÅ}$ $P_i \le 1 \text{ W}$	
$C_i \le 10 \text{ nF}$	
$L_i = 0$	

Basic specification, Position 3 (Output) = 3, 4

Power supply	
FISCO	Entity
$\begin{array}{l} U_i \leq 17.5 \; V_{DC} \\ I_i \leq 500 \; mA \\ P_i \leq 5.5 \; W \\ C_i \leq 5 \; nF \\ L_i \leq 10 \; \mu H \end{array}$	$\begin{array}{l} U_i \leq 32 \; V_{DC} \\ I_i \leq 250 \; mA \\ P_i \leq 1.2 \; W \\ C_i \leq 5 \; nF \\ L_i \leq 10 \; \mu H \end{array}$



www.addresses.endress.com

