Safety Instructions **Deltapilot M FMB50, FMB51, FMB52, FMB53**4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

Ex ic IIC T6...T4 Gc IECEx KEM 09.0016

Document: XA00493P-B

Safety instructions for electrical apparatus for explosion-hazardous areas according to IEC standards



XA00493P-B Deltapilot M

Deltapilot M XA00493P-B

Deltapilot M FMB50, FMB51, FMB52, FMB53

4-20 mA HART, PROFIBUS PA, FOUNDATION Fieldbus

english

Associated This document is an integral part of the following Operating Instructions:

Documentation BA00382P/00

The Operating Instructions which are supplied and correspond to the device type apply.

Supplementary Explosion-protection brochure:

Documentation CP00021Z/11

Designation Explanation of the labelling and type of protection can be found in the explosion protection brochure.

Designation according to IECEx
Equipment protection level (EPL) Gc

Designation of type of protection/


level of protection Ex ic IIC T6...T4 Gc

Applied standards IEC 60079-0 :2011

IEC 60079-11:2011

XA00493P-B Deltapilot M

Safety instructions: Installation



1

- A Power supply
- B Zone 2, Electronic
- C Zone 2, Process
- 1 Certified associated apparatus
- 2 FMB50, FMB51, FMB52, FMB53
- 3 Option FMB50, FMB51, FMB52: Separate housing
- Comply with the installation and safety instructions in the Operating Instructions.
- Install the device according to the manufacturer's instructions and any other valid standards and regulations.
- Only install the devices in media for which the wetted materials have sufficient durability.
- Avoid electrostatic charging of the plastic surfaces, for plastic process connections or plastic coatings.
- ullet The intrinsically safe input power circuit of the device is isolated from ground potential and has a dielectric strength of at least 500 V_{rms} with respect to it.
- Avoid impact or friction sparks for light metal flanges or flange faces (e.g. titanium, zirconium).
- In case of additional or alternative special varnishing of the enclosure or other metallic parts the danger of an electrostatic charging must be observed. Do not rub surfaces with dry cloth.

FMB51

• Mechanically fix rod probes which are more than 3 m (e.g. using guy ropes).

FMB52, FMB53

- Avoid electrostatic charging of the cable.
- Secure probes against swinging.

Service connection

- For service operations the Commubox FXA191 or FXA195 (from Endress+Hauser) can be connected to the display socket.
- Comply with the safety instructions of the Commubox.

Deltapilot M XA00493P-B

Temperature tables

Туре	Type of protection/ level of protection	Temperature class	Process temperature	Ambient temperature (Housing)
FMB50	Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	-40 °C ≤ Ta ≤ +40 °C
		T4	≤ 100 °C	-40 °C ≤ Ta ≤ +70 °C

The process temperatures refer to the temperature at the separation membrane (do not exceed the max. ambient temperature at the housing).

Туре	Type of protection/ level of protection	Temperature class	Process temperature	Ambient temperature (Housing)
FMB51	Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	-40 °C ≤ Ta ≤ +40 °C
		T4	≤85 °C	-40 °C ≤ Ta ≤ +70 °C

The process temperatures refer to the temperature at the rod (do not exceed the max. ambient temperature at the housing).

Туре	Type of protection/ level of protection	Temperature class	Process temperature	Ambient temperature (Housing)
FMB52	Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	-40 °C ≤ Ta ≤ +40 °C
		T4	≤ 80 °C	-40 °C ≤ Ta ≤ +70 °C

The process temperatures refer to the temperature at the cable (do not exceed the max. ambient temperature at the housing).

Туре	Type of protection/ level of protection	Temperature class	Process temperature	Ambient temperature (Housing)
FMB53	Ex ic IIC T6T4 Gc	Т6	≤ 80 °C	-40 °C ≤ Ta ≤ +40 °C
		T4	≤ 80 °C	-40 °C ≤ Ta ≤ +70 °C

The process temperatures refer to the temperature at the cable (do not exceed the max. ambient temperature at the housing).

Connection data

Electronic insert	Electrical data
4-20 mA HART	$ \begin{array}{l} Ui \leq 45 \ V \ DC \\ li & \leq 300 \ mA \\ Pi & \leq 1 \ W \\ Ci \leq 10 \ nF \\ Li & = 0 \end{array} $
PROFIBUS PA, FOUNDATION Fieldbus	$\begin{array}{ll} \text{Ui} \leq 17.5 \text{ V DC} \\ \text{li} & \leq 500 \text{ mA} \\ \text{Pi} \leq 5.5 \text{ W} \\ \text{Ci} \leq 5 \text{ nF} \\ \text{Li} \leq 10 \mu\text{H} \\ \text{(FISCO field device)} \\ \text{or} \\ \text{Ui} \leq 32 \text{ V DC} \\ \text{li} & \leq 250 \text{ mA} \\ \text{Pi} \leq 1.2 \text{ W} \\ \text{Ci} \leq 5 \text{ nF} \\ \text{Li} \leq 10 \mu\text{H} \end{array}$

XA00493P-B Deltapilot M

Deltapilot M XA00493P-B



www.addresses.endress.com

