



Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

1 Type of device

- Field device / signal processing device
- Monitoring- / operation system / hand held terminal etc.
- Modem / interface

Manufacturer : Endress+Hauser
 Device : Liquistation
 Type : CSF48, CSF34
 Previous software version : 1.04.01

How can the previous software version number be identified:

- (a) With standard Fieldbus communication
- (b) with FieldCare/DTM
- (c) Display

2 Software

New software version : 1.05.00

Description of the modification in comparison with the predecessor version:

Samper - New Features, Enhancements & Improvements:

- Autocontinue after power fail
- Reference turn and manuel sampling via fieldbus impelemented

Enhancements & Improvements:

- Support of the optical sensors for fresh water turbidity CUS51D
- Implementation of ChemoClean Plus for freely programmable state machine up to 4 relays
- Cleaning scheduler enhanced with calender function
- Measurement range switch enhanced to more measurement parameter
- HOLD function enhanced to 8 individual channels
- New supported fieldbus protocol EtherNet/IP
- Integrated webserver enhanced with login
- External pressure sensor usable for dissolved oxygen measurement
- External temperature sensor usable for conductivity measurement
- Print of configuration optimized
- Feed forward control of PID parameter via fieldbus
- Calibration data sets for SAC, nitrate and turbidity selectable via fieldbus
- Oxygen measurement: salinity calculation via external conductivity sensor possible
- Conductivity measurement: output value according display value



Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

3 Compatibility

Is the operating tool compatible with the installed device software?

- Yes
 No, description:

Is a software update generally recommended?

- Yes, reason:

The software update can be performed by means of ...

- SD card

- No, reason:

Update only necessary if functional enhancements are desired

4 Instruction manual

Is a new instruction manual necessary due to the modification of the software?

- Yes
 No

Which manual corresponds to the new software:

Device	Communication options	Manual Marking	
CSF48, CSF34	All		
		BA00443CDE.pdf	Liquistation Commissioning
		BA00463CDE.pdf	Liquistation Maintenance & Diagnostics
		BA00464CDE.pdf	Liquistation Operation & Setting
		BA00467CDE.pdf	Liquistation Calibration

The new instruction manuals can be referred in Internet:

<http://www.endress.com> - area „DOWNLOAD“
 - declaration of the device and kind of manual

5 Price



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions

Manufacturer Information

for users regarding software updates
(following the NAMUR recommendation 53)

Change in price of device in comparison with the predecessor version?

- Yes, new list price and update costs (without installation) are enclosed
- No